

CONTENTS

CR

	CR	
PRECAUTIONS	5	INTAKE MANIFOLD 20
Precautions for Draining Coolant	5	Removal and Installation 20
Precautions for Disconnecting Fuel Piping	5	REMOVAL 20
Precautions for Removal and Disassembly	5	INSTALLATION 21
Precautions for Inspections, Repairs, and Replacement	5	EXHAUST MANIFOLD AND THREE WAY CATALYST 22
Precautions for Assembling and Installing	5	Removal and Installation 22
Parts Requiring Angle Tightening	5	REMOVAL 22
Precautions for Liquid Gasket	6	INSPECTION AFTER REMOVAL 23
REMOVAL OF LIQUID GASKET SEALING 6		INSTALLATION 23
LIQUID GASKET APPLICATION PROCEDURE 6		OIL PAN AND OIL STRAINER 24
PREPARATION	7	Removal and Installation 24
Special Service Tools 7		REMOVAL 24
Commercial Service Tools 9		INSTALLATION 25
NOISE, VIBRATION AND HARSHNESS (NVH)		INSPECTION AFTER INSTALLATION 26
TROUBLESHOOTING	10	IGNITION COIL 27
NVH Troubleshooting — Engine Noise 10		Removal and Installation 27
Use the Chart Below to Help You Find the Cause of the Symptom. 11		REMOVAL 27
DRIVE BELTS	12	INSTALLATION 27
Checking drive Belts 12		SPARK PLUG (PLATINUM-TIPPED TYPE) 28
Tension Adjustment 12		Removal and Installation 28
ALTERNATOR AND A/C COMPRESSOR BELT (WITH A/C MODELS) 13		REMOVAL 28
ALTERNATOR BELT (WITHOUT A/C MODELS) 13		INSPECTION AFTER REMOVAL 28
WATER PUMP BELT 14		INSTALLATION 29
Removal and Installation 14		FUEL INJECTOR AND FUEL TUBE 30
REMOVAL 14		Removal and Installation 30
INSTALLATION 14		REMOVAL 30
Removal and Installation of Drive Belt Idler Pulley. 14		INSTALLATION 31
REMOVAL 15		INSPECTION AFTER INSTALLATION 32
INSTALLATION 15		ROCKER COVER 33
AIR CLEANER AND AIR DUCT	16	Removal and Installation 33
Removal and Installation 16		REMOVAL 33
REMOVAL 16		INSTALLATION 34
INSTALLATION 17		CAMSHAFT 36
Changing Air Cleaner Filter 19		Removal and Installation 36
REMOVAL 19		REMOVAL 36
INSTALLATION 19		INSTALLATION 39

INSPECTION AFTER REMOVAL	43	ING	88
Valve Clearance	45	PISTON TO CYLINDER BORE CLEARANCE	88
INSPECTION	45	OUTER DIAMETER OF CRANKSHAFT JOUR-	
ADJUSTMENT	46	NAL	90
TIMING CHAIN	48	OUTER DIAMETER OF CRANKSHAFT PIN	90
Removal and Installation	48	OUT-OF-ROUND AND TEPER OF CRANK-	
REMOVAL	49	SHAFT	90
INSPECTION AFTER REMOVAL	52	CRANKSHAFT RUNOUT	90
INSTALLATION	52	OIL CLEARANCE OF CONNECTING ROD	
INSPECTION AFTER INSTALLATION	55	BEARING	91
OIL SEAL	56	OIL CLEARANCE OF MAIN BEARING	91
Removal and Installation of Valve Oil Seal	56	CRUSH HEIGHT OF MAIN BEARING OR CON-	
REMOVAL	56	NECTING ROD BEARING	92
INSTALLATION	56	FLYWHEEL RUNOUT	92
Removal and Installation of Front Oil Seal	56	SERVICE DATA AND SPECIFICATIONS (SDS)	93
REMOVAL	56	Standard and Limit	93
INSTALLATION	57	GENERAL SPECIFICATIONS	93
Removal and Installation of Rear Oil Seal	57	INTAKE MANIFOLD AND EXHAUST MANI-	
REMOVAL	57	FOLD	93
INSTALLATION	57	DRIVE BELTS	94
CYLINDER HEAD	59	SPARK PLUG	94
On Vehicle Inspection	59	CYLINDER HEAD	94
COMPRESSION PRESSURE INSPECTION	59	VALVE	95
Removal and Installation	60	CAMSHAFT AND CAMSHAFT BEARING	98
REMOVAL	60	CYLINDER BLOCK	98
INSPECTION AFTER REMOVAL	61	PISTON, PISTON RING AND PISTON PIN	100
INSTALLATION	61	CONNECTING ROD	100
Disassembly and Assembly	62	CRANKSHAFT	101
DISASSEMBLY	63	MAIN BEARING	101
ASSEMBLY	63	CONNECTING ROD BEARING	102
INSPECTION AFTER DISASSEMBLY	64	MISCELLANEOUS COMPONENTS	102
ENGINE ASSEMBLY	69	Tightening Torque	103
Removal and Installation	69		
REMOVAL	70		
INSTALLATION	72		
INSPECTION AFTER INSTALLATION	72		
CYLINDER BLOCK	73		
Disassembly and Assembly	73	K9K	
DISASSEMBLY	74		
ASSEMBLY	76		
How to Select Piston and Bearing	82	PRECAUTIONS	105
DESCRIPTION	82	Precautions for Drain Coolant	105
HOW TO SELECT PISTON	82	Precautions for Disconnecting Fuel Piping	105
HOW TO SELECT MAIN BEARING	83	Precautions for Removal and Disassembly	105
Inspection After Disassembly	84	Precautions for Inspection, Repair and Replace-	
CRANKSHAFT SIDE CLEARANCE	84	ment	105
CONNECTING ROD SIDE CLEARANCE	85	Precautions for Assembly and Installation	105
PISTON AND PISTON PIN CLEARANCE	85	Parts Requiring Angular Tightening	105
PISTON RING SIDE CLEARANCE	85	Precautions For Liquid Gasket	106
PISTON RING END GAP	86	REMOVAL OF LIQUID GASKET	106
CONNECTING ROD BEND AND TORSION	86	LIQUID GASKET APPLICATION PROCEDURE	106
CONNECTING ROD BEARING HOUSING		Cleanliness Instructions Which Must Be Followed	
DIAMETER (BIG END)	87	When Working On The High Pressure Direct Injec-	
CONNECTING ROD BUSHING OIL CLEAR-		tion System	106
ANCE DIAMETER (SMALL END)	87	RISKS RELATING TO CONTAMINATION	106
CYLINDER BLOCK DISTORTION	88	The Sources Of Contamination	107
INNER DIAMETER OF MAIN BEARING HOUS-		Precautions To Be Followed Before Any Work Is	
		Carried Out On The Injection System	107
		Cleaning Precautions To Be Followed Before Car-	
		rying Out Any Work On The Fuel System	107
		Precautions To Be Followed During The Operation	
		Instructions For Fitting The Plugs	109

PREPARATION	111	GLOW PLUG	136
Special Service Tools	111	Removal and Installation	136
Commercial Service Tools	114	REMOVAL	136
IDENTIFICATION INFORMATION	116	INSTALLATION	136
Engine Identification	116	VACUUM PUMP	137
NOISE, VIBRATION AND HARSHNESS (NVH)		Removal and Installation	137
TROUBLESHOOTING	117	REMOVAL	137
NVH Troubleshooting —Engine Noise	117	INSTALLATION	137
Use the Chart Below to Help You Find the Cause		ROCKER COVER	138
of the Symptom.	118	Removal and Installation	138
ENGINE ROOM COVER	119	REMOVAL	138
Removal and Installation	119	INSTALLATION	139
REMOVAL	120	TIMING BELT	140
INSTALLATION	120	Removal and Installation	140
DRIVE BELTS	121	REMOVAL	140
Checking Drive Belts	121	INSTALLATION	143
Tension Adjustment	121	CYLINDER HEAD	144
MODELS WITH A/C COMPRESSOR	121	Removal and Installation	144
MODELS WITHOUT A/C COMPRESSOR	121	REMOVAL	144
Removal and Installation	121	INSTALLATION	145
REMOVAL	121	Disassembly and Assembly	145
INSTALLATION	122	DISASSEMBLY	145
AIR CLEANER AND AIR DUCT	123	INSPECTION AFTER DISASSEMBLY	145
Removal and Installation	123	ASSEMBLY	146
REMOVAL	123	ENGINE ASSEMBLY	147
INSTALLATION	123	Removal and Installation	147
Changing Air Cleaner Filter	124	REMOVAL	147
REMOVAL	124	INSTALLATION	149
INSTALLATION	124	INSPECTION AFTER INSTALLATION	149
CHARGE AIR COOLER	125	OVERHAUL	151
Removal and Installation	125	Tightening Torques	151
REMOVAL	125	UPPER ENGINE	151
INSPECTION AFTER REMOVAL	126	BOTTOM ENGINE	151
INSTALLATION	126	Standard Replacement	152
EGR UNIT	127	PREPARING USED ENGINE	152
Removal and Installation	127	Disassembly	153
REMOVAL	127	REMOVING THE UPPER ENGINE	153
INSTALLATION	128	POSITIONING THE BELT AT THE TIMING	
EXHAUST MANIFOLD, TURBOCHARGER, CATA-		POINT	154
LYST	129	DISASSEMBLY OF THE CYLINDER HEAD	158
Removal and Installation	129	Cleaning	160
REMOVAL	129	Inspection	160
INSTALLATION	130	GASKET FACE	160
INSPECTION AFTER INSTALLATION	130	CAMSHAFT END PLAY	161
Disassembly and Assembly	131	Valve Clearance	161
DISASSEMBLY	131	CHECKING AND ADJUSTING THE VALVE	
INSPECTION AFTER DISASSEMBLY	131	CLEARANCE	161
ASSEMBLY	132	Assembly	162
OIL PAN	133	ASSEMBLY OF THE CYLINDER HEAD	162
Removal and Installation	133	Disassembly of The Bottom Engine	167
REMOVAL	133	REMOVAL	167
INSPECTION AFTER REMOVAL	135	Assembly	170
INSTALLATION	135	INSTALLATION OF OIL JETS	170
INSPECTION AFTER INSTALLATION	135	METHOD FOR INSTALLING THE OIL COOLER	

A

EM

C

D

E

F

G

H

I

J

K

L

M

AND OIL FILTER	172	VALVE SPRING	194
Removing The Piston Pins	172	PISTON	194
CONNECTING ROD BEARING	172	INSPECTION OF VALVE CLEARANCE	194
ON THE CONNECTING ROD BODY	173	CAMSHAFT	195
ON THE CONNECTING ROD CAP	174	Piston	196
INSTALLATION OF MAIN BEARING	175	PISTON MARKING	196
ON THE CYLINDER BLOCK	176	TABLE OF PISTON PIN HEIGHT	196
ON THE BEARING CAPS	176	MEASURING THE PISTON DIAMETER	196
INSTALLATION OF NO. 1 BEARING	177	PISTON RING	197
CONNECTING RODS / PISTON ASSEMBLY ..	177	PISTON RING END GAP	197
DIRECTION FOR INSTALLATION THE SNAP		Connecting Rod	197
RINGS ON THE PISTON	178	DIRECTION OF INSTALLATION OF THE CON-	
INSTALLATION OF THE SNAP RINGS	178	NECTING ROD IN RELATION TO THE PISTON	198
CHECKING PISTON PROTRUSION	178	DIRECTION FOR INSTALLATION THE SNAP	
INSTALLATION OF REAR OIL SEAL RETAINER		RINGS ON THE PISTON	198
AND OIL PUMP	179	Crankshaft	198
INSTALLATION OF THE CRANKSHAFT SEAL		WORKING OUT THE CLASS OF MAIN BEAR-	
GASKETS	181	ING (ORIGINAL FITMENT)	199
INSTALLATION OF THE CYLINDER HEAD ..	184	Cylinder Block	199
TIMING ADJUSTMENT	186	TABLE OF CYLINDER BLOCK MAIN BEARING	
BASIC INSPECTION	191	HOUSING INNER DIAMETERS	199
Cylinder Head	191	MATCHING THE MAIN BEARING	200
CYLINDER HEAD TIGHTENING PROCEDURE	191	Main Bearing and Cap	200
THICKNESS OF THE CYLINDER HEAD GAS-		MAIN BEARING	200
KET	191	CONNECTING ROD BEARING	201
INSPECTION OF THE PISTON PROTRUSION	191	Preparing the engine to be on the stand	201
VALVE	192	Parts To Be Replaced After Removal	202
VALVE SEAT	192	Installation of Thread Inserts	203
VALVE GUIDE	192		

PRECAUTIONS

PFP:00001

Precautions for Draining Coolant

- Drain coolant only after the engine has cooled down.

EBS000EB

Precautions for Disconnecting Fuel Piping

EM

- Before starting work, make sure no fire or spark producing items are in the work area.
- Release fuel pressure before disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

C

Precautions for Removal and Disassembly

EBS000ED

- Use correct special service tool in the specified position. Always pay attention to safety.
- Be careful not to damage surface accuracy of mating or sliding surfaces.
- To prevent foreign material from entering the engine, close openings with appropriate tape as necessary.
- Arrange disassembled parts in their normal positions in order to simplify locating the cause of damage or excessive wear and to insure correct reassembly.
- The removal order of nuts and bolts should in principle move diagonally from the outside. Locations for which order is stipulated should follow that order.

D

Precautions for Inspections, Repairs, and Replacement

EBS000EE

- Thoroughly inspect each part following inspection procedure, then correct or replace as necessary. Inspect new parts in the same way, and replace if necessary.

E

Precautions for Assembling and Installing

EBS000EF

- Always use a torque wrench when tightening nuts and bolts.
- Unless otherwise specified, tighten nuts and bolts from inside to outside in crisscross pattern. Tighten them gradually and evenly in two to three steps.
- Always replace gasket, packing, oil seals, and O-rings with new ones.
- Thoroughly wash, clean, and blow dry each part. Be sure that engine oil and coolant passages are free of clogs.
- Remove any dirt and lint on sliding and mating surfaces. Before assembly, apply ample amount of engine oil to sliding surfaces.
- If coolant was drained, bleed air from the system.
- Follow the procedure below to make sure there are no fuel leaks.
 - Turn the ignition switch to ON (do not start engine), and with fuel pressure applied in the fuel line, check to make sure there are no fuel leaks from the connection.
 - Start the engine, and at increased speed, check again to see if there are any fuel leaks from the connection.
- After assembly, start engine and increase the engine speed, then check coolant, fuel, oil, grease, and exhaust gas for leakage.

H

Parts Requiring Angle Tightening

EBS000EG

- Use an angle wrench when attaching the following parts.
 - Cylinder head bolt
 - Main bearing cap bolt
 - Connecting rod cap nut
- The specified torque written for these parts is not the final tightening value, but is the torque used for tightening before angle tightening.
- When tightening, make sure there is no debris on the threads or mating surfaces, and lubricate the threads with engine oil.

I

J

K

L

M

Precautions for Liquid Gasket

REMOVAL OF LIQUID GASKET SEALING

EBS000EH

- Unscrew nuts and bolts. Use a seal cutter to cut the liquid gasket and remove the joined parts.


CAUTION:

Be careful not to damage the mating surfaces.


- In positions where a seal cutter is difficult to use, lightly tap with a plastic hammer and remove.

CAUTION:


When using a screwdriver, be careful not to scratch the mating surfaces.

**LIQUID GASKET APPLICATION PROCEDURE**


- Using a scraper (1), remove any old liquid gasket remaining on the gasket application surface and its mating surface.
 - Remove any old liquid gasket remaining in the gasket application groove and on the threads of bolts and bolt holes.
- Using white gasoline, wipe the gasket application surface and its mating surface to remove any moisture, oil, and foreign material.
- Set the genuine liquid gasket in a tube presser.



- Apply a continuous bead of liquid gasket to the specified position at the specified diameter.
 - Apply liquid gasket in the application groove.



- Apply liquid gasket inside bolt holes. There may be times when application to the exterior is required, so follow those instructions if such are found in the text.
- Attaching should be done within 5 minutes after gasket application.
- Immediately wipe off any protruding liquid gasket.
- Do not retighten nuts and bolts after installation.
- After finishing work, wait at least 30 minutes before refilling engine oil and coolant.

**CAUTION:**

Follow all specific instructions in this manual.

PREPARATION







[CR]

PREPARATION

Special Service Tools







PFP:00002

EBS000EI

Tool number Tool name	Description
KV10111100 Seal cutter	<p>Removing parts attached with liquid gasket</p>  <p>ZZA0013D</p>
KV10117100 Heated oxygen sensor wrench	<p>Removing and Installing heated oxygen sensor For 22 mm (0.87 in) width hexagon nut</p>  <p>NT379</p>
KV10105630 Ring gear stopper	<p>Removing and installing crankshaft pulley Removing and installing flywheel, drive plate</p>  <p>ZZA1005D</p>
KV10105610 Stopper plate	Removing and installing crankshaft pulley
	 <p>ZZA0009D</p>
KV10112100 Angle wrench	Tightening bolts for bearing cap, cylinder head, etc.
	 <p>NT014</p>
ST10120000 Cylinder head bolt wrench	<p>Loosening and tightening cylinder head bolt a: 13 mm (0.51 in) dia. b: 12 mm (0.47 in) c: 10 mm (0.39 in)</p>  <p>NT583</p>
KV101092S0 Valve spring compressor set 1. KV10116200 Valve spring compressor set 2. KV10109220 Adapter	Removing and installing valve mechanism
	 <p>ZZA0993D</p>

PREPARATION

[CR]








Tool number Tool name	Description
KV10107902 Valve oil seal puller	Removing valve oil seal
	
KV10115600 Valve oil seal drift	Installing valve oil seal
	
EM03470000 Piston ring compressor	piston assembly into cylinder bore
	
1. ST15243000 Valve seat drift 2. KV11103710 Adapter 3. KV11103720 Adapter	Installing valve seat
	
KV10107400 Piston pin Press stand 1. KV10107310 Center shaft 2. ST03140030 Stand 3. ST13040030 Spring 4. KV10107320 Cap 5. ST13040050 Drift	Disassembling and assembling piston with connecting rod
	
WS39930000 Tube presser	Pressing the tube of liquid gasket
	

PREPARATION

[CR]

Commercial Service Tools

EBS000HU


Tool name	Description	
Spark plug wrench	Removing and installing spark plug	EM
	 16 mm (0.63 in)	NT047
Crankshaft pulley puller	Removing crankshaft pulley	D
		PBIC0887E
Manual lift table caddy	Removing and installing engine	F
		ZZA1210D
Valve seat cutter set	Finishing valve seat dimensions	I
		NT048
Piston ring expander	Removing and installing piston ring	K
		NT030
Valve guide drift	Removing and installing valve guide Intake & Exhaust: a: 9.5 mm (0.374 in) dia. b: 5.5 mm (0.217 in) dia.	M
		NT015
Valve guide reamer	Reaming valve guide 1 or hole for oversize valve guide 2 Intake & Exhaust: d1 : 5.0 mm (0.217 in) dia. d2 : 9.675 mm (0.381 in) dia.	L
		NT016

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting — Engine Noise

EBS000GA



PBIC1413E

Use the Chart Below to Help You Find the Cause of the Symptom.

EBS000GB

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.

If necessary, repair or replace these parts.

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item	Reference page
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving			
Top of engine Rocker cover Cylinder head	Ticking or clicking	C	A	—	A	B	—	Tappet noise	Valve clearance	EM-45
	Rattle	C	A	—	A	B	C	Camshaft bearing noise	Camshaft journal clearance Camshaft runout	EM-43 EM-43
Crank-shaft pulley Cylinder block (Side of engine) Oil pan	Slap or knock	—	A	—	B	B	—	Piston pin noise	Piston and piston pin clearance Connecting rod bushing clearance	EM-85 EM-87
	Slap or rap	A	—	—	B	B	A	Piston slap noise	Piston-to-bore clearance Piston ring side clearance Piston ring end gap Connecting rod bend and torsion	EM-88 EM-85 EM-86 EM-86
	Knock	A	B	C	B	B	B	Connecting rod bearing noise	Connecting rod bushing clearance (Small end) Connecting rod bearing clearance (Big end)	EM-87 EM-87
	Knock	A	B	—	A	B	C	Main bearing noise	Main bearing oil clearance Crankshaft runout	EM-91 EM-90
Front of engine Timing chain cover	Tapping or ticking	A	A	—	B	B	B	Timing chain and chain tensioner noise	Timing chain cracks and wear Timing chain tensioner operation	EM-52 EM-49
Front of engine	Squeaking or fizzing	A	B	—	B	—	C	Drive belts (Sticking or slipping)	Drive belts deflection	EM-12
	Creaking	A	B	A	B	A	B	Drive belts (Slipping)	Idler pulley bearing operation	
	Squall Creak	A	B	—	B	A	B	Water pump noise	Water pump operation	CO-21 "WATER PUMP"

A: Closely related B: Related C: Sometimes related —: Not related

A

EM

C

D

E

F

G

H

I

J

K

L

M



DRIVE BELTS

PFP:02117

Checking drive Belts

EBS000GC

- Inspection should be done only when engine is cold or over 30 minutes after the engine is stopped.
- Turn the crankshaft pulley two times clockwise, and make sure tension on all pulleys is equal before doing the test.
- Visually check the belts for wear, damage, and cracks on inside and edges.
- When measuring deflection, apply 98.1 N (10 kg, 22lb) at the ▼ marked point.



CAUTION:

When measuring belt tension immediately after the belt is installed, first set the tension to the standard, rotate the crankshaft for more than two turns in order to eliminate variance in the belt tension between pulleys, then measure and adjust tension to the standard again.

Location	Tension [N (kg, lb)]			Deflection [mm (in)] [When pressed by force of 98.1N (10 kg, 22lb)]			
	New	At adjustment	Limit	Measuring point	New belt	At adjustment	Limit
Alternator and A/C compressor belt	603 - 691 (61.5 - 70.5, 135.6 - 155.3)	495 - 583 (50.5 - 59.5, 111.3 - 131.1)	196 (20, 44.1)	A	6.6 - 7.8 (0.260 - 0.307)	7.3 - 8.5 (0.287 - 0.335)	13.8 (0.543)
				B	5.6 - 6.6 (0.220 - 0.260)	7.1 - 8.3 (0.280 - 0.327)	11.9 (0.469)
Alternator belt	603 - 691 (61.5 - 70.5, 135.6 - 155.3)	495 - 583 (50.5 - 59.5, 111.3 - 131.1)	196 (20, 44.1)	A	3.1 - 4.1 (0.122 - 0.161)	9.8 - 10.6 (0.386 - 0.417)	13.8 (0.543)
Water pump belt	446 - 534 (45.5 - 54.5, 100.3 - 120.0)	348 - 436 (35.5 - 44.5, 78.2 - 98.0)	137 (14, 30.9)	C	6.7 - 7.3 (0.264 - 0.287)	7.6 - 8.6 (0.299 - 0.339)	12.4 (0.448)
				D	4.7 - 5.6 (0.185 - 0.220)	7.0 - 7.7 (0.276 - 0.303)	8.6 (0.339)

Tension Adjustment

EBS000GD

Location	Location of adjuster and tightening method
Alternator and A/C compressor drive belt	Adjusting bolt on idler pulley
Water pump belt	Adjusting bolt on idler pulley

CAUTION:

- When the belt is replaced with new one, adjust the belt tension to the value for "New belt", because new belt will not fully seat in the pulley groove.
- When tension of the belt being used exceeds "Limit", adjust it to the value for "At adjustment".
- When installing a belt, make sure that it is correctly engaged with the pulley groove.
- Do not allow oil or engine coolant to get on the belt.
- Do not twist or bend the belt strongly.

A

EM

C

D

E

F

G

H

I

J

K

L


M

ALTERNATOR AND A/C COMPRESSOR BELT (WITH A/C MODELS)

- Remove RH front fender protector.
- Loosen lock nut (1).
- Tighten lock nut (1) with fingers.
- Loosen lock nut (1) half a turn counter-clockwise.
- Adjust the belt tension by turning the adjuster bolt (2).
For the specified belt tension, refer to [EM-12, "Checking drive Belts"](#).
- Tighten lock nut (1).

Nut (1) :**扳手 : 24.5 - 31.4 N·m (2.5 - 3.2 kg-m, 18 - 23 ft-lb)**

- Turn the crankshaft pulley two times clockwise.
- Check that the belt tension is within the standard. Refer to [MA-21, "Checking drive Belts"](#).




PBIC1290E

ALTERNATOR BELT (WITHOUT A/C MODELS)

- Remove RH front fender protector.
- Loosen lock nut (1).
- Tighten lock nut (1) with fingers.
- Loosen lock nut (1) half a turn counter-clockwise.
- Adjust the belt tension by turning the adjuster bolt (2).
For the specified belt tension, refer to [EM-12, "Checking drive Belts"](#).
- Tighten lock nut (1).

Nut (1) :**扳手 : 24.5 - 31.4 N·m (2.5 - 3.2 kg-m, 18 - 23 ft-lb)**

- Turn the crankshaft pulley two times clockwise.
- Check that the belt tension is within the standard. Refer to [MA-21, "Checking drive Belts"](#).



PBIC1416E

WATER PUMP BELT

1. Remove RH front fender protector.
2. Loosen lock nut (3).
3. Tighten lock nut (3) with fingers.
4. Adjust the belt tension by turning the adjuster bolt (4).
For the specified belt tension, refer to [EM-12, "Checking drive Belts"](#) .
5. Tighten lock nut (3).

Nut (3) :

 : 24.5 - 31.4 N·m (2.5 - 3.2 kg·m, 18 - 23 ft-lb)

6. Turn the crankshaft pulley two times clockwise.
7. Check that the belt tension is within the standard. Refer to [MA-21, "Checking drive Belts"](#) .

Removal and Installation

EBS000GE

REMOVAL

- Fully loosen each belt while referring to [EM-12, "Tension Adjustment"](#) . Remove them one by one, starting with the one in the front.

INSTALLATION

1. Install belts to the pulley in the reverse order of removal.

CAUTION:

- Make sure the belt is securely inside the groove on each pulley.
- Make sure there is no oil, grease, or coolant in pulley grooves.

2. Adjust tension of each belt.

CAUTION:

- When measuring belt tension immediately after the belt is installed, first set the tension to the standard, rotate the crankshaft for more than two turns in order to eliminate variance in the belt tension between pulleys, then measure and adjust tension to the standard.
- When measuring belt tension, hand tighten idler pulley lock nut to eliminate any looseness.


3. Tighten the lock nut of adjustment parts to the specified torque.

4. Make sure that tension of each belt is within the standard.

Removal and Installation of Drive Belt Idler Pulley

EBS000GF

SEC. 275



PBIC1417E

1. Adjuster bolt (for water pump belt)
2. Idler pulley assembly
3. Shaft

4. Cover	5. Spacer	6. Idler pulley
7. Cover	8. Bracket	9. Adjuster bolt (for alternator and A/C compressor belt)

REMOVAL

1. Remove drive belts. Refer to [EM-14, "Removal and Installation"](#) .
2. Pull the adjuster bolt out from the shaft.
3. Move the idler pulley assembly along the bracket slide groove and remove by turning the shaft end at the wider part of the groove. (For alternator and A/C compressor belt)
4. Remove the lock nut and remove the shaft by pulling towards the rear of the engine. (For water pump belt)

A

EM

INSTALLATION

1. Install belts to pulley in reverse order of removal.

C

D

CAUTION:

- Make sure belt is correctly engaged with the pulley groove.
- Check for oil and coolant on belt and each pulley groove.

E

2. Adjust belt tension. Refer to [EM-12, "Tension Adjustment"](#) .
3. Tighten each adjusting bolt and nut to the specified torque.
4. Make sure that tension of each belt is within the standard.

F

G

H

I

J

K

L


M

AIR CLEANER AND AIR DUCT

PFP:16500

Removal and Installation

EBS000EO



1. EVAP canister purge volume control solenoid valve	2. Vacuum hose	3. Vacuum hose
4. Manifold absolute pressure sensor	5. O-ring	6. Vacuum hose
7. Air cleaner case (upper)	8. Gasket	9. Air cleaner case (lower)
10. Gasket	11. Clip	12. Air duct
13. Gasket	14. Gasket	15. Electric throttle control actuator
16. Air cleaner body	17. Air cleaner filter	18. Gasket

REMOVAL

NOTE:

The steps 1 to 2 can be skipped, moving straight to the step 3 (separation of harnesses and hoses, etc. cannot be skipped)

1. Remove the harness connector and then the manifold absolute pressure sensor.

CAUTION:

- Handle manifold absolute pressure sensor with care. Avoid impacts.
- Make sure no foreign matter is attached to the sensor (oils, chemicals, etc.)

2. Remove the harness connector and vacuum hose and then the EVAP canister purge volume control solenoid valve.

CAUTION:

- Handle EVAP canister purge volume control solenoid valve with care. Avoid impacts.

3. Remove air duct.

- Remove the clips, and with air duct (2) turned to nearly 90 degrees, pull off from the air cleaner body (1).

4. Remove the clips, pull the air cleaner body down then forward, and then remove the air cleaner body and the air cleaner filter.

NOTE:

Removal and disassembly of the air cleaner case (upper) and (lower) follows below.

5. Move the transaxle breather hose.

6. Remove the air cleaner case assembly in the following order.

- The entire air cleaner case (upper and lower) is referred to as the air cleaner case assembly.


a. Separate the harness connector from the electronic throttle control actuator.

b. Separate the brake booster vacuum hose.


c. Loosen bolts in the reverse of the order shown in figure.

7. Remove the air cleaner case assembly by raising.


- Slowly raise the force evenly on the intake manifold joint to lift it and remove the air cleaner case assembly.

**CAUTION:**

- To avoid damaging parts, do not use sudden force.
- Block the intake manifold openings with tape to make sure no foreign particles get inside it while you are removing the air cleaner case assembly.



8. Loosen the bolts in reverse of the order shown in the figure and separate the air cleaner case (upper) and (lower).



9. Remove the electronic throttle control actuator from the air cleaner case (upper).

- Turn the air cleaner case (upper) over on the protective sheet to make sure the surface does not get scratched.
- The electronic throttle control actuator should be handled with the following precautions in mind.

CAUTION:


- Handle electronic throttle control actuator with care. Avoid impacts.
- Do not disassemble or adjust.

INSTALLATION

1. Install the electronic throttle control actuator (1) to the air cleaner case (upper) (2) in the following procedure:

- Install the gasket (3) to the connector base.
- Attach the gasket (4) to the outer groove on the throttle bore on the side of the air cleaner case (upper) (2).
- Install electronic throttle control actuator.

- There is no pre-determined order in which the mounting bolts should be tightened.
- Perform the "Throttle Valve Closed Position Learning" when harness connector of the electric throttle control actuator is



AIR CLEANER AND AIR DUCT

[CR]

disconnected. Refer to [EC-42, "Throttle Valve Closed Position Learning"](#) (WITH EURO-OBD), [EC-503, "Throttle Valve Closed Position Learning"](#) (WITHOUT EURO-OBD).

- Perform the "Idle Air Volume Learning" and "Throttle Valve Closed Position Learning" when the electric throttle control actuator is replaced. Refer to [EC-42, "Idle Air Volume Learning"](#) and [EC-42, "Throttle Valve Closed Position Learning"](#) (WITH EURO-OBD), [EC-503, "Idle Air Volume Learning"](#) and [EC-503, "Throttle Valve Closed Position Learning"](#) (WITHOUT EURO-OBD).

2. Assemble the air cleaner case (upper) and (lower).


- Tighten bolts evenly in two steps in the order shown in figure.

1st step

 : 1.9 - 2.2 N·m (0.20 - 0.22 kg·m, 17 - 19 in·lb)

2nd step

 : 3.8 - 4.4 N·m (0.40 - 0.44 kg·m, 35 - 38 in·lb)



3. Attach the air cleaner case assembly in the following order.

- a. Attach the gasket (for the intake manifold (1) and the PCV path (2))


- Attach for the intake manifold so that the case protrusion (4) fit into the cutout hole (3) on the side of the gasket.
- Make sure foreign particles do not attach to the gasket or the sealing area.

- b. Insert the air cleaner case assembly into the intake manifold.

- At the same time, insert the bottom path protrusions into the PCV path holes on the rocker cover.

CAUTION:

Insert straight, making sure the axis is lined up, to prevent the gaskets from being crooked or twisted.




- c. Tighten bolts in the numerical order shown in figure.

- Tighten bolts evenly in several steps.

CAUTION:

Tighten after making sure the positioning of bolts 5 and 6 is true.



4. Install air cleaner body and air cleaner filter. Refer to [EM-19, "Changing Air Cleaner Filter"](#) .

5. Attach air duct.

6. Attach EVAP canister purge volume control solenoid valve.

7. Attach the manifold absolute pressure sensor.

- Make sure no foreign particles attach to the flange, O-ring, or attachment hole.
- Tighten the mounting bolt after making sure it is fully inserted into the mounting hole.


Changing Air Cleaner Filter

REMOVAL

1. Remove air duct. Refer to [EM-16, "REMOVAL"](#) .
2. Remove clips (2) of air cleaner body (1).
3. After moving the air cleaner body downward, remove it by pulling it forward.
 - While pressing down the radiator upper hose, remove air cleaner body (1).
4. Remove air cleaner filter from the air cleaner body.


NOTE:

In some cases the air cleaner filter might remain in the air cleaner case (upper).



INSTALLATION

1. Set the air cleaner filter on the air cleaner case (upper) (1).
2. Insert the two projections (3) on the air cleaner body (2) into the two notch holes (4) on the rear of the air cleaner case (upper) (1), then lift up and fasten with the clip.
3. Attach air duct.




INTAKE MANIFOLD

PFP:14003

Removal and Installation

EBS000EQ

SEC. 140



PBIC1421E


1. Support bracket
2. Gasket
3. Stud bolt
4. Intake manifold

REMOVAL

1. Remove air duct and air cleaner case assembly. Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#).
2. Remove the PCV hose (between the intake manifold and the rocker cover) from the intake manifold side.
3. Remove the support bracket mounting bolt (No. 1 port upper engine front side)
4. Loosen nuts and bolts in the reverse of the order shown in the figure to remove the intake manifold.

CAUTION:


Disregard No. 6 shown in figure in the loosening order.



PBIC1422E

NOTE:

Removal and installation of No. 5 nut is made easier by inserting the tool into the recommended cutout part (2) on the No. 1 port (1). (The same applies to No. 4 nut)



PBIC1298E

INSTALLATION

- Install in the reverse order of removal paying attention to the following.


Attachment of the Intake Manifold

- Check for damage or foreign material on the mounting surfaces.
- Tighten nuts and bolts in numerical order shown in figure.

NOTE:

No. 6 in the figure shows the 2nd tightening of No. 1 bolt.

- When installing support bracket, refer to [EM-31, "INSTALLATION"](#) .



A

EM

C

D

E

F

G

H

I

J

K

L

M


EXHAUST MANIFOLD AND THREE WAY CATALYST

PFP:14004

Removal and Installation

EBS00018

SEC. 140-208-226



PBIC1423E

1. Bracket	2. Gasket	3. Exhaust manifold
4. Heated oxygen sensor 1	5. Exhaust manifold cover	6. Stud bolt
7. Three way catalyst (manifold)	8. Three way catalyst cover	9. Support

REMOVAL

1. Remove air duct. Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#) .
2. Remove RH front fender protector.
3. Remove alternator and A/C compressor belt. Refer to [EM-12, "DRIVE BELTS"](#) .
4. Remove A/C compressor with piping connected, move A/C compressor to body side and secure it onto body with a rope.
5. Remove exhaust front tube connection at front. Refer to [EX-3, "EXHAUST SYSTEM"](#) .
6. Remove RH engine mount stay and alternator bracket.
7. Loosen the lower bolt and move the alternator to the front of the vehicle.
8. As needed, remove the heated oxygen sensor 1 in the following order.


NOTE:

Steps 2 to 7 above are not needed for heated oxygen sensor 1 removal.

- a. Separate the harness connector and remove it from bracket.
- b. Using heated oxygen sensor wrench (special service tool), remove heated oxygen sensor 1.

CAUTION:

- Handle it carefully, avoid any chance of impact caused by dropping.



PBIC1424E

EXHAUST MANIFOLD AND THREE WAY CATALYST


[CR]

- Do not over torque the heated oxygen sensor. Doing so may cause damage to the heated oxygen sensor, resulting in the MI coming on.

9. Remove exhaust manifold cover.
10. Remove the three way catalyst cover.
11. Loosen nuts and bolts in the reverse of the order shown in figure to remove the exhaust manifold and three way catalyst.

CAUTION:

Be careful not to damage the A/C piping.



12. Separate the exhaust manifold and three way catalyst.


CAUTION:

Avoid impacts to three way catalyst.

INSPECTION AFTER REMOVAL

Surface Distortion

- Using a reliable straightedge (1) and feeler gauge (2), check distortion of mounting surface on exhaust manifold.
Limit : 0.3 mm (0.012 in)
- If it exceeds the limit, replace the exhaust manifold.




INSTALLATION

- Install in the reverse order of removal paying attention to the following.

Installation of Exhaust Manifold and Three Way Catalyst

- Check for damage or foreign material on the mounting surfaces.
- Tighten nuts in numerical order shown in figure.



Installation of Heated Oxygen Sensor 1

CAUTION:

- Do not over torque the heated oxygen sensor. Doing so may cause damage to the heated oxygen sensor, resulting in the MI coming on.


OIL PAN AND OIL STRAINER

PFP:11110

Removal and Installation

EBS000ES

SEC. 110•150



- 1. Oil pan (upper)
- 2. Transaxle connecting bolt
- 3. Oil strainer
- 4. Drain plug
- 5. Washer
- 6. Oil pan (lower)
- 7. Rear plate cover
- 8. Transaxle connecting bolt

REMOVAL

NOTE:

Installation and removal of manual transmission vehicle oil pan (upper) require removal of the transaxle.

1. Remove RH front fender protector.
2. Drain the engine oil.
3. Remove the oil pan (lower) in the following order.
 - a. Loosen bolts in the reverse of the order shown in figure.
 - b. Insert seal cutter (special service tool) between oil pan (upper) and oil pan (lower). Slide seal cutter by tapping on the side of the tool with a hammer. Remove oil pan (lower).

CAUTION:

Exercise care not to damage mating surface.

NOTE:


The following is the order for removing the oil pan (upper).

4. Remove the oil level gauge.
5. Remove drive belts. Refer to [EM-12, "DRIVE BELTS"](#).
6. Remove the A/C compressor with piping connected and move the A/C compressor aside.

CAUTION:

Hang it with rope and temporarily tighten to body to avoid putting stress on air conditioner piping.


7. Remove the exhaust front tube. Refer to [EX-3, "EXHAUST SYSTEM"](#).



OIL PAN AND OIL STRAINER

[CR]


8. Remove three way catalyst support. Refer to [EM-22, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#).
9. Remove the transaxle in the following order. (M/T models)
 - a. Mount engine slingers on cylinder head. Refer to [EM-60, "Removal and Installation"](#).
 - b. Lift with a hoist and position engine.
 - c. Remove transaxle. Refer to [EM-69, "Removal and Installation"](#).
10. Remove oil pan (upper) with the following procedure.
 - a. Remove oil pan (upper) to transaxle connecting bolts (A/T models). Refer to [AT-430, "REMOVAL AND INSTALLATION"](#).
 - b. Loosen oil pan (upper) mounting bolts in the reverse of the order shown in figure.



- c. Insert a flathead offset screwdriver into the cutout (1) shown in figure and create a crack between the oil pan and cylinder block.
- d. Insert seal cutter (special service tool) between oil pan (upper) and cylinder block. Slide seal cutter by tapping on the side of the tool with a hammer. Remove oil pan (upper).

CAUTION:

Exercise care not to damage mating surface.



11. Remove oil strainer.

INSTALLATION

1. Install oil strainer.


NOTE:

Do not use O-ring, gasket, or other seal parts.

2. Attach the oil pan (upper) in the following order.
 - a. Apply the liquid gasket to the position shown in figure. Use Genuine Liquid Gasket or equivalent.

CAUTION:

- For bolt holes with ★ marks (3 locations), apply liquid gasket outside the holes.
- Apply a bead of 5.5 to 6.5 mm (0.127 - 0.256 in) in diameter to area "A" and "B".



OIL PAN AND OIL STRAINER

[CR]

b. Tighten bolts in the numerical order shown in figure.

NOTE:



See below for mounting positions of bolts

Under head 70 mm (2.76 in) : 4, 8, 12


Under head 90 mm (3.54 in) : 9, 10

Under head 25 mm (0.98 in) : Other than the above

c. Tighten transaxle connecting bolts. (A/T models)
3. Install transaxle assembly. (M/T models)
4. Install oil pan (lower) in the following procedure:
a. Apply the liquid gasket to the position shown in figure. Use Genuine Liquid Gasket or equivalent.



b. Tighten bolts in the numerical order shown in figure.



5. Install oil pan drain plug.
● For washer installation direction, refer to components figure on [EM-24, "Removal and Installation"](#) .
6. Reinstall removed parts in reverse order of removal.

CAUTION:

Engine oil should be filled at least 30 minutes after the oil pan is installed.

INSPECTION AFTER INSTALLATION

- Check engine oil level. Refer to [LU-4, "ENGINE OIL"](#) .
- Warm up engine and check the oil amount and no leakage of oil. Refer to [LU-4, "ENGINE OIL"](#) .

IGNITION COIL

PFP:22448

Removal and Installation

EBS000ET

A

EM

C

D

E

F

G

H

I


J

K

L

M

SEC. 220



: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

PBIC1432E

1. Ignition coil

2. Spark plug

REMOVAL

1. Remove air duct and air cleaner case assembly. Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#).
2. Disconnect harness connector from the ignition coil.
3. Remove ignition coil.

CAUTION:

- Handle ignition coil with care. Avoid impacts.
- Do not disassemble.

INSTALLATION

Install in the reverse order of removal.

SPARK PLUG (PLATINUM-TIPPED TYPE)

PFP:22401


Removal and Installation

REMOVAL

1. Remove ignition coil. Refer to [EM-27, "IGNITION COIL"](#) .
2. Remove spark plugs with a spark plug wrench.

CAUTION:

Handle spark plug with care. Avoid impacts.



INSPECTION AFTER REMOVAL

- Use standard type spark plug for normal condition.
- The hot type spark plug is suitable when fouling occurs with the standard type spark plug under conditions such as:
 - Frequent engine starts
 - Low ambient temperatures
- The cold type spark plug is suitable when spark plug knock occurs with the standard type spark plug under conditions such as:
 - Extended highway driving
 - Frequent high engine revolution

Make	NGK	Champion
Standard type	LFR5AP-11	REC10PYC4
Hot type	LFR4AP-11	—
Cold type	LFR6AP-11	—

Gap (Nominal) : 1.1 mm (0.043 in)

CAUTION:


- Do not use a wire brush for cleaning.
- If plug tip is covered with carbon, spark plug cleaner may be used.

Cleaner air pressure:

Less than 588 kPa (6 kg/cm² , 85 psi)

Cleaning time:


Less than 20 seconds



SPARK PLUG (PLATINUM-TIPPED TYPE)

[CR]

- Checking and adjusting plug gap is not required between change intervals.



INSTALLATION

Install in the reverse order of removal.

Spark plug

 : 19.6 - 29.4 N·m (2.0 - 3.0 kg·m, 15 - 21 ft-lb)

A

EM

C

D

E

F

G

H

I

J

K

L

M

FUEL INJECTOR AND FUEL TUBE

[CR]


FUEL INJECTOR AND FUEL TUBE

PFP:16600

Removal and Installation

EBS000GG

SEC. 164



PBIC1433E

1. O-ring (brown)	2. Clip	3. O-ring (black)
4. Fuel tube	5. Fuel feed hose	6. Fuel injector

REMOVAL

1. Release fuel pressure. Refer to [EC-44, "FUEL PRESSURE RELEASE" \(WITH EURO-OBD\)](#), [EC-505, "FUEL PRESSURE RELEASE" \(WITHOUT EURO-OBD\)](#).
2. Remove air duct and air cleaner case assembly. Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#).
3. Remove intake manifold support bracket.
4. Remove the fuel hose on the side of the fuel tube.


CAUTION:

Attach a plug to the removed hose to prevent fuel leaks.

5. Separate the fuel injector harness and move to a position where it will not get in the way of work.
 - If it is stuck or otherwise difficult to remove, remove the fuel injector and fuel tube assembly from the cylinder head and separate fuel injector harness in a better position.
6. Loosen bolts in the reverse of the order shown in the figure and then remove the fuel injector and fuel tube assembly.

CAUTION:

- Make sure the fuel injector nozzle does not touch the other parts.
- Take out without tipping, as this will cause fuel to leak.



PBIC1434E


FUEL INJECTOR AND FUEL TUBE

[CR]

7. Remove the fuel injector (2) from the fuel tube (1) in the following order.
 - a. Open and pull out the clip (3).
 - b. Remove fuel injector from the fuel tube by pulling straight.

CAUTION:

- Be careful not to damage the nozzle.
- Do not drop or impact the fuel injector.
- Do not disassemble or adjust fuel injector.



INSTALLATION

1. Keep in mind the following points when attaching the O-ring to the fuel injector.

CAUTION:

- The upper and lower O-rings are different, so use caution when attaching them.

Fuel tube side : Black
Nozzle side : Brown

- Handle O-ring with bare hands. Never wear gloves.
- Lubricate O-ring with engine oil.
- Do not clean O-ring with solvent.
- Make sure the O-ring and its mating part are free of foreign material.
- When installing the O-ring, be careful not to scratch it with tools or your fingernails. Also be careful not to twist or stretch O-ring. If O-ring is stretched while it is being attached, do not insert it into fuel tube immediately.

2. Install the fuel injector onto the fuel tube in the following procedure:

- a. Insert the clip (3) into the clip mounting groove (2) on the fuel injector (1).

- Insert clip cutout (5) into fuel injector protrusion (4).


CAUTION:

- Always replace clip with new one.
- Make sure the clip does not interfere with the O-ring. If it does, replace the O-ring.

- b. With the clip assembly as is, insert the fuel injector (1) into the fuel tube (6).

- Make sure the axis is lined up when inserting.
- Insert clip cutout (8) into fuel tube protrusion (7).
- Make sure the flange (10) on the fuel tube fits securely in the clip flange groove (9).

- c. Make sure the fuel injector does not spin or come off.



FUEL INJECTOR AND FUEL TUBE

[CR]

3. Install fuel tube and injector assembly onto cylinder head.

CAUTION:

Make sure the injector nozzle does not touch the other parts.


- Tighten bolts evenly in two steps in the order shown in figure.

1st step

 : 11.8 - 13.8 N·m (1.2 - 1.4 kg·m, 9 - 10 ft-lb)

2nd step

 : 20.8 - 28.2 N·m (2.1 - 2.9 kg·m, 16 - 20 ft-lb)



4. Connect fuel feed hose..

CAUTION:

Securely tighten the hose clamp at a position where it does not get in the way of the bulge.

5. Install intake manifold support bracket.

- Tighten mounting bolts in the following order.


- Tighten bolts temporarily in numerical order shown in the figure.
- Tighten bolts to the specification in numerical order shown in the figure.

Bolt 1

 : 6.9 - 9.5 N·m (0.7 - 0.96 kg·m, 61 - 84 in-lb)

Bolts 2 and 3

 : 8.4 - 10.8 N·m (0.86 - 1.1 kg·m, 75 - 95 in-lb)



6. Reinstall removed parts in reverse order of removal.

INSPECTION AFTER INSTALLATION

- Follow the procedure below to make sure there are no fuel leaks.
- 1. Turn the ignition switch to ON (do not start engine), and with fuel pressure applied in the fuel line, check to make sure there are no fuel leaks from the connection.
- 2. Start the engine, and with the increased speed, check again to see if there are any fuel leaks from the connection.

ROCKER COVER

PFP:13264

Removal and Installation

EBS000EX

A

EM

C

D

E

F

G

H


I

J

K

L

M



PBIC1436E

1. Harness bracket	2. Grommet	3. PCV control valve
4. PCV hose	5. Oil filler cap	6. Intake valve timing control solenoid valve
7. O-ring	8. Rocker cover	9. Rocker cover oil seal
10. Gasket	11. Gasket	

REMOVAL

1. Remove air duct and air cleaner case assembly. Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#) .
2. Remove RH engine mount stay. Refer to [EM-69, "Removal and Installation"](#) .

NOTE:

It is not necessary to support the engine using a jack.

3. Remove ignition coil. Refer to [EM-27, "IGNITION COIL"](#) .
4. Remove ignition coil harness bracket.
5. Disconnect PCV hose and intake valve timing control solenoid valve harness connector.
6. Remove the PCV control valve if necessary.
7. Remove the intake valve timing control solenoid valve if necessary.


CAUTION:

- Handle intake valve timing control solenoid valve with care. Avoid impacts.
- Do not disassemble.

ROCKER COVER

[CR]

8. Loosen bolts in the reverse of the order shown in the figure to remove rocker cover.



9. Remove the rocker cover oil seal using a screwdriver.


CAUTION:

Be careful not to damage the rocker cover.

INSTALLATION

1. Install rocker cover oil seal.

- Using drift with outer diameter 97 mm (3.82 in) and inner diameter 83 mm (3.27 in) to 88 mm (3.46 in), press oil seal in.
- Press-fit the oil seal evenly to the mounting surface.




2. Install the rocker cover in the following procedure:


a. Install the gasket (1) to the No. 1 camshaft bracket upper surface.

- Match up the positioning pins (2) and gasket holes in the direction of the shape of the camshaft bracket when attaching.

b. Install the gasket to the rocker cover mounting groove.



c. Apply the liquid gasket to the position shown in figure. Use Genuine Liquid Gasket or equivalent.




ROCKER COVER

[CR]

d. Tighten bolts evenly in two steps in the order shown in the figure, to the specified torque.
● See below for mounting positions of bolts

Under head 45 mm (1.77 in) : 1, 2 (inside bolts)

Under head 20 mm (0.79 in) : Other than above (outside bolts)



3. Install intake valve timing control solenoid valve.
● Make sure no foreign particles attach to the flange, O-ring, or attachment hole.
● Tighten the mounting bolt after making sure it is fully inserted into the mounting hole.

4. Install PCV control valve.
● Insert until the flange is flush with the grommet.

5. Reinstall removed parts in reverse order of removal.

CAMSHAFT


PFP:13001

Removal and Installation

SMA for VIN >SJN**AK12U1133450

EBS000EY

SEC. 111•130•220



PBIC1438E

1. Camshaft bracket (No. 2 - 5)
2. Camshaft bracket (No. 1)
3. Camshaft (intake)
4. Camshaft (exhaust)
5. Valve lifter
6. Camshaft sprocket (intake)
7. Camshaft sprocket (exhaust)
8. Chain tensioner
9. Cylinder head front cover
10. Timing chain
11. Cylinder head
12. O-ring
13. Camshaft position sensor (PHASE)

REMOVAL


1. Remove RH front fender protector.
2. Secure the engine position using one of the following methods. Remove RH engine mount stay and engine mount bracket (upper). Refer to [EM-69, "Removal and Installation"](#).
 - Mount engine slingers and hook with hoist. Refer to [EM-69, "Removal and Installation"](#) .
 - Support the oil pan bottom with a jack stand, etc.
3. Remove rocker cover. Refer to [EM-33, "ROCKER COVER"](#) .
4. Remove the camshaft position sensor (PHASE) from the back of the cylinder head if necessary.

CAUTION:

- Handle camshaft position sensor (PHASE) with care. Avoid impacts.
- The tip of the sensor is magnetic, so do not let metal dust get on it or place it next to objects which can be affected by magnets.

5. Remove RH headlamp. Refer to [LT-6, "HEADLAMP -CONVENTIONAL TYPE-](#) .
6. Remove the cylinder head front cover.
7. Following the procedure below, place cylinder No. 1 at TDC of its compression stroke


a. Turn the crankshaft pulley clockwise as seen from the engine front, and match up the crankshaft pulley TDC mating mark (no color) (2) with the timing indicator (1) on the front cover.



b. Confirm mating marks (1) stamped on intake and exhaust sprockets are located as shown.

- If there is no position mark at the position in the figure, turn the crankshaft pulley once more to position them as in the figure.

c. Make sure mating marks on intake and exhaust camshaft sprockets are located as shown in the figure, then paint mating marks on the timing chain links.




8. Make sure the intake camshaft sprocket is in the most advanced position.

CAUTION:

Installation and removal of the intake camshaft sprocket must be done in the most advanced position for the following reasons, so make sure you follow the procedure exactly.

- The sprocket (1) and vane (camshaft coupling) (3) are designed to spin and move within the range of a certain angle.
- With the engine stopped the vane (3) is in the most retarded position. It will not spin because it is locked to the sprocket side by the internal lock pin (2).
- If the camshaft sprocket mounting bolts are turned in the situation described above (the most retarded position), the lock pin (2) will become damaged and cause malfunctions because of the increased horizontal load (cutting force) on the lock pin (2).

• Put the intake camshaft sprocket in the most advance position in the following steps.




CAUTION:

The chain tensioner must not be removed before doing this step.

NOTE:

The spinning direction in the following description is as seen from the engine front.

a. Immobilize the hexagonal part of the camshaft with a wrench (1) to prevent the intake camshaft from moving.



b. Apply air pressure with an air gun (2) to the advanced angle side oil passage of the intake valve timing control on the top surface of the No. 1 camshaft bracket (1).


Compression pressure

: 300 kPa (3.00 bar, 3 kg/cm², 43.5 psi) or more

NOTE:

The air pressure is used to move the lock pin into the disengage position.

- Keep applying air pressure until step "e" is completed.



CAUTION:


- Be sure not to damage the oil passage with the tip of the air gun.
- Wipe all the oil off on the top surface of the No. 1 camshaft bracket to prevent oil from being blown with the air, and the area around the air gun should be covered with a rag when applying air pressure. Eye protection should be worn as needed.

c. Turn the intake camshaft slowly counter-clockwise in direction A (towards the intake manifold).

- Keep the air pressure on.

CAUTION:

Also be sure the wrench immobilizing the camshaft does not come loose.




d. While doing the above, once you hear a click (the sound of the internal lock pin disengaging) from inside the intake camshaft sprocket, start turning the intake camshaft in the opposite direction, direction B (clockwise: towards the exhaust manifold) and to the most advanced angle position.


- Keep the air pressure on.
- If there is no click, as soon as the vane (camshaft coupling) starts moving independently of the camshaft sprocket, the lock pin has become disengaged.
- If the lock pin does not become disengaged, shake the wrench immobilizing the camshaft slightly.
- If this still does not help in disengaging the lock pin, tap the intake camshaft front very lightly with a plastic hammer.

e. Once the vane starts to spin and then the camshaft sprocket starts to spin with the camshaft, it has reached the most advanced position, so stop.

- Make sure the most advanced position locating intake valve timing control advance mark (1) of vane (3) and alignment mark (2) of sprocket (4) as shown in the figure.



9. Attach the stopper pin (1) such as a paper clip to secure the plunger in the full compressed position and remove the chain tensioner (2).




10. Keeping the wrench on the camshaft hexagonal part, loosen the mounting bolts and remove the intake and exhaust camshaft sprockets.

CAUTION:

- Make sure the tools do not come in contact with the A/C piping.
- Do not loosen mounting bolts with securing anything other than the camshaft hexagonal part or with tensioning the timing chain.

NOTE:

With the front cover attached, the timing chain and crankshaft sprocket will not come off, so there is no need to take steps to maintain the timing chain tension.



- The intake camshaft sprocket should be handled with the following precautions in mind.

CAUTION:

- When removing intake camshaft sprocket, using adhesive tape or equivalent, prevent vane from rotating so that lock pin will not rejoin in the most retarded position.
- Handle it carefully, and avoid any chance of impact caused by dropping.
- Do not disassemble. (Do not loosen the four front bolts.)

NOTE:

While removing the intake camshaft sprocket, if the lock pin has been rejoined in the most retarded position, do the following to restore it.

a. Reinstall the intake camshaft sprocket to the intake camshaft and tighten the mounting bolts enough to prevent air leaking out when the air pressure is applied later.

CAUTION:

To prevent internal lock pin from damaging, keep the torque on the mounting bolts to the minimum required to prevent air from escaping.

b. Apply the air pressure, disengage the lock pin following step 8, and turn the vane to the most advanced position. (The timing chain need not be attached for this step.)

c. Remove the intake camshaft sprocket from camshaft.

11. Remove camshaft brackets.

- Loosen bolts in several steps in reverse order shown in the figure.


12. Remove camshaft.

CAUTION:

Do not deform or damage intake camshaft rear end signal plate.

13. Remove valve lifter.

- Identify installation position of each valve. Arrange removed valve lifters so they cannot be mixed up.




INSTALLATION

1. Install valve lifter.

- Install it in its original positions.


2. Install camshaft.

- You can distinguish between the intake and the exhaust by looking at the different shapes of the front and rear ends of the camshaft.


**NOTE:**

- Paint distinguishing the applicable engine (1) can be found between the cams for cylinders No. 2 to 3.
- Paint distinguishing the applicable engine (2) can be found between the cams for cylinders No. 3 to 4.(CR12DE, CR14DE)

Paint distinguishing the applicable engine	(1)	(2)
CR10DE	INT	Green
	EXH	White
CR12DE, CR14DE	INT	Green
	EXH	Red




- Install the camshaft front ends dowel pin hole (1) and dowel pin (2) so that they are positioned as shown in the figure.



3. Install camshaft brackets.

- Completely remove any foreign material on bottom surfaces of camshaft brackets and top surface of cylinder head.
- Referring to the marks on top of the camshaft bracket, install so that it is in the same position and facing the same direction as when removed.



4. Tighten camshaft bracket bolts in the following order.

a. Bolt sizes vary with installation position. Refer to the following when installing bolts.

Bolt color

1 - 10	: Black
11, 12	: Gold

b. First tighten bolts 9 through 12, then tighten bolts 1 through 8 in numerical order.

 : 2.0 N·m (0.2 kg·m, 18 in-lb)

c. Tighten all bolts in numerical order shown in the figure.


 : 5.9 N·m (0.6 kg·m, 52 in-lb)

d. Retighten all bolts in numerical order shown in the figure.


 : 9.0 - 11.8 N·m (0.92 - 1.2 kg·m, 80 - 104 in-lb)

5. Install the intake camshaft sprocket in the following procedure:

- Make sure the most advanced position checking intake valve timing control advance mark (1) of vane (3) and alignment mark (2) of sprocket (4) are located as shown in the figure.




PBIC0969E



PBIC1634E


a. Install timing chain (2) by aligning its mating mark (3) (marked when timing chain is removed) with mark (4) on camshaft sprocket (1).

- Install by aligning the dowel pin on the back of the camshaft sprocket with dowel pin hole on the camshaft.



PBIC1317E



b. Keeping the camshaft hexagonal part still with the wrench (2), tighten the mounting bolt for the intake camshaft sprocket (1).




PBIC1318E

c. Remove adhesive tape or equivalent from camshaft sprocket.

6. Install the exhaust camshaft sprocket (1) in the following procedure:
 - a. Install timing chain (2) by aligning its mating mark (3) (marked when timing chain is removed) with mark (4) on camshaft sprocket (1).
 - Install by aligning the dowel pin groove of the sprocket with dowel pin on the camshaft.
 - b. Keeping the camshaft hexagonal part still with the wrench, tighten the mounting bolt for the exhaust camshaft sprocket.
 - c. Make sure the markings for the intake and the exhaust camshaft sprockets and the timing chain are all lined up.
7. Install chain tensioner (2).
 - Install the stopper pin (1) with plunger secured.
 - After installation, remove the stopper pin (1) and release the plunger.
 - Make sure again that mating marks on the intake and exhaust camshaft sprockets and mating marks on timing chain are aligned.




8. Turn the crankshaft pulley (1) slowly clockwise to return the intake camshaft sprocket to the most retarded position.



- When first turning the crankshaft the intake camshaft sprocket will turn. Once it is turned more, and the vane (camshaft) also turns, then it has reached the most retarded position.
- After spinning the crankshaft slightly in a counterclockwise direction, you can make sure the lock pin has joined by seeing if the vane and the sprocket move together.

9. Install the cylinder head front cover.
 - Evenly apply the liquid gasket to the position shown in figure. Use Genuine Liquid Gasket or equivalent.
 - Install so that the cylinder head front cover matches up with the dowel pin on the cylinder head side.
10. Install camshaft position sensor (PHASE).
 - Make sure no foreign particles attach to the flange, O-ring, or attachment hole.
 - Tighten the mounting bolt after making sure it is fully inserted into the mounting hole.
11. Inspect and adjust valve clearance. Refer to [EM-45, "Valve Clearance"](#).
12. Reinstall removed parts in reverse order of removal.



INSPECTION AFTER REMOVAL**Camshaft Runout**

- Put V block on precise flat bed, and support No. 2 and No. 5 journal of camshaft.


CAUTION:

Do not support journal No. 1 (on the side of the camshaft sprocket) because it has a different diameter from the other four locations.

- Set a dial gauge (1) vertically onto journal No. 3.
- Rotate the camshaft in one direction by hand and read indication on the gauge. (Total indication reading)

Limit : 0.04 mm (0.0016 in) or less

- If exceeds the limit, replace the camshaft.



PBIC1323E

Camshaft Cam Height

- Measure with a micrometer (1).

Standard**CR10DE**


Intake : 39.155 - 39.345 mm (1.5415 - 1.5490 in)

Exhaust : 39.155 - 39.345 mm (1.5415 - 1.5490 in)

CR12DE, CR14DE

Intake : 40.359 - 40.549 mm (1.5889 - 1.5964 in)

Exhaust : 39.743 - 39.933 mm (1.5647 - 1.5722 in)



PBIC1324E

- If it exceeds the standard, replace the camshaft.

Camshaft Journal Clearance**Outer Diameter of Camshaft Journal**


- Measure with a micrometer (1).

Standard**No. 1**

: 27.935 - 27.955 mm (1.0998 - 1.1006 in)

No. 2 to No. 5

: 23.450 - 23.470 mm (0.9232 - 0.9240 in)



PBIC1325E

Inner Diameter of Camshaft Journal


- Tighten camshaft bracket bolts to the specified torque.
- Using an inside micrometer (1), measure inner diameter of the camshaft bracket.

Standard**No. 1**

: 28.000 - 28.021 mm (1.1024 - 1.1032 in)

No. 2 to No. 5

: 23.500 - 23.525 mm (0.9252 - 0.9262 in)



PBIC1326E

Calculation of Camshaft Journal Clearance

(Journal clearance) = (inner diameter of camshaft bracket) - (outer diameter of camshaft journal).

Standard**No. 1****: 0.045 - 0.086 mm (0.0018 - 0.0034 in)****No. 2 to No. 5****: 0.030 - 0.071 mm (0.0012 - 0.0028 in)**

- If clearance exceeded the standard, replace the camshaft and/or the cylinder head. Refer to the standard values for each individual part.

NOTE:


Since the camshaft brackets and the cylinder head are machined together, replacement must be done using the cylinder head assembly.

Camshaft End Play

- Set a dial gauge (1) to the camshaft front end in thrust direction. Move the camshaft back and forth (axially) and read indication on the gauge.

Standard : 0.070 - 0.143 mm (0.0028 - 0.0056 in)

- When out of the standard, replace with new camshaft and measure again.
- When out of the standard again, replace with new cylinder head.




PBIC1327E

Camshaft Sprocket Runout

- Put V block on precise flat bed, and support No. 2 and No. 5 journal of camshaft.
- Using a dial gauge, measure camshaft sprocket runout.

Limit**Intake : 0.20 mm (0.0079 in)****Exhaust : 0.15 mm (0.0059 in)**

- If it exceeds the limit, replace camshaft sprocket.




KBIA1493J

Valve Lifter

Check for cracks and wear on valve lifter surface.

- If anything above is found, replace valve lifter.




KBIA1597J

Valve Lifter Clearance**Outer Diameter of Valve Lifter**


- Measure with a micrometer (1).

Standard : 29.960 - 29.975 mm(1.1795 - 1.1801 in) dia.

**Valve Lifter Hole Diameter**

- Using an inside micrometer (1), measure the valve lifter hole diameter in cylinder head.

Standard : 30.000 - 30.021 mm (1.1811 - 1.1819 in) dia.



Calculation of valve lifter clearance

(Valve lifter clearance) = (valve lifter hole diameter) - (outer diameter of valve lifter)

Standard : 0.025 - 0.061 mm (0.0010 - 0.0024 in)


- If clearance exceeded the standard, replace either one or both of valve lifter and cylinder head. Refer to the standard values for valve lifter outer diameter and hole diameter.

Valve Clearance INSPECTION

EBS000EZ

- Whenever the camshaft and valve related parts are removed and installed or replaced, or symptoms due to changes in valve clearance as a result of aging (poor starting, rough idle, unusual noise) are obvious, check valve clearance with the following procedure:

- Warm up engine and stop it.
- Remove the following parts.
 - RH front fender protector
 - Rocker cover; Refer to [EM-33, "ROCKER COVER"](#) .
- Turn the crankshaft pulley clockwise as seen from the engine front, and match up the crankshaft pulley TDC mating mark (no color) (2) with the timing indicator (1) on the front cover.
- When doing this, make sure both the intake and exhaust cam noses on cylinder No. 1 are facing outwards. (No. 1 cylinder at TDC of its compression stroke)
 - If they are not facing out, turn the crankshaft pulley further. It is OK to do step 6 first (checking when No. 4 cylinder at TDC of its compression stroke).





- Referring to the figure, measure valve clearances of valves with \times in table below using a feeler gauge (1).

CAMSHAFT

[CR]

Cylinder		No. 1	No. 2	No. 3	No. 4
No. 1 cylinder at TDC of its compression stroke.	INT	×	×		
	EXH	×		×	

No. 1 cylinder at compression TDC



Valve clearance standard:

Hot	Intake	: 0.314 - 0.426 mm (0.012 - 0.017 in)
	Exhaust	: 0.338 - 0.462 mm (0.013 - 0.018 in)
Cold*	Intake	: 0.29 - 0.37 mm (0.011 - 0.015 in)
	Exhaust	: 0.32 - 0.40 mm (0.013 - 0.016 in)

*: Approximately 20°C (68°F) (Reference data)


When adjusted for cold engine, the standard values for warm engine must be checked to see if they are correct, too.

6. Rotate crankshaft by 360° clockwise (when viewed from front) to align No. 4 cylinder at TDC of its compression stroke.
7. Referring to the figure, measure valve clearances of valves with × in table below.

Cylinder		No. 1	No. 2	No. 3	No. 4
No. 4 cylinder at TDC of its compression stroke.	INT			×	×
	EXH		×		×

8. Adjustment of places outside range of standard values is done as follows.

No. 4 cylinder at compression TDC




ADJUSTMENT

NOTE:

- The adjustment is made by selecting the thickness of the head of the valve lifter. (An adjuster shim is not used)
- The set thickness for the valve filter is measured at normal temperature, but any changes in dimension because of temperature differences may be ignored. Accordingly, adjustment should use values for a warmed up engine (ready for inspection).

1. Remove camshaft. Refer to [EM-36, "Removal and Installation"](#).
2. Remove the valve lifters for parts which are outside the range of standard values.

3. Using a micrometer (1), measure thickness of the removed valve lifter center part.



4. Measure the thickness of the valve lifter to be replaced using the following formula.

How to determine valve lifter thickness

$$t = t_1 + (C_1 - C_2)$$

t = Valve lifter thickness to be replaced

t_1 = Removed valve lifter thickness

C_1 = Valve clearance measurement


C_2 = Standard valve clearance

Intake : 0.37 mm (0.015 in)

Exhaust : 0.40 mm (0.016 in)

- New valve lifter thickness (1) can be identified by stamp marks (2) on the reverse side (inside of cylindrical part).

Stamp mark	Valve lifter thickness
00	3.00 mm (0.1181 in)
02	3.02 mm (0.1189 in)
.	.
.	.
68	3.68 mm (0.1449 in)



- Valve lifter thickness settings: Thickness 3.00 - 3.68 mm (0.1181 - 0.1449 in) in 0.02 mm (0.0008 in) intervals and 35 types.

5. Install selected valve lifter.
6. Install camshaft. Refer to [EM-36, "Removal and Installation"](#).
7. Manually turn crankshaft a few turns.
8. Make sure that the valve clearance is within the standard using the reference value when engine is cold.
9. After restoring, make sure the valve clearance is within the range of standard values with the engine warmed up.


TIMING CHAIN

PFP:13028

Removal and Installation

EBS000OF0

SEC. 111•130•135



PBIC1444E

1. Cylinder head front cover
2. Camshaft sprocket (intake)
3. Camshaft sprocket (exhaust)
4. Chain tensioner
5. Slack guide
6. Front cover
7. Front oil seal
8. Crankshaft pulley
9. Timing chain
10. Tension guide
11. Dowel pin
12. Oil pump drive spacer
13. Crankshaft sprocket
14. O-ring

REMOVAL**Operation Description****M/T
models**

1. Remove engine and transaxle assembly from the vehicle. Refer to [EM-69, "Removal and Installation"](#) .
2. Separate engine from transaxle. Refer to [EM-69, "Removal and Installation"](#) .
3. Remove parts remaining in step 3 and proceed to step 5.

**A/T
models**

: Start from step 1 with the engine mounted in the vehicle.

NOTE:

The reason for doing work with the engine by itself for M/T models is stated below.


- It is necessary to remove the transaxle when removing and installing the oil pan (upper).
- For this reason, the entirety of the supporting engine mount disappears when removing and installing the front cover.

1. Remove RH front wheel and RH front fender protector.
2. Drain the engine oil.
3. Remove the following parts.
 - Drive belts and drive belt idler pulleys; Refer to [EM-12, "DRIVE BELTS"](#) .
 - Rocker cover; Refer to [EM-33, "ROCKER COVER"](#) .
 - Exhaust front tube; Refer to [EX-3, "EXHAUST SYSTEM"](#) .
 - Starter motor; Refer to [SC-39, "STARTING SYSTEM"](#) .
 - Oil pan (lower and upper) and oil strainer; Refer to [EM-24, "OIL PAN AND OIL STRAINER"](#) .
 - RH headlamp; Refer to [LT-6, "HEADLAMP -CONVENTIONAL TYPE-"](#) .
4. Using the following procedure, remove the RH engine mount stay and the RH engine mount brackets (upper and lower).
 - a. The engine should be immobilized using any one of the following methods.
 - Mount engine slingers and hook with hoist. Refer to [EM-69, "Removal and Installation"](#) .
 - Support the transaxle bottom with a jack stand, etc.

CAUTION:


Make sure the transaxle is not scratched while the bottom is being supported.

- b. Remove RH engine mount stay and RH engine mount bracket (upper and lower). Refer to [EM-69, "Removal and Installation"](#) .
5. Remove alternator. Refer to [SC-15, "CHARGING SYSTEM"](#) .
6. Remove cylinder head front cover. Refer to [EM-36, "CAMSHAFT"](#) .
7. Remove the cylinder head auxiliary bolts (1).




PBIC1335E

8. Set No. 1 cylinder at TDC on its compression stroke.
 - a. Turn the crankshaft pulley clockwise as seen from the engine front, and match up the crankshaft pulley TDC mating mark (no color) (2) with the timing indicator (1) on the front cover.



PBIC1305E

- b. Confirm mating marks (1) stamped on intake and exhaust sprockets are rotated as shown.
 - If there is no position mark in the figure, turn the crankshaft pulley once more to position them as in the figure.




PBIC1306E

9. Remove the crankshaft pulley in the following order.
 - a. Using the starter motor mounting hole, attach a ring gear stopper (special service tool) and secure the crankshaft.
 - You can also secure the crankshaft counterweight using hammer handle, etc., after removing the oil pan (upper). Make sure no foreign matter gets inside the engine.
 - b. Loosen crankshaft bolt and pull it out.

CAUTION:

Do not remove the mounting bolts as they will be used as a supporting point for the pulley puller.




PBIC1445E

- c. Place the crankshaft pulley puller (1) tab on the crank pulley hole, and pull the crankshaft pulley (2) through.

CAUTION:

Do not put the pulley tab on the crank pulley wide-diameter pulley, as this will damage the internal dampers.

10. Remove the idler pulley bracket assembly for drive belts from the front cover. Refer to [EM-12, "DRIVE BELTS"](#).




PBIC1338E

11. Remove the front cover in the following order.

- To give more freedom to the front cover position during installation and removal, pull out the oil pump drive spacer (2) over the front oil seal (1).
- Pull out straight, using long nosed pliers or two screwdrivers, etc.

CAUTION:

Be careful not to damage oil pump drive spacer surface.




b. Remove front cover carefully.

- Remove bolts A to C shown in the figure.

CAUTION:

- To prevent the front of the cylinder head gasket from getting bent or damaged, remove so that it comes apart cleanly from the front cover top and the gasket bottom.
- Replace the cylinder head gasket with a new one if it is damaged.




c. Remove O-ring from the cylinder block.

12. Remove the front cover dowel pins (1) from the cylinder block.

- After warming with an industrial drier (2), use locking pliers (3) to pull out the dowel pins.

NOTE:

This step is in preparation for installing the front cover. If the timing chain is to be removed, it can be done later.



13. Remove the front oil seal from the front cover.

- Insert a screwdriver behind the oil seal and pull up to remove.

14. Secure the intake camshaft sprocket in the most advanced position. Refer to [EM-36, "CAMSHAFT"](#).

NOTE:

The following steps are for removing the timing chain and other related parts.

15. Remove chain tensioner. Refer to [EM-36, "CAMSHAFT"](#).

16. Remove camshaft sprocket. Refer to [EM-36, "CAMSHAFT"](#).

NOTE:


No markings are needed between the camshaft sprocket and timing chain.

17. Remove timing chain, the timing chain slack guide, and the tension guide.

18. Remove the crankshaft sprocket.


INSPECTION AFTER REMOVAL

Make sure there are no noticeable cracks or wear on the timing chain, and replace if there are.

**INSTALLATION****CAUTION:**

- Completely remove liquid gasket attached to mounting surfaces using a scraper, and clean off with white gasoline.
- After installation, wipe off any extra liquid gasket.

1. Install the timing chain and related parts in the following steps.
 - See the figure for positions sprockets, timing chain (1), and installation of other parts.
 - Attach each sprocket with its mating mark towards the engine front.
- a. Install timing chain and crankshaft sprocket (2).
 - You can make sure the No. 1 cylinder is at the TDC of its compression stroke by checking if the crankshaft key is straight up.
 - Place the timing chain on the front of the camshaft to make sure it does not fall.
- b. Install timing chain slack guide (3) and the tension guide (4).
- c. Install camshaft sprockets. Refer to [EM-36, "CAMSHAFT"](#).
 - Align the mating marks on camshaft sprocket and timing chain here.




- d. Install chain tensioner. Refer to [EM-36, "CAMSHAFT"](#).
- e. Check again to make sure all the mating marks are in place.
- f. Temporarily install the oil pump drive spacer, the crankshaft pulley, and the crankshaft pulley bolt, and make it so that the crankshaft can be turned.
- g. Turn the crankshaft clockwise viewing from engine front. Place intake side camshaft in the most retarded position. Refer to [EM-36, "CAMSHAFT"](#).
- h. Turn the crankshaft a few more times clockwise and make sure nothing is wrong with it.
- i. Remove the parts installed in step f.

TIMING CHAIN

[CR]

2. Install front oil seal to front cover.


- Make sure the oil seal lettering is towards the engine front.
- Using suitable drift, press oil seal in until it is flush with end surface of mounting position.
- Do this without damaging the outer diameter of the oil seal.



PBIC1446E


3. Install the front cover with the following procedure:

- a. Install O-ring (1) to the cylinder block.
- b. Apply liquid gasket to the contact area between the bottom of the cylinder head gasket (2) and the cylinder block (two places in the figure) using a screwdriver.
Use Genuine Liquid Gasket or equivalent.



PBIC1342E

- c. Evenly apply the liquid gasket to the back of the front cover as per the position in the figure.
- d. Apply a thin, even layer of liquid gasket to the entire upper surface of the front cover.
Use Genuine Liquid Gasket or equivalent.




PBIC1447E

- e. With the inner rotor internal diameter part of the oil pump resting on the top of the crankshaft [with a space between the top of the front cover and the bottom of the cylinder head gasket (3)], bring the front cover (1) as close as possible to the cylinder block. (To the left in the figure)
- f. To make sure the front cover comes into contact with the cylinder head gasket (3) bottom and the cylinder block (2) front at the same time, lift it diagonally and set it in the mounting position. (To the right in the figure)

CAUTION:

- Be careful not to damage the cylinder head gasket (3).
- Attach using caution not to let the liquid gasket get cut off by getting attached to unnecessary parts.




PBIC1343E


TIMING CHAIN

[CR]

- g. Temporarily secure the front cover so it does not move using several bolts.
- h. Press fit dowel pins (1) to the cylinder block through the front cover.




- i. Temporarily tighten the front cover bolts.
 - A [Under head length: 25 mm (0.98 in)], B [Under head length: 40 mm (1.57 in)], C [Under head length: 50 mm (1.97 in)]
- j. Temporarily tighten the cylinder head auxiliary bolts.
- k. Tighten front cover bolts and the cylinder head auxiliary bolts to the specified torque.




4. Install oil pump drive spacer (1).
 - When installing, align with flat face of oil pump inner rotor.
 - If they are not aligned properly, turn the inner rotor with a screwdriver until they do.

CAUTION:

Be careful not to damage the oil seal lip.



5. Install the drive belt idler pulley bracket assembly. Refer to [EM-12, "DRIVE BELTS"](#) .
6. Install crankshaft pulley.
 - When installing, make sure the front oil seal lip does not fold back and the garter spring of oil seal lip does not fall.
 - Secure the crankshaft as in "REMOVAL" and tighten the bolts.
7. Install the cylinder head front cover.
 - Evenly apply the liquid gasket to the position shown in figure. Use Genuine Liquid Gasket or equivalent
8. Install RH engine mount bracket and RH engine mount stay. Refer to [EM-69, "Removal and Installation"](#) .
9. Reinstall removed parts in reverse order of removal.



INSPECTION AFTER INSTALLATION

- In order to allow liquid gasket to be cured, perform inspection at least 30 minutes after the last step in which parts sealed with liquid gasket are installed.
- With engine warmed up, check each part for engine oil leakage.

A

EM

C

D

E

F

G

H

I

J

K

L

M

OIL SEAL

PFP:12279



Removal and Installation of Valve Oil Seal**REMOVAL**

1. Remove camshaft. Refer to [EM-36, "CAMSHAFT"](#) .
2. Remove valve lifter. Refer to [EM-36, "CAMSHAFT"](#) .
3. Turn the crankshaft, put the cylinder to have the oil seal removed in the TDC position to prevent the valve from falling into the cylinder.


CAUTION:

When rotating the crankshaft, make sure the timing chain does not get caught in the front cover.

4. Using a valve spring compressor (special service tool), remove the valve collet, valve spring retainer, and valve spring.
5. Using a valve oil seal puller (special service tool), remove the valve oil seal.

**INSTALLATION**

1. Apply engine oil to the new valve oil seal joint and seal lip.
2. Using a valve oil seal drift (special service tool), press fit the valve oil seal to the height shown in the figure.
3. Reinstall removed parts in reverse order of removal.

**Removal and Installation of Front Oil Seal****REMOVAL**

1. Remove the following parts.
 - RH front fender protector
 - Drive belt; Refer to [EM-12, "DRIVE BELTS"](#) .
 - Crankshaft pulley; Refer to [EM-48, "TIMING CHAIN"](#) .
2. Using a screwdriver, remove the front oil seal.

CAUTION:

Be careful not to damage the front cover or the crankshaft.


EBS000F2

INSTALLATION


1. Apply engine oil to the new front oil seal joint and seal lip.
2. Using a suitable drift (1), press fit until the front end of front oil seal is level with the mounting surface.
 - Suitable drift (1) : outer diameter 50 mm (1.97 in), inner diameter 44 mm (1.73 in).

CAUTION:

- Be careful not to damage the front cover or the crank-shaft.
- Press in straight, making sure the oil seal does not curl or tilt.



- See the figure for the direction the front oil seal should be fitted.
3. Reinstall removed parts in reverse order of removal.

**Removal and Installation of Rear Oil Seal****REMOVAL**

1. Remove transaxle assembly.
 - M/T: Refer to [MT-7, "REMOVAL AND INSTALLATION"](#) .
 - A/T: Refer to [AT-430, "REMOVAL AND INSTALLATION"](#) .
2. Remove clutch cover and clutch disc. (M/T models) Refer to [CL-10, "CLUTCH DISC, CLUTCH COVER AND FLYWHEEL"](#) .
3. Remove flywheel (M/T models), drive plate and adopter (A/T models). Refer to [EM-73, "CYLINDER BLOCK"](#) .
4. Using a screwdriver, remove the rear oil seal.

CAUTION:


Be careful not to damage the mounting surface.

INSTALLATION

1. Using a suitable drift (1), press fit until the rear end of front oil seal is level with the mounting surface.
 - Suitable drift (1): outer diameter 102 mm (4.02 in), inner diameter 90 mm (3.54 in).

CAUTION:


- Do not touch the grease applied to the oil seal lip.
- Be careful not to damage the rear oil seal retainer or the crankshaft.
- Press in straight, making sure the oil seal does not curl or tilt.



OIL SEAL

[CR]

- Press rear oil seal (2) into rear oil seal retainer (3) so that it does not project from the end.



2. Reinstall removed parts in reverse order of removal.

CYLINDER HEAD

PFP:11041

On Vehicle Inspection

EBS000F4


COMPRESSION PRESSURE INSPECTION

1. Warm up engine thoroughly. Then, stop it.
2. Release fuel pressure with the following procedure.
 - a. Remove rear seat assembly.
 - b. Open the inspection hole cover.
 - c. Disconnect fuel level sensor unit, fuel filter, and fuel pump assembly connector, and start engine. Refer to [FL-4, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#).
 - d. After you stop the engine, crank it two or three times to consume the fuel in the pipes.

CAUTION:

After release the fuel pressure and until the compression pressure inspection, leave the harness connector off.

3. Remove ignition coil and spark plug from all the cylinders. Refer to [EM-27, "IGNITION COIL"](#) and [EM-28, "SPARK PLUG \(PLATINUM-TIPPED TYPE\)"](#).
4. Attach a engine tachometer (not required in use of CONSULT-II).
5. Install compression tester (1) with adapter onto spark plug hole.




PBIC1349E

- Use compression tester whose picking up end inserted to spark plug hole is smaller than 20 mm (0.79 in) in diameter. Otherwise, it may be caught by cylinder head during removal.

6. With accelerator pedal fully depressed, turn ignition switch to "START" for cranking. When the gauge pointer stabilizes, read the compression pressure and engine rpm. Perform these steps to check each cylinder.

[kPa (bar, kg/cm², psi)/350rpm]

Engine type	CR10DE	CR12DE, CR14DE
Standard	1,432 (14.32, 14.6, 208)	1,383 (13.83, 14.1, 201)
Minimum	1,236 (12.36, 12.6, 179)	1,187 (11.87, 12.1, 172)
Difference limit among cylinders	98 (0.98, 1.0, 14)	98 (0.98, 1.0, 14)



20 mm (0.79 in) dia.

Use compressor tester whose end (rubber portion) is less than 20 mm (0.79 in) dia. Otherwise, it may be caught by cylinder head during removal.

SEM387C

CAUTION:

Always use a fully charged battery to obtain specified engine speed.


- If the engine speed is out of specified range, check battery liquid for proper gravity. Check engine speed again with normal battery gravity.
- If compression pressure is below minimum value, check valve clearances and parts associated with combustion chamber (Valve, valve seat, piston, piston ring, cylinder bore, cylinder head, cylinder head gasket). After the checking, measure compression pressure again.
- If some cylinders have low compression pressure, pour small amount of engine oil into the spark plug hole of the cylinder to re-check it for compression.
- If the added engine oil improves the compression, the piston rings may be worn out or damaged. Check the piston rings and replace if necessary.

- If the compression pressure remains at low level despite the addition of engine oil, the valves may be malfunctioning. Check the valves for damage. Replace the valve or valve seat accordingly.
- If two adjacent cylinders have respectively low compression pressure and their compression remains low even after the addition of engine oil, the gasket is leaking. In such a case, replace the cylinder head gasket.

7. After inspection, install removed parts in reverse order of removal.

Removal and Installation

EBS0000F5



PBIC1448E

1. Cylinder head assembly
2. Cylinder head bolt
3. Washer
4. Cylinder head auxiliary bolt
5. Cylinder head auxiliary bolt
6. Gasket

REMOVAL

1. Release the fuel pressure. Refer to [EC-44, "FUEL PRESSURE RELEASE" \(WITH EURO-OBD\)](#), [EC-505, "FUEL PRESSURE RELEASE" \(WITHOUT EURO-OBD\)](#).
2. Drain engine coolant. Refer to [CO-8, "ENGINE COOLANT"](#).
3. Remove the following components and related parts.
 - RH front fender protector
 - Alternator and A/C compressor drive belt; Refer to [EM-12, "DRIVE BELTS"](#).
 - Air duct and air cleaner case assembly; Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#).
 - Intake manifold; Refer to [EM-20, "INTAKE MANIFOLD"](#).
 - Fuel injector and fuel tube assembly; Refer to [EM-30, "FUEL INJECTOR AND FUEL TUBE"](#).
 - Radiator upper hose and lower hose; Refer to [CO-11, "RADIATOR"](#).
 - Alternator and alternator bracket; Refer to [SC-15, "CHARGING SYSTEM"](#).
 - Exhaust manifold and three way catalyst assembly; Refer to [EM-22, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#).
 - Ignition coil; Refer to [EM-27, "IGNITION COIL"](#).
 - Rocker cover; Refer to [EM-33, "ROCKER COVER"](#).
 - Camshaft; Refer to [EM-36, "CAMSHAFT"](#).


CAUTION:

For the method for maintaining engine position, select the method which supports the bottom of the oil pan.

- Heated oxygen sensor harness bracket; Refer to [EM-22, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#).
- Water outlet, thermostat, engine coolant temperature sensor and heater pipe; Refer to [CO-23, "THERMOSTAT"](#).

- Water suction pipe mounting bolt; Refer to [CO-21, "WATER PUMP"](#) .

4. Loosen bolts in the reverse order shown in the figure and then remove the cylinder head assembly.
5. Remove cylinder head gasket.




INSPECTION AFTER REMOVAL

Cylinder Head Bolt Outer Diameter

- Cylinder head bolts are tightened by plastic zone tightening method. Whenever the size difference between d1 and d2 exceeds the limit, replace them with new one.


Limit (d1 - d2) : 0.12 mm (0.0047 in)

- If reduction of outer diameter appears in a position other than d2, use it as d2 point.



INSTALLATION

1. Evenly apply the liquid gasket to the position in the figure and then install the cylinder head gasket. Use Genuine Liquid Gasket or equivalent.



2. Attach the cylinder head assembly and then tighten bolts 1 to 10 in the order shown in the figure.

CAUTION:

For step c, loosen them in reverse of the order in the figure.


NOTE:

Bolts 11 to 13 should be tightened in step 3 after tightening bolts 1 to 10.

- a. Apply new engine oil to threads and seat surfaces of bolts.
- b. Tighten at 61.7 - 71.7 N·m (6.3 - 7.3 kg-m, 46 - 52 ft-lb).
- c. Loosen completely to 0 N·m (0 kg-m).
- d. Tighten at 22.5 - 32.5 N·m (2.3 - 3.3 kg-m, 17 - 23 ft-lb).
- e. Tighten with 90 - 95 degrees clockwise [Target: 90 degrees]. (Angle tightening)

CAUTION:


Check and confirm the tightening angle by using angle wrench (special service tool). Avoid judgment by visual inspection without the tool.




CYLINDER HEAD

[CR]

- Check tightening angle indicated on the angle wrench indicator plate.



3. Tighten auxiliary bolts (11 to 13) in the numerical order shown in the figure.




4. Reinstall removed parts in reverse order of removal.

Disassembly and Assembly

EBS000F6

SEC. 111•130•210•220



PBIC1451E

1. Spark plug	2. Valve collet	3. Valve spring retainer
4. Valve spring	5. Valve spring seat	6. Valve oil seal
7. Valve guide	8. Cylinder head	9. Valve seat (INT)

10. Valve (INT)
13. Spark plug tube

11. Valve (EXH)

12. Valve seat (EXH)


DISASSEMBLY

1. Remove spark plugs with a spark plug wrench.
2. Remove valve lifter.
 - Mark position on valve lifter for assembly.
3. Remove valve collet.
 - Compress the valve spring with a valve spring compressor (special service tool). Remove valve collet with a magnetic driver.

CAUTION:

When working, take care not to damage valve lifter holes.

4. Remove valve spring retainer and valve spring.
5. Push the valve stem toward the combustion chamber side and remove the valve.
 - Before removal, check valve guide clearance. Refer to [EM-65, "Valve Guide Clearance"](#).
 - Mark position on valve for assembly.
6. Remove valve oil seal.
 - Use valve oil seal puller (special service tool).
7. Remove valve spring seat.
8. When valve seat replacement is necessary, refer to [EM-66, "Replacement of Valve Seat"](#).
9. When valve guide replacement is necessary, refer to [EM-65, "Valve Guide Replacement"](#).
10. Remove spark plug tube, as necessary.
 - Using a pair of pliers, pull spark plug tube out of cylinder head.





CAUTION:

- Take care not to damage cylinder head.
- Once removed, a spark plug tube will be deformed and cannot be reused. Do not remove it unless absolutely necessary.

ASSEMBLY

1. Install valve guide. Refer to [EM-65, "Valve Guide Replacement"](#).
2. Install valve seat. Refer to [EM-66, "Replacement of Valve Seat"](#).
3. Install valve oil seal.
 - Using a valve oil seal drift (special service tool), install to the dimensions specified in the figure.
4. Install valve spring seat.
5. Install valve.
 - Valves of larger diameter are for intake side.
6. Install valve spring.
7. Install valve spring retainer.
8. Install valve collet.
 - Use a valve spring compressor (special service tool) to compress the valve spring, then install collet with a magnetic finger.



- After installing valve component parts, tap valve stem tip with a plastic hammer to assure a proper fit.

9. Install valve lifter.

- Install it in its original positions.


10. Install spark plug tube.

- Press-fit into cylinder head in the following order.

- Remove the old liquid gasket which has become attached to the cylinder head mounting hole.
- Apply the liquid gasket to the area around the spark plug tube press-fit.
- Use Genuine Liquid Gasket or equivalent.
- Using a drift, press-fit spark plug tube so that its height "H" is as specified in the figure.

Standard press-fit height "H"

: 41.0 - 42.0 mm (1.614 - 1.654 in)



CAUTION:

- Press-fit, making sure not to deform the spark plug tube.
- After press-fitting, wipe off liquid gasket protruding onto cylinder head upper face.

11. Install spark plug.

- Use a spark plug wrench.

INSPECTION AFTER DISASSEMBLY

Cylinder Head Distortion

1. Using a scraper, wipe off oil, scale, gasket, sealant, and carbon deposits from surface of cylinder head.


CAUTION:

Do not allow gasket fragments to enter oil or engine coolant passages.

2. Check flatness of the cylinder head lower surface. Measure distortion in six directions shown in figure, at several points in each direction.


Limit : 0.1 mm (0.004 in)

- if it exceeds the limit, replace the cylinder head.



Valve Dimensions

- Check dimensions of each valve. For dimensions, refer to [EM-95, "VALVE"](#).
- If dimensions are out of the standard, replace valve.




Valve Guide Clearance

Check valve guide clearance before removing the valve guide.

1. Make sure valve stem diameter is within the standard.
2. Push the valve out toward combustion chamber for approximately 15 mm (0.59 in). Measure runout while pushing the valve toward the dial gauge (1).
3. The half of the dial gauge reading is the valve guide clearance.

Standard


Intake : 0.020 - 0.053 mm (0.0008 - 0.0021 in)
Exhaust : 0.040 - 0.073 mm (0.0016 - 0.0029 in)




Valve Guide Replacement

When valve guide is removed, replace with oversized [0.2 mm (0.008 in)] valve guide.

1. To remove valve guide, heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil.



2. Drive out valve guide with a press [under a 20 kN (2 ton, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and suitable tool.




3. Ream cylinder head valve guide hole.

Valve guide hole diameter (for service parts):

Intake and exhaust


: 9.685 - 9.696 mm (0.3813 - 0.3817 in) dia.



CYLINDER HEAD

[CR]


- Heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil.



- Press valve guide from camshaft side to dimensions as in illustration.

CAUTION:

Cylinder head contains heat. When working, wear protective equipment to avoid getting burned.




- Using valve guide reamer, apply reamer finish to valve guide.

Standard


Intake and exhaust

: 5.500 - 5.518 mm (0.2165 - 0.2172 in) dia.



Valve Seat Contact

- After confirming that the dimensions of valve guides and valves are within specifications, perform this procedure.
- Apply prussian blue (or white lead) onto contacting surface of valve seat to check the condition of the valve contact on the surface.
- Check if the contact area band is continuous all around the circumference.
- If not, grind to adjust valve fitting and check again. If the contacting surface still has N.G conditions even after the re-check, replace valve seat.



Replacement of Valve Seat

When valve seat is removed, replace with oversized [0.5 mm (0.020 in)] valve seat.

- Bore out old seat until it collapses. Boring should not continue beyond the bottom face of the seat recess in cylinder head. Set the machine depth stop to ensure this.

CYLINDER HEAD

[CR]


2. Ream cylinder head recess diameter for service valve seat.

Oversize [0.5 mm (0.020 in)]:


Intake: 29.000 - 29.016 mm (1.1417 - 1.1424 in)

Exhaust: 24.000 - 24.016 mm (0.9449 - 0.9455 in)

- Be sure to ream in circles concentric to the valve guide center.
- This will enable valve seat to fit correctly.




3. Heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil.



4. Provide valve seats cooled well with dry ice. Force fit valve seat into cylinder head.

CAUTION:


- Avoid directly touching cold valve seats.
- Cylinder head contains heat. When working, wear protective equipment to avoid getting burned.



5. Using valve seat cutter set (commercial service tool) or valve seat grinder, finish the seat to the specified dimensions.

CAUTION:


When using valve seat cutter, firmly grip the cutter handle with both hands. Then, press on the contacting surface all around the circumference to cut in a single drive. Improper pressure on with the cutter or cutting many different times may result in stage valve seat.



Grind to obtain the dimensions indicated in figure.

Standard:

- D1 dia. : 25.4 mm (1.000 in)
- D2 dia. : 27.0 - 27.2 mm (1.062 - 1.070 in)
- D3 dia. : 28.7 - 28.9 mm (1.129 - 1.137 in)
- D4 dia. : 22.0 - 22.2 mm (0.866 - 0.874 in)
- D5 dia. : 23.7 - 23.9 mm (0.933 - 0.940 in)




6. Using compound, grind to adjust valve fitting.
7. Check again for normal contact.

Valve Spring Squareness

Set try square (1) along the side of valve spring and rotate the spring. Measure the maximum clearance between the top face of spring and try square (1).

Limit : 1.6 mm (0.063 in)

- if exceeds the limit, replace the valve spring.




Valve Spring Dimensions and Valve Spring Pressure Load

- Check valve spring pressure load at specified spring height.

Standard

- Free height : 53.3 mm (2.098 in)**
- Installation height : 32.82 mm (1.2921 in)**
- Installation load : 149 - 165 N (15.2 - 16.8 kg, 33.5 - 37 lb)**
- Height during valve open : 24.73 mm (0.9736 in)**
- Load with valve open : 228 - 250 N (23.3 - 25.5 kg, 51.3 - 56.2 lb)**




- If the dimensions exceed the standard, replace the valve spring.

ENGINE ASSEMBLY

PFP:10001

Removal and Installation

EBS00007



1. LH engine mount insulator
2. LH engine mount bracket (vehicle side)
3. LH engine mount bracket (transaxle side)
4. RH engine mount stay
(The shape may not be the same as figure)
5. RH engine mount insulator
6. RH engine mount bracket (upper)
7. RH engine mount bracket (lower)
8. Rear engine mount bracket
9. Rear torque rod

WARNING:

- Situate vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.

CAUTION:

- Always be careful to work safely, avoid forceful or uninstructed operations.
- Do not start working until exhaust system and engine coolant are cool enough.
- If items or work required are not covered by the engine main body section, refer to the applicable sections.
- Always use the support point specified for lifting.
- Use either 2-pole lift type or separate type lift as best you can. If board-on type is used for unavoidable reasons, support at the rear axle jacking point with transmission jack or similar tool before starting work, in preparation for the backward shift of center of gravity.
- For supporting points for lifting and jacking point at rear axle, refer to [GI-38, "Garage Jack and Safety Stand"](#).

REMOVAL

Description of work

Remove engine and transaxle assembly from vehicle, and separate engine and transaxle.

Preparation

1. When engine can be hoisted, remove engine hood.
2. Release fuel pressure. Refer to [EC-44, "FUEL PRESSURE RELEASE"](#) (WITH EURO-OBD), [EC-505, "FUEL PRESSURE RELEASE"](#) (WITHOUT EURO-OBD).
3. Drain engine coolant. Refer to [CO-8, "ENGINE COOLANT"](#) .
4. Remove the following parts.
 - RH and LH front wheel
 - RH and LH front fender protector
 - Exhaust front tube; Refer to [EX-3, "EXHAUST SYSTEM"](#) .
 - Drive belt; Refer to [EM-12, "DRIVE BELTS"](#) .
 - Air duct; Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#) .
 - Battery
 - Radiator; Refer to [CO-11, "RADIATOR"](#) .


Engine room LH

5. Disconnect the harness connectors and terminals from the following parts.

NOTE:

Figure shows A/T models. The position of the ground wire on the transaxle side is different for M/T models.

- Remove the ECM (1) from the bracket and disconnect the two harness connectors.



PBIC1356E

CAUTION:

Avoid impacts to ECM.

- Disconnect the intermediate connector (2) for the main harness between the vehicle and the engine room below the ECM.
- Disconnect the harness connectors on the battery positive terminal (3).
- Disconnect the ground wire on the transaxle (4) side.

6. Disconnect heater hose. Plug the hose immediately to prevent engine coolant from draining.
7. Disconnect the shift cable and the control cable (M/T models) or control cable (A/T models) from the transaxle.
 - M/T: Refer to [MT-12, "CONTROL LINKAGE"](#) .
 - A/T: Refer to [AT-418, "A/T SHIFT LOCK SYSTEM"](#) .
8. Disconnect the clutch tube from the transaxle side and temporarily fasten to vehicle. (M/T models)
 - Install the plug to prevent the clutch fluid from leaking.
9. Remove the crankshaft position sensor (POS) from the transaxle.

CAUTION:

Handle it carefully, avoid any chance of impact caused by dropping.

Engine room front and RH

10. Remove the ground wire between the alternator bracket and the vehicle.
11. Remove RH engine mount stay, alternator bracket, and alternator.
12. Remove A/C compressor from engine with piping connected, and temporarily install it to vehicle with rope to avoid putting stress on air conditioner pipes.
13. Remove fuel tube protector. Refer to [EM-30, "FUEL INJECTOR AND FUEL TUBE"](#) .
14. Disconnect fuel hose. Plug the hose immediately to prevent fuel from draining.


Vehicle underbody

15. Remove the ABS wheel sensor from the steering knuckle.

16. Remove brake caliper from steering knuckle. Temporarily fix on vehicle side with rope or so to avoid putting stress on brake hose. Refer to [BR-21, "FRONT DISC BRAKE"](#).
17. Remove RH and LH drive shafts. Refer to [FAX-10, "FRONT DRIVE SHAFT"](#).
18. Remove rear torque rod (1).

NOTE:

Figure shows A/T models. The shape of the bracket on the transaxle side is different for M/T models.

**Removal**


19. Install engine slinger to cylinder head front left side (1) and rear right side (2) and support the engine position with a hoist.

NOTE:

Front side and rear side engine slinger are common parts.

 : 16.6 - 23.5 N·m (1.7 - 2.3 kg·m, 13 - 17 in)


- For front side, remove harness bracket under fuel tube protector and mount by using harness bracket mounting hole. Refer to [EM-30, "FUEL INJECTOR AND FUEL TUBE"](#).




20. Lift to a height sufficient to allow easy work, support the bottom of the engine with either a manual lift table caddy (commercial service tool) or two suitable jacks, and adjust the tension of the hoist.

CAUTION:

- Put a piece of wood or something similar as the supporting surface, secure a completely stable condition.
- Make sure the hanging chain or hanging hook does not come into contact with the A/C piping or the vehicle (cowl top). Also make sure they do not get in the way by moving while the work is being done.



21. Remove the RH engine mount bracket (upper) (1) mounting bolts (2).
22. Remove the LH engine mount bolt-securing nut (3).



23. Carefully lower the manual lift table caddy or suitable jack, (or carefully raise the lift), and remove the engine and transaxle assembly from the vehicle.
 - If you are going to lower the engine side, do this in tandem with the hoist.

CAUTION:

- This should be done making sure it does not come in contact with the vehicle.
- Check that all connection points have been disconnected.

- Make sure the hanging chain or hanging hook does not come into contact with the A/C piping or the vehicle (cowl top).
- During engine and transaxle assembly removal, always be careful to prevent the vehicle from falling off the lift due to changes in the center of gravity.
- If necessary, support the rear side of the vehicle with jack to prevent it from falling off.

Separation Work

- On level ground, separate engine and transaxle with the following procedure:

CAUTION:

During the operation, securely support the engine by placing a piece of wood under the engine oil pan, transaxle oil pan, and suspension member, and suspend the engine slingers by hoist.

24. Remove the starter motor. Refer to [SC-39, "STARTING SYSTEM"](#) .

25. Separate the engine and the transaxle.

- M/T: Refer to [MT-7, "REMOVAL AND INSTALLATION"](#) .
- A/T: Refer to [AT-430, "REMOVAL AND INSTALLATION"](#) .

INSTALLATION

Install in the reverse order of removal while being careful of the following.

- Do not allow the engine mount insulator to be damaged and be careful no oil gets on it.
- For a part with a specified installation orientation, refer to component figure in [EM-69, "Removal and Installation"](#) .
- Make sure all mount insulators are seated properly, then tighten nuts and bolts.

INSPECTION AFTER INSTALLATION

- Before starting engine, check the levels of engine coolant, lubrications and working oils. If less than required quantity, fill to the specified level.
- Use procedure below to check for fuel leakage.
 - Turn ignition switch ON (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
 - Start engine. With engine speed increased, check again for fuel leakage at connection points.
 - Run engine to check for unusual noise and vibration.
- Warm up engine thoroughly to make sure there is no leakage of engine coolant, lubricants, working oil, fuel and exhaust gas.
- Bleed air from passages in pipes and tubes of applicable lines, such as in cooling system.
- After cooling down engine, again check amounts of engine coolant, lubricants, oil, and fluid. Refill to specified level, if necessary.

CYLINDER BLOCK

[CR]


CYLINDER BLOCK

PFP:11010

Disassembly and Assembly

EBS000GH

SEC. 110•120•220•226



1. Rear oil seal	2. Rear oil seal retainer	3. Knock sensor
4. Cylinder block	5. Oil level gauge guide	6. Top ring
7. Second ring	8. Oil ring	9. Piston
10. Piston pin	11. Connecting rod	12. Connecting rod bearing
13. Thrust bearing	14. Main bearing	15. Crankshaft
16. Key	17. Connecting rod cap	18. Connecting rod nut
19. Main bearing cap bolt	20. Main bearing cap	21. Rear plate
22. Flywheel (M/T models)	23. Adapter (A/T models)	24. Drive plate (A/T models)
25. O-ring	26. Crankshaft position sensor (POS)	

DISASSEMBLY

1. Remove engine and transaxle assembly from the vehicle and separate transaxle from the vehicle. Refer to [EM-69, "Removal and Installation"](#) .
2. Install engine to engine stand in the following procedure.


NOTE:

We will use as an example the engine stand (commercial service tool) specified to support the cylinder block rear (transaxle mounting surface).

- a. Remove clutch cover and clutch disc. (M/T models) Refer to [CL-10, "CLUTCH DISC, CLUTCH COVER AND FLYWHEEL"](#) .
- b. Remove the flywheel (M/T models), the drive plate and the adapter (A/T models).
 - Using a ring gear stopper (special service tool), secure the crankshaft, loosen the bolts diagonally and remove.

NOTE:

Figure shows the drive plate.




CAUTION:

Make sure signal plate (1) are not damaged or deformed.

NOTE:


Figure shows the drive plate.

- c. Remove rear plate.



- d. Lift engine using a hoist and mount it on an engine stand (1).

- For installation of engine slingers, refer to [EM-69, "Removal and Installation"](#) .



3. Drain engine oil and engine coolant from engine.
4. Remove following components and related parts.
 - Air cleaner case assembly; Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#) .
 - Intake manifold; Refer to [EM-20, "INTAKE MANIFOLD"](#) .
 - Fuel injector and fuel tube assembly; Refer to [EM-30, "FUEL INJECTOR AND FUEL TUBE"](#) .
 - Ignition coil; Refer to [EM-27, "IGNITION COIL"](#) .
 - Rocker cover; Refer to [EM-33, "ROCKER COVER"](#) .
 - Oil pan and oil strainer; Refer to [EM-24, "OIL PAN AND OIL STRAINER"](#) .
 - Front cover and timing chain; Refer to [EM-48, "TIMING CHAIN"](#) .
 - Camshaft; Refer to [EM-36, "CAMSHAFT"](#) .
 - Cylinder head assembly; Refer to [EM-59, "CYLINDER HEAD"](#) .
 - Oil filter; Refer to [LU-6, "OIL FILTER"](#) .
 - Oil pressure switch; Refer to [LU-4, "OIL PRESSURE CHECK"](#) .
5. Remove knock sensor.

CAUTION:

Avoid impact such as a dropping.

6. Remove oil level gauge guide, if necessary.

CAUTION:


Once removed, it cannot be reused. Do not remove it unless absolutely necessary.

7. Remove rear oil seal retainer.
 - Remove by inserting a screwdriver between main bearing cap and rear oil seal retainer.
8. Remove rear oil seal from rear oil seal retainer.
 - Remove by driving it out using a screwdriver.

CAUTION:

Make sure the rear oil seal retainer is not damaged.

9. Remove piston and connecting rod assembly.
 - Before removing connecting rod, check connecting rod side clearance. Refer to [EM-85, "CONNECTING ROD SIDE CLEARANCE"](#) .
- a. Position the crankshaft pin corresponding to the connecting rod to be removal onto the bottom dead center.
- b. Remove connecting rod cap.
- c. Push the piston and connecting rod assembly out toward cylinder head side with handle of a hammer.
10. Remove connecting rod bearings from connecting rod and connecting rod cap.




EMG0025D

CAUTION:

When removing, check each part, and arrange them in a way that prevents mixing them up.

11. Remove piston rings from piston.
 - Use piston ring expander (1).
- CAUTION:**
 - Be careful not to damage piston.
 - Do not expand piston rings excessively. It can damage piston rings.
 - Before removal of piston ring, check piston ring side clearance. Refer to [EM-85, "PISTON RING SIDE CLEARANCE"](#) .



PBIC1362E

CYLINDER BLOCK

[CR]

12. Remove piston from connecting rod.


- Use a piston pin press stand and a press to remove the piston pin.

NOTE:

The joint between the connecting rod and the piston pin is a press fit.

CAUTION:

Be careful not to damage the piston and connecting rod.



PBIC1574E

13. Remove the main bearing cap in the following order.


a. Loosen and remove bolts in several steps in reverse of the numerical order shown in figure.

- Before loosening main bearing cap bolts, measure the crankshaft side clearance. Refer to [EM-84, "CRANKSHAFT SIDE CLEARANCE"](#).

b. Tapping lightly with a plastic hammer, remove the main bearing cap.

14. Remove crankshaft.

15. Remove main bearing and thrust bearing from cylinder block and main bearing cap.



PBIC1457E

CAUTION:

Identify installation position of each part. Arrange removed parts so as not to mix them up.

ASSEMBLY

1. Thoroughly clean engine coolant and oil passages in cylinder block, as well as inside of crank case and cylinder bores, with compressed air.


2. If the plug (1) in figure is removed, apply liquid gasket to the plug screw.

Use Genuine Liquid Gasket or equivalent.

- Do not reuse washer. Replace it with a new washer.

- Tighten to the specified torque.

: 58.8 - 68.6 N·m (6.0 - 6.9 kg·m, 44 - 50 ft-lb)




PBIC1363E

3. Install main bearings and thrust bearings.

a. Clean bearing mounting surfaces on cylinder block and main bearing cap to remove any foreign material, dust, and oil on them.

b. Install thrust bearings (1) on both sides of cylinder block No. 3 housing (2).

- Install thrust bearing with its oil groove (3) facing crankshaft arm side (outer side).




PBIC1364E

CYLINDER BLOCK

[CR]

c. Install main bearing (1) in paying attention to the direction.

- Install main bearing with oil groove and oil hole (2) to cylinder block, and the one without oil groove and oil hole to main bearing cap (5).
- Before installing the main bearing, lubricate bearing surface (inside) with new engine oil. Do not apply engine oil to back surface, but thoroughly clean it.
- When installing, align the bearing stopper (3) to the notch (4).
- Make sure that oil holes in cylinder block and main bearing are aligned.



4. Install crankshaft to cylinder block.


- Rotate crankshaft by hand and make sure it turns smoothly.

5. Install main bearing cap.

- Install main bearing cap with its front mark (1) facing front of engine.


NOTE:

Since it is machined together with the cylinder block, it cannot be replaced on its own.



6. Tighten main bearing cap bolts in numerical order shown in figure with the following steps.

- Lubricate threads and seat surface of each bolt with new engine oil.
- Tighten it to 24.5 - 30.3 N·m (2.5 - 3.0 kg-m, 18 - 22 ft-lb).
- Tighten with 95 - 100 degrees clockwise [Target: 95 degrees].(Angle tightening)




- Use an angle wrench (special service tool) to check tightening angle.

CAUTION:

Check tightening angle with an angle wrench. Do not visually check the tightening angle.

- After tightening main bearing cap bolts, rotate crankshaft by hand and make sure that it turns smoothly.
- Check crankshaft side clearance. Refer to [EM-84, "CRANK-SHAFT SIDE CLEARANCE"](#).




7. Install the piston onto the connecting rod in the following procedure:

CYLINDER BLOCK

[CR]

a. Set so that the piston front mark (1) on the piston head and the connecting rod cylinder number (2) engraving are in the position shown in figure.




b. Press fit the piston pin using the piston pin press stand (special service tool).

NOTE:

The joint between the connecting rod and the piston pin is a press fit.


- After finishing work, make sure the piston moves freely.




8. Install piston rings with piston ring expander as shown in the figure.

CAUTION:

- Be careful not to damage piston.
- Make sure the piston ring does not spread out too much and break.




- Against the piston front mark (1), position end gaps of each piston ring as shown in figure.
- Install top ring and second ring with stamp mark side facing up.



9. Install connecting rod bearing to connecting rod and connecting rod cap.

- When installing connecting rod bearing, lubricate bearing surface (inside) with new engine oil. Do not apply engine oil to back surface, but thoroughly clean it.
- Install connecting rod bearing by aligning the stopper protrusion (1) with notch (2) on connecting rod.




10. Install piston and connecting rod assembly to crankshaft.

- Position the crankshaft pin corresponding to the connecting rod to be removal onto the bottom dead center.
- Apply enough engine oil to cylinder bore, piston and crankshaft pin.
- Install connecting rod to cylinder position corresponding to cylinder No. stamped on it.
- Using a piston ring compressor (special service tool) (1), install piston so that piston grade number on piston head faces toward engine front.

CAUTION:


Be careful not to damage the cylinder wall and crankshaft pin, resulting from an interference of the connecting rod big end.



PBIC1370E

11. Install connecting rod cap.

- Be sure that cylinder No. (1) on connecting rod and connecting rod cap match.




PBIC1371E

12. Tighten connecting rod nuts in following steps.

- a. Lubricate threads and seat surface of connecting rod nuts and bolts with new engine oil.
- b. Tighten at 13.7 - 15.7 N·m (1.4 - 1.6 kg·m, 10.1 - 11.5 ft-lb).
- c. Tighten with 45 - 50 degrees clockwise [Target: 45 degrees]. (Angle tightening)

CAUTION:

Check tightening angle with an angle wrench (special service tool). Do not visually check the tightening angle.




PBIC1459E

- After the nuts were tightened, rotate crankshaft by hand and make sure that it turns smoothly.
- Check connecting rod side clearance. Refer to [EM-85, "CONNECTING ROD SIDE CLEARANCE"](#).

13. Install rear oil seal.

- Make sure the area surrounding the oil seal is not damaged, and use an oil seal drift to press fit.
- Press fit until the end of rear oil seal is level with the edges of the retainer.




PBIC1460E

CYLINDER BLOCK

[CR]

14. Install rear oil seal retainer.

- Evenly apply the liquid gasket to the position shown in figure. Use Genuine Liquid Gasket or equivalent.
- Install so that it matches up with the dowel pin on the cylinder block side.




15. Install oil level gauge guide (1).

- Press fit the oil level gauge guide (1) into the cylinder block with the assembly reference surface on the plate set as shown in the figure.
- Apply sealant to the press fit areas.

CAUTION:

Replace used oil level gauges with new ones.




16. Install knock sensor.

- Install connector so that it is positioned towards the engine front.

CAUTION:

- Handle it carefully to avoid impact. If any impact is applied, replace it with new one.
- Confirm no foreign material adhere to cylinder block and knock sensor mounting surfaces.
- Be sure to use specified bolts.
- Do not hold connector when tightening bolts.
- Make sure installed sensor connector is away from contact with other parts.



17. For the following, install the parts disassembled in step 4 in the reverse order.

18. Secure the position of the engine with the hoist, remove the bolts, and lower from the engine stand.

19. Install rear plate.

CYLINDER BLOCK

[CR]

20. Install the flywheel (M/T models) (1), the adapter (A/T models) (2), and the drive plate (A/T models) (3).


- Install so that signal plate (4) is towards the back of the engine.
- Install by aligning the dowel pin hole (6) with the dowel pin (5) on the back of the crankshaft.

NOTE:


Figure shows A/T models.

CAUTION:

Make sure signal plate (4) are not damaged or deformed.



- Using a ring gear stopper (special service tool), secure the crankshaft, and tighten the bolts diagonally.



21. Reinstall removed parts remained in reverse order of removal.

How to Select Piston and Bearing

DESCRIPTION

EBS000GI


Selection points	Selection parts	Selection items	Selection methods
Between cylinder block and crankshaft	Main bearing	Main bearing grade (Bearing thickness)	Determined by cylinder block bearing housing grade (inner diameter of housing) and crankshaft journal grade (outer diameter of journal).
Between cylinder block and piston	Piston and piston pin assembly Note: Piston and piston pin are a set. They make up one part as an assembly.	Piston grade (Piston outer diameter)	Piston grade = cylinder bore grade (inner diameter of bore)

- The identification grade stamped on each part is the grade for the dimension measured in new condition. This grade cannot apply to reused parts.
- For reused or repaired parts, measure the dimension accurately. Determine the grade by comparing the measurement with the values of each selection table.
- For details of the measurement method of each part, the reuse standards and the selection method of the selective fitting parts, refer to the text.

HOW TO SELECT PISTON


When New Cylinder Block is Used

- Check cylinder bore grade (1, 2, or 3) on cylinder block bottom rear surface and select piston of the same grade.



NOTE:

The piston head shape varies from engine to engine, as do their positions shown in figure.



When Cylinder Block is Reused

1. Measure cylinder bore inner diameter.
2. Determine the bore grade by comparing the measurement with the values under the cylinder bore inner diameter of the "Piston Selection Table".
3. Select the piston of the same grade.

CYLINDER BLOCK

[CR]

Piston selection Table

CR10DE,CR12DE

Unit: mm (in)

Grade	1	2	3
Inner diameter of cylinder bore	71.000 - 71.010 (2.7953 - 2.7957)	71.010 - 71.020 (2.7957 - 2.7961)	71.020 - 71.030 (2.7961 - 2.7965)
Outer diameter of piston	70.980 - 70.990 (2.7945 - 2.7949)	70.990 - 71.000 (2.7949 - 2.7953)	71.000 - 71.010 (2.7953 - 2.7957)

CR14DE


Unit: mm (in)

Grade	1	2	3
Inner diameter of cylinder bore	73.000 - 73.010 (2.8740 - 2.8744)	73.010 - 73.020 (2.8744 - 2.8748)	73.020 - 73.030 (2.8748 - 2.8752)
Outer diameter of piston	72.980 - 72.990 (2.8732 - 2.8736)	72.990 - 73.000 (2.8736 - 2.8740)	73.000 - 73.010 (2.8740 - 2.8744)


HOW TO SELECT MAIN BEARING

When New Cylinder Block and Crankshaft are Used

1. "Main Bearing Selection Table" rows correspond to bearing housing grade (0, 1, 2, or 3) on cylinder block bottom rear surface.



2. Apply journal diameter grade (0, 1, 2, or 3) stamped on crankshaft front side to column in "Main Bearing Selection Table".
3. Select main bearing (STD 1 to 7) at the point where selected row and column meet in the following selection table.



When Cylinder Block and Crankshaft are Reused

1. Measure inner diameter of cylinder block main bearing housing and outer diameter of crankshaft journal.
2. Find measured dimension in "Cylinder block bearing housing inner diameter" row of "Main Bearing Selection Table".
3. Find the measured dimension in "Crankshaft main journal diameter" column in the following selection table.
4. Select main bearing (STD 1 to 7) at the point where selected row and column meet in the following selection table.

CYLINDER BLOCK

[CR]

Main bearing Selection Table

Units: mm (in)

Cylinder block main bearing housing inner diameter	-	49.004/49.000 (1.9293/1.9291)	49.008/49.004 (1.9294/1.9293)	49.012/49.008 (1.9296/1.9294)	49.016/49.012 (1.9298/1.9296)	
Crankshaft journal diameter	Grade (stamped)	-	0	1	2	3
44.970/44.966 (1.7705/1.7703)	0	<ul style="list-style-type: none"> ● Bearing grade No. ● Bearing thickness ● Identification color 	STD1 2.002/2.006 (0.0788/0.0790) Red	STD 2 2.004/2.008 (0.0789/0.0791) Green	STD 3 2.006/2.010 (0.0790/0.0791) Yellow	STD 4 2.008/2.012 (0.0791/0.0792) Blue
44.966/44.962 (1.7703/1.7702)	1	<ul style="list-style-type: none"> ● Bearing grade No. ● Bearing thickness ● Identification color 	STD 2 2.004/2.008 (0.0789/0.0791) Green	STD 3 2.006/2.010 (0.0790/0.0791) Yellow	STD 4 2.008/2.012 (0.0791/0.0792) Blue	STD 5 2.010/2.014 (0.0791/0.0793) Pink
44.962/44.958 (1.7702/1.7700)	2	<ul style="list-style-type: none"> ● Bearing grade No. ● Bearing thickness ● Identification color 	STD 3 2.006/2.010 (0.0790/0.0791) Yellow	STD 4 2.008/2.012 (0.0791/0.0792) Blue	STD 5 2.010/2.014 (0.0791/0.0793) Pink	STD 6 2.012/2.016 (0.0792/0.0794) White
44.958/44.954 (1.7700/1.7698)	3	<ul style="list-style-type: none"> ● Bearing grade No. ● Bearing thickness ● Identification color 	STD 4 2.008/2.012 (0.0791/0.0792) Blue	STD 5 2.010/2.014 (0.0791/0.0793) Pink	STD 6 2.012/2.016 (0.0792/0.0794) White	STD 7 2.014/2.018 (0.0793/0.0794) Blue/yellow

Undersize Bearing Usage Guide

- If specified oil clearance cannot be obtained by standard size main bearing, use undersize (US) bearing.
- When using undersize bearing, install it, measure bearing inner diameter, and grind journal to obtain specified oil clearance.


Bearing undersize table

Unit: mm (in)

Size	Thickness
US 0.25 (0.0098)	2.123 - 2.131 (0.836 - 0.839)

CAUTION:

Keep fillet R when grinding crankshaft journal (1) in order to use undersize bearing (All journals).



EBS000GJ

Inspection After Disassembly


CRANKSHAFT SIDE CLEARANCE

- Using a dial gauge (1), measure the clearance between the thrust bearings and the crankshaft arm when the crankshaft is moved fully forward or backward.

Standard : 0.060 - 0.260 mm (0.0024 - 0.0102 in)

Limit : 0.3 mm (0.012 in)

- If the measured value exceeds the limit, replace the thrust bearings, and measure again. If it still exceeds the limit, replace the crankshaft also.



PBIC1376E


CONNECTING ROD SIDE CLEARANCE

- Measure side clearance between connecting rod and crankshaft arm with feeler gauge (1).

Standard : 0.050 - 0.420 mm (0.0020 - 0.0165 in)


Repair limit : 0.5 mm (0.0197 in)

- If the measured value exceeds the limit, replace the connecting rod, and measure again. If it still exceeds the limit, replace the crankshaft also.

**PISTON AND PISTON PIN CLEARANCE****Inner Diameter of Piston Pin**


- Measure the inner diameter of piston pin bore with an inside micrometer (1).

Standard : 18.008 - 18.012 mm (0.7090 - 0.7091 in)

**Outer Diameter of Piston Pin**

- Using a micrometer (1), measure piston pin outer diameter.

Standard : 17.996 - 18.000 mm (0.7085 - 0.7087 in)

**Piston and Piston pin Clearance**


(Piston pin clearance) = (Piston pin bore diameter) - (Outer diameter of piston pin)

Standard : 0.008 - 0.016 mm (0.0003 - 0.0006 in)

- If clearance exceeds the standard, replace piston and piston pin assembly.
- When replacing piston and piston pin assembly, refer to [EM-82, "HOW TO SELECT PISTON"](#)

PISTON RING SIDE CLEARANCE

- Measure side clearance of piston ring and piston ring groove with feeler gauge (1).



Standard:

Top ring : 0.040 - 0.080 mm (0.0016 - 0.0031 in)
 2nd ring : 0.025 - 0.070 mm (0.0010 - 0.0028 in)
 Oil ring : 0.030 - 0.140 mm (0.0021 - 0.0055 in)

Limit:

Top ring : 0.11 mm (0.0043 in)
 2nd ring : 0.1 mm (0.0039 in)

- If out of specification, replace piston and/or piston ring assembly.

PISTON RING END GAP


- Check if inner diameter of cylinder bore is within specification.
 Refer to [EM-88, "PISTON TO CYLINDER BORE CLEARANCE"](#)
- Insert piston ring (1) until middle of cylinder with piston (2), and measure gap.

Standard:

Top ring : 0.18 - 0.33 mm (0.0071 - 0.0130 in)
 2nd ring : 0.50 - 0.65 mm (0.0197 - 0.0256 in)
 Oil ring : 0.20 - 0.70 mm (0.0079 - 0.0276 in)

Limit:

Top ring : 0.57 mm (0.0224 in)
 2nd ring : 0.85 mm (0.0335 in)
 Oil ring : 0.96 mm (0.0378 in)



- If out of specification, replace piston ring. If gap still exceeds the limit even with a new ring, re-bore cylinder and use oversized piston and piston ring.

CONNECTING ROD BEND AND TORSION


- Check connecting rod bend and torsion with a connecting rod aligner.

Bend:


Limit : 0.15 mm (0.0059 in) per 100 mm (3.94 in) length

Torsion:

Limit : 0.30 mm (0.0118 in) per 100 mm (3.94 in) length



- If it exceeds the limit, replace connecting rod assembly.




CONNECTING ROD BEARING HOUSING DIAMETER (BIG END)

- Install the connecting rod cap without the connecting rod bearing installed. After tightening the connecting rod bolt to the specified torque, measure the connecting rod big end inner diameter using an inside micrometer (1). Refer to [EM-76, "ASSEMBLY"](#) for the tightening procedure.


Standard : 43.000 - 43.013 mm (1.6929 - 1.6934 in) dia.

- If it exceeds the standard, replace the connecting rod.

**CONNECTING ROD BUSHING OIL CLEARANCE DIAMETER (SMALL END)****Inner Diameter of Connecting Rod Bushing (Small End)**


- Using an inside micrometer (1), measure inner diameter of bushing.

Standard : 17.962 - 17.978 mm (0.7072 - 0.7078 in) dia.

**Outer Diameter of Piston Pin**

- Using a micrometer (1), measure piston pin outer diameter.

Standard : 17.996 - 18.000 mm (0.7996 - 0.7087 in) dia.

**Connecting Rod Bushing Oil Clearance (Small End)**

(Connecting rod small end oil clearance) = (Inner diameter of connecting rod small end) - (Outer diameter of piston pin)

Standard : -0.018 - -0.038 mm (-0.0007 - -0.0015 in)

- If the measured value exceeds the standard, replace the connecting rod assembly and/or piston and piston pin assembly.
- If replacing the piston and piston pin assembly, refer to [EM-82, "HOW TO SELECT PISTON"](#).

CYLINDER BLOCK DISTORTION

- Using a scraper, remove gasket on the cylinder block surface, and also remove oil, scale, carbon, or other contamination.


CAUTION:

Be careful not to allow gasket flakes to enter the oil or coolant passages.

- Measure the distortion on the block upper face at some different points in 6 directions.

Limit : 0.1 mm (0.004 in)

- If out of the distortion limit, replace the cylinder block.

**INNER DIAMETER OF MAIN BEARING HOUSING**


- Install the main bearing cap with the main bearings removed, and tighten the mounting bolts to the specified torque. Refer to [EM-76, "ASSEMBLY"](#) for the tightening procedure.
- Using a bore gauge (1), measure the inner diameter of the main bearing housing.

Standard : 49.000 - 49.016 mm (1.9291 - 1.9298 in) dia.


- If out of specification, replace cylinder block and main bearing cap as an assembly.

NOTE:

Cylinder block cannot be replaced as a single part because it is machined together with main bearing cap.

**PISTON TO CYLINDER BORE CLEARANCE****Inner Diameter of Cylinder Bore**

- Using a bore gauge (1), measure cylinder bore for wear, out-of-round and taper at 6 different points on each cylinder. (X and Y directions at A, B and C) (Y is in longitudinal direction of engine)

**Standard inner diameter:**

CR10DE, : 71.000 - 71.030 mm

CR12DE (2.7953 - 2.7965 in) dia.

**CR14DE : 73.000 - 73.030 mm
(2.8740 - 2.8744 in) dia.**

Wear limit:


0.2 mm (0.008 in)

Out-of-round (Difference between X and Y):

0.015 mm (0.0006 in)

Taper limit (Difference between A and C):

0.01 mm (0.0004 in)



- If the measured value exceeds the limit, or if there are scratches and/or seizure on the cylinder inner wall, hone or rebore the inner wall.

- An oversize piston is provided. When using an oversize piston, re bore the cylinder so that the clearance of the piston-to-cylinder bore satisfies the standard.
- When using an oversize piston, use it for all cylinders with oversize piston rings.

Oversize (OS) : 0.2 mm (0.008 in)

Outer Diameter of piston

- Measure piston skirt outer diameter using micrometer (1).

Measurement point (Distance from the top)

CR10DE : 37.3 mm (1.469 in)

CR12DE : 34.3 mm (1.350 in)


CR14DE : 32.3 mm (1.272 in)

Standard

CR10DE : 70.980 - 71.010 mm (2.7945 - 2.7949 in) dia.

CR12DE : 70.980 - 71.010 mm (2.7949 - 2.7953 in) dia.

CR14DE : 72.980 - 73.010 mm (2.7953 - 2.7957 in) dia.



PBIC1386E

Piston to Cylinder Bore Clearance

- Calculate by outer diameter of piston skirt and inner diameter of cylinder (direction X, position B).
(Clearance) = (Inner diameter of cylinder) – (Outer diameter of piston skirt).
- Standard : 0.010 - 0.030 mm (0.0004 - 0.0012 in)
- If clearance exceeds the standard, replace piston and piston pin assembly. Refer to [EM-82, "HOW TO SELECT PISTON"](#).

Reboring Cylinder Bore

1. Cylinder bore size is determined by adding piston-to-cylinder bore clearance to piston diameter "A".

Rebored size calculation: $D = A + B - C$

where,

D: Bored diameter

A: Piston diameter as measured

B: Piston - to - cylinder bore clearance (standard value)

C: Honing allowance 0.02 mm (0.0008 in)


2. Install main bearing caps, and tighten to the specified torque. Otherwise, cylinder bores may be distorted in final assembly.
3. Cut cylinder bores.
- When any cylinder needs boring, all other cylinders must also be bored.
- Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.
4. Hone cylinders to obtain specified piston-to-cylinder bore clearance.
5. Measure finished cylinder bore for out-of-round and taper.
- Measurement should be done after cylinder bore cools down.

OUTER DIAMETER OF CRANKSHAFT JOURNAL

- Using a micrometer (1), measure outer diameter of crankshaft journals.

Standard : 44.954 - 44.970 mm (1.7698 - 1.7705 in) dia.

- If it is out of the standard, measure the main bearing oil clearance. Then use the undersize bearing. Refer to [EM-91, "OIL CLEARANCE OF MAIN BEARING"](#).



OUTER DIAMETER OF CRANKSHAFT PIN

- Using a micrometer, measure outer diameter of crankshaft pin.

Standard : 39.961 - 39.974 mm (1.5733 - 1.5738 in) dia.

- If it is out of the standard, measure the connecting rod bearing oil clearance. Then use the undersize bearing. Refer to [EM-91, "OIL CLEARANCE OF CONNECTING ROD BEARING"](#).


OUT-OF-ROUND AND TAPER OF CRANKSHAFT

- Using a micrometer, measure the dimensions at 4 different points shown in the figure on each journal and pin.
- Out-of-round (1) is indicated by the difference in dimensions between 1 and 2 at A and B.
- Taper (2) is indicated by the difference in dimension between A and B at 1 and 2.

Limit:

Out-of-round (X - Y) : 0.005 mm (0.0002 in)

Taper (1 - 2) : 0.005 mm (0.0002 in)




- If the measured value exceeds the limit, correct or replace the crankshaft.
- If corrected, measure the bearing oil clearance of the corrected journal or pin. Then select the main bearing or connecting rod bearing. Refer to [EM-91, "OIL CLEARANCE OF MAIN BEARING"](#) or [EM-91, "OIL CLEARANCE OF CONNECTING ROD BEARING"](#).

CRANKSHAFT RUNOUT

- Place a V-block on a precise flat table to support the journals on the both end of the crankshaft.
- Place a dial gauge (1) straight up on the No. 3 journal.
- Rotate crankshaft and read indication on the gauge. (Total indicator reading)

Limit : 0.05 mm (0.002 in)

- If it exceeds the limit, replace the crankshaft.




OIL CLEARANCE OF CONNECTING ROD BEARING

Method of Measurement

- Install the connecting rod bearings to the connecting rod and the cap, and tighten the connecting rod nuts to the specified torque. Using a inside micrometer (1) measure the inner diameter of connecting rod bearing. Refer to [EM-76, "ASSEMBLY"](#) for the tightening procedure.

(Oil clearance) = (Inner diameter of connecting rod bearing) – (Outer diameter of crankshaft pin)

Standard : 0.010 - 0.044 mm (0.0004 - 0.0017 in)
Limit : 0.064 mm (0.0025 in)



PBIC1382E


- When exceeding limit, use undersize bearing so that oil clearance remains within the standard value. Refer to [EM-91, "Undersize Bearing Usage Guide"](#).

Method of Using Plastigage

- Remove oil and dust on the crankshaft pin and the surfaces of each bearing completely.
- Cut a plastigage (1) slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Install the connecting rod bearings to the connecting rod cap, and tighten the connecting rod nuts to the specified torque. Refer to [EM-76, "ASSEMBLY"](#) for the tightening procedure.

CAUTION:

Never rotate crankshaft while Plastigage is in place.



PBIC1390E

NOTE:


The procedure when the measured value exceeds the limit is same as that described in the "Method of Measurement".

Undersize Bearing Usage Guide

- If specified oil clearance cannot be obtained by standard size connecting rod bearing, use undersize (US) bearing.
- When using undersize bearing, install it, measure bearing inner diameter, and grind crankshaft pin to obtain specified oil clearance.

Bearing undersize table

Size	Thickness	Unit: mm (in)
STD (Reference)	1.504 - 1.508 (0.0529 - 0.0594)	
US 0.25 (0.0098)	1.627 - 1.635 (0.0641 - 0.0644)	



PBIC1391E

CAUTION:

Keep fillet R when grinding crankshaft pin (1) in order to use undersize bearing (All crankshaft pin).

OIL CLEARANCE OF MAIN BEARING

Method of Measurement

- Install the main bearings to the cylinder block and bearing cap. Measure the main bearing inner diameter with the bearing cap bolt tightened with main bearing cap to the specified torque. Refer to [EM-76, "ASSEMBLY"](#) for the tightening procedure.

(Oil clearance) = (Inner diameter of main bearing) – (Outer diameter of crankshaft journal)

Standard : 0.018 - 0.034 mm (0.0007 - 0.0013 in)
Limit : 0.05 mm (0.002 in)

- If the measured value exceeds the limit, select main bearings (including the undersize) referring to the main bearing inner diameter and crankshaft journal outer diameter, so that the oil clearance satisfies the standard. Refer to [EM-83, "HOW TO SELECT MAIN BEARING"](#) .

Method of Using Plastigage

- Remove oil and dust on the crankshaft journal and the surfaces of each bearing completely.
- Cut a plastigage (1) slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Tighten the main bearing bolts with main bearing cap to the specified torque. Refer to [EM-76, "ASSEMBLY"](#) for the tightening procedure.


CAUTION:

Never rotate crankshaft while Plastigage is in place.

- Remove the bearing cap and bearings, and using the scale on the plastigage bag, measure the plastigage width.

NOTE:

The procedure when the measured value exceeds the limit is same as that described in the "Method of Measurement".




PBIC1392E

CRUSH HEIGHT OF MAIN BEARING OR CONNECTING ROD BEARING

- When the bearing cap is removed after being tightened to the specified torque with main bearings or connecting rod bearings (1) installed, the tip end of bearing must protrude. Refer to [EM-76, "ASSEMBLY"](#) for the tightening procedure.

Standard : There must be crush height (2).

- If the standard is not met, replace main bearings or connecting bearings.




PBIC1393E

FLYWHEEL RUNOUT

- The runout of the clutch contact surface of the flywheel should be measured using a dial gauge (1). (Total indicator reading)

Flywheel (M/T models)

Limit : 0.15 mm (0.0059 in)



PBIC1394E

SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]


SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit

GENERAL SPECIFICATIONS

EBS000GK

Engine	CR10DE	CR12DE	CR14DE			
Cylinder arrangement	4, in-line					
Displacement	cm ³ (cu in)	977 (59.62)	1,240 (75.66)	1,386 (84.57)		
Bore and stroke	mm (in)	71.0 x 63.0 (2.795 x 2.480)	71.0 x 78.3 (2.795 x 3.083)	73.0 x 82.8 (2.874 x 3.260)		
Valve arrangement	DOHC					
Firing order	1-3-4-2					
Number of piston rings	Compression	2				
	Oil	1				
Number of main bearings		5				
Compression ratio		10.2	9.9			
Compression pressure kPa (bar, kg/cm ² , psi) / 350 rpm	Standard	1,432 (14.32, 14.6, 208)	1,383 (13.83, 14.1, 201)			
	Minimum	1,236 (12.36, 12.6, 179)	1,187 (11.87, 12.1, 172)			
	Differential limit between cylinders	98 (0.98, 1.0, 14)				
Valve timing (Intake valve timing control - OFF)						
	Unit: degree					
	a	b	c	d	e	f
CR10DE	208	208	- 17	45	4	24
CR12DE, CR14DE	216	224	- 11	55	4	32

INTAKE MANIFOLD AND EXHAUST MANIFOLD

Unit: mm (in)

		Limit
Surface distortion		0.3 (0.012)


SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

DRIVE BELTS


Location	Tension [N (kg, lb)]			Deflection [mm (in)] [When pressed by force of 98.1N (10 kg, 22lb)]			
	New	At adjustment	Limit	Measuring point	New belt	At adjustment	Limit
Alternator and A/C compressor belt	603 - 691 (61.5 - 70.5, 135.6 - 155.3)	495 - 583 (50.5 - 59.5, 111.3 - 131.1)	196 (20, 44.1)	A	6.6 - 7.8 (0.260 - 0.307)	7.3 - 8.5 (0.287 - 0.335)	13.8 (0.543)
				B	5.6 - 6.6 (0.220 - 0.260)	7.1 - 8.3 (0.280 - 0.327)	11.9 (0.469)
Alternator belt	603 - 691 (61.5 - 70.5, 135.6 - 155.3)	495 - 583 (50.5 - 59.5, 111.3 - 131.1)	196 (20, 44.1)	A	3.1 - 4.1 (0.122 - 0.161)	9.8 - 10.6 (0.386 - 0.417)	13.8 (0.543)
Water pump belt	446 - 534 (45.5 - 54.5, 100.3 - 120.0)	348 - 436 (35.5 - 44.5, 78.2 - 98.0)	137 (14, 30.9)	C	6.7 - 7.3 (0.264 - 0.287)	7.6 - 8.6 (0.299 - 0.339)	12.4 (0.448)
				D	4.7 - 5.6 (0.185 - 0.220)	7.0 - 7.7 (0.276 - 0.303)	8.6 (0.339)

With A/C compressor



PBIC1414E

Without A/C compressor



PBIC1415E

SPARK PLUG

Make	NGK	Champion
Standard type	LFR5AP-11	REC10PYC4
Hot type	LFR4AP-11	—
Cold type	LFR6AP-11	—
Gap (nominal)	1.1 mm (0.043 in)	

CYLINDER HEAD

Unit: mm (in)

	Limit
Cylinder head distortion	0.1 (0.004)
Height	121.2 (4.77)


SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

VALVE

Valve Dimensions

Unit: mm (in)



		Standard
Valve head diameter "D"	Intake	27.4 - 27.6 (1.079 - 1.087)
	Exhaust	22.4 - 22.6 (0.882 - 0.890)
Valve length "L"	Intake	97.85 (3.8524)
	Exhaust	97.92 (3.8551)
Valve stem diameter "d"	Intake	5.465 - 5.480 (0.2152 - 0.2157)
	Exhaust	5.445 - 5.460 (0.2144 - 0.2150)
Valve seat angle "α"		45°15' - 45°45'
Valve margin "T"		1.05 - 1.35 (0.0413 - 0.0531)

Valve Clearance

Unit: mm (in)

	Hot	Cold* (reference data)
Intake	0.314 - 0.426 (0.012 - 0.017)	0.29 - 0.37 (0.011 - 0.015)
Exhaust	0.338 - 0.462 (0.013 - 0.018)	0.32 - 0.40 (0.013 - 0.016)

*: At a temperature of approximately 20°C (68°F)

Valve Guide

Unit: mm (in)

Engine Models		CR10DE, CR12DE, CR14DE			
Valve guide	Outer diameter	Intake		Exhaust	
		Standard	Service	Standard	Service
	Inner diameter (Finished size)	5.500 - 5.518 (0.2165 - 0.2172)		5.500 - 5.518 (0.2165 - 0.2172)	
Cylinder head valve guide hole diameter		9.475 - 9.496 (0.3730 - 0.3739)	9.685 - 9.696 (0.3813 - 0.3817)	9.475 - 9.496 (0.3730 - 0.3739)	9.685 - 9.696 (0.3813 - 0.3817)
Interference fit of valve guide		0.026 - 0.059 (0.0010 - 0.0023)	0.027 - 0.049 (0.0011 - 0.0019)	0.026 - 0.059 (0.0010 - 0.0023)	0.027 - 0.049 (0.0011 - 0.0019)
Stem to guide clearance		0.020 - 0.053 (0.0008 - 0.0021)		0.040 - 0.073 (0.0016 - 0.0029)	
Valve deflection limit (Dial gauge reading)		0.2 (0.0079)		0.2 (0.0079)	



SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

Valve Seat



Unit: mm (in)

INTAKE



* Cylinder head machining data
MBIB1127E

EXHAUST



* Cylinder head machining data
MBIB1128E

Dia.	CR10DE, CR12DE, CR14DE
A	25.4 (1.00)
B	27.0 - 27.2 (1.062 - 1.070)
C	28.7 - 28.9 (1.129 - 1.137)
D	29.000 - 29.016 (1.1417 - 1.1424)
E	22.0 - 22.2 (0.866 - 0.874)
F	23.7 - 23.9 (0.933 - 0.940)
G	24.000 - 24.016 (0.9449 - 0.9455)

Valve Spring

Free height	mm (in)	53.3 (2.098)
Pressure load N (kg, lb) at height mm (in)	Standard	Installation 149 - 165 N (15.2 - 16.8, 33.5 - 37.1) at 32.82 (1.2921)
		Valve open 228 - 250 N (23.3 - 25.5, 51.3 - 56.2) at 24.73 (0.9736)
Out-of-square mm (in)	Limit	Less than 1.6 (0.063)

Valve Lifter

Unit: mm (in)

	Standard
Valve lifter outer diameter	29.960 - 29.975 (1.1795 - 1.1801)
Valve lifter hole inner diameter	30.000 - 30.021 (1.1811 - 1.1819)
Clearance between valve lifter and valve lifter hole	0.025 - 0.061 (0.0010 - 0.0024)


Available Valve Lifter

Thickness mm (in)	Identification Mark
3.000 (0.1181)	00
3.020 (0.1189)	02
3.040 (0.1197)	04

SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

Thickness mm (in)	Identification Mark	
3.060 (0.1205)	06	A
3.080 (0.1213)	08	
3.100 (0.1220)	10	EM
3.120 (0.1228)	12	
3.140 (0.1236)	14	
3.160 (0.1244)	16	C
3.180 (0.1252)	18	
3.200 (0.1260)	20	D
3.220 (0.1268)	22	
3.240 (0.1276)	24	
3.260 (0.1283)	26	E
3.280 (0.1291)	28	
3.300 (0.1299)	30	F
3.320 (0.1307)	32	
3.340 (0.1315)	34	G
3.360 (0.1323)	36	
3.380 (0.1323)	38	
3.400 (0.1339)	40	H
3.420 (0.1346)	42	
3.440 (0.1354)	44	
3.460 (0.1362)	46	I
3.480 (0.1370)	48	
3.500 (0.1378)	50	J
3.520 (0.1386)	52	
3.540 (0.1394)	54	K
3.560 (0.1402)	56	
3.580 (0.1409)	58	
3.600 (0.1417)	60	L
3.620 (0.1425)	62	
3.640 (0.1433)	64	
3.660 (0.1441)	66	
3.680 (0.1449)	68	M



PBIC1077E


SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

CAMSHAFT AND CAMSHAFT BEARING

Unit: mm (in)

	Standard
Camshaft runout [TIR*]	0.04 (0.0016)




SEM671

		CR10DE	CR12DE, CR14DE
Standard			
Cam height "A"	Intake	39.155 - 39.345 (1.5415 - 1.5490)	40.359 - 40.549 (1.5889 - 1.5964)
	Exhaust	39.155 - 39.345 (1.5415 - 1.5490)	39.743 - 39.933 (1.5647 - 1.5722)
Outer diameter of camshaft journal			
	No. 1 journal	27.935 - 27.955 (1.0998 - 1.1006)	
	No. 2 to No. 5 journals	23.450 - 23.470 (0.9232 - 0.9240)	
Inner diameter of camshaft bracket			
	No. 1 journal	28.000 - 28.021 (1.1024 - 1.1032)	
	No. 2 to No. 5 journals	23.500 - 23.525 (0.9252 - 0.9262)	
Camshaft journal clearance			
	No. 1 journal	0.045 - 0.086 (0.0018 - 0.0034)	
	No. 2 to No. 5 journals	0.030 - 0.071 (0.0012 - 0.0028)	
Camshaft end play			0.070 - 0.143 (0.0028 - 0.0056)

*: Total indicator reading

CYLINDER BLOCK

Unit: mm (in)



PBIC0613E

	CR10DE, CR12DE	CR14DE	Limit
Standard			
Surface flatness	—	0.1 (0.004)	
Height "H" (nominal)	189 (8.4232 - 8.4271)	—	

SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

Cylinder bore inner diameter	Grade No. 1	71.000 - 71.010 (2.7953 - 2.7957)	73.000 - 73.010 (2.8740 - 2.8744)	0.2 (0.008)*	EM
	Grade No. 2	71.010 - 71.020 (2.7957 - 2.7961)	73.010 - 73.020 (2.8744 - 2.8748)		
	Grade No. 3	71.020 - 71.030 (2.7961 - 2.7965)	73.020 - 73.030 (2.8748 - 2.8752)		
Out-of-round (Difference between X and Y)		—		0.015 (0.0006)	A
Taper (Difference between A and C)		—		0.01 (0.0004)	C
Difference in inner diameter between cylinders			0.05 (0.0020)	0.2 (0.008)	
Main bearing housing inner diameter	Grade 0	49.000 - 49.004 (1.9291 - 1.9293)		—	D
	Grade 1	49.004 - 49.008 (1.9293 - 1.9294)		—	E
	Grade 2	49.008 - 49.012 (1.9294 - 1.9296)		—	F
	Grade 3	49.012 - 49.016 (1.9296 - 1.9298)		—	G

*: Cylinder bore wear

A

EM

C

D

E

F

G

H

I

J

K

L

M


SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

PISTON, PISTON RING AND PISTON PIN

Available Piston

Unit: mm (in)



PBIC0188E

		CR10DE	CR12DE	CR14DE
		Standard		
Piston skirt diameter "A"	Grade No. 1	70.980 - 70.990 (2.7945 - 2.7949)	70.980 - 70.990 (2.7945 - 2.7949)	72.980 - 72.990 (2.8732 - 2.8736)
	Grade No. 2	70.990 - 71.000 (2.7949 - 2.7953)	70.990 - 71.000 (2.7949 - 2.7953)	72.990 - 73.000 (2.8736 - 2.8740)
	Grade No. 3	71.000 - 71.010 (2.7953 - 2.7957)	71.000 - 71.010 (2.7953 - 2.7957)	73.000 - 73.010 (2.8740 - 2.8744)
0.2 (0.002) oversize (service)		71.180 - 71.210 (2.8024 - 2.8035)	71.180 - 71.210 (2.8024 - 2.8035)	73.180 - 73.210 (2.8811 - 2.8823)
"H" dimension		37.3 (1.469)	34.3 (1.350)	32.3 (1.272)
Piston pin hole inner diameter		18.008 - 18.012 (0.7090 - 0.7091)		
Piston to cylinder bore clearance		0.010 - 0.030 (0.0004 - 0.0012)		

Piston Ring

Unit: mm (in)

		Standard	Limit
Side clearance	Top	0.040 - 0.080 (0.0016 - 0.0031)	0.110 (0.0043)
	2nd	0.025 - 0.070 (0.0010 - 0.0028)	0.1 (0.0039)
	Oil ring	0.030 - 0.140 (0.0021 - 0.0055)	—
End gap	Top	0.18 - 0.33 (0.0071 - 0.0130)	0.57 (0.0224)
	2nd	0.50 - 0.65 (0.0197 - 0.0256)	0.85 (0.0335)
	Oil (rail ring)	0.20 - 0.70 (0.0079 - 0.0276)	0.96 (0.0378)

Piston Pin

Unit: mm (in)

Piston pin outer diameter	Standard	17.996 - 18.000 (0.7085 - 0.7087)
Piston pin to piston clearance	Standard	0.008 - 0.016 (0.0003 - 0.0006)
Piston pin to connecting rod bushing clearance	Standard	-0.018 - -0.038 (-0.0007 - -0.0015)

CONNECTING ROD

Unit: mm (in)

		CR10DE	CR12DE, CR14DE
Center distance		120.70 - 120.80 (4.752 - 4.756)	129.45 - 129.55 (5.096 - 5.100)
Bend [per 100 (3.94)]	Limit		0.15 (0.0059)
Torsion [per 100 (3.94)]	Limit		0.30 (0.0118)

SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]


Connecting rod bushing inner diameter* (small end)	Standard	17.962 - 17.978 (0.7072 - 0.7078)
Connecting rod big end inner diameter	Standard	43.000 - 43.013 (1.6929 - 1.6934)
Side clearance	Standard	0.050 - 0.420 (0.0020 - 0.0165)
	Limit	0.5 (0.0197)

*: After installing in connecting rod

CRANKSHAFT


Unit: mm (in)

Main journal dia. "Dm"	Grade No. 0	44.966 - 44.970 (1.7703 - 1.7705)
	Grade No. 1	44.962 - 44.966 (1.7702 - 1.7703)
	Grade No. 2	44.958 - 44.962 (1.7700 - 1.7702)
	Grade No. 3	44.954 - 44.958 (1.7698 - 1.7700)
Pin dia. "Dp"	Standard	39.961 - 39.974 (1.5733 - 1.5738)
Out-of-round (X - Y)	Limit	0.005 (0.0002)
Taper (A - B)	Limit	0.005 (0.0002)
Runout [TIR*]	Limit	0.05 (0.0020)
Side clearance	Standard	0.060 - 0.260 (0.0024 - 0.0102)
	Limit	0.3 (0.012)



SEM645

Out-of-round
Taper
X - Y
A - B



SEM715

*: Total indicator reading

MAIN BEARING

Standard size

Unit: mm (in)

Grade No.	Thickness	Identification color
STD1	2.002 - 2.006 (0.0788 - 0.0790)	Red
STD2	2.004 - 2.008 (0.0789 - 0.0791)	Green
STD3	2.006 - 2.010 (0.0790 - 0.0791)	Yellow
STD4	2.008 - 2.012 (0.0791 - 0.0792)	Blue
STD5	2.010 - 2.014 (0.0791 - 0.0793)	Pink
STD6	2.012 - 2.016 (0.0792 - 0.0794)	White
STD7	2.014 - 2.018 (0.0793 - 0.0794)	Blue/yellow

Undersize

Unit: mm (in)

Grade	Thickness
US 0.25 (0.0098)	2.123 - 2.131 (0.836 - 0.839)

SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

Bearing Clearance

Unit: mm (in)

Main bearing clearance	Standard	0.018 - 0.034 (0.0007 - 0.0013)
	Limit	0.05 (0.002)

CONNECTING ROD BEARING

Standard Size

Unit: mm (in)

Grade	Thickness
Standard	1.504 - 1.508 (0.0529 - 0.0594)

Undersize

Unit: mm (in)

Grade	Thickness
US 0.25 (0.0098)	1.627 - 1.635 (0.0641 - 0.0644)

Bearing Clearance

Unit: mm (in)

Connecting rod bearing clearance	Standard	0.010 - 0.044 (0.0004 - 0.0017)
	Limit	0.064 (0.0025)

MISCELLANEOUS COMPONENTS

Unit: mm (in)

Flywheel runout [TIR*]	Limit	0.15 (0.0059)
Camshaft sprocket runout [TIR*]	Intake	0.20 (0.0079)
	Exhaust	0.15 (0.0059)

*: Total indicator reading

SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

Tightening Torque

EBS000HQ

A

*1: Parts to be tightened in particular orders

1)-: Order of tightening when tightening two or more steps separately.

Unit: N·m (kg·m, ft·lb)
Unit: N·m (kg·m, in·lb)*2

EM

Idler pulley locknut (for water pump belt)	24.5 - 31.4 (2.5 - 3.2, 18 - 23)	
Idler pulley locknut (for alternator and A/C compressor belt)	24.5 - 31.4 (2.5 - 3.2, 18 - 23)	
Idler pulley bracket (for alternator and A/C compressor belt)	16.6 - 23.5 (1.7 - 2.4, 13 - 17)	
Manifold absolute pressure sensor	1.2 - 1.7 (0.12 - 0.17, 11 - 15)*2	
*1 Air cleaner case (upper) to (lower)	1) 1.9 - 2.2 (0.20 - 0.22, 17 - 19)*2 2) 3.8 - 4.4 (0.40 - 0.44, 35 - 38)*2	D
*1 Air cleaner case assembly	5.4 - 7.3 (0.55 - 0.74, 48 - 64)*2	E
Electronic throttle control actuator	7.2 - 9.6 (0.73 - 0.99, 64 - 86)*2	
EVAP canister purge volume control solenoid valve	4.3 - 5.8 (0.44 - 0.59, 38 - 51)*2	
*1 Intake manifold	6.9 - 9.4 (0.71 - 0.96, 61 - 84)*2	F
Support bracket	M6 × 15 mm (0.59 in)	6.9 - 9.5 (0.71 - 0.96, 61 - 84)*2
	M6 × 12 mm (0.47 in)	8.4 - 10.8 (0.86 - 1.1, 75 - 95)*2
*1 Fuel injector and fuel tube assembly	1) 11.8 - 13.8 (1.2 - 1.4, 9 - 10) 2) 20.8 - 28.2 (2.1 - 2.9, 16 - 20)	G
Clamp for fuel feed hose	1.0 - 1.5 (0.10 - 0.15, 9 - 13)*2	H
*1 Exhaust manifold	25.5 - 29.4 (2.6 - 2.9, 19 - 21)	I
Exhaust manifold cover	6.3 - 8.3 (0.65 - 0.84, 56 - 73)*2	
Heated oxygen sensor 1	40 - 50 (4.1 - 5.1, 30 - 36)	J
Heated oxygen sensor harness bracket	6.9 - 9.5 (0.71 - 0.96, 61 - 84)*2	
Three way catalyst (under exhaust manifold)	29.4 - 34.3 (3.0 - 3.4, 22 - 25)	K
Three way catalyst support	33.3 - 46.1 (3.4 - 4.7, 25 - 34)	
Three way catalyst cover	6.3 - 8.3 (0.65 - 0.84, 56 - 73)*2	L
Ignition coil	3.8 - 4.4 (0.39 - 0.44, 34 - 38)*2	
Spark plug	19.6 - 29.4 (2.0 - 2.9, 15 - 21)	M
*1 Rocker cover	M6 × 45 mm (1.77 in)	8.8 - 10.8 (0.90 - 1.1, 78 - 95)*2
	M6 × 20 mm (0.79 in)	6.9 - 10.8 (0.71 - 1.1, 61 - 95)*2
Intake valve timing control solenoid valve	6.3 - 8.3 (0.65 - 0.84, 56 - 73)*2	
Harness bracket	6.3 - 8.3 (0.65 - 0.84, 56 - 73)*2	
*1 Oil pan (upper)	6.9 - 9.5 (0.71 - 0.96, 61 - 84)*2	
*1 Oil pan (lower)	6.9 - 9.5 (0.71 - 0.96, 61 - 84)*2	
Oil pan drain plug	29.4 - 39.2 (3.0 - 3.9, 22 - 28)	
Connecting bolt between oil pan (upper) and transaxle	16.6 - 23.5 (1.7 - 2.3, 13 - 17)	
Oil strainer	6.3 - 8.3 (0.65 - 0.84, 56 - 73)*2	
Cylinder head front cover	6.9 - 9.5 (0.71 - 0.96, 61 - 84)*2	
Chain tensioner	6.9 - 9.5 (0.71 - 0.96, 61 - 84)*2	
Camshaft position sensor (PHASE)	7.1 - 10.8 (0.73 - 1.1, 63 - 95)*2	
Camshaft sprocket	Intake Exhaust	78.4 - 88.2 (8.0 - 8.9, 58 - 65) 78.4 - 88.2 (8.0 - 8.9, 58 - 65)

SERVICE DATA AND SPECIFICATIONS (SDS)

[CR]

*1 Camshaft bracket	1) 2.0 (0.2, 18) ^{*2} 2) 5.9 (0.6, 52) ^{*2} 3) 9.0 - 11.8 (0.92 - 1.2, 80 - 104) ^{*2}
Chain tension guide	16.6 - 23.5 (1.7 - 2.3, 13 - 17)
Chain slack guide	12.7 - 18.6 (1.3 - 1.8, 10 - 13)
Crankshaft pulley	132.4 - 152.0 (14 - 15, 98 - 112)
Front cover	6.3 - 8.3 (0.65 - 0.84, 56 - 73) ^{*2}
*1 Cylinder head bolt	1) 61.7 - 71.7 (6.3 - 7.3, 46 - 52) 2) 0 (0.0, 0) 3) 22.5 - 32.5 (2.3 - 3.3, 17 - 23) 4) 90° - 95° (Angle tightening) 9.0 - 11.8 (0.92 - 1.2, 80 - 104) ^{*2}
*1 Cylinder head auxiliary bolt	16.6 - 23.5 (1.7 - 2.3, 13 - 17)
Engine slinger	95 - 115 (9.7 - 11, 70 - 84)
LH engine mount insulator	43 - 54 (4.4 - 5.5, 32 - 39)
LH engine mount bracket (vehicle side)	60 - 70 (6.2 - 7.1, 45 - 51)
LH engine mount bracket (transaxle side)	40 - 50 (4.1 - 5.1, 30 - 36)
RH engine mount stay	60 - 70 (6.2 - 7.1, 45 - 51)
RH engine mount insulator RH	40 - 50 (4.1 - 5.1, 30 - 36)
RH engine mount bracket (upper)	40 - 50 (4.1 - 5.1, 30 - 36)
RH engine mount bracket (lower)	64 - 74 (6.6 - 7.5, 48 - 54) 75 - 85 (7.7 - 8.7, 56 - 62)
Rear engine mount bracket	A/T models M/T models
Rear torque rod	75 - 85 (7.7 - 8.7, 56 - 62)
Connecting nut between LH engine mount insulator and LH engine mount bracket (transaxle side)	60 - 70 (6.2 - 7.1, 45 - 51)
Connecting bolt between RH engine mount insulator and RH engine mount bracket (upper)	90 - 100 (9.2 - 10, 67 - 73)
*1 Main bearing cap	1) 24.5 - 30.3 (2.5 - 3.0, 18 - 22) 2) 95° - 100° (Angle tightening)
Connecting rod cap	1) 13.7 - 15.7 (1.4 - 1.6, 10.1 - 11.5) 2) 45° - 50° (Angle tightening)
Rear oil seal retainer	6.9 - 9.5 (0.71 - 0.96, 61 - 84) ^{*2}
Flywheel (M/T)	83.4 - 93.2 (8.5 - 9.5, 62 - 68)
Drive plate (A/T)	93.2 - 103 (9.5 - 10, 69 - 75)
Knock sensor	15.7 - 20.6 (1.6 - 2.1, 12 - 15)
Crankshaft position sensor (POS) [Note: transaxle side mounting parts]	7.1 - 10.8 (0.73 - 1.1, 63 - 95) ^{*2}

PRECAUTIONS

PFP:00001

Precautions for Drain Coolant

Drain coolant when engine is cooled.

EBS01C5X

Precautions for Disconnecting Fuel Piping

EBS01C5Y

- Before starting work, make sure no fire or spark producing items are in the work area.
- Release fuel pressure before disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

EM

Precautions for Removal and Disassembly

EBS01C5Z

- When instructed to use special service tools, use the specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Cover openings of engine system with tape or the equivalent, if necessary, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and re-assembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified.

D

Precautions for Inspection, Repair and Replacement

EBS01C60

Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

E

Precautions for Assembly and Installation

EBS01C61

- Use torque wrench to tighten bolts or nuts to specified value.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly same as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check oil or coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assemble, spread the oil on sliding surfaces well.
- Release air within route when refilling after draining coolant.
- Before starting engine, apply fuel pressure to fuel lines with turning ignition switch ON (with engine stopped). Then make sure that there are no leaks at fuel line connections.
- After repairing, start engine and increase engine speed to check coolant, fuel, oil, and exhaust systems for leakage.

H

Parts Requiring Angular Tightening

EBS01C62

- Use an angle wrench for the final tightening of the following engine parts.
- Cylinder head bolts
- Lower cylinder block bolts
- Connecting rod cap bolts
- Crankshaft pulley bolt (No angle wrench is required as the bolt flange is provided with notches for angular tightening)
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.

M

Precautions For Liquid Gasket

REMOVAL OF LIQUID GASKET

EBS01C63

- After removing the mounting bolts and nuts, separate the mating surface using a seal cutter and remove the liquid gasket.


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap the liquid gasket applied area.

CAUTION:

If for some unavoidable reason a tool such as a flat-bladed screwdriver is used, be careful not to damage the mating surfaces.


**LIQUID GASKET APPLICATION PROCEDURE**

- Using a scraper, remove the old liquid gasket adhering to the gasket application surface and the mating surface.

- Remove the liquid gasket completely from the groove of the gasket application surface, mounting bolts and bolt holes.


- Wipe the gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.

- Attach the liquid gasket to the tube presser.
Use Genuine Liquid Gasket or equivalent.



- Apply the liquid gasket without breaks to the specified location with the specified dimensions.

- If there is a groove for the liquid gasket application, apply the gasket to the groove.



- As for the bolt holes, normally apply the gasket inside the holes. If specified, it should be applied outside the holes. Make sure to read the instruction in this manual.

- Within five minutes of gasket application, install the mating component.


- If the liquid gasket protrudes, wipe it off immediately.

- Do not retighten after the installation.

- After 30 minutes or more have passed from the installation, fill the engine oil and coolant.

CAUTION:

If there are instructions in this manual, observe them.



Cleanliness Instructions Which Must Be Followed When Working On The High Pressure Direct Injection System

RISKS RELATING TO CONTAMINATION

EBS01C64

The system is very sensitive to contamination. The risks caused by the introduction of contamination are:

- Damage to or destruction of the high pressure injection system,
- Seizing or leaking of a component.

All After-Sales operations must be performed under very clean conditions. This means that no impurities (particles a few microns in size) must be allowed to enter the system during dismantling or into the circuits via the fuel unions. The cleanliness principle must be applied from the filter to the injectors.

The Sources Of Contamination

EBS01C65

Contamination is caused by:

- Metal or plastic chips,
- Paint,
- Fibres,
- Of cardboard,
- Brushes,
- Paper,
- Clothing,
- Cloths.
- Foreign bodies such as hairs,
- Ambient air,
- Etc.

CAUTION:

It is forbidden to clean the engine using a high pressure washer because of the risk of damaging connections. Also moisture may collect in the connectors and cause electrical connection problems.

Precautions To Be Followed Before Any Work Is Carried Out On The Injection System

EBS01C66

- Ensure that you have the plugs for the unions to be opened [bag of plugs sold by the Parts Stores - Nissan part No.: 16830 BN700 (Renault part No.: 77 01 206 804)]. Plugs are to be used once only. After use, they must be thrown away (once used they are soiled and cleaning is not sufficient to make them reusable). Unused plugs must be thrown away.
- Ensure that you have the resealable plastic bags for storing removed parts. There is less risk of parts stored in this way being exposed to contamination. The bags must be used only once, and after use they must be thrown away.
- Make sure that lint-free cleaning cloths are available. The use of conventional cloth or paper is prohibited. These are not lint-free and may contaminate the fuel circuit of the system. Each lint-free cloth should only be used once.

Cleaning Precautions To Be Followed Before Carrying Out Any Work On The Fuel System

EBS01C67

- For each operation, use new thinner (used thinner contains impurities). Pour it into a clean receptacle.
- For each operation, use a clean brush which is in good condition (the brush must not shed its bristles).
- Use a brush and thinners to clean the connections to be opened.
- Blow compressed air over the cleaned parts (tools, bench and parts, connections and injection system zone). Check that no bristles remain adhered.
- Wash your hands before and during the operation if necessary.
- When wearing leather protective gloves, cover these with latex gloves.

Precautions To Be Followed During The Operation

EBS01C68

- As soon as the circuit is open, all openings must be plugged to prevent impurities from entering the system. The plugs to be used are available from the Parts Stores [Nissan Part No.: 16830 BN700 (Renault Part No.: 77 01 206 804)]. They must not be reused under any circumstances.
- Close the hermetically sealed bag, even if it has to be reopened shortly afterwards. Ambient air carries contamination.
- All components of the injection system that are removed must be stored in a hermetically sealed plastic bag once the plugs have been inserted.
- The use of a brush, thinner, bellows, sponge or normal cloth is strictly forbidden once the circuit has been opened. In fact, these items are likely to result in impurities entering the system.

PRECAUTIONS

[K9K]

- A new component replacing an old one must not be removed from its packaging until it is to be fitted to the vehicle.

Instructions For Fitting The Plugs

EBS01C69

NISSAN part number: 16830 BN700
 (Renault part number: 77 01 206 804)

A

EM

C

D

E

F

G

H


I

J

K

L

M



MBIB0321E

CAUTION:

- The engine must not run with:
 - Diesel containing more than 10% diester
 - Petrol, even in very small amounts.
- The system can inject the diesel into the engine at a pressure of up to 140,000 kPa (1,400 bar, 1,428 kg/cm², 20,300 psi). Before carrying out any work, check that the injector rail is no longer pressurized and that the fuel temperature is not too high.
- You must respect the cleaning and safety advice specified in this document for any work on the high pressure injection system.

PRECAUTIONS

[K9K]

- Removal of the interior of the pump and injectors is prohibited. Only the flow actuator, the diesel temperature sensor and the venturi may be changed on the pump.
- For safety reasons, it is strictly forbidden to undo a high pressure pipe union when the engine is running.
- It is forbidden to remove the pressure sensor from the fuel rail because this may cause contamination problems. If the pressure sensor develops a fault, the pressure sensor, fuel rail and the five high pressure pipes must be replaced.
- It is strictly forbidden to remove any fuel injection pump pulley bearing the Renault part No. 070 575. The pulley must be replaced when the high pressure pump is replaced.
- It is forbidden to repair the wiring connecting the accelerometer and the engine speed sensor. If the wiring should fail, it has to be replaced with new wiring.
- Applying 12 volts directly to any component in the system is prohibited.
- Ultrasonic decoking and cleaning are prohibited.
- Never start the engine if the battery is not connected correctly.
- Disconnect the injection system computer when carrying out any welding work on the vehicle.
- All disconnected plastic air inlet hoses must be replaced.

A 16 character code called C2I (Individual Injector Corrector) is marked on the injectors. This code, specific to each injector, takes into account any manufacturing variations and specifies the flow injected by each injector. The code of the new injector must be programmed into the computer when injector is replaced.

The code of the four injectors must be programmed into the computer when the computer is replaced.

There are two possibilities:

- If it is possible to communicate with the computer:
 - Upload the data from the computer into the diagnostic tool.
 - Change the computer.
 - Download the data from the diagnostic tool to the computer.
 - Using the diagnostic tool, ensure that the computer has not detected errors relating to the injector codes and check that the instrument panel warning light is off.
- If it is not possible to communicate with the computer:
 - Change the computer.
 - Read the data on the injectors.
 - Store the data in the computer using the diagnostic tool.
 - Using the diagnostic tool, ensure that the computer has not detected faults relating to the injector codes and check that the instrument panel warning light is off.

PREPARATION








[K9K]

PREPARATION

Special Service Tools







PFP:00002

EBS01C6A

NISSAN tool number (RENAULT tool No.) Tool name	Description	EM
KV113B0020 (Emb. 880) Sliding hammer	 MBIB0358E	Inertia extractor
KV113B0030 (Mot. 11) Crankshaft bearing remover	 MBIB0359E	Crankshaft bearing extractor
KV113B0040 (Mot. 251-01) Dial gauge stand set	 MBIB0360E	Gauge stand used with KV113B0050 (Mot. 252-01)
KV113B0050 (Mot. 252-01) Dial gauge stand set	 MBIB0361E	Thrust plate for measuring the protrusion of cylinder liners used with KV113B0040 (Mot. 251-01).
KV113B0060 (Mot. 582-01) Ring gear stopper	 MBIB0363E	Flywheel immobilizing tool.
KV113B0070 (Mot. 792-03) Engine sub-attachment	 MBIB0367E	Engine mounting plate for engine stand
KV113B0080 (Mot. 799-01) Camshaft pulley holder	 MBIB0368E	Tool for locking sprockets for toothed timing belt






PREPARATION

[K9K]

NISSAN tool number (RENAULT tool No.) Tool name	Description
KV113B0090 (Mot. 1335) Valve seal remover	Tool for removing valve stem seals
	 MBIB0370E
KV113B0100 (Mot. 1378) Engine sub-attachment	X and Y engine pins
	 MBIB0371E
KV113B0110 (Mot. 1430) TDC set pin	Set of TDC pins
KV113B0120 (Mot. 1485-01) Oil jet remover	Tool for removing the piston bottom oil jets
	 MBIB0372E
KV113B0130 (Mot. 1489) TDC set pin	TDC setting pin
	 MBIB0373E
KV113B0140 (Mot. 1492) Bearing assembling set	Tool for installing connecting rod bearing
	 MBIB0374E
KV113B0150 (Mot. 1492-03) Bearing assembling adapter	Adaptation kit for installing the detachable cap connecting rod bearing
	 MBIB0375E
KV113B0160 (Mot. 1493-01) Bearing insert	Tool for installing main bearing
	 MBIB0376E




PREPARATION

[K9K]

NISSAN tool number (RENAULT tool No.) Tool name	Description	A
KV113B0170 (Mot. 1494) Oil jet remover plate	Tool for removing oil jets	EM
KV113B0180 (Mot. 1511-01) Valve seal drift	Tool for installing valve stem seals	C
		D
	MBIB0378E	E
KV113E0010 (Mot. 1566) Fuel spill tube spanner	Spanner for installing and removing high pressure pipes	F
		G
	MBIB0379E	H
KV113B0190 (Mot. 1567) Clip pliers	Pliers for exhaust gas recycling pipe clips	I
KV113B0200 (Mot. 1573) Cylinder head stand	Cylinder head support	J
		K
	MBIB0380E	L
KV113B0210 (Mot. 1585) Front oil seal drift	Tool for installing crankshaft seals, flywheel end	M
		N
	MBIB0381E	O
KV113B0220 (Mot. 1586) Front oil seal drift set	Tool for installing crankshaft seals, timing end	P
KV113B0230 (Mot. 1632) Camshaft seal insert	Tool for installing inlet camshaft seals	Q
KV113B0240 (Rou. 15-01) Shaft protector	Internal shaft protector 16 mm (0.63 in) dia.	R
EM03470000 (—) Piston ring compressor	Installing piston assembly into cylinder bore	S
		T
	NT044	U




PREPARATION

[K9K]

NISSAN tool number (RENAULT tool No.) Tool name	Description
KV10111100 (—) Seal cutter	Removing oil pan
 NT046	
WS39930000 (—) Tube presser	Pressing the tube of liquid gasket
 NT052	
KV10112100 (—) Angle wrench	Tightening bolts for bearing cap, cylinder head, etc. in angle
 NT014	







Commercial Service Tools

EBS01C6B

(RENAULT tool No.) Tool name	Description
Manual lift table caddy	Removing and installing engine
 ZZA1210D	
Piston ring expander	Removing and installing piston ring
 NT030	
(Mot. 588)	Liner retaining strap
 MBIB0364E	

PREPARATION

[K9K]

(RENAULT tool No.) Tool name	Description
(664000) Cylinder head test container	 <p>Tool for testing the cylinder head, including: a tray and the various kits suited for each model of cylinder head (plug, sealing plate, blanking plate).</p>
Torx socket	Standard 1/2" (12.7 mm) square drive 8/12 / 14 female torx socket.
(Mot. 1505)	 <p>Tool for installing valve stem seals</p>
Glow plug wrench	 <p>Articulated wrench for removing and installing the glow plugs</p>
Main bearing wrench	 <p>Wrench for removing main bearings</p>
(Mot. 1638) Belt tension gauge	 <p>Checking drive belt tension</p>
Engine support bar	 <p>Using with engine support chain A: Approx. 12.5 mm (0.492in)</p>
Engine support chain	 <p>Using with engine support bar</p>

IDENTIFICATION INFORMATION

PFP:00010


Engine Identification

EBS01C6C

Identification is by means of an engraved plate on the cylinder block which carries:

- A: engine type
- B: engine type approval letter
- D: code
- E: engine suffix
- F: engine serial number
- G: engine assembly plant

Engine	Compression ratio	Bore and stroke mm (in)	Displacement cm ³ (cu in)
K9K	18.25/1	76 x 80.5 (2.992 x 3.169)	1,461 (89.15)



MBIB0322E

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting — Engine Noise

EBS01C6D

A

EM

C

D

E

F

G

H


I

J

K

L

M



MBIB0554E

Use the Chart Below to Help You Find the Cause of the Symptom.

EBS01C6E

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.

If necessary, repair or replace these parts.

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item	Reference page
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving			
Top of engine Rocker cover Cylinder head	Ticking or clicking	C	A	—	A	B	—	Tappet noise	Valve clearance	EM-194
Crank-shaft pulley Cylinder block (Side of engine) Oil pan	Slap or rap	A	—	—	B	B	A	Piston slap noise	Piston ring end gap	EM-197
Front of engine Timing belt cover	Tapping or ticking	A	A	—	B	B	B	Timing belt tensioner noise	Timing belt tensioner operation	EM-140
Front of engine	Squeaking or fizzing	A	B	—	B	—	C	Drive belts (Sticking or slipping)	Drive belts deflection	EM-121
	Squall Creak	A	B	—	B	A	B	Water pump noise	Water pump operation	CO-39

A: Closely related B: Related C: Sometimes related —: Not related

ENGINE ROOM COVER

PFP:14049

Removal and Installation

EBS01C6F

A

EM

C

D

E

F

G

H


I

J

K

L

M


SEC. 140
48 kW models

MBIB1032E

1. Engine room cover

2. Engine room cover bracket

SEC. 140
60 kW models



MBIB1033E

1. Engine room cover

2. Engine room cover bracket

REMOVAL

- Remove engine room cover from engine room cover bracket.

CAUTION:

Do not damage or scratch cover when installing or removing.

INSTALLATION

- Install in the reverse order of removal.

NOTE:

Press engine room cover until hearing the "click".

DRIVE BELTS

PFP:02117


Checking Drive Belts

EBS01C6G

WARNING:**Be sure to perform when the engine is stopped.**


1. Inspect belts for cracks, fraying, wear and oil. If necessary, replace.
2. Tighten auto-tensioner lock nut (models with A/C compressor) or idler pulley lock nut (models without A/C compressor) by hand and measure deflection or tension without looseness.

SEC. 117



3. When measuring deflection, apply 98 N (10 kg, 22 lb) at the ▼ marked point as shown (models without A/C compressor).

SEC. 117

**Tension Adjustment****MODELS WITH A/C COMPRESSOR**

EBS01C6H

Belt tensioning is not necessary, as it is automatically adjusted by auto-tensioner.**MODELS WITHOUT A/C COMPRESSOR**

Belt tightening method for adjustment	Adjusting bolt on idler pulley
---------------------------------------	--------------------------------

- The tension value is 234 ± 10 Hz.

NOTE:

The engine must be turned through two revolutions in order to position the belt correctly.

CAUTION:

- When checking belt tension immediately after installation, first adjust it to the specified value. Then, after turning the crankshaft two turns or more, re-adjust to the specified value to avoid variation in deflection between pulleys.
- When installing belt, make sure that it is correctly engaged with pulley groove.
- Keep oil and water away from belt.
- Do not twist or bend belt excessively.

Removal and Installation

EBS01C6I


CAUTION:

- Replace any belt that has been removed with a new one.
- Auto-tensioner and idle pulley must be replaced with a new one when the belt is replaced.
- Do not run the engine without the drive belts to avoid damaging the crankshaft pulley.

REMOVAL

1. Remove engine undercover.
2. Remove RH front wheel.
3. Remove right side splash cover.

4. Remove RH head light assembly.
5. Remove drive belt.
- Turn clockwise adjusting bolt.



MBIB0353E

6. If necessary, remove auto-tensioner (models with A/C compressor) or idler pulley (models without A/C compressor).


INSTALLATION

1. Install auto-tensioner mounting bolt (models with A/C compressor) or idler pulley mounting bolt (models without A/C compressor).

Auto-tensioner mounting bolt : **40 N·m (4.1 kg·m, 30 ft-lb)**
(models with A/C compressor)

Idler pulley mounting bolt : **30 N·m (3.1 kg·m, 22 ft-lb)**
(models without A/C compressor)

- The right figure is for example of models with A/C compressor. Align the notch and tighten mounting bolt.



MBIB0558E


2. Install the drive belt.

CAUTION:

- Make sure belt is correctly engaged with the pulley groove.
- Check for oil and coolant on belt and each pulley groove.

NOTE:

The drive belt has five teeth as opposed to the pulleys which have six. It is therefore essential to ensure that tooth (O) remains free when installing the belt.



MBIB0516E

3. Adjust belt tension (models without A/C compressor). Refer to [EM-121, "Tension Adjustment"](#).
4. Make sure that tension of each belt is within the standard.


AIR CLEANER AND AIR DUCT

PFP:16500

Removal and Installation

EBS01C6J

SEC. 165



1. Air duct (suction) 2. Intake air temperature sensor (Mod-els without charge air cooler) 3. Air cleaner case
 4. Air cleaner filter 5. Air duct (inlet)

REMOVAL

1. Disconnect battery ground cable.
2. Disconnect battery positive cable.
3. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#) .
4. Remove air duct (suction) mounting clip and remove air duct (suction).
5. Remove battery.
6. Disconnect the harness connector from the temperature sensor. (Models without charge air cooler)
7. Remove air duct (inlet) by loosing clamp screw.
8. Remove temperature sensor from air duct (inlet). (Models without charge air cooler)
9. Remove air cleaner case by sliding the air cleaner case frontward.

CAUTION:

Handle temperature sensor with care.

- Do not shock it.
- Do not disassemble it.
- Do not touch its sensor.

INSTALLATION

- Install in the reverse order of removal.

A

EM

C

D

E

F

G

H

I

J

K


L

M


**Changing Air Cleaner Filter
REMOVAL**

EBS01C6K

1. Open air cleaner case.



2. Remove air cleaner filter.

**INSTALLATION**

Install in the reverse order of removal.

CHARGE AIR COOLER

PFP:14461

Removal and Installation

EBS01C6L

A

EM

C

D

E

F

G

H

I


J

K

L

M

SEC. 117•144



: N•m (kg-m, in-lb)

MBIB1234E

1. Hose clamp	2. Air inlet hose	3. Air inlet tube
4. Charge air cooler	5. Inlet pipe assembly	6. EGR control solenoid
7. Bracket	8. Radiator core support upper	9. Reinforcement


REMOVAL

1. Remove the front bumper. Refer to [EI-4, "FRONT BUMPER"](#) .
2. Remove the engine room cover.
3. Remove air inlet hose and tube between inlet pipe assembly and charge air cooler.

CHARGE AIR COOLER

[K9K]


- Push releases buttons on each topside of the charge air cooler and release it from downside mounting points.



- Pull the charge air cooler to right side to disconnect it from the air inlet tube.

CAUTION:

- Avoid interference between the charge air cooler and radiator.
- When removing charge air cooler, close opening on turbo charger and intake manifold with shop cloth or other suitable material.



INSPECTION AFTER REMOVAL

- Check that the charge air cooler is not full of oil. In that case, clean it with cleaning agent and then let it dry.
- Check air passages of charge air cooler core and fins for clogging, leaks or deformation. Clean or replace charge air cooler in necessary.
- Be careful not to deform core fins.
- For cleaning procedure of charge air cooler core, refer to [CO-38, "Checking Radiator"](#) .

INSTALLATION

Apply a neutral detergent (fluid) to the joint between hoses and pipes (oil is not permissible).

Pay attention to identification mark and direction.


When installing air inlet hoses and tubes. Refer to [EM-125, "Removal and Installation"](#) .

EGR UNIT

PFP:14710

Removal and Installation

EBS01C6M

A
EM
C
D
E
F
G
H
I
J
K
L
M

- 1. Air inlet tube
- 2. Heat insulator
- 3. EGR solenoid valve
- 4. Gasket
- 5. EGR unit housing
- 6. EGR tube
- 7. Joint


REMOVAL

1. Remove battery ground cable.
2. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#).
3. Remove air cleaner case and air duct (inlet). Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#).
4. Remove wiper assembly.
5. Remove bulk head cover.

EGR UNIT


[K9K]

6. Disconnect EGR solenoid valve connector.
7. Remove mounting bolt.
8. Loosen turbocharger inlet tube.
9. Remove front engine slinger. Refer to [EM-147, "ENGINE ASSEMBLY"](#).
10. Remove air inlet tube.



MBIB0564E

11. Remove heat insulator.
12. Remove EGR tube clamp.
13. Remove air duct assembly.
14. Remove EGR unit housing and EGR tube.



MBIB0565E

INSTALLATION

- Install in the reverse order of removal.

EXHAUST MANIFOLD, TURBOCHARGER, CATALYST

PFP:14004

Removal and Installation

EBS01C6N

A

EM

C

D

E

F

G

H


I

J

K

L

M



1. Catalyst	2. Bracket	3. Turbocharger assembly
4. Hose	5. Exhaust manifold	6. EGR unit
7. Gasket		

REMOVAL

1. Remove battery ground cable.
2. Remove engine undercover.
3. Remove air cleaner case and air duct (inlet). Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#) .
4. Remove wiper assembly.
5. Remove bulk head cover.
6. Remove EGR unit assembly. Refer to [EM-127, "EGR UNIT"](#) .
7. Remove turbocharger assembly as follows:

EXHAUST MANIFOLD, TURBOCHARGER, CATALYST


[K9K]

- a. Remove catalyst mounting bolts and brackets.
- b. Remove exhaust front tube. Refer to [EX-3, "Removal and Installation"](#).


CAUTION:

Temporarily fix on vehicle side with rope or so to avoid putting stress on exhaust center tube.

- c. Remove catalyst.



8. Each wiring and piping (disconnect/move).
9. Loosen exhaust manifold mounting nuts in the reverse order as shown.




10. Rotate the exhaust manifold and turbocharger assembly so that the rear side (EGR tube mounting side) faces upward. And then pull out the assembly from between the engine and the air conditioning piping.

CAUTION:

Be careful not to deform each turbocharger piping when pulling out the assembly.

INSTALLATION

1. Tighten the mounting nuts in numerical order as shown.



2. Install in reverse order of removal after this step.


INSPECTION AFTER INSTALLATION

Start engine and raise engine speed to check no exhaust emission leaks.

Disassembly and Assembly

EBS01C60

SEC. 140•144



MLIA0008E

1. Washer	2. Oil tube	3. O-ring
4. Turbocharger	5. Exhaust manifold	6. Gasket
7. Turbocharger oil outlet pipe	8. Gasket	

DISASSEMBLY


- After applying penetrative lubricant to the mounting nuts, check for the penetration of the lubricant, and then loosen the nuts to remove.

CAUTION:

Do not disassemble or adjust the turbocharger body.

INSPECTION AFTER DISASSEMBLY

Turbocharger



MBIB0570E

CAUTION:

When the compressor wheel turbine wheel or rotor shaft is damaged, remove all the fragments and foreign matter left in the following passages in order to prevent a secondary failure:

Suction side : Between turbocharger and air cleaner
 Exhaust side : Between turbocharger and catalyst

EXHAUST MANIFOLD, TURBOCHARGER, CATALYST

[K9K]

ASSEMBLY

- Install in the reverse order of removal.

NOTE:

Apply LOCTITE FRENETANCH or equivalent to the threads of the turbocharger oil inlet pipe union to the cylinder head.

OIL PAN

PFP:11110

Removal and Installation

EBS01C6P

A

EM

C

D

E

F

G

H


I

J

K

L

M




1. Baffle plate
2. Gasket
3. Oil pan
4. O-ring
5. Drain plug
6. Oil level gauge
7. Crankshaft position sensor (POS)

CAUTION:

To avoid the danger of being scalded, never drain the engine oil when the engine is hot.

REMOVAL


1. Remove engine undercover.
2. Remove RH front wheel.
3. Remove right side splash cover.
4. Remove drive shaft assembly RH side. Refer to [FAX-10, "FRONT DRIVE SHAFT"](#).
5. Remove center bearing bracket as shown.



OIL PAN

[K9K]

6. Remove A/C compressor bracket mounting bolt as shown.




7. Remove oil level gauge guide.
8. Drain engine oil. Refer to [LU-13, "Changing Engine Oil"](#).


CAUTION:

Perform when engine is cold.


9. Remove oil pan and transaxle joint bolts.



10. Support the engine bottom of the oil pan with a transmission jack etc.




11. Remove oil pan bolt reverse order as shown.



- Insert seal cutter (special service tool) between upper oil pan and cylinder block. Slide tool by tapping on the side of the tool with a hammer.

CAUTION:

Exercise care not to damage mating surface.



12. Remove oil pan and baffle plate.



INSPECTION AFTER REMOVAL

Clean oil pump assembly if any object attached.

INSTALLATION

- Install in the reverse order of removal paying attention to the following.

1. Apply liquid gasket as shown.
 - Use Genuine Liquid Gasket or equivalent.




2. Install baffle plate.

3. Install oil pan bolts in numerical order as shown.

- Tighten the bolts in the numerical order shown in the figure to a torque of 8 N·m (0.8 kg-m, 71 in-lb).
- Tighten the mounting bolts of oil pan on the clutch housing without locking.
- Tighten the bolts in the numerical order shown in the figure to a torque of 15 N·m (1.5 kg-m, 11 ft-lb).
- Tighten the mounting bolts of oil pan on the clutch housing to a torque of 44 N·m (4.5 kg-m, 32 ft-lb).

4. At least 30 minutes after oil pan is installed, pour engine oil.

**INSPECTION AFTER INSTALLATION**

- Inspection the engine oil level. Refer to [LU-12, "ENGINE OIL"](#) .
- Start the engine, and make sure there is no leak of engine oil. Refer to [LU-12, "ENGINE OIL"](#) .


GLOW PLUG

PFP:22401

Removal and Installation

EBS01C6Q

SEC. 220



MBIB0576E

1. Glow plug

REMOVAL

CAUTION:

Remove glow plug only if necessary. If carbon adheres, it may be stuck and broken.

1. Disconnect battery ground cable.
2. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#) .
3. Disconnect harness connector from glow plug.
4. Remove glow plug.

CAUTION:

- When removing or installing, do not use such tools as an air impact wrench.
- Handle it carefully without giving any impact, even after removal. [As a guide, if it drops from height of 10 cm (3.94 in) or higher, always replace it.]

INSTALLATION

1. Remove adhered carbon from glow plug installation hole with a reamer.
2. Install glow plug.
3. Install remaining parts in reverse order of removal.

VACUUM PUMP

PFP:41920

Removal and Installation

EBS01C6R

A

EM

C

D

E

F

G

H

I


J

K

L

M

SEC. 135



: Always replace after every disassembly.

MBIB1040E

1. Vacuum pump

2. Gasket

3. Vacuum hose

REMOVAL

1. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#) .
2. Remove battery.
3. Remove air cleaner case and air duct (suction). Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#) .
4. Remove rear engine slinger. Refer to [EM-147, "ENGINE ASSEMBLY"](#) .
5. Disconnect vacuum hose from vacuum pump side.
6. Remove vacuum pump.

INSTALLATION

- Install in the reverse order of removal.


ROCKER COVER

PFP:13264

Removal and Installation

EBS01C6S

SEC. 111




MLIA0009E

1. Oil filler cap
2. Oil catcher
3. Rocker cover
4. Gasket

REMOVAL


1. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#) .
2. Remove battery.
3. Remove air cleaner case and air duct (suction). Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#) .
4. Remove rocker cover.
 - Loosen holding bolts in the reverse order as shown in the figure and remove.



MBIB0580E

INSTALLATION


1. Apply liquid gasket on locations shown in the figure.
 - Use Genuine Liquid gasket or equivalent.



2. Tighten holding bolts in the numerical order as shown in the figure.

 **10 N·m (1.02 kg·m, 7.4 ft-lb)**

3. Install in the reverse order of removal after this steps.




TIMING BELT

PFP:13028

Removal and Installation

EBS01C6T

SEC. 120•130•135



MBIB1258E

1. Timing belt inner cover
2. Timing belt
3. Camshaft sprocket
4. Timing belt tensioner
5. Timing belt upper cover
6. Camshaft position sensor
7. Timing belt lower cover
8. Cylinder head suspended bracket
9. Crankshaft pulley
10. Crankshaft sprocket
11. Rear oil seal
12. Rear oil seal retainer
13. Gasket


CAUTION:

- Apply new engine oil to parts marked in illustration before installation.
- Replace any belt that has been removed.
- Never turn the engine in the direction opposite to that of normal operation.
- When replacing the timing belt, be sure to replace the timing belt tensioner.
- Do not run the engine without the drive belts to avoid damaging the crankshaft pulley.

REMOVAL


1. Remove the following parts.
 - Battery ground cable
 - Undercover
 - RH front wheel
 - RH head light assembly
2. Remove right side splash cover.
3. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#).
4. Remove air cleaner case and air duct (suction). Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#).
5. Remove drive shaft lock pin and lock nut. Refer to [FAX-10, "FRONT DRIVE SHAFT"](#).
6. Remove ABS sensor from brake caliper.
7. Remove strut lower bolts.

8. Remove drive shaft assembly RH side.
9. Remove drive belt. Refer to [EM-121, "DRIVE BELTS"](#) .
10. Remove oil pan. Refer to [EM-133, "OIL PAN"](#) .
11. Install engine slingers. Refer to [EM-147, "ENGINE ASSEMBLY"](#) .
12. Set the engine support bar (commercial service tool) or suitable tool, and secure the engine in position.




MBIB1046E

13. Remove RH engine torque rod.
14. Remove RH engine mounting.




MBIB1041E

15. Remove RH engine mounting support bracket, RH engine mounting insulator and reservoir tank.
16. Remove upper timing cover, camshaft position sensor and cylinder head suspended mounting bracket.



MLIA0003E

17. Remove the TDC pin cap.




MBIB0392E


TIMING BELT

[K9K]


18. Position the hole (A) of the camshaft pulley almost opposite the hole (B) of the cylinder head.



19. Screw in the TDC pin (special service tool).




20. Turn the engine clockwise (timing side) until the crankshaft touches the TDC pin (special service tool).



21. The pin (special service tool) must engage in the camshaft pulley and cylinder head holes.

22. Remove TDC pin (special service tool).




23. Remove crankshaft pulley as follows:


- Loosen the crankshaft pulley fixing bolts by locking the flywheel with a screwdriver and pull crankshaft pulley with both hands to remove it.

CAUTION:


Do not remove fixing bolts. Keep loosened fixing bolts in place to protect removed crankshaft pulley from dropping.



24. Slacken the timing belt by loosening the bolt of tensioner, then remove timing belt.



25. Remove crankshaft sprocket.
26. Remove timing belt tensioner and inner timing cover.



27. If necessary, remove rear oil seal retainer.

INSTALLATION


- Install in the reverse order of removal paying attention to the following.

Rear Oil Seal Retainer

- Refer to [EM-179, "INSTALLATION OF REAR OIL SEAL RETAINER AND OIL PUMP"](#) .

Timing Belt

- Refer to [EM-186, "TIMING ADJUSTMENT"](#) .
- When install crankshaft pulley, lock crankshaft with a hammer handle or similar tool.




CYLINDER HEAD

PFP:11041

Removal and Installation

EBS01C6U

SEC. 102•111•130•135



MBIB0596E

1. Front engine slinger
2. Camshaft bracket
3. Camshaft
4. Camshaft sprocket
5. Cylinder head suspended bracket
6. Shim
7. Valve rotator
8. Valve spring retainer
9. Valve spring
10. Valve cotter
11. Exhaust valve
12. Intake valve
13. Rear engine slinger
14. Cap
15. Cylinder head gasket
16. Cylinder head

CAUTION:

Apply new engine oil to parts marked in illustration before installation.

REMOVAL

1. Remove the following parts.
 - Battery ground cable
 - Undercover
 - RH front wheel
 - RH head light assembly
2. Remove right side splash cover.
3. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#) .
4. Drain engine coolant. Refer to [CO-32, "DRAINING ENGINE COOLANT"](#) .

CAUTION:
Perform when engine is cold.

5. Remove air cleaner case and air duct (suction). Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#) .
6. Remove radiator upper hose. Refer to [CO-34, "RADIATOR"](#) .
7. Disconnect fuel feed tube and return tube from fuel injection pump. Refer to EC-K9K-31, "Injector rail", "DIESEL EQUIPMENT" in EC section.
8. Remove oil level gauge guide.

9. Remove harnesses and connectors.
10. Remove heater hoses.
11. Remove turbocharger assembly. Refer to [EM-129, "EXHAUST MANIFOLD, TURBOCHARGER, CATALYST".](#)
12. Remove drive belt. Refer to [EM-121, "DRIVE BELTS".](#)
13. Remove rocker cover. Refer to [EM-138, "ROCKER COVER".](#)
14. Support underneath of engine by setting a manual lift table caddy (commercial service tool) or equivalent tool.

CAUTION:


Put a piece of wood or something similar as supporting surface, secure a completely stable condition.

15. Remove timing belt. Refer to [EM-140, "TIMING BELT".](#)
16. Remove engine support bar.

CAUTION:

During the removal operation, always be careful to prevent engine moves downward from the vehicle.

17. Remove cylinder head bolt in the reverse order as shown.



18. Remove cylinder head assembly.

INSTALLATION

- Install in the reverse order of removal paying attention to the following.

Cylinder Head Bolts**NOTE:**

Use a syringe to remove any oil which may have entered the cylinder head mounting bolt holes to achieve correct tightening of the bolts.

CAUTION:

All bolts must always be changed after removal. Do not oil the new bolts.


- Tighten all the bolts in the numerical order as shown.

 **25 N·m (2.6 kg-m, 18 ft-lb)**

- Check that all the bolts are correctly tightened to 25 N·m (2.6 kg-m, 18 ft-lb), then angle tightening of 245 to 265 degrees.

CAUTION:

- Use an angle wrench (special service tool) to check tightening angle.
- Do not retighten the cylinder head bolts after performing this procedure.

**Disassembly and Assembly****DISASSEMBLY**

- Refer to [EM-158, "DISASSEMBLY OF THE CYLINDER HEAD".](#)

INSPECTION AFTER DISASSEMBLY

- Refer to [EM-160, "Inspection".](#)

EBS01C6V

- Refer to [EM-161, "Valve Clearance"](#) .
- Refer to [EM-191, "Cylinder Head"](#) .

ASSEMBLY

- Refer to [EM-170, "Assembly"](#) .

ENGINE ASSEMBLY

PFP:10001

Removal and Installation

EBS01C6W

A

EM

C

D

E

F

G

H


I

J

K

L

M



- 1. LH engine mounting
- 2. Rear torque rod
- 3. Engine rear mounting bracket
- 4. RH engine mounting
- 5. RH engine mounting insulator

WARNING:

- Situate vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.

CAUTION:

- Always be careful to work safely, avoid forceful or uninstructed operations.
- Do not start working until exhaust system and coolant are cool enough.
- If items or work required are not covered by the engine main body section, refer to the applicable sections.
- Always use the support point specified for lifting.
- Use either 2-pole lift type or separate type lift as best you can. If board-on type is used for unavoidable reasons, support at the rear axle jacking point with transmission jack or similar tool before starting work, in preparation for the backward shift of center of gravity.
- For supporting points for lifting and jacking point at rear axle, refer to [GI-38, "LIFTING POINT"](#).

REMOVAL**Description of work**

Remove engine and transaxle assembly from vehicle down ward. Separate engine and transaxle.

Preparation

1. Remove the following parts.
 - Battery ground cable
 - Undercover

- Right side splash cover
- LH/RH front wheel
- RH head light assembly

Engine room

2. Drain engine coolant. Refer to [LU-13, "Changing Engine Oil"](#) .


CAUTION:

Perform when engine is cold.

3. Remove engine room cover. Refer to [EM-119, "ENGINE ROOM COVER"](#) .
4. Remove air cleaner case and air duct (suction). Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#) .
5. Remove radiator upper hose. Refer to [CO-34, "RADIATOR"](#) .
6. Remove reservoir tank and hoses. Refer to [CO-34, "RADIATOR"](#) .
7. Remove fuel feed and return tubes. Refer to EC-K9K-31, "Injection rail", "DIESEL EQUIPMENT".
8. Remove vacuum hose. Refer to [EM-137, "VACUUM PUMP"](#) .
9. Remove turbocharger air duct. Refer to [EM-129, "EXHAUST MANIFOLD, TURBOCHARGER, CATALYST"](#) .
10. Disconnect heater hoses.
11. Disconnect engine room harness from the engine side and set it aside for easier work.
12. Disconnect transaxle side harness and clutch hose. Refer to [CL-10, "CLUTCH DISC, CLUTCH COVER AND FLYWHEEL"](#) .
13. Disconnect drain hose transaxle side.
14. Disconnect shift cable and select cable. Refer to [MT-12, "CONTROL LINKAGE"](#) (with JH3 transaxle) or [MT-42, "CONTROL LINKAGE"](#) (with JR5 transaxle).
15. Loosen wire bracket.
16. Disconnect all the body-side vacuum hoses and air hoses at engine side.
17. Disconnect fuel feed and return hoses, and plug it to prevent fuel from draining.

Vehicle underbody

18. Remove drive shaft lock pin and lock nut. Refer to [FAX-10, "FRONT DRIVE SHAFT"](#) .
19. Remove ABS sensor from brake caliper.
20. Remove strut lower bolts.
21. Remove drive shaft assembly RH and LH.
22. Remove drive belt. Refer to [EM-121, "DRIVE BELTS"](#) .
23. Remove A/C compressor with piping connected from engine (with A/C compressor models). Temporarily secure it on body with a rope to avoid putting load on it.
24. Remove exhaust front tube. Refer to [EX-3, "Removal and Installation"](#) .
25. Remove engine rear mounting bracket.




Removal


26. Install engine slingers into front right of cylinder head and rear left of cylinder head.

Slinger bolts:

: 21 N·m (2.14 kg·m, 15.5 ft-lb)



27. Set the engine support bar (commercial service tool) or suitable tool, and secure the engine in position.



- Use a manual lift table caddy (commercial service tool) or equivalently rigid tool such as a jack or trestle. Securely support bottom of engine and transaxle.


CAUTION:

Put a piece of wood or something similar as the supporting surface, secure a completely stable condition.

28. Remove RH and LH engine mounting bolts.
29. Remove engine and transaxle assembly from vehicle downward by carefully operating supporting tools.

CAUTION:

- During the operation, make sure that no part interferes with body side.
- Before and during this lifting, always check if any harnesses are left connected.
- During the removal operation, always be careful to prevent vehicle from falling off the lift due to changes in the center of gravity.
- If necessary, support vehicle by setting a jack or equivalent tool at the rear.



MBIB1045E

Separation Work

CAUTION:

During the operation, secure support the engine by placing a piece of wood under the engine oil pan, transaxle oil pan and suspended the engine slinger by baby crane (movable hoist) etc.

30. Remove starter motor.
31. Separate engine and transaxle.

INSTALLATION

Install in the reverse order of removal.

- Do not allow oil to get on mounting insulator. Be careful not to damage mounting insulator.
- When installation directions are specified, install parts according to the direction marks on them referring to components illustration.
- Make sure that each mounting insulator is seated properly, and tighten mounting bolts and nuts.

INSPECTION AFTER INSTALLATION

- Before starting engine check the levels of coolant, lubrications and working oils. If less than required quantity, fill to the specified level.

ENGINE ASSEMBLY

[K9K]

- Before starting engine, bleed air from fuel piping. Refer to [FL-16, "Bleeding Fuel Filter"](#) .
- Run engine to check for unusual noise and vibration.
- Warm up engine thoroughly to make sure there is no leakage of coolant, lubricants, working oil, fuel and exhaust gas.
- Bleed air from passages in pipes and tubes of applicable lines.

OVERHAUL

[K9K]

OVERHAUL

PFP:00000

Tightening Torques UPPER ENGINE

EBS01C6X

Unit: N·m (kg·m, in-lb)*2 Unit: N·m (kg·m, ft-lb)

Tightening torque	Cylinder head	: *1	EM
	Camshaft bearing	: 10 (1.0, 7)	C
	Camshaft pulley	: 30 (3.1, 22) + 84° (Angle tightening)	D
	Vacuum pump	: 21 (2.1, 15)	E
	Cylinder head coolant outlet unit	: 10 (1.0, 7)	F
	Exhaust manifold	: 26 (2.7, 19)	G
	Glow plug	: 15 (1.5, 11)	H
	Rocker cover	: 10 (1.0, 7)	I
	Turbocharger-manifold mounting	: 26 (2.7, 19)	J
	Turbocharger oil return pipe	: 9 (0.9, 80)*2	K
	Turbocharger oil delivery pipe	: 23 (2.3, 17)	L
	Timing tensioner	: 25 (2.6, 18)	M
	TDC cap	: 20 (2.0, 15)	
	Cylinder head suspended mounting bracket	: 21 (2.1, 15)	

*1: Refer to tightening procedure in the text.

BOTTOM ENGINE

Unit: N·m (kg·m, in-lb)*2 Unit: N·m (kg·m, ft-lb)

Tightening torque	Oil cooler connector bolt	: 45 (4.6, 33)	
	Oil filter bracket	: 45 (4.6, 33)	
	Main bearing cap	: 27 (2.8, 20) + 47°±5° (Angle tightening)	
	Connecting rod	: 20 (2.0, 15) + 45°±6° (Angle tightening)	
	Knock sensor	: 20 (2.0, 15)	
	Oil level sensor	: 22 (2.2, 16)	
	Oil pump	: 25 (2.6, 18)	
	Oil pan	: *1	
	Water pump	: 11 (1.1, 8)	
	Flywheel	: 50 - 55 (5.1 - 5.6, 37 - 40)	
	Crankshaft pulley	: 20 (2.0, 15) + 130°±15° (Angle tightening)	
	Water pump inlet pipe	: 20 (2.0, 15)	
	Alternator bracket	: 44 (4.5, 32)	
	Alternator	: 25 (2.6, 18)	
	A/C compressor	: 21 (2.1, 15)	

*1: Refer to tightening procedure in the text.

Standard Replacement PREPARING USED ENGINE

EBS01C6Y

The engine should be cleaned and drained (oil and water).

Leave on the used engine or include in the return box:

- Oil filter
- Oil pressure switch
- Water pump
- Fuel injection pump
- Rail
- Injectors
- Glow plugs
- Oil level gauge
- Vacuum pump
- Flywheel

Remember to remove:

- All coolant pipes
- Exhaust manifold
- Alternator
- Power steering pump
- A/C compressor
- Alternator bracket
- Oil level sensor
- Cylinder head coolant outlet unit


The used engine should be secured to the base under the same conditions as the overhauled engine:

- Plastic plugs and covers fitted
- Cardboard cover over the assembly


Disassembly**REMOVING THE UPPER ENGINE**

EBS01C62

1. Remove the upper timing cover by unclipping the two tabs (A).




2. Remove the lower timing cover by unclipping the three tabs (B) and pulling out the plastic bolt (C).




A
B
C
D
E
F
G
H
I
J
K
L
M

3. Remove the cylinder head suspended mounting bracket.



MBIB0391E


4. Remove the TDC pin cap.



MBIB0392E

POSITIONING THE BELT AT THE TIMING POINT

1. Position the hole (A) of the camshaft pulley almost opposite the hole (B) of the cylinder head.




MBIB0393E


OVERHAUL

[K9K]


2. Screw in the Tool KV113B0130 (Mot. 1489).




3. Turn the engine clockwise (timing side) until the crankshaft touches the Tool KV113B0130 (Mot. 1489).



4. The Tool KV113B110 (Mot. 1430) must engage in the camshaft pulley and cylinder head holes.
5. Remove Tool KV113B0130 (Mot. 1489).




6. Install the Tool KV113B0060 (Mot. 582-01).



OVERHAUL


[K9K]

7. Remove the crankshaft pulley.




MBIB0398E

8. Slacken the timing belt by loosening the bolt of the tensioner, then remove the timing belt.



MBIB0399E


9. Remove the timing belt tensioner and inner timing cover.




MBIB0400E

10. Remove air cleaner case. Refer to [EM-123, "AIR CLEANER AND AIR DUCT"](#).


11. Remove the clamp, oil vapor rebreathing pipe and turbocharger oil supply pipe on the cylinder head side.




12. Remove the turbocharger oil supply pipe on the turbocharger side, nuts (A) and the torx bolt of the turbocharger flange, bolts (B) of the catalytic converter bracket, and turbocharger oil return pipe (C).



13. Unclip the fuel return pipe from the cylinder head cover at the fuel spill tube, then remove the rocker cover.



14. Remove the oil level gauge guide and cylinder head.




DISASSEMBLY OF THE CYLINDER HEAD


1. Place the cylinder head on Tool KV113B0200 (Mot. 1573).

CAUTION:


Pay strict attention to the rules regarding cleanliness. Refer to [EM-105, "PRECAUTIONS"](#).




2. Remove fuel injection pump and related parts. Refer to EC-K9K-20, "High pressure pump", "DIESEL EQUIPMENT" in EC section.
3. Remove the injectors (by marking them in relation to their cylinder), glow plugs using Tool KV113E0010 (Mot. 1566), and rear engine slinger.



4. Remove the vacuum pump and water outlet.




5. Remove the front engine slinger, EGR unit, air inlet pipe and exhaust manifold.




OVERHAUL

[K9K]


6. Remove the camshaft pulley using Tool KV113B0080 (Mot. 799-01).




7. Remove the camshaft brackets.



8. Remove the tappets, noting their position.




9. Compress the valve springs using the valve lifter.
Remove the keys, upper cups and springs.



NOTE:


Before removing the valves and the valve stem seals, it is vital to measure position "H" of one of the old seals in relation to the cylinder head using Tool KV113B0180 (Mot. 1511-01) or suitable tool.




10. Install the push rod (A) of Tool KV113B0180 (Mot. 1511-01) on the valve stem seal.

NOTE:

The inner diameter of the push rod must be identical to that of the valve. In addition, the bottom of the push rod must come into contact with the metal upper section of the valve stem seal.



11. Install the guide tube (B) over the push rod until the guide tube comes into contact with the cylinder head, locking the push rod with the knurled wheel.
12. Remove the guide tube assembly plus push rod, being careful not to loosen the knurled wheel.
13. Remove the valves and valve guide seals using the Tool KV113B0090 (Mot. 1335).



Cleaning

EBS01C70

- It is very important not to scratch the gasket faces of any aluminium components.
- Use suitable tool to dissolve any part of the seal which remains stuck to the metal surface.
- Apply the dissolving product to the part to be cleaned, wait approximately 10 minutes, then remove it using a wooden spatula.
- Wear gloves while carrying out this operation.
- Do not allow this dissolving product to drip on to the paintwork.
- **Great care should be taken when performing this operation, to prevent foreign objects from entering the pipes taking oil under pressure to the camshafts (pipes in both the cylinder head and its cover) and the oil return pipes.**
- **Failure to follow these instructions could lead to the blocking of the oilways, resulting in rapid and serious damage to the engine.**

Inspection

GASKET FACE

EBS01C71

- Inspect mating surface bow using a ruler and a set of shims.

Maximum bow : 0.05 mm (0.0020 in)

- Test the cylinder head to detect possible cracks using the cylinder head test tools (comprising a tray and a kit suited to the cylinder head, plug, sealing plate and blanking plate). The approval number of the cylinder head test container (commercial service tool) is 664000.

CAMSHAFT END PLAY


NOTE:

Set the dial gauge to the cylinder head and inspect following dimensions:

Outer diameter : 18 mm (0.71 in)

Height : 15 mm (0.59 in)

1. Install the camshaft.
2. Install the camshaft brackets (positioning them correctly with bracket 1 on the flywheel end), then tighten the bolts to a torque of 10 N·m (1.0 kg-m, 7 ft-lb).
Check the end play, which must be between 0.08 mm (0.0031 in) and 0.178 mm (0.0070 in).
Remove the camshaft brackets and the camshaft.



MBIB0420E

Valve Clearance

CHECKING AND ADJUSTING THE VALVE CLEARANCE


1. Install the tappet.
2. Install the camshaft.
3. Install the camshaft brackets.

① : 10 N·m (1.0 kg-m, 7 ft-lb)

4. Place the valves of the cylinder concerned at the "end of exhaust - beginning of inlet" position and check the clearance (X).

NOTE:

Dimension (Y) corresponds to the tappet thickness sizes (there are 25 sizes at the service parts).



MBIB0333E

5. Compare the values recorded with the values specified, then replace the tappets which are not within tolerance.

Clearance, under cold condition:


Intake : 0.125 - 0.25 mm (0.0049 - 0.0098 in)

Exhaust : 0.325 - 0.45 mm (0.0128 - 0.0177 in)

6. Remove the camshaft brackets.
7. Remove the camshaft.
8. Remove the tappet not within tolerance.

Determining dimension Y.

Set up the following assembly using KV113B0050 (Mot. 252-01) and dial gauge, then calibrate the gauge.



MBIB0334E

9. Raise the gauge extension (without modifying the position of the magnetic support/gauge assembly), then slide in the tappet to be measured.


- Note dimension (Y) and repeat the operation for the tappets where the valve clearance is not within tolerance.
- Refer to the Replacement Parts Catalogue for the vehicle concerned to select the various thicknesses of the tappet(s).

10. Check the valve clearance again.

11. Remove the camshaft brackets.

12. Remove the camshaft.

13. Remove the tappet(s) not within tolerance.



MBIB0335E

14. Grease the underside of the tappets and the camshaft brackets.


15. Degrease the gasket faces (of the cylinder head and brackets 1 and 6). They should be clean, dry and free from grease (in particular, remove finger marks).

16. Lay four beads of Loctite with a width of 1 mm (0.04 in) on brackets 1 and 6 of the cylinder head.

17. Install the camshaft.

18. Install the camshaft brackets (these are numbered from 1 to 6 and bearing (1) should be positioned on the flywheel end).

 : 10 N·m (1.0 kg·m, 7 ft-lb)



MBIB0427E

Assembly

ASSEMBLY OF THE CYLINDER HEAD


1. Install new valves and grind them gently into their respective seats. Clean all the parts thoroughly, mark them for identification purposes, then carry out the refitting operation.

Lubricate the inside of the valve guide.

- It is imperative to fit the valve stem seals using Tool KV113B0180 (Mot. 1511-01) or suitable tool.

NOTE:


Do not lubricate the valve stem seals before fitting them.



MBIB0421E

New Valve Stem Seals

1. Place the valve in the cylinder head.
2. Place the barrel of Tool KV113B0180 (Mot. 1511-01) over the valve stem (the inner diameter of the barrel must be identical to the diameter of the valve stem).




MBIB0422E


OVERHAUL

[K9K]


3. Keep the valve pressed against its seat.
4. Place the valve stem seal (not lubricated) over the tool barrel.




5. Push the valve stem seal past the tool barrel, then withdraw the barrel.



6. Place the guide tube plus push rod assembly on the valve stem seal.
7. Push the valve stem seal down by tapping the top of the sleeve with the palm of your hand until the guide tube touches the cylinder head.
8. Repeat these operations for all the valves.




9. Install the valve springs and upper cups using valve spring compressor.
10. Install the keys using tweezers.



11. Check the valve protrusion using KV113B0040 (Mot. 251-01) and KV113B0050 (Mot. 252-01) as shown.


Valve protrusion : **-0.07 to 0.07 mm (-0.0028 to 0.0028 in)**




Camshaft Seal

- This engine can be fitted with two different types of seals. Old and new seals are easily recognized.

 1. The old rubber seal is installed with a spring (A) and has a "V"-shaped sealing lip (B).




2. The new rubber seal has a flat sealing lip (C) and a protector (D) which also assists in installing the seal to the engine.




OVERHAUL

[K9K]


3. Screw the shouldered rod of Tool KV113B0230 (Mot. 1632) onto the stud of the camshaft.
4. Install the old seal on the camshaft.




5. For the new seal, put the protector with the seal on the cam-shaft, taking care not to touch the seal.




6. Install the cover (E) and the collar nut (F) of Tool KV113B0230 (Mot. 1632).




7. Screw the collar nut until the cover touches the cylinder head.




8. Remove the nut, the cover, the protector and the shouldered rod.
9. Install the camshaft pulley. Tighten the new nut to a torque of 30 N·m (3.1 kg-m, 22 ft-lb) plus an angle tightening of 84°.




10. Install the vacuum pump with a new gasket. Tighten the bolts to a torque of 21 N·m (2.1 kg-m, 15 ft-lb).
11. Install water outlet unit with a new gasket. Tighten the bolts to a torque of 26 N·m (2.7 kg-m, 19 ft-lb).



12. Install the exhaust manifold with new gasket. Tighten the bolts to a torque of 26 N·m (2.7 kg-m, 19 ft-lb) in the numerical order as shown.
13. Install the EGR unit with new clips. Tighten the mounting bolts of the valve to a torque of 21 N·m (2.1 kg-m, 15 ft-lb), then tighten the clips of the pipe using Tool KV113B0190 (Mot. 1567).
14. Install the air inlet pipe with a new seal.
15. Install the front engine slinger.




16. Clean the injector sockets and the injector bodies, as well as their brackets using a lint-free cloth (use the wipes recommended for this purpose) dipped in clean solvent. Dry off using a different new wipe. Replace the compression washer with a new washer.
17. Install the injectors (using the marks made during removal). Tighten the mounting flanges to a torque of 28 N·m (2.9 kg-m, 21 ft-lb).
18. Install the glow plugs. Tighten them to a torque of 15 N·m (1.5 kg-m, 11 ft-lb).
19. Install the rear engine slinger.
20. Install fuel injection pump and related parts. Refer to EC-K9K-20, "High pressure pump", "DIESEL EQUIPMENT" in EC section.




Disassembly of The Bottom Engine REMOVAL

EBS01C74


1. Install the Tool KV113B0060 (Mot. 582-01).




2. Remove the clutch housing.
3. Remove the flywheel.



4. Remove the oil pan bolt in reverse order as shown.



5. Remove the baffle plate.



A

EM

C

D

E

F

G

H

I


J

K


L

M


6. Remove the oil level sensor.
7. Remove the oil pump.



8. Remove the rear oil seal retainer.
9. Remove the water pump.



10. Remove the oil pump chain.
11. Remove the oil pump drive sprocket.



WARNING:


Do not use a sharp point to mark the bearing caps in relation to their connecting rods to avoid starting a crack in the rod. Use a permanent marker pen.

12. Remove the big end cap bolts and the connecting rod/piston assemblies.


NOTE:

It is essential to mark the position of the main bearing cap, as the category may be different for each bearing.


13. Remove the main bearing caps.
14. Remove the crankshaft.



15. Remove the oil pressure switch, the knock sensor and oil filter bracket connecting bolt.




16. Remove the oil cooler connecting bolt.



REPLACEMENT OF THE OIL JETS


Removal

1. To remove the oil jets (A), they must be drilled with a 7 mm (0.28 in) diameter drill. This is necessary in order to remove the spring stop (B) and the spring (C).




NOTE:


Do not remove the ball (D) to prevent from entering the cooling circuit.




2. Remove the using a suitable brush.



3. Screw Tool KV113B0120 (Mot. 1485-01) in the drilled out jets using a 6 mm (0.24 in) Allen key which must slide into the tool.



4. Screw Tool KV113B0020 (Emb. 880) onto KV113B0120 (Mot. 1485-01) and remove the oil jet.




Assembly

INSTALLATION OF OIL JETS

- The oil jets must be installed using Tool KV113B0170 (Mot. 1494).

Installation of The Oil Jets For No. 1 and No. 3 Cylinders


- Install plate (A) of Tool KV113B0170 (Mot. 1494) onto the cylinder block (as shown in the figure) without tightening the two bolts (C).
- Position the guide rod (B) in the plate (A) and the end of the guide rod in the hole of the oil jet to center the plate (A).
- Tighten the two bolts (C).
- Remove the guide rod.




5. Install the push rod instead of the guide rod, then insert the oil jet into the push rod.

NOTE:


Check that the oil jet is correctly oriented with the end of the jet (D) directed towards the center of the cylinder.



6. With a hammer, tap the push rod until the shoulder (E) of the push rod comes into contact with the plate (A).

**Installation of The Oil Jets For No. 1 and No. 4 Cylinders**


1. Fit plate (A) of Tool KV113B0170 (Mot. 1494) onto the cylinder block (as shown in the figure) without tightening the two bolts (C).
2. Position the guide rod (B) in the plate (A) and the end of the guide rod in the hole of the oil jet to center the plate (A).
3. Tighten the two bolts (C).
4. Remove the guide rod.




5. Position the push rod instead of the guide rod, then insert the oil jet into the push rod.

NOTE:

Check that the oil jet is correctly oriented with the end of the jet (D) directed towards the center of the cylinder.




6. With a hammer, tap the push rod until the shoulder (E) of the push rod comes into contact with the plate (A).



Orientation Of The Oil Jets (See Diagram Below)

A	Orientation of the oil jets of No. 2 and No. 4 cylinders
B	Orientation of the oil jets of No. 1 and No. 3 cylinders

1. Clean the cylinder block and crankshaft by passing a wire through the lubrication channels.



METHOD FOR INSTALLING THE OIL COOLER AND OIL FILTER

1. Install oil cooler. Refer to [LU-16, "OIL COOLER"](#) .
2. Install oil filter. Refer to [LU-14, "OIL FILTER"](#) .

Removing The Piston Pins

EBS01C76



NOTE:

It is imperative to mark the connecting rod to match it to its piston, because the piston height classes in the same engine may be different (see Technical Specifications section).

To remove the piston pin, remove the snap ring using a screwdriver, then release the pin.


CONNECTING ROD BEARING

1. The connecting rod bearing are installed using Tool KV113B0140 (Mot. 1492) and Tool KV113B0150 (Mot. 1492-03).




ON THE CONNECTING ROD BODY

1. Slide the connecting rod bearing support (A) of Tool KV113B0150 [Mot. 1492-03 (positioning the engraved mark (B) as shown in the figure)] into the groove (C) of the base of Tool KV113B0140 (Mot. 1492).




MBIB0462E

2. Install the guide (D) of Tool KV113B0150 (Mot. 1492-03) onto the base (as shown in the figure).




MBIB0463E

3. Lay the body of the connecting rod on the base of the tool (as shown in the diagram). Check that the lower part (E) of the small end is touching the centering pin and push the guide (G) in the direction of the arrow.




MBIB0464E

4. Lay the connecting rod bearing [with a width of 20.625 mm (0.8120 in)] (F) on the connecting rod bearing support, then push it in the direction of the arrow (as shown in the figure).




MBIB0465E

5. Bring the connecting rod support up against the base of the connecting rod body.
6. Remove the connecting rod body support and repeat the operation for the remaining connecting rod bodies.




ON THE CONNECTING ROD CAP


1. Position the connecting rod bearing support either on the engraved mark (C) if the width of the connecting rod bearing is equal to 20.625 mm (0.8120 in).
2. Position the connecting rod bearing support either on the engraved mark (D) if the width of the connecting rod bearing is equal to 17.625 mm (0.6939 in).




3. Install the connecting rod cap as shown in the figure.




4. Push the guide (in the direction of the arrow) until the connecting rod cap is in contact with the pins (I) on the base of the tool.



5. Install the connecting rod bearing (H) on the bearing support, then push it in the direction of the arrow (as shown in the figure).




6. Bring the connecting rod bearing support up against the base of the connecting rod cap.
7. Remove the connecting rod bearing support and repeat the operation for the remaining connecting rod caps.




INSTALLATION OF MAIN BEARING

1. Position the grooved main bearing on the cylinder block.




2. Install the smooth bearing cap on the bearings.




ON THE CYLINDER BLOCK


1. Position tool KV113B0160 (Mot. 1493-01) on the cylinder block.




2. Install the bearing cap in Tool KV113B0160 (Mot. 1493-01), then press at (A) until the bearing cap is touching at (B) with KV113B0160 (Mot. 1493-01).

**ON THE BEARING CAPS**


1. Position Tool KV113B0160 (Mot. 1493-01) on the bearing cap.




2. Install the main bearing in Tool KV113B0160 (Mot. 1493-01), then press at (A) until the main bearing is touching at (B) with Tool KV113B0160 (Mot. 1493-01).



3. Oil the main bearing.
4. Install the crankshaft.
5. Install the lateral shims on bearing No. 3, putting the grooves on the crankshaft side.
6. Install the main bearing caps on bearing cap No. 1 (these are numbered from 1 - 5 and these numbers should be positioned opposite the water pump). Then tighten the bolts to a torque of 27 N·m (2.8 kg-m, 20 ft-lb) plus an angle tightening of $47^\circ \pm 5^\circ$.




7. Check the lateral clearance of the crankshaft which should be without wear on lateral shims: 0.045 - 0.252 mm (0.0018 - 0.0099 in)
8. Check the lateral clearance of the crankshaft which should be with wear on the lateral shims: 0.045 - 0.852 mm (0.0018 - 0.0335 in)



INSTALLATION OF NO. 1 BEARING

1. **Degrease the gasket faces (of the cylinder block and bearing No. 1). They should be clean, dry and free from grease (in particular, remove finger marks).**
2. Lay two beads of liquid sealant with a width of 1 mm (0.04 in) on bearing No. 1 of the cylinder block.
Tighten the bolts of bearing cap No. 1 to a torque of 27 N·m (2.8 kg-m, 20 ft-lb) plus an angle tightening of $47^\circ \pm 5^\circ$.




CONNECTING RODS / PISTON ASSEMBLY

- The pistons have a mark engraved on their heads indicating the engine rear side.

1. Oil the piston pin.
2. Check that the piston pins rotate correctly in the new piston and in the matching connecting rod.


Direction Of Installation Of The Connecting Rod In Relation To The Piston

- Point the mark (A) engraved on the top of the piston upwards and the flat (B) of the big end downwards as shown in the figure.



DIRECTION FOR INSTALLATION THE SNAP RINGS ON THE PISTON


- Position the opening (C) of the snap rings opposite the removal and fitting channel (D).

**INSTALLATION OF THE SNAP RINGS**


- Rings set to their original adjustment must be free within their channels.
- Ensure the snap rings are fitted the correct way, with the word TOP pointing upwards.

Orientation Of The Piston Rings In The Piston


- Ensure the break in each piston ring is correctly oriented as shown in the figure.



- Apply new engine oil to the pistons.
- Install the connecting rod/piston assemblies into the cylinder block using the ring, being careful to fit them the right way round (mark towards the flywheel).
- Install the connecting rods onto the oiled crankshaft pins of the crankshaft.
- Install the connecting rod caps, ensuring they are correctly matched.
- Tighten the big end cap bolts to a torque of 20 N·m (2.0 kg-m, 15 ft-lb), plus an angle tightening of $45^\circ \pm 6^\circ$.
- Inspect that the big ends have the correct lateral clearance of 0.205 to 0.467 mm (0.0081 to 0.0184 in).

**CHECKING PISTON PROTRUSION**

- Clean the piston head.
- Turn the crankshaft one turn in its operating direction to bring piston No. 1 close to TDC.
- Install Tool KV113B0050 (Mot. 252-01) on the piston.
- Install Tool KV113B0040 (Mot. 251-01) equipped with a gauge on support plate KV113B0050 (Mot. 252-01), and find TDC.


**NOTE:**

All measurements must be carried out along the longitudinal axis of the engine, in order to eliminate any errors due to tilting of the piston.

WARNING:


The gauge follower must not be in the valve clearance.

5. Inspect the piston protrusion which must be 0.099 to 0.285 mm (0.0039 to 0.0112 in).



INSTALLATION OF REAR OIL SEAL RETAINER AND OIL PUMP

1. Tighten the knock sensor to a torque of 20 N·m (2.0 kg-m, 15 ft-lb).
2. Tighten the oil pressure switch to a torque of 22 N·m (2.2 kg-m, 16 ft-lb).
3. Install the oil pump sprocket and chain to a torque of 25 N·m (2.6 kg-m, 18 ft-lb).




NOTE:


The gasket faces (cylinder block, rear oil seal retainer and water pump) must be clean, dry and free from grease (in particular, remove finger marks).

The rear oil seal retainer should be applied with liquid gasket. The bead (A) must be 1.5 to 2 mm (0.059 to 0.079 in) wide and be applied in accordance with the figure.

- Use Genuine Liquid Gasket or equivalent.





4. Install the rear oil seal retainer.
 - Tighten bolts 1 and 6 to a torque of 8 N·m (0.8 kg-m, 71 in-lb).
 - Tighten bolts 2, 3, 4 and 5 to a torque of 12 N·m (1.2 kg-m, 9 ft-lb).
 - Tighten bolts 1 and 6 to a torque of 12 N·m (1.2 kg-m, 9 ft-lb).
5. Put a new gasket to water pump face and install the water pump. Put a drop of locking sealant on the bolts, then tighten them to a torque of 11 N·m (1.1 kg-m, 8 ft-lb) in the numerical order.
 - Use Genuine thread locking sealant or equivalent.




NOTE:

The gasket faces (cylinder block and rear oil seal retainer) must be clean, dry and free from grease (in particular, remove finger marks).


6. Apply four beads (B) of liquid gasket, with a diameter of 5 mm (0.20 in).
7. Apply two drops (C) of liquid gasket, with a diameter of 7 mm (0.28 in) at the intersection of the rear oil seal retainer and the cylinder block.
 - Use Genuine Liquid Gasket or equivalent.



8. When installing the oil pan, ensure that the tabs (D) of the baffle plate are correctly positioned in the slots (E).
9. When installing the oil pan, ensure that the cylinder block and the oil pan are correctly aligned on the flywheel side, to prevent the clutch housing from being damaged when installing the transaxle.
10. Install the baffle plate.




11. Install the oil pan and tighten the bolts as follows:
 - Tighten the bolts in the numerical order shown in the figure to a torque of 8 N·m (0.8 kg-m, 71 in-lb).
 - Tighten the mounting bolts of oil pan on the clutch housing without locking.
 - Tighten the bolts in the numerical order shown in the figure to a torque of 15 N·m (1.5 kg-m, 11 ft-lb).
 - Tighten the mounting bolts of oil pan on the clutch housing to a torque of 44 N·m (4.5 kg-m, 32 ft-lb).




INSTALLATION OF THE CRANKSHAFT SEAL GASKETS


1. Crankshaft elastomer seal, timing side.
2. Screw the threaded rod (A) of Tool KV113B0220 (Mot. 1586) into the crankshaft.




3. Position the spacer (B) of Tool KV113B0220 (Mot. 1586) on the crankshaft.



4. Install the protector complete with the seal onto the spacer, taking care not to touch the seal.





5. Install the cover (A) and the nut (B) (putting the threaded part (C) of the nut on the side away from the engine) of Tool KV113B0220 (Mot. 1586).




OVERHAUL

[K9K]


6. Tighten the nut until the cover touches the spacer.



7. Remove the nut, the cover, the protector and the threaded rod.




8. Crankshaft elastomer seal, flywheel side.
9. Install Tool KV113B0210 (Mot. 1585) on the crankshaft, securing it with bolts (F).



OVERHAUL


[K9K]

10. Put the protector complete with the seal on Tool KV113B0210 (Mot. 1585), being careful not to touch the seal.




MBIB0495E

11. Install the cover (G) and nut (H) (putting the threaded part (I) of the nut on the side away from the engine) of Tool KV113B0210 (Mot. 1585).




MBIB0496E

12. Tighten the nut until the cover touches the cylinder block.




MBIB0497E




MBIB0498E

13. Remove the nut, the cover, the protector and the threaded rod.




14. Install Tool KV113B0060 (Mot. 582-01) and tighten the new bolts to a torque of 50 to 55 N·m (5.1 to 5.6 kg-m, 37 to 40 ft-lb).



15. Install the clutch housing, tightening the bolts to a torque of 8 N·m (0.8 kg-m, 71 in-lb).

16. Remove Tool KV113B0060 (Mot. 582-01).




INSTALLATION OF THE CYLINDER HEAD

1. Position the pistons at mid-stroke.
2. Install the cylinder head gasket using the centering dowels of the cylinder block.
3. Tighten the cylinder head, Refer to [EM-162, "ASSEMBLY OF THE CYLINDER HEAD"](#).


NOTE:

The gasket faces (cylinder head and rocker cover) must be clean, dry and free from grease (in particular, remove finger marks).


4. Lay four beads (A) of liquid gasket, with a diameter of 2 mm (0.08 in).
 - Use Genuine Liquid Gasket or equivalent.




5. Install the rocker cover, tightening the bolts to a torque of 10 N·m (1.0 kg-m, 7 ft-lb) in the numerical order as shown.




6. Put new seals on the pipe ends and install the turbocharger oil return pipe.
7. Install the turbocharger, tightening the nuts and the torx bolt to a torque of 26 N·m (2.7 kg-m, 19 ft-lb).
8. Install the catalytic converter bracket.
9. Install the turbocharger oil supply pipe.



10. Tighten the bolts of the turbocharger oil return pipe to a torque of 9 N·m (0.9 kg-m, 80 in-lb).
11. Tighten the nut and the bolt of the turbocharger oil supply pipe to a torque of 23 N·m (2.3 kg-m, 17 ft-lb).
12. Install the oil vapor rebreathing pipe.
13. Install the new turbocharger air ducts.



14. Install the inner timing cover.
15. Install the timing tensioner.




TIMING ADJUSTMENT**CAUTION:**


It is essential to degrease the end of the crankshaft, the bore of the crankshaft sprocket and the bearing faces of the accessories pulley to prevent any slip between the timing and the crankshaft which would risk destroying the engine.

Ensure that the peg (A) of the tension wheel is correctly positioned in the groove (B).

1. Insert Tool KV113B0110 (Mot. 1430) in the camshaft and cylinder head pulley holes.
2. Check that the mark on the high pressure pump pulley (C) is opposite the bolt head (D).
3. Check that the crankshaft is touching Tool KV113B0130 (Mot. 1489) (the crankshaft groove (E) must be facing upwards).




MBIB0507E




MBIB0395E

4. Install the timing belt, aligning the marks on the belt with those on the camshaft and fuel injection pump sprockets (19 teeth spaces on the belt between the marks on the camshaft and pump sprockets).




MBIB0508E


5. Using a 6 mm (0.24 in) Allen key, move the movable index (F) of the tension wheel into the position shown below, by turning the key counterclockwise.




6. Tighten the tension wheel bolts to a torque of 25 N·m (2.6 kg·m, 18 ft-lb).
 7. Install the crankshaft pulley, tightening the M12 bolt to a torque of 60 N·m (6.1 kg·m, 44 ft-lb), then angle tighten to $100^\circ \pm 10^\circ$, or M14 bolt to a torque of 120 N·m (12 kg·m, 89 ft-lb), then angle tighten to $95^\circ \pm 15^\circ$.
 8. Remove Tool KV113B0130 (Mot. 1489) and Tool KV113B0110 (Mot. 1430).
 9. Turn the crankshaft two full turns in a clockwise direction (timing side). Just before the hole (G) of the camshaft pulley is opposite the cylinder head hole (H), Tool KV113B0130 (Mot. 1489) into the cylinder block.
 10. Then move the crankshaft slowly and without jolting it until it is resting on the pin.



11. Check that Tool KV113B0110 (Mot. 1430) is correctly inserted in the holes of the camshaft and cylinder head pulleys and that there are 19 teeth spaces between the marks on the camshaft (I) and the fuel pump (J) sprockets.
 12. Remove Tool KV113B0130 (Mot. 1489) and Tool KV113B0110 (Mot. 1430).




13. Undo the tension wheel bolt by a maximum of one turn while holding it using a 6 mm (0.24 in) Allen key, then gradually bring the movable index (K) (by turning the key clockwise) to the center of the timing window (L) and tighten the nut to a torque of 25 N·m (2.6 kg·m, 18 ft-lb).
 14. Install the cap of the TDC pin, apply liquid gasket to the thread and tighten to a torque of 20 N·m (2.0 kg·m, 15 ft-lb).



OVERHAUL


[K9K]

15. Install the cylinder head suspended bracket. Tighten the bolts to a torque of 21 N·m (2.1 kg-m, 15 ft-lb).




MBIB0512E

16. Install the lower timing cover by positioning the tab (M) into the hole (N) on the inner timing cover.



MBIB0513E




MBIB0514E

OVERHAUL


[K9K]

17. Install the upper timing cover.
18. Remove the engine from the Tool KV113B0070 (Mot. 792-03).




MBIB0515E

19. Install the water pipe. Tighten the bolt to a torque of 22 N·m (2.2 kg-m, 16 ft-lb).
20. Install the two water hoses.




MBIB0356E

21. Install the alternator bracket. Tighten the bolts to a torque of 44 N·m (4.5 kg-m, 32 ft-lb).



MBIB0355E


22. Install the alternator. Tighten the bolts to a torque of 21 N·m (2.1 kg-m, 15 ft-lb).
23. Install the A/C compressor. Tighten the bolts to a torque of 21 N·m (2.1 kg-m, 15 ft-lb).
24. Install the power steering pump or the washer which replaces the pulley (if the engine has one). Tighten the bolts to a torque of 21 N·m (2.1 kg-m, 15 ft-lb).



25. Install the drive belt.

NOTE:


The accessories belt has five teeth as opposed to the pulleys which have six. It is therefore essential to ensure that tooth "O" remains free when installing the belt.



Models With A/C Compressor

NOTE:

The engine must be turned through two revolutions in order to position the belt correctly.




Models Without A/C Compressor

1. The belt is tensioned using tool belt tension gauge (commercial service tool) (with the two mounting bolts of the tensioner undone).
2. The tension value is 233 ± 5 Hz.

NOTE:

The engine must be turned through two revolutions in order to position the belt correctly.



BASIC INSPECTION

PFP:00013

Cylinder Head

EBS01C77

CYLINDER HEAD TIGHTENING PROCEDURE**NOTE:**


Use a syringe to remove any oil which may have entered the cylinder head mounting bolt holes to achieve correct tightening of the bolts.

1. All bolts must always be changed after removal. Do not oil the new bolts.
2. Tighten all the bolts in the numerical order as shown.

 : 25 N·m (2.6 kg-m, 18 ft-lb)


3. Check that all the bolts are correctly tightened to 25 N·m (2.6 kg-m, 18 ft-lb) then angle tightening of 245 to 265 degrees.

Do not retighten the cylinder head bolts after performing this procedure.

**THICKNESS OF THE CYLINDER HEAD GASKET**

- The thickness of the cylinder head gasket is measured at (A):

Thickness : 0.75 - 0.81 mm (0.0295 - 0.0319 in)

**INSPECTION OF THE PISTON PROTRUSION**

1. Clean the piston heads in order to eliminate any traces of deposits.
2. Turn the crankshaft one turn in its operating direction to bring piston No. 1 close to TDC.
3. Install Tool KV113B0040 (Mot. 251-01) equipped with a gauge on its base plate KV113B0050 (Mot. 252-01), and find TDC of the piston.

NOTE:


All measurements must be carried out along the longitudinal axis of the engine, in order to eliminate any errors due to tilting of the piston.

WARNING:

The gauge follower must not be in the valve clearance.

Measure the piston protrusion.

The protrusion must be: 0.099 - 0.285 mm (0.0039 - 0.0112 in).




Height of the cylinder head:

H = 127 mm (5.00 in)

Gasket face bow:

Cylinder head : 0.05 mm (0.0020 in)

Cylinder block : 0.03 mm (0.0012 in)

**NO REGRINDING IS AUTHORIZED**

Test the cylinder head to detect possible cracks using the cylinder head test container (comprising a tray and a kit suited to the cylinder head, plug, sealing plate and blanking plate).

VALVE

Valve Dimensions

Stem diameter:

Intake : 5.969 - 5.985 mm (0.2350 - 0.2356 in)
Exhaust : 5.955 - 5.971 mm (0.2344 - 0.2351 in)

Face angle:

Intake and exhaust : 90°

Head diameter:

Intake : 33.38 - 33.62 mm (1.3142 - 1.3236 in)
Exhaust : 28.88 - 29.12 mm (1.1370 - 1.1465 in)

Valve length:

Intake : 100.73 - 101.17 mm (3.9657 - 3.9831 in)
Exhaust : 100.53 - 100.97 mm (3.9579 - 3.9752 in)

Max. valve lift:

Intake : 8.015 mm (0.3156 in)
Exhaust : 8.595 mm (0.3384 in)

Protrusion of valves in relation to the cylinder head gasket face:

Intake and exhaust : -0.7 to 0.7 mm (-0.028 to 0.028 in)

VALVE SEAT

Seat angle (α):

Intake : 89°30'
and
exhaust

Contacting width (X):


Intake : 1.8 mm (0.071 in)
and
exhaust

Seat outer diameter (D):

Intake : 34.444 - 34.460 mm (1.3561 - 1.3567 in)
Exhaust : 30.034 - 30.050 mm (1.1824 - 1.1831 in)

Diameter of the housing in the cylinder head:

Intake : 34.444 - 34.474 mm (1.3561 - 1.3572 in)
Exhaust : 29.955 - 29.985 mm (1.1793 - 1.1805 in)



MBIB0327E

VALVE GUIDE

Length:

Intake and exhaust : 40.35 - 40.65 mm (1.5886 - 1.6004 in)

Guide outer diameter:

Standard : 11.044 - 11.062 mm (0.4348 - 0.4355 in)

Guide inner diameter:

Intake and exhaust

Not machined : 5.50 - 5.62 mm (0.2165 - 0.2213 in)

Machined* : 6.000 - 6.018 mm (0.2362 - 0.2369 in)

BASIC INSPECTION

[K9K]

* This dimension is measured with the guide fitted in the cylinder head.

Diameter of the housing in the cylinder head:


Standard : 10.9925 - 11.0075 mm (0.4328 - 0.4334 in)

The intake and exhaust guides have valve stem seals which must be changed each time the valves are removed.


It is imperative to fit the valve stem seals using Tool KV113B0180 (Mot. 1511-01) or suitable tool.

NOTE:

Do not lubricate the valve stem seals before fitting them.




MBIB0328E



MBIB0329E

Angle of the intake and exhaust guides (in degrees)

Intake and exhaust : $\alpha = 90$




MBIB0330E

Position of the intake and exhaust valve guides

Intake : A = 14 mm (0.55 in)

Exhaust : A = 14.2 mm (0.559 in)



MBIB0331E

VALVE SPRING

The valve springs are tapered (ensure the correct direction of fitting).

Free height: : 43.31 mm (1.7051 in)

Length under a load of

230 N (23.5 kg, 51.7 lb) : 33.80 mm (1.3307 in)

500 N (51.0 kg, 112.4 lb) : 24.80 mm (0.9764 in)

Joined spires: : 23.40 mm (0.9213 in)

Wire diameter: : 3.45 mm (0.1358 in)

Inner diameter:


Bottom : 18.78 - 18.82 mm
(0.7394 - 0.7409 in)

Top : 13.90 - 14.30 mm
(0.5472 - 0.5630 in)

Outer diameter:

Bottom : 25.50 - 25.90 mm
(1.0039 - 1.0197 in)

Top : 20.8 - 21.2 mm
(0.819 - 0.835 in)



MBIB0332E

WARNING:

This engine does not have any valve spring lower washers.

PISTON

Piston outer diameter : 34.965 - 34.985 mm (1.3766 - 1.3774 in)


Diameter of the housing in the cylinder head : 35.00 - 35.04 mm (1.3780 - 1.3795 in)

INSPECTION OF VALVE CLEARANCE

1. Place the valves of the cylinder concerned at the "end of exhaust - beginning of intake" position and inspect the clearance (X).

NOTE:

Dimension (Y) corresponds to the tappet thickness sizes (there are 25 sizes at the service parts).



MBIB0333E

2. Compare the values recorded with the values specified, then replace the tappets which are not within tolerance.

Clearance, when the engine is cold:


Intake : 0.125 - 0.25 mm (0.0049 - 0.0098 in)

Exhaust : 0.325 - 0.45 mm (0.0128 - 0.0177 in)

3. The camshaft must be removed to replace the tappets.

Determining dimension "Y".

4. Set up the following assembly using Tool KV113B0050 (Mot. 252-01) and dial gauge, then calibrate the gauge.




MBIB0334E

5. Raise the gauge extension (without modifying the position of the magnetic support/gauge assembly), then slide in the tappet to be measured.

Note dimension (Y) and repeat the operation for the tappets where the valve clearance is not within tolerance.

Refer to the Replacement Parts Catalogue for the vehicle concerned to select the various thicknesses of the tappet(s). The service parts supplies 25 sizes of single-piece tappets.



CAMSHAFT

End play : 0.08 - 0.178 mm (0.0031 - 0.0070 in)

Number of bearings : 6

Diameter of the camshaft bearings

On the camshaft:

Bearings 1, 2, 3, 4, 5 : 24.979 - 24.999 mm (0.9834 - 0.9842 in)

Bearing 6 : 27.979 - 27.999 mm (1.1015 - 1.1023 in)

On the cylinder head:

Bearings 1, 2, 3, 4, 5 : 25.04 - 25.06 mm (0.9858 - 0.9866 in)

Bearing 6 : 28.04 - 28.06 mm (1.1039 - 1.1047 in)

Timing diagram

Intake opening retard * : -9

Intake closing retard : 20


Exhaust opening advance : 27

Exhaust closing advance ** : -7

* As the intake opening retard is negative, the valve is opened after TDC.

** As the exhaust closing advance is negative, the valve is closed before TDC.

1	Cylinder block TDC fixed mark
2	Flywheel TDC moving mark
3	Flywheel BDC moving mark
4	Intake Opening Retard
5	Exhaust Closing Advance
6	Intake Closing Retard
7	Exhaust Opening Advance
8	Direction of engine rotation (flywheel end).




Piston

EBS01C78

- Install the piston pin in the connecting rod and in the piston.
- The piston pin is retained by circlips.

PISTON MARKING

1	Direction of fitting of the piston mark towards the flywheel
2	Height between the piston pin and the top of the piston (see table below).
3	Used by the supplier only
4	Used by the supplier only
5	Used by the supplier only
6	Piston axis of symmetry
7	Piston pin hole axis
8	Offset between the hole axis (7) and the piston's axis of symmetry (6) is 0.3 mm (0.012 in)



MBIB0337E

TABLE OF PISTON PIN HEIGHT

Unit: mm (in)

* Mark on piston	Piston pin height
K	41.667 (1.6404)
L	41.709 (1.6421)
M	41.751 (1.6437)
N	41.793 (1.6454)
P	41.835 (1.6470)

The tolerance on the piston pin heights is ± 0.02 mm (± 0.0008 in).

* The different piston pin heights are exclusively reserved for the engine assembly plant.
The service parts will only supply piston classes (height) L, M, N.


NOTE:

- If the engine is installed with a K class piston, an L class piston must be installed as a replacement.
- If the engine is installed with a P class piston, an N class piston must be installed as a replacement.

MEASURING THE PISTON DIAMETER

The piston diameter must be measured at height A = 56 mm (2.20 in).

Piston diameter	: 75.933 - 75.947 mm (2.9895 - 2.9900 in)
Piston pin:	
Length	: 59.7 - 60.3 mm (2.350 - 2.374 in)
Outer diameter	: 24.8 - 25.2 mm (0.976 - 0.992 in)
Inner diameter	: 13.55 - 13.95 mm (0.5335 - 0.5492 in)




MBIB0338E

PISTON RING

Thickness:

Top ring	: 1.97 - 1.99 mm (0.0776 - 0.0783 in)
2nd ring	: 1.97 - 1.99 mm (0.0776 - 0.0783 in)
Oil ring	: 2.47 - 2.49 mm (0.0972 - 0.0980 in)

The piston rings are supplied ready adjusted.



PISTON RING END GAP

Top ring	: 0.20 - 0.35 mm (0.0079 - 0.0138 in)
2nd ring	: 0.70 - 0.90 mm (0.0276 - 0.0354 in)
Oil ring	: 0.25 - 0.50 mm (0.0098 - 0.0197 in)


Connecting Rod

EBS01C79

The connecting rod is of the detachable cap type.

WARNING:

- The bolts must be coated with engine oil under the heads and on the threads when the connecting rods are installed in the engine.
- The big end caps are positioned on the connecting rod by irregularities on the parting line.
- The occurrence of impacts or a foreign body between the body - cap mating surfaces will lead to rapid rupture of the connecting rod.



Lateral big end play	: 0.205 - 0.467 mm (0.0081 - 0.0184 in)
Diametrical big end play	: 0.035 - 0.045 mm (0.0014 - 0.0018 in)
Center distance between the big end and small end	: 133.75 mm (5.2657 in)
Diameter of the big end	: 47.610 - 47.628 mm (1.8744 - 1.8751 in)
Diameter of the small end (without ring)	: 27.24 - 27.26 mm (1.0724 - 1.0732 in)
(with ring)	: 25.013 - 25.025 mm (0.9848 - 0.9852 in)

NOTE:

The connecting rod small end rings cannot be replaced.


BASIC INSPECTION

[K9K]

The maximum weight difference for the connecting rod, piston and piston pin assemblies for the same engine must be 0.245 N (25 g, 0.88 oz).


WARNING:

- To avoid initiating a crack in the connecting rod, do not use a sharp point to mark the big end caps in relation to their connecting rod.
- Use a permanent marker pen.




DIRECTION OF INSTALLATION OF THE CONNECTING ROD IN RELATION TO THE PISTON

- Point the mark (A) engraved on the top of the piston upwards and the machined flat (B) of the big end downwards as shown in the figure.



DIRECTION FOR INSTALLATION THE SNAP RINGS ON THE PISTON

- Position the opening (C) of the snap rings opposite of the removal and installation channel (D).



Crankshaft

EBS01C7A

Number of main journals : 5

Crankshaft side clearance:

Without wear on side shims : 0.045 - 0.252 mm (0.0018 - 0.0099 in)

With wear on side shims : 0.045 - 0.852 mm (0.0018 - 0.0335 in)

Crankshaft diametrical clearance:

Journals : 0.027 - 0.054 mm (0.0011 - 0.0021 in)

Crankshaft pins : 0.035 - 0.045 mm (0.0014 - 0.0018 in)

Journal diameter: : 47.99 - 48.01 mm (1.8894 - 1.8902 in)

Crankshaft pin diameter: : 43.96 - 43.98 mm (1.7307 - 1.7315 in)

- The lateral shims are located on bearing No. 3.
- No rectifications are allowed.

BASIC INSPECTION

[K9K]

WORKING OUT THE CLASS OF MAIN BEARING (ORIGINAL FITMENT)

Marking (A) On The Crankshaft

Detail of the marking (A):

Number of journals

1*	2	3	4	5	Classes of journal diameters
B	B	C	C	B	A = D1 B = D2 C = D3

* Flywheel end.




Table Of Journal Diameter Classes

Unit: mm (in)

Journal class mark on the crankshaft	Journal diameter
A = D1	47.990 - 47.996 (1.8894 - 1.8896)
B = D2	47.997 - 48.003 (1.8896 - 1.8899)
C = D3	48.004 - 48.010 (1.8899 - 1.8902)

Cylinder Block

EBS01C7B

The diameters of the bearings (A) of the cylinder block are marked by a hole on the block (B) located above the oil filter.





TABLE OF CYLINDER BLOCK MAIN BEARING HOUSING INNER DIAMETERS

Hole position (B)	Class reference	Cylinder block main bearing housing inner diameter
X = 33 mm (1.30 in)	1 or blue	51.936 - 51.942 mm (2.0447 - 2.0450 in)
Y = 43 mm (1.69 in)	2 or red	51.942 - 51.949 mm (2.0450 - 2.0452 in)

NOTE:

The marking zone includes:

BASIC INSPECTION

[K9K]

- X - Y gives the diameter class of bearings A or B.

MATCHING THE MAIN BEARING

	Journal diameter class		
	D1	D2	D3
1*	C1 1.949 - 1.955 mm (0.0767 - 0.0770 in) yellow	C2 1.946 - 1.952 mm (0.0766 - 0.0769 in) blue	C3 1.943 - 1.949 mm (0.0765 - 0.0767 in) black
2*	C4 1.953 - 1.959 mm (0.0769 - 0.0771 in) red	C1 1.949 - 1.955 mm (0.0767 - 0.0770 in) yellow	C2 1.946 - 1.952 mm (0.0766 - 0.0769 in) blue
Bearing thickness and class			

* Cylinder block main bearing diameter class.

NOTE:

The service parts will only supply class C2 (blue).


Main Bearing and Cap

MAIN BEARING

EBS01C7C


- The engine is installed with main bearing without a locator notch.

1. The main bearings are installed on the cylinder block and on the bearings using Tool KV113B0160 (Mot. 1493-01).




MBIB0347E

2. For direction of installation on the cylinder block, install grooved main bearing on all the bearings.



MBIB0348E

3. For direction of installation on the bearing caps, install non-grooved main bearing.



MBIB0349E

CONNECTING ROD BEARING

- The engine is installed with connecting rod bearing without a locator notch.


NOTE:

The upper and lower connecting rod bearing are not the same width.



Connecting rod bearing width:

Upper bearing : 20.625 mm (0.8120 in)

Lower bearing : 17.625 mm (0.6939 in)




- The connecting rod bearing are installed using Tool KV113B0140 (Mot. 1492) and Tool KV113B0150 (Mot. 1492-03).

**Preparing the engine to be on the stand**

EBS01C7D

Before the engine is mounted on the Tool KV113B0070 (Mot. 792-03), the engine's electrical harness must be removed and the engine oil drained.


- Remove the drive belt.




BASIC INSPECTION

[K9K]


2. Remove the alternator.




3. Remove the air conditioning compressor or idler pulley.
4. Remove the multifunction support.



5. Remove the coolant inlet pipe on the water pump.



6. Place the rods (A), (X), (Y) or Tool KV113B0100 (Mot. 1378) on the cylinder block so that they fit into the holes (20, 32, 33) on the plate of Tool KV113B0070 (Mot. 792-03).



Parts To Be Replaced After Removal

EBS01C7E

- All gaskets
- Flywheel bolts
- Crankshaft bearing bolts
- Camshaft pulley bolt
- Crankshaft pulley bolts
- Big end cap bolts
- Injector holder copper washers
- Fuel injection tubes

BASIC INSPECTION

[K9K]

- Pipe plugs
- Belts
- Timing belt tension wheel
- Oil jets
- Turbocharger plastic pipes

A

EM

Installation of Thread Inserts

EBS01C7F

Threaded holes on all engine component parts can be repaired by using thread inserts.

C

D

E

F

G

H

I

J

K

L

M

BASIC INSPECTION

[K9K]
