

SECTION **LT**
LIGHTING SYSTEM

A
B
C

CONTENTS

D
E

PRECAUTIONS	5	Side)	34
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	High-Beam Indicator Does Not Illuminate	35
HEADLAMP - CONVENTIONAL TYPE-	6	Headlamp Low Beam Does Not Illuminate (Both Sides)	35
Component Parts and Harness Connector Location...	6	Headlamp Low Beam Does Not Illuminate (One Side)	38
System Description	6	Headlamp Low Beam And High Beam Does Not Illuminate (One Side)	38
OUTLINE	6	Headlamps Do Not Turn OFF	39
COMBINATION SWITCH READING FUNCTION ...	7	Aiming Adjustment	40
FRIENDLY LIGHTING FUNCTION	7	PREPARATION BEFORE ADJUSTING	40
FAIL-SAFE FUNCTION	7	LOW BEAM AND HIGH BEAM	40
CAN Communication	8	ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)	40
SYSTEM DESCRIPTION	8	Bulb Replacement	41
CAN Communication Unit	8	HEADLAMP	41
TYPE 1/TYPE 2	9	CLEARANCE LAMPS (PARKING LAMPS)	41
TYPE 3/TYPE 4	12	Removal and Installation	41
TYPE 5/TYPE 6	14	REMOVAL	41
TYPE 7/TYPE 8	17	INSTALLATION	41
TYPE 9/TYPE 10	19	HEADLAMP - DAYTIME LIGHT SYSTEM -	42
Wiring Diagram — H/LAMP—	22	Component Parts and Harness Connector Location..	42
Terminals and Reference Value for BCM	24	System Description	42
Terminals and Reference Values for IPDM E/R	25	HEADLAMP OPERATION	43
How to Proceed With Trouble Diagnosis	26	COMBINATION SWITCH READING FUNCTION ..	44
Preliminary Check	26	DAYTIME LIGHT OPERATION	44
CHECK POWER SUPPLY AND GROUND CIRCUIT	26	FRIENDLY LIGHTING FUNCTION	44
CONSULT-II Functions (BCM)	28	FAIL-SAFE FUNCTION	44
CONSULT-II BASIC OPERATION	28	CAN Communication	45
WORK SUPPORT	29	SYSTEM DESCRIPTION	45
DATA MONITOR	29	CAN Communication Unit	45
ACTIVE TEST	30	TYPE 1/TYPE 2	46
SELF-DIAGNOSTIC RESULTS	30	TYPE 3/TYPE 4	49
CONSULT-II Functions (IPDM E/R)	31	TYPE 5/TYPE 6	51
CONSULT-II BASIC OPERATION	31	TYPE 7/TYPE 8	54
SELF-DIAG RESULTS	32	TYPE 9/TYPE 10	56
DATA MONITOR	32	Wiring Diagram — DTRL —	59
ACTIVE TEST	33	WITH GASOLINE ENGINE	59
Headlamp High Beam Does Not Illuminate (Both Sides)	33	WITH DIESEL ENGINE	61
Headlamp High Beam Does Not Illuminate (One		Terminals and Reference Value for BCM	63

F
G
H
I
J
L
M



Terminals and Reference Values for IPDM E/R	64	COMBINATION SWITCH READING FUNCTION	100
How to Proceed With Trouble Diagnosis	64	CAN Communication	101
Preliminary Check	64	SYSTEM DESCRIPTION	101
CHECK POWER SUPPLY AND GROUND CIR- CUIT	64	CAN Communication Unit	101
CONSULT-II Function (BCM)	65	TYPE 1/TYPE 2	102
CONSULT-II Function (IPDM E/R)	65	TYPE 3/TYPE 4	105
Daytime Light Control Does Not Operate Properly..	65	TYPE 5/TYPE 6	107
Headlamp High Beam Does Not Illuminate (Both Sides)	67	TYPE 7/TYPE 8	110
RH High beam Does Not Illuminate	67	TYPE 9/TYPE 10	112
Headlamp LH High Beam Does Not Illuminate	68	Wiring Diagram — R/FOG —	115
Headlamp Low Beam Does Not Illuminate (Both Sides)	68	Terminals and Reference Value for BCM	117
RH Low Beam Does Not Illuminate	68	How to Proceed With Trouble Diagnosis	118
Headlamp LH Low Beam Does Not Illuminate	70	Preliminary Check	118
High-Beam Indicator Lamp Does Not Illuminate	70	CHECK POWER SUPPLY AND GROUND CIR- CUIT	118
Headlamps Do Not Turn OFF	70	CONSULT-II Function (BCM)	119
Aiming Adjustment	70	Rear Fog Lamp Does Not Illuminate	119
Bulb Replacement	70	Bulb Replacement	120
Removal and Installation	70	Removal and Installation	120
HEADLAMP AIMING CONTROL	71	TURN SIGNAL AND HAZARD WARNING LAMPS.121	
Wiring Diagram— H/AIM —	71	System Description	121
Switch Circuit Inspection	73	TURN SIGNAL OPERATION	121
Removal and Installation	73	HAZARD LAMP OPERATION	121
FRONT FOG LAMP	74	MULTI-REMOTE CONTROL SYSTEM OPERA- TION	122
System Description	74	COMBINATION SWITCH READING FUNCTION	123
OUTLINE	74	CAN Communication	124
COMBINATION SWITCH READING FUNCTION..	74	SYSTEM DESCRIPTION	124
FAIL-SAFE FUNCTION	74	CAN Communication Unit	124
CAN Communication	75	TYPE 1/TYPE 2	125
SYSTEM DESCRIPTION	75	TYPE 3/TYPE 4	128
CAN Communication Unit	75	TYPE 5/TYPE 6	130
TYPE 1/TYPE 2	76	TYPE 7/TYPE 8	133
TYPE 3/TYPE 4	79	TYPE 9/TYPE 10	135
TYPE 5/TYPE 6	81	Wiring Diagram — TURN —	138
TYPE 7/TYPE 8	84	Terminals and Reference Value for BCM	140
TYPE 9/TYPE 10	86	How to Proceed With Trouble Diagnosis	142
Wiring Diagram — F/FOG —	89	Preliminary Check	142
WITH GASOLINE ENGINE	89	CHECK POWER SUPPLY AND GROUND CIR- CUIT	142
WITH DIESEL ENGINE	91	CONSULT-II Functions (BCM)	144
Terminals and Reference Value for BCM	93	CONSULT-II BASIC OPERATION	144
Terminals and Reference Values for IPDM E/R	93	WORK SUPPORT	145
How to Proceed With Trouble Diagnosis	94	DATA MONITOR	145
Preliminary Check	94	ACTIVE TEST	146
CHECK POWER SUPPLY AND GROUND CIR- CUIT	94	Turn Signal Lamp Does Not Operate	147
CONSULT-II Function (BCM)	95	Hazard Lamp Does Not Operate	148
CONSULT-II Function (IPDM)	95	Turn Signal Indicator Lamp Does Not Operate	150
Front fog lamps Does Not Illuminate (Both Sides)..	95	Bulb Replacement	150
Front Fog Lamp Does Not Illuminate (One Side) ...	96	FRONT TURN SIGNAL LAMP	150
Aiming Adjustment	98	SIDE TURN SIGNAL LAMP	150
Bulb Replacement	98	REAR TURN SIGNAL LAMP	150
Removal and Installation	98	Removal and Installation	150
REMOVAL	98	FRONT TURN SIGNAL LAMP	150
INSTALLTION	99	SIDE TURN SIGNAL LAMP	151
REAR FOG LAMP	100	REAR TURN SIGNAL LAMP	151
System Description	100	PARKING, LICENSE PLATE AND TAIL LAMPS ...152	
OUTLINE	100	System Description	152
		OPERATION BY LIGHTING SWITCH	152

COMBINATION SWITCH READING FUNCTION	152	HAZARD SWITCH	188	
FAIL-SAFE FUNCTION	153	Removal and Installation	188	A
CAN Communication	154	REMOVAL	188	
SYSTEM DESCRIPTION	154	INSTALLATION	188	
CAN Communication Unit	154	COMBINATION SWITCH	189	B
TYPE 1/TYPE 2	155	System Description	189	
TYPE 3/TYPE 4	158	COMBINATION SWITCH READING FUNCTION	189	
TYPE 5/TYPE 6	160	Wiring Diagram — COMBSW —	192	C
TYPE 7/TYPE 8	163	CONSULT-II Functions (BCM)	193	
TYPE 9/TYPE 10	165	CONSULT-II BASIC OPERATION	193	
Schematic	168	DATA MONITOR	195	D
Wiring Diagram — TAIL/L —	169	Check Combination Switch	196	
Terminals and Reference Value for BCM	172	Removal and Installation	199	
Terminals and Reference Value for IPDM E/R	172	REMOVAL	199	
How to Proceed With Trouble Diagnosis	173	INSTALLATION	199	E
Preliminary Check	173	INTERIOR ROOM LAMP	200	
CHECK POWER SUPPLY AND GROUND CIRCUIT	173	System Description	200	
CONSULT-II Function (BCM)	174	POWER SUPPLY AND GROUND	200	F
CONSULT-II Function (IPDM E/R)	174	SWITCH OPERATION	201	
Parking, License Plate And Tail Lamps Does Not Illuminate	174	INTERIOR ROOM LAMP TIMER OPERATION	201	
Parking Lamp Does Not Illuminate (One Side)	175	ON-OFF CONTROL	201	G
Rear Combination Lamp (Tail lamp) Does Not Illuminate (One Side)	176	CAN Communication	202	
License plate Lamp Does Not Illuminate	178	SYSTEM DESCRIPTION	202	
Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)	179	CAN Communication Unit	202	H
Bulb Replacement	179	TYPE 1/TYPE 2	203	
PARKING LAMP	179	TYPE 3/TYPE 4	206	I
TAIL LAMP	179	TYPE 5/TYPE 6	208	
LICENSE PLATE LAMP	179	TYPE 7/TYPE 8	211	J
Removal and Installation of Parking Lamp, Tail Lamp and License Plate Lamp	180	TYPE 9/TYPE 10	213	
PARKING LAMP	180	Schematic	216	
TAIL LAMP	180	Wiring Diagram — INT/L —	217	
LICENSE PLATE LAMP	180	Terminals and Reference Value for BCM	220	
STOP LAMP	181	How to Proceed With Trouble Diagnosis	220	
Wiring Diagram— STOP/L —	181	Preliminary Check	221	
Bulb Replacement	182	CHECK POWER SUPPLY AND GROUND CIRCUIT	221	LT
STOP LAMP	182	CONSULT-II Functions (BCM)	222	
HIGH-MOUNTED STOP LAMP	182	CONSULT-II BASIC OPERATION	222	
Removal and Installation	182	DATA MONITOR	223	L
STOP LAMP	182	ACTIVE TEST	224	
HIGH-MOUNTED STOP LAMP	182	Room Lamp Does Not Operate	225	
BACK-UP LAMP	183	Luggage Room Lamp Does Not Illuminate	227	M
Wiring Diagram — BACK/L —	183	Bulb Replacement	229	
Bulb Replacement	185	Removal and Installation	229	
Removal and Installation	185	REMOVAL	229	
REAR COMBINATION LAMP	186	INSTALLATION	229	
Bulb Replacement	186	ILLUMINATION	230	
REAR TURN SIGNAL LAMP BULB, BACK-UP LAMP BULB, STOP/TAIL LAMP BULB, REAR FOG LAMP BULB	186	System Description	230	
Removal and Installation	186	ILLUMINATION OPERATION BY LIGHTING SWITCH	230	
REMOVAL	186	COMBINATION SWITCH READING FUNCTION	231	
INSTALLATION	186	CAN Communication	232	
LIGHTING AND TURN SIGNAL SWITCH	187	SYSTEM DESCRIPTION	232	
Removal and Installation	187	CAN Communication Unit	232	
		TYPE 1/TYPE 2	233	
		TYPE 3/TYPE 4	236	
		TYPE 5/TYPE 6	238	
		TYPE 7/TYPE 8	241	
		TYPE 9/TYPE 10	243	

Schematic	246	BULB SPECIFICATIONS	255
Wiring Diagram — ILL —	247	Headlamp	255
Removal and Installation	254	Exterior Lamp	255
GLOVE BOX LAMP	254	Interior Lamp/Illumination	255

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS0085Y

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A
B
C
D
E
F
G
H
I
J
LT
L
M

LT


HEADLAMP -CONVENTIONAL TYPE-

HEADLAMP -CONVENTIONAL TYPE-

PFP:26010

Component Parts and Harness Connector Location

EKS00EKT



System Description

EKS00EKT

The headlamp operation is controlled by the lighting switch which built into the combination switch, BCM and IPDM E/R (intelligent power distribution module engine room). Headlamp low relay, headlamp LH and RH relays are built into IPDM E/R. BCM read combination switch condition. refer to [LT-189, "System Description"](#).

OUTLINE

Power is supplied at all times

- to headlamp high LH relay, located in the IPDM E/R, and
- to headlamp high RH relay, located in the IPDM E/R, and
- to headlamp low relay, located in the IPDM E/R, and
- to BCM (body control module) terminals 74 and 79
- through 40A fusible link (letter J , located in the fuse and fusible link box),
- to IPDM E/R
- through 20A fusible link (No.52, located in the IPDM E/R),
- to combination meter terminal 27
- through 10A fuse [No. 8, located in the fuse block (J/B)].

With the ignition switch in the ON or START position, power is supplied

- to BCM (body control module) terminal 24
- through 10A fuse [No. 4, located in the fuse block (J/B)],
- to combination meter terminal 28
- through 10A fuse [No. 2, located in the fuse block (J/B)],
- to IPDM E/R.

Ground is supplied

- to BCM (body control module) terminal 2 and 70
- to combination meter terminals 21, 22 and 23
- through body grounds M19 and M20, and
- to IPDM E/R terminals 3 and 54
- through body grounds E25(Gasoline engine models), E26 and E40.

Low Beam Operation

When the lighting switch is turned to 2ND position and placed in LOW position, BCM reads combination switch condition (refer to [LT-189, "System Description"](#)). And BCM sends low beam request signal to IPDM E/R with

HEADLAMP -CONVENTIONAL TYPE-

CAN communication line. Then IPDM E/R turns on headlamp low relay. With headlamp low relay is energized, power is supplied.

- through 15A fuse (No. 39, located in the IPDM E/R)
- through terminal 50 of the IPDM E/R
- to terminal 1 of headlamp LH, and
- through 15A fuse (No. 40, located in the IPDM E/R)
- through terminal 48 of the IPDM E/R
- to terminal 1 of headlamp RH.

Ground is supplied

- to terminal 3 of each headlamp
- through body grounds E25(Gasoline engine models), E26 and E40.

With power and ground supplied, low beam headlamps will illuminate.

High Beam Operation/Flash-to-Pass Operation

With the lighting switch is turned to 2ND position and placed in HIGH or PASS position, BCM reads combination switch condition (refer to [LT-189. "System Description"](#)). And BCM sends high beam request signal to IPDM E/R and combination meter with CAN communication line. Then IPDM E/R turns on headlamp high relay LH and RH. With headlamp high relays are energized, power is supplied.

- through 10A fuse (No. 34, located in the IPDM E/R)
- through terminal 47 of the IPDM E/R
- to terminal 2 of headlamp LH, and
- through 10A fuse (No. 33, located in the IPDM E/R)
- through terminal 46 of the IPDM E/R
- to terminal 2 of headlamp RH.

Ground is supplied

- to terminal 3 of each headlamp
- through body grounds E25(Gasoline engine models), E26 and E40.

With power and ground supplied, the high beam headlamps will illuminate.

When combination meter receives high beam request signal from BCM across the CAN communication lines, combination meter will illuminate high beam indicator.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-189. "System Description"](#) .

FRIENDLY LIGHTING FUNCTION

Low beam headlamps will illuminate for 30 seconds when,

- ignition switch is in OFF position,
- lighting switch is placed in OFF position, and
- lighting switch is placed in PASS position.

BCM re-starts to count for 30 seconds, when all doors are locked with remote controller or Intelligent Key during friendly lighting function is activating.

Friendly lighting function time can be changed using "WORK SUPPORT" mode in "HEADLAMP".

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, headlamps illuminate with low beam when the ignition switch is turned from OFF to ON and headlamps are turned off when the ignition switch is turn from ON to OFF. If the fail-safe system is operating, headlamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control.(Refer to [PG-19. "FAIL-SAFE FUNCTION"](#))

HEADLAMP -CONVENTIONAL TYPE-

CAN Communication SYSTEM DESCRIPTION

EKS00ERC

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LT7

Go to CAN system, when selecting your car model from the following table.


Body type	3door/5door																			
Axle	2WD																			
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K									
Handle	LHD/RHD																			
Brake control	ABS system					ESP system					ABS									
Transmission	A/T		M/T			A/T		M/T			M/T									
Intelligent Key system	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable
CAN communication unit																				
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×			×	×			×	×			×	×			×	×		
Drive computer	×		×		×		×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×					×	×	×	×								
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	LT-9, "TYPE 1/ TYPE 2"				LT-12, "TYPE 3/ TYPE 4"				LT-14, "TYPE 5/ TYPE 6"				LT-17, "TYPE 7/ TYPE 8"				LT-19, "TYPE 9/ TYPE 10"			

×: Applicable


HEADLAMP -CONVENTIONAL TYPE-

TYPE 1/TYPE 2 System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

HEADLAMP -CONVENTIONAL TYPE-

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

HEADLAMP -CONVENTIONAL TYPE-

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

I

J

LT

L


M

HEADLAMP -CONVENTIONAL TYPE-

TYPE 3/TYPE 4


System diagram

- Type 3



MKIB0275E

- Type 4



MKIB0276E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

HEADLAMP -CONVENTIONAL TYPE-

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP -CONVENTIONAL TYPE-


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

HEADLAMP -CONVENTIONAL TYPE-

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP -CONVENTIONAL TYPE-


Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

HEADLAMP - CONVENTIONAL TYPE-


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

HEADLAMP -CONVENTIONAL TYPE-

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


HEADLAMP -CONVENTIONAL TYPE-

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP -CONVENTIONAL TYPE-

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

HEADLAMP -CONVENTIONAL TYPE-

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A

B

C

D

E

F

G

H

I

J

LT

L


M

HEADLAMP - CONVENTIONAL TYPE-






EKS00EKW

Wiring Diagram — H/LAMP—

LT-H/LAMP-01

-  : DATA LINE
-  : LHD MODELS
-  : RHD MODELS

REFER TO PG-POWER.




REFER TO THE FOLLOWING.


-  -SUPER MULTIPLE JUNCTION (SMJ)
-  -FUSE BLOCK-JUNCTION BOX (J/B)
-  -ELECTRICAL UNITS

HEADLAMP - CONVENTIONAL TYPE-

LT-H/LAMP-02



A
B
C
D
E
F
G
H
I
J
K
L
M






REFER TO THE FOLLOWING.
 (M1) -SUPER MULTIPLE JUNCTION (SMJ)

HEADLAMP -CONVENTIONAL TYPE-

Terminals and Reference Value for BCM

EKS00EKX

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
2	B	Ground	ON	—	Approx. 0
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1	ON	Headlamps, turn signals, wipers OFF (wiper volume is 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2166J</p>
14	P	Combination switch output 3			
15	W	Combination switch output 5			
33	R	Combination switch output 2			
34	Y	Combination switch output 4	ON	Headlamps, turn signals, wipers OFF (wiper volume is other than 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
19	R	CAN H			
24	OR	Ignition power supply	ON	—	Approx. 12
39	W	CAN L	—	—	—
70	B	Ground	ON	—	Approx. 0
74	W	Battery power supply	OFF	—	Approx. 12
79	Y	Battery power supply	OFF	—	Approx. 12

HEADLAMP -CONVENTIONAL TYPE-

Terminals and Reference Values for IPDM E/R

EKS00EKY

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)	
			Ignition switch	Operation or condition		
3	B	Ground	ON	—	Approx. 0	
46	Y	Headlamp high beam (RH)	ON	Lighting switch (high beam)	ON	Approx. 12
					OFF	Approx. 0
47	G	Headlamp high beam (LH)	ON	Lighting switch (high beam)	ON	Approx. 12
					OFF	Approx. 0
48	PU	Headlamp low beam (RH)	ON	Lighting switch (low beam)	ON	Approx. 12
					OFF	Approx. 0
50	L	Headlamp low beam (LH)	ON	Lighting switch (low beam)	ON	Approx. 12
					OFF	Approx. 0
52	R	CAN H	—	—	—	
54	B	Ground	ON	—	Approx. 0	
58	W	CAN L	—	—	—	

A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP -CONVENTIONAL TYPE-

EKS00EKZ

How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaints.
2. Understand operation description and function description.
Refer to Headlamp [LT-6, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-26, "Preliminary Check"](#) .
4. Confirm headlamp does not operate by fail-safe control of IPDM E/R. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#) .
5. Check symptom and repair or replace the cause of malfunction.
6. Dose the headlamp operate normally? Yes: GO TO 7. No: GO TO 5.
7. INSPECTION END.

Preliminary Check

EKS00ELO

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check BCM fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch ON or START position	4

Refer to [LT-22, "Wiring Diagram — H/LAMP—"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)		OFF	ACC	ON
M50	74 (W)	Ground	Battery voltage	Battery voltage	Battery voltage
M50	79 (Y)		Battery voltage	Battery voltage	Battery voltage
M48	24 (OR)		0V	0V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse. If NG, repair or replace the harness or fuse.



HEADLAMP -CONVENTIONAL TYPE-


3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Connector	Terminals		Continuity
	Terminal (Wire color)		
M48	2 (B)	Ground	Yes
M50	70 (B)	Ground	Yes

OK or NG

- OK >> INSPECTION END.
- NG >> Repair or replace the harness.



A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP -CONVENTIONAL TYPE-

CONSULT-II Functions (BCM)

EKS00EL1

CONSULT-II can display each diagnosis item using the diagnostic test modes shown following. Data is received and transmitted via the control module communication line.


BCM trouble diagnosis item	Inspection Item, Diagnosis Mode	Description
Headlamp	Work support	Changes the setting for each function.
	Data monitor	Displays BCM input data in real time.
	Active test	Sends a drive signal to electronic components to check their operation.
BCM C/U	Self-diagnosis	BCM performs self-diagnosis of CAN communication and combination switch

CONSULT-II BASIC OPERATION


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "BCM" on the "SELECT SYSTEM" screen.
If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




HEADLAMP -CONVENTIONAL TYPE-

6. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.



7. Touch "WORK SUPPORT", "DATA MONITOR", or "ACTIVE TEST" on the "SELECT DIAG MODE" screen.



WORK SUPPORT

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "BATTERY SAVER" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER	Battery saver can be selected.	ON	—
		OFF	○

DATA MONITOR

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on the "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
SELECTION FROM MENU	Selects and monitors individual items.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

A
B
C
D
E
F
G
H
I
J
L
M

LT

HEADLAMP -CONVENTIONAL TYPE-

Display Item List

Monitor item	UNIT.	Display content
IGN ON SW	[ON/OFF]	Displays status (Ignition switch ON: ON/Others OFF, ACC: OFF) as judged from the ignition switch signal.
HI BEAM SW	[ON/OFF]	Displays status (High beam switch: ON/Others: OFF) as judged from lighting switch signal.
HEADLAMP SW	[ON/OFF]	Displays status (Headlamp switch: ON/Others: OFF) as judged from lighting switch signal.
LIGHT SW 1ST	[ON/OFF]	Displays status (Lighting switch 1st position: ON/Others: OFF) as judged from lighting switch signal.
PASSING SW	[ON/OFF]	Displays status (Flash-to-pass switch: ON/Others: OFF) as judged from lighting switch signal.
FR FOG SW	[ON/OFF]	Displays status (Front fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
RR FOG SW	[ON/OFF]	Displays status (Rear fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
DOOR SW DR	[ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the door switch DR signal.
H/L WASH SW	[ON/OFF]	Displays status (Headlamp washer switch: ON/Others: OFF) as judged from headlamp washer switch signal.
ENGINE STATUS	[STOP/ STALL/ RUN/ CRA]	Displays status (Engine stop: STOP/engine stall: STALL/engine running: RUN/engine cranking: CRA) as judged from the engine status.

ACTIVE TEST

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on the "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During operation check, touching "STOP" deactivates operation.

Display Item List

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Tail lamp relay can be operated by any ON-OFF operation.
Headlamp relay output	HEADLAMP	Headlamp relay can be operated by any ON-OFF operation.
Front fog lamp relay output	FR FOG LAMP	Front fog lamp relay can be operated by any ON-OFF operation.
Rear fog lamp relay output	RR FOG LAMP	Rear fog lamp relay can be operated by any ON-OFF operation.

SELF-DIAGNOSTIC RESULTS

Operation Procedure

1. Touch "BCM C/U" on "SELECT TEST ITEM" screen.
2. Touch "SELF-DIAGNOSTIC RESULTS" on "SELECT DIAG MODE" screen.
3. Self-diagnostic results are displayed.

Display Item List

Item to be displayed	CONSULT-II display	Description
CAN communication	CAN COMMUNICATION [U1000]	Malfunction is detected in CAN communication.
CAN communication system	CAN COMMUNICATION SYSTEM TO 6 [U1000]	Malfunction is detected in CAN system.
Combination switch	Diagnosis 1-5 systems open circuit	Malfunction is detected in combination switch system.

HEADLAMP -CONVENTIONAL TYPE-

CONSULT-II Functions (IPDM E/R)

EKS00EL2

CONSULT-II can display each diagnosis item using the diagnostic test modes shown following. Data is received and transmitted via the control module communication line.


Inspection Item, Diagnosis Mode	Description
Self-diagnostic results	Refer to PG-34, "SELF-DIAG RESULTS" .
Data monitor	Displays the real-time input/output data from IPDM E/R I/O data.
Active test	IPDM E/R can Sends a drive signal to electronic components to check their operation.

CONSULT-II BASIC OPERATION


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "IPDM E/R" on the "SELECT SYSTEM" screen. If "IPDM E/R" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



HEADLAMP -CONVENTIONAL TYPE-

6. Touch “SELF-DIAG RESULTS”, “DATA MONITOR”, “ACTIVE TEST” on the “SELECT DIAG MODE” screen.



SELF-DIAG RESULTS

IPDM E/R perform self-diagnosis of CAN communication. Refer to [PG-34, "SELF-DIAG RESULTS"](#) .

DATA MONITOR

Operation Procedure

1. Touch “DATA MONITOR” on the “SELECT DIAG MODE” screen.
2. Touch “ALL SIGNALS”, “MAIN SIGNALS” or “SELECTION FROM MENU” on the “DATA MONITOR” screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitors previously selected items.
SELECTION FROM MENU	Items are freely selected and monitored.

3. Touch “START”.
4. For “SELECTION FROM MENU”, touch the required monitor items. For “ALL SIGNALS”, all items are monitored. For “MAIN SIGNALS”, the previously selected items are monitored.
5. Touch “RECORD” while monitoring to record the status of the item being monitored. To stop recording, touch “STOP”.

All Signals, Main Signals, Selection From Menu

Monitor item name	Display and unit	Monitor item selection			Display content
		All signals	Main signals	selection from menu	
TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
IGN RLY	ON/OFF	×	×	×	Status of ignition relay being monitored by IPDM E/R
BAT VOLT	V	×		×	Value measured at IPDM E/R

NOTE:

- IPDM E/R data monitoring is performed with ignition switch ON. When monitored at ACC position, the display might not be normal.

HEADLAMP -CONVENTIONAL TYPE-

ACTIVE TEST

Operation Procedure

1. Touch "ACTIVE TEST" on the "SELECT DIAG MODE" screen.
2. Touch item to be tested and check operation of the selected item.
3. Touch "START".
4. Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	HEADLAMP	Headlamp relay (LO, HI) can be operated using random operation (OFF, HI ON, LO ON).
Front fog lamp relay output	FRONT FOG LAMP	Fog lamp relay can be operated by any ON-OFF operation.
Tail lamp relay output	TAIL LAMP	Tail lamp relay can be operated by any ON-OFF operation.

Headlamp High Beam Does Not Illuminate (Both Sides)

EKS00EL3

1. CHECK BETWEEN COMBINATION SWITCH AND BCM

With CONSULT-II

Select BCM on CONSULT-II. Check lighting switch ("HI BEAM SW") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in : HI BEAM SW ON
2nd position and placed in
HIGH or PASS position

When lighting switch is in : HI BEAM SW OFF
OFF position

Without CONSULT-II

Refer to [LT-196, "Check Combination Switch"](#).

OK or NG

OK >> GO TO 2.

NG >> Refer to [LT-196, "Check Combination Switch"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HI BEAM SW	ON
H/L SW POS	ON
LIGHT SW 1ST	OFF
AUTO LIGHT SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF
VEHICLE SPEED	0 km/h
	Page Down
	RECORD
MODE	BACK LIGHT COPY

MKIB0843E

2. CHECK BETWEEN IPDM E/R TO HEADLAMP

With CONSULT-II

1. Select "IPDM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "HEADLAMP" on "ACTIVE TEST" screen.
3. Make sure that headlamp (high beam) operate normally.

Without CONSULT-II

1. Start up auto active test. Refer to [PG-42, "Auto Active Test"](#).
2. Make sure that headlamp (high beam) operate normally.

OK or NG

OK >> GO TO 3.

NG >> Check the following:

- Headlamp LH/RH bulb
- Headlamp ground circuit harness
- Open or short for the harness between headlamp LH/RH and IPDM E/R.
If there are no malfunctions, replace IPDM E/R.

ACTIVE TEST	
HEAD LAMP	OFF
HI	LO
MODE	BACK LIGHT COPY

SKIA2339E

HEADLAMP -CONVENTIONAL TYPE-

3. CHECK BETWEEN IPDM E/R AND BCM

Select IPDM E/R on CONSULT-II. Check lighting switch (“HL HI REQ”) in “DATA MONITOR” mode with CONSULT-II.

**When lighting switch is in : HL HI REQ ON
2nd position and placed in
HIGH or PASS position**

**When lighting switch is in : HL HI REQ OFF
OFF position**

DATA MONITOR			
MONITOR			
MOTOR FAN REQ		1	
AC COMP REQ		OFF	
TAIL & CLR REQ		OFF	
HL LO REQ		OFF	
HL HI REQ		OFF	
FR FOG REQ		OFF	
FR WIP REQ		STOP	
WIP AUTO STOP		ON	
WIP PROT		OFF	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA2475E

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Replace BCM.

Headlamp High Beam Does Not Illuminate (One Side)

EKS00EL4

1. CHECK BULB

Check headlamp bulb which does not illuminate.

OK or NG

- OK >> GO TO 2.
- NG >> Replace headlamp bulb.

2. CHECK FUSE

Check the following

- 10A fuse (No. 33, located in the IPDM E/R).
- 10A fuse (No. 34, located in the IPDM E/R).


OK or NG

- OK >> GO TO 3.
- NG >> If fuse is blown be sure to eliminate cause of malfunction before installing new fuse.

3. CHECK BETWEEN IPDM E/R AND HEADLAMP

1. Disconnect IPDM E/R connector and headlamp connector.
2. Check continuity between harness connector terminals of IPDM E/R and harness connector terminal of headlamp.

Terminals					Continuity
Headlamp		IPDM E/R			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
RH	E42	E15	46 (Y)	Yes	
LH	E21		47 (G)		



OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness or connector.

HEADLAMP -CONVENTIONAL TYPE-


4. CHECK BETWEEN HEADLAMP AND GROUND

Check continuity between harness connector of headlamp and ground.

Headlamp			Continuity
Connector		Terminal (Wire color)	
RH	E42	3 (B)	Yes
LH	E21	3 (B)	

OK or NG

- OK >> Replace IPDM E/R.
- NO >> Repair harness or connector.



High-Beam Indicator Does Not Illuminate

1. CHECK BULB

Check high-beam indicator bulb.

OK or NG

- OK >> Replace combination meter.
- NG >> Replace indicator bulb.

Headlamp Low Beam Does Not Illuminate (Both Sides)

1. CHECK BETWEEN COMBINATION SWITCH AND BCM

With CONSULT-II

Select BCM on CONSULT-II. Check lighting switch ("H/L SW POS") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in : H/L SW POS ON
2nd position

When lighting switch is in : H/L SW POS OFF
OFF position

Without CONSULT-II

Refer to [LT-196, "Check Combination Switch"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Refer to [LT-196, "Check Combination Switch"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HI BEAM SW	ON
H/L SW POS	ON
LIGHT SW 1ST	OFF
AUTO LIGHT SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF
VEHICLE SPEED	0 km/h
Page Down	
RECORD	
MODE	BACK LIGHT COPY

MKIB0843E

2. CHECK BETWEEN IPDM E/R AND HEADLAMP

With CONSULT-II

1. Select "IPDM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "HEADLAMP" on "ACTIVE TEST" screen.
3. Make sure that headlamp (low beam) operate normally.

Without CONSULT-II

1. Start up auto active test. Refer to [PG-42, "Auto Active Test"](#).
2. Make sure that headlamp (low beam) operate normally.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 4.

ACTIVE TEST	
HEAD LAMP	OFF
HI LO	
MODE BACK LIGHT COPY	

SKIA2339E

HEADLAMP -CONVENTIONAL TYPE-

3. CHECK BETWEEN IPDM E/R AND BCM

Select IPDM E/R on CONSULT-II. Check lighting switch (“HL LO REQ”) in “DATA MONITOR” mode with CONSULT-II.

When lighting switch is in 2nd position : HL LO REQ ON

When lighting switch is in OFF position : HL LO REQ OFF

DATA MONITOR			
MONITOR			
MOTOR FAN REQ		1	
AC COMP REQ		OFF	
TAIL & CLR REQ		OFF	
HL LO REQ		OFF	
HL HI REQ		OFF	
FR FOG REQ		OFF	
FR WIP REQ		STOP	
WIP AUTO STOP		ON	
WIP PROT		OFF	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA2475E

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace BCM.

4. CHECK BETWEEN IPDM E/R AND HEADLAMPS


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and LH/RH headlamp connector.
3. Check continuity between harness connector of IPDM E/R and harness connector of LH/RH headlamp.

Terminals					Continuity
Headlamp		IPDM E/R			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
RH	E42	E15	48	48 (PU)	Yes
LH	E21		50	50 (L)	

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness or connector.




HEADLAMP -CONVENTIONAL TYPE-

5. CHECK IPDM E/R

With CONSULT-II


1. Connect IPDM E/R connector and headlamp LH/RH connector.
2. Select "IPDM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Select "HEADLAMP" on "ACTIVE TEST" screen.
4. Check voltage between headlamp LH/RH connector terminals and ground.



Terminals			(-)	Voltage [V]
(+)				
Connector		Terminal (Wire color)		
RH	E42	1 (PU)	Ground	Battery voltage
LH	E21	1 (L)		

Without CONSULT-II

1. Connect IPDM E/R connector and headlamp LH/RH connector.
2. Start auto active test. Refer to [PG-42, "Auto Active Test"](#), check voltage between headlamp LH/RH connector terminals and ground.




Terminals			(-)	Voltage [V]
(+)				
Connector		Terminal (Wire color)		
RH	E42	1 (PU)	Ground	Battery voltage
LH	E21	1 (L)		

OK or NG

- OK >> GO TO 6.
 NG >> Replace IPDM E/R.

6. CHECK IPDM E/R AND GROUND

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R connector terminals and ground.



Terminals			(-)	Continuity
(+)				
Connector		Terminal (Wire color)		
E11		3 (B)	Ground	Yes
E16		54 (B)		

OK or NG

- OK >> Check the condition of the harness and connectors.
 NG >> Repair or replace the harness.

HEADLAMP -CONVENTIONAL TYPE-

Headlamp Low Beam Does Not Illuminate (One Side)

EKS00EL7

1. CHECK BULB

Check headlamp bulb.

OK or NG

- OK >> GO TO 2.
- NG >> Replace headlamp bulb.

2. FUSE CHECK

Check the following

15A fuse (No. 39, located in the IPDM E/R).

15A fuse (No. 40, located in the IPDM E/R).

OK or NG

- OK >> GO TO 3.
- NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.


3. CHECK BETWEEN IPDM E/R AND HEADLAMPS

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and headlamp connector.
3. Check continuity between harness connector of IPDM E/R and harness connector terminal of headlamp.

Terminals				Continuity
Headlamp		Terminals		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
RH	E42	E15	48 (PU)	Yes
LH	E21		50 (L)	

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness or connector.




4. CHECK BETWEEN HEADLAMP AND GROUND

Check continuity between harness connector of headlamp and ground.

Headlamp			Continuity
Connector	Terminal (Wire color)		
RH	E42	3 (B)	Yes
LH	E21	3 (B)	

OK or NG

- OK >> Replace IPDM E/R.
- NO >> Repair or replace harness or connector.



Headlamp Low Beam And High Beam Does Not Illuminate (One Side)

EKS00EL8

1. CHECK BULB

Check headlamp bulb.

OK or NG

- OK >> GO TO 2.
- NG >> Replace headlamp bulb.

HEADLAMP -CONVENTIONAL TYPE-


2. CHECK BETWEEN HEADLAMP AND GROUND

1. Disconnect headlamp connector.
2. Check continuity between harness connector of headlamp and ground.

Headlamp			Continuity
Connector		Terminal (Wire color)	
RH	E42	3 (B)	Yes
LH	E21	3 (B)	

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair or replace harness or connector.



Headlamps Do Not Turn OFF

1. CHECK IPDM E/R

- Check whether symptom is caused by IPDM E/R fail-safe operation or by factors other than fail-safe operation. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#) and check CAN system.

OK or NG

- Fail-safe operation >> Refer to [PG-48, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#).
- Other than fail-safe operation >> Refer to [PG-51, "Diagnosis of IPDM E/R Integrated Relay"](#).

HEADLAMP -CONVENTIONAL TYPE-


EKS00ELA

Aiming Adjustment

- Turn the aiming adjusting screw to adjust.
- For positions of the adjustment screws, refer to the figures.

CAUTION:

Adjustment with the aiming adjusting screw must be done in the tightening direction. (When adjusting in the loosening direction, first loosen the screw, then tighten again.)



PREPARATION BEFORE ADJUSTING

For details, refer to the regulations in your own country.


Before performing aiming adjustment, check the following.

1. Keep all tyres inflated to correct pressures.
2. Place vehicle on flat surface.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.

LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam on.
2. Use adjusting screws to perform aiming adjustment.

ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Basic illumination area for adjustment should be within the range shown on the aiming chart.

HEADLAMP -CONVENTIONAL TYPE-


Adjust headlamp accordingly.

Bulb Replacement HEADLAMP

EKS00ELB

1. Turn ignition switch OFF.
2. Disconnect headlamp connector.
3. Remove rubber cover.
4. Remove the retaining spring lock, then remove the bulb.
5. Install in reverse order of remove.

Headlamps (High beam, Low beam) : 12V 60/55W (H4)



CLEARANCE LAMPS (PARKING LAMPS)

1. Turn ignition switch OFF.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.
4. Install in reverse order of remove.

Parking lamps : 12V 5W


CAUTION:

After the bulb is installed, the rubber cover must be attached securely to insure the assembly is water-tight.

Removal and Installation REMOVAL

EKS00ELC

1. Remove fender protector. Refer to [EI-11, "FENDER PROTECTOR"](#) .
2. Remove bolt of front fender front end and bolt of front bumper fascia. Remove front bumper fascia. Refer to [EI-4, "FRONT BUMPER"](#) .
3. Disconnect the headlamp, clearance lamp and headlamp aiming connector.
4. Remove headlamp bolts.
5. Pull the entire headlamp forward while raising top mounting bracket.



INSTALLATION

Install in the reverse order of removal, paying attention to the following.

Headlamp bolt

Tightening torque

: 4.4 - 6.5 N-m (0.45 - 0.66 kg-m, 39 - 58 in-lb)


HEADLAMP - DAYTIME LIGHT SYSTEM -

HEADLAMP - DAYTIME LIGHT SYSTEM -

PFP:26010

Component Parts and Harness Connector Location

EKS00ELD



System Description

EKS00ELE

The headlamp system for Northern Europe vehicles is equipped with a daytime light system that activates the low beam headlamps at approximately half illumination whenever the engine is running.

Power is supplied at all times

- to headlamp high LH and RH relay located in the IPDM E/R (intelligent power distribution module engine room).
- to headlamp low relay located in the IPDM E/R.

Power is also supplied at all times

- to BCM terminals 74 and 79
- through 40A fusible link (letter J , located in the fuse and fusible link box),
- to IPDM E/R
- through 20A fuse (No.52, located in the IPDM E/R),
- to daytime light relay terminals 1 and 5
- through 10A fuse (No.27, located in the fuse and fusible link box) and
- to combination meter terminal 27
- through 10A fuse [No. 8, located in the fuse block (J/B)].

With the ignition switch in the ON or START position, power is supplied

- to BCM terminal 24
- through 10A fuse [No. 4, located in the fuse block (J/B)],
- to combination meter terminal 28

HEADLAMP - DAYTIME LIGHT SYSTEM -

- through 10A fuse [No. 2, located in the fuse block (J/B)]
- to IPDM E/R.

With the ignition switch in the START position, power is supplied

- to BCM terminal 3
- through 10A fuse [No. 14, located in the fuse block (J/B)].

Ground is supplied

- to BCM terminals 2 and 70, and
- to combination meter terminals 21, 22 and 23
- through body grounds M19 and M20,
- to IPDM E/R terminals 3 and 54
- through body grounds E25(Gasoline engine models), E26 and E40.

HEADLAMP OPERATION

Low Beam Operation

When the lighting switch is turned to 2ND position and placed in LOW position, BCM read combination switch condition (refer to [LT-189, "System Description"](#)). And BCM send low beam request signal to IPDM E/R with CAN communication line. Then IPDM E/R is turned on headlamp low relay. Headlamp low relay is energized and then power is supplied

- through 15A fuse (No. 39, located in the IPDM E/R)
- through terminal 50 of the IPDM E/R
- to terminal 1 of headlamp LH, and
- through 15A fuse (No. 40, located in the IPDM E/R)
- through terminal 48 of the IPDM E/R
- to terminal 1 of headlamp RH.

Ground is supplied at all times

- to terminal 3 of headlamp LH
- through body grounds E25(Gasoline engine models), E26 and E40, and
- to terminal 3 of headlamp RH
- through daytime light relay 3 and 4
- through body grounds E25(Gasoline engine models), E26, E40.

With power and ground supplied, low beam headlamps will illuminate.

High Beam Operation (When engine stopped)/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, BCM read combination switch condition (refer to [LT-189, "System Description"](#)). And BCM send high beam request signal to IPDM E/R and combination meter with CAN communication line. Then IPDM E/R is turned on headlamp high LH and RH relay. Headlamp high relays are energized and then power is supplied

- through 10A fuse (No. 34, located in the IPDM E/R)
- through terminal 47 of the IPDM E/R
- to terminal 2 of the headlamp LH and
- through 10A fuse (No. 33, located in the IPDM E/R)
- through terminal 46 of the IPDM E/R
- to terminal 2 of the headlamp RH.

Ground is supplied

- to terminal 3 of headlamp LH
- through body grounds E25(Gasoline engine models), E26 and E40
- to terminal 3 of headlamp RH
- through daytime light relay 3 and 4
- through body grounds E25, E26 and E40

When power and ground supplied, the high beam headlamps will illuminate.

When combination meter received high beam request signal, combination meter will illuminate high beam indicator.

HEADLAMP - DAYTIME LIGHT SYSTEM -

COMBINATION SWITCH READING FUNCTION

Refer to [LT-189, "System Description"](#)

DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF position. BCM sends daytime light request signal to IPDM E/R with CAN communication line. Ground is supplied

- through terminal 65 of IPDM E/R
- to terminal 2 of daytime light relay.

Daytime light relay is energized, power is supplied.

- through daytime light relay terminals 3 and 5
- to terminal 3 of headlamp RH
- through terminal 1 of headlamp RH
- to IPDM E/R terminal 48
- through IPDM E/R terminal 50
- to terminal 1 of headlamp LH.

Ground is supplied

- to terminal 3 of headlamp LH and
- to IPDM E/R terminals 3 and 54
- through body grounds E25(Gasoline engine models), E26 and E40.

Because the low beam headlamps are now wired in series, they operate at half illumination.

If the lighting switch is in the 1st and 2nd position, daytime light operation is canceled.

FRIENDLY LIGHTING FUNCTION

High beam headlamps will illuminate for 30 seconds when,

- ignition switch is in OFF position,
- lighting switch is placed in OFF position, and
- lighting switch is placed in PASS position.

BCM re-starts to count for 30 seconds, when all doors are locked with remote controller or Intelligent Key during Friendly lighting function is activating.

Friendly lighting function time can be changed using "WORK SUPPORT" mode in "HEADLAMP".

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, headlamps illuminate when the ignition switch is turned from OFF to ON or ACC and headlamps are turned off when the ignition switch is turn from ON or ACC to OFF. If the fail-safe system is operating, headlamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-19, "FAIL-SAFE FUNCTION"](#))

HEADLAMP - DAYTIME LIGHT SYSTEM -

CAN Communication SYSTEM DESCRIPTION

EKS00ERE

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LT8

Go to CAN system, when selecting your car model from the following table.


Body type	3door/5door																			
Axle	2WD																			
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K									
Handle	LHD/RHD																			
Brake control	ABS system					ESP system					ABS									
Transmission	A/T		M/T			A/T		M/T			M/T									
Intelligent Key system	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable														
CAN communication unit																				
ECM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Data link connector	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Combination meter	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Intelligent Key unit	x	x			x	x			x	x			x	x			x	x		
Drive computer	x		x		x		x		x		x		x		x		x		x	
EPS control unit	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
BCM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
ABS actuator and electric unit (control unit)	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
TCM	x	x	x	x					x	x	x	x								
IPDM E/R	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CAN communication type	<u>LT-46, "TYPE 1/ TYPE 2"</u>				<u>LT-49, "TYPE 3/ TYPE 4"</u>				<u>LT-51, "TYPE 5/ TYPE 6"</u>				<u>LT-54, "TYPE 7/ TYPE 8"</u>				<u>LT-56, "TYPE 9/ TYPE 10"</u>			

x: Applicable


HEADLAMP - DAYTIME LIGHT SYSTEM -

TYPE 1/TYPE 2 System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

HEADLAMP - DAYTIME LIGHT SYSTEM -

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

A
B
C
D
E
F
G
H
I
J
L
M

LT


HEADLAMP - DAYTIME LIGHT SYSTEM -

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


HEADLAMP - DAYTIME LIGHT SYSTEM -

TYPE 3/TYPE 4 System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

HEADLAMP - DAYTIME LIGHT SYSTEM -


Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

HEADLAMP - DAYTIME LIGHT SYSTEM -

TYPE 5/TYPE 6


System diagram

- Type 5



MKIB0273E

- Type 6



MKIB0274E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

HEADLAMP - DAYTIME LIGHT SYSTEM -

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

HEADLAMP - DAYTIME LIGHT SYSTEM -

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A
B
C
D
E
F
G
H
I
J

LT


L
M

HEADLAMP - DAYTIME LIGHT SYSTEM -


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

HEADLAMP - DAYTIME LIGHT SYSTEM -

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R

A
B
C
D
E
F
G
H
I
J
L
M

LT


HEADLAMP - DAYTIME LIGHT SYSTEM -

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



HEADLAMP - DAYTIME LIGHT SYSTEM -

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

A
B
C
D
E
F
G
H
I
J
K
L
M

LT

HEADLAMP - DAYTIME LIGHT SYSTEM -

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					



HEADLAMP - DAYTIME LIGHT SYSTEM -

EKS00ELG


Wiring Diagram — DTRL — WITH GASOLINE ENGINE

LT-DTRL-01

A
B
C
D
E
F
G
H
I
J
LT
L
M




REFER TO THE FOLLOWING.
 (M1), (F1) -SUPER MULTIPLE JUNCTION (SMJ)
 (M16) -FUSE BLOCK- JUNCTION BOX (J/B)
 (M48), (M49), (M50) -ELECTRICAL UNITS
 (M81), (M82) -JOINT CONNECTOR (J/C)



MKWA3236E



HEADLAMP - DAYTIME LIGHT SYSTEM -

LT-DTRL-02



PRECEDING PAGE
 A R
 B W


--- : DATA LINE



REFER TO THE FOLLOWING.
 (M1) -SUPER MULTIPLE JUNCTION (SMJ)


HEADLAMP - DAYTIME LIGHT SYSTEM -

WITH DIESEL ENGINE



A
B
C
D
E
F
G
H
I
J
K
L
M




LT



REFER TO THE FOLLOWING.
 (M1) : (F101) -SUPER MULTIPLE JUNCTION (SMJ)
 (M16) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M48) (M49) (M50) -ELECTRICAL UNITS
 (M81) : (M82) -JOINT CONNECTOR (J/C)

HEADLAMP - DAYTIME LIGHT SYSTEM -

LT-DTRL-04






REFER TO THE FOLLOWING.
 (M1) -SUPER MULTIPLE JUNCTION (SMJ)

HEADLAMP - DAYTIME LIGHT SYSTEM -

Terminals and Reference Value for BCM

EKS00ELI

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
2	B	Ground	ON	—	Approx. 0
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2166J</p>
14	P	Combination switch output 3			
15	W	Combination switch output 5			
33	R	Combination switch output 2			
34	Y	Combination switch output 4	ON	Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
19	R	CAN H			
24	OR	Ignition power supply	ON	—	Approx. 12
39	W	CAN L	—	—	—
48	L	Start signal	OFF	—	Approx. 0
			ON	—	Approx. 0
			START	—	Approx. 12
70	B	Ground	ON	—	Approx. 0
74	W	Battery power supply	OFF	—	Approx. 12
79	Y	Battery power supply	OFF	—	Approx. 12

A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP - DAYTIME LIGHT SYSTEM -

Terminals and Reference Values for IPDM E/R

EKS00ELJ

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)	
			Ignition switch	Operation or condition		
3	B	Ground	ON	—	Approx. 0	
46	Y	Headlamp HI (RH)	ON	Lighting switch (high beam)	ON	Approx. 12
47	G	Headlamp HI (LH)	ON		OFF	Approx. 0
48	PU	Headlamp LO (RH)	ON	Lighting switch (low beam)	ON	Approx. 12
50	L	Headlamp LO (LH)	ON		OFF	Approx. 0
52	R	CAN H	—	—	—	
54	B	Ground	ON	—	Approx. 0	
58	W	CAN L	—	—	—	
65	L	Daytime light relay	ON	Engine status (Lighting switch OFF)	RUNNING	Approx. 0
					STOP	Approx. 12

How to Proceed With Trouble Diagnosis

EKS00ELK

1. Confirm the symptom or customer complaints.
2. Understand operation description and function description. Refer to Headlamp [LT-42, "System Description"](#).
3. Carry out the Preliminary Check. Refer to [LT-64, "Preliminary Check"](#)
4. Confirm headlamp does not operate by fail-safe control of IPDM E/R. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#)
5. Check symptom and repair or replace the cause of malfunction.
6. Dose the headlamp operate normally? Yes: GO TO 7. No: GO TO 5.
7. INSPECTION END.

Preliminary Check

EKS00ELL

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check BCM fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch (ON)	4
	Ignition switch (START)	14

Refer to [LT-59, "Wiring Diagram — DTRL —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#).

HEADLAMP - DAYTIME LIGHT SYSTEM -

2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)	Connector		Terminal (Wire color)	OFF	ACC
M50	74 (W)	Ground	Battery voltage	Battery voltage	Battery voltage
M50	79 (Y)		Battery voltage	Battery voltage	Battery voltage
M48	24 (OR)		0V	0V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminals		Continuity
Connector	Terminal (Wire color)	
M48	2 (B)	Ground Yes
M50	70 (B)	

OK or NG

OK >> INSPECTION END

NG >> Repair or replace the harness.



CONSULT-II Function (BCM)

Refer to [LT-28, "CONSULT-II Functions \(BCM\)"](#) .

CONSULT-II Function (IPDM E/R)

Refer to [LT-31, "CONSULT-II Functions \(IPDM E/R\)"](#) .

Daytime Light Control Does Not Operate Properly

1. CHECK HEADLAMP OPERATION

Lighting switch is turned to 2nd position.

Does headlamp operate normally?

Yes >> GO TO 2.

No >> Check the following.


- Headlamp does not illuminate (both sides). GO TO [LT-35, "Headlamp Low Beam Does Not Illuminate \(Both Sides\)"](#) .
- Headlamp does not illuminate (one side). GO TO [LT-38, "Headlamp Low Beam Does Not Illuminate \(One Side\)"](#) .

HEADLAMP - DAYTIME LIGHT SYSTEM -

2. CHECK DAYTIME LIGHT RELAY

1. Turn ignition switch OFF.
2. Disconnect daytime light relay connector.
3. Check voltage between daytime light relay harness connector and ground.

Terminals		(-)	Voltage [V]
(+)			
Connector	Terminal (Wire color)		
E2	1 (Y)	Ground	Battery voltage
	5 (Y)		



OK or NG

- OK >> GO TO 3.
 NG >> Check the following.
- 10A fuse (No. 27, located in fuse and fusible link box).
 - Harness for open or short between daytime relay and fuse.


3. CHECK IPDM E/R OUTPUT SIGNAL

1. Disconnect IPDM E/R connector and connector daytime light relay.
2. Check voltage between IPDM E/R harness connector E17 terminal 65(L) and ground.

Battery voltage should exist.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 5.




4. CHECK IPDM E/R OUTPUT SIGNAL

1. Connect IPDM E/R connector.
2. Check voltage between IPDM and ground.

Connector	Terminal (Wire color)	Condition	Voltage [V]
E17	65 (L)	Engine stop	Approx. 12
		Engine running	Approx. 0

OK or NG

- OK >> Replace daytime relay.
 NG >> Replace IPDM E/R.



HEADLAMP - DAYTIME LIGHT SYSTEM -


5. CHECK IPDM E/R OUTPUT SIGNAL CIRCUIT

1. Disconnect daytime light relay connector.
2. Check continuity between harness connector E2 terminal 2 (L) of daytime light relay and harness connector E17 terminal 65 (L) of IPDM E/R.

Continuity should exist.

OK or NG

- OK >> Replace daytime light relay.
 NG >> Repair or replace harness or connector.



Headlamp High Beam Does Not Illuminate (Both Sides)

EKS00ELP

Refer to [LT-33, "Headlamp High Beam Does Not Illuminate \(Both Sides\)"](#).

RH High beam Does Not Illuminate

EKS00ELQ

1. CHECK BULB

Check bulb of headlamp RH.


OK or NG

- OK >> GO TO 2.
 NG >> Replace bulb of headlamp.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect headlamp RH connector.
3. Check voltage between headlamp RH harness connector E41 terminal 2 (Y) and ground.

Terminals			Condition	Voltage [V]
(+)		(-)		
Connector	Terminal (Wire color)			
E41	2 (Y)	Ground	Lighting switch high beam ON	Battery voltage



OK or NG

- OK >> GO TO 5.
 NG >> GO TO 3.


3. CHECK IPDM E/R CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E15 terminal 46 (Y) of IPDM E/R and harness connector E41 terminal 2 (Y) of headlamp RH.

Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness or connector.



HEADLAMP - DAYTIME LIGHT SYSTEM -

4. CHECK FUSE

Check 10A fuse [No. 33, located in IPDM E/R].

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace fuse. If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

5. CHECK HEADLAMP RH GROUND CIRCUIT


Check continuity between harness connector E2 terminal 3 (R) of daytime light relay and harness connector E41 terminal 3 (R) of headlamp RH.

Continuity should exist.

OK or NG

OK >> GO TO 6.

NG >> Repair or replace harness or connector.



6. CHECK DAYTIME LIGHT GROUND CIRCUIT


Check continuity daytime light relay harness connector E2 terminal 4 (B) and ground.

Continuity should exist.

OK or NG

OK >> Replace daytime light relay.

NG >> Repair or replace harness or connector.



Headlamp LH High Beam Does Not Illuminate

EKS00ELR

Refer to [LT-34. "Headlamp High Beam Does Not Illuminate \(One Side\)"](#) .

Headlamp Low Beam Does Not Illuminate (Both Sides)

EKS00ELS

Refer to [LT-35. "Headlamp Low Beam Does Not Illuminate \(Both Sides\)"](#) .

RH Low Beam Does Not Illuminate

EKS00ELT

1. CHECK BULB

Check bulb of headlamp RH.

OK or NG

OK >> GO TO 2.

NG >> Replace bulb of lamp.

HEADLAMP - DAYTIME LIGHT SYSTEM -


2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect headlamp RH connector.
3. Check voltage between headlamp RH harness connector E41 terminal 1 (PU) and ground.

Terminals			Condition	Voltage [V]
(+)		(-)		
Connector	Terminal (Wire color)			
E41	1 (PU)	Ground	Lighting switch low beam ON	Battery voltage

OK or NG

- OK >> GO TO 5.
NG >> GO TO 3.




3. CHECK IPDM E/R CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E15 terminal 48 (PU) of IPDM E/R and harness connector E41 terminal 1 (PU) of headlamp RH.

Continuity should exist.

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace harness or connector.



4. CHECK FUSE

Check 15A fuse (No. 40 located in IPDM E/R). Refer to [PG-49, "IPDM E/R Terminal Inspection"](#).

OK or NG

- OK >> Replace IPDM E/R.
NG >> Replace fuse. If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.


5. CHECK HEADLAMP RH GROUND CIRCUIT

Check continuity between harness connector E2 terminal 3 (R) of daytime light relay and harness connector E41 terminal 3 (R) of headlamp RH.

Continuity should exist.

OK or NG

- OK >> GO TO 6.
NG >> Repair or replace harness or connector.



HEADLAMP - DAYTIME LIGHT SYSTEM -


6. CHECK DAYTIME LIGHT GROUND CIRCUIT

Check continuity daytime light relay harness connector E2 terminal 4 (B) and ground.

Continuity should exist.

OK or NG

- OK >> Replace daytime light relay.
- NG >> Repair or replace harness connector.



Headlamp LH Low Beam Does Not Illuminate

EKS00ELU

Refer to [LT-38, "Headlamp Low Beam Does Not Illuminate \(One Side\)"](#) .

High-Beam Indicator Lamp Does Not Illuminate

EKS00ELV

Refer to [LT-35, "High-Beam Indicator Does Not Illuminate"](#) .

Headlamps Do Not Turn OFF

EKS00ELW

Refer to [LT-39, "Headlamps Do Not Turn OFF"](#) .

Aiming Adjustment

EKS00ELX

Refer to [LT-40, "Aiming Adjustment"](#) .

Bulb Replacement

EKS00ELY

Refer to [LT-41, "Bulb Replacement"](#) .

Removal and Installation

EKS00ELZ

Refer to [LT-41, "Removal and Installation"](#) .

HEADLAMP AIMING CONTROL

HEADLAMP AIMING CONTROL



PF26010

Wiring Diagram— H/AIM —

EKS00EM0



LT-H/AIM-01

▬ : DATA LINE
 ◯ L : LHD MODELS
 ◯ R : RHD MODELS



REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK-JUNCTION BOX (J/B)




A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP AIMING CONTROL


LT-H/AIM-02

▬ : DATA LINE

⬡ : WITH GASOLINE ENGINE



PRE-
CEDING
PAGE



REFER TO THE FOLLOWING.


⬡ -SUPER MULTIPLE JUNCTION (SMJ)

HEADLAMP AIMING CONTROL

Switch Circuit Inspection

EKS00EM1


Using a circuit tester, check continuity between the headlamp aiming switch connector terminals in each operation status of the aiming switch.



Removal and Installation

EKS00EM2

1. Remove switch panel finisher. Refer to [IP-4, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Pull forward while expands switch panel finisher hooks, and remove from switch panel finisher.



A
B
C
D
E
F
G
H
I
J
LT
L
M

FRONT FOG LAMP

System Description

EKS00EM3

The front fog lamp operation is controlled by the lighting switch which built into the combination switch, BCM (body control module) and IPDM E/R (intelligent power distribution module engine/room). Front fog lamp relay is built into IPDM E/R. BCM read combination switch condition. Refer to [LT-189, "System Description"](#)

OUTLINE

Power is supplied at all times

- to front fog lamp relay, located in the IPDM E/R
- to IPDM E/R
- through 20A fusible link (No.52, located in the IPDM E/R).

Power is also supplied at all times

- to terminals 74 and 79 of the BCM
- through 40A fusible link (letter J , fuse and fusible link box).

When the ignition switch is ON or START position, power is supplied

- to terminal 24 of the BCM
- through 10A fuse [No. 4, located in fuse block (J/B)],
- to IPDM E/R

Ground is supplied

- to BCM terminals 2 and 70
- through body grounds M19, and M20,
- to IPDM E/R terminals 3 and 54
- through body grounds E25(Gasoline engine models), E26 and E40.

FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 1ST position and the fog lamp switch must be ON for fog lamp operation.

When the lighting switch is turned to 1ST position and front fog lamp switch in ON position, BCM reads combination switch condition (refer to [LT-189, "System Description"](#)). And BCM sends low beam request signal to IPDM E/R with CAN communication line. Then IPDM E/R is turned on front fog lamp relay. Front fog lamp relay is energized and then power is supplied.

- to front fog lamp LH terminal 1
- through IPDM E/R terminal 44, and
- to front fog lamp RH terminal 1
- through IPDM E/R terminal 43.

Ground is supplied

- to front fog lamp LH terminal 2
- through body grounds E25(Gasoline engine models), E26, E40, and
- to front fog lamp RH terminal 2
- through body grounds E25(Gasoline engine models), E26 and E40.

With power and grounds supplied, the front fog lamps illuminate.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-189, "System Description"](#)

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, front fog lamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control.

FRONT FOG LAMP

EKS00ERG

CAN Communication SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LT9

Go to CAN system, when selecting your car model from the following table.


Body type	3door/5door																			
Axle	2WD																			
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K									
Handle	LHD/RHD																			
Brake control	ABS system					ESP system					ABS									
Transmission	A/T		M/T			A/T		M/T			M/T									
Intelligent Key system	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable		
CAN communication unit																				
ECM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
Data link connector	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
Combination meter	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
Intelligent Key unit	x	x			x	x			x	x			x	x			x	x		
Drive computer	x		x		x		x		x		x		x		x		x		x	
EPS control unit	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
BCM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
ABS actuator and electric unit (control unit)	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
TCM	x	x	x	x					x	x	x	x								
IPDM E/R	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
CAN communication type	<u>LT-76, "TYPE 1/ TYPE 2"</u>				<u>LT-79, "TYPE 3/ TYPE 4"</u>				<u>LT-81, "TYPE 5/ TYPE 6"</u>				<u>LT-84, "TYPE 7/ TYPE 8"</u>				<u>LT-86, "TYPE 9/ TYPE 10"</u>			

x: Applicable

FRONT FOG LAMP


TYPE 1/TYPE 2 System diagram

- Type 1



MKIB0273E

- Type 2



MKIB0274E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

FRONT FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

A
B
C
D
E
F
G
H
I
J
LT
L
M


FRONT FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


FRONT FOG LAMP

TYPE 3/TYPE 4 System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R


FRONT FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


FRONT FOG LAMP

TYPE 5/TYPE 6 System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

FRONT FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

FRONT FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A
B
C
D
E
F
G
H
I
J

LT

L


M

FRONT FOG LAMP

TYPE 7/TYPE 8


System diagram

- Type 7



MKIB0275E

- Type 8



MKIB0276E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

FRONT FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R

A
B
C
D
E
F
G
H
I
J
L
M

LT


FRONT FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



FRONT FOG LAMP

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

A
B
C
D
E
F
G
H
I
J
K
L
M

LT

FRONT FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


FRONT FOG LAMP

EKS00EM5



Wiring Diagram — F/FOG — WITH GASOLINE ENGINE

LT-F/FOG-01


: DATA LINE
 : LHD MODELS
 : RHD MODELS



A
B
C
D
E
F
G
H
I
J
LT
L
M



REFER TO THE FOLLOWING.
 (M1) -SUPER MULTIPLE JUNCTION (SMJ)
 (M16) -FUSE BLOCK-JUNCTION BOX (J/B)





FRONT FOG LAMP

LT-F/FOG-02

▬ : DATA LINE




REFER TO PG-POWER.






FRONT FOG LAMP

WITH DIESEL ENGINE


LT-F/FOG-03

-  : DATA LINE
-  : LHD MODELS
-  : RHD MODELS





REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK-JUNCTION BOX (J/B)






FRONT FOG LAMP



FRONT FOG LAMP

Terminals and Reference Value for BCM

EKS00EM7

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
2	B	Ground	ON	—	Approx. 0
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2166J</p>
14	P	Combination switch output 3			
15	W	Combination switch output 5			
33	R	Combination switch output 2			
34	Y	Combination switch output 4	ON	Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
19	R	CAN H			
24	OR	Ignition power supply	ON	—	Approx. 12
39	W	CAN L	—	—	—
70	B	Ground	ON	—	Approx. 0
74	W	BAT power supply	—	—	Approx. 12
79	Y	Battery power supply	—	—	Approx. 12

Terminals and Reference Values for IPDM E/R

EKS00EM8

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
3	B	Ground	ON	—	Approx. 0
43	W	Front fog lamp (RH)	ON	ON	Approx. 12
				OFF	Approx. 0
44	PU	Front fog lamp (LH)	ON	ON	Approx. 12
				OFF	Approx. 0
52	R	CAN H	—	—	—
54	B	Ground	ON	—	Approx. 0
58	W	CAN L	—	—	—

FRONT FOG LAMP

EKS00EM9

How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaints.
2. Understand operation description and function description.
Refer to Front fog lamp [LT-74, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-94, "Preliminary Check"](#)
4. Confirm headlamp does not operate by fail-safe control of IPDM E/R. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#) .
5. Check symptom and repair or replace the cause of malfunction.
6. Dose the front fog lamp operate normally? Yes: GO TO 7. No: GO TO 5.
7. INSPECTION END.

Preliminary Check

EKS00EMA

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check BCM fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch ON or START position	4

Refer to [LT-89, "Wiring Diagram — F/FOG —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

2. POWER SUPPLY CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM connector and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)		OFF	ACC	ON
M50	74 (W)	Ground	Battery voltage	Battery voltage	Battery voltage
M50	79 (Y)		Battery voltage	Battery voltage	Battery voltage
M48	24 (OR)		0V	0V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse. If NG, repair or replace the harness or fuse.



FRONT FOG LAMP


3. CHECK GROUND CIRCUIT

Check continuity between BCM and ground.

Terminals		(-)	Continuity
(+) Connector			
Terminal (Wire color)			
M48	2 (B)	Ground	Yes
M50	70 (B)		

OK or NG

- OK >> INSPECTION END.
- NG >> Repair or replace the harness.



CONSULT-II Function (BCM)

Refer to [LT-28, "CONSULT-II Functions \(BCM\)"](#) .

CONSULT-II Function (IPDM)

Refer to [LT-31, "CONSULT-II Functions \(IPDM E/R\)"](#) .

Front fog lamps Does Not Illuminate (Both Sides)

1. CHECK FUSE

Check the following
20A fuse (No. 55, located in the IPDM E/R).

OK or NG

- OK >> GO TO 2.
- NG >> Replace front fog lamp fuses, if fuses are blown, it verified that harness are malfunctions for short between IPDM E/R and front fog lamps.

2. CHECK BETWEEN COMBINATION SWITCH AND BCM

Ⓟ With CONSULT-II

Select BCM on CONSULT-II. Check lighting switch ("FR FOG SW") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in 1st position and fog lamp switch in ON position : FR FOG SW ON

When lighting switch is in OFF position : FR FOG SW OFF

ⓧ Without CONSULT-II

Refer to [LT-196, "Check Combination Switch"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refer to [LT-196, "Check Combination Switch"](#) .

DATA MONITOR			
MONITOR			
IGN ON SW		ON	
HI BEAM SW		ON	
H/L SW POS		ON	
LIGHT SW 1ST		OFF	
AUTO LIGHT SW		OFF	
PASSING SW		OFF	
FR FOG SW		OFF	
DOOR SW-DR		OFF	
VEHICLE SPEED		0 km/h	
Page Down			
RECORD			
MODE	BACK	LIGHT	COPY

FRONT FOG LAMP

3. CHECK BETWEEN IPDM E/R AND FRONT FOG LAMP

With CONSULT-II

1. Select "IPDM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "FRONT FOG" on "SELECT TEST ITEM" screen.
3. Make sure that front fog lamp operate normally.

Without CONSULT-II

1. Start up auto active test. Refer to [PG-42, "Auto Active Test"](#).
2. Make sure that front fog lamp operate normally.

OK or NG

OK >> GO TO 4.

NG >> Check the following:

- Fog lamp bulbs
- Fog lamp ground circuit harness
- Harness between fog lamps and IPDM E/R

ACTIVE TEST			
FRONT FOG LAMP	OFF		
ON			
MODE	BACK	LIGHT	COPY

MKIB0552E

4. CHECK BETWEEN IPDM E/R AND BCM

Select IPDM E/R on CONSULT-II. Check lighting switch ("FR FOG REQ") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in 1st position and fog lamp switch in ON position : FR FOG REQ ON

When lighting switch is in OFF position : FR FOG REQ OFF

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace BCM.

DATA MONITOR	
MONITOR	
MOTOR FAN REQ	1
AC COMP REQ	OFF
TAIL & CLR REQ	OFF
HL LO REQ	OFF
HL HI REQ	OFF
FR FOG REQ	OFF
FR WIP REQ	STOP
WIP AUTO STOP	ON
WIP PROT	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

SKIA2475E

Front Fog Lamp Does Not Illuminate (One Side)

1. CHECK BULB

Check front fog bulb.

OK or NG

OK >> GO TO 2.

NG >> Replace front fog lamp bulb.

EKS00EME

FRONT FOG LAMP


2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front fog lamp connector.
3. Turn ignition switch ON.
4. Check voltage between front fog lamp harness connector terminal and ground.

Terminals		(-)	Condition	Voltage [V]
(+)				
Connector	Terminal (Wire color)			
E7	1 (PU)	Ground	Lighting switch high beam ON	Battery voltage
E37	1 (W)			

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 4.




3. CHECK BETWEEN IPDM E/R AND FRONT FOG LAMPS

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between harness connector terminals of IPDM E/R and harness connector terminal of front fog lamps.

Terminals				Continuity	
IPDM E/R		Front fog lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E15	43 (W)	RH	E34	1 (W)	Yes
	44 (PU)	LH	E7	1 (PU)	

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair or replace harness or connector.




4. CHECK FRONT FOG LAMP AND GROUND CIRCUIT

Check continuity between front fog lamp harness connector E7 (LH) or E34 (RH) terminal 2 (B) and ground.

Continuity should exist.

OK or NG

- OK >> Check the condition of harness and the connector.
 NG >> Repair or replace harness or connector.




FRONT FOG LAMP


Aiming Adjustment

EKS00EMF


1. Set the top edge of the fog lamp lens as shown in the figure.



2. Turn front fog lamps ON.



3. Adjust front fog lamps as shown in the figure.
 - When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.



Bulb Replacement

EKS00EMG

1. Turn ignition switch OFF
2. Remove fender protector. Refer to [EI-11, "FENDER PROTECTOR"](#) .
3. Remove front bumper. Refer to [EI-4, "FRONT BUMPER"](#) .
4. Turn bulb socket counterclockwise and unlock it.
5. Remove bulb from socket.

Front fog lamp: 12V-55W (H11)

Removal and Installation


REMOVAL

EKS00EMH

1. Turn ignition switch OFF
2. Remove fender protector. Refer to [EI-11, "FENDER PROTECTOR"](#) .
3. Remove front bumper. Refer to [EI-4, "FRONT BUMPER"](#) .

FRONT FOG LAMP

4. Remove front fog lamp mounting bolt.



A
B
C
D
E
F
G
H
I
J
LT
L
M

INSTALLTION

Install in the reverse order of removal.

REAR FOG LAMP

REAR FOG LAMP

PFP:26550

System Description

EKS00EMI

The rear fog lamp operation is controlled by the lighting switch which built into the combination switch and BCM (body control module).BCM read combination switch condition.Refer to [LT-189, "System Description"](#)

OUTLINE

Power is supplied at all times

- through 40A fusible link (letter J , located in fuse and fusible link box)
- to terminals 74 and 79 of the BCM.

When the ignition switch is in ON or START position, power is supplied

- through 10A fuse [No. 4, located in fuse block (J/B)]
- to terminal 24 of the BCM.

Ground is supplied

- to BCM terminals 2 and 70
- through body grounds M19 and M20.

REAR FOG LAMP OPERATION

When the lighting switch is turned to 2ND position or front fog lamp switch ON position and rear fog lamp switch in ON position, BCM read combination switch condition (refer to [LT-189, "System Description"](#)). Rear fog lamp is energized and then power is supplied.

With the rear fog lamp switch in the ON position, BCM supplies the power supply to rear fog lamp.

- to rear combination lamp LH/RH terminal 6
- through BCM terminal 69

Ground is supplied

- to rear combination lamp LH/RH terminal 4
- through body grounds B17, B23, B44 and B51

With power and grounds supplied, the rear fog lamps illuminate.

Rear fog indicator illuminate when combination meter receives input requesting rear fog indicator illuminate. This is communicated to BCM across the CAN communication lines.

When combination meter received rear fog lamp request signal, combination meter will illuminate rear fog indicator.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-189, "System Description"](#)

REAR FOG LAMP

CAN Communication SYSTEM DESCRIPTION

EKS00ERI

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LTA

Go to CAN system, when selecting your car model from the following table.


Body type	3door/5door																			
Axle	2WD																			
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K									
Handle	LHD/RHD																			
Brake control	ABS system					ESP system					ABS									
Transmission	A/T		M/T			A/T		M/T			M/T									
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable
CAN communication unit																				
ECM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Data link connector	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Combination meter	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Intelligent Key unit	x	x			x	x			x	x			x	x			x	x		
Drive computer	x		x		x		x		x		x		x		x		x		x	
EPS control unit	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
BCM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
ABS actuator and electric unit (control unit)	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
TCM	x	x	x	x					x	x	x	x								
IPDM E/R	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CAN communication type	<u>LT-102, "TYPE 1/TYPE 2"</u>				<u>LT-105, "TYPE 3/TYPE 4"</u>				<u>LT-107, "TYPE 5/TYPE 6"</u>				<u>LT-110, "TYPE 7/TYPE 8"</u>				<u>LT-112, "TYPE 9/TYPE 10"</u>			

x: Applicable


REAR FOG LAMP

TYPE 1/TYPE 2 System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

REAR FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

A
B
C
D
E
F
G
H
I
J
K
L
M

LT


REAR FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


REAR FOG LAMP

TYPE 3/TYPE 4 System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R


REAR FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


REAR FOG LAMP

TYPE 5/TYPE 6 System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

REAR FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

REAR FOG LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A
B
C
D
E
F
G
H
I
J

LT

L


M

REAR FOG LAMP

TYPE 7/TYPE 8


System diagram

- Type 7



MKIB0275E

- Type 8



MKIB0276E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

REAR FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R

A
B
C
D
E
F
G
H
I
J
L
M

LT


REAR FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



REAR FOG LAMP

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

A
B
C
D
E
F
G
H
I
J
K
L
M

LT

REAR FOG LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					



REAR FOG LAMP





Wiring Diagram — R/FOG —

SMA for VIN >SJN**AK12U1309269

EKS00EMK

LT-R/FOG-01

 : DATA LINE
 : LHD MODELS
 : RHD MODELS



REFER TO THE FOLLOWING.






- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK-JUNCTION BOX (J/B)



A
B
C
D
E
F
G
H
I
J
LT
L
M

REAR FOG LAMP

LT-R/FOG-02






REFER TO THE FOLLOWING.

(M16) - FUSE BLOCK - JUNCTION BOX (J/B)

REAR FOG LAMP

Terminals and Reference Value for BCM

EKS00EML

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
2	B	Ground	ON	—	Approx. 0
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2166J</p>
14	P	Combination switch output 3			
15	W	Combination switch output 5			
33	R	Combination switch output 2			
34	Y	Combination switch output 4	ON	Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)	 <p style="text-align: right; font-size: small;">SKIA2167J</p>
19	R	CAN H			
24	OR	Ignition power supply	ON	—	Approx. 12
39	W	CAN L	—	—	—
69	R	Rear fog lamp signal	ON	Rear fog lamp switch ON	Approx. 12
				Rear fog lamp switch OFF	Approx. 0
70	B	Ground	ON	—	Approx. 0
74	W	BAttery power supply	—	—	Approx. 12
79	Y	Battery power supply	—	—	Approx. 12

A
B
C
D
E
F
G
H
I
J
LT
L
M

REAR FOG LAMP

EKS00EMM

How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaints.
2. Understand operation description and function description.
Refer to rear fog lamp [LT-100, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-118, "Preliminary Check"](#)
4. Check symptom and repair or replace the cause of malfunction.
5. Does the rear fog lamp operate normally? Yes: GO TO 6. No: GO TO 4.
6. INSPECTOPN END.

Preliminary Check

EKS00EMN

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check BCM fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch (ON)	4

Refer to [LT-115, "Wiring Diagram — R/FOG —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)			OFF	ACC	ON
Connector	Terminal (Wire color)				
M50	79 (Y)	Ground	Battery voltage	Battery voltage	Battery voltage
M48	24 (OR)		0V	0V	Battery voltage
M50	74 (W)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse. If NG, repair or replace the harness or fuse.



REAR FOG LAMP


3. CHECK GROUND CIRCUIT

Check continuity between BCM and ground.

Terminals		(-)	Continuity
(+) Connector			
Terminal (Wire color)			
M48	2 (B)	Ground	Yes
M50	70 (B)		

OK or NG

- OK >> INSPECTION END.
- NG >> Repair or replace the harness.



CONSULT-II Function (BCM)

Refer to [LT-28, "CONSULT-II Functions \(BCM\)"](#).

Rear Fog Lamp Does Not Illuminate

1. AHECK BETWEEN COMBINATION SWITCH AND BCM

With CONSULT-II

Select BCM on CONSULT-II. Check lighting switch ("RR FOG SW") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in 2nd position, fog lamp switch in ON position and rear fog lamp switch in ON position

When rear fog lamp switch is in OFF position

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HI BEAM SW	ON
H/L SW POS	ON
LIGHT SW 1ST	OFF
AUTO LIGHT SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF
VEHICLE SPEED	0 km/h
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

MKIB0843E

Without CONSULT-II

Refer to [LT-189, "COMBINATION SWITCH"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Refer to [LT-189, "COMBINATION SWITCH"](#).


2. CHECK BCM OUTPUT SIGNAL

Check voltage between BCM terminal 69 (R) and ground.

Connector	Terminal (Wire color)	(-)	Condition	Voltage
M50	69 (R)	Ground	Rear fog switch ON	Battery voltage
			Rear fog switch OFF	Approx. 0

OK or NG

- OK >> GO TO 3.
- NG >> Replace BCM.




REAR FOG LAMP

3. CHECK BETWEEN BCM AND REAR FOG LAMPS

1. Turn ignition switch OFF.
2. Disconnect BCM connector and rear combination lamp connector.
3. Check continuity between BCM and rear combination lamps.

Terminals					Continuity
Rear fog lamp (Rear combination lamp)			BCM		
Connector		Terminal (Wire color)	Connector	Terminal (Wire color)	
RHD models	B36	6 (R)	M50	69 (R)	Yes
LHD models	B37	6 (R)			



OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness or connector.

4. CHECK BULB

Check rear fog lamp bulb.

OK or NG

- OK >> GO TO 5.
 NG >> Replace rear fog lamp bulb.


5. CHECK REAR FOG LAMP GROUND CIRCUIT

Check continuity between rear fog lamp harness connector B36 (RHD) or B37 (LHD) terminal 4(B) and ground.

Continuity should exist.

OK or NG

- OK >> Replace rear fog lamp.
 NG >> Repair or replace harness or connector.



Bulb Replacement

Refer to [LT-186, "Bulb Replacement"](#) .

Removal and Installation

Refer to [LT-186, "Removal and Installation"](#) .

EKS00EMQ

EKS00EMR

TURN SIGNAL AND HAZARD WARNING LAMPS

TURN SIGNAL AND HAZARD WARNING LAMPS

PPF:26120

System Description

EKS00EMS

TURN SIGNAL OPERATION

When the ignition switch is in the ON or START position, power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM (body control module) terminal 24, and
- through 10A fuse [No. 2, located in the fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to BCM terminals 2 and 70, and
- to combination meter terminals 21, 22 and 23
- through body grounds M19 and M20.

LH Turn

When the turn signal switch (combination switch) is moved to the LH position, the BCM read combination switch condition (Refer to [LT-189, "System Description"](#)) power is supplied.

- through BCM terminal 65
- to front turn signal lamp LH terminal 1,
- to side turn signal lamp LH terminal 1 and
- to rear combination lamp LH (turn signal) terminal 5.

Ground is supplied to the front turn signal lamp LH terminal 2 and side turn signal lamp LH terminal 2 through body grounds E25(Gasoline engine models), E26 and E40.

Ground is also supplied to rear combination lamp LH (turn signal) terminal 4 through body grounds B17, B23, B44, and B51.

BCM send turn indicator signal to combination meter with CAN communication line. Combination meter is flashed turn LH indicator lamp.

With power and ground supplied, the BCM controls the flashing of the LH turn signal lamps.

RH Turn

When the turn signal switch (combination switch) is moved to the RH position, the BCM read combination meter condition (Refer to [LT-189, "System Description"](#)). Power is supplied.

- through BCM terminal 66
- to front turn signal lamp RH terminal 1,
- to side turn signal lamp RH terminal 1 and
- to rear combination lamp RH (turn signal) terminal 5.

Ground is supplied to the front turn signal lamp RH terminal 2 and side turn signal lamp RH terminal 2 through body grounds E25(Gasoline engine models), E26 and E40.

Ground is supplied to rear combination lamp RH (turn signal) terminal 4 through body ground B17, B23, B44 and B51.

BCM send turn indicator signal to combination meter via CAN communication line. Combination meter is flashed turn RH indicator lamp.

With power and ground supplied, the BCM controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times

- to BCM terminals 74 and 79
- through 40A fusible link (letter J , located in the fuse and fusible link box), and
- to combination meter terminal 27
- through 10A fuse [No. 8, located in the fuse block (J/B)].

Ground is supplied

- to hazard switch terminal 1,
- to BCM terminals 2 and 70 and
- to combination meter terminals 21, 22 and 23
- through body grounds M19 and M20.

A
B
C
D
E
F
G
H
I
J
L
M

LT

TURN SIGNAL AND HAZARD WARNING LAMPS

When the hazard switch is ON position, ground is supplied

- to BCM terminal 26
- through hazard switch terminal 2.

Power is supplied

- through BCM terminal 65
- to front turn signal lamp LH terminal 1
- to side turn signal lamp LH terminal 1
- to rear combination lamp LH (turn signal) terminal 5
- through BCM terminal 66
- to front turn signal lamp RH terminal 1
- to side turn signal lamp RH terminal 1
- to rear combination lamp RH (turn signal) terminal 5.

Ground is supplied

- to the front turn signal lamp LH terminal 2 and side turn signal lamp LH terminal 2 through body grounds E25(Gasoline engine models), E26 and E40
- to the front turn signal lamp RH terminal 2 and side turn signal lamp RH terminal 2 through body grounds E25(Gasoline engine models), E26 and E40
- to rear combination lamp LH (turn signal) terminal 4 through body grounds B17, B23, B44 and B51
- to rear combination lamp RH (turn signal) terminal 4 through body grounds B17, B23, B44 and B51.

BCM send turn indicator signal to combination meter with CAN communication line. Combination meter is flashed turn LH and RH indicator lamps.

With power and ground supplied, the BCM controls the flashing of the hazard warning lamps.

MULTI-REMOTE CONTROL SYSTEM OPERATION

Power is supplied at all times

- to BCM terminals 74 and 79
- through 40A fusible link (letter J , located in the fuse and fusible link box), and
- to combination meter terminal 27
- through 10A fuse [No. 8, located in the fuse block (J/B)].

Ground is supplied

- to BCM terminals 2 and 70
- through body grounds M19, M20, and
- to combination meter terminals 21, 22 and 23
- through body grounds M19 and M20.

When BCM receives LOCK or UNLOCK signal from remote controller, power is supplied.

- through BCM terminal 65
- to front turn signal lamp LH terminal 1
- to side turn signal lamp LH terminal 1
- to rear combination lamp LH (turn signal) terminal 5
- through BCM terminal 66
- to front turn signal lamp RH terminal 1
- to side turn signal lamp RH terminal 1
- to rear combination lamp RH (turn signal) terminal 5.

Ground is supplied

- to the front turn signal lamp LH terminal 2 and side turn signal lamp LH terminal 2 through body grounds E25(Gasoline engine models), E26 and E40.
- to the front turn signal lamp RH terminal 2 and side turn signal lamp RH terminal 2 through body grounds E25(Gasoline engine models), E26 and E40.
- to rear combination lamp LH (turn signal) terminal 4 through body grounds B17, B23, B44 and B51.
- to rear combination lamp RH (turn signal) terminal 4 through body grounds B17, B23, B44 and B51.

TURN SIGNAL AND HAZARD WARNING LAMPS

BCM send turn indicator signal to combination meter via CAN communication line. Combination meter is flashed turn LH and RH indicator lamps.
With power and ground supplied, the BCM controls the flashing of the hazard warning lamps.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-189, "System Description"](#)

A

B

C

D

E

F

G

H

I

J

LT

L

M

TURN SIGNAL AND HAZARD WARNING LAMPS

CAN Communication SYSTEM DESCRIPTION

EKS00ERK

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LTB

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door																					
Axle	2WD																					
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K											
Handle	LHD/RHD																					
Brake control	ABS system										ESP system										ABS	
Transmission	A/T					M/T					A/T					M/T					M/T	
Intelligent Key system	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable		
CAN communication unit																						
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×		
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×		
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×		
Intelligent Key unit	×	×			×	×			×	×			×	×			×	×				
Drive computer	×		×		×		×		×		×		×		×		×		×			
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×		
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×		
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×		
TCM	×	×	×	×					×	×	×	×										
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×		
CAN communication type	<u>LT-125, "TYPE 1/ TYPE 2"</u>				<u>LT-128, "TYPE 3/ TYPE 4"</u>				<u>LT-130, "TYPE 5/ TYPE 6"</u>				<u>LT-133, "TYPE 7/ TYPE 8"</u>				<u>LT-135, "TYPE 9/ TYPE 10"</u>					


×: Applicable

TURN SIGNAL AND HAZARD WARNING LAMPS


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

A
B
C
D
E
F
G
H
I
J
LT
L
M

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

I

J

LT

L


M

TURN SIGNAL AND HAZARD WARNING LAMPS


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
B
C
D
E
F
G
H
I
J
LT
L
M

TURN SIGNAL AND HAZARD WARNING LAMPS


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R	
A/T shift position signal		R						T		A
A/T shift schedule change demand signal							T	R		B
Stop lamp switch signal		T						R		C
O/D OFF indicator lamp signal		R						T		D
Engine and A/T integrated control signal	T							R		E
	R							T		
Fuel consumption monitor signal	T	R								
Oil pressure switch signal		R		R					T	
A/C compressor request signal	T								R	F
A/C switch signal	R								T	
Heater fan switch signal	R					T				G
Cooling fan speed request signal	T								R	
Cooling fan speed status signal	R								T	
Position lights request signal		R		R		T			R	H
Position light status signal	R								T	
Low beam request signal						T			R	I
Low beam status signal	R								T	
High beam request signal		R				T			R	J
High beam status signal	R								T	
Day time light request signal						T			R	
Vehicle speed signal	R	R			R		T			LT
	R	T	R	R	R	R				
Sleep/wake up signal		R	R			T			R	
Door switch signal		R	R	R		T			R	L
Turn indicator signal		R				T				
Buzzer output signal		R				T				M
		R	T							
MI signal	T	R		R						
Front wiper request signal						T			R	
Front wiper stop position signal						R			T	
Rear window defogger switch signal						T			R	
Rear window defogger control signal	R								T	
Drive computer signal		T		R						
EPS warning lamp signal		R		R	T					
ABS warning lamp signal		R		R			T			
ESP warning lamp signal		R		R			T			
ESP OFF indicator signal		R					T			
SLIP indicator lamp signal		R					T			


TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


TURN SIGNAL AND HAZARD WARNING LAMPS

TYPE 7/TYPE 8 System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 LT
 L
 M

TURN SIGNAL AND HAZARD WARNING LAMPS

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A

B

C

D

E

F

G

H

I

J



LT

L

M


TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02



REFER TO THE FOLLOWING.

- M1** -SUPER MULTIPLE JUNCTION (SMJ)
- M82** -JOINT CONNECTOR (J/C)





TURN SIGNAL AND HAZARD WARNING LAMPS

Terminals and Reference Value for BCM

EKS00EMV

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)	
			Ignition switch	Operation or condition		
2	B	Ground	ON	—	Approx. 0	
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	<p style="text-align: right; font-size: small;">SKIA2167J</p>	
8	L	Combination switch input 3				
9	PU	Combination switch input 1				
27	GY	Combination switch input 4				
28	G	Combination switch input 2				
13	GY	Combination switch output 1	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	<p style="text-align: right; font-size: small;">SKIA2166J</p>	
14	P	Combination switch output 3				
15	W	Combination switch output 5				
33	R	Combination switch output 2				
34	Y	Combination switch output 4	ON	Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)	<p style="text-align: right; font-size: small;">SKIA2167J</p>	
19	R	CAN H				—
24	OR	Ignition power supply	ON	—	Approx. 12	
26	L	Hazard	OFF	Hazard switch	ON	Approx. 0
					OFF	<p style="text-align: right; font-size: small;">SKIA2239J</p>
39	W	CAN L	—	—	—	

TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
65	P	Turn signal (LH)	ON	Combination switch	Turn left ON  SKIA1120J
66	R	Turn signal (RH)			Turn right ON  SKIA1120J
70	B	Ground	ON	—	Approx. 0
74	W	Battery power supply	—	—	Approx. 12
79	Y	Battery power supply	—	—	Approx. 12

A
B
C
D
E
F
G
H
I
J
LT
L
M

TURN SIGNAL AND HAZARD WARNING LAMPS

EKS00EMW

How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaints.
2. Understand operation description and function description.
Refer to Turn signal and hazard warning lamps [LT-121, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-142, "Preliminary Check"](#)
4. Check symptom and repair or replace the cause of malfunction.
5. Dose the turn signal and hazard warning lamps operate normally? Yes: GO TO 6. No: GO TO 4.
6. INSPECTION end.

Preliminary Check

EKS00EMX

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check BCM fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch ON or START position	4

Refer to [LT-138, "Wiring Diagram — TURN —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

2. POWER SUPPLY CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM connector and ground.

Terminals		(-)	Ignition switch position		
(+)			OFF	ACC	ON
Connector	Terminal (Wire color)	Ground	Battery voltage	Battery voltage	Battery voltage
M50	74 (W)		Battery voltage	Battery voltage	Battery voltage
M50	79 (Y)		Battery voltage	Battery voltage	Battery voltage
M48	24 (OR)		0V	0V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse. If NG, repair or replace the harness or fuse.



TURN SIGNAL AND HAZARD WARNING LAMPS

3. CHECK GROUND CIRCUIT


Check continuity between BCM and ground.

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)		
M48	2 (B)	Ground	Yes
M50	70 (B)		

OK or NG

OK >> INSPECTION END

NG >> Repair or replace the harness (ground circuit).



A
B
C
D
E
F
G
H
I
J
LT
L
M

TURN SIGNAL AND HAZARD WARNING LAMPS

CONSULT-II Functions (BCM)

EKS00EMY

CONSULT-II can display each diagnosis item using the diagnostic test modes shown following. Data is received and transmitted via the control module communication line.


BCM trouble diagnosis item	Inspection Item, Diagnosis Mode	Description
Flasher	Work Support	Changes the setting for each function.
	Data monitor	Displays BCM input data in real time.
	Active Test	Sends a drive signal to electronic components to check their operation.

CONSULT-II BASIC OPERATION


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and "CONSULT-II CONVERTER" to data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "BCM" on "SELECT SYSTEM" screen.
If "BCM" is not indicated, go to [GI-36. "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




TURN SIGNAL AND HAZARD WARNING LAMPS

6. Touch "FLASHER" on "SELECT TEST ITEM" screen.



7. Touch "WORK SUPPORT", "DATA MONITOR" or "ACTIVE TEST" on "SELECT DIAG MODE" screen.



WORK SUPPORT

Supported Item	All items will be monitored.
HAZARD LAMP SET	hazard reminder function mode can be changed in this mode.

Hazard Lamp Set

	MODE1		MODE2		MODE3		MODE4	
Remote controller operation	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	-	-	-	Twice	Once	-	Once	Twice

DATA MONITOR

Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on the "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
SELECTION FROM MENU	Selects and monitors individual items.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

Display Item List

Monitor item "UNIT"	Display content
IGN ON SW [ON/OFF]	Displays status (Ignition switch ON: ON/Others OFF, ACC: OFF) as judged from the ignition switch signal.
HAZARD SW [ON/OFF]	Displays status (Hazard ON: ON/Hazard OFF: OFF) as judged from hazard switch signal.
TURN SIGNAL R [ON/OFF]	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.

TURN SIGNAL AND HAZARD WARNING LAMPS

Monitor item "UNIT"	Display content
TURN SIGNAL L [ON/OFF]	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
TURN/L MNTR [ON/OFF]	Displays status (One bulb blown: ON/Others: OFF) as judged from bulb signal.

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check left or right turn signal lamp operation. The turn signal lamp turned ON when "LH" or "RH" on CONSULT-II screen is touched.

TURN SIGNAL AND HAZARD WARNING LAMPS

EKS00EMZ

Turn Signal Lamp Does Not Operate

1. CHECK BULB

Check turn signal lamp bulb.

OK or NG

- OK >> GO TO 2.
- NG >> Replace turn signal lamp bulb.

2. CHECK BCM INPUT SIGNAL

With CONSULT-II

Select BCM on CONSULT-II. Check turn signal ("TURN SIGNAL") in "DATA MONITOR" mode with CONSULT-II.

When combination switch : TURN SIGNAL L ON
LH position

When combination switch : TURN SIGNAL R ON
RH position

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HAZARD SW	ON
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF
TURN/L MNTR	OFF

MKIB0844E

Without CONSULT-II


Refer to [LT-196, "Check Combination Switch"](#).

OK or NG

- OK >> GO TO 3.
- NG >> Refer to [LT-196, "Check Combination Switch"](#).

3. CHECK BCM

- Connect BCM connector and all turn signal lamp connectors.
- Check voltage between BCM connector M50 terminals 65, 66 and ground.



Terminals			(-)	Condition	Voltage
(+)					
Connector	Terminal (Wire color)				
RH	M50	66 (R)	Ground	Combination switch	
LH		65 (P)			

SKIA1120J

OK or NG

- OK >> Check harness for open between BCM and turn signal lamps, turn signal lamp ground circuit.
- NG >>
 - Replace BCM
 - Check harness for short between BCM and turn signal lamps. If NG, repair or replace the harness.

TURN SIGNAL AND HAZARD WARNING LAMPS

EKS00EN0

Hazard Lamp Does Not Operate

1. CHECK BULB

Check turn signal lamp bulb.

OK or NG

OK >> GO TO 2.

NG >> Replace turn signal lamp bulb.

2. CHECK BCM INPUT SIGNAL

① With CONSULT-II

Select BCM on CONSULT-II. Check turn signal ("HAZARD SW") in "DATA MONITOR" mode with CONSULT-II.

When hazard switch ON : HAZARD SW ON

When hazard switch OFF : HAZARD SW OFF

⊗ Without CONSULT-II

Refer to [LT-196, "Check Combination Switch"](#).

OK or NG

OK >> GO TO 3.

NG >> Refer to [LT-196, "Check Combination Switch"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HAZARD SW	ON
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF
TURN/L MNTR	OFF

MKIB0844E

3. CHECK HAZARD SWITCH AND BCM

1. Turn ignition switch OFF.
2. Disconnect BCM connector and hazard switch connector.
3. Check continuity between harness connector M48 terminal 26 (L) of BCM and hazard switch harness connector M61 terminal 2 (L).

Continuity should exist.


4. Check continuity between harness connector M48 terminal 26 (L) of BCM and body ground.

Continuity should not exist.

OK or NG

OK >> GO TO 4.


NG >> Repair or replace harness or connector.



TURN SIGNAL AND HAZARD WARNING LAMPS

4. CHECK BCM AND GROUND

1. Connect BCM connector.
2. Check voltage between harness connector M48 terminal 26 (L) of BCM and ground with hazard switch in OFF position.



Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			IGN switch	Condition	
26	L	Hazard	OFF	ON	Approx. 0
				OFF	

OK or NG

- OK >> GO TO 5.
- NG >> Replace BCM.


5. CHECK HAZARD SWITCH

Check continuity hazard switch connector M61.

Terminal		Condition	Continuity
2	1	Hazard switch is ON	Yes
		Hazard switch is OFF	No

OK or NG

- OK >> GO TO 6.
- NG >> Replace hazard switch.




6. CHECK HAZARD SWITCH AND GROUND

Check continuity between harness connector M61 terminal 1 (B) of hazard switch and ground.

Continuity should exist.

OK or NG

- OK >> INSPECTION END.
- NG >> Repair or replace harness or connector.



TURN SIGNAL AND HAZARD WARNING LAMPS

Turn Signal Indicator Lamp Does Not Operate

EKS00EN1

1. CHECK BULB

Check indicator bulb.

OK or NG


- OK >> Replace combination meter.
- NG >> Replace indicator bulb.

Bulb Replacement FRONT TURN SIGNAL LAMP

EKS00EN2

1. Remove front grille. Refer to [EI-8, "FRONT GRILLE"](#).
2. Turn bulb socket left to release lock and remove it.
3. Remove bulb.


Front turn signal lamp : 12V-21W



SIDE TURN SIGNAL LAMP

1. Remove side turn signal lamp. Refer to [LT-151, "SIDE TURN SIGNAL LAMP"](#).
2. Turn bulb socket left to release lock and remove it.
3. Remove bulb.

Side turn signal lamp : 12V-5W




REAR TURN SIGNAL LAMP

Refer to [LT-186, "REAR COMBINATION LAMP"](#).

Removal and Installation FRONT TURN SIGNAL LAMP

EKS00EN3


1. Remove front grille. Refer to [EI-8, "FRONT GRILLE"](#).
2. Remove screw and tabs, and then remove front turn signal lamp from front grille.



TURN SIGNAL AND HAZARD WARNING LAMPS

SIDE TURN SIGNAL LAMP

1. Pull the side turn signal lamp in direction B while pushing it in direction A as shown by the arrow in the figure and remove from the vehicle.
2. Disconnect side turn signal lamp connector.
When installing, face surface with rib upwards.



REAR TURN SIGNAL LAMP

Refer to [LT-186, "REAR COMBINATION LAMP"](#) .

A
B
C
D
E
F
G
H
I
J
LT
L
M

PARKING, LICENSE PLATE AND TAIL LAMPS

System Description

EKS00EN4

The parking, license plate and tail lamps operation is controlled by the lighting switch which built into the combination switch, BCM (body control module) and IPDM E/R (intelligent power distribution module engine room). Tail lamp relay is built into IPDM E/R. BCM read combination switch condition. Refer to [LT-189, "System Description"](#)

Power is supplied at all times

- to tail lamp relay, located in the IPDM E/R, and
- to IPDM E/R
- through 20A fusible link (No.52, located in the IPDM E/R).

Power is also supplied at all times

- to BCM terminals 74 and 79
- through 40A fusible link (letter J , located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- to BCM terminal 24
- through 10A fuse [No. 4, located in the fuse block (J/B)].

Ground is supplied

- to BCM terminals 2 and 70
- through body grounds M19 and M20.
- to IPDM E/R terminals 3 and 54
- through body grounds E25(Gasoline engine models), E26 and E40.

OPERATION BY LIGHTING SWITCH

When the lighting switch is turned to 1ST position, BCM read combination switch condition (refer to [LT-189, "System Description"](#)). And BCM send parking, license plate and tail lamps request signal to IPDM E/R with CAN communication line. Then IPDM E/R is turned on tail lamp relay. Tail lamp relay is energized and then power is supplied.

- through terminal 49 of the IPDM E/R
- to parking lamp LH terminal 1
- through terminal 15 of the IPDM E/R
- to rear combination lamp LH terminal 3
- through terminal 45 of the IPDM E/R
- to parking lamp RH terminal 1
- through terminal 16 of the IPDM E/R
- to rear combination lamp RH terminal 3
- to license plate lamp terminal 2.

Ground is supplied at all times

- to each parking lamps terminal 2
- through body grounds E25(Gasoline engine models), E26 and E40
- to each rear combination lamps terminal 4
- to license plate lamp terminal 1
- through body grounds B17, B23, B44 and B51.

With power and ground supplied, the parking, license plate and tail lamps illuminate.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-189, "System Description"](#)

PARKING, LICENSE PLATE AND TAIL LAMPS

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, parking, license plate and tail lamps illuminate when the ignition switch is turned from OFF to ON or ACC and parking, license plate and tail lamps are turned off when the ignition switch is turned from ON or ACC to OFF. If the fail-safe system is operating, parking, license plate and tail lamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-19. "FAIL-SAFE FUNCTION"](#))

A

B

C

D

E

F

G

H

I

J

LT

L

M

PARKING, LICENSE PLATE AND TAIL LAMPS

CAN Communication SYSTEM DESCRIPTION

EKS00ERM

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LTC

Go to CAN system, when selecting your car model from the following table.


Body type	3door/5door																			
Axle	2WD																			
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K									
Handle	LHD/RHD																			
Brake control	ABS system					ESP system					ABS									
Transmission	A/T		M/T			A/T		M/T			M/T									
Intelligent Key system	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable														
CAN communication unit																				
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
Intelligent Key unit	×	×			×	×			×	×			×	×			×	×		
Drive computer	×		×		×		×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
TCM	×	×	×	×					×	×	×	×								
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
CAN communication type	<u>LT-155, "TYPE 1/ TYPE 2"</u>				<u>LT-158, "TYPE 3/ TYPE 4"</u>				<u>LT-160, "TYPE 5/ TYPE 6"</u>				<u>LT-163, "TYPE 7/ TYPE 8"</u>				<u>LT-165, "TYPE 9/ TYPE 10"</u>			

×: Applicable


PARKING, LICENSE PLATE AND TAIL LAMPS

TYPE 1/TYPE 2 System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

I

J

LT


L

M


PARKING, LICENSE PLATE AND TAIL LAMPS

TYPE 3/TYPE 4 System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

PARKING, LICENSE PLATE AND TAIL LAMPS


Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A
B
C
D
E
F
G
H
I
J
LT
L
M


PARKING, LICENSE PLATE AND TAIL LAMPS

TYPE 5/TYPE 6 System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R	
A/T shift position signal		R						T		A
A/T shift schedule change demand signal							T	R		B
Stop lamp switch signal		T						R		C
O/D OFF indicator lamp signal		R						T		D
Engine and A/T integrated control signal	T							R		E
	R							T		
Fuel consumption monitor signal	T	R								
Oil pressure switch signal		R		R					T	
A/C compressor request signal	T								R	F
A/C switch signal	R								T	
Heater fan switch signal	R					T				G
Cooling fan speed request signal	T								R	
Cooling fan speed status signal	R								T	
Position lights request signal		R		R		T			R	H
Position light status signal	R								T	
Low beam request signal						T			R	I
Low beam status signal	R								T	
High beam request signal		R				T			R	J
High beam status signal	R								T	
Day time light request signal						T			R	
Vehicle speed signal	R	R			R		T			LT
	R	T	R	R	R	R				
Sleep/wake up signal		R	R			T			R	
Door switch signal		R	R	R		T			R	L
Turn indicator signal		R				T				
Buzzer output signal		R				T				M
		R	T							
MI signal	T	R		R						
Front wiper request signal						T			R	
Front wiper stop position signal						R			T	
Rear window defogger switch signal						T			R	
Rear window defogger control signal	R								T	
Drive computer signal		T		R						
EPS warning lamp signal		R		R	T					
ABS warning lamp signal		R		R			T			
ESP warning lamp signal		R		R			T			
ESP OFF indicator signal		R					T			
SLIP indicator lamp signal		R					T			


PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


PARKING, LICENSE PLATE AND TAIL LAMPS

TYPE 7/TYPE 8 System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



A
B
C
D
E
F
G
H
I
J
LT
L
M

PARKING, LICENSE PLATE AND TAIL LAMPS

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A

B

C

D

E

F

G

H

I

J

LT


L

M

PARKING, LICENSE PLATE AND TAIL LAMPS

Schematic

EKS00EN6




MKWA1440E





PARKING, LICENSE PLATE AND TAIL LAMPS

Wiring Diagram — TAIL/L —

SMA for VIN >SJN**AK12U1309269 EKS00EN7

LT-TAIL/L-01

-  : DATA LINE
-  : LHD MODELS
-  : RHD MODELS



REFER TO THE FOLLOWING.




- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK-JUNCTION BOX (J/B)



A
B
C
D
E
F
G
H
I
J
LT
L
M





PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02





PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-03



REFER TO THE FOLLOWING.
(M1) -SUPER MULTIPLE JUNCTION (SMJ)



PARKING, LICENSE PLATE AND TAIL LAMPS

Terminals and Reference Value for BCM

EKS00EN8

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
2	B	Ground	ON	—	Approx. 0
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	
14	P	Combination switch output 3			
15	W	Combination switch output 5			
33	R	Combination switch output 2			
34	Y	Combination switch output 4	ON	Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)	
19	R	CAN H			
24	OR	Ignition power supply	ON	—	Approx. 12
39	W	CAN L	—	—	—
70	B	Ground	ON	—	Approx. 0
74	W	Battery power supply	—	—	Approx. 12
79	Y	Battery power supply	—	—	Approx. 12

Terminals and Reference Value for IPDM E/R

EKS00EN9

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)	
			Ignition switch	Operation or condition		
3	B	Ground	ON	—	Approx. 0	
15	GY	Tail lamp (LH)	ON	Lighting switch	1st position	Approx. 12
16	PU	Tail lamp (RH)			OFF	Approx. 0
45	R	Tail lamp (RH)		OFF	OFF	Approx. 0
49	GY	Tail lamp (LH)				
52	R	CAN H	—	—	—	
54	B	Ground	ON	—	Approx. 0	
58	W	CAN L	—	—	—	

PARKING, LICENSE PLATE AND TAIL LAMPS

EKS00ENA

How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaints.
2. Understand operation description and function description.
Refer to Parking, license plate and tail lamps [LT-152, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-173, "Preliminary Check"](#) .
4. Confirm parking, license plate and tail lamps does not operate by fail-safe control of IPDM E/R. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#) .
5. Check symptom and repair or replace the cause of malfunction.
6. Dose the parking, license plate and tail lamps operate normally? Yes: GO TO 7. No: GO TO 5.
7. INSPECTION END.

Preliminary Check

EKS00ENB

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check BCM fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch ON or START position	4

Refer to [LT-169, "Wiring Diagram — TAIL/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

2. POWER SUPPLY CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM connector and ground.

Terminals		(-)	Ignition switch position			
(+)	Terminal (Wire color)		OFF	ACC	ON	
Connector	M50	74 (W)	Ground	Battery voltage	Battery voltage	Battery voltage
	M50	79 (Y)		Battery voltage	Battery voltage	Battery voltage
	M48	24 (OR)		0V	0V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse. If NG, repair or replace the harness.



PARKING, LICENSE PLATE AND TAIL LAMPS


3. GROUND CIRCUIT CHECK

Check continuity between BCM and ground.

Terminals		(-)	Continuity
(+)	Terminal (Wire color)		
Connector			
M48	2 (B)	Ground	Yes
M50	70 (B)		

OK or NG

- OK >> INSPECTION END.
- NG >> Repair or replace the harness.



CONSULT-II Function (BCM)

EKS00ENC

Refer to [LT-28, "CONSULT-II Functions \(BCM\)"](#).

CONSULT-II Function (IPDM E/R)

EKS00END

Refer to [LT-31, "CONSULT-II Functions \(IPDM E/R\)"](#).

Parking, License Plate And Tail Lamps Does Not Illuminate

EKS00ENE

1. CHECK BETWEEN COMBINATION SWITCH AND BCM

☐ With CONSULT-II

Select BCM on CONSULT-II. Check lighting switch ("LIGHT SW 1ST") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in : LIGHT SW 1ST ON
1ST position

When lighting switch is in : LIGHT SW 1ST OFF
OFF position

☒ Without CONSULT-II

Refer to [LT-196, "Check Combination Switch"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Refer to [LT-196, "Check Combination Switch"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HI BEAM SW	ON
H/L SW POS	ON
LIGHT SW 1ST	OFF
AUTO LIGHT SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF
VEHICLE SPEED	0 km/h
Page Down	
RECORD	
MODE	BACK LIGHT COPY

MKIB0843E

2. CHECK BETWEEN IPDM E/R TO PARKING LAMP

☐ With CONSULT-II

- Select "IPDM E/R" by CONSULT-II, and select "Active test" on "Diagnosis System selection" screen.
- Select "TAIL LAMP" on "Select Test Item" screen.
- Make sure that parking lamps operate normally.

☒ Without CONSULT-II

- Start up auto active test. Refer to [PG-42, "Auto Active Test"](#).
- Make sure that parking lamps operate normally.

OK or NG

- OK >> GO TO 3.
- NG >> Replace IPDM E/R.

ACTIVE TEST	
TAIL LAMP	OFF
ON	
MODE BACK LIGHT COPY	

SKIA2348E

PARKING, LICENSE PLATE AND TAIL LAMPS

3. CHECK BETWEEN IPDM E/R AND BCM

Select IPDM E/R on CONSULT-II. Check lighting switch ("TAIL & CLR REQ") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in 1ST position : TAIL & CLR REQ ON

When lighting switch is in OFF position : TAIL & CLR REQ OFF

OK or NG

- OK >> INSPECTION END
- NG >> Replace BCM.

DATA MONITOR	
MONITOR	
MOTOR FAN REQ	1
AC COMP REQ	OFF
TAIL & CLR REQ	OFF
HL LO REQ	OFF
HL HI REQ	OFF
FR FOG REQ	OFF
FR WIP REQ	STOP
WIP AUTO STOP	ON
WIP PROT	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

SKIA2475E

Parking Lamp Does Not Illuminate (One Side)

1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

- OK >> GO TO 2.
- NG >> Replace parking lamp bulb.

2. CHECK FUSE

Check the following

- 10A fuse (No. 35, located in the IPDM E/R).
- 10A fuse (No. 36, located in the IPDM E/R).

OK or NG

- OK >> GO TO 3.
- NG >> Replace fuse.


3. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect parking lamp connector.
3. Check voltage between parking lamp harness connector terminal 1 and ground.

Terminals			Condition	Voltage [V]
(+)		(-)		
Connector	Terminal (Wire color)			
RH	E37	1 (R)	Lighting switch 1st position	Battery voltage
LH	E22	1 (GY)		

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.




PARKING, LICENSE PLATE AND TAIL LAMPS

4. CHECK BETWEEN IPDM E/R AND PARKING LAMP

1. Disconnect IPDM E/R connector.
2. Check harness continuity between IPDM E/R connector and parking lamp connector.

Terminals					Continuity
IPDM E/R		Parking lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E15	45 (R)	RH	E37	1 (R)	Yes
	49 (GY)	LH	E22	1 (GY)	




OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair or replace harness or connector.

5. CHECK GROUND CIRCUIT

Check continuity between parking lamp harness connector and ground.

Terminals				Continuity
Connector		Terminal (Wire color)		
RH	E37	2 (B)		Yes
LH	E22	2 (B)		



OK or NG

- OK >> Check condition of harness and connector.
 NG >> Repair or replace harness.

Rear Combination Lamp (Tail lamp) Does Not Illuminate (One Side)

EKS00ENG

1. CHECK BULB

Check rear combination lamp (tail lamp) bulb.

OK or NG

- OK >> GO TO 2.
 NG >> Replace rear combination lamp (tail lamp) bulb.

2. CHECK FUSE

Check the following

- 10A fuse (No. 35, located in the IPDM E/R).
- 10A fuse (No. 36, located in the IPDM E/R).

OK or NG


- OK >> GO TO 3.
 NG >> Replace fuse.

PARKING, LICENSE PLATE AND TAIL LAMPS

3. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear combination lamp (tail lamp) connector.
3. Check voltage between rear combination lamp (tail lamp) connector and ground.

Terminals			(-)	Condition	Voltage [V]
(+)					
Connector	Terminal (Wire color)		Ground	Lighting switch 1st position	Battery voltage
RH	B36	3 (PU)			
LH	B37	3 (PU)			




OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. CHECK BETWEEN IPDM E/R AND REAR COMBINATION LAMP (TAIL LAMP)

1. Disconnect IPDM E/R connector.
2. Check harness continuity between IPDM E/R connector and rear combination lamp (tail lamp) connector.

Terminals					Continuity
IPDM E/R		Rear combination lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E13	16 (PU)	RH	B36	3 (PU)	Yes
	15 (GY)	LH	B37	3 (GY)	




OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair or replace harness or connector.

5. CHECK GROUND CIRCUIT

Check continuity between tail lamp and ground.

Terminals			(-)	Continuity
(+)				
Connector	Terminal (Wire color)		Ground	Yes
RH	B36	4 (B)		
LH	B37	4 (B)		



OK or NG

- OK >> Check condition of harness and connector.
 NG >> Repair or replace harness.

PARKING, LICENSE PLATE AND TAIL LAMPS

EKS00ENH

License plate Lamp Does Not Illuminate

1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

OK >> GO TO 2.

NG >> Replace license plate lamp bulb.

2. CHECK FUSE

Check the following

- 10A fuse (No. 35, located in the IPDM E/R).

OK or NG

OK >> GO TO 3.

NG >> Replace fuse.

3. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect license plate lamp connector.
3. Check voltage between license plate lamp connector B38 terminal 2 (L) and ground.

Battery voltage.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.



4. CHECK BETWEEN IPDM E/R AND LICENSE PLATE LAMP


1. Disconnect IPDM E/R connector.
2. Check continuity between license plate lamp connector B38 terminal 2 (L) and IPDM E/R connector E13 terminal 16 (PU).

Continuity should exist.

OK or NG

OK >> Replace IPDM E/R.

NG >> Repair or replace harness or connector.



5. CHECK GROUND CIRCUIT


Check continuity between license plate lamp connector B38 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

OK >> Check condition of harness and connector.

NG >> Repair or replace harness.



PARKING, LICENSE PLATE AND TAIL LAMPS

Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

EKS00ENI

1. CHECK IPDM E/R

- Check whether symptom is caused by IPDM E/R fail-safe operation or by factors other than fail-safe operation. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#) .

OK or NG

Fail-safe operation>>Refer to [PG-48, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#) .

Other than fail-safe operation>>Refer to [PG-51, "Diagnosis of IPDM E/R Integrated Relay"](#)

Bulb Replacement PARKING LAMP

EKS00ENJ

Refer to [LT-41, "Bulb Replacement"](#) .


TAIL LAMP

Refer to [LT-186, "REAR COMBINATION LAMP"](#) .

LICENSE PLATE LAMP

1. Remove license plate lamp. Refer to [LT-180, "LICENSE PLATE LAMP"](#) .
2. Rotate license plate lamp bulb socket counterclockwise to release lock, then remove socket.
3. Remove bulb from license plate lamp bulb socket.

License plate lamp : 12V-10W



A
B
C
D
E
F
G
H
I
J
L
M

LT

PARKING, LICENSE PLATE AND TAIL LAMPS

Removal and Installation of Parking Lamp, Tail Lamp and License Plate Lamp

EKS00ENK

PARKING LAMP

Refer to [LT-41, "Removal and Installation"](#) .


TAIL LAMP

Refer to [LT-186, "REAR COMBINATION LAMP"](#) .

LICENSE PLATE LAMP

Removal

1. Insert a screwdriver or the like wrapped in a cloth into the lens notch and remove license plate lamp from rear bumper.



Installation

Install in the reverse order of removal.


STOP LAMP

PFP:26554

STOP LAMP

Wiring Diagram— STOP/L —


SMA for VIN >SJN**AK12U1309269 EKS00ENL



LT-STOP/L-01

- (L) : LHD MODELS
- (R) : RHD MODELS
- (LA) : LHD MODELS WITH A/T
- (LM) : LHD MODELS WITH M/T
- (RA) : RHD MODELS WITH A/T
- (RM) : RHD MODELS WITH M/T
- (ES) : WITH ESP
- (OE) : WITHOUT ESP

- *1 8D: (L)
- 4: (R)
- *2 9D: (L)
- 8: (R)
- *3 1: (ES)
- 2: (OE)



REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK-JUNCTION BOX (J/B)

MKWA1754E

STOP LAMP

EKS00ENN


Bulb Replacement STOP LAMP

Refer to [LT-186, "REAR COMBINATION LAMP"](#) .

HIGH-MOUNTED STOP LAMP

1. Remove high-mounted stop lamp. Refer to [LT-182, "HIGH-MOUNTED STOP LAMP"](#) .
2. Turn bulb socket left to release lock and remove it.
3. Remove bulb.

High-mounted stop lamp : 12V-21W



EKS00ENN


Removal and Installation STOP LAMP

Refer to [LT-186, "REAR COMBINATION LAMP"](#) .

HIGH-MOUNTED STOP LAMP

Removal

1. Open back door and with both hands pull high-mounted stop lamp cover roof side horizontal edge in direction A to remove it.
2. Push high-mounted stop lamp clip shown in figure in direction B, release top hooks, then push in direction C to release it, then remove it from back door.




Installation

Install in the reverse order of removal.


BACK-UP LAMP

LT-BACK/L-02



- (L) : LHD MODELS
- (R) : RHD MODELS
- (ES) : WITH ESP
- (OE) : WITHOUT ESP

- *1 3 : (ES)
- 6 : (OE)
- *2 12 : (ES)
- 10 : (OE)



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)

BACK-UP LAMP

Bulb Replacement

EKS00ENP

Refer to [LT-186, "REAR COMBINATION LAMP"](#) .

A

Removal and Installation

EKS00ENQ

Refer to [LT-186, "REAR COMBINATION LAMP"](#) .

B

C

D

E

F

G

H

I

J

LT

L

M

REAR COMBINATION LAMP

REAR COMBINATION LAMP


PFP:26554

Bulb Replacement

EKS00ENR

REAR TURN SIGNAL LAMP BULB, BACK-UP LAMP BULB, STOP/TAIL LAMP BULB, REAR FOG LAMP BULB

1. Open the back door, and remove rear combination lamp. Refer to [LT-186, "Removal and Installation"](#) .
2. Release holder assembly bottom hooks and remove from combination lamp housing.
3. Remove all bulbs.




Stop/Tail lamp	: 12V-21/5W
Rear turn signal lamp	: 12V-21W
Back-up lamp	: 12V-21W
Rear fog lamp	: 12V-21W

Removal and Installation

REMOVAL

EKS00ENS

1. Open the back door, and remove rear combination lamp bolts.
2. Pull the rear combination lamp toward rear of the vehicle and remove from the vehicle.
3. Disconnect rear combination lamp connector.



INSTALLATION

Install in the reverse order of removal, paying attention to the following.

Rear combination lamp bolts

Tightening torque : 3.24 - 7.75 N·m (0.33 - 0.79 kg·m, 29 - 69 in·lb)

LIGHTING AND TURN SIGNAL SWITCH

LIGHTING AND TURN SIGNAL SWITCH

PPF:25540

Removal and Installation

EKS00ENT

Refer to [LT-199, "Removal and Installation"](#) .

A

B

C

D

E

F

G

H

I

J

LT

L

M

HAZARD SWITCH

HAZARD SWITCH


PFP:25290

Removal and Installation

EKS00ENU

REMOVAL

1. Remove air conditioner finisher. Refer to [IP-4, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove connector.
3. Press tab on reverse side and pull hazard switch towards you to remove.



INSTALLATION

Install in the reverse order of removal.

COMBINATION SWITCH

PFP:25567

COMBINATION SWITCH

System Description

COMBINATION SWITCH READING FUNCTION


EKS00ENV

1. Description

- BCM reads combination switch (headlamp, wiper washer, turn signal) status, and controls various electrical components according to the results.
- BCM reads information of 20 switches results by combining five output terminals (output 1 - 5) and five input terminals (input 1 - 5).

2. Operation description

- BCM makes current flow through transistors in output terminals (output 1 - 5) at regular intervals in order.
- When any of switches is turned ON, a circuit is established between output terminals (output 1 - 5) and input terminals (input 1 - 5).
- At this time, transistors in output terminals (output 1 - 5) operate, and current flows, and then voltage of input terminals (input 1 - 5) corresponding to switch varies. Interface inside BCM detects status, and judges that the switch is ON.



3. BCM - Operation table of combination switches

COMBINATION SWITCH

- BCM reads operation status of combination switches by the combination shown in the table.


	Combination SW INPUT 1		Combination SW INPUT 2		Combination SW INPUT 3		Combination SW INPUT 4		Combination SW INPUT 5	
	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
Combination SW OUTPUT 1	—	—	FR WIPER HI ON	FR WIPER HI OFF	V/INT 1 ON	V/INT 1 OFF	RR WIPER INT ON	RR WIPER INT OFF	V/INT 2 ON	V/INT 2 OFF
Combination SW OUTPUT 2	FR WASHER ON	FR WASHER OFF	—	—	RR WASHER ON	RR WASHER OFF	V/INT 3 ON	V/INT 3 OFF	RR WIPER ON	RR WIPER OFF
Combination SW OUTPUT 3	FR WIPER LOW ON	FR WIPER LOW OFF	FR WIPER INT ON	FR WIPER INT OFF	—	—	—	—	RR FOG ON	RR FOG OFF
Combination SW OUTPUT 4	TURN LH ON	TURN LH OFF	PASSING ON	PASSING OFF	HEADLAMP 2 ON	HEADLAMP 2 OFF	—	—	FR FOG ON	FR FOG OFF
Combination SW OUTPUT 5	TURN RH ON	TURN RH OFF	HEADLAMP 1 ON	HEADLAMP 1 OFF	HI BEAM ON	HI BEAM OFF	TAIL LAMP ON	TAIL LAMP OFF	—	—

MKIB0370E

NOTE:

Dual switches are set for headlamps.

4. Example (When front fog lamp switch is turned ON)
 1. When front fog lamp switch is turned ON position, FR FOG ON contact inside combination switch becomes ON.
 2. Transistor in output 5 operates, and BCM detects that voltage at input 4 varies.
 3. When BCM detects voltage change at input 4 while transistor in output 5 is in ON status, BCM determines that front fog lamp switch is set to ON, and sends a front fog lamp request signal to IPDM E/R via CAN communication line.
 4. When BCM detects voltage change at input 4 when transistor in output 5 is operated again, it determines that front fog lamp ON operation continues.



MKIB0752E


NOTE:

Each output terminal transistor is activated at 20 ms intervals. Therefore, after a switch is turned ON, the electrical loads are activated with a time delay, but this time delay is too short to be noticed.

5. Operation mode
 - Combination switch reading function has operation modes shown below.
 - a. Normal mode

COMBINATION SWITCH

- When BCM is not in sleep mode, each output (1 - 5) terminal turns ON-OFF at 20 ms intervals.
- b. Sleep mode
- While BCM is in sleep status, transistors in output 1 and 3 stop their input, with BCM entering a power-saving mode. Input 2, 4 and 5 turn ON-OFF every 20 ms, and accept only output from lighting switch system.



A
B
C
D
E
F
G
H
I
J

LT

L
M

COMBINATION SWITCH

EKS00ENW





Wiring Diagram — COMBSW —

LT-COMBSW-01

▬ : DATA LINE

⬅ : LHD MODELS

➡ : RHD MODELS



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)

(M16) -FUSE BLOCK-JUNCTION BOX (J/B)

COMBINATION SWITCH

CONSULT-II Functions (BCM)

EKS00ENX

CONSULT-II can display each diagnosis item using the diagnostic test modes shown following. Data is received and transmitted via the control module communication line.


BCM trouble diagnosis item	Inspection Item, Diagnosis Mode	Description
Combination switch	Data monitor	Displays BCM input data in real time.

CONSULT-II BASIC OPERATION


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and "CONSULT-II CONVERTER" to data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM CAN" on the "SELECT SYSTEM" screen. If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



COMBINATION SWITCH

6. Touch "COMBINATION SWITCH" on "SELECT TEST ITEM" screen.
7. Touch "DATA MONITOR" on the "SELECT DIAG MODE" screen.

SELECT SYSTEM			
HEADLAMP			
WIPER			
FLASHER			
AIR CONDITIONER			
COMB SW			
BCM			
Page up			
	BACK	LIGHT	COPY

MKIB0394E

COMBINATION SWITCH

DATA MONITOR

Operation Procedure

1. Touch "COMBINATION SWITCH" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on the "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
SELECTION FROM MENU	Selects and monitors individual items.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

Display Item List

Monitor item "UNIT"	Display content
TURN SIGNAL R [ON/OFF]	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L [ON/OFF]	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
HI BEAM SW [ON/OFF]	Displays status (High beam switch: ON/Others: OFF) as judged from lighting switch signal.
H/L SW POS [ON/OFF]	Displays status (Headlamp switch 1: ON/Others: OFF) as judged from lighting switch signal.
LIGHT SW 1ST [ON/OFF]	Displays status (Lighting switch 1st position: ON/Others: OFF) as judged from lighting switch signal.
PASSING SW [ON/OFF]	Displays status (Flash-to-pass switch: ON/Others: OFF) as judged from lighting switch signal.
FR FOG SW [ON/OFF]	Displays status (Front fog lamp switch: ON/Others: OFF) as judged from lighting switch signal. (ON is also displayed when rear fog lamp switch is on.)
RR FOG SW [ON/OFF]	Displays status (Rear fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
FR WIPER HI [ON/OFF]	Displays status (Front Wiper HI: ON/Others: OFF) as judged from wiper switch signal.
FR WIPER LOW [ON/OFF]	Displays status (Front Wiper LOW: ON/Others: OFF) as judged from wiper switch signal.
FR WIPER INT [ON/OFF]	Displays status (Front Wiper INT: ON/Others: OFF) as judged from wiper switch signal.
FR WASHER SW [ON/OFF]	Displays status (Front Washer Switch: ON/Others: OFF) as judged from wiper switch signal.
INT VOLUME [1 - 7]	Displays intermittent operation dial position setting (1 - 7) as judged from wiper switch signal.
RR WIPER ON [ON/OFF]	Displays status (Rear Wiper ON: ON/Others: OFF) as judged from wiper switch signal.
RR WIPER INT [ON/OFF]	Displays status (Rear Wiper INT: ON/Others: OFF) as judged from wiper switch signal.
RR WASHER SW [ON/OFF]	Displays status (Rear Washer Switch: ON/Others: OFF) as judged from wiper switch signal.

COMBINATION SWITCH


EKS00ENY

Check Combination Switch

1. CHECK COMBINATION SWITCH OPERATION

1. Check the malfunctioning operation which is controlled by combination switch, and check the group which including the malfunctioning operation.

Group 5	Group 4	Group 3	Group 2	Group 1
—	FR WASHER	FR WIPER LO	TURN LH	TURN RH
FR WIPER HI	—	FR WIPER INT	PASSING	HEAD LAMP1
V/INT 1	RR WASHER	—	HEAD LAMP2	HI BEAM
RR WIPER INT	V/INT 3	—	—	TAIL LAMP
V/INT 2	RR WIPER ON	RR FOG	FR FOG	—



>> Confirm the group where malfunctioning operation is in and GO TO 2.

2. CHECK SYSTEM

With CONSULT-II

1. Select BCM on CONSULT-II. Check combination switch ("COMB SW") in "DATA MONITOR" mode with CONSULT-II.
2. Select "START" and confirm all switch except the malfunctioning switch are operating normally. (Refer to [LT-195, "Display Item List"](#))

Example: When there is RR fog lamp switch malfunction, confirm that "FR WIPER LOW" and "FR WIPER INT", which are in the same group 3, turn ON/OFF normally.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HI BEAM SW	ON
H/L SW POS	ON
LIGHT SW 1ST	OFF
AUTO LIGHT SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF
VEHICLE SPEED	0 km/h
Page Down	
RECORD	
MODE	BACK LIGHT COPY

Without CONSULT-II

Operate combination switch to Make sure other switches in the system with an error operate normally.

Example: When there is an error with RR fog lamp switch, make sure front wiper low operation and front wiper intermittent operation in the same group 3 operate normally.

What is the inspection results?

Other switches in the group with an error operate normally.>>Replace combination switch.

Other switches in the group with an error do not operate normally.>>GO TO 3.

COMBINATION SWITCH

3. CHECK HARNESS


1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM harness connector of the inoperative system and the corresponding combination switch connector terminals.
4. Check continuity between BCM harness connector of the suspect system and ground.

Group	Connector terminal		Continuity	
	BCM	Combination switch		
1	output 1	13 (GY)	6 (GY)	Yes
	input 1	9 (PU)	1 (PU)	
2	output 2	33 (R)	7 (R)	
	input 2	28 (G)	2 (G)	
3	output 3	14 (P)	10 (P)	
	input 3	8 (L)	3 (L)	
4	output 4	34 (Y)	9 (Y)	
	input 4	27 (GY)	4 (GY)	
5	output 5	15 (W)	8 (W)	
	input 5	7 (BR)	5 (BR)	

Group	Connector terminal		Continuity	
	BCM	—		
1	output 1	13 (GY)	Ground	No
	input 1	9 (PU)		
2	output 2	33 (R)		
	input 2	28 (G)		
3	output 3	14 (P)		
	input 3	8 (L)		
4	output 4	34 (Y)		
	input 4	27 (GY)		
5	output 5	15 (W)		
	input 5	7 (BR)		

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness connector.



A
B
C
D
E
F
G
H
I
J
L
M

LT

COMBINATION SWITCH

4. CHECK BCM OUTPUT SIGNAL


Connect BCM and combination switch connector, and check voltage waveform of malfunctioning system.

Group	Connector	terminal (wire color)	
		(+)	(-)
1	M32	1 (PU)	Ground
2		2 (G)	
3		3 (L)	
4		4 (GY)	
5		5 (BR)	

OK or NG

OK >> Repair combination switch.

NG >> Replace BCM.



MKIB0754E

COMBINATION SWITCH

EKS00ENZ

Removal and Installation

REMOVAL

1. Remove steering column cover. Refer to [PS-7, "STEERING COLUMN"](#) .
2. Remove driver air bag module. Refer to [SRS-36, "DRIVER AIR BAG MODULE"](#) .
3. Remove spiral cable. Refer to [SRS-38, "SPIRAL CABLE"](#) .
4. Remove screw and remove combination switch.

INSTALLATION

Install in the reverse order of removal, for details.

A

B

C

D

E

F

G

H

I

J

LT

L

M

INTERIOR ROOM LAMP

INTERIOR ROOM LAMP

PFP:26410

System Description POWER SUPPLY AND GROUND

EKS00E00

Power is supplied at all times:

- through 40A fusible link (letter J , located in the fuse and fusible link box)
- to BCM terminals 74 and 79.
- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to luggage room lamp terminal 1
- to BCM terminal 72
- to key switch terminal 1 (without Intelligent Key system) or
- to key switch and ignition knob switch terminal 3 (Gasoline engine with Intelligent Key system)
- through 10A fuse [No. 17, located in the fuse block (J/B)]
- to key switch and ignition knob switch terminals 1 (Diesel engine models with Intelligent Key system)

When the key is removed from ignition key cylinder, power is interrupted:

- through key switch terminal 2 (without Intelligent Key system) or
- through key switch and ignition knob switch terminal 4 (Gasoline engine models with Intelligent Key system) or
- through key switch and ignition knob switch terminal 2 (Diesel engine models with Intelligent Key system)
- to BCM terminal 48.

When Intelligent Key unit receives unlock signal from Intelligent Key controller. BCM receives door lock/unlock signal from Intelligent Key unit via CAN communication line.

With the ignition key switch in the ON or START position, power is supplied:

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM terminal 24.

Ground is supplied:

- through body grounds M19 and M20
- to BCM terminals 2 and 70.

When any door is opened, ground is supplied:

- through case ground of front door switch (driver side)
- to front door switch (driver side) terminal 1
- to BCM terminal 29.
- through case ground of front door switch (passenger side)
- to front door switch (passenger side) terminal 1
- to BCM terminal 30.
- through case ground of rear door switch LH
- to rear door switch LH terminal 1
- to BCM terminal 59.
- through case ground of rear door switch RH
- to rear door switch RH terminal 1
- to BCM terminal 60.
- through body grounds B17, B23, B44 and B51
- to back door switch terminal 2
- to back door switch terminal 1
- to BCM terminal 10.

When a signal, or combination of signal is received by the BCM ground is supplied:

- through BCM terminal 21
- to interior room lamp terminal 1

With power and ground are supplied, the interior room lamp illuminates.

INTERIOR ROOM LAMP

SWITCH OPERATION

Ground is supplied:

- through body grounds M19 and M20
- to interior room lamp terminal 3,

When interior room lamp switch is ON, power is supplied:

- to interior room lamp terminal 2
- through BCM terminal 73.

With power and ground are supplied, the interior room lamp illuminates.

When back door is opened, ground supplied:

- to luggage room lamp terminal 2
- through back door release actuator (back door switch) terminal 2 and 1
- through body grounds B17,B23,B44 and B51.

With power and ground are supplied, the luggage room lamp illuminates.

INTERIOR ROOM LAMP TIMER OPERATION

When interior room lamp switch is in the "DOOR" position, the BCM keeps the interior room lamp illuminated for about 30 seconds when:

- unlock signal is received from Intelligent Key controller, while all doors are closed and key is out of the ignition key cylinder (with Intelligent Key system).
- unlock signal is received from remote controller while all doors are closed and key is out of the ignition key cylinder (without Intelligent Key system).
- key is removed from ignition key cylinder while all doors are closed (without Intelligent Key system)
- any door is opened and then closed while key is out of the ignition key cylinder.

The timer is canceled when:

- ignition switch is turned ON.
- lock signal is received from Intelligent Key controller, while all doors are closed and key is out of the ignition key cylinder (with Intelligent Key system).
- lock signal is received from remote controller while all doors are closed and key is out of the ignition key cylinder (without Intelligent Key system).

ON-OFF CONTROL

When the driver side door, front passenger door, rear LH or RH door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position.

A

B

C

D

E

F

G

H

I

J

LT

L

M

INTERIOR ROOM LAMP

CAN Communication SYSTEM DESCRIPTION

EKS00ERO

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LTD

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door																			
Axle	2WD																			
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K									
Handle	LHD/RHD																			
Brake control	ABS system					ESP system					ABS									
Transmission	A/T		M/T			A/T		M/T			M/T									
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable
CAN communication unit																				
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×			×	×			×	×			×	×			×	×		
Drive computer	×		×		×		×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×					×	×	×	×								
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	<u>LT-203, "TYPE 1/TYPE 2"</u>				<u>LT-206, "TYPE 3/TYPE 4"</u>				<u>LT-208, "TYPE 5/TYPE 6"</u>				<u>LT-211, "TYPE 7/TYPE 8"</u>				<u>LT-213, "TYPE 9/TYPE 10"</u>			


×: Applicable

INTERIOR ROOM LAMP


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

INTERIOR ROOM LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

INTERIOR ROOM LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

I

J

LT

L


M

INTERIOR ROOM LAMP


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

INTERIOR ROOM LAMP


Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A
B
C
D
E
F
G
H
I
J
LT
L
M


INTERIOR ROOM LAMP

TYPE 5/TYPE 6 System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

INTERIOR ROOM LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

A
B
C
D
E
F
G
H
I
J
LT
L
M


INTERIOR ROOM LAMP

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


INTERIOR ROOM LAMP

TYPE 7/TYPE 8 System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

INTERIOR ROOM LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


INTERIOR ROOM LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 LT
 L
 M

INTERIOR ROOM LAMP

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

INTERIOR ROOM LAMP

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
B
C
D
E
F
G
H
I
J
L
M

LT

INTERIOR ROOM LAMP

Schematic





EKS00E02



MKWA1533E

INTERIOR ROOM LAMP

LT-INT/L-02






INTERIOR ROOM LAMP

LT-INT/L-03

⬡ : LHD MODELS
⬢ : RHD MODELS

A
B
C
D
E
F
G
H
I
J
LT
L
M



MKWA1534E

INTERIOR ROOM LAMP

Terminals and Reference Value for BCM

EKS00E04

Terminal No.	Wire color	Signal designation	Measuring condition				Reference value (V)	
			Ignition switch	Operation or condition				
2	B	Ground	ON	—			Approx. 0	
10	OR	Back door switch signal	OFF	Back door switch signal	ON (open)		Approx. 0	
					OFF (close)		Approx. 12	
21	Y	Logical lighting control	OFF	Room lamp switch: DOOR position	Key is inserted	Any door switch	ON (Open)	Approx. 0
							OFF (Close)	Approx. 12
					Close all doors	Key is removed from key cylinder		Approx. 0
						Turn ignition switch ON		Approx. 12
					Key is removed			Approx. 0
					Interior room lamp timer	OFF	Approx. 12	
ON	Approx. 0							
24	OR	Ignition power supply	ON	—			Approx. 12	
29	L	Driver door switch signal	OFF	Driver door switch signal	ON (open)		Approx. 0	
					OFF (closed)		Approx. 12	
30	LG	Passenger door switch signal	OFF	Passenger door switch signal	ON (open)		Approx. 0	
					OFF (close)		Approx. 12	
48	P*1	Key detection switch signal	OFF	Remove key.			Approx. 0	
	OR*2			Key is inserted.			Approx. 12	
59	L	Rear door switch LH signal	OFF	Rear door switch LH signal	ON (open)		Approx. 0	
					OFF (close)		Approx. 12	
60	G	Rear door switch RH signal	OFF	Rear door switch RH signal	ON (open)		Approx. 0	
					OFF (close)		Approx. 12	
70	B	Ground	ON	—			Approx. 0	
73	PU	Room lamp signal	OFF	Room lamp switch: DOOR position	Key is inserted.	Any door switch	ON (open)	Approx. 0
							OFF (closed)	Approx. 12
			—	Close all doors.	Key is removed after being fully inserted.		Approx. 0	
Turn ignition switch ON.			Approx. 12					
74	W	Battery power supply	OFF	—			Approx. 12	
79	Y	Battery power supply	OFF	—			Approx. 12	

*1: With Intelligent Key system

*2: Without Intelligent Key system

How to Proceed With Trouble Diagnosis

EKS00E05

1. Confirm the symptom or customer complaints.
2. Understand operation description and function description.
Refer to Interior room lamp [LT-200, "System Description"](#).
3. Carry out the Preliminary Check. Refer to [LT-221, "Preliminary Check"](#)
4. Check symptom and repair or replace the cause of malfunction.
5. Does the interior room lamp operate normally? Yes: GO TO 6. No: GO TO 4.
6. INSPECTION END.

INTERIOR ROOM LAMP

EKS00E06

Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

Check BCM fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch ON or START position	4

Refer to [LT-217, "Wiring Diagram — INT/L —"](#) .

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)			OFF	ACC	ON
Connector	Terminal (Wire color)	Ground	Battery voltage	Battery voltage	Battery voltage
M50	74 (W)		Battery voltage	Battery voltage	Battery voltage
	79 (Y)		Battery voltage	Battery voltage	Battery voltage
M48	24 (OR)	0V	0V	Battery voltage	



OK or NG

OK >> GO TO 3.

NG >> Repair harness for open or short between BCM and fuse. If NG, repair and replace the harness or fuse.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminals			Continuity
Connector	Terminal (Wire color)		
M48	2 (B)	Ground	Yes
M50	70 (B)		

OK or NG

OK >> INSPECTION END

NG >> Repair or replace the harness.



INTERIOR ROOM LAMP

CONSULT-II Functions (BCM)

EKS00E07

CONSULT-II can display each diagnosis item using the diagnostic test modes shown following. Data is received and transmitted via the control module communication line.


BCM trouble diagnosis item	Inspection Item, Diagnosis Mode	Description
Room lamp	Data monitor	Displays BCM input data in real time.
	Active test	BCM can send a drive signal to electrical components to their operation.

CONSULT-II BASIC OPERATION


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and "CONSULT-II CONVERTER" to data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "BCM" on the "SELECT SYSTEM" screen.
If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




INTERIOR ROOM LAMP

6. Touch "INT LAMP" on "SELECT TEST ITEM" screen.



7. Touch "DATA MONITOR", or "ACTIVE TEST" on the "SELECT DIAG MODE" screen.



DATA MONITOR

Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on the "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
SELECTION FROM MENU	Selects and monitors individual items.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

Display Item List

Monitor item "UNIT"	Display content
IGN ON SW [ON/OFF]	Displays status (Ignition switch ON: ON/Others OFF, ACC: OFF) as judged from the ignition switch signal.
PUSH SW (*1) [ON/OFF]	Displays status (Ignition knob is pushed: ON/ released: OFF) as judged from the ignition knob switch signal.
KEY IN SW (*2) [ON/OFF]	Displays status (Key inserted: ON/Key removed: OFF) as judged from the key switch signal.
DOOR SW-DR [ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the front door switch RH signal.
DOOR SW-AS [ON/OFF]	Displays status (Door open: ON/Door closed: OFF) as judged from the front door switch LH signal.
DOOR SW-RR [ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the rear door switch RH signal.
DOOR SW-RL [ON/OFF]	Displays status (Door open: ON/Door closed: OFF) as judged from the rear door switch LH signal.

INTERIOR ROOM LAMP

Monitor item "UNIT"	Display content
BACK DOOR SW [ON/OFF]	Displays status (Door open: ON/Door closed: OFF) as judged from the back door switch signal.
CDL LOCK SW [ON/OFF]	Displays status (Locked: ON/Others: OFF) as judged from lock signal.
CDL UNLOCK SW [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal.
KEYLESS LOCK (*2) [ON/OFF]	Displays status (Locked: ON/Others: OFF) as judged from lock signal. (Locked by Multi-Remote control system)
KEYLESS UNLOCK(*2) [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal. (Unlocked by Multi-Remote control system)
I-KEY LOCK (*1) [ON/OFF]	Displays status (Locked: ON/Others: OFF) as judged from lock signal. (Locked by Intelligent Key system)
I-KEY UNLOCK (*1) [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal. (Unlocked by Intelligent Key system)
I-KEY ALL UNL (*1) [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal. (Unlocked by Intelligent Key system)

*1: Displayed for models with Intelligent Key system.

*2: Displayed for models without Intelligent Key system.

ACTIVE TEST

Test Item	Description
INT LAMP	This test is able to check interior lamp operation. The interior lamp turned ON when "ON" on CONSULT-II display is touched.

INTERIOR ROOM LAMP

EKS00E08


Room Lamp Does Not Operate

1. CHECK SWITCH SIGNAL

SMA for VIN >SJM**AK12U1149635

Select BCM on CONSULT-II. Check following item in "DATA MONITOR" mode with CONSULT-II.

Monitor item	Condition	
IGN ON SW	Ignition switch is in ON position	ON
	Ignition switch is in other position	OFF
PUSH SW	Ignition knob is pushed	ON
	Ignition knob is released	OFF
KEY IN SW	Key is inserted	ON
	Key is removed	OFF
DOOR SW-DR	Front RH door is opened	ON
	Front RH door is closed	OFF
DOOR SW-AS	Front LH door is opened	ON
	Front LH door is closed	OFF
DOOR SW-RR	Rear RH door is opened	ON
	Rear RH door is closed	OFF
DOOR SW-RL	Rear LH door is opened	ON
	Rear LH door is closed	OFF
BACK DOOR SW	Back door is opened	ON
	Back door is closed	OFF
CDL LOCK SW	Lock/unlock switch lock position	ON
	Lock/unlock switch unlock position	OFF
CDL UNLOCK SW	Lock/unlock switch unlock position	ON
	Lock/unlock switch lock position	OFF
KEYLESS LOCK (*2)	Keyless lock/unlock switch lock position	ON
	Keyless lock/unlock switch unlock position	OFF
KEYLESS UNLOCK (*2)	Keyless lock/unlock switch unlock position	ON
	Keyless lock/unlock switch lock position	OFF
I-KEY LOCK (*1)	Intelligent Key lock/unlock switch lock position	ON
	Intelligent Key lock/unlock switch unlock position	OFF
I-KET UNLOCK (*1)	Intelligent Key lock/unlock switch unlock position	ON
	Intelligent Key lock/unlock switch lock position	OFF
I-KEY ALL UNL (*1)	Intelligent Key all door unlock switch unlock position	ON
	Intelligent Key all door unlock switch lock position	OFF



*1: Display for models with Intelligent Key system

*2: Displayed for models without Intelligent Key system

OK or NG

OK >> GO TO 2.

NG >> ● IGN ON SW: Refer to [DI-110, "Ignition ON Signal Check"](#) .

- PUSH SW (with Intelligent Key system): Refer to [DI-107, "Key Switch Signal Check/With Intelligent Key System"](#)
- KEY IN SW (without Intelligent Key system): Refer to [DI-105, "Key Switch Signal Check/Without Intelligent Key System"](#)
- DOOR SW-DR: Refer to [BL-58, "DRIVER SIDE"](#)
- DOOR SW-AS: Refer to [BL-60, "PASSENGER SIDE"](#)


INTERIOR ROOM LAMP

- DOOR SW-RR: Refer to [BL-64, "REAR RH SIDE"](#)
- DOOR SW-RL: Refer to [BL-62, "REAR LH SIDE"](#)
- BACK DOOR SW: Refer to [BL-66, "Check External Back Door Release Switch"](#)
- CDL LOCK/UNLOCK SW: Refer to [BL-50, "Check Door Lock / Unlock Switch"](#)
- KEYLESS LOCK/UNLOCK: Refer to [BL-143, "Remote controller Check"](#)
- I-KEY LOCK/UNLOCK: Refer to [BL-194, "Check Door Request Switch"](#)
- I-KEY ALL UNL: Refer to [BL-194, "Check Door Request Switch"](#)

2. CHECK BCM OUTPUT SIGNAL

1. Interior room lamp switch is in DOOR position.
2. Check voltage between BCM and ground.

Terminal (+)		Terminal (-)	Condition				Voltage (V)
Con-connector	Terminal (Wire color)		Ignition switch	Key is inserted	Any door switch	ON (open) OFF (closed)	
M50	73 (PU)	Ground	OFF	Key is inserted	Any door switch	ON (open)	Approx. 0
						OFF (closed)	Approx. 12
			—	Close all doors.	Key is removed after being fully inserted.	—	Approx. 0
						Turn ignition switch ON.	Approx. 12



OK or NG

- OK >> GO TO 3.
 NG >> Replace BCM.

3. CHECK INTERIOR ROOM LAMP INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and room lamp connector.
3. Check continuity between BCM harness connector M50 terminal 73(PU) and interior room lamp harness connector R2 terminal 2(PU).


Continuity should exist.

4. Check continuity between BCM connector M50 terminal 73 (PU) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness or connector.



INTERIOR ROOM LAMP

4. CHECK INTERIOR ROOM LAMP GROUND CIRCUIT

1. Check continuity between BCM connector M48 terminal 21(Y) and interior room lamp connector R2 terminal 1 (Y).

Continuity should exist.


2. Check continuity between BCM connector M48 terminal 21 (Y) and ground.

Continuity should not exist.

OK or NG


OK >> GO TO 5.

NG >> Repair or replace harness or connector.



5. CHECK BCM OUTPUT SIGNAL

1. Interior room lamp switch is in DOOR position.
2. Connect BCM connector
3. Check voltage between BCM connector terminal and ground.



Terminal No.	Wire color	Signal designation	Measuring condition				Reference value (V)	
			Ignition switch	Operation or condition				
21	Y	Logical lighting control	OFF	Room lamp switch: DOOR position	Key is inserted	Any door switch	ON (Open)	Approx. 0
							OFF (Close)	Approx. 12
					Close all doors	Key is removed from key cylinder		Approx. 0
						Turn ignition switch ON		Approx. 12
					Key is removed			
Interior room lamp timer			OFF	Approx. 12				
			ON	Approx. 0				

OK or NG

OK >> Check condition of the harness and connector.

NG >> Replace BCM.

Luggage Room Lamp Does Not Illuminate

EKS00E09

1. CHECK BULB

Check luggage room lamp bulb.

OK or NG

OK >> GO TO 2.

NG >> Replace luggage room lamp bulb.

INTERIOR ROOM LAMP


2. CHECK LUGGAGE ROOM LAMP INPUT SIGNAL

Check voltage between luggage room lamp harness connector B40 terminal 1(Y) and ground.

Battery voltage should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Check harness for open or short between luggage room lamp and fuse. If NG, repair or replace the harness or fuse.



3. CHECK BACK DOOR SWITCH CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect back door release actuator connector and luggage room lamp connector.
3. Check continuity between back door release actuator harness connector B55 terminal 1(OR) and luggage room lamp harness connector B41 terminal 2(L).

Continuity should exist.

4. Check continuity between

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace the harness.




4. CHECK BACK DOOR SWITCH GROUND CIRCUIT

Check continuity between back door release actuator harness connector B55 terminal 2(B) and ground.

Continuity should exist.

OK or NG

- OK >> GO TO 5.
- NG >> Repair or harness connector.




5. CHECK BACK DOOR SWITCH

Check continuity back door switch terminals.

Terminals		Condition	Continuity
1	2	Back door : OPEN	Yes
		Back door : CLOSED	No

OK or NG

- OK >> Check condition of the harness and connector.
- NG >> Replace the back door release actuator.



INTERIOR ROOM LAMP


Bulb Replacement

SMA for VIN >SJN**AK12U1149635

EKS00EOA

1. Remove interior room lamp. Refer to [LT-229, "Removal and Installation"](#).
2. Remove bulb.


Interior room lamp : 12V - 10W



Removal and Installation

REMOVAL

1. Without damaging the headliner, insert a clip driver in the interior room lamp back edge to disengage metal clips.
2. Disconnect connector and remove interior room lamp.



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
LT
L
M

ILLUMINATION

PFP:27545

System Description

SMA for VIN >SJN**AK12U1309269

EKS00EOC

The illumination lamps operation is controlled by the lighting switch which built into the combination switch, BCM and IPDM E/R. Tail lamp relay is built into IPDM E/R. BCM read combination switch condition. Refer to [LT-189, "System Description"](#)

Power is supplied at all times

- to tail lamp relay (located in the IPDM E/R).

Power is also supplied at all times

- to BCM terminals 74 and 79
- through 40A fusible link (letter J , located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- to BCM terminal 24
- through 10A fuse [No. 4, located in the fuse block (J/B)].
- to power window main switch terminal 5
- to front power window switch (passenger side) terminal 1
- through BCM terminal 78

Ground is supplied

- to BCM terminals 2 and 70
- through grounds M19, and M20.

ILLUMINATION OPERATION BY LIGHTING SWITCH

When the lighting switch is turned to 1ST position, BCM read combination switch condition (refer to [LT-189, "System Description"](#)). And BCM send illumination lamp request signal to IPDM E/R via CAN communication line. Then IPDM E/R is turned on tail lamp relay. Tail lamp relay is energized and then power is supplied:

- through terminal 15 of the IPDM E/R
- to heated seat switch driver side (illumination) terminal 5
- to heated seat switch passenger side (illumination) terminal 5
- to door lock/unlock switch terminal 2
- through terminal 16 of the IPDM E/R
- to audio unit terminal 36
- to audio and navi control unit terminal 36
- to heater control panel terminal 15
- to A/C auto amplifier terminal 11
- to headlamp aiming switch terminal 3
- to headlamp washer switch terminal 3
- to hazard switch terminal 3
- to ashtray illumination terminal 1 and
- to A/T device terminal 5
- to ESP OFF switch terminal 3

Ground is supplied at all times

- to door lock/unlock switch terminal 4
- to heated seat switch driver side terminal 6
- to heated seat switch passenger side terminal 6
- through body grounds B17, B23, B44 and B51
- to heater control panel terminal 7
- to A/C auto amplifier terminal 12
- to headlamp aiming switch terminal 4
- to headlamp washer switch terminal 4
- to hazard switch terminal 4
- to ashtray illumination terminal 2

ILLUMINATION

- to A/T device terminal 4
- to power window main switch terminal 7
- to front power window switch (passenger side) terminal 7
- to ESP OFF switch terminal 4
- through body grounds M19 and M20
- to audio unit terminal 36
- to audio and navi control unit terminal 36
- through body ground M60

With power and ground supplied, illumination lamps illuminate.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-189, "System Description"](#)

A

B

C

D

E

F

G

H

I

J

LT

L

M

ILLUMINATION

EKS00ERG

CAN Communication SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LTE

Go to CAN system, when selecting your car model from the following table.


Body type	3door/5door																			
Axle	2WD																			
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE					K9K									
Handle	LHD/RHD																			
Brake control	ABS system					ESP system					ABS									
Transmission	A/T		M/T		A/T		M/T		M/T											
Intelligent Key system	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable	Appli- cable	Not appli- cable
CAN communication unit																				
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×			×	×			×	×			×	×			×	×		
Drive computer	×		×		×		×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×					×	×	×	×								
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	<u>LT-233, "TYPE 1/ TYPE 2"</u>				<u>LT-236, "TYPE 3/ TYPE 4"</u>				<u>LT-238, "TYPE 5/ TYPE 6"</u>				<u>LT-241, "TYPE 7/ TYPE 8"</u>				<u>LT-243, "TYPE 9/ TYPE 10"</u>			

×: Applicable


ILLUMINATION

TYPE 1/TYPE 2 System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

ILLUMINATION

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

ILLUMINATION

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


A
B
C
D
E
F
G
H
I
J
LT
L
M

LT


ILLUMINATION

TYPE 3/TYPE 4 System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

ILLUMINATION

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
B
C
D
E
F
G
H
I
J
L
M

LT


ILLUMINATION

TYPE 5/TYPE 6 System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

ILLUMINATION

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R	
A/T shift position signal		R						T		A
A/T shift schedule change demand signal							T	R		B
Stop lamp switch signal		T						R		C
O/D OFF indicator lamp signal		R						T		D
Engine and A/T integrated control signal	T							R		E
	R							T		
Fuel consumption monitor signal	T	R								
Oil pressure switch signal		R		R					T	
A/C compressor request signal	T								R	F
A/C switch signal	R								T	
Heater fan switch signal	R					T				G
Cooling fan speed request signal	T								R	
Cooling fan speed status signal	R								T	
Position lights request signal		R		R		T			R	H
Position light status signal	R								T	
Low beam request signal						T			R	I
Low beam status signal	R								T	
High beam request signal		R				T			R	J
High beam status signal	R								T	
Day time light request signal						T			R	
Vehicle speed signal	R	R			R		T			LT
	R	T	R	R	R	R				
Sleep/wake up signal		R	R			T			R	
Door switch signal		R	R	R		T			R	L
Turn indicator signal		R				T				
Buzzer output signal		R				T				M
		R	T							
MI signal	T	R		R						
Front wiper request signal						T			R	
Front wiper stop position signal						R			T	
Rear window defogger switch signal						T			R	
Rear window defogger control signal	R								T	
Drive computer signal		T		R						
EPS warning lamp signal		R		R	T					
ABS warning lamp signal		R		R			T			
ESP warning lamp signal		R		R			T			
ESP OFF indicator signal		R					T			
SLIP indicator lamp signal		R					T			


ILLUMINATION

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						


ILLUMINATION

TYPE 7/TYPE 8 System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

ILLUMINATION

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


ILLUMINATION

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



A
B
C
D
E
F
G
H
I
J
LT
L
M

ILLUMINATION

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn- ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

ILLUMINATION

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A
B
C
D
E
F
G
H
I
J
LT
L
M


LT

ILLUMINATION

Schematic

SMA for VIN >SJN**AK12U1309269

EKS00EOE



MKW1756E

ILLUMINATION


Wiring Diagram — ILL —

SMA for VIN >SJN**AK12U1309269

EKS00E0F


LT-ILL-01

▬ : DATA LINE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M22) W



REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK-JUNCTION BOX (J/B)



1	1	1	1	2	2	2	2	2	2
3	3	3	3	4	4	4	4	4	4

(M81) L


1	1	1	1	1	1	1	1	1	1
2	2	2	2	2	2	2	2	3	3

(M82) L


A
B
C
D
E
F
G
H
I
J
LT
L
M

ILLUMINATION

LT-ILL-02




- (L) : LHD MODELS
- (R) : RHD MODELS
- (ES) : WITH ESP
- (OE) : WITHOUT ESP
- *1 4: (ES)
- 3: (OE)
- *2 10: (ES)
- 8: (OE)





ILLUMINATION

LT-ILL-03







A
B
C
D
E
F
G
H
I
J
LT
L
M



MKWA1748E

ILLUMINATION

LT-ILL-04




REFER TO THE FOLLOWING.


(M1) -SUPER MULTIPLE JUNCTION (SMJ)

ILLUMINATION

LT-ILL-05










A
B
C
D
E
F
G
H
I
J
LT
L
M




ILLUMINATION

LT-ILL-06



ILLUMINATION

LT-ILL-07



A
B
C
D
E
F
G
H
I
J
LT
L
M

MKWA1760E

ILLUMINATION

Removal and Installation GLOVE BOX LAMP

EKS00EOG

Refer to [IP-4, "INSTRUMENT PANEL ASSEMBLY"](#) .

BULB SPECIFICATIONS

BULB SPECIFICATIONS

SMA for VIN >SJN**AK12U1149635 PFP:26297

Headlamp

EKS00EOH

Item		Wattage (W)
High/Low	Halogen	60/55 (H4)

Exterior Lamp

EKS00EOI

Item		Wattage (W)
Clearance lamp		5
Front turn signal lamp		21 (amber)
Side turn signal lamp		5
Front fog lamp		55 (H11)
Rear combination lamp	Rear fog lamp	21
	Stop/Tail lamp	21/5
	Turn signal lamp	21
	Back-up lamp	21
License plate lamp		10
High-mounted stop lamp		21

Interior Lamp/Illumination

EKS00EOJ

Item	Wattage (W)
Interior room lamp	10
Luggage room lamp	10

A

B

C

D

E

F

G

H

I

J

LT

L

M

BULB SPECIFICATIONS
