

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

PRECAUTIONS	3	Configuration	36
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	DESCRIPTION	36
Maintenance Information	3	READ CONFIGURATION PROCEDURE	36
RHD MODELS	3	WRITE CONFIGURATION PROCEDURE	38
LHD MODELS	3		
POWER SUPPLY ROUTING	4	Auto Active Test	42
Schematic	4	DESCRIPTION	42
Wiring Diagram — POWER —	5	OPERATION PROCEDURE	42
BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION	5	INSPECTION IN AUTO ACTIVE TEST MODE	43
ACCESSIONARY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"	11	CONCEPT OF AUTO ACTIVE TEST	44
IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"	12	Schematic	46
Fuse	17	IPDM E/R Terminal Arrangement	47
Fusible Link	17	Inspection With CONSULT-II (Self-Diagnosis)	48
Circuit Breaker	17	IPDM E/R Terminal Inspection	49
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	18	IPDM E/R Power Supply and Ground Circuit Check..	49
System Description	18	Diagnosis of IPDM E/R Integrated Relay	51
SYSTEMS CONTROLLED BY IPDM E/R	18	Removal and Installation of IPDM E/R	52
FAIL-SAFE FUNCTION	19	REMOVAL	52
IPDM E/R STATUS CONTROL	19	INSTALLATION	53
FUNCTION OF IPDM E/R	19	GROUND	54
CAN Communication	20	Ground Distribution	54
SYSTEM DESCRIPTION	20	MAIN HARNESS	54
CAN Communication Unit	20	ENGINE ROOM HARNESS	58
TYPE 1/TYPE 2	21	ENGINE CONTROL HARNESS/CR ENGINE MODELS	61
TYPE 3/TYPE 4	24	ENGINE CONTROL HARNESS/K9K ENGINE MODELS	62
TYPE 5/TYPE 6	26	BODY HARNESS	63
TYPE 7/TYPE 8	29	HARNESS	67
TYPE 9/TYPE 10	31	Harness Layout	67
Function of Detecting Ignition Relay Malfunction ..	33	HOW TO READ HARNESS LAYOUTS	67
CONSULT-II Function (IPDM E/R)	33	OUTLINE/CR ENGINE MODELS	68
CONSULT-II BASIC OPERATION	33	OUTLINE/K9K ENGINE MODELS	69
SELF-DIAG RESULTS	34	MAIN HARNESS/LHD MODELS	70
DATA MONITOR	35	MAIN HARNESS/RHD MODELS	72
ACTIVE TEST	36	ENGINE ROOM HARNESS/CR ENGINE MODELS	74
		ENGINE ROOM HARNESS/K9K ENGINE MODELS	76
		ENGINE CONTROL HARNESS/CR ENGINE MODELS	78

ENGINE CONTROL HARNESS/K9K ENGINE MODELS	80	HARNESS CONNECTOR	99
BODY HARNESS	82	Description	99
ROOM LAMP HARNESS	85	HARNESS CONNECTOR (TAB-LOCKING TYPE)	99
FRONT DOOR HARNESS LH SIDE/LHD MOD- ELS	86	HARNESS CONNECTOR (SLIDE-LOCKING TYPE)	100
FRONT DOOR HARNESS LH SIDE/RHD MOD- ELS	87	JOINT CONNECTOR (J/C)	101
FRONT DOOR HARNESS RH SIDE/LHD MOD- ELS	88	Terminal Arrangement	101
FRONT DOOR HARNESS RH SIDE/RHD MOD- ELS	89	ELECTRICAL UNITS	102
REAR DOOR HARNESS LH	90	Terminal Arrangement	102
REAR DOOR HARNESS RH	91	SMJ (SUPER MULTIPLE JUNCTION)	103
Wiring Diagram Codes (Cell Codes)	92	Terminal Arrangement	103
ELECTRICAL UNITS LOCATION	95	STANDARDIZED RELAY	104
Electrical Units Location	95	Description	104
ENGINE COMPARTMENT	95	NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS	104
PASSENGER COMPARTMENT	97	TYPE OF STANDARDIZED RELAYS	104
		FUSE BLOCK - JUNCTION BOX (J/B)	106
		Terminal Arrangement	106
		FUSE AND FUSIBLE LINK BOX	107
		Terminal Arrangement	107

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EKS008IN

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Maintenance Information

EKS008IP

If any of following part is replaced, always replace with new* one.

If it's not (or fail to do so), the electrical system may not be operated properly.

*: New one means a virgin control unit that has never been energized on-board.

RHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM
- IPDM E/R
- Combination meter
- EPS control unit

LHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM

A

B

C

D

E

F

G

H

I

J

PG

L

M

POWER SUPPLY ROUTING

POWER SUPPLY ROUTING


SMA for VIN >SJN**AK12U1288860

PFP:00011

Schematic

SMA for VIN >SJN**AK12U1309269

EKS00795



⑥ With gasoline engine
⑦ With diesel engine


* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

POWER SUPPLY ROUTING

Wiring Diagram — POWER — BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION


EKS00796

SMA for VIN > SJN**AK12U1288860 SMA for VIN > SJN**AK12U1309269 PG-POWER-01





POWER SUPPLY ROUTING


PRECEDING PAGE A W → PG-POWER-02



PRECEDING PAGE D W →



REFER TO THE FOLLOWING.




MKWA1840E

POWER SUPPLY ROUTING

PG-POWER-03

(G) : WITH GASOLINE ENGINE

(D) : WITH DIESEL ENGINE




MKWA1841E

POWER SUPPLY ROUTING

PG-POWER-04

■ : DATA LINE




MKWA1506E

POWER SUPPLY ROUTING

PG-POWER-05


 : WITH GASOLINE ENGINE

A
B
C
D
E
F
G
H
I
J
PG
L
M



POWER SUPPLY ROUTING


PG-POWER-06



MKWA3239E

POWER SUPPLY ROUTING

ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”



PG-POWER-07

(L) : LHD MODELS

(R) : RHD MODELS

A

B

C

D

E

F

G

H


I

J

PG

L

M



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)


(M16) -FUSE BLOCK- JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17							

MKWA1508E


POWER SUPPLY ROUTING

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”



| REFER TO THE FOLLOWING.

**M1 -SUPER MULTIPLE
JUNCTION (SMJ)**



POWER SUPPLY ROUTING


PG-POWER-09

(G) : WITH GASOLINE ENGINE

(D) : WITH DIESEL ENGINE

*1 PU : (G)

W : (D)



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)

(M16) -FUSE BLOCK- JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17							

POWER SUPPLY ROUTING


PG-POWER-10

(G) : WITH GASOLINE ENGINE

(D) : WITH DIESEL ENGINE

*1 LG : (G)

BR : (D)



POWER SUPPLY ROUTING



PG-POWER-11

◆ : WITH GASOLINE ENGINE

A
B
C
D
E
F
G
H
I
J

PG

L
M





MKWA1844E

POWER SUPPLY ROUTING

PG-POWER-12

 LHD MODELS

 : RHD MODELS



I REFER TO THE FOLLOWING.

M16 -FUSE BLOCK-
JUNCTION BOX (UP)

CONVENTIONAL (S.E.)


13 14 15 16 17

POWER SUPPLY ROUTING

Fuse

EKS00797

- If fuse is blown, be sure to eliminate cause of incident before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

EKS00798

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:


- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of incident.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

EKS00799

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

PFP:284B7

System Description

EKS0080P

- IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) integrates the relay box and the fuse box which has been conventionally placed in the engine room. It controls the built-in relay with the control circuit in IPDM E/R.
- IPDM E/R integrated control circuit performs ON-OFF control of the relay and transmission of various signals (oil pressure switch, park/neutral position switch, reverse switch) through CAN communication with BCM and ECM.

NOTE:

All IPDM E/R integrated relays can never be removed.

SYSTEMS CONTROLLED BY IPDM E/R

1. Lamp control
Using the CAN communication line, it receives signals from BCM and controls following lamps:
 - Headlamps (Hi, Lo)
 - Parking lamps, tail lamps and license plate lamp
 - Front fog lamps
2. Front wiper control
Using the CAN communication line, it receives signals from BCM and controls front wiper.
3. Headlamp washer control
Using the CAN communication line, it receives signals from BCM and controls headlamp washer.
4. Rear window defogger control
Using the CAN communication line, it receives signals from BCM and controls rear window defogger.
5. A/C compressor control
Using the CAN communication line, it receives signals from ECM and controls A/C compressor.
6. Cooling fan control
Using the CAN communication line, it receives signals from ECM and controls cooling fan.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

FAIL-SAFE FUNCTION

- When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
- Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled parts	Fail-safe mode
Headlamp	With the ignition switch ON, the headlamp (low) is ON. With the ignition switch OFF, the headlamp (low) is OFF.
Parking lamp/ license plate lamp/ tail lamp	With the ignition switch ON, the tail lamp is ON. With the ignition switch OFF, the tail lamp is OFF.
Cooling fan	With the ignition switch ON, the cooling fan HI operates. With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned off, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger is OFF
Front fog lamp	Front fog lamp is OFF
Headlamp washer	Headlamp washer is OFF
A/C compressor	A/C compressor is OFF

IPDM E/R STATUS CONTROL

In order to save power, the IPDM E/R switches status by itself based on each operating condition.

- CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by the IPDM E/R is normally performed.
 - When the IPDM E/R is not controlling any load, a sleep request signal is received from the BCM and the mode is switched to sleep waiting status.
- Sleep waiting status
 - Process to stop CAN communication is activated.
 - All systems controlled by IPDM E/R are stopped. When 1 second has elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
- Sleep status
 - The IPDM E/R operates in low current consumption mode.
 - CAN communication is not active.
 - When a change in the CAN communication line or ignition switch ON is detected, the mode switches to CAN communication status.

FUNCTION OF IPDM E/R

- Park/neutral position switch signal output function
The signal (ON/OFF) input from the Park/neutral position is output to ECM.
- Oil pressure switch output function
The signal (ON/OFF) input from the oil pressure switch is output to the combination meter using the CAN communication line.
- Reverse switch signal output function
The signal (ON/OFF) input from the reverse switch is output to BCM using the CAN communication line.

CAN Communication SYSTEM DESCRIPTION

EKSOOKKK

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00KKL

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door								
Axle	2WD								
Engine	CR10DE/CR12DE/CR14DE				CR12DE/CR14DE				K9K
Handle	LHD/RHD								
Brake control	ABS system				ESP system				ABS
Transmission	A/T		M/T		A/T		M/T		M/T
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable

CAN communication unit

ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×			×	×			×	×			×	×		×	×
Drive computer	×		×		×		×		×		×	×	×	×	×	×	×
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×					×	×	×	×					
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	<u>PG-21, "TYPE 1/ TYPE 2"</u>				<u>PG-24, "TYPE 3/ TYPE 4"</u>				<u>PG-26, "TYPE 5/ TYPE 6"</u>				<u>PG-29, "TYPE 7/ TYPE 8"</u>		<u>PG-31, "TYPE 9/ TYPE 10"</u>		


x: Applicable

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R				T		R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

I

J

PG

L


M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A
B
C
D
E
F
G
H
I
J
PG

L


M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated con- trol signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

A
B
C
D
E
F
G
H
I
J
PG

L
M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction sig- nal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T		R	
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T		R	
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal	R	T						


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

Function of Detecting Ignition Relay Malfunction

EKS0080R

- When a contact point of the integrated ignition relay is stuck and cannot be turned OFF, the IPDM E/R turns ON tail lamp relay for 10 minutes to indicate IPDM E/R malfunction.

NOTE:

When the ignition switch is turned ON, the tail lamp is off.

CONSULT-II Function (IPDM E/R)


EKS0080S

CONSULT-II can display each diagnostic item using the diagnostic modes shown following. Data is received and transmitted via the control module communication line.


Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.

CONSULT-II BASIC OPERATION

- Turn ignition switch OFF.
- Connect CONSULT-II CONVERTER and CONSULT-II to data link connector.
- Turn ignition switch ON.




- Touch "START (NISSAN BASED VHCL)".




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

5. Touch "IPDM E/R" on "SELECT SYSTEM" screen.

- If "IPDM E/R" is not displayed, print "SELECT SYSTEM" screen, then refer to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Select part to be diagnosed on "SELECT DIAG MODE" screen.



SELF-DIAG RESULTS

Operation Procedure

1. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
2. Check display content in self-diagnostic results.

Display Item List

Display Items	Malfunction Return Condition	TIME		Possible causes
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	—
CAN COMM CIRCUIT	<ul style="list-style-type: none"> • If CAN communication reception/transmission data has an malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. • When the data in CAN communication is not received before the specified time 	×	×	Any of or several items below have malfunctions. <ul style="list-style-type: none"> • CAN CIRC 1 • CAN CIRC 2 • CAN CIRC 3 • CAN1 STAT • CAN2 STAT • CAN3 STAT
IGN RELAY ON	When the ignition switch is not ON position, the ignition relay in the IPDM E/R is ON.	×	×	Ignition relay (integrated in IPDM E/R)
IGN RELAY OFF	When the ignition switch is ON position, the ignition relay in the IPDM E/R is OFF.	×	×	Ignition relay (integrated in IPDM E/R)
EEPROM	Malfunction is detected with the integrated EEPROM memory diagnosis.	×	×	IPDM E/R

×:Applicable

NOTE:

The details for display of the period are as follows:

- CRNT: Malfunction currently detected with IPDM E/R.
- PAST: Malfunction detected in the past and memorized with IPDM E/R.

DATA MONITOR

Operation Procedure

1. Touch “DATA MONITOR” on “SELECT MONITOR ITEM” screen.
2. Touch “ALL SIGNALS”, “MAIN SIGNALS” or “SELECT FROM MENU” on the “DATA MONITOR” screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECT FROM MENU	Select any item for monitoring.

3. Touch “START”.
4. Touch the required monitoring item on “SELECT ITEM MENU”. In “ALL SIGNALS”, all items are monitored. In “MAIN SIGNALS”, predetermined items are monitored.
5. Touch “RECORD” while monitoring to record the status of the item being monitored. To stop recording, touch “STOP”.

All Items, Main Items, Select Item Menu

Item name	Display or unit	Monitor item selection			Description
		ALL SIGNALS	MAIN SIGNALS	SELECT FROM MENU	
MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
A/C COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
HL WASHER REQ	ON/OFF	×		×	This item cannot be monitored. (No change of display)
FR WIP REQ	OFF/1LO/LO/HI	×	×	×	Signal status input from BCM
WIP AUTO STOP	ON/OFF	×	×	×	Output status of IPDM E/R
WIP PROTECTION	OFF/LS/HS/Block	×		×	Control status of IPDM E/R
ST RLY REQ	ON/OFF	×		×	Status of input signal CAUTION
IGN RLY STATUS	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM
RR DEF STOP REQ	ON/OFF	×		×	Input signal status
ALT LOAD	%	×		×	This item cannot be monitored. (No change of display)
ALT CRNT	A	×		×	
ALT NO	##	×		×	
BAT VOLT	V	×		×	Value measured with IPDM E/R
ENG COOL TEMP	°C	×		×	Signal status input from ECM
OIL P SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R
REV SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R

x:applicable

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- The vehicle without the intelligent key system displays only ON without change.

ACTIVE TEST

Operation Procedure

1. Touch “ACTIVE TEST” on “SELECT DIAG-MODE” screen.
2. Touch item to be tested, and check operation.
3. Touch “START”.
4. Touch “STOP” while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp (HI, LO) output	HEADLAMP	With a certain operation (OFF, HI ON, LO ON), the headlamp relay (Lo, Hi) can be operated.
Front fog lamp output	FRONT FOG LAMP	With a certain ON-OFF operation, the fog lamp relay can be operated.
Tail lamp output	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger output	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) output	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan output	MOTOR FAN	With a certain operation (OFF, Status 1, Status 2, Status 3), the cooling fan can be operated.
Headlamp washer output	HEADLAMP WASHER	With a certain ON-OFF operation, the headlamp washer can be operated.

Configuration DESCRIPTION

EKS00EJ9

There are two CONFIGURATION functions, as follows.

READ CONFIGURATION is a function for confirming the vehicle configuration written on IPDM E/R.

WRITE CONFIGURATION is a function for writing a vehicle configuration to IPDM E/R.

CAUTION:


- When replacing IPDM E/R, completely perform WRITE CONFIGURATION with CONSULT-II.
- Orderly complete the procedure of WRITE CONFIGURATION.
- If you set incorrect WRITE CONFIGURATION, vehicle operation will not be correct.
- Configuration is different by each vehicle model, confirm configuration in each case.

READ CONFIGURATION PROCEDURE

CAUTION:


If CONSULT-II is used with no connection of CONSULT CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


2. Touch “START(NISSAN BASED VHCL)”.



3. Touch “IPDM E/R” on “SELECT SYSTEM” screen.
If “IPDM E/R” is not indicated, go to [GI-36, “CONSULT-II Data Link Connector \(DLC\) Circuit”](#).




4. Touch “CONFIGURATION” on “SELECT DIAG MODE” screen.




5. Touch “K12”, and “OK” on “VEHICLE SELECT” screen.
For canceling, touch “CANCEL” on “VEHICLE SELECT” screen.

NOTE:

Confirm vehicle model on IDENTIFICATION PLATE, refer to GI section.




6. Touch “READ CONFIGURATION” on “CONFIGURATION” screen.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


7. Configuration of current IPDM E/R are printed out automatically. Configuration of brand-new IPDM E/R before executing "WRITE CONFIGURATION" is as follows.

MANUAL SET ITEM	
ITEM	SET VAL
ALT TYPE	TYPE 1
AUTO SET ITEM	
STARTER MODE	MODE 1



MKIB0760E

8. Touch "BACK" on "READ CONFIGURATION" screen.




MKIB0761E

WRITE CONFIGURATION PROCEDURE

CAUTION:


If CONSULT-II is used with no connection of CONSULT CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


2. Touch "START(NISSAN BASED VHCL)".



3. Touch "IPDM E/R" on "SELECT SYSTEM" screen.
If "IPDM E/R" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




4. Touch "CONFIGURATION" on "SELECT DIAG MODE" screen.




5. Touch "K12", and "OK" on "VEHICLE SELECT" screen.
For canceling, touch "CANCEL" on "VEHICLE SELECT" screen.

NOTE:

Confirm vehicle model on IDENTIFICATION PLATE, refer to GI section.




6. Touch "WRITE CONFIGURATION" on "CONFIGURATION" screen.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

7. Touch “YES”.
For canceling, touch “NO”.



8. Touch “TYPE 1”, “TYPE 2” or “TYPE 3” on “WRITE CONFIGURATION” screen based on the following ITEM LIST.

< ITEM LIST >

ITEM	SET VAL	NOTE
Alternator type	TYPE 1	Gasoline engine models
	TYPE 2	PTC heater is not equipped, if 14 digits of the applied model code is marked without “H” or “J”. i.e.:EDHARAFK12EEA “E” ...
	TYPE 3	PTC heater is equipped, if 14 digits of the applied model code is marked with “H” or “J”. i.e.:EDHARAFK12EEA “H” ...

For canceling, touch “CANCEL”.

9. Touch “CHNG SETTING” on “WRITE CONFIGURATION” screen.


CAUTION:

Make sure to touch “CHNG SETTING even if the indicated configuration of brand new IPDM E/R is same as the desirable configuration.



If not, configuration which is set automatically by selecting vehicle model can not be memorized.

10. Touch “OK” on “WRITE CONFIGURATION” screen.

When touched “CANCEL”, go to previous screen.




11. Wait until the next screen during setting.




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

12. WRITE CONFIGURATION results are printed out automatically. Check "WRITE CONFIGURATION" is correctly executed by comparing sheet automatically printed out with desirable configuration.



MKIB0766E

13. Touch "OK" on "WRITE CONFIGURATION" screen. WRITE CONFIGURATION is completed.



MKIB0767E

A
B
C
D
E
F
G
H
I
J
L
M

PG

Auto Active Test

DESCRIPTION

EKS0080T

- In the auto active test, the IPDM E/R sends a drive signal to the following systems to check operation.
- Rear window defogger
- Front wiper (Low, High)
- Parking lamps, license lamps, tail lamps
- Front fog lamp
- Headlamp (Low, High)
- Headlamp washer
- A/C compressor (magnetic clutch)
- Cooling fan

OPERATION PROCEDURE

1. Close hood, and keep wiper arms off the windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON, and within 20 seconds, press the driver side door switch 10 times. Then turn ignition switch OFF.

CAUTION:

Keep passenger side door closed.

4. Turn ignition switch ON within 10 seconds.
5. When auto active test mode is actuated, oil pressure warning lamp starts blinking.
6. After a series of operations is repeated 3 times, auto active test is completed.

NOTE:

When the auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

When the auto active test cannot be started, check the oil pressure switch system [DI-77, "Oil Pressure Warning Lamp Stays Off \(Ignition Switch ON\)"](#) and the [BL-58, "Check Door Switch"](#).

INSPECTION IN AUTO ACTIVE TEST MODE

When the auto active test is started, repeat steps 1 to 9 as below three times.

- Step 1: Rear window defogger is operated for 10 seconds.
- Step 2: Front wiper is operated with low speed for 5 seconds and high speed for 5 seconds.
- Step 3: Parking, license plate, tail lamp are turned on for 10 seconds.
- Step 4: Front fog lamp is turned on for 10 seconds.

NOTE:


If the fog lamp is not equipped, this step will be skipped. (In this case, next step will be start after 10 seconds.)

- Step 5: Headlamp (low) is turned on for 10 seconds.
- Step 6: Headlamp (high) is blinked ON and OFF for 5 times.
- Step 7: Headlamp washer is operated for 1 second and it is stopped for 9 seconds.

NOTE:

If the headlamp washer is not equipped, this step will be skipped. (In this case, next step will be start after 10 seconds.)

- Step 8: A/C compressor ON and OFF operation is repeated for 5 times.
- Step 9: Cooling fan motor is operated with low speed for 5 seconds and high speed for 5 seconds.



*1: Step 4 will be skipped, if the front fog lamp is not equipped. (In the case, next step will be start after 10 seconds.)

*2: Step 7 will be skipped, if the headlamp washer is not equipped. (In the case, next step will be start after 10 seconds.)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

CONCEPT OF AUTO ACTIVE TEST

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.

Diagnosis Chart in Auto Active Test Mode

Symptom	Inspection Contents	Possible causes		Reference page
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	● BCM signal input system	GW-14
		NO	● Harness for open or short between the IPDM E/R and the rear window defogger ● Open circuit of rear window defogger ● IPDM E/R (integrated relay) malfunction (Rear window defogger relay)	
Front wiper does not illuminate.	Perform auto active test. Does the front wiper operate?	YES	● BCM signal input system	WW-5 (without rain sensor) or WW-48 (with rain sensor)
		NO	● Wiper motor malfunction ● Front wiper motor ground.	
Either of parking lamp, license plate lamp and tail lamp does not illuminate.	Perform auto active test. Does parking lamp, license plate lamp and tail lamp illuminate?	YES	● BCM signal input system	LT-152
		NO	● Bulb ● Harness for open or short between IPDM E/R and parking, license plate or tail lamp. ● IPDM E/R (integrated relay) malfunction	
Front fog lamp does not illuminate.	Perform auto active test. Does the front fog lamp illuminate?	YES	● BCM signal input system	LT-74
		NO	● Bulb ● Harness for open or short between IPDM E/R and front fog lamp. ● IPDM E/R (integrated relay) malfunction	
Headlamp (Hi, Lo) does not illuminate.	Perform auto active test. Does headlamp?	YES	● BCM signal input system	LT-6 "HEAD-LAMP-CONVENTIONAL TYPE-" or LT-42 , "HEAD-LAMP-DAYTIME LIGHT SYS-TEM -"
		NO	● Bulb ● Headlamp ground system malfunction ● Open or short in harness or headlamp between IPDM E/R and headlamps ● IPDM E/R (integrated relay) malfunction (headlamp relay)	
Headlamp washer does not operate.	Perform auto active test. Does the Headlamp washer operate?	YES	● BCM signal input system	WW-110
		NO	● Harness for open or short between IPDM E/R and headlamp washer. ● Headlamp washer relay is malfunction.	
The cooling fan is inoperative.	Perform auto active test. Does the cooling fan operate?	YES	● Signal input system of ECM ● CAN communication signal between ECM and IPDM E/R*	EC-352 (with EURO-OBD) or EC-689 (without EURO-OBD)
		NO	● Malfunction of cooling fan ● Harness open or short between the IPDM E/R and the cooling fan. ● IPDM E/R (integrated relay) malfunction	

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Symptom	Inspection Contents		Possible causes	Reference page
The A/C compressor is inoperative.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> ● CAN communication signal between BCM and ECM*. ● CAN communication signal between ECM and IPDM E/R*. ● BCM signal input system ● Signal input system of ECM. 	ATC-54
		NO	<ul style="list-style-type: none"> ● Magnetic clutch inoperative. ● Harness for open or short between IPDM E/R and magnetic clutch. ● IPDM E/R (integrated relay) malfunction 	
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> ● Harness for open or short between IPDM E/R and oil pressure switch. ● Oil pressure switch malfunction 	DI-65
		NO	<ul style="list-style-type: none"> ● CAN communication signal between IPDM E/R and combination meter*. ● Combination meter 	

*: Perform IPDM E/R self-diagnosis with CONSULT-II. Refer to [PG-48, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)

A

B

C

D

E

F

G

H

I

J

PG


L

M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Schematic

EKS0080U




NOTE:

Refer to each control system for details of connecting parts.

MKWA1514E

IPDM E/R Terminal Arrangement

EKS0080V



MKWA1370E

Inspection With CONSULT-II (Self-Diagnosis)

EKS0080W

1. CHECK SELF-DIAGNOSTIC RESULT

1. Connect CONSULT-II and select "IPDM E/R" on the Diagnosis System Selection screen.
2. Select "SELF-DIAG RESULTS" on the diagnosis mode selection screen.
3. Check display content in self-diagnostic results.

CONSULT-II display	CONSULT-II display code	TIME		Details of diagnosis result
		CRN T	PAS T	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	—
IGN RELAY ON	B2098	×	×	Ignition relay malfunction (integrated in IPDM E/R)
IGN RELAY OFF	B2099	×	×	Ignition relay malfunction (integrated in IPDM E/R)
EEPROM	B2100	×	×	IPDM E/R malfunction
CAN COMM CIRCUIT	U1000	×	×	Any of or several items below have malfunction. ● TRANSMIT DIAG ● ECM ● BCM/SEC

x: Applicable

CAUTION:

If errors of the CAN communication system and the ignition relay ON or OFF are displayed at the same time after the self-diagnostic result, replace the IPDM E/R and perform the self-diagnosis again.

NOTE:

The details for display of the period are as follows:

- CRNT: Malfunction currently detected with IPDM E/R.
- PAST: Malfunction detected in the past and memorized with IPDM E/R.

Contents displayed

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END.

CAN COMM CIRCUIT>>[LAN-4, "Precautions When Using CONSULT-II".](#)

IGN RELAY ON>>Replace IPDM E/R.

IGN RELAY OFF>>Replace IPDM E/R.



EEPROM>>Replace IPDM E/R.

IPDM E/R Terminal Inspection

EKS0080X

CAUTION:**This is performed when the IPDM E/R is checked without removing the battery.**

1. Remove the headlamp (LH).
2. Remove tabs of the IPDM E/R and place the IPDM E/R with its connector facing upward. Check each terminal.



IPDM E/R Power Supply and Ground Circuit Check

EKS0089R

1. CHECK FUSE AND FUSIBLE LINK

Make sure that the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Power source	Fuse, fusible link No.
1	Battery	Letter C
2	Battery	Letter D
40	Ignition switch (ON)	80

OK or NG

OK >> GO TO 2.

NG >> Replace fuse or fusible link.

 A
B
C
D
E
F
G
H
I
J

PG


M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R harness connector.
2. Check voltage between IPDM E/R and ground.

Terminals		Ignition switch position			
Connector	Terminal (Wire color)	(-)	OFF	ACC	ON
E10	1 (R)	Ground	Battery voltage	Battery voltage	Battery voltage
	2 (G)		Battery voltage	Battery voltage	Battery voltage
E14	40 (PU)		0V	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.
 NG >> Check harness between fuse, fusible link and IPDM E/R.


3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors.
2. Check continuity between IPDM E/R harness connectors E12 terminal 14 (B), E16 terminal 54 (B) and ground.

Continuity should exist.

OK or NG

OK >> INSPECTION END.
 NG >> Repair harness for ground circuit.



Diagnosis of IPDM E/R Integrated Relay

EKS0080Z

1. CHECK SYMPTOM

Check the symptom of the malfunction relay.

What is the symptom?

No operation>>GO TO 2.

No stop>> GO TO 4.

2. CHECK RELAY TYPE

Which is the relay with error?

Front fog lamp relay, headlamp relay (Hi, Lo), tail lamp relay, front wiper relay (main, Hi/Lo), rear window defogger relay, A/C relay, starter motor relay, cooling fan relay (1, 2, 3)>>GO TO 5.

Ignition relay>> Go to [PG-48, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)ECM relay>>Go to [EC-125, "POWER SUPPLY CIRCUIT FOR ECM"](#) (CR engine models with EURO-OBD), [EC-567, "POWER SUPPLY CIRCUIT FOR ECM"](#) (CR engine models without EURO-OBD) or [EC-K9K-237, "Wiring diagram — Main power supply and ground circuit", "DIESEL INJECTION"](#) (K9K engine models).Throttle motor relay>>Go to [EC-305, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models with EURO-OBD) or [EC-673, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models without EURO-OBD).Fuel pump relay>>Go to [EC-450, "FUEL PUMP CIRCUIT"](#) (CR engine models with EURO-OBD) or [EC-826, "FUEL PUMP CIRCUIT"](#) (CR engine models without EURO-OBD).**3. CHECK RELAY**Send an operation signal to the relay using a diagnosis tool. Check the voltage at the input and output terminals of inoperative relays according to the table below or check for continuity between input and output terminals. Refer to [PG-36, "ACTIVE TEST"](#) or [PG-42, "Auto Active Test"](#) .

Relay name	IPDM E/R terminal number		Voltage [V]	Diagnosis tool	
	Input side	Output side		CONSULT-II ACTIVE TEST	Auto ACTIVE TEST
Front fog lamp relay	1	43, 44	Battery voltage	×	×
Headlamp Hi relay		46, 47		×	×
Headlamp Lo relay		48, 50		×	×
Tail lamp relay		15, 16, 45, 49		×	×
Front wiper main relay		23		×	×
Front wiper HI/LO relay		24		×	×
A/C relay		41			×
Rear windows defogger relay	2	8		×	×
Cooling fan Lo relay 1	14	10		×	×
Cooling fan Hi relay 2		12		×	×

x: Applicable

OK or NG

OK >> Check the control unit that controls the inoperative relay. (system)

NG >> Replace the IPDM E/R. (malfunction of relay)

A

B

C

D

E

F

G

H

I

J

PG

L

M

4. CHECK RELAY TYPE

Which is the relay with error?

Front fog lamp relay, headlamp relay (Hi, Lo), tail lamp relay, front wiper relay (main, Hi/Lo), rear window defogger relay, A/C relay, starter motor relay, cooling fan relay (1, 2, 3)>>GO TO 5.

Ignition relay>> Go to [PG-48, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)

ECM relay>>Go to [EC-125, "POWER SUPPLY CIRCUIT FOR ECM"](#) (CR engine models with EURO-OBD), [EC-567, "POWER SUPPLY CIRCUIT FOR ECM"](#) (CR engine models without EURO-OBD) or [EC-K9K-237, "Wiring diagram — Main power supply and ground circuit", "DIESEL INJECTION"](#) (K9K engine models).

Throttle motor relay>>Go to [EC-305, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models with EURO-OBD) or [EC-673, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models without EURO-OBD).

Fuel pump relay>>Go to [EC-450, "FUEL PUMP CIRCUIT"](#) (CR engine models with EURO-OBD) or [EC-826, "FUEL PUMP CIRCUIT"](#) (CR engine models without EURO-OBD).

5. CHECK INPUT SIGNAL

Check the control signal status of the relay on the IPDM E/R that receives from each control unit with the data monitor of CONSULT-II. Refer to [PG-35, "DATA MONITOR"](#).

What is the data monitor result?

Other than OFF>>Check the control unit that controls the relay (system) not deactivated.

OFF >> Replace the IPDM E/R. (error of relay ON)

Removal and Installation of IPDM E/R

EKS0087Q

CAUTION:

Always replace with new* IPDM E/R when the IPDM E/R replacement is required.

*: New one means virgin control unit that has never been energized on-board.



REMOVAL

NOTE:

If possible, before removing IPDM E/R, retrieve current IPDM E/R configuration to use for reference when configuring brand-new IPDM E/R after installation. Refer to [PG-36, "Configuration"](#).


1. Remove battery. Refer to [SC-14, "Removal and Installation"](#) in SC section.

2. Pull out IPDM E/R cover A from IPDM cover B.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

3. Disconnect harness connector from IPDM E/R.
4. Remove IPDM E/R from IPDM E/R cover A.



INSTALLATION

- Install in the reverse order of removal.

NOTE:

When replacing IPDM E/R, it must be configured. Refer to [PG-36, "Configuration"](#) .

A
B
C
D

E

F

G

H

I

J

PG

L

M

GROUND


GROUND

Ground Distribution MAIN HARNESS

SMA for VIN >SJN**AK12U1309269

PFP:00011

EKS0079A



A



Next page

MKWA1845E

GROUND

Preceding page

A



A

B

C

D

E

F

G

H

I

J

PG

L

M

CONNECTOR NUMBER	CONNECT TO
(M11)	Headlamp aiming switch (Terminal No. 2)
(M11)	Headlamp aiming switch (Terminal No. 4)
(M12)	Headlamp washer switch (Terminal No. 2) (With headlamp washer)
(M12)	Headlamp washer switch (Terminal No. 4) (With headlamp washer)
(M13)	Door mirror remote control switch (LHD models)
(M14)	ESP off switch (Terminal No. 2) (LHD models)
(M14)	ESP off switch (Terminal No. 4) (LHD models)
(M17)	Data link connector (Terminal No. 4) (LHD models)
(M17)	Data link connector (Terminal No. 5) (LHD models)
(M28)	Drive computer
(M32)	Combination switch (LHD models)
(M37)	Clutch interlock switch (With M/T and Intelligent Key system)
(M42)	Fan control amp. (With auto A/C)
(M45)	Thermal control amplifier (With manual A/C)
(M48)	BCM (Body control module) (Terminal No. 2) (RHD models)
(M50)	BCM (Body control module) (Terminal No. 70) (RHD models)
(M51)	Intelligent Key unit (With Intelligent Key system)
(M58)	Heater control panel (Terminal No. 6) (Without auto A/C)
(M58)	Heater control panel (Terminal No. 7) (Without auto A/C)
(M58)	Heater control panel (Terminal No. 10) (Without auto A/C)
(M61)	Hazard switch (Terminal No. 1)
(M61)	Hazard switch (Terminal No. 4)

B


Next page

MKWA1846E

GROUND

Preceding page

B





: With ESP



: Without ESP

*1 M87:	*3 M84:
M6:	M56:
*2 D13:	*4 D42:
D1:	D31:

GROUND



CONNECTOR NUMBER	CONNECT TO
(M24)	EPS control unit




CONNECTOR NUMBER	CONNECT TO
(M27)	Audio unit (Terminal No. 38) (With audio unit)
(M27)	Audio and NAVI control unit (Terminal No. 38) (With NAVI control unit)

GROUND

ENGINE ROOM HARNESS

SMA for VIN >SJN**AK12U1309269





Next page

MKWA1497E

GROUND

Preceding page



CONNECTOR NUMBER	CONNECT TO
(E2)	Daytime light relay (With daytime light system)
(E3)	Cooling fan motor (Gasoline engine with A/C)
(E3)	Cooling fan motor-1 (Diesel engine with A/C and with PTC heater)
(E4)	Cooling fan motor (Gasoline engine without A/C)
(E4)	Cooling fan motor-2 (Diesel engine without A/C)
(E8)	Front turn signal lamp LH
(E11)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 3)
(E16)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 54)
(E20)	Headlamp aiming motor LH
(E24)	Side turn signal lamp LH
(E34)	Front fog lamp RH (With front fog lamp)
(E37)	Parking lamp RH
(E42)	Headlamp RH (Without daytime light system)
(E43)	Brake fluid level switch
(E63)	Cooling fan motor-2 (With PTC heater)
(E109)	Stop lamp switch (LHD models with A/T)
(F129)	Compressor (With diesel engine)
(E60) (F101)	Engine control harness (With diesel engine)



Next page

A
B
C
D
E
F
G
H
I
J



PG
L
M

GROUND


Preceding page



CONNECTOR NUMBER	CONNECT TO
E7	Front fog lamp LH (With front fog lamp)
E21	Headlamp LH
E22	Parking lamp LH
E27	Shield wire (Crash zone sensor) (For circuit from terminal No. 1, 2)
E30	Horn
E32	Front turn signal lamp RH
E33	Headlamp washer motor (With headlamp washer)
E35	Side turn signal lamp RH
E39	Headlamp aiming motor RH
E44	Front wiper motor



CONNECTOR NUMBER	CONNECT TO
E45	ABS actuator and electric unit (Control unit) (Terminal No. 1) (Without ESP)
E45	ABS actuator and electric unit (Control unit) (Terminal No. 4) (Without ESP)




CONNECTOR NUMBER	CONNECT TO
E47	ABS actuator and electric unit (Control unit) (Terminal No. 1) (With ESP)
E47	ABS actuator and electric unit (Control unit) (Terminal No. 4) (With ESP)


GROUND

ENGINE CONTROL HARNESS/CR ENGINE MODELS

SMA for VIN >SJN**AK12U1309269



CONNECTOR NUMBER	CONNECT TO
(F26)	Condenser
(F33)	Ignition coil No. 1 (With power transistor)
(F34)	Ignition coil No. 2 (With power transistor)
(F35)	Ignition coil No. 3 (With power transistor)
(F36)	Ignition coil No. 4 (With power transistor)



CONNECTOR NUMBER	CONNECT TO
(F31)	Alternator (E)


A
B
C
D
E
F
G
H
I
J

PG
L
M

GROUND

ENGINE CONTROL HARNESS/K9K ENGINE MODELS

SMA for VIN >SJN**AK12U1309269





CON- NECTOR NUMBER	CONNECT TO
(F134)	ECM (Terminal No. 111)
(F134)	ECM (Terminal No. 112)



GROUND

BODY HARNESS

SMA for VIN >SJN**AK12U1309269



CONNECTOR NUMBER	CONNECT TO
(B13)	Shield wire [RH side air bag (Satellite) sensor] (For circuit from terminal No. 1, 2)




CONNECTOR NUMBER	CONNECT TO
(B19)	Shield wire [LH side air bag (Satellite) sensor] (For circuit from terminal No. 1, 2)

A
B
C
D
E
F
G
H
I
J

PG
L
M

GROUND





CONNECTOR NUMBER	CONNECT TO
(B5)	Seat belt buckle switch RH
(B6)	Heated seat RH (With heated seat)
(B10)	Seat belt buckle switch LH
(B11)	Heated seat LH (With heated seat)
(B28)	Fuel level sensor unit and fuel pump (With gasoline engine) • Fuel pump
(B36)	Rear combination lamp RH
(B37)	Rear combination lamp LH
(B38)	License plate lamp
(B56)	Heated seat switch RH (Terminal No. 4) (With heated seat)
(B56)	Heated seat switch RH (Terminal No. 6) (With heated seat)
(B57)	Heated seat switch LH (Terminal No. 4) (With heated seat)
(B57)	Heated seat switch LH (Terminal No. 6) (With heated seat)
(B58)	Door lock/unlock switch (Without ESP)



Next page



GROUND

Preceding page



A
B
C
D
E
F
G
H
I
J

CONNECTOR NUMBER	CONNECT TO
(B47)	High-mounted stop lamp



PG
L

M

Next page

MKWA1322E



GROUND

Preceding page

F

CONNECTOR NUMBER	CONNECT TO
(B52)	External back door release switch
(B53)	Rear wiper motor
(B54)	Door request switch (Back door) (With Intelligent Key system)
(B55)	Back door release actuator (Terminal No. 2) • Back door switch
(B55)	Back door release actuator (Terminal No. 4) • Release motor

Body ground



Body ground

CONNECTOR NUMBER	CONNECT TO
(B201)	Rear window defogger

MKWA1323E

HARNESS

HARNESS

Harness Layout

HOW TO READ HARNESS LAYOUTS


The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Body Harness
- Body No.2 Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

Example:



SMA for VIN >SJN**AK12U1337130

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9	—	—		
• Ground terminal etc.	—			

SKIA0404E


PG

HARNESS

OUTLINE/CR ENGINE MODELS

SMA for VIN >SJN**AK12U1288860


SMA for VIN >SJN**AK12U1337130



MKWA1354E

HARNESS

OUTLINE/K9K ENGINE MODELS



A
B
C
D
E
F
G
H
I
J

PG


L

M

MKWA1490E

HARNESS

MAIN HARNESS/LHD MODELS



MKWA1852E

HARNESS


B2 ★ (M1)	SMJ	To (E101)	C3 (M33)	W/2	Key switch (Without Intelligent Key system)	E4 (M65)	B/6	Mode door motor (With auto A/C)
B3 (M2)	Y/4	To (E102) (Without ESP)	D2 (M34)	GY/6	Key switch and ignition knob switch (With Intelligent Key system)	E4 (M66)	B/6	Air mix door motor (With auto A/C)
A2 (M3)	B/2	To (E103)	D2 (M35)	GY/4	NATS antenna amp.	G5 (M67)	B/1	Parking brake switch
A3 (M4)	W/2	To (E104) (With headlamp washer without ESP)	D2 (M36)	-/4	NATS antenna amp. (Without Intelligent Key system)	F4 (M68)	W/6	A/T device (With A/T)
A4 (M5)	W/12	To (D2) (Without ESP)	D2 (M37)	BR/2	Clutch interlock switch (With M/T and Intelligent Key system)	G4 (M69)	Y/20	Air bag diagnosis sensor unit
A5 (M6)	W/10	To (D1) (Without ESP)	D2 (M38)	W/6	Ignition switch	B3 (M78)	W/12	Oil level warning unit (With diesel engine)
A5 (M7)	W/12	To (B4)	D1 (M39)	W/2	In-vehicle sensor (With auto A/C)	A3 (M79)	W/20	Joint connector-1
B5 (M8)	W/10	To (B3) (Without ESP)	D3 (M40)	W/4	Fan resistor (Without auto A/C)	A4 (M80)	W/20	Joint connector-2
F3 (M9)	W/24	To (B2)	D3 (M41)	G/6	Fan control amp. (With auto A/C)	F1 ★ (M81)	L/20	Joint connector-3
F3 (M10)	W/10	To (B1) (Without ESP)	D3 (M42)	G/2	Fan control amp. (With auto A/C)	D2 (M82)	L/20	Joint connector-4
B3 (M11)	W/4	Headlamp aiming switch	D4 (M43)	B/6	Intake door motor (With auto A/C)	G3 (M83)	Gy/6	To (D41) (With ESP)
C3 (M12)	GY/8	Headlamp washer switch (With headlamp washer)	D4 (M44)	W/3	Intake sensor (With auto A/C)	G2 (M84)	W/12	To (D42) (With ESP)
C3 (M13)	W/10	Door mirror remote control switch	E3 (M45)	W/3	Thermal control amplifier (With manual A/C)	F5 (M85)	W/6	Door lock/unlock switch (With ESP)
B4 (M14)	GY/6	ESP off switch	E1 (M46)	B/2	Blower motor (Without A/C)	A4 (M86)	Gy/6	To (D12) (With ESP)
B4 (M15)	W/5	Headlamp washer relay (With headlamp washer without ESP)	E1 (M47)	-/2	Blower motor (With A/C)	A5 (M87)	W/12	To (D13) (With ESP)
B4 ★ (M16)	-	Fuse block (JY/B)	F1 (M48)	W/40	BCM (Body control module)	G3 (M88)	W/6	To (B60) (With ESP)
C4 (M17)	W/16	Data link connector	E1 (M49)	W/24	BCM (Body control module)			
B2 (M18)	W/2	Sunload sensor (With auto A/C)	E1 (M50)	B/15	BCM (Body control module)			
B2 ★ (M19)	-	Body ground	F2 (M51)	W/40	Intelligent Key unit (With Intelligent Key system)			
B2 ★ (M20)	-	Body ground	E2 (M52)	W/5	Door lock/unlock relay (With Intelligent Key system)			
C2 (M21)	-	Body ground	F1 (M53)	Y/2	Front passenger air bag module			
C2 ★ (M22)	W/40	Combination meter	F1 (M54)	W/8	To (R1)			
C1 (M23)	W/6	EPS control unit	F2 (M55)	W/12	To (D32) (Without ESP)			
C1 (M24)	W/1	EPS control unit	F2 (M56)	W/10	To (D31) (Without ESP)			
C2 (M25)	B/1	EPS control unit	F3 (M57)	W/1	Towbar kit			
E1 (M26)	-/20	Audio unit or NAVI control unit	E3 (M58)	W/15	Heater control panel (Without auto A/C)	★	Be sure to connect and lock the connectors securely after repair work.	
E2 (M27)	B/16	Audio unit or NAVI control unit	E3 (M59)	B/2	Power socket		Failure to do so may cause the ECM to have diagnostic trouble codes.	
E2 (M28)	W/12	Drive computer (With drive computer)	E3 (M60)	-	Body ground			
C3 (M29)	GY/8	Combination switch (Spiral cable) (Steering switch)	E3 (M61)	W/4	Hazard switch			
C3 (M30)	Y/6	Combination switch (Spiral cable) (Air bag)	F3 (M62)	W/2	Ashtray illumination			
C3 (M31)	W/4	Steering lock unit (With Intelligent Key system)	F3 (M63)	B/18	A/C auto amp. (With auto A/C)			
C2 (M32)	W/16	Combination switch	F2 (M64)	W/18	A/C auto amp. (With auto A/C)			

MKWA1853E

Harness

MAIN HARNESS/RHD MODELS

SMA for VIN >SJN**AK12U1288860



MKWA1854E

HARNESS


C1 ★ M1		To (E101)	F3 (M37)	Clutch interlock switch (With M/T and Intelligent Key system)	D1 (M78)	W/12	Oil level warning unit (With diesel engine)
C1 M2		To (E102) (Without ESP)		Ignition switch	G3 (M79)	W/20	Joint connector-1
C1 M3		To (E103)	E3 (M38)	In-vehicle sensor (With auto A/C)	G3 (M80)	W/20	Joint connector-2
D1 M4		To (D2) (Without ESP)	E5 (M39)	Fan resistor (Without auto A/C)	C1 ★ (M81)	L/20	Joint connector-3
G4 M5		W/12	C2 (M40)	Fan control amp. (With auto A/C)	C1 (M82)	L/20	Joint connector-4
G4 M6		W/10	E1 (M41)	Fan control amp. (With auto A/C)	B2 (M83)	G/Y/6	To (D41) (With ESP)
C3 M7		W/12	E1 (M42)	Fan control amp. (With auto A/C)	C3 (M84)	W/12	To (D42) (With ESP)
C3 M8		W/10	E1 (M43)	Intake door motor (With auto A/C)	D4 (M85)	W/6	Door lock/unlock switch (With ESP)
G4 M9		W/24	E1 (M44)	Intake sensor (With auto A/C)			
G5 M10		W/10	E4 (M45)	Thermal control amplifier	G4 (M86)	G/Y/6	To (D42) (With ESP)
G3 M11		W/4	E4 (M45)	(With manual A/C)	G4 (M87)	W/12	To (D13) (With ESP)
G3 M13		W/10	E1 (M46)	Blower motor (Without A/C)	F4 (M88)	W/6	To (B80) (With ESP)
G3 M14		GY/6	F1 (M47)	Blower motor (With A/C)			
F3 ★ M16		—					
F4 M17		W/16	E1 (M48)	BCM (Body control module)			
D1 M18		W/2	D1 (M49)	BCM (Body control module)	G2 ★ (M20)	W/10	To (M71)
F2 ★ M19		—	D1 (M50)	BCM (Body control module)	G3 ★ (M202)	B/2	Stop lamp switch (With M)
F2 ★ M20		—	D4 (M51)	Intelligent Key unit	G3 ★ (M203)	W/4	Stop lamp switch (With A)
F2 M21		—	D4 (M51)	(With Intelligent Key system)	F4 ★ (M204)	B/6	Accelerator pedal position sensor
F5 ★ M22		W/40	E4 (M52)	Door lock/unlock relay (With Intelligent Key system)			
F2 M23		W/6					
F2 M24		W/1	C2 (M53)	Front passenger air bag module			
F1 M25		B/1	G2 (M54)	W/8	To (R1)		
C2 M26		—/20	B2 (M55)	W/12	To (D32) (Without ESP)		
C2 M27		B/16	B3 (M56)	W/10	To (D31) (Without ESP)		
C2 M28		W/12	Drive computer	G4 (M57)	W/1	Towbar kit	
E4 (M29)		GY/8	(With drive computer)	C3 (M58)	W/15	Heater control panel (Without auto A/C)	
E4 (M30)		Y/6	Combination switch (Spiral cable) (Steering switch)	D3 (M59)	B/2	Power socket	
E3 M31		W/4	(With Intelligent Key system)	E5 (M60)	—	Body ground	
F5 M32		W/16	Combination switch (Spiral cable) (Air bag)	D3 (M61)	W/4	Hazard switch	
G5 M33		W/2	Steering lock unit	D3 (M62)	W/2	Ashtray illumination	
E3 M34		GY/6	(Without Intelligent Key system)	D3 (M63)	B/18	A/C auto amp. (With auto A/C)	★ : Be sure to connect and lock the connector securely after repair work.
E4 (M35)		GY/4	Key switch and ignition knob switch (With Intelligent Key system)	D4 (M66)	B/6	Mode door motor (With auto A/C)	Failure to do so may cause the ECM to diagnostic trouble codes.
F4 (M36)		—/4	NATS antenna amp. (With Intelligent Key system)	B4 (M67)	B/1	Parking brake switch	Do not disconnect these connectors except in the case of working according to the WORK FLOW of TROUBLE DIAGNOSIS in EC and AT sections.
				C3 (M68)	W/6	A/T device (With A/T)	
				B4 (M69)	Y/20	Air bag diagnosis sensor unit	
				G1 ★ (M71)	W/10	To (M20)	
				G2 (M72)	W/6	After market alarm unit (Option connector)	
							(Without Intelligent Key system)

HARNESS

SMA for VIN >SJN**AK12U1309269

SMA for VIN >SJN**AK12U1288860

ENGINE ROOM HARNESS/CR ENGINE MODELS



HARNESS

G3	E1	-	Fuse, fusible link and relay box	C3 ★ (E40)	-	Body ground
B1	E2	W/5	Daytime light relay (With daytime light system)	D3 (E41)	B/3	Headlamp RH (With daytime light system)
F3 ★ (E3)	E4	B/2	Cooling fan motor (With A/C)	D3 (E42)	B/3	Headlamp RH (Without daytime light system)
F3 ★ (E4)	-/2		Cooling fan motor (Without A/C)	D1, D2 (E43)	GY/2	Brake fluid level switch
F3 ★ (E5)	B/2		Resistor (With A/C)	D2 (E44)	GY/6	Front wiper motor
G3 ★ (E6)	E6	GY/2	Dropping resistor (With A/T)	D3, E3 (E45)	B/26	ABS actuator and electric unit (Control unit) (Without ESP)
G4	E7	B/2	Front fog lamp LH (With front fog lamp)	D2, E2 (E46)	-	Body ground (Without ESP)
G3	E8	GY/2	Front turn signal lamp LH	E3, F3 (E47)	SMJ	ABS actuator and electric unit (Control unit) (With ESP)
E3	E9	B/1	After market alarm unit (Hood switch) (RHD models)	D2, E2 (E48)	-	Body ground (With ESP)
E5	E10	B/2	IPDM E/R (Intelligent power distribution module engine room)	F2 ★ (E49)	SMJ	ECM
E5 ★ (E11)	B/6		IPDM E/R (Intelligent power distribution module engine room)	F2 ★ (E50)	SMJ	To (F1)
F5 ★ (E12)	W/6		IPDM E/R (Intelligent power distribution module engine room)	B1 (E51)	W/3	Horn relay
F5 ★ (E13)	BR/12		IPDM E/R (Intelligent power distribution module engine room)	G4 (E52)	B/2	Outside air temperature sensor (With drive computer)
F5 ★ (E14)	W/16		IPDM E/R (Intelligent power distribution module engine room)	E1 ★ (E101)	SMJ	To (M1)
G5	E15	BR/8	IPDM E/R (Intelligent power distribution module engine room)	E1 (E102)	Y/4	To (M2) (Without ESP)
G5 ★ (E16)	W/12		IPDM E/R (Intelligent power distribution module engine room)	F1 (E103)	B/2	To (M3)
G5 ★ (E17)	W/8		IPDM E/R (Intelligent power distribution module engine room)	E1 (E104)	W/2	To (M4) (With headlamp washer and without ESP)
G2	E18	BR/2	Fusible link holder	F1 ★ (E105)	W/24	TCM (With A/T)
F2	E19	GY/2	Fusible link holder	F1 ★ (E106)	GY/24	TCM (With A/T)
F1	E20	B/3	Headlamp aiming motor LH	E1 ★ (E107)	B/6	Accelerator pedal position sensor (LHD models)
G2	E21	B/3	Headlamp LH	D1 ★ (E108)	B/2	Stop lamp switch (LHD models with M/T)
G1	E22	B/2	Parking lamp LH	D1 ★ (E109)	W/4	Stop lamp switch (LHD models with A/T)
G2	E23	B/2	Front wheel sensor LH	F1 (E112)	W/16	To (B59) (With ESP)
F1	E24	W/2	Side turn signal lamp LH	E1 (E113)	W/5	Headlamp washer relay (With headlamp washer and with ESP)
G2 ★ (E25)	-		Body ground			
G2 ★ (E26)	-		Body ground			
E3	E27	Y/2	Crash zone sensor			
E4	E28	B/3	Refrigerant pressure sensor (With A/C)			
F4	E29	B/2	Ambient sensor (With A/C)			
G4	E30	B/1	Horn (-)			
F4	E31	B/1	Horn (+)			
D4	E32	GY/2	Front turn signal lamp RH			
E5	E33	-/2	Headlamp washer motor (With headlamp washer)			
E4	E34	B/2	Front fog lamp RH (With front fog lamp)			
B2	E35	-/2	Side turn signal lamp RH			
D5	E36	B/2	Washer motor			
D2	E37	B/2	Parking lamp RH			
C3	E38	B/2	Front wheel sensor RH			
D3	E39	B/3	Headlamp aiming motor RH			

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

MKWA1857E


HARNESS

SMA for VIN >SJN**AK12U1309269

ENGINE ROOM HARNESS/K9K ENGINE MODELS

SMA for VIN >SJN**AK12U1288860

SMA for VIN >SJN**AK12U1337130



HARNESS

MKWA1859E

HARNESS

SMA for VIN >SJN**AK12U1309269

SMA for VIN >SJN**AK12U1288860

ENGINE CONTROL HARNESS/CR ENGINE MODELS

SMA for VIN >SJN**AK12U1337130



MKWA1476E

HARNESS

E2 ★ F1	SMJ	: To E60
F2 ★ F2	SMJ	: ECM
F2 F3	-	: Fusible link holder
F2 F4	-	: Fusible link holder
D2 F6	-	: Starter motor (Except for cold area)
D2 F7	-	: Starter motor (For cold area)
E2 F8	-	: Starter motor (Except for cold area)
E3 F9	B/1	: Starter motor (For cold area)
F3 ★ F10	G/3	: Park/neutral position switch (With M/T)
F2 ★ F11	BR/3	: Revolution sensor (With A/T)
F4 ★ F12	B/10	: Park/neutral position switch (With A/T)
G4 ★ F13	B/8	: Terminal cord assembly (With A/T)
E2 ★ F14	B/3	: Camshaft position sensor
E2 ★ F15	-	: Engine ground
D2 ★ F16	GY/4	: Manifold absolute pressure sensor
E2 ★ F17	L/2	: EVAP canister purge volume control solenoid valve
C3 ★ F18	GY/2	: Injector No. 1
D3 ★ F19	GY/2	: Injector No. 2
D2 ★ F20	GY/2	: Injector No. 3
E2 ★ F21	GY/2	: Injector No. 4
D3 ★ F22	G/2	: Intake valve timing control solenoid valve
E2 ★ F23	GY/2	: Engine coolant temperature sensor
E4 ★ F24	G/4	: Heated oxygen sensor 2
D3 F25	B/1	: Oil pressure switch
C3 F26	W/2	: Condenser
D3 ★ F27	B/2	: Knock sensor
D5 F28	B/1	: Compressor (With A/C)
E4 F29	GY/2	: Alternator
E4 F30	-	: Alternator
E4 F31	-	: Alternator (E)
D4 F32	-	: Body ground
D4 F33	GY/3	: Ignition coil No. 1
E3 F34	GY/3	: Ignition coil No. 2
E3 F35	GY/3	: Ignition coil No. 3
E3 F36	GY/3	: Ignition coil No. 4
E3 ★ F37	G/4	: Heated oxygen sensor 1
E2 ★ F38	G/3	: Crankshaft position sensor
C2 ★ F39	B/6	: Electric throttle control actuator

MKWA1860E

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


HARNESS

SMA for VIN > SJN**AK12U1309269

ENGINE CONTROL HARNESS/K9K ENGINE MODELS

SMA for VIN > SJN**AK12U1288860

SMA for VIN > SJN**AK12U1337130



MKWA3241E

HARNESS

G2	SMJ	:	To (E60)
E2	(F102)	B/8	Glow relay
F3	(F103)	GY/1	To (E62)
E2	(F104)	-	Fusible link holder
C3	(F105)	-	Starter motor
C3	(F106)	-	Starter motor
C3	(F107)	G/3	Park/neutral position switch
D2	(F108)	-/2	Charge air temperature sensor (Without intercooler)
D2	(F109)	-/2	Intake air temperature sensor
D3	(F110)	B/2	Crankshaft position sensor (POS)
D2	(F111)	-/4	Engine coolant temperature sensor
E2	(F112)	-/4	Charge air pressure sensor (With intercooler)
B2	(F113)	-/6	EGR volume control solenoid valve
D2	(F114)	-/3	Charge air pressure sensor (Without intercooler)
C2	(F115)	-/2	Fuel injector No. 1
C2	(F116)	-/2	Fuel injector No. 2
B2	(F117)	-/2	Fuel injector No. 3
B2	(F118)	-/2	Fuel injector No. 4
C2	(F119)	B/1	Glow plug No. 1
C2	(F120)	B/1	Glow plug No. 2
C2	(F121)	B/1	Glow plug No. 3
B2	(F122)	B/1	Glow plug No. 4
C3	(F123)	B/3	Common rail fuel pressure sensor
C4	(F124)	W/1	Oil pressure switch
C3	(F125)	B/2	Knock sensor (Accelerometer)
C4	(F126)	B/2	Oil level sensor
B4	(F127)	-	Alternator (B)
B3	(F128)	B/2	Alternator (S), (L)
B4	(F129)	GY/2	Compressor (With A/C)
A3	(F130)	B/3	Camshaft sensor
B3	(F131)	BR/2	Fuel flow actuator
B2	(F132)	G/2	Fuel temperature sensor
F2	(F133)	-	Body ground
F2	(F134)	SMJ	ECM


MKWA1862E

A
B
C
D
E
F
G
H
I
J
M

PG

HARNESS

BODY HARNESS





MKWA1863E

HARNESS

G2 B1	W/10	To (M10)	B/1	Luggage room lamp (+)
G2 B2	W/24	To (M9)	B/1	Luggage room lamp
D1 B3	W/10	To (M8)	(B42)	RH side curtain air bag module (With curtain air bag)
D2 B4	W/12	To (M7)	(B43)	LH side curtain air bag module (With curtain air bag)
E4 B5	W/2	Seat belt buckle switch RH	(B44)	Body ground
E2 B6	W/3	Heated seat RH (With heated seat)	(B45)	High-mounted stop lamp
E3 B7	BR/2	Front RH side air bag module	(B46)	Front RH seat belt pre-tensioner (With 3 doors)
E2 B8	Y/12	Air bag diagnosis sensor unit	(B47)	Front LH seat belt pre-tensioner (With 3 doors)
D2 B9	Y/12	Air bag diagnosis sensor unit	(B48)	Heated seat switch RH (With heated seat)
CC2 B10	W/2	Seat belt buckle switch LH	(B49)	Heated seat switch LH (With heated seat)
C3 B11	W/3	Heated seat LH (With heated seat)	(B50)	Door lock/unlock switch (Without ESP)
D2 B12	BR/2	Front LH side air bag module	(B51)	To (E112)
F2 B13	Y/2	RH side air bag (satellite) sensor	(B52)	To (M88)
F1 B14	W/6	To (D81)	(B53)	Yaw rate/side G sensor (With ESP)
F3 B15	B/2	Front RH seat belt pre-tensioner (With 5 doors)	(B54)	
E2 B16	W/3	Front door switch RH	(B55)	
F3 B17	—	Body ground	(B56)	
C22 B18	—	Body ground	(B57)	
C22 B19	Y/2	LH side air bag (satellite) sensor	(B58)	
C22 B20	W/6	To (D61)	(B59)	
B21 B22	B/2	Front LH seat belt pre-tensioner (With 5 doors)	(B60)	
C22 B23	W/3	Front door switch LH	(B61)	
C22 B24	—	Body ground	(B62)	
D3 B25	GY/2	Inside key antenna (Center console) (With Intelligent Key system)	(B63)	
D3 B28	GY/4	Fuel level sensor unit and fuel pump	(B64)	
D3 B29	BR/2	Inside key antenna (Luggage room) (With Intelligent Key system)	(B65)	
F3 B30	W/1	Rear door switch RH (With 5 doors)	(B66)	
B21 B31	W/1	Rear door switch LH (With 5 doors)	(B67)	
E4 B32	BR/2	Rear door speaker RH (3 doors with 6 speakers)	(B68)	
B33 B34	BR/2	Rear door speaker LH (3 doors with 6 speakers)	(B69)	
E3 B35	B/2	Rear wheel sensor RH	(B70)	
B33 B36	B/2	Rear wheel sensor LH	(B71)	
D4 A2	B/6	Rear combination lamp RH	(B72)	
B37 C3	B/6	Rear combination lamp LH	(B73)	
B38 B44	B/2	License plate lamp	(B74)	Outside antenna (Back door) (With Intelligent Key system)

HARNESS

(B50)	B/1	: Rear window defogger (+)
(B51)	-	: Body ground
(B52)	W/2	: External back door release switch
(B53)	W/3	: Rear wiper motor
(B54)	BR/2	: Door request switch (Back door) (With Intelligent Key system)
(B55)	W/4	: Back door release actuator
(B201)	B/1	: Rear window defogger (-)
(B202)	-	: Body ground



MKWA1482E

HARNESS

ROOM LAMP HARNESS

SMA for VIN >SJN**AK12U1288860

SMA for VIN >SJN**AK12U1309269

SMA for VIN >SJN**AK12U1337130

A

B

C

D

E

F

G

H


I

J

PG

L

M



- (R1) W/8 : To **(W54)**
- (R2) W/3 : Interior room lamp
- (R3) B/3 : Rain sensor (With rain sensor)
- (R4) W/4 : Sunroof switch (With sunroof)
- (R5) GY/10 : Sunroof motor assembly (With sunroof)

MKWA1483E


HARNESS

FRONT DOOR HARNESS LH SIDE/LHD MODELS

SMA for VIN >SJN**AK12U1288860

SMA for VIN >SJN**AK12U1309269

SMA for VIN >SJN**AK12U1337130



- (D1) W/10 : To (M6) (Without ESP)
- (D2) W/12 : To (M5) (Without ESP)
- (D3) GY/6 : Door mirror actuator (Driver side)
- (D4) BR/2 : Tweeter LH (With 6 speakers)
- (D5) GY/2 : Front power window motor (Driver side)
- (D6) W/2 : Front door speaker LH
- (D7) W/16 : Power window main switch
- (D8) BR/2 : Intelligent Key warning buzzer (With Intelligent Key system)
- (D9) B/6 : Door lock actuator (Driver side)
- (D10) GY/2 : Door request switch (Driver side) (With Intelligent Key system)
- (D11) W/2 : Outside antenna (Driver side) (With Intelligent Key system)
- (D12) GY/6 : To (M86) (With ESP)
- (D13) W/12 : To (M87) (With ESP)

HARNESS

FRONT DOOR HARNESS LH SIDE/RHD MODELS

SMA for VIN >SJN**AK12U1288860

A

SMA for VIN >SJN**AK12U1309269

B

SMA for VIN >SJN**AK12U1337130

C

D

E

F

G

H


I

J

PG

L

M



- (D31) W/10 : To (M56) (Without ESP)
- (D32) W/12 : To (M55) (Without ESP)
- (D33) GY/6 : Door mirror actuator (Passenger side)
- (D34) BR/2 : Tweeter LH (With 6 speakers)
- (D35) GY/2 : Front power window motor (Passenger side)
- (D36) W/2 : Front door speaker LH
- (D37) W/8 : Front power window switch (Passenger side)
- (D38) B/6 : Door lock actuator (Passenger side)
- (D39) GY/2 : Door request switch (Passenger side) (With Intelligent Key system)
- (D40) W/2 : Outside antenna (Passenger side) (With Intelligent Key system)
- (D41) GY/6 : To (M83) (With ESP)
- (D42) W/12 : To (M84) (With ESP)


HARNESS

FRONT DOOR HARNESS RH SIDE/LHD MODELS

SMA for VIN >SJN**AK12U1288860

SMA for VIN >SJN**AK12U1309269

SMA for VIN >SJN**AK12U1337130



- [D31] W/10 : To [M56] (Without ESP)
- [D32] W/12 : To [M55] (Without ESP)
- [D33] GY/6 : Door mirror actuator (Passenger side)
- [D34] BR/2 : Tweeter RH (With 6 speakers)
- [D35] GY/2 : Front power window motor (Passenger side)
- [D36] W/2 : Front door speaker RH
- [D37] W/8 : Front power window switch (Passenger side)
- [D38] B/6 : Door lock actuator (Passenger side)
- [D39] GY/2 : Door request switch (Passenger side) (With Intelligent Key system)
- [D40] W/2 : Outside antenna (Passenger side) (With Intelligent Key system)
- [D41] GY/6 : To [M83] (With ESP)
- [D42] W/12 : To [M84] (With ESP)


Harness

FRONT DOOR HARNESS RH SIDE/RHD MODELS

SMA for VIN >SJN**AK12U1288860

SMA for VIN >SJN**AK12U1309269

SMA for VIN >SJN**AK12U1337130



- D1** W/10 : To **M6** (Without ESP)
- D2** W/12 : To **M5** (Without ESP)
- D3** GY/6 : Door mirror actuator (Driver side)
- D4** BR/2 : Tweeter RH (With 6 speakers)
- D5** GY/2 : Front power window motor (Driver side)
- D6** W/2 : Front door speaker RH
- D7** W/16 : Power window main switch
- D8** BR/2 : Intelligent Key warning buzzer (With Intelligent Key system)
- D9** B/6 : Door lock actuator (Driver side)
- D10** GY/2 : Door request switch (Driver side) (With Intelligent Key system)
- D11** W/2 : Outside antenna (Driver side) (With Intelligent Key system)
- D12** GY/6 : To **M86** (With ESP)
- D13** W/12 : To **M87** (With ESP)


HARNESS

REAR DOOR HARNESS LH

SMA for VIN >SJN**AK12U1288860

SMA for VIN >SJN**AK12U1309269

SMA for VIN >SJN**AK12U1337130



D61 W/6 : To **B20**

D62 W/2 : Rear door speaker LH (With 6 speakers)

D63 B/6 : Rear door lock actuator LH

HARNESS

REAR DOOR HARNESS RH

SMA for VIN >SJN**AK12U1288860

SMA for VIN >SJN**AK12U1309269

A

SMA for VIN >SJN**AK12U1337130

B

C

D

E

F


G

H

I

J

PG



D81 W/6 : To B14

D82 W/2 : Rear door speaker RH (With 6 speakers)

D83 B/6 : Rear door lock actuator RH

L

M

HARNESS

Wiring Diagram Codes (Cell Codes)

EKS0079C

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Gear Function
2NDSIG	AT	A/T 2ND Gear Function
3RDSIG	AT	A/T 3RD Gear Function
4THSIG	AT	A/T 4TH Gear Function
A/C	ATC	Auto Air Conditioner
A/C	MTC	Manual Air Conditioner
A/WIP	WW	Front Wiper and Washer System (With Rain Sensor)
ABS	BRC	Anti-lock Brake System
AP/SEN	EC	Manifold Absolute Pressure Sensor
APPS	EC	Accelerator Pedal Position Sensor
APPS1	EC	Accelerator Pedal Position Sensor 1
APPS2	EC	Accelerator Pedal Position Sensor 2
APPS3	EC	Accelerator Pedal Position Sensor
AUDIO	AV	Audio
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Source
BACK/L	LT	Back-up Lamp
BRK/SW	EC	Brake Switch
BTS	EC	Turbocharger Air Temperature Sensor
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Power Socket
CKPS	EC	Crankshaft Position Sensor
CMPS	EC	Crankshaft Position Sensor
COMBSW	LT	Combination Switch
COOL/F	EC	Cooling System
CRFPS	EC	Common Rail Fuel Pressure Sensor
D/COMP	DI	Drive Computer
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Headlamp - With Daytime Light System
ECM/PW	EC	ECM Power Supply
ECTS	EC	Engine Coolant Temperature Sensor
EGRC/V	EC	EGR Control System
ENGSS	AT	Engine Speed Signal
EPS	STC	Electric Power Steering System
ESP	BRC	Electronic Stability Program System
ETC1	EC	Electrical Throttle Control Function
ETC2	EC	Electrical Throttle Control Motor Relay

HARNESS

Code	Section	Wiring Diagram Name
ETC3	EC	Electrical Throttle Control Motor
F/FOG	LT	Front Fog Lamp
F/PUMP	EC	Fuel Pump
FRO2	EC	Heated Oxygen Sensor 1
FTS	AT	A/T Fluid Temperature Sensor
FTS	EC	Fuel Temperature Sensor
FUEL	EC	Fuel Injection System Function
GLOW	EC	Glow Control System
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp
H/SEAT	SE	Heated Seat
HEATER	MTC	Heater
HLC	WW	Headlamp Washer
HO2S1	EC	Heated Oxygen Sensor 1
HO2S1H	EC	Heated Oxygen Sensor 1 Heater
HO2S2	EC	Heated Oxygen Sensor 2
HO2S2H	EC	Heated Oxygen Sensor 2 Heater
HORN	WW	Horn
I/KEY	BL	Intelligent Key System
IATS	EC	Intake Air Temperature Sensor
IATSEN	EC	Intake Air Temperature Sensor
IGNSYS	EC	Ignition Signal
ILL	LT	Illumination
IMV/D	EC	Fuel Flow Actuator
INJECT	EC	Injector
INT/L	LT	Interior and Luggage Room Lamps
IVC	EC	Intake Valve Timing Control Solenoid Valve
IVC/V	EC	Intake Valve Timing Control Solenoid Valve
KS	EC	Knock Sensor
LPSV	AT	Line Pressure Solenoid Valve
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
METER	DI	Combination Meters
MIL/DL	EC	Malfunction Indicator, Data Link Connector for CONSULT-II
MIRROR	GW	Door Mirror
MULTI	BL	Multi-remote Control System
NATS	BL	NATS (Nissan Anti-Theft System)
NAVI	AV	Audio and Navigation System
NONDTC	AT	NON-detective Items
OVRCSV	AT	Overrun Clutch Solenoid Valve
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PNP/SW	AT	Park/Neutral Position (PNP) Switch
PNP/SW	EC	Park/Neutral Position (PNP) Switch

A
B
C
D
E
F
G
H
I
J

PG

L
M

HARNESS

Code	Section	Wiring Diagram Name
PNPSW	EC	Park/Neutral Position (PNP) Switch
POS	EC	Crankshaft Position Sensor (POS)
POWER	PG	Power Supply Routing Circuit
PRGVLV	EC	EVAP Canister Purge Volume Control Solenoid Valve
PRWIRE	BL	After Market Alarm - Prewire
PTC/H	MTC	PTC Heater
R/FOG	LT	Rear Fog Lamp
RP/SEN	EC	Refrigerant Pressure Sensor
RRO2	EC	Heated Oxygen Sensor 2
S/LOCK	BL	Power Door Lock-Super Lock
SEN/PW	EC	Electric Throttle Control Actuator (Throttle Position Sensor)
SHIFT	AT	A/T Shift Lock System
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	LT	Stop Lamp
TAIL/L	LT	Parking, License Plate and Tail Lamps
TCBST	EC	TC Boost Pressure Sensor
TCV	AT	Torque Converter Clutch Solenoid Valve
TPS	AT	Throttle Position Sensor
TPS1	EC	Electric Throttle Control Actuator (Throttle Position Sensor 1)
TPS2	EC	Electric Throttle Control Actuator (Throttle Position Sensor 2)
TPS3	EC	Electric Throttle Control Actuator (Throttle Position Sensor 3)
TURN	LT	Turn Signal and Hazard Warning Lamps
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Senor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	DI	Warning Lamps
WINDOW	GW	Power Window System
WIP/R	WW	Rear Wiper and Washer System
WIPER	WW	Front Wiper and Washer System

ELECTRICAL UNITS LOCATION


ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location ENGINE COMPARTMENT

EKS0079D



A
B
C
D
E
F
G
H
I
J



IPDM E/R (Intelligent power distribution module engine room)

Fuse, fusible link and relay box


View with headlamp LH removed




MKWA1869E

ELECTRICAL UNITS LOCATION

Fusible link box (With diesel engine)




PTC relay box (With PTC heater)




MKWA1870E

ELECTRICAL UNITS LOCATION

PASSENGER COMPARTMENT



ELECTRICAL UNITS LOCATION



MKWA1872E

HARNESS CONNECTOR

HARNESS CONNECTOR

PFP:00011

Description

EKS0079E

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]



JOINT CONNECTOR (J/C)

JOINT CONNECTOR (J/C)

Terminal Arrangement

PFP:B4341

EKS00EOL

A

B

C

D

E

F

G

H







I

J

PG

L

M



ELECTRICAL UNITS

ELECTRICAL UNITS


PFP:00011

Terminal Arrangement

EKS0079F


ECM

E49 : G




(Black)

F2 : G




E61 : D




(Black)

F134 : D




TCM (TRANSMISSION CONTROL MODULE)

E105



(White)


E106



(Gray)


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

E45 : OE



(Black)

E47 : ES




(Black)




BCM (BODY CONTROL MODULE)

M48




(White)

M49



(White)


M50



(Black)


A/C AUTO AMP.

M63



(Black)

M64



(White)

G

D

ES

OE

: With gasoline engine

: With diesel engine

: With ESP

: Without ESP

MKWA1873E



SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

Terminal Arrangement

PFP:B4341

EKS007XZ



: With gasoline engine

: With diesel engine

MKWA1515E

STANDARDIZED RELAY

STANDARDIZED RELAY


PFP:00011

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

EKS0079G

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H


TYPE OF STANDARDIZED RELAYS

1M 1 Make

2M 2 Make















1T 1 Transfer

1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M+1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

A
B
C
D
E
F
G
H
I
J

PG
L
M


FUSE BLOCK - JUNCTION BOX (J/B)

FUSE BLOCK - JUNCTION BOX (J/B)

PFP:24350

Terminal Arrangement

EKS0079H



MKWA1516E


FUSE AND FUSIBLE LINK BOX

FUSE AND FUSIBLE LINK BOX

Terminal Arrangement


PFP:24381

EKS00791



A
B
C
D
E
F
G
H
I
J

PG



G : With gasoline engine

D : With diesel engine

MKWA1874E

FUSE AND FUSIBLE LINK BOX
