

SECTION SC

STARTING & CHARGING SYSTEM

CONTENTS

PRECAUTIONS	3	DARK CURRENT INSPECTION	24
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II	25
Wiring Diagrams and Trouble Diagnosis	3	Trouble Diagnoses (K9K Engine Models)	26
PREPARATION	4	DIAGNOSIS PROCEDURE	26
Special Service Tools	4	PRE-DIAGNOSIS INSPECTION	26
BATTERY	5	DIAGNOSIS CHART BY SYMPTOM	26
How to Handle Battery	5	INSPECTION FLOW BY CHARGE WARNING LAMP	26
METHODS OF PREVENTING OVER-DISCHARGE	5	CHARGE WARNING LAMP LINE INSPECTION	27
CHECKING ELECTROLYTE LEVEL	5	VOLTAGE DETECTION LINE AND CHARGE WARNING LAMP INSPECTION	28
SPECIFIC GRAVITY CHECK	6	INSPECTION OF INSUFFICIENT ALTERNATOR POWER GENERATION	29
Battery Test and Charging Chart	7	INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION	30
CHART I	7	DARK CURRENT INSPECTION	31
CHART II	8	OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II	33
A: SLOW CHARGE	9	Removal and Installation (CR Engine Models)	34
B: STANDARD CHARGE	11	REMOVAL	34
C: QUICK CHARGE	12	INSTALLATION	34
Removal and Installation	14	Removal and Installation (K9K Engine Models)	35
CHARGING SYSTEM	15	REMOVAL	35
System Description (CR Engine Models)	15	INSTALLATION	35
System Description (K9K Engine Models)	15	Disassembly	36
Wiring Diagram — CHARGE — (CR Engine Models)	16	REAR COVER	36
Wiring Diagram — CHARGE — (K9K Engine Models)	17	REAR BEARING	36
Trouble Diagnoses (CR Engine Models)	19	Inspection	36
DIAGNOSIS PROCEDURE	19	ROTOR CHECK	36
PRE-DIAGNOSIS INSPECTION	19	BRUSH CHECK	36
DIAGNOSIS CHART BY SYMPTOM	19	STATOR CHECK	37
INSPECTION FLOW BY CHARGE WARNING LAMP	19	Assembly	37
CHARGE WARNING LAMP LINE INSPECTION	20	RING FITTING IN REAR BEARING	37
VOLTAGE DETECTION LINE AND CHARGE WARNING LAMP INSPECTION	21	REAR COVER INSTALLATION	37
WIRING LAYOUT	23	STARTING SYSTEM	39
INSPECTION OF INSUFFICIENT ALTERNATOR POWER GENERATION	23	System Description	39
INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION	23	M/T MODELS	39
POWER GENERATION	23	A/T MODELS	39

Wiring Diagram—START—(K9K Engine Models)..	42	PINION/CLUTCH CHECK	49
Trouble Diagnoses	44	BRUSH CHECK	49
Removal and Installation (CR Engine Models)	45	YOKE CHECK	51
REMOVAL	45	ARMATURE CHECK	51
INSTALLATION	45	Assembly	52
Removal and Installation (K9K Engine Models)	45	PINION PROTRUSION LENGTH ADJUST- MENT	52
REMOVAL	45	SERVICE DATA AND SPECIFICATIONS (SDS)	54
INSTALLATION	45	Battery	54
Disassembly and Assembly	46	Starter	54
Inspection	49	Alternator	54
MAGNETIC SWITCH CHECK	49		

PRECAUTIONS

PRECAUTIONS

PFP:00011

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EKS007Z9

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Wiring Diagrams and Trouble Diagnosis

EKS007ZA

When you read wiring diagrams, refer to the followings:

- [GI-14, "How to Read Wiring Diagrams"](#) in GI section
- [PG-4, "POWER SUPPLY ROUTING"](#) for power distribution circuit in PG section

When you perform trouble diagnosis, refer to the followings:

- [GI-10, "How to Follow Trouble Diagnoses"](#) in GI section
- [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section

A

B

C

D

E

F

G

H

I

J

SC

L

M



PREPARATION

PREPARATION

PFP:00002

Special Service Tools

EKS007ZY

Tool name	Description
CONSULT-II unit, and Program card AED02E	 PBIA3527J
CONSULT-II CONVERTER	 PBIA3526J
Current measurement probe for CONSULT-II EG1187 1900	 MKIA0065E

BATTERY

PFP:00011

How to Handle Battery

EKS0072B


CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.


METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".




- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)



- Check the charge condition of the battery.

Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.




CHECKING ELECTROLYTE LEVEL

WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

BATTERY

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




Sulphation

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.

To determine if a battery has been "sulphated", note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.





SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.
2. Convert into specific gravity at 20°C (68°F).

Example:

- When electrolyte temperature is 35°C (95°F) and specific gravity of electrolyte is 1.230, converted specific gravity at 20°C (68°F) is 1.240.
- When electrolyte temperature is 0°C (32°F) and specific gravity of electrolyte is 1.210, converted specific gravity at 20°C (68°F) is 1.196.




BATTERY

Battery Test and Charging Chart CHART I

EKS007ZC

A
B
C
D
E
F
G
H
I
J
SC
L
M



SEL754W

*1. [SC-6, "SPECIFIC GRAVITY CHECK"](#)

*2. [SC-8, "CHART II"](#)


*3. [SC-9, "A: SLOW CHARGE"](#)

*4. [SC-11, "B: STANDARD CHARGE"](#)

*5. [SC-12, "C: QUICK CHARGE"](#)

BATTERY

CHART II



*: [SC-7, "CHART I"](#)

- Check battery type and determine the specified current using the following table.


Fig. 1 Discharging Current (Load Tester)

Type	Current (A)
28B19R(L)	90
34B19R(L)	99
46B24R(L)	135
55B24R(L)	135
50D23R(L)	150
55D23R(L)	180
65D26R(L)	195
80D26R(L)	195
75D31R(L)	210
063 [YUASA type code]	210
95D31R(L)	240
115D31R(L)	240
025 [YUASA type code]	240
065 [YUASA type code]	255
027 [YUASA type code]	285
075 [YUASA type code]	300
110D26R(L)	300
95E41R(L)	300
067 [YUASA type code]	325

BATTERY

Type	Current (A)
130E41R(L)	330
096 [YUASA type code]	375
096 [YUASA type code]	375
010S [YUASA type code]	360
LB1 FCM 047 620 [FULMAN type code]	420
LB2 FCM 055 622 [FULMAN type code]	510
LB2 FCM 050 622 [FULMAN type code]	600

A: SLOW CHARGE



*1. [SC-6, "SPECIFIC GRAVITY CHECK"](#)

*2. [SC-8, "CHART II"](#)


BATTERY

Fig. 2 Initial Charging Current Setting (Slow Charge)

CONVERTED SPECIFIC GRAVITY			BATTERY TYPE																
Below 1.100	BL1 FCM 047 620 [FULMEN type code]	LB2 FCM 050 622 [FULMEN type code]	LB2 FCM 055 622 [FULMEN type code]	28B19R(L)	34B19R(L)	46B24R(L)	55B24R(L)	50D23R(L)	55D23R(L)	025 [YUASA type code]	027 [YUASA type code]	65D26R(L)	80D26R(L)	063 [YUASA type code]					
2.55 (A)	2.75 (A)	3.0 (A)	4.0 (A)	5.0 (A)						7.0 (A)		8.0 (A)		8.5 (A)	9.0 (A)	10.0 (A)	11.0 (A)	14.0 (A)	130E41R(L)

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary.

Fig. 3 Additional Charge (Slow Charge)



SEL757W


*: [SC-8, "CHART II"](#)

CAUTION:

- Set charging current to value specified in Fig. 2. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY

B: STANDARD CHARGE



SEL758W

*1. SC-6. "SPECIFIC GRAVITY CHECK"


*2. SC-8, "CHART II"

Fig. 4 Initial Charging Current Setting (Standard Charge)

BATTERY

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary.

Fig. 5 Additional Charge (Standard Charge)




*. [SC-8, "CHART II"](#)

CAUTION:

- Do not use standard charge method on a battery whose specific gravity is less than 1.100.
- Set charging current to value specified in Fig. 4. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

C: QUICK CHARGE



*. [SC-8, "CHART II"](#)

BATTERY

Fig. 6 Initial Charging Current Setting and Charging Time (Quick Charge)

CONVERTED SPECIFIC GRAVITY	CURRENT [A]		BATTERY TYPE	CHARGING TIME
	10 (A)	15 (A)		
Above 1.220	1.190 - 1.220	1.160 - 1.190	1.130 - 1.160	1.100 - 1.130
				2.5 hours
				2.0 hours
				1.5 hours
				1.0 hours
				0.75 hours (45 min.)

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary.

CAUTION:

- Do not use quick charge method on a battery whose specific gravity is less than 1.100.
- Set initial charging current to value specified in Fig. 6. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- Be careful of a rise in battery temperature because a large current flow is required during quick-charge operation.

If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY

- Do not exceed the charging time specified in Fig. 6, because charging battery over the charging time can cause deterioration of the battery.

Removal and Installation

EKS007ZD

Observe the following to ensure proper servicing.

CAUTION:


- When removing, remove negative terminal first. But for installation, install positive terminal first.
- Tighten parts to the specified torque shown below.

Battery bracket mounting bolt:

 : 12.7 - 15.7 N·m (1.3 - 1.6 kg-m, 10 - 11 ft-lb)

Battery cable tightening nut:

 : 3.0 - 5.0 N·m (0.31 - 0.51 kg-m, 27 - 44 in-lb)



CHARGING SYSTEM

PFP:00011

System Description (CR Engine Models)

EKS0072E

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal 4 (S) through:

- 10A fuse [No. 26, located in the fuse block (J/B)].

Terminal B supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal 4 (S) detecting the input voltage. The charging circuit is protected by the 100A link.

The alternator is grounded to the body.

With the ignition switch in the ON or START position, power is supplied

- 10A fuse [No. 2, located in the fuse block (J/B)]
- to combination meter terminal 28 for the charge warning lamp.

Ground is supplied

- to terminal 38 of the combination meter
- through terminal 3 (L) of the alternator.

The charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.

System Description (K9K Engine Models)

EKS00K2U

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

With the ignition switch in the ON or START position, power is supplied to alternator terminal 4 (S) through:

- IPDM E/R (Intelligent Power Distribution Module Engine Room)

Terminal B supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal 4 (S) detecting the input voltage. The charging circuit is protected by the 100A link.

The alternator is grounded to the body.

With the ignition switch in the ON or START position, power is supplied

- 10A fuse [No. 2, located in the fuse block (J/B)]
- to combination meter terminal 28 for the charge warning lamp.

Ground is supplied

- to terminal 38 of the combination meter
- through terminal 3 (L) of the alternator.

The charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.



If the charge warning lamp illuminates with the engine running, a fault is indicated.

CHARGING SYSTEM

Wiring Diagram — CHARGE — (CR Engine Models)

EKS007ZF

SC-CHARGE-01



5

F3

REFER TO THE FOLLOWING.

(M1), (F1) -SUPER MULTIPLE JUNCTION (SMJ)

(M16) -FUSE BLOCK- JUNCTION BOX (J/B)


MKWA0787E

CHARGING SYSTEM

Wiring Diagram — CHARGE — (K9K Engine Models)


EKS00K2V

SC-CHARGE-02



M1 , F101 -SUPER MULTIPLE
FUNCTION (SMF)



JUNCTION (SMJ)
M16 -FUSE BLOCK-
JUNCTION BOX (J/B)



CHARGING SYSTEM

SC-CHARGE-03

■ ■ ■ : DATA LINE



MKWA1452E

Trouble Diagnoses (CR Engine Models)

EKS007ZG

DIAGNOSIS PROCEDURE

1. Check malfunction symptoms or customer's remarks.
2. Perform pre-diagnosis inspection. Refer to [SC-19, "PRE-DIAGNOSIS INSPECTION"](#) .
3. Perform trouble diagnosis for each trouble symptom. Refer to [SC-19, "DIAGNOSIS CHART BY SYMPTOM"](#) .
4. Repair or replace parts indicated inspection flow based on the charge warning lamp. Refer to [SC-19, "INSPECTION FLOW BY CHARGE WARNING LAMP"](#) .
5. End

PRE-DIAGNOSIS INSPECTION

1. Perform alternator belt inspection. Refer to [EM-12, "DRIVE BELTS"](#) in EM section.
2. Inspect battery.
3. Check alternator terminal B for loose or improper connection.
4. Check alternator connector and terminals for loose connection, disconnection and bend.
5. Check connecting condition of harness for charging system harness (fusible link terminal and battery terminal).
6. After performing 1 to 5 above, go to trouble diagnosis for symptoms. Refer to [SC-19, "DIAGNOSIS CHART BY SYMPTOM"](#) .

DIAGNOSIS CHART BY SYMPTOM

Symptom	Reference page
Battery discharge	Refer to SC-19, "INSPECTION FLOW BY CHARGE WARNING LAMP" .
Charge warning lamp illuminates.	Refer to SC-19, "INSPECTION FLOW BY CHARGE WARNING LAMP" .
Other than the above symptoms (splashing out of battery fluid, nasty smell and others)	SC-23, "INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION" .


INSPECTION FLOW BY CHARGE WARNING LAMP

1. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch ON.
2. Check if charge warning lamp illuminates.

Does charge warning lamp illuminate?

YES >> GO TO 2.
NO >> Go to [SC-20, "CHARGE WARNING LAMP LINE INSPECTION"](#) .




2. CHARGE WARNING LAMP INSPECTION

1. Start engine.
2. Check if charge warning lamp goes off.

Does charge warning lamp goes off?

YES >> GO TO 3.
NO >> Go to [SC-21, "VOLTAGE DETECTION LINE AND CHARGE WARNING LAMP INSPECTION"](#) .



CHARGING SYSTEM


3. CHARGE WARNING LAMP INSPECTION

1. Set engine speed at 2,500 rpm.
2. Check if charge warning lamp illuminates.

Does charge warning lamp illuminate?

YES >> Go to [SC-23, "INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION"](#).

NO >> Go to [SC-23, "INSPECTION OF INSUFFICIENT ALTERNATOR POWER GENERATION"](#).



CHARGE WARNING LAMP LINE INSPECTION


CAUTION:

If open circuit is detected in L terminal, alternator cannot start generating.

INSPECTION PROCEDURE

1. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch OFF.
2. Disconnect alternator connector
3. Connect alternator connector terminal 3 to ground.




4. Turn ignition switch ON.

Does charge warning lamp illuminate?

YES >> GO TO 4.

NO >> GO TO 2.



2. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Check meter and terminals (meter side, and harness side) for damage, deformation or improper connection.

OK or NG

OK >> GO TO 3.

NG >> Repair terminals and connectors.

CHARGING SYSTEM

3. CONTINUITY INSPECTION

1. Disconnect combination meter connector.
2. Check continuity between combination meter connector terminal 38 and alternator connector terminal 3.

38 - 3

: Continuity should exist.

OK or NG


OK >> Replace combination meter. (Do not replace alternator, since it is normal.)
NG >> Repair the harnesses or connectors. (Do not replace alternator, since it is normal.)

4. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch OFF.
2. Connect alternator connector.
3. Turn ignition switch ON.

Does charge warning lamp illuminate?

YES >> Repair alternator connector. (Poor connection and intermittent problem) (Do not replace alternator, since it is normal.)
NO >> Replace alternator. (circuit malfunction in alternator)



VOLTAGE DETECTION LINE AND CHARGE WARNING LAMP INSPECTION


INSPECTION PROCEDURE

1. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch OFF.
2. Disconnect alternator connector.
3. Turn ignition switch ON.

Does charge warning lamp stay ON?

YES >> GO TO 5.
NO >> GO TO 2.



2. VOLTAGE INSPECTION


Check voltage between alternator connector terminal 4 and ground.

4 - Ground

: 12V or more

Is the inspection result 12V or more?

YES >> Replace alternator.
NO >> GO TO 3.



CHARGING SYSTEM

3. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Check alternator connector and terminal 4 (alternator side, and harness side) for damage, deformation or improper connection.

OK or NG

OK >> GO TO 4.

NG >> Repair terminals and connectors.

4. CHECK FUSES.

Check if alternator S terminal fuse #26 (10A) is blown.

OK or NG

OK >> Repair harness between fuse #26 (10A) and alternator connector terminal 4. (Do not replace alternator, since it is normal.)

NG >> Replace fuse. (Do not replace alternator, since it is normal.)

5. CONTINUITY INSPECTION

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter connector terminal 38 and ground, and combination meter connector terminal 38 and alternator terminal 3.

38 - Ground : Continuity should not exist.

38 - 3 : Continuity should exist.

OK or NG

OK >> Replace combination meter. (Do not replace alternator, since it is normal.)

>> Repair the harnesses or connectors. (Do not replace alternator, since it is normal.)

CHARGING SYSTEM

INSPECTION OF INSUFFICIENT ALTERNATOR POWER GENERATION

CAUTION:

Check them using charged battery performed battery inspection.


1. VOLTAGE INSPECTION

1. Increase engine speed to 2,500 rpm.
2. Turn electrical load to ON. (Headlamp LO turns on, blower fan motor maximum airflow amount)
3. Check battery voltage.

Is the inspection result 12.8V to 15.1V?

YES >> GO TO 2.

NO >> Replace alternator. (Alternator power generation error.)



2. CURRENT INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery ground cable.
3. Attach current measurement probe for CONSULT-II to the harness for alternator terminal B. (If the probe can not be attached properly, then connect the sub-harness between alternator terminal B and the vehicle side harness as shown in figure, and attach the probe to sub-harness.)
4. Connect battery ground cable.
5. Increase engine speed to 2,500 rpm.
6. Turn electrical load to ON. (Headlamp LO turns on, blower fan motor maximum airflow amount, rear window defogger)
7. Check alternator terminal B current.


CAUTION:

Be careful of rotating parts because the engine is running.

Is the inspection result 30A or more?

YES >> GO TO dark current inspection. Refer to [SC-24, "DARK CURRENT INSPECTION"](#). (Alternator is normal. Do not replace.)

NO >> Replace alternator. (Alternator power generation error.)



INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION


1. ALTERNATOR VOLTAGE INSPECTION

1. Increase engine speed to 2,500 rpm.
2. Check battery voltage.

Is the inspection result 16V or less?

YES >> GO TO 2.

NO >> Replace alternator. (Excessive alternator power generation.)



CHARGING SYSTEM

2. BATTERY VOLTAGE INSPECTION


1. Turn the ignition switch OFF.
2. Disconnect alternator connector.
3. Check voltage between alternator connector terminal 4 and ground.

4 - Ground

: 12V or more

Is the inspection result 12V or more?

YES >> Replace alternator. (Alternator power generation error)
NO >> GO TO 3.



3. FUSE CHECK

Check if fuse #26 (10A) is blown.

OK or NG

OK >> Repair harness between fuse #26 (10A) and alternator harness connector terminal 4. (Alternator is normal. Do not replace.)
NG >> Replace fuse. (Alternator is normal. Do not replace.)


DARK CURRENT INSPECTION

Dark Current : Small current while ignition switch is "OFF".

NOTE:

- If battery ground cable is disconnected from battery terminal, a large dark current may not be reproduced. When battery discharge occurs, never disconnect battery terminal while using ammeter.
- Do not connect CONSULT-II CONVERTER to data link connector when measuring dark current. CONSULT-II power should be supplied using AC adapter or internal battery.

1. Attach current measurement probe for CONSULT-II to battery ground cable. Refer to [SC-25, "OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II"](#) .
2. Check that all electrical equipment is turned OFF.
3. Remove key. Close and lock doors. Check that room lamp turns off.
4. Measure dark current. Is it 50mA or less? Refer to [SC-25, "OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II"](#) .



NOTE:

Dark current stable time is different due to equipment and use of the vehicle. If it is not 50mA or less after leaving for 1 minute, measure dark current again after leaving for 30 minutes or more.

If YES, GO TO 7. If NO, GO TO 5.

5. Remove and install fuses one by one. Search for the fuse that greatly changes dark current.

NOTE:

If dark current is greatly reduced when removing the fuse, and even if dark current is not greatly increased when installing it again, the fuse circuit may be the cause.


6. Check that dark current changes when moving the suspect circuit harness. If dark current changes, check harness for short. If dark current does not change, electronic unit in the circuit may not be entering the energy-saving mode when it turns OFF. If it does not enter the energy-saving mode, replace electronic unit.
7. No malfunction for alternator and electrical equipment. Electric load may be larger than alternator generating ability. Check the customer's usage.

CHARGING SYSTEM

OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II

For details, refer to the supplied "CONSULT-II Current Probe Operation Manual".


1. Turn current probe power supply OFF and connect to CONSULT-II. (Red: CH1, Black: Ground)
2. Touch "SUB MODE".
3. Touch "Extending Measurement Mode" on "SUB MODE" screen.
4. CAUTION is displayed, touch "OK".



5. Set current probe range switch at the range to measure, turn current probe power supply ON. When measuring dark current, set 4A range. (Check that POWER indicator turns on. Refer to CONSULT-II Current Probe Operation Manual.)
6. Touch the same measuring range at CONSULT-II.

NOTE:


If current probe measuring range is different from CONSULT-II measuring range, incorrect value is displayed.



7. Adjust 0 point of current probe or CONSULT-II. (Do not clamp anything to probe.)

NOTE:


If 0 point is dislocated greatly, adjust at current probe side generally.



8. Align current direction mark, clamp harness, and measure current. If current direction is incorrect, it is displayed negative value.

NOTE:

- When current is measured, close probe joint securely.
- If multiple harnesses are clamped, measurement cannot be performed. Always clamp only one.



CHARGING SYSTEM

Trouble Diagnoses (K9K Engine Models)

EKS00K2W

DIAGNOSIS PROCEDURE

1. Check malfunction symptoms or customer's remarks.
2. Perform pre-diagnosis inspection. Refer to [SC-26, "PRE-DIAGNOSIS INSPECTION"](#).
3. Perform trouble diagnosis for each trouble symptom. Refer to [SC-26, "DIAGNOSIS CHART BY SYMPTOM"](#).
4. Repair or replace parts indicated inspection flow based on the charge warning lamp. Refer to [SC-26, "INSPECTION FLOW BY CHARGE WARNING LAMP"](#).
5. End

PRE-DIAGNOSIS INSPECTION

1. Perform alternator belt inspection. Refer to [EM-121, "DRIVE BELTS"](#).
2. Inspect battery.
3. Check alternator terminal B for loose or improper connection.
4. Check alternator connector and terminals for loose connection, disconnection and bend.
5. Check connecting condition of harness for charging system harness (fusible link terminal and battery terminal).
6. After performing 1 to 5 above, go to trouble diagnosis for symptoms. Refer to [SC-26, "DIAGNOSIS CHART BY SYMPTOM"](#).

DIAGNOSIS CHART BY SYMPTOM

Symptom	Reference page
Battery discharge	Refer to SC-26, "INSPECTION FLOW BY CHARGE WARNING LAMP" .
Charge warning lamp illuminates.	Refer to SC-26, "INSPECTION FLOW BY CHARGE WARNING LAMP" .
Other than the above symptoms (splashing out of battery fluid, nasty smell and others)	SC-30, "INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION" .


INSPECTION FLOW BY CHARGE WARNING LAMP

1. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch ON.
2. Check if charge warning lamp illuminates.

Does charge warning lamp illuminate?

YES >> GO TO 2.
NO >> Go to [SC-27, "CHARGE WARNING LAMP LINE INSPECTION"](#).




2. CHARGE WARNING LAMP INSPECTION

1. Start engine.
2. Check if charge warning lamp goes off.

Does charge warning lamp goes off?

YES >> GO TO 3.
NO >> Go to [SC-28, "VOLTAGE DETECTION LINE AND CHARGE WARNING LAMP INSPECTION"](#).



CHARGING SYSTEM


3. CHARGE WARNING LAMP INSPECTION

1. Set engine speed at 2,500 rpm.
2. Check if charge warning lamp illuminates.

Does charge warning lamp illuminate?

YES >> Go to [SC-30, "INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION"](#).

NO >> Go to [SC-30, "INSPECTION OF INSUFFICIENT ALTERNATOR POWER GENERATION"](#).



CHARGE WARNING LAMP LINE INSPECTION


CAUTION:

If open circuit is detected in L terminal, alternator cannot start generating.

INSPECTION PROCEDURE

1. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch OFF.
2. Remove alternator connector.
3. Connect alternator connector terminal 3 to ground.




4. Turn ignition switch ON.

Does charge warning lamp illuminate?

YES >> GO TO 4.

NO >> GO TO 2.



2. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Check combination meter and terminals (meter side, and harness side) for damage, deformation or improper connection.

OK or NG

OK >> GO TO 3.

NG >> Repair terminals and connectors.

CHARGING SYSTEM

3. CONTINUITY INSPECTION

1. Disconnect combination meter connector.
2. Check continuity between combination meter connector terminal 38 and alternator connector terminal 3.

38 - 3

: Continuity should exist.

OK or NG

OK >> Replace combination meter. (Do not replace alternator, since it is normal.)

NG >> Repair the harnesses or connectors. (Do not replace alternator, since it is normal.)


4. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch OFF.
2. Connect alternator connectors.
3. Turn ignition switch ON.

Does charge warning lamp illuminate?

YES >> Repair alternator connector. (Poor connection and intermittent problem) (Do not replace alternator, since it is normal.)

NO >> Replace alternator. (circuit malfunction in alternator)



VOLTAGE DETECTION LINE AND CHARGE WARNING LAMP INSPECTION

INSPECTION PROCEDURE


1. CHARGE WARNING LAMP INSPECTION

1. Turn ignition switch OFF.
2. Disconnect alternator connector.
3. Turn ignition switch ON.

Does charge warning lamp stay ON?

YES >> GO TO 6.

NO >> GO TO 2.



2. VOLTAGE INSPECTION

Check voltage between alternator connector terminal 4 and ground.


4 - Ground

: 12V or more

Is the inspection result 12V or more?

YES >> Replace alternator.

NO >> GO TO 3.



CHARGING SYSTEM

3. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Check alternator connector and terminal 4 (alternator side, and harness side) for damage, deformation or improper connection.

OK or NG

OK >> GO TO 4.

NG >> Repair terminals and connectors.

4. CONNECTOR INSPECTION

Check IPDM E/R and terminals (IPDM E/R side, and harness side) for damage, deformation or improper connection.

OK or NG

OK >> GO TO 5.

NG >> Repair terminals and connectors.

5. CONTINUITY INSPECTION

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R connector terminal 63 and alternator connector terminal 4.

63 - 4

: Continuity should exist.

OK or NG

OK >> Replace IPDM E/R. (Do not replace alternator, since it is normal.)

Repair the harnesses or connectors. (Do not replace alternator, since it is normal.)

6. CONTINUITY INSPECTION

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter connector terminal 38 and ground, and combination meter connector terminal 38 and alternator terminal 3.

38 - Ground

: Continuity should not exist.

38 - 3

: Continuity should exist.

OK or NG

OK >> Replace combination meter. (Do not replace alternator, since it is normal.)

>> Repair the harnesses or connectors. (Do not replace alternator, since it is normal.)

CHARGING SYSTEM

INSPECTION OF INSUFFICIENT ALTERNATOR POWER GENERATION

CAUTION:

Check them using charged battery performed battery inspection.


1. VOLTAGE INSPECTION

1. Increase engine speed to 2,500 rpm.
2. Turn electrical load to ON. (Headlamp LO turns on, blower fan motor maximum airflow amount)
3. Check battery voltage.

Is the inspection result 12.8V to 15.1V?

YES >> GO TO 2.

NO >> Replace alternator. (Alternator power generation error.)



2. CURRENT INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the battery ground cable.
3. Attach current measurement probe for CONSULT-II to the harness for alternator terminal B. (If the probe can not be attached properly, then connect the sub-harness between alternator terminal B and the vehicle side harness as shown in figure, and attach the probe to sub-harness.)
4. Connect battery ground cable.
5. Increase engine speed to 2,500 rpm.
6. Turn electrical load to ON. (Headlamp LO turns on, blower fan motor maximum airflow amount, rear window defogger)
7. Check alternator terminal B current.


CAUTION:

Be careful of rotating parts because the engine is running.

Is the inspection result 30A or more?

YES >> GO TO dark current inspection. Refer to [SC-31, "DARK CURRENT INSPECTION"](#). (Alternator is normal. Do not replace.)

NO >> Replace alternator. (Alternator power generation error.)



INSPECTION OF EXCESSIVE ALTERNATOR POWER GENERATION


1. ALTERNATOR VOLTAGE INSPECTION

1. Increase engine speed to 2,500 rpm.
2. Check battery voltage.

Is the inspection result 16V or less?

YES >> GO TO 2.

NO >> Replace alternator. (Excessive alternator power generation.)



2. BATTERY VOLTAGE INSPECTION


1. Turn ignition switch OFF.
2. Disconnect alternator connector.
3. Turn ignition switch ON.
4. Check voltage between alternator connector terminal 4 and ground.

4 - Ground

: 12V or more

Is the inspection result 12V or more?

YES >> Replace alternator. (Alternator power generation error)
 NO >> GO TO 3.



3. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Check IPDM E/R and terminals (IPDM E/R side, and harness side) for damage, deformation or improper connection.

OK or NG

OK >> GO TO 4.

NG >> Repair terminals and connectors.

4. CONTINUITY INSPECTION

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R connector terminal 63 and alternator connector terminal 4.

63 - 4

: Continuity should exist.

OK or NG

OK >> Replace IPDM E/R. (Do not replace alternator, since it is normal.)

NG >> Repair the harnesses or connectors. (Do not replace alternator, since it is normal.)

DARK CURRENT INSPECTION

Dark Current: Small current while ignition switch is "OFF".

NOTE:

- If battery ground cable is disconnected from battery terminal, a large dark current may not be reproduced. When battery discharge occurs, never disconnect battery terminal while using ammeter.
- Do not connect CONSULT-II CONVERTER to data link connector when measuring dark current. CONSULT-II power should be supplied using AC adapter or internal battery.


1. Attach current measurement probe for CONSULT-II to battery ground cable. Refer to [SC-33, "OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II"](#).
2. Check that all electrical equipment is turned OFF.
3. Remove key. Close and lock doors. Check that room lamp turns off.
4. Measure dark current. Is it 50mA or less? Refer to [SC-33, "OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II"](#).

NOTE:

Dark current stable time is different due to equipment and use of the vehicle. If it is not 50mA or less after leaving for 1 minute, measure dark current again after leaving for 30 minutes or more.

If YES, GO TO 7. If NO, GO TO 5.

5. Remove and install fuses one by one. Search for the fuse that greatly changes dark current.



CHARGING SYSTEM

NOTE:

If dark current is greatly reduced when removing the fuse, and even if dark current is not greatly increased when installing it again, the fuse circuit may be the cause.


6. Check that dark current changes when moving the suspect circuit harness. If dark current changes, check harness for short. If dark current does not change, electronic unit in the circuit may not be entering the energy-saving mode when it turns OFF. If it does not enter the energy-saving mode, replace electronic unit.
7. No malfunction for alternator and electrical equipment. Electric load may be larger than alternator generating ability. Check the customer's usage.

CHARGING SYSTEM

OPERATION PROCEDURE OF CURRENT MEASUREMENT PROBE FOR CONSULT-II

For details, refer to the supplied "CONSULT-II Current Probe Operation Manual".


1. Turn current probe power supply OFF and connect to CONSULT-II. (Red: CH1, Black: Ground)
2. Touch "SUB MODE".
3. Touch "Extending Measurement Mode" on "SUB MODE" screen.
4. CAUTION is displayed, touch "OK".



5. Set current probe range switch at the range to measure, turn current probe power supply ON. When measuring dark current, set 4A range. (Check that POWER indicator turns on. Refer to CONSULT-II Current Probe Operation Manual.)
6. Touch the same measuring range at CONSULT-II.

NOTE:


If current probe measuring range is different from CONSULT-II measuring range, incorrect value is displayed.



7. Adjust 0 point of current probe or CONSULT-II. (Do not clamp anything to probe.)

NOTE:


If 0 point is dislocated greatly, adjust at current probe side generally.



8. Align current direction mark, clamp harness, and measure current. If current direction is incorrect, it is displayed negative value.

NOTE:


- When current is measured, close probe joint securely.
- If multiple harnesses are clamped, measurement cannot be performed. Always clamp only one.




Removal and Installation (CR Engine Models)

REMOVAL


1. Disconnect battery ground cable.
2. Remove fender protector from RH side.
3. Remove alternator drive belt. Refer to [EM-14, "Removal and Installation"](#).
4. Remove idler pulley bracket mounting bolt, and remove idler pulley assembly.




5. Disconnect alternator harness connector. B terminal mounting nut, ground wire mounting nut, and remove harness clips.



6. Remove engine mounting stay from RH side.
7. Remove alternator upper bracket mounting bolt, and alternator mounting bolt from upper side.



8. Loosen lower side alternator mounting bolt, and pull out from U-cut portion on front cover.
9. Remove alternator assembly from engine.



INSTALLATION

Install in the reverse order of removal, taking care of the following point.

- Install alternator, and check tension of belt. Refer to [EM-12, "Tension Adjustment"](#) in "ENGINE MECHANICAL (EM)" section.

CAUTION:

Be sure to tighten B terminal mounting nut carefully.


CHARGING SYSTEM

B terminal nut:	 : 9.32 - 10.8 N·m (0.95 - 1.1 kg·m, 82 - 95 in·lb)
Ground bolt:	 : 2.94 - 4.9 N·m (0.30 - 0.49 kg·m, 26 - 43 in·lb)
Alternator mounting bolt:	 : 33.3 - 46.1 N·m (3.4 - 4.7 kg·m, 24 - 34 ft·lb)
Alternator upper bracket bolt:	 : 33.3 - 46.1 N·m (3.4 - 4.7 kg·m, 24 - 34 ft·lb)
Engine mounting stay bolt:	 : 40.0 - 50.0 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)
Idler pulley bracket bolt:	 : 16.6 - 23.5 N·m (1.7 - 2.4 kg·m, 12 - 17 ft·lb)
Idler pulley nut:	 : 25.5 - 33.3 N·m (2.6 - 3.3 kg·m, 19 - 24 ft·lb)


Removal and Installation (K9K Engine Models)

REMOVAL


1. Disconnect battery ground cable.
2. Remove under cover and RH fender protector.
3. Remove front bumper. Refer to [EI-4, "FRONT BUMPER"](#) .
4. Remove alternator drive belt. Refer to [EM-121, "DRIVE BELTS"](#) .
5. Disconnect alternator harness connector and B terminal nut.



6. Remove alternator mounting bolt from upper side.



7. Remove alternator mounting bolt from lower side.
8. Remove alternator assembly from engine.



INSTALLATION

Install in the reverse order of removal, taking care of the following point.

- Install alternator, and check tension of belt. Refer to [EM-121, "DRIVE BELTS"](#) .


CAUTION:

Be sure to tighten B terminal mounting nut carefully.

CHARGING SYSTEM

Disassembly REAR COVER

EKS007ZJ



CAUTION:

Rear cover may be hard to remove because a ring is used to lock outer race of rear bearing. To facilitate removal of rear cover, heat just bearing box section with a 200W soldering iron. Do not use a heat gun, as it can damage diode assembly.

REAR BEARING

CAUTION:

- Do not reuse rear bearing after removal. Replace with a new one.
- Do not lubricate rear bearing outer race.

Inspection

ROTOR CHECK

EKS007ZK

1. Resistance test

Resistance


: Refer to SDS. [SC-54, "SERVICE DATA AND SPECIFICATIONS \(SDS\)"](#) .

- Not within the specified values... Replace rotor.
- 2. Insulator test
- Continuity exists... Replace rotor.
- 3. Check slip ring for wear.

Slip ring minimum outer diameter


: Refer to SDS. [SC-54, "SERVICE DATA AND SPECIFICATIONS \(SDS\)"](#) .

- Not within the specified values... Replace rotor.



BRUSH CHECK


1. Check smooth movement of brush.
 - Not smooth... Check brush holder and clean.
2. Check brush for wear.
 - Replace brush if it is worn down to the limit line.



CHARGING SYSTEM


STATOR CHECK

1. Continuity test
 - No continuity... Replace stator.



2. Ground test

- Continuity exists... Replace stator.




Assembly

RING FITTING IN REAR BEARING

- Fix ring into groove in rear bearing so that it is as close to the adjacent area as possible.


CAUTION:

Do not reuse rear bearing after removal.




REAR COVER INSTALLATION

1. Fit brush assembly, diode assembly, regulator assembly and stator.



CHARGING SYSTEM

2. Push brushes up with fingers and install them to rotor.
Take care not to damage slip ring sliding surface.



SEL049Z

STARTING SYSTEM

STARTING SYSTEM

PFP:00011

System Description

EKS007ZM

M/T MODELS

Power is supplied at all times

- through 40A fusible link (letter H, located in the fuse and fusible link box)
- to ignition switch terminal 1.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No.50 located in IPDM E/R]
- to park/neutral position switch terminal 2
- through 10A fuse [No.4, located in fuse block(J/B)]
- through IPDM E/R terminal 21
- to starter relay.

With the shift lever in the N position (under the ignition switch ON or START position)

Power is supplied

- through park/neutral position switch terminal 2 and 3
- to IPDM E/R terminal 31

and then starter relay is energized.

When ignition switch turn to START position, power is supplied

- through ignition switch terminal 1 and 5
- through IPDM E/R terminal 1
- to starter motor terminal 1.

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

A/T MODELS

Power is supplied at all times

- through 40A fusible link (letter H, located in the fuse and fusible link box)
- to ignition switch terminal 1.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 50 located in the intelligent power distribution module]
- to park/neutral position switch terminal 1.

With the selector lever in the P or N position (under the ignition switch ON or START position)

Power is supplied

- through park/neutral position switch terminal 1 and 2
- through IPDM E/R terminal 21
- to starter relay.
- through park/neutral position switch terminal 1 and 2
- to IPDM E/R terminal 31.

and then starter relay is energized.

When ignition switch turn to START position, power is supplied

- through ignition switch terminal 1 and 5
- through IPDM E/R terminal 9 and 11
- to starter motor terminal 1

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

A

B

C

D

E

F

G

H

I

J

SC


L

M

STARTING SYSTEM

Wiring Diagram — START — (CR Engine Models)

EKS007ZN



SC-START-01


 : FOR COLD AREAS
 : EXCEPT FOR COLD AREAS

REFER TO
PG-POWER.

IPDM E/R
(INTELLIGENT
POWER
DISTRIBUTION
MODULE
ENGINE ROOM)
E11, E12,
E13, E14,
E16

NEXT
PAGE






REFER TO THE FOLLOWING.
M1 , F1 -SUPER
MULTIPLE JUNCTION (SMJ)



STARTING SYSTEM

SC-START-02

(A) : WITH A/T
(M) : WITH M/T




REFER TO THE FOLLOWING.

(M1), (F1) -SUPER
MULTIPLE JUNCTION (SMJ)
(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)


STARTING SYSTEM

Wiring Diagram — START — (K9K Engine Models)

EKS00K2Z





REFER TO THE FOLLOWING.
M1 , **F101** -SUPER MULTIPLE
JUNCTION (SMJ)



STARTING SYSTEM

SC-START-04




REFER TO THE FOLLOWING.
 (M1, F101) -SUPER MULTIPLE
 JUNCTION (SMJ)
 (M16) -FUSE BLOCK-
 JUNCTION BOX (J/B)

STARTING SYSTEM

Trouble Diagnoses

EKS007ZQ


If any abnormality is found, immediately disconnect battery negative terminal.



Removal and Installation (CR Engine Models)

REMOVAL

1. Disconnect negative battery cable.
2. Remove starter motor mounting bolt from upper side.
3. Disconnect S terminal and B terminal from starter motor.
4. Remove starter motor mounting bolt from lower side.
5. Remove starter motor from lower side the vehicle.




INSTALLATION

Install in the reverse order of removal.

Removal and Installation (K9K Engine Models)

REMOVAL

1. Disconnect negative battery cable.
2. Remove starter motor mounting bolt from upper side.
3. Disconnect S terminal and B terminal from starter motor.
4. Remove starter motor mounting bolt from lower side.
5. Remove starter motor from lower side the vehicle.



INSTALLATION


Install in the reverse order of removal.

STARTING SYSTEM

Disassembly and Assembly

EKS007ZS

SEC. 233
M0T84581



(H) : High-temperature grease point

MKIA0081E

1. Gear case	2. Sleeve bearing	3. Shift lever
4. Plate	5. Packing	6. Adjusting plate
7. Magnetic switch assembly	8. Stopper clip	9. Pinion stopper
10. Pinion assembly	11. Internal gear	12. Pinion shaft
13. Planetary gear	14. Ball	15. Packing
16. Yoke	17. Armature	18. Brush holder assembly
19. Rear bearing	20. Rear cover	


Through-bolt:

M0T84581

: 4.1 - 7.1 N·m (0.45 - 0.72 kg·m, 39.1 - 62.5 in-lb)

STARTING SYSTEM

SEC. 233
0 001 116 009



MKIA0082E

1. Bushing	2. Gear case	3. Magnetic switch assembly
4. Stopper clip	5. Pinion stopper	6. Bushing
7. Pinion assembly	8. Shift lever	9. Armature
10. Packing	11. Yoke	12. Brush holder
13. Rear cover	14. Bushing	15. Cap

A
B
C
D
E
F
G
H
I
J


SC

L

M

STARTING SYSTEM

SEC. 233
MOT86181



: High-temperature grease point

YEL148E

1. Gear case	2. Gear case metal	3. Shift lever
4. Plate	5. Packing	6. Adjusting plate
7. Magnetic switch assembly	8. Stopper clip	9. Pinion stopper
10. Pinion assembly	11. Internal gear	12. Gear shaft
13. Planetary gear	14. Ball	15. Packing
16. Yoke	17. Armature	18. Brush holder
19. Rear cover		

STARTING SYSTEM


Inspection

MAGNETIC SWITCH CHECK


EKS007ZT

- Before starting to check, disconnect battery ground cable.
- Disconnect "M" terminal of starter motor.

1. Continuity test (between "S" terminal and switch body).
 - No continuity ... Replace.




2. Continuity test (between "S" terminal and "M" terminal).
 - No continuity ... Replace.



PINION/CLUTCH CHECK

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth (If equipped).
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident ... Replace.



BRUSH CHECK


Brush

Check wear of brush.

Wear limit length

: Refer to SDS. SC-54,
"SERVICE DATA AND
SPECIFICATIONS (SDS)".

- Excessive wear ... Replace.




STARTING SYSTEM

Brush Spring Check

Check brush spring pressure with brush spring detached from brush.


Spring pressure (with new brush) : Refer to SDS. SC-54, "SERVICE DATA AND SPECIFICATIONS (SDS)" .

- Not within the specified values ... Replace.



Brush Holder

1. Perform insulation test between brush holder (positive side) and its base (negative side).
 - Continuity exists. ... Replace.
2. Check brush to see if it moves smoothly.
 - If brush holder is bent, replace it; if sliding surface is dirty, clean.




STARTING SYSTEM

YODE CHECK

Magnet is secured to yoke by bonding agent. Check magnet to see that it is secured to yoke and for any cracks. Replace malfunctioning parts as an assembly.



CAUTION:

Do not clamp yoke in a vice or strike it with a hammer.



ARMATURE CHECK

1. Continuity test (between two segments side by side).
 - No continuity ... Replace.
2. Insulation test (between each commutator bar and shaft).
 - Continuity exists. ... Replace.
3. Check commutator surface.
 - Rough ... Sand lightly with No. 500 - 600 emery paper.





STARTING SYSTEM

4. Check diameter of commutator.

Commutator minimum diameter : Refer to SDS. SC-54, "SERVICE DATA AND SPECIFICATIONS (SDS)".

- Less than specified value ... Replace.

5. Check depth of insulating mold from commutator surface.



- Less than 0.2 mm (0.008 in) ... Undercut to 0.5 to 0.8 mm (0.020 to 0.031 in)

Assembly

EKS007ZU

Apply high-temperature grease to lubricate the bearing, gears and frictional surface when assembling the starter.


Carefully observe the following instructions.

PINION PROTRUSION LENGTH ADJUSTMENT

Clearance


With pinion driven out by magnetic switch, push pinion back to remove slack and measure clearance " ℓ " between the front edge of the pinion and the pinion stopper.

Clearance " ℓ " : Refer to SDS. SC-54, "SERVICE DATA AND SPECIFICATIONS (SDS)".



STARTING SYSTEM

- Not in the specified value ... Adjust by adjusting plate.



A
B
C
D

E

F

G

H

I

J

SC

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Battery

EKS0072V

Applied model	CR10, CR12, CR14		
Type	FULMEN type code		
	LB1 (FCM 047 620)	LB2 (FCM 055 622)	LB2 (FCM 050 622)
Capacity V-AH	12-47	12-55	12-50

Starter

EKS007ZW

Type	M0T84581	0 001 116 009	M0T86181
	MITSUBISHI make Reduction gear type	BOSCH make Non reduction	MITSUBISHI make Reduction gear type
Applied model	CR12, CR14	CR10, CR12, CR14	K9K engine
System voltage V		12	
No-load	Terminal voltage V	11.0	11.5
	Current A	Less than 90	Less than 48
	Revolution rpm	More than 2,800	More than 5,800
	Minimum diameter of commutator mm (in)	—	33.5 (1.319)
	Minimum length of brush mm (in)	—	3.5 (0.138)
	Brush spring tension N (kg, lb)	—	—
	Clearance between bearing metal and armature shaft mm (in)	Less than 0.2 (0.008)	—
	Clearance "ℓ" between pinion front edge and pinion stopper mm (in)	0.3 - 2.5 (0.012 - 0.098)	0.0 - 3.9 (0 - 0.154)
			0.5 - 2.0 (0.020 - 0.079)

Alternator

SMA for VIN >SJN**AK12U1044368

EKS007ZX

Type	252694	—
	VALEO Make	—
Applied model	CR10, CR12, CR14	K9K
Nominal rating V-A	12-77	—
Ground polarity	Negative	—
Minimum revolutions under no-load (When 13.5V is applied) rpm	—	—
Hot output current (When 13.5V is applied) A/rpm	More than 39/1,800 More than 60/2,500 More than 76/5,000 More than 77/6,000	—
Regulated output voltage V	14.4	—
Minimum length of brush mm (in)	—	—
Brush spring pressure N (g, oz)	—	—
Slip ring minimum diameter mm (in)	—	—
Rotor coil resistance at 20° (68°F) Ω	—	—