



SECTION
WIPER, WASHER & HORN
CONTENTS

PRECAUTIONS	4	Front Wiper Low Speed Operation Does Not Operate	38
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	Front Wiper High Speed Operation Does Not Operate	39
Wiper and Washer System	4	Front Wiper INT Does Not Operate	40
FRONT WIPER AND WASHER SYSTEM	5	Front Wiper Interval Time Is Not Controlled by Vehicle Speed	40
Components Parts and Harness Connector Location	5	After Front Wipers Operate for 10 Seconds, They Stop for 20 Seconds	41
System Description	5	Front Wipers Do Not Stop	42
WIPER OPERATION	6	Removal and Installation of Front Wiper Arm	42
WASHER OPERATION	7	REMOVAL	42
FAIL-SAFE FUNCTION	7	INSTALLATION	42
BCM WIPER SWITCH READING FUNCTION	8	Adjustment of Front Wiper Arm Stop Position	42
CAN Communication	10	Removal and Installation of Front Wiper Motor and Link	43
SYSTEM DESCRIPTION	10	REMOVAL	43
CAN Communication Unit	10	INSTALLATION	43
TYPE 1/TYPE 2	11	Adjustment of Spray Positions of Front Washer Nozzle	44
TYPE 3/TYPE 4	14	Washer Hose Routing	45
TYPE 5/TYPE 6	16	Removal and Installation of Front Washer Nozzle..	45
TYPE 7/TYPE 8	19	REMOVAL	45
TYPE 9/TYPE 10	21	CHECK VALVE INSPECTION	45
Schematic	24	INSTALLATION	45
Wiring Diagram — WIPER —	25	Inspection of Front Wiper and Washer Switch Circuit..	46
Terminals and Reference Values for BCM	28	Removal and Installation of Front Wiper and Washer Switch	46
Terminals and Reference Values for IPDM E/R	29	Removal and Installation of Front Wiper and Washer Tank	46
How to Proceed With Trouble Diagnosis	29	REMOVAL	46
Preliminary Inspection	29	INSTALLATION	46
CHECK POWER SUPPLY AND GROUND CIRCUIT	29	Removal and Installation of Front Wiper and Washer Pump	46
CONSULT-II Function (BCM)	31	REMOVAL	46
CONSULT-II BASIC OPERATION	31	INSTALLATION	47
WORK SUPPORT	32	FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)	48
DATA MONITOR	32	Components Parts and Harness Connector Location	48
ACTIVE TEST	33		
CONSULT-II Function (IPDM E/R)	33		
CONSULT-II BASIC OPERATION	33		
DATA MONITOR	34		
ACTIVE TEST	35		
Front Wiper Does Not Operate	35		
Front Wiper Does Not Return to Stop Position	37		

System Description	48	INSTALLATION	81
WIPER OPERATION	49	Removal and Installation of Rain Sensor	81
WASHER OPERATION	50	REMOVAL	81
FAIL-SAFE FUNCTION	50	INSTALLATION	81
BCM WIPER SWITCH READING FUNCTION	51	REAR WIPER AND WASHER SYSTEM	82
CAN Communication	53	Components Parts and Harness Connector Location	82
SYSTEM DESCRIPTION	53	System Description	82
CAN Communication Unit	53	WIPER OPERATION	82
TYPE 1/TYPE 2	54	INTERMITTENT OPERATION	83
TYPE 3/TYPE 4	57	WASHER OPERATION	83
TYPE 5/TYPE 6	59	BCM WIPER SWITCH READING FUNCTION	83
TYPE 7/TYPE 8	62	CAN Communication	85
TYPE 9/TYPE 10	64	SYSTEM DESCRIPTION	85
Schematic	67	CAN Communication Unit	85
Wiring Diagram — A/WIP —	68	TYPE 1/TYPE 2	87
Terminals and Reference Values for BCM	71	TYPE 3/TYPE 4	90
Terminals and Reference Values for IPDM E/R	72	TYPE 5/TYPE 6	92
How to Proceed With Trouble Diagnosis	72	TYPE 7/TYPE 8	95
Preliminary Inspection	72	TYPE 9/TYPE 10	97
CHECK POWER SUPPLY AND GROUND CIR- CUIT	72	Wiring Diagram — WIP/R —	100
CONSULT-II Function (BCM)	73	Terminals and Reference Values for BCM	102
CONSULT-II Function (IPDM E/R)	74	How to Proceed With Trouble Diagnosis	102
Front Wiper Does Not Operate	74	Preliminary Check	103
Front Wiper Does Not Return to Stop Position	74	CHECK POWER SUPPLY AND GROUND CIR- CUIT	103
Front Wiper Low Speed Operation Does Not Oper- ate	74	CONSULT-II Function (BCM)	103
Front Wiper High Speed Operation Does Not Oper- ate	74	Rear Wiper Does Not Operate	104
Front Wiper INT Does Not Operate	74	Rear Wiper Stop Position Is Not Restored	105
Auto Wiper Does Not Operate Properly	74	Only Rear Wiper INT Does Not Operate	106
After Front Wipers Operate for 10 Seconds, They Stop for 20 Seconds	76	Removal and Installation of Rear Wiper Arm	106
Front Wipers Do Not Stop	76	REMOVAL	106
Removal and Installation of Front Wiper Arm	76	INSTALLATION	106
REMOVAL	76	Adjusting Rear Wiper Arm Stop Position	107
INSTALLATION	76	Removal and Installation of Rear Wiper Motor	107
Adjustment of Front Wiper Arm Stop Position	76	REMOVAL	107
Removal and Installation of Front Wiper Motor and Link	77	INSTALLATION	107
REMOVAL	77	Rear Wiper Blade	108
INSTALLATION	77	REMOVAL AND INSTALLATION	108
Adjustment of Spray Positions of Front Washer Noz- zle	78	Adjusting Rear Washer Nozzle Spray Position	108
Washer Hose Routing	79	Rear Washer Hose Circuit	108
Removal and Installation of Front Washer Nozzle	79	Removal and Installation of Rear Washer Nozzle	108
REMOVAL	79	REMOVAL	108
CHECK VALVE INSPECTION	79	CHECK VALVE INSPECTION	109
INSTALLATION	79	INSTALLATION	109
Inspection of Front Wiper and Washer Switch Circuit	80	Rear Wiper and Washer Switch Circuit Inspection	109
Removal and Installation of Front Wiper and Washer Switch	80	Removal and Installation of Rear Wiper and Washer Switch	109
Removal and Installation of Front Wiper and Washer Tank	80	Removal and Installation of Rear Wiper and Washer Tank	109
REMOVAL	80	Removal and Installation of Rear Wiper and Washer Pump	109
INSTALLATION	80	HEADLAMP WASHER	110
Removal and Installation of Front Wiper and Washer Pump	80	System Description	110
REMOVAL	80	HEADLAMP WASHER OPERATION	110
INSTALLATION	80	Wiring Diagram —HLC—	111
Removal and Installation of Front Wiper and Washer Pump	80	CONSULT-II Function (BCM)	113
REMOVAL	80	CONSULT-II Function (IPDM E/R)	113

REMOVAL	113	Wiring Diagram —HORN—	114
INSTALLATION	113	Removal and Installation	115
Removal and Installation for Washer Tank	113	REMOVAL	115
Removal and Installation for Washer Pump	113	INSTALLATION	115
Washer Tube Layout	113	POWER SOCKET	116
HORN	114	Wiring Diagram —CIGAR—	116
		Removal and Installation	117
		REMOVAL	117
		INSTALLATION	117

A

B

C

D

E

F

G

H

I

J

WW

L

M

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EKS00860

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Wiper and Washer System

EKS007AW

- If snow or other obstacle stops wipers from moving while front wipers are operating, wipers will stop moving to protect motor. In this case, turn the switch OFF and remove obstacle. Wait at least 20 seconds before turning the switch ON again to start front wipers.
- If rear wiper operation is stopped 5 seconds or more due to snow or other reason, the BCM stops rear wiper operation to protect motor. At this time, after removing cause of stoppage, turn rear wiper switch to OFF, wait at least 1 min, then turn wiper switch to ON or INT to restart wiper.
- The hood may be scratched if opened while front wipers are locked back.
- If there is unevenness or peeling of windshield glass wax, other oil films, or glass coating, wipers may not wipe correctly (juddering or other non-standard conditions may occur).
- Washer pump may malfunction if operated continuously for 1 minute or longer.

FRONT WIPER AND WASHER SYSTEM

FRONT WIPER AND WASHER SYSTEM

PFP:28810

Components Parts and Harness Connector Location


EKS00861

A
B
C
D
E
F
G
H
I
J

WW

L

M



System Description

EKS00862

- Front wiper HI/LO relay and front wiper main relay are built into IPDM E/R.
- Wiper switch (combination switch) is composed of a combination of 5 output terminals and 5 input terminals. Terminal combination status is read by BCM when switch is turned ON.
- BCM controls front wiper LO, HI, and INT (intermittent) operation.
- IPDM E/R operates wiper motor according to CAN communication signals from BCM.

Power is supplied at all times

- through 20A fuse (NO.38, located in the IPDM E/R)
- to front wiper main relay.
- through 20A fuse (NO.52, located in the IPDM E/R)
- to IPDM E/R (CPU).
- through 40A fusible link (letter J, located in fuse and fusible link box)
- to BCM terminals 74 and 79.

When ignition switch ON or START position, power is supplied

- through 10A fuse [NO.4, located in fuse block (J/B)]
- to BCM terminal 24,
- through 15A fuse [NO.1, located in fuse block (J/B)]
- to combination switch terminal 11, and
- to front wiper HI/LO relay, front wiper main relay and IPDM E/R (CPU)

Ground is supplied

FRONT WIPER AND WASHER SYSTEM

- through body grounds E25 (CR engine models), E26 and E40
- to front wiper motor terminal 1 and,
- to IPDM E/R terminals 3 and 54, and
- through body grounds M19 and M20
- to combination switch terminal 12 and
- to BCM terminals 2 and 70

WIPER OPERATION

Low Speed Wiper Operation

When front wiper switch is placed in LO position, BCM read combination switch condition (Refer to [WW-8, "BCM WIPER SWITCH READING FUNCTION"](#)). And BCM sent front wiper request signal (LO) to IPDM E/R with CAN communication line. When IPDM E/R receives front wiper request signal (LO), it turns ON front wiper main relay (built into IPDM E/R).

Power is supplied

- to front wiper motor terminal 3,
- through front wiper main relay and front wiper HI/LO relay and
- through IPDM E/R terminal 23.

Ground is supplied

- to front wiper motor terminal 1,
- through body grounds E25 (CR engine models), E26 and E40.

With power and ground are supplied, the front wiper motor operates at low speed.

High Speed Wiper Operation

When front wiper switch is placed in HI position, BCM read combination switch condition (Refer to [WW-8, "BCM WIPER SWITCH READING FUNCTION"](#)). And BCM sent front wiper request signal (HI) to IPDM E/R with CAN communication line. When IPDM E/R receives front wiper request signal (HI), it turns ON front wiper HI/LO relay and front wiper main relay (built into IPDM E/R).

Power is supplied

- to front wiper motor terminal 2,
- through front wiper main relay and front wiper HI/LO relay and,
- through IPDM E/R terminal 24.

Ground is supplied

- to front wiper motor terminal 1
- through body grounds E25, E26 and E40.

With power and ground are supplied, the front wiper motor operates at high speed.

Intermittent Operation

When front wiper switch is placed in INT position, BCM read combination switch condition (refer to [WW-8, "BCM WIPER SWITCH READING FUNCTION"](#)) and it operates as follows.

- BCM reads combination switch condition of V/INT 1, 2 and 3, it determines INT volume.(Refer to [WW-8, "BCM WIPER SWITCH READING FUNCTION"](#))
- BCM receives vehicle speed signal from combination meter with CAN communication line.
- BCM calculates intermittent interval from INT volume and vehicle speed signal.
- BCM sends front wiper request signal to IPDM E/R for every intermittent interval via CAN communication line.

Power is supplied

- to front wiper motor terminal 3,
- through front wiper main relay and front wiper HI/LO relay and
- through IPDM E/R terminal 23.

Ground is supplied

- to front wiper motor terminal 1,
- through body grounds E25 (CR engine models), E26 and E40.

With power and ground are supplied, the front wiper motor operates.

FRONT WIPER AND WASHER SYSTEM

Auto Stop Operation

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach stop position.

When wiper arms are not located at stop position with wiper switch OFF, power is supplied

- from terminal 23 of the IPDM E/R
- to front wiper motor terminal 3, in order to continue wiper motor operation at low speed.

Ground is supplied

- to front wiper motor terminal 1
- through body grounds E25 (CR engine models), E26 and E40.

When wiper arms reach stop position, front wiper motor terminals 1 and 4 are connected.

Then the IPDM E/R sends auto stop operation signal to BCM with CAN communication line.

When BCM receives auto-stop operation signal, BCM sends wiper stop signal to IPDM E/R with CAN communication line.

IPDM E/R stops wiper motor. Wiper motor will then stop wiper arms at the STOP position.

Mist Operation

When the wiper switch is placed in the mist position, wiper operate ones. The wiper operation is the same as the front wiper low speed operation. If the switch is held in the mist position, front wiper low speed operation continues.

WASHER OPERATION

When front wiper switch is pulled to washer position, power is supplied

- through combination switch terminal 13
- to washer motor terminal 1.

Ground is supplied

- to washer motor terminal 2
- through combination switch terminals 12 and 14, and
- through body grounds M19 and M20.

With power and ground supplied, the washer motor operates, and at the same time,

When the wiper switch is pulled to the WASH position for 1 second or more. BCM sends front wiper request signal (low) to IPDM E/R with CAN communication line. And the front wiper motor operates at low speed for approximately 3 times to clean wind shield

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, front wiper low speed operates when the ignition switch is turned from OFF to ON or ACC and front wiper are stopped when the ignition switch is turn from ON or ACC to OFF. If the fail-safe system is operating, front wiper does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-19, "FAIL-SAFE FUNCTION"](#))

A

B

C

D

E

F

G

H

I

J

WW

L


M

FRONT WIPER AND WASHER SYSTEM

BCM WIPER SWITCH READING FUNCTION

BCM reads combination switch (wiper switch) status, and controls front wipers based on the results.

BCM is a combination of 5 output terminals (output 1 - 5) and 5 input terminals (input 1 - 5). It reads 20 types of switch data and 5 types of diagnosis data.



Operation Description

- BCM operates output terminal (output 1 to 5) transistor at a set period and turns ON the current in order.
- When any (or multiple) switches are turned ON, a circuit is formed between the output terminals (output 1 to 5) and input terminals (input 1 to 5).
- At this time, when output terminals (output 1 to 5) operate transistors and carry current. If voltage of corresponding input terminal (input 1 to 5) changes, interface in BCM detects this state and judges that switch is ON.

Table Of BCM - Combination Switch Operations

BCM reads operation status of combination switch using combinations shown in table below.


	Combination SW INPUT 1		Combination SW INPUT 2		Combination SW INPUT 3		Combination SW INPUT 4		Combination SW INPUT 5	
	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
Combination SW OUTPUT 1	—	—	FR WIPER HI ON	FR WIPER HI OFF	V/INT 1 ON	V/INT 1 OFF	RR WIPER INT ON	RR WIPER INT OFF	V/INT 2 ON	V/INT 2 OFF
Combination SW OUTPUT 2	FR WASHER ON	FR WASHER OFF	—	—	RR WASHER ON	RR WASHER OFF	V/INT 3 ON	V/INT 3 OFF	RR WIPER ON	RR WIPER OFF
Combination SW OUTPUT 3	FR WIPER LOW ON	FR WIPER LOW OFF	FR WIPER INT ON	FR WIPER INT OFF	—	—	—	—	RR FOG ON	RR FOG OFF
Combination SW OUTPUT 4	TURN LH ON	TURN LH OFF	PASSING ON	PASSING OFF	HEADLAMP 2 ON	HEADLAMP 2 OFF	—	—	FR FOG ON	FR FOG OFF
Combination SW OUTPUT 5	TURN RH ON	TURN RH OFF	HEADLAMP 1 ON	HEADLAMP 1 OFF	HI BEAM ON	HI BEAM OFF	TAIL LAMP ON	TAIL LAMP OFF	—	—

MKIB0370E

FRONT WIPER AND WASHER SYSTEM

Example: (Wiper Switch Placed In LO Position)

- If front wiper switch is placed in LO position, the contact of front wiper LO in combination switch is turned ON. At this time, when output 1 transistor operates, driver control unit detects that voltage has been changed at input 3.
- When output 1 transistor is ON and BCM detects current changes at input 3, BCM determines that wiper switch is at LO. BCM uses CAN communication and sends front wiper signals to IPDM E/R.
- When output 1 transistor operates again and BCM detects voltage change at input 3, BCM recognizes that front wiper LO operation is continuing.



NOTE:

Each output terminal transistor operates at 20 ms intervals. Therefore, after a switch is turned ON, the electrical loads are activate with a time delay. However, this delay is too small to be detected.

Intermittent Operation

Wiper intermittent operation delay interval is determined from a combination of 3 switches (V/INT 1, V/INT 2, and V/INT 3) and vehicle speed signal.

During each intermittent operation delay interval, BCM sends front wiper request signal to IPDM E/R.

Wiper Volume Position Setting

Wiper dial position	Intermittent interval	Combination switch		
		V/INT 1	V/INT 2	V/INT 3
Wiper volume position 1	Small	ON	ON	ON
Wiper volume position 2		ON	ON	OFF
Wiper volume position 3		ON	OFF	OFF
Wiper volume position 4		OFF	OFF	OFF
Wiper volume position 5		OFF	OFF	ON
Wiper volume position 6		OFF	ON	ON
Wiper volume position 7		OFF	ON	OFF

Example: For wiper volume position 1...

Using combination switch reading function, BCM reads ON/OFF status of V/INT 1, 2, and 3.

When combination switch status is as listed below, BCM determines that it is wiper volume position 1.

- V/INT 1: ON (input 1 and output 3 are performing.)
- V/INT 2: ON (input 1 and output 5 are performing.)
- V/INT 3: ON (input 2 and output 4 are performing.)

BCM determines front wiper intermittent interval from wiper volume 1 and vehicle speed, and sends wiper request signal (INT) to IPDM E/R for every intermittent interval via CAN communication line.

FRONT WIPER AND WASHER SYSTEM

CAN Communication SYSTEM DESCRIPTION

EKS00K70

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00K7P

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door																	
Axle	2WD																	
Engine	CR10DE/CR12DE/CR14DE						CR12DE/CR14DE						K9K					
Handle	LHD/RHD																	
Brake control	ABS system						ESP system						ABS					
Transmission	A/T			M/T			A/T			M/T			M/T					
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable
CAN communication unit																		
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×			×	×			×	×			×	×			×	×
Drive computer	×		×		×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×					×	×	×	×						
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	WW-11, "TYPE 1/TYPE 2"				WW-14, "TYPE 3/TYPE 4"				WW-16, "TYPE 5/TYPE 6"				WW-19, "TYPE 7/TYPE 8"				WW-21, "TYPE 9/TYPE 10"	


x: Applicable

FRONT WIPER AND WASHER SYSTEM


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

FRONT WIPER AND WASHER SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R				T		R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

FRONT WIPER AND WASHER SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

I

J

WW

L


M

FRONT WIPER AND WASHER SYSTEM


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

FRONT WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 L
 M
 WW

FRONT WIPER AND WASHER SYSTEM


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

FRONT WIPER AND WASHER SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

A
B
C
D
E
F
G
H
I
J

WW

L
M

FRONT WIPER AND WASHER SYSTEM


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction sig- nal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T		R	
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T		R	
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

FRONT WIPER AND WASHER SYSTEM


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

FRONT WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


FRONT WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal	R	T						


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



FRONT WIPER AND WASHER SYSTEM

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

FRONT WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A

B

C

D

E

F

G

H

I

J

WW


L

M

FRONT WIPER AND WASHER SYSTEM

Schematic

EKS00863






MKWA1457E

FRONT WIPER AND WASHER SYSTEM

Wiring Diagram — WIPER —


EKS00864

WW-WIPER-01




MKWA1458E

FRONT WIPER AND WASHER SYSTEM






FRONT WIPER AND WASHER SYSTEM



FRONT WIPER AND WASHER SYSTEM

Terminals and Reference Values for BCM

EKS00865

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
2	B	Ground	ON	—	Approx. 0
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	 SKIA2167J
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	 SKIA2166J
14	P	Combination switch output 3			
15	W	Combination switch output 5		Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)	 SKIA2167J
33	R	Combination switch output 2			
34	Y	Combination switch output 4			
19	R	CAN H	—	—	—
24	OR	Ignition power supply	ON	—	Approx. 12
39	W	CAN L	—	—	—
70	B	Ground	ON	—	Approx. 0
74	W	Battery power supply	OFF	—	Approx. 12
79	Y	Battery power supply	OFF	—	Approx. 12

FRONT WIPER AND WASHER SYSTEM

Terminals and Reference Values for IPDM E/R

EKS00866

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
3	B	Ground	ON	—	Approx. 0
23	Y	Low speed power source	ON	Wiper switch	OFF
					LO Battery voltage
24	*1	High speed power source	ON	Wiper switch	OFF
					HI Battery voltage
52	R	CAN H	—	—	—
54	B	Ground	—	—	Approx. 0
55	OR	Wiper auto stop signal	ON	Wiper operating	Battery voltage
				Wiper stopped	Approx. 0
58	W	CAN L	—	—	—

*1: CR engine models (LG), K9K engine models (BR)

How to Proceed With Trouble Diagnosis

EKS00867

1. Confirm the symptoms and customer complaint.
2. Understand operation description and function description. Refer to [WW-5, "System Description"](#) .
3. Carry out the Preliminary check. Refer to [WW-29, "Preliminary Inspection"](#) .
4. Confirm front wiper does not operate by fail-safe control of IPDM E/R. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#) .
5. Check symptom and repair or replace the cause of malfunction.
6. Does the front wiper operate normally? Yes: GO TO 7. No: GO TO 5.
7. Inspection end.

Preliminary Inspection

EKS00868

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSE

WW

- Check fuse and fusible link for blown-out.

Unit	Power source	Fuse No.
Front washer motor	Ignition ON or START	1
Front wiper main relay	Battery	38
BCM	Battery	J
	Ignition switch ON or START position	4

Refer to [WW-25, "Wiring Diagram — WIPER —"](#)

OK or NG


OK >> GO TO 2.
 NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse, Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

FRONT WIPER AND WASHER SYSTEM

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position		
Connector	Terminal (Wire color)	(-)	OFF	ACC
M50	74 (W)	Ground	Battery voltage	Battery voltage
M50	79 (Y)		Battery voltage	Battery voltage
M48	24 (OR)		0V	0V



OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.

3. CHECK GROUND CIRCUIT


1. Disconnect IPDN E/R harness connector and front wiper motor harness connector.
2. Check continuity between IPDM E/R harness connector, front wiper motor harness connector and ground.

Terminals		Continuity	
Connector	Terminal (Wire color)	(-)	Ground
E11	3 (B)		Yes
E44	1 (B)		

OK or NG

OK >> GO TO 4.

NG >> Harness for open ground circuit.



4. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminals		Continuity	
Connector	Terminal (Wire color)	(-)	Ground
M48	2 (B)		Yes
M50	70(B)		Yes

OK or NG

OK >> INSPECTION END.

NG >> Check harness ground circuit.



FRONT WIPER AND WASHER SYSTEM

CONSULT-II Function (BCM)

EKS007B0

CONSULT-II can display each diagnostic item using the diagnostic modes shown following. Data is received and transmitted via the control module communication line.


BCM trouble diagnosis item	Inspection Item, Diagnosis Mode	Description
Wiper	Data monitor	Displays BCM input data in real time.
	Active test	Device operation can be checked by applying a drive signal to device.

CONSULT-II BASIC OPERATION


CAUTION:

If CONSULT-II is used without CONSULT-II CONVERTER connected, malfunction may be detected by self-diagnosis in control units that use CAN Communication.


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector.
3. Turn ignition switch ON.



4. Touch “START (NISSAN BASED VHCL)”. ---




5. Touch "BCM" on the "SELECT SYSTEM" screen.
If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .




FRONT WIPER AND WASHER SYSTEM

6. Touch "WIPER" on the "SELECT TEST ITEM" screen.



7. Touch "WORK SUPPORT", "DATA MONITOR", or "ACTIVE TEST" on "SELECT DIAG MODE".



WORK SUPPORT

Supported item	Description
RR WIP RVRS	Rear wiper reverse range operation setting can be changed.

DATA MONITOR

Operation Procedure

1. Touch "WIPER" on the "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELET FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
SELECT FROM MENU	Selects and monitors individual items.

4. Touch "START".
5. When "SELECT FROM MENU" is selected, touched items to be monitored. If "ALL SIGNALS" is selected, all items will be monitored.
6. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

Display Item List

Monitor item "UNIT"	Contents
IGN ON SW [ON/OFF]	Displays "ignition switch ON (ON)/Other OFF or ACC (OFF)" status as judged from ignition switch signal.
FR WIPER HI [ON/OFF]	Displays "Front Wiper HI (ON)/Others (OFF)" status as judged from wiper switch signal.
FR WIPER LOW [ON/OFF]	Displays "Front Wiper LOW (ON)/Others (OFF)" status as judged from wiper switch signal.
FR WIPER INT [ON/OFF]	Displays "Front Wiper INT (ON)/Others (OFF)" status as judged from wiper switch signal.
FR WASHER SW [ON/OFF]	Displays "Front Washer Switch (ON)/Others (OFF)" status as judged from wiper switch signal.
INT VOLUME [1 - 7]	Displays intermittent operation dial position setting (1 - 7) as judged from wiper switch signal.
FR WIPER STOP [ON/OFF]	Displays "Stopped (ON)/Operating (OFF)" status as judged from the auto-stop signal.

FRONT WIPER AND WASHER SYSTEM

Monitor item "UNIT"		Contents
VEHICLE SPEED	[km/h]	Displays vehicle speed status as judged from vehicle speed signal.
H/L WASHER SW	[ON/OFF]	Displays (Headlamp washer switch: ON/Others: OFF) as judged from headlamp washer switch signal
H/L SW POS	[ON/OFF]	Displays (Headlamp switch: ON/Others: OFF) as judged from lighting switch signal
RR WIPER ON	[ON/OFF]	Displays "Rear Wiper ON (ON)/Others (OFF)" status as judged from wiper switch signal.
RR WIPER INT	[ON/OFF]	Displays "Rear Wiper INT (ON)/Others (OFF)" status as judged from wiper switch signal.
RR WASHER SW	[ON/OFF]	Displays "Rear Washer Switch (ON)/Others (OFF)" status as judged from wiper switch signal.
RR WIPER STOP	[ON/OFF]	Displays "Rear Wiper Stop (ON)/Others (OFF)" status as judged from wiper switch signal.
REVERSE SW CAN	[ON/OFF]	Displays "Reverse position (ON)/Others (OFF)" status as judged from reverse signal.
R/WIP MTR SIG	[ON/OFF]	Displays "Rear wiper motor signal (ON)/Others (OFF)" status as judged to rear wiper motor output signal.

ACTIVE TEST

Operation Procedure

1. Touch "WIPER" on the "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on the "SELECT DIAG MODE" screen.
3. Touch item to be tested, and check operation.
4. During operation check, touching "BACK" deactivates operation.

Display Item List

Test item	Indication CONSULT-II display	Description
Front wiper output	FR WIPER	Front wiper can be operated by any ON-OFF operation.
Rear wiper output	RR WIPER	Rear wiper can be operated by any ON-OFF operation.
Head lamp washer output	HEAD LAMP WASHER	Head lamp washer can be operated by any ON-OFF operation.

CONSULT-II Function (IPDM E/R)

EKS007B1

CONSULT-II can display each diagnostic item using the diagnostic modes shown following. Data is received and transmitted via the control module communication line.


Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	Refer to PG-34, "SELF-DIAG RESULTS" .
DATA MONITOR	Displays input/output data of IPDM E/R in real time.
ACTIVE TEST	IPDM E/R sends a drive signal to components for electric load operation check.

CONSULT-II BASIC OPERATION

CAUTION:

If CONSULT-II is used without CONSULT-II CONVERTER connected, malfunction may be detected by self-diagnosis in control units that use CAN Communications.


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector.
3. Turn ignition switch ON.




PBIA3525E

FRONT WIPER AND WASHER SYSTEM


4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “IPDM E/R” on “SELECT SYSTEM” screen.
If “IPDM E/R” is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Select required diagnosis mode on “SELECT DIAG MODE”.



DATA MONITOR

Operation Procedure

1. Touch “DATA MONITOR” on “SELECT DIAG MODE” screen.
2. Touch either of “ALL SIGNALS”, “MAIN SIGNALS”, or “SELECT FROM MENU” on “DATA MONITOR” screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitors preselected items.
CAN DIAG SUPPORT MNTR	Monitors CAN communication status.
SELECT FROM MENU	Monitors items optionally selected.

3. Touch “START”.
4. When “SELECT FROM MENU” is selected, touch items to be monitored. When “ALL SIGNALS” is selected, all items are monitored. When “MAIN SIGNALS” is selected, only preselected items are monitored.
5. Touch “RECORD” while monitoring to record the status of the item being monitored. To stop recording, touch “STOP”.

FRONT WIPER AND WASHER SYSTEM

All Signals, Main Signals, Select From Menu

Item name	Display or unit	Monitor item selection			Description
		All signals	Main signal	Select from menu	
HEADLAMP WASHER REQUEST	ON/OFF	×		×	Signal status input from BCM
FR WIPER REQUEST	OFF/LO/HI	×	×	×	Signal status input from BCM
WIPER AUTO STOP	ON/OFF	×	×	×	IPDM E/R output status
WIPER PROTECTION	OFF/LS/HS/Block	×		×	IPDM E/R control status (LS: low speed operation/ HS: high speed operation/ BLOCK: wiper arm is locked)

CAUTION:

- Perform IPDM E/R data monitor with ignition switch ON. Monitoring with ignition switch in ACC position may cause an improper display.

ACTIVE TEST

Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "STOP" during a test to stop the operation.

Test item	Indication on CONSULT-II display	Description
front wiper	FRONT WIPER	Front wiper relay (HI/LO, main) can be operated by switching (OFF, High speed ON and Low speed ON) optionally.
Headlamp washer	HEADLAMP WASHER	Headlamp washer relay can be operated by switching (ON and OFF) optionally.

Front Wiper Does Not Operate

EKS00872

WW

1. CHECK FRONT WIPER OPERATION

With CONSULT-II

1. Select "IPDM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "FRONT WIPER" on "SELECT TEST ITEM" screen.
3. Make sure that front wipers operate normally.

Without CONSULT-II

1. Start up auto active test. Refer to [PG-42, "Auto Active Test"](#) .
2. Make sure that front wipers operate normally.

OK or NG

OK >> GO TO 5.
NG >> GO TO 2.

ACTIVE TEST	
FRONT WIPER	OFF
HI	LO
MODE	BACK
LIGHT	COPY

SKIA3486E

2. CHECK FUSE

Check 20A fuse (#38) (No.38, located in IPDM E/R).

OK or NG

OK >> GO TO 3.
NG >> Replace fuse.

FRONT WIPER AND WASHER SYSTEM

3. IPDM E/R INSPECTION

With CONSULT-II


Using active test, check voltage between IPDM E/R connector terminals 23, 24 and ground while front wiper relay (main, HI/LO) is operating.

- For IPDM E/R terminal inspection method, refer to [PG-49, "IPDM E/R Terminal Inspection"](#).

Without CONSULT-II

Start up auto active test, and check voltage between IPDM E/R connector terminals 23, 24 and ground while front wiper relay (main, HI/LO) is operating.

- For IPDM E/R terminal inspection method, refer to [PG-49, "IPDM E/R Terminal Inspection"](#).



Connector terminal		Measuring condition	Voltage
IPDM E/R	(-)		
Connector	Terminal (Wire color)		
E13	23 (Y)	Ground	Stopped Approx. 0
			LO operation Battery voltage
	24 (*1)		Stopped Approx. 0
			HI operation Battery voltage

*1: CR engine models (LG), K9K engine models (BR)

OK or NG

OK >> GO TO 4.

NG >> Replace IPDM E/R.

4. FRONT WIPER TO GROUND INSPECTION


- Turn ignition switch OFF.
- Disconnect front wiper motor harness connector.
- Check continuity between front wiper motor harness connector E44 terminal 1(B) and ground.

Continuity should exist.

OK or NG

OK >> Replace wiper motor.

NG >> Repair harness or connector.



FRONT WIPER AND WASHER SYSTEM

5. CHECK CAN COMMUNICATION CIRCUIT

Select "IPDM" by CONSULT-II, and perform self-diagnosis for "IPDM".

Are self-diagnosis results displayed?

NO DTC>>GO TO 6.

CAN COMM CIRCUIT>>Check CAN communication line. GO TO [BCS-31, "CAN Communication Inspection With CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	

LKIA0073E

6. CHECK COMBINATION SWITCH OPERATION

With CONSULT-II

Select "BCM" on CONSULT-II. With "WIPER" data monitor, confirm that "FR WIPER INT", "FR WIPER LOW", and "FR WIPER HI" turn ON-OFF according to wiper switch operation.

Without CONSULT-II

Refer to [LT-196, "Check Combination Switch"](#).

OK or NG

OK >> Replace BCM.

NG >> Refer to [LT-196, "Check Combination Switch"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
FR WIPER HI	OFF
FR WIPER LOW	OFF
FR WIPER INT	OFF
FR WASHER SW	OFF
INT VOLUME	1
FR WIPER STOP	ON
RR WIPER ON	OFF
RR WIPER INT	OFF
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

SKIA2175E

Front Wiper Does Not Return to Stop Position

EKS00873

1. CHECK AUTO STOP INPUT SIGNAL

With CONSULT-II

Select IPDM on CONSULT-II. Check ("FR WIPER STOP") in "DATA MONITOR" mode with CONSULT-II.

When front wiper is operating : FR WIPER STOP OFF

When front wiper is stopped : FR WIPER STOP ON

Without CONSULT-II

GO TO 2.

OK or NG

OK >> Replace IPDM E/R.

NG >> GO TO 2.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
FR WIPER HI	OFF
FR WIPER LOW	OFF
FR WIPER INT	OFF
FR WASHER SW	OFF
INT VOLUME	1
FR WIPER STOP	ON
RR WIPER ON	OFF
RR WIPER INT	OFF
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

SKIA2175E

WW

L

M

FRONT WIPER AND WASHER SYSTEM

2. CHECK IPDM E/R OUTPUT SIGNAL

Check voltage between IPDM E/R harness connector E16 terminal 55(OR) and ground while front wiper motor is stopped and while it is operating.


- For IPDM E/R terminal inspection method, refer to [PG-49, "IPDM E/R Terminal Inspection"](#).

Terminals		Condition	Voltage [V]
Connector	Terminal (Wire color)		
E16	55 (OR)	Wiper operating	Battery voltage
		Wiper stopped	Approx. 0

OK or NG

OK >> GO TO 3.

NG >> Replace front wiper motor.




3. CHECK AUTO STOP CIRCUIT

- Turn ignition switch OFF.
- Disconnect IPDM E/R connector and front wiper motor connector.
- Check continuity between IPDM E/R harness connector E16 terminal 55(OR) and front wiper motor harness connector E44 terminal 4(OR).
- Check continuity between IPDM E/R harness connector E16 terminal 55 (OR) and ground

55 (OR) – 4 (OR) :Continuity should exist.

55 (OR) – Ground :Continuity should not exist.



OK or NG

OK >> Replace IPDM E/R.

NG >> Repair harness or connector.

Front Wiper Low Speed Operation Does Not Operate

EKS00874

1. CHECK FRONT WIPER MOTOR LOW SPEED OPERATION

With CONSULT-II

- Select "IPDM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Select "FRONT WIPER" on "SELECT TEST ITEM" screen.
- Make sure that front wiper (low speed) operates normally.


Without CONSULT-II

- Start up auto active test. Refer to [PG-42, "Auto Active Test"](#).
- Make sure that front wiper (low speed) operates normally.

OK or NG

OK >> GO TO [LT-196, "Check Combination Switch"](#).

NG >> GO TO 2.



FRONT WIPER AND WASHER SYSTEM


2. CHECK IPDM E/R OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Front wiper switch turn to LO position.
3. Check voltage between IPDM E/R harness connector E13 terminal 23(Y) and ground.
- For IPDM E/R terminal inspection method, refer to [PG-49, "IPDM E/R Terminal Inspection"](#).

Battery voltage should exist

OK or NG

OK >> GO TO 3.
NG >> Replace IPDM E/R.



3. CHECK FRONT WIPER MOTOR CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector E13 terminal 23(Y) and front wiper motor harness connector E44 terminal 3(Y).
4. Check continuity between IPDM E/R harness connector E13 terminal 23 (Y) and ground.

23 (Y) – 3 (Y) :Continuity should exist.

23 (Y) – Ground :Continuity should not exist.

OK or NG

OK >> Replace front wiper motor.
NG >> Repair harness or connector.



Front Wiper High Speed Operation Does Not Operate

EKS00875

1. CHECK FRONT WIPER MOTOR HIGH SPEED OPERATION

With CONSULT-II


1. Select "IPDM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "FRONT WIPER" on "SELECT TEST ITEM" screen.
3. Make sure that front wiper (high speed) operates normally.

Without CONSULT-II

1. Start up auto active test. Refer to [PG-42, "Auto Active Test"](#).
2. Make sure that front wiper (high speed) operates normally.

OK or NG

OK >> GO TO [LT-196, "Check Combination Switch"](#).
NG >> GO TO 2.



FRONT WIPER AND WASHER SYSTEM


2. CHECK IPDM E/R OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Front wiper switch turn to HI position.
3. Check voltage between IPDM E/R harness connector E13 terminal 24(LG or BR) and ground.
- For IPDM E/R terminal inspection method, refer to [PG-49, "IPDM E/R Terminal Inspection"](#).

Battery voltage should exist

OK or NG

OK >> GO TO 3.
NG >> Replace IPDM E/R.



3. CHECK FRONT WIPER MOTOR CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector E13 terminal 24(LG or BR) and front wiper motor harness connector E44 terminal 2(LG or BR).
4. Check continuity between IPDM E/R harness connector E13 terminal 24(LG or BR) and ground.

24 (LG or BR) – 3 (LG or BR) :Continuity should exist.

24 (LG or BR) – Ground :Continuity should not exist.

OK or NG

OK >> Replace front wiper motor.
NG >> Repair harness or connector.



Front Wiper INT Does Not Operate

EKS00876

Refer to [LT-196, "Check Combination Switch"](#).

Front Wiper Interval Time Is Not Controlled by Vehicle Speed

EKS00879

1. CHECK CAN COMMUNICATION LINE


Select "BCM" by CONSULT-II, and perform self-diagnosis for "BCM".

Are self-diagnosis results displayed?

NO DTC>>GO TO 2

CAN COMM CIRCUIT>>Check CAN communication line of BCM.

GO TO [BCS-31, "CAN Communication Inspection With CONSULT-II \(Self-Diagnosis\)"](#).



2. CHECK COMBINATION METER

Confirm that speedometer operates normally.

OK or NG

OK >> Replace BCM.

NG >> Combination meter vehicle speed system malfunction. GO TO [DI-31, "Inspection/Vehicle Speed Signal"](#).

After Front Wipers Operate for 10 Seconds, They Stop for 20 Seconds

EKS0087A

CAUTION:

- When auto-stop signal has not varied for 10 seconds or longer while IPDM E/R is operating front wipers, IPDM E/R considers that front wipers are locked, and stops wiper output. That causes this symptom.
- This status can be checked by IPDM E/R DATA MONITOR on which "WIPER PROTECTION" item shows "Block".

1. CHECK IPDM E/R INPUT SIGNAL

With CONSULT-II

Select IPDM on CONSULT-II. Check ("FR WIPER STOP") in "DATA MONITOR" mode with CONSULT-II.

When front wiper is operating : FR WIPER STOP OFF

When front wiper is stopped : FR WIPER STOP ON

DATA MONITOR	
MONITOR	
IGN ON SW	ON
FR WIPER HI	OFF
FR WIPER LOW	OFF
FR WIPER INT	OFF
FR WASHER SW	OFF
INT VOLUME	1
FR WIPER STOP	ON
RR WIPER ON	OFF
RR WIPER INT	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

SKIA2175E

Without CONSULT-II

GO TO 2.

OK or NG

OK >> Replace IPDM E/R.

NG >> GO TO 2.

2. CHECK IPDM E/R OUTPUT SIGNAL


- Turn ignition switch ON.
- Front wiper switch turn to INT position.
- Check voltage between IPDM E/R harness connector E16 terminal 55(OR) and ground.
- For IPDM E/R terminal inspection method, refer to [PG-49, "IPDM E/R Terminal Inspection"](#).

Connector terminal		Condition	Voltage [V]
(+)	(-)		
Connector	Terminal (Wire color)		
E16	55 (OR)	Wiper operating	Battery voltage
		Wiper stopped	Approx. 0

OK or NG

OK >> GO TO 3.

NG >> Replace front wiper motor.



SKIA2172E

FRONT WIPER AND WASHER SYSTEM

3. CHECK FRONT WIPER MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector E16 terminal 55 (OR) and front wiper motor harness connector E44 terminal 4 (OR).
4. Check continuity between IPDM E/R harness connector E16 terminal 55 (OR) and ground.


55 (OR) – 4 (OR) :Continuity should exist.

55 (OR) – Ground :Continuity should not exist.

OK or NG

OK >> Replace IPDM E/R.

NG >> Repair harness or connector.



EKS0087B

Front Wipers Do Not Stop

Refer to PG-51, "Diagnosis of IPDM E/R Integrated Relay".


Removal and Installation of Front Wiper Arm

REMOVAL

EKS007B3

1. Turn the wiper switch ON to operate the wiper motor, then turn it OFF (auto stop).
2. Open hood, remove nut cover, and remove wiper arm nut.
3. Lift up driver wiper arm and remove wiper arm from vehicle.
4. Close hood, lift up passenger wiper arm, and remove wiper arm from vehicle.

Before attaching the front wiper arm, clean the arm mount shown in the figure to prevent nuts from being loosened.



ELH0717D


INSTALLATION

1. Lower wiper blade to glass so that center end of blade comes to the position shown in diagram. Align blade end with marking set within blade set position black print.)
2. Tighten wiper arm nuts.

Wiper arm nut:

: 20.6 - 26.5 N·m (2.1 - 2.7 kg·m, 15 - 20 ft-lb)

3. Spray washer fluid. Turn wiper switch ON to operate wiper motor, then turn it OFF (auto stop).
4. Make sure wiper blade stops at the position shown in the figure.



MKIB0495E

Stop position A : 33.7 - 48.7 mm (1.327 - 1.917 in)

Stop position B : 33.7 - 48.7 mm (1.327 - 1.917 in)

Adjustment of Front Wiper Arm Stop Position


EKS007B4

Refer to WW-42, "Removal and Installation of Front Wiper Arm".

FRONT WIPER AND WASHER SYSTEM

Removal and Installation of Front Wiper Motor and Link


EKS007B5



- 1. Wiper motor
- 2. Wiper link
- 3. Wiper frame
- 4. Wiper link
- 5. Pivot
- 6. Shaft seal

REMOVAL

1. Operate the wiper motor, and stop it at the auto stop position.
2. Remove wiper arm nuts, and remove wiper arm from vehicle.
3. Remove cowl top cover. Refer to [EI-10, "COWL TOP"](#) .
4. Remove wiper motor connector.
5. Remove shaft seal
6. Remove wiper motor assembly bolts and driver pivot nuts, and then remove wiper motor assembly from vehicle.
7. Remove the wiper link from the wiper frame and the motor arm.
8. Remove wiper motor screws, and then remove wiper motor from wiper frame.



INSTALLATION

1. Connect the wiper motor to the vehicle-side connector. Turn the wiper switch ON to operate the wiper motor, then turn the wiper switch OFF (auto stop).
2. Disconnect wiper motor connector.
3. Install wiper motor to wiper frame.

Wiper motor screw

① : 5.8 - 7.0 N·m (0.59 - 0.71 kg·m, 51 - 62 in·lb)

4. Install wiper link to wiper frame and motor arm.
5. Connect wiper motor assembly to the connector. Turn wiper switch ON to operate wiper motor, then turn wiper switch OFF (auto stop).
6. Install the wiper motor assembly to the vehicle.

FRONT WIPER AND WASHER SYSTEM

Wiper motor assembly bolt

: 3.8 - 5.1 N·m (0.39 - 0.52 kg·m, 34 - 45 in-lb)

Pivot nut

: 3.8 - 5.1 N·m (0.39 - 0.52 kg·m, 34 - 45 in-lb)

7. Install shaft seal
8. Install cowl top cover. Refer to [EI-10, "COWL TOP"](#).
9. Attach wiper arms.

CAUTION:

- Do not drop the wiper motor or cause it to contact other parts.
- Check the grease conditions of the motor arm and wiper link joint (at retainer). Apply grease if necessary.


NISSAN MP special grease No. 2 (KRB0012025)

Adjustment of Spray Positions of Front Washer Nozzle


EKS007B6

Adjust spray positions to match the positions listed below.

Spray position	h	l (width)	φ (spray point area)
A	165 (6.50)	375 (14.76)	80 (3.15)
B	342 (13.46)	157 (6.18)	80 (3.15)
C	253 (9.96)	109 (4.29)	80 (3.15)
D	347 (13.66)	299 (11.77)	80 (3.15)




To adjust the spray position, insert a needle or similar object into the spray opening and move up/down and left/right.



FRONT WIPER AND WASHER SYSTEM

Washer Hose Routing

EKS007B7




Removal and Installation of Front Washer Nozzle

EKS007B8


REMOVAL

1. Open hood.
2. While pushing nozzle spray point side along body, use the nozzle stop point as the support point and rotate nozzle to remove it from body.
3. Remove washer tube.



CHECK VALVE INSPECTION

Make sure air can pass through the hose by blowing forward (toward the nozzle) and air cannot pass through by sucking.



INSTALLATION

1. Install washer tube in nozzle.
2. Install nozzle to body.

FRONT WIPER AND WASHER SYSTEM

3. Adjust nozzle spray location.

CAUTION:

The spray points differ, so be sure to install left and right nozzles correctly.

Inspection of Front Wiper and Washer Switch Circuit

EKS007B9

Refer to [LT-196, "Check Combination Switch"](#).

Removal and Installation of Front Wiper and Washer Switch

EKS007BA


Refer to [LT-199, "Removal and Installation"](#).

Removal and Installation of Front Wiper and Washer Tank


EKS007BB

REMOVAL

1. Remove cap, with pushing down fill opening, remove washer tank inlet from radiator core support upper.



2. Remove fender protector. Refer to [EI-11, "FENDER PROTECTOR"](#).
3. Remove washer pump connector.
4. Remove washer tank bolts.



5. Remove the washer hose, and remove the washer tank from the vehicle.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

After installing, add water up to the top of the inlet washer tank. Make sure there is no leakage.

Washer tank mounting screw


 : 3.8 - 5.1 N·m (0.39 - 0.52 kg·m, 34 - 45 in-lb)

Removal and Installation of Front Wiper and Washer Pump

EKS007BC

REMOVAL

1. Remove fender protector. Refer to [EI-11, "FENDER PROTECTOR"](#).
2. Remove washer pump connector and hose.
3. Pull out the washer pump in the direction shown by the arrow, and remove the washer pump from the washer tank.



FRONT WIPER AND WASHER SYSTEM

INSTALLATION

Paying attention to the items listed below, install in the reverse order of removal.

CAUTION:

When installing the washer pump, there must be no twisting or other unusual stress on the packing.

A

B

C

D

E

F

G

H

I

J

WW

L

M


FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

PFP:28536

Components Parts and Harness Connector Location

EKS0087Y



System Description

EKS008WD

- Front wiper HI/LO relay and front wiper main relay are built into IPDM E/R.
- Wiper switch (combination switch) is composed of a combination of 5 output terminals and 5 input terminals. Terminal combination status is read by BCM when switch is turned ON.
- BCM controls front wiper LO, HI, and INT (intermittent) operation.
- IPDM E/R operates wiper motor according to CAN communication signals from BCM.

Power is supplied at all times

- through 20A fuse (NO.38, located in the IPDM E/R)
- to front wiper main relay.
- through 20A fuse (NO.52, located in the IPDM E/R)
- to IPDM E/R (CPU).
- through 40A fusible link (letter J, located in fuse and fusible link box)
- to BCM terminals 74 and 79.

When ignition switch ON or START position, power is supplied

- through 10A fuse [NO.4, located in fuse block (J/B)]
- to BCM terminal 24, and
- to rain sensor terminal 1.
- through 15A fuse [NO.1, located in fuse block (J/B)]
- to combination switch terminal 11, and
- to front wiper HI/LO relay, front wiper main relay and IPDM E/R (CPU)

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Ground is supplied

- through body grounds E25 (CR engine models), E26 and E40
- to front wiper motor terminal 1 and,
- to IPDM E/R terminals 3 and 54, and
- through body grounds M19 and M20
- to combination switch terminal 12
- to rain sensor terminal 3, and
- to BCM terminals 2 and 70

WIPER OPERATION

Low Speed Wiper Operation

When front wiper switch is placed in LO position, BCM read combination switch condition (Refer to [WW-51, "BCM WIPER SWITCH READING FUNCTION"](#)). And BCM sent front wiper request signal (LO) to IPDM E/R with CAN communication line. When IPDM E/R receives front wiper request signal (LO), it turns ON front wiper main relay (built into IPDM E/R).

Power is supplied

- to front wiper motor terminal 3,
- through front wiper main relay and front wiper HI/LO relay and
- through IPDM E/R terminal 23.

Ground is supplied

- to front wiper motor terminal 1,
- through body grounds E25 (CR engine models), E26 and E40.

With power and ground are supplied, the front wiper motor operates at low speed.

High Speed Wiper Operation

When front wiper switch is placed in HI position, BCM read combination switch condition (Refer to [WW-51, "BCM WIPER SWITCH READING FUNCTION"](#)). And BCM sent front wiper request signal (HI) to IPDM E/R with CAN communication line. When IPDM E/R receives front wiper request signal (HI), it turns ON front wiper HI/LO relay and front wiper main relay (built into IPDM E/R).

Power is supplied

- to front wiper motor terminal 2,
- through front wiper main relay and front wiper HI/LO relay and,
- through IPDM E/R terminal 24.

Ground is supplied

- to front wiper motor terminal 1
- through body grounds E25 (CR engine models), E26 and E40.

With power and ground are supplied, the front wiper motor operates at high speed.

Auto Wiper Operation

When the wiper switch is placed in the INT position, the wiper does not operate until rain sensor perceives rain.

When rain sensor detection of rain drop, rain sensor send rain signal to BCM

- from rain sensor terminal 2
- to BCM terminal 63.

BCM send wiper request signal to IPDM E/R with CAN communication line. IPDM E/R operate front wiper.

Change the wiper speed by rainfall.

The rain sensor sensitivity is controlled by the wiper volume switch combined with front wiper and washer switch and BCM.

Auto Stop Operation

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach stop position.

When wiper arms are not located at stop position with wiper switch OFF, power is supplied

- from terminal 23 of the IPDM E/R
- to front wiper motor terminal 3, in order to continue wiper motor operation at low speed.

Ground is supplied

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

- to front wiper motor terminal 1
- through body grounds E25 (CR engine models), E26 and E40.

When wiper arms reach stop position, front wiper motor terminals 1 and 4 are disconnected.

Then the IPDM E/R sends auto stop operation signal to BCM with CAN communication line.

When BCM receives auto-stop operation signal, BCM sends wiper stop signal to IPDM E/R with CAN communication line.

IPDM E/R stops wiper motor. Wiper motor will then stop wiper arms at the STOP position.

Mist Operation

When the wiper switch is placed in the mist position, wiper operate ones. The wiper operation is the same as the front wiper low speed operation. If the switch is held in the mist position, front wiper low speed operation continues.

WASHER OPERATION

When front wiper switch is pulled to washer position, power is supplied

- through combination switch terminal 13
- to washer motor terminal 1.

Ground is supplied

- to washer motor terminal 2
- through combination switch terminals 12 and 14, and
- through body times M19 and M20.

With power and ground supplied, the washer motor operates, and at the same time,

When the wiper switch is pulled to the WASH position for 1 second or more. BCM sends front wiper request signal (low) to IPDM E/R with CAN communication line. And the front wiper motor operates at low speed for approximately 3 times to clean wind shield


FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, front wiper low speed operates when the ignition switch is turned from OFF to ON or ACC and front wiper are stopped when the ignition switch is turned from ON or ACC to OFF. If the fail-safe system is operating, front wiper does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-19, "FAIL-SAFE FUNCTION"](#))

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

BCM WIPER SWITCH READING FUNCTION

BCM reads combination switch (wiper switch) status, and controls front wipers based on the results. BCM is a combination of 5 output terminals (output 1 - 5) and 5 input terminals (input 1 - 5). It reads 20 types of switch data and 5 types of diagnosis data.



Operation Description

- BCM operates output terminal (output 1 to 5) transistor at a set period and turns ON the current in order.
- When any (or multiple) switches are turned ON, a circuit is formed between the output terminals (output 1 to 5) and input terminals (input 1 to 5).
- At this time, when output terminals (output 1 to 5) operate transistors and carry current. If voltage of corresponding input terminal (input 1 to 5) changes, interface in BCM detects this state and judges that switch is ON.

Table Of BCM - Combination Switch Operations

BCM reads operation status of combination switch using combinations shown in table below.


	Combination SW INPUT 1		Combination SW INPUT 2		Combination SW INPUT 3		Combination SW INPUT 4		Combination SW INPUT 5	
	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
Combination SW OUTPUT 1	—	—	FR WIPER HI ON	FR WIPER HI OFF	V/INT 1 ON	V/INT 1 OFF	RR WIPER INT ON	RR WIPER INT OFF	V/INT 2 ON	V/INT 2 OFF
Combination SW OUTPUT 2	FR WASHER ON	FR WASHER OFF	—	—	RR WASHER ON	RR WASHER OFF	V/INT 3 ON	V/INT 3 OFF	RR WIPER ON	RR WIPER OFF
Combination SW OUTPUT 3	FR WIPER LOW ON	FR WIPER LOW OFF	FR WIPER INT ON	FR WIPER INT OFF	—	—	—	—	RR FOG ON	RR FOG OFF
Combination SW OUTPUT 4	TURN LH ON	TURN LH OFF	PASSING ON	PASSING OFF	HEADLAMP 2 ON	HEADLAMP 2 OFF	—	—	FR FOG ON	FR FOG OFF
Combination SW OUTPUT 5	TURN RH ON	TURN RH OFF	HEADLAMP 1 ON	HEADLAMP 1 OFF	HI BEAM ON	HI BEAM OFF	TAIL LAMP ON	TAIL LAMP OFF	—	—

MKIB0370E

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Example: (Wiper Switch Placed In LO Position)

- If front wiper switch is placed in LO position, the contact of front wiper LO in combination switch is turned ON. At this time, when output 1 transistor operates, driver control unit detects that voltage has been changed at input 3.
- When output 1 transistor is ON and BCM detects current changes at input 3, BCM determines that wiper switch is at LO. BCM uses CAN communication and sends front wiper signals to IPDM E/R.
- When output 1 transistor operates again and BCM detects voltage change at input 3, BCM recognizes that front wiper LO operation is continuing.



NOTE:

Each output terminal transistor operates at 20 ms intervals. Therefore, a delay occurs between the switch becoming ON and operation of the electric load. However, this delay is too small to be detected.

Intermittent Operation

Wiper intermittent operation delay interval is determined from a combination of 3 switches (V/INT 1, V/INT 2, and V/INT 3) and vehicle speed signal.

During each intermittent operation delay interval, BCM sends front wiper request signal to IPDM E/R.

Wiper Volume Position Setting

Wiper dial position	Intermittent interval	Combination switch		
		V/INT 1	V/INT 2	V/INT 3
Wiper volume position 1	Small	ON	ON	ON
Wiper volume position 2		ON	ON	OFF
Wiper volume position 3		ON	OFF	OFF
Wiper volume position 4		OFF	OFF	OFF
Wiper volume position 5		OFF	OFF	ON
Wiper volume position 6		OFF	ON	ON
Wiper volume position 7		OFF	ON	OFF

Example: For wiper volume position 1.

Using combination switch reading function, BCM reads ON/OFF status of V/INT 1, 2, and 3.

When combination switch status is as listed below, BCM determines that it is wiper volume position 1.

- V/INT 1: ON (input 1 and output 3 are conducting.)
- V/INT 2: ON (input 1 and output 5 are conducting.)
- V/INT 3: ON (input 2 and output 4 are conducting.)

BCM determines front wiper intermittent interval from wiper volume 1 and vehicle speed, and sends wiper request signal (INT) to IPDM E/R for every intermittent interval via CAN communication line.

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

CAN Communication SYSTEM DESCRIPTION

EKS00K7Q

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00K7R

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door									
Axle	2WD									
Engine	CR10DE/CR12DE/CR14DE				CR12DE/CR14DE				K9K	
Handle	LHD/RHD									
Brake control	ABS system				ESP system				ABS	
Transmission	A/T		M/T		A/T		M/T		M/T	
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable						
CAN communication unit										
ECM	x	x	x	x	x	x	x	x	x	x
Data link connector	x	x	x	x	x	x	x	x	x	x
Combination meter	x	x	x	x	x	x	x	x	x	x
Intelligent Key unit	x	x			x	x		x	x	
Drive computer	x		x		x		x		x	
EPS control unit	x	x	x	x	x	x	x	x	x	x
BCM	x	x	x	x	x	x	x	x	x	x
ABS actuator and electric unit (control unit)	x	x	x	x	x	x	x	x	x	x
TCM	x	x	x	x			x	x	x	
IPDM E/R	x	x	x	x	x	x	x	x	x	x
CAN communication type	WW-54, "TYPE 1/TYPE 2"		WW-57, "TYPE 3/TYPE 4"		WW-59, "TYPE 5/TYPE 6"		WW-62, "TYPE 7/TYPE 8"		WW-64, "TYPE 9/TYPE 10"	

x: Applicable


A
B
C
D
E
F
G
H
I
J
WW
L
M

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R				T		R
Door switch signal		R	R	R			T		R
Turn indicator signal		R					T		
Buzzer output signal		R					T		
		R	T						
MI signal	T	R		R					
Front wiper request signal							T		R
Front wiper stop position signal							R		T
Rear window defogger switch signal							T		R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R				T	
ABS operation signal	R							T	
Brake warning lamp signal		R		R				T	
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

A
B
C
D
E
F
G
H
I
J

WW

L

M

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)


Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal								T	R
Stop lamp switch signal		T							R
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T		R	
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T		R	
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A
B
C
D
E
F
G
H
I
J

WW

L


M

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal	R	T						


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
	R	T						
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

A
B
C
D
E
F
G
H
I
J

WW

L

M


FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Schematic


EKS00880



FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)


Wiring Diagram — A/WIP —

EKS00881




MKWA1462E

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)






FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)



FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Terminals and Reference Values for BCM

EKS00882

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
2	B	Ground	ON	—	Approx. 0
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	 SKIA2167J
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1			
14	P	Combination switch output 3	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	 SKIA2166J
15	W	Combination switch output 5			
33	R	Combination switch output 2			
34	Y	Combination switch output 4			
19	R	CAN H	—	—	—
24	OR	Ignition power supply	ON	—	Approx. 12
39	W	CAN L	—	—	—
63	BR	Rain sensor signal	ON	Wiper is stopped	 MKIB0173E
				Wiper is moving (Apply a few drops of water to detection attachment)	
70	B	Ground	ON	—	Approx. 0
74	W	Battery power supply	OFF	—	Approx. 12
79	Y	Battery power supply	OFF	—	Approx. 12

A

B

C

D

E

F

G

H

J

WW

L

M

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Terminals and Reference Values for IPDM E/R

EKS00883

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
3	B	Ground	ON	—	Approx. 0
23	Y	Low speed power source	ON	Wiper switch	OFF
				LO	Battery voltage
24	*1	High speed power source	ON	Wiper switch	OFF
					Approx. 0
52	R	CAN H	—	—	—
54	B	Ground	—	—	Approx. 0
55	OR	Wiper auto stop signal	ON	Wiper operating	
				Wiper stopped	
58	W	CAN L	—	—	—

*1: CR engine models (LG), K9K engine models (BR)

How to Proceed With Trouble Diagnosis

EKS00884

1. Confirm the symptoms and customer complaint.
2. Understand operation description and function description. Refer to [WW-48, "System Description"](#) .
3. Carry out the Preliminary check. Refer to [WW-72, "Preliminary Inspection"](#) .
4. Confirm front wiper does not operate by fail-safe control of IPDM E/R. Refer to [PG-19, "FAIL-SAFE FUNCTION"](#) .
5. Check symptom and repair or replace the cause of malfunction.
6. Does the front wiper operate normally? Yes: GO TO 7. No: GO TO 5.
7. INSPECTION END.

Preliminary Inspection

EKS008WE

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSE

- Check fuse and fusible link for blown-out.

Unit	Power source	Fuse No.
Front washer motor	Ignition ON or START	1
Front wiper main relay	Battery	38
BCM	Battery	J
	Ignition switch ON or START position	4

Refer to [WW-68, "Wiring Diagram — A/WIP —"](#)

OK or NG

OK >> GO TO 2.


NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse, Refer to [PG-4, "POWER SUPPLY ROUTING"](#) .

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position			
Connector	Terminal (Wire color)	(-)	OFF	ACC	ON
M50	74 (W)	Ground	Battery voltage	Battery voltage	Battery voltage
M50	79 (Y)		Battery voltage	Battery voltage	Battery voltage
M48	24 (OR)		0V	0V	Battery voltage



OK or NG


OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.

3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R harness connector and front wiper motor harness connector.
2. Check continuity between IPDM E/R harness connector, front wiper motor harness connector and ground.

Terminals		Continuity	
Connector	Terminal (Wire color)	(-)	Ground
E11	3 (B)		
E44	1 (B)		Yes



OK or NG


OK >> GO TO 4.

NG >> Harness for open ground circuit.

4. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminals		Continuity	
Connector	Terminal (Wire color)	(-)	Ground
M48	2 (B)		Yes
M50	70(B)		Yes



OK or NG

OK >> INSPECTION END.

NG >> Check harness ground circuit.

CONSULT-II Function (BCM)

EKS00886

Refer to [WW-31, "CONSULT-II Function \(BCM\)"](#).

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

CONSULT-II Function (IPDM E/R)

EKS008W1

Refer to [WW-33, "CONSULT-II Function \(IPDM E/R\)"](#).

Front Wiper Does Not Operate

EKS00889

Refer to [WW-35, "Front Wiper Does Not Operate"](#)

Front Wiper Does Not Return to Stop Position

EKS0088A

Refer to [WW-37, "Front Wiper Does Not Return to Stop Position"](#)

Front Wiper Low Speed Operation Does Not Operate.

EKS0088B

Refer to [WW-38, "Front Wiper Low Speed Operation Does Not Operate"](#)

Front Wiper High Speed Operation Does Not Operate

EKS0088C

Refer to [WW-39, "Front Wiper High Speed Operation Does Not Operate"](#)

Front Wiper INT Does Not Operate

EKS0088D

Refer to [LT-196, "Check Combination Switch"](#).

Auto Wiper Does Not Operate Properly

EKS0088T

1. CHECK RAIN SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rain sensor and ground.


Connector	Terminal (wire color)		Ignition switch position		
	(+)	(-)	OFF	ACC	ON
R3	1 (W)	Ground	0	0	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No.4, located in fuse block (J/B)].
- Harness for open or short between rain sensor and fuse.



2. CHECK RAIN SENSOR GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect rain sensor connector.
3. Check continuity between rain sensor harness connector R3 terminal 3 (B) and ground.

Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness ground circuit.



FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

3. CHECK RAIN SENSOR INPUT SIGNAL CIRCUIT


1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M49 terminal 63 (BR) and rain sensor harness connector R3 terminal 2 (BR).

Continuity should exist.

OK or NG



OK >> GO TO 4.


NG >> Repair harness or connector.



4. CHECK RAIN SENSOR INPUT SIGNAL

1. Connect BCM connector and rain sensor connector.
2. Turn ignition switch ON
3. Check voltage signal between BCM harness connector M49 terminal 63 (BR) and ground.

Wiper is stopped	Wiper is operate (Apply a few drops of water to detection attachment)
 MKIB0173E	 MKIB0174E



OK or NG

OK >> Replace BCM.

NG >> Replace rain sensor.

A
B
C
D
E
F
G
H
I
J

WW

L

M

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

After Front Wipers Operate for 10 Seconds, They Stop for 20 Seconds

EKS0088F

Refer to [WW-41, "After Front Wipers Operate for 10 Seconds, They Stop for 20 Seconds"](#).

Front Wipers Do Not Stop

EKS0088G

Refer to [PG-49, "IPDM E/R Terminal Inspection"](#).


Removal and Installation of Front Wiper Arm

EKS008WF

REMOVAL

1. Turn the wiper switch ON to operate the wiper motor, then turn it OFF (auto stop).
2. Open hood, remove nut cover, and remove wiper arm nut.
3. Lift up driver wiper arm and remove wiper arm from vehicle.
4. Close hood, lift up passenger wiper arm, and remove wiper arm from vehicle.

Before attaching the front wiper arm, clean the arm mount shown in the figure to prevent nuts from being loosened.



INSTALLATION

1. Lower wiper blade to glass so that center end of blade comes to the position shown in diagram. Align blade end with marking set within blade set position black print.)
2. Tighten wiper arm nuts.


Wiper arm nut:

20.6 - 26.5 N·m (2.1 - 2.7 kg·m, 15- 20 ft-lb)

3. Spray washer fluid. Turn wiper switch ON to operate wiper motor, then turn it OFF (auto stop).
4. Make sure wiper blade stops at the position shown in the figure.

Stop position A : 33.7 - 48.7 mm (1.327 - 1.917 in)

Stop position B : 33.7 - 48.7 mm (1.327 - 1.917 in)



Adjustment of Front Wiper Arm Stop Position

EKS0088I

Refer to [WW-76, "Removal and Installation of Front Wiper Arm"](#).


FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Removal and Installation of Front Wiper Motor and Link

EKS0088J

A
B
C
D
E
F
G
H
I
J


WW
L
M



1. Wiper motor	2. Wiper link	3. Wiper frame
4. Wiper link	5. Pivot	6. Shaft seal

REMOVAL

1. Operate the wiper motor, and stop it at the auto stop position.
2. Remove wiper arm nuts, and remove wiper arm from vehicle.
3. Remove cowl top cover. Refer to [EI-10, "COWL TOP"](#) .
4. Remove wiper motor connector.
5. Remove shaft seal
6. Remove wiper motor assembly bolts and driver pivot nuts, and then remove wiper motor assembly from vehicle.
7. Remove the wiper link from the wiper frame and the motor arm.
8. Remove wiper motor screws, and then remove wiper motor from wiper frame.



INSTALLATION

1. Connect the wiper motor to the vehicle-side connector. Turn the wiper switch ON to operate the wiper motor, then turn the wiper switch OFF (auto stop).
2. Disconnect wiper motor connector.
3. Install wiper motor to wiper frame.

Wiper motor screw

$\text{N} \cdot \text{m}$ ($0.59 - 0.71 \text{ kg} \cdot \text{m}$, $51 - 62 \text{ in} \cdot \text{lb}$)

4. Install wiper link to wiper frame and motor arm.
5. Connect wiper motor assembly to the connector. Turn wiper switch ON to operate wiper motor, then turn wiper switch OFF (auto stop).
6. Install the wiper motor assembly to the vehicle.

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Wiper motor assembly bolt

: 3.8 - 5.1 N·m (0.39 - 0.52 kg·m, 34 - 45 in-lb)

Pivot nut

: 3.8 - 5.1 N·m (0.39 - 0.52 kg·m, 34 - 45 in-lb)

7. Install shaft seal
8. Install cowl top cover. Refer to [EI-10, "COWL TOP"](#).
9. Attach wiper arms.

CAUTION:

- Do not drop the wiper motor or cause it to contact other parts.
- Check the grease conditions of the motor arm and wiper link joint (at retainer). Apply grease if necessary.

NISSAN MP special grease No. 2 (KRB0012025)


Adjustment of Spray Positions of Front Washer Nozzle

EKS0088K


Adjust spray positions to match the positions listed below.

Unit: mm (in)

Spray position	h	l (width)	ϕ (spray point area)
A	165 (6.50)	375 (14.76)	80 (3.15)
B	342 (13.46)	157 (6.18)	80 (3.15)
C	253 (9.96)	109 (4.29)	80 (3.15)
D	347 (13.66)	299 (11.77)	80 (3.15)




To adjust the spray position, insert a needle or similar object into the spray opening and move up/down and left/right.



FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

Washer Hose Routing

EKS0088L




MKIB0480E

Removal and Installation of Front Washer Nozzle

REMOVAL


1. Open hood.
2. While pushing nozzle spray point side along body, use the nozzle stop point as the support point and rotate nozzle to remove it from body.
3. Remove washer tube.



MKIB0481E

CHECK VALVE INSPECTION

Make sure air can pass through the hose by blowing forward (toward the nozzle) and air cannot pass through by sucking.



MKIB0482E

INSTALLATION

1. Install washer tube in nozzle.
2. Install nozzle to body.

FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

3. Adjust nozzle spray location.

CAUTION:

The spray points differ, so be sure to install left and right nozzles correctly.

Inspection of Front Wiper and Washer Switch Circuit

EKS0088N

Refer to [LT-196, "Check Combination Switch"](#).

Removal and Installation of Front Wiper and Washer Switch

EKS0088O


Refer to [LT-199, "Removal and Installation"](#).

Removal and Installation of Front Wiper and Washer Tank


EKS0088P

REMOVAL

1. Remove cap, and while pushing down fill opening, remove washer tank inlet from radiator core support upper.



2. Remove fender protector. Refer to [EI-11, "FENDER PROTECTOR"](#).
3. Remove washer pump connector.
4. Remove washer tank bolts.



5. Remove the washer hose, and remove the washer tank from the vehicle.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

After installing, add water up to the top of the inlet washer tank. Make sure there is no leakage.

Washer tank mounting screw


: 3.8 - 5.1 N·m (0.39 - 0.52 kg·m, 34 - 45 in-lb)

Removal and Installation of Front Wiper and Washer Pump

EKS0088Q

REMOVAL

1. Remove fender protector. Refer to [EI-11, "FENDER PROTECTOR"](#).
2. Remove washer pump connector and hose.
3. Pull out the washer pump in the direction shown by the arrow, and remove the washer pump from the washer tank.



FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR)

INSTALLATION

Paying attention to the items listed below, install in the reverse order of removal.

CAUTION:


When installing the washer pump, there must be no twisting or other unusual stress on the packing.

Removal and Installation of Rain Sensor

REMOVAL

1. Remove inside mirror. Refer to [GW-80, "INSIDE MIRROR"](#).
2. Remove clip and pawl.
3. Pull out the rain sensor.
4. Remove rain sensor harness connector.

SMA for VIN >SJNxAK12U1000000



INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

WW

L

M


REAR WIPER AND WASHER SYSTEM

REAR WIPER AND WASHER SYSTEM

PFP:28710

Components Parts and Harness Connector Location

EKS0087E



System Description

EKS0087F

- Wiper switch (combination switch) is composed of a combination of 5 output terminals and 5 input terminals. Terminal combination status is read by BCM when switch is turned ON.
- BCM controls rear wiper and INT (intermittent) operation.

Power is supplied at all times

- through 40A fusible link (letter J, located in fuse and fusible link box)
- to BCM terminals 74 and 79.

When ignition switch turned ON or START position, power is supplied

- through 10A fuse [No. 4 located in the fuse block (J/B)]
- to BCM terminal 24.
- through 15A fuse [No. 1 located in the fuse block (J/B)]
- to combination switch terminal 11.

Ground is supplied

- through body grounds M19 and M20
- to BCM terminals 2 and 70, and
- to combination switch terminal 12.
- through body ground B17, B23, B44 and B51
- to rear wiper motor terminal 3.

WIPER OPERATION

BCM read combination switch condition (Refer to [WW-83, "BCM WIPER SWITCH READING FUNCTION"](#)),
Power is supplied

- through BCM terminal 71
- to rear wiper motor terminal 1.

REAR WIPER AND WASHER SYSTEM

Ground is supplied

- to rear wiper motor terminal 3
- through body grounds B17, B23, B44 and B51.

With power and ground supplied, the rear wiper motor operates.

INTERMITTENT OPERATION

The rear wiper motor operates the wiper arms at low speed of approximately every 7 seconds. This feature is controlled by the BCM.

When rear wiper switch is placed in INT position, BCM read combination switch condition (Refer to [WW-83, "BCM WIPER SWITCH READING FUNCTION"](#)), power is supplied.

- through BCM terminal 71.
- to rear wiper motor terminal 1

Ground is supplied.

- to rear wiper motor terminal 3
- through body ground B17, B23, B44 and B51.

The wiper motor operates at intermittent.

WASHER OPERATION

When rear wiper switch is pushed to WASH position,

Power is supplied.

- through combination switch terminal 14
- to washer motor terminal 2.

Ground is supplied

- to washer motor terminal 1
- to combination switch terminals 12 and 13, and
- through grounds M19 and M20.


With power and ground supplied, the rear washer motor is operated, and at the same time,

When the wiper switch is pushed to the WASH position for 1 second or more, BCM reads combination switch condition (Refer to [WW-83, "BCM WIPER SWITCH READING FUNCTION"](#)), rear wiper motor is operated by BCM, and the rear wiper motor operates approximately 3 times after wiper switch is released.

BCM WIPER SWITCH READING FUNCTION

BCM reads combination switch (wiper switch) status, and controls rear wipers based on the results.

BCM is a combination of 5 output terminals (output 1 - 5) and 5 input terminals (input 1 - 5). It reads 20 types of switch data and 5 types of diagnosis data.



REAR WIPER AND WASHER SYSTEM

Operation Description

- BCM operates output terminal (output 1 to 5) transistor at a set period and turns ON the current in order.
- When any (or multiple) switches are turned ON, a circuit is formed between the output terminals (output 1 to 5) and input terminals (input 1 to 5).
- At this time, when output terminals (output 1 to 5) operate transistors and carry current. If voltage of corresponding input terminal (input 1 to 5) changes, interface in BCM detects this state and judges that switch is ON.

Table of BCM - Combination Switch Operations

BCM reads operation status of combination switch using combinations shown in table below.

	Combination SW INPUT 1		Combination SW INPUT 2		Combination SW INPUT 3		Combination SW INPUT 4		Combination SW INPUT 5	
	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
Combination SW OUTPUT 1	—	—	FR WIPER HI ON	FR WIPER HI OFF	V/INT 1 ON	V/INT 1 OFF	RR WIPER INT ON	RR WIPER INT OFF	V/INT 2 ON	V/INT 2 OFF
Combination SW OUTPUT 2	FR WASHER ON	FR WASHER OFF	—	—	RR WASHER ON	RR WASHER OFF	V/INT 3 ON	V/INT 3 OFF	RR WIPER ON	RR WIPER OFF
Combination SW OUTPUT 3	FR WIPER LOW ON	FR WIPER LOW OFF	FR WIPER INT ON	FR WIPER INT OFF	—	—	—	—	RR FOG ON	RR FOG OFF
Combination SW OUTPUT 4	TURN LH ON	TURN LH OFF	PASSING ON	PASSING OFF	HEADLAMP 2 ON	HEADLAMP 2 OFF	—	—	FR FOG ON	FR FOG OFF
Combination SW OUTPUT 5	TURN RH ON	TURN RH OFF	HEADLAMP 1 ON	HEADLAMP 1 OFF	HI BEAM ON	HI BEAM OFF	TAIL LAMP ON	TAIL LAMP OFF	—	—


MKIB0370E

Sample Operation: (Rear Wiper Switch Placed In LO Position)

- If rear wiper switch is turned to ON position, the contact of rear wiper ON in combination switch is turned ON. At this time, when output 5 transistor operates, driver control unit detects that voltage has been changed at input 2.
- When output 5 transistor is ON and BCM detects current changes at input 2, BCM determines that wiper switch is at ON.

REAR WIPER AND WASHER SYSTEM

- When output 5 transistor operates again and BCM detects voltage change at input 2, BCM recognizes that rear wiper ON operation is continuing.



NOTE:

Each OUTPUT terminal transistor is activate at 20 ms intervals. Therefore, after a switch is turned ON, electrical loads are activated with a time delay. However, this delay is so small it is undetectable.

CAN Communication SYSTEM DESCRIPTION

EKS00K7S

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00K7T

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door												
Axle	2WD												
Engine	CR10DE/CR12DE/CR14DE					CR12DE/CR14DE			K9K				
Handle	LHD/RHD												
Brake control	ABS system				ESP system				ABS				
Transmission	A/T		M/T		A/T		M/T		M/T				
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable			

CAN communication unit

ECM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Data link connector	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Combination meter	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Intelligent Key unit	x	x			x	x			x	x			x	x			x	x		
Drive computer	x		x		x		x		x		x		x		x		x		x	
EPS control unit	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
BCM	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x

REAR WIPER AND WASHER SYSTEM

Body type	3door/5door									
Axle	2WD									
Engine	CR10DE/CR12DE/CR14DE				CR12DE/CR14DE				K9K	
Handle	LHD/RHD									
Brake control	ABS system				ESP system				ABS	
Transmission	A/T		M/T		A/T		M/T		M/T	
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable						
CAN communication unit										
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×				×	×	
IPDM E/R	×	×	×	×	×	×	×	×	×	×
CAN communication type	<u>WW-87, "TYPE 1/TYPE 2"</u>		<u>WW-90, "TYPE 3/TYPE 4"</u>		<u>WW-92, "TYPE 5/TYPE 6"</u>		<u>WW-95, "TYPE 7/TYPE 8"</u>		<u>WW-97, "TYPE 9/TYPE 10"</u>	


×: Applicable

REAR WIPER AND WASHER SYSTEM


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

REAR WIPER AND WASHER SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R				T		R
Door switch signal		R	R	R			T		R
Turn indicator signal		R					T		
Buzzer output signal		R					T		
		R	T						
MI signal	T	R		R					
Front wiper request signal							T		R
Front wiper stop position signal							R		T
Rear window defogger switch signal							T		R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R				T	
ABS operation signal	R							T	
Brake warning lamp signal		R		R				T	
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

REAR WIPER AND WASHER SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

I

J

WW

L


M

REAR WIPER AND WASHER SYSTEM


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

REAR WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 L
 M
 WW

REAR WIPER AND WASHER SYSTEM


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

REAR WIPER AND WASHER SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 WW

L
 M

REAR WIPER AND WASHER SYSTEM


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction sig- nal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

REAR WIPER AND WASHER SYSTEM


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

REAR WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


REAR WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal	R	T						


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



REAR WIPER AND WASHER SYSTEM

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

REAR WIPER AND WASHER SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A

B

C

D

E

F

G

H

I

J

WW

L

M



REAR WIPER AND WASHER SYSTEM

Wiring Diagram — WIP/R —

SMA for VIN >SJN**AK12U1309269 EKS0087H

WW-WIP/R-01

 : WITH ESP
 : WITHOUT ESP




M1 -SUPER MULTIPLE

JUNCTION (SMJ)

M16 -FUSE BLOCK-




REAR WIPER AND WASHER SYSTEM



REAR WIPER AND WASHER SYSTEM

Terminals and Reference Values for BCM

EKS0087G

Terminal No.	Wire color	Signal designation	Measuring condition		Reference value (V)	
			Ignition switch	Operation or condition		
2	B	Ground	ON	—	Approx. 0	
7	BR	Combination switch input 5	ON	Headlamps, turn signal, wipers OFF	 SKIA2167J	
8	L	Combination switch input 3				
9	PU	Combination switch input 1				
27	GY	Combination switch input 4				
28	G	Combination switch input 2				
13	GY	Combination switch output 1	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	 SKIA2166J	
14	P	Combination switch output 3				
15	W	Combination switch output 5		Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)		
33	R	Combination switch output 2				
34	Y	Combination switch output 4			 SKIA2167J	
23	P	Rear wiper position detection signal	ON	Rear wiper operating	Approx. 0	
				Rear wiper not operating	Approx. 12	
24	OR	Ignition power supply	ON	—	Approx. 12	
70	B	Ground	ON	—	Approx. 0	
71	BR	Rear wiper operation signal	ON	Rear wiper operating	Approx. 12	
				Rear wiper not operating	Approx. 0	
74	W	Battery power supply	OFF	—	Approx. 12	
79	Y	Battery power supply	OFF	—	Approx. 12	

How to Proceed With Trouble Diagnosis

EKS0087I

1. Confirm the symptoms and customer complaint.
2. Understand operation description and function description. Refer to [WW-82, "System Description"](#) .
3. Carry out the Preliminary check. Refer to [WW-103, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the rear wiper operate normally? Yes: GO TO 6. No: GO TO 4.
6. INSPECTION END.

REAR WIPER AND WASHER SYSTEM

Preliminary Check

CHECK POWER SUPPLY AND GROUND CIRCUIT

EKS008WI

1. CHECK FUSES

- Check fuse and fusible link for blown-out.

UNIT	POWER SOURCE	FUSE No.
BCM	Battery	J
	Ignition switch ON or START position	4
Combination switch	Ignition switch (ON)	1

Refer to [WW-100, "Wiring Diagram — WIP/R —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#).

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position		
Connector	(+)	(-)	OFF	ACC
M50	74 (W)	Ground	Battery voltage	Battery voltage
	79 (Y)		Battery voltage	Battery voltage
	24 (OR)		0V	0V



OK or NG


OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminals		Continuity	
Connector	(+)	(-)	
M48	2 (B)	Ground	Yes
M50	70(B)	Ground	Yes



OK or NG

OK >> INSPECTION END.

NG >> Check harness ground circuit.

CONSULT-II Function (BCM)

EKS007BF

Refer to [WW-31, "CONSULT-II Function \(BCM\)"](#).

REAR WIPER AND WASHER SYSTEM

Rear Wiper Does Not Operate

EKS0087K

1. CHECK REAR WIPER OPERATION

With CONSULT-II

1. Select "BCM" by CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "REAR WIPER" on "SELECT TEST ITEM" screen.
3. Make sure that rear wipers operate normally.

Without CONSULT-II

1. Start up auto active test. Refer to [PG-42, "Auto Active Test"](#).
2. Make sure that rear wipers operate normally.

OK or NG

OK >> GO TO [LT-196, "Check Combination Switch"](#).
NG >> GO TO 2.

ACTIVE TEST	
RR WIPER	OFF
ON	
MODE	BACK LIGHT COPY

SKIA3503E


2. CHECK BCM OUTPUT SIGNAL

1. Turn ignition switch to ON.
2. Rear wiper switch is in placed in ON position.
3. Check voltage between BCM harness connector M50 terminal 71(BR) and ground.

Connector terminal		Measuring condition	Voltage [V]
(+)	(-)		
Connector	Terminal (wire color)		
B53	71 (BR)	Ground	Rear wiper stopped
			Approx 0
			Rear wiper operating
			Battery voltage

OK or NG

OK >> GO TO 3.
NG >> Replace BCM.



3. CHECK REAR WIPER MOTOR CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM and rear wiper connector.
3. Check continuity between BCM harness connector M50 terminal 71(BR) and rear wiper motor harness connector B53 terminal 1(BR).
4. Check continuity between BCM harness connector M50 terminal 71(BR) and ground.

71 (BR) – 1 (BR) :Continuity should exist.

71 (BR) – Ground :Continuity should not exist.

OK or NG

OK >> GO TO 4.
NG >> Repair or replace harness.



REAR WIPER AND WASHER SYSTEM


4. CHECK REAR WIPER MOTOR GROUND

Check continuity between rear wiper motor harness connector B53 terminal 3(B) and ground.

Continuity should exist.

OK or NG

OK >> Replace rear wiper motor.
NG >> Repair harness or connector.



EKS0087L

Rear Wiper Stop Position Is Not Restored

1. CHECK AUTO STOP INPUT SIGNAL

With CONSULT-II

Select BCM on CONSULT-II. Check ("RR WIPER STOP") in "DATA MONITOR" mode with CONSULT-II.

When rear wiper is operating : RR WIPER STOP OFF
When rear wiper is stopped : RR WIPER STOP ON

DATA MONITOR	
MONITOR	
FR WIPER INT	ON
FR WASHER SW	OFF
INT VOLUME	1
FR WIPER STOP	OFF
RR WIPER ON	OFF
RR WIPER INT	OFF
RR WASHER SW	OFF
RR WIPER STOP	OFF
VEHICLE SPEED	0.4 km/h
Page Up	
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

MKIB0498E

Without CONSULT-II

GO TO 2.

OK or NG

OK >> Replace BCM.
NG >> GO TO 2.

2. CHECK BCM OUTPUT SIGNAL


While rear wiper motor is stopped and while operating, measure voltage between rear wiper motor connector terminal 2 and ground.

1. Turn ignition switch is ON.
2. Rear wiper switch is placed in INT position.
3. Check voltage between BCM and rear wiper motor.

Connector	(+)	(-)	Condition	Voltage [V]
Connector	Terminal (wire color)			
B53	2 (P)	Ground	Wiper operating	Approx. 0
			Wiper stopped	Battery voltage

OK or NG

OK >> GO TO 3.
NG >> Replace BCM.




MKIB0504E

REAR WIPER AND WASHER SYSTEM

3. CHECK AUTO STOP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the BCM connector and rear wiper motor connector.
3. Check continuity between BCM harness connector M48 terminal 23(P) and front wiper motor harness connector B53 terminal 2(P).

Continuity should exist.




4. Check continuity between rear wiper motor harness connector B53 terminal 3(B) and ground.

Continuity should exist.

OK or NG

OK >> Replace rear wiper motor.
NG >> Repair harness or connector.



Only Rear Wiper INT Does Not Operate

EKS0087M


Refer to [LT-196, "Check Combination Switch"](#), and check it.

Removal and Installation of Rear Wiper Arm REMOVAL

EKS007BH

1. Turn the wiper switch ON to operate the wiper motor, then turn it OFF (auto stop).
2. Lift up nut cover and remove nut.
3. Raise wiper arm, and remove wiper arm from the vehicle.

When attaching rear wiper arm, clean wiper installation location as shown in figure to prevent loosening of nut.




INSTALLATION

1. Lower wiper blade to glass so that center end of blade comes to the position shown in diagram.
2. Tighten the wiper arm with nuts and install the nut cover.

Wiper arm nut:

10.8 - 13.2 N·m (1.1 - 1.3 kg·m, 8- 10 ft-lb)

3. Spray washer fluid. Turn wiper switch ON to operate wiper, then turn it OFF (auto-stop).
4. Make sure wiper blade stops at the position shown in the figure.



REAR WIPER AND WASHER SYSTEM

Stop position A : 25.5 - 40.5 mm (1.004 - 1.594 in)

NOTE:

Installation is made easier by aligning wiper blade end to line under black printing.


Adjusting Rear Wiper Arm Stop Position

EKS007BI

Refer to [WW-106, "Removal and Installation of Rear Wiper Arm"](#).

Removal and Installation of Rear Wiper Motor


EKS007BJ



1. Rear wiper motor
2. Seal rubber
3. Rear wiper arm
4. Wiper blade

REMOVAL

1. Remove back door finisher. Refer to [EI-18, "BACK DOOR TRIM"](#).
2. Turn wiper switch ON to operate wiper, then turn it OFF (auto-stop).
3. Disconnect wiper motor connector.
4. Lift up nut cover, remove wiper arm nut, and lift up wiper arm to remove it from vehicle.
5. Remove wiper motor screws. Remove wiper motor from vehicle.
6. Remove seal rubber from vehicle.



CAUTION:

Do not drop the wiper motor or cause it to contact other parts.

INSTALLATION

1. Remove seal rubber from vehicle.
2. Attach wiper motor to vehicle.

Wiper motor screw

: 4.3 - 5.8 N·m (0.44 - 0.59 kg·m, 38 - 51 in-lb)

3. Connect the wiper motor to the vehicle-side connector. Turn the wiper switch ON to operate the wiper motor, then turn the wiper switch OFF (auto stop).
4. Attach wiper arm to vehicle.

Wiper arm nut:

: 10.8 - 13.2 N·m (1.1 - 1.3 kg·m, 8 - 10 ft-lb)

REAR WIPER AND WASHER SYSTEM

5. Adjust wiper arm stop position.
6. Put down nut cover.
7. Install back door finisher. Refer to [EI-18, "BACK DOOR TRIM"](#) .

Rear Wiper Blade


REMOVAL AND INSTALLATION

EKS007BK

1. Hold the wiper blade with both hands, push arm end in arrow B direction, remove lock, and remove blade.

CAUTION:

To replace blade, replace blade assembly.




Adjusting Rear Washer Nozzle Spray Position


EKS007BL

Adjust spray positions to match the positions listed below.

Spray position	H (height)	ϕ (spray point area)
A	20	30



To adjust the spray position, insert a needle or similar object into the spray opening and move up/down and left/right.



Rear Washer Hose Circuit


EKS007BM

Refer to [WW-45, "Washer Hose Routing"](#) .

Removal and Installation of Rear Washer Nozzle REMOVAL

EKS007BN


1. Remove high-mount stop lamp. Refer to [LT-182, "HIGH-MOUNTED STOP LAMP"](#) .
2. Remove washer nozzle from washer hose.
3. Push outward while pushing hooks on back of nozzle.



REAR WIPER AND WASHER SYSTEM

CHECK VALVE INSPECTION

Make sure air can pass through the hose by blowing forward (toward the nozzle) and air cannot pass through by sucking.



INSTALLATION

1. Install in the reverse order of removal.
2. Nozzle spray position must be adjusted.

Rear Wiper and Washer Switch Circuit Inspection

EKS007BO

Refer to [LT-196, "Check Combination Switch"](#) .

Removal and Installation of Rear Wiper and Washer Switch

EKS007BP

Refer to [LT-199, "Removal and Installation"](#) .

Removal and Installation of Rear Wiper and Washer Tank

EKS007BQ

Refer to [WW-46, "Removal and Installation of Front Wiper and Washer Tank"](#) .

Removal and Installation of Rear Wiper and Washer Pump

EKS007BR

Refer to [WW-46, "Removal and Installation of Front Wiper and Washer Pump"](#) .

A
B
C
D

E

F

G

H

J

WW

L

M

HEADLAMP WASHER

PFP:28620

System Description

EKS0087R

- Wiper switch (combination switch) is composed of a combination of 5 output terminals and 5 input terminals. Terminal combination status is read by BCM when switch is turned ON.
- BCM controls headlamp washer operation.
- IPDM E/R operates headlamp washer motor according to CAN communication signals from BCM.

Power is supplied at all times

- through 30 A fusible link (letter L, located in fuse and fusible link box).
- to headlamp washer relay terminals 1 and 3.
- through 40 A fusible link (letter J, located in fuse and fusible link box).
- to BCM terminals 74 and 79.
- through 20 A fuse (NO.52, located in IPDM E/R).
- to IPDM E/R (CPU).

When ignition switch ON or START position, power is supplied

- to IPDM E/R (CPU), and
- through 10 A fuse [NO.4, located in fuse block (J/B)]
- to BCM terminal 24.

Ground is supplied

- to IPDM E/R terminals 3 and 54, and
- to head lamp washer motor terminal 1,
- through body grounds E25 (CR engine models), E26 and E40.
- to BCM terminals 2 and 70, and
- to head lamp washer switch terminal 2,
- through body grounds M19 and M20.

HEADLAMP WASHER OPERATION

When lighting switch is placed in 1st position, BCM read combination switch condition (Refer to [WW-83, "BCM WIPER SWITCH READING FUNCTION"](#)).

And headlamp washer switch ON, ground is supplied.

- to BCM terminal 62, and
- through headlamp washer switch terminal 1 and 2.
- through body grounds M19 and M20.

BCM sends headlamp washer request signal to IPDM E/R with CAN communication line.

And IPDM E/R is grounded to headlamp washer relay terminal 2 through IPDM E/R terminal 56.

Then headlamp washer relay is energized, power is supplied.

- through headlamp washer relay terminal 5
- to headlamp washer motor terminal 2.

Ground is supplied.

- to terminal 1 of headlamp washer motor
- through body grounds E25 (CR engine models), E26 and E40.



With power and ground supplied, the headlamp washer operates.

HEADLAMP WASHER

Wiring Diagram —HLC—



SMA for VIN >SJN**AK12U1133256 EKS0087S

WW-HLC-01



HEADLAMP WASHER

WW-HLC-02



MKWA1817E

WW-112

CONSULT-II Function (BCM)

EKS008WJ

Refer to [WW-31, "CONSULT-II Function \(BCM\)"](#).

CONSULT-II Function (IPDM E/R)

EKS008WK

Refer to [WW-33, "CONSULT-II Function \(IPDM E/R\)"](#).

Removal and Installation for Washer Nozzle REMOVAL

EKS0087T

1. Remove front bumper. Refer to [EI-4, "FRONT BUMPER"](#)
2. Remove washer tube.
3. Remove washer nozzle from front bumper.

INSTALLATION

Install in the reverse order of removal.

Removal and Installation for Washer Tank

EKS0087V

Refer to [WW-46, "Removal and Installation of Front Wiper and Washer Tank"](#),


Removal and Installation for Washer Pump

EKS0087W

1. Remove front bumper. Refer to [EI-4, "FRONT BUMPER"](#)
2. Remove washer pump connector and hose.
3. Pull out washer pump in the direction of the arrow in the figure, and remove the washer pump from the washer tank.


CAUTION:

When installing washer pump, there should be no packing twist, etc.



Washer Tube Layout

EKS0087X



HORN

HORN

PFP:25610





Wiring Diagram —HORN—

SMA for VIN >SJN**AK12U1309269

EKS008IL

WW-HORN-01

 : WITH GASOLINE ENGINE



REFER TO THE FOLLOWING.
M1 -SUPER MULTIPLE
JUNCTION (SMJ)

*:THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


HORN

Removal and Installation

EKS007CG

REMOVAL

1. Remove front grille. Refer to EI-8, "FRONT GRILLE" .
2. Remove horn nut.
3. Disconnect horn connectors, and the remove horn from vehicle.



INSTALLATION

Note the following, and install in the reverse order of the removal.

Horn nut

 15.6 - 18.6 N·m (1.6 - 1.9 kg·m, 12 - 14 ft-lb)

A

B

C

D

E

F

G

H

I

J

WW

L

M

POWER SOCKET


POWER SOCKET

PFP:253A2

Wiring Diagram —CIGAR—

EKS008IM

WW-CIGAR-01



2
1
M59
B

REFER TO THE FOLLOWING.
M16 -FUSE BLOCK-
JUNCTION BOX (J/B)

MKWA0805E


WW-116

POWER SOCKET

Removal and Installation

REMOVAL

1. Remove air conditioner panel. Refer to [IP-7, "L. Air Conditioner Finisher"](#).
2. Disconnect the power socket connector.
3. Remove inner socket while spreading tabs on the socket ring (2 locations).



INSTALLATION

Note the following, and install in the reverse order of the removal.

CAUTION:

Align inner socket protruding area with socket ring and install.

EKS007CH

A

B

C

D

E

F

G

H

I

J

WW

L

M

POWER SOCKET
