

# SECTION **DI**

## DRIVER INFORMATION SYSTEM

### CONTENTS

<b>APPLICATION NOTICE</b> .....	3	WITH ESP .....	25
How to Check Vehicle Type .....	3	Terminals and Reference Value for Combination	
<b>PRECAUTIONS</b> .....	4	Meter .....	26
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	Combination Meter Self-Diagnosis .....	26
Maintenance Information .....	4	PERFORMING SELF-DIAGNOSIS MODE .....	26
RHD MODELS .....	4	Trouble Diagnoses .....	30
LHD MODELS .....	4	PRELIMINARY CHECK .....	30
Precautions For Trouble Diagnosis .....	4	SYMPTOM CHART .....	32
CAN SYSTEM .....	4	Power Supply and Ground Circuit Check .....	33
Precautions For Harness Repair .....	4	Inspection/Vehicle Speed Signal .....	33
CAN SYSTEM .....	4	Inspection/Engine Revolution Signal .....	33
<b>COMBINATION METERS</b> .....	6	Inspection/Fuel Level Sensor Unit .....	34
Component Parts and Harness Connector Location... .....	6	FUEL LEVEL SENSOR UNIT .....	34
System Description .....	6	LOW-FUEL WARNING LAMP .....	34
POWER SUPPLY AND GROUND CIRCUIT .....	6	Inspection/Water Temperature Warning/indicator	
UNIFIED CONTROL METER .....	6	Lamp .....	35
DISPLAY CHANGE AFTER IGNITION SWITCH ON .....	7	Fuel Gauge Pointer Fluctuates Indicator Wrong	
HOW TO CHANGE THE DISPLAY FOR ODO/ TRIP METER .....	7	Value or Varies .....	35
WATER TEMPERATURE WARNING/INDICATOR LAMP .....	8	Fuel Gauge Does Not Move to FULL position .....	35
TACHOMETER .....	8	Fuel Gauge Does Not Work .....	36
FUEL GAUGE .....	8	Electrical Components Inspection .....	36
SPEEDOMETER .....	8	FUEL LEVEL SENSOR UNIT CHECK .....	36
CAN Communication .....	9	Removal and Installation for Combination Meter .....	36
SYSTEM DESCRIPTION .....	9	REMOVAL .....	36
CAN Communication Unit .....	9	INSTALLATION .....	36
TYPE 1/TYPE 2 .....	10	Disassembly and Assembly for Combination Meter .....	37
TYPE 3/TYPE 4/TYPE 5/TYPE 6 .....	13		
TYPE 7/TYPE 8 .....	15		
TYPE 9/TYPE 10/TYPE 11/TYPE 12 .....	18		
TYPE 13/TYPE 14 .....	20		
Combination Meter .....	22		
CHECK .....	22		
Schematic .....	23		
Wiring Diagram — METER — .....	24		
WITHOUT ESP .....	24		
<b>DRIVE COMPUTER</b> .....	38		
Component Parts and Harness Connector and Harness Connector Location .....	38		
System Description .....	38		
DRIVE COMPUTER .....	38		
MAINTENANCE .....	40		
OIL LEVEL INDICATOR .....	40		
HOW TO CHANGE FOR STEERING SWITCH..	40		
OUTSIDE AIR TEMPERATURE .....	41		
CAN Communication .....	42		
SYSTEM DESCRIPTION .....	42		
CAN Communication Unit .....	42		
TYPE 1/TYPE 2 .....	43		
TYPE 3/TYPE 4/TYPE 5/TYPE 6 .....	46		

---

TYPE 7/TYPE 8 .....	48	RETRACTABLE HARD TOP WARNING CHIME..	80
TYPE 9/TYPE 10/TYPE 11/TYPE 12 .....	51	CAN Communication .....	81
TYPE 13/TYPE 14 .....	53	SYSTEM DESCRIPTION .....	81
Wiring Diagram — D/COMP — .....	55	CAN Communication Unit .....	81
Terminals and Reference Value for Combination		TYPE 1/TYPE 2 .....	82
Meter .....	57	TYPE 3/TYPE 4/TYPE 5/TYPE 6 .....	85
Self-Diagnosis Function .....	57	TYPE 7/TYPE 8 .....	87
Outside Air Temperature is not Displayed .....	58	TYPE 9/TYPE 10/TYPE 11/TYPE 12 .....	90
Steering Wheel Switch Does Not Operate .....	60	TYPE 13/TYPE 14 .....	92
<b>WARNING LAMPS .....</b>	<b>62</b>	Schematic .....	94
Schematic .....	62	Wiring Diagram — CHIME — .....	95
Wiring Diagram—WARN—/With Gasoline Engine		Terminals and Reference Value for BCM .....	99
Models .....	63	Terminals and Reference Value for Combination	
Wiring Diagram — WARN — / With Diesel Engine		Meter .....	100
Models .....	69	CONSULT-II Inspection Procedure .....	101
CONSULT-II Functions .....	74	DIAGNOSTIC ITEMS DESCRIPTION .....	101
Oil Pressure Warning Lamp Stays Off (Ignition		CONSULT-II BASIC OPERATION .....	101
Switch ON) .....	74	CONSULT- II Application Items .....	102
Oil Pressure Warning Lamp Does Not Turn Off (Oil		DATA MONITOR .....	102
Pressure Is Normal) .....	76	ACTIVE TEST .....	102
Electrical Components Inspection .....	77	Symptom Chart .....	103
OIL PRESSURE SWITCH CHECK .....	77	Power Supply and Ground Circuit Check .....	103
<b>WARNING CHIME .....</b>	<b>78</b>	Lighting Switch Input Signal Check .....	104
Component Parts and Harness Connector Location..	78	Key Switch Signal Check/Without Intelligent Key	
System Description .....	78	System .....	105
POWER SUPPLY AND GROUND CIRCUIT .....	78	Key Switch Signal Check/With Intelligent Key Sys-	
IGNITION KEY WARNING CHIME .....	79	tem .....	107
IGNITION SWITCH OFF WARNING CHIME		Ignition Knob Switch Signal Check .....	108
(WITH INTELLIGENT KEY SYSTEM) .....	79	Ignition ON Signal Check .....	110
LIGHT WARNING CHIME .....	79	Front Door Switch (Driver side) Check .....	111
SEAT BELT WARNING CHIME .....	80	Seat Belt Buckle Switch Check .....	112

# APPLICATION NOTICE

## APPLICATION NOTICE

PFP:00000

### How to Check Vehicle Type

EKS000Q7A

Confirm K9K engine type with Model written on identification plate (refer to [GI-44, "IDENTIFICATION INFORMATION"](#) ),then refer to service information in DI section.

Vehicle type	Engine type
xTKxxxxK12Vxx	Euro3 48kW
xTKxxxxK12Yxx	Euro3 60kW
xTKxxxxK12Txx	Euro4 50kW
xTKxxxxK12Uxx	Euro4 63kW

A

B

C

D

E

F

G

H

I

J

DI

L

M

# PRECAUTIONS

## PRECAUTIONS

PFP:00011

### Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EKS0086Z

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

## Maintenance Information

EKS008W0

If any of following part is replaced, always replace with new\* one.

If it's not (or fail to do so), the electrical system may not be operated properly.

\*: New one means a virgin control unit that has never been energized on-board.

### RHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM
- IPDM E/R
- Combination meter
- EPS control unit

### LHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM

## Precautions For Trouble Diagnosis

EKS008WG

### CAN SYSTEM


- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery cable before checking the circuit.

## Precautions For Harness Repair

EKS008WH

### CAN SYSTEM


- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



PKIA0306E

## PRECAUTIONS

- Do not perform bypass wire connections for the repair parts.  
(The spliced wire will become separated and the characteristics of twisted line will be lost.)



A  
B  
C  
D

E

F

G

H

I

J

DI

L

M


# COMBINATION METERS

## COMBINATION METERS

PFP:24814

### Component Parts and Harness Connector Location

EKS00824



MIIB1004E

## System Description

### POWER SUPPLY AND GROUND CIRCUIT

EKS00822

Power is supplied at all times

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to combination meter terminal 27.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 2, located in the fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to combination meter terminals 21, 22 and 23
- through body grounds M19 and M20.

## UNIFIED CONTROL METER


- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature warning/indicator lamp are controlled totally by control unit built in combination meter.
- Signal of speedometer, odo/trip meter, tachometer and water temperature warning/indicator lamp are received via CAN communication line.
- Engine coolant temperature is indicated by water temperature warning/indicator lamp color (blue or red).
- Digital meter is adopted for odo/trip meter\*.  
\*: The record of the odometer is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter display segments can be checked in self-diagnosis mode.
- Meter/gauge can be checked in self-diagnosis mode.

# COMBINATION METERS


## DISPLAY CHANGE AFTER IGNITION SWITCH ON

The display will change in the following order after the ignition is turned ON.


- During the 5 to 10 seconds after the ignition is turned ON.  
Maintenance distance, wrench symbol display



- During the 5 to 10 seconds after ignition is turned ON.  
Oil level display



- About 10 seconds after ignition is turned ON.  
Odo, Trip, or selected items are displayed.



## HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

- The CAN communication signals (vehicle speed signal) from ABS actuator and electric unit (control unit), and the memory signals from the meter memory circuit are processed by the combination meter, and the mileage is displayed.
- Operating the odo/trip meter switch allows switching the mode in the refer to [DI-38, "DRIVE COMPUTER"](#).
- When resetting with trip A displayed, only trip A display is reset (same as trip B).

# COMBINATION METERS

## WATER TEMPERATURE WARNING/INDICATOR LAMP

The water temperature warning/indicator lamp indicate the engine coolant temperature.

ECM provides a engine coolant temperature signal to combination meter for water temperature warning/indicator lamp via CAN communication line.

When turn ignition switch ON, water temperature warning/indicator lamp will be ON with red color for 1 second.

After engine started,

- Water temperature warning/indicator lamp will be ON with blue color while engine coolant temperature is less than 55 °C.
- Water temperature warning/indicator lamp will be OFF with blue color, while engine coolant temperature is more than 55 °C.
- Water temperature warning/indicator lamp will be OFF, while engine coolant temperature is between 55 °C and 114 °C.
- Water temperature warning/indicator lamp will be ON with red color, while engine coolant temperature is more than 114 °C.

## TACHOMETER

The tachometer indicates engine speed in revolution per minutes (rpm).

ECM provides an engine speed signal to combination meter for tachometer via CAN communication line.

## FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable resistor signal supplied

- to combination meter terminal 6 for the fuel level sensor
- from terminal 2 of the fuel level sensor unit
- through terminal 4 of the fuel level sensor unit and
- through combination meter terminal 24.

## SPEEDOMETER

ABS actuator and electric unit (control unit) provides a vehicle speed signal to the combination meter for the speedometer via CAN communication line.

# COMBINATION METERS

## CAN Communication SYSTEM DESCRIPTION

EKS00K37

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

EKS00QPF

Body type	3door/5door	3door/5door/C+C	3door/5door	3door/5door/C+C	3door/5door
Axle	2WD				
Engine	CR12DE/CR14DE	HR16DE	CR12DE/CR14DE	HR16DE	K9K
Handle	LHD/RHD				
Brake control	ABS			ESP	
Transmission	A/T	M/T	A/T	M/T	
Intelligent Key system	×	×	×	×	×

### CAN communication unit

ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×					×	×						
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	DI-10, "TYPE 1/TYPE 2"	DI-13, "TYPE 3/TYPE 4/TYPE 5/TYPE 6"			DI-15, "TYPE 7/TYPE 8"	DI-18, "TYPE 9/TYPE 10/TYPE 11/TYPE 12"			DI-20, "TYPE 13/TYPE 14"					

×


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

## COMBINATION METERS


## **TYPE 1/TYPE 2**

## System diagram

- Type 1



- Type 2



## **Input/output signal chart**

T: Transmit R: Receive

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R						
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T							R
Closed throttle position signal	T							R
Wide open throttle position signal	T							R
Overdrive control switch signal		T						R

# COMBINATION METERS

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/T position indicator signal		R					T	
Stop lamp switch signal		T					R	
O/D OFF indicator signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				

## COMBINATION METERS


Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/C switch signal	R				T			
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

# COMBINATION METERS


## TYPE 3/TYPE 4/TYPE 5/TYPE 6

### System diagram

- Type 3/Type 5



- Type 4/Type 6



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R

# COMBINATION METERS

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		


\*: C+C only

# COMBINATION METERS


## TYPE 7/TYPE 8

### System diagram

- Type 7



- Type 8



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R				R		
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T					R	R	
Closed throttle position signal	T						R	
Wide open throttle position signal	T						R	
Overdrive control switch signal		T					R	
A/T position indicator signal		R					T	

# COMBINATION METERS

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
A/T shift schedule change demand signal						T	R	
Stop lamp switch signal		T					R	
O/D OFF indicator lamp signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
ESP warning lamp signal		R				T		
ESP OFF indicator signal		R				T		
SLIP indicator lamp signal		R				T		
Steering angle signal				T		R		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			

## COMBINATION METERS

Signals	ECM	Combina-tion meter.	Intelli- gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/ R
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				
A/C switch signal	R				T			
A/T torque signal						R	T	
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

A

B

C

D

E

F

G

H

I

J

DI

L


M

# COMBINATION METERS


## TYPE 9/TYPE 10/TYPE 11/TYPE 12

### System diagram

- Type 9/Type 11



- Type 10/Type 12



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R				R	
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Accelerator pedal position signal	T					R	
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R

# COMBINATION METERS

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Low beam request signal					T		R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
ESP warning lamp signal		R				T	
ESP OFF indicator signal		R				T	
SLIP indicator lamp signal		R				T	
Steering angle signal				T		R	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		

\*: C+C only

A  
B  
C  
D  
E  
F  
G  
H  
I  
J


DI  
L  
M

## COMBINATION METERS


## **TYPE 13/TYPE 14**

## System diagram

- Type 13



- Type 14



# COMBINATION METERS

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R			R		
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R
High beam request signal		R			T		R
Day time light request signal					T		R
Vehicle speed signal	R	R		R	R	T	
	R	T	R	R			
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
Glow indicator signal	T	R					
R range signal					R		T



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

DI  
L  
M

# COMBINATION METERS

## Combination Meter CHECK

EKS00825




MKWA4023E

# COMBINATION METERS

## Schematic

EKS00826







MKWA4024E

# COMBINATION METERS

## Wiring Diagram — METER — WITHOUT ESP

EKS00827




REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK- JUNCTION BOX (J/B)
- (E45), (E49), (E61), (E66) -ELECTRICAL UNITS

## COMBINATION METERS

## WITH ESP



**M1 -SUPER MULTIPLE  
JUNCTION (SMJ)**

**M16 -FUSE BLOCK-  
JUNCTION BOX (J/B)**

### JUNCTION BOX (J/B)

**E47, E49, E50**  
**ELECTRICAL UNITS**

# COMBINATION METERS

## Terminals and Reference Value for Combination Meter

EKS00P1C

Terminal No.	Wire color	Item	Condition		Reference value (V) (Approx.)
			Ignition switch	Operation or condition	
1	R	CAN- H	—	—	—
2	W	CAN- L	—	—	—
6	BR	Fuel level sensor signal	—	—	Refer to (CR engine) <a href="#">FL-4, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"</a> (HR engine) <a href="#">FL-14, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"</a> (K9K engine) <a href="#">FL-27, "FUEL LEVEL SENSOR UNIT"</a> .
21	B	Ground	—	—	0
22	B	Ground	—	—	0
23	B	Ground	—	—	0
24	PU	Fuel level sensor ground	ON	—	0
27	LG	Battery power supply	OFF	—	Battery voltage
28	GY	Ignition switch ON or START	ON	—	Battery voltage



## Combination Meter Self-Diagnosis PERFORMING SELF-DIAGNOSIS MODE

EKS00828






1. Turn the ignition switch ON.
2. Turn ignition switch OFF after setting the display to trip A or B.
3. Turn ON the ignition switch while pressing the trip button.
4. Release the trip button after the ignition switch is turned ON.
5. Press the trip button 3 time to start self-diagnosis. The sequence (A to J) is activated by pressing the trip button.

### NOTE:




If either reset button is not pressed for 20 seconds at each step or if the ignition switch is turned OFF, the self-diagnosis mode is exited.

	Check items	Display	Remarks
A	Segment test		All odo/trip meter, segments are ON.
B	Work instruction code		This information is not used for service. Skip this step.

# COMBINATION METERS

	Check items	Display	Remarks
C	Software code	 <p>80419 This code is an example. MIIB1039E</p>	This information is not used for service. Skip this step.
D	EEPROM code	 <p>EE000 This code is an example. MIIB1040E</p>	This information is not used for service. Skip this step.
E	Hardware code	 <p>HA000 This code is an example. MIIB1041E</p>	This information is not used for service. Skip this step.
F	PCB code	 <p>PC000 This code is an example. MIIB1042E</p>	This information is not used for service. Skip this step.
G	Meter/gauge test (Sweeping movement)	 <p>PC000 MIIB1043E</p>	<p>Tachometer, speedometer, fuel level gauge and have sweeping movement test. (The meter/gauges operate MIN. → MAX., MAX. → MIN. for 2 times) Water temperature warning/indicator lamp are ON with blue color. during the sweep movement.</p>

# COMBINATION METERS

	Check items	Display	Remarks
H	Error 1 (Bit 0 - Bit 3)	 <p>3 2 1 0 bit 1 0000 This value is an example. MIIIB1044E</p>	<p>The segment of each bit displays "0", meaning no malfunction. If the bit(s) displays figures other than "0", the item of the bit has malfunctioned.</p> <p>For details, refer to <a href="#">DI-29, "Malfunction Chart for "Error 1" and "Error E""</a>.</p>
I	Error E (Bit 4 - Bit 7)	 <p>7 6 5 4 bit E 0000 This value is an example. MIIIB1045E</p>	
J	Fuel warning lamp test	 <p>FUEL Flashing MIIIB1046E</p>	<p>All warning lamp and indicator lamp are ON [Except for water temperature (High) warning lamp, water temperature (Low) indicator lamp and security indicator lamp] and odo/trip meter segment "FUEL" flashes.</p>

# COMBINATION METERS

## Malfunction Chart for “Error 1” and “Error E”

Bit	Detectable items	Description of the malfunction	Displayed figure on the bit	
			Malfunc-tion	No mal-function
0	Speedometer input signal	No input signal When no signal is detected for 30 minutes continuously with the ignition ON, it should be judged as signal malfunction. (If input signal is detected later, then the judgement will be canceled immediately.)	1	0
		Unusual input signal When any signal of frequency which would not exist in normal conditions is detected, it should be judged as signal malfunction.	2	
1	Tachometer input signal	No input signal When no signal is detected for 30 minutes continuously with the ignition ON, it should be judged as signal malfunction. (If input signal is detected later, then the judgement will be canceled immediately.)	1	0
		Unusual input signal When any signal of frequency which would not exist in normal conditions is detected, it should be judged as signal malfunction.	2	
2	Fuel level input signal	Short circuit When short circuit of the signal line is detected for 5 seconds or more, it should be judged as short-circuit malfunction.	1	0
		Open circuit When open circuit of the signal line is detected for 5 seconds or more, it should be judged as open-circuit malfunction.	2	
3	Water temperature input signal	Short circuit When short circuit of the signal line is detected for 5 seconds or more, it should be judged as short-circuit malfunction.	1	0
		Open circuit When open circuit of the signal line is detected for 5 seconds or more, it should be judged as open-circuit malfunction.	2	
4	Reset buttons	Short circuit for reset buttons When the short circuit is continuously detected for 5 minutes or more, it should be judged as short-circuit malfunction.	Right side reset button has malfunctioned.	1
			Left side reset button has malfunctioned.	2
			Both reset buttons have malfunctioned.	3
5	CPU	CPU RAM malfunction	1	0
6	—	—	0	0

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

DI  
L  
M

# COMBINATION METERS

## Trouble Diagnoses PRELIMINARY CHECK

EKS00829

### 1. CHECK POWER SUPPLY

1. Turn ignition switch ON.
2. Warning lamps should illuminate (seat belt warning or door warning etc.).

Do warning lamps illuminate?

YES >> GO TO 2.

NO >> Power supply and ground check. Refer to [DI-33, "Power Supply and Ground Circuit Check"](#).

### 2. CHECK OPERATION OF SELF-DIAGNOSIS MODE

Perform self-diagnosis mode. Refer to [DI-26, "PERFORMING SELF-DIAGNOSIS MODE"](#).

Can self-diagnosis mode be activated?

YES >> GO TO 3.

NO >> Replace combination meter. Refer to [DI-36, "Removal and Installation for Combination Meter"](#).

### 3. CHECK OPERATION OF METER/GAUGE

Check meter/gauge operation in self-diagnosis mode (Meter/gauge test). Refer to [DI-26, "PERFORMING SELF-DIAGNOSIS MODE"](#).

Is any malfunction indicated in self-diagnosis mode?

YES >> GO TO "Symptom Chart 1". Refer to [DI-32, "Symptom Chart 1"](#).

NO >> GO TO 4.

### 4. CHECK WATER TEMPERATURE WARNING/INDICATOR

- Check water temperature waring lamp (Red color)

1. Turn ignition switch OFF.
2. When turn ignition switch ON, water temperature warning/indicator lamp will be ON with red color for 1 second.

  - Check water temperature indicator lamp (Blue color)

Check meter/gauge operation in self-diagnosis mode (Meter/gauge test). Refer to [DI-26, "Combination Meter Self-Diagnosis"](#).

Does water temperature warning/indicator lamp is ON?

Yes >> GO TO 5.

No >> Replace combination meter.

### 5. CHECK SEGMENTS

Check all odo/trip meter segments in self-diagnosis mode (Odo/trip meter segment test). Refer to [DI-26, "PERFORMING SELF-DIAGNOSIS MODE"](#).

Is any malfunction indicated in self-diagnosis mode?

YES >> GO TO "Symptom Chart 1". Refer to [DI-32, "Symptom Chart 1"](#).

NO >> GO TO 6.

### 6. CHECK WARNING INDICATOR LAMP

Check fuel warning lamp in self-diagnosis mode (Fuel warning lamp test). Refer to [DI-26, "PERFORMING SELF-DIAGNOSIS MODE"](#).

**All warning/indicator lamp should turn ON.**

OK or NG

OK >> GO TO 7.

NG >> Replace combination meter.

# COMBINATION METERS

## 7. CHECK INPUT SIGNALS

Check input signals from each sensors in self-diagnosis mode (Error 1 and Error E). Refer to [DI-29, "Malfunction Chart for "Error 1" and "Error E""](#).

### OK or NG

OK      >> GO TO 8.

NG      >> GO TO "Symptom Chart 2". Refer to [DI-32, "Symptom Chart 2"](#).

## 8. CHECK OTHER MALFUNCTION

Check each malfunction according to the instruction of the "SYMPTOM CHART 3". Refer to [DI-32, "Symptom Chart 3"](#).

### OK or NG

OK      >> Combination meter is OK.

NG      >> Check the case of malfunction.

A

B

C

D

E

F

G

H

I

J

DI

L

M

# COMBINATION METERS

## SYMPTOM CHART

### Symptom Chart 1

Symptom	Possible causes	Repair order
Odo/trip meter indicates malfunction in Diagnosis mode.	Unified meter control unit	Replace combination meter. Refer to <a href="#">DI-36, "Removal and Installation for Combination Meter"</a> .
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of speedometer/tachometer/fuel gauge/Water temperature lamp. indicates malfunction in Diagnosis mode.		

### Symptom Chart 2

Symptom	Possible causes	Repair order
Speedometer input signal indicates malfunction in Diagnosis mode.	Speedometer input signal	Check signal for speedometer. Refer to <a href="#">DI-33, "Inspection/Vehicle Speed Signal"</a> .
Tachometer input signal indicates malfunction in Diagnosis mode.	Tachometer input signal	Check signal for tachometer. Refer to <a href="#">DI-33, "Inspection/Engine Revolution Signal"</a> .
Fuel level input signal indicates malfunction in Diagnosis mode.	Fuel level input signal	Check fuel level signal. Refer to <a href="#">DI-34, "Inspection/Fuel Level Sensor Unit"</a> .
Water temperature input signal Indicates malfunction in Diagnosis mode.	Water temp. warning/indicator lamps input signal	Check water temperature signal. Refer to <a href="#">DI-35, "Inspection/Water Temperature Warning/indicator Lamp"</a> .
Reset buttons indicates malfunction in Diagnosis mode.	Unified meter control unit	Combination meter. Refer to <a href="#">DI-36, "Removal and Installation for Combination Meter"</a> .
CPU indicates malfunction in Diagnosis mode.	Unified meter control unit	Combination meter. Refer to <a href="#">DI-36, "Removal and Installation for Combination Meter"</a> .

### Symptom Chart 3

Symptom	Possible causes	Repair order
Fuel gauge pointer fluctuates, Indicator wrong value or varies.	-	Check the case of malfunction. Refer to <a href="#">DI-35, "Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies"</a> .
Fuel gauge does not move to "F" position.	-	Check the case of malfunction. Refer to <a href="#">DI-35, "Fuel Gauge Does Not Move to FULL position"</a> .
Fuel gauge does not work.	-	Check the case of malfunction. Refer to <a href="#">DI-36, "Fuel Gauge Does Not Work"</a> .

# COMBINATION METERS

## Power Supply and Ground Circuit Check

EKS0082A

### 1. CHECK POWER SUPPLY CIRCUIT

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector and ground.


Terminals		Ignition switch position		
Connector	(+)	(-)	OFF	ACC
M22	27 (LG)	Ground	Battery voltage	Battery voltage
	28 (GY)		0V	0V

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 2, located in fuse block (J/B)].
- 10A fuse [No. 8, located in fuse block (J/B)].
- Harness for open or short between fuse and combination meter.



### 2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between combination meter connector M22 terminal 21, 22, 23 and ground.

**21 (B) - Ground**

: Continuity should exist.

**22 (B) - Ground**

: Continuity should exist.


**23 (B) - Ground**

: Continuity should exist.

OK or NG

OK >> INSPECTION END

NG >> Harness for open ground circuit.



## Inspection/Vehicle Speed Signal

EKS0082C

### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT SYSTEM

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-22, "CONSULT-II Functions"](#)

OK or NG

OK >> Perform "PRELIMINARY CHECK" again.

NG >> Perform "Diagnostic procedure" for displayed self-diagnosis result.

## Inspection/Engine Revolution Signal

EKS0082D

### 1. CHECK ECM SYSTEM

Perform ECM self-diagnosis. Refer to [EC-55, "Emission-related Diagnostic Information"](#) (CR engine models with EURO-OBD), [EC-484, "Emission-related Diagnostic Information"](#) (CR engine models without EURO-OBD), [EC-833, "Emission-related Diagnostic Information"](#) (HR engine models with EURO-OBD), [EC-1269, "Emission-related Diagnostic Information"](#) (HR engine models without EURO-OBD) or EC-K9K-64, "Trouble diagnosis — Introduction", "DIESEL INJECTION" (K9K engine models).

OK or NG

OK >> Perform "PRELIMINARY CHECK" again.

NG >> Perform "Diagnostic procedure" for displayed DTC.

# COMBINATION METERS

## Inspection/Fuel Level Sensor Unit FUEL LEVEL SENSOR UNIT

EKS0082E

The following symptoms do not indicate a malfunction.

- Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.

### LOW-FUEL WARNING LAMP

Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the warning lamp ON timing may be changed.

#### 1. CHECK HARNESS CONNECTOR

- Turn ignition switch OFF.
- Check combination meter, fuel level sensor unit and terminals (meter-side, module-side, and harness-side) for poor connection and bend.

##### OK or NG

OK >> GO TO 2.

NG >> Repair or replace terminals or connectors.

#### 2. CHECK FUEL LEVEL SENSOR INPUT SIGNAL CIRCUIT

- Disconnect fuel level sensor unit connector and combination meter connector.
- Check the following.
- Harness continuity between fuel level sensor unit and fuel pump harness connector B28 terminal 2 and combination meter harness connector M22 terminal 6.

**2 (BR) – 6 (BR)** : Continuity should exist.


- Harness continuity between combination meter harness connector M22 terminal 6 and ground.

**6 (BR) – Ground** : Continuity should not exist.

##### OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



#### 3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT


Check harness continuity between fuel level sensor unit and fuel pump harness connector B28 terminal 4 and combination meter connector M22 terminal 24.

**4 (PU) – 24 (PU)** : Continuity should exist.

##### OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



#### 4. CHECK FUEL LEVEL SENSOR UNIT

Refer to DI-36, "FUEL LEVEL SENSOR UNIT CHECK".

##### OK or NG

OK >> GO TO 5.

NG >> Replace fuel level sensor unit.

# COMBINATION METERS

## 5. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any components inside the arm.

### OK or NG

OK      >> Replace combination meter.  
NG      >> Install fuel level sensor unit properly.

## Inspection/Water Temperature Warning/indicator Lamp

EKS0082F

### 1. CHECK ECM SYSTEM

Perform ECM self-diagnosis. Refer to [EC-55, "Emission-related Diagnostic Information"](#) (CR engine models with EURO-OBD), [EC-484, "Emission-related Diagnostic Information"](#) (CR engine models without EURO-OBD) , [EC-833, "Emission-related Diagnostic Information"](#) (HR engine models with EURO-OBD), [EC-1269, "Emission-related Diagnostic Information"](#) (HR engine models without EURO-OBD) or EC-K9K-64, "Trouble diagnosis — Introduction", "DIESEL INJECTION" (K9K engine models).

### OK or NG

OK      >> Perform "PRELIMINARY CHECK" again.  
NG      >> Perform "Diagnostic procedure" for displayed DTC.

## Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies

EKS0082G

### 1. CHECK FUEL GAUGE FLUCTUATION

Test drive vehicle to see if gauge fluctuates only during driving or at the instant of stopping.

#### Does the indication value vary only during driving or at the instant of stopping?

YES      >> The pointer fluctuation may be caused by fuel level change in the fuel tank. Condition is normal.  
NO      >> Ask the customer about the situation when the symptom occurs in detail, and perform the trouble diagnosis.

## Fuel Gauge Does Not Move to FULL position

EKS0082H

### 1. QUESTION 1

Does it take a long time for the pointer to move to FULL position?

### YES or NO

YES      >> GO TO 2.  
NO      >> GO TO 3.

### 2. QUESTION 2

Was the vehicle fueled with the ignition switch ON?

### YES or NO

YES      >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise it will take a long time to move to FULL position because of the characteristic of the fuel gauge.  
NO      >> GO TO 3.

### 3. QUESTION 3

Is the floor or the vehicle inclined?

### YES or NO

YES      >> It may not be filled fully.  
NO      >> GO TO 4.

### 4. QUESTION 4

During driving, does the fuel gauge pointer move gradually toward EMPTY position?

### YES or NO

YES      >> Check the components. Refer to [DI-36, "Electrical Components Inspection"](#) .  
NO      >> The float arm may interfere or bind with any of the components in the fuel tank.

# COMBINATION METERS

## Fuel Gauge Does Not Work

EKS0082I

### 1. CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Check combination meter, fuel level sensor unit and terminals (meter-side, and harness-side) for poor connection and bend.

OK or NG

OK >> GO TO 2.

NG >> Repair connector.

### 2. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation [refer to [FL-4, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#) (CR engine models) or [FL-27, "FUEL LEVEL SENSOR UNIT"](#) (K9K engine models)], and check whether the float arm interferes or binds with any components inside the arm.

OK or NG

OK >> Perform "PRELIMINARY CHECK" again.

NG >> Check fuel level sensor unit. Refer to [DI-36, "Electrical Components Inspection"](#) .

## Electrical Components Inspection


EKS0082J

### FUEL LEVEL SENSOR UNIT CHECK

For removal, refer to [refer to [FL-4, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#) (CR engine models), [FL-14, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#) (HR engine models) or [FL-27, "FUEL LEVEL SENSOR UNIT"](#) (K9K engine models)].

Check the resistance between terminals 2 and 4.

Ohmmeter	Float position	Resistance value [ $\Omega$ ]
4	Full	Approx. 46
	Empty	Approx. 320



## Removal and Installation for Combination Meter

EKS0082K


### CAUTION:

Always replace with new\* combination meter when the combination meter replacement is required.

\*: New one means virgin control unit that has never been energized on-board.

### REMOVAL

1. Remove the upper instrument panel. Refer to [IP-6, "C. Upper Instrument Panel"](#) .
2. Remove the steering column cover. Refer to [IP-6, "G. Steering Column Cover"](#) .
3. Remove the cluster lid A. Refer to [IP-7, "I. Cluster lid "A""](#) .
4. Remove the screws (3), and pull out combination meter.
5. Disconnect connectors and remove combination meter.



### INSTALLATION


- Install in the reverse order of removal.

## COMBINATION METERS

## Disassembly and Assembly for Combination Meter

*EKS0082L*

**SEC. 248**



MKIB1705E

## 1. Front cover

## 2. Upper housing

### 3. Unified meter control unit assembly

1. Disengage the tabs (13) to separate upper housing.
2. Disengage the tabs (7) to separate front cover.

A  
B  
C  
D  
E  
F  
G  
H


DI

## DRIVE COMPUTER

PFP:24859

### Component Parts and Harness Connector and Harness Connector Location

EKS0082N



### System Description

EKS0082M

Refer to Owner's Manual for drive computer operating instructions.

Drive computer can be set trip A, trip B, range, average fuel consumption, average speed, time and maintenance information, etc.

And, combination meter is displayed drive computer information.

### DRIVE COMPUTER

Drive computer can indicate the following item.

- Range
- Average fuel consumption
- Average speed
- Time

Indication can be changed by in the following order by pushing trip button.

Trip A → Trip B → Range → Average fuel consumption → Average speed → Time → Trip A .....

### Range


- The elapsed time indication provides driver with an estimation of the distance that can be driven before refuelling. The range is conducted by fuel tank level sensor unit (fuel remaining), ECM pulse signal (fuel consumption) and vehicle speed signal.
- The range is conducted by combination meter and sent to CAN communication line. Combination meter calculate the range by fuel level sensor unit (fuel remaining), ECM pulse signal (fuel consumption signal) and vehicle speed signal.
- When combination meter low fuel warning lamp is ON. Display will be changed range automatically and flashing as following.

Range reached < 16km

Range display (number, symbol and unit) will be display "----".

Range changed > 34km


Number will be displayed.



# DRIVE COMPUTER


## Average Fuel Consumption

- The average fuel economy is conducted by combination meter sent to CAN communication line. Combination meter calculate the average fuel economy by fuel consumption signal and vehicle speed signal.
- Indication will be renewed every 30 seconds.
- When pushing trip button more than approx.3 seconds, average fuel economy will be reset.
- There are two display types,  $\ell/100\text{km}$  and mpg.
- Fuel economy with a range is 0 to 99.9 ( $\ell/100\text{ km}$ ) or (mpg).




## Average Speed

- Average vehicle speed indication is conducted by trip distance and trip time.
- Indication will be renewed every 30 seconds.
- When pushing trip button more than approximately 3 seconds, average speed will be reset.
- If average vehicle speed is reset, average fuel consumption will be reset at the same time.
- there are two display types, km/h or mph .



## Time

- Trip time is calculated by drive computer as elapsed time since last reset.
- It only increases with ignition switch ON.
- When pushing trip button more than approximately 3 seconds, trip time distance will be reset.




# DRIVE COMPUTER

## MAINTENANCE


- Show the distance to the next maintenance.
- When the set distance is reached, the wrench symbol in the combination meter illuminates.
- Use the following procedure to set the distance.

1. Ignition switch ON.
2. Press and hold the clock switch (about 3 seconds) while the maintenance distance and wrench mark are displayed (about 5 seconds after turning on the ignition).
3. Change to the distance setting mode. The maintenance distance and wrench mark will flash.
4. While these are flashing, press the clock switch to display the current maintenance distance.
5. Press the clock switch again to increase the setting distance in 500 km increments.
6. The maximum setting is 31,500 km. Pressing the clock switch one more time after this will return the setting to 0.
7. When the setting procedure is complete, do not touch the switch for 5 seconds in order for the setting to be registered.




## OIL LEVEL INDICATOR

- The oil amount is shown on the display about 5 to 10 seconds after the ignition is turned on.
- The display changes depending on the oil level.
  - Oil level Low  
" \_ \_ \_ 0 "
  - Oil level Hi  
" 0 0 0 0 0 "
- The indicator flashes when the oil level drops below the set level.



## HOW TO CHANGE FOR STEERING SWITCH

- Indication can be changed in the following order by pushing steering switch.  
Trip A → Trip B → Range → Average fuel consumption → Average Speed → Time → Trip A ....



# DRIVE COMPUTER

## OUTSIDE AIR TEMPERATURE

Outside air temperature is displayed ON when ignition switch ON.

- When the outside air temperature is lower than -30°C or higher than 56°C the display shows only “—” though it is operating. This is not a malfunction.
- When the outside air temperature drops below freezing point (Approx. 3°C), it indicator as following. (Low temperature warning)
  - Outside air temperature is 3°C…“3°C” is flushed.
  - Outside air temperature is -2°C…“°C” is flushed.
  - Outside air temperature is more than 4°C low temperature warning is canceled.

Combination meter should read ambient sensor.

The ambient sensor is regulated by a variable resistor signal supplied

- to combination meter terminal 25
- from ambient sensor terminal 3
- through ambient sensor terminal 4 and
- through combination meter terminal 26.

A

B

C

D

E

F

G

H

I

J

DI

L

M

# DRIVE COMPUTER

## CAN Communication SYSTEM DESCRIPTION

EKS00K39

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

EKS00QPG

Body type	3door/5door	3door/5door/C+C	3door/5door	3door/5door/C+C	3door/5door
Axle	2WD				
Engine	CR12DE/CR14DE	HR16DE	CR12DE/CR14DE	HR16DE	K9K
Handle	LHD/RHD				
Brake control	ABS			ESP	
Transmission	A/T	M/T	A/T	M/T	
Intelligent Key system	×	×	×	×	×

### CAN communication unit

ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×					×	×						
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	DI-43, "TYPE 1/TYPE 2"	DI-46, "TYPE 3/TYPE 4/TYPE 5/TYPE 6"			DI-48, "TYPE 7/TYPE 8"	DI-51, "TYPE 9/TYPE 10/TYPE 11/TYPE 12"			DI-53, "TYPE 13/TYPE 14"					


×: Applicable

# DRIVE COMPUTER


## TYPE 1/TYPE 2

### System diagram

- Type 1



- Type 2



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R						
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T							R
Closed throttle position signal	T							R
Wide open throttle position signal	T							R
Overdrive control switch signal		T						R

# DRIVE COMPUTER

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/T position indicator signal		R					T	
Stop lamp switch signal		T					R	
O/D OFF indicator signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				

# DRIVE COMPUTER

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/C switch signal	R				T			
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

A

B

C

D

E

F

G

H

I

J

DI

L


M

# DRIVE COMPUTER


## TYPE 3/TYPE 4/TYPE 5/TYPE 6

### System diagram

- Type 3/Type 5



- Type 4/Type 6



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R

# DRIVE COMPUTER

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		

\*: C+C only


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI

L  
M


# DRIVE COMPUTER

## TYPE 7/TYPE 8 System diagram

- Type 7



- Type 8



## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R				R		
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T					R	R	
Closed throttle position signal	T						R	
Wide open throttle position signal	T						R	
Overdrive control switch signal		T					R	
A/T position indicator signal		R					T	

# DRIVE COMPUTER

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
A/T shift schedule change demand signal						T	R	
Stop lamp switch signal		T					R	
O/D OFF indicator lamp signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
ESP warning lamp signal		R				T		
ESP OFF indicator signal		R				T		
SLIP indicator lamp signal		R				T		
Steering angle signal				T		R		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			

## DRIVE COMPUTER


Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				
A/C switch signal	R				T			
A/T torque signal						R	T	
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

# DRIVE COMPUTER


## TYPE 9/TYPE 10/TYPE 11/TYPE 12

### System diagram

- Type 9/Type 11



- Type 10/Type 12



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R				R	
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Accelerator pedal position signal	T					R	
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R

# DRIVE COMPUTER

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Low beam request signal					T		R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
ESP warning lamp signal		R				T	
ESP OFF indicator signal		R				T	
SLIP indicator lamp signal		R				T	
Steering angle signal				T			R
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		


\*: C+C only

# DRIVE COMPUTER


## TYPE 13/TYPE 14

### System diagram

- Type 13



- Type 14



# DRIVE COMPUTER

## Input/output signal chart

T: Transmit R: Receive


Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R			R		
Fuel consumption monitor signal	T	R					
Oil pressure switch signal			R				T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R
High beam request signal		R			T		R
Day time light request signal					T		R
Vehicle speed signal	R	R		R	R	T	
	R	T	R	R			
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
Glow indicator signal	T	R					
R range signal					R		T

# DRIVE COMPUTER

## Wiring Diagram — D/COMP —



EKS00820

DI-D/COMP-01



REFER TO THE FOLLOWING.

(M16) -FUSE BLOCK-  
JUNCTION BOX (J/B)



MKWA4027E

## DRIVE COMPUTER

〈OH〉: WITHOUT PTC HEATER

 : K9K EURO 3 48kW/60kW MODELS  
AND EURO 4 50kW/63kW WITH  
PTC HEATER MODELS



 : K9K EURO 4 50kW/60kW WITHOUT PTC HEATER MODELS

## : HR ENGINE MODELS

 WITH DIESEL ENGINE

DI-D/COMP-02

\*1 10F :  \*2 11F :   
 16F :  17F :   
 5 :  13 : 



M1 E1 E101

MT, M, TOT

**-SUPER MULTIPLE  
FUNCTION (SMF)**

\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

# DRIVE COMPUTER

## Terminals and Reference Value for Combination Meter

EKS00P1D

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Operation or condition	
1	R	CAN- H	—	—	—
2	W	CAN- L	—	—	—
6	BR	Fuel level sensor signal	—	—	Refer to (CR engine) <a href="#">FL-4, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"</a> (HR engine) <a href="#">FL-14, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"</a> (K9K engine) <a href="#">FL-27, "FUEL LEVEL SENSOR UNIT"</a> .
21	B	Ground	—	—	0
22	B	Ground	—	—	0
23	B	Ground	—	—	0
24	PU	Fuel level sensor ground	ON	—	0
25	LG	Ambient sensor signal	ON	—	2.6
				Disconnect ambient sensor connector	5
26	OR	Ambient sensor ground	ON	—	0
27	LG	Battery power supply	OFF	—	Battery voltage
28	GY	Ignition switch ON or START	ON	—	Battery voltage
29	G	Sterring switch signal	ON	Sterring switch release	10
				Sterring switch pushed	0
36	Y	Oil level sensor signal	ON	—	—
37	G	Oil level sensor ground	ON	—	0

## Self-Diagnosis Function

EKS0082R

Ref to [DI-26, "Combination Meter Self-Diagnosis"](#)

**Outside Air Temperature is not Displayed**


EKS0081G

**1. CHECK AMBIENT SENSOR IN PUT SIGNAL**

1. Turn ignition switch OFF.
2. Disconnect ambient sensor connector.
3. Turn ignition switch ON.
4. Check voltage between ambient sensor harness connector E52 terminal 3 and ground.

**3 (LG) – Ground****: Approx. 5V**OK or NG


OK      >> GO TO 2.  
 NG      >> GO TO 4.

**2. CHECK AMBIENT SENSOR GROUND CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector.
3. Check continuity between ambient sensor harness connector E52 terminal 4 and combination meter harness connector M22 terminal 26.

**4 (OR) - 26 (OR)****: Continuity should exist.**OK or NG

OK      >> GO TO 3.  
 NG      >> Repair harness or connector.


**3. CHECK AMBIENT SENSOR**

Check ambient sensor harness connector E52 terminals 3 and 4.

Temperature °C	Resistance [kΩ]
-20	16.53
-10	9.93
0	6.19
10	3.99
20	2.65
30	1.81
40	1.27
50	0.91

OK or NG

OK      >> Replace combination meter.  
 NG      >> Replace ambient sensor.



## 4. CHECK AMBIENT SENSOR CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between ambient sensor harness connector E52 terminal 3 and combination meter harness connector M28 terminal 25.

**3 (LG) - 25 (LG)**

**: Continuity should exist.**

OK or NG

OK      >> Replace combination meter.  
NG      >> Repair harness or connector.



# DRIVE COMPUTER

## Steering Wheel Switch Does Not Operate

EKS0088R


### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter and ground.

Connector	Terminals (Wire color)		Condition	Voltage [V] (Approx.)
	(+)	(-)		
M22	29 (G)	Ground	Steering wheel switch is pushed.	0
			Steering wheel switch is released.	Battery voltage

OK or NG

OK >> Replace combination meter.  
NG >> GO TO 2.




### 2. CHECK STEERING WHEEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect steering wheel switch.
3. Check steering wheel switch (drive computer).

Connector	Terminals		Condition	Continuity
M502	16	19	Steering wheel switch is pushed.	No
			Steering wheel switch is released.	Yes

OK or NG

OK >> GO TO 3.  
NG >> Replace steering wheel switch.




### 3. CHECK STEERING WHEEL SWITCH CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between combination meter harness connector M22 terminal 29 and combination switch (spiral cable) harness connector M29 terminal 25.

**29 (G) - 25 (G) : Continuity should exist.**

OK or NG

OK >> GO TO 4.  
NG >> Replace harness or connector.



## 4. CHECK STEERING WHEEL SWITCH GROUND CIRCUIT

1. Disconnect audio unit connector.
2. Check continuity between combination switch harness connector M29 terminal 32 and audio unit harness connector M26 terminal 12.


**32 (L) - 12 (L)**

**: Continuity should exist.**

OK or NG

OK    >> Check audio unit ground circuit. Refer to [AV-14, "Power Supply Circuit Inspection"](#).

NG    >> Repair harness or connector.




# WARNING LAMPS

## WARNING LAMPS

### Schematic

PFP:24814


EKS0072G



## **WARNING LAMPS**

## Wiring Diagram — WARN — / With Gasoline Engine Models

EKS0072H




# WARNING LAMPS

DI-WARN-02

REFER TO PG-POWER.

◊ A : WITH A/T  
 ◊ IK : WITH INTELLIGENT  
 KEY SYSTEM



REFER TO THE FOLLOWING.

M16 -FUSE BLOCK-  
 JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

M9 W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

M22 W

2	1	6	5	4	3
6	5	4	3	2	1

M68 W

24	23	18			
3	4	12	11	6	5
22	15	1	16	2	

M69 Y

1	1	1	1	2	2	2	2	2	2	2
3	3	3	3	4	4	4	4	4	4	4

M81 L

4	3	2	1
4	3	2	1


B28 GY

# WARNING LAMPS

DI-WARN-03


L : LHD MODELS  
 ES : WITH ESP  
 C : CR ENGINE MODELS  
R : RHD MODELS  
 OE : WITHOUT ESP  
 H : HR ENGINE MODELS

■ : DATA LINE




REFER TO THE FOLLOWING.

(M1, F1) - SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (E45, E47) - ELECTRICAL UNITS



MKWA4032E

# WARNING LAMPS







# WARNING LAMPS

DI-WARN-05

HB : HATCHBACK  
CC : C+C



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M



MKWA4034E

# WARNING LAMPS

## DI-WARN-06





REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (E49), (E66) -ELECTRICAL UNITS

## **WARNING LAMPS**

## Wiring Diagram — WARN — / With Diesel Engine Models


EKS00K3F



REFERR TO THE FOLLOWING



REF. TO THE FOLLOWING  
M1 , F101 - SUPER  
MULTIPLE JUNCTION (SMJ)  
M16 - FUSE BLOCK -  
JUNCTION BOX (J/B)

# WARNING LAMPS




## WARNING LAMPS

DI-WARN-09






REFER TO THE FOLLOWING.  
M1 , F101 - SUPER MULTIPLE  
JUNCTION (SMJ)  
E45 - ELECTRICAL UNITS

# WARNING LAMPS



DI-WARN-10

: DATA LINE  
 (L) : LHD MODELS  
 (R) : RHD MODELS  
 (5D) : WITH 5 DOORS







MKWA4039E

# WARNING LAMPS

DI-WARN-11

— : DATA LINE



REFER TO THE FOLLOWING.

- (M1) - SUPER MULTIPLE JUNCTION (SMJ)
- (E61) - ELECTRICAL UNITS

# WARNING LAMPS

## CONSULT-II Functions

EKS00870

CONSULT-II performs the following functions with combination of data receiving, command and transmission using the CAN communication line from the IPDM E/R.

Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.

## Oil Pressure Warning Lamp Stays Off (Ignition Switch ON)

EKS00833

### 1. CHECK IPDM SELF-DIAGNOSIS

1. Perform IPDM E/R self-diagnosis. Refer to [PG-34, "CONSULT-II Function \(IPDM E/R\)"](#).

self-diagnostic results content

NON DTC IS DETECTED >>GO TO 2.

CAN COMMUNICATION CIRCUIT >>Check IPDM. Refer to [PG-49, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#).


### 2. CHECK IPDM E/R DATA MONITOR

#### With CONSULT-II

Check oil pressure switch ("OIL P SW") in "DATA MONITOR" mode with CONSULT-II.

Engine is stopped (IGN ON) : OIL P SW CLOSE

Engine is running : OIL P SW OPEN




#### Without CONSULT-II

1. Disconnect oil pressure switch.
2. Turn the ignition switch ON.
3. Check voltage between oil pressure switch harness connector F25 (CR engine models), F45 (HR engine models), F124 (K9K Euro 3 48kw / 60kw models) or F137 (K9K Euro 4 50kw / 63kw models) terminal 1 and ground.

1 (W) - Ground : Battery voltage

OK or NG

OK >> Replace combination meter.  
NG >> GO TO 3.



### 3. CHECK OIL PRESSURE SWITCH

Check oil pressure switch. Refer to [DI-77, "OIL PRESSURE SWITCH CHECK"](#).

OK or NG

OK >> GO TO 4.  
NG >> Replace the oil pressure switch.

## WARNING LAMPS

### 4. CHECK OIL PRESSURE SWITCH CIRCUIT


1. Disconnect IPDM E/R connector and oil pressure switch connector.
2. Check continuity between IPDM E/R harness connector E17 terminal 66 and oil pressure switch harness connector F25 (CR engine models), F45 (HR engine models), F124 (K9K Euro 3 48kw / 60kw models) or F137 (K9K Euro 4 50kw / 63kw models) terminal 1.

**66 (W) - 1 (W)**

**: Continuity should exist.**

OK or NG

OK      >> Replace IPDM E/R.  
NG      >> Repair harness or connector.



# WARNING LAMPS

## Oil Pressure Warning Lamp Does Not Turn Off (Oil Pressure Is Normal)

EKS00834

### NOTE:

For oil pressure inspection, refer to [LU-6, "OIL PRESSURE CHECK"](#) (CR engine models) or [LU-24, "OIL PRESSURE CHECK"](#) (K9K engine models).


### 1. CHECK OIL PRESSURE SWITCH INPUT

#### With CONSULT-II

Check oil pressure switch ("OIL P SW") in "DATA MONITOR" mode with CONSULT-II.

Engine is stopped (IGN ON) : OIL P SW CLOSE

Engine is running : OIL P SW OPEN




#### Without CONSULT-II

1. Disconnect oil pressure switch.
2. Turn the ignition switch ON.
3. Check voltage between oil pressure switch harness connector F25 (CR engine models), F45 (HR engine models), F124 (K9K Euro 3 48kw / 60kw models) or F137 (K9K Euro 4 50kw / 63kw models) terminal 1 and ground.

1 (W) - Ground : Battery voltage

OK or NG

OK >> GO TO 2.  
NG >> GO TO 3.



### 2. CHECK OIL PRESSURE SWITCH

Check oil pressure switch. Refer to [DI-77, "OIL PRESSURE SWITCH CHECK"](#).

OK or NG

OK >> Replace combination meter.  
NG >> Replace the oil pressure switch.


### 3. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E17 terminal 66 and ground.

66 (W) - Ground : Continuity should not exist.

OK or NG

OK >> Replace IPDM E/R.  
NG >> Repair harness or connector.




## WARNING LAMPS

### Electrical Components Inspection OIL PRESSURE SWITCH CHECK

EKS0072J

	Oil pressure kPa (bar, kg/cm <sup>2</sup> , psi)	Continuity
Engine running	More than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3)	No
Engine not running	Less than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3)	Yes

Check the continuity between the terminals of oil pressure switch and body ground.



A

B

C

D

E

F

G

H

I

J

DI

L

M


# WARNING CHIME

## WARNING CHIME

PFP:24814

### Component Parts and Harness Connector Location

EKS0072M



MKIB2213E

### System Description

EKS0072L

The warning chime is controlled by the BCM.

The warning chime is located in the combination meter.

### POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 40A fusible link (letter J, located in fuse and fusible link box)
- to BCM terminals 74 and 79
- through 10A fuse [No. 8, located in fuse block (J/B)]
- to combination meter terminal 27
- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to key switch terminal 1 (without Intelligent Key system)
- through 10A fuse [No. 17, located in the fuse block (J/B)]
- to key switch and ignition knob terminals 1 and 3 (with Intelligent Key system).

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM terminal 24.
- through 10 A fuse [No. 2, located in the fuse block (J/B)]
- to combination meter terminals 28

Ground is supplied

## WARNING CHIME

- to BCM terminals 2 and 70, and
- to combination meter terminals 21, 22 and 23,
- through body grounds, M19 (LHD models) and M20 (RHD models).

### IGNITION KEY WARNING CHIME

With the key in the ignition key cylinder, the ignition switch in OFF or ACC position, and the driver's door open, the warning chime will sound.

Power is supplied

- through key switch terminal 2 (without Intelligent Key system) or
- through key switch and ignition knob terminal 2 (with Intelligent Key system)
- to BCM terminal 3.

Ground is supplied

- from front door switch LH (LHD models) or RH (RHD models) terminal 1
- to BCM terminal 29.

Ground is supplied through the case of the front door switch LH (LHD models) or RH (RHD models).

BCM sends buzzer output signal to combination meter via CAN communication line.

When combination meter receives buzzer output signal, it sounds warning chime.

### IGNITION SWITCH OFF WARNING CHIME (WITH INTELLIGENT KEY SYSTEM)

When ignition knob switch is pushed (ignition switch is OFF position), and the driver's door open, the earning chime will sound. Power is supplied

- through key switch and ignition knob terminal 4
- to Intelligent Key unit terminal 7.

Ground is supplied

- from front door switch LH (LHD models) or RH (RHD models) terminal 1
- to BCM terminal 29.

Ground is supplied through the case of the front door switch LH (LHD models) or RH (RHD models).

BCM sends door switch signal (driver side) to Intelligent Key unit via CAN communication line.

Then, Intelligent Key unit sends buzzer output signal to combination meter via CAN communication line.

When combination meter receives buzzer output signal, it sounds warning chime.

### LIGHT WARNING CHIME

With ignition switch OFF position, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. [Except when headlamp battery saver control operates (for 5 minutes after ignition switch is turned to OFF or ACC position) and headlamps do not illuminate.]

Signal is supplied

- from combination switch (lighting switch) terminals 1, 2, 3, 4, 5, 6, 7, 8, 9 and 10
- to BCM terminals 7, 8, 9, 13, 14, 15, 27, 28, 33 and 34

#### NOTE:

BCM detection lighting switch in 1st or 2nd position, refer to [LT-212, "COMBINATION SWITCH READING FUNCTION"](#).

Ground is supplied

- from front door switch LH (LHD models) or RH (RHD models) terminal 1
- to BCM terminal 29.

Ground is supplied through the case of the front door switch LH (LHD models) or RH (RHD models).

BCM sends buzzer output signal to combination meter via CAN communication line. when combination meter receives buzzer output signal, it sounds warning chime.

## **WARNING CHIME**

---

### **SEAT BELT WARNING CHIME**

With ignition switch ON, vehicle speed more than 20km/h and seat belt unfastened [seat belt buckle switch (driver side)], warning chime will be sound.

Ground is supplied

- to combination meter 9
- though seat belt buckle switch LH (LHD) or RH (RHD) terminal 2
- though seat belt buckle switch LH (LHD) or RH (RHD) terminal 1
- though body grounds B17, B23 and B81 (retractable hard top models) or B17, B23, B44 and B51 (hatch back models).

Will these conditions, when power and ground are supplied, the seat belt warning chime sounds.

### **RETRACTABLE HARD TOP WARNING CHIME**

Refer to RF-40, "[INDICATOR LAMP AND BUZZER FUNCTION](#)"

# WARNING CHIME

## CAN Communication SYSTEM DESCRIPTION

EKS00K3B

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

EKS00QPH

Body type	3door/5door	3door/5door/C+C	3door/5door	3door/5door/C+C	3door/5door
Axle	2WD				
Engine	CR12DE/CR14DE	HR16DE	CR12DE/CR14DE	HR16DE	K9K
Handle	LHD/RHD				
Brake control	ABS			ESP	
Transmission	A/T	M/T	A/T	M/T	
Intelligent Key system	×	×	×	×	×

### CAN communication unit

ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×					×	×						
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	DI-82, "TYPE 1/TYPE 2"	DI-85, "TYPE 3/TYPE 4/ TYPE 5/TYPE 6"			DI-87, "TYPE 7/TYPE 8"	DI-90, "TYPE 9/TYPE 10/ TYPE 11/TYPE 12"			DI-92, "TYPE 13/TYPE 14"					

×

A

B

C

D

E

F

G

H

I

J

DI

L


M

# WARNING CHIME


## TYPE 1/TYPE 2

### System diagram

- Type 1



- Type 2



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R						
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T						R	
Closed throttle position signal	T						R	
Wide open throttle position signal	T						R	
Overdrive control switch signal		T					R	

# WARNING CHIME

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/T position indicator signal		R					T	
Stop lamp switch signal		T					R	
O/D OFF indicator signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J

DI  
 L  
 M

## WARNING CHIME


Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/C switch signal	R				T			
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

# WARNING CHIME


## TYPE 3/TYPE 4/TYPE 5/TYPE 6

### System diagram

- Type 3/Type 5



- Type 4/Type 6



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R

# WARNING CHIME

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		


\*: C+C only

# WARNING CHIME


## TYPE 7/TYPE 8

### System diagram

- Type 7



- Type 8



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R				R		
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T					R	R	
Closed throttle position signal	T						R	
Wide open throttle position signal	T						R	
Overdrive control switch signal		T					R	
A/T position indicator signal		R					T	

# WARNING CHIME

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
A/T shift schedule change demand signal						T	R	
Stop lamp switch signal		T					R	
O/D OFF indicator lamp signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
ESP warning lamp signal		R				T		
ESP OFF indicator signal		R				T		
SLIP indicator lamp signal		R				T		
Steering angle signal				T		R		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			

## WARNING CHIME

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				
A/C switch signal	R				T			
A/T torque signal						R	T	
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

A

B

C

D

E

F

G

H

I

J

DI

L


M

# WARNING CHIME


## TYPE 9/TYPE 10/TYPE 11/TYPE 12

### System diagram

- Type 9/Type 11



- Type 10/Type 12



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R				R	
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Accelerator pedal position signal	T					R	
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R

# WARNING CHIME

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Low beam request signal					T		R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
ESP warning lamp signal		R				T	
ESP OFF indicator signal		R				T	
SLIP indicator lamp signal		R				T	
Steering angle signal				T		R	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		

\*: C+C only

A  
B  
C  
D  
E  
F  
G  
H  
I  
J


DI  
L  
M

# WARNING CHIME


## TYPE 13/TYPE 14

### System diagram

- Type 13



- Type 14



# WARNING CHIME

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R			R		
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R
High beam request signal		R			T		R
Day time light request signal					T		R
Vehicle speed signal	R	R		R	R	T	
	R	T	R	R			
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
Glow indicator signal	T	R					
R range signal					R		T


A  
B  
C  
D  
E  
F  
G  
H  
I  
J

DI  
L  
M

## WARNING CHIME

## **Schematic**

EKS00EKJ







# WARNING CHIME

## Wiring Diagram — CHIME —




EKS0072N

### DI-CHIME-01



REFER TO THE FOLLOWING.

M16 -FUSE BLOCK-  
JUNCTION BOX (J/B)  
M81 -JOINT CONNECTOR (J/C)





MKWA4042E

## WARNING CHIME

DI-CHIME-02

DATA LINE



1 REFER TO THE FOLLOWING.

### M1 -SUPERB MULTIPLE



### JUNCTION (SM-1)

M16 -ELISE BLOCK-

**INTRODUCTION**

# WARNING CHIME

DI-CHIME-03



MKWA4043E







## WARNING CHIME

DI-CHIME-04

 : LHD MODELS

**R** : RHD MODELS




CC : C+C



# WARNING CHIME

## Terminals and Reference Value for BCM

EKS00837

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Measurement method	
2	B	Ground	ON	—	0
3	P (OR)	Key switch signal	OFF	key is withdrawn.	0
				Key is inserted.	Battery voltage
7	BR	Combination switch input 5	ON	—	 SKIA2166J
8	L	Combination switch input 3			
9	PU	Combination switch input 1			
27	GY	Combination switch input 4			
28	G	Combination switch input 2			
13	GY	Combination switch output 1	ON	Headlamp, turn signal and wipers are OFF. (wiper INT volume is 1 or 7)	 SKIA2166J
14	P	Combination switch output 3			
15	W	Combination switch output 5			
33	R	Combination switch output 2			
34	Y	Combination switch output 4	ON	Headlamp, turn signal and wipers are OFF. (wiper INT volume is other than 1 and 7)	 SKIA2167J
19	R	CAN H			
24	OR	Ignition switch (ON or START)	ON	—	Battery voltage
29	L	Front door switch (driver side)	OFF	ON (open)	0
				OFF (closed)	Battery voltage
39	W	CAN L	—	—	—
70	B	Ground	ON	—	0
74	Y	Battery power supply	OFF	—	Battery voltage
79	Y	Battery power supply	OFF	—	Battery voltage

( ) : Without Intelligent Key system

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

## WARNING CHIME

### Terminals and Reference Value for Combination Meter

EKS000QNS

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Measurement method	
1	R	CAN H	—	—	—
2	W	CAN L	—	—	—
9	OR	Seat belt buckle switch (Driver side)	ON	Unfastened.	0
				Fastened.	Battery voltage
21	B	Ground	ON	—	0
22	B	Ground	ON	—	0
23	B	Ground	ON	—	0
27	LG	Battery power supply	OFF	—	Battery voltage
28	GY	Ignition switch (ON or START)	ON	—	Battery voltage

## CONSULT-II Inspection Procedure

EKS00720

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

## DIAGNOSTIC ITEMS DESCRIPTION


BCM diagnosis position	Diagnosis mode	Description
BUZZER	Data monitor	The input data to the BCM is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
BCM	Self-diagnosis	BCM performs self-diagnosis of CAN communication.

## CONSULT-II BASIC OPERATION


**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.



3. Turn ignition switch "ON".
4. Touch "START" (NISSAN BASED VHCL).




5. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




# WARNING CHIME

6. Touch "BUZZER" on "SELECT TEST ITEM".



7. Touch "DATA MONITOR" or "ACTIVE TEST" on "SELECT DIAG MODE" screen.



## CONSULT-II Application Items

### DATA MONITOR

EKS008WL

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
PUSH SW (*1)	Indicates [ON/OFF] condition of ignition knob switch.
KEY IN SW (*2)	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch (passenger side).
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
BACKDOOR SW	Indicates [ON/OFF] condition of back door switch.
CDL LOCK SW	Indicates [ON/OFF] condition of door lock/unlock switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of door lock/unlock switch.
LIGHTING SW	Indicates [ON/OFF] condition of lighting switch.
TRANK OPNR SW	Indicates [ON/OFF] condition of back door release actuator.

\*1: displayed for models with Intelligent Key System.

\*2: displayed for models without Intelligent Key System.

## ACTIVE TEST

Test item	Description
LIGHT WARN ALM	This test is check light warning chime operation. Light warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.
KEY REMINDER WARN	This test is check key warning chime operation. Key warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.
BACK DR OPEN WARN	This test is check back door open warning chime operation. Back door open warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.
DOOR WARNIG IND	This test is check door warning chime operation. Door warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.

# WARNING CHIME

## Symptom Chart

EKS0072P

Symptom	Diagnoses/Service procedure	Reference page
Light warning chime does not activate.	1. Power supply and ground circuit check	<a href="#">DI-103</a>
	2. Lighting switch check	<a href="#">DI-104</a>
	3. Front door switch (driver side) check	<a href="#">DI-111</a>
	4. Ignition ON signal check	<a href="#">DI-110</a>
Key warning chime does not activate.	1. Power supply and ground circuit check	<a href="#">DI-103</a>
	2. Key switch signal check/with Intelligent Key system	<a href="#">DI-107</a>
	3. Key switch signal check/without Intelligent Key system	<a href="#">DI-105</a>
	4. Front door switch (driver side) check	<a href="#">DI-111</a>
	5. Ignition ON signal check	<a href="#">DI-110</a>
Ignition switch OFF warning chime does not activate./With Intelligent Key system	1. Power supply and ground circuit check	<a href="#">DI-103</a>
	2. Ignition knob switch signal check	<a href="#">DI-108</a>
	3. Front door switch (driver side) check	<a href="#">DI-111</a>
	4. Ignition ON signal check	<a href="#">DI-110</a>
Seat belt warning chime does not activate.	1. CAN communication check	<a href="#">LAN-7</a>
	2. Ignition ON signal check	<a href="#">DI-110</a>
	3. Seat belt buckle switch check	<a href="#">DI-112</a>
	4. Replace combination meter	<a href="#">DI-37</a>
All warning chimes do not activate.	1. Power supply and ground circuit check	<a href="#">DI-103</a>
	2. BCM self-diagnosis check	<a href="#">BCS-21</a>

## Power Supply and Ground Circuit Check

EKS0072Q

### 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check the voltage between BCM connector and ground.


Terminals		Ignition switch position		
Connector	(+)	(-)	OFF	ACC
M50	74 (Y)	Ground	Battery voltage	Battery voltage
	79 (Y)		Battery voltage	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 40A fusible link [letter J , located in fuse and fusible link box.]
- Harness for open or short between BCM and fuse



# WARNING CHIME


## 2. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector M48 terminal 2, M50 terminal 70 and ground.

2 (B) - Ground	: Continuity should exist.
70 (B) - Ground	: Continuity should exist.

OK or NG

OK >> INSPECTION END  
NG >> Repair ground harness.



## Lighting Switch Input Signal Check

EKS0072R

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

#### With CONSULT-II

Check lighting switch ("LIGHTING SW") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in : LIGHTING SW ON  
1st or 2nd position  
When lighting switch is in : LIGHTING SW OFF  
OFF position

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
LIGHTING SW	OFF
TRNK OPNR SW	OFF

Page Up

RECORD

MODE	BACK	LIGHT	COPY
------	------	-------	------

MKIB0848E

OK or NG

OK >> GO TO 2.  
NG >> Check combination switch. Refer to [LT-219, "Check Combination Switch"](#) .

## 2. CHECK BCM SELF-DIAGNOSIS

Perform BCM self-diagnosis. Refer to [BCS-21, "CONSULT-II Function \(BCM\)"](#) in BCS section.

SELF-DIAG RESULTS		
DTC RESULTS		TIME
NO DTC IS DETECTED. FURTHER TESTING. MAY BE REQUIRED.		

MKIB0460E

Self-diagnosis result contents

NO DTC DETECTED>>Replace BCM.  
CAN communication circuit>>Refer to [BCS-30, "CAN Communication Inspection With CONSULT-II \(Self-Diagnosis\)"](#) .

## Key Switch Signal Check/Without Intelligent Key System

EKS0072S

## 1. CHECK KEY SWITCH INPUT SIGNAL

## With CONSULT-II

Check key switch ("KEY IN SW") in "DATA MONITOR" mode with CONSULT-II.

When key is inserted to  
ignition key cylinder : KEY IN SW ONWhen key is withdrawn  
from ignition key cylinder : KEY IN SW OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	OFF
DOOR SW 1	OFF
DOOR SW 2	OFF
DOOR SW 3	ON
DOOR SW 4	ON
DOOR SW BACK	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

MKIB0567E

## Without CONSULT-II


Check voltage between BCM and ground.

Connector	Terminal (Wire color)		Condition	Voltage [V] (Approx.)
	(+)	(-)		
M48	3 (OR)	Ground	Key is inserted	Battery voltage
			key is withdrawn	0

OK or NG

OK &gt;&gt; Key switch is OK.

NG &gt;&gt; GO TO 2.



## 2. CHECK KEY SWITCH POWER SUPPLY CIRCUIT

1. Disconnect key switch harness connector.
2. Check voltage between key switch harness connector M33 terminal 1 and ground.


1 (Y) – Ground : Battery voltage

OK or NG

OK &gt;&gt; GO TO 3.

NG &gt;&gt; Check the following.

- 10A fuse [No. 6, located in fuse block (J/B)]
- Harness for open or short between key switch and fuse



# WARNING CHIME

## 3. CHECK KEY SWITCH INPUT SIGNAL CIRCUIT


Check harness continuity between key switch harness connector M33 terminal 2 and BCM harness connector M48 terminal 3.

**2 (OR) – 3 (OR)** : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair or replace harness.



## 4. CHECK KEY SWITCH


Check continuity between key switch harness connector M33 terminals 1 and 2.

Terminal	Condition	Continuity
1	Key is inserted.	Yes
	key is withdrawn.	No

OK or NG

OK >> Key switch is OK.

NG >> Replace key switch.



# WARNING CHIME

## Key Switch Signal Check/With Intelligent Key System

EKS0081H

### 1. CHECK KEY SWITCH INPUT SIGNAL

#### With CONSULT-II

Check ignition knob switch ("PUSH SW") in "DATA MONITOR" mode with CONSULT-II.

When ignition knob is pushed : PUSH SW ON

When ignition knob is released : PUSH SW OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

MKIB0847E


#### Without CONSULT-II

Check voltage between BCM and ground.

Connector	Terminal (wire color)		Condition	Voltage [V] (Approx.)
	(+)	(-)		
M48	3 (P)	Ground	Key is inserted.	Battery voltage
			key is withdrawn.	0

OK or NG

OK >> Key switch and ignition knob switch is OK.  
NG >> GO TO 2.



MKIB0739E

### 2. CHECK KEY SWITCH POWER SUPPLY CIRCUIT


1. Disconnect key switch and ignition knob switch harness connector.
2. Check voltage between key switch and ignition knob switch harness connector M34 terminal 1 and ground.

1 (W) – Ground : Battery voltage

OK or NG

OK >> GO TO 3.  
NG >> Check the following.

- 10A fuse [No. 6 located in fuse block (J/B)]
- Harness for open or short between key switch and ignition knob switch and fuse



MKIB0546E

# WARNING CHIME

## 3. CHECK KEY SWITCH INPUT SIGNAL CIRCUIT


Check harness continuity between key switch and ignition knob switch harness connector M34 terminal 2 and BCM harness connector M48 terminal 3.

**2 (P) – 3 (P)** : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair or replace harness.



## 4. CHECK KEY SWITCH AND IGNITION KNOB SWITCH


Check continuity between key switch and ignition knob switch harness connector M34 terminals 1 and 2.

Terminal		Condition	Continuity
1	2	Key is inserted.	Yes
		key is withdrawn.	No

OK or NG

OK >> Key switch and ignition knob switch is OK.

NG >> Replace key switch and ignition knob switch.



## Ignition Knob Switch Signal Check

EKS008II


### 1. PERFORM INTELLIGENT KEY UNIT SELF-DAIAGNOSIS

Perform Intelligent Key unit self-diagnosis, Refer to [BL-213, "CONSULT-II Function \(INTELLIGENT KEY\)"](#).

Self-diagnosis result contents

NO DTC DETECTED>>GO TO 2.

CAN communication circuit>>Refer to [BL-220, "Check CAN Communication System"](#).



# WARNING CHIME

## 2. CHECK KEY SWITCH INPUT SIGNAL

### With CONSULT-II

Check ignition knob switch ("PUSH SW") in "DATA MONITOR" mode with CONSULT-II.

**When ignition knob switch is pushed** : PUSH SW ON

**When ignition knob switch is leaved** : PUSH SW OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

MKIB0847E


### Without CONSULT-II

Check voltage between Intelligent Key unit and ground.

Connector	Terminal (Wire color)		Condition	Voltage [V] (Approx.)
	(+)	(-)		
M51	7 (GY)	Ground	Ignition knob switch is pushed.	Battery voltage
			Ignition knob switch is leaved.	0

OK or NG

OK >> Key switch and ignition knob switch is OK.  
NG >> GO TO 3.



## 3. CHECK IGNITION KNOB SWITCH POWER SUPPLY CIRCUIT


1. Disconnect key switch and ignition knob switch harness connector.
2. Check voltage between key switch and ignition knob switch harness connector M34 terminal 3 and ground.

**3 (BR) – Ground : Battery voltage**

OK or NG

OK >> GO TO 4.  
NG >> Check the following.

- 10A fuse [No. 17, located in fuse block (J/B)]
- Harness for open or short between key switch and ignition knob switch and fuse




## 4. CHECK KEY SWITCH AND IGNITION KNOB SWITCH INPUT SIGNAL CIRCUIT

Check harness continuity between key switch and ignition knob switch harness connector M34 terminal 4 and Intelligent Key unit harness connector M51 terminal 7.

**4 (GY) – 7 (GY) : Continuity should exist.**

OK or NG

OK >> GO TO 5.  
NG >> Repair or replace harness.



# WARNING CHIME


## 5. CHECK KEY SWITCH AND IGNITION KNOB SWITCH

Check continuity between key switch and ignition knob switch harness connector M34 terminals 3 and 4.

Terminal		Condition	Continuity
3	4	Ignition knob switch is pushed.	Yes
		Ignition knob switch is leaved.	No

OK or NG

OK    >> Key switch and ignition knob switch is OK.  
 NG    >> Replace key switch and ignition knob switch.



## Ignition ON Signal Check

EKS0087C


### 1. CHECK IGNITION ON SIGNAL

#### With CONSULT-II

Check ignition switch "ON" signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.

**When ignition switch is ON : IGN ON SW ON**

**When ignition switch is OFF : IGN ON SW OFF**



#### Without CONSULT-II

Check voltage between BCM harness connector and ground.


Connector	Terminal (Wire color)		Ignition switch position		
	(+)	(-)	OFF	ACC	ON
M48	24 (OR)	Ground	0V	0V	Battery voltage

OK or NG

OK    >> INSPECTION END

NG    >> Check the following.

- 10A fuse [No. 4, located in fuse block (J/B)].
- Harness for open or short between BCM and fuse.



# WARNING CHIME

## Front Door Switch (Driver side) Check

EKS0072T

### 1. CHECK FRONT DOOR SWITCH (DRIVER SIDE) INPUT SIGNAL

#### With CONSULT-II

Check front door switch ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.

When driver's door is open : DOOR SW-DR ON

When driver's door is closed : DOOR SW-DR OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

MKIB0847E

#### Without CONSULT-II


Check voltage between BCM harness and ground.

Connector	Terminal (wire color)		Condition (Driver's door)	Voltage [V] (Approx.)
	(+)	(-)		
M48	29 (L)	Ground	Door is opened.	0
			Door is closed.	Battery voltage

OK or NG

OK >> INSPECTION END

NG >> GO TO 2.



MKIB0463E

### 2. CHECK DOOR SWITCH OPEN OR SHORT CIRCUIT

1. Disconnect BCM connector and front door switch (driver side) connector.
2. Harness continuity between BCM harness connector M48 terminal 29 and front door switch (driver side) connector B22 (LHD models) or B16 (RHD models) terminal 1.

29 (L) - 1 (LG or L) : Continuity should exist.


3. Harness continuity between BCM harness connector M48 terminal 29 and ground.

29 (L) - Ground : Continuity should not exist.

OK or NG

OK >> Check front door switch (driver side) ground condition.

NG >> Repair harness or connector.



MKIB0464E

# WARNING CHIME

## Seat Belt Buckle Switch Check

EKS000QNT


### 1. CHECK SEAT BELT BUCKLE SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter connector and ground.

Connector	Terminal (wire color)		Condition of driver side seat belt	Voltage [V] (Approx.)
	(+)	(-)		
M22	9 (OR)	Ground	Fastened	Battery voltage
			Unfastened.	0

OK or NG

OK >> INSPECTION END  
NG >> GO TO 2.



### 2. CHECK DOOR SWITCH OPEN OR SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter and seat belt buckle switch LH (LHD) or RH (RHD) connector.
3. Harness continuity between combination meter connector M22 terminal 9 and seat belt buckle switch connector B10 (LHD models) or B5 (RHD models) terminal 2.


**9 (OR) - 2 (OR) : Continuity should exist.**

4. Harness continuity between combination meter connector M22 terminal 9 and ground.

**9 (OR) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 3.  
NG >> Repair harness or connector.




### 3. CHECK SEAT BELT BUCKLE SWITCH

Check continuity between seat belt buckle switch terminals 1 and 2.

Terminal		Condition of driver side seat belt	Continuity
1	2	Fastened	No
		Unfastened.	Yes

OK or NG

OK >> GO TO 4.  
NG >> Replace driver side seat belt buckle switch.



## WARNING CHIME


### 4. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch connector B10 (LHD) or B5 (RHD) terminal 1 and ground.

**1 (B) – Ground** : Continuity should exist.

OK or NG

OK >> Check the condition of harness and connector.  
NG >> Repair or replace



A

B

C

D

E

F

G

H

I

J

DI

L

M

## **WARNING CHIME**

---