

SECTION **GW**

GLASSES, WINDOW SYSTEM & MIRRORS

CONTENTS

HATCHBACK

APPLICATION NOTICE	4
How to Check Vehicle Type	4
PRECAUTIONS	5
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5
Precautions for Procedures without Cowl Top Cover....	5
Precautions	5
WINDSHIELD GLASS	6
Removal and Installation	6
REMOVAL	6
INSTALLATION	8
SIDE WINDOW GLASS	10
Removal and Installation	10
REMOVAL	10
INSTALLATION	10
BACK DOOR WINDOW GLASS	12
Removal and Installation	12
REMOVAL	12
INSTALLATION	13
REAR WINDOW DEFOGGER	16
Component Parts and Harness Connector Location..	16
System Description	16
CAN Communication	18
SYSTEM DESCRIPTION	18
CAN Communication Unit	18
TYPE 1/TYPE 2	19
TYPE 3/TYPE 4/TYPE 5/TYPE 6	22
TYPE 7/TYPE 8	24
TYPE 9/TYPE 10/TYPE 11/TYPE 12	27
TYPE 13/TYPE 14	29
Schematic – DEF –	31
Wiring Diagram –DEF–	32
Terminal and Reference Value for BCM	35
Terminal and Reference Value for IPDM E/R	35
Work Flow	35
CONSULT-II Inspection Procedure	36
DATA MONITOR	37
ACTIVE TEST	37

Trouble Diagnoses Symptom Chart	38
BCM Power Supply and Ground Circuit Check	38
Rear Window Defogger Switch Circuit Check/With Auto A/C	40
Rear Window Defogger Switch Circuit Check/Without Auto A/C	41
Rear Window Defogger Power Supply Circuit Check	43
Rear Window Defogger Circuit Check	44
Door Mirror Defogger Power Supply Circuit Check..	45
Driver Side Door Mirror Defogger Circuit Check ...	46
Passenger Side Door Mirror Defogger Circuit Check	47
Filament Check	48
Filament Repair	49
REPAIR EQUIPMENT	49
REPAIRING PROCEDURE	49
POWER WINDOW SYSTEM	50
Component Parts and Harness Connector Location..	50
System Description	50
FRONT DRIVER SIDE DOOR	51
FRONT PASSENGER SIDE DOOR	51
AUTO OPERATION	53
Wiring Diagram – WINDOW – / Conventional Type..	54
Wiring Diagram – WINDOW – / Auto Operation Type..	56
Terminal and Reference Value for BCM	58
Work Flow	58
Trouble Diagnosis Symptom Chart / Conventional Type	58
Trouble Diagnosis Symptom Chart / Auto Operation Type	59
BCM Power Supply and Ground Circuit Check	59
Power Window Switch Power Supply and Ground Circuit Check / Conventional Type	60
Power Window Switch Power Supply and Ground Circuit Check / Auto Operation Type	62
Power Window Main Switch Check / Conventional Type	63
Power Window Main Switch Check / Auto Operation Type	64

Front Power Window Motor (Driver Side) Check (LHD models) / Conventional Type	64	(SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	87
Front Power Window Motor (Driver Side) Check (LHD models) / Auto Operation Type	65	Precautions for Procedures without Cowl Top Cover ..	87
Front Power Window Motor (Driver Side) Check (RHD models) / Conventional Type	66	Precautions	87
Front Power Window Motor (Driver Side) Check (RHD models) / Auto Operation Type	66	WINDSHIELD GLASS	88
Front Power Window Motor (Passenger Side) Check	67	Removal and Installation	88
Front Power Window Switch (Passenger Side) Check	68	REMOVAL	88
Front Power Window Switch (Passenger Side) Circuit Check (LHD models) / Conventional Type	69	INSTALLATION	90
Front Power Window Switch (Passenger Side) Circuit Check (LHD models) / Auto Operation Type	70	FRONT ROOF GLASS	92
Front Power Window Switch (Passenger Side) Circuit Check (RHD models) / Conventional Type	71	Removal and Installation	92
Front Power Window Switch (Passenger Side) Circuit Check (RHD models) / Auto Operation Type	72	REMOVAL	92
Front Power Window Switch (Passenger Side) Power Supply Check	73	INSTALLATION	93
FRONT DOOR GLASS AND REGULATOR	74	REAR ROOF GLASS	94
Removal and Installation	74	Removal and Installation	94
REMOVAL	74	REMOVAL	94
INSTALLATION	75	INSTALLATION	95
INSPECTION AFTER REMOVAL	76	REAR WINDOW DEFOGGER	96
SETTING AFTER INSTALLATION (DRIVER'S SIDE ONLY)	76	Component Parts and Harness Connector Location ..	96
FITTING INSPECTION	76	System Description	96
REAR DOOR GLASS AND REGULATOR	77	CAN Communication	99
Removal and Installation	77	SYSTEM DESCRIPTION	99
REMOVAL	77	CAN Communication Unit	99
INSPECTION AFTER REMOVAL	78	TYPE 1/TYPE 2	100
INSTALLATION	79	TYPE 3/TYPE 4/TYPE 5/TYPE 6	103
FITTING INSPECTION	79	TYPE 7/TYPE 8	105
DOOR MIRROR	80	TYPE 9/TYPE 10/TYPE 11/TYPE 12	108
Wiring Diagram — MIRROR — LHD Models	80	TYPE 13/TYPE 14	110
Wiring Diagram — MIRROR — RHD Models	81	Schematic — DEF —	112
Removal and Installation	82	Wiring Diagram —DEF—	113
REMOVAL	82	Terminal and Reference Value for BCM	116
INSTALLATION	82	Terminal and Reference Value for IPDM E/R	116
Disassembly and Assembly	83	Work Flow	116
DISASSEMBLY	83	CONSULT-II Inspection Procedure	117
ASSEMBLY	83	DATA MONITOR	118
INSIDE MIRROR	85	ACTIVE TEST	118
Removal and Installation	85	Trouble Diagnoses Symptom Chart	119
REMOVAL	85	BCM Power Supply and Ground Circuit Check ..	119
INSTALLATION	85	Rear Window Defogger Switch Circuit Check / With	
Removal and Installation (With Rain Sensor)	85	Auto A/C	121
REMOVAL	85	Rear Window Defogger Switch Circuit Check / With-	
INSTALLATION	85	out Auto A/C	122
POWER WINDOW SYSTEM	131	Rear Window Defogger Power Supply Circuit	
Component Parts and Harness Connector Location ..	131	Check	124
System Description	131	Rear Window Defogger Circuit Check	125
DRIVER SIDE WINDOW (LHD MODELS)	132	Door Mirror Defogger Power Supply Circuit Check ..	126
DRIVER SIDE WINDOW (RHD MODELS)	133	Driver Side Door Mirror Defogger Circuit Check ..	127
FRONT PASSENGER SIDE WINDOW (LHD MODELS)	134	Passenger Side Door Mirror Defogger Circuit Check ..	

C+C

APPLICATION NOTICE	86
How to Check Vehicle Type	86
PRECAUTIONS	87
Precautions for Supplemental Restraint System	

FRONT PASSENGER SIDE WINDOW (RHD MODELS)	136	FRONT DOOR GLASS AND REGULATOR	170
REAE LH SIDE WINDOW (LHD MODELS)	138	Removal and Installation	170
REAE LH SIDE WINDOW (RHD MODELS)	139	DOOR GLASS	170
REAE RH SIDE WINDOW (LHD MODELS)	141	REGULATOR ASSEMBLY	171
REAE RH SIDE WINDOW (RHD MODELS)	143	Disassembly and Assembly	172
AUTO OPERATION	143	REGULATOR ASSEMBLY	172
Schematic – WINDOW –	144	ASSEMBLY	172
Wiring Diagram – WINDOW –	145	Inspection after Installation	172
Terminal and Reference Value for BCM	149	FITTING INSPECTION	172
Terminal and Reference Value for Retractable Hard Top	149	SIDE WINDOW GLASS	174
CONSULT-II Inspection Procedure	150	Removal and Installation	174
DATA MONITOR	151	REMOVAL	174
ACTIVE TEST	151	INSTALLATION	175
Work Flow	151	INSPECTION AFTER REMOVAL	175
Trouble Diagnosis Symptom Chart / LHD Models	152	Disassembly and Assembly	176
Trouble Diagnosis Symptom Chart / RHD Models	152	DISASSEMBLY	176
Power Window Circuit Check 1	152	ASSEMBLY	176
Power Window Circuit Check 2	155	Inspection after Installation	176
Power Window Circuit Check 3	157	FITTING INSPECTION	176
Power Window Circuit Check 4	158	DOOR MIRROR	177
Power Window Circuit Check 5	159	Wiring Diagram — MIRROR — LHD Models	177
Power Window Circuit Check 6	160	Wiring Diagram — MIRROR — RHD Models	178
Front Power Window Motor LH Circuit Check 1 ..	161	Removal and Installation	179
Front Power Window Motor LH Circuit Check 2 ..	162	REMOVAL	179
Front Power Window Motor RH Circuit Check 1 ..	163	INSTALLATION	179
Front Power Window Motor RH Circuit Check 2 ..	164	Disassembly and Assembly	179
Rear Power Window Motor LH Circuit Check 1 ..	165	DISASSEMBLY	180
Rear Power Window Motor LH Circuit Check 2 ..	166	ASSEMBLY	180
Rear Power Window Motor RH Circuit Check 1 ..	167	INSIDE MIRROR	181
Rear Power Window Motor RH Circuit Check 2 ..	168	Removal and Installation	181
Power Window Main Switch Ground Circuit Check ..	169	REMOVAL	181
		INSTALLATION	181

A
B
C
D
E
F
G
H
GW
J
K
L
M

APPLICATION NOTICE

[HATCHBACK]

APPLICATION NOTICE

PFP:00000

How to Check Vehicle Type

EIS000DWS

Confirm K9K engine type with Model written on identification plate (refer to [GI-44, "IDENTIFICATION INFORMATION"](#)), then refer to service information in GW section.

Vehicle type	Engine type
xTKxxxxK12Vxx	Euro3 48kW
xTKxxxxK12Yxx	Euro3 60kW
xTKxxxxK12Txx	Euro4 50kW
xTKxxxxK12Uxx	Euro4 63kW

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EIS004PK

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Procedures without Cowl Top Cover

EIS00DZ1

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.

**Precautions**

EIS004PL

- When removing or disassembling any part, be careful not to damage or deform it. Protect parts, which may get in the way with cloth.
- When removing parts with a screwdriver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If a clip is deformed or damaged, replace it.
- If an unreusable part is removed, replace it with a new one.
- Tighten bolts and nuts firmly to the specified torque.
- After re-assembly has been completed, make sure each part functions correctly.
- Remove stains in the following way.

Water-soluble stains:

Dip a soft cloth in warm water, and then squeeze it tightly. After wiping the stain, wipe with a soft dry cloth.

Oil stain:

Dissolve a synthetic detergent in warm water (density of 2 to 3% or less), dip the cloth, then clean off the stain with the cloth. Next, dip the cloth in fresh water and squeeze it tightly. Then clean off the detergent completely. Then wipe the area with a soft dry cloth.

- Do not use any organic solvent, such as thinner or benzine.

WINDSHIELD GLASS


[HATCHBACK]

WINDSHIELD GLASS

Removal and Installation

PFP:72712

EIS004K7




1. Windshield molding

2. Windshield glass

REMOVAL

1. Remove headlining. Refer to [EI-33, "HEADLINER"](#) .
2. Remove cowl top cover. Refer to [EI-13, "COWL TOP"](#) .
3. Peel off double-sided tape and remove front fender covers (LH/RH) from front fenders (LH/RH).




4. Apply protective tape around windshield glass to protect the painted surface from damage.
5. Guiding a cutter knife along glass, cut the surface of moldings.
6. With pliers, draw out all the remaining molding left in flanged area of body to remove it completely from adhering surface on glass.

WINDSHIELD GLASS

[HATCHBACK]

- When re-using the windshield glass, put match marks on body and glass.




7. Cut adhesive.

- Depending on the tool in use, follow the procedures below:

CAUTION:

If windshield glass is reused, do not use a windshield knife. (It may scratch glass surface.)

- With a windshield knife (when replacing glass).
- To smoothly cut with windshield knife, apply soapy water onto the adhesive on the body side surrounding the windshield.
- Insert windshield knife into the bonded area. Cut adhesive by pulling the knife, keeping the tip parallel to glass edge.





b. With a piano wire (when reusing glass).

- Working from inside cabin, drill a through hole in the adhesive with a drill or pick.
- From inside the passenger room, pass a piano wire through the hole and tie both ends to screwdrivers or similar tools.
- With two persons, one holding one end of the piano wire outside the vehicle while the other holding the other end inside the vehicle, pulling the wire alternately to cut off the adhesive.

CAUTION:

- Do not press piano wire excessively against glass edge.
- Put a copper plate to keep the piano wire clear of plastic parts such as the instrument panel.

- Use rubber suction cups (SST) to remove glass from the vehicle.




INSTALLATION


1. Using a knife or spatula, trim the adhesive (sealant) remaining on body down to approximately 2 mm thick so that the contour becomes smooth.

CAUTION:

If bonded area on body is scratched, be sure to repair it with a 2-component urethane. Do not use lacquer.



2. Put the clip in the panel hole.
3. When installing new glass, mount glass onto the vehicle and paint mating marks on body and glass, then remove glass again.
4. When reusing glass, use a knife or spatula to remove the remaining adhesive (sealant) and smooth out the surface.
5. Clean bonded area on glass with white gasoline.



6. Apply primer G along the entire circumference of glass.

CAUTION:

There are 2 types of primer. Never confuse the application methods.

Primer M: for painted surfaces

Primer G: for glass

NOTE:

The essential function of primers is to strengthen adhesion between glass and painted surface.

7. Apply primer M on areas where adhesive contacts on the side of vehicle body.

CAUTION:

- If primer M adheres to a painted surface other than bonding area, or if it overflows, quickly remove it with white gasoline.
- Place a copper plate to keep primer M clear of the instrument panel.

8. After applying primers, apply the adhesive along the entire circumference of the glass as shown in the figure, and within the time specified in the instructions for the adhesive.


- Open adhesive by cutting off the nozzle tip and set it in a sealant gun.

9. After setting rubber suction cups (SST) to glass, align mating marks on body and glass. Install glass to the body.

10. Press entire surface of glass lightly to fit it completely.

11. Remove protective tape.

12. Using a spatula, repair any adhesive overflow or shortage to make the surface smooth.



13. Position windshield moldings and allow their adhesion. Refer to [EI-16, "WINDSHIELD MOLDING"](#) .

CAUTION:


- Be sure to install windshield molding before adhesive hardens.
- After installing glass, keep door windows open and avoid driving vehicle until adhesive has completely cured.

WINDSHIELD GLASS

[HATCHBACK]

14. Check for water leaks.
15. Remove double-sided tape from front fender cover and apply primer (Sumitomo 3M K520) to double-sided tape application position shown in the figure. Then apply new double-sided tape and install front fender.

Double-sided adhesive tape : Part equivalent to Sumitomo 3M-5571 (t: 0.8)



16. Install cowl top cover. Refer to [EI-13, "COWL TOP"](#).

17. Install headlining. Refer to [EI-33, "HEADLINER"](#).

A
B
C
D

E

F

G

H

GW

J

K

L


M

SIDE WINDOW GLASS

PFP:83300

Removal and Installation

EIS004K8



1. Side window glass

REMOVAL

1. Remove rear side finisher and lock pillar upper garnish. Refer to [EI-26, "Removal and Installation \(3-Door\)"](#).
2. Apply protective tape on body panel along the circumference side window glass to protect coated surfaces from damage.
3. For the side window glass vehicle front side, open front door, and from outside of vehicle insert cutter knife between side window glass and lock pillar panel and cut adhesive parallel to glass.
4. For side window glass adhesion areas other than the above, working from inside vehicle, insert cutter knife between side door window glass and body panel. Guide cutter edge along glass to cut off adhesive.

CAUTION:

Cut carefully so that the tip end of cutter knife does not contact painted surface.

5. Remove glass out of vehicle, unclipping.

INSTALLATION

1. With a knife, scrape off adhesive remaining on the vehicle body to as thin and flat as 2 mm.



CAUTION:

If scratches are made on vehicle-side bonding surface, be sure to repair it. Always use 2-component type urethane paint. Do not use lacquer type paint.

2. Using a knife or spatula to remove the remaining adhesive and smooth out the surface. (When glass is reused)
3. Clean bonded area on glass with white gasoline.
4. Apply primer G along the entire circumference of glass.

CAUTION:

As 2 primers will be used, they must be used exactly as specified.
Primer M: for painted surfaces



Primer G: for glass**NOTE:**


The essential function of primers is to strengthen adhesion between the glass and painted surface primer.

5. Apply primer M on areas where adhesive contacts on the side of vehicle body.

CAUTION:

If primer M adheres to a painted surface other than bonding area, or if it overflows, quickly remove it with white gasoline.

6. After applying primers, apply the adhesive along the entire circumference of the glass as shown in the figure, and within the time specified in the instructions for the adhesive.
 - Open adhesive by cutting off the nozzle tip and set it in a sealant gun.




7. After setting rubber suction cups (SST) to glass, align mating marks on body and glass. Install glass to the body.
8. Press entire surface of glass lightly to fit it completely.
9. Remove protective tape.
10. Using a spatula, go over areas with excessive or insufficient adhesive and neatly smooth the surface.

CAUTION:

After installing glass, keep door windows open and avoid driving vehicle until adhesive has completely cured.

11. Check for water leaks.
12. Install rear side finisher and lock pillar upper garnish. Refer to [EI-26, "Removal and Installation \(3-Door\)"](#).



BACK DOOR WINDOW GLASS


[HATCHBACK]

BACK DOOR WINDOW GLASS

PFP:90300

Removal and Installation

EIS004K9



1. Back door window glass

2. Back door window molding (LH side)

3. Back door window molding (RH side)

REMOVAL

1. Remove back door finisher. Refer to [EI-22, "BACK DOOR TRIM"](#) .
2. Remove high mounted stop lamp. Refer to [LT-203, "Bulb Replacement"](#) .
3. Remove rear wiper arm and rear wiper motor. Refer to [WW-109, "Removal and Installation of Rear Wiper Arm"](#) and [WW-109, "Removal and Installation of Rear Wiper Motor"](#) .
4. Disconnect rear window defogger connector.
5. Apply protective tape around windshield glass to protect the painted surface from damage.
6. Cut adhesive.
 - Depending on the tool in use, follow the procedures below:


CAUTION:

When reusing the glass, do not use the windshield knife. (Because it will damage the glass)

BACK DOOR WINDOW GLASS

[HATCHBACK]


- a. With a windshield knife (when replacing glass).
- i. For smooth movement of windshield knife, apply soapy water around bonded area on glass hatch panel.
- ii. Insert windshield knife into the bonded area from passenger room side. Cut adhesive by pulling the knife, keeping the tip parallel to glass edge.




- b. With a piano wire (when reusing glass).
- i. Working from inside the passenger room, make a hole in the adhesive with the cutter.
- ii. From inside the passenger room, pass a piano wire through the hole and tie both ends to screwdrivers or similar tools.
- iii. With two persons, one holding one end of the piano wire outside the vehicle while the other holding the other end inside the vehicle, pulling the wire alternately to cut off the adhesive.

CAUTION:

- Do not press piano wire excessively against glass edge.



7. Unclip and remove glass from the vehicle with rubber suction cups (SST).




INSTALLATION

1. Using a knife or spatula, trim the bond remaining on body down to approximately 2 mm thick so that the contour becomes smooth.

CAUTION:

If scratches or flaws are made on the body surface in the width of adhesion, be sure to repair them with 2-liquid type urethane paint. Do not use lacquer type paint.


2. When reusing glass, use a knife or spatula to remove the remaining adhesive and smooth out the surface.
3. With white gasoline, clean the glass surface where adhesive is applied and the surrounding areas.



BACK DOOR WINDOW GLASS

[HATCHBACK]

4. Bond the back door window molding to the perimeter of the glass using double-sided tape. (Bond aligning double-sided tape bonded area to glass edge.)



5. Apply primer G along the entire circumference of glass.

CAUTION:

As 2 primers will be used, they must be used exactly as specified.

Primer M: for painted surfaces

Primer G: for glass

NOTE:

The essential function of primers is to strengthen adhesion between the glass and painted surface primer.


6. Apply primer M on areas where adhesive contacts on the side of vehicle body.

CAUTION:


If primer M adheres to a painted surface other than bonding area, or if it overflows, quickly remove it with white gasoline.

7. After applying primers, apply the adhesive along the entire circumference of the glass as shown in the figure, and within the time specified in the instructions for the adhesive.

- Open adhesive by cutting off the nozzle tip and set it in a sealant gun.



8. After setting rubber suction cups (SST) to glass, align the clips with the holes on the body panel and install.



9. Press entire surface of glass lightly to fit it completely.

10. Remove protective tape.

11. Using a spatula, repair any adhesive overflow or shortage and make the surface smooth.

CAUTION:

After installing glass, keep door windows open and avoid driving vehicle until adhesive has completely cured.

12. Check for water leaks.

13. Connect rear window defogger connector.

BACK DOOR WINDOW GLASS

[HATCHBACK]

14. Install rear wiper arm and rear wiper motor. Refer to [WW-109, "Removal and Installation of Rear Wiper Arm"](#) and [WW-109, "Removal and Installation of Rear Wiper Motor"](#) .
15. Install high-mounted stop lamp. Refer to [LT-203, "Bulb Replacement"](#) .
16. Install back door finisher. Refer to [EI-22, "BACK DOOR TRIM"](#) .

A

B

C

D

E

F

G

H

GW

J

K

L


M

REAR WINDOW DEFOGGER

PFP:25350

Component Parts and Harness Connector Location

EIS004KA



EIS004KB

System Description

The rear window defogger system is controlled by BCM (Body Control Module) and IPDM E/R (Intelligent Power Distribution Module Engine Room).

The rear window defogger operates only for approximately 15 minutes.

Power is at all times supplied

- through 15A fuse [No. 45, and 46, located in the IPDM E/R]
- to rear window defogger relay
- through 20A fuse [No. 52, located in the fuse block (J/B)]
- to IPDM E/R
- through 40A fusible link [letter J , located in the fuse block (J/B)]
- to BCM terminal 74 and 79.

With the ignition switch turned to ON or START position,

Power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM terminal 24

Ground is supplied

- to BCM terminal 2 and 70
- through body grounds M19, and M20.
- to A/C auto amp terminal 14 (with auto A/C) or
- to heater control panel terminal 10 (without auto A/C)

- through body grounds M19 and M20.
- to internal CPU of IPDM E/R terminal 3 and 54
- through body grounds E26 and E40. (without CR engine)
- through body grounds E25, E26 and E40. (with CR engine)

When rear window defogger switch is turned to ON,

Ground is supplied

- to BCM terminal 4
- through A/C auto amp terminal 17 (with auto A/C) or
- through heater control panel terminal 9 (without auto A/C)
- through A/C auto amp terminal 14 (with auto A/C) or
- through heater control panel terminal 10 (without auto A/C)
- through body grounds M19 and M20.

Then rear window defogger switch is illuminated.

Then BCM recognizes that rear window defogger switch is turned to ON.

Then it sends rear window defogger switch signals to IPDM E/R via DATA LINE (CAN-H, CAN-L).

When IPDM receives rear window defogger switch signals,

Ground is supplied

- to rear window defogger relay terminal
- through internal CPU of IPDM E/R terminal
- through internal CPU of IPDM E/R and IPDM E/R terminal 54
- through body grounds E26 and E40. (without CR engine)
- through body grounds E25, E26 and E40. (with CR engine)

and then rear window defogger relay is energized.

When rear window defogger relay is turned ON,

Power is supplied,

- through rear window defogger relay terminals
- through IPDM E/R terminal 8
- to rear window defogger terminal 1.

Rear window defogger terminal 2, is grounded through body ground D202.

With power and ground supplied, rear window defogger filaments heat and defog the rear window.

When rear window defogger relay is turned to ON,

Power is supplied (with mirror defogger)

- through rear window defogger relay terminal
- through IPDM E/R terminal 8
- through 10A fuse [No. 13, located in the fuse block (J/B)]
- to door mirror defogger (Driver side and passenger side) terminal 6.

Door mirror defogger (Driver side and passenger side) terminal 5 is grounded through body grounds M19 and M20.

With power and ground supplied, door mirror defogger filaments heat and defog the mirror.

A

B

C

D

E

F

G

H

GW

J

K

L

M

REAR WINDOW DEFOGGER

[HATCHBACK]

CAN Communication SYSTEM DESCRIPTION

EIS00AOW

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EIS00E76

Body type	3door/5door	3door/5door/C+C			3door/5door	3door/5door/C+C			3door/5door		
Axle	2WD										
Engine	CR12DE/CR14DE			HR16DE		CR12DE/CR14DE			HR16DE		
Handle	LHD/RHD										
Brake control	ABS					ESP					
Transmission	A/T		M/T			A/T		M/T			
Intelligent Key system	×		×		×		×		×		

CAN communication unit

ECM	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×					×	×				
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	<u>GW-19. "TYPE 1/ TYPE 2"</u>		<u>GW-22. "TYPE 3/TYPE 4/ TYPE 5/TYPE 6"</u>				<u>GW-24. "TYPE 7/ TYPE 8"</u>	<u>GW-27. "TYPE 9/TYPE 10/ TYPE 11/TYPE 12"</u>			<u>GW-29. "TYPE 13/ TYPE 14"</u>	

×: Applicable


REAR WINDOW DEFOGGER

[HATCHBACK]


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R						
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T							R
Closed throttle position signal	T							R
Wide open throttle position signal	T							R
Overdrive control switch signal		T						R

REAR WINDOW DEFOGGER

[HATCHBACK]

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/T position indicator signal		R					T	
Stop lamp switch signal		T					R	
O/D OFF indicator signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
Brake warning lamp signal		R				T		
Back-up lamp signal					R	T		
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				

REAR WINDOW DEFOGGER

[HATCHBACK]

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/C switch signal	R				T			
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

A

B

C

D

E

F

G

H

GW

J

K

L

M


REAR WINDOW DEFOGGER

[HATCHBACK]


TYPE 3/TYPE 4/TYPE 5/TYPE 6

System diagram

- Type 3/Type 5



- Type 4/Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R

REAR WINDOW DEFOGGER

[HATCHBACK]

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		

*: C+C only

A
B
C
D
E
F
G
H
GW
J
K
L
M


REAR WINDOW DEFOGGER

[HATCHBACK]


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R				R		
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T					R	R	
Closed throttle position signal	T						R	
Wide open throttle position signal	T						R	
Overdrive control switch signal		T					R	
A/T position indicator signal		R					T	

REAR WINDOW DEFOGGER

[HATCHBACK]

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
A/T shift schedule change demand signal						T	R	
Stop lamp switch signal		T					R	
O/D OFF indicator lamp signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
ESP warning lamp signal		R				T		
ESP OFF indicator signal		R				T		
SLIP indicator lamp signal		R				T		
Steering angle signal				T		R		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			

A
B
C
D
E
F
G
H

GW

J
K
L
M

REAR WINDOW DEFOGGER

[HATCHBACK]

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				
A/C switch signal	R				T			
A/T torque signal						R	T	
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T


REAR WINDOW DEFOGGER

[HATCHBACK]


TYPE 9/TYPE 10/TYPE 11/TYPE 12

System diagram

- Type 9/Type 11



- Type 10/Type 12



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R				R	
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Accelerator pedal position signal	T					R	
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R

REAR WINDOW DEFOGGER

[HATCHBACK]

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Low beam request signal					T		R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
ESP warning lamp signal		R				T	
ESP OFF indicator signal		R				T	
SLIP indicator lamp signal		R				T	
Steering angle signal				T			R
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		

*: C+C only


REAR WINDOW DEFOGGER

[HATCHBACK]


TYPE 13/TYPE 14

System diagram

- Type 13



- Type 14



A
B
C
D
E
F
G
H

GW
J
K
L

M

REAR WINDOW DEFOGGER

[HATCHBACK]

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R			R		
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R
High beam request signal		R			T		R
Day time light request signal					T		R
Vehicle speed signal	R	R		R	R	T	
	R	T	R	R			
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
Glow indicator signal	T	R					
R range signal					R		T

REAR WINDOW DEFOGGER

[HATCHBACK]

Schematic – DEF –

EIS004KD







MKWA1387E

REAR WINDOW DEFOGGER

[HATCHBACK]

Wiring Diagram –DEF–

EIS004KE



| REFER TO THE FOLLOWING.




M1 - SUPERB MULTIPLE

JUNCTION (SM-I)




M16 - FUSE BLOCK

REAR WINDOW DEFOGGER

[HATCHBACK]




REFER TO THE FOLLOWING.
M1 - SUPER MULTIPLE
JUNCTION (SMJ)
M16 - FUSE BLOCK -
JUNCTION BOX (J/B)



REAR WINDOW DEFOGGER

[HATCHBACK]

GW-DEF-03



REAR WINDOW DEFOGGER

[HATCHBACK]

Terminal and Reference Value for BCM

EIS004KF

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
2	B	Ground	—	0
4	W	Rear window defogger switch signal	When rear window defogger switch is pressed.	0
			When rear window defogger switch is OFF.	5
19	R	CAN- H	—	—
24	O/R	Ignition switch ON or START	Ignition switch (ON or START position)	Battery voltage
39	W	CAN- L	—	—
70	B	Ground	—	0
74	Y	BAT power supply	—	Battery voltage
79	Y	BAT power supply	—	Battery voltage

Terminal and Reference Value for IPDM E/R

EIS004KG

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
3	B	Ground (Power)	—	0
8	R	Rear window defogger relay output signal	When rear window defogger switch is ON.	Battery voltage
			When rear window defogger switch is OFF.	0
52	R	CAN- H	—	—
54	B	Ground (Signal)	—	0
58	W	CAN- L	—	—

Work Flow

EIS004KH

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [GW-16, "System Description"](#) .
3. According to the trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [GW-38, "Trouble Diagnoses Symptom Chart"](#) .
4. Does rear window defogger operate normally? YES: GO TO 5, NO: GO TO 3.
5. INSPECTION END.

A

B

C

D

E

F

G

H

GW

J

K

L

M

CONSULT-II Inspection Procedure


EIS004KI

Inspection Item, Diagnosis Mode	Description
DATA MONITOR	The input/output data of the BCM is displayed in real time.
ACTIVE TEST	The BCM sends a drive signal to electronic components to check their operation.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunction might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and CONSULT-II CONVERTER to data link connector.




3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM".
If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




6. Touch "REAR DEFOGGER".



REAR WINDOW DEFOGGER

[HATCHBACK]

7. Select diagnosis mode, "DATA MONITOR" and "ACTIVE TEST".



DATA MONITOR

Display Item List

Monitor item "Operation"		Content
REAR DEF SW	"ON / OFF"	Displays "Press (ON) / others (OFF)" status determined with the rear window defogger switch.
IGN ON SW	"ON / OFF"	Displays "IGN SW ON (ON) / OFF (OFF)" status determined with the ignition switch signal.
ENGINE STATUS	"STOP / STALL / RUN / CRA "	Displays "Engine stop (STOP) / engine stall (STALL) / engine running (RUN) / engine cranking (CRA)" as judged from engine status.

ACTIVE TEST

Display Item List

Test item	Content
REAR DEFOGGER	Gives a drive signal to the rear window defogger to activate it.

Trouble Diagnoses Symptom Chart

EIS004KK

- Check that other systems using the signal of the following systems operate normally.

Symptom	Diagnoses / service procedure	Refer to page
Rear window defogger and door mirror defogger do not operate. (With door mirror defogger)	1. BCM power supply and ground circuit check. 2. IPDM E/R auto active test check. 3. Rear window defogger switch circuit check (with auto A/C). 3. Rear window defogger switch circuit check (without auto A/C). 4. Rear window defogger power supply circuit check. 5. Replace IPDM E/ R.	GW-38 PG-43 GW-40 GW-41 GW-43 PG-53
Rear window defogger does not operate. (without door mirror defogger)	1. BCM power supply and ground circuit check. 2. IPDM E/R auto active test check. 3. Rear window defogger switch circuit check (with auto A/C). 3. Rear window defogger switch circuit check (without auto A/C). 4. Rear window defogger power supply circuit check. 5. Rear window defogger circuit check. 6. Filament check. 7. Replace IPDM E/ R.	GW-38 PG-43 GW-40 GW-41 GW-43 GW-44 GW-48 PG-53
Rear window defogger does not operate but both of door mirror defoggers operate. (With door mirror defogger)	1. Rear window defogger circuit check. 2. Filament check.	GW-44 GW-48
Both of door mirror defoggers do not operate but rear window defogger operate. (With door mirror defogger)	1. Door mirror defogger power supply circuit check.	GW-45
Driver side door mirror defogger does not operate. (With door mirror defogger)	1. Driver side door mirror defogger circuit check.	GW-46
Passenger side door mirror defogger does not operate. (With door mirror defogger)	1. Passenger side door mirror defogger circuit check.	GW-47

BCM Power Supply and Ground Circuit Check

EIS004KK

First perform the “SELF-DIAG RESULTS” in “BCM” with CONSULT-II, then perform the each trouble diagnosis of malfunction system indicated “SELF-DIAG RESULTS” of “BCM”, Refer to [BCS-21, "CONSULT-II Function \(BCM\)"](#) .

1. FUSE INSPECTION

- Check 10A fuse [No.4, located in fuse block (J/B)]
- Check 40A fusible link (letter J located in the fuse and fusible link box).

NOTE:

Refer to [GW-16, "Component Parts and Harness Connector Location"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown out, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-5, "POWER SUPPLY ROUTING"](#) .

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM connector M48, M50 terminal 24, 74, 79 and ground.

24 (OR) – Ground :Battery voltage.


74 (W) – Ground :Battery voltage.

79 (Y) – Ground :Battery voltage.

OK or NG

OK >> GO TO 3.

NG >> Check BCM power supply circuit for open or short.



3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM connector M48, M50 terminal 2, 70 and ground.


2 (B) – Ground :Continuity should exist.

70 (B) – Ground :Continuity should exist.

OK or NG

OK >> Power supply and ground circuit is OK.

NG >> Check BCM ground circuit for open or short.



Rear Window Defogger Switch Circuit Check / With Auto A/C

EIS004KL

1. CHECK REAR WINDOW DEFOGGER SWITCH OPERATION**With CONSULT-II**

Check ("REAR DEF SW", "IGN ON SW") in DATA MONITOR mode with CONSULT-II. Refer to [GW-37](#).

When engine is running

ENGINE STATUS :RUN

When rear defogger switch is turned to ON

REAR DEF SW :ON

When ignition switch is turned to ON

IGN ON SW :ON

DATA MONITOR	
MONITOR	
ENGINE STATUS	RUN
REAR DEF SW	OFF
IGN ON SW	ON

MKIB0549E


Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between BCM connector ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	4 (W)	Ground	Rear window defogger switch is pressed.	0
			Rear window defogger switch is OFF.	5

OK or NG

OK >> Rear window defogger switch check is OK.
NG >> GO TO 2.

**2. CHECK REAR WINDOW DEFOGGER SWITCH CIRCUIT HARNESS CONTINUITY**

1. Turn ignition switch OFF.
2. Disconnect BCM and A/C auto amp connector.
3. Check continuity between BCM connector M48 terminal 4 and A/C auto amp connector M63 terminal 17.


4 (W) – 17 (W) :Continuity should exist

4. Check continuity between BCM connector M48 terminal 4 and ground

4 (W) – Ground :Continuity should not exist

OK or NG

OK >> GO TO 3.
NG >> Repair or replace harness between BCM and A/C auto amp.



3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M48 terminal 4 and ground.


4 (W) – Ground

:Approx. 5

OK or NG

OK >> Replace rear window defogger switch. Refer to [ATC-71, "Removal and Installation"](#)

NG >> Replace BCM.



Rear Window Defogger Switch Circuit Check / Without Auto A/C

EIS004OV

1. CHECK REAR WINDOW DEFOGGER SWITCH OPERATION

With CONSULT-II

Check ("REAR DEF SW", "IGN ON SW") in DATA MONITOR mode with CONSULT-II. Refer to [GW-37](#).

When engine is running


ENGINE STATUS :RUN

When rear defogger switch is turned to ON

REAR DEF SW :ON

When ignition switch is turned to ON

IGN ON SW :ON



Without CONSULT-II


1. Turn ignition switch ON.
2. Check voltage between BCM connector ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	4 (W)	Ground	Rear window defogger switch is pressed.	0
			Rear window defogger switch is OFF.	5

OK or NG

OK >> Rear window defogger switch check is OK.

NG >> GO TO 2.



2. CHECK REAR WINDOW DEFOGGER SWITCH CIRCUIT HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and heater control panel connector.
3. Check continuity between BCM connector M48 terminal 4 and heater control panel connector M58 terminal 9.

4 (W) – 9 (W) :Continuity should exist


4. Check continuity between BCM connector M48 terminal 4 and ground

4 (W) – Ground :Continuity should not exist

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness between BCM and heater control panel.



3. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M48 terminal 4 and ground.

4 (W) – Ground :Approx. 5

OK or NG

OK >> Replace heater control panel. Refer to [MTC-46, "Removal and Installation"](#).

NG >> Replace BCM.



Rear Window Defogger Power Supply Circuit Check

EIS004KM

1. CHECK FUSE

Check if any of the following fuses for IPDM E/R are blown.


COMPONENT PARTS	TERMINAL NO. (SIGNAL)	AMPERE	FUSE NO.
IPDM E/R	3 (BAT power supply)	15A	#45
		15A	#46

NOTE:Refer to [GW-16, "Component Parts and Harness Connector Location"](#) .**OK or NG**

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse, refer to [GW-16, "Component Parts and Harness Connector Location"](#) .**2. CHECK REAR WINDOW DEFOGGER RELAY**

Check rear window defogger relay in "ACTIVE TEST" mode with CONSULT-II. Refer to

Do you hear of the operation sound of rear window defogger relay.**OK or NG**

OK >> GO TO 3.

NG >> Replace IPDM E/R.


3. CHECK REAR WINDOW DEFOGGER RELAY OUTPUT SIGNAL

1. Turn rear window defogger switch ON.
2. Check voltage between IPDM E/R connector E11 terminal 8 and ground.

8 (R) – Ground**: Battery voltage****OK or NG**

OK >> Rear window defogger power supply circuit check is OK.

NG >> Check connector for damage and loose connection.



REAR WINDOW DEFOGGER

[HATCHBACK]

Rear Window Defogger Circuit Check

EIS004KN


1. CHECK REAR WINDOW DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear window defogger connector.
3. Turn ignition switch ON.
4. Check voltage between rear window defogger connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
B50	1 (B)	Ground	Rear window defogger switch ON.	Battery voltage
			Rear window defogger switch OFF.	0

OK or NG

OK >> GO TO 2.
NG >> GO TO 3.



2. CHECK REAR WINDOW DEFOGGER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rear window defogger connector B201 terminal 2 and ground.


2(B) – Ground **:Continuity should exist**

OK or NG

OK >> Check filament, Refer to [GW-48, "Filament Check"](#)

- If filament is OK.
Check the condition of the harness and the connector.
- If filament is NG.
Repair filament.

NG >> Repair or replace harness between rear window defogger and ground.



3. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R connector E11 terminal 8 and rear window defogger connector B50 terminal 1.


8 (R) – 1 (B) **:Continuity should exist.**

4. Check continuity between IPDM E/R connector E11 terminal 8 and ground.

8 (R) – Ground **:Continuity should not exist.**

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.



Door Mirror Defogger Power Supply Circuit Check

EIS004KO

1. CHECK FUSE

Check if any of the following fuse for Fuse block (J/B) are blown.

COMPONENT PARTS	AMPERE	FUSE NO.
Fuse block (J/B)	10A	#13

NOTE:Refer to [GW-16, "Component Parts and Harness Connector Location"](#) .**OK or NG**

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse, refer to [GW-16, "Component Parts and Harness Connector Location"](#) .**2. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT 1**


1. Turn ignition switch ON.
2. Check voltage between door mirror connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D3 (driver side)	6 (LG)	Ground	Rear window defogger switch ON	Battery voltage
D33 (passenger side)	6 (OR)		Rear window defogger switch OFF	0

OK or NG

OK >> GO TO 3.

NG >> Check harness between IPDM E/R and door mirror.


**3. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect door mirror connector.
3. Check continuity between door mirror connector D3 (driver side), D33 (passenger side) terminal 5 and ground.

5 (B) – Ground**:Continuity should exist.****OK or NG**

OK >> INSPECTION END.

NG >> Repair or replace harness.



Driver Side Door Mirror Defogger Circuit Check

EIS004KP


1. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between door mirror (driver side) connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D3	6 (LG)	Ground	Rear window defogger switch ON	Battery voltage
			Rear window defogger switch OFF.	0

OK or NG


OK >> GO TO 2.
NG >> Repair or replace harness between fuse block (J/B) and door mirror (driver side).

**2. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect door mirror (driver side) connector.
3. Check continuity between door mirror (driver side) connector D3 terminal 5 and ground.

5 (B) – Ground : Continuity should exist.OK or NG


OK >> GO TO 3
NG >> Repair or replace harness between door mirror (driver side) and ground.

**3. CHECK DOOR MIRROR DEFOGGER**

Check continuity between each door mirror connector D3 (driver side) terminal 5 and 6.

5 – 6 : Continuity should exist.OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Replace door mirror (driver side).



REAR WINDOW DEFOGGER

[HATCHBACK]

Passenger Side Door Mirror Defogger Circuit Check

EIS004KQ


1. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between door mirror (passenger side) connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D33	6 (OR)	Ground	Rear window defogger switch ON	Battery voltage
			Rear window defogger switch OFF	0

OK or NG

OK >> GO TO 2.
NG >> Repair or replace harness between fuse block (J/B) and door mirror (passenger side).




2. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Check continuity between door mirror (passenger side) connector D33 terminal 5 and ground.

5 (B) – Ground : Continuity should exist.

OK or NG

OK >> GO TO 3
NG >> Repair or replace harness between door mirror (passenger side) and ground.




3. CHECK DOOR MIRROR DEFOGGER

Check continuity between each door mirror connector D33 (passenger side) terminal 5 and 6.

5 – 6 : Continuity should exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Replace door mirror (passenger side).




REAR WINDOW DEFOGGER

[HATCHBACK]


Filament Check

EIS004KR


1. When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.



2. Attach probe circuit tester (in Volt range) to middle portion of each filament.



3. If a filament is burned out, circuit tester registers 0 or battery voltage.
4. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



Filament Repair


REPAIR EQUIPMENT

EIS004KS



- Conductive silver composition (Dupont No. 4817 or equivalent)
- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

REPAIRING PROCEDURE

- Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
- Apply a small amount of conductive silver composition to tip of drawing pen.
Shake silver composition container before use.
- Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
- After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.
Do not touch repaired area while test is being conducted.



- Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet.
If a heat gun is not available, let the repaired area dry for 24 hours.




POWER WINDOW SYSTEM

PFP:25401

Component Parts and Harness Connector Location

EIS004PM



MIIB0726E

System Description

EIS004PN

Power is supplied at all time

- from 40A fusible link (letter J, located in the fuse and fusible link box)
- to BCM terminal 74 and 79.

With ignition switch in ON or START position,

Power is supplied

- through 10A fuse [No.4, located in the fuse block (J/B)]
- to BCM terminal 24.
- through BCM terminal 78
- to power window main switch terminal 5 (conventional type)
- to power window main switch terminal 15 (auto operation type)
- to front power window switch (passenger side) terminal 1.

Ground supplied

- to BCM terminal 2 and 70
- through body grounds M19 and M20.

FRONT DRIVER SIDE DOOR

Ground is supplied

- to power window main switch terminal 7
- through body grounds M19 and 20.

Window Up (Conventional Type)

When the driver side switch in the power window main switch is pressed in the up position,

Power is supplied

- through power window main switch terminal 2 (LHD), 6 (RHD)
- to front power window motor (driver side) terminal 2.

Ground is supplied

- to front power window motor (driver side) terminal 1
- through power window main switch terminal 3 (LHD), 4 (RHD).

Then, the motor raises the window until the switch is released.

Window Down (Conventional Type)

When the driver side switch in the power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 3 (LHD), 4 (RHD)
- to front power window motor (driver side) terminal 1.

Ground is supplied

- to front power window motor (driver side) terminal 2
- through power window main switch terminal 2 (LHD), 6 (RHD).

Then, the motor lowers the window until the switch is released.

Window Up (Auto Operation Type)

When the driver side switch in the power window main switch is pressed in the up position,

Power is supplied

- through power window main switch terminal 8 (LHD), 16 (RHD)
- to front power window motor (driver side) terminal 2.

Ground is supplied

- to front power window motor (driver side) terminal 1
- through power window main switch terminal 11 (LHD), 12 (RHD).

Then, the motor raises the window until the switch is released.

Window Down (Auto Operation Type)

When the driver side switch in the power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 11 (LHD), 12 (RHD)
- to front power window motor (driver side) terminal 1.

Ground is supplied

- to front power window motor (driver side) terminal 2
- through power window main switch terminal 8 (LHD), 16 (RHD).

Then, the motor lowers the window until the switch is released.

FRONT PASSENGER SIDE DOOR

Ground is supplied

- to power window main switch terminal 7
- through body grounds M19 and M20.

Power Window Main Switch Operation (Conventional Type)**WINDOW UP**

When the passenger side switch in power window main switch is pressed in the up position

Power is supplied

A

B

C

D

E

F

G

H

GW

J

K

L

M

- through power window main switch terminal 6 (LHD), 2 (RHD)
- through front power window switch (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- to front power window motor (passenger side) terminal 2.

Ground is supplied

- to front power window motor (passenger side) terminal 1
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4 (LHD), 3 (RHD)

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the passenger side switch in power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 4 (LHD), 3 (RHD)
- through front power window switch (passenger side) terminal 3
- through front power window switch (passenger side) terminal 4
- to front power window motor (passenger side) terminal 1.

Ground is supplied

- to front power window motor (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6 (LHD), 2(RHD).

Then, the motor lowers the window until the switch is released.

Power Window Main Switch Operation (Auto Operation Type)

WINDOW UP

When the passenger side switch in power window main switch is pressed in the up position

Power is supplied

- through power window main switch terminal 16 (LHD), 8 (RHD)
- through front power window switch (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- to front power window motor (passenger side) terminal 2.

Ground is supplied

- to front power window motor (passenger side) terminal 1
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 12 (LHD), 11 (RHD)

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the passenger side switch in power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 12 (LHD), 11 (RHD)
- through front power window switch (passenger side) terminal 3
- through front power window switch (passenger side) terminal 4
- to front power window motor (passenger side) terminal 1.

Ground is supplied

- to front power window motor (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 16 (LHD), 8 (RHD).

Then, the motor lowers the window until the switch is released.

Front Power Window Switch (Passenger Side) Operation (Conventional Type)**WINDOW UP**

When the front door window switch (passenger side) is pressed in the up position

Power is supplied

- through front power window switch (passenger side) terminal 5
- to front power window motor (passenger side) terminal 2.

Ground is supplied

- to front power window motor (passenger side) terminal 1
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4 (LHD), 3 (RHD).

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the front door window switch (passenger side) is pressed in the down position

Power is supplied

- through front power window switch (passenger side) terminal 4
- to front power window motor (passenger side) terminal 1.

Ground is supplied

- to front power window motor (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6 (LHD), 2 (RHD).

Then, the motor lowers the window until the switch is released.

Front Power Window Switch (Passenger Side) Operation (Auto Operation Type)**WINDOW UP**

When the front door window switch (passenger side) is pressed in the up position

Power is supplied

- through front power window switch (passenger side) terminal 5
- to front power window motor (passenger side) terminal 2.

Ground is supplied

- to front power window motor (passenger side) terminal 1
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 12 (LHD), 11 (RHD).

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the front door window switch (passenger side) is pressed in the down position

Power is supplied

- through front power window switch (passenger side) terminal 4
- to front power window motor (passenger side) terminal 1.

Ground is supplied

- to front power window motor (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 16 (LHD), 8 (RHD).

Then, the motor lowers the window until the switch is released.

AUTO OPERATION

The power window AUTO feature enables the driver to open or close the window without holding the window switch in the down or up position.

When place the foreign body while operating, operation is stopped.

A

B

C

D

E

F

G

H

GW

J

K

L

M







POWER WINDOW SYSTEM

[HATCHBACK]

Wiring Diagram – WINDOW – / Conventional Type

EIS004PP


GW-WINDOW-01



REFER TO THE FOLLOWING.

(M1) - SUPER MULTIPLE JUNCTION (SMJ)

(M16) - FUSE BLOCK - JUNCTION BOX (J/B)




MIWA0656E

POWER WINDOW SYSTEM

[HATCHBACK]

GW-WINDOW-02



1 2 D5 GY , D35 GY

1 7 3 4 5 2 D37 W

1 2 3 4 5 6 7 8 9 10 11 12 D42 W

MIWA0657E


POWER WINDOW SYSTEM

[HATCHBACK]

Wiring Diagram – WINDOW – / Auto Operation Type

EIS00DFP

GW-WINDOW-03



(L) : LHD MODELS

(R) : RHD MODELS

*1 11 : (L)

12 : (R)

*2 8 : (L)


16 : (R)

*3 12 : (L)

11 : (R)

*4 16 : (L)


8 : (R)



REFER TO THE FOLLOWING.

(M1) - SUPER MULTIPLE JUNCTION (SMJ)

(M16) - FUSE BLOCK - JUNCTION BOX (J/B)




MIWA0585E

POWER WINDOW SYSTEM

[HATCHBACK]

GW-WINDOW-04



1 2 D5 GY , D35 GY

1 7 3 4 5 2 D37 W

1 2 3 4 5 6 7 8 9 10 11 12 D42 W

MIWA0586E

POWER WINDOW SYSTEM

[HATCHBACK]

Terminal and Reference Value for BCM

EIS004PS

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
2	B	Ground	—	0
24	OR	Ignition switch (ON or START)	Ignition switch (ON or START position)	Battery voltage
70	B	Ground (power)	—	0
74	Y	Battery power supply (BCM)	—	Battery voltage
78	R	Power window power supply	Ignition switch (ON or START position)	Battery voltage
			Other than above	0
79	Y	Battery power supply (power window)	—	Battery voltage

Work Flow

EIS004PT

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [GW-50, "System Description"](#)
3. According to the trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [GW-58, "Trouble Diagnosis Symptom Chart / Conventional Type"](#)
4. Does power window system operate normally? Yes, GO TO 5, If No, GO TO 3.
5. INSPECTION END

Trouble Diagnosis Symptom Chart / Conventional Type

EIS004PV

Symptom	Repair order	Refer to page
None of the power windows can be operated using any switch.	1. BCM power supply and ground circuit check	GW-59
	2. Power window switch power supply and ground circuit check	GW-60
	3. Power window main switch check	GW-63
Driver side power window alone does not operate.	1. Power window motor (driver side) check (LHD models)	GW-64
	1. Power window motor (driver side) check (RHD models)	GW-66
	2. Replace power window main switch	EI-20
Passenger side power window alone does not operate.	1. Front power window motor (passenger side) check	GW-67
	2. Front power window switch (passenger side) check	GW-68
	3. Front power window switch (passenger side) circuit check (LHD models)	GW-69
	3. Front power window switch (passenger side) circuit check (RHD models)	GW-71
	4. Replace power window main switch	EI-20
Passenger side power window does not operate using front power window switch (passenger side), but power window main switch can be operate.	1. Front power window switch (passenger side) power supply check	GW-73
	2. Front power window switch (passenger side) check	GW-68

Trouble Diagnosis Symptom Chart / Auto Operation Type

EIS00DFQ

Symptom	Repair order	Refer to page
None of the power windows can be operated using any switch.	1. BCM power supply and ground circuit check	GW-59
	2. Power window switch power supply and ground circuit check	GW-62
	3. Power window main switch check	GW-64
Driver side power window alone does not operate.	1. Power window motor (driver side) check (LHD models)	GW-65
	1. Power window motor (driver side) check (RHD models)	GW-66
	2. Replace power window main switch	EI-20
Passenger side power window alone does not operate.	1. Front power window motor (passenger side) check	GW-67
	2. Front power window switch (passenger side) check	GW-68
	3. Front power window switch (passenger side) circuit check (LHD models)	GW-70
	3. Front power window switch (passenger side) circuit check (RHD models)	GW-72
	4. Replace power window main switch	EI-20
Passenger side power window does not operate using front power window switch (passenger side), but power window main switch can be operate.	1. Front power window switch (passenger side) power supply check	GW-73
	2. Front power window switch (passenger side) check	GW-68
Auto operation does not operate	1. Replace power window main switch	EI-20

BCM Power Supply and Ground Circuit Check

EIS004QL

First perform the “SELF-DIAG RESULTS” in “BCM” with CONSULT-II, then perform the each trouble diagnosis of malfunction system indicated “SELF-DIAG RESULTS” of “BCM”, Refer to [BCS-21. "CONSULT-II Function \(BCM\)"](#).

1. FUSE INSPECTION

- Check 10A fuse [No.4, located in fuse block (J/B)]
- Check 40A fusible link (letter J located in the fuse and fusible link box).

NOTE:

Refer to [GW-50, "Component Parts and Harness Connector Location"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown out, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-5, "POWER SUPPLY ROUTING"](#) .

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM connector M48, M50 terminal 24, 74, 79 and ground.

24 (OR) – Ground :Battery voltage.


74 (W) – Ground :Battery voltage.

79 (Y) – Ground :Battery voltage.

OK or NG

OK >> GO TO 3.

NG >> Check BCM power supply circuit for open or short.



3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM connector M48, M50 terminal 2, 70 and ground.


2 (B) – Ground :Continuity should exist.

70 (B) – Ground :Continuity should exist.

OK or NG

OK >> Power supply and ground circuit is OK.

NG >> Check BCM ground circuit for open or short.



Power Window Switch Power Supply and Ground Circuit Check / Conventional Type

EIS004PX

1. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch ON.
2. Check voltage between BCM connector M50 terminals 78 and ground.

78 (R) – Ground :Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Replace BCM.



2. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM, power window main switch and front power window switch (passenger side) connector.
3. Check continuity between BCM connector M50 terminal 78 and power window main switch connector D7 terminal 5, and ground.

78 (R) – 5 (R)

: Continuity should exist.

78 (R) – Ground

: Continuity should not exist.



4. Check continuity between BCM connector M50 terminal 78 and front power window switch (passenger side) connector D37 terminal 1.


78 (R) – 1 (R)

: Continuity should exist.

OK or NG

OK >> GO TO 3

NG >> Repair or replace harness.



3. CHECK GROUND CIRCUIT

Check continuity between power window main switch connector D7 terminal 7 and ground.


7 (B) – Ground

: Continuity should exist.

OK or NG

OK >> Power window switch power supply and ground circuit is OK.

NG >> Repair or replace harness.



Power Window Switch Power Supply and Ground Circuit Check / Auto Operation Type

EIS00DFR

1. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch ON.
2. Check voltage between BCM connector M50 terminals 78 and ground.

78 (R) – Ground

: Battery voltage

OK or NG

OK >> GO TO 2.
NG >> Replace BCM.



2. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM, power window main switch and front power window switch (passenger side) connector.
3. Check continuity between BCM connector M50 terminal 78 and power window main switch connector D7 terminal 10, and ground.

78 (R) – 10 (R)

: Continuity should exist.

78 (R) – Ground

: Continuity should not exist.




4. Check continuity between BCM connector M50 terminal 78 and front power window switch (passenger side) connector D37 terminal 1.

78 (R) – 1 (R)

: Continuity should exist.

OK or NG

OK >> GO TO 3
NG >> Repair or replace harness.



3. CHECK GROUND CIRCUIT


Check continuity between power window main switch connector D7 terminal 15 and ground.

15 (B) – Ground : Continuity should exist.

OK or NG

OK >> Power window switch power supply and ground circuit is OK.

NG >> Repair or replace harness.




Power Window Main Switch Check / Conventional Type

EIS004QM

1. CHECK POWER WINDOW MAIN SWITCH

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch 2, 3, 4, 6 and 7.

2 – 7 : Continuity should exist.
3 – 7 : Continuity should exist.
4 – 7 : Continuity should exist.
6 – 7 : Continuity should exist.



4. Power window main switch operate, check continuity between power window main switch 2, 3, 4, 6 and 5.


Terminals	Condition	Continuity
2, (6)	5	Yes
3, (4)		
4, (3)		
6, (2)		

() : RHD models

OK or NG

OK >> Power window main switch is OK. Check the condition of the harness and the connector.

NG >> Replace power window main switch.




Power Window Main Switch Check / Auto Operation Type

EIS000FS

1. CHECK POWER WINDOW MAIN SWITCH

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch 8, 11, 12, 16 and 15.


8 – 15	: Continuity should exist.
11 – 15	: Continuity should exist.
12 – 15	: Continuity should exist.
16 – 15	: Continuity should exist.



4. Power window main switch operate, check continuity between power window main switch 8, 11, 12, 16 and 15.

Terminals		Condition	Continuity
8, (16)	10	Driver side UP	Yes
11, (12)		Driver side DOWN	
12, (11)		Passenger side DOWN	
16, (8)		Passenger side UP	

(): RHD models



OK or NG

OK >> Power window main switch is OK. Check the condition of the harness and the connector.

NG >> Replace power window main switch.

Front Power Window Motor (Driver Side) Check (LHD models) / Conventional Type

EIS004QN

1. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL


1. Turn ignition switch ON.
2. Check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	2 (Y)	Ground	Driver side UP	Battery voltage
	3 (L)		Driver side DOWN	

OK or NG

OK >> GO TO 2.

NG >> Replace power window main switch.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window motor (driver side) connector.
3. Check continuity between power window main switch connector D7 terminal 2, 3 and front power window motor (driver side) connector D5 terminal 1, 2.


2 (Y) – 2 (Y) : Continuity should exist.
3 (L) – 1 (L) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 2, 3 and ground.

2 (Y) – Ground : Continuity should not exist.
3 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.



Front Power Window Motor (Driver Side) Check (LHD models) / Auto Operation Type

EIS000DFT


1. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	8 (Y)	Ground	Driver side UP	Battery voltage
	11 (L)		Driver side DOWN	

OK or NG

OK >> GO TO 2.
 NG >> Replace power window main switch.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window motor (driver side) connector.
3. Check continuity between power window main switch connector D7 terminal 8, 11 and front power window motor (driver side) connector D5 terminal 1, 2.


8 (Y) – 2 (Y) : Continuity should exist.
11 (L) – 1 (L) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 8, 11 and ground.

8 (Y) – Ground : Continuity should not exist.
11 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.



POWER WINDOW SYSTEM

[HATCHBACK]

Front Power Window Motor (Driver Side) Check (RHD models) / Conventional Type

EIS004QO


1. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	4 (L)	Ground	Driver side DOWN	Battery voltage
	6 (Y)		Driver side UP	

OK or NG

OK >> GO TO 2.
NG >> Replace power window main switch.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window motor (driver side) connector.
3. Check continuity between power window main switch connector D7 terminal 4, 6 and front power window motor (driver side) connector D5 terminal 1, 2.


4 (L) – 1 (L) : Continuity should exist.
6 (Y) – 2 (Y) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 4, 6 and ground.

4 (L) – Ground : Continuity should not exist.
6 (Y) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.



Front Power Window Motor (Driver Side) Check (RHD models) / Auto Operation Type

EIS00DFU


1. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	12 (L)	Ground	Driver side DOWN	Battery voltage
	16 (Y)		Driver side UP	

OK or NG

OK >> GO TO 2.
NG >> Replace power window main switch.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window motor (driver side) connector.
3. Check continuity between power window main switch connector D7 terminal 12, 16 and front power window motor (driver side) connector D5 terminal 1, 2.


12 (L) – 1 (L) : Continuity should exist.
16 (Y) – 2 (Y) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 12, 16 and ground.

12 (L) – Ground : Continuity should not exist.
16 (Y) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.



Front Power Window Motor (Passenger Side) Check

EIS004QP


1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Power window main switch operate, check voltage between front power window switch (passenger side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D37	4 (L)	Ground	Passenger side DOWN	Battery voltage
	5 (Y)		Passenger side UP	

OK or NG

OK >> GO TO 2.
 NG >> Further inspection is necessary. Refer to symptom chart.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) and front power window motor (passenger side) connector.
3. Check continuity between front power window switch (passenger side) connector D37 terminal 4, 5 and front power window motor (passenger side) connector D35 terminal 1, 2.


4 (L) – 1 (L) : Continuity should exist.
5 (Y) – 2 (Y) : Continuity should exist.

4. Check continuity between front power window switch (passenger side) connector D37 terminal 4, 5 and ground.

4 (L) – Ground : Continuity should not exist.
5 (Y) – Ground : Continuity should not exist.

OK or NG

OK >> Replace front power window motor (passenger side).
 NG >> Repair or replace harness.



Front Power Window Switch (Passenger Side) Check

EIS004QQ

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)


1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector, check continuity between front power window switch (passenger side) terminals.

Terminals		Condition	Continuity
1	5	UP	Yes
1	4	DOWN	
2	5	No operation	
3	4	No operation	

OK or NG

OK >> GO TO 2.

NG >> Replace front power window switch (passenger side).


**2. CHECK POWER SUPPLY**

1. Turn ignition switch ON.
2. Check voltage between front power window switch (passenger side) connector D37 terminal 1 and ground.

1 (R) – Ground**: Battery voltage**OK or NG

OK >> Further inspection is necessary. Refer to symptom chart.

NG >> GO TO 3.

**3. CHECK HARNESS CONTINUITY**

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 78 and front power window switch (passenger side) connector D37 terminal 1.


78 (R) – 1 (R)**: Continuity should exist.**

3. Check continuity between BCM connector M50 terminal 78 and ground.

78 (R) – Ground**: Continuity should not exist.**OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Repair or replace harness.



Front Power Window Switch (Passenger Side) Circuit Check (LHD models) / Conventional Type

EIS004QR

1. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window switch (passenger side) connector.
3. Check continuity between power window main switch connector D7 terminal 4, 6 and front power window switch (passenger side) connector D37 terminal 2, 3.


4 (G) – 3 (G)	: Continuity should exist.
6 (PU) – 2 (PU)	: Continuity should exist.
4. Check continuity between power window main switch connector D7 terminal 4, 6 and ground.

4 (G) – Ground	: Continuity should not exist.
6 (PU) – Ground	: Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness.



2. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL


1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Power window main switch operate, check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	4 (G)	Ground	Passenger side DOWN	Battery voltage
	6 (PU)		Passenger side UP	

OK or NG

OK >> GO TO 3.

NG >> Replace power window main switch.



3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between power window main switch connector D7 terminal 4, 6 and ground.

4 (G) – Ground	: Continuity should exist.
6 (PU) – Ground	: Continuity should exist.

OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Replace power window main switch.



Front Power Window Switch (Passenger Side) Circuit Check (LHD models) / Auto Operation Type

EIS00DFV

1. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window switch (passenger side) connector.
3. Check continuity between power window main switch connector D7 terminal 12, 16 and front power window switch (passenger side) connector D37 terminal 2, 3.

12 (G) – 3 (G) : Continuity should exist.
16 (PU) – 2 (PU) : Continuity should exist.


4. Check continuity between power window main switch connector D7 terminal 12, 16 and ground.

12 (G) – Ground : Continuity should not exist.
16 (PU) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness.



2. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL


1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Power window main switch operate, check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	12 (G)	Ground	Passenger side DOWN	Battery voltage
	16 (PU)		Passenger side UP	

OK or NG

OK >> GO TO 3.

NG >> Replace power window main switch.




3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between power window main switch connector D7 terminal 12, 16 and ground.

12 (G) – Ground : Continuity should exist.
16 (PU) – Ground : Continuity should exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Replace power window main switch.



Front Power Window Switch (Passenger Side) Circuit Check (RHD models) / Conventional Type

EIS00DFW

1. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window switch (passenger side) connector.
3. Check continuity between power window main switch connector D7 terminal 2, 3 and front power window switch (passenger side) connector D37 terminal 2, 3.

2 (PU) – 2 (PU) : Continuity should exist.
3 (G) – 3 (G) : Continuity should exist.


4. Check continuity between power window main switch connector D7 terminal 2, 3 and ground.

2 (PU) – Ground : Continuity should not exist.
3 (G) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness.



2. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL


1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Power window main switch operate, check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	2 (PU)	Ground	Passenger side UP	Battery voltage
	3 (G)		Passenger side DOWN	

OK or NG

OK >> GO TO 3.

NG >> Replace power window main switch.



3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between power window main switch connector D7 terminal 2, 3 and ground.

2 (PU) – Ground : Continuity should exist.
3 (G) – Ground : Continuity should exist.

OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Replace power window main switch.



Front Power Window Switch (Passenger Side) Circuit Check (RHD models) / Auto Operation Type

EIS004QS

1. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window switch (passenger side) connector.
3. Check continuity between power window main switch connector D7 terminal 8, 11 and front power window switch (passenger side) connector D37 terminal 2, 3.

8 (PU) – 2 (PU) : Continuity should exist.
11 (G) – 3 (G) : Continuity should exist.


4. Check continuity between power window main switch connector D7 terminal 8, 11 and ground.

8 (PU) – Ground : Continuity should not exist.
11 (G) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness.



2. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL


1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Power window main switch operate, check voltage between power window main switch connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	8 (PU)	Ground	Passenger side UP	Battery voltage
	11 (G)		Passenger side DOWN	

OK or NG

OK >> GO TO 3.

NG >> Replace power window main switch.



3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between power window main switch connector D7 terminal 8, 11 and ground.

8 (PU) – Ground : Continuity should exist.
11 (G) – Ground : Continuity should exist.

OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Replace power window main switch.



Front Power Window Switch (Passenger Side) Power Supply Check

EIS004QT

1. CHECK POWER SUPPLY


1. Turn ignition switch ON.
2. Check voltage between front power window switch (passenger side) connector D37 terminal 1 and ground.

1 (R) – Ground

: Battery voltage

OK or NG

OK >> Front power window switch (passenger side) power supply is OK.
 NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and front power window switch connector.
3. Check continuity between BCM connector M50 terminal 78 and front power window switch (passenger side) connector D37 terminal 1.

78 (R) – 1 (R)

: Continuity should exist.


4. Check continuity between BCM connector M50 terminal 78 and ground.

78 (R) – Ground

: Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.




FRONT DOOR GLASS AND REGULATOR

PFP:80300

Removal and Installation

EIS004L8



- 1. Door panel
- 2. Lower sash (front)
- 3. Lower sash (rear)
- 4. Door glass run
- 5. Door glass
- 6. Regulator
- 7. Power window motor


REMOVAL

1. Remove front door finisher. Refer to [EI-20, "DOOR FINISHER"](#) .
2. Fully close door glass.
3. Disconnect front speaker harness connector, and then remove sealing screen.

NOTE:

If sealing screen is reused, cut butyl tape in a way that leaves it on sealing screen.


4. Remove front door inner frame. (5-door vehicles only)
5. Remove buzzer. (Vehicle with intelligent key system only)



FRONT DOOR GLASS AND REGULATOR


[HATCHBACK]

6. Remove lower sash (rear) bolts, move bottom toward front of door panel, pull out top inserted part from door panel, and remove lower sash (rear).




7. While supporting door glass, operate power window switch to raise/lower door glass until glass bolts can be seen.


8. Remove door glass bolts.



9. While holding door glass, raise glass up from rear edge while pulling glass out of sash toward the inside of the door.



10. Remove the power window motor harness connector and bolts, and remove regulator assembly from door panel.



11. Remove lower sash (front) bolts, move bottom toward back of door panel, pull out top insertion part from door panel, and remove lower sash (front).
12. Remove corner cover. Refer to [GW-82, "Removal and Installation"](#).
13. Pull out and remove door glass run from door panel.

INSTALLATION


Install in the reverse order of removal.

INSPECTION AFTER REMOVAL

Check the regulator assembly for the following. If a failure is detected, replace or grease it.

- Wire wear
- Regulator assembly deformation
- Grease condition on each sliding part

Apply grease (Nissan MP Special Grease No. 2) to the areas indicated by the arrows in the figure.

**SETTING AFTER INSTALLATION (DRIVER'S SIDE ONLY)****Setting Limit Switch**

After performing the following work, reset the limit switch (with motor).

- Removal and Installation of regulator assembly
- Removal and Installation of motor from regulator assembly
- Operation of regulator assembly as an independent unit
- Removal and Installation of glass
- Removal and Installation of door glass run


Reset Operation

After installing each component, follow the steps below:

1. Raise glass to the bottom position.
2. Press and hold the reset switch to lower the window to the bottom dead end.
3. Release the reset switch, check the reset switch returns to the original position, and then raise the window to the top dead end.

CAUTION:

Do not raise the window automatically to the top dead end.

**FITTING INSPECTION**

- Make sure glass is securely fit into door glass run groove.
- Lower glass slightly (approximately 10 to 20 mm), and confirm clearance to the sash is parallel. If clearance between glass and sash is not parallel, loosen bolts for regulator assembly, glass, and carrier plate, and then correct glass position.

REAR DOOR GLASS AND REGULATOR

[HATCHBACK]


REAR DOOR GLASS AND REGULATOR

PFP:82300

Removal and Installation

EIS004L9

SEC. 823



: N·m (kg·m, in-lb)

MIB0197E

1. Door panel	2. Partition sash	3. Door glass run
4. Partition weather strip	5. Door glass	6. Partition glass
7. Regulator		

GW

REMOVAL

1. Remove rear door finisher. Refer to [EI-20, "DOOR FINISHER"](#) .
2. Remove rear speaker harness connector.
3. Remove sealing screen.

NOTE:

If sealing screen is reused, cut butyl tape in a way that leaves it on sealing screen.


4. After removing partition sash bolts screws, pull partition sash straight down, tilt the top forward, and pull up.

J

K

L

M




MIB0198E


REAR DOOR GLASS AND REGULATOR

[HATCHBACK]


5. Pull out partition glass in the direction shown by the arrows in the figure.



6. While supporting door glass, operate power window switch to raise/lower door glass until glass bolts can be seen.
7. Remove door glass bolts.
8. Pull door glass up to remove it.




9. Remove regulator assembly bolts to remove assembly out of door panel.



10. Pull out and remove door glass run from door panel.

INSPECTION AFTER REMOVAL

- Check the regulator assembly for the following. If a failure is detected, replace or grease it.
 - Gear wear
 - Regulator assembly deformation
 - Grease condition on each sliding part
- Apply grease (Nissan MP Special Grease No. 2) to the areas indicated by the arrows in the figure.



INSTALLATION

Install in the reverse order of removal.

FITTING INSPECTION

- Make sure the window is seated in the groove of the glass run.
- Lower glass slightly (approximately 10 to 20 mm), and confirm clearance to the sash is parallel. If clearance between glass and sash is not parallel, loosen bolts for regulator assembly, glass, and main channel, and then correct glass position.

A

B

C

D

E

F

G

H

GW

J

K

L

M

DOOR MIRROR






[HATCHBACK]

DOOR MIRROR

PFP:96301

Wiring Diagram — MIRROR — LHD Models

EIS004LB



REFER TO THE FOLLOWING.

M16 - FUSE BLOCK -
JUNCTION BOX (J/B)






MIWA0587E

DOOR MIRROR

[HATCHBACK]

Wiring Diagram — MIRROR — RHD Models

EIS00C4A




REFERR TO THE FOLLOWING

**M16 - FUSE BLOCK -
JUNCTION BOX (J/B)**

Removal and Installation

E1S004LC



1. Door mirror

2. Corner cover

MIIB0203E

REMOVAL

CAUTION:

Be careful not to damage mirror body.

1. Remove front door finisher. Refer to [EI-20, "DOOR FINISHER"](#) .
2. Remove corner cover.
3. Disconnect door mirror harness connector. (Electric door mirrors only)
4. Remove door mirror nuts and door mirror assembly.



INSTALLATION

Install in the reverse order of removal.

Disassembly and Assembly

E1S004LD

SEC. 963



MIIB0204E


1. Mirror body (integrated with holder) 2. Power unit
 4. Connector (electric) 5. Housing 3. Electric unit
 6. Base

DISASSEMBLY

1. Remove all terminals from the harness connector.

CAUTION:**Before pulling out terminal, note connector terminal layout.**

2. Turn mirror glass surface upward.
3. Apply protective tape to the housing.
4. As shown in the figure, insert a thin, screwdriver in the concave gap between mirror glass (mirror holder) and power unit to push up tabs (2 locations) on mirror holder to disengage lower part of mirror holder, and remove mirror body.

CAUTION:**When pushing up the tabs, do not forcibly push up only 1 concave but try to push up using 2 concave positions.**

5. Remove base.
6. Remove electric unit.
7. Remove power unit, and disconnect connector.
8. Separate the power unit from the Electric retracting unit.

ASSEMBLY

1. Install power unit to the electric unit.
2. Connect connector to power unit.
3. Install electric unit and base to the housing.
4. Place power unit and mirror body in a horizontal position.

A
B
C
D
E
F
G
H

GW

J

K

L

M


DOOR MIRROR

[HATCHBACK]

- Engage upper tabs of mirror glass (mirror holder) with power unit. Then, press lower part of mirror glass down until lower part snaps into place and engages lower tabs.

CAUTION:

After finishing work, visually confirm that lower tabs (2) at the bottom of mirror face are securely engaged.



- Insert harness terminal into connector.

CAUTION:

Make sure to insert harness terminal into the correct connector. Do not confuse the locations.

INSIDE MIRROR


PFP:96321

Removal and Installation

EIS004LE

REMOVAL

Pull the inside mirror upward to remove it.

**INSTALLATION**


Install in the reverse order of removal.

Removal and Installation (With Rain Sensor)

EIS00DH4

REMOVAL

Slide the inside mirror downward to remove.

**INSTALLATION**

Install in the reverse order of removal.

APPLICATION NOTICE

[C+C]

APPLICATION NOTICE

PFP:00000

How to Check Vehicle Type

EIS00E4J

Confirm K9K engine type with Model written on identification plate (refer to [GI-44, "IDENTIFICATION INFORMATION"](#)), then refer to service information in GW section.

Vehicle type	Engine type
xTKxxxxK12Vxx	Euro3 48kW
xTKxxxxK12Yxx	Euro3 60kW
xTKxxxxK12Txx	Euro4 50kW
xTKxxxxK12Uxx	Euro4 63kW

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EIS00E4G

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Procedures without Cowl Top Cover

EIS00E4H

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.

**Precautions**

EIS00E4I

- When removing or disassembling any part, be careful not to damage or deform it. Protect parts, which may get in the way with cloth.
- When removing parts with a screwdriver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If a clip is deformed or damaged, replace it.
- If an unreusable part is removed, replace it with a new one.
- Tighten bolts and nuts firmly to the specified torque.
- After re-assembly has been completed, make sure each part functions correctly.
- Remove stains in the following way.

Water-soluble stains:

Dip a soft cloth in warm water, and then squeeze it tightly. After wiping the stain, wipe with a soft dry cloth.

Oil stain:

Dissolve a synthetic detergent in warm water (density of 2 to 3% or less), dip the cloth, then clean off the stain with the cloth. Next, dip the cloth in fresh water and squeeze it tightly. Then clean off the detergent completely. Then wipe the area with a soft dry cloth.

- Do not use any organic solvent, such as thinner or benzine.

A

B

C

D

E

F

G

H

GW

J

K

L


M

WINDSHIELD GLASS

PFP:72712

Removal and Installation

EIS00E4F



MIIB1175E


1. Windshield molding

2. Windshield glass

3. Spacer

REMOVAL

1. Remove cowl top cover. Refer to [EI-13, "COWL TOP"](#) .
2. Peel off double-sided tape and remove front fender covers (LH/ RH) from front fenders (LH/RH).




3. Remove roof finisher. Refer to [EI-37, "ROOF FINISHER"](#) .
4. Remove upper instrument panel. Refer to [IP-4, "INSTRUMENT PANEL ASSEMBLY"](#) .
5. Remove windshield finisher. Refer to [EI-36, "WINDSHIELD FINISHER"](#) .
6. Remove front pillar garnish. Refer to [EI-28, "Removal and Installation \(C+C\)"](#) .
7. Remove urethane from attached to the bottom of passenger room side windshield.
8. Apply protective tape around windshield glass to protect the painted surface from damage.

WINDSHIELD GLASS

[C+C]

9. Guiding a cutter knife along glass, cut the surface of moldings.
10. With pliers, draw out all the remaining molding left in flanged area of body to remove it completely from adhering surface on glass.
 - When re-using the windshield glass, put match marks on body and glass.




11. Cut adhesive.
 - Depending on the tool in use, follow the procedures below:

CAUTION:

If windshield glass is reused, do not use a windshield knife. (It may scratch glass surface.)


- a. With a windshield knife (when replacing glass).
 - i. To smoothly cut with windshield knife, apply soapy water onto the adhesive on the body side surrounding the windshield.
 - ii. Insert windshield knife into the bonded area. Cut adhesive by pulling the knife, keeping the tip parallel to glass edge.




- b. With a piano wire (when reusing glass).
 - i. Working from inside cabin, drill a through hole in the adhesive with a drill or pick.
 - ii. From inside the passenger room, pass a piano wire through the hole and tie both ends to screwdrivers or similar tools.
 - iii. With two persons, one holding one end of the piano wire outside the vehicle while the other holding the other end inside the vehicle, pulling the wire alternately to cut off the adhesive.

CAUTION:

- Do not press piano wire excessively against glass edge.
- Put a copper plate to keep the piano wire clear of plastic parts such as the instrument panel.



12. Use rubber suction cups (SST) to remove glass from the vehicle.




INSTALLATION


1. Using a knife or spatula, trim the adhesive (sealant) remaining on body down to approximately 2 mm thick so that the contour becomes smooth.

CAUTION:

If bonded area on body is scratched, be sure to repair it with a 2-component urethane. Do not use lacquer.



2. Put the clip in the panel hole.
3. When installing new glass, mount glass onto the vehicle and paint mating marks on body and glass, then remove glass again.
4. When reusing glass, use a knife or spatula to remove the remaining adhesive (sealant) and smooth out the surface.
5. Clean bonded area on glass with white gasoline.



6. Apply primer G along the entire circumference of glass.

CAUTION:

There are 2 types of primer. Never confuse the application methods.

Primer M: for painted surfaces

Primer G: for glass

NOTE:

The essential function of primers is to strengthen adhesion between glass and painted surface.

7. Apply primer M on areas where adhesive contacts on the side of vehicle body.

CAUTION:

- If primer M adheres to a painted surface other than bonding area, or if it overflows, quickly remove it with white gasoline.
- Place a copper plate to keep primer M clear of the instrument panel.

8. After applying primers, apply the adhesive along the entire circumference of the glass as shown in the figure, and within the time specified in the instructions for the adhesive.


- Open adhesive by cutting off the nozzle tip and set it in a sealant gun.

9. After setting rubber suction cups (SST) to glass, align mating marks on body and glass. Install glass to the body.

10. Press entire surface of glass lightly to fit it completely.

11. Remove protective tape.

12. Using a spatula, repair any adhesive overflow or shortage to make the surface smooth.



13. Position windshield moldings and allow their adhesion. Refer to [EI-16, "WINDSHIELD MOLDING"](#) .


CAUTION:

- Be sure to install windshield molding before adhesive hardens.
- After installing glass, keep door windows open and avoid driving vehicle until adhesive has completely cured.

14. Check for water leaks.

15. Remove double-sided tape from front fender cover and apply primer (Sumitomo 3M K520) to double-sided tape application position shown in the figure. Then apply new double-sided tape and install front fender.

Double-sided adhesive tape : Part equivalent to Sumitomo 3M-5571 (t: 0.8)



16. Install urethane from.

17. Install front pillar garnish. Refer to [EI-28, "Removal and Installation \(C+C\)"](#).

18. Install windshield finisher. Refer to [EI-36, "WINDSHIELD FINISHER"](#).

19. Install upper instrument panel. Refer to [IP-4, "INSTRUMENT PANEL ASSEMBLY"](#).

20. Install roof finisher. Refer to [EI-37, "ROOF FINISHER"](#).

21. Install cowl top cover. Refer to [EI-13, "COWL TOP"](#).

A
B
C
D

E
F

G
H

GW

J
K
L


M

FRONT ROOF GLASS

PFP:97352

Removal and Installation

EIS00E6E



1. Front roof glass

2. Primer

3. Weatherstrip

REMOVAL

1. Remove front roof headlining. Refer to [RF-170, "Removal and Installation of Headlining"](#) .
2. Remove front pillar garnish. Refer to [EI-28, "Removal and Installation \(C+C\)"](#) .
3. Remove sunshade. Refer to [RF-173, "Removal and Installation of Sunshade Assembly"](#) .
4. Remove
 - using piano wire or power cutting tool and an inflatable pump bag.
- If a front roof glass is reused, mark the body and the glass with mating marks.

WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.


CAUTION:

- When a front roof glass is reused, do not use a cutting knife or power cutting tool.
- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.

5. Remove the front roof glass, using suction lifter.

INSTALLATION

- Use a genuine Nissan Urethane Adhesive Kit (if available) or equivalent and follow the instructions furnished with it.



- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger compartment air pressure when a door is closed.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the front roof glass in case of an accident.

CAUTION:


- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidity. The curing time will increase under lower temperature and lower humidity.

REAR ROOF GLASS

PFP:97353

Removal and Installation

EIS00E6F



1. Rear roof glass

2. Primer

3. Weatherstrip

4. Trunk lid

REMOVAL

1. Remove rear headlining. Refer to [RF-170, "Removal and Installation of Headlining"](#) .
2. Remove rear roof weatherstrip. Refer to [RF-174, "Removal and Installation of Roof Sealing"](#) .
3. Remove the rear parcel shelf finisher. Refer to [RF-161, "Component Parts Drawing"](#) .
4. Remove the connectors and grounds for the rear window defogger and printed antenna.
5. Remove glass using piano wire or power cutting tool and an inflatable pump bag.
- If a rear roof glass is reused, mark the body and the glass with mating marks.

WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.


CAUTION:

- When a rear roof glass is reused, do not use a cutting knife or power cutting tool.
- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.

6. Remove the rear roof glass, using suction lifter.

INSTALLATION

- Use a genuine Nissan Urethane Adhesive Kit (if available) or equivalent and follow the instructions furnished with it.



- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger compartment air pressure when a door is closed.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the rear roof glass in case of an accident.

CAUTION:


- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidity. The curing time will increase under lower temperature and lower humidity.

REAR WINDOW DEFOGGER

PFP:25350

Component Parts and Harness Connector Location

EIS00E3S



System Description

EIS00E3T

The rear window defogger system is controlled by BCM (Body Control Module) and IPDM E/R (Intelligent Power Distribution Module Engine Room).

The rear window defogger operates only for approximately 15 minutes.

The rear window defogger will be operable when retractable hard top is closed.

When the retractable hard top is open, the retractable hard top control unit send signal to BCM by using the K-line.

When the signal is received, the BCM will prohibit or retractable the operation of rear defogger.
Power is at all times supplied

- through 15A fuse [No. 45, and 46, located in the IPDM E/R]
- to rear window defogger relay

- through 20A fuse [No. 52, located in the fuse block (J/B)]
- to IPDM E/R
- through 40A fusible link [letter J, located in the fuse block (J/B)]
- to BCM terminal 74 and 79.

With the ignition switch turned to ON or START position,
Power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM terminal 24

Ground is supplied

- to BCM terminal 2 and 70
- through body grounds M19, and M20.
- to A/C auto amp terminal 14 (with auto A/C) or
- to heater control panel terminal 10 (without auto A/C)
- through body grounds M19 and M20.
- to internal CPU of IPDM E/R terminal 3 and 54
- through body grounds E26 and E40. (without CR engine)
- through body grounds E25, E26 and E40. (with CR engine)

When rear window defogger switch is turned to ON,

Ground is supplied

- to BCM terminal 4
- through A/C auto amp terminal 17 (with auto A/C) or
- through heater control panel terminal 9 (without auto A/C)
- through A/C auto amp terminal 14 (with auto A/C) or
- through heater control panel terminal 10 (without auto A/C)
- through body grounds M19 and M20.

Then rear window defogger switch is illuminated.

Then BCM recognizes that rear window defogger switch is turned to ON.

Then it sends rear window defogger switch signals to IPDM E/R via DATA LINE (CAN-H, CAN-L).

When IPDM receives rear window defogger switch signals,

Ground is supplied

- to rear window defogger relay terminal
- through internal CPU of IPDM E/R terminal
- through internal CPU of IPDM E/R and IPDM E/R terminal 54
- through body grounds E26 and E40. (without CR engine)
- through body grounds E25, E26 and E40. (with CR engine)

and then rear window defogger relay is energized.

When rear window defogger relay is turned ON,

Power is supplied,

- through rear window defogger relay terminals
- through IPDM E/R terminal 8
- to rear window defogger terminal 1.

Rear window defogger terminal 2, is grounded through body grounds B17, B23 and B81.

With power and ground supplied, rear window defogger filaments heat and defog the rear window.

When rear window defogger relay is turned to ON,

Power is supplied (with mirror defogger)

- through rear window defogger relay terminal
- through IPDM E/R terminal 8
- through 10A fuse [No. 13, located in the fuse block (J/B)]
- to door mirror defogger (Driver side and passenger side) terminal 6.

Door mirror defogger (Driver side and passenger side) terminal 5 is grounded through body grounds M19 and M20.

A

B

C

D

E

F

G

H

GW

J

K

L

M

REAR WINDOW DEFOGGER

[C+C]

With power and ground supplied, door mirror defogger filaments heat and defog the mirror.

REAR WINDOW DEFOGGER

[C+C]

CAN Communication SYSTEM DESCRIPTION

EIS00E3U

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EIS00E77

Body type	3door/5door	3door/5door/C+C	3door/5door	3door/5door/C+C	3door/5door
Axle	2WD				
Engine	CR12DE/CR14DE	HR16DE	CR12DE/CR14DE	HR16DE	K9K
Handle	LHD/RHD				
Brake control	ABS			ESP	
Transmission	A/T	M/T	A/T	M/T	
Intelligent Key system	×	×	×	×	×

CAN communication unit

ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×		×		×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×					×	×						
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN communication type	GW-100, "TYPE 1/ TYPE 2"	GW-103, "TYPE 3/TYPE 4/ TYPE 5/TYPE 6"				GW-105, "TYPE 7/ TYPE 8"	GW-108, "TYPE 9/TYPE 10/ TYPE 11/TYPE 12"				GW-110, "TYPE 13/ TYPE 14"			

×

A

B

C

D

E

F

G

H

GW

J

K

L

M


REAR WINDOW DEFOGGER

[C+C]


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R						
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T						R	
Closed throttle position signal	T						R	
Wide open throttle position signal	T						R	
Overdrive control switch signal		T					R	

REAR WINDOW DEFOGGER

[C+C]

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/T position indicator signal		R					T	
Stop lamp switch signal		T					R	
O/D OFF indicator signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				

REAR WINDOW DEFOGGER

[C+C]

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	EPS control unit	BCM	ABS actua-tor and electric unit (control unit)	TCM	IPDM E/R
A/C switch signal	R				T			
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T


REAR WINDOW DEFOGGER

[C+C]


TYPE 3/TYPE 4/TYPE 5/TYPE 6

System diagram

- Type 3/Type 5



- Type 4/Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R

REAR WINDOW DEFOGGER

[C+C]

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		

*: C+C only


REAR WINDOW DEFOGGER

[C+C]


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R				R		
Engine coolant temperature signal	T	R						
A/T self-diagnosis signal	R						T	
Output shaft revolution signal	R						T	
Accelerator pedal position signal	T					R	R	
Closed throttle position signal	T						R	
Wide open throttle position signal	T						R	
Overdrive control switch signal		T					R	
A/T position indicator signal		R					T	

REAR WINDOW DEFOGGER

[C+C]

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
A/T shift schedule change demand signal						T	R	
Stop lamp switch signal		T					R	
O/D OFF indicator lamp signal		R					T	
Engine and A/T integrated control signal	T						R	
	R						T	
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R						T
A/C compressor request signal	T							R
Heater fan switch signal	R				T			
Cooling fan speed request signal	T							R
Position lights request signal		R			T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal		R			T			R
High beam status signal	R							T
Day time light request signal					T			R
Vehicle speed signal	R	R		R		T		
	R	T	R	R	R			
Sleep/wake up signal		R	R		T			R
Door switch signal		R	R		T			R
Turn indicator signal		R			T			
Buzzer output signal		R			T			
		R	T					
MI signal	T	R						
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R							T
EPS warning lamp signal		R		T				
ABS warning lamp signal		R				T		
ESP warning lamp signal		R				T		
ESP OFF indicator signal		R				T		
SLIP indicator lamp signal		R				T		
Steering angle signal				T		R		
Brake warning lamp signal		R				T		
Back-up lamp signal				R	T			
Front fog lamp request signal		R			T			R
Rear fog lamp status signal		R			T			
Headlamp washer request signal					T			R
Door lock/unlock request signal			T		R			

REAR WINDOW DEFOGGER

[C+C]

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	TCM	IPDM E/R
Door lock/unlock status signal			R		T			
KEY indicator signal		R	T					
LOCK indicator signal		R	T					
Engine status signal	T			R				
A/C switch signal	R				T			
A/T torque signal						R	T	
Brake system malfunction signal		T		R				
Parking brake switch signal		T		R				
R range signal					R			T

A

B

C

D

E

F

G

H

GW

J

K

L

M


REAR WINDOW DEFOGGER

[C+C]


TYPE 9/TYPE 10/TYPE 11/TYPE 12

System diagram

- Type 9/Type 11



- Type 10/Type 12



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R				R	
Engine coolant temperature signal	T	R					
Fuel consumption monitor signal	T	R					
Accelerator pedal position signal	T					R	
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R

REAR WINDOW DEFOGGER

[C+C]

Signals	ECM	Combina- tion meter.	Intelligent Key unit	EPS con- trol unit	BCM	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Low beam request signal					T		R
Low beam status signal	R						T
High beam request signal		R			T		R
High beam status signal	R						T
Day time light request signal					T		R
Vehicle speed signal	R	R		R		T	
	R	T	R	R	R		
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
Rear window defogger control signal	R						T
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
ESP warning lamp signal		R				T	
ESP OFF indicator signal		R				T	
SLIP indicator lamp signal		R				T	
Steering angle signal				T			R
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
A/C switch signal	R				T		
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
R range signal					R		T
Retractable hard top warning lamp signal*		R			T		

*: C+C only


REAR WINDOW DEFOGGER

[C+C]


TYPE 13/TYPE 14

System diagram

- Type 13



- Type 14



REAR WINDOW DEFOGGER

[C+C]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelligent Key unit	EPS con-trol unit	BCM	ABS actu-ator and electric unit (con-trol unit)	IPDM E/R
Engine speed signal	T	R					
Engine coolant temperature signal	T	R			R		
Fuel consumption monitor signal	T	R					
Oil pressure switch signal		R					T
A/C compressor request signal	T						R
Heater fan switch signal	R				T		
Cooling fan speed request signal	T						R
Position lights request signal		R			T		R
Low beam request signal					T		R
High beam request signal		R			T		R
Day time light request signal					T		R
Vehicle speed signal	R	R		R	R	T	
	R	T	R	R			
Sleep/wake up signal		R	R		T		R
Door switch signal		R	R		T		R
Turn indicator signal		R			T		
Buzzer output signal		R			T		
		R	T				
MI signal	T	R					
Front wiper request signal					T		R
Front wiper stop position signal					R		T
Rear window defogger switch signal					T		R
EPS warning indicator signal		R		T			
ABS warning lamp signal		R				T	
Brake warning lamp signal		R				T	
Back-up lamp signal				R	T		
Front fog lamp request signal		R			T		R
Rear fog lamp status signal		R			T		
Headlamp washer request signal					T		R
Door lock/unlock request signal			T		R		
Door lock/unlock status signal			R		T		
KEY indicator signal		R	T				
LOCK indicator signal		R	T				
Engine status signal	T			R			
Brake system malfunction signal		T		R			
Parking brake switch signal		T		R			
Glow indicator signal	T	R					
R range signal					R		T


A
B
C
D
E
F
G
H
GW
J
K
L
M

REAR WINDOW DEFOGGER

[C+C]

Schematic – DEF –

EIS00E3W





MIWA0577E

REAR WINDOW DEFOGGER

[C+C]

Wiring Diagram –DEF–

EIS00E3X



M1 - SUPER MULTIPLE JUNCTION (SMJ)



JUNCTION (SMJ)
M16 - FUSE BLOCK -
JUNCTION BOX (JB)

REAR WINDOW DEFOGGER

[C+C]

- (L) : LHD MODELS
- (R) : RHD MODELS
- (AA) : WITH AUTO A/C
- (OA) : WITHOUT AUTO A/C
- *1 18 : (AA)
- 8 : (OA)
- *2 17 : (AA)
- 9 : (OA)
- *3 14 : (AA)
- 10 : (OA)

PRECEDING
PAGE



REFER TO THE FOLLOWING.

(M1) - SUPER MULTIPLE JUNCTION (SMJ)


(M16) - FUSE BLOCK - JUNCTION BOX (J/B)

MIWA0579E

REAR WINDOW DEFOGGER

[C+C]

GW-DEF-06



MIWA0655E

REAR WINDOW DEFOGGER

[C+C]

Terminal and Reference Value for BCM

EIS00E3Y

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
2	B	Ground	—	0
4	W	Rear window defogger switch signal	When rear window defogger switch is pressed.	0
			When rear window defogger switch is OFF.	5
19	R	CAN- H	—	—
24	O/R	Ignition switch ON or START	Ignition switch (ON or START position)	Battery voltage
39	W	CAN- L	—	—
63	P	K- line	—	—
70	B	Ground	—	0
74	Y	BAT power supply	—	Battery voltage
79	Y	BAT power supply	—	Battery voltage

Terminal and Reference Value for IPDM E/R

EIS00E3Z

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
3	B	Ground (Power)	—	0
8	R	Rear window defogger relay output signal	When rear window defogger switch is ON.	Battery voltage
			When rear window defogger switch is OFF.	0
52	R	CAN- H	—	—
54	B	Ground (Signal)	—	0
58	W	CAN- L	—	—

Work Flow

EIS00E40

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [GW-16, "System Description"](#) .
3. According to the trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [GW-38, "Trouble Diagnoses Symptom Chart"](#) .
4. Does rear window defogger operate normally? YES: GO TO 5, NO: GO TO 3.
5. INSPECTION END.

CONSULT-II Inspection Procedure


EIS00E41

Inspection Item, Diagnosis Mode	Description
DATA MONITOR	The input/output data of the BCM is displayed in real time.
ACTIVE TEST	The BCM sends a drive signal to electronic components to check their operation.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunction might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and CONSULT-II CONVERTER to data link connector.




3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM".
If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




6. Touch "REAR DEFOGGER".



REAR WINDOW DEFOGGER

[C+C]

7. Select diagnosis mode, "DATA MONITOR" and "ACTIVE TEST".



DATA MONITOR

Display Item List

Monitor item "Operation"		Content
REAR DEF SW	"ON / OFF"	Displays "Press (ON) / others (OFF)" status determined with the rear window defogger switch.
IGN ON SW	"ON / OFF"	Displays "IGN SW ON (ON) / OFF (OFF)" status determined with the ignition switch signal.
ENGINE STATUS	"STOP / STALL / RUN / CRA "	Displays "Engine stop (STOP) / engine stall (STALL) / engine running (RUN) / engine cranking (CRA)" as judged from engine status.

ACTIVE TEST

Display Item List

Test item	Content
REAR DEFOGGER	Gives a drive signal to the rear window defogger to activate it.

Trouble Diagnoses Symptom Chart

EIS00E42

- Check that other systems using the signal of the following systems operate normally.

Symptom	Diagnoses / service procedure	Refer to page
Rear window defogger and door mirror defogger do not operate. (With door mirror defogger)	1. BCM power supply and ground circuit check. 2. IPDM E/R auto active test check. 3. Rear window defogger switch circuit check (with auto A/C). 3. Rear window defogger switch circuit check (without auto A/C). 4. Rear window defogger power supply circuit check. 5. Replace IPDM E/ R.	GW-38 PG-43 GW-40 GW-41 GW-43 PG-53
Rear window defogger does not operate. (without door mirror defogger)	1. BCM power supply and ground circuit check. 2. IPDM E/R auto active test check. 3. Rear window defogger switch circuit check (with auto A/C). 3. Rear window defogger switch circuit check (without auto A/C). 4. Rear window defogger power supply circuit check. 5. Rear window defogger circuit check. 6. Filament check. 7. Replace IPDM E/ R.	GW-38 PG-43 GW-40 GW-41 GW-43 GW-44 PG-53
Rear window defogger does not operate but both of door mirror defoggers operate. (With door mirror defogger)	1. Rear window defogger circuit check. 2. Filament check.	GW-44 GW-48
Both of door mirror defoggers do not operate but rear window defogger operate. (With door mirror defogger)	1. Door mirror defogger power supply circuit check.	GW-45
Driver side door mirror defogger does not operate. (With door mirror defogger)	1. Driver side door mirror defogger circuit check.	GW-46
Passenger side door mirror defogger does not operate. (With door mirror defogger)	1. Passenger side door mirror defogger circuit check.	GW-47

BCM Power Supply and Ground Circuit Check

EIS00E43

First perform the “SELF-DIAG RESULTS” in “BCM” with CONSULT-II, then perform the each trouble diagnosis of malfunction system indicated “SELF-DIAG RESULTS” of “BCM”, Refer to [BCS-21, "CONSULT-II Function \(BCM\)"](#) .

1. FUSE INSPECTION

- Check 10A fuse [No.4, located in fuse block (J/B)]
- Check 40A fusible link (letter J located in the fuse and fusible link box).

NOTE:

Refer to [GW-16, "Component Parts and Harness Connector Location"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown out, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-5, "POWER SUPPLY ROUTING"](#) .

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM connector M48, M50 terminal 24, 74, 79 and ground.

24 (OR) – Ground :Battery voltage.


74 (W) – Ground :Battery voltage.

79 (Y) – Ground :Battery voltage.

OK or NG

OK >> GO TO 3.

NG >> Check BCM power supply circuit for open or short.



3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM connector M48, M50 terminal 2, 70 and ground.


2 (B) – Ground :Continuity should exist.

70 (B) – Ground :Continuity should exist.

OK or NG

OK >> Power supply and ground circuit is OK.

NG >> Check BCM ground circuit for open or short.



Rear Window Defogger Switch Circuit Check / With Auto A/C

EIS00E44

1. CHECK REAR WINDOW DEFOGGER SWITCH OPERATION

With CONSULT-II

Check ("REAR DEF SW", "IGN ON SW") in DATA MONITOR mode with CONSULT-II. Refer to [GW-37](#).

When engine is running

ENGINE STATUS :RUN

When rear defogger switch is turned to ON

REAR DEF SW :ON

When ignition switch is turned to ON

IGN ON SW :ON

DATA MONITOR	
MONITOR	RUN
ENGINE STATUS	OFF
REAR DEF SW	ON
IGN ON SW	ON

MKIB0549E


Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between BCM connector ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	4 (W)	Ground	Rear window defogger switch is pressed.	0
			Rear window defogger switch is OFF.	5

OK or NG

OK >> Rear window defogger switch check is OK.
NG >> GO TO 2.



2. CHECK REAR WINDOW DEFOGGER SWITCH CIRCUIT HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and A/C auto amp connector.
3. Check continuity between BCM connector M48 terminal 4 and A/C auto amp connector M63 terminal 17.


4 (W) – 17 (W) :Continuity should exist

4. Check continuity between BCM connector M48 terminal 4 and ground

4 (W) – Ground :Continuity should not exist

OK or NG

OK >> GO TO 3.
NG >> Repair or replace harness between BCM and A/C auto amp.



3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M48 terminal 4 and ground.


4 (W) – Ground

:Approx. 5

OK or NG

OK >> Replace rear window defogger switch. Refer to [ATC-71, "Removal and Installation"](#)

NG >> Replace BCM.



Rear Window Defogger Switch Circuit Check / Without Auto A/C

EIS00E45

1. CHECK REAR WINDOW DEFOGGER SWITCH OPERATION

With CONSULT-II

Check ("REAR DEF SW", "IGN ON SW") in DATA MONITOR mode with CONSULT-II. Refer to [GW-37](#).

When engine is running


ENGINE STATUS :RUN

When rear defogger switch is turned to ON

REAR DEF SW :ON

When ignition switch is turned to ON

IGN ON SW :ON




Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between BCM connector ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	4 (W)	Ground	Rear window defogger switch is pressed.	0
			Rear window defogger switch is OFF.	5

OK or NG

OK >> Rear window defogger switch check is OK.
NG >> GO TO 2.



2. CHECK REAR WINDOW DEFOGGER SWITCH CIRCUIT HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and heater control panel connector.
3. Check continuity between BCM connector M48 terminal 4 and heater control panel connector M58 terminal 9.

4 (W) – 9 (W)

:Continuity should exist

4. Check continuity between BCM connector M48 terminal 4 and ground


4 (W) – Ground

:Continuity should not exist

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness between BCM and heater control panel.



3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M48 terminal 4 and ground.


4 (W) – Ground

:Approx. 5

OK or NG

OK >> Replace heater control panel. Refer to [MTC-46, "Removal and Installation"](#).

NG >> Replace BCM.



REAR WINDOW DEFOGGER

[C+C]

Rear Window Defogger Power Supply Circuit Check

EIS00E46

1. CHECK FUSE

Check if any of the following fuses for IPDM E/R are blown.

COMPONENT PARTS	TERMINAL NO. (SIGNAL)	AMPERE	FUSE NO.
IPDM E/R	3 (BAT power supply)	15A	#45
		15A	#46

NOTE:

Refer to [GW-16, "Component Parts and Harness Connector Location"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse, refer to [GW-16, "Component Parts and Harness Connector Location"](#) .

2. CHECK REAR WINDOW DEFOGGER RELAY


Check rear window defogger relay in "ACTIVE TEST" mode with CONSULT-II. Refer to

Do you hear of the operation sound of rear window defogger relay?

OK or NG

OK >> GO TO 3.

NG >> Replace IPDM E/R.



3. CHECK REAR WINDOW DEFOGGER RELAY OUTPUT SIGNAL

1. Turn rear window defogger switch ON.
2. Check voltage between IPDM E/R connector E11 terminal 8 and ground.


8 (R) – Ground

: Battery voltage

OK or NG

OK >> Rear window defogger power supply circuit check is OK.

NG >> Check connector for damage and loose connection.



REAR WINDOW DEFOGGER

[C+C]

Rear Window Defogger Circuit Check

EIS00E47


1. CHECK REAR WINDOW DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear window defogger connector.
3. Turn ignition switch ON.
4. Check voltage between rear window defogger connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
B302	1 (B)	Ground	Rear window defogger switch ON.	Battery voltage
			Rear window defogger switch OFF.	0

OK or NG

OK >> GO TO 2.
NG >> GO TO 3.



2. CHECK REAR WINDOW DEFOGGER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rear window defogger connector B303 terminal 2 and ground.


2(B) – Ground :Continuity should exist

OK or NG

OK >> Check filament, Refer to [GW-48, "Filament Check"](#)

- If filament is OK.
Check the condition of the harness and the connector.
- If filament is NG.
Repair filament.

NG >> Repair or replace harness between rear window defogger and ground.



3. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R connector E11 terminal 8 and rear window defogger connector B302 terminal 1.


8 (R) – 1 (B) :Continuity should exist.

4. Check continuity between IPDM E/R connector E11 terminal 8 and ground.

8 (R) – Ground :Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.



Door Mirror Defogger Power Supply Circuit Check

EIS00E48

1. CHECK FUSE

Check if any of the following fuse for Fuse block (J/B) are blown.

COMPONENT PARTS	AMPERE	FUSE NO.
Fuse block (J/B)	10A	#13

NOTE:Refer to [GW-16, "Component Parts and Harness Connector Location"](#) .**OK or NG**

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse, refer to [GW-16, "Component Parts and Harness Connector Location"](#) .**2. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT 1**


1. Turn ignition switch ON.
2. Check voltage between door mirror connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D3 (driver side)	6 (LG)	Ground	Rear window defogger switch ON	Battery voltage
D33 (passenger side)	6 (OR)		Rear window defogger switch OFF	0

OK or NG

OK >> GO TO 3.

NG >> Check harness between IPDM E/R and door mirror.


**3. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect door mirror connector.
3. Check continuity between door mirror connector D3 (driver side), D33 (passenger side) terminal 5 and ground.

5 (B) – Ground**:Continuity should exist.****OK or NG**

OK >> INSPECTION END.

NG >> Repair or replace harness.



Driver Side Door Mirror Defogger Circuit Check

EIS00E49


1. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between door mirror (driver side) connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D3	6 (LG)	Ground	Rear window defogger switch ON	Battery voltage
			Rear window defogger switch OFF.	0

OK or NG


OK >> GO TO 2.
NG >> Repair or replace harness between fuse block (J/B) and door mirror (driver side).

**2. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect door mirror (driver side) connector.
3. Check continuity between door mirror (driver side) connector D3 terminal 5 and ground.

5 (B) – Ground : Continuity should exist.OK or NG


OK >> GO TO 3
NG >> Repair or replace harness between door mirror (driver side) and ground.

**3. CHECK DOOR MIRROR DEFOGGER**

Check continuity between each door mirror connector D3 (driver side) terminal 5 and 6.

5 – 6 : Continuity should exist.OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Replace door mirror (driver side).



REAR WINDOW DEFOGGER

[C+C]

Passenger Side Door Mirror Defogger Circuit Check

EIS00E4A


1. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between door mirror (passenger side) connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D33	6 (OR)	Ground	Rear window defogger switch ON	Battery voltage
			Rear window defogger switch OFF	0

OK or NG

OK >> GO TO 2.
NG >> Repair or replace harness between fuse block (J/B) and door mirror (passenger side).




2. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Check continuity between door mirror (passenger side) connector D33 terminal 5 and ground.

5 (B) – Ground : Continuity should exist.

OK or NG

OK >> GO TO 3
NG >> Repair or replace harness between door mirror (passenger side) and ground.




3. CHECK DOOR MIRROR DEFOGGER

Check continuity between each door mirror connector D33 (passenger side) terminal 5 and 6.

5 – 6 : Continuity should exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Replace door mirror (passenger side).




REAR WINDOW DEFOGGER

[C+C]


Filament Check

EIS00E4B


1. When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.



2. Attach probe circuit tester (in Volt range) to middle portion of each filament.



3. If a filament is burned out, circuit tester registers 0 or battery voltage.
4. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



A
B
C
D
E
F
G
H

GW
J
K
L
M

Filament Repair


REPAIR EQUIPMENT

EIS00E4C


- Conductive silver composition (Dupont No. 4817 or equivalent)
- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

REPAIRING PROCEDURE


- Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
- Apply a small amount of conductive silver composition to tip of drawing pen.
Shake silver composition container before use.
- Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



- After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.
Do not touch repaired area while test is being conducted.



- Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet.
If a heat gun is not available, let the repaired area dry for 24 hours.




POWER WINDOW SYSTEM

PFP:25401

Component Parts and Harness Connector Location

EIS00E34



MIB1159E

System Description

EIS00E35

Power is supplied at all time

- from 40A fusible link (letter J, located in the fuse and fusible link box)
- to BCM terminal 74 and 79.
- through 15A fuse [No.23, located in the fuse block (J/B)]
- to retractable hard top control unit terminal 44.

With ignition switch in ON or START position,

Power is supplied

- through 10A fuse [No.4, located in the fuse block (J/B)]
- to BCM terminal 24
- to retractable hard top control unit terminal 3
- to power window main switch terminal 5
- to front power window switch (passenger side) terminal 1.
- through BCM terminal 78
- to retractable hard top control unit terminal 57
- to retractable hard top control unit terminal 58

Ground supplied

- to BCM terminal 52 and 70
- through body grounds M19 and M20.
- to retractable hard top control unit terminals 49, 60 and 61

A
B
C
D
E
F
G
H
GW
J
K

- through body grounds B17, B23 and B81.

DRIVER SIDE WINDOW (LHD MODELS)

Ground is supplied

- to power window main switch terminal 7
- through body grounds M19 and 20.

Window Up

Up operation of the driver side window can only be activated after the rear LH side window fully closed.

When the driver side switch in the power window main switch is pressed in the up position,

Power is supplied

- through power window main switch terminal 2
- to retractable hard top control unit terminal 5.

When the retractable hard top control unit terminal 5 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 55
- to front power window motor LH terminal 2.

At the same time ground of terminal 56.

Ground is supplied

- to front power window motor LH terminal 1
- through retractable hard top control unit terminal 62
- through retractable hard top control unit terminal 4
- through power window main switch terminal 3
- through power window main switch terminal 7.

Then, the motor raises the window until the switch is released.

Window Down

When the driver side switch in the power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 3
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 62
- to front power window motor LH terminal 1.

At the same time ground of terminal 56.

Ground is supplied

- to front power window motor LH terminal 2
- through retractable hard top control unit terminal 55
- through retractable hard top control unit terminal 5
- through power window main switch terminal 2
- through power window main switch terminal 7.

Then, the motor lowers the window until the switch is released.

DRIVER SIDE WINDOW (RHD MODELS)

Ground is supplied

- to power window main switch terminal 7
- through body grounds M19 and 20.

Window Up

Up operation of the driver side window can only be activated after the rear RH side window fully closed.

When the driver side switch in the power window main switch is pressed in the up position,

Power is supplied

- through power window main switch terminal 6
- to retractable hard top control unit terminal 7.

When the retractable hard top control unit terminal 7 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 53
- to front power window motor RH terminal 2.

At the same time ground of terminal 54.

Ground is supplied

- to front power window motor RH terminal 1
- through retractable hard top control unit terminal 59
- through retractable hard top control unit terminal 6
- through power window main switch terminal 4
- through power window main switch terminal 7.

Then, the motor raises the window until the switch is released.

Window Down

When the driver side switch in the power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 4
- to retractable hard top control unit terminal 6

When the retractable hard top control unit terminal 6 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 59
- to front power window motor RH terminal 1.

At the same time ground of terminal 54.

Ground is supplied

- to front power window motor RH terminal 2
- through retractable hard top control unit terminal 53
- through retractable hard top control unit terminal 7
- through power window main switch terminal 6
- through power window main switch terminal 7.

Then, the motor lowers the window until the switch is released.

A

B

C

D

E

F

G

H

GW

J

K

L

M

FRONT PASSENGER SIDE WINDOW (LHD MODELS)

Power Window Main Switch Operation

WINDOW UP

Up operation of the driver side window can only be activated after the rear RH side window fully closed.

When the passenger side switch in power window main switch is pressed in the up position

Power is supplied

- through power window main switch terminal 6
- through front power window switch (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 7.

When the retractable hard top control unit terminal 7 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 53
- to front power window motor RH terminal 2.

At the same time ground of terminal 54.

Ground is supplied

- to front power window motor RH terminal 1
- through retractable hard top control unit terminal 59
- through retractable hard top control unit terminal 6
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the passenger side switch in power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 4
- through front power window switch (passenger side) terminal 3
- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 6.

When the retractable hard top control unit terminal 6 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 59
- to front power window motor RH terminal 1.

At the same time ground of terminal 54.

Ground is supplied

- to front power window motor RH terminal 2
- through retractable hard top control unit terminal 53
- through retractable hard top control unit terminal 7
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

Front Power Window Switch (Passenger Side) Operation

WINDOW UP

Up operation of the driver side window can only be activated after the rear RH side window fully closed.

When the front door window switch (passenger side) is pressed in the up position

Power is supplied

- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 7.

When the retractable hard top control unit terminal 7 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 53
- to front power window motor RH terminal 2.

At the same time ground of terminal 54.

Ground is supplied

- to front power window motor RH terminal 1
- through retractable hard top control unit terminal 59
- through retractable hard top control unit terminal 6
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the front door window switch (passenger side) is pressed in the down position

Power is supplied

- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 6.

When the retractable hard top control unit terminal 6 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 59
- to front power window motor RH terminal 1.

At the same time ground of terminal 54.

Ground is supplied

- to front power window motor RH terminal 2
- through retractable hard top control unit terminal 53.
- through retractable hard top control unit terminal 7
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

A

B

C

D

E

F

G

H

GW

J

K

L

M

FRONT PASSENGER SIDE WINDOW (RHD MODELS)

Power Window Main Switch Operation

WINDOW UP

Up operation of the driver side window can only be activated after the rear LH side window fully closed.

When the passenger side switch in power window main switch is pressed in the up position

Power is supplied

- through power window main switch terminal 2
- through front power window switch (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 55
- to front power window motor LH terminal 2

At the same time ground of terminal 56.

Ground is supplied

- to front power window motor LH terminal 1
- through retractable hard top control unit terminal 62
- through retractable hard top control unit terminal 4
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the passenger side switch in power window main switch is pressed in the down position

Power is supplied

- through power window main switch terminal 3
- through front power window switch (passenger side) terminal 3
- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 62
- to front power window motor LH terminal 1.

At the same time ground of terminal 56.

Ground is supplied

- to front power window motor LH terminal 2
- through retractable hard top control unit terminal 55
- through retractable hard top control unit terminal 5
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

Front Power Window Switch (Passenger Side) Operation

WINDOW UP

Up operation of the driver side window can only be activated after the rear LH side window fully closed.

When the front door window switch (passenger side) is pressed in the up position

Power is supplied

- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 55
- to front power window motor LH terminal 2.

At the same time ground of terminal 56.

Ground is supplied

- to front power window motor LH terminal 1
- through retractable hard top control unit terminal 62
- through retractable hard top control unit terminal 4
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the front door window switch (passenger side) is pressed in the down position

Power is supplied

- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 62
- to front power window motor LH terminal 1.

At the same time ground of terminal 56.

Ground is supplied

- to front power window motor LH terminal 2
- through retractable hard top control unit terminal 55
- through retractable hard top control unit terminal 5
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

A

B

C

D

E

F

G

H

GW

J

K

L

M

REAE LH SIDE WINDOW (LHD MODELS)

Power Window Main Switch Operation

WINDOW UP

Power is supplied

- through power window main switch terminal 2
- to retractable hard top control unit terminal 5.

When the retractable hard top control unit terminal 5 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 56
- to rear power window motor LH terminal 2.

Ground is supplied

- to rear power window motor LH terminal 1
- through retractable hard top control unit terminal 62
- through retractable hard top control unit terminal 4
- through power window main switch terminal 3
- through power window main switch terminal 7.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

Rear LH side window open operation can only be performed when the driver side window is fully opened.

When the driver side window is fully closed, either keep pressing or repress the driver side switch in the power window main switch in down position,

Power is supplied

- through power window main switch terminal 3
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 62
- to rear power window motor LH terminal 1.

Ground is supplied

- to front power window motor LH terminal 2
- through retractable hard top control unit terminal 56
- through retractable hard top control unit terminal 5
- through power window main switch terminal 2
- through power window main switch terminal 7.

Then, the motor lowers the window until the switch is released.

REAE LH SIDE WINDOW (RHD MODELS)**Power Window Main Switch Operation****WINDOW UP**

When the passenger side switch in power window main switch is pressed in the up position

Power is supplied

- through power window main switch terminal 2
- through front power window switch (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 5.

When the retractable hard top control unit terminal 5 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 56
- to rear power window motor LH terminal 2

Ground is supplied

- to rear power window motor LH terminal 1
- through retractable hard top control unit terminal 62
- through retractable hard top control unit terminal 4
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

Rear LH side window open operation can only be performed when the passenger side window is fully opened.

When the passenger side window is fully closed, either keep pressing or repress the passenger side switch in the power window main switch in down position,

Power is supplied

- through power window main switch terminal 3
- through front power window switch (passenger side) terminal 3
- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 62
- to rear power window motor LH terminal 1.

Ground is supplied

- to rear power window motor LH terminal 2
- through retractable hard top control unit terminal 56
- through retractable hard top control unit terminal 5
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

A

B

C

D

E

F

G

H

GW

J

K

L

M

Front Power Window Switch (Passenger Side) Operation

WINDOW UP

Power is supplied

- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 5.

When the retractable hard top control unit terminal 5 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 56
- to rear power window motor LH terminal 2.

Ground is supplied

- to rear power window motor LH terminal 1
- through retractable hard top control unit terminal 62
- through retractable hard top control unit terminal 4
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

Rear LH side window open operation can only be performed when the passenger side window is fully opened.

When the front door window switch (passenger side) is pressed in the down position

Power is supplied

- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 4.

When the retractable hard top control unit terminal 4 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 62
- to rear power window motor LH terminal 1.

Ground is supplied

- to rear power window motor LH terminal 2
- through retractable hard top control unit terminal 55
- through retractable hard top control unit terminal 5
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

REAE RH SIDE WINDOW (LHD MODELS)**Power Window Main Switch Operation****WINDOW UP**

When the passenger side switch in power window main switch is pressed in the up position

Power is supplied

- through power window main switch terminal 6
- through front power window switch (passenger side) terminal 2
- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 7.

When the retractable hard top control unit terminal 7 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 54
- to rear power window motor RH terminal 2

Ground is supplied

- to rear power window motor RH terminal 1
- through retractable hard top control unit terminal 59
- through retractable hard top control unit terminal 6
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

Rear RH side window open operation can only be performed when the passenger side window is fully opened.

When the passenger side window is fully closed, either keep pressing or repress the passenger side switch in the power window main switch in down position,

Power is supplied

- through power window main switch terminal 4
- through front power window switch (passenger side) terminal 3
- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 6.

When the retractable hard top control unit terminal 6 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 59
- to rear power window motor RH terminal 1.

Ground is supplied

- to rear power window motor RH terminal 2
- through retractable hard top control unit terminal 54
- through retractable hard top control unit terminal 7
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

A

B

C

D

E

F

G

H

GW

J

K

L

M

Front Power Window Switch (Passenger Side) Operation

WINDOW UP

Power is supplied

- through front power window switch (passenger side) terminal 5
- to retractable hard top control unit terminal 7.

When the retractable hard top control unit terminal 7 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 54
- to rear power window motor RH terminal 2.

Ground is supplied

- to rear power window motor RH terminal 1
- through retractable hard top control unit terminal 59
- through retractable hard top control unit terminal 6
- through front power window switch (passenger side) terminal 4
- through front power window switch (passenger side) terminal 3
- through power window main switch terminal 4.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

Rear RH side window open operation can only be performed when the passenger side window is fully opened.

When the passenger side window is fully closed, either keep pressing or repress the front power window switch (passenger side) in down position,

Power is supplied

- through front power window switch (passenger side) terminal 4
- to retractable hard top control unit terminal 6.

When the retractable hard top control unit terminal 6 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 59
- to rear power window motor RH terminal 1.

Ground is supplied

- to rear power window motor RH terminal 2
- through retractable hard top control unit terminal 54
- through retractable hard top control unit terminal 7
- through front power window switch (passenger side) terminal 5
- through front power window switch (passenger side) terminal 2
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

REAE RH SIDE WINDOW (RHD MODELS)

Power Window Main Switch Operation

WINDOW UP

Power is supplied

- through power window main switch terminal 6
- to retractable hard top control unit terminal 7.

When the retractable hard top control unit terminal 7 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 54
- to rear power window motor RH terminal 2

Ground is supplied

- to rear power window motor RH terminal 1
- through retractable hard top control unit terminal 59
- through retractable hard top control unit terminal 6
- through power window main switch terminal 4
- through power window main switch terminal 7.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

Rear RH side window open operation can only be performed when the driver side window is fully opened.

When the driver side window is fully closed, either keep pressing or repress the driver side switch in the power window main switch in down position,

Power is supplied

- through power window main switch terminal 4
- to retractable hard top control unit terminal 6.

When the retractable hard top control unit terminal 6 is energized

Power will be supplied toward

- through retractable hard top control unit terminal 59
- to rear power window motor RH terminal 1.

Ground is supplied

- to rear power window motor RH terminal 2
- through retractable hard top control unit terminal 54
- through retractable hard top control unit terminal 7
- through power window main switch terminal 6
- through power window main switch terminal 7.

Then, the motor lowers the window until the switch is released.

AUTO OPERATION

(Driver side)

The power window AUTO feature enables the driver to open or close the window without holding the window switch in the down or up position.

When place the foreign body while operating, operation is stopped.

(Passenger side)

The power window AUTO feature enables the driver to open the window without holding the window switch in the down position.

A

B

C

D

E

F

G

H

GW

J

K

L


M

POWER WINDOW SYSTEM

[C+C]

Schematic – WINDOW –

EIS00E4K



MIWA0580E

POWER WINDOW SYSTEM



[C+C]

Wiring Diagram – WINDOW –

EIS00E36

GW-WINDOW-05

L : LHD MODELS
R : RHD MODELS




(M1) - SUPER MULTIPLE JUNCTION (SMJ)
(M16) - FUSE BLOCK - JUNCTION BOX (J/B)

MIWA0581E

POWER WINDOW SYSTEM

[C+C]

PRE-
CEDING PAGE



GW-WINDOW-06

(L) : LHD MODELS

(R) : RHD MODELS

*1 3: (L)
4: (R)

*2 2: (L)
6: (R)

*3 4: (L)
3: (R)

*4 6: (L)
2: (R)


*5 Y: (L)
OR: (R)

*6 L: (L)
G: (R)


*7 OR: (L)
Y: (R)

*8 G: (L)
L: (R)


PRE-
CEDING PAGE




(D7)
W



(D13), (D42)
W, W



(D14), (D43)
W, W







(D37)
W

MIWA0582E

POWER WINDOW SYSTEM

[C+C]

GW-WINDOW-07




MIWA0583E

POWER WINDOW SYSTEM

[C+C]

GW-WINDOW-08



1	2	3		4	5
6	7	8	9	10	11

56	55		54	53
62	61	60	59	58

MIWA0584E

POWER WINDOW SYSTEM

[C+C]

Terminal and Reference Value for BCM

EIS00E38

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
2	B	Ground	—	0
24	OR	Power supply (IGN)	Ignition switch (ON or START position)	Battery voltage
			Other than above	0
70	B	Ground (power)	—	0
74	Y	Power supply (BAT)	—	Battery voltage
78	R	Power window power supply	Ignition switch (ON or START position)	Battery voltage
			Other than above	0
79	Y	Battery power supply (power window)	—	Battery voltage

Terminal and Reference Value for Retractable Hard Top

EIS00E4L

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
3	OR	Power supply (IGN)	Ignition switch (ON or START position)	Battery voltage
			Other than above	0
4	Y	LH side power window DOWN input signal	When LH side power window DOWN at operate	Battery voltage
5	L	LH side power window UP input signal	When LH side power window UP at operate	Battery voltage
6	OR	RH side power window DOWN input signal	When RH side power window DOWN at operate	Battery voltage
7	G	RH side power window UP input signal	When RH side power window UP at operate	Battery voltage
44	R	Power supply (BAT)	—	Battery voltage
49	B	Ground	—	0
53	PU	Front power window motor RH UP signal	When RH side power window UP at operate	Battery voltage
54	W	Rear power window motor RH UP signal	When front RH side window fully- open and RH side power window UP at operate	Battery voltage
55	GY	Front power window motor LH UP signal	When LH side power window UP at operate	Battery voltage
56	P	Rear power window motor LH UP signal	When front LH side window fully- open and LH side power window UP at operate	Battery voltage
57	R	Power supply (BCM)	Ignition switch (ON or START position)	Battery voltage
			Other than above	0
58	R	Power supply (BCM)	Ignition switch (ON or START position)	Battery voltage
			Other than above	0
59	G	Power window motor RH side DOWN signal	When RH side power window DOWN at operate	When RH side power window DOWN at operate
60	B	Ground	—	0

A
B
C
D
E
F
G
H
GW
J
K
L
M

POWER WINDOW SYSTEM

[C+C]

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
61	B	Ground	—	0
62	LG	Power window motor LH side DOWN signal	When LH side power window DOWN at operate	Battery voltage

CONSULT-II Inspection Procedure


EIS00E4M

Inspection Item, Diagnosis Mode	Description
DATA MONITOR	The input/output data of the BCM is displayed in real time.
ACTIVE TEST	The BCM sends a drive signal to electronic components to check their operation.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunction might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and CONSULT-II CONVERTER to data link connector.




3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM".


If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




POWER WINDOW SYSTEM

[C+C]

6. Touch "RETRACTABLE HARD TOP".



7. Select diagnosis mode, "DATA MONITOR" and "ACTIVE TEST".



DATA MONITOR

Display Item List

Monitor item	Content
DR WIN UP	Indicates [ON/OFF] condition of up signal from driver side power window switch.
DR WIN DOWN	Indicates [ON/OFF] condition of down signal from driver side power window switch.
AS WIN UP	Indicates [ON/OFF] condition of up signal from passenger side power window switch.
AS WIN DOWN	Indicates [ON/OFF] condition of down signal from passenger side power window switch .

ACTIVE TEST

Display Item List

Test item	Content
DR FR WINDOW	This test is able to check front power window motor driver side operation. This power window motor up or down when ""UP"" or ""DOWN"" on CONSULT-II screen is touched.
AS FR WINDOW	This test is able to check front power window motor passenger side operation. This power window motor up or down when ""UP"" or ""DOWN"" on CONSULT-II screen is touched.
DR RR WINDOW	This test is able to check rear power window motor driver side operation. This power window motor up or down when ""UP"" or ""DOWN"" on CONSULT-II screen is touched.
AS RR WINDOW	This test is able to check rear power window motor passenger side operation. This power window motor up or down when ""UP"" or ""DOWN"" on CONSULT-II screen is touched.

Work Flow

EIS00E39

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [GW-50, "System Description"](#)
3. Check self-diagnosis, results using CONSULT-II. Refer to
4. According to the trouble diagnosis chart, repair or replace the cause of the malfunction.
Refer to [GW-58, "Trouble Diagnosis Symptom Chart / Conventional Type"](#)
5. Does power window system operate normally? Yes, GO TO 6, If No, GO TO 4.
6. INSPECTION END

POWER WINDOW SYSTEM

[C+C]

Trouble Diagnosis Symptom Chart / LHD Models

EIS00E3A

Symptom	Repair order	Refer to page
None of the power windows can not be operated using and switch.	1. Power window main switch ground circuit check	GW-169
Driver side power window alone does not operate.	1 .Power window switch circuit check 1	GW-59
	2. Front power window motor LH circuit check 1	GW-60
	3. Replace retractable hard top control unit	GW-63
Passenger side power window alone does not operate using any switch..	1. Power window switch circuit check 3	GW-64
	2. Front power window motor RH circuit check 1	GW-66
	3. Replace retractable hard top control unit	EI-20
Passenger side power window alone does not operate using power window main switch, but front power window switch (passenger side) can be operate.	1. Power window switch circuit check 5	GW-67
Rear LH power window alone does not operate.	1. Rear power window motor LH circuit check 1	GW-73
	2. Replace retractable hard top control unit	GW-68
Rear RH power window alone does not operate.	1. Rear power window motor RH circuit check 1	GW-167
	2. Replace retractable hard top control unit	EI-20

Trouble Diagnosis Symptom Chart / RHD Models

EIS00E4N

Symptom	Repair order	Refer to page
None of the power windows can not be operated using and switch.	1. Power window main switch ground circuit check	GW-169
Driver side power window alone does not operate.	1 .Power window switch circuit check 2	GW-59
	2. Front power window motor LH circuit check 2	GW-60
	3. Replace retractable hard top control unit	GW-63
Passenger side power window alone does not operate using any switch..	1. Power window switch circuit check 4	GW-64
	2. Front power window motor RH circuit check 2	GW-66
	3. Replace retractable hard top control unit	EI-20
Passenger side power window alone does not operate using power window main switch, but front power window switch (passenger side) can be operate.	1. Power window switch circuit check 6	GW-67
Rear LH power window alone does not operate.	1. Rear power window motor LH circuit check 2	GW-73
	2. Replace retractable hard top control unit	GW-68
Rear RH power window alone does not operate.	1. Rear power window motor RH circuit check 2	GW-168
	2. Replace retractable hard top control unit	EI-20

Power Window Circuit Check 1

EIS00E3C

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between power window main switch connector D7 terminal 5 and ground.


5 (R) – Ground

: Battery voltage.

OK or NG

OK >> GO TO 2.

NG >> Check power window main switch power supply circuit for open or short..



2. CHECK POWER WINDOW MAIN SWITCH


1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch terminal 2, 3 and 5, 7.

Terminals		Condition	Continuity	
2	5	UP	Yes	
3	5	DOWN		
2	7	No operation		
3	7	No operation		

OK or NG

OK >> GO TO 3.

NG >> Replace power window main switch.




3. CHECK FUNCTION

With CONSULT-II

1. Connect power window main switch connector.
2. Check ("DR WIN UP", "DR WIN DOWN") in DATA MONITOR mode for "RETORACTABLE HARD TOP" with CONSULT-II.

Monitor item	Condition of driver side power window switch
DR WIN UP	UP : ON
	DOWN : OFF
DR WIN DOWN	UP : OFF
	DOWN : ON



Without CONSULT-II


1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Power window main switch operated, check voltage between retractable hard top control unit connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B82	4 (Y)	Ground	Opening	Battery voltage	
			Other than above	0	
	5 (L)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Power window switch circuit are OK.

NG >> GO TO 4.



4. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch and retractable hard top control unit connector.
3. Check continuity between power window main switch connector D7 terminal 2, 3 and retractable hard top control unit connector B82 terminal 4, 5.


2 (L) – 5 (L) : Continuity should exist.

3 (Y) – 4 (Y) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 2, 3 and Ground.

2 (L) – Ground : Continuity should not exist.

3 (Y) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Repair or replace harness.

Power Window Circuit Check 2

EIS00E4X


1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between power window main switch connector D7 terminal 5 and ground.

5 (R) – Ground : Battery voltage.OK or NG

OK >> GO TO 2.

NG >> Check power window main switch power supply circuit for open or short..

**2. CHECK POWER WINDOW MAIN SWITCH**


1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch terminal 4, 6 and 5, 7.

Terminals		Condition	Continuity
4	5	DOWN	Yes
6	5	UP	
4	7	No operation	
6	7	No operation	

OK or NG

OK >> GO TO 3.

NG >> Replace power window main switch.



3. CHECK FUNCTION

With CONSULT-II

1. Connect power window main switch connector.
2. Check ("DR WIN UP", "DR WIN DOWN") in DATA MONITOR mode for "RETORACTABLE HARD TOP" with CONSULT-II.

Monitor item	Condition of driver side power window switch
DR WIN UP	UP : ON
	DOWN : OFF
DR WIN DOWN	UP : OFF
	DOWN : ON

DATA MONITOR	
MONITOR	
DR WIN UP	OFF
DR WIN DOWN	OFF
AS WIN UP	OFF
AS WIN DOWN	OFF

MIIIB1165E


Without CONSULT-II

1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Power window main switch operated, check voltage between retractable hard top control unit connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B82	6 (OR)	Ground	Opening	Battery voltage	
			Other than above	0	
	7 (G)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Power window switch circuit are OK.
NG >> GO TO 4.




4. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch and retractable hard top control unit connector.
3. Check continuity between power window main switch connector D7 terminal 4, 6 and retractable hard top control unit connector B82 terminal 6, 7.

4 (OR) – 6 (OR) : Continuity should exist.
6 (G) – 7 (G) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 4, 6 and Ground.

4 (OR) – Ground : Continuity should not exist.
6 (G) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Power Window Circuit Check 3

EIS00E42

1. POWER WINDOW INPUT SIGNAL

With CONSULT-II

Check ("AS WIN UP", "AS WIN DOWN") in DATA MONITOR mode for "RETRORACTABLE HARD TOP" with CONSULT-II.

Monitor item	Condition of passenger side power window switch
AS WIN UP	UP : ON
	DOWN : OFF
AS WIN DOWN	UP : OFF
	DOWN : ON

DATA MONITOR	
MONITOR	
DR WIN UP	OFF
DR WIN DOWN	OFF
AS WIN UP	OFF
AS WIN DOWN	OFF

MIB1165E

Without CONSULT-II


1. Turn ignition switch ON.
2. Check voltage between retractable hard top control unit connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B82	6 (OR)	Ground	Opening	Battery voltage	
			Other than above	0	
	7 (G)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Power window switch circuit are OK.

NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit and front power window switch passenger side connector..
3. Check continuity between retractable hard top control unit connector B82 terminal 6, 7 and front power window switch passenger side connector D37 terminal 4, 5.

6 (OR) – 4 (OR) : Continuity should exist.

7 (G) – 5 (G) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B82 terminal 6, 7 and ground.


6 (OR) – Ground : Continuity should not exist.

7 (G) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Repair or replace harness.



Power Window Circuit Check 4

EIS00E50

1. POWER WINDOW INPUT SIGNAL

With CONSULT-II

Check ("AS WIN UP", "AS WIN DOWN") in DATA MONITOR mode for "RETRACTABLE HARD TOP" with CONSULT-II.

Monitor item	Condition of passenger side power window switch
AS WIN UP	UP : ON
	DOWN : OFF
AS WIN DOWN	UP : OFF
	DOWN : ON

DATA MONITOR	
MONITOR	
DR WIN UP	OFF
DR WIN DOWN	OFF
AS WIN UP	OFF
AS WIN DOWN	OFF

MIIB1165E

Without CONSULT-II


1. Turn ignition switch ON.
2. Check voltage between retractable hard top control unit connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B82	4 (Y)	Ground	Opening	Battery voltage	
			Other than above	0	
	5 (L)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Power window switch circuit are OK.

NG >> GO TO 5.



MIIB1115E

2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit and front power window switch passenger side connector.
3. Check continuity between retractable hard top control unit connector B82 terminal 4, 5 and front power window switch passenger side connector D37 terminal 4, 5.

4 (Y) – 4 (Y) : Continuity should exist.
5 (L) – 5 (L) : Continuity should exist.


4. Check continuity between retractable hard top control unit connector B82 terminal 4, 5 and ground.

4 (Y) – Ground : Continuity should not exist.
5 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Repair or replace harness.



MIIB1170E

Power Window Circuit Check 5

EIS00E4S


1. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window switch (passenger side) connector.
3. Check continuity between power window main switch connector D7 terminal 4, 6 and front power window switch (passenger side) connector D37 terminal 2, 3.

4 (G) – 3 (G) : Continuity should exist.
6 (PU) – 2 (PU) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 4, 6 and Ground.

4 (G) – Ground : Continuity should not exist.
6 (PU) – Ground : Continuity should not exist.



OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness.

2. CHECK POWER WINDOW MAIN SWITCH


Passenger side switch operated, check continuity between power window main switch terminal 4, 6 and 5.

Terminals		Condition	Continuity
4	5	DOWN	Yes
5	5	UP	

OK or NG

OK >> Check the condition of the harness and connector.

NG >> Replace power window main switch.



Power Window Circuit Check 6

EIS00E4Y


1. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch and front power window switch (passenger side) connector.
3. Check continuity between power window main switch connector D7 terminal 2, 3 and front power window switch (passenger side) connector D37 terminal 2, 3..

2 (PU) – 2 (PU) : Continuity should exist.
3 (G) – 3 (G) : Continuity should exist.

4. Check continuity between power window main switch connector D7 terminal 2, 3 and Ground.

2 (PU) – Ground : Continuity should not exist.
3 (G) – Ground : Continuity should not exist.



OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness.


2. CHECK POWER WINDOW MAIN SWITCH

Passenger side switch operated, check continuity between power window main switch connector D7 terminal 2, 3 and 5.

Terminals		Condition	Continuity
2	5	UP	Yes
3	5	DOWN	

OK or NG

OK >> Check the condition of the harness and connector.
 NG >> Replace power window main switch.



Front Power Window Motor LH Circuit Check 1


EIS00E40

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (DR FR WINDOW) in the ACTIVE TEST.

Test item	Description
DR FR WINDOW	Driver side power window motor UP or DOWN when "UP" or "DOWN" on CONSULT-II screen is touched.




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH connector.
3. Turn ignition switch ON.
4. Power window main switch operated, check voltage between front power window motor LH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
D5	1 (LG)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (GY)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace front power window motor LH.
NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 55, 62 and front power window motor LH connector D5 terminal 1, 2.


55 (GY) – 2 (GY) : Continuity should exist.

62 (LG) – 1 (LG) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 55, 62 and ground.

55 (GY) – Ground : Continuity should not exist.

62 (LG) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Front Power Window Motor LH Circuit Check 2


EIS00E4P

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (AS FR WINDOW) in the ACTIVE TEST.

Test item	Description	
AS FR WINDOW	Passenger side power window motor UP or DOWN when "UP" or "DOWN" on CONSULT-II screen is touched.	




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH connector.
3. Turn ignition switch ON.
4. Power window main switch operated, check voltage between front power window motor LH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
D5	1 (LG)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (GY)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace front power window motor LH.
NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 55, 62 and front power window motor LH connector D5 terminal 1, 2.


55 (GY) – 2 (GY) : Continuity should exist.

62 (LG) – 1 (LG) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 55, 62 and ground.

55 (GY) – Ground : Continuity should not exist.

62 (LG) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Front Power Window Motor RH Circuit Check 1


EIS00E4Q

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (AS FR WINDOW) in the ACTIVE TEST.

Test item	Description
AS FR WINDOW	Passenger side power window motor UP or DOWN when "UP" or "DOWN" on CONSULT-II screen is touched.




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH connector.
3. Turn ignition switch ON.
4. Power window main switch operated, check voltage between front power window motor RH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
D35	1 (G)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (PU)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace front power window motor RH.
NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 53, 59 and front power window motor RH connector D35 terminal 1, 2.


53 (PU) – 2 (PU) : Continuity should exist.

59 (G) – 1 (G) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 55, 59 and ground.

53 (PU) – Ground : Continuity should not exist.

59 (G) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Front Power Window Motor RH Circuit Check 2


EIS00E4R

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (DR FR WINDOW) in the ACTIVE TEST.

Test item	Description
DR FR WINDOW	Driver side power window motor UP or DOWN when "UP" or "DOWN" on CONSULT-II screen is touched.




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH connector.
3. Turn ignition switch ON.
4. Power window main switch operated, check voltage between front power window motor RH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
D35	1 (G)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (PU)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace front power window motor RH.
NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 53, 59 and front power window motor RH connector D35 terminal 1, 2.


53 (PU) – 2 (PU) : Continuity should exist.

59 (G) – 1 (G) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 55, 59 and ground.

53 (PU) – Ground : Continuity should not exist.

59 (G) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Rear Power Window Motor LH Circuit Check 1


EIS00E4T

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (DR RR WINDOW) in the ACTIVE TEST.

Test item	Description
DR RR WINDOW	Rear LH side power window motor UP or DOWN when "UP" or "DOWN" on CONSULT-II screen is touched.




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B72	1 (L)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (P)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace rear power window motor LH.
NG >> GO TO 2.




2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 56, 62 and rear power window motor LH connector B72 terminal 1, 2.

56 (P) – 2 (P) : Continuity should exist.
62 (LG) – 1 (L) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 56, 62 and ground.

56 (P) – Ground : Continuity should not exist.
62 (LG) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Rear Power Window Motor LH Circuit Check 2


EIS00E4U

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (AS RR WINDOW) in the ACTIVE TEST.

Test item	Description
AS RR WINDOW	Rear LH side power window motor UP or DOWN when "UP" or "DOWN" on CONSULT-II screen is touched.




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B72	1 (L)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (P)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace rear power window motor LH.
NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 56, 62 and rear power window motor LH connector B72 terminal 1, 2.


56 (P) – 2 (P) : Continuity should exist.

62 (LG) – 1 (L) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 56, 62 and ground.

56 (P) – Ground : Continuity should not exist.

62 (LG) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Rear Power Window Motor RH Circuit Check 1


E1500E4V

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (AS RR WINDOW) in the ACTIVE TEST.

Test item	Description
AS RR WINDOW	Rear RH side power window motor UP or DOWN when "UP" or "DOWN" on CONSULT-II screen is touched.




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B67	1 (G)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (W)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace rear power window motor RH.
NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 54, 59 and rear power window motor RH connector B67 terminal 1, 2.


54 (W) – 2 (W) : Continuity should exist.

59 (G) – 1 (G) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 54, 59 and ground..

54 (W) – Ground : Continuity should not exist.

59 (G) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Rear Power Window Motor RH Circuit Check 2


EIS00E4W

1. POWER WINDOW OUTPUT SIGNAL CHECK

With CONSULT-II

Check the operation with (DR RR WINDOW) in the ACTIVE TEST.

Test item	Description	
DR RR WINDOW	DR RR WINDOW	UP




Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx)	
	(+)	(-)			
B67	1 (G)	Ground	Opening	Battery voltage	
			Other than above	0	
	2 (W)		Closing	Battery voltage	
			Other than above	0	

OK or NG

OK >> Replace rear power window motor RH.
NG >> GO TO 2.



2. CHECK POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect retractable hard top control unit connector.
3. Check continuity between retractable hard top control unit connector B84 terminal 54, 59 and rear power window motor RH connector B67 terminal 1, 2.


54 (W) – 2 (W) : Continuity should exist.

59 (G) – 1 (G) : Continuity should exist.

4. Check continuity between retractable hard top control unit connector B84 terminal 54, 59 and ground..

54 (W) – Ground : Continuity should not exist.

59 (G) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.

Power Window Main Switch Ground Circuit Check


EIS00E6G

1. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch connector D7 terminal 7 and ground.

7 (B) – Ground**:Continuity should exist.**OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.




FRONT DOOR GLASS AND REGULATOR

PFP:80300

Removal and Installation

EIS00E33

SEC. 803



MIIB1178E

- 1. Door glass
- 2. Door glass run
- 3. Lower sash
- 4. Regulator assembly
- 5. Power window motor

DOOR GLASS


Removal

1. Remove front door finisher. Refer to [EI-20, "DOOR FINISHER"](#) .
2. Disconnect front speaker harness connector, and then remove sealing screen.

NOTE:

If sealing screen is reused, cut butyl tape in a way that leaves it on sealing screen.

3. Remove front door inner frame and front door inner pad.




MIIB1179E


FRONT DOOR GLASS AND REGULATOR

[C+C]


4. Operate power window switch to raise/lower door glass until glass bolts can be seen.
5. Remove door glass bolts.



6. Lift the door glass from the door panel while opening the rear side window bracket.



7. Remove door mirror. Refer to [GW-179, "Removal and Installation"](#) .
8. Remove front door inside seal. Refer to [EI-20, "DOOR FINISHER"](#) .
9. Remove glass run.
10. Remove the lower sash screws and nuts, and then remove the lower sash.



Installation

Install in the reverse order of removal.

CAUTION:

Be careful not to remove the front side window bracket.

Glass mounting bolts

Tightening torque : 8 N·m (0.8 kg·m, 71 in·lb)

REGULATOR ASSEMBLY

Removal

1. Remove front door glass. Refer to [GW-170, "DOOR GLASS"](#) .
2. Disconnect power window motor harness connector.

A

B

C

D

E

F

G

H

GW

J

K


L

M

FRONT DOOR GLASS AND REGULATOR

[C+C]

3. Remove the regulator assembly bolts and nuts.



4. Remove the clips, and remove regulator assembly from door panel.

Installation


1. Remove the windshield bracket from the regulator assembly.
2. Install regulator assembly for door panel.
3. Connect power window motor harness connector.
4. Install front glass bracket.
5. Install front door glass. Refer to [GW-170, "DOOR GLASS"](#).

Inspection after removal

Check the regulator assembly for the following. If a failure is detected, replace or grease it.

- Wire wear
- Regulator assembly deformation
- Grease condition on each sliding part

The arrows in the figure show body grease application points of the body grease.



Disassembly and Assembly REGULATOR ASSEMBLY

EIS00E6B

Removal

Remove power window motor from regulator assembly.

ASSEMBLY

Assemble in the reverse order of disassembly.

Inspection after Installation

EIS00E6A

FITTING INSPECTION

- Make sure glass is securely fit into door glass run groove.

Up/Down Adjustment

- Lower glass slightly (approximately 10 to 20 mm), and confirm clearance to the weatherstrip is parallel. If clearance between glass and sash is not parallel, loosen bolts for glass, and glass bracket, and then correct glass position.


Inclination Adjustment

1. Raise glass to the fully-closed position.

FRONT DOOR GLASS AND REGULATOR


[C+C]

2. Loosen the nuts of regulator lower side and move the stud bolt, and then adjust the inclination of window.



3. Remove the rear fixing nut of rail upper part, and then perform the adjustment by rotating the adjusting bolt.

- Turn the adjusting bolt clockwise to move the door glass upper end inward.
- Turn the adjusting bolt counterclockwise to move the door glass upper end outward.



NOTE:

If water leaks, repair the fitting. Refer to [RF-167, "Adjustment of Retractable Hard Top Assembly"](#).


A
B
C
D
E
F
G
H
GW
J
K
L
M

SIDE WINDOW GLASS

PFP:83300

Removal and Installation

EIS00E4E



MIIB1187E

1. Anchor reinforce	2. Side window glass	3. Back plate
4. Spacer	5. Regulator assembly	6. Power window motor


REMOVAL

1. Fully open the roof.
2. Fully open the side window.
3. Remove the rear seat cushion, seat back, headrest. Refer to [SE-17, "BENCH SEAT \(C+C\)"](#)
4. Remove the back side trim finisher. Refer to [EI-39, "BACK SIDE TRIM"](#) .
5. Remove the body side trim. Refer to [EI-28, "Removal and Installation \(C+C\)"](#) .
6. Remove a part of trunk lid weatherstrip. Refer to [BL-257, "Removal and Installation of Trunk Lid Weather-strip"](#) .
7. Remove sealing screen.

NOTE:

If sealing screen is reused, cut butyl tape in a way that leaves it on sealing screen.

8. Remove the bracket bolt from passenger room side.




MIIB1188E


SIDE WINDOW GLASS

[C+C]


9. Remove the bracket bolt from upper side.



10. Remove regulator nut and, remove anchor reinforce.



11. Loosen the nuts of regulator adjusting bolt.



12. Lift up the module together with the window, and then remove them.

INSTALLATION


Install in the reverse order of remove.

INSPECTION AFTER REMOVAL

Check the regulator assembly for the following. If a failure is detected, replace or grease it.

- Wire wear
- Regulator assembly deformation
- Grease condition on each sliding part


The arrows in the figure show body grease application points of the body grease.



Disassembly and Assembly

DISASSEMBLY

1. Remove window nuts, and then remove the window together with the carrier plate.
2. Remove the spacer from the back plate, and then remove the window.
3. Remove the power window motor from regulator assembly.



ASSEMBLY

Assemble in the reverse order of disassembly.

Glass mounting nuts

Tightening torque : 6.5 N·m (0.66 kg·m, 58 in·lb)

Inspection after Installation


FITTING INSPECTION

EIS00E6D

- Make sure glass is securely fit into door glass run groove.
- Lower glass slightly (approximately 10 to 20 mm), and confirm clearance to the sash is parallel. If clearance between glass and sash is not parallel, loosen bolts for regulator assembly, glass, and carrier plate, and then correct glass position.


Up/Down Adjustment

1. Loosen the window nuts at the window fully-closed position, and then perform the window up/down adjustment.



Inclination Adjustment

1. Loosen the nuts of regulator adjusting bolt.
2. Rotate the regulator adjusting bolt, and then perform the fitting adjustment between the window upper end and weatherstrip.



NOTE:

If water repair the fitting. Refer to [RF-167, "Adjustment of Retractable Hard Top Assembly"](#).

DOOR MIRROR




[C+C]

DOOR MIRROR

PFP:96301

Wiring Diagram — MIRROR — LHD Models

E1500E2Y



REFER TO THE FOLLOWING.

M16 - FUSE BLOCK -
JUNCTION BOX (J/B)

MIWA0587E

Wiring Diagram — MIRROR — RHD Models

EIS00E22

GW-MIRROR-02

◆ HB : HATCHBACK

◆ CC : C+C

*1 1 : HB







3 : CC

*2 6 : HB

9 : CC

*3 9 : HB

10 : CC



REFER TO THE FOLLOWING.


(M16) - FUSE BLOCK -
JUNCTION BOX (J/B)

Removal and Installation

EIS00E30

A
B
C
D
E
F
G
H

GW

J
K
L
M

MIIB1196E

1. Door mirror assembly

REMOVAL

CAUTION:

Be careful not to damage mirror body.


1. Remove front door finisher. Refer to [EI-20, "DOOR FINISHER"](#) .
2. Remove front tweeter. Refer to [AV-17, "Removal and Installation of Front Pillar Tweeter"](#) .
3. Disconnect door mirror harness connector.
4. Remove door mirror bolts and door mirror assembly.

INSTALLATION

Install in the reverse order of removal.

Disassembly and Assembly

EIS00E31




MIIB1197E


1. Mirror body (integrated with holder)
2. Door mirror assembly
3. Mirror cover

DISASSEMBLY

1. Turn mirror glass surface upward.
2. Apply protective tape to the housing.
3. Insert a screwdriver or similar tool between the mirror body and power unit, and then pry the mirror body to remove it.



4. Retract the door mirror and remove the clips, and then remove the mirror cover.

**ASSEMBLY**

1. Retract the door mirror, and then install the mirror cover.
2. Place power unit and mirror body in a horizontal position.
3. Engage upper tabs of mirror glass body (mirror holder) with power unit. Then, press lower part of mirror glass down until lower part snaps into place and engages lower tabs.

CAUTION:

After finishing work, visually confirm that tabs at the bottom of mirror face are securely engaged.


INSIDE MIRROR

PFP:96321

Removal and Installation

REMOVAL

Pull the inside mirror upward to remove it.



INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

GW

J

K

L

M

INSIDE MIRROR

[C+C]
