

ENGINE CONTROL SYSTEM

SECTION EC

GI
MA
EM
LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CONTENTS

| | | |
|---|--------|--|
| | KA24DE | |
| TROUBLE DIAGNOSIS - INDEX | 13 | |
| Alphabetical & P No. Index for DTC | 13 | |
| PRECAUTIONS | 17 | |
| Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 17 | |
| Precautions for On Board Diagnostic (OBD) | | |
| System of Engine and A/T | 17 | |
| Engine Fuel & Emission Control System | 18 | |
| Precautions | 19 | |
| Wiring Diagrams and Trouble Diagnosis | 20 | |
| PREPARATION | 21 | |
| Special Service Tools | 21 | |
| Commercial Service Tools | 21 | |
| ENGINE AND EMISSION CONTROL OVERALL SYSTEM | 23 | |
| Engine Control Component Parts Location | 23 | |
| Circuit Diagram | 25 | |
| System Diagram | 26 | |
| Vacuum Hose Drawing | 27 | |
| System Chart | 28 | |
| ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION | 29 | |
| Multiport Fuel Injection (MFI) System | 29 | |
| Distributor Ignition (DI) System | 31 | |
| Air Conditioning Cut Control | 33 | |
| Fuel Cut Control (at no load & high engine speed) | 33 | |
| Evaporative Emission System | 34 | |
| Positive Crankcase Ventilation | 39 | |
| BASIC SERVICE PROCEDURE | 40 | |
| Fuel Pressure Release | 40 | |
| Fuel Pressure Check | 40 | |
| Fuel Pressure Regulator Check | 41 | |
| Injector | 41 | |
| Fast Idle Cam (FIC) | 41 | |
| Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment | 42 | |

| | | |
|--|-----|--|
| ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION | 56 | |
| Introduction | 56 | |
| Two Trip Detection Logic | 56 | |
| Emission-related Diagnostic Information | 57 | |
| Malfunction Indicator Lamp (MIL) | 69 | |
| OBD System Operation Chart | 73 | |
| CONSULT-II | 78 | |
| Generic Scan Tool (GST) | 89 | |
| TROUBLE DIAGNOSIS - INTRODUCTION | 91 | |
| Introduction | 91 | |
| Work Flow | 93 | |
| TROUBLE DIAGNOSIS - BASIC INSPECTION | 95 | |
| Basic Inspection | 95 | |
| TROUBLE DIAGNOSIS - GENERAL DESCRIPTION | 109 | |
| DTC Inspection Priority Chart | 109 | |
| Fail-safe Chart | 110 | |
| Symptom Matrix Chart | 111 | |
| CONSULT-II Reference Value in Data Monitor Mode | 115 | |
| Major Sensor Reference Graph in Data Monitor Mode | 117 | |
| ECM Terminals and Reference Value | 120 | |
| TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT | 128 | |
| Description | 128 | |
| Diagnostic Procedure | 128 | |
| TROUBLE DIAGNOSIS FOR POWER SUPPLY | 129 | |
| Main Power Supply and Ground Circuit | 129 | |
| DTC P0100 MASS AIR FLOW SENSOR (MAFS) | 136 | |
| Component Description | 136 | |
| CONSULT-II Reference Value in Data Monitor Mode | 136 | |
| ECM Terminals and Reference Value | 136 | |
| On Board Diagnosis Logic | 137 | |
| DTC Confirmation Procedure | 137 | |
| Overall Function Check | 139 | |
| Wiring Diagram | 140 | |

CONTENTS (Cont'd)

| | | | |
|---|-----|---|-----|
| Diagnostic Procedure | 141 | DTC P0131 FRONT HEATED OXYGEN SENSOR | |
| DTC P0105 ABSOLUTE PRESSURE SENSOR | 146 | (FRONT HO2S) (LEAN SHIFT MONITORING) | 198 |
| Component Description | 146 | Component Description | 198 |
| On Board Diagnosis Logic..... | 146 | CONSULT-II Reference Value in Data Monitor | |
| DTC Confirmation Procedure | 147 | Mode | 198 |
| Overall Function Check | 148 | ECM Terminals and Reference Value | 198 |
| Wiring Diagram | 149 | On Board Diagnosis Logic..... | 199 |
| Diagnostic Procedure | 150 | DTC Confirmation Procedure | 199 |
| DTC P0110 INTAKE AIR TEMPERATURE | | Overall Function Check | 200 |
| SENSOR | 161 | Diagnostic Procedure | 200 |
| Component Description | 161 | DTC P0132 FRONT HEATED OXYGEN SENSOR | |
| On Board Diagnosis Logic..... | 161 | (FRONT HO2S) (RICH SHIFT MONITORING) | 205 |
| DTC Confirmation Procedure | 162 | Component Description | 205 |
| Wiring Diagram | 163 | CONSULT-II Reference Value in Data Monitor | |
| Diagnostic Procedure | 164 | Mode | 205 |
| DTC P0115 ENGINE COOLANT TEMPERATURE | | ECM Terminals and Reference Value | 205 |
| SENSOR (ECTS) (CIRCUIT) | 167 | On Board Diagnosis Logic..... | 206 |
| Component Description | 167 | DTC Confirmation Procedure | 206 |
| CONSULT-II Reference Value in Data Monitor | | Overall Function Check | 207 |
| Mode | 167 | Diagnostic Procedure | 207 |
| On Board Diagnosis Logic..... | 167 | DTC P0133 FRONT HEATED OXYGEN SENSOR | |
| DTC Confirmation Procedure | 168 | (FRONT HO2S) (RESPONSE MONITORING) | 212 |
| Wiring Diagram | 169 | Component Description | 212 |
| Diagnostic Procedure | 170 | CONSULT-II Reference Value in Data Monitor | |
| DTC P0120 THROTTLE POSITION SENSOR | 172 | Mode | 212 |
| Component Description | 172 | ECM Terminals and Reference Value | 212 |
| CONSULT-II Reference Value in Data Monitor | | On Board Diagnosis Logic..... | 213 |
| Mode | 172 | DTC Confirmation Procedure | 213 |
| ECM Terminals and Reference Value | 173 | Overall Function Check | 214 |
| On Board Diagnosis Logic..... | 173 | Wiring Diagram | 215 |
| DTC Confirmation Procedure | 174 | Diagnostic Procedure | 216 |
| Wiring Diagram | 177 | DTC P0134 FRONT HEATED OXYGEN SENSOR | |
| Diagnostic Procedure | 178 | (FRONT HO2S) (HIGH VOLTAGE) | 223 |
| DTC P0125 ENGINE COOLANT TEMPERATURE | | Component Description | 223 |
| (ECT) SENSOR | 186 | CONSULT-II Reference Value in Data Monitor | |
| Component Description | 186 | Mode | 223 |
| On Board Diagnosis Logic..... | 186 | ECM Terminals and Reference Value | 223 |
| DTC Confirmation Procedure | 186 | On Board Diagnosis Logic..... | 224 |
| Wiring Diagram | 187 | DTC Confirmation Procedure | 224 |
| Diagnostic Procedure | 188 | Wiring Diagram | 225 |
| DTC P0130 FRONT HEATED OXYGEN SENSOR | | Diagnostic Procedure | 226 |
| (FRONT HO2S) (CIRCUIT) | 190 | DTC P0135 FRONT HEATED OXYGEN SENSOR | |
| Component Description | 190 | HEATER | 230 |
| CONSULT-II Reference Value in Data Monitor | | Description | 230 |
| Mode | 190 | CONSULT-II Reference Value in Data Monitor | |
| ECM Terminals and Reference Value | 190 | Mode | 230 |
| On Board Diagnosis Logic..... | 191 | ECM Terminals and Reference Value | 230 |
| DTC Confirmation Procedure | 192 | On Board Diagnosis Logic..... | 230 |
| Overall Function Check | 193 | DTC Confirmation Procedure | 231 |
| Wiring Diagram | 194 | Wiring Diagram | 232 |
| Diagnostic Procedure | 195 | Diagnostic Procedure | 233 |

CONTENTS (Cont'd)

| | | |
|---|---|----|
| DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)235 | Wiring Diagram.....275 | GI |
| Component Description.....235 | Diagnostic Procedure.....276 | |
| CONSULT-II Reference Value in Data Monitor Mode.....235 | DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)278 | MA |
| ECM Terminals and Reference Value.....235 | On Board Diagnosis Logic.....278 | |
| On Board Diagnosis Logic.....235 | DTC Confirmation Procedure.....278 | EM |
| DTC Confirmation Procedure.....236 | Wiring Diagram.....280 | |
| Overall Function Check.....237 | Diagnostic Procedure.....281 | |
| Wiring Diagram.....238 | DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)286 | LC |
| Diagnostic Procedure.....239 | On Board Diagnosis Logic.....286 | |
| DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)245 | DTC Confirmation Procedure.....286 | EC |
| Component Description.....245 | Wiring Diagram.....288 | |
| CONSULT-II Reference Value in Data Monitor Mode.....245 | Diagnostic Procedure.....289 | FE |
| ECM Terminals and Reference Value.....245 | DTC P0180 FUEL TANK TEMPERATURE SENSOR293 | |
| On Board Diagnosis Logic.....245 | Component Description.....293 | CL |
| DTC Confirmation Procedure.....246 | On Board Diagnosis Logic.....293 | |
| Overall Function Check.....247 | DTC Confirmation Procedure.....294 | MT |
| Wiring Diagram.....248 | Wiring Diagram.....295 | |
| Diagnostic Procedure.....249 | Diagnostic Procedure.....296 | |
| DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)255 | DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE299 | AT |
| Component Description.....255 | On Board Diagnosis Logic.....299 | |
| CONSULT-II Reference Value in Data Monitor Mode.....255 | DTC Confirmation Procedure.....299 | TF |
| ECM Terminals and Reference Value.....255 | Diagnostic Procedure.....300 | |
| On Board Diagnosis Logic.....255 | DTC P0325 KNOCK SENSOR (KS)308 | |
| DTC Confirmation Procedure.....256 | Component Description.....308 | PD |
| Overall Function Check.....257 | ECM Terminals and Reference Value.....308 | |
| Wiring Diagram.....258 | On Board Diagnosis Logic.....308 | AX |
| Diagnostic Procedure.....259 | DTC Confirmation Procedure.....308 | |
| DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)265 | Wiring Diagram.....309 | SU |
| Component Description.....265 | Diagnostic Procedure.....310 | |
| CONSULT-II Reference Value in Data Monitor Mode.....265 | DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)312 | |
| ECM Terminals and Reference Value.....265 | Component Description.....312 | BR |
| On Board Diagnosis Logic.....265 | ECM Terminals and Reference Value.....312 | |
| DTC Confirmation Procedure.....266 | On Board Diagnosis Logic.....312 | ST |
| Overall Function Check.....266 | DTC Confirmation Procedure.....313 | |
| Wiring Diagram.....267 | Wiring Diagram.....314 | RS |
| Diagnostic Procedure.....268 | Diagnostic Procedure.....315 | |
| DTC P0141 REAR HEATED OXYGEN SENSOR HEATER273 | DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)318 | |
| Description.....273 | Component Description.....318 | BT |
| CONSULT-II Reference Value in Data Monitor Mode.....273 | ECM Terminals and Reference Value.....318 | |
| ECM Terminals and Reference Value.....273 | On Board Diagnosis Logic.....319 | HA |
| On Board Diagnosis Logic.....273 | DTC Confirmation Procedure.....320 | |
| DTC Confirmation Procedure.....274 | Wiring Diagram.....321 | SC |
| | Diagnostic Procedure.....322 | |
| | DTC P0400 EGR FUNCTION (CLOSE)326 | |
| | Description.....326 | EL |
| | On Board Diagnosis Logic.....327 | |

CONTENTS (Cont'd)

| | | | |
|--|-----|---|-----|
| DTC Confirmation Procedure | 328 | On Board Diagnosis Logic..... | 398 |
| Overall Function Check | 329 | DTC Confirmation Procedure | 399 |
| Wiring Diagram | 330 | Diagnostic Procedure | 400 |
| Diagnostic Procedure | 331 | DTC P0500 VEHICLE SPEED SENSOR (VSS) | 412 |
| DTC P0402 EGRC-BPT VALVE FUNCTION | 338 | Component Description | 412 |
| Description | 338 | ECM Terminals and Reference Value | 412 |
| On Board Diagnosis Logic..... | 338 | On Board Diagnosis Logic..... | 412 |
| DTC Confirmation Procedure | 339 | DTC Confirmation Procedure | 412 |
| Overall Function Check | 340 | Overall Function Check | 413 |
| Diagnostic Procedure | 341 | Wiring Diagram | 414 |
| DTC P0420 THREE WAY CATALYST FUNCTION | 346 | Diagnostic Procedure | 415 |
| On Board Diagnosis Logic..... | 346 | DTC P0505 IDLE AIR CONTROL VALVE (IACV) - | |
| DTC Confirmation Procedure | 346 | AUXILIARY AIR CONTROL (AAC) VALVE | 416 |
| Overall Function Check | 347 | Description | 416 |
| Diagnostic Procedure | 348 | CONSULT-II Reference Value in Data Monitor | |
| DTC P0440 EVAP CONTROL SYSTEM (SMALL | | Mode | 417 |
| LEAK) (NEGATIVE PRESSURE) | 351 | ECM Terminals and Reference Value | 417 |
| On Board Diagnosis Logic..... | 351 | On Board Diagnosis Logic..... | 417 |
| DTC Confirmation Procedure | 352 | DTC Confirmation Procedure | 418 |
| Diagnostic Procedure | 354 | Wiring Diagram | 419 |
| DTC P0443 EVAP CANISTER PURGE VOLUME | | Diagnostic Procedure | 420 |
| CONTROL SOLENOID VALVE (CIRCUIT) | 367 | DTC P0510 CLOSED THROTTLE POSITION | |
| Description | 367 | SWITCH | 422 |
| CONSULT-II Reference Value in Data Monitor | | Component Description | 422 |
| Mode | 367 | ECM Terminals and Reference Value | 422 |
| ECM Terminals and Reference Value | 368 | On Board Diagnosis Logic..... | 422 |
| On Board Diagnosis Logic..... | 368 | DTC Confirmation Procedure | 423 |
| DTC Confirmation Procedure | 369 | Overall Function Check | 423 |
| Wiring Diagram | 370 | Wiring Diagram | 424 |
| Diagnostic Procedure | 371 | Diagnostic Procedure | 425 |
| DTC P0446 EVAPORATIVE EMISSION (EVAP) | | DTC P0605 ECM | 429 |
| CANISTER VENT CONTROL VALVE (CIRCUIT) | 375 | Component Description | 429 |
| Component Description | 375 | On Board Diagnosis Logic..... | 429 |
| CONSULT-II Reference Value in Data Monitor | | DTC Confirmation Procedure | 429 |
| Mode | 375 | Diagnostic Procedure | 430 |
| ECM Terminals and Reference Value | 375 | DTC P1105 MAP/BARO SWITCH SOLENOID | |
| On Board Diagnosis Logic..... | 375 | VALVE | 431 |
| DTC Confirmation Procedure | 376 | Description | 431 |
| Wiring Diagram | 377 | CONSULT-II Reference Value in Data Monitor | |
| Diagnostic Procedure | 378 | Mode | 431 |
| DTC P0450 EVAPORATIVE EMISSION (EVAP) | | ECM Terminals and Reference Value | 432 |
| CONTROL SYSTEM PRESSURE SENSOR | 383 | On Board Diagnosis Logic..... | 432 |
| Component Description | 383 | DTC Confirmation Procedure | 432 |
| CONSULT-II Reference Value in Data Monitor | | Wiring Diagram | 434 |
| Mode | 383 | Diagnostic Procedure | 435 |
| ECM Terminals and Reference Value | 383 | DTC P1148 CLOSED LOOP CONTROL | 447 |
| On Board Diagnosis Logic..... | 384 | On Board Diagnosis Logic..... | 447 |
| DTC Confirmation Procedure | 385 | DTC Confirmation Procedure | 447 |
| Wiring Diagram | 386 | Overall Function Check | 448 |
| Diagnostic Procedure | 387 | Diagnostic Procedure | 448 |
| DTC P0455 EVAP CONTROL SYSTEM (GROSS | | DTC P1320 IGNITION SIGNAL | 449 |
| LEAK) | 398 | Component Description | 449 |

CONTENTS (Cont'd)

| | | |
|---|-----|----|
| CONSULT-II Reference Value in Data Monitor Mode | 449 | |
| ECM Terminals and Reference Value | 449 | |
| On Board Diagnosis Logic..... | 450 | |
| DTC Confirmation Procedure | 450 | |
| Wiring Diagram | 451 | |
| Diagnostic Procedure | 452 | |
| DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG) | 457 | |
| Component Description | 457 | |
| ECM Terminals and Reference Value | 457 | |
| On Board Diagnosis Logic..... | 457 | |
| DTC Confirmation Procedure | 458 | |
| Wiring Diagram | 459 | |
| Diagnostic Procedure | 460 | |
| DTC P1400 EGRC-SOLENOID VALVE | 463 | |
| Component Description | 463 | |
| CONSULT-II Reference Value in Data Monitor Mode | 463 | |
| ECM Terminals and Reference Value | 463 | |
| On Board Diagnosis Logic..... | 463 | |
| DTC Confirmation Procedure | 464 | |
| Overall Function Check | 464 | |
| Wiring Diagram | 465 | |
| Diagnostic Procedure | 466 | |
| DTC P1401 EGR TEMPERATURE SENSOR | 470 | |
| Component Description | 470 | |
| On Board Diagnosis Logic..... | 470 | |
| DTC Confirmation Procedure | 471 | |
| Overall Function Check | 472 | |
| Wiring Diagram | 473 | |
| Diagnostic Procedure | 474 | |
| DTC P1402 EGR FUNCTION (OPEN) | 476 | |
| Description | 476 | |
| On Board Diagnosis Logic..... | 477 | |
| DTC Confirmation Procedure | 477 | |
| Wiring Diagram | 479 | |
| Diagnostic Procedure | 480 | |
| DTC P1440 EVAP CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE) | 485 | |
| On Board Diagnosis Logic..... | 485 | |
| DTC Confirmation Procedure | 486 | |
| Diagnostic Procedure | 486 | |
| DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | 487 | |
| Description | 487 | |
| CONSULT-II Reference Value in Data Monitor Mode | 487 | |
| ECM Terminals and Reference Value | 488 | |
| On Board Diagnosis Logic..... | 488 | |
| DTC Confirmation Procedure | 489 | |
| Wiring Diagram | 490 | |
| Diagnostic Procedure | 491 | GI |
| DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE) | 499 | |
| Component Description | 499 | MA |
| CONSULT-II Reference Value in Data Monitor Mode | 499 | EM |
| ECM Terminals and Reference Value | 499 | |
| On Board Diagnosis Logic..... | 499 | |
| DTC Confirmation Procedure | 500 | LC |
| Diagnostic Procedure | 501 | |
| DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING | 505 | EC |
| System Description..... | 505 | |
| On Board Diagnosis Logic..... | 505 | FE |
| DTC Confirmation Procedure | 506 | |
| Overall Function Check | 506 | CL |
| Diagnostic Procedure | 507 | |
| DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN) | 515 | MT |
| Component Description | 515 | |
| CONSULT-II Reference Value in Data Monitor Mode | 515 | AT |
| ECM Terminals and Reference Value | 515 | |
| On Board Diagnosis Logic..... | 515 | TF |
| DTC Confirmation Procedure | 516 | |
| Overall Function Check | 517 | |
| Diagnostic Procedure | 518 | PD |
| DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) | 523 | AX |
| Description | 523 | |
| CONSULT-II Reference Value in Data Monitor Mode | 523 | SU |
| ECM Terminals and Reference Value | 523 | |
| On Board Diagnosis Logic..... | 524 | |
| DTC Confirmation Procedure | 524 | BR |
| Wiring Diagram | 525 | |
| Diagnostic Procedure | 526 | |
| DTC P1491 VACUUM CUT VALVE BYPASS VALVE | 530 | ST |
| Description | 530 | |
| CONSULT-II Reference Value in Data Monitor Mode | 530 | RS |
| ECM Terminals and Reference Value | 530 | |
| On Board Diagnosis Logic..... | 531 | BT |
| DTC Confirmation Procedure | 531 | |
| Overall Function Check | 532 | HA |
| Wiring Diagram | 533 | |
| Diagnostic Procedure | 534 | |
| DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH | 541 | SC |
| Component Description | 541 | EL |

CONTENTS (Cont'd)

| | | | |
|---|-----|---|-----|
| CONSULT-II Reference Value in Data Monitor Mode | 541 | EGR Temperature Sensor | 579 |
| ECM Terminals and Reference Value | 541 | Fuel Pump | 579 |
| On Board Diagnosis Logic..... | 541 | IACV-AAC Valve | 580 |
| DTC Confirmation Procedure | 542 | Injector | 580 |
| Overall Function Check | 543 | Resistor..... | 580 |
| Wiring Diagram..... | 544 | Throttle Position Sensor | 580 |
| Diagnostic Procedure For M/T Models..... | 545 | Front Heated Oxygen Sensor Heater..... | 580 |
| TROUBLE DIAGNOSIS FOR OVERHEAT | 547 | Calculated Load Value..... | 580 |
| On Board Diagnosis Logic..... | 547 | Intake Air Temperature Sensor..... | 580 |
| Overall Function Check | 547 | Rear Heated Oxygen Sensor Heater | 580 |
| Diagnostic Procedure | 548 | Crankshaft Position Sensor (OBD)..... | 580 |
| Main 11 Causes of Overheating..... | 551 | Fuel Tank Temperature Sensor | 580 |
| INJECTOR | 552 | | |
| Component Description | 552 | VG33E | |
| ECM Terminals and Reference Value | 552 | TROUBLE DIAGNOSIS - INDEX | 581 |
| Wiring Diagram..... | 553 | Alphabetical & P No. Index for DTC | 581 |
| Diagnostic Procedure | 554 | PRECAUTIONS | 587 |
| START SIGNAL | 557 | Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 587 |
| CONSULT-II Reference Value in Data Monitor Mode | 557 | Precautions for On Board Diagnostic (OBD) System of Engine and A/T..... | 587 |
| ECM Terminals and Reference Value | 557 | Engine Fuel & Emission Control System | 588 |
| Wiring Diagram..... | 558 | Precautions..... | 589 |
| Diagnostic Procedure | 559 | Wiring Diagrams and Trouble Diagnosis..... | 590 |
| FUEL PUMP | 561 | PREPARATION | 591 |
| System Description..... | 561 | Special Service Tools | 591 |
| Component Description | 561 | Commercial Service Tools..... | 591 |
| CONSULT-II Reference Value in Data Monitor Mode | 561 | ENGINE AND EMISSION CONTROL OVERALL SYSTEM | 593 |
| ECM Terminals and Reference Value | 561 | Engine Control Component Parts Location..... | 593 |
| Wiring Diagram..... | 562 | Circuit Diagram | 595 |
| Diagnostic Procedure | 563 | System Diagram | 596 |
| POWER STEERING OIL PRESSURE SWITCH | 568 | Vacuum Hose Drawing | 597 |
| Component Description | 568 | System Chart..... | 598 |
| CONSULT-II Reference Value in Data Monitor Mode | 568 | ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION | 599 |
| ECM Terminals and Reference Value | 568 | Multiport Fuel Injection (MFI) System | 599 |
| Wiring Diagram..... | 569 | Distributor Ignition (DI) System | 601 |
| Diagnostic Procedure | 570 | Air Conditioning Cut Control..... | 602 |
| IACV-FICD SOLENOID VALVE | 572 | Fuel Cut Control (at no load & high engine speed)..... | 603 |
| Component Description | 572 | Evaporative Emission System | 603 |
| ECM Terminals and Reference Value | 572 | Positive Crankcase Ventilation | 609 |
| Wiring Diagram..... | 573 | BASIC SERVICE PROCEDURE | 610 |
| Diagnostic Procedure | 574 | Fuel Pressure Release..... | 610 |
| MIL & DATA LINK CONNECTORS | 578 | Fuel Pressure Check..... | 610 |
| Wiring Diagram..... | 578 | Fuel Pressure Regulator Check | 611 |
| SERVICE DATA AND SPECIFICATIONS (SDS) | 579 | Injector | 611 |
| Fuel Pressure Regulator..... | 579 | Fast Idle Cam (FIC)..... | 612 |
| Idle Speed and Ignition Timing..... | 579 | Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment..... | 614 |
| Ignition Coil..... | 579 | | |
| Mass Air Flow Sensor..... | 579 | | |
| Engine Coolant Temperature Sensor | 579 | | |

CONTENTS (Cont'd)

| | | |
|---|-----|----|
| ON BOARD DIAGNOSTIC SYSTEM | | |
| DESCRIPTION | 627 | |
| Introduction | 627 | |
| Two Trip Detection Logic | 627 | |
| Emission-related Diagnostic Information | 628 | |
| Malfunction Indicator Lamp (MIL) | 642 | |
| OBD System Operation Chart | 646 | |
| CONSULT-II | 651 | |
| Generic Scan Tool (GST) | 663 | |
| TROUBLE DIAGNOSIS - INTRODUCTION | 665 | |
| Introduction | 665 | |
| Work Flow | 667 | |
| TROUBLE DIAGNOSIS - BASIC INSPECTION | 669 | |
| Basic Inspection | 669 | |
| TROUBLE DIAGNOSIS - GENERAL | | |
| DESCRIPTION | 686 | |
| DTC Inspection Priority Chart | 686 | |
| Fail-safe Chart | 687 | |
| Symptom Matrix Chart | 688 | |
| CONSULT-II Reference Value in Data Monitor Mode | 692 | |
| Major Sensor Reference Graph in Data Monitor Mode | 694 | |
| ECM Terminals and Reference Value | 697 | |
| TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT | 706 | |
| Description | 706 | |
| Diagnostic Procedure | 706 | |
| TROUBLE DIAGNOSIS FOR POWER SUPPLY | 707 | |
| Main Power Supply and Ground Circuit | 707 | |
| DTC P0100 MASS AIR FLOW SENSOR (MAFS) | 713 | |
| Component Description | 713 | |
| CONSULT-II Reference Value in Data Monitor Mode | 713 | |
| ECM Terminals and Reference Value | 713 | |
| On Board Diagnosis Logic | 713 | |
| DTC Confirmation Procedure | 714 | |
| Overall Function Check | 716 | |
| Wiring Diagram | 717 | |
| Diagnostic Procedure | 718 | |
| DTC P0105 ABSOLUTE PRESSURE SENSOR | 722 | |
| Component Description | 722 | |
| On Board Diagnosis Logic | 722 | |
| DTC Confirmation Procedure | 723 | |
| Overall Function Check | 724 | |
| Wiring Diagram | 725 | |
| Diagnostic Procedure | 726 | |
| DTC P0110 INTAKE AIR TEMPERATURE SENSOR | 734 | |
| Component Description | 734 | |
| On Board Diagnosis Logic | 734 | |
| DTC Confirmation Procedure | 734 | |
| Wiring Diagram | 736 | GI |
| Diagnostic Procedure | 737 | |
| DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT) | 739 | MA |
| Component Description | 739 | |
| On Board Diagnosis Logic | 739 | EM |
| DTC Confirmation Procedure | 740 | |
| Wiring Diagram | 741 | |
| Diagnostic Procedure | 742 | LC |
| DTC P0120 THROTTLE POSITION SENSOR | 744 | |
| Description | 744 | |
| CONSULT-II Reference Value in Data Monitor Mode | 744 | EC |
| ECM Terminals and Reference Value | 745 | |
| On Board Diagnosis Logic | 745 | FE |
| DTC Confirmation Procedure | 746 | |
| Wiring Diagram | 749 | CL |
| Diagnostic Procedure | 750 | |
| DTC P0125 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) | 758 | MT |
| Description | 758 | |
| On Board Diagnosis Logic | 758 | AT |
| DTC Confirmation Procedure | 759 | |
| Wiring Diagram | 760 | |
| Diagnostic Procedure | 761 | TF |
| DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT) | 763 | |
| Component Description | 763 | PD |
| CONSULT-II Reference Value in Data Monitor Mode | 763 | AX |
| ECM Terminals and Reference Value | 763 | |
| On Board Diagnosis Logic | 764 | |
| DTC Confirmation Procedure | 765 | SU |
| Overall Function Check | 766 | |
| Wiring Diagram | 767 | |
| Diagnostic Procedure | 769 | BR |
| DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING) | 772 | ST |
| Component Description | 772 | |
| CONSULT-II Reference Value in Data Monitor Mode | 772 | RS |
| ECM Terminals and Reference Value | 772 | |
| On Board Diagnosis Logic | 773 | |
| DTC Confirmation Procedure | 774 | BT |
| Overall Function Check | 775 | |
| Diagnostic Procedure | 775 | |
| DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING) | 780 | HA |
| Component Description | 780 | |
| CONSULT-II Reference Value in Data Monitor Mode | 780 | SC |
| ECM Terminals and Reference Value | 780 | EL |

CONTENTS (Cont'd)

| | | | |
|--|-----|--|-----|
| On Board Diagnosis Logic..... | 781 | On Board Diagnosis Logic..... | 825 |
| DTC Confirmation Procedure | 782 | DTC Confirmation Procedure | 826 |
| Overall Function Check | 783 | Overall Function Check | 827 |
| Diagnostic Procedure | 783 | Wiring Diagram..... | 828 |
| DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) | | Diagnostic Procedure | 830 |
| FRONT HO2S (RESPONSE MONITORING) | 788 | DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) | |
| Component Description | 788 | REAR HO2S (RESPONSE MONITORING) | 835 |
| CONSULT-II Reference Value in Data Monitor | | Component Description | 835 |
| Mode..... | 788 | CONSULT-II Reference Value in Data Monitor | |
| ECM Terminals and Reference Value | 788 | Mode..... | 835 |
| On Board Diagnosis Logic..... | 789 | ECM Terminals and Reference Value | 835 |
| DTC Confirmation Procedure | 789 | On Board Diagnosis Logic..... | 835 |
| Overall Function Check | 790 | DTC Confirmation Procedure | 836 |
| Wiring Diagram..... | 791 | Overall Function Check | 837 |
| Diagnostic Procedure | 793 | Wiring Diagram..... | 838 |
| DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) | | Diagnostic Procedure | 840 |
| FRONT HO2S (HIGH VOLTAGE) | 801 | DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) | |
| Component Description | 801 | REAR HO2S (HIGH VOLTAGE) | 845 |
| CONSULT-II Reference Value in Data Monitor | | Component Description | 845 |
| Mode..... | 801 | CONSULT-II Reference Value in Data Monitor | |
| ECM Terminals and Reference Value | 801 | Mode..... | 845 |
| On Board Diagnosis Logic..... | 802 | ECM Terminals and Reference Value | 845 |
| DTC Confirmation Procedure | 802 | On Board Diagnosis Logic..... | 845 |
| Wiring Diagram..... | 803 | DTC Confirmation Procedure | 846 |
| Diagnostic Procedure | 805 | Overall Function Check | 846 |
| DTC P0135 (RIGHT, -B1), P0155 (LEFT, -B2) | | Wiring Diagram..... | 847 |
| FRONT HO2S HEATER | 809 | Diagnostic Procedure | 849 |
| Description..... | 809 | DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) | |
| CONSULT-II Reference Value in Data Monitor | | REAR HO2S HEATER | 853 |
| Mode..... | 809 | Description..... | 853 |
| ECM Terminals and Reference Value | 809 | CONSULT-II Reference Value in Data Monitor | |
| On Board Diagnosis Logic..... | 809 | Mode..... | 853 |
| DTC Confirmation Procedure | 810 | ECM Terminals and Reference Value | 853 |
| Wiring Diagram..... | 811 | On Board Diagnosis Logic..... | 853 |
| Diagnostic Procedure | 813 | DTC Confirmation Procedure | 854 |
| DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) | | Wiring Diagram..... | 855 |
| REAR HO2S (MIN. VOLTAGE MONITORING) | 815 | Diagnostic Procedure | 857 |
| Component Description | 815 | DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) | |
| CONSULT-II Reference Value in Data Monitor | | FUEL INJECTION SYSTEM FUNCTION (LEAN) | 860 |
| Mode..... | 815 | On Board Diagnosis Logic..... | 860 |
| ECM Terminals and Reference Value | 815 | DTC Confirmation Procedure | 861 |
| On Board Diagnosis Logic..... | 815 | Wiring Diagram..... | 862 |
| DTC Confirmation Procedure | 816 | Diagnostic Procedure | 864 |
| Overall Function Check | 817 | DTC P0172 (RIGHT, -B1), P0175 (LEFT, -B2) | |
| Wiring Diagram..... | 818 | FUEL INJECTION SYSTEM FUNCTION (RICH) | 868 |
| Diagnostic Procedure | 820 | On Board Diagnosis Logic..... | 868 |
| DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) | | DTC Confirmation Procedure | 869 |
| REAR HO2S (MAX. VOLTAGE MONITORING) | 825 | Wiring Diagram..... | 870 |
| Component Description | 825 | Diagnostic Procedure | 872 |
| CONSULT-II Reference Value in Data Monitor | | DTC P0180 FUEL TANK TEMPERATURE | |
| Mode..... | 825 | SENSOR | 875 |
| ECM Terminals and Reference Value | 825 | Component Description | 875 |

CONTENTS (Cont'd)

| | | |
|--|-----|----|
| On Board Diagnosis Logic..... | 875 | |
| DTC Confirmation Procedure | 876 | |
| Wiring Diagram | 877 | |
| Diagnostic Procedure | 878 | |
| DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION | 880 | |
| On Board Diagnosis Logic..... | 880 | |
| Overall Function Check | 881 | |
| Wiring Diagram | 884 | |
| Diagnostic Procedure | 885 | |
| Main 12 Causes of Overheating..... | 892 | |
| DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE | 893 | |
| On Board Diagnosis Logic..... | 893 | |
| DTC Confirmation Procedure | 894 | |
| Diagnostic Procedure | 894 | |
| DTC P0325 KNOCK SENSOR (KS) | 902 | |
| Component Description | 902 | |
| ECM Terminals and Reference Value | 902 | |
| On Board Diagnosis Logic..... | 902 | |
| DTC Confirmation Procedure | 902 | |
| Wiring Diagram | 903 | |
| Diagnostic Procedure | 904 | |
| DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) | 906 | |
| Component Description | 906 | |
| ECM Terminals and Reference Value | 906 | |
| On Board Diagnosis Logic..... | 907 | |
| DTC Confirmation Procedure | 907 | |
| Wiring Diagram | 908 | |
| Diagnostic Procedure | 909 | |
| DTC P0340 CAMSHAFT POSITION SENSOR (CMPS) | 912 | |
| Component Description | 912 | |
| ECM Terminals and Reference Value | 912 | |
| On Board Diagnosis Logic..... | 913 | |
| DTC Confirmation Procedure | 914 | |
| Wiring Diagram | 915 | |
| Diagnostic Procedure | 916 | |
| DTC P0400 EGR FUNCTION (CLOSE) | 919 | |
| Description (If Equipped with EGR Valve) | 919 | |
| On Board Diagnosis Logic..... | 920 | |
| DTC Confirmation Procedure | 921 | |
| Overall Function Check | 922 | |
| Wiring Diagram | 923 | |
| Diagnostic Procedure | 924 | |
| DTC P0402 EGRC-BPT VALVE FUNCTION | 933 | |
| Description (If Equipped with EGR Valve) | 933 | |
| On Board Diagnosis Logic..... | 933 | |
| DTC Confirmation Procedure | 934 | |
| Overall Function Check | 935 | |
| Diagnostic Procedure | 935 | |
| DTC P0420 (RIGHT BANK, -B1), P0430 (LEFT BANK, -B2) THREE WAY CATALYST FUNCTION | 941 | GI |
| On Board Diagnosis Logic..... | 941 | |
| DTC Confirmation Procedure | 942 | MA |
| Overall Function Check | 943 | |
| Diagnostic Procedure | 944 | EM |
| DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE) | 947 | |
| On Board Diagnosis Logic..... | 947 | LC |
| DTC Confirmation Procedure | 948 | |
| Diagnostic Procedure | 949 | |
| DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT) | 950 | EC |
| Description | 950 | |
| CONSULT-II Reference Value in Data Monitor Mode | 950 | FE |
| ECM Terminals and Reference Value | 951 | CL |
| On Board Diagnosis Logic..... | 952 | |
| DTC Confirmation Procedure | 952 | |
| Wiring Diagram | 953 | MT |
| Diagnostic Procedure | 954 | |
| DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT) | 957 | AT |
| Component Description | 957 | |
| CONSULT-II Reference Value in Data Monitor Mode | 957 | TF |
| ECM Terminals and Reference Value | 957 | |
| On Board Diagnosis Logic..... | 958 | PD |
| DTC Confirmation Procedure | 958 | |
| Wiring Diagram | 959 | AX |
| Diagnostic Procedure | 960 | |
| DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR | 963 | SU |
| Component Description | 963 | |
| CONSULT-II Reference Value in Data Monitor Mode | 963 | BR |
| ECM Terminals and Reference Value | 963 | |
| On Board Diagnosis Logic..... | 964 | ST |
| DTC Confirmation Procedure | 964 | |
| Wiring Diagram | 965 | |
| Diagnostic Procedure | 966 | RS |
| DTC P0455 EVAP CONTROL SYSTEM (GROSS LEAK) | 974 | |
| On Board Diagnosis Logic..... | 974 | BT |
| DTC Confirmation Procedure | 975 | |
| Diagnostic Procedure | 976 | |
| DTC P0500 VEHICLE SPEED SENSOR (VSS) | 988 | HA |
| Component Description | 988 | |
| ECM Terminals and Reference Value | 988 | SC |
| On Board Diagnosis Logic..... | 988 | |
| DTC Confirmation Procedure | 988 | |
| Overall Function Check | 989 | EL |

CONTENTS (Cont'd)

| | | | |
|--|------|--|------|
| Wiring Diagram | 990 | DTC P1320 IGNITION SIGNAL | 1028 |
| Diagnostic Procedure | 991 | Component Description | 1028 |
| DTC P0505 IDLE AIR CONTROL VALVE (IACV) - | | ECM Terminals and Reference Value | 1028 |
| AUXILIARY AIR CONTROL (AAC) VALVE | 992 | On Board Diagnosis Logic..... | 1029 |
| Description | 992 | DTC Confirmation Procedure | 1029 |
| CONSULT-II Reference Value in Data Monitor | | Wiring Diagram | 1030 |
| Mode | 993 | Diagnostic Procedure | 1031 |
| ECM Terminals and Reference Value | 993 | DTC P1336 CRANKSHAFT POSITION SENSOR | |
| On Board Diagnosis Logic..... | 993 | (CKPS) (OBD) (COG) | 1036 |
| DTC Confirmation Procedure | 993 | Component Description | 1036 |
| Wiring Diagram | 995 | ECM Terminals and Reference Value | 1036 |
| Diagnostic Procedure | 996 | On Board Diagnosis Logic..... | 1037 |
| DTC P0510 CLOSED THROTTLE POSITION | | DTC Confirmation Procedure | 1037 |
| SWITCH | 998 | Wiring Diagram | 1038 |
| Component Description | 998 | Diagnostic Procedure | 1039 |
| CONSULT-II Reference Value in Data Monitor | | DTC P1400 EGRC-SOLENOID VALVE | 1043 |
| Mode | 998 | Component Description (If Equipped with EGR | |
| ECM Terminals and Reference Value | 998 | Valve) | 1043 |
| On Board Diagnosis Logic..... | 998 | CONSULT-II Reference Value in Data Monitor | |
| DTC Confirmation Procedure | 999 | Mode | 1043 |
| Overall Function Check | 999 | ECM Terminals and Reference Value | 1043 |
| Wiring Diagram | 1000 | On Board Diagnosis Logic..... | 1044 |
| Diagnostic Procedure | 1001 | DTC Confirmation Procedure | 1044 |
| DTC P0600 A/T CONTROL | 1006 | Wiring Diagram | 1045 |
| System Description..... | 1006 | Diagnostic Procedure | 1046 |
| ECM Terminals and Reference Value | 1006 | DTC P1401 EGR TEMPERATURE SENSOR | 1048 |
| On Board Diagnosis Logic..... | 1006 | Component Description (If Equipped with EGR | |
| DTC Confirmation Procedure | 1007 | Valve) | 1048 |
| Overall Function Check | 1007 | On Board Diagnosis Logic..... | 1048 |
| Wiring Diagram | 1008 | DTC Confirmation Procedure | 1049 |
| Diagnostic Procedure | 1009 | Overall Function Check | 1050 |
| DTC P0605 ECM | 1011 | Wiring Diagram | 1051 |
| Component Description | 1011 | Diagnostic Procedure | 1052 |
| On Board Diagnosis Logic..... | 1011 | DTC P1402 EGR FUNCTION (OPEN) | 1055 |
| DTC Confirmation Procedure | 1011 | Description (If Equipped with EGR Valve) | 1055 |
| Diagnostic Procedure | 1012 | On Board Diagnosis Logic..... | 1056 |
| DTC P1105 MAP/BARO SWITCH SOLENOID | | DTC Confirmation Procedure | 1056 |
| VALVE | 1013 | Wiring Diagram | 1058 |
| Description | 1013 | Diagnostic Procedure | 1059 |
| CONSULT-II Reference Value in Data Monitor | | DTC P1440 EVAP CONTROL SYSTEM (SMALL | |
| Mode | 1013 | LEAK) (POSITIVE PRESSURE) | 1065 |
| ECM Terminals and Reference Value | 1014 | On Board Diagnosis Logic..... | 1065 |
| On Board Diagnosis Logic..... | 1014 | DTC Confirmation Procedure | 1066 |
| DTC Confirmation Procedure | 1014 | Diagnostic Procedure | 1066 |
| Wiring Diagram | 1016 | DTC P1444 EVAP CANISTER PURGE VOLUME | |
| Diagnostic Procedure | 1017 | CONTROL SOLENOID VALVE | 1067 |
| DTC P1148 (RIGHT BANK, -B1), P1168 (LEFT | | Description | 1067 |
| BANK, -B2) CLOSED LOOP CONTROL | 1026 | CONSULT-II Reference Value in Data Monitor | |
| On Board Diagnosis Logic..... | 1026 | Mode | 1067 |
| DTC Confirmation Procedure | 1026 | ECM Terminals and Reference Value | 1068 |
| Overall Function Check | 1027 | On Board Diagnosis Logic..... | 1068 |
| Diagnostic Procedure | 1027 | DTC Confirmation Procedure | 1069 |

CONTENTS (Cont'd)

| | | |
|--|------|----|
| Wiring Diagram | 1070 | |
| Diagnostic Procedure | 1071 | |
| DTC P1446 EVAPORATIVE EMISSION (EVAP) | | |
| CANISTER VENT CONTROL VALVE (CLOSE) | 1079 | |
| Component Description | 1079 | |
| CONSULT-II Reference Value in Data Monitor | | |
| Mode | 1079 | |
| ECM Terminals and Reference Value | 1079 | |
| On Board Diagnosis Logic..... | 1080 | |
| DTC Confirmation Procedure | 1080 | |
| Wiring Diagram | 1081 | |
| Diagnostic Procedure | 1082 | |
| DTC P1447 EVAPORATIVE EMISSION (EVAP) | | |
| CONTROL SYSTEM PURGE FLOW | | |
| MONITORING | 1086 | |
| System Description..... | 1086 | |
| On Board Diagnosis Logic..... | 1086 | |
| DTC Confirmation Procedure | 1087 | |
| Overall Function Check | 1088 | |
| Diagnostic Procedure | 1089 | |
| DTC P1448 EVAPORATIVE EMISSION (EVAP) | | |
| CANISTER VENT CONTROL VALVE (OPEN) | 1098 | |
| Component Description | 1098 | |
| CONSULT-II Reference Value in Data Monitor | | |
| Mode | 1098 | |
| ECM Terminals and Reference Value | 1098 | |
| On Board Diagnosis Logic..... | 1098 | |
| DTC Confirmation Procedure | 1099 | |
| Overall Function Check | 1100 | |
| Wiring Diagram | 1101 | |
| Diagnostic Procedure | 1102 | |
| DTC P1490 VACUUM CUT VALVE BYPASS | | |
| VALVE (CIRCUIT) | 1106 | |
| Description | 1106 | |
| CONSULT-II Reference Value in Data Monitor | | |
| Mode | 1106 | |
| ECM Terminals and Reference Value | 1106 | |
| On Board Diagnosis Logic..... | 1107 | |
| DTC Confirmation Procedure | 1107 | |
| Wiring Diagram | 1108 | |
| Diagnostic Procedure | 1109 | |
| DTC P1491 VACUUM CUT VALVE BYPASS | | |
| VALVE | 1112 | |
| Description | 1112 | |
| CONSULT-II Reference Value in Data Monitor | | |
| Mode | 1112 | |
| ECM Terminals and Reference Value | 1112 | |
| On Board Diagnosis Logic..... | 1113 | |
| DTC Confirmation Procedure | 1113 | |
| Overall Function Check | 1114 | |
| Wiring Diagram | 1115 | |
| Diagnostic Procedure | 1116 | |
| DTC P1605 A/T DIAGNOSIS COMMUNICATION | | |
| LINE | 1121 | GI |
| Component Description | 1121 | |
| ECM Terminals and Reference Value | 1121 | MA |
| On Board Diagnosis Logic..... | 1121 | |
| DTC Confirmation Procedure | 1121 | EM |
| Wiring Diagram | 1122 | |
| Diagnostic Procedure | 1123 | |
| DTC P1706 PARK/NEUTRAL POSITION (PNP) | | |
| SWITCH | 1124 | LC |
| Component Description | 1124 | |
| CONSULT-II Reference Value in Data Monitor | | EC |
| Mode | 1124 | |
| ECM Terminals and Reference Value | 1124 | |
| On Board Diagnosis Logic..... | 1124 | FE |
| DTC Confirmation Procedure | 1124 | |
| Overall Function Check | 1125 | CL |
| Wiring Diagram | 1126 | |
| Diagnostic Procedure | 1127 | |
| TROUBLE DIAGNOSIS FOR OVERHEAT | | |
| (COOLING SYSTEM) | 1132 | MT |
| System Description..... | 1132 | |
| CONSULT-II Reference Value in Data Monitor | | AT |
| Mode | 1132 | |
| ECM Terminals and Reference Value | 1132 | TF |
| On Board Diagnosis Logic..... | 1133 | |
| Overall Function Check | 1134 | |
| Wiring Diagram | 1135 | PD |
| Diagnostic Procedure | 1136 | |
| Main 12 Causes of Overheating..... | 1143 | |
| INJECTOR | 1144 | AX |
| Component Description | 1144 | |
| CONSULT-II Reference Value in Data Monitor | | SU |
| Mode | 1144 | |
| ECM Terminals and Reference Value | 1144 | |
| Wiring Diagram | 1145 | BR |
| Diagnostic Procedure | 1146 | |
| START SIGNAL | 1149 | |
| CONSULT-II Reference Value in Data Monitor | | ST |
| Mode | 1149 | |
| ECM Terminals and Reference Value | 1149 | |
| Wiring Diagram | 1150 | RS |
| Diagnostic Procedure | 1151 | |
| FUEL PUMP | 1153 | BT |
| System Description..... | 1153 | |
| Component Description | 1153 | |
| CONSULT-II Reference Value in Data Monitor | | HA |
| Mode | 1153 | |
| ECM Terminals and Reference Value | 1153 | |
| Wiring Diagram | 1154 | SC |
| Diagnostic Procedure | 1155 | |
| POWER STEERING OIL PRESSURE SWITCH | 1159 | EL |

CONTENTS (Cont'd)

| | | | |
|--|------|--|------|
| Component Description | 1159 | Ignition Coil | 1171 |
| CONSULT-II Reference Value in Data Monitor | | Mass Air Flow Sensor..... | 1171 |
| Mode | 1159 | Engine Coolant Temperature Sensor | 1171 |
| ECM Terminals and Reference Value | 1159 | EGR Temperature Sensor (If So Equipped)..... | 1171 |
| Wiring Diagram | 1160 | Front Heated Oxygen Sensor Heater..... | 1171 |
| Diagnostic Procedure | 1161 | Fuel Pump | 1172 |
| IACV-FICD SOLENOID VALVE | 1164 | IACV-AAC Valve | 1172 |
| Component Description | 1164 | Injector | 1172 |
| ECM Terminals and Reference Value | 1164 | Resistor | 1172 |
| Wiring Diagram | 1165 | Throttle Position Sensor | 1172 |
| Diagnostic Procedure | 1166 | Calculated Load Value..... | 1172 |
| MIL & DATA LINK CONNECTORS | 1170 | Intake Air Temperature Sensor..... | 1172 |
| Wiring Diagram | 1170 | Rear Heated Oxygen Sensor Heater | 1172 |
| SERVICE DATA AND SPECIFICATIONS (SDS) | 1171 | Crankshaft Position Sensor (OBD)..... | 1172 |
| Fuel Pressure Regulator..... | 1171 | Fuel Tank Temperature Sensor | 1172 |
| Idle Speed and Ignition Timing..... | 1171 | | |

Alphabetical & P No. Index for DTC

NGEC0001

NGEC0001S01

ALPHABETICAL INDEX FOR DTC

| Items (CONSULT-II screen terms) | DTC*6 | | Reference page |
|------------------------------------|---------------------|-------|----------------|
| | CONSULT-II GST*2 | ECM*1 | |
| Unable to access ECM | — | — | EC-110 |
| *COOLAN T SEN/CIRC | P0125 | 0908 | EC-186 |
| ABSL PRES SEN/CIRC | P0105 | 0803 | EC-146 |
| AIR TEMP SEN/CIRC | P0110 | 0401 | EC-161 |
| CAM POS SEN/CIRC | P0340 | 0101 | EC-318 |
| CLOSED LOOP | P1148 | 0307 | EC-447 |
| CLOSED TP SW/CIRC | P0510 | 0203 | EC-422 |
| COOLANT T SEN/CIRC | P0115 | 0103 | EC-167 |
| CPS/CIRC (OBD) COG | P1336 | 0905 | EC-457 |
| CPS/CIRCUIT (OBD) | P0335 | 0802 | EC-312 |
| CYL 1 MISFIRE | P0301 | 0608 | EC-299 |
| CYL 2 MISFIRE | P0302 | 0607 | EC-299 |
| CYL 3 MISFIRE | P0303 | 0606 | EC-299 |
| CYL 4 MISFIRE | P0304 | 0605 | EC-299 |
| ECM | P0605 | 0301 | EC-429 |
| EGR SYSTEM | P0400 | 0302 | EC-326 |
| EGR SYSTEM | P1402 | 0514 | EC-476 |
| EGR TEMP SEN/CIRC | P1401 | 0305 | EC-470 |
| EGRC SOLENOID/V | P1400 | 1005 | EC-463 |
| EGRC-BPT VALVE | P0402 | 0306 | EC-338 |
| EVAP GROSS LEAK | P0455 | 0715 | EC-398 |
| EVAP PURG FLOW/MON | P1447 | 0111 | EC-505 |
| EVAP SMALL LEAK | P0440 | 0705 | EC-351 |
| EVAP SMALL LEAK | P1440 | 0213 | EC-485 |
| EVAP SYS PRES SEN | P0450 | 0704 | EC-383 |
| FR O2 SEN HEATER | P0135 | 0901 | EC-230 |
| FRONT O2 SENSOR | P0130 | 0303 | EC-190 |
| FRONT O2 SENSOR | P0131 | 0411 | EC-198 |
| FRONT O2 SENSOR | P0132 | 0410 | EC-205 |
| FRONT O2 SENSOR | P0133 | 0409 | EC-212 |
| FRONT O2 SENSOR | P0134 | 0412 | EC-223 |
| FUEL SYS DIAG-LEAN | P0171 | 0115 | EC-278 |
| FUEL SYS DIAG-RICH | P0172 | 0114 | EC-286 |
| FUEL TEMP SEN/CIRC | P0180 | 0402 | EC-293 |

TROUBLE DIAGNOSIS — INDEX

KA24DE

Alphabetical & P No. Index for DTC (Cont'd)

| Items (CONSULT-II screen terms) | DTC*6 | | Reference page |
|---|---------------------|-------------|----------------|
| | CONSULT-II GST*2 | ECM*1 | |
| IACV/AAC VLV/CIRC | P0505 | 0205 | EC-416 |
| IGN SIGNAL-PRIMARY | P1320 | 0201 | EC-449 |
| KNOCK SEN/CIRCUIT | P0325 | 0304 | EC-308 |
| MAF SEN/CIRCUIT*3 | P0100 | 0102 | EC-136 |
| MAP/BARO SW SOL/CIR | P1105 | 1302 | EC-431 |
| MULTI CYL MISFIRE | P0300 | 0701 | EC-299 |
| NO SELF DIAGNOSTIC FAILURE INDICATED | P0000 | 0505 | — |
| NO SELF DIAGNOSTIC FAILURE INDICATED | No DTC | Flashing*5 | EC-70 |
| OVERHEAT | — | 0208 | EC-547 |
| P-N POS SW/CIRCUIT | P1706 | 1003 | EC-541 |
| PURG VOLUME CONT/V | P0443 | 1008 | EC-367 |
| PURG VOLUME CONT/V | P1444 | 0214 | EC-487 |
| REAR O2 SENSOR | P0137 | 0511 | EC-235 |
| REAR O2 SENSOR | P0138 | 0510 | EC-245 |
| REAR O2 SENSOR | P0139 | 0707 | EC-255 |
| REAR O2 SENSOR | P0140 | 0512 | EC-265 |
| RR O2 SEN HEATER | P0141 | 0902 | EC-273 |
| THRTL POS SEN/CIRC*3 | P0120 | 0403 | EC-172 |
| TW CATALYST SYSTEM | P0420 | 0702 | EC-346 |
| VC CUT/V BYPASS/V | P1491 | 0311 | EC-530 |
| VC/V BYPASS/V | P1490 | 0801 | EC-523 |
| VEH SPEED SEN/CIRC*4 | P0500 | 0104 | EC-412 |
| VENT CONTROL VALVE | P0446 | 0903 | EC-375 |
| VENT CONTROL VALVE | P1446 | 0215 | EC-499 |
| VENT CONTROL VALVE | P1448 | 0309 | EC-515 |

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: The MIL illuminates when the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

*5: While engine is running.

*6: 1st trip DTC No. is the same as DTC No.

P NO. INDEX FOR DTC

NGEC0001S02

| DTC*6 | | Items (CONSULT-II screen terms) | Reference page |
|---------------------|-------------|---|----------------|
| CONSULT-II GST*2 | ECM*1 | | |
| — | — | Unable to access ECM | EC-110 |
| No DTC | Flashing*5 | NO SELF DIAGNOSTIC FAILURE INDICATED | EC-70 |
| P0000 | 0505 | NO SELF DIAGNOSTIC FAILURE INDICATED | — |

TROUBLE DIAGNOSIS — INDEX

KA24DE

Alphabetical & P No. Index for DTC (Cont'd)

| DTC*6 | | Items (CONSULT-II screen terms) | Reference page | |
|---------------------|-------|------------------------------------|----------------|-----------|
| CONSULT-II GST*2 | ECM*1 | | | |
| P0100 | 0102 | MAF SEN/CIRCUIT*3 | EC-136 | GI |
| P0105 | 0803 | ABSL PRES SEN/CIRC | EC-146 | MA |
| P0110 | 0401 | AIR TEMP SEN/CIRC | EC-161 | EM |
| P0115 | 0103 | COOLANT T SEN/CIRC | EC-167 | |
| P0120 | 0403 | THRTL POS SEN/CIRC*3 | EC-172 | LC |
| P0125 | 0908 | *COOLAN T SEN/CIRC | EC-186 | |
| P0130 | 0303 | FRONT O2 SENSOR | EC-190 | EC |
| P0131 | 0411 | FRONT O2 SENSOR | EC-198 | |
| P0132 | 0410 | FRONT O2 SENSOR | EC-205 | FE |
| P0133 | 0409 | FRONT O2 SENSOR | EC-212 | |
| P0134 | 0412 | FRONT O2 SENSOR | EC-223 | CL |
| P0135 | 0901 | FR O2 SEN HEATER | EC-230 | |
| P0137 | 0511 | REAR O2 SENSOR | EC-235 | MT |
| P0138 | 0510 | REAR O2 SENSOR | EC-245 | |
| P0139 | 0707 | REAR O2 SENSOR | EC-255 | AT |
| P0140 | 0512 | REAR O2 SENSOR | EC-265 | |
| P0141 | 0902 | RR O2 SEN HEATER | EC-273 | TF |
| P0171 | 0115 | FUEL SYS DIAG-LEAN | EC-278 | |
| P0172 | 0114 | FUEL SYS DIAG-RICH | EC-286 | PD |
| P0180 | 0402 | FUEL TEMP SEN/CIRC | EC-293 | AX |
| P0300 | 0701 | MULTI CYL MISFIRE | EC-299 | |
| P0301 | 0608 | CYL 1 MISFIRE | EC-299 | SU |
| P0302 | 0607 | CYL 2 MISFIRE | EC-299 | |
| P0303 | 0606 | CYL 3 MISFIRE | EC-299 | BR |
| P0304 | 0605 | CYL 4 MISFIRE | EC-299 | |
| P0325 | 0304 | KNOCK SEN/CIRCUIT | EC-308 | ST |
| P0335 | 0802 | CPS/CIRCUIT (OBD) | EC-312 | |
| P0340 | 0101 | CAM POS SEN/CIRC | EC-318 | RS |
| P0400 | 0302 | EGR SYSTEM | EC-326 | |
| P0402 | 0306 | EGRC-BPT VALVE | EC-338 | BT |
| P0420 | 0702 | TW CATALYST SYSTEM | EC-346 | |
| P0440 | 0705 | EVAP SMALL LEAK | EC-351 | HA |
| P0443 | 1008 | PURG VOLUME CONT/V | EC-367 | |
| P0446 | 0903 | VENT CONTROL VALVE | EC-375 | SC |
| P0450 | 0704 | EVAP SYS PRES SEN | EC-383 | |
| P0455 | 0715 | EVAP GROSS LEAK | EC-398 | EL |

TROUBLE DIAGNOSIS — INDEX

KA24DE

Alphabetical & P No. Index for DTC (Cont'd)

| DTC*6 | | Items (CONSULT-II screen terms) | Reference page |
|---------------------|-------|------------------------------------|----------------|
| CONSULT-II GST*2 | ECM*1 | | |
| P0500 | 0104 | VEH SPEED SEN/CIRC*4 | EC-412 |
| P0505 | 0205 | IACV/AAC VLV/CIRC | EC-416 |
| P0510 | 0203 | CLOSED TP SW/CIRC | EC-422 |
| P0605 | 0301 | ECM | EC-429 |
| P1105 | 1302 | MAP/BARO SW SOL/CIR | EC-431 |
| P1148 | 0307 | CLOSED LOOP | EC-447 |
| P1320 | 0201 | IGN SIGNAL-PRIMARY | EC-449 |
| P1336 | 0905 | CPS/CIRC (OBD) COG | EC-457 |
| P1400 | 1005 | EGRC SOLENOID/V | EC-463 |
| P1401 | 0305 | EGR TEMP SEN/CIRC | EC-470 |
| P1402 | 0514 | EGR SYSTEM | EC-476 |
| P1440 | 0213 | EVAP SMALL LEAK | EC-485 |
| P1444 | 0214 | PURG VOLUME CONT/V | EC-487 |
| P1446 | 0215 | VENT CONTROL VALVE | EC-499 |
| P1447 | 0111 | EVAP PURG FLOW/MON | EC-505 |
| P1448 | 0309 | VENT CONTROL VALVE | EC-515 |
| P1490 | 0801 | VC/V BYPASS/V | EC-523 |
| P1491 | 0311 | VC CUT/V BYPASS/V | EC-530 |
| P1706 | 1003 | P-N POS SW/CIRCUIT | EC-541 |
| — | 0208 | OVERHEAT | EC-547 |

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: The MIL illuminates when the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

*5: While engine is running.

*6: 1st trip DTC No. is the same as DTC No.

PRECAUTIONS

KA24DE

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NGEC0002

The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

In addition to the supplemental air bag modules for a frontal collision, the supplemental side air bag used along with the seat belt helps to reduce the risk or severity of injury to the driver and front passenger in a side collision. The supplemental side air bag consists of air bag modules (located in the outer side of front seats), satellite sensor, diagnosis sensor unit (one of components of supplemental air bags for a frontal collision), wiring harness, warning lamp (one of components of supplemental air bags for a frontal collision). Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses (except "SEAT BELT PRE-TENSIONER" connector) can be identified with yellow harness connector (and with yellow harness protector or yellow insulation tape before the harness connectors).

Precautions for On Board Diagnostic (OBD) System of Engine and A/T

NGEC0003

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to "Description", "HARNESS CONNECTOR", *EL-5*.
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission Control Module) before returning the vehicle to the customer.

Engine Fuel & Emission Control System


NGEC0004

ECM

- Do not disassemble ECM.
- Do not turn on board diagnostic test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value.
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
 - 1) Keep the antenna as far away as possible from the electronic control units.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls.
Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

ECM PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor or crankshaft position sensor (OBD).





FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque. (Refer to MA section.)

ECM HARNESS HANDLING

- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in.) away from adjacent harnesses to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.






Precautions

NGEC0005

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.
 - : 3 - 5 N·m (0.3 - 0.5 kg·m, 26 - 43 in·lb)
- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminals when connecting pin connectors.
- Before replacing ECM, perform Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-120.
- After performing each TROUBLE DIAGNOSIS, perform "Overall Function Check" or "DTC Confirmation Procedure". The DTC should not be displayed in the "DTC Confirmation Procedure" if the repair is completed. The "Overall Function Check" should be a good result if the repair is completed.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Precautions (Cont'd)



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.

Wiring Diagrams and Trouble Diagnosis

NGEC0006

When you read Wiring diagrams, refer to the followings:

- “HOW TO READ WIRING DIAGRAMS”, **GI-10**.
- “POWER SUPPLY ROUTING”, **EL-9**.

When you perform trouble diagnosis, refer to the followings:

- “HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSIS” in **GI-34**.
- “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT”, **GI-23**

PREPARATION



KA24DE

Special Service Tools

Special Service Tools




NGEC0007

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description | | GI |
|--|---|---|----|
| KV10117100 (J36471-A) Heated oxygen sensor wrench |  | Loosening or tightening front heated oxygen sensor with 22 mm (0.87 in) hexagon nut | MA |
| KV10114400 (J-38365) Heated oxygen sensor wrench |  | Loosening or tightening rear heated oxygen sensor a: 22 mm (0.87 in) | EM |
| | NT379 | | LC |
| | NT636 | | EC |

Commercial Service Tools

NGEC0008

| Tool name | Description | | AT |
|---|---|---|----|
| Fuel filler cap adapter |  | Checking fuel tank vacuum relief valve opening pressure | TF |
| | NT653 | | PD |
| Leak detector (J41416) |  | Locating the EVAP leak | AX |
| | NT703 | | SU |
| EVAP service port adapter (J41413-OBID) |  | Applying positive pressure through EVAP service port | BR |
| | NT704 | | ST |
| | | | RS |
| | | | BT |
| | | | HA |
| | | | SC |

PREPARATION




KA24DE

Commercial Service Tools (Cont'd)



| Tool name | Description |
|---|--|
| Hose clipper (—) | <div data-bbox="527 226 820 451" data-label="Image"> <p>Approx. 20 mm (0.79 in)</p> </div> <p data-bbox="409 472 470 493">NT720</p> <p data-bbox="950 220 1482 336">Clamping the EVAP purge hose between the fuel tank and EVAP canister applied to DTC P1440 [EVAP control system (Small leak — Positive pressure)]</p> |
| Socket wrench | <div data-bbox="527 514 812 745" data-label="Image"> <p>19 mm (0.75 in)</p> <p>More than 32 mm (1.26 in)</p> </div> <p data-bbox="409 751 470 772">NT705</p> <p data-bbox="950 504 1482 556">Removing and installing engine coolant temperature sensor</p> |
| Oxygen sensor thread cleaner (J-43897-18) (J-43897-12) | <div data-bbox="560 798 787 1060" data-label="Image"> <p>a</p> <p>b</p> <p>Mating surface shave cylinder</p> <p>Flutes</p> </div> <p data-bbox="409 1066 483 1087">AEM488</p> <p data-bbox="950 787 1482 871">Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown in "Commercial Service tools".</p> <p data-bbox="950 871 1482 924">a: J-43897-18 18 mm diameter, for Zirconia Oxygen Sensor</p> <p data-bbox="950 924 1482 976">b: J-43897-12 12 mm diameter, for Titania Oxygen Sensor</p> |
| Anti-seize lubricant (Permatex [®] 133AR or equivalent meeting MIL specification MIL-A-907) | <div data-bbox="592 1123 755 1344" data-label="Image"> </div> <p data-bbox="409 1375 483 1396">AEM489</p> <p data-bbox="950 1102 1482 1155">Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p> |

Engine Control Component Parts Location

NGEC0009





Driver side



- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX


SEF312V



AEC041B

Circuit Diagram


NGEC0010



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

System Diagram

NGEC0011




Vacuum Hose Drawing

NGEC0012

Refer to "System Diagram" on EC-26 for vacuum control system.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



System Chart

NGEC0013

| Input (Sensor) | ECM Function | Output (Actuator) |
|---|---|---|
| <ul style="list-style-type: none"> ● Camshaft position sensor ● Mass air flow sensor ● Engine coolant temperature sensor ● Front heated oxygen sensor ● Ignition switch ● Throttle position sensor ● PNP switch ● Air conditioner switch ● Knock sensor ● EGR temperature sensor*1 ● Crankshaft position sensor (OBD) ● EVAP control system pressure sensor*1 ● Fuel tank temperature sensor ● Battery voltage ● Power steering oil pressure switch ● Vehicle speed sensor ● Intake air temperature sensor ● Absolute pressure sensor ● Rear heated oxygen sensor*2 ● Closed throttle position switch*3 | Fuel injection & mixture ratio control | Injectors |
| | Distributor ignition system | Power transistor |
| | Idle air control system | IACV-AAC valve and IACV-FICD solenoid valve |
| | Fuel pump control | Fuel pump relay |
| | Front heated oxygen sensor monitor & on board diagnostic system | Malfunction indicator lamp (On the instrument panel) |
| | EGR control | EGRC-solenoid valve |
| | Front and rear heated oxygen sensor heater control | Heated oxygen sensor heater |
| | EVAP canister purge flow control | <ul style="list-style-type: none"> ● EVAP canister purge volume control valve ● EVAP canister purge control solenoid valve |
| | Air conditioning cut control | Air conditioner relay |
| | ON BOARD DIAGNOSIS for EVAP system | <ul style="list-style-type: none"> ● EVAP canister vent control valve ● Vacuum cut valve bypass valve ● MAP/BARO switch solenoid valve |

*1: These sensors are not used to control the engine system. They are used only for the on board diagnosis.

*2: Under normal conditions, this sensor is not for engine control operation.

*3: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

KA24DE

Multiport Fuel Injection (MFI) System

Multiport Fuel Injection (MFI) System

DESCRIPTION

Input/Output Signal Chart

NGEC0014

GI

NGEC0014S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|---|--|----------|
| Camshaft position sensor | Engine speed and piston position | Fuel injection & mixture ratio control | Injector |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Front heated oxygen sensor | Density of oxygen in exhaust gas | | |
| Throttle position sensor | Throttle position Throttle valve idle position | | |
| PNP switch | Gear position | | |
| Vehicle speed sensor | Vehicle speed | | |
| Ignition switch | Start signal | | |
| Air conditioner switch | Air conditioner operation | | |
| Knock sensor | Engine knocking condition | | |
| Absolute pressure sensor | Ambient barometric pressure | | |
| Battery | Battery voltage | | |
| Power steering oil pressure switch | Power steering operation | | |
| Rear heated oxygen sensor* | Density of oxygen in exhaust gas | | |

MA

EM

LC

EC

FE

CL

MT

AT

TF

* Under normal conditions, this sensor is not for engine control operation.

Basic Multiport Fuel Injection System

NGEC0014S02

PD

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

AX

Various Fuel Injection Increase/Decrease Compensation

NGEC0014S03

SU

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- High-load, high-speed operation

BR

ST

RS

<Fuel decrease>

- During deceleration
- During high engine speed operation

BT

HA


SC

EL

IDX

Mixture Ratio Feedback Control (Closed loop control)

NGEC0014S04



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a front heated oxygen sensor in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the front heated oxygen sensor, refer to EC-190. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Rear heated oxygen sensor is located downstream of the three way catalyst. Even if the switching characteristics of the front heated oxygen sensor shift, the air-fuel ratio is controlled to stoichiometric by the signal from the rear heated oxygen sensor.

Open Loop Control

NGEC0014S05

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of front heated oxygen sensor or its circuit
- Insufficient activation of front heated oxygen sensor at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- When starting the engine

Mixture Ratio Self-learning Control

NGEC0014S06

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the front heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the front heated oxygen sensor indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.


ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

KA24DE

Multiport Fuel Injection (MFI) System (Cont'd)

Fuel Injection Timing

NGEC0014S07



SEF337W

Two types of systems are used.

Sequential Multiport Fuel Injection System

NGEC0014S0701

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

NGEC0014S0702

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

Fuel Shut-off

NGEC0014S08

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Distributor Ignition (DI) System

DESCRIPTION


Input/Output Signal Chart

NGEC0015

NGEC0015S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|---|-------------------------|------------------|
| Camshaft position sensor | Engine speed and piston position | Ignition timing control | Power transistor |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Throttle position sensor | Throttle position Throttle valve idle position | | |
| Vehicle speed sensor | Vehicle speed | | |
| Ignition switch | Start signal | | |
| Knock sensor | Engine knocking | | |
| PNP switch | Gear position | | |
| Battery | Battery voltage | | |

System Description

NGEC0015S02


The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown above.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec

A°BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions.

If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

KA24DE

Air Conditioning Cut Control

Air Conditioning Cut Control

DESCRIPTION

Input/Output Signal Chart

=NGEC0016

NGEC0016S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|------------------------------|-----------------------------|-----------------------|
| Air conditioner switch | Air conditioner "ON" signal | Air conditioner cut control | Air conditioner relay |
| Throttle position sensor | Throttle valve opening angle | | |
| Camshaft position sensor | Engine speed | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Vehicle speed sensor | Vehicle speed | | |
| Power steering oil pressure switch | Power steering operation | | |

System Description

NGEC0016S02

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- When the engine coolant temperature becomes excessively high.
- When operating power steering and air conditioner during low engine speed or when fully releasing accelerator pedal.
- When engine speed is excessively low.

Fuel Cut Control (at no load & high engine speed)

DESCRIPTION

Input/Output Signal Chart

NGEC0017

NGEC0017S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|------------------|-----------|
| Vehicle speed sensor | Vehicle speed | Fuel cut control | Injectors |
| PNP switch | Neutral position | | |
| Throttle position sensor | Throttle position | | |
| Camshaft position sensor | Engine speed | | |

If the engine speed is above 3,000 rpm with no load, (for example, in Neutral and engine speed over 3,000 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.


NOTE:

This function is different from deceleration control listed under "Multiport Fuel Injection (MFI) System", EC-29.

Evaporative Emission System

DESCRIPTION

=NGEC0018




SEF927U

The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating.

EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.



SEF314V


INSPECTION EVAP Canister

NGEC0019

NGEC0019S01

Check EVAP canister as follows:

1. Pinch the fresh air hose.
2. Blow air into port A and check that air flows freely through port B.



AEC879A

Tightening Torque

NGEC0019S02


Tighten EVAP canister as shown in the figure.

Make sure new O-ring is installed properly between EVAP canister and EVAP canister vent control valve.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

KA24DE

Evaporative Emission System (Cont'd)



Fuel Tank Vacuum Relief Valve (Built into fuel filler cap)

NGEC0019S03

1. Wipe clean valve housing.
2. Check valve opening pressure and vacuum.

Pressure:

16.0 - 20.0 kPa (0.163 - 0.204 kg/cm², 2.32 - 2.90 psi)


Vacuum:

-6.0 to -3.5 kPa (-0.061 to -0.036 kg/cm², -0.87 to -0.51 psi)

3. If out of specification, replace fuel filler cap as an assembly.

CAUTION:

Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.



Vacuum Cut Valve and Vacuum Cut Valve Bypass Valve

NGEC0019S05

Refer to EC-530.

Evaporative Emission (EVAP) Canister Purge Volume Control Solenoid Valve


NGEC0019S06

Refer to EC-487.

Tank Fuel Temperature Sensor

NGEC0019S08

Refer to EC-293.



EVAP Service Port

NGEC0019S09

Positive pressure is delivered to the EVAP system through the EVAP service port. If fuel vapor leakage in the EVAP system occurs, use a leak detector to locate the leak.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

KA24DE

Evaporative Emission System (Cont'd)

EVAP SYSTEM CLOSE
APPLY PRESSURE TO EVAP SYSTEM FROM SERVICE PORT USING HAND PUMP WITH PRESSURE GAUGE AT NEXT SCREEN. NEVER USE COMPRESSED AIR OR HIGH PRESSURE PUMP! DO NOT START ENGINE. TOUCH START.

PEF658U



How to Detect Fuel Vapor Leakage

NGEC0019S10

CAUTION:

- Never use compressed air or a high pressure pump.
- Do not start engine.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in EVAP system.

NOTE:

Improper installation of adapter to the service port may cause a leak.

With CONSULT-II

- 1) Attach the EVAP service port adapter securely to the EVAP service port.
- 2) Also attach the pressure pump and hose.
- 3) Turn ignition switch "ON".
- 4) Select the "EVAP SYSTEM CLOSE" of "WORK SUPPORT MODE" with CONSULT-II.
- 5) Touch "START". A bar graph (Pressure indicating display) will appear on the screen.
- 6) Apply positive pressure to the EVAP system until the pressure indicator reaches the middle of the bar graph.
- 7) Remove the EVAP service port adapter and hose with pressure pump.
- 8) Locate the leak using a leak detector. Refer to "Evaporative Emission Line Drawing", EC-36.

Without CONSULT-II

- 1) Attach the EVAP service port adapter securely to the EVAP service port and pressure pump with pressure gauge to the EVAP service port.
- 2) Apply battery voltage to between the terminals of both EVAP canister vent control valve and vacuum cut valve bypass valve to make a closed EVAP system.
- 3) To locate the leak, deliver positive pressure to the EVAP system until pressure gauge points reach 1.38 to 2.76 kPa (0.014 to 0.028 kg/cm², 0.2 to 0.4 psi).
- 4) Remove the EVAP service port adapter and hose with pressure pump.
- 5) Locate the leak using a leak detector. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36.

EVAPORATIVE EMISSION LINE DRAWING

NGEC0020

NOTE:


Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

KA24DE

Evaporative Emission System (Cont'd)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

KA24DE

Evaporative Emission System (Cont'd)




AEC869A

Positive Crankcase Ventilation

DESCRIPTION

NGEC0022



This system returns blow-by gas to the intake collector.


The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air duct into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the intake collector under all conditions.




INSPECTION

NGEC0023

PCV (Positive Crankcase Ventilation) Valve

NGEC0023S01

With engine running at idle, remove PCV valve from breather separator. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over the valve inlet.








Ventilation Hose

NGEC0023S02

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Fuel Pressure Release



Fuel Pressure Release

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger. NGEC0024

Ⓜ WITH CONSULT-II NGEC0024S01

1. Start engine.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.

ⓧ WITHOUT CONSULT-II NGEC0024S02

1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF and reconnect fuel pump fuse.

Fuel Pressure Check

- When reconnecting fuel line, always use new clamps. NGEC0025
- Make sure that clamp screw does not contact adjacent parts.
- Use a torque driver to tighten clamps.
- Use Pressure Gauge to check fuel pressure.
- Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.

1. Release fuel pressure to zero.
2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
3. Install pressure gauge between fuel filter and fuel tube.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

At idle speed:


With vacuum hose connected

Approximately 235 kPa (2.4 kg/cm², 34 psi)

With vacuum hose disconnected

Approximately 294 kPa (3.0 kg/cm², 43 psi)

If results are unsatisfactory, perform Fuel Pressure Regulator Check, EC-41.




Fuel Pressure Regulator Check

NGEC0026

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a rubber cap.
3. Connect variable vacuum source to fuel pressure regulator.
4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.




Injector

REMOVAL AND INSTALLATION

NGEC0027

1. Release fuel pressure to zero.
2. Remove injector tube assembly with injectors from intake manifold.
3. Remove injectors from injector tube assembly.
 - Push injector tail piece.
 - Do not pull on the connector.
4. Install injector to fuel tube assembly.
 - a. Clean exterior of injector tail piece.
 - b. Use new O-rings.



Always replace O-rings with new ones. Lubricate O-rings with a smear of engine oil.



5. Install injectors with fuel tube assembly to intake manifold. **Tighten in numerical order shown in the figure.**
 - a. First, tighten all bolts to 9.3 to 10.8 N·m (0.95 to 1.1 kg-m, 6.9 to 8.0 ft-lb).
 - b. Then, tighten all bolts to 21 to 26 N·m (2.1 to 2.7 kg-m, 15 to 20 ft-lb).
6. Install fuel hoses to fuel tube assembly.
7. Reinstall any parts removed in reverse order of removal.

CAUTION:

After properly connecting injectors to fuel tube assembly, check connections for fuel leakage.



Fast Idle Cam (FIC)

COMPONENT DESCRIPTION

NGEC0502

The FIC is installed on the throttle body to maintain adequate engine speed while the engine is cold. It is operated by a volumetric change in wax located inside the thermo-element. The thermo-element is operated by engine coolant temperature.

For inspection refer to "TROUBLE DIAGNOSIS-BASIC INSPECTION", "Basic Inspection", EC-95.

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment

NGEC0028


NGEC0028S01

PREPARATION

- Make sure that the following parts are in good order.
 - a) Battery
 - b) Ignition system
 - c) Engine oil and coolant levels
 - d) Fuses
 - e) ECM harness connector
 - f) Vacuum hoses
 - g) Air intake system
(Oil filler cap, oil level gauge, etc.)
 - h) Fuel pressure
 - i) Engine compression
 - j) EGR valve operation
 - k) Throttle valve
 - l) EVAP system
- On models equipped with air conditioner, checks should be carried out while the air conditioner is "OFF".
- On models equipped with automatic transaxle, when checking idle speed, ignition timing and mixture ratio, checks should be carried out while shift lever is in "P" or "N" position.
- When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- Turn off headlamps, heater blower, rear window defogger.
- Keep front wheels pointed straight ahead.

Overall Inspection Sequence

NGEC0028S0101




GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SEF941VB


INSPECTION PROCEDURE

=NGEC0028S02

| | | | |
|----------|-------------------------|---|---------|
| 1 | INSPECTION START | <p>1. Visually check the following:</p> <ul style="list-style-type: none"> ● Air cleaner clogging ● Hoses and duct for leaks ● EGR valve operation ● Electrical connectors ● Gasket (intake manifold, cylinder head, exhaust system) ● Throttle valve and throttle position sensor operation <p>2. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. Ensure engine speed stays below 1,000 rpm.</p> <div style="text-align: center; margin: 20px 0;">  </div> <p>3. Open engine hood and run engine at about 2,000 rpm for about 2 minutes under no-load.</p> <p>4. Perform the Diagnostic Test Mode II (Self-diagnostic results). Refer to EC-71.</p> <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: center;">OK or NG</p> | SEF810K |
| OK | ▶ | <ul style="list-style-type: none"> ● GO TO 2. (With CONSULT-II) ● GO TO 3. (Without CONSULT-II) | |
| NG | ▶ | <ol style="list-style-type: none"> 1. Repair or replace components as necessary. 2. GO TO 2. (With CONSULT-II) 3. GO TO 3. (Without CONSULT-II) | SEF217U |


2 CHECK IGNITION TIMING
Ⓟ With CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine two or three times under no-load, then run engine at idle speed for about 1 minute.



3. Select "IGNITION TIMING ADJ" in WORK SUPPORT mode.
4. Touch "START".


SEF978U

 GI
MA
EM
LC
EC


PEF546N

 FE
CL
MT
AT
TF

5. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
6. Check ignition timing with a timing light.



SEF320V

 PD
AX
SU
BR
ST

M/T: 20°±2° BTDC
A/T: 20°±2° BTDC (in "P" or "N" position)

OK or NG

 RS
BT


| | | |
|----|---|----------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

 HA
SC
EL

3 CHECK IGNITION TIMING


⊗ Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine two or three times under no-load, then run engine at idle speed for about 1 minute.




SEF978U

3. Turn off engine and disconnect throttle position sensor harness connector.



SEF265S

4. Start engine and rev it (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
5. Check ignition timing with a timing light.




SEF320V

M/T: 20°±2° BTDC

A/T: 20°±2° BTDC (in "P" or "N" position)

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |


| | | |
|---|-------------------------------|----------|
| 4 | ADJUST IGNITION TIMING | |
| <p>Ⓟ With CONSULT-II 1. Adjust ignition timing to the specified value by turning distributor after loosening bolts which secure distributor.</p> | | |
| <p>ⓧ Without CONSULT-II 1. Adjust ignition timing to the specified value by turning distributor after loosening bolts which secure distributor. 2. Turn off engine and connect throttle position sensor harness connector to throttle position sensor.</p> | | |
|  | | |
| SEF265S | | |
| Models with CONSULT-II ▶ | | GO TO 2. |
| Models without CONSULT-II ▶ | | GO TO 3. |

| | | | | | | | | | | | | | | | | | | | | | | |
|--|------------------------------|----------|---------------------|--|-------------------|--|----------------|------|---------|--|---------------|---------|------------|----------|--------------|----|--|--|--|--|--|--|
| 5 | CHECK BASE IDLE SPEED | | | | | | | | | | | | | | | | | | | | | |
| <p>Ⓟ With CONSULT-II 1. Read idle speed in "IGNITION TIMING ADJ" in "WORK SUPPORT" mode.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">IGNITION TIMING ADJ</td></tr> <tr><td colspan="2" style="text-align: center;">CONDITION SETTING</td></tr> <tr><td style="text-align: center;">IGN/T FEEDBACK</td><td style="text-align: center;">HOLD</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">CMPS-RPM(REF)</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">IGN TIMING</td><td style="text-align: center;">XXX BTDC</td></tr> <tr><td style="text-align: center;">CLSD THL POS</td><td style="text-align: center;">ON</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | | IGNITION TIMING ADJ | | CONDITION SETTING | | IGN/T FEEDBACK | HOLD | MONITOR | | CMPS-RPM(REF) | XXX rpm | IGN TIMING | XXX BTDC | CLSD THL POS | ON | | | | | | |
| IGNITION TIMING ADJ | | | | | | | | | | | | | | | | | | | | | | |
| CONDITION SETTING | | | | | | | | | | | | | | | | | | | | | | |
| IGN/T FEEDBACK | HOLD | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| IGN TIMING | XXX BTDC | | | | | | | | | | | | | | | | | | | | | |
| CLSD THL POS | ON | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| PEF773W | | | | | | | | | | | | | | | | | | | | | | |
| <p>M/T: 750±50 rpm A/T: 750±50 rpm (in "P" or "N" position)</p> | | | | | | | | | | | | | | | | | | | | | | |
| <p>ⓧ Without CONSULT-II 1. Check idle speed. M/T: 750±50 rpm A/T: 750±50 rpm (in "P" or "N" position)</p> | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK (With CONSULT-II) ▶ | | GO TO 7. | | | | | | | | | | | | | | | | | | | | |
| OK (Without CONSULT-II) ▶ | | GO TO 8. | | | | | | | | | | | | | | | | | | | | |
| NG ▶ | | GO TO 6. | | | | | | | | | | | | | | | | | | | | |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

6 ADJUST BASE IDLE SPEED

1. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
2. Adjust idle speed by turning idle speed adjusting screw.



M/T: 750±50 rpm
A/T: 750±50 rpm (in "P" or "N" position)

SEF240SA


Models with CONSULT-II ► GO TO 7.

Models without CONSULT-II ► GO TO 8.

7 CHECK TARGET IDLE SPEED

With CONSULT-II

1. Touch "BACK" on CONSULT-II.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.



SEF602K

3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) | XXX rpm |
| | |


PEF190P

M/T: 800±50 rpm
A/T: 800±50 rpm (in "P" or "N" position)


OK or NG

OK ► GO TO 10.

NG ► GO TO 9.


| | | | | | | | | | |
|----------|--------------------------------|--|----|---|-----------|----|---|----------|---|
| 8 | CHECK TARGET IDLE SPEED | <p>⊗ Without CONSULT-II</p> <p>1. Turn off engine and connect throttle position sensor harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF265S</p> <p>2. Start engine. 3. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. 4. Check target idle speed. M/T: 800±50 rpm A/T: 800±50 rpm (in "P" or "N" position)</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 10.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 9.</td> </tr> </table> | OK | ▶ | GO TO 10. | NG | ▶ | GO TO 9. | GI MA EM LC <div style="background-color: black; color: white; padding: 5px;">EC</div> FE CL MT AT TF PD AX SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 10. | | | | | | | |
| NG | ▶ | GO TO 9. | | | | | | | |

| | | | | | | |
|----------|-----------------------------------|--|--|---|-----------|--|
| 9 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <p>1. Check IACV-AAC valve and replace if necessary. Refer to EC-416. 2. Check IACV-AAC valve harness and repair if necessary. Refer to EC-416. 3. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"></td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 10.</td> </tr> </table> | | ▶ | GO TO 10. | |
| | ▶ | GO TO 10. | | | | |

| 10 | CHECK FRONT HEATED OXYGEN SENSOR SIGNAL | | | | | | | | |
|---|--|--------------|--|------------|---------|---------------|---------|------------|------|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. See "FR O2 MNTR" in "DATA MONITOR" mode. 2. Run engine at about 2,000 rpm for about 2 minutes under no-load. 3. Maintain engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature) and check that the monitor fluctuates between "LEAN" and "RICH" more than five times during 10 seconds. <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse; width: 150px; margin: auto;"> <thead> <tr> <th colspan="2" style="padding: 2px;">DATA MONITOR</th> </tr> <tr> <th style="padding: 2px;">MONITORING</th> <th style="padding: 2px;">NO FAIL</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">CMPS~RPM(REF)</td> <td style="padding: 2px;">XXX rpm</td> </tr> <tr> <td style="padding: 2px;">FR O2 MNTR</td> <td style="padding: 2px;">RICH</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-right: 50px;">PEF054P</p> <p>1 cycle: RICH → LEAN → RICH 2 cycles: RICH → LEAN → RICH → LEAN → RICH</p> | | DATA MONITOR | | MONITORING | NO FAIL | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH |
| DATA MONITOR | | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Set "Front heated oxygen sensor monitor" in the Diagnostic Test Mode II. (See page EC-70.) <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 50px;">SEF979U</p> <ol style="list-style-type: none"> 2. Run engine at about 2,000 rpm for about 2 minutes under no-load (engine is warmed up to normal operating temperature). 3. Maintain engine at 2,000 rpm under no-load and check that MIL goes on more than five times during 10 seconds. <div style="text-align: center; margin: 20px 0;">  <p style="margin-top: 10px;">OK or NG</p> </div> <p style="text-align: right; margin-right: 50px;">SEF217U</p> | | | | | | | | | |
| OK | ▶ INSPECTION END | | | | | | | | |
| NG | ▶ GO TO 11. | | | | | | | | |

| | | |
|-----------|--|--|
| 11 | CHECK FRONT HEATED OXYGEN SENSOR HARNESS | |
| | <p>1. Turn off engine and disconnect battery ground cable. 2. Disconnect ECM harness connector. 3. Disconnect front heated oxygen sensor harness connector. 4. Then connect harness connector terminal for front heated oxygen sensor to ground with a jumper wire.</p> <div style="text-align: center;"> <p style="text-align: center;">Front heated oxygen sensor harness connector</p> </div> <p style="text-align: right;">SEF508V</p> <p>5. Check for continuity between terminal 50 of ECM harness connector and body ground.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEF250P</p> <p>Continuity exists...OK Continuity does not exist...NG</p> <p style="text-align: center;">OK or NG</p> | |
| OK | <p>▶ 1. Connect ECM harness connector to ECM. 2. Connect battery ground cable. 3. GO TO 13.</p> | |
| NG | <p>▶ 1. Repair or replace harness. 2. GO TO 12.</p> | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | |
|---|---|
| 12 | PREPARATION FOR IDLE SPEED ADJUSTING |
| <p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode. 2. Touch "START". <div style="border: 1px solid black; padding: 10px; margin: 10px auto; width: 60%; text-align: center;"> <p>IGNITION TIMING ADJ</p> <p>IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.</p> </div> <p style="text-align: right; margin-top: 10px;">PEF546N</p> | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Stop engine and disconnect throttle position sensor harness connector. <div style="text-align: center; margin: 10px 0;">  </div> <p>2. Start engine.</p> <p style="text-align: right; margin-top: 10px;">SEF265S</p> | |
| ▶ GO TO 6. | |

13 PREPARATION FOR "CO" % CHECK

Ⓜ With CONSULT-II

1. Select "ENGINE COOLANT TEMP" in "ACTIVE TEST" mode.
2. Set "COOLANT TEMP" to 5°C (41°F) by touching "Qu" and "Qd" and "UP", "DOWN".


| ACTIVE TEST | |
|---------------|----------|
| COOLANT TEMP | XXX |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| INJ PULSE | XXX msec |
| IGN TIMING | XXX BTDC |
| | |
| | |
| | |
| | |

PEF946W

1. Connect ECM harness connector to ECM.
2. Disconnect engine coolant temperature sensor harness connector.
3. Connect a resistor (4.4 kΩ) between terminals of engine coolant temperature sensor harness connector.



Engine coolant temperature sensor harness connector





SEF053RA

4. Connect battery ground cable.

▶ GO TO 14.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | | |
|--|---------------------|---|-----------|
| 14 | CHECK "CO" % | | |
| <p><input checked="" type="checkbox"/> Without CONSULT-II</p> <p>1. Start engine and warm it up until engine coolant temperature indicator points to middle of gauge. (Be sure to start engine after setting "COOLANT TEMP" or installing a 4.4 kΩ resistor.)</p> | | | |
|  | | | |
| SEF810K | | | |
| <p>2. Rev engine two or three times under no-load, then run engine at idle speed.</p> | | | |
|  | | | |
| SEF978U | | | |
| <p>3. Check "CO"%.</p> <p style="color: blue; text-align: center;">Idle CO: 2.9 - 10.8% and engine runs smoothly.</p> | | | |
| <p>4. <input type="checkbox"/> With CONSULT-II After checking CO%, touch "BACK".</p> | | | |
| <p>5. <input checked="" type="checkbox"/> Without CONSULT-II After checking CO%,</p> <p style="margin-left: 20px;">a. Disconnect the resistor from terminals of engine coolant temperature sensor harness connector.</p> <p style="margin-left: 20px;">b. Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.</p> | | | |
| OK or NG | | | |
| OK | | ▶ | GO TO 15. |
| NG | | ▶ | GO TO 16. |

| | | | |
|---|--|---|-----------|
| 15 | CHECK FRONT HEATED OXYGEN SENSOR SIGNAL | | |
| <p><input type="checkbox"/> With CONSULT-II</p> <p>1. Replace front heated oxygen sensor.</p> <p>2. See "FR O2 MNTR" in "DATA MONITOR" mode.</p> <p>3. Maintain engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.). Check that the monitor fluctuates between "LEAN" and "RICH" more than five times during 10 seconds.</p> <p style="margin-left: 20px;">1 cycle: RICH → LEAN → RICH</p> <p style="margin-left: 20px;">2 cycles: RICH → LEAN → RICH → LEAN → RICH</p> | | | |
| <p><input checked="" type="checkbox"/> Without CONSULT-II</p> <p>1. Replace front heated oxygen sensor.</p> <p>2. Set "Front heated oxygen sensor monitor" in the Diagnostic Test Mode II. (See page EC-70.)</p> <p>3. Maintain engine at 2,000 rpm under no-load. Check that the malfunction indicator lamp goes on and off more than five times during 10 seconds.</p> | | | |
| OK or NG | | | |
| OK | | ▶ | GO TO 12. |
| NG | | ▶ | GO TO 16. |

BASIC SERVICE PROCEDURE

KA24DE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

| | |
|---|-----------------------------------|
| 16 | DETECT MALFUNCTIONING PART |
| <ol style="list-style-type: none">1. Connect front heated oxygen sensor harness connector to front heated oxygen sensor.2. Check fuel pressure regulator. Refer to EC-41.3. Check mass air flow sensor and its circuit. Refer to EC-136.4. Check injector and its circuit. Refer to EC-552. Clean or replace if necessary.5. Check engine coolant temperature sensor and its circuit. Refer to EC-167, 186.6. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.) | |
|  | GO TO 12. |

- **If a vehicle contains a part which is operating outside of design specifications with no MIL illumination, the part shall not be replaced prior to emission testing unless it is determined that the part has been tampered with or abused in such a way that the diagnostic system cannot reasonably be expected to detect the resulting malfunction.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Introduction

NGEC0029

The ECM has an on board diagnostic system which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

| | |
|---|---------------------|
| Diagnostic Trouble Code (DTC) | Mode 3 of SAE J1979 |
| Freeze Frame data | Mode 2 of SAE J1979 |
| System Readiness Test (SRT) code | Mode 1 of SAE J1979 |
| 1st Trip Diagnostic Trouble Code (1st Trip DTC) | Mode 7 of SAE J1979 |
| 1st Trip Freeze Frame data | |
| Test values and Test limits | Mode 6 of SAE J1979 |

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

| | DTC | 1st trip DTC | Freeze Frame data | 1st trip Freeze Frame data | SRT code | Test value |
|------------|-----|--------------|-------------------|----------------------------|----------|------------|
| ECM*3 | X | X*1 | — | — | — | — |
| CONSULT-II | X | X | X | X | X | — |
| GST | X | X*2 | X | — | X | X |

*1: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

*2: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

*3: In diagnostic test mode II (Self-diagnostic results)

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to EC-110.)

Two Trip Detection Logic

NGEC0030

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

X: Applicable —: Not applicable

| Items | MIL | | | | DTC | | 1st trip DTC | |
|--|----------|-------------|----------|-------------|---------------------|---------------------|---------------------|---------------------|
| | 1st trip | | 2nd trip | | 1st trip displaying | 2nd trip displaying | 1st trip displaying | 2nd trip displaying |
| | Blinking | Lighting up | Blinking | Lighting up | | | | |
| Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 (0701, 0605 - 0608) is being detected | X | — | — | — | — | — | X | — |
| Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 (0701, 0605 - 0608) is being detected | — | — | X | — | — | X | — | — |
| Closed loop control — DTC: P1148 (0307) | — | X | — | — | X | — | X | — |
| Fail-safe items | — | X | — | — | X*1 | — | X*1 | — |
| Except above | — | — | — | X | — | X | X | — |

*1: Except "ECM".

Emission-related Diagnostic Information

NGEC0031

NGEC0031S01

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed. If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory. Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION". Refer to EC-67.

For malfunctions in which 1st trip DTCs are displayed, refer to EC-66. These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of SAE J1979. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to page EC-93. Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

How to read DTC and 1st Trip DTC

NGEC0031S0101

DTC and 1st trip DTC can be read by the following methods.

- 1)  **No Tools**
The number of blinks of MIL in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 0101, 0201, 1003, 1104, etc.
These DTCs are controlled by NISSAN.
 - 2)  **With CONSULT-II**
 **With GST**
CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P1320, P0705, P0750, etc.
These DTCs are prescribed by SAE J2012.
(CONSULT-II also displays the malfunctioning component or system.)
- **1st trip DTC No. is the same as DTC No.**
 - **Output of a DTC indicates a malfunction. However, Mode II and GST do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".
If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

| | | | | |
|----------------------|------------------------|------|------------------------|------|
| DTC display | SELF DIAG RESULTS | | SELF DIAG RESULTS | |
| | FAILURE DETECTED | TIME | FAILURE DETECTED | TIME |
| | IACV-AAC VALVE [P0505] | 0 | IACV-AAC VALVE [P0505] | 1t |
| | | | | |
| 1st trip DTC display | SELF DIAG RESULTS | | SELF DIAG RESULTS | |
| | FAILURE DETECTED | TIME | FAILURE DETECTED | TIME |
| | IACV-AAC VALVE [P0505] | 0 | IACV-AAC VALVE [P0505] | 1t |
| | | | | |

AEC037B

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

NGEC0031S02

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed and absolute pressure sensor at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see EC-81.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

| Priority | Items | |
|----------|----------------------------|--|
| 1 | Freeze frame data | Misfire — DTC: P0300 - P0304 (0701, 0605 - 0608) Fuel Injection System Function — DTC: P0171 (0115), P0172 (0114) |
| 2 | | Except the above items (Includes A/T related items) |
| 3 | 1st trip freeze frame data | |

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION". Refer to EC-67.

SYSTEM READINESS TEST (SRT) CODE

NGEC0031S03

System Readiness Test (SRT) code is specified in Mode 1 of SAE J1979.

As part of enhanced emissions test for Inspection and Maintenance (I/M), certain states require that the status of srt be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "incomplete", use the information in this service manual to set the SRT to "complete".

In most cases, the ECM will automatically complete its self-diagnosis cycle during normal usage and the SRT status will indicate "complete" for each application system. Once set as "complete", the SRT status remains "complete" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern and the SRT will indicate "incomplete" for these items.

NOTE:

The SRT will also indicate "incomplete" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "complete" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "incomplete" for one or more of the SRT items, the vehicle is returned to the customer untested.

NOTE:

If MIL is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "complete" for all test items. Therefore, it is important to check SRT ("complete") and DTC (No DTCs) before the inspection.

This service manual contains the service procedure and support information to perform a comprehensive road test that enables the ECM to complete the SRT.

SRT Item

NGEC0031S0308

| Self-diagnosis result | | Example | | | | |
|-----------------------|--------|----------------|-------------------------------|-------------------------------|-------------------------------|-------------------------------|
| | | Diagnosis | Ignition OFF – ON – OFF |
| All OK | Case 1 | P0400 | OK (1) | – (1) | OK (2) | – (2) |
| | | P0402 | OK (1) | – (1) | – (1) | OK (2) |
| | | P1402 | OK (1) | OK (2) | – (2) | – (2) |
| | | SRT of EGR | “complete” | “complete” | “complete” | “complete” |
| | Case 2 | P0400 | OK (1) | – (1) | – (1) | – (1) |
| | | P0402 | – (0) | – (0) | OK (1) | – (1) |
| | | P1402 | OK (1) | OK (2) | – (2) | – (2) |
| | | SRT of EGR | “incomplete” | “incomplete” | “complete” | “complete” |
| NG exists | Case 3 | P0400 | OK | OK | – | – |
| | | P0402 | – | – | – | – |
| | | P1402 | NG | – | NG | NG (Consecutive NG) |
| | | (1st trip) DTC | 1st trip DTC | – | 1st trip DTC | DTC (=MIL “ON”) |
| | | SRT of EGR | “incomplete” | “incomplete” | “incomplete” | “complete” |

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is OK.

– : Self-diagnosis is not carried out.

SRT Set Timing

NGEC0031S0310

SRT is set as “complete” after self-diagnosis has been performed one or more times. Completion of SRT will occur if the result is OK or NG. The set timing is different between them and is shown in the following table. When all SRT related self-diagnoses showed OK results in a same cycle (Ignition OFF – ON – OFF), the SRT will indicate “complete”.

→ Case 1 above

When all SRT related self-diagnoses show OK results through several different cycles, the SRT will indicate “complete” at the time the respective self-diagnoses have at least one OK result.

→ Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate “complete”.

→ Case 3 above

The previous table shows that the minimum number of cycles for setting SRT as “incomplete” is one (1) for each self-diagnosis (Case 1 and 2) or two (2) for one self-diagnosis (Case 3). However, in preparation for the State emissions inspection, it is unnecessary of each self-diagnosis to be executed twice (Case 3) because of the following reasons;

- The SRT will indicate “complete” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “complete” of the SRT only with OK self-diagnosis result.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to “complete” of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “incomplete”.

NOTE:

SRT can be set as “complete” together with the DTC(s). Therefore, DTC check must always be carried out prior to the State emission inspection even though the SRT indicates “complete”.

How to Display SRT Code

NGEC0031S0301

1. **With CONSULT-II**
Selecting “SRT STATUS” in “DTC CONFIRMATION” mode with CONSULT-II.

Emission-related Diagnostic Information (Cont'd)

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

2.  **With GST**

Selecting Mode 1 with GST (Generic Scan Tool)

A sample of CONSULT-II display for SRT code is shown below.

"INCMP" means the self-diagnosis is incomplete and SRT is not set. "CMPLT" means the self-diagnosis is complete and SRT is set.


| SRT STATUS | |
|---------------|-------|
| CATALYST | CMPLT |
| EVAP SYSTEM | INCMP |
| O2 SENSOR | CMPLT |
| O2 SEN HEATER | CMPLT |
| EGR SYSTEM | INCMP |

PEF948W

SRT Service Procedure

=NGEC0031S0311

If a vehicle has been rejected for the State emissions inspection due to one or more SRT items indicating "incomplete", review the following flowchart diagnostic sequence.



AEC032B

*1 EC-57

*2 EC-59

*3 EC-62

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

How to Set SRT Code

-NGEC0031S0302

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

① With CONSULT-II

Perform corresponding DTC confirmation procedure one by one based on "Performance Priority" in the table on EC-59.


② Without CONSULT-II

The most efficient driving pattern in which SRT codes can be properly set is explained on EC-63. The driving pattern should be performed one or more times to set all SRT codes.

Driving Pattern

NGEC0031S0303

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.



GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Emission-related Diagnostic Information (Cont'd)

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time required, for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminals 59 and 43 is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminals 59 and 43 is lower than 1.4V).**
- **The engine is started at the tank fuel temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 60 and ground is less than 4.1V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- The driving pattern outlined in *2 must be repeated at least 3 times.


Pattern 4:

- Tests are performed after the engine has been operated for at least 17 minutes.
- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted all over again.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Operate the vehicle in the following driving pattern.

- 1) Decelerate vehicle to 0 km/h (0 MPH) and let engine idle.
- 2) Repeat driving pattern shown below at least 10 times.
- **During acceleration, hold the accelerator pedal as steady as possible.**
- 3) Repeat steps 1 and 2 until the EGR system SRT is set.



*3: Checking the vehicle speed with GST is advised.

Suggested Transmission Gear Position for A/T Models

Set the selector lever in the "D" position with the overdrive switch turned ON.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

Emission-related Diagnostic Information (Cont'd)

Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.

| Gear change | For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]: | | For quick acceleration in low altitude areas and high altitude areas [over 1,219 m (4,000 ft)]: |
|-------------|--|----------------------------------|---|
| | ACCEL shift point km/h (MPH) | CRUISE shift point km/h (MPH) | km/h (MPH) |
| 1st to 2nd | 24 (15) | 24 (15) | 24 (15) |
| 2nd to 3rd | 40 (25) | 29 (18) | 40 (25) |
| 3rd to 4th | 58 (36) | 48 (30) | 64 (40) |
| 4th to 5th | 64 (40) | 63 (39) | 72 (45) |

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

NGEC0031S04

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is "OK" or "NG" while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (9 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

X: Applicable —: Not applicable

| SRT item | Self-diagnostic test item | Test value (GST display) | | Test limit | Application |
|------------------|--|--------------------------|-----|------------|-------------|
| | | TID | CID | | |
| CATALYST | Three way catalyst function | 01H | 01H | Max. | X |
| | | 02H | 81H | Min. | X |
| EVAP SYSTEM | EVAP control system (Small leak) | 05H | 03H | Max. | X |
| | EVAP control system purge flow monitoring | 06H | 83H | Min. | X |
| O2 SENSOR | Front heated oxygen sensor | 09H | 04H | Max. | X |
| | | 0AH | 84H | Min. | X |
| | | 0BH | 04H | Max. | X |
| | | 0CH | 04H | Max. | X |
| | Rear heated oxygen sensor | 0DH | 04H | Max. | X |
| | | 19H | 86H | Min. | X |
| | | 1AH | 86H | Min. | X |
| | | 1BH | 06H | Max. | X |
| 1CH | 06H | Max. | X | | |
| O2 SENSOR HEATER | Front heated oxygen sensor heater | 29H | 08H | Max. | X |
| | | 2AH | 88H | Min. | X |
| | Rear heated oxygen sensor heater | 2DH | 0AH | Max. | X |
| | | 2EH | 8AH | Min. | X |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

Emission-related Diagnostic Information (Cont'd)

| SRT item | Self-diagnostic test item | Test value (GST display) | | Test limit | Application |
|------------|---------------------------|--------------------------|-----|------------|-------------|
| | | TID | CID | | |
| EGR SYSTEM | EGR function | 31H | 8CH | Min. | X |
| | | 32H | 8CH | Min. | X |
| | | 33H | 8CH | Min. | X |
| | | 34H | 8CH | Min. | X |
| | | 35H | 0CH | Max. | X |
| | EGRC-BPT valve function | 36H | 0CH | Max. | X |
| | | 37H | 8CH | Min. | X |

EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

X: Applicable —: Not applicable NGEC0031S05

| Items (CONSULT-II screen terms) | DTC*4 | | SRT code | Test value/Test limit (GST only) | 1st trip DTC*4 | Reference page |
|---|---------------------|-------------|----------|--|----------------|-------------------|
| | CONSULT-II GST*2 | ECM*1 | | | | |
| NO SELF DIAGNOSTIC FAILURE INDICATED | P0000 | 0505 | — | — | — | — |
| MAF SEN/CIRCUIT | P0100 | 0102 | — | — | X | EC-136 |
| ABSL PRES SEN/CIRC | P0105 | 0803 | — | — | X | EC-146 |
| AIR TEMP SEN/CIRC | P0110 | 0401 | — | — | X | EC-161 |
| COOLANT T SEN/CIRC | P0115 | 0103 | — | — | X | EC-167 |
| THRTL POS SEN/CIRC | P0120 | 0403 | — | — | X | EC-172 |
| *COOLAN T SEN/CIRC | P0125 | 0908 | — | — | X | EC-186 |
| FRONT O2 SENSOR | P0130 | 0303 | X | X | X*3 | EC-190 |
| FRONT O2 SENSOR | P0131 | 0411 | X | X | X*3 | EC-198 |
| FRONT O2 SENSOR | P0132 | 0410 | X | X | X*3 | EC-205 |
| FRONT O2 SENSOR | P0133 | 0409 | X | X | X*3 | EC-212 |
| FRONT O2 SENSOR | P0134 | 0412 | X | X | X*3 | EC-223 |
| FR O2 SEN HEATER | P0135 | 0901 | X | X | X*3 | EC-230 |
| REAR O2 SENSOR | P0137 | 0511 | X | X | X*3 | EC-235 |
| REAR O2 SENSOR | P0138 | 0510 | X | X | X*3 | EC-245 |
| REAR O2 SENSOR | P0139 | 0707 | X | X | X*3 | EC-255 |
| REAR O2 SENSOR | P0140 | 0512 | X | X | X*3 | EC-265 |
| RR O2 SEN HEATER | P0141 | 0902 | X | X | X*3 | EC-273 |
| FUEL SYS DIAG-LEAN | P0171 | 0115 | — | — | X | EC-278 |
| FUEL SYS DIAG-RICH | P0172 | 0114 | — | — | X | EC-286 |
| FUEL TEMP SEN/CIRC | P0180 | 0402 | — | — | X | EC-293 |
| MULTI CYL MISFIRE | P0300 | 0701 | — | — | X | EC-299 |
| CYL 1 MISFIRE | P0301 | 0608 | — | — | X | EC-299 |
| CYL 2 MISFIRE | P0302 | 0607 | — | — | X | EC-299 |
| CYL 3 MISFIRE | P0303 | 0606 | — | — | X | EC-299 |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

Emission-related Diagnostic Information (Cont'd)

| Items (CONSULT-II screen terms) | DTC*4 | | SRT code | Test value/Test limit (GST only) | 1st trip DTC*4 | Reference page |
|------------------------------------|---------------------|-------|----------|--|----------------|-------------------|
| | CONSULT-II GST*2 | ECM*1 | | | | |
| CYL 4 MISFIRE | P0304 | 0605 | — | — | X | EC-299 |
| KNOCK SEN/CIRCUIT | P0325 | 0304 | — | — | — | EC-308 |
| CPS/CIRCUIT (OBD) | P0335 | 0802 | — | — | X | EC-312 |
| CAM POS SEN/CIRC | P0340 | 0101 | — | — | X | EC-318 |
| EGR SYSTEM | P0400 | 0302 | X | X | X*3 | EC-326 |
| EGRC-BPT VALVE | P0402 | 0306 | X | X | X*3 | EC-338 |
| TW CATALYST SYSTEM | P0420 | 0702 | X | X | X*3 | EC-346 |
| EVAP SMALL LEAK | P0440 | 0705 | X | X | X*3 | EC-351 |
| PURG VOLUME CONT/V | P0443 | 1008 | — | — | X | EC-367 |
| VENT CONTROL VALVE | P0446 | 0903 | — | — | X | EC-375 |
| EVAP SYS PRES SEN | P0450 | 0704 | — | — | X | EC-383 |
| EVAP GROSS LEAK | P0455 | 0715 | X | X | X*3 | EC-398 |
| VEH SPEED SEN/CIRC | P0500 | 0104 | — | — | X | EC-412 |
| IACV/AAC VLV/CIRC | P0505 | 0205 | — | — | X | EC-416 |
| CLOSED TP SW/CIRC | P0510 | 0203 | — | — | X | EC-422 |
| ECM | P0605 | 0301 | — | — | X | EC-429 |
| MAP/BARO SW SOL/CIR | P1105 | 1302 | — | — | X | EC-431 |
| CLOSED LOOP | P1148 | 0307 | — | — | — | EC-447 |
| IGN SIGNAL-PRIMARY | P1320 | 0201 | — | — | X | EC-449 |
| CPS/CIRC (OBD) COG | P1336 | 0905 | — | — | X | EC-457 |
| EGRC SOLENOID/V | P1400 | 1005 | — | — | X | EC-463 |
| EGR TEMP SEN/CIRC | P1401 | 0305 | — | — | X | EC-470 |
| EGR SYSTEM | P1402 | 0514 | X | X | X*3 | EC-476 |
| EVAP SMALL LEAK | P1440 | 0213 | X | X | X*3 | EC-485 |
| PURG VOLUME CONT/V | P1444 | 0214 | — | — | X | EC-487 |
| VENT CONTROL VALVE | P1446 | 0215 | — | — | X | EC-499 |
| EVAP PURG FLOW/MON | P1447 | 0111 | X | X | X*3 | EC-505 |
| VENT CONTROL VALVE | P1448 | 0309 | — | — | X | EC-515 |
| VC/V BYPASS/V | P1490 | 0801 | — | — | X | EC-523 |
| VC CUT/V BYPASS/V | P1491 | 0311 | — | — | X | EC-530 |
| P-N POS SW/CIRCUIT | P1706 | 1003 | — | — | X | EC-541 |

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: These are not displayed with GST.

*4: 1st trip DTC No. is the same as DTC No.

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

Ⓜ How to Erase DTC (With CONSULT-II)

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

- seconds and then turn it ON (engine stopped) again.
2. Turn CONSULT-II "ON" and touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" again.

| DIAGNOSIS SYSTEM SELECTION |
|----------------------------|
| ENGINE |
| |
| |
| |
| |
| |
| |

2. Turn **CONSULT-II** "ON" and touch "ENGINE".

| DIAGNOSIS MODE SELECTION |
|--------------------------|
| WORK SUPPORT |
| SELF-DIAG RESULTS |
| DATA MONITOR |
| ACTIVE TEST |
| DTC & SRT CONFIRMATION |
| |
| |

3. Touch "SELF-DIAG RESULTS".

| SELF DIAG RESULTS | |
|--------------------------|------|
| FAILURE PART: | TIME |
| COOLANT TEMP SEN [P0115] | 0 |
| | |
| | |

4. Touch "ERASE". (The DTC in the ECM will be erased.)

AEC054B

The emission-related diagnostic information can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

How to Erase DTC (With GST)

NGEC0031S0602

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Select Mode 4 with GST (Generic Scan Tool).

The emission-related diagnostic information in the ECM can be erased by selecting Mode 4 with GST (Generic Scan Tool).

How to Erase DTC (No Tools)

NGEC0031S0603

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON again.
2. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. (See EC-71.)

The emission-related diagnostic information in the ECM can be erased by changing the diagnostic test mode from Diagnostic Test Mode II to Mode I by turning the mode selector on the ECM. (Refer to EC-71.)

NOTE:

- **If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.**
- **Erasing the emission-related diagnostic information using CONSULT-II or GST is easier and quicker than switching the mode selector on the ECM.**
- **The following data are cleared when the ECM memory is erased.**
 - 1) Diagnostic trouble codes
 - 2) 1st trip diagnostic trouble codes
 - 3) Freeze frame data
 - 4) 1st trip freeze frame data
 - 5) System readiness test (SRT) codes
 - 6) Test values
 - 7) Others


Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

Malfunction Indicator Lamp (MIL)

DESCRIPTION

NGEC0032

GI



MA

EM

LC

EC

The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to "WARNING LAMPS", *EL-87* or see EC-578.
2. When the engine is started, the MIL should go off.
 - If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

On Board Diagnostic System Function

=NGEC0032S01

The on board diagnostic system has the following four functions.

Diagnostic Test Mode I

1. BULB CHECK:

This function checks the MIL bulb for damage (blown, open circuit, etc.).

If the MIL does not come on, check MIL circuit and ECM test mode selector. (See next page.)

2. MALFUNCTION WARNING:

This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected.

The following malfunctions will light up or blink the MIL in the 1st trip.

- "Misfire (Possible three way catalyst damage)"
- "Closed loop control"
- Fail-safe mode

Diagnostic Test Mode II

3. SELF-DIAGNOSTIC RESULTS:

This function allows DTCs and 1st trip DTCs to be read.

4. FRONT HEATED OXYGEN SENSOR MONITOR:

This function allows the fuel mixture condition (lean or rich), monitored by front heated oxygen sensor, to be read.

MIL Flashing without DTC

NGEC0032S0101

If the ECM is in Diagnostic Test Mode II, MIL may flash when engine is running. In this case, check ECM test mode selector following "HOW TO SWITCH DIAGNOSTIC TEST MODES" on next page.

How to switch the diagnostic test (function) modes, and details of the above functions are described later. (Refer to EC-71.)


| Condition | | Diagnostic Test Mode I | Diagnostic Test Mode II |
|---|---|------------------------|------------------------------------|
| Ignition switch in ON position  | Engine stopped  | BULB CHECK | SELF-DIAGNOSTIC RESULTS |
| | Engine running  | MALFUNCTION WARNING | FRONT HEATED OXYGEN SENSOR MONITOR |

The following emission-related diagnostic information is cleared when the ECM memory is erased.

- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Others

How to Switch Diagnostic Test Modes

How to Switch Diagnostic Test Modes



*1: EC-578

*3: EC-578

*4: EC-110

*2: EC-70

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Malfunction Indicator Lamp (MIL) (Cont'd)

Diagnostic Test Mode I — Bulb Check

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the MIL bulb. NGEC0032S03
Refer to "WARNING LAMPS", *EL-87* or see EC-578.

Diagnostic Test Mode I — Malfunction Warning

NGEC0032S04



| MIL | Condition |
|-----|--|
| ON | When the malfunction is detected or the ECM's CPU is malfunctioning. |
| OFF | No malfunction. |

- These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS).

Diagnostic Test Mode II — Self-diagnostic Results

NGEC0032S05

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MIL. The DTC and 1st trip DTC are displayed at the same time. If the MIL does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MIL illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-II or GST. A DTC will be used as an example for how to read a code.



Long (0.6 second) blinking indicates the two LH digits of number and short (0.3 second) blinking indicates the two RH digits of number. For example, the malfunction indicator lamp blinks 10 times for 6 seconds (0.6 sec x 10 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "1003" and refers to the malfunction of the park/neutral position (PNP) switch.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC "0505" refers to no malfunction. (See TROUBLE DIAGNOSIS — INDEX, EC-13.)

How to Erase Diagnostic Test Mode II (Self-diagnostic results)

NGEC0032S0501

The DTC can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)

- If the battery is disconnected, the DTC will be lost from the backup memory after approx. 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

Diagnostic Test Mode II — Front Heated Oxygen Sensor Monitor

NGEC0032S06

In this mode, the MIL displays the condition of the fuel mixture (lean or rich) which is monitored by the front heated oxygen sensor.

| MIL | Fuel mixture condition in the exhaust gas | Air fuel ratio feedback control condition |
|--------------------|---|---|
| ON | Lean | Closed loop system |
| OFF | Rich | |
| *Remains ON or OFF | Any condition | Open loop system |

*: Maintains conditions just before switching to open loop.

To check the front heated oxygen sensor function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MIL comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

OBD System Operation Chart

NGEC0033

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DETECTABLE ITEMS

NGEC0033S01

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to “Two Trip Detection Logic” on EC-56.
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The “TIME” in “SELF-DIAGNOSTIC RESULTS” mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in “OK” for the 2nd trip.

SUMMARY CHART

NGEC0033S02

| Items | Fuel Injection System | Misfire | Other |
|-------------------------------------|-----------------------|-------------------|----------------|
| MIL (goes off) | 3 (pattern B) | 3 (pattern B) | 3 (pattern B) |
| DTC, Freeze Frame Data (no display) | 80 (pattern C) | 80 (pattern C) | 40 (pattern A) |
| 1st Trip DTC (clear) | 1 (pattern C), *1 | 1 (pattern C), *1 | 1 (pattern B) |
| 1st Trip Freeze Frame Data (clear) | *1, *2 | *1, *2 | 1 (pattern B) |

For details about patterns “B” and “C” under “Fuel Injection System” and “Misfire”, see EC-75.


For details about patterns “A” and “B” under “Other”, see EC-77.

*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR “MISFIRE” <EXHAUST QUALITY DETERIORATION>, “FUEL INJECTION SYSTEM”

NGEC0033S03



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame

- data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: The 1st trip DTC and the 1st trip

- freeze frame data will be cleared at the moment OK is detected.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

Driving Pattern B

NGEC0033S04

NGEC0033S0401

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MIL will go off when the B counter reaches 3. (*2 in “OBD SYSTEM OPERATION CHART”)

Driving Pattern C

NGEC0033S0402

Driving pattern C means the vehicle operation as follows:

1) The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), “T” should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), “T” should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NGEC0033S05



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC


- and the 1st trip freeze frame data will be stored in ECM.
- *6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NGEC0033S06

NGEC0033S0601

Driving Pattern A



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

Driving Pattern B

NGEC0033S0602


Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CONSULT-II




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


=NGEC0034

NGEC0034S01


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to data link connector for CONSULT-II. (Data link connector for CONSULT-II is located behind the fuse box cover.)



3. Turn ignition switch ON.
4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

CONSULT-II (Cont'd)

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

NGEC0034S02

| Item | | DIAGNOSTIC TEST MODE | | | | | | | | | |
|---------------------------------|-------|---|-------------------------|---------------------|---------------|-------------|------------------------|-------------------|----|----|----|
| | | WORK SUP-PORT | SELF-DIAGNOSTIC RESULTS | | DATA MONI-TOR | ACTIVE TEST | DTC & SRT CONFIRMATION | | | | |
| | | | DTC*1 | FREEZE FRAME DATA*2 | | | SRT STATUS | DTC WORK SUP-PORT | | | |
| ENGINE CONTROL COMPONENT PARTS | INPUT | Camshaft position sensor | | X | X | X | | | | GI | |
| | | Mass air flow sensor | | X | | X | | | | MA | |
| | | Engine coolant temperature sensor | | X | X | X | X | | | | EM |
| | | Front heated oxygen sensor | | X | | X | | X | X | | LC |
| | | Rear heated oxygen sensor | | X | | X | | X | X | | EC |
| | | Vehicle speed sensor | | X | X | X | | | | | FE |
| | | Throttle position sensor | X | X | | X | | | | | CL |
| | | Fuel tank temperature sensor | | X | | X | X | | | | MT |
| | | EVAP control system pressure sensor | | X | | X | | | | | AT |
| | | Absolute pressure sensor | | X | X | X | | | | | TF |
| | | EGR temperature sensor | | X | | X | | | | | PD |
| | | Intake air temperature sensor | | X | | X | | | | | AX |
| | | Crankshaft position sensor (OBD) | | X | | | | | | | SU |
| | | Knock sensor | | X | | | | | | | BR |
| | | Ignition switch (start signal) | | | | X | | | | | ST |
| | | Closed throttle position switch | | X | | X | | | | | RS |
| | | Closed throttle position switch (throttle position sensor signal) | | | | X | | | | | BT |
| | | Air conditioner switch | | | | X | | | | | HA |
| | | Park/Neutral position (PNP) switch | | X | | X | | | | | SC |
| | | Power steering oil pressure switch | | | | X | | | | | EL |
| Air conditioner pressure switch | | | | X | | | | | EL | | |
| Battery voltage | | | | X | | | | | BT | | |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

CONSULT-II (Cont'd)

| Item | | DIAGNOSTIC TEST MODE | | | | | | | |
|---------------------------------------|---|----------------------|-------------------------|---------------------|--------------|-------------|------------------------|-------------------|--|
| | | WORK SUP-PORT | SELF-DIAGNOSTIC RESULTS | | DATA MONITOR | ACTIVE TEST | DTC & SRT CONFIRMATION | | |
| | | | DTC*1 | FREEZE FRAME DATA*2 | | | SRT STATUS | DTC WORK SUP-PORT | |
| ENGINE CONTROL COMPONENT PARTS | OUTPUT | Injectors | | | | X | X | | |
| | Power transistor (Ignition timing) | X | X (Ignition signal) | | X | X | | | |
| | IACV-AAC valve | X | X | | X | X | | | |
| | EVAP canister purge volume control solenoid valve | | X | | X | X | | X | |
| | Air conditioner relay | | | | X | | | | |
| | Fuel pump relay | X | | | X | X | | | |
| | EGRC-solenoid valve | | X | | X | X | | | |
| | Front heated oxygen sensor heater | | X | | X | | X | | |
| | Rear heated oxygen sensor heater | | X | | X | | X | | |
| | Torque converter clutch solenoid valve | | X | | X | | | X | |
| | EVAP canister vent control valve | | X | | X | X | | | |
| | Vacuum cut valve bypass valve | | X | | X | X | | X | |
| | MAP/BARO switch solenoid valve | | X | | X | X | | | |
| | Calculated load value | | | X | X | | | | |

X: Applicable

*1: This item includes 1st trip DTCs.

*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-58.

FUNCTION

NGEC0034S03

| Diagnostic test mode | Function |
|-------------------------|---|
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit. |
| Self-diagnostic results | Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly. *1 |
| Data monitor | Input/Output data in the ECM can be read. |
| Active test | Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range. |
| DTC confirmation | The status of system monitoring tests and the self-diagnosis status/result can be confirmed. |
| ECM part number | ECM part numbers can be read. |

*1 The following emission-related diagnostic information is cleared when the ECM memory is erased.

- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data

- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Others

WORK SUPPORT MODE

NGEC0034S04

| WORK ITEM | CONDITION | USAGE |
|-----------------------|--|---|
| IGNITION TIMING ADJ | <ul style="list-style-type: none"> IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANKSHAFT POSITION SENSOR. | When adjusting initial ignition timing |
| IACV-AAC VALVE ADJ | SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ENGINE WARMED UP NO-LOAD | When adjusting idle speed |
| FUEL PRESSURE RELEASE | <ul style="list-style-type: none"> FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. | When releasing fuel pressure from fuel line |
| EVAP SYSTEM CLOSE | OPEN THE VACUUM CUT VALVE BYPASS VALVE AND CLOSE THE EVAP CANISTER VENT CONTROL VALVE IN ORDER TO MAKE EVAP SYSTEM CLOSE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> BATTERY VOLTAGE IS SUFFICIENT. IGN SW "ON" ENGINE NOT RUNNING AMBIENT TEMPERATURE IS ABOVE 0°C (32°F). NO VACUUM AND NO HIGH PRESSURE IN EVAP SYSTEM TANK FUEL TEMP. IS MORE THAN 0°C (32°F). WITHIN 10 MINUTES AFTER STARTING "EVAP SYSTEM CLOSE" WHEN TRYING TO EXECUTE "EVAP SYSTEM CLOSE" UNDER THE CONDITIONS ABOVE, CONSULT-II WILL DISCONTINUE AND DISPLAY INSTRUCTIONS. <p>NOTE: WHEN STARTING ENGINE, CONSULT-II MAY DISPLAY "BATTERY VOLTAGE IS LOW. CHARGE BATTERY", EVEN WHEN USING A CHARGED BATTERY.</p> | When detecting EVAP vapor leak point of EVAP system |

SELF DIAGNOSTIC MODE

DTC and 1st Trip DTC

NGEC0034S05

Regarding items of "DTC and 1st trip DTC", refer to "TROUBLE DIAGNOSIS — INDEX", EC-13.

Freeze Frame Data and 1st Trip Freeze Frame Data

NGEC0034S0502

| Freeze frame data item* | Description |
|---------------------------|---|
| DIAG TROUBLE CODE [PXXXX] | <ul style="list-style-type: none"> Engine Control component part/control system has a trouble code, it is displayed as "PXXXX". [Refer to "Alphabetical & P No. Index for DTC" (EC-13).] |
| FUEL SYS DATA | <ul style="list-style-type: none"> "Fuel injection system status" at the moment a malfunction is detected is displayed. One mode in the following is displayed. <ul style="list-style-type: none"> "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop |
| CAL/LD VALUE [%] | <ul style="list-style-type: none"> The calculated load value at the moment a malfunction is detected is displayed. |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

CONSULT-II (Cont'd)

| Freeze frame data item* | Description |
|---|---|
| COOLANT TEMP [°C] or [°F] | <ul style="list-style-type: none"> The engine coolant temperature at the moment a malfunction is detected is displayed. |
| S-FUEL TRIM [%] | <ul style="list-style-type: none"> "Short-term fuel trim" at the moment a malfunction is detected is displayed. The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule. |
| L-FUEL TRIM [%] | <ul style="list-style-type: none"> "Long-term fuel trim" at the moment a malfunction is detected is displayed. The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim. |
| ENGINE SPEED [rpm] | <ul style="list-style-type: none"> The engine speed at the moment a malfunction is detected is displayed. |
| VHCL SPEED [km/h] or [mph] | <ul style="list-style-type: none"> The vehicle speed at the moment a malfunction is detected is displayed. |
| ABSOL PRESS [kPa] or [kg/cm ²] or [psi] | <ul style="list-style-type: none"> The absolute pressure at the moment a malfunction is detected is displayed. |

*: The items are the same as those of 1st trip freeze frame data.

DATA MONITOR MODE

NGEC0034S06

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks |
|----------------------------|-------------------|--------------|--|---|
| CMPS-RPM (REF) [rpm] | ○ | ○ | <ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (180° signal) of the camshaft position sensor. | <ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated. |
| MAS AIR/FL SE [V] | ○ | ○ | <ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. |
| COOLAN TEMP/S [°C] or [°F] | ○ | ○ | <ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. | <ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed. |
| FR O2 SENSOR [V] | ○ | ○ | <ul style="list-style-type: none"> The signal voltage of the front heated oxygen sensor is displayed. | |
| RR O2 SENSOR [V] | ○ | ○ | <ul style="list-style-type: none"> The signal voltage of the rear heated oxygen sensor is displayed. | |
| FR O2 MNTR [RICH/LEAN] | ○ | ○ | <ul style="list-style-type: none"> Display of front heated oxygen sensor signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. | <ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously. |
| RR O2 MNTR [RICH/LEAN] | ○ | | <ul style="list-style-type: none"> Display of rear heated oxygen sensor signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

CONSULT-II (Cont'd)

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks |
|-------------------------------|-------------------|--------------|---|---|
| VHCL SPEED SE [km/h] or [mph] | ○ | ○ | <ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. | |
| BATTERY VOLT [V] | ○ | ○ | <ul style="list-style-type: none"> The power supply voltage of ECM is displayed. | |
| THRTL POS SEN [V] | ○ | ○ | <ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. | |
| TANK F/TMP SE [°C] or [°F] | ○ | | <ul style="list-style-type: none"> The fuel temperature judged from the fuel tank temperature sensor signal voltage is displayed. | |
| EGR TEMP SEN [V] | ○ | | <ul style="list-style-type: none"> The signal voltage of the EGR temperature sensor is displayed. | |
| INT/A TEMP SE [°C] or [°F] | ○ | | <ul style="list-style-type: none"> The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated. | |
| START SIGNAL [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. | <ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal. |
| CLSD THL/P SW [ON/OFF] | | | <ul style="list-style-type: none"> Indicates mechanical contact [ON/OFF] condition of the closed throttle position switch. | |
| CLSD THL POS [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal. | |
| AIR COND SIG [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioning signal. | |
| P/N POSI SW [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition from the PNP switch signal. | |
| PW/ST SIGNAL [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure switch signal. | |
| IGNITION SW [ON/OFF] | ○ | | <ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. | |
| INJ PULSE [msec] | | ○ | <ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. | <ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated. |
| B/FUEL SCHDL [msec] | | ○ | <ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. | |
| IGN TIMING [BTDC] | | ○ | <ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. | |
| IACV-AAC/V [%] | | ○ | <ul style="list-style-type: none"> Indicates the IACV-AAC valve control value computed by ECM according to the input signals. | |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

CONSULT-II (Cont'd)

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks |
|--------------------------------|-------------------|--------------|---|--|
| PURG VOL C/V [step] | | ○ | <ul style="list-style-type: none"> Indicates the EVAP canister purge volume control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. | |
| A/F ALPHA [%] | | | <ul style="list-style-type: none"> Indicates the mean value of the air-fuel ratio feedback correction factor per cycle. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control. |
| EVAP SYS PRES [V] | | ○ | <ul style="list-style-type: none"> The signal voltage of EVAP control system pressure sensor is displayed. | |
| AIR COND RLY [ON/OFF] | | | <ul style="list-style-type: none"> Indicates the air conditioner relay control condition determined by ECM according to the input signals. | |
| FUEL PUMP RLY [ON/OFF] | | | <ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. | |
| EGRC SOL/V [ON/OFF] (FLOW/CUT) | | | <ul style="list-style-type: none"> Indicates the control condition of the EGRC-solenoid valve determined by ECM according to the input signals. ON ... EGR valve is operational OFF ... EGR valve operation is cut-off | |
| VENT CONT/V [ON/OFF] | | | <ul style="list-style-type: none"> The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is indicated. ON ... Closed OFF ... Open | |
| FR O2 HEATER [ON/OFF] | | | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of front heated oxygen sensor heater determined by ECM according to the input signals. | |
| RR O2 HEATER [ON/OFF] | | | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of rear heated oxygen sensor heater determined by ECM according to the input signals. | |
| VC/V BYPASS/V [ON/OFF] | | | <ul style="list-style-type: none"> The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ON ... Open OFF ... Closed | |
| CAL/LD VALUE [%] | | | <ul style="list-style-type: none"> "Calculated load value" indicates the value of the current airflow divided by peak airflow. | |
| ABSOL TH-P/S [%] | | | <ul style="list-style-type: none"> "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. | |
| MASS AIRFLOW [gm/s] | | | <ul style="list-style-type: none"> Indicates the mass airflow computed by ECM according to the signal voltage of the mass air flow sensor. | |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

KA24DE

CONSULT-II (Cont'd)

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks |
|-----------------------------|-------------------|--------------|--|---|
| MAP/BARO SW/V [MAP/BARO] | | | <ul style="list-style-type: none"> The control condition of the MAP/BARO switch solenoid valve (determined by ECM according to the input signal) is indicated. MAP ... Intake manifold absolute pressure BARO ... Ambient barometric pressure | |
| ABSOL PRES/SE [V] | | | <ul style="list-style-type: none"> The signal voltage of the absolute pressure sensor is displayed. | |
| VOLTAGE [V] | | | <ul style="list-style-type: none"> Voltage measured by the voltage probe. | |
| PULSE [msec] or [Hz] or [%] | | | <ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. | <ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured. |

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

NGEC0034S07

| TEST ITEM | CONDITION | JUDGEMENT | CHECK ITEM (REMEDY) |
|--------------------|---|--|--|
| FUEL INJECTION | <ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Harness and connector Fuel injectors Front heated oxygen sensor |
| IACV-AAC/V OPENING | <ul style="list-style-type: none"> Engine: After warming up, idle the engine. Change the IACV-AAC valve opening percent using CONSULT-II. | Engine speed changes according to the opening percent. | <ul style="list-style-type: none"> Harness and connector IACV-AAC valve |
| ENG COOLANT TEMP | <ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature indication using CONSULT-II. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor Fuel injectors |
| IGNITION TIMING | <ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Adjust initial ignition timing |
| POWER BALANCE | <ul style="list-style-type: none"> Engine: After warming up, idle the engine. Air conditioner switch “OFF” Shift lever “N” Cut off each injector signal one at a time using CONSULT-II. | Engine runs rough or dies. | <ul style="list-style-type: none"> Harness and connector Compression Injectors Power transistor Spark plugs Ignition coils |
| FUEL PUMP RELAY | <ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay “ON” and “OFF” using CONSULT-II and listen to operating sound. | Fuel pump relay makes the operating sound. | <ul style="list-style-type: none"> Harness and connector Fuel pump relay |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

| |
|---------------|
| KA24DE |
|---------------|

CONSULT-II (Cont'd)

| TEST ITEM | CONDITION | JUDGEMENT | CHECK ITEM (REMEDY) |
|---------------------|--|--|---|
| EGRC SOLENOID VALVE | <ul style="list-style-type: none"> ● Ignition switch: ON ● Turn EGRC-solenoid valve "ON" and "OFF" using CONSULT-II and listen to operating sound. | EGRC-solenoid valve makes an operating sound. | <ul style="list-style-type: none"> ● Harness and connector ● EGRC-solenoid valve |
| SELF-LEARNING CONT | <ul style="list-style-type: none"> ● In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. | | |
| PURG VOL CONT/V | <ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control valve opening step using CONSULT-II. | Engine speed changes according to the opening step. | <ul style="list-style-type: none"> ● Harness and connector ● EVAP canister purge volume control valve |
| TANK F/TEMP SEN | <ul style="list-style-type: none"> ● Change the fuel tank temperature using CONSULT-II. | | |
| VENT CONTROL/V | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" using CONSULT-II and listen to operating sound. | Solenoid valve makes an operating sound. | <ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve |
| VC/V BYPASS/V | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" using CONSULT-II and listen to operating sound. | Solenoid valve makes an operating sound. | <ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve |
| MAP/BARO SW/V | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the MAP/BARO switch solenoid valve between "MAP" and "BARO" using CONSULT-II and listen to operating sound. | MAP/BARO switch solenoid valve makes an operating sound. | <ul style="list-style-type: none"> ● Harness and connector ● MAP/BARO switch solenoid valve |

DTC & SRT CONFIRMATION MODE

=NGEC0034S08

SRT STATUS Mode

NGEC0034S0801

For details, refer to "SYSTEM READINESS TEST (SRT) CODE", EC-58.

DTC Work Support Mode

NGEC0034S0802

| TEST MODE | TEST ITEM | CONDITION | REFERENCE PAGE |
|--------------------|-----------------------|---|----------------|
| EVAPORATIVE SYSTEM | EVAP SML LEAK P0440 | Refer to corresponding trouble diagnosis for DTC. | EC-351 |
| | EVAP SML LEAK P1440 | | EC-485 |
| | PURG VOL CN/V P1444 | | EC-487 |
| | PURGE FLOW P1447 | | EC-505 |
| | VC CUT/V BP/V P1491 | | EC-530 |
| | PURG CN/V & S/V P1493 | | EC-367 |
| FR O2 SENSOR | FR O2 SENSOR P0130 | | EC-190 |
| | FR O2 SENSOR P0131 | | EC-198 |
| | FR O2 SENSOR P0132 | | EC-205 |
| | FR O2 SENSOR P0133 | | EC-212 |
| RR O2 SENSOR | RR O2 SENSOR P0137 | | EC-235 |
| | RR O2 SENSOR P0138 | | EC-245 |
| | RR O2 SENSOR P0139 | | EC-255 |
| EGR SYSTEM | EGR SYSTEM P0400 | EC-326 | |
| | EGRC-BPT/VLV P0402 | EC-338 | |
| | EGR SYSTEM P1402 | EC-476 | |

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)


NGEC0034S10

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.


- 1) "AUTO TRIG" (Automatic trigger):
 - The malfunction will be identified on the CONSULT-II screen in real time.
In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.
At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at left, and the data after the malfunction detection is recorded. Then the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.
The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "RECORDING Speed". Refer to CONSULT-II OPERATION MANUAL.
- 2) "MANU TRIG" (Manual trigger):
 - DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.
DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

- 1) "AUTO TRIG"
 - While trying to detect the DTC/1st trip DTC by performing the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
 - While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "Incident Simulation Tests" in "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT", *GI-24*.)
- 2) "MANU TRIG"
 - If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



SEF720X



Generic Scan Tool (GST)

NGEC0035


DESCRIPTION

NGEC0035S01

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 8 different functions explained on the next page.

ISO9141 is used as the protocol.


The name "GST" or "Generic Scan Tool" is used in this service manual.



GST INSPECTION PROCEDURE


NGEC0035S02

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector for GST. (Data link connector for GST is located under LH dash panel near the fuse box cover.)



3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION




KA24DE

Generic Scan Tool (GST) (Cont'd)

FUNCTION

NGEC0035S03

| Diagnostic test mode | | Function |
|----------------------|------------------|---|
| MODE 1 | READINESS TESTS | This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information. |
| MODE 2 | (FREEZE DATA) | This mode gains access to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze Frame Data" (EC-81).] |
| MODE 3 | DTCs | This mode gains access to emission-related power train trouble codes which were stored by ECM. |
| MODE 4 | CLEAR DIAG INFO | This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7) |
| MODE 6 | (ON BOARD TESTS) | This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored. |
| MODE 7 | (ON BOARD TESTS) | This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions. |
| MODE 8 | — | — |
| MODE 9 | (CALIBRATION ID) | This mode is to enable the off-board to request vehicle specific information such as Vehicle Identification Number (VIN) and Calibration ID. |



KEY POINTS

- WHAT** Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

SEF907L

Introduction

NGEC0036

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on EC-93.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

DIAGNOSTIC WORKSHEET

NGEC0036S01

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.


Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the malfunction indicator lamp to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere [for the models with EVAP (SMALL LEAK) diagnosis].

Work Flow

NGEC0037



*1: If the incident cannot be duplicated, refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.
 *2: If the on board diagnostic system cannot be performed, check main power supply and ground circuit.

Refer to "TROUBLE DIAGNOSIS FOR POWER SUPPLY", EC-129.
 *3: If time data of "SELF-DIAG RESULTS" is other than "0" or "1t" refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT", EC-128.
 *4: If the malfunctioning part cannot

be found, refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.
 *5: EC-110
 *6: EC-63

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

SEF944VB

DESCRIPTION FOR WORK FLOW

NGEC0037S01

| STEP | DESCRIPTION |
|----------|---|
| STEP I | Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-92. |
| STEP II | <p>Before confirming the concern, check and write down (print out using CONSULT-II or Generic Scan Tool) the (1st trip) Diagnostic Trouble Code (DTC) and the (1st trip) freeze frame data, then erase the code and the data. (Refer to EC-67.) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV.</p> <p>Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-111.)</p> <p>Also check related service bulletins for information.</p> |
| STEP III | <p>Try to confirm the symptom and under what conditions the incident occurs.</p> <p>The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.</p> <p>If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.)</p> <p>If the malfunction code is detected, skip STEP IV and perform STEP V.</p> |
| STEP IV | <p>Try to detect the (1st trip) Diagnostic Trouble Code by driving in (or performing) the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or Generic Scan Tool.</p> <p>During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.</p> <p>If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.)</p> <p>In case the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" is not available, perform the "OVERALL FUNCTION CHECK" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative.</p> <p>The "NG" result of the "OVERALL FUNCTION CHECK" is the same as the (1st trip) DTC detection.</p> |
| STEP V | <p>Take the appropriate action based on the results of STEP I through IV.</p> <p>If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX.</p> <p>If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-95.) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-111.)</p> |
| STEP VI | <p>Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode.</p> <p>Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-120.</p> <p>The "DIAGNOSTIC PROCEDURE" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the DIAGNOSTIC PROCEDURE. For details, refer to "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT", "Circuit Inspection", GI-26.</p> <p>Repair or replace the malfunction parts.</p> |
| STEP VII | <p>Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint.</p> <p>Perform the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" and confirm the normal code [Diagnostic trouble code No. P0000 or 0505] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one.</p> <p>Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM. (Refer to EC-67.)</p> |

Basic Inspection

NGEC0038

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT


HA


SC


EL

IDX

| | | |
|--|-------------------------|----------|
| 1 | INSPECTION START | |
| <p>1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.</p> <p>2. Open engine hood and check the following:</p> <ul style="list-style-type: none"> ● Harness connectors for improper connections ● Vacuum hoses for splits, kinks, or improper connections ● Wiring for improper connections, pinches, or cuts | | |
|  | | |
| SEF142I | | |
| With CONSULT-II | ▶ | GO TO 2. |
| With GST | ▶ | GO TO 4. |
| No tools | ▶ | GO TO 5. |

| | | |
|---|--|------------|
| 2 | CONNECT CONSULT-II TO THE VEHICLE | |
| <p>Connect "CONSULT-II" to the data link connector and select "ENGINE" from the menu. Refer to EC-78.</p> | | |
|  | | |
| SEF163X | | |
| | | ▶ GO TO 3. |


| | | | |
|--|------------------------------|--|--|
| 3 | CHECK FI CAM FUNCTION | | |
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Adjust accelerator wire. Refer to “Adjust Accelerator Wire”, FE-3. 2. Warm up engine to 75°C (167°F). 3. Stop engine and wait at least 5 seconds, then turn ignition switch ON. 4. Select “COOLAN TEMP/S” in “DATA MONITOR” mode with CONSULT-II. 5. When the engine coolant temp is 75 to 85°C (167 to 185°F), confirm the clearance is less than 0.05mm (0.002in), between stopper and throttle drum as shown in the figure. | | | |
|  | | | |
| AEC871A | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 6. | |
| NG | ▶ | Replace throttle body assembly. Refer to “OUTER COMPONENT PARTS”, EM-12 . | |

| | | | |
|---|------------------------------|--|--|
| 4 | CHECK FI CAM FUNCTION | | |
| <p> With GST</p> <ol style="list-style-type: none"> 1. Adjust accelerator wire. Refer to “Adjust Accelerator Wire”, FE-3. 2. Warm up engine to 75°C (167°F). 3. Stop engine and wait at least 10 seconds, then turn ignition switch ON. 4. Select “MODE 1” with GST. 5. When the engine coolant temp is 75 to 85°C (167 to 185°F), confirm the clearance is less than 0.05mm (0.002in), between stopper and throttle drum as shown in the figure. | | | |
|  | | | |
| AEC871A | | | |
| OK or NG | | | |
| OK (With CONSULT-II) | ▶ | GO TO 6. | |
| OK (Without CONSULT-II) | ▶ | GO TO 14. | |
| NG | ▶ | Replace throttle body assembly. Refer to “OUTER COMPONENT PARTS”, EM-12 . | |

5 CHECK FI CAM FUNCTION


No Tools

1. Adjust accelerator wire. Refer to "Adjust Accelerator Wire", **FE-3**.
2. Disconnect engine coolant temperature sensor harness connector and check resistance as shown in the figure.



SEF536H

3. Warm up engine until the resistance of coolant temperature sensor is 0.26 to 0.39 kΩ.
4. Turn ignition switch OFF.
5. When engine coolant temperature is 75 to 85°C (167 to 185°F), with the voltage between 1.10 to 1.36V, make sure that the clearance is less than 0.05mm (0.002in), between stopper and throttle adjusting screw as shown in figure.



AEC871A

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 14. |
| NG | ▶ | Replace throttle body assembly. Refer to "OUTER COMPONENT PARTS", EM-12 . |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

6 CHECK IGNITION TIMING

Ⓜ With CONSULT-II


1. Warm up engine to normal operating temperature.
2. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode.
3. Touch "START".

IGNITION TIMING ADJ

IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.

PEF546N

4. Check ignition timing at idle using timing light.



SEF320V

Ignition timing:
 $20^{\circ} \pm 2^{\circ}$ BTDC (in "P" or "N" position)

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 7. |
| NG | ▶ | <ol style="list-style-type: none"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. 2. GO TO 7. |

| | | | | | | | | | | | | | | | | | | | | | | | | |
|--|------------------------------|--|----------------|--|-------------|--|---------------|---------|-------------------|--|------------|-------|--|--|--|--|---------|--|----------------|-------|--------------|-------|--|--|
| 7 | CHECK BASE IDLE SPEED | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Ⓟ With CONSULT-II</p> <p>1. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode and touch "START".</p> | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">IACV-AAC/V ADJ</td></tr> <tr><td colspan="2" style="text-align: center;">ADJ MONITOR</td></tr> <tr><td style="text-align: center;">CMPS-RPM(POS)</td><td style="text-align: center;">700 rpm</td></tr> <tr><td colspan="2" style="text-align: center;">CONDITION SETTING</td></tr> <tr><td style="text-align: center;">IACV-ACC/V</td><td style="text-align: center;">FIXED</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">COOLANT TEMP/S</td><td style="text-align: center;">XXX°C</td></tr> <tr><td style="text-align: center;">CLSD THL POS</td><td style="text-align: center;">XXX N</td></tr> <tr><td> </td><td> </td></tr> </table> | | | IACV-AAC/V ADJ | | ADJ MONITOR | | CMPS-RPM(POS) | 700 rpm | CONDITION SETTING | | IACV-ACC/V | FIXED | | | | | MONITOR | | COOLANT TEMP/S | XXX°C | CLSD THL POS | XXX N | | |
| IACV-AAC/V ADJ | | | | | | | | | | | | | | | | | | | | | | | | |
| ADJ MONITOR | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(POS) | 700 rpm | | | | | | | | | | | | | | | | | | | | | | | |
| CONDITION SETTING | | | | | | | | | | | | | | | | | | | | | | | | |
| IACV-ACC/V | FIXED | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | |
| COOLANT TEMP/S | XXX°C | | | | | | | | | | | | | | | | | | | | | | | |
| CLSD THL POS | XXX N | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>2. Check idle speed. 750±50 rpm (in "P" or "N" position)</p> | | PEF120W | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | 1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. 2. GO TO 8. | | | | | | | | | | | | | | | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


8 CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION (CHECK THROTTLE POSITION SENSOR IDLE POSITION)

With CONSULT-II

NOTE:

Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Check FI cam. Refer to procedure 3.
3. Stop engine.
4. Turn ignition switch ON.
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Select "CLSD THL/P SW" from the menu.
7. Read "CLSD THL/P SW" signal under the following conditions.
 - Insert a 0.1 mm (0.004 in) and 0.3 mm (0.012 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure and check the signal.



AEC871A

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CLSD THL/P SW | OFF |

PEF122W

"CLSD THL/P SW" signal should remain "ON" while inserting 0.1 mm (0.004 in) feeler gauge.
 "CLSD THL/P SW" signal should remain "OFF" while inserting 0.3 mm (0.012 in) feeler gauge.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | GO TO 9. |


9 ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-1

Ⓟ With CONSULT-II

NOTE:

- Never adjust throttle adjust screw (TAS).
- Do not touch throttle drum when checking "CLSD THL/P SW" signal.
Doing so may cause an incorrect adjustment.

1. Warm engine up to normal operating temperature.
2. Check FI cam. Refer to procedure 3.
3. Stop engine.
4. Loosen throttle position sensor fixing bolts.
5. Turn ignition switch ON.
6. Select "CLSD THL/P SW" in "DATA MONITOR" mode.
7. Insert a 0.1 mm (0.004 in) feeler gauge between throttle adjust screw and throttle drum as shown in the figure.



AEC871A

8. Open throttle valve and then close.
9. Check "CLSD THL/P SW" signal.

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CLSD THL/P SW | OFF |

PEF122W

"CLSD THL/P SW" signal should remain "OFF" when the throttle valve is closed.

If it is impossible to adjust closed throttle position switch, replace throttle position sensor.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 11. |
| NG | ▶ | GO TO 10. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



| | |
|---|--|
| 10 | ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-2 |
| <p> With CONSULT-II Turn throttle position sensor body counterclockwise until "CLSD THL/P SW" signal switches to "OFF".</p> | |
| | |
| AEC872A | |
| ▶ | GO TO 11. |

| | |
|--|---|
| 11 | ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-3 |
| <p> With CONSULT-II</p> <p>1. Temporarily tighten sensor body fixing bolts as follows.</p> <ul style="list-style-type: none"> ● Gradually move the sensor body clockwise and stop it when "CLSD THL/P SW" signal switches from "OFF" to "ON" when tightening sensor body fixing bolts. | |
| | |
| AEC872A | |
| <p>2. Make sure two or three times that the signal is "ON" when the throttle valve is closed and "OFF" when it is opened.</p> <p>3. Remove 0.1 mm (0.004 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.</p> <p>4. Make sure two or three times that the signal remains "OFF" when the throttle valve is closed.</p> <p>5. Tighten throttle position sensor.</p> <p>6. Check "CLSD THL/P SW" signal again.</p> <p style="margin-left: 20px;">The signal remains "OFF" while closing throttle valve.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ 1. Remove 0.3 mm (0.012 in) feeler gauge. 2. GO TO 12. |
| NG | ▶ GO TO 9. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| 12 | RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY | | | | | | |
|---|--|--------------|--|------------|---------|--------------|----|
| <p>Ⓟ With CONSULT-II NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <ol style="list-style-type: none"> 1. Start engine. 2. Warm up engine to normal operating temperature. 3. Select "CLSD THL POS" in "DATA MONITOR" mode manual trigger. 4. Stop engine. (Turn ignition switch OFF.) 5. Turn ignition switch ON and wait at least 5 seconds. <div style="text-align: center; margin: 10px 0;"> <p>The diagram illustrates the components involved in the reset procedure. On the left, two throttle levers are shown, one labeled 'P' and the other 'N', with the word 'or' between them. In the center, an ignition switch is shown in two positions: 'ON' and 'OFF', connected by a double-headed arrow. Above the ignition switch, there are symbols for a throttle cable (C to H) and an engine block.</p> </div> <ol style="list-style-type: none"> 6. Turn ignition switch OFF and wait at least 5 seconds. 7. Repeat steps 5 and 6 until "CLSD THL POS" in "DATA MONITOR" mode with CONSULT-II changes to "ON". <div style="text-align: right; margin-top: 10px;">SEF864V</div> | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;">NO FAIL</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">CLSD THL POS</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table> <div style="text-align: right; margin-top: 10px;">PEF123W</div> | | DATA MONITOR | | MONITORING | NO FAIL | CLSD THL POS | ON |
| DATA MONITOR | | | | | | | |
| MONITORING | NO FAIL | | | | | | |
| CLSD THL POS | ON | | | | | | |
| <p style="margin: 0;">▶ GO TO 13.</p> | | | | | | | |

| | |
|--|--|
| 13 | CHECK TARGET IDLE SPEED |
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "CMPS-RPM (REF)" in "DATA MONITOR" mode. 3. Check idle speed. 800±50 rpm (in "P" or "N" position) <p style="text-align: center; margin-top: 10px;">OK or NG</p> | |
| OK | ▶ INSPECTION END |
| NG | ▶ Adjust idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. |

| | |
|---|---|
| 14 | CHECK IGNITION TIMING |
| <p>⊗ Without CONSULT-II</p> <p>1. Warm up engine to normal operating temperature. 2. Stop engine and disconnect throttle position sensor harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF265S</p> <p>3. Start engine. 4. Rev engine (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed. 5. Check ignition timing at idle using timing light.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF320V</p> <p>Ignition timing: $20^{\circ} \pm 2^{\circ}$ BTDC (in "P" or "N" position)</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 15. |
| NG | ▶ 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. 2. GO TO 15. |

| | |
|---|---|
| 15 | CHECK BASE IDLE SPEED |
| <p>⊗ Without CONSULT-II</p> <p>Make sure that engine speed falls to the following speed.</p> <p>M/T: 750±50 rpm A/T: 750±50 rpm (in "P" or "N" position)</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 16. |
| NG | ▶ 1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. 2. GO TO 16. |



16 CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION (CHECK THROTTLE POSITION SENSOR IDLE POSITION)

Without CONSULT-II

NOTE:


Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Check FI cam. Refer to procedure 5.
3. Stop engine.
4. Disconnect closed throttle position switch harness connector .
5. Connect the tester probe to closed throttle position switch terminals 5 and 6.
6. Check harness continuity under the following conditions.



SEF862V

- Insert the 0.1 mm (0.004 in) and 0.3 mm (0.012 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure.



AEC871A

“Continuity should exist” while inserting 0.1 mm (0.004 in) feeler gauge.
“Continuity should not exist” while inserting 0.3 mm (0.012 in) feeler gauge.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 18. |
| NG | ▶ | GO TO 17. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


17 ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-1

⊗ Without CONSULT-II

NOTE:

- Never adjust throttle adjust screw (TAS).
- Do not touch throttle drum when checking "continuity".
Doing so may cause an incorrect adjustment.

1. Warm engine up to normal operating temperature.
2. Check FI cam. Refer to procedure 5.
3. Stop engine.
4. Loosen throttle position sensor fixing bolts.
5. Disconnect closed throttle position sensor harness connector.
6. Insert 0.1 mm (0.004 in) feeler gauge between the throttle adjust screw and throttle drum as shown in the figure.




AEC871A

7. Open throttle valve then close.
8. Check continuity between closed throttle position switch terminal 5 and 6.



DISCONNECT

Closed throttle position
switch connector


SEF862V

The continuity should not exist while closing the throttle position sensor body.


If it is impossible to adjust closed throttle position switch, replace throttle position sensor.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 19. |
| NG | ▶ | GO TO 18. |

| | |
|--|--|
| 18 | ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-2 |
| <p>⊗ Without CONSULT-II Turn throttle position sensor body counterclockwise until continuity does not exist.</p> | |
|  | |
| AEC872A | |
| ▶ | GO TO 19. |

GI
 MA
 EM
 LC
EC

| | |
|---|--|
| 19 | ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-3 |
| <p>⊗ Without CONSULT-II 1. Temporarily tighten sensor body fixing bolts as follows. ● Gradually move the sensor body clockwise and stop it when the continuity comes to exist, then tighten sensor body fixing bolts.</p> | |
|  | |
| AEC872A | |
| <p>2. Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened. 3. Remove 0.1 mm (0.004 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge. 4. Make sure two or three times that continuity does not exist when the throttle valve is closed. 5. Tighten throttle position sensor. 6. Check the continuity again. Continuity does not exist while closing the throttle valve.</p> | |
| OK or NG | |
| OK | ▶ GO TO 20. |
| NG | ▶ GO TO 17. |

FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS

| | |
|---|-----------------------|
| 20 | REINSTALLATION |
| <p>⊗ Without CONSULT-II 1. Remove 0.3 mm (0.012 in) feeler gauge. 2. Reconnect throttle position sensor harness connector and closed throttle position switch harness connector. 3. Rev engine (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed.</p> | |
| ▶ | GO TO 21. |

BT
 HA
 SC
 EL
 IDX

| | |
|---|--|
| 21 | RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY |
| <p>⊗ Without CONSULT-II</p> <p>NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <ol style="list-style-type: none"> 1. Start engine. 2. Warm up engine to normal operating temperature. 3. Stop engine. (Turn ignition switch "OFF".) 4. Turn ignition switch "ON" and wait at least 5 seconds. <div style="text-align: center; margin: 10px 0;"> <p>The diagram illustrates the components for step 4: a throttle lever with 'P' and 'N' positions, an ignition switch with 'ON' and 'OFF' positions, and a car icon. A double-headed arrow connects the 'ON' and 'OFF' positions of the ignition switch.</p> </div> <p style="text-align: right; margin-right: 50px;">SEF864V</p> <ol style="list-style-type: none"> 5. Turn ignition switch "OFF" and wait at least 5 seconds. 6. Repeat steps 4 and 5, 20 times. | |
| ▶ | GO TO 22. |

| | | | | | | | |
|--|--------------------------------|--|---|-----------|----|---|--|
| 22 | CHECK TARGET IDLE SPEED | | | | | | |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Check idle speed. 800±50 rpm (in "P" or "N" position) <p style="text-align: center; margin: 10px 0;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 5px;">OK</td> <td style="width: 10%; text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">GO TO 23.</td> </tr> <tr> <td style="padding: 5px;">NG</td> <td style="text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;"> 1. Adjust target idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. 2. GO TO 23. </td> </tr> </table> | | OK | ▶ | GO TO 23. | NG | ▶ | 1. Adjust target idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. 2. GO TO 23. |
| OK | ▶ | GO TO 23. | | | | | |
| NG | ▶ | 1. Adjust target idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-42. 2. GO TO 23. | | | | | |

| | |
|--|------------------------------|
| 23 | ERASE UNNECESSARY DTC |
| <p>After this inspection, unnecessary DTC No. might be displayed. Erase the stored memory in ECM and TCM. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", (EC-67) .</p> | |
| ▶ | INSPECTION END |

DTC Inspection Priority Chart

NGEC0039

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | Detected items (DTC) | |
|----------|--|---|
| 1 | <ul style="list-style-type: none"> ● P0100 Mass air flow sensor (0102) ● P0110 Intake air temperature sensor (0401) ● P0115, P0125 Engine coolant temperature sensor (0103) (0908) ● P0120 Throttle position sensor (0403) ● P0180 Fuel tank temperature sensor (0402) ● P0325 Knock sensor (0304) ● P0340 Camshaft position sensor (0101) ● P0500 Vehicle speed sensor (0104) ● P0605 ECM (0301) ● P1320 Ignition signal (0201) ● P1400 EGRC-solenoid valve (1005) ● P1706 Park/neutral position switch (1003) | GI MA EM LC <div style="background-color: black; color: white; padding: 5px; text-align: center;">EC</div> |
| 2 | <ul style="list-style-type: none"> ● P0105 Absolute pressure sensor (0803) ● P0130 - P0134 Front heated oxygen sensor (0303 - 0412) ● P0135 Front heated oxygen sensor heater (0901) ● P0137 - P0140 Rear heated oxygen sensor (0510 - 0707) ● P0141 Rear heated oxygen sensor heater (0902) ● P0335, P1336 Crankshaft position sensor (OBD) (0802) (0905) ● P0443, P1444 EVAP canister purge volume control solenoid valve (1008), (0214) ● P0446, P1446, P1448 EVAP canister vent control valve (0903), (0215), (0309) ● P0450 EVAP control system pressure sensor (0704) ● P0510 Closed throttle position switch (0203) ● P1105 MAP/BARO switch solenoid valve (1302) ● P1401 EGR temperature sensor (0305) ● P1447 EVAP control system purge flow monitoring (0111) ● P1490, P1491 Vacuum cut valve bypass valve (0801) (0311) | FE CL MT AT TF |
| 3 | <ul style="list-style-type: none"> ● P0172, P0171 Fuel injection system function (0114), (0115) ● P0300 - P0304 Misfire (0701 - 0605) ● P0400, P1402 EGR function (0302) (0514) ● P0402 EGRC-BPT valve function (0306) ● P0420 Three way catalyst function (0702) ● P0440, P1440, P0445 EVAP control system (SMALL LEAK) (0705) (0213), (GROSS LEAK) (0715) ● P0505 IACV-AAC valve (0205) ● P1148 Closed loop control (0307) | PD AX SU |

GI

 MA

 EM

 LC

EC

 FE

 CL

 MT

 AT

 TF

 PD

 AX

 SU

 BR

 ST

 RS

 BT

 HA

 SC

 EL

 IDX

Fail-safe Chart

=NGEC0040

The ECM enters fail-safe mode if any of the following malfunctions is detected due to the open or short circuit. When the ECM enters the fail-safe mode, the MIL illuminates.

| DTC No. | | Detected items | Engine operating condition in fail-safe mode | | | | | | | | | | | | | |
|----------------------|---|---|---|---|--|-------------------------|---------------------|---|----------------|--|-----------------|--|-----------|---|----------------|-----------|
| CONSULT-II GST | ECM*1 | | | | | | | | | | | | | | | |
| P0100 | 0102 | Mass air flow sensor circuit | Engine speed will not rise more than 2,400 rpm due to the fuel cut. | | | | | | | | | | | | | |
| P0110 | 0401 | Intake air temperature sensor | The ECM functions on the assumption that the intake air temperature is 25°C (77°F). | | | | | | | | | | | | | |
| P0115 | 0103 | Engine coolant temperature sensor circuit | Engine coolant temperature will be determined by ECM based on the time after turning ignition switch to ON or START. CONSULT-II displays the engine coolant temperature decided by ECM. | | | | | | | | | | | | | |
| | | | Condition | Engine coolant temperature decided (CONSULT-II display) | | | | | | | | | | | | |
| | | | Just as ignition switch is turned to ON or Start | 40°C (104°F) | | | | | | | | | | | | |
| | | | More than approx. 4 minutes after ignition ON or Start | 80°C (176°F) | | | | | | | | | | | | |
| | | | Except as shown above | 40 - 80°C (104 - 176°F) (Depends on the time) | | | | | | | | | | | | |
| P0120 | 0403 | Throttle position sensor circuit | Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor. | | | | | | | | | | | | | |
| | | | Condition | Driving condition | | | | | | | | | | | | |
| | | | When engine is idling | Normal | | | | | | | | | | | | |
| | | | When accelerating | Poor acceleration | | | | | | | | | | | | |
| Unable to access ECM | Unable to access Diagnostic Test Mode II | ECM | <p>ECM fail-safe activating condition The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MIL on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed.</p> <p>Engine control with fail-safe When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation and IACV-AAC valve operation are controlled under certain limitations.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td></td> <td style="text-align: center;">ECM fail-safe operation</td> </tr> <tr> <td style="text-align: center;">Engine speed</td> <td style="text-align: center;">Engine speed will not rise more than 3,000 rpm</td> </tr> <tr> <td style="text-align: center;">Fuel injection</td> <td>Simultaneous multiport fuel injection system</td> </tr> <tr> <td style="text-align: center;">Ignition timing</td> <td>Ignition timing is fixed at the preset valve</td> </tr> <tr> <td style="text-align: center;">Fuel pump</td> <td>Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls</td> </tr> <tr> <td style="text-align: center;">IACV-AAC valve</td> <td style="text-align: center;">Full open</td> </tr> </table> <p>Replace ECM, if ECM fail-safe condition is confirmed.</p> | | | ECM fail-safe operation | Engine speed | Engine speed will not rise more than 3,000 rpm | Fuel injection | Simultaneous multiport fuel injection system | Ignition timing | Ignition timing is fixed at the preset valve | Fuel pump | Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls | IACV-AAC valve | Full open |
| | ECM fail-safe operation | | | | | | | | | | | | | | | |
| Engine speed | Engine speed will not rise more than 3,000 rpm | | | | | | | | | | | | | | | |
| Fuel injection | Simultaneous multiport fuel injection system | | | | | | | | | | | | | | | |
| Ignition timing | Ignition timing is fixed at the preset valve | | | | | | | | | | | | | | | |
| Fuel pump | Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls | | | | | | | | | | | | | | | |
| IACV-AAC valve | Full open | | | | | | | | | | | | | | | |

*: In Diagnostic Test Mode II (Self-diagnostic results)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

Symptom Matrix Chart

Symptom Matrix Chart SYSTEM — ENGINE CONTROL SYSTEM

NGEC0041
NGEC0041S01

| | | SYMPTOM | | | | | | | | | | | Reference page | | |
|--------------------------------------|---------------------------------------|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|---------------------------------|----------------------------|----------------|---------------------------|-----------------------------|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEAT/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | | EXCESSIVE OIL CONSUMPTION | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Fuel | Fuel pump circuit | 1 | 1 | 2 | 3 | 2 | | 2 | 2 | | | 3 | | 2 | EC-561 |
| | Fuel pressure regulator system | 3 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | | 4 | | | EC-41 |
| | Injector circuit | 1 | 1 | 2 | 3 | 2 | | 2 | 2 | | | 2 | | | EC-553 |
| | Evaporative emission system | 3 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | | 4 | | | EC-34 |
| Air | Positive crankcase ventilation system | 3 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | | 4 | 1 | | EC-39 |
| | Incorrect idle speed adjustment | 3 | 3 | | | | 1 | 1 | 1 | 1 | | 1 | | | EC-42 |
| | IACV-AAC valve circuit | 1 | 1 | 2 | 3 | 3 | 2 | 2 | 2 | 2 | | 2 | | 2 | EC-416 |
| | IACV-FICD solenoid valve circuit | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | | 3 | | | EC-573 |
| Ignition | Incorrect ignition timing adjustment | 3 | 3 | 1 | 1 | 1 | | 1 | 1 | | | 1 | | | EC-42 |
| | Ignition circuit | 1 | 1 | 2 | 2 | 2 | | 2 | 2 | | | 2 | | | EC-449 |
| EGR | EGRC-solenoid valve circuit | | 2 | 2 | 3 | 3 | | | | | | 3 | | | EC-463 |
| | EGR system | 2 | 1 | 2 | 3 | 3 | 3 | 2 | 2 | 3 | | 3 | | | EC-326, 338, 476 |
| Main power supply and ground circuit | | 2 | 2 | 3 | 3 | 3 | | 3 | 3 | | 2 | 3 | | 2 | EC-129 |
| Air conditioner circuit | | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | | 3 | | 2 | HA-22 |

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

Symptom Matrix Chart (Cont'd)

| | SYMPTOM | | | | | | | | | | | | | Reference page |
|---|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|-----------------------------|-------------------|
| | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | BATTERY DEAD (UNDER CHARGE) | |
| Warranty symptom code | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Camshaft position sensor circuit | 2 | 2 | 3 | 3 | 3 | | 3 | 3 | | | 3 | | | EC-318 |
| Mass air flow sensor circuit | 1 | 1 | 2 | 2 | 2 | | 2 | 2 | | | 2 | | | EC-136 |
| Front heated oxygen sensor circuit | | 1 | 2 | 3 | 2 | | 2 | 2 | | | 2 | | | EC-190, 198 |
| Engine coolant temperature sensor circuit | 1 | 1 | 2 | 3 | 2 | 3 | 2 | 2 | 3 | | 2 | | | EC-167, 186 |
| Throttle position sensor circuit | | 1 | 2 | | 2 | 2 | 2 | 2 | 2 | | 2 | | | EC-172 |
| Incorrect throttle position sensor adjustment | | 3 | 1 | | 1 | 1 | 1 | 1 | 1 | | 1 | | | EC-95 |
| Vehicle speed sensor circuit | | 2 | 3 | | 3 | | | | | | 3 | | | EC-412 |
| Knock sensor circuit | | | 2 | | | | | | | | 3 | | | EC-308 |
| ECM | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | | | EC-429, 110 |
| Start signal circuit | 2 | | | | | | | | | | | | | EC-558 |
| PNP switch circuit | | | 3 | | 3 | | 3 | 3 | | | 3 | | | EC-541 |
| Power steering oil pressure switch circuit | | 2 | | | | | 3 | 3 | | | | | | EC-569 |

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

Symptom Matrix Chart (Cont'd)

SYSTEM — ENGINE MECHANICAL & OTHER

NGEC0041S03

| | | SYMPTOM | | | | | | | | | | | Reference page | | | |
|-----------------------|--|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|-------------------|---------------------------|-----------------------------|---|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | | EXCESSIVE OIL CONSUMPTION | BATTERY DEAD (UNDER CHARGE) | |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | | |
| Fuel | Fuel tank | 5 | 5 | | | | | | | | | | | | FE-4 | |
| | Fuel piping | | | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | | |
| | Vapor lock | | | | | | | | | | | | | | | |
| | Valve deposit | | | | | | | | | | | | | | | |
| | Poor fuel (Heavy weight gasoline, Low octane) | 5 | | | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | — |
| Air | Air duct | | | | | | | | | | | | | | | |
| | Air cleaner | | | | | | | | | | | | | | | |
| | Air leakage from air duct (Mass air flow sensor — throttle body) | | 5 | 5 | | 5 | | 5 | 5 | | | 5 | | | | |
| | Throttle body, Throttle wire | 5 | | | 5 | | 5 | | | 5 | | | | | FE-3 | |
| | Air leakage from intake manifold/Collector/Gasket | | | | | | | | | | | | | | — | |
| Cranking | Battery | 1 | 1 | 1 | | 1 | | 1 | 1 | | | | | 1 | SC-2 | |
| | Alternator circuit | | | | | | | | | | | | | | | |
| | Starter circuit | 3 | | | | | | | | | | 1 | | | | |
| | Flywheel/Drive plate | 6 | | | | | | | | | | | | | EM-52 | |
| | PNP switch | 4 | | | | | | | | | | | | | — | |

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

Symptom Matrix Chart (Cont'd)

| | | SYMPTOM | | | | | | | | | | | | Reference page | |
|-----------------------|--|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|-------------------|-----------------------------|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Engine | Cylinder head | | | | | | | | | | | | | | EM-29, EM-44 |
| | Cylinder head gasket | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | 4 | 5 | 3 | | |
| | Cylinder block | | | | | | | | | | | | 4 | | |
| | Piston | | | | | | | | | | | | | | |
| | Piston ring | | | | | | | | | | | | | | |
| | Connecting rod | 6 | 6 | 6 | 6 | 6 | | 6 | 6 | | | 6 | | | |
| | Bearing | | | | | | | | | | | | | | |
| | Crankshaft | | | | | | | | | | | | | | |
| Valve mechanism | Timing chain | | | | | | | | | | | | | | EM-18, EM-29 |
| | Camshaft | | | | | | | | | | | | | | |
| | Intake valve | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | |
| | Exhaust valve | | | | | | | | | | | | 3 | | |
| Exhaust | Exhaust manifold/Tube/Muffler/Gasket | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | FE-8 |
| | Three way catalyst | | | | | | | | | | | | | | |
| Lubrication | Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | MA-21, LC-6 |
| | Oil level (Low)/Filthy oil | | | | | | | | | | | | | | |
| Cooling | Radiator/Hose/Radiator filler cap | | | | | | | | | | | | | | LC-11 |
| | Thermostat | | | | | | | | | 5 | | | | | |
| | Water pump | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | 4 | 5 | | | |
| | Water gallery | | | | | | | | | | | | | | |
| | Coolant level (low)/Contaminated coolant | | | | | | | | | | | | | | |

1 - 6: The numbers refer to the order of inspection.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0042

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.

* Specification data may not be directly related to their components signals/values/operations.

(i.e., Adjust ignition timing with a timing light before monitoring IGN TIMING. Specification data might be displayed even when ignition timing is not adjusted to specification. This IGN TIMING monitors the data calculated by the ECM according to the input signals from the camshaft position sensor and other ignition timing related sensors.)

- If the real-time diagnosis results are NG, and the on board diagnostic system results are OK, when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|----------------|--|---|
| CMPS-RPM (REF) | <ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value. | Almost the same speed as the CONSULT-II value. |
| MAS AIR/FL SE | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load | Idle 0.9 - 1.8V |
| | | 2,500 rpm 1.9 - 2.3V |
| COOLAN TEMP/S | <ul style="list-style-type: none"> ● Engine: After warming up | More than 70°C (158°F) |
| FR O2 SENSOR | <ul style="list-style-type: none"> ● Engine: After warming up | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR | | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |
| RR O2 SENSOR | <ul style="list-style-type: none"> ● Engine: After warming up | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR | | LEAN ↔ RICH |
| VHCL SPEED SE | <ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value | Almost the same speed as the CONSULT-II value |
| BATTERY VOLT | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) | 11 - 14V |
| THRTL POS SEN | <ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) | Throttle valve fully closed 0.2 - 0.8V |
| | | Throttle valve fully opened 3.5 - 4.5V |
| EGR TEMP SEN | <ul style="list-style-type: none"> ● Engine: After warming up | Less than 4.5V |
| START SIGNAL | <ul style="list-style-type: none"> ● Ignition switch: ON → START → ON | OFF → ON → OFF |
| CLSD THL/P SW | <ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) | Throttle valve: Idle position ON |
| | | Throttle valve: Slightly open OFF |
| CLSD THL POS | <ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) | Throttle valve: Idle position ON |
| | | Throttle valve: Slightly open OFF |
| AIR COND SIG | <ul style="list-style-type: none"> ● Engine: After warming up, idle the engine | A/C switch: OFF OFF |
| | | A/C switch: ON (Compressor operates.) ON |
| P/N POSI SW | <ul style="list-style-type: none"> ● Ignition switch: ON | Shift lever: "P" or "N" ON |
| | | Except above OFF |
| PW/ST SIGNAL | <ul style="list-style-type: none"> ● Engine: After warming up, idle the engine | Steering wheel in neutral position (forward direction) OFF |
| | | The steering wheel is turned ON |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|---|--------------------|
| IGNITION SW | ● Ignition switch: ON → OFF → ON | ON → OFF → ON |
| INJ PULSE | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | 2.5 - 3.3 msec |
| | 2,000 rpm | 2.4 - 3.2 msec |
| B/FUEL SCHDL | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | 0.8 - 1.2 msec |
| | 2,000 rpm | 0.8 - 1.2 msec |
| IGN TIMING | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | Approx. 20° BTDC |
| | 2,000 rpm | More than 25° BTDC |
| IACV-AAC/V | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | Approx. 30% |
| | 2,000 rpm | — |
| PURG VOL C/V | ● Engine: After warming up ● Air conditioner switch: OFF ● No-load Idle | 0% |
| | 2,000 rpm (More than 200 seconds after starting engine) | — |
| A/F ALPHA | ● Engine: After warming up Maintaining engine speed at 2,000 rpm | 50 - 159% |
| EVAP SYS PRES | ● Ignition switch: ON | Approx. 3.4V |
| AIR COND RLY | ● Air conditioner switch: OFF → ON | OFF → ON |
| FUEL PUMP RLY | ● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking | ON |
| | ● Except as shown above | OFF |
| EGRC SOL/V | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | ON (Cut) |
| | Engine speed: Revving engine from idle to 3,000 rpm quickly. | OFF (Flow) |
| VENT CONT/V | ● Ignition switch: ON | OFF |
| FR O2 HEATER | ● Engine speed: Below 3,000 rpm (All models) For 6 seconds after engine speed exceeds 3,000 rpm (4WD models only) | ON |
| | ● Engine speed: Above 3,000 rpm (2WD models) More than 6 seconds after engine speed exceeds 3,000 rpm (4WD models) | OFF |
| RR O2 HEATER | ● Engine speed: Idle after driving 2 minutes at 70 km/h (43 MPH) or more | ON |
| | ● Ignition switch: ON (Engine stopped) | OFF |
| VC/V BYPASS/V | ● Ignition switch: ON | OFF |
| CAL/LD VALUE | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | 9.5 - 34.0% |
| | 2,500 rpm | 13.9 - 24.9% |
| ABSOL TH-P/S | ● Engine: After warming up, engine stopped ● Ignition switch: ON Throttle valve: fully closed | 0.0% |
| | Throttle valve: fully opened | Approx. 80% |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|---|-------------------------------|
| MASS AIRFLOW | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle 0.9 - 5.8 g·m/s |
| | | 2,500 rpm 7.5 - 13.2 g·m/s |
| MAP/BARO SW/V | <ul style="list-style-type: none"> ● Engine: For 5 seconds after starting engine | BARO |
| | <ul style="list-style-type: none"> ● Ignition switch: More than 5 seconds after turning ignition switch "ON" ● Engine: More than 5 seconds after stating engine | MAP |
| ABSOL PRES/SE | <ul style="list-style-type: none"> ● Ignition switch: ON ● Engine: For 5 seconds after stating engine | Approx. 4.4V |
| | <ul style="list-style-type: none"> ● Engine: More than 5 seconds after starting engine (After warming up) | Approx. 1.2V |

GI
MA
EM
LC
EC

FE
CL
MT

Major Sensor Reference Graph in Data Monitor Mode

NGEC0043

The following are the major sensor reference graphs in "DATA MONITOR" mode.

(Select "MANU TRIG" in "DATA MONITOR" with CONSULT-II. "Trigger Point" is set to 100%, "Recording Speed" is set to MAX..)

AT
TF


THRTL POS SEN, ABSOL TH·P/S, CLSD THL POS

NGEC0043S01

Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch ON.

The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".

PD
AX



SU
BR
ST
RS

CMPS-RPM (REF), MAS AIR/FL SE, THRTL POS SEN, RR O2 SEN, FR O2 SEN, INJ PULSE


NGEC0043S02

Below is the data for "CMPS-RPM (REF)", "MAS AIR/FL SE", "THRTL POS SEN", "RR O2 SEN", "FR O2 SEN" and "INJ PULSE" when revving engine quickly up to 4,800 rpm under no load after warming up engine to normal operating temperature.


Each value is for reference, the exact value may vary.

BT
HA
SC
EL
IDX

Major Sensor Reference Graph in Data Monitor Mode (Cont'd)



- “CMPS•RPM(REF)” should increase gradually while depressing the accelerator pedal and should decrease gradually after releasing the pedal without any intermittent drop or rise.




- “MAS AIR/FL SE” should increase when depressing the accelerator pedal and should decrease at the moment “THRTL POS SEN” is closed (accelerator pedal is released).

SEF059P


TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "RR O2 SENSOR" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "FR O2 SENSOR" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT




HA

SC

SEF417R

EL

IDX



ECM Terminals and Reference Value

NGEC0044

PREPARATION

NGEC0044S01

1. ECM is located behind the instrument lower cover. For this inspection:

- Remove instrument lower cover.

2. Remove ECM harness protector.

3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.

- Open harness securing clip to make testing easier.
- Use extreme care not to touch 2 pins at one time.
- Data is for comparison and may not be exact.


TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

ECM Terminals and Reference Value (Cont'd)

ECM HARNESS CONNECTOR TERMINAL LAYOUT

NGEC0044S02



SEF533P

ECM INSPECTION TABLE

NGEC0044S03

Specification data are reference values and are measured between each terminal and 32 (ECM ground).





| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-----------------|---|-------------------|
| 1 | PU/W | Ignition signal | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>0 - 0.5V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>0.2 - 1.0V</p> |
| 2 | B | Ignition check | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>12 - 14V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>12 - 13V</p> |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE


ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---|--|---|
| 3 | P/L | Tachometer | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>0 - 1V</p>  |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>0.5 - 2V</p>  |
| 4 | LG/R | ECM relay (Self shut-off) | <p>[Engine is running] [Ignition switch OFF]</p> <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF | <p>0 - 1V</p> |
| | | | <p>[Ignition switch OFF]</p> <ul style="list-style-type: none"> ● More than a few seconds after turning ignition switch OFF | <p>BATTERY VOLTAGE (11 - 14V)</p> |
| 5 | R/Y | EVAP canister purge volume control solenoid valve | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed | <p>BATTERY VOLTAGE (11 - 14V)</p>  |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm (More than 200 seconds after starting engine) | <p>12 - 13V</p>  |
| 10 | B/R | ECM ground | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed | <p>Engine ground</p> |
| 11 | W/R | Fuel pump relay | <p>[Ignition switch ON]</p> <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch ON. <p>[Engine is running]</p> | <p>0 - 1V</p> |
| | | | <p>[Ignition switch ON]</p> <ul style="list-style-type: none"> ● More than 5 seconds after turning ignition switch ON | <p>BATTERY VOLTAGE (11 - 14V)</p> |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE





ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) | |
|---------------|------------|--|--|---|----------------|
| 12 | P | Air conditioner relay | [Engine is running] <ul style="list-style-type: none"> ● Both A/C switch and blower switch are ON* *: Any mode except "OFF", ambient air temperature above 10°C (50°F). | Approximately 0V | GI |
| | | | [Engine is running] <ul style="list-style-type: none"> ● A/C switch is OFF | BATTERY VOLTAGE (11 - 14V) | MA EM |
| 18 | R/W | Malfunction indicator lamp | [Ignition switch ON] | 0 - 1V | LC |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) | EC |
| 19 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground | |
| 20 | L/OR | Start signal | [Ignition switch ON] | Approximately 0V | FE |
| | | | [Ignition switch START] | BATTERY VOLTAGE (11 - 14V) | CL |
| 21 | G/R | Air conditioner dual-pressure switch | [Engine is running] <ul style="list-style-type: none"> ● Both air conditioner switch and blower switch are ON (Compressor operates) | Approximately 0V | MT |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Air conditioner switch is OFF | BATTERY VOLTAGE (11 - 14V) | AT |
| 22 | L/B | Park/neutral position (PNP) switch | [Ignition switch ON] <ul style="list-style-type: none"> ● Gear position is "N" or "P" | Approximately 0V | TF |
| | | | [Ignition switch ON] <ul style="list-style-type: none"> ● Except the above gear position | Approximately 5V | PD |
| 23 | L | Throttle position sensor | [Ignition switch ON] <ul style="list-style-type: none"> ● Warm-up condition ● Accelerator pedal fully released | 0.2 - 0.8V | AX |
| | | | [Ignition switch ON] <ul style="list-style-type: none"> ● Accelerator pedal fully depressed | 3.5 - 4.5V | SU |
| 24 | W/G | Ignition switch | [Ignition switch OFF] | 0V | BR |
| | | | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) | ST |
| 25 | B/Y | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground | |
| 28 | BR/W | Throttle position switch (Closed position) | [Ignition switch ON] <ul style="list-style-type: none"> ● Warm-up condition ● Accelerator pedal released | BATTERY VOLTAGE (11 - 14V) | RS |
| | | | [Ignition switch ON] <ul style="list-style-type: none"> ● Accelerator pedal depressed | Approximately 0V | BT |
| 29 | G/B | Vehicle speed sensor | [Engine is running] <ul style="list-style-type: none"> ● Lift up the vehicle ● In 2nd gear position ● 40 km/h (25 MPH) | 1 - 4V  | HA SC EL |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE




ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---|---|---|
| 32 | B/Y | ECM ground | [Engine is running] ● Idle speed | Engine ground (Probe this terminal with (-) tester probe when measuring) |
| 39 | GY/R | Power steering oil pressure switch | [Engine is running] ● Steering wheel is fully turned | Approximately 0V |
| | | | [Engine is running] ● Steering wheel is not turned | Approximately 5V |
| 42 | BR | Sensors' power supply | [Ignition switch ON] | Approximately 5V |
| 43 | B/W | Sensors' ground | [Engine is running] ● Idle speed | Approximately 0V |
| 44 | PU | Camshaft position sensor (Reference signal) | [Engine is running] ● Warm-up condition ● Idle speed | 0.2 - 0.5V  |
| | | | [Engine is running] ● Engine speed is 2,000 rpm | 0 - 0.5V  |
| 45 | B/R | Absolute pressure sensor | [Ignition switch ON] ● Engine is not running | Approximately 4.4V |
| | | | [Engine is running] ● For 5 seconds after starting engine | Approximately 1.2V |
| 47 | L | Crankshaft position sensor (OBD) | [Engine is running] ● Warm-up condition ● Idle speed | Approximately 0V  |
| | | | [Engine is running] ● Engine speed is 2,000 rpm | Approximately 0V  |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

ECM Terminals and Reference Value (Cont'd)




| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--|---|---|
| 49 | LG | Camshaft position sensor (Position signal) | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | Approximately 2.6V  |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | Approximately 2.5 - 2.6V  |
| 50 | B | Front heated oxygen sensor | [Engine is running] <ul style="list-style-type: none"> ● After warming up to normal operating temperature and engine speed is 2,000 rpm. | 0 - Approximately 1.0V  |
| 54 | R | Mass air flow sensor | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | 0.9 - 1.8V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm | 1.8 - 2.3V |
| 55 | G | Mass air flow sensor ground | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | Approximately 0V |
| 56 | OR | Rear heated oxygen sensor | [Engine is running] <ul style="list-style-type: none"> ● After warming up to normal operating temperature and revving engine from idle to 3,000 rpm quickly | 0 - Approximately 1.0V |
| 59 | LG/R | Engine coolant temperature sensor | [Engine is running] | Approximately 0 - 4.8V Output voltage varies with engine coolant temperature |
| 60 | Y/B | Fuel tank temperature sensor | [Engine is running] | Approximately 0 - 4.8V Output voltage varies with fuel temperature |
| 61 | PU/R | Intake air temperature sensor | [Engine is running] | Approximately 0 - 4.8V Output voltage varies with intake air temperature |
| 62 | Y | EVAP control system pressure sensor | [Ignition switch ON] | Approximately 3.4V |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|------------------------------------|---|--|
| 63 | G/OR | EGR temperature sensor | [Engine is running] ● Warm-up condition ● Idle speed | Less than 4.5V |
| | | | [Engine is running] ● Warm-up condition ● EGR system is operating | 0 - 1.5V |
| 64 | W | Knock sensor | [Engine is running] ● Idle speed | Approximately 2.4V |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 69 | LG/R | Data link connector for GST | [Engine is running] ● Idle speed (GST is disconnected) | 0.2 - 14V |
| 75 | Y/R | Data link connector for CONSULT-II | [Engine is running] ● Idle speed (CONSULT-II is connected and turned ON) | 3 - 10V |
| 76 | GY/L | | | 0 - 4V |
| 80 | SB | Power supply (Back-up) | [Ignition switch OFF] | BATTERY VOLTAGE (11 - 14V) |
| 101 | OR/L | IACV-AAC valve | [Engine is running] ● Warm-up condition ● Idle speed | 10.5 - 11.5V  |
| | | | [Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm | 1 - 13V  |
| 102 | W/B | Injector No. 1 | [Engine is running] ● Warm-up condition ● Idle speed | BATTERY VOLTAGE (11 - 14V)  |
| 104 | W/R | Injector No. 3 | | |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

KA24DE

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) | |
|---------------|------------|-----------------------------------|--|-------------------------------|----------------------------------|
| 109 | W/L | Injector No. 2 | [Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm | BATTERY VOLTAGE (11 - 14V) | GI MA EM LC |
| 111 | W/PU | Injector No. 4 | | | |
| | | | | | |
| 103 | G/W | EGRC-solenoid valve | [Engine is running] ● Warm-up condition ● Idle speed | 0 - 1V | EC |
| | | | [Engine is running] ● Warm-up condition ● Revving engine from idle to 3,000 rpm quickly | BATTERY VOLTAGE (11 - 14V) | FE |
| 108 | R/G | EVAP canister vent control valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) | CL |
| 116 | B/R | ECM ground | [Engine is running] ● Idle speed | Engine ground | MT |
| 117 | B/P | Current return | [Engine is running] ● Idle speed | BATTERY VOLTAGE (11 - 14V) | AT |
| 118 | LG/B | MAP/BARO switch solenoid valve | [Ignition switch ON] ● For 5 seconds after turning ignition switch ON | 0 - 1V | TF |
| | | | [Engine is running] ● Idle speed ● For 5 seconds after starting engine | | |
| | | | [Ignition switch ON] ● More than 5 seconds after turning ignition switch ON | BATTERY VOLTAGE (11 - 14V) | PD |
| | | | [Engine is running] ● Idle speed ● More than 5 seconds after starting engine | | |
| 119 | BR/Y | Front heated oxygen sensor heater | [Engine is running] ● Engine speed is below 3,000 rpm. (All models) | Approximately 0.4V | BR |
| | | | [Engine is running] ● Engine speed is above 3,000 rpm. (2WD models) ● More than 6 seconds after engine speed exceeds 3,000 rpm (4WD models) | BATTERY VOLTAGE (11 - 14V) | ST |
| 120 | P/B | Vacuum cut valve bypass valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) | RS |
| 122 | R/B | Rear heated oxygen sensor heater | [Engine is running] ● Idle speed after driving 2 minutes at 70 km/h (43 MPH) or more | Approximately 0.4V | BT |
| | | | [Ignition switch ON] ● Engine is not running | BATTERY VOLTAGE (11 - 14V) | HA |
| 124 | B/R | ECM ground | [Engine is running] ● Idle speed | Engine ground | SC |

Description

Description

NGEC0045

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on DTC (1st trip) visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

COMMON I/I REPORT SITUATIONS

NGEC0045S01

| STEP in Work Flow | Situation |
|-------------------|--|
| II | The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "1t". |
| III | The symptom described by the customer does not recur. |
| IV | (1st trip) DTC data does not appear during the DTC CONFIRMATION PROCEDURE. |
| VI | The TROUBLE DIAGNOSIS for PXXXX does not indicate the problem area. |

Diagnostic Procedure


NGEC0046

| | |
|--|---------------------------------------|
| 1 | INSPECTION START |
| Erase (1st trip) DTCs. Refer to "HOW TO ERASE EMISSION-RELATED INFORMATION", EC-67. | |
| | ▶ GO TO 2. |
| 2 | CHECK GROUND TERMINALS |
| Check ground terminals for corroding or loose connection. Refer to "Circuit Inspection", "GROUND INSPECTION", GI-29 . | |
| OK or NG | |
| OK | ▶ GO TO 3. |
| NG | ▶ Repair or replace. |
| 3 | SEARCH FOR ELECTRICAL INCIDENT |
| Perform "Incident Simulation Tests", GI-24 . | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair or replace. |
| 4 | CHECK CONNECTOR TERMINALS |
| Refer to "How to Check Enlarged Contact Spring of Terminal", GI-21 . | |
| OK or NG | |
| OK | ▶ INSPECTION END |
| NG | ▶ Repair or replace connector. |



Main Power Supply and Ground Circuit WIRING DIAGRAM

NGEC0047

EC-MAIN-01



Refer to the following.
 (M65), (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)



GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY

KA24DE

Main Power Supply and Ground Circuit (Cont'd)

ECM TERMINALS AND REFERENCE VALUE

NGEC0048

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---------------------------|---|---|
| 4 | LG/R | ECM relay (Self shut-off) | [Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF | 0 - 1V |
| | | | [Ignition switch OFF] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 10 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 19 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 24 | W/G | Ignition switch | [Ignition switch OFF] | 0V |
| | | | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 25 | B/Y | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 32 | B/Y | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground (Probe this terminal with (-) tester probe when measuring) |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 80 | SB | Power supply (Back-up) | [Ignition switch OFF] | BATTERY VOLTAGE (11 - 14V) |
| 116 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 117 | B/P | Current return | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) |
| 124 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |

TROUBLE DIAGNOSIS FOR POWER SUPPLY

KA24DE

Main Power Supply and Ground Circuit (Cont'd)

DIAGNOSTIC PROCEDURE


-NGEC0049

| | | |
|-------------------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Start engine. Is engine running? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 4. |
| No | ▶ | GO TO 2. |

| | | |
|---|-----------------------------|-----------|
| 2 | CHECK POWER SUPPLY-I | |
| <p>1. Turn ignition switch OFF and then ON. 2. Check voltage between ECM terminal 24 and ground with CONSULT-II or tester.</p> | | |
| | | |
| <p>Voltage: Battery voltage</p> <p style="text-align: right;">SEF600P</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | GO TO 3. |


| | | |
|---|-----------------------------------|-------------------------------|
| 3 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M65, E43 ● Harness connectors M59, F27 ● 10A fuse ● Harness for open or short between ECM and ignition switch | | |
| | ▶ | Repair harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | |
|--|------------------------------|----------|
| 4 | CHECK POWER SUPPLY-II | |
| <p>1. Stop engine. 2. Check voltage between ECM harness connector F29 terminal 80 and ground with CONSULT-II or tester.</p> | | |
|  | | |
| <p>Voltage: Battery voltage</p> <p>OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |

MEC698B

| | | |
|---|-----------------------------------|-------------------------------|
| 5 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F27, M59 ● 10A fuse ● Harness for open or short between ECM and fuse | | |
| ▶ | | Repair harness or connectors. |


| | | |
|---|-------------------------------|-----------|
| 6 | CHECK POWER SUPPLY-III | |
| <p>1. Turn ignition switch ON and then OFF. 2. Check voltage between ECM harness connector F29 terminals 67, 72, 117 and ground with CONSULT-II or tester.</p> | | |
|  | | |
| <p>Voltage: After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop to approximately 0V.</p> <p>OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG (Battery voltage does not exist.) | ▶ | GO TO 7. |
| NG (Battery voltage exists for more than a few seconds.) | ▶ | GO TO 13. |

SEF121V

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


7 CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM

1. Disconnect ECM harness connector.
2. Disconnect ECM relay.



SEF323V

3. Check harness continuity between ECM harness connector F29 terminals 67, 72, 117 and relay harness connector F30 terminal 3.



SEF122V

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 9. |
| NG | ▶ | GO TO 8. |

8 DETECT MALFUNCTIONING PART

Check the following.


- Harness for open or short between ECM relay and ECM


▶ Repair open circuit or short to ground or short to power in harness or connectors.

| | |
|--|---|
| 9 | CHECK VOLTAGE BETWEEN ECM RELAY AND GROUND |
| <p>Check voltage between ECM relay terminals 2, 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEF120V</p> <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 11. |
| NG | ▶ GO TO 10. |

| | |
|---|-----------------------------------|
| 10 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F27, M59 ● 10A fuse ● Harness for open or short between ECM relay and fuse | |
| ▶ | Repair harness or connectors. |

| | |
|---|--|
| 11 | CHECK OUTPUT SIGNAL CIRCUIT |
| <p>1. Check harness continuity between ECM harness connector F29 terminal 4 and relay harness connector F30 terminal 1.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEF605P</p> <p style="text-align: center;">Continuity should exist.</p> | |
| <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 12. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |


| | | |
|--|------------------------|--------------------|
| 12 | CHECK ECM RELAY | |
| <ol style="list-style-type: none"> 1. Apply 12V direct current between ECM relay terminals 1 and 2. 2. Check continuity between ECM relay terminals 3 and 5. | | |
|  | | |
| <p>12V (1 - 2) applied: Continuity exists. No voltage applied: No continuity</p> <p style="text-align: right;">SEF511P</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 13. |
| NG | ▶ | Replace ECM relay. |

| | | |
|---|-----------------------------|--|
| 13 | CHECK GROUND CIRCUIT | |
| <ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM harness connector F29 terminals 10, 19, 25, 32, 116, 124 and engine ground. | | |
|  | | |
| <p>Continuity should exist.</p> <p style="text-align: right;">SEF119V</p> | | |
| <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|--|------------------------------------|-----------------------|
| 14 | CHECK INTERMITTENT INCIDENT | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| ▶ | | INSPECTION END |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Component Description



Component Description

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

NGEC0051

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|--|------------------|
| MAS AIR/FL SE | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | 0.9 - 1.8V |
| | 2,500 rpm | 1.9 - 2.3V |
| CAL/LD VALUE | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | 9.5 - 34.0% |
| | 2,500 rpm | 13.9 - 24.9% |
| MASS AIRFLOW | ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | 0.9 - 5.8 g-m/s |
| | 2,500 rpm | 7.5 - 13.2 g-m/s |

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

NGEC0052

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|-----------------------------|---|-------------------|
| 54 | R | Mass air flow sensor | [Engine is running] ● Warm-up condition ● Idle speed | 0.9 - 1.8V |
| | | | [Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm | 1.9 - 2.3V |
| 55 | G | Mass air flow sensor ground | [Engine is running] ● Warm-up condition ● Idle speed | Approximately 0V |

On Board Diagnosis Logic

NGEC0053

| DTC No. | Malfunction is detected when ... | | Check Items (Possible Cause) |
|---------------|----------------------------------|--|--|
| P0100 0102 | A) | An excessively high voltage from the sensor is sent to ECM when engine is not running. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor |
| | C) | A high voltage from the sensor is sent to ECM under light load driving condition. | |
| | B) | An excessively low voltage from the sensor is sent to ECM* when engine is running. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor |
| | D) | A low voltage from the sensor is sent to ECM under heavy load driving condition. | |

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

| Detected items | Engine operating condition in fail-safe mode |
|------------------------------|---|
| Mass air flow sensor circuit | Engine speed will not rise more than 2,400 rpm due to the fuel cut. |

DTC Confirmation Procedure

NGEC0054


Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C". If there is no problem on "PROCEDURE FOR MALFUNCTION C", perform "PROCEDURE FOR MALFUNCTION D".

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.



PROCEDURE FOR MALFUNCTION A

NGEC0054S01

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-141.

With GST

Follow the procedure "With CONSULT-II".

| | | |
|----------|--------------------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) XXX rpm | |

PEF360V

PROCEDURE FOR MALFUNCTION B

NGEC0054S02

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait 5 seconds at most.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-141.

With GST

Follow the procedure "With CONSULT-II".

NOTE:

If 1st trip DTC is confirmed after more than 5 seconds, there may be malfunction C.

| | | |
|----------|---|---------|
| 4 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) XXX rpm COOLAN TEMP/S XXX °C | |

PEF361V

PROCEDURE FOR MALFUNCTION C

NGEC0054S03

NOTE:


If engine will not start or stops soon wait at least 10 seconds with engine stopped (Ignition switch "ON") instead of running engine at idle speed.

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and warm it up to normal operating temperature.
- 4) Run engine for at least 10 seconds at idle speed.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-141.

With GST

Follow the procedure "With CONSULT-II".




7

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) | XXX rpm |
| VHCL SPEED SE | XXX km/h |
| THRTL POS SEN | XXX v |

PEF723W

| | |
|--------------|-------------------|
| CALC LOAD | 20% |
| COOLANT TEMP | 95°C |
| SHORT FT #1 | 2% |
| LONG FT #1 | 0% |
| SHORT FT #2 | 4% |
| LONG FT #2 | 0% |
| ENGINE SPD | 2637RPM |
| VEHICLE SPD | 0MPH |
| IGN ADVANCE | 41.0° |
| INTAKE AIR | 41°C |
| MAF | 14.1gm/sec |
| THROTTLE POS | 3% |

SEF534P



PROCEDURE FOR MALFUNCTION D

NGEC0054S04

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Start engine and warm it up to normal operating temperature. If engine cannot be started, go to "Diagnostic Procedure", EC-141.
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Check the voltage of MAS AIR/FL SE with "DATA MONITOR".
- 5) Increases engine speed to about 4,000 rpm.
- 6) Monitor the linear voltage rise in response to engine speed increases.
If NG, go to "Diagnostic Procedure", EC-141.
If OK, go to following step.
- 7) Maintain the following conditions for at least 10 consecutive seconds.

| | |
|------------------|--|
| CMPS-RPM (REF) | More than 2,000 rpm |
| THRTL POS SEN | More than 3V |
| Selector lever | Suitable position |
| Driving location | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-141.

Overall Function Check

NGEC0055

Use this procedure to check the overall function of the mass air flow sensor circuit. During this check, a 1st trip DTC might not be confirmed.

PROCEDURE FOR MALFUNCTION D

NGEC0055S01

With GST

- 1) Turn ignition switch ON.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Select "MODE 1" with GST.
- 4) Check the mass air flow sensor signal with "MODE 1".
- 5) Check for linear mass air flow rise in response to increases to about 4,000 rpm in engine speed.
- 6) If NG, go to "Diagnostic Procedure", EC-141.




No Tools

- 1) Turn ignition switch ON.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Check the voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.
- 4) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.
- 5) If NG, go to "Diagnostic Procedure", EC-141.

Wiring Diagram

NGEC0056

EC-MAFS-01




Diagnostic Procedure

NGEC0057

| 1 | INSPECTION START | | | | | | | |
|---|-------------------------|----------|-------------|------|------------|---|------------|----|
| Which malfunction (A, B, C or D) is duplicated? | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">MALFUNCTION</th> <th style="width: 50%;">Type</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">A and/or C</td> <td style="text-align: center;">I</td> </tr> <tr> <td style="text-align: center;">B and/or D</td> <td style="text-align: center;">II</td> </tr> </tbody> </table> | | | MALFUNCTION | Type | A and/or C | I | B and/or D | II |
| MALFUNCTION | Type | | | | | | | |
| A and/or C | I | | | | | | | |
| B and/or D | II | | | | | | | |
| MTBL0063 | | | | | | | | |
| Type I or Type II | | | | | | | | |
| Type I | ▶ | GO TO 3. | | | | | | |
| Type II | ▶ | GO TO 2. | | | | | | |


| | | |
|---|----------------------------|----------------------|
| 2 | CHECK INTAKE SYSTEM | |
| Check the followings for connection. | | |
| <ul style="list-style-type: none"> ● Air duct ● Air cleaner ● Vacuum hoses ● Intake air passage between air duct to collector | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Reconnect the parts. |

| | | |
|---|--------------------------------|----------|
| 3 | RETIGHTEN GROUND SCREWS | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws. | | |
|  | | |
| SEF325V | | |
| ▶ | | GO TO 4. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

4 CHECK POWER SUPPLY


1. Disconnect Mass air flow sensor harness connector.



AEC131A

2. Turn ignition switch ON.

3. Check voltage between terminal 2 and ground with CONSULT-II or tester.



SEF126V

Voltage: Battery voltage

OK or NG

OK ► GO TO 6.

NG ► GO TO 5.

5 DETECT MALFUNCTIONING PART

Check the following.


- Harness for open or short between ECM relay and mass air flow sensor
- Harness for open or short between Mass air flow sensor and ECM

► Repair harness or connectors.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

6 CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between Mass air flow sensor terminal 3 and ECM terminal 55. Refer to EC-140.



SEF124V

Continuity should exist.

4. Also check harness for short to ground and short to power.


OK or NG

OK ► GO TO 7.

NG ► Repair open circuit or short to ground or short to power in harness or connectors.

7 CHECK INPUT SIGNAL CIRCUIT

1. Check harness continuity between terminal 4 and ECM terminal 54.



SEF125V

Continuity should exist.

2. Also check harness for short to ground and short to power.


OK or NG

OK ► GO TO 8.

NG ► Repair open circuit or short to ground or short to power in harness or connectors.

8 CHECK MASS AIR FLOW SENSOR

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.




SEF326V

| Conditions | Voltage V |
|--|--------------------------|
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 |
| Idle (Engine is warmed-up to normal operating temperature.) | 0.9 - 1.8 |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.9 - 2.3 |
| Idle to about 4,000 rpm* | 1.3 - 1.7 to Approx. 3.0 |

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

MTBL0326

4. If the voltage is out of specification, disconnect Mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove Mass air flow sensor from air duct. Check hot wire for damage or dust.



SEF893J

OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace mass air flow sensor. |

9 CHECK SHIELD CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect joint connector-2.
3. Check the following.
 - Continuity between joint connector-2 terminal 1 and ground
 - Joint connector-2
 (Refer to "HARNESS LAYOUT", *EL-272*)
Continuity should exist.
4. Also check harness for short to ground and short to power.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 10. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 10 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
|  | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL


IDX

Component Description



Component Description

The absolute pressure sensor is connected to the MAP/BARO switch solenoid valve by a hose. The sensor detects ambient barometric pressure and intake manifold pressure and sends the voltage signal to the ECM. As the pressure increases, the voltage rises.



On Board Diagnosis Logic

NGEC0060

| DTC No. | Malfunction is detected when ... | | Check Items (Possible Cause) |
|---------------|----------------------------------|--|---|
| P0105 0803 | A) | An excessively low or high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> ● Harness or connectors (Absolute pressure sensor circuit is open or shorted.) ● Absolute pressure sensor |
| | B) | A high voltage from the sensor is sent to ECM under light load driving conditions. | <ul style="list-style-type: none"> ● Hoses (Hoses between the intake manifold and absolute pressure sensor are disconnected or clogged.) ● Intake air leaks ● MAP/BARO switch solenoid valve ● Absolute pressure sensor |
| | C) | A low voltage from the sensor is sent to ECM under heavy load driving conditions. | <ul style="list-style-type: none"> ● Absolute pressure sensor |

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If the 1st trip DTC is not confirmed on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

| | | |
|----------|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | COOLAN TEMP/S | XXX °C |

PEF002P

PROCEDURE FOR MALFUNCTION A

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-150.

With GST

- 1) Turn ignition switch ON and wait at least 6 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-150.

No Tools

- 1) Turn ignition switch ON and wait at least 6 seconds.
- 2) Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-150.

| | | |
|----------|---------------|---------|
| 4 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |

PEF361V

PROCEDURE FOR MALFUNCTION B

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine and let it idle.
- 5) Wait at least 10 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-150.

With GST

Follow the procedure "With CONSULT-II".

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

7

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| VHCL SPEED SE | XXX km/h |
| B/FUEL SCHDL | XXX msec |
| ABSOL PRES/SE | XXX V |

PEF127V

PROCEDURE FOR MALFUNCTION C

NGEC0061S03

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II and check "ABSOL PRES/SE" signal.

The voltage of "ABSOL PRES/SE" should be more than 1.74 [V].

If the check result is NG, go to "Diagnostic Procedure", EC-150.

If the check result is OK, go to following step.

- 3) Start engine and warm it up to normal operating temperature.
- 4) Turn ignition switch OFF and wait at least 5 seconds.
- 5) Start engine and let it idle for at least 10 seconds.
- 6) Select "DATA MONITOR" mode with CONSULT-II.
- 7) Drive the vehicle at least 3 consecutive seconds under the following conditions,

| | |
|------------------|--|
| B/FUEL SCHDL | More than 4 msec |
| CMPS-RPM (REF) | 3,000 - 4,800 rpm |
| Selector lever | Suitable position |
| Driving location | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-150.

| | | |
|--------------|-------|----------|
| ENGINE SPD | | 0RPM |
| COOLANT TEMP | | 69°C |
| VEHICLE SPD | | 0MPH |
| IGN ADVANCE | | 3.0° |
| CALC LOAD | | 0.0% |
| MAP | | 101KPa |
| MAF | | 0.25gm/s |
| THROTTLE POS | | 0.0% |
| INTAKE AIR | | 27°C |
| FUEL SYS #1 | | OL |
| FUEL SYS #2 | | UNUSED |
| SHORT FT #1 | | 0.0% |
| LONG FT #1 | | 0.0% |
| O2S B1 S1 | | 0.000V |
| O2FT B1 S1 | | 0.0% |
| O2S B1 S2 | | 0.000V |

SEF518R

Overall Function Check

NGEC0062

PROCEDURE FOR MALFUNCTION C

NGEC0062S01


Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

With GST

- 1) Turn ignition switch ON.
- 2) Select absolute pressure sensor signal in "MODE 1" with GST.
- 3) Make sure that the pressure of absolute pressure sensor signal is more than 46 kPa (0.47 kg/cm², 6.7 psi).
- 4) If NG, go to "Diagnostic Procedure", EC-150.

No Tools

- 1) Turn ignition switch ON.
- 2) Make sure that the voltage between ECM terminal 45 (Absolute pressure sensor signal) and ground is more than 1.74 [V].
- 3) If NG, go to "Diagnostic Procedure", EC-150.






DTC P0105 ABSOLUTE PRESSURE SENSOR

KA24DE
Wiring Diagram

Wiring Diagram

NGEC0063

EC-AP/SEN-01



AEC982A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


Diagnostic Procedure


NGEC0064

If the trouble is duplicated after “PROCEDURE FOR MALFUNCTION A or C”, perform “PROCEDURE A” below. If the trouble is duplicated after “PROCEDURE FOR MALFUNCTION B”, perform “PROCEDURE B” EC-154.

PROCEDURE A

NGEC0064S01

| | | |
|---|--------------------------------|----------|
| 1 | RETIGHTEN GROUND SCREWS | |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> | | |
|  | | |
| <small>SEF325V</small> | | |
| ▶ | | GO TO 2. |

| | | |
|---|------------------------|--|
| 2 | CHECK CONNECTOR | |
| <p>1. Disconnect absolute pressure sensor harness connector.</p> | | |
|  | | |
| <small>SEF328V</small> | | |
| <p>2. Check sensor harness connector for water. Water should not exist.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | | ▶ GO TO 3. |
| NG | | ▶ Repair or replace harness connector. |


| | | |
|----------|---------------------------|--|
| 3 | CHECK POWER SUPPLY | <p>1. Turn ignition switch ON.</p> <p>2. Check voltage between absolute pressure sensor terminal 3 and engine ground with CONSULT-II or tester.</p> <div style="text-align: center;"> </div> <p style="color: blue; font-weight: bold;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair harness or connectors. |

| | | |
|----------|-----------------------------|--|
| 4 | CHECK GROUND CIRCUIT | <p>1. Turn ignition switch OFF.</p> <p>2. Check harness continuity between absolute pressure sensor terminal 1 and engine ground. Refer to EC-149.</p> <div style="text-align: center;"> </div> <p style="color: blue; font-weight: bold;">Continuity should exist.</p> <p style="text-align: center;">OK or NG</p> |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

5 CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM harness connector F29 terminal 45 and absolute pressure sensor harness connector F23 terminal 2.



SEF129V

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |

6 DETECT MALFUNCTIONING PART

Check the following.


- Harness for open or short between ECM and absolute pressure sensor
- Harness for open or short between absolute pressure sensor and TCM (Transmission control module)

| | | |
|--|---|--|
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |
|--|---|--|

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


7 CHECK ABSOLUTE PRESSURE SENSOR

1. Remove absolute pressure sensor with its harness connector connected.



SEF328V

2. Remove hose from absolute pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM harness connector terminal 45 (Absolute pressure sensor signal) and engine ground.



SEF132V

The voltage should be 3.2 to 4.8V.

4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

OK ► GO TO 8.

NG ► Replace absolute pressure sensor.

8 CHECK SHIELD CIRCUIT

1. Turn ignition switch OFF.
2. Remove joint connector-2.
3. Check the following.
 - Continuity between joint connector-2 terminal 1 and ground
 - Joint connector-2
(Refer to "HARNESS LAYOUT" *EL-263*.)
Continuity should exist.
4. Also check harness for short to ground and short to power.
5. Then reconnect joint connector-2.

OK or NG

OK ► GO TO 9.

NG ► Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0105 ABSOLUTE PRESSURE SENSOR



KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

PROCEDURE B

NGEC0064S02


| | |
|---|-------------------------|
| 1 | INSPECTION START |
| <ol style="list-style-type: none">1. Start engine and warm it up to normal operating temperature.2. Turn ignition switch OFF.3. Connect MAP/BARO switch solenoid valve and absolute pressure sensor with a rubber tube that has a vacuum gauge. | |
|  <p>SEF328V</p> | |
|  <p>SEF385U</p> | |
| Models with CONSULT-II ▶ | GO TO 2. |
| Models without CONSULT-II ▶ | GO TO 3. |

| 2 | CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|--|---------------|-----|---------------|-----|----------------|---------|----------------|---------|---------------|-------|---------------|-------|--|--|--|--|--|--|--|-------------|--|---------------|------|---------------|------|----------------|---------|----------------|---------|---------------|-------|---------------|-------|--|--|--|--|--|--|---|---------------|---|---------------|------------------|------|------------------|-----|--------------|
| <p>(With CONSULT-II)</p> <ol style="list-style-type: none"> Start engine and let it idle. Select "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II. Touch "MAP" and "BARO" alternately and check for vacuum. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%; border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>MAP/BARO SW/V</td><td>MAP</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXX rpm</td></tr> <tr><td>MAP/BARO SW/V</td><td>MAP</td></tr> <tr><td>ABSOL PRES/SE</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> </td> <td style="width: 30%; border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>MAP/BARO SW/V</td><td>BARO</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXX rpm</td></tr> <tr><td>MAP/BARO SW/V</td><td>BARO</td></tr> <tr><td>ABSOL PRES/SE</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> </td> <td style="width: 35%; border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><td>MAP/BARO SW/V</td><td>Vacuum</td></tr> <tr><td>BARO</td><td>Should not exist</td></tr> <tr><td>MAP</td><td>Should exist</td></tr> </table> </td> </tr> </table> | | <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>MAP/BARO SW/V</td><td>MAP</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXX rpm</td></tr> <tr><td>MAP/BARO SW/V</td><td>MAP</td></tr> <tr><td>ABSOL PRES/SE</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | ACTIVE TEST | | MAP/BARO SW/V | MAP | MONITOR | | CMPS-RPM (REF) | XXX rpm | MAP/BARO SW/V | MAP | ABSOL PRES/SE | XXX V | | | | | | | | | <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>MAP/BARO SW/V</td><td>BARO</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXX rpm</td></tr> <tr><td>MAP/BARO SW/V</td><td>BARO</td></tr> <tr><td>ABSOL PRES/SE</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | ACTIVE TEST | | MAP/BARO SW/V | BARO | MONITOR | | CMPS-RPM (REF) | XXX rpm | MAP/BARO SW/V | BARO | ABSOL PRES/SE | XXX V | | | | | | | | | <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><td>MAP/BARO SW/V</td><td>Vacuum</td></tr> <tr><td>BARO</td><td>Should not exist</td></tr> <tr><td>MAP</td><td>Should exist</td></tr> </table> | MAP/BARO SW/V | Vacuum | BARO | Should not exist | MAP | Should exist |
| <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>MAP/BARO SW/V</td><td>MAP</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXX rpm</td></tr> <tr><td>MAP/BARO SW/V</td><td>MAP</td></tr> <tr><td>ABSOL PRES/SE</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | ACTIVE TEST | | MAP/BARO SW/V | MAP | MONITOR | | CMPS-RPM (REF) | XXX rpm | MAP/BARO SW/V | MAP | ABSOL PRES/SE | XXX V | | | | | | | | | <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>MAP/BARO SW/V</td><td>BARO</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXX rpm</td></tr> <tr><td>MAP/BARO SW/V</td><td>BARO</td></tr> <tr><td>ABSOL PRES/SE</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | ACTIVE TEST | | MAP/BARO SW/V | BARO | MONITOR | | CMPS-RPM (REF) | XXX rpm | MAP/BARO SW/V | BARO | ABSOL PRES/SE | XXX V | | | | | | | | | <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><td>MAP/BARO SW/V</td><td>Vacuum</td></tr> <tr><td>BARO</td><td>Should not exist</td></tr> <tr><td>MAP</td><td>Should exist</td></tr> </table> | MAP/BARO SW/V | Vacuum | BARO | Should not exist | MAP | Should exist | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | MAP | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | MAP | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ABSOL PRES/SE | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | BARO | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | BARO | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ABSOL PRES/SE | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | Vacuum | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BARO | Should not exist | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAP | Should exist | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF174X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 9. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |


GI
MA
EM
LC
EC

| 3 | CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR | | | | | | |
|--|--|-----------|--------|-------------------------------------|------------------|---|--------------|
| <p>(Without CONSULT-II)</p> <ol style="list-style-type: none"> Start engine and let it idle. Check for vacuum under the following condition. | | | | | | | |
| <table border="1" style="width: 80%; border-collapse: collapse; margin: auto;"> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Vacuum</th> </tr> <tr> <td>For 5 seconds after starting engine</td> <td>Should not exist</td> </tr> <tr> <td>More than 5 seconds after starting engine</td> <td>Should exist</td> </tr> </table> | | Condition | Vacuum | For 5 seconds after starting engine | Should not exist | More than 5 seconds after starting engine | Should exist |
| Condition | Vacuum | | | | | | |
| For 5 seconds after starting engine | Should not exist | | | | | | |
| More than 5 seconds after starting engine | Should exist | | | | | | |
| MTBL0080 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ | GO TO 9. | | | | | |
| NG | ▶ | GO TO 4. | | | | | |

FE
CL
MT
AT
TF
PD
AX
SU

| | | |
|--|--------------------------|------------------------------------|
| 4 | CHECK VACUUM HOSE | |
| <ol style="list-style-type: none"> Turn ignition switch OFF. Check vacuum hose for clogging, cracks, disconnection or improper connection. | | |
|  | | |
| SEF109L | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Clean, repair or replace the hose. |

BR
ST
RS
BT
HA
SC
EL

| | | | |
|--|--------------------------|----------------------------------|--|
| 5 | CHECK VACUUM PORT | | |
| Check vacuum port for clogging. | | | |
|  | | | |
| SEF368U | | | |
| OK or NG | | | |
| OK (With CONSULT-II) | ▶ | GO TO 6. | |
| OK (Without CONSULT-II) | ▶ | GO TO 7. | |
| NG | ▶ | Clean or repair the vacuum port. | |

6 CHECK MAP/BARO SWITCH SOLENOID VALVE

Ⓟ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Check the following.
 - Condition: At idle under no-load
 - CONSULT-II display
 - Time for voltage to change

| ACTIVE TEST | |
|----------------|---------|
| MAP/BARO SW/V | MAP |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| MAP/BARO SW/V | MAP |
| ABSOL PRES/SE | XXX V |
| | |
| | |
| | |

| MAP/BARO | AVSOL PRES/SE (Voltage) |
|----------|-------------------------------|
| BARO | More than 2.6V |
| MAP | Less than the voltage at BARO |

| ACTIVE TEST | |
|----------------|---------|
| MAP/BARO SW/V | BARO |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| MAP/BARO SW/V | BARO |
| ABSOL PRES/SE | XXX V |
| | |
| | |
| | |

| MAP/BARO SW/V | Required time to switch |
|---------------|-------------------------|
| BARO to MAP | Less than 1 second |
| MAP to BARO | |



SEF170X

OK or NG

OK ▶ GO TO 8.

NG ▶ GO TO 7.(Without CONSULT-II)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| 7 | CHECK MAP/BARO SWITCH SOLENOID VALVE | | | | | | | | | | | | | | | |
|---|--|--|--|--|---|-----|----|-----------|----|-----|----|---|----------|----|---|---|
| <p>⊗ Without CONSULT-II</p> <p>1. Turn ignition switch OFF and remove MAP/BARO switch solenoid valve.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF338V</p> <p>2. Check air passage continuity.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">MEC488B</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Air passage continuity between A and B</th> <th style="text-align: center;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">No supply</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0283</p> <p>3. Check the time required for the solenoid valve to switch. It should be less than 1 second.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace MAP/BARO switch solenoid valve.</td> </tr> </table> | | Condition | Air passage continuity between A and B | Air passage continuity between A and C | 12V direct current supply between terminals 1 and 2 | Yes | No | No supply | No | Yes | OK | ▶ | GO TO 8. | NG | ▶ | Replace MAP/BARO switch solenoid valve. |
| Condition | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | No | | | | | | | | | | | | | | |
| No supply | No | Yes | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | | | | | |
| NG | ▶ | Replace MAP/BARO switch solenoid valve. | | | | | | | | | | | | | | |

| | | | | | | | |
|---|----------------------------|------------|---|-----------|----|---|------------|
| 8 | CHECK INTAKE SYSTEM | | | | | | |
| <p>Check intake system for air leaks.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 12.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair it.</td> </tr> </table> | | OK | ▶ | GO TO 12. | NG | ▶ | Repair it. |
| OK | ▶ | GO TO 12. | | | | | |
| NG | ▶ | Repair it. | | | | | |

DTC P0105 ABSOLUTE PRESSURE SENSOR

KA24DE

Diagnostic Procedure (Cont'd)


| | | | |
|----------|---|---|--|
| 9 | CHECK HOSE BETWEEN ABSOLUTE PRESSURE SENSOR AND MAP/BARO SWITCH SOLENOID VALVE | <p>1. Turn ignition switch OFF. 2. Check hose for clogging, cracks, disconnection or improper connection.</p> <div style="text-align: center;"> <p>Split</p> <p>Clogging</p> <p>Improper connection</p> </div> <p style="text-align: right;">SEF109L</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 10. | |
| NG | ▶ | Repair or reconnect hose. | |

| | | | |
|-----------|--------------------------------|---|--|
| 10 | CHECK HARNESS CONNECTOR | <p>1. Disconnect absolute pressure sensor harness connector. 2. Check sensor harness connector for water. Water should not exist.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 11. | |
| NG | ▶ | Repair or replace harness connector. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

11 CHECK ABSOLUTE PRESSURE SENSOR


1. Remove absolute pressure sensor with its harness connector connected.



SEF328V

2. Remove hose from absolute pressure sensor.

3. Turn ignition switch ON and check output voltage between ECM terminal 45 (Absolute pressure sensor signal) and engine ground.



SEF132V

The voltage should be 3.2 to 4.8V.

4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG


OK ► GO TO 12.

NG ► Replace absolute pressure sensor.

12 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

► INSPECTION END




Component Description

NGEC0066

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



<Reference data>

| Intake air temperature °C (°F) | Voltage* V | Resistance kΩ |
|-----------------------------------|---------------|------------------|
| 20 (68) | 3.5 | 2.1 - 2.9 |
| 80 (176) | 1.23 | 0.27 - 0.38 |

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ECM terminal 32 (ECM ground).

On Board Diagnosis Logic

NGEC0067

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P0110 0401 | A) An excessively low or high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air temperature sensor |
| | B) Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor. | |

Engine operating condition in fail-safe mode

The ECM functions on the assumption that the intake air temperature is 25°C (77°F).


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". =NGEC0068

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.



PROCEDURE FOR MALFUNCTION A


NGEC0068S01

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-164.

With GST

Follow the procedure "With CONSULT-II".



PROCEDURE FOR MALFUNCTION B

NGEC0068S02

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

With CONSULT-II

- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - a) Turn ignition switch ON.
 - b) Select "DATA MONITOR" mode with CONSULT-II.
 - c) Check the engine coolant temperature.
 - d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 2) Turn ignition switch ON.
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine.
- 5) Hold vehicle speed more than 70 km/h (44 MPH) for 105 consecutive seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-164.

With GST

Follow the procedure "With CONSULT-II".

DTC P0110 INTAKE AIR TEMPERATURE SENSOR

KA24DE

Wiring Diagram

Wiring Diagram

NGEC0069

EC-IATS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA


SC

EL


IDX



— : Detectable line for DTC
 — : Non-detectable line for DTC



Refer to the following.
 (M65), (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)




AEC983A

| | | | |
|----------|-----------------------------|--|---|
| 3 | CHECK GROUND CIRCUIT | <p>1. Turn ignition switch OFF.</p> <p>2. Check harness continuity between intake air temperature sensor terminal 2 and engine ground. Refer to the wiring diagram.</p> <div style="text-align: center; margin: 20px 0;"> </div> <p style="text-align: right; margin-right: 20px;">SEF102S</p> <p style="text-align: center; color: blue; font-weight: bold;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center; font-weight: bold;">OK or NG</p> | GI MA EM LC EC FE CL MT |
| OK | ▶ | GO TO 5. | |
| NG | ▶ | GO TO 4. | |

| | | | |
|----------|-----------------------------------|--|---|
| 4 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M58, F28 ● Harness connectors M59, F27 ● Harness for open or short between ECM and intake air temperature sensor | AT TF PD AX SU BR ST RS BT HA SC EL IDX |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

5 CHECK INTAKE AIR TEMPERATURE SENSOR

Check resistance as shown in the figure.




SEF205W

<Reference data>

| EGR coolant temperature °C (°F) | Voltage* V | Resistance k Ω |
|------------------------------------|---------------|-------------------|
| -10 (14) | 4.4 | 7.0 - 11.4 |
| 20 (68) | 3.5 | 2.1 - 2.9 |
| 50 (122) | 2.2 | 0.68 - 1.00 |
| 90 (194) | 0.9 | 0.236 - 0.260 |

*: These data are reference values and are measured between ECM terminal ⑤⑨ (Engine coolant temperature sensor) and ECM terminal ③② (ECM ground).

MTBL0327



SEF012P

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace intake air temperature sensor. |

6 CHECK INTERMITTENT INCIDENT


Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

▶ INSPECTION END

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

KA24DE


Component Description



Component Description

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

NGEC0072



<Reference data>

| Engine coolant temperature °C (°F) | Voltage* V | Resistance kΩ |
|------------------------------------|------------|---------------|
| -10 (14) | 4.4 | 7.0 - 11.4 |
| 20 (68) | 3.5 | 2.1 - 2.9 |
| 50 (122) | 2.2 | 0.68 - 1.00 |
| 90 (194) | 0.9 | 0.236 - 0.260 |

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ECM terminal 32 (ECM ground).

CONSULT-II Reference Value in Data Monitor Mode

NGEC0073

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|----------------------------|------------------------|
| COOLAN TEMP/S | ● Engine: After warming up | More than 70°C (158°F) |

On Board Diagnosis Logic

NGEC0074

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0115 0103 | ● An excessively high or low voltage from the sensor is sent to ECM.* | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor |

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

| Detected items | Engine operating condition in fail-safe mode | |
|---|---|---|
| Engine coolant temperature sensor circuit | Engine coolant temperature will be determined by ECM based on the time after turning ignition switch to ON or START. CONSULT-II displays the engine coolant temperature decided by ECM. | |
| | Condition | Engine coolant temperature decided (CONSULT-II display) |
| | Just as ignition switch is turned to ON or Start | 40°C (104°F) |
| | More than approx. 4 minutes after ignition ON or Start | 80°C (176°F) |
| Except as shown above | 40 - 80°C (104 - 176°F) (Depends on the time) | |

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

KA24DE

DTC Confirmation Procedure

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | COOLAN TEMP/S | XXX °C |

PEF002P

DTC Confirmation Procedure

NGEC0075

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-170.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)


KA24DE

Wiring Diagram

Wiring Diagram

NGEC0076

EC-ECTS-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



AEC984A



DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0077

| | |
|--|---------------------------|
| 1 | CHECK POWER SUPPLY |
| <p>1. Turn ignition switch OFF. 2. Disconnect engine coolant temperature sensor harness connector.</p> | |
|  | |
| <p>3. Turn ignition switch ON. 4. Check voltage between engine coolant temperature sensor terminal 1 and ground with CONSULT-II or tester.</p> | |
|  | |
| <p>Voltage: Approximately 5V</p> | |
| <p>OK or NG</p> | |
| OK | ▶ GO TO 3. |
| NG | ▶ GO TO 2. |

SEF330V

SEF206W

| | |
|--|-----------------------------------|
| 2 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between ECM and engine coolant temperature sensor. | |
| ▶ | Repair harness or connectors. |

| | |
|---|-----------------------------|
| 3 | CHECK GROUND CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between engine coolant temperature sensor terminal 2 and engine ground. Refer to EL-141. Continuity should exist. 3. Also check harness for short to ground and short to power.</p> | |
| <p>OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between ECM and engine coolant temperature sensor. | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |


DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)


5 CHECK ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.



<Reference data>

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.1 - 2.9 |
| 50 (122) | 0.68 - 1.00 |
| 90 (194) | 0.236 - 0.260 |



OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace engine coolant temperature sensor. |

6 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

▶ **INSPECTION END**

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Component Description


NGEC0079

NOTE:

If DTC P0120 (0403) is displayed with DTC P0510 (0203), first perform trouble diagnosis for DTC P0510, EC-422.

The throttle position sensor responds to the accelerator pedal movement. This sensor is a type of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

NGEC0080

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|--|---|
| THRTL POS SEN | ● Ignition switch: ON (Engine stopped) | Throttle valve: fully closed 0.2 - 0.8V |
| | ● Engine: After warming up | Throttle valve: fully opened 3.5 - 4.5V |
| ABSOL TH-P/S | ● Ignition switch: ON (Engine stopped) | Throttle valve: fully closed 0.0% |
| | ● Engine: After warming up | Throttle valve: fully opened Approx. 80% |

DTC P0120 THROTTLE POSITION SENSOR

KA24DE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

=NGEC0081

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|--------------------------|---|-------------------|
| 23 | L | Throttle position sensor | [Ignition switch ON] ● Warm-up condition ● Accelerator pedal fully released | 0.2 - 0.8V |
| | | | [Ignition switch ON] ● Accelerator pedal fully depressed | 3.5 - 4.5V |
| 42 | BR | Sensors' power supply | [Ignition switch ON] | Approximately 5V |
| 43 | B/W | Sensors' ground | [Engine is running] ● Idle speed | Approximately 0V |

On Board Diagnosis Logic

NGEC0082

| DTC No. | Malfunction is detected when ... | | Check Items (Possible Cause) |
|---------------|----------------------------------|---|---|
| P0120 0403 | A) | An excessively low or high voltage from the sensor is sent to ECM.* | <ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Throttle position sensor |
| | B) | A high voltage from the sensor is sent to ECM under light load driving condition. | <ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Throttle position sensor ● Fuel injector ● Camshaft position sensor ● Mass air flow sensor |
| | C) | A low voltage from the sensor is sent to ECM under heavy load driving condition. | <ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Intake air leaks ● Throttle position sensor |

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

| Detected items | Engine operating condition in fail-safe mode | |
|-------------------------------------|--|-------------------|
| Throttle position sensor circuit | Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor. | |
| | Condition | Driving condition |
| | When engine is idling | Normal |
| | When accelerating | Poor acceleration |

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".

=NGEC0083

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A


NGEC0083S01

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 10V at idle.
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.



Ⓟ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 5 consecutive seconds.

| | |
|----------------|--|
| VHCL SPEED SE | More than 4 km/h (2 MPH) |
| Selector lever | Suitable position except "P" or "N" position |

- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-178.

Ⓢ With GST


Follow the procedure "With CONSULT-II".

Ⓝ No Tools

- 1) Start engine and maintain the following conditions for at least 5 consecutive seconds.

| | |
|----------------|--|
| Vehicle speed | More than 4 km/h (2 MPH) |
| Selector lever | Suitable position except "P" or "N" position |

- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-178.



PROCEDURE FOR MALFUNCTION B

NGEC0083S02

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and let it idle for at least 10 seconds. If idle speed is over 1,100 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,100 rpm.

| | |
|-------------------|--|
| Selector lever | Suitable position except "N" (Higher gear position such as 3rd or 4th is better to keep low engine rpm.) |
| Accelerator pedal | Released |
| Vehicle speed | As slow as possible |

- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-178.

With GST

Follow the procedure "With CONSULT-II".

No Tools

- 1) Start engine and let it idle for at least 10 seconds. If idle speed is over 1,100 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,100 rpm.


| | |
|-------------------|--|
| Selector lever | Suitable position except "N" (Higher gear position such as 3rd or 4th is better to keep low engine rpm.) |
| Accelerator pedal | Released |
| Vehicle speed | As slow as possible |

- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-178.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | |
|----------|---------------------|---------|
| 6 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | THRTL POS SEN | XXX V |
| | ABSOL TH~P/S | XXX % |

PEF024P



| | | |
|---------------|---------------------|---------|
| 9 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS~RPM(REF) | XXX rpm |
| | MAS AIR/FL SE | XXX V |
| COOLAN TEMP/S | XXX °C | |

PEF235U

PROCEDURE FOR MALFUNCTION C

NGEC0083S03

CAUTION:

Always drive vehicle at a safe speed.

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II.
- 5) Select "THRTL POS SEN" and "ABSOL TH~P/S" in "DATA MONITOR" mode with CONSULT-II.
- 6) Press RECORD on CONSULT-II SCREEN at the same time accelerator pedal is depressed.
- 7) Print out the recorded graph and check the following:
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal is fully depressed is approximately 4V.
 If NG, go to "Diagnostic Procedure", EC-178.
 If OK, go to following step.
- 8) Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT-II.
- 9) Maintain the following conditions for at least 10 consecutive seconds.

| | |
|------------------|--|
| CMPS-RPM (REF) | More than 2,000 rpm |
| MAS AIR/FL SE | More than 3V |
| COOLAN TEMP/S | More than 70°C (158°F) |
| Selector lever | Suitable position |
| Driving location | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 10) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-178.

Ⓜ With GST

Follow the procedure "With CONSULT-II".


DTC P0120 THROTTLE POSITION SENSOR

KA24DE
Wiring Diagram

Wiring Diagram

NGEC0084

EC-TPS-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS




BT

HA

SC

EL

IDX



AEC985A

Diagnostic Procedure

NGEC0085


| 1 | INSPECTION START | | | | | | | | | |
|---|-------------------------|----------|-------------|------|---|---|---|---|---|---|
| Which malfunction A, B or C is duplicated? | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">MALFUNCTION</th> <th style="width: 50%;">Type</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">A</td> <td style="text-align: center;">A</td> </tr> <tr> <td style="text-align: center;">B</td> <td style="text-align: center;">B</td> </tr> <tr> <td style="text-align: center;">C</td> <td style="text-align: center;">C</td> </tr> </tbody> </table> | | | MALFUNCTION | Type | A | A | B | B | C | C |
| MALFUNCTION | Type | | | | | | | | | |
| A | A | | | | | | | | | |
| B | B | | | | | | | | | |
| C | C | | | | | | | | | |
| MTBL0066 | | | | | | | | | | |
| Type A, B or C | | | | | | | | | | |
| Type A or B | ▶ | GO TO 4. | | | | | | | | |
| Type C | ▶ | GO TO 2. | | | | | | | | |

| 2 | ADJUST THROTTLE POSITION SENSOR | | | | | | | | | | | |
|--|--|----------|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|
| 1. Check the following items. Refer to "Basic Inspection", EC-95. | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Items</th> <th style="width: 50%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>20° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>800 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> | | | Items | Specifications | Ignition timing | 20° ± 2° BTDC | Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | Target idle speed | 800 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | | |
| Ignition timing | 20° ± 2° BTDC | | | | | | | | | | | |
| Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | | | | | | | | | | | |
| Target idle speed | 800 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| MTBL0328 | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | |
| OK | ▶ | GO TO 3. | | | | | | | | | | |

| | | |
|---|----------------------------|----------------------|
| 3 | CHECK INTAKE SYSTEM | |
| Check the following for connection. | | |
| <ul style="list-style-type: none"> ● Air duct ● Air cleaner ● Vacuum hoses ● Intake air passage between air duct to intake manifold collector | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Reconnect the parts. |

4 RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.




SEF325V

▶ GO TO 5.


5 CHECK POWER SUPPLY

1. Disconnect throttle position sensor harness connector.



SEF265S

2. Turn ignition switch ON.
3. Check voltage between terminal 1 and ground with CONSULT-II or tester.



SEF564P

Voltage: Approximately 5V

OK or NG

- | | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Repair harness or connectors. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA


SC

EL

IDX

| | | |
|---|-----------------------------|----------|
| 6 | CHECK GROUND CIRCUIT | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check harness continuity between throttle position sensor terminal 3 and engine ground. Refer to the wiring diagram. | | |
|  | | |
| SEF565P | | |
| <p style="color: blue; margin: 0;">Continuity should exist.</p> <ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

| | |
|--|-----------------------------------|
| 7 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ECM and throttle position sensor | |
| ▶ | |
| Repair open circuit or short to ground or short to power in harness or connectors. | |

| | | |
|--|-----------------------------------|--|
| 8 | CHECK INPUT SIGNAL CIRCUIT | |
| <ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 23 and terminal 2. | | |
|  | | |
| SEF211W | | |
| <p style="color: blue; margin: 0;">Continuity should exist.</p> <ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 9. |
| OK (Without CONSULT-II) | ▶ | GO TO 10. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 9 | CHECK THROTTLE POSITION SENSOR | | | | | | | | | | | |
|---|---------------------------------------|--|---------------------------|-----------|-------------------|-----------------|----------------|---------------------|-----------------|---------------|---------------|-------|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine and turn ignition switch ON. 3. Select "DATA MONITOR" mode with CONSULT-II. 4. Check voltage of "THRTL POS SEN" under the following conditions. | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;">NO FAIL</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">CMPS-RPM(REF)</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">COOLAN TEMP/S</td> <td style="text-align: center;">XXX °C</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> </tbody> </table> | | | DATA MONITOR | | MONITORING | NO FAIL | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | THRTL POS SEN | XXX V |
| DATA MONITOR | | | | | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | |
| <p>NOTE: Voltage measurement must be made with throttle position sensor installed in vehicle.</p> | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Throttle valve conditions</th> <th style="text-align: center;">Voltage V</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Completely closed</td> <td style="text-align: center;">0.15 - 0.85 (a)</td> </tr> <tr> <td style="text-align: center;">Partially open</td> <td style="text-align: center;">Between (a) and (b)</td> </tr> <tr> <td style="text-align: center;">Completely open</td> <td style="text-align: center;">3.5 - 4.7 (b)</td> </tr> </tbody> </table> | | | Throttle valve conditions | Voltage V | Completely closed | 0.15 - 0.85 (a) | Partially open | Between (a) and (b) | Completely open | 3.5 - 4.7 (b) | | |
| Throttle valve conditions | Voltage V | | | | | | | | | | | |
| Completely closed | 0.15 - 0.85 (a) | | | | | | | | | | | |
| Partially open | Between (a) and (b) | | | | | | | | | | | |
| Completely open | 3.5 - 4.7 (b) | | | | | | | | | | | |
| <p>If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-95.</p> | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | |
| OK (Type B in step 1) ▶ | | GO TO 11. | | | | | | | | | | |
| OK (Type A or C in step 1) ▶ | | GO TO 14. | | | | | | | | | | |
| NG ▶ | | Replace throttle position sensor. To adjust it, perform "Basic Inspection", EC-95. | | | | | | | | | | |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

| | |
|-----------|---------------------------------------|
| 10 | CHECK THROTTLE POSITION SENSOR |
|-----------|---------------------------------------|

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and turn ignition switch ON.
3. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground under the following conditions.



SEF767W

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

| Throttle valve conditions | Voltage V |
|---------------------------|---------------------|
| Completely closed | 0.15 - 0.85 (a) |
| Partially open | Between (a) and (b) |
| Completely open | 3.5 - 4.7 (b) |

MTBL0329


If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-95.

OK or NG

| | | |
|----------------------------|---|--|
| OK (Type B in step 1) | ▶ | GO TO 11. |
| OK (Type A or C in step 1) | ▶ | GO TO 14. |
| NG | ▶ | Replace throttle position sensor. To adjust it, perform "Basic Inspection", EC-95. |

11 CHECK MASS AIR FLOW SENSOR

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.




SEF326V

| Conditions | Voltage V |
|--|--------------------------|
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 |
| Idle (Engine is warmed-up to normal operating temperature.) | 0.9 - 1.8 |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.9 - 2.3 |
| Idle to about 4,000 rpm* | 1.3 - 1.7 to Approx. 3.0 |

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

MTBL0326

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



SEF893J

OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Replace mass air flow sensor. |


DTC P0120 THROTTLE POSITION SENSOR

KA24DE



Diagnostic Procedure (Cont'd)

12 CHECK CAMSHAFT POSITION SENSOR



1. Start engine and warm it up to normal operating temperature.
2. Check voltage between ECM terminals 49 and engine ground, ECM terminal 44 or 48 and ground.



Terminal 44 or 48 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|--|---|
| Voltage | 0.2 - 0.5V | 0 - 0.5V |
| Pulse signal |  |  |

Terminal 49 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|---|--|
| Voltage | Approximately 2.6V | Approximately 2.5 - 2.6V |
| Pulse signal |  |  |

SEF893W


OK or NG

OK ► GO TO 13.

NG ► Replace distributor assembly with camshaft position sensor.

13 CHECK FUEL INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.



Resistance: 10 - 14Ω [at 25°C (77°F)]

SEF273W

OK or NG

OK ► GO TO 14.

NG ► Replace fuel injector.

DTC P0120 THROTTLE POSITION SENSOR

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|-----------|--|--|
| 14 | CHECK SHIELD CIRCUIT | |
| | <p>1. Turn ignition switch OFF. 2. Remove joint connector-2. 3. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between joint connector-2 terminal 1 and ground ● Joint connector-2 (Refer to "HARNES LAYOUT", <i>EL-263</i>) Continuity should exist. <p>4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 15. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |



| | | |
|-----------|--|-----------------------|
| 15 | CHECK INTERMITTENT INCIDENT | |
| | Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| | ▶ | INSPECTION END |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR

KA24DE

Component Description



Component Description

NGEC0087

NOTE:

If DTC P0125 (0908) is displayed with P0115 (0103), first perform trouble diagnosis for DTC P0115, EC-167.

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>


| Engine coolant temperature °C (°F) | Voltage* V | Resistance kΩ |
|---------------------------------------|---------------|------------------|
| -10 (14) | 4.4 | 7.0 - 11.4 |
| 20 (68) | 3.5 | 2.1 - 2.9 |
| 50 (122) | 2.2 | 0.68 - 1.00 |
| 90 (194) | 0.9 | 0.236 - 0.260 |

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ECM terminal 32 (ECM ground).

On Board Diagnosis Logic

NGEC0089

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0125 0908 | <ul style="list-style-type: none"> • Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. • Engine coolant temperature is insufficient for closed loop fuel control. | <ul style="list-style-type: none"> • Harness or connectors (High resistance in the circuit) • Engine coolant temperature sensor • Thermostat |



DTC Confirmation Procedure

NGEC0090

CAUTION:

Be careful not to overheat engine.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for 65 minutes at idle speed.
If "COOLAN TEMP/S" increases to more than 10°C (50°F) within 65 minutes, stop engine because the test result will be OK.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-188.

With GST

Follow the procedure "With CONSULT-II".

DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR


KA24DE

Wiring Diagram

Wiring Diagram

NGEC0091

EC-ECTS-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



AEC984A

DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0092

| | | |
|--|---------------------------|----------|
| 1 | CHECK POWER SUPPLY | |
| <p>1. Turn ignition switch OFF. 2. Disconnect engine coolant temperature sensor harness connector.</p> | | |
| | | |
| SEF330V | | |
| <p>3. Turn ignition switch ON. 4. Check voltage between coolant temperature sensor connector F9 terminal 1 and ground with CONSULT-II or tester.</p> | | |
| | | |
| SEF206W | | |
| Voltage: Approximately 5V | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

| | |
|--|-----------------------------------|
| 2 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between ECM and engine coolant temperature sensor. | |
| ▶ Repair harness or connectors. | |



| | | |
|---|-----------------------------|----------|
| 3 | CHECK GROUND CIRCUIT | |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between engine coolant temperature sensor connector F9 terminal 2 and engine ground. Refer to the wiring diagram. Continuity should exist. 3. Also check harness for short to ground and short to power.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

| | |
|--|-----------------------------------|
| 4 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between ECM and engine coolant temperature sensor. | |
| ▶ Repair open circuit or short to ground or short to power in harness or connectors. | |

DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR

KA24DE

Diagnostic Procedure (Cont'd)

| 5 | CHECK ENGINE COOLANT TEMPERATURE SENSOR | <p>Check resistance as shown in the figure.</p> <div style="text-align: center;">  </div> <p><Reference data></p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">50 (122)</td> <td style="text-align: center;">0.68 - 1.00</td> </tr> <tr> <td style="text-align: center;">90 (194)</td> <td style="text-align: center;">0.236 - 0.260</td> </tr> </tbody> </table> <div style="text-align: center; margin-top: 20px;">  </div> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; border-right: 1px solid black;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 6.</td> </tr> <tr> <td style="border-right: 1px solid black;">NG</td> <td style="text-align: center;">▶</td> <td>Replace engine coolant temperature sensor.</td> </tr> </table> | Temperature °C (°F) | Resistance kΩ | 20 (68) | 2.1 - 2.9 | 50 (122) | 0.68 - 1.00 | 90 (194) | 0.236 - 0.260 | OK | ▶ | GO TO 6. | NG | ▶ | Replace engine coolant temperature sensor. | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 2px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> <p>SU</p> |
|---------------------|--|---|---------------------|---------------|---------|-----------|----------|-------------|----------|---------------|----|---|----------|----|---|--|---|
| Temperature °C (°F) | Resistance kΩ | | | | | | | | | | | | | | | | |
| 20 (68) | 2.1 - 2.9 | | | | | | | | | | | | | | | | |
| 50 (122) | 0.68 - 1.00 | | | | | | | | | | | | | | | | |
| 90 (194) | 0.236 - 0.260 | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 6. | | | | | | | | | | | | | | | |
| NG | ▶ | Replace engine coolant temperature sensor. | | | | | | | | | | | | | | | |


| | | | | | | | | | |
|----------|-----------------------------------|---|----|---|----------|----|---|--|---|
| 6 | CHECK THERMOSTAT OPERATION | <p>When the engine is cooled [lower than 76.5°C (170°F)], condition grasp lower radiator hose and confirm the engine coolant does not flow.</p> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; border-right: 1px solid black;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 7.</td> </tr> <tr> <td style="border-right: 1px solid black;">NG</td> <td style="text-align: center;">▶</td> <td>Repair or replace thermostat. Refer to "Thermostat", "ENGINE COOLING SYSTEM", LC-13.</td> </tr> </table> | OK | ▶ | GO TO 7. | NG | ▶ | Repair or replace thermostat. Refer to "Thermostat", "ENGINE COOLING SYSTEM", LC-13 . | <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> |
| OK | ▶ | GO TO 7. | | | | | | | |
| NG | ▶ | Repair or replace thermostat. Refer to "Thermostat", "ENGINE COOLING SYSTEM", LC-13 . | | | | | | | |

| | | | | | | |
|----------|------------------------------------|---|--|---|-----------------------|--|
| 7 | CHECK INTERMITTENT INCIDENT | <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; border-right: 1px solid black;"></td> <td style="width: 5%; text-align: center;">▶</td> <td>INSPECTION END</td> </tr> </table> | | ▶ | INSPECTION END | <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| | ▶ | INSPECTION END | | | | |

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

KA24DE


Component Description



Component Description

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0094



CONSULT-II Reference Value in Data Monitor Mode

NGEC0095

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|---------------------------------------|---|
| FR O2 SENSOR | | | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR | <ul style="list-style-type: none"> Engine: After warming up | Maintaining engine speed at 2,000 rpm | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0096


Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------|--|--|
| 50 | B | Front heated oxygen sensor | <p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | <p>0 - Approximately 1.0V</p> <p>SEF008W</p> |

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

KA24DE

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0097

Under the condition in which the front heated oxygen sensor signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0130 0303 | <ul style="list-style-type: none"> ● The voltage from the sensor is constantly approx. 0.3V. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Front heated oxygen sensor |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

KA24DE

On Board Diagnosis Logic (Cont'd)

| | | |
|---|--------------------|----------|
| 5 | FR O2 SENSOR P0130 | |
| | OUT OF CONDITION | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF138V

| | | |
|---|--------------------|----------|
| 5 | FR O2 SENSOR P0130 | |
| | TESTING | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF139V

| | | |
|---|--------------------|--|
| 5 | FR O2 SENSOR P0130 | |
| | COMPLETED | |

PEF210V

DTC Confirmation Procedure

=NGEC0098

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "FR O2 SENSOR P0130" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 3) Touch "START".
- 4) Let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,000 rpm after this step. If the engine speed limit is exceeded, return to step 4.

- 5) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

| | |
|----------------|-----------------------------|
| CMPS-RPM (REF) | 1,400 - 3,200 rpm |
| Vehicle speed | 70 - 100 km/h (43 - 62 MPH) |
| B/FUEL SCHDL | 1.0 - 5.2 msec |
| Selector lever | Suitable position |

If "TESTING" is not displayed after 5 minutes, retry from step 2.


- 6) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-195.

During this test, P1148 may be displayed on CONSULT-II screen.

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

KA24DE

Overall Function Check



Overall Function Check

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed. =NGEC0099

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
- 4) If NG, go to "Diagnostic Procedure", EC-195.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)






KA24DE

Wiring Diagram

Wiring Diagram

NGEC0100

EC-FRO2-01



AEC986A



DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)


KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0101

| | | | |
|------------|-------------------------|---|--|
| 1 | INSPECTION START | <ol style="list-style-type: none"> Turn ignition switch OFF. Loosen and retighten engine ground screws.  <ol style="list-style-type: none"> Disconnect front heated oxygen sensor harness connector.  | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> |
| ▶ GO TO 2. | | <p>SEF325V</p> <p>SEF331V</p> | |

| | | | |
|---|-----------------------------------|--|---|
| 2 | CHECK INPUT SIGNAL CIRCUIT | <ol style="list-style-type: none"> Disconnect ECM harness connector. Check harness continuity between ECM harness connector F29 terminal 50 and terminal 2.  <p style="color: blue;">Continuity should exist.</p> <ol style="list-style-type: none"> Check harness continuity between ECM harness connector F29 terminal 50 (or terminal 2) and ground. Also check harness for short to power. <p style="text-align: center;">OK or NG</p> | <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> |
| OK (With CONSULT-II) ▶ GO TO 3. | | | |
| OK (Without CONSULT-II) ▶ GO TO 4. | | | |
| NG ▶ Repair open circuit or short to ground or short to power in harness or connectors. | | | |

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)

3 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
3. Select "FR O2 SENSOR" AND "FR O2 MNTR" in Item Selection.
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "START" on CONSULT-II screen.

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLANT TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| FR O2 MNTR | LAEN |
| INJ PULSE | XXX msec |

PEF084P

6. Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R


SEF947V

R = "FR O2 MNTR", "RICH"

L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.3V at least once.
- "FR O2 SENSOR" voltage never exceeds 1.0V.

| SPREADSHEET | | |
|-------------|-----------------|----------------|
| REPLAY MODE | REPLAY MODE | |
| NUMERICAL | SHOW TRIGGER | |
| | CMPS-RPM rpm | FR O2 SEN V |
| XXX | XXX | XXX |



• Maximum voltage should be over 0.6V at least one time.

• Minimum voltage should be below 0.30V at least one time.

PEF736W

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK ▶ GO TO 5.

NG ▶ Replace front heated oxygen sensor.

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|---|
| 4 | CHECK FRONT HEATED OXYGEN SENSOR |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground. <div style="text-align: center; margin: 10px 0;"> </div> <ol style="list-style-type: none"> 3. Check the following with engine speed held at 2,000 rpm constant under no load. <ul style="list-style-type: none"> ● Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p style="margin-left: 20px;">CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center; margin-left: 20px;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ Replace front heated oxygen sensor. |

| | |
|--|--|
| 5 | CHECK SHIELD CIRCUIT |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove joint connector-1. 3. Check the following. <ul style="list-style-type: none"> ● Continuity between joint connector-1 terminal 1 and ground ● Joint connector-1 (Refer to "HARNES LAYOUT", EL-272.) <p style="margin-left: 20px; color: blue;">Continuity should exist.</p> 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. <p style="text-align: center; margin-left: 20px;">OK or NG</p> | |
| OK | ▶ GO TO 6. |
| NG | ▶ Repair open circuit, short to ground or short to power in harness or connectors. |


| | |
|--|------------------------------------|
| 6 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

KA24DE


Component Description



Component Description

NGEC0103

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

NGEC0104

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|---------------------------------------|---|
| FR O2 SENSOR | | | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR | <ul style="list-style-type: none"> Engine: After warming up | Maintaining engine speed at 2,000 rpm | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0105


Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------|--|--|
| 50 | B | Front heated oxygen sensor | <p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | <p>0 - Approximately 1.0V</p> <p>SEF008W</p> |

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

KA24DE

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0106

To judge the malfunction, the output from the front heated oxygen sensor is monitored to determine whether the “rich” output is sufficiently high and whether the “lean” output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.

GI
MA
EM
LC

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0131 0411 | <ul style="list-style-type: none"> The maximum and minimum voltages from the sensor are not reached to the specified voltages. | <ul style="list-style-type: none"> Front heated oxygen sensor Front heated oxygen sensor heater Fuel pressure Injectors Intake air leaks |

EC
FE
CL

| | | |
|---|--------------------|----------|
| 6 | FR O2 SENSOR P0131 | |
| | OUT OF CONDITION | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF143V

DTC Confirmation Procedure

NGEC0107

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

AT
TF
PD

| | | |
|---|--------------------|----------|
| 6 | FR O2 SENSOR P0131 | |
| | TESTING | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF144V

With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Stop engine and wait at least 5 seconds.
- Turn ignition switch ON and select “FR O2 SENSOR P0131” of “FRONT O2 SENSOR” in “DTC WORK SUPPORT” mode with CONSULT-II.
- Touch “START”.
- Start engine and let it idle for at least 3.0 minutes.

NOTE:

Never raise engine speed above 3,000 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

AX
SU
BR
ST

| | | |
|---|--------------------|--|
| 6 | FR O2 SENSOR P0131 | |
| | COMPLETED | |

PEF211V

| | |
|----------------|-----------------------------|
| CMPS.RPM (REF) | 1,700 - 3,000 rpm |
| Vehicle speed | 80 - 100 km/h (50 - 62 MPH) |
| B/FUEL SCHDL | 1.0 - 4.9 msec |
| Selector lever | Suitable position |

RS
BT
HA

SC
EL
IDX


DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

KA24DE

DTC Confirmation Procedure (Cont'd)

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-200.



Overall Function Check

NGEC0108

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
- 4) If NG, go to "Diagnostic Procedure", EC-200.

Diagnostic Procedure

NGEC0109

| | |
|---|---|
| 1 | RETIGHTEN FRONT HEATED OXYGEN SENSOR |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten front heated oxygen sensor.</p> <div style="text-align: center;"> </div> <p>Tightening torque: 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)</p> | |
| ▶ | GO TO 2. |

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA.

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".


| ACTIVE TEST | |
|--------------------|---------|
| SELF-LEARN CONTROL | 100 % |
| MONITOR | |
| CMPS-RPM | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| A/F ALPHA | XXX % |
| | |
| | |
| | |

SEF165X

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected? Is it difficult to start engine?

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.



AEC131A

4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-67.
7. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
8. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC 0115 detected? Is it difficult to start engine?

Yes or No

| | | |
|-----|---|---|
| Yes | ▶ | Perform trouble diagnosis for DTC P0171. Refer to EC-278. |
| No | ▶ | GO TO 3. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|--|-------------------------------------|
| 3 | CHECK FRONT HEATED OXYGEN SENSOR HEATER | |
| <p>Check resistance between terminals 3 and 1.</p> <div style="text-align: center;">  </div> | | |
| SEF220W | | |
| <p>Resistance: 2.3 - 4.3 Ω at 25°C (77°F)</p> <p>Check continuity between terminals 2 and 1, 3 and 2.</p> <p>Continuity should not exist.</p> <p>CAUTION: Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 4. |
| OK (Without CONSULT-II) | ▶ | GO TO 5. |
| NG | ▶ | Replace front heated oxygen sensor. |

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

4 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
3. Select "FR O2 SENSOR" AND "FR O2 MNTR" in Item Selection.
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "START" on CONSULT-II screen.

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLANT TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| FR O2 MNTR | LAEN |
| INJ PULSE | XXX msec |

PEF084P

6. Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R


SEF947V

R = "FR O2 MNTR", "RICH"

L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.3V at least once.
- "FR O2 SENSOR" voltage never exceeds 1.0V.

| SPREADSHEET | | |
|-------------|--------------|-----------|
| REPLAY MODE | REPLAY MODE | |
| NUMERICAL | SHOW TRIGGER | |
| | CMPS-RPM | FR O2 SEN |
| | rpm | V |
| XXX | XXX | XXX |



• Maximum voltage should be over 0.6V at least one time.

• Minimum voltage should be below 0.30V at least one time.

PEF736W

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK ► GO TO 6.

NG ► Replace front heated oxygen sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|---|
| 5 | CHECK FRONT HEATED OXYGEN SENSOR |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground. <div style="text-align: center; margin: 10px 0;"> </div> <ol style="list-style-type: none"> 3. Check the following with engine speed held at 2,000 rpm constant under no load. <ul style="list-style-type: none"> ● Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p style="margin-left: 20px;">CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center; margin-left: 20px;">OK or NG</p> | |
| OK | ▶ GO TO 6. |
| NG | ▶ Replace front heated oxygen sensor. |


AEC873A

| | |
|---|------------------------------------|
| 6 | CHECK INTERMITTENT INCIDENT |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. Refer to "Wiring Diagram", EC-194, for circuit.</p> | |
| ▶ | INSPECTION END |

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

KA24DE

Component Description




SEF463R

Component Description

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0111



SEF288D

CONSULT-II Reference Value in Data Monitor Mode

NGEC0112

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|---------------------------------------|---|
| FR O2 SENSOR | | | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR | <ul style="list-style-type: none"> Engine: After warming up | Maintaining engine speed at 2,000 rpm | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0113


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------|--|--|
| 50 | B | Front heated oxygen sensor | <p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | <p>0 - Approximately 1.0V</p> <p>SEF008W</p> |

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

KA24DE

On Board Diagnosis Logic






On Board Diagnosis Logic

NGEC0114

To judge the malfunction, the output from the front heated oxygen sensor is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0132 0410 | <ul style="list-style-type: none"> The maximum and minimum voltages from the sensor are beyond the specified voltages. | <ul style="list-style-type: none"> Front heated oxygen sensor Front heated oxygen sensor heater Fuel pressure Injectors |



DTC Confirmation Procedure

NGEC0115

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Stop engine and wait at least 5 seconds.
- Turn ignition switch ON and select “FR O2 SENSOR P0132” of “FRONT O2 SENSOR” in “DTC WORK SUPPORT” mode with CONSULT-II.
- Touch “START”.
- Start engine and let it idle for at least 3.0 minutes.

NOTE:

Never raise engine speed above 3,000 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

| | |
|----------------|-----------------------------|
| CMPS.RPM (REF) | 1,700 - 3,000 rpm |
| Vehicle speed | 80 - 100 km/h (50 - 62 MPH) |
| B/FUEL SCHDL | 1.0 - 4.9 msec |
| Selector lever | Suitable position |

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

KA24DE

DTC Confirmation Procedure (Cont'd)

If "TESTING" is not displayed after 5 minutes, retry from step 2.


- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-207.

GI

MA

EM

LC



AEC873A

Overall Function Check

NGEC0116

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

EC

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and ECM ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.35V at least one time.
- 4) If NG, go to "Diagnostic Procedure", EC-207.

FE

CL

MT

AT

TF

PD

AX

Diagnostic Procedure

NGEC0117

SU

| | |
|--|---|
| 1 | RETIGHTEN FRONT HEATED OXYGEN SENSOR |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten front heated oxygen sensor.</p> <div style="text-align: center;"> <p>Vehicle front</p> <p>Front heated oxygen sensor</p> <p>40 - 60 (4.1 - 6.1, 30 - 44)</p> <p>: N·m (kg·m, ft·lb)</p> </div> <p>Tightening torque: 40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb)</p> | |
| ▶ | GO TO 2. |

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA

Ⓜ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".


| ACTIVE TEST | |
|--------------------|---------|
| SELF-LEARN CONTROL | 100 % |
| MONITOR | |
| CMPS-RPM | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| A/F ALPHA | XXX % |
| | |
| | |
| | |

SEF165X

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected? Is it difficult to start engine?

ⓧ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.



SEF293W

4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-67.
7. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
8. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC 0114 detected? Is it difficult to start engine?

Yes or No

| | | |
|-----|---|---|
| Yes | ▶ | Perform trouble diagnosis for DTC P0172. Refer to EC-286. |
| No | ▶ | GO TO 3. |

3 CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect front heated oxygen sensor harness connector.
3. Check harness connector for water.
Water should not exit.


OK or NG

| | | |
|----|---|--------------------------------------|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair or replace harness connector. |

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|--|-------------------------------------|
| 4 | CHECK FRONT HEATED OXYGEN SENSOR HEATER | |
| <p>Check resistance between terminals 3 and 1.</p> <div style="display: flex; justify-content: center; align-items: center; gap: 20px;">     </div> | | |
| SEF220W | | |
| <p>Resistance: 2.3 - 4.3 Ω at 25°C (77°F)</p> <p>Check continuity between terminals 2 and 1, 3 and 2.</p> <p>Continuity should not exist.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 5. |
| OK (Without CONSULT-II) | ▶ | GO TO 6. |
| NG | ▶ | Replace front heated oxygen sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

5 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
3. Select "FR O2 SENSOR" and "FR O2 MNTR" in item selection.
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLANT TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| FR O2 MNTR | LAEN |
| INJ PULSE | XXX msec |

PEF084P

6. Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R


SEF947V

R = "FR O2 MNTR", "RICH"

L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.3V at least once.
- "FR O2 SENSOR" voltage never exceeds 1.0V.

| SPREADSHEET | | |
|-------------|--------------|-----------|
| REPLAY MODE | REPLAY MODE | |
| NUMERICAL | SHOW TRIGGER | |
| | CMPS-RPM | FR O2 SEN |
| | rpm | V |
| XXX | XXX | XXX |



- Maximum voltage should be over 0.6V at least one time.

- Minimum voltage should be below 0.30V at least one time.

PEF736W

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|-------------------------------------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace front heated oxygen sensor. |

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|---|-------------------------------------|
| 6 | CHECK FRONT HEATED OXYGEN SENSOR | |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground. | | |
| | | |
| AEC873A | | |
| <ol style="list-style-type: none"> Check the following with engine speed held at 2,000 rpm constant under no load. <ul style="list-style-type: none"> Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). The maximum voltage is over 0.6V at least one time. The minimum voltage is below 0.3V at least one time. The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace front heated oxygen sensor. |


| | | |
|---|------------------------------------|-----------------------|
| 7 | CHECK INTERMITTENT INCIDENT | |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. Refer to "Wiring Diagram", EC-194, for circuit.</p> | | |
| | ▶ | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE


Component Description



Component Description

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0119



CONSULT-II Reference Value in Data Monitor Mode

NGEC0120

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|---------------------------------------|---|
| FR O2 SENSOR | | | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR | <ul style="list-style-type: none"> Engine: After warming up | Maintaining engine speed at 2,000 rpm | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0121


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------|--|--|
| 50 | B | Front heated oxygen sensor | <p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | <p>0 - Approximately 1.0V</p> <p>SEF008W</p> |

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE

On Board Diagnosis Logic



On Board Diagnosis Logic

To judge the malfunction of front heated oxygen sensor, this diagnosis measures response time of front heated oxygen sensor signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and front heated oxygen sensor temperature index. Judgment is based on whether the compensated time (front heated oxygen sensor cycling time index) is inordinately long or not.

NGEC0122

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P0133 0409 | <ul style="list-style-type: none"> The response of the voltage signal from the sensor takes more than the specified time. | <ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Front heated oxygen sensor Front heated oxygen sensor heater Fuel pressure Injectors Intake air leaks Exhaust gas leaks PCV Mass air flow sensor |

| | | | | | | | | | | | | | | |
|--------------------|--|--------------------|--|------------------|--|---------|--|---------------|---------|---------------|-------|--------------|----------|---------|
| 6 | <table border="1"> <tr> <td colspan="2">FR O2 SENSOR P0133</td> </tr> <tr> <td colspan="2">OUT OF CONDITION</td> </tr> <tr> <td colspan="2">MONITOR</td> </tr> <tr> <td>CMPS~RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table> | FR O2 SENSOR P0133 | | OUT OF CONDITION | | MONITOR | | CMPS~RPM(REF) | XXX rpm | THRTL POS SEN | XXX V | B/FUEL SCHDL | XXX msec | PEF148V |
| FR O2 SENSOR P0133 | | | | | | | | | | | | | | |
| OUT OF CONDITION | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | |
| B/FUEL SCHDL | XXX msec | | | | | | | | | | | | | |

| | | | | | | | | | | | | | | |
|--------------------|---|--------------------|--|---------|--|---------|--|---------------|---------|---------------|-------|--------------|----------|---------|
| 6 | <table border="1"> <tr> <td colspan="2">FR O2 SENSOR P0133</td> </tr> <tr> <td colspan="2">TESTING</td> </tr> <tr> <td colspan="2">MONITOR</td> </tr> <tr> <td>CMPS~RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table> | FR O2 SENSOR P0133 | | TESTING | | MONITOR | | CMPS~RPM(REF) | XXX rpm | THRTL POS SEN | XXX V | B/FUEL SCHDL | XXX msec | PEF149V |
| FR O2 SENSOR P0133 | | | | | | | | | | | | | | |
| TESTING | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | |
| B/FUEL SCHDL | XXX msec | | | | | | | | | | | | | |

| | | | | | | |
|--------------------|--|--------------------|--|-----------|--|---------|
| 6 | <table border="1"> <tr> <td colspan="2">FR O2 SENSOR P0133</td> </tr> <tr> <td colspan="2">COMPLETED</td> </tr> </table> | FR O2 SENSOR P0133 | | COMPLETED | | PEF213V |
| FR O2 SENSOR P0133 | | | | | | |
| COMPLETED | | | | | | |

DTC Confirmation Procedure

NGEC0123

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Stop engine and wait at least 5 seconds.
- Turn ignition switch ON and select "FR O2 SENSOR P0133" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- Touch "START".
- Start engine and let it idle for at least 3.0 minutes.

NOTE:

Never raise engine speed above 3,000 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 20 seconds.)

| | |
|----------------|-----------------------------|
| CMPS-RPM (REF) | 1,700 - 3,600 rpm |
| Vehicle speed | 80 - 120 km/h (50 - 75 MPH) |
| B/FUEL SCHDL | 1.1 - 4.9 msec |
| Selector lever | Suitable position |


DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE

DTC Confirmation Procedure (Cont'd)

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-216.



Overall Function Check

NGEC0124

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
- 4) If NG, go to "Diagnostic Procedure", EC-216.

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)


KA24DE

Wiring Diagram





Wiring Diagram

NGEC0125

EC-FRO2-01



- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX



AEC986A


DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)


KA24DE


Diagnostic Procedure

Diagnostic Procedure

NGEC0126

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> | |
|  | |
| SEF325V | |
| ▶ | GO TO 2. |

| | |
|---|---|
| 2 | RETIGHTEN FRONT HEATED OXYGEN SENSOR |
| Loosen and retighten front heated oxygen sensor. | |
|  | |
| SEF332V | |
| <p>Tightening torque: 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)</p> | |
| ▶ | GO TO 3. |

| | |
|---|-------------------------------|
| 3 | CHECK EXHAUST AIR LEAK |
| <p>1. Start engine and run it at idle. 2. Listen for an exhaust air leak before three way catalyst.</p> | |
|  | |
| SEF099P | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair or replace. |


DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|----------------------------------|--------------------|
| 4 | CHECK FOR INTAKE AIR LEAK | |
| Listen for an intake air leak between the mass air flow sensor and the intake manifold. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair or replace. |

| 5 | CLEAR THE SELF-LEARNING DATA | | | | | | | | | | | | | | | | | | | | | |
|---|-------------------------------------|--|-------------|--|--------------------|-------|---------|--|----------|---------|---------------|--------|--------------|-------|-----------|-------|--|--|--|--|--|--|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II. Clear the self-learning control coefficient by touching "CLEAR". | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>SELF-LEARN CONTROL</td><td>100 %</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM</td><td>XXX rpm</td></tr> <tr><td>COOLAN TEMP/S</td><td>XXX °C</td></tr> <tr><td>FR O2 SENSOR</td><td>XXX V</td></tr> <tr><td>A/F ALPHA</td><td>XXX %</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | | ACTIVE TEST | | SELF-LEARN CONTROL | 100 % | MONITOR | | CMPS-RPM | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SENSOR | XXX V | A/F ALPHA | XXX % | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN CONTROL | 100 % | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | | |
| FR O2 SENSOR | XXX V | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| SEF165X | | | | | | | | | | | | | | | | | | | | | | |
| <ol style="list-style-type: none"> Run engine for at least 10 minutes at idle speed. <p>Is the 1st trip DTC P0171 or P0172 detected? Is it difficult to start engine?</p> | | | | | | | | | | | | | | | | | | | | | | |

| | | |
|---|---|---|
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Turn ignition switch OFF. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed. | | |
|  | | |
| AEC131A | | |
| <ol style="list-style-type: none"> Stop engine and reconnect mass air flow sensor harness connector. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-67. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II. Run engine for at least 10 minutes at idle speed. <p>Is the 1st trip DTC 0114 or 0115 detected? Is it difficult to start engine?</p> <p style="text-align: center;">Yes or No</p> | | |
| Yes | ▶ | Perform trouble diagnosis for DTC P0171, P0172. Refer to EC-278, 286. |
| No | ▶ | GO TO 6. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 6 | CHECK INPUT SIGNAL CIRCUIT |
| <p>1. Disconnect front heated oxygen sensor harness connector and ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 50 and terminal 2.</p> | |
| | |
| SEF141V | |
| <p>Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal 50 (or terminal 2) and ground.</p> <p>Continuity should not exist.</p> <p>4. Also check harness for short to power.</p> | |
| OK or NG | |
| OK | ▶ GO TO 7. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|--|
| 7 | CHECK FRONT HEATED OXYGEN SENSOR HEATER |
| <p>Check resistance between terminals 3 and 1.</p> | |
| | |
| SEF220W | |
| <p>Resistance: 2.3 - 4.3 Ω at 25°C (77°F)</p> <p>Check continuity between terminals 2 and 1, 3 and 2.</p> <p>Continuity should not exist.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. | |
| OK or NG | |
| OK (With CONSULT-II) | ▶ GO TO 8. |
| OK (Without CONSULT-II) | ▶ GO TO 9. |
| NG | ▶ Replace front heated oxygen sensor. |

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

8 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
3. Select "FR O2 SENSOR" and "FR O2 MNTR" in item selection.
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "START" on CONSULT-II screen.

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLANT TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| FR O2 MNTR | LAEN |
| INJ PULSE | XXX msec |

PEF084P

6. Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R


R = "FR O2 MNTR", "RICH"

L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.3V at least once.
- "FR O2 SENSOR" voltage never exceeds 1.0V.

SEF947V

| SPREADSHEET | | |
|-------------|--------------|-----------|
| REPLAY MODE | REPLAY MODE | |
| NUMERICAL | SHOW TRIGGER | |
| | CMPS-RPM | FR O2 SEN |
| | rpm | V |
| XXX | XXX | XXX |



• Maximum voltage should be over 0.6V at least one time.

• Minimum voltage should be below 0.30V at least one time.

PEF736W

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK ► GO TO 10.

NG ► Replace front heated oxygen sensor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)


KA24DE

Diagnostic Procedure (Cont'd)

9 CHECK FRONT HEATED OXYGEN SENSOR

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground.



AEC873A

3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|-------------------------------------|
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace front heated oxygen sensor. |


DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

10 CHECK MASS AIR FLOW SENSOR

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.




SEF326V

| Conditions | Voltage V |
|--|--------------------------|
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 |
| Idle (Engine is warmed-up to normal operating temperature.) | 0.9 - 1.8 |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.9 - 2.3 |
| Idle to about 4,000 rpm* | 1.3 - 1.7 to Approx. 3.0 |

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

MTBL0326

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



SEF893J

OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 11. |
| NG | ▶ | Replace mass air flow sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|--|------------------------|---|------------------------------|
| 11 | CHECK PCV VALVE | | |
| <p>1. With engine running at idle, remove PCV valve from breather separator.</p> <p>2. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over the valve inlet.</p> | | | |
|  | | | |
| SEC137A | | | |
| OK or NG | | | |
| OK | | ▶ | GO TO 12. |
| NG | | ▶ | Repair or replace PCV valve. |


| | | | |
|--|-----------------------------|---|--|
| 12 | CHECK SHIELD CIRCUIT | | |
| <p>1. Turn ignition switch OFF.</p> <p>2. Remove joint connector-1.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between joint connector-1 terminal 1 and ground ● Joint connector-1 <p>(Refer to "HARNESS LAYOUT", <i>EL-272</i>.)</p> <p style="color: blue;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect joint connector.</p> | | | |
| OK or NG | | | |
| OK | | ▶ | GO TO 13. |
| NG | | ▶ | Repair open circuit, short to ground or short to power in harness or connectors. |

| | | | |
|--|------------------------------------|---|-----------------------|
| 13 | CHECK INTERMITTENT INCIDENT | | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | | |
| | | ▶ | INSPECTION END |

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

KA24DE


Component Description



Component Description

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0128



CONSULT-II Reference Value in Data Monitor Mode

NGEC0129

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|---------------------------------------|---|
| FR O2 SENSOR | | | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR | <ul style="list-style-type: none"> Engine: After warming up | Maintaining engine speed at 2,000 rpm | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0130

Specification data are reference values and are measured between each terminal and 43 (ECM ground).


| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------|--|--|
| 50 | B | Front heated oxygen sensor | <p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | <p>0 - Approximately 1.0V</p> <p>SEF008W</p> |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

KA24DE

On Board Diagnosis Logic




On Board Diagnosis Logic

NGEC0131

To judge the malfunction, the diagnosis checks that the front heated oxygen sensor output is not inordinately high.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0134 0412 | <ul style="list-style-type: none"> An excessively high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Front heated oxygen sensor |



DTC Confirmation Procedure

NGEC0132

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Restart engine and let it idle for 35 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-226.

Ⓜ With GST

- 1) Start engine and warm it up to normal operating temperature.
 - 2) Turn ignition switch OFF and wait at least 5 seconds.
 - 3) Restart engine and let it idle for 35 seconds.
 - 4) Turn ignition switch OFF and wait at least 5 seconds.
 - 5) Restart engine and let it idle for 35 seconds.
 - 6) Select "MODE 3" with GST.
 - 7) If DTC is detected, go to "Diagnostic Procedure", EC-226.
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II or ECM (Diagnostic Test Mode II) is recommended.**

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)


KA24DE

Wiring Diagram

Wiring Diagram






NGEC0133

EC-FRO2-01



- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST

- RS
- BT
- HA
- SC
- EL
- IDX



AEC986A


DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)



KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0134

| | |
|--|---|
| 1 | RETIGHTEN FRONT HEATED OXYGEN SENSOR |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten front heated oxygen sensor.</p> <div style="text-align: center;">  </div> <p>Tightening torque: 40 - 60 N-m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)</p> <p style="text-align: right;">SEF332V</p> | |
| ▶ | GO TO 2. |

| | |
|---|--|
| 2 | CHECK INPUT SIGNAL CIRCUIT |
| <p>1. Disconnect front heated oxygen sensor harness connector and ECM harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF331V</p> | |
| <p>2. Check harness continuity between ECM terminal 50 and terminal 2.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF141V</p> | |
| <p>Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal 50 (or terminal 2) and ground. Continuity should not exist.</p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 3. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|--------------------------------|--------------------------------------|
| 3 | CHECK HARNESS CONNECTOR | |
| Check front heated oxygen sensor harness connector for water. Water should not exist. | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 4. |
| OK (Without CONSULT-II) | ▶ | GO TO 5. |
| NG | ▶ | Repair or replace harness connector. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

KA24DE

Diagnostic Procedure (Cont'd)

4 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
3. Select "FR O2 SENSOR" and "FR O2 MNTR" in item selection.
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "START" on CONSULT-II screen.

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLANT TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| FR O2 MNTR | LAEN |
| INJ PULSE | XXX msec |

PEF084P

6. Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R


SEF947V

R = "FR O2 MNTR", "RICH"

L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.3V at least once.
- "FR O2 SENSOR" voltage never exceeds 1.0V.

| SPREADSHEET | | |
|-------------|-----------------|----------------|
| REPLAY MODE | REPLAY MODE | |
| NUMERICAL | SHOW TRIGGER | |
| | CMPS-RPM rpm | FR O2 SEN V |
| XXX | XXX | XXX |



• Maximum voltage should be over 0.6V at least one time.

• Minimum voltage should be below 0.30V at least one time.

PEF736W

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK ▶ GO TO 6.

NG ▶ Replace front heated oxygen sensor.

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | | | | | | |
|--|---|-------------------------------------|----|---|----------|----|---|-------------------------------------|
| 5 | CHECK FRONT HEATED OXYGEN SENSOR | | | | | | | |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; margin-right: 20px;">AEC873A</p> <ol style="list-style-type: none"> 3. Check the following with engine speed held at 2,000 rpm constant under no load. <ul style="list-style-type: none"> ● Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p style="margin-left: 20px;">CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center; margin-left: 20px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 20%; padding: 5px;">OK</td> <td style="width: 10%; text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">GO TO 6.</td> </tr> <tr> <td style="padding: 5px;">NG</td> <td style="text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">Replace front heated oxygen sensor.</td> </tr> </table> | | | OK | ▶ | GO TO 6. | NG | ▶ | Replace front heated oxygen sensor. |
| OK | ▶ | GO TO 6. | | | | | | |
| NG | ▶ | Replace front heated oxygen sensor. | | | | | | |

| | | | | | | | | |
|--|-----------------------------|--|----|---|----------|----|---|--|
| 6 | CHECK SHIELD CIRCUIT | | | | | | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove joint connector-1. 3. Check the following. <ul style="list-style-type: none"> ● Continuity between joint connector-1 terminal 1 and ground ● Joint connector-1 (Refer to "HARNES LAYOUT", EL-272.) <p style="margin-left: 20px; color: blue;">Continuity should exist.</p> 4. Also check harness for short to ground and short to power. Then reconnect joint connector. <p style="text-align: center; margin-left: 20px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 20%; padding: 5px;">OK</td> <td style="width: 10%; text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">GO TO 7.</td> </tr> <tr> <td style="padding: 5px;">NG</td> <td style="text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">Repair open circuit, short to ground or short to power in harness or connectors.</td> </tr> </table> | | | OK | ▶ | GO TO 7. | NG | ▶ | Repair open circuit, short to ground or short to power in harness or connectors. |
| OK | ▶ | GO TO 7. | | | | | | |
| NG | ▶ | Repair open circuit, short to ground or short to power in harness or connectors. | | | | | | |

| | | |
|--|------------------------------------|-----------------------|
| 7 | CHECK INTERMITTENT INCIDENT | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| ▶ | | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Description

Description

NGEC0136

SYSTEM DESCRIPTION

NGEC0136S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|---|-----------------------------------|
| Camshaft position sensor | Engine speed | Front heated oxygen sensor heater control | Front heated oxygen sensor heater |

The ECM performs ON/OFF control of the front heated oxygen sensor heater corresponding to the engine operating condition.

OPERATION

NGEC0136S02

| Engine speed | Front heated oxygen sensor heater |
|-----------------|-----------------------------------|
| Above 3,000 rpm | OFF |
| Below 3,000 rpm | ON |

CONSULT-II Reference Value in Data Monitor Mode

NGEC0137

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---------------------------------|---------------|
| FR O2 HEATER | ● Engine speed: Below 3,000 rpm | ON |
| | ● Engine speed: Above 3,000 rpm | OFF |

ECM Terminals and Reference Value

NGEC0138

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-----------------------------------|--|----------------------------|
| 119 | BR/Y | Front heated oxygen sensor heater | [Engine is running] ● Engine speed is below 3,000 rpm. | Approximately 0.4V |
| | | | [Engine is running] ● Engine speed is above 3,000 rpm. | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0139

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0135 0901 | <ul style="list-style-type: none"> The current amperage in the front heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM through the front heated oxygen sensor heater.) | <ul style="list-style-type: none"> Harness or connectors (The front heated oxygen sensor heater circuit is open or shorted.) Front heated oxygen sensor heater |

DTC Confirmation Procedure


NGEC0140

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.



 With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 6 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-233.

 With GST

- 1) Start engine and run it for at least 6 seconds at idle speed.
 - 2) Turn ignition switch OFF and wait least 6 seconds at idle speed.
 - 3) Select "MODE 3" with GST.
 - 4) If DTC is detected, go to "Diagnostic Procedure", EC-233.
- When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II or ECM (Diagnostic Test Mode II) is recommended.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC






EL

IDX

Wiring Diagram



NGEC0141

EC-FRO2/H-01



Diagnostic Procedure


NGEC0142

| | | | |
|----------|---------------------------|---|-------------------------------|
| 1 | CHECK POWER SUPPLY | | |
| | | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect front heated oxygen sensor harness connector.</p>  <p>3. Turn ignition switch ON.</p> <p>4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p>  <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>SEF331V</p> <p>SEF213W</p> |
| | OK | ▶ GO TO 3. | |
| | NG | ▶ GO TO 2. | |

| | | | |
|----------|-----------------------------------|--|--|
| 2 | DETECT MALFUNCTIONING PART | | |
| | | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● 15A fuse ● Harness for open or short between front heated oxygen sensor and 15A fuse <p style="text-align: right;">▶ Repair harness or connectors.</p> | |

| | | | |
|----------|-----------------------------|---|--|
| 3 | CHECK GROUND CIRCUIT | | |
| | | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between front heated oxygen sensor terminal 3 and ECM terminal 119. Refer to the wiring diagram.</p> <p style="color: blue;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| | OK | ▶ GO TO 4. | |
| | NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


| | |
|---|--|
| 4 | CHECK FRONT HEATED OXYGEN SENSOR HEATER |
| <p>Check resistance between terminals 3 and 1.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 50px;">SEF220W</p> <p>Resistance: 2.3 - 4.3 Ω at 25°C (77°F)</p> <p>Check continuity between terminals 2 and 1, 3 and 2.</p> <p>Continuity should not exist.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center; margin: 10px 0;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ Replace front heated oxygen sensor. |

| | |
|---|------------------------------------|
| 5 | CHECK INTERMITTENT INCIDENT |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> | |
| ▶ | INSPECTION END |

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

Component Description



Component Description

NGEC0144

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0145

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|-------------------------------|
| RR O2 SENSOR | ● Engine: After warming up Revsing engine from idle to 3,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0146

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---------------------------|--|------------------------|
| 56 | OR | Rear heated oxygen sensor | [Engine is running] ● After warming up to normal operating temperature and revving engine from idle to 3,000 rpm quickly | 0 - Approximately 1.0V |



On Board Diagnosis Logic

NGEC0147

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the minimum voltage of the sensor is sufficiently low during various driving conditions such as fuel-cut.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0137 0511 | ● The minimum voltage from the sensor does not reach the specified voltage. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor ● Fuel pressure ● Injectors |

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

On Board Diagnosis Logic (Cont'd)

6

RR O2 SENSOR P0137

WAIT
OPEN ENGINE HOOD.
KEEP ENGINE RUNNING AT
IDLE SPEED FOR MAXIMUM
OF 5 MINUTES.

SEF548X

8

RR O2 SENSOR P0137

MAINTAIN
1800 - 2800 RPM UNTIL FINAL
RESULT APPEARS.

1800 rpm 2300 rpm 2800 rpm

SEF549X

8

RR O2 SENSOR P0137

COMPLETED

SELF-DIAG RESULTS

SEF550X

DTC Confirmation Procedure

NGEC0148

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Open engine hood before conducting following procedure With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure the "COOLANT TEMP/S" is more then 70°C (158°F).
- 6) Select "RR O2 SEN P0137", of "REAR O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 7) Start engine and follow the instructions of CONSULT-II.
- 8) Make sure the "OK" is displayed after touching "SELF-DIAG RESULTS".
If NG is displayed, refer to "DIAGNOSTIC PROCEDURE", EC-239.
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a) Stop engine and cool down "COOLANT TEMP/SE" to less then 70°C 158°F.
 - b) Turn ignition switch ON
 - c) Select "DATA MONITOR" mode with CONSULT-II.
 - d) Perform from step 6) again when the "COOLANT TEMP/S" reach to 70°C 158°F.

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

Overall Function Check



Overall Function Check

=NGEC0149

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

⊗ Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and ECM ground.
- 4) Check the voltage when revving engine up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 0.54V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should be below 0.54V at least once during this procedure.
- 6) If NG, go to "Diagnostic Procedure", EC-239.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)







KA24DE

Wiring Diagram

Wiring Diagram

NGEC0150

EC-RRO2-01



AEC988A


DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0151

| | |
|--|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p>  <p>The diagram shows a top-down view of the engine compartment. Two engine ground screws are labeled F11 and F12. An air duct is also shown. An arrow points to the front of the vehicle.</p> | |
| ▶ | GO TO 2. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".


| ACTIVE TEST | |
|--------------------|---------|
| SELF-LEARN CONTROL | 100 % |
| MONITOR | |
| CMPS-RPM | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| A/F ALPHA | XXX % |
| | |
| | |
| | |

SEF165X

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected? Is it difficult to start engine?

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.



AEC131A

4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-67.
7. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
8. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC 0114 detected? Is it difficult to start engine?


Yes or No

| | | |
|-----|---|---|
| Yes | ▶ | Perform trouble diagnosis for DTC P0172. Refer to EC-286. |
| No | ▶ | GO TO 3. |

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|----------|-----------------------------------|---|---|
| 3 | CHECK INPUT SIGNAL CIRCUIT | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect rear heated oxygen sensor harness connector and ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 56 and terminal 1.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF157V</p> <p>Continuity should exist.</p> <p>4. Check harness continuity between ECM terminal 56 (or terminal 1) and ground.</p> <p>Continuity should not exist.</p> <p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | GI MA EM LC EC FE CL MT |
| OK | ▶ | GO TO 5. | |
| NG | ▶ | GO TO 4. | |

| | | | |
|----------|-----------------------------------|---|----------------|
| 4 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Harness for open or short between rear heated oxygen sensor and ECM <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p> | AT TF PD |
|----------|-----------------------------------|---|----------------|

| | | | |
|-------------------------|-----------------------------|--|---|
| 5 | CHECK GROUND CIRCUIT | <p>1. Check harness continuity between rear heated oxygen sensor terminal 4 and engine ground. Refer to "Wiring Diagram", EC-238.</p> <p>Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | AX SU BR ST RS BT HA SC EL IDX |
| OK (With CONSULT-II) | ▶ | GO TO 6. | |
| OK (Without CONSULT-II) | ▶ | GO TO 7. | |
| NG | ▶ | GO TO 4. | |

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

6 CHECK REAR HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT-II.
4. Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.


| ACTIVE TEST | |
|----------------|---------|
| FUEL INJECTION | 25 % |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 SENSOR | XXX V |
| RR O2 SENSOR | XXX V |
| FR O2 MNTR | RICH |
| RR O2 MNTR | RICH |
| | |
| | |

PEF102P

"RR O2 SENSOR" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "RR O2 SENSOR" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



OK ▶

GO TO 8.

NG ▶

Replace rear heated oxygen sensor.

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | | | | | | | |
|----------|--|--|----|---|----------|----|---|------------------------------------|---|
| 7 | CHECK REAR HEATED OXYGEN SENSOR | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and ECM ground. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; margin-right: 20px;">AEC874A</p> <ol style="list-style-type: none"> 4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.) The voltage should be above 0.56V at least once. If the voltage is above 0.56V at step 4, step 5 is not necessary. 5. Check the voltage when revving up to 5,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position. The voltage should be below 0.54V at least once. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center; margin: 10px 0;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace rear heated oxygen sensor.</td> </tr> </table> | OK | ▶ | GO TO 8. | NG | ▶ | Replace rear heated oxygen sensor. | GI MA EM LC EC FE CL MT AT TF PD |
| OK | ▶ | GO TO 8. | | | | | | | |
| NG | ▶ | Replace rear heated oxygen sensor. | | | | | | | |

| | | | | | | | | | |
|----------|-----------------------------|---|----|---|-----------|----|---|----------|---|
| 8 | CHECK SHIELD CIRCUIT | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect harness connectors F27. 3. Check harness continuity between harness connector F27 terminal 14 and ground. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; margin-right: 20px;">SEF158V</p> <p>Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Then reconnect harness connectors. <p style="text-align: center; margin: 10px 0;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 10.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 9.</td> </tr> </table> | OK | ▶ | GO TO 10. | NG | ▶ | GO TO 9. | AX SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 10. | | | | | | | |
| NG | ▶ | GO TO 9. | | | | | | | |

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

KA24DE


Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 9 | DETECT MALFUNCTIONING PART |
| Check the following. | |
| <ul style="list-style-type: none">● Joint connector-1 (Refer to "HARNES LAYOUT", <i>EL-272</i>.)● Harness for open or short between harness connector F27 and engine ground | |
| ▶ | Repair open circuit, short to ground or short to power in harness or connectors. |
| 10 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

Component Description



SEF327R

Component Description

NGEC0153

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0154

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|-------------------------------|
| RR O2 SENSOR | ● Engine: After warming up Revsing engine from idle to 3,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0155

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---------------------------|--|------------------------|
| 56 | OR | Rear heated oxygen sensor | [Engine is running] ● After warming up to normal operating temperature and revving engine from idle to 3,000 rpm quickly | 0 - Approximately 1.0V |



SEF303U

On Board Diagnosis Logic

NGEC0156

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the maximum voltage of the sensor is sufficiently high during various driving conditions such as fuel-cut.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0138 0510 | ● The maximum voltage from the sensor does not reach the specified voltage. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor ● Fuel pressure ● Injectors ● Intake air leaks |

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

On Board Diagnosis Logic (Cont'd)

| RR O2 SENSOR P0138 |
|--|
| WAIT OPEN ENGINE HOOD. KEEP ENGINE RUNNING AT IDLE SPEED FOR MAXIMUM OF 5 MINUTES. |

SEF551X

| RR O2 SENSOR P0138 |
|---|
| MAINTAIN 1800 - 2800 RPM UNTIL FINAL RESULT APPEARS. |
|  |

SEF552X

| RR O2 SENSOR P0138 |
|--------------------|
| COMPLETED |
| SELF-DIAG RESULTS |

SEF553X

DTC Confirmation Procedure

NGEC0157

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Open engine hood before conducting following procedure With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure the "COOLANT TEMP/S" is more then 70°C (158°F).
- 6) Select "RR O2 SEN P0138", of "REAR O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 7) Start engine and follow the instructions of CONSULT-II.
- 8) Make sure the "OK" is displayed after touching "SELF-DIAG RESULTS".
If NG is displayed, refer to "DIAGNOSTIC PROCEDURE", EC-249.
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a) Stop engine and cool down "COOLANT TEMP/SE" to less then 70°C 158°F.
 - b) Turn ignition switch ON.
 - c) Select "DATA MONITOR" mode with CONSULT-II.
 - d) Perform from step 6) again when the 'COOLANT TEMP/S' reach to 70°C 158°F.

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

Overall Function Check



Overall Function Check

=NGEC0158

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

⊗ Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and ECM ground.
- 4) Check the voltage when revving engine up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.56V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position .
The voltage should be above 0.56V at least once during this procedure.
- 6) If NG, go to "Diagnostic Procedure", EC-249.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)






KA24DE

Wiring Diagram

Wiring Diagram

NGEC0159

EC-RRO2-01



AEC988A


DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0160

| | |
|----------|---|
| 1 | RETIGHTEN GROUND SCREWS 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.  <p>The diagram shows a top-down view of the engine compartment. Two engine ground screws are labeled F11 and F12. An air duct is also shown. An arrow points to the front of the vehicle.</p> |
| ▶ | GO TO 2. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".


| ACTIVE TEST | |
|--------------------|---------|
| SELF-LEARN CONTROL | 100 % |
| MONITOR | |
| CMPS-RPM | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| A/F ALPHA | XXX % |
| | |
| | |
| | |

SEF165X

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected? Is it difficult to start engine?

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.



AEC131A

4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-67.
7. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
8. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC 0115 detected? Is it difficult to start engine?

Yes or No

| | | |
|-----|---|---|
| Yes | ▶ | Perform trouble diagnosis for DTC P0171. Refer to EC-278. |
| No | ▶ | GO TO 3. |

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|-----------------------------------|
| 3 | CHECK INPUT SIGNAL CIRCUIT |
| <p>1. Disconnect rear heated oxygen sensor harness connector and ECM harness connector.</p> <p>2. Check harness continuity between ECM harness connector F29 terminal 56 and terminal 1.</p> | |
| | |
| <p style="text-align: right;">SEF157V</p> <p>Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal 56 (or terminal 1) and ground.</p> <p>Continuity should not exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Harness for open or short between ECM and rear heated oxygen sensor | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|--|
| 5 | CHECK GROUND CIRCUIT |
| <p>1. Check harness continuity between rear heated oxygen sensor connector M21 terminal 4 and engine ground. Refer to :Wiring Diagram", EC-248.</p> <p>Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK (With CONSULT-II) | ▶ GO TO 6. |
| OK (Without CONSULT-II) | ▶ GO TO 7. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

6 CHECK REAR HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT-II.
4. Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.


| ACTIVE TEST | |
|----------------|---------|
| FUEL INJECTION | 25 % |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 SENSOR | XXX V |
| RR O2 SENSOR | XXX V |
| FR O2 MNTR | RICH |
| RR O2 MNTR | RICH |
| | |
| | |

PEF102P

"RR O2 SENSOR" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "RR O2 SENSOR" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



OK ► GO TO 8.

NG ► Replace rear heated oxygen sensor.

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | | | | | |
|--|--|------------------------------------|---|----------|----|---|------------------------------------|
| 7 | CHECK REAR HEATED OXYGEN SENSOR | | | | | | |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and ECM ground. <div style="text-align: center;"> </div> <ol style="list-style-type: none"> 4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.) The voltage should be above 0.56V at least once. If the voltage is above 0.56V at step 4, step 5 is not necessary. 5. Check the voltage when revving up to 5,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "O/D" OFF (A/T). The voltage should be below 0.54V at least once. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace rear heated oxygen sensor.</td> </tr> </table> | | OK | ▶ | GO TO 8. | NG | ▶ | Replace rear heated oxygen sensor. |
| OK | ▶ | GO TO 8. | | | | | |
| NG | ▶ | Replace rear heated oxygen sensor. | | | | | |

| | | | | | | | |
|--|-----------------------------|-----------|---|-----------|----|---|----------|
| 8 | CHECK SHIELD CIRCUIT | | | | | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect harness connectors F27. 3. Check harness continuity between harness connector F27 terminal 14 and ground. <div style="text-align: center;"> </div> <p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Then reconnect harness connectors. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 10.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 9.</td> </tr> </table> | | OK | ▶ | GO TO 10. | NG | ▶ | GO TO 9. |
| OK | ▶ | GO TO 10. | | | | | |
| NG | ▶ | GO TO 9. | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

KA24DE


Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 9 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none">● Joint connector-1 (Refer to "HARNESS LAYOUT", <i>EL-262</i>.)● Harness for open or short between harness connector F27 and engine ground | |
| ▶ | Repair open circuit, short to ground or short to power in harness or connectors. |
| 10 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

Component Description



Component Description

NGEC0162

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0163

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|-------------------------------|
| RR O2 SENSOR | ● Engine: After warming up Revsing engine from idle to 3,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0164

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---------------------------|--|------------------------|
| 56 | OR | Rear heated oxygen sensor | [Engine is running] ● After warming up to normal operating temperature and revving engine from idle to 3,000 rpm | 0 - Approximately 1.0V |



On Board Diagnosis Logic

NGEC0165

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the switching response of the sensor's voltage is faster than specified during various driving conditions such as fuel-cut.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P0139 0707 | ● It takes more than the specified time for the sensor to respond between rich and lean. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor ● Fuel pressure ● Injectors ● Intake air leaks |

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

On Board Diagnosis Logic (Cont'd)

| |
|--|
| RR O2 SENSOR P0139 |
| WAIT OPEN ENGINE HOOD. KEEP ENGINE RUNNING AT IDLE SPEED FOR MAXIMUM OF 5 MINUTES. |

SEF554X

| |
|---|
| RR O2 SENSOR P0139 |
| MAINTAIN 1800 - 2800 RPM UNTIL FINAL RESULT APPEARS. |
|  |

SEF555X

| |
|---------------------------|
| RR O2 SENSOR P0139 |
| COMPLETED |
| SELF-DIAG RESULTS |

SEF556X

DTC Confirmation Procedure

NGEC0166

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Open engine hood before conducting following procedure With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure the "COOLANT TEMP/S" is more then 70°C (158°F).
- 6) Select "RR O2 SEN P0139", of "REAR O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 7) Start engine and follow the instructions of CONSULT-II.
- 8) Make sure the "OK" is displayed after touching "SELF-DIAG RESULTS".
If NG is displayed, refer to "DIAGNOSTIC PROCEDURE", EC-259.
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a) Stop engine and cool down "COOLANT TEMP/SE" to less then 70°C 158°F.
 - b) Turn ignition switch ON
 - c) Select "DATA MONITOR" mode with CONSULT-II.
 - d) Perform from step 6) again when the 'COOLANT TEMP/S" reach to 70°C 158°F.

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

Overall Function Check



Overall Function Check

=NGEC0167

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

⊗ Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should change at more than 0.06V for 1 second during this procedure.
- 6) If NG, go to "Diagnostic Procedure", EC-259.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)






KA24DE

Wiring Diagram

Wiring Diagram

NGEC0168

EC-RRO2-01



AEC988A


DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0169

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p>  <p>The diagram shows a top-down view of the engine compartment. Two engine ground screws are labeled F11 and F12. An air duct is also shown. A downward arrow indicates the vehicle front direction.</p> | |
| ▶ | GO TO 2. |

SEF325V

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA

Ⓟ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".


| ACTIVE TEST | |
|--------------------|---------|
| SELF-LEARN CONTROL | 100 % |
| MONITOR | |
| CMPS-RPM | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| A/F ALPHA | XXX % |
| | |
| | |
| | |

SEF165X

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected? Is it difficult to start engine?

ⓧ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.



AEC131A

4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-67.
7. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
8. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC 0114 or 0115 detected? Is it difficult to start engine?

Yes or No

| | | |
|-----|---|--|
| Yes | ▶ | Perform trouble diagnosis for DTC P0171 or P0172. Refer to EC-278 or EC-286. |
| No | ▶ | GO TO 3. |

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|-----------------------------------|
| 3 | CHECK INPUT SIGNAL CIRCUIT |
| <p>1. Disconnect rear heated oxygen sensor harness connector and ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 56 and terminal 1.</p> | |
| | |
| SEF157V | |
| <p>Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal 56 (or terminal 1) and ground.</p> <p>Continuity should not exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Harness for open or short between rear heated oxygen sensor and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|-----------------------------|
| 5 | CHECK GROUND CIRCUIT |
| <p>1. Check harness continuity between rear heated oxygen sensor terminal 4 and engine ground. Refer to the wiring diagram.</p> <p>Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK (With CONSULT-II) | ▶ GO TO 6. |
| OK (Without CONSULT-II) | ▶ GO TO 7. |
| NG | ▶ GO TO 4. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

6 CHECK REAR HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT-II.
4. Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.


| ACTIVE TEST | |
|----------------|---------|
| FUEL INJECTION | 25 % |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 SENSOR | XXX V |
| RR O2 SENSOR | XXX V |
| FR O2 MNTR | RICH |
| RR O2 MNTR | RICH |
| | |
| | |

PEF102P

"RR O2 SENSOR" should be above 0.56V at least once when the "FUEL INJECTION" is +25%."RR O2 SENSOR" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



| | | |
|----|---|------------------------------------|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace rear heated oxygen sensor. |

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|----------|--|---|--|
| 7 | CHECK REAR HEATED OXYGEN SENSOR | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and engine ground. <div style="text-align: center; margin: 10px 0;"> </div> <ol style="list-style-type: none"> 4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.) The voltage should be above 0.56V at least once. If the voltage is above 0.56V at step 4, step 5 is not necessary. 5. Check the voltage when revving up to 5,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position. The voltage should be below 0.54V at least once. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 5px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> |
| OK | ▶ | GO TO 8. | PD |
| NG | ▶ | Replace rear heated oxygen sensor. | AX <p style="vertical-align: top; text-align: center;">SU</p> <p style="vertical-align: top; text-align: center;">BR</p> <p style="vertical-align: top; text-align: center;">ST</p> <p style="vertical-align: top; text-align: center;">RS</p> <p style="vertical-align: top; text-align: center;">BT</p> <p style="vertical-align: top; text-align: center;">HA</p> <p style="vertical-align: top; text-align: center;">SC</p> <p style="vertical-align: top; text-align: center;">EL</p> <p style="vertical-align: top; text-align: center;">IDX</p> |

| | | | |
|----------|-----------------------------|--|--|
| 8 | CHECK SHIELD CIRCUIT | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect harness connectors F27. 3. Check harness continuity between harness connector F27 terminal 14 and ground. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; margin-top: 10px;">SEF158V</p> <p style="text-align: center; color: blue; margin-top: 10px;">Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Then reconnect harness connectors. <p style="text-align: center;">OK or NG</p> | <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| OK | ▶ | GO TO 10. | SC <p style="vertical-align: top; text-align: center;">EL</p> <p style="vertical-align: top; text-align: center;">IDX</p> |
| NG | ▶ | GO TO 9. | EL <p style="vertical-align: top; text-align: center;">IDX</p> |

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

KA24DE


Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 9 | DETECT MALFUNCTIONING PART |
| Check the following. | |
| <ul style="list-style-type: none">● Joint connector-1 (Refer to "HARNESS LAYOUT", <i>EL-272</i>.)● Harness for open or short between harness connector F27 and engine ground | |
| ▶ | Repair open circuit, short to ground or short to power in harness or connectors. |
| 10 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

KA24DE

Component Description



Component Description

NGEC0171

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0172

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|-------------------------------|
| RR O2 SENSOR | ● Engine: After warming up Revsing engine from idle to 3,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0173

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---------------------------|--|------------------------|
| 56 | OR | Rear heated oxygen sensor | [Engine is running] ● After warming up to normal operating temperature and revving engine from idle to 3,000 rpm | 0 - Approximately 1.0V |



On Board Diagnosis Logic

NGEC0174

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether or not the voltage is too high during various driving conditions such as fuel-cut.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0140 0512 | ● An excessively high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor |

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

KA24DE

DTC Confirmation Procedure

| | | |
|---------------|---------------|---------|
| 5 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS~RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| VHCL SPEED SE | XXX km/h | |
| B/FUEL SCHDL | XXX msec | |

PEF168V

DTC Confirmation Procedure

NGEC0175

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 3) Maintain the following conditions for at least 5 consecutive seconds.

| | |
|----------------|--|
| CMPS-RPM (REF) | 1,400 - 3,200 rpm |
| VHCL SPEED SE | 64 - 120 km/h (40 - 75 MPH) |
| B/FUEL SCHDL | 0.5 - 4.8 msec (A/T) 0.5 - 5.2 msec (M/T) |
| COOLAN TEMP/S | 70 - 100°C (158 - 212°F) |
| Selector lever | Suitable position |

- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-268.



Overall Function Check

NGEC0176

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

ⓧ Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and ECM ground.
- 4) Check the voltage after revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 2V during this procedure.
- 5) If NG, go to "Diagnostic Procedure", EC-268.

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

KA24DE

Wiring Diagram

Wiring Diagram

NGEC0177

EC-RRO2-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS





BT

HA

SC

EL

IDX



AEC988A


DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)


KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0178

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> | |
|  | |
| SEF325V | |
| ▶ GO TO 2. | |

| | | | | | | | |
|--|-----------------------------------|----------|---|----------|----|---|----------|
| 2 | CHECK INPUT SIGNAL CIRCUIT | | | | | | |
| <p>1. Disconnect rear heated oxygen sensor harness connector and ECM harness connector. 2. Check harness continuity between ECM terminal 56 and terminal 1.</p> | | | | | | | |
|  | | | | | | | |
| SEF157V | | | | | | | |
| <p>Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal 56 (or terminal 1) and ground. Continuity should not exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | |
| <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; border-right: 1px solid black;">OK</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td style="border-right: 1px solid black;">NG</td> <td style="text-align: center;">▶</td> <td>GO TO 3.</td> </tr> </table> | | OK | ▶ | GO TO 4. | NG | ▶ | GO TO 3. |
| OK | ▶ | GO TO 4. | | | | | |
| NG | ▶ | GO TO 3. | | | | | |

| | |
|--|-----------------------------------|
| 3 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Harness for open or short between rear heated oxygen sensor and ECM | |
| ▶ Repair open circuit or short to ground or short to power in harness or connectors. | |

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|-----------------------------|----------|
| 4 | CHECK GROUND CIRCUIT | |
| <p>1. Check harness continuity between rear heated oxygen sensor terminal 4 and engine ground. Refer to "Wiring Diagram", EC-267. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

| | | |
|--|--------------------------------|--------------------------------------|
| 5 | CHECK HARNESS CONNECTOR | |
| <p>Check rear heated oxygen sensor harness connector for water. Water should not exist.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | Repair or replace harness connector. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

KA24DE

Diagnostic Procedure (Cont'd)

6 CHECK REAR HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT-II.
4. Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.


| ACTIVE TEST | |
|----------------|---------|
| FUEL INJECTION | 25 % |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 SENSOR | XXX V |
| RR O2 SENSOR | XXX V |
| FR O2 MNTR | RICH |
| RR O2 MNTR | RICH |
| | |
| | |

PEF102P

"RR O2 SENSOR" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "RR O2 SENSOR" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



OK ▶

GO TO 8.

NG ▶

Replace rear heated oxygen sensor.

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|----------|--|--|---|
| 7 | CHECK REAR HEATED OXYGEN SENSOR | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Set voltmeter probes between ECM terminals 56 (Rear heated oxygen sensor signal) and ECM ground. <div style="text-align: center; margin: 10px 0;"> </div> <ol style="list-style-type: none"> 4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.) The voltage should be above 0.56V at least once. If the voltage is above 0.56V at step 4, step 5 is not necessary. 5. Check the voltage when revving up to 5,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position. The voltage should be below 0.54V at least once. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center; margin-top: 10px;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 5px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> |
| OK | ▶ | GO TO 8. | PD |
| NG | ▶ | Replace rear heated oxygen sensor. | AX <p style="text-align: center;">SU</p> <p style="text-align: center;">BR</p> <p style="text-align: center;">ST</p> <p style="text-align: center;">RS</p> <p style="text-align: center;">BT</p> <p style="text-align: center;">HA</p> <p style="text-align: center;">SC</p> <p style="text-align: center;">EL</p> <p style="text-align: center;">IDX</p> |

| | | | |
|----------|-----------------------------|--|--|
| 8 | CHECK SHIELD CIRCUIT | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect harness connectors F27. 3. Check harness continuity between harness connector F27 terminal 14 and ground. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; margin-top: 10px;">SEF158V</p> <p>Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Then reconnect harness connectors. <p style="text-align: center; margin-top: 10px;">OK or NG</p> | <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| OK | ▶ | GO TO 10. | SC <p style="text-align: center;">EL</p> <p style="text-align: center;">IDX</p> |
| NG | ▶ | GO TO 9. | EL <p style="text-align: center;">IDX</p> |

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 9 | DETECT MALFUNCTIONING PART |
| Check the following. | |
| <ul style="list-style-type: none">● Joint connector-1 (Refer to "HARNESS LAYOUT", <i>EL-272</i>.)● Harness for open or short between harness connector F27 and engine ground | |
| ▶ | Repair open circuit, short to ground or short to power in harness or connectors. |
| 10 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

Description

NGEC0180

SYSTEM DESCRIPTION

NGEC0180S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|--|----------------------------------|
| Camshaft position sensor | Engine speed | Rear heated oxygen sensor heater control | Rear heated oxygen sensor heater |

The ECM performs ON/OFF control of the rear heated oxygen sensor heater corresponding to the engine speed.

OPERATION

NGEC0180S02

| | |
|--------------------------------------|----------------------------------|
| Engine condition | Rear heated oxygen sensor heater |
| Ignition switch ON Engine stopped | OFF |
| Engine is running. | ON |

CONSULT-II Reference Value in Data Monitor Mode

NGEC0181

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|---------------|
| RR O2 HEATER | <ul style="list-style-type: none"> Engine speed: Idle [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] | ON |
| | <ul style="list-style-type: none"> Ignition switch ON (Engine stopped) | OFF |

ECM Terminals and Reference Value

NGEC0182

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|----------------------------------|---|----------------------------|
| 122 | R/B | Rear heated oxygen sensor heater | [Engine is running] <ul style="list-style-type: none"> After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more | Approximately 0.4V |
| | | | [Ignition switch "ON"] <ul style="list-style-type: none"> Engine stopped | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0183

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0141 0902 | <ul style="list-style-type: none"> The current amperage in the rear heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM through the rear heated oxygen sensor heater.) | <ul style="list-style-type: none"> Harness or connectors (The rear heated oxygen sensor heater circuit is open or shorted.) Rear heated oxygen sensor heater |

DTC Confirmation Procedure

NGEC0184

NOTE:

If "DTC Confirmation Procedure " has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is in between 10.5V at idle.

| | | |
|---|------------------------|---------|
| 2 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS~RPM(REF) XXX rpm | |
| | VHCL SPEED SE XXX km/h | |
| | THRTL POS SEN XXX v | |

PEF723W

With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-276.

With GST

- 1) Start engine.
- 2) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 3) Stop vehicle and let engine idle for at least 6 seconds.
- 4) Turn ignition switch OFF and wait at least 10 seconds.
- 5) Start engine.
- 6) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes
- 7) Stop vehicle and let engine idle for at least 6 seconds.
- 8) Select "MODE 3" with GST.
- 9) If DTC is detected, go to "Diagnostic Procedure", EC-276.

When using GST, "DTC Confirmation Procedure " should be performed twice as much as when using CONSULT-II or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II or ECM (Diagnostic Test Mode II) is recommended.

DTC P0141 REAR HEATED OXYGEN SENSOR HEATER

KA24DE

Wiring Diagram

Wiring Diagram

NGEC0185

EC-RR02/H-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS







BT

HA

SC

EL


IDX



AEC989A

Diagnostic Procedure

NGEC0186

| | | | |
|--|---------------------------|---|----------|
| 1 | CHECK POWER SUPPLY | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect rear heated oxygen sensor harness connector. 3. Turn ignition switch ON. 4. Check voltage between terminal 2 and ground. | | | |
|  | | | |
| <p>Voltage: Battery voltage</p> <p>OK or NG</p> | | | |
| OK | | ▶ | GO TO 3. |
| NG | | ▶ | GO TO 2. |

SEF218W

| | | | |
|--|-----------------------------------|---|-------------------------------|
| 2 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● 15A fuse ● Harness for open or short between rear heated oxygen sensor and 15A fuse | | | |
| | | ▶ | Repair harness or connectors. |

| | | | |
|--|-----------------------------|---|----------|
| 3 | CHECK GROUND CIRCUIT | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between rear heated oxygen sensor terminal 3 and ECM terminal 122. Refer to the wiring diagram. <p>Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. | | | |
| <p>OK or NG</p> | | | |
| OK | | ▶ | GO TO 5. |
| NG | | ▶ | GO TO 4. |


| | | | |
|---|-----------------------------------|---|--|
| 4 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M58, F28 ● Harness for open or short between rear heated oxygen sensor heater and ECM | | | |
| | | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

5 CHECK REAR HEATED OXYGEN SENSOR HEATER

Check the following.

1. Check resistance between terminals 2 and 3.



Resistance: 2.3 - 4.3Ω at 25°C (77°F)

SEF221W

2. Check continuity.

| Terminal No. | Continuity |
|---------------|------------|
| 1 and 2, 3, 4 | No |
| 4 and 1, 2, 3 | |

MTBL0330

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|------------------------------------|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace rear heated oxygen sensor. |

6 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

▶ **INSPECTION END**

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

KA24DE

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0188

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

| Sensor | Input Signal to ECM | ECM function | Actuator |
|----------------------------|---|--|-----------|
| Front heated oxygen sensor | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | Fuel injection & mixture ratio control | Injectors |

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0171 0115 | <ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) | <ul style="list-style-type: none"> Intake air leaks Front heated oxygen sensor Injectors Exhaust gas leaks Incorrect fuel pressure Lack of fuel Mass air flow sensor |

4


| ACTIVE TEST | |
|--------------------|---------|
| SELF~LEARN CONTROL | 100 % |
| MONITOR | |
| COMP~LEARN | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| A/F ALPHA | XXX % |
| | |
| | |
| | |

PEF737W

6

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) | XXX rpm |
| | |
| | |
| | |

PEF712T



DTC Confirmation Procedure

NGEC0189

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 5 seconds.
- Turn ignition switch ON and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT-II.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-281.
- If it is difficult to start engine at step 6, the fuel injection system has a malfunction.
- Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-281. If engine does not start, visually check for exhaust and intake air leak.

Ⓜ With GST

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 5 seconds.
- Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- Stop engine and reconnect mass air flow sensor harness connector.
- Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- Select "MODE 4" with GST and erase the 1st trip DTC P0100.

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

KA24DE

DTC Confirmation Procedure (Cont'd)

- 7) Start engine again and run it for at least 10 minutes at idle speed.
- 8) Select "MODE 7" with GST. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-281.
- 9) If it is difficult to start engine at step 8, the fuel injection system has a malfunction.
- 10) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-281. If engine does not start, visually check for exhaust and intake air leak.

GI

MA

EM

No Tools

LC

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Turn ignition switch OFF.
- 6) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure 1st trip DTC 0102 is detected.
- 7) Erase the 1st trip DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I. Refer to "How to Erase DTC (No Tools)", EC-68.
- 8) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 9) Start engine again and run it for at least 10 minutes at idle speed. The 1st trip DTC 0115 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-281.
- 10) If it is difficult to start engine at step 9, the fuel injection system also has a malfunction.
- 11) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-281. If engine does not start, visually check for exhaust and intake air leak.

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)






KA24DE

Wiring Diagram

Wiring Diagram

NGEC0190

EC-FUEL-01



AEC990A


DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0191

| | | |
|--|-------------------------------|--------------------|
| 1 | CHECK EXHAUST AIR LEAK | |
| <p>1. Start engine and run it at idle. 2. Listen for an exhaust air leak before three way catalyst.</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">SEF099P</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Repair or replace. |



| | | |
|---|----------------------------------|--------------------|
| 2 | CHECK FOR INTAKE AIR LEAK | |
| <p>Listen for an intake air leak between the mass air flow sensor and the intake manifold.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 3 | CHECK FRONT HEATED OXYGEN SENSOR CIRCUIT |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect front heated oxygen sensor harness connector and ECM harness connector.</p> | |
|  | |
| <p>3. Check harness continuity between ECM terminal 50 and terminal 2.</p> | |
|  | |
| <p>Continuity should exist.</p> <p>4. Check harness continuity between ECM terminal 50 (or terminal 2) and ground.</p> <p>Continuity should not exist.</p> <p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

SEF331V

SEF141V

| | |
|---|----------------------------|
| 4 | CHECK FUEL PRESSURE |
| <p>1. Release fuel pressure to zero. Refer to EC-40.</p> <p>2. Install fuel pressure gauge and check fuel pressure.</p> <p style="margin-left: 20px;">At idling:</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm², 34 psi)</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm², 43 psi)</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 6. |
| NG | ▶ GO TO 5. |

| | |
|--|-----------------------------------|
| 5 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuel pump and circuit Refer to EC-561. ● Fuel pressure regulator Refer to EC-41. ● Fuel lines Refer to "ENGINE MAINTENANCE", MA-20. ● Fuel filter for clogging | |
| ▶ | Repair or replace. |

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|-----------------------------------|--|
| 6 | CHECK MASS AIR FLOW SENSOR | |
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II. at idling: 0.9 - 5.8 g-m/sec at 2,500 rpm: 7.5 - 13.2 g-m/sec | | |
| <p> With GST</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Check mass air flow sensor signal in MODE 1 with GST. at idling: 0.9 - 5.8 g-m/sec at 2,500 rpm: 7.5 - 13.2 g-m/sec | | |
| <p> No Tools</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Check voltage between ECM terminal 47 (Mass air flow sensor signal) and ground. at idling: 0.9 - 1.8V at 2,500 rpm: 1.9 - 2.3V | | |
| OK or NG | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-136. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

KA24DE

Diagnostic Procedure (Cont'd)

7 CHECK FUNCTION OF INJECTORS

Ⓜ With CONSULT-II

1. Install all parts removed.
2. Start engine.
3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.


| ACTIVE TEST | |
|----------------|---------|
| POWER BALANCE | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| MAS AIR/FL SEN | XXX V |
| IACV-AAC/V | XXX % |
| | |
| | |
| | |
| | |

SEF167X

4. Make sure that each circuit produces a momentary engine speed drop.

ⓧ Without CONSULT-II

1. Install all parts removed.
2. Start engine.
3. Listen to each injector operating sound.



MEC703B

Clicking noise should be heard.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Perform trouble diagnosis for "INJECTORS", EC-553. |

8 REMOVE INJECTOR


1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch OFF.
3. Remove injector with fuel tube assembly. Refer to EC-41.
Keep fuel hose and all injectors connected to injector gallery. The injector harness connectors should remain connected.

| | | |
|--|---|----------|
| | ▶ | GO TO 9. |
|--|---|----------|

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|-----------------------|---|
| 9 | CHECK INJECTOR | |
| <p>1. Disconnect all ignition coil harness connectors. 2. Place pans or saucers under each injector. 3. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.</p> | | |
|  | | |
| <p>Fuel should be sprayed evenly for each cylinder.</p> <p style="text-align: right;">SEF595Q</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace injectors from which fuel does not spray out. Always replace O-ring with new one. |

| | | |
|--|------------------------------------|--|
| 10 | CHECK INTERMITTENT INCIDENT | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| ▶ INSPECTION END | | |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

KA24DE

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0192

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

| Sensor | Input Signal to ECM | ECM function | Actuator |
|----------------------------|---|--|-----------|
| Front heated oxygen sensor | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | Fuel injection & mixture ratio control | Injectors |

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0172 0114 | <ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) | <ul style="list-style-type: none"> Front heated oxygen sensor Injectors Exhaust gas leaks Incorrect fuel pressure Mass air flow sensor |

4


| ACTIVE TEST | |
|--------------------|---------|
| SELF~LEARN CONTROL | 100 % |
| MONITOR | |
| COMP~LEARN | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| A/F ALPHA | XXX % |
| | |
| | |
| | |

PEF737W

6

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) | XXX rpm |
| | |
| | |
| | |

PEF712T



DTC Confirmation Procedure

NGEC0193

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓟ With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 5 seconds.
- Turn ignition switch ON and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT-II.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-289.
- If it is difficult to start engine at step 6, the fuel injection system has a malfunction.
- Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-289. If engine does not start, remove ignition plugs and check for fouling, etc.

Ⓢ With GST

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 5 seconds.
- Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- Stop engine and reconnect mass air flow sensor harness connector.
- Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- Select "MODE 4" with GST and erase the 1st trip DTC P0100.

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

KA24DE

DTC Confirmation Procedure (Cont'd)

- 7) Start engine again and run it for at least 10 minutes at idle speed.
- 8) Select "MODE 7" with GST. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-289. GI
- 9) If it is difficult to start engine at step 8, the fuel injection system has a malfunction. MA
- 10) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-289. If engine does not start, remove ignition plugs and check for fouling, etc. EM
LC

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart engine and run it for at least 3 seconds at idle speed. EC
- 4) Stop engine and reconnect mass air flow sensor harness connector. FE
- 5) Turn ignition switch ON. CL
- 6) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure 1st trip DTC 0102 is detected.
- 7) Erase the 1st trip DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I. Refer to "How to Erase DTC (No Tools)", EC-68. MT
- 8) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected. AT
- 9) Start engine again and run it for at least 10 minutes at idle speed. The 1st trip DTC 0114 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-289. TF
PD
- 10) If it is difficult to start engine at step 9, the fuel injection system also has a malfunction.
- 11) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-289. If engine does not start, remove ignition plugs and check for fouling, etc. AX
SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)



KA24DE

Wiring Diagram

Wiring Diagram

NGEC0194

EC-FUEL-01



AEC990A


DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)



KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0195

| | | | |
|----------|-----------------------------------|---|---------|
| 1 | CHECK FOR EXHAUST AIR LEAK | | |
| | | <ol style="list-style-type: none"> 1. Start engine and run it at idle. 2. Listen for an exhaust air leak before the warm-up three way catalyst (California model), the three way catalyst (Non-California model). | |
| | |  | |
| | | OK or NG | SEF099P |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Repair or replace. | |

| | | | |
|----------|---|---|---------|
| 2 | CHECK FRONT HEATED OXYGEN SENSOR CIRCUIT | | |
| | | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect front heated oxygen sensor harness connector and ECM harness connector. | |
| | |  | |
| | | 3. Check harness continuity between ECM terminal 50 and terminal 2. | SEF331V |
| | |  | |
| | | Continuity should exist. | SEF141V |
| | | 4. Check harness continuity between ECM terminal 50 (or terminal 2) and ground. Continuity should not exist. | |
| | | 5. Also check harness for short to ground and short to power. | |
| | | OK or NG | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|----------------------------|----------|
| 3 | CHECK FUEL PRESSURE | |
| <p>1. Release fuel pressure to zero. Refer to EC-40.</p> <p>2. Install fuel pressure gauge and check fuel pressure.</p> <p style="margin-left: 20px;">At idling:</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is connected. Approximately 235 kPa (2.4 kg/cm², 34 psi)</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is disconnected. Approximately 294 kPa (3.0 kg/cm², 43 psi)</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |


| | | |
|---|-----------------------------------|--------------------|
| 4 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuel pump and circuit (Refer to EC-561.) ● Fuel pressure regulator (Refer to EC-41.) | | |
| ▶ | | Repair or replace. |

| | | |
|---|-----------------------------------|--|
| 5 | CHECK MASS AIR FLOW SENSOR | |
| <p> With CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.</p> <p style="margin-left: 20px;">at idling: 0.9 - 5.8 g-m/sec</p> <p style="margin-left: 20px;">at 2,500 rpm: 7.5 - 13.2 g-m/sec</p> | | |
| <p> With GST</p> <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Check mass air flow sensor signal in MODE 1 with GST.</p> <p style="margin-left: 20px;">at idling: 0.9 - 5.8 g-m/sec</p> <p style="margin-left: 20px;">at 2,500 rpm: 7.5 - 13.2 g-m/sec</p> | | |
| <p> No Tools</p> <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Check voltage between ECM terminal 47 (Mass air flow sensor signal) and ground.</p> <p style="margin-left: 20px;">at idling: 0.9 - 1.8V</p> <p style="margin-left: 20px;">at 2,500 rpm: 1.9 - 2.3V</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-141. |

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

KA24DE

Diagnostic Procedure (Cont'd)

| 6 | CHECK FUNCTION OF INJECTORS | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|------------------------------------|--|--|---------------|--|---------|--|---------------|---------|----------------|-------|------------|-------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Install all parts removed. 2. Start engine. 3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>POWER BALANCE</th> <th></th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS~RPM(REF)</th> <th>XXX rpm</th> </tr> <tr> <th>MAS AIR/FL SEN</th> <th>XXX V</th> </tr> <tr> <th>IACV-AAC/V</th> <th>XXX %</th> </tr> <tr> <td> </td> <td> </td> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | ACTIVE TEST | | POWER BALANCE | | MONITOR | | CMPS~RPM(REF) | XXX rpm | MAS AIR/FL SEN | XXX V | IACV-AAC/V | XXX % | | | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POWER BALANCE | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAS AIR/FL SEN | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | |
| IACV-AAC/V | XXX % | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PEF564N | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>4. Make sure that each circuit produces a momentary engine speed drop.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Install all parts removed. 2. Start engine. 3. Listen to each injector operating sound. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Clicking noise should be heard.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>OK or NG</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Perform trouble diagnosis for "INJECTORS", EC-553. | | | | | | | | | | | | | | | | | | | | | | | | | |

| | |
|---|------------------------|
| 7 | REMOVE INJECTOR |
| <ol style="list-style-type: none"> 1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle. 2. Turn ignition switch OFF. 3. Remove injector assembly. Refer to EC-41. Keep fuel hose and all injectors connected to injector gallery. | |
| <p style="text-align: right;">▶</p> | |
| <p>GO TO 8.</p> | |

| | | |
|---|-----------------------|--|
| 8 | CHECK INJECTOR | |
| <ol style="list-style-type: none"> 1. Disconnect all injector harness connectors. 2. Disconnect all ignition coil harness connectors. 3. Prepare pans or saucers under each injectors. 4. Crank engine for about 3 seconds. Make sure fuel does not drip from injector. | | |
| <p>OK or NG</p> | | |
| OK (Does not drip) | ▶ | GO TO 9. |
| NG (Drips) | ▶ | Replace the injectors from which fuel is dripping. Always replace O-ring with new one. |


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

KA24DE

Diagnostic Procedure (Cont'd)


| | |
|--|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |



Component Description

NGEC0196

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

| Fluid temperature °C (°F) | Voltage* V | Resistance kΩ |
|------------------------------|---------------|------------------|
| 20 (68) | 3.5 | 2.3 - 2.7 |
| 50 (122) | 2.2 | 0.79 - 0.90 |

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ECM terminal 32 (ECM ground).

On Board Diagnosis Logic

NGEC0197

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|--|
| P0180 0402 | <ul style="list-style-type: none"> An excessively high or low voltage is sent to ECM. Rationally incorrect voltage is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor. | <ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Fuel tank temperature sensor |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | |
|----------|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | INT/A TEMP/S | XXX °C |

PEF609W

DTC Confirmation Procedure

=NGEC0198

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 10 seconds.
If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-296.
If the result is OK, go to following step.

NOTE:

If "COOLAN TEMP/S" is already less than 60°C (140°F) before step 4), the result will be OK. If "COOLAN TEMP/S" is above 60°C (140°F), go to the following step.

- 4) Check "COOLAN TEMP/S" signal.
If the signal is less than 60°C (140°F), the result will be OK.
If the signal is above 60°C (140°F), go to the following step.
- 5) Cool engine down until "COOLAN TEMP/S" signal is less than 60°C (140°F).
- 6) Wait at least 10 seconds.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-296.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

Wiring Diagram

NGEC0199

EC-TFTS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS





BT

HA

SC



EL

IDX



Diagnostic Procedure

NGEC0200

| | | | |
|----------|---------------------------|---|------------------------------|
| 1 | CHECK POWER SUPPLY | <p>1. Turn ignition switch OFF. 2. Disconnect fuel level sensor unit harness connector.</p> <div style="text-align: center;">  <p>The diagram shows a circular fuel tank temperature sensor unit. It has a 'Feed' terminal on the left and 'Quick connectors' on the right. An arrow labeled 'Front' points to the right side of the unit.</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal T and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>The circuit diagram shows a battery connected to a switch labeled 'T.S.'. The switch is connected to terminal T of a connector. Terminal T is also connected to a voltmeter (V) which is grounded. A 'DISCONNECT' symbol is shown between the battery and the switch. The connector also has terminals G, S, E, and P2.</p> </div> <p style="color: blue;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> | <p>AFE095</p> <p>SEF170V</p> |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | GO TO 2. | |

| | | | |
|----------|-----------------------------------|---|--|
| 2 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors B101, M67 ● Harness connectors M81, F36 ● Harness for open or short between ECM and fuel tank temperature sensor | |
| | ▶ | Repair harness or connector. | |

| | |
|--|--|
| 3 | CHECK GROUND CIRCUIT |
| <p>1. Turn ignition switch OFF.</p> <p>2. Check harness continuity between terminal E and body ground.</p> | |
| | |
| <p>Continuity should exist.</p> | |
| <p>3. Also check harness for short to ground and short to power.</p> | |
| <p>OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

SEF171V

| | |
|---|--|
| 4 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors B101, M67 ● Harness for open or short between ECM and body ground | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX


5 CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.



AFE095

2. Check resistance by heating with hot water or heat gun as shown in the figure.



SEF172VA

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.3 - 2.7 |
| 50 (122) | 0.79 - 0.90 |

MTBL0291

OK or NG

| | | |
|----|---|---------------------------------------|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace fuel tank temperature sensor. |

6 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

▶ **INSPECTION END**

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0202


When a misfire occurs, the engine speed will fluctuate. If the engine speed fluctuates enough to cause the CKP sensor signal to vary, ECM can determine that a misfire is occurring.

| Sensor | Input Signal to ECM | ECM function |
|----------------------------------|---------------------|-------------------------------|
| Crankshaft position sensor (OBD) | Engine speed | On board diagnosis of misfire |

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**
 On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MIL will blink. When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change. When the misfire condition decreases to a level that will not damage the TWC, the MIL will turn off. If another misfire condition occurs that can damage the TWC on a second trip, the MIL will blink. When the misfire condition decreases to a level that will not damage the TWC, the MIL will remain on. If another misfire condition occurs that can damage the TWC, the MIL will begin to blink again.
- Two Trip Detection Logic (Exhaust quality deterioration)**
 For misfire conditions that will not damage the TWC (but will affect vehicle emission), the MIL will only light when the misfire is detected on a second trip. During this condition, ECM monitors the CKP sensor signal every 1000 revolutions. A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|--------------|---|---|
| P0300 (0701) | <ul style="list-style-type: none"> Multiple cylinders misfire. | <ul style="list-style-type: none"> Improper spark plug Insufficient compression |
| P0301 (0608) | <ul style="list-style-type: none"> No. 1 cylinder misfires. | <ul style="list-style-type: none"> Incorrect fuel pressure EGR valve The injector circuit is open or shorted |
| P0302 (0607) | <ul style="list-style-type: none"> No. 2 cylinder misfires. | <ul style="list-style-type: none"> Injectors Intake air leak The ignition secondary circuit is open or shorted |
| P0303 (0606) | <ul style="list-style-type: none"> No. 3 cylinder misfires. | <ul style="list-style-type: none"> Lack of fuel Drive plate/Flywheel |
| P0304 (0605) | <ul style="list-style-type: none"> No. 4 cylinder misfires. | <ul style="list-style-type: none"> Front heated oxygen sensor Incorrect distributor rotor |



DTC Confirmation Procedure

NGEC0203

CAUTION:
Always drive vehicle at a safe speed.

NOTE:
If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- Turn ignition switch ON, and select "DATA MONITOR" mode with CONSULT-II.
- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 5 seconds.
- Start engine again and drive at 1,500 - 3,000 rpm for at least 3 minutes.
Hold the accelerator pedal as steady as possible.

NOTE:
Refer to the freeze frame data for the test driving conditions.
5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-300.

With GST

Follow the procedure "With CONSULT-II".

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0204

| | |
|--|--|
| 1 | CHECK FOR INTAKE AIR LEAK |
| 1. Start engine and run it at idle speed. 2. Listen for the sound of the intake air leak. | |
| OK or NG | |
| OK | ▶ GO TO 2. |
| NG | ▶ Discover air leak location and repair. |

| | |
|--|--|
| 2 | CHECK FOR EXHAUST SYSTEM CLOGGING |
| Stop engine and visually check exhaust tube, three way catalyst and muffler for dents. | |
| OK or NG | |
| OK | ▶ GO TO 3. |
| NG | ▶ Repair or replace it. |

| | |
|---|---------------------------|
| 3 | CHECK EGR FUNCTION |
| Perform DTC Confirmation Procedure for DTC P1402 EGR FUNCTION (OPEN). Refer to EC-476. | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair EGR system. |

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

4 PERFORM POWER BALANCE TEST

With CONSULT-II

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.


| ACTIVE TEST | |
|----------------|---------|
| POWER BALANCE | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| MAS AIR/FL SEN | XXX V |
| IACV-AAC/V | XXX % |
| | |
| | |
| | |
| | |

PEF564N

2. Is there any cylinder which does not produce a momentary engine speed drop?

Without CONSULT-II

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?




SEF319V

Yes or No

- Yes ► GO TO 5.
- No ► GO TO 8.

5 CHECK INJECTOR

Does each injector make an operating sound at idle?



MEC703B


Yes or No


- Yes ► GO TO 6.
- No ► Check injector(s) and circuit(s). Refer to EC-553.

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

Diagnostic Procedure (Cont'd)


| | | |
|---|-----------------------------|----------|
| 6 | CHECK IGNITION SPARK | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ignition wire from spark plug. 3. Connect a known good spark plug to the ignition wire. 4. Place end of spark plug against a suitable ground and crank engine. 5. Check for spark. | | |
|  | | |
| SEF282G | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

| | | |
|---|-----------------------------|--|
| 7 | CHECK IGNITION WIRES | |
| <ol style="list-style-type: none"> 1. Inspect wires for cracks, damage, burned terminals and for improper fit. 2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks. | | |
|  | | |
| SEF174P | | |
| Resistance: | | |
| 13.6 - 18.4 kΩ/m (4.15 - 5.61 kΩ/ft) at 25°C (77°F) | | |
| If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one. | | |
| OK or NG | | |
| OK | ▶ | Check distributor rotor head for incorrect parts. Check ignition coil, power transistor and their circuits. Refer to EC-449. |
| NG | ▶ | Replace. |

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE


Diagnostic Procedure (Cont'd)

| | | |
|---|--------------------------|---|
| 8 | CHECK SPARK PLUGS | |
| Remove the spark plugs and check for fouling, etc. | | |
|  | | |
| SEF156I | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to "ENGINE MAINTENANCE", MA-22 . |

GI
MA
EM
LC
EC

| | | |
|---|-----------------------------------|---|
| 9 | CHECK COMPRESSION PRESSURE | |
| Refer to EM-15 . | | |
| <ul style="list-style-type: none"> ● Check compression pressure. <ul style="list-style-type: none"> Standard: 1,226 kPa (12.5 kg/cm², 178 psi)/300 rpm Minimum: 1,030 kPa (10.5 kg/cm², 149 psi)/300 rpm Difference between each cylinder: 98 kPa (1.0 kg/cm², 14 psi)/300 rpm | | |
| OK or NG | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | Check pistons, piston rings, valves, valve seats and cylinder head gaskets. |

FE
CL
MT
AT
TF
PD
AX

| | | |
|---|----------------------------|-----------|
| 10 | CHECK FUEL PRESSURE | |
| <ol style="list-style-type: none"> 1. Install any parts removed. 2. Release fuel pressure to zero. Refer to EC-40. 3. Install fuel pressure gauge and check fuel pressure. | | |
|  | | |
| AEC064B | | |
| OK or NG | | |
| At idle: Approx. 235 kPa (2.4 kg/cm², 34 psi) | | |
| OK | ▶ | GO TO 12. |
| NG | ▶ | GO TO 11. |

SU
BR
ST
RS
BT
HA
SC
EL

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|-----------------------------------|
| 11 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuel pump and circuit Refer to EC-561. ● Fuel pressure regulator Refer to EC-41. ● Fuel lines Refer to "ENGINE MAINTENANCE", <i>MA-20</i>. ● Fuel filter for clogging | |
| ▶ | Repair or replace. |

| 12 | CHECK IGNITION TIMING | | | | | | | | | | |
|--|---|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|---|---|-------------------|---------------------------------------|
| <p>1. Check the following items. Refer to "Basic Inspection", EC-95.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Items</th> <th style="text-align: center;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>20° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>800 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0328</p> <p style="text-align: center;">OK or NG</p> | | Items | Specifications | Ignition timing | 20° ± 2° BTDC | Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | Target idle speed | 800 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | |
| Ignition timing | 20° ± 2° BTDC | | | | | | | | | | |
| Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | | | | | | | | | | |
| Target idle speed | 800 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| OK (With CONSULT-II) | ▶ GO TO 13. | | | | | | | | | | |
| OK (Without CONSULT-II) | ▶ GO TO 14. | | | | | | | | | | |
| NG | ▶ Adjust ignition timing. | | | | | | | | | | |

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

Diagnostic Procedure (Cont'd)

13 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
3. Select "FR O2 SENSOR" and "FR O2 MNTR" in item selection.
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "START" on CONSULT-II screen.

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLANT TEMP/S | XXX °C |
| FR O2 SENSOR | XXX V |
| FR O2 MNTR | LAEN |
| INJ PULSE | XXX msec |

PEF084P

6. Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R


SEF947V

R = "FR O2 MNTR", "RICH"

L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.3V at least once.
- "FR O2 SENSOR" voltage never exceeds 1.0V.

| SPREADSHEET | | |
|-------------|--------------|-----------|
| REPLAY MODE | REPLAY MODE | |
| NUMERICAL | SHOW TRIGGER | |
| | CMPS-RPM | FR O2 SEN |
| | rpm | V |
| XXX | XXX | XXX |



• Maximum voltage should be over 0.6V at least one time.

• Minimum voltage should be below 0.30V at least one time.

PEF736W

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK ► GO TO 15.

NG ► Replace front heated oxygen sensor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|---|
| 14 | CHECK FRONT HEATED OXYGEN SENSOR |
| <p>⊗ Without CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and ECM ground.</p> | |
| | |
| AEC873A | |
| <p>3. Check the following with engine speed held at 2,000 rpm constant under no load.</p> <ul style="list-style-type: none"> ● Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 15. |
| NG | ▶ Replace front heated oxygen sensor. |

| | |
|---|-----------------------------------|
| 15 | CHECK MASS AIR FLOW SENSOR |
| <p>Ⓜ With CONSULT-II</p> <p>Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.</p> <p style="color: blue;">at idling: 0.9 - 5.8 g-m/sec</p> <p style="color: blue;">at 2,500 rpm: 7.5 - 13.2 g-m/sec</p> | |
| <p>Ⓜ With GST</p> <p>Check mass air flow sensor signal in MODE 1 with GST.</p> <p style="color: blue;">at idling: 0.9 - 5.8 g-m/sec</p> <p style="color: blue;">at 2,500 rpm: 7.5 - 13.2 g-m/sec</p> | |
| <p>Ⓜ No Tools</p> <p>Check voltage between ECM terminal 47 (Mass air flow sensor signal) and ground.</p> <p style="color: blue;">at idling: 0.9 - 1.8V</p> <p style="color: blue;">at 2,500 rpm: 1.9 - 2.3V</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 17. |
| NG | ▶ GO TO 16. |

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|-------------------------|-----------------------|
| 16 | CHECK CONNECTORS | |
| Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-136. | | |
| OK or NG | | |
| NG | ▶ | Repair or replace it. |

GI

MA

| | | |
|--|-----------------------------------|--------------------|
| 17 | CHECK SYMPTOM MATRIX CHART | |
| Check items on the rough idle symptom in "Symptom Matrix Chart", EC-111. | | |
| OK or NG | | |
| OK | ▶ | GO TO 18. |
| NG | ▶ | Repair or replace. |

EM

LC

EC

| | | |
|---|-------------------------------|-----------|
| 18 | ERASE THE 1ST TRIP DTC | |
| Some tests may cause a 1st trip DTC to be set. Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to EC-67. | | |
| OK or NG | | |
| | ▶ | GO TO 19. |

FE

CL

| | | |
|--|------------------------------------|-----------------------|
| 19 | CHECK INTERMITTENT INCIDENT | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| OK or NG | | |
| | ▶ | INSPECTION END |

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Component Description



Component Description

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM. **Freeze frame data will not be stored in the ECM for the knock sensor. The MIL will not light for knock sensor malfunction. The knock sensor has one trip detection logic.**


ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--------------|-------------------------------------|--------------------|
| 64 | W | Knock sensor | [Engine is running] ● Idle speed | Approximately 2.4V |

On Board Diagnosis Logic

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|--|
| P0325 0304 | ● An excessively low or high voltage from the knock sensor is sent to ECM. | <ul style="list-style-type: none"> ● Harness or connectors (The knock sensor circuit is open or shorted.) ● Knock sensor |



DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

☑ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 5 seconds at idle speed.
- 3) If DTC is detected, go to "Diagnostic Procedure", EC-310.

☑ With GST

Follow the procedure "With CONSULT-II".

DTC P0325 KNOCK SENSOR (KS)

KA24DE
Wiring Diagram

Wiring Diagram

NGEC0210

EC-KS-01 GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL


IDX




AEC992A

Diagnostic Procedure

NGEC0211

| | |
|--|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| Loosen and retighten engine ground screws. | |
|  | |
| SEF325V | |
| ▶ | GO TO 2. |

| | |
|---|-------------------------------------|
| 2 | CHECK INPUT SIGNAL CIRCUIT-1 |
| 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 64 and ground. | |
|  | |
| <p style="color: blue; margin: 0;">Resistance: Approximately 500 - 620 kΩ [at 25°C (77°F)]</p> It is necessary to use an ohmmeter which can measure more than 10 MΩ. | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ GO TO 3. |

SEF173V

| | |
|---|--|
| 3 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between knock sensor and ECM. | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P0325 KNOCK SENSOR (KS)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|---------------------------|-----------------------|
| 4 | CHECK KNOCK SENSOR | |
| <p>Use an ohmmeter which can measure more than 10 MΩ.</p> <ol style="list-style-type: none"> 1. Disconnect knock sensor harness connector. 2. Check resistance between terminal 1 and ground. | | |
| | | |
| <p style="text-align: center;">Resistance: 500 - 620 kΩ [at 25°C (77°F)]</p> <p>CAUTION: Discard any knock sensors that have been dropped or physically damaged. Use only new ones.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace knock sensor. |

SEF174V

| | | |
|--|-----------------------------|----------|
| 5 | CHECK SHIELD CIRCUIT | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove joint connector-2. 3. Check the following. Refer to the wiring diagram. <ul style="list-style-type: none"> ● Continuity between joint connector-2 terminal 1 and ground ● Joint connector-2 (Refer to "HARNESS LAYOUT", <i>EL-272</i>.) <p style="text-align: center;">Continuity should exist.</p> 4. Also check harness for short to ground and short to power. 5. Then reconnect harness connectors. | | |
| OK or NG | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |



| | |
|---|--|
| 6 | DETECT MALFUNCTIONING PART |
| Check the joint connector-2. (Refer to "HARNESS LAYOUT", <i>EL-272</i> .) | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|------------------------------------|
| 7 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) KA24DE

Component Description



Component Description

NGEC0213

The crankshaft position sensor (OBD) is located on the transaxle housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not directly used to control the engine system. It is used only for the on board diagnosis.

ECM Terminals and Reference Value

NGEC0214

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (AC Voltage) |
|----------------------|---------------|----------------------------------|--|-------------------|
| 47 | L | Crankshaft position sensor (OBD) | [Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed | |
| | | | [Engine is running] <ul style="list-style-type: none"> • Engine speed is 2,000 rpm | |

On Board Diagnosis Logic

NGEC0215

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0335 0802 | <ul style="list-style-type: none"> • The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. | <ul style="list-style-type: none"> • Harness or connectors (The crankshaft position sensor (OBD) circuit is open.) • Crankshaft position sensor (OBD) • Dead battery |

NGEC0216

| 2 | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITORING</th> <th style="width: 50%;">NO FAIL</th> </tr> <tr> <td>CMPS-RPM(REF)</td> <td>XXX rpm</td> </tr> </table> | DATA MONITOR | | MONITORING | NO FAIL | CMPS-RPM(REF) | XXX rpm |
|---------------|---|--------------|--|------------|---------|---------------|---------|
| DATA MONITOR | | | | | | | |
| MONITORING | NO FAIL | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | |

PEF357V

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 15 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-315.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) KA24DE

Wiring Diagram

Wiring Diagram

NGEC0217


EC-CKPS-01





AEC993A

Diagnostic Procedure

NGEC0218

| | | |
|----------|--------------------------------|---|
| 1 | RETIGHTEN GROUND SCREWS | <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF325V</p> |
| ▶ | | GO TO 2. |

GI
MA
EM
LC
EC

| | | |
|----------|-----------------------------------|---|
| 2 | CHECK INPUT SIGNAL CIRCUIT | <p>1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF335V</p> <p>2. Check continuity between ECM terminal 47 and terminal 2.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF175V</p> <p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> |
| OK ▶ | | GO TO 4. |
| NG ▶ | | GO TO 3. |

FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS

BT
HA
SC
EL
IDX


DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 3 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E202, E32 ● Harness connectors E41, F25 ● Harness for open or short between crankshaft position sensor (OBD) and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|-----------------------------|
| 4 | CHECK GROUND CIRCUIT |
| <p>1. Reconnect ECM harness connector.</p> <p>2. Check harness continuity between crankshaft position sensor (OBD) terminal 1 and engine ground. Refer to the wiring diagram.</p> <p style="color: blue; font-weight: bold;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 6. |
| NG | ▶ GO TO 5. |

| | |
|---|--|
| 5 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E202, E32 ● Harness connectors E41, F25 ● Harness for open or short between crankshaft position sensor (OBD) and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |



| | |
|--|-----------------------------|
| 6 | CHECK SHIELD CIRCUIT |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect harness connector E32.</p> <p>3. Check harness continuity between harness connector E32 terminal 2 and ground.</p> | |
|  | |
| <p style="color: blue; font-weight: bold;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect harness connectors.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 7. |

SEF177V

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) KA24DE

Diagnostic Procedure (Cont'd)



| | |
|--|--|
| 7 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors E41, F25 ● Joint connector-1 (Refer to "HARNESS LAYOUT", <i>EL-272</i>.) ● Harness for open or short between harness connector E32 and Engine ground | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|---|
| 8 | CHECK CRANKSHAFT POSITION SENSOR (OBD) |
| 1. Disconnect crankshaft position sensor (OBD) harness connector. 2. Loosen the fixing bolt of the sensor. 3. Remove the sensor. 4. Visually check the sensor for chipping. | |
|  | |
| 5. Check resistance as shown in the figure. | |
|  | |
| <p>Resistance: Approximately 512 - 632Ω [at 20°C (68°F)]</p> <p>OK or NG</p> | |
| OK | ▶ GO TO 9. |
| NG | ▶ Replace crankshaft position sensor (OBD). |

| | |
|--|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Component Description



Component Description

NGEC0220

The camshaft position sensor is a basic component of the engine control system. It monitors engine speed and piston position. These input signals to the engine control system are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° (POS) signal and 4 slits for a 180° (REF) signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.

The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

ECM Terminals and Reference Value

NGEC0221

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---|---|----------------------------|
| 4 | LG/R | ECCS relay (Self shut-off) | [Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> For a few seconds after turning ignition switch OFF | 0 - 1V |
| | | | [Ignition switch OFF] <ul style="list-style-type: none"> More than a few seconds after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 44 | PU | Camshaft position sensor (Reference signal) | [Engine is running] (Warm-up condition) <ul style="list-style-type: none"> Idle speed | 0.2 - 0.5V |
| 48 | PU | | [Engine is running] <ul style="list-style-type: none"> Engine speed is 2,000 rpm | 0 - 0.5V |

DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

KA24DE

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--|--|------------------------------|
| 49 | LG | Camshaft position sensor (Position signal) | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | Approximately 2.6V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | Approximately 2.5 - 2.6V |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 117 | B/P | Current return | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0222

| DTC No. | Malfunction is detected when ... | | Check Items (Possible Cause) |
|---------------|----------------------------------|--|---|
| P0340 0101 | A) | Either 1° or 180° signal is not sent to ECM for the first few seconds during engine cranking. | <ul style="list-style-type: none"> ● Harness or connectors (The camshaft position sensor circuit is open or shorted.) ● Camshaft position sensor ● Starter motor (Refer to EL section.) ● Starting system circuit (Refer to EL section.) ● Dead (Weak) battery |
| | B) | Either 1° or 180° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed. | |
| | C) | The relation between 1° and 180° signal is not in the normal range during the specified engine speed. | |

DTC Confirmation Procedure

Perform "Procedure for malfunction A" first. If DTC cannot be confirmed, perform "Procedure for malfunction B and C". =NGEC0223

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

2

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| COOLAN TEMP/S | XXX °C |

PEF002P

PROCEDURE FOR MALFUNCTION A

NGEC0223S01

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Crank engine for at least 2 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-322.

With GST

Follow the procedure "With CONSULT-II".

3

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |

PEF357V

PROCEDURE FOR MALFUNCTION B AND C

NGEC0223S02

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-322.


With GST

Follow the procedure "With CONSULT-II".



Wiring Diagram

NGEC0224

EC-CMPS-01



GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX






AEC994A

Diagnostic Procedure

NGEC0225

| | | |
|---|------------------------------|---|
| 1 | CHECK STARTING SYSTEM | |
| Does the engine turn over? (Does the starter motor operate?) | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | Check starting system. (Refer to EL section.) |

| | | |
|---|--------------------------------|----------|
| 2 | RETIGHTEN GROUND SCREWS | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws. | | |
|  <p>The diagram shows a top-down view of the engine compartment. Two engine ground screws are highlighted with circles and labeled 'Engine ground F11' and 'Engine ground F12'. An 'Air duct' is also labeled. A downward arrow on the right side is labeled 'Vehicle front'.</p> | | |
| SEF325V | | |
| ▶ | | GO TO 3. |

| | | | |
|---|---------------------------|---|---------|
| 3 | CHECK POWER SUPPLY | | |
| 1. Disconnect camshaft position sensor harness connector. | |  <p style="text-align: right;">Ignition coil and condenser harness connector</p> <p style="text-align: center;">Camshaft position sensor and power transistor harness connector</p> | SEF128S |
| 2. Turn ignition switch ON. | | | |
| 3. Check voltage between terminal 5 and ground with CONSULT-II or tester. | | | |
| | |  | SEF040S |
| | | Voltage: Battery voltage | |
| | | OK or NG | |
| OK | ▶ | GO TO 5. | |
| NG | ▶ | GO TO 4. | |

| | | | |
|--|-----------------------------------|--|--|
| 4 | DETECT MALFUNCTIONING PART | | |
| Check the following. | | | |
| <ul style="list-style-type: none"> ● Harness for open or short between camshaft position sensor and ECM relay ● Harness for open or short between camshaft position sensor and ECM | | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX














DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 5 | CHECK INPUT SIGNAL CIRCUIT |
| <ol style="list-style-type: none"> Turn ignition switch OFF. Disconnect ECM harness connector. Check harness continuity between sensor terminal 4 and ECM terminal 49, sensor terminal 3 and ECM terminals 44, 48. | |
| | |
| SEF178V | |
| <p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 6. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|--|
| 6 | CHECK GROUND CIRCUIT |
| <ol style="list-style-type: none"> Turn ignition switch OFF. Check harness continuity between distributor (camshaft position sensor) terminal 6 and engine ground. Refer to the wiring diagram. <p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 7. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| 7 | CHECK CAMSHAFT POSITION SENSOR | <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Check voltage between ECM terminal 49 and engine ground, ECM terminal 44 or 48 and ground.</p> | | | | | | | | | | |
|--|---|--|------|-----------|---------|--------------------|--------------------------|--------------|---|--|--|---|
|  | | <p>Terminal 44 or 48 and engine ground</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Condition</th> <th style="width: 40%;">Idle</th> <th style="width: 40%;">2,000 rpm</th> </tr> </thead> <tbody> <tr> <td>Voltage</td> <td style="text-align: center;">0.2 - 0.5V</td> <td style="text-align: center;">0 - 0.5V</td> </tr> <tr> <td>Pulse signal</td> <td style="text-align: center;">  </td> <td style="text-align: center;">  </td> </tr> </tbody> </table> | | Condition | Idle | 2,000 rpm | Voltage | 0.2 - 0.5V | 0 - 0.5V | Pulse signal |  |  |
| Condition | Idle | 2,000 rpm | | | | | | | | | | |
| Voltage | 0.2 - 0.5V | 0 - 0.5V | | | | | | | | | | |
| Pulse signal |  |  | | | | | | | | | | |
| <p>Terminal 49 and engine ground</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Condition</th> <th style="width: 40%;">Idle</th> <th style="width: 40%;">2,000 rpm</th> </tr> </thead> <tbody> <tr> <td>Voltage</td> <td style="text-align: center;">Approximately 2.6V</td> <td style="text-align: center;">Approximately 2.5 - 2.6V</td> </tr> <tr> <td>Pulse signal</td> <td style="text-align: center;">  </td> <td style="text-align: center;">  </td> </tr> </tbody> </table> | | Condition | Idle | 2,000 rpm | Voltage | Approximately 2.6V | Approximately 2.5 - 2.6V | Pulse signal |  |  | SEF893W | |
| Condition | Idle | 2,000 rpm | | | | | | | | | | |
| Voltage | Approximately 2.6V | Approximately 2.5 - 2.6V | | | | | | | | | | |
| Pulse signal |  |  | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | |
| NG | ▶ | Replace camshaft position sensor. | | | | | | | | | | |

| | | | |
|-----------------|-----------------------------|--|--|
| 8 | CHECK SHIELD CIRCUIT | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect joint connector-2.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between joint connector-2 terminal 1 and ground ● Joint connector-2 (Refer to "HARNESS LAYOUT", EL-272.) Continuity should exist. <p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect joint connector-1.</p> | |
| OK or NG | | | |
| OK | ▶ | GO TO 9. | |
| NG | ▶ | Repair open circuit, short to ground or short to power in harness or connectors. | |

| | | | |
|----------|------------------------------------|---|-----------------------|
| 9 | CHECK INTERMITTENT INCIDENT | <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> | |
| | | ▶ | INSPECTION END |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Description SYSTEM DESCRIPTION



NGEC0227

NGEC0227S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|----------------------------|--------------|---------------------|
| Camshaft position sensor | Engine speed | EGR control | EGRC-solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Intake air temperature sensor | Intake air temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| Vehicle speed sensor | Vehicle speed | | |

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current flows through the solenoid valve is cut. This causes the vacuum to be discharged into the atmosphere. The EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction
- Low intake air temperature



COMPONENT DESCRIPTION

NGEC0227S02

Exhaust Gas Recirculation (EGR) Valve


NGEC0227S0201

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.

DTC P0400 EGR FUNCTION (CLOSE)

KA24DE


Description (Cont'd)



EGRC-Solenoid Valve

NGEC0227S0202

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the intake manifold collector to the EGR valve.



On Board Diagnosis Logic

NGEC0228

If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0400 0302 | <ul style="list-style-type: none"> No EGR flow is detected under conditions that call for EGR. | <ul style="list-style-type: none"> EGR valve stuck closed EGRC-BPT valve Vacuum hose EGRC-solenoid valve EGR passage EGR temperature sensor Exhaust gas leaks |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | | | | | | | | | | | | |
|------------------|---|------------------|--|------------------|--|---------|--|---------------|---------|---------------|-------|--------------|----------|
| 8 | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">EGR SYSTEM P0400</td></tr> <tr><td colspan="2" style="text-align: center;">OUT OF CONDITION</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">CMPS~RPM(POS)</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">THRTL POS SEN</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">B/FUEL SCHDL</td><td style="text-align: center;">XXX msec</td></tr> </table> | EGR SYSTEM P0400 | | OUT OF CONDITION | | MONITOR | | CMPS~RPM(POS) | XXX rpm | THRTL POS SEN | XXX V | B/FUEL SCHDL | XXX msec |
| EGR SYSTEM P0400 | | | | | | | | | | | | | |
| OUT OF CONDITION | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | |
| CMPS~RPM(POS) | XXX rpm | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | |
| B/FUEL SCHDL | XXX msec | | | | | | | | | | | | |

PEF603W

| | | | | | | | | | | | | | |
|------------------|--|------------------|--|---------|--|---------|--|---------------|---------|---------------|-------|--------------|----------|
| 8 | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">EGR SYSTEM P0400</td></tr> <tr><td colspan="2" style="text-align: center;">TESTING</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">CMPS~RPM(POS)</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">THRTL POS SEN</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">B/FUEL SCHDL</td><td style="text-align: center;">XXX msec</td></tr> </table> | EGR SYSTEM P0400 | | TESTING | | MONITOR | | CMPS~RPM(POS) | XXX rpm | THRTL POS SEN | XXX V | B/FUEL SCHDL | XXX msec |
| EGR SYSTEM P0400 | | | | | | | | | | | | | |
| TESTING | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | |
| CMPS~RPM(POS) | XXX rpm | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | |
| B/FUEL SCHDL | XXX msec | | | | | | | | | | | | |

PEF604W

| | | | | | |
|------------------|--|------------------|--|-----------|--|
| 8 | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">EGR SYSTEM P0400</td></tr> <tr><td colspan="2" style="text-align: center;">COMPLETED</td></tr> </table> | EGR SYSTEM P0400 | | COMPLETED | |
| EGR SYSTEM P0400 | | | | | |
| COMPLETED | | | | | |

PEF785U

DTC Confirmation Procedure

NGEC0229

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- P0400 will not be displayed at “SELF-DIAG RESULTS” mode with CONSULT-II even though DTC work support test result is “NG”.

TESTING CONDITION:

For best results, perform the test at a temperature above 5°C (41°F).

④ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Check “COOLAN TEMP/S” in “DATA MONITOR” mode with CONSULT-II and confirm it is within the range listed below.

COOLAN TEMP/S: Less than 40°C (104°F)

If the value is out of range, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to lower the coolant temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.




- 3) Start engine and let it idle monitoring “COOLAN TEMP/S” value. When the “COOLAN TEMP/S” value reaches 70°C (158°F), immediately go to the next step.
- 4) Select “EGR SYSTEM P0400” of “EGR SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
- 5) Touch “START”.
- 6) Accelerate vehicle to a speed of 40 km/h (25 MPH) once and then stop vehicle with engine running.
If “COMPLETED” appears on CONSULT-II screen, go to step 9.
If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
- 7) Check the output voltage of “THRTL POS SEN” (at closed throttle position) and note it.
- 8) When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions until “TESTING” changes to “COMPLETED”. (It will take approximately 30 seconds or more.)

| | |
|----------------|---|
| CMPS-RPM (REF) | 2,000 - 2,600 rpm |
| Vehicle speed | 10 km/h (6 MPH) or more |
| B/FUEL SCHDL | 2.5 - 3.5 msec |
| THRTL POS SEN | $(X + 0.23) - (X + 0.74) V$ X = Voltage value measured at step 7 |
| Selector lever | Suitable position |

If “TESTING” is not displayed after 5 minutes, retry from step 2.

- 9) Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to “Diagnostic Procedure”, EC-331.

NGEC0230



Overall function check

Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm.

Overall Function Check

Use this procedure to check the overall EGR function. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the EGR valve lifting when revving engine from 2,000 rpm to 4,000 rpm quickly under no load using the following methods.
 - Disconnect EGRC-solenoid valve harness connector. (The DTC for EGRC-solenoid valve will be displayed, however, ignore it.)
- 3) Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at idle speed.

Less than 4.5V should exist.

If NG, go to next step.
- 4) Turn ignition switch OFF.
- 5) Check harness continuity between EGR temperature sensor harness connector terminal 2 and ECM terminal 43 (ECM ground).

Continuity should exist.
- 6) Check "EGR TEMPERATURE SENSOR". Refer to "CHECK EGR TEMPERATURE SENSOR" in "Diagnostic Procedure".

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0400 EGR FUNCTION (CLOSE)



KA24DE

Wiring Diagram


Wiring Diagram

NGEC0231

EC-EGRC1-01




Refer to the following.
 (M65), (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)



AEC995A

Diagnostic Procedure

NGEC0232

| | | |
|---|-----------------------------|-----------------------------------|
| 1 | CHECK EXHAUST SYSTEM | |
| <p>1. Start engine. 2. Check exhaust pipes and muffler for leaks.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF099P</p> | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 2. |
| OK (Without CONSULT-II) | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace exhaust system. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0400 EGR FUNCTION (CLOSE)


KA24DE

Diagnostic Procedure (Cont'd)

2 CHECK VACUUM SOURCE TO EGR VALVE

With CONSULT-II

1. Warm engine up to normal operating temperature.
2. Disconnect vacuum hose to EGR valve.
3. Check for vacuum existence at idle.



SEF337V

Vacuum should not exist at idle.

4. Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT-II and turn the solenoid valve ON.
5. Check for vacuum existence when revving engine from 2,000 rpm up to 4,000 rpm.

| ACTIVE TEST | |
|---------------|---------|
| EGRC SOL/V | ON |
| (EGR) | FLOW |
| MONITOR | |
| CMPS-RPM(REF) | XXX rpm |
| | |
| | |
| | |
| | |

PEF788U

Vacuum should exist when revving engine.


OK or NG


| | | |
|----|---|----------|
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 5. |

DTC P0400 EGR FUNCTION (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)


| | | | | | | | | | |
|----------|---|---|----|---|----------|----|---|----------|---|
| 3 | CHECK VACUUM SOURCE TO EGR VALVE | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Warm engine up to normal operating temperature. 2. Disconnect vacuum hose to EGR valve. 3. Check for vacuum existence at idle. <div style="text-align: center; margin: 10px 0;">  <p style="font-size: small;">Vacuum hose connected to EGR valve</p> </div> <p style="text-align: right; font-size: x-small;">SEF337V</p> <p>Vacuum should not exist at idle.</p> <ol style="list-style-type: none"> 4. Disconnect EGRC-solenoid valve harness connector. (The 1st trip DTC for EGRC-solenoid valve will be displayed, but ignore it.) 5. Check for vacuum existence when revving engine from 2,000 rpm up to 4,000 rpm. <p>Vacuum should exist when revving engine.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 5.</td> </tr> </table> | OK | ▶ | GO TO 4. | NG | ▶ | GO TO 5. | GI MA EM LC EC FE CL MT AT |
| OK | ▶ | GO TO 4. | | | | | | | |
| NG | ▶ | GO TO 5. | | | | | | | |

| | | | | | | | | | |
|----------|------------------------|---|----|---|-----------|----|---|------------------------------|---|
| 4 | CHECK EGR VALVE | <ul style="list-style-type: none"> ● Apply vacuum to EGR vacuum port with a hand vacuum pump. <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; font-size: x-small;">MEF137D</p> <p>EGR valve spring should lift.</p> <ul style="list-style-type: none"> ● Check for sticking. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 11.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair or replace EGR valve.</td> </tr> </table> | OK | ▶ | GO TO 11. | NG | ▶ | Repair or replace EGR valve. | TF PD AX SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 11. | | | | | | | |
| NG | ▶ | Repair or replace EGR valve. | | | | | | | |

DTC P0400 EGR FUNCTION (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|--------------------------|--------------------------------|
| 5 | CHECK VACUUM HOSE | |
| <p>1. Turn ignition switch OFF. 2. Check vacuum hose for clogging, cracks or improper connection.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF109L</p> <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | Repair or replace vacuum hose. |

| 6 | CHECK EGRC-SOLENOID VALVE OPERATION | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|--|-------------|--|---------------------|------------|---------|--|---------------|---------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| <p><input checked="" type="checkbox"/> With CONSULT-II</p> <p>1. Turn ignition switch ON. 2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.</p> <div style="text-align: center;"> <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>EGRC SOL/V (EGR)</th> <th>ON FLOW</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS-RPM(REF)</th> <th>XXX rpm</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> </div> <p style="text-align: right;">PEF788U</p> <p>Clicking noise should be heard.</p> <p style="text-align: center;">OK or NG</p> | | | ACTIVE TEST | | EGRC SOL/V (EGR) | ON FLOW | MONITOR | | CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOL/V (EGR) | ON FLOW | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Repair or replace EGRC-solenoid valve or repair circuit. | | | | | | | | | | | | | | | | | | | | | | | | |


| | | |
|---|--|----------|
| 7 | CHECK EGRC-SOLENOID VALVE OPERATION | |
| <p><input checked="" type="checkbox"/> Without CONSULT-II</p> <p>Check operating sound of the solenoid valve when disconnecting and reconnecting EGRC-solenoid valve harness connector. (The DTC or the 1st trip DTC for the EGRC-solenoid valve will be displayed, however, ignore it.) Clicking noise should be heard.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | GO TO 8. |


DTC P0400 EGR FUNCTION (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 8 | DETECT MALFUNCTION PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M59, F27 ● 10A fuse ● Harness for open or short between fuse block and EGRC-solenoid valve ● Harness for open or short between ECM and EGRC-solenoid valve | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 9 | CHECK EGRC-SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|---|--|------------------|--------|---------|--|----------------|---------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|-------------------------------------|---|---|----|-----|----|-----|----|-----|
| <p> With CONSULT-II Check air passage continuity. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th colspan="2" style="text-align: center;">ACTIVE TEST</th> </tr> <tr> <th style="text-align: center;">EGRC SOL/V (EGR)</th> <th style="text-align: center;">ON CUT</th> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <th style="text-align: center;">CMPS-RPM (REF)</th> <th style="text-align: center;">XXX rpm</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition EGRC SOLENOID VALVE</th> <th style="text-align: center;">Air passage continuity between A and B</th> <th style="text-align: center;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">OFF</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | ACTIVE TEST | | EGRC SOL/V (EGR) | ON CUT | MONITOR | | CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | ON | Yes | No | OFF | No | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOL/V (EGR) | ON CUT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | Yes | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | No | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF169X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| <p> Without CONSULT-II Check air passage continuity shown in the figure.</p> | | | | | | | | | | |
|---|---|---|---|---|---|-----|----|-----------|----|-----|
|  | AEC919 | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Air passage continuity between A and B</th> <th style="text-align: center;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">No supply</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | | Condition | Air passage continuity between A and B | Air passage continuity between A and C | 12V direct current supply between terminals 1 and 2 | Yes | No | No supply | No | Yes |
| Condition | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | No | | | | | | | | |
| No supply | No | Yes | | | | | | | | |
| MTBL0283 | | | | | | | | | | |
| <p>If NG or operation takes more than 1 second, replace solenoid valve.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | |


| | | |
|----|---|--|
| OK | ▶ | GO TO 10. |
| NG | ▶ | If NG or operation takes more than 1 second, replace solenoid valve. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0400 EGR FUNCTION (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|-----------------------------|
| 10 | CHECK EGRC-BPT VALVE |
| <p>1. Plug one of two ports of EGRC-BPT valve. 2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve.</p> | |
|  <p>3. If a leakage is noted, replace the valve.</p> <p style="text-align: right;">SEF083P</p> | |
| OK or NG | |
| OK | ▶ GO TO 11. |
| NG | ▶ Replace EGRC-BPT valve. |


DTC P0400 EGR FUNCTION (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)


11 CHECK EGR TEMPERATURE SENSOR

Check resistance change and resistance value.



<Reference data>

| EGR temperature °C (°F) | Voltage V | Resistance MΩ |
|-------------------------|-----------|---------------|
| 0 (32) | 4.81 | 7.9 - 9.7 |
| 50 (122) | 2.82 | 0.57 - 0.70 |
| 100 (212) | 0.8 | 0.08 - 0.10 |



SEF643Q

MTBL0294

SEF526Q

OK or NG

| | | |
|----|---|---------------------------------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Replace EGR temperature sensor. |

12 CHECK INTERMITTENT INCIDENT


Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

▶ **INSPECTION END**

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Description

NGEC0234



SYSTEM DESCRIPTION

NGEC0234S01


The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

On Board Diagnosis Logic

NGEC0235

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is large, then the vacuum to the EGR valve is interrupted through the EGRC-solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0402 0306 | <ul style="list-style-type: none"> The EGRC-BPT valve does not operate properly. | <ul style="list-style-type: none"> EGRC-BPT valve EGR valve Loose or disconnected rubber tube Blocked rubber tube Camshaft position sensor Blocked exhaust system Orifice Mass air flow sensor EGRC-solenoid valve |



DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above 5°C (41°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.





With CONSULT-II


- 1) Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Stop engine and wait at least 5 seconds.
- 4) Turn ignition switch ON and select "EGRC-BPT/V P0402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 5) Start engine and let it idle.
- 6) Touch "START".
- 7) Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
- 8) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen and the bar chart may increase. Maintain the conditions many times until "COMPLETED" appears.

| | |
|----------------|--|
| Selector lever | Suitable position |
| CMPS-RPM (REF) | 1,400 - 1,800 rpm |
| Vehicle speed | 30 - 100 km/h (19 - 62 MPH) |
| B/FUEL SCHDL | 2.0 - 2.8 msec |
| THRTL POS SEN | $(X - (X + 0.88) V)$ X = Voltage value measured at step 7 |


NOTE:

- The bar chart on CONSULT-II screen indicates the status of this test. However, the test may be finished before the bar chart becomes full scale.
 - If the bar chart indication does not continue to progress, completely release accelerator pedal once and try to meet the conditions again.
 - If "TESTING" does not appear on CONSULT-II screen, retry from step 2.
- 9) If CONSULT-II instructs to carry out "Overall Function Check", go to next step. If "NG" is displayed, refer to "Diagnostic Procedure", EC-341.
 - 10) Open engine hood.
 - 11) Raise engine speed to 2,400 to 3,200 rpm under no-load and hold it. Then touch "NEXT" on CONSULT-II screen.





- 12) Check vacuum gauge while keeping engine speed at 2,400 to 3,200 rpm.
Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).
 If NG, go to "Diagnostic Procedure", EC-341.
 If OK, touch "YES" on the CONSULT-II screen.
- 13) Check the EGR valve lifting when revving from 2,000 rpm to 4,000 rpm quickly under no load.
 EGR valve should lift up, and go down without sticking when the engine is returned to idle.
 If NG, check EGR valve.
 If OK, touch "YES" or the CONSULT-II screen.
- 14) Check the rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for cracks, blockages or twisting.
 If NG, repair or replace.
 If OK, touch "YES" on the CONSULT-II screen.



Overall Function Check

Use this procedure to check the overall function of the EGRC-BPT valve. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
- 2) Lift up vehicle.
- 3) Start engine and shift to 1st gear position.
- 4) Check vacuum gauge while keeping engine speed at 2,400 to 3,200 rpm.
Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).
 If NG, go to "Diagnostic Procedure", EC-341.
 If OK, go to next step.
- 5) Check the EGR valve lifting when revving from 2,000 rpm to 4,000 rpm quickly under no load.
 EGR valve should lift up, and go down without sticking when the engine is returned to idle.
- 6) Check rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for misconnection, cracks or blockages.
- 7) If NG, go to "Diagnostic Procedure", EC-341.


Diagnostic Procedure

=NGEC0238

| | | |
|---|-------------------|--------------------------------|
| 1 | CHECK HOSE | |
| Check vacuum hose for clogging and improper connection. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Repair or replace vacuum hose. |

| | | |
|------------------------------------|-----------------------------|-----------------------------------|
| 2 | CHECK EXHAUST SYSTEM | |
| Check exhaust system for collapse. | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace exhaust system. |

| | | |
|--|----------------------|----------------------|
| 3 | CHECK ORIFICE | |
| Check if orifice is installed in vacuum hose between EGRC-BPT valve and EGRC-solenoid valve. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Replace vacuum hose. |


| | | |
|--|-----------------------------|-------------------------|
| 4 | CHECK EGRC-BPT VALVE | |
| 1. Plug one of two ports of EGRC-BPT valve. 2. Vacuum from the other port and check leakage without applying any pressure from under EGR-BPT valve. Leakage should exist. | | |
|  | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace EGRC-BPT valve. |

SEF172P

 GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

5 CHECK CAMSHAFT POSITION SENSOR

1. Start engine and warm it up to normal operating temperature.
2. Check voltage between ECM terminals 49 and engine ground ECM terminal 44 or 48 and ground.



Terminal 44 or 48 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|------------|-----------|
| Voltage | 0.2 - 0.5V | 0 - 0.5V |
| Pulse signal | | |

Terminal 49 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|--------------------|--------------------------|
| Voltage | Approximately 2.6V | Approximately 2.5 - 2.6V |
| Pulse signal | | |


SEF893W

OK or NG

| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace camshaft position sensor. |

6 CHECK MASS AIR FLOW SENSOR

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.




SEF326V

| Conditions | Voltage V |
|--|--------------------------|
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 |
| Idle (Engine is warmed-up to normal operating temperature.) | 0.9 - 1.8 |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.9 - 2.3 |
| Idle to about 4,000 rpm* | 1.3 - 1.7 to Approx. 3.0 |

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

MTBL0326


4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.




SEF893J

OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace mass air flow sensor. |

| 7 | CHECK EGRC-SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|---|--|------------------|--------|---------|--|----------------|---------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|-------------------------------------|---|---|----|-----|----|-----|----|-----|
| <p>④ With CONSULT-II Check air passage continuity. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">ACTIVE TEST</th> </tr> <tr> <th style="text-align: center;">EGRC SOL/V (EGR)</th> <th style="text-align: center;">ON CUT</th> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <th style="text-align: center;">CMPS-RPM (REF)</th> <th style="text-align: center;">XXX rpm</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition EGRC SOLENOID VALVE</th> <th style="text-align: center;">Air passage continuity between A and B</th> <th style="text-align: center;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">OFF</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | ACTIVE TEST | | EGRC SOL/V (EGR) | ON CUT | MONITOR | | CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | ON | Yes | No | OFF | No | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOL/V (EGR) | ON CUT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | Yes | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | No | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF169X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |


| <p>⊗ Without CONSULT-II Check air passage continuity shown in the figure.</p> | | | | | | | | | | |
|---|---|---|---|---|---|-----|----|-----------|----|-----|
|  | | | | | | | | | | |
| AEC919 | | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Air passage continuity between A and B</th> <th style="text-align: center;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">No supply</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | | Condition | Air passage continuity between A and B | Air passage continuity between A and C | 12V direct current supply between terminals 1 and 2 | Yes | No | No supply | No | Yes |
| Condition | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | No | | | | | | | | |
| No supply | No | Yes | | | | | | | | |
| MTBL0283 | | | | | | | | | | |
| <p>If NG or operation takes more than 1 second, replace solenoid valve.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | |

| | | |
|----|---|------------------------------|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace EGRC-solenoid valve. |

DTC P0402 EGRC-BPT VALVE FUNCTION


KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|------------------------|--------------------|
| 8 | CHECK EGR VALVE | |
| <ul style="list-style-type: none"> Apply vacuum to EGR vacuum port with a hand vacuum pump. | | |
|  | | |
| <p>EGR valve spring should lift.</p> <ul style="list-style-type: none"> Check for sticking. | | |
| MEF137D | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace EGR valve. |

| | | |
|--|------------------------------------|-----------------------|
| 9 | CHECK INTERMITTENT INCIDENT | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| | ▶ | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



On Board Diagnosis Logic

NGEC0240

The ECM monitors the switching frequency ratio of front and rear heated oxygen sensors.

A three way catalyst* with high oxygen storage capacity will indicate a low switching frequency of rear heated oxygen sensor. As oxygen storage capacity decreases, the rear heated oxygen sensor switching frequency will increase.

When the frequency ratio of front and rear heated oxygen sensors approaches a specified limit value, the three way catalyst* malfunction is diagnosed.

*: Warm-up three way catalyst (For California)

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0420 0702 | <ul style="list-style-type: none"> • Three way catalyst does not operate properly. • Three way catalyst does not have enough oxygen storage capacity. | <ul style="list-style-type: none"> • Three way catalyst* • Exhaust tube • Intake air leaks • Injectors • Injector leaks • Spark plug • Improper ignition timing |

*: Warm-up three way catalyst (For California)

3

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS~RPM (REF) | XXX rpm |
| FR O2 SEN | XXX V |
| RR O2 SEN | XXX V |
| FR O2 MNTR | RICH |
| RR O2 MNTR | LEAN |
| VHCL SPEED SE | XXX km/h |

PEF321U

7

| SRT STATUS | |
|---------------|-------|
| CATALYST | CMPLT |
| EVAP SYSTEM | INCMP |
| O2 SENSOR | CMPLT |
| O2 SEN HEATER | CMPLT |
| EGR SYSTEM | INCMP |

PEF215U

DTC Confirmation Procedure

NGEC0241

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set "MANU TRIG" and "HI SPEED", then select "FR O2 SENSOR", "RR O2 SENSOR", "FR O2 MNTR", "RR O2 MNTR" in "DATA MONITOR" mode with CONSULT-II.
- 4) Touch "RECORD" on CONSULT-II screen with engine speed held at 2,000 rpm constantly under no load.
- 5) Make sure that the switching frequency between "RICH" and "LEAN" of "RR O2 MNTR" is much less than that of "FR O2 MNTR" as shown below.

Switching frequency ratio = A/B

A: Rear heated oxygen sensor switching frequency

B: Front heated oxygen sensor switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, the warm-up three way catalyst (models for California) is not operating properly.

If the "FR O2 MNTR" does not indicate "RICH" and "LEAN" periodically more than 5 times within 10 seconds at step 4, perform trouble diagnoses for DTC P0133 first. (See EC-212.)

If the result is NG, go to "Diagnostic Procedure", EC-348.


If the result is OK, go to following step.

- 6) Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT-II.
- 7) Drive vehicle (with transmission in 5th position) at a speed of approximately 84 to 96 km/h (52 to 60 MPH) with the following for at least 10 consecutive minutes.

(Drive the vehicle in an area where vehicle speed and accelerator pressure can be held steady and constant.)

If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-348.

- 8) Select "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.
- 9) Verify that "CATALYST" is "CMPLT".
If not "CMPLT", repeat the test from step 6.



Overall Function Check

NGEC0242

Use this procedure to check the overall function of the three way catalyst. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeters probes between ECM terminals 50 (Front heated oxygen sensor signal), 56 (Rear heated oxygen sensor signal) and engine ground.
- 4) Keep engine speed at 2,000 rpm constant under no load.
- 5) Make sure that the voltage switching frequency (high & low) between ECM terminal 56 and engine ground is much less than that of ECM terminal 50 and engine ground.

Switching frequency ratio = A/B

A: Rear heated oxygen sensor voltage switching frequency

B: Front heated oxygen sensor voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst does not operate properly.


NOTE:

If the voltage at terminal 50 does not switch periodically more than 5 times within 10 seconds at step 4, perform trouble diagnosis for DTC P0133 first. (See EC-190.)

Diagnostic Procedure

=NGEC0243

| | | |
|--|-----------------------------|--------------------|
| 1 | CHECK EXHAUST SYSTEM | |
| Visually check exhaust tubes and muffler for dent. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Repair or replace. |

| | | |
|---|-------------------------------|--------------------|
| 2 | CHECK EXHAUST AIR LEAK | |
| 1. Start engine and run it at idle. 2. Listen for an exhaust air leak before the warm-up three way catalyst (California model), the three way catalyst (Non-California model). | | |
|  | | |
| OK or NG | | |
| SEF099P | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace. |


| | | |
|---|------------------------------|--------------------|
| 3 | CHECK INTAKE AIR LEAK | |
| Listen for an intake air leak after the mass air flow sensor. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair or replace. |

| 4 | CHECK IGNITION TIMING | | | | | | | | | | | |
|--|--|-------------------------|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|
| 1. Check the following items. Refer to "Basic Inspection", EC-95. | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Items</th> <th style="text-align: center;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>20° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>800 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> | | | Items | Specifications | Ignition timing | 20° ± 2° BTDC | Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | Target idle speed | 800 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | | |
| Ignition timing | 20° ± 2° BTDC | | | | | | | | | | | |
| Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | | | | | | | | | | | |
| Target idle speed | 800 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | |
| MTBL0328 | | | | | | | | | | | | |
| OK | ▶ | GO TO 5. | | | | | | | | | | |
| NG | ▶ | Adjust ignition timing. | | | | | | | | | | |

| | | |
|----------|------------------------|---|
| 5 | CHECK INJECTORS | <ol style="list-style-type: none"> 1. Refer to Wiring Diagram for Injectors, EC-553. 2. Stop engine and then turn ignition switch ON. 3. Check voltage between ECM terminals 102, 104, 109 and 111 and ground with CONSULT-II or tester. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right;">SEF189V</p> <p style="text-align: center;">Battery voltage should exist.</p> <p style="text-align: center;">OK or NG</p> |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Perform "Diagnostic Procedure" INJECTOR, EC-554. |

| | | |
|----------|-----------------------------|---|
| 6 | CHECK IGNITION SPARK | <ol style="list-style-type: none"> 1. Disconnect ignition wire from spark plug. 2. Connect a known good spark plug to the ignition wire. 3. Place end of spark plug against a suitable ground and crank engine. 4. Check for spark. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right;">SEF282G</p> <p style="text-align: center;">OK or NG</p> |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | | |
|--|-----------------------------|---|--|
| 7 | CHECK IGNITION WIRES | | |
| <ol style="list-style-type: none"> 1. Inspect wires for cracks, damage, burned terminals and for improper fit. 2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks. | | | |
|  | | | |
| SEF174P | | | |
| <p>Resistance: 13.6 - 18.4 kΩ/m (4.15 - 5.61 kΩ/ft) at 25°C (77°F)</p> <p>If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.</p> <p style="text-align: center;">OK or NG</p> | | | |
| OK | | ▶ | Check ignition coil, power transistor and their circuits. Refer to EC-449. |
| NG | | ▶ | Replace. |

| | | | |
|--|-----------------------|---|--|
| 8 | CHECK INJECTOR | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove injector assembly. Refer to EC-41. Keep fuel hose and all injectors connected to injector gallery. 3. Disconnect camshaft position sensor harness connector. 4. Turn ignition switch ON. Make sure fuel does not drip from injector. | | | |
| OK or NG | | | |
| OK (Does not drip.) | | ▶ | GO TO 9. |
| NG (Drips.) | | ▶ | Replace the injector(s) from which fuel is dripping. |

| | | | |
|--|------------------------------------|---|--|
| 9 | CHECK INTERMITTENT INCIDENT | | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | | |
| Trouble is fixed. | | ▶ | INSPECTION END |
| Trouble is not fixed. | | ▶ | Replace warm-up three way catalyst*. *: Three way catalyst (For Non-California) |

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0244


NOTE:

If DTC P0440 OR P1440 is displayed with DTC P1448, perform trouble diagnosis for DTC P1448 first. (See EC-515.)

This diagnosis detects leaks in the EVAP purge line using engine intake manifold vacuum.

If pressure does not increase, the ECM will check for leaks in the line between the fuel tank and EVAP canister purge volume control solenoid valve under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control solenoid valve is opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge volume control solenoid valve will be closed.



| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0440 0705 | <ul style="list-style-type: none"> ● EVAP control system has a leak. ● EVAP control system does not operate properly. | <ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Absolute pressure sensor ● Fuel tank temperature sensor ● MAP/BARO switch solenoid valve and the circuit ● Blocked or bent rubber tube to MAP/BARO switch solenoid valve ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water. ● EVAP control system pressure sensor ● Fuel level sensor |

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

On Board Diagnosis Logic (Cont'd)

| | |
|--|---------|
| <p>EVAP SML LEAK P0440/P1440</p> <p>1)FOR BEST RSLT,PERFORM AT FOLLOWING CONDITIONS. -FUEL LEVEL: 1/4-3/4 -AMBIENT TEMP: 0-30 C(32-86F) -OPEN ENGINE HOOD. 2)START ENG WITH VHCL STOPPED. IF ENG IS ON,STOP FOR 5 SEC.THEN RESTART. 3)TOUCH START.</p> | SEF565X |
|--|---------|

| | |
|--|---------|
| <p>EVAP SML LEAK P0440/P1440</p> <p>WAIT 2 TO 10 MINUTES. KEEP ENGINE RUNNING AT IDLE SPEED.</p> | SEF566X |
|--|---------|

| | |
|--|---------|
| <p>EVAP SML LEAK P0440/P1440</p> <p>OK</p> <p>SELF-DIAG RESULTS</p> <p>NO DTC DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> | SEF567X |
|--|---------|

DTC Confirmation Procedure

NGEC0245

NOTE:

- If DTC P0440 or P1440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. Refer to EC-515.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

TESTING CONDITION:

- Perform “DTC WORK SUPPORT” when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
 - Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
- 1) Turn ignition switch ON.
 - 2) Turn ignition switch OFF and wait at least 5 seconds.
 - 3) Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
 - 4) Check that the following conditions are met.

| | |
|---------------|-----------------------|
| COOLAN TEMP/S | 0 - 70°C (32 - 158°F) |
| INT/A TEMP SE | 0 - 60°C (32 - 140°F) |

- 5) Select “EVAP SML LEAK P0440” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II. Follow the instruction displayed.

NOTE:

- If the engine cannot be maintained within the range on CONSULT-II screen, go to “Basic Inspection”, EC-95.
- 6) Make sure that “OK” is displayed.
If “NG” is displayed, refer to “Diagnostic Procedure”, EC-354.

NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

Ⓜ With GST

- 1) Start engine.
- 2) Drive vehicle according to “Driving pattern”, EC-63.

NOTE:

Be sure to read the explanation of “Driving pattern” on EC-63 before driving vehicle.

- 3) Stop vehicle.
- 4) Select “MODE 1” with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
- 5) Turn ignition switch OFF and wait at least 5 seconds.
- 6) Start engine.
It is not necessary to cool engine down before driving.
- 7) Drive vehicle again according to the “Driving pattern”, EC-63.
- 8) Stop vehicle.
- 9) Select “MODE 3” with GST.
 - If P1447 is displayed on the screen, go to “Diagnostic Procedure”, EC-507.
 - If P0440 is displayed on the screen, go to “Diagnostic Procedure”, EC-354.

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

DTC Confirmation Procedure (Cont'd)

- If P1440 is displayed on the screen, go to “Diagnostic Procedure”, EC-486.
 - If P0440, P1440 and P1447 are not displayed on the screen, go to the following step.
- 10) Select “MODE 1” with GST.
- If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 5.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

=NGEC0246

| | |
|---|--|
| 1 | CHECK FUEL FILLER CAP DESIGN |
| 1. Turn ignition switch OFF. 2. Check for genuine NISSAN fuel filler cap design. | |
|  | |
| SEF915U | |
| OK or NG | |
| OK | ▶ GO TO 2. |
| NG | ▶ Replace with genuine NISSAN fuel filler cap. |

| | |
|--|--|
| 2 | CHECK FUEL FILLER CAP INSTALLATION |
| Check that the cap is tightened properly rotating the cap clockwise. | |
| OK or NG | |
| OK | ▶ GO TO 3. |
| NG | ▶ <ul style="list-style-type: none">● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.● Retighten until ratcheting sound is heard. |

| | |
|--|---------------------------------------|
| 3 | CHECK FUEL FILLER CAP FUNCTION |
| Check for air releasing sound while opening the fuel filler cap. | |
| OK or NG | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |


DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE


Diagnostic Procedure (Cont'd)

4 CHECK FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.
2. Check valve opening pressure and vacuum.



SEF427N



SEF943S

Pressure:
16.0 - 20.0 kPa (0.163 - 0.204 kg/cm², 2.32 - 2.90 psi)

Vacuum:
-6.0 to -3.5 kPa (-0.061 to -0.036 kg/cm², -0.87 to -0.51 psi)

CAUTION:

Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace fuel filler cap with a genuine one. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE


Diagnostic Procedure (Cont'd)

5 INSTALL PRESSURE PUMP

1. Install the EVAP service port adapter and the pressure pump securely to EVAP service port.



SEF339V



SEF462UE

NOTE:

- Improper installation of service port may cause leaking.

| | |
|-----------------------------|----------|
| Models with CONSULT-II ▶ | GO TO 6. |
| Models without CONSULT-II ▶ | GO TO 7. |

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|----------|----------------------------|
| 6 | CHECK FOR EVAP LEAK |
|----------|----------------------------|

Ⓟ With CONSULT-II

1. Turn ignition switch ON.
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.




PEF658U

3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of bar graph.


NOTE:

- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.



PEF917U

4. Using EVAP leak detector, locate the leak portion. For the leak detector, refer to instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36.



SEF200U

OK or NG

| | | |
|----|---|--------------------|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Repair or replace. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)


KA24DE

Diagnostic Procedure (Cont'd)

7 CHECK FOR EVAP LEAK

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)




SEF503V

3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12 volts until the end of test.) Shown in the above figure.
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg).

NOTE:

- Never use compressed air or a high pressure pump.
 - Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.
5. Using EVAP leak detector, locate the leak. For the leak detector, refer to instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36.



SEF200U


OK or NG

| | | |
|----|---|--------------------|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Repair or replace. |


DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|----------|------------------------------|--|--|
| 8 | CHECK WATER SEPARATOR | <p>1. Check visually for insect nests in the water separator air inlet.</p> <p>2. Check visually for cracks or flaws in the appearance.</p> <p>3. Check visually for cracks or flaws in the hose.</p> <p>4. Check that A and C are not clogged by blowing air into B with A, and then C plugged.</p> <div style="text-align: center;">  <p>* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> </div> <p style="text-align: right;">SEF829T</p> <p>5. In case of NG in items 2 - 4, replace the parts. ● Do not disassemble water separator.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 9. | |
| NG | ▶ | Replace water separator. | |

| | | | |
|----------|---|--|--|
| 9 | CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT | <p>Refer to "DTC Confirmation Procedure", EC-376.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 10. | |
| NG | ▶ | Repair or replace EVAP canister vent control valve and O-ring or harness/connectors. | |

| | | | |
|-------------------------|---|--|--|
| 10 | CHECK IF EVAP CANISTER IS SATURATED WITH WATER | <p>1. Remove EVAP canister with EVAP canister vent control valve attached.</p> <p>2. Check if water will drain from the EVAP canister.</p> <div style="text-align: center;">  <p style="text-align: right;">SEF596U</p> </div> <p style="text-align: center;">Yes or No</p> | |
| Yes | ▶ | GO TO 11. | |
| No (With CONSULT-II) | ▶ | GO TO 13. | |
| No (Without CONSULT-II) | ▶ | GO TO 14. | |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|----------------------------|-----------|
| 11 | CHECK EVAP CANISTER | |
| Weigh the EVAP canister with EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0 lb). | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 13. |
| OK (Without CONSULT-II) | ▶ | GO TO 14. |
| NG | ▶ | GO TO 12. |

| | | |
|--|-----------------------------------|---------------------------------------|
| 12 | DETECT MALFUNCTIONING PART | |
| Check the following. | | |
| 1. Visually check the EVAP canister for damage. | | |
| 2. Check hose connection between EVAP canister and water separator for clogging and poor connection. | | |
| | ▶ | Repair hose or replace EVAP canister. |

| 13 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | |
|--|--|-----------|-------------|--|-----------------|-------|---------|--|---------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|
| <input checked="" type="checkbox"/> With CONSULT-II | | | | | | | | | | | | | | | | | | | | | | |
| 1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port. | | | | | | | | | | | | | | | | | | | | | | |
| 2. Start engine. | | | | | | | | | | | | | | | | | | | | | | |
| 3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode. | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>PURG VOL CONT/V</td> <td>XXX %</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS~RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | PURG VOL CONT/V | XXX % | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | XXX % | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| PEF190V | | | | | | | | | | | | | | | | | | | | | | |
| 4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%. | | | | | | | | | | | | | | | | | | | | | | |
| 5. Check vacuum hose for vacuum. Vacuum should exist. | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 17. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 15. | | | | | | | | | | | | | | | | | | | | |

| | | |
|--|--|-----------|
| 14 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | |
| <input checked="" type="checkbox"/> Without CONSULT-II | | |
| 1. Start engine and warm it up to normal operating temperature. | | |
| 2. Stop engine. | | |
| 3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port. | | |
| 4. Start engine and let it idle for at least 60 seconds. | | |
| 5. Check vacuum hose for vacuum. Vacuum should exist. | | |
| OK or NG | | |
| OK | ▶ | GO TO 17. |
| NG | ▶ | GO TO 15. |

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|--------------------------|-------------------------------|
| 15 | CHECK VACUUM HOSE | |
| Check vacuum hoses for clogging or disconnection. Refer to "Vacuum Hose Drawing", EC-27. | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 16. |
| OK (Without CONSULT-II) | ▶ | GO TO 17. |
| NG | ▶ | Repair or reconnect the hose. |

| 16 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | |
|--|--|--|------------------------------------|---|-----------------|-------|---------|----|---------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|
| <p>Ⓜ With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening. If OK, inspection end. If NG, go to following step.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>PURG VOL CONT/V</td><td>XXX %</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS~RPM(REF)</td><td>XXX rpm</td></tr> <tr><td>FR O2 MNTR</td><td>RICH</td></tr> <tr><td>A/F ALPHA</td><td>XXX %</td></tr> <tr><td>THRTL POS SEN</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | | ACTIVE TEST | | PURG VOL CONT/V | XXX % | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | XXX % | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| <p>3. Check air passage continuity.</p> | | | | | | | | | | | | | | | | | | | | | | |
| PEF190V | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition PURG VOL CONT/V value</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">100.0%</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">0.0%</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | | Condition PURG VOL CONT/V value | Air passage continuity between A and B | 100.0% | Yes | 0.0% | No | | | | | | | | | | | | | | |
| Condition PURG VOL CONT/V value | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | |
| 100.0% | Yes | | | | | | | | | | | | | | | | | | | | | |
| 0.0% | No | | | | | | | | | | | | | | | | | | | | | |
| MTBL0302 | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 18. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. | | | | | | | | | | | | | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE


Diagnostic Procedure (Cont'd)

17 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 **Without CONSULT-II**
Check air passage continuity.



SEF660U



SEF661U

| Condition | Air passage continuity between A and B |
|---|---|
| 12V direct current supply between terminals | Yes |
| No supply | No |

MTBL0303

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 18. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |


DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)


18 CHECK ABSOLUTE PRESSURE SENSOR

1. Remove absolute pressure sensor with its harness connector connected.



SEF328V

2. Remove hose from absolute pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM terminal 45 (Absolute pressure sensor signal) and engine ground.



SEF132V

The voltage should be 3.2 to 4.8V.

4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG


| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 19. |
| NG | ▶ | Replace absolute pressure sensor. |


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 19 | CHECK MAP/BARO SWITCH SOLENOID VALVE AND CIRCUIT |
| Refer to "DTC Confirmation Procedure", EC-432. | |
|  | |
| SEF338V | |
| OK or NG | |
| OK | ▶ GO TO 20. |
| NG | ▶ Repair or replace MAP/BARO switch solenoid valve or harness/connector. |

| 20 | CHECK FUEL TANK TEMPERATURE SENSOR | | | | | | |
|--|---|---------------------|---------------|---------|-----------|----------|-------------|
| Check resistance by heating with hot water or heat gun as shown in the figure. | | | | | | | |
|  | | | | | | | |
| AFE095 | | | | | | | |
| SEF172VA | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Temperature °C (°F)</th> <th style="padding: 5px;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 5px;">20 (68)</td> <td style="text-align: center; padding: 5px;">2.3 - 2.7</td> </tr> <tr> <td style="text-align: center; padding: 5px;">50 (122)</td> <td style="text-align: center; padding: 5px;">0.79 - 0.90</td> </tr> </tbody> </table> | | Temperature °C (°F) | Resistance kΩ | 20 (68) | 2.3 - 2.7 | 50 (122) | 0.79 - 0.90 |
| Temperature °C (°F) | Resistance kΩ | | | | | | |
| 20 (68) | 2.3 - 2.7 | | | | | | |
| 50 (122) | 0.79 - 0.90 | | | | | | |
| MTBL0291 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ GO TO 21. | | | | | | |
| NG | ▶ Replace fuel tank temperature sensor. | | | | | | |


DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)


21 CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



SEF341V

2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
4. Check output voltage between ECM terminal 62 and engine ground.




SEF198V

| Pressure (Relative to atmospheric pressure) | Voltage (V) |
|---|-------------|
| 0 kPa (0 mmHg, 0 inHg) | 3.0 - 3.6 |
| -9.3 kPa (-70 mmHg, -2.76 inHg) | 0.4 - 0.6 |

MTBL0295

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.



SEF799W

- Never apply force to the air hole protector of the sensor, if equipped.
- Discard any EVAP control system pressure sensor which has been dropped from height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 22. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|---------------------------------|
| 22 | CHECK EVAP PURGE LINE |
| Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36. | |
| OK or NG | |
| OK | ▶ GO TO 23. |
| NG | ▶ Repair or reconnect the hose. |

| | |
|--|------------------------------|
| 23 | CLEAN EVAP PURGE LINE |
| Clean EVAP purge line (pipe and rubber tube) using air blower. | |
| | ▶ GO TO 24. |

| | |
|---|--------------------------------|
| 24 | CHECK FUEL LEVEL SENSOR |
| 1. Remove fuel level sensor assembly. Refer to <i>FE-4</i> . 2. Refer to "FUEL LEVEL SENSOR CHECK", <i>EL-86</i> | |
| OK or NG | |
| OK | ▶ GO TO 25. |
| NG | ▶ Replace fuel level sensor. |

| | |
|--|------------------------------------|
| 25 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| | ▶ INSPECTION END |

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

KA24DE

Description


Description SYSTEM DESCRIPTION

NGEC0248

NGEC0248S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|--|----------------------------------|---|
| Camshaft position sensor | Engine speed | EVAP canister purge flow control | EVAP canister purge volume control solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| Throttle position switch | Closed throttle position | | |
| Front heated oxygen sensors | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | | |
| Fuel tank temperature sensor | Fuel temperature in fuel tank | | |
| Vehicle speed sensor | Vehicle speed | | |

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



COMPONENT DESCRIPTION

NGEC0248S02

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0249

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|---------------|
| PURG VOL C/V | ● Engine: After warming up ● Air conditioner switch "OFF" ● Shift lever: "N" ● No-load Idle (Vehicle stopped) | 0% |
| | 2,000 rpm | — |

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)



KA24DE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NGEC0250

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---|--|---|
| 4 | LG/R | ECCS relay (Self-shutoff) | [Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF | 0 - 1V |
| | | | [Ignition switch OFF] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 5 | R/Y | EVAP canister purge volume control solenoid valve | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V)  |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm (More than 200 seconds after starting engine) | BATTERY VOLTAGE (11 - 14V)  |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 117 | B/P | Current return | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0251

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|--|
| P0443 1008 | An improper voltage signal is sent to ECM through the valve. | <ul style="list-style-type: none"> ● Harness or connectors (The valve circuit is open or shorted.) ● EVAP canister purge volume control solenoid valve |

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

KA24DE

DTC Confirmation Procedure

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |

PEF357V

DTC Confirmation Procedure

=NGEC0252

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and let it idle for at least 30 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-371

Ⓜ With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)






KA24DE

Wiring Diagram

Wiring Diagram

NGEC0253

EC-PGC/V-01



AEC996A



DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0254

| | | | |
|----------|---------------------------|---|---|
| 1 | CHECK POWER SUPPLY | | |
| | | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect EVAP canister purge volume control solenoid valve harness connector.</p> <div style="text-align: center;">  <p>EVAP canister purge volume control solenoid valve harness connector</p> <p>Vehicle front</p> <p>EVAP service port</p> </div> <p>3. Turn ignition switch ON.</p> <p>4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <p style="color: blue;">Voltage: Battery voltage</p> <div style="text-align: center;">  <p>DISCONNECT T.S.</p> <p>ON</p> <p>V</p> </div> <p style="text-align: center;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> |
| | OK | ▶ | GO TO 3. |
| | NG | ▶ | GO TO 2. |

SEF339V

SEF192V


| | | | |
|----------|-----------------------------------|--|---|
| 2 | DETECT MALFUNCTIONING PART | | |
| | | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM | <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> |
| | | ▶ | Repair harness or connectors. |

IDX

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|------------------------------------|
| 3 | CHECK OUTPUT SIGNAL CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 5 and terminal 1. Continuity should exist.</p> | |
|  | |
| SEF193V | |
| <p>If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK (With CONSULT-II) | ▶ GO TO 5. |
| OK (Without CONSULT-II) | ▶ GO TO 6. |
| NG | ▶ GO TO 4. |

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between EVAP canister purge volume control solenoid valve and ECM. | |
| | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)



| 5 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|--|--|-----------------|-------|---------|--|---------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|------------------------------------|---|--------|-----|------|----|----|---|----------|----|---|--|
| <p>Ⓟ With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening. If OK, inspection end. If NG, go to following step.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>PURG VOL CONT/V</td><td>XXX %</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS~RPM(REF)</td><td>XXX rpm</td></tr> <tr><td>FR O2 MNTR</td><td>RICH</td></tr> <tr><td>A/F ALPHA</td><td>XXX %</td></tr> <tr><td>THRTL POS SEN</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> <p>3. Check air passage continuity.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse; text-align: center;"> <tr><th>Condition PURG VOL CONT/V value</th><th>Air passage continuity between A and B</th></tr> <tr><td>100.0%</td><td>Yes</td></tr> <tr><td>0.0%</td><td>No</td></tr> </table> <p style="text-align: right; margin-right: 20px;">PEF190V</p> <p style="text-align: right; margin-right: 20px;">MTBL0302</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 7.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>Replace EVAP canister purge volume control solenoid valve.</td> </tr> </table> | | ACTIVE TEST | | PURG VOL CONT/V | XXX % | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | | Condition PURG VOL CONT/V value | Air passage continuity between A and B | 100.0% | Yes | 0.0% | No | OK | ▶ | GO TO 7. | NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | XXX % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition PURG VOL CONT/V value | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 100.0% | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0.0% | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)


| 6 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | |
|---|--|--|--|---|-----|-----------|----|
| <p> Without CONSULT-II Check air passage continuity.</p> | | | | | | | |
|  | | | | | | | |
| SEF660U | | | | | | | |
|  | | | | | | | |
| SEF661U | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>No supply</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | Condition | Air passage continuity between A and B | 12V direct current supply between terminals | Yes | No supply | No |
| Condition | Air passage continuity between A and B | | | | | | |
| 12V direct current supply between terminals | Yes | | | | | | |
| No supply | No | | | | | | |
| MTBL0303 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. | | | | | |

| | |
|---|------------------------------------|
| 7 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ INSPECTION END | |


DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

KA24DE

Component Description



SEF378Q



SEF143S

Component Description

NGEC0256

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CONSULT-II Reference Value in Data Monitor Mode

NGEC0257

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|---------------|
| VENT CONT/V | ● Ignition switch: ON | OFF |

ECM Terminals and Reference Value

NGEC0258

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------------|----------------------|----------------------------|
| 108 | R/G | EVAP canister vent control valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0259

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0446 0903 | ● An improper voltage signal is sent to ECM through EVAP canister vent control valve. | ● Harness or connectors (EVAP canister vent control valve circuit is open or shorted.) ● EVAP canister vent control valve |

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

KA24DE

DTC Confirmation Procedure

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

DTC Confirmation Procedure

NGEC0260

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-378.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)


KA24DE

Wiring Diagram

Wiring Diagram



NGEC0261

EC-VENT/V-01




GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST

RS
BT
HA
SC
EL
IDX



Refer to the following.
M65, E43 - SUPER
MULTIPLE JUNCTION (SMJ)



AEC997A

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0262

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |



| 2 | CHECK CIRCUIT | | | | | | | | | | | | | | | | | | | | | |
|---|----------------------|----------|-------------|--|----------------|-----|---------|--|---------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|
| <p>1. Turn ignition switch ON.</p> <p>2. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <td>VENT CONTROL/V</td> <td>OFF</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS~RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table> | | | ACTIVE TEST | | VENT CONTROL/V | OFF | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | OFF | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| <p>3. Make sure that ratcheting sound is heard from the vent control valve.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 3. | | | | | | | | | | | | | | | | | | | | |

PEF361U

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | | | | | | | |
|----------|---------------------------|---|---|---|----------|----|---|----------|-----------|
| 3 | CHECK POWER SUPPLY | <p>1. Turn ignition switch OFF. 2. Disconnect EVAP canister vent control valve harness connector.</p> <div style="text-align: center;">  <p>EVAP canister vent control valve</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue; font-weight: bold;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; font-weight: bold;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> | | | | | | |
| | | <p>SEF143S</p> <p>SEF240W</p> | | | | | | | |
| | | <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; border-right: 1px solid black;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td style="border-right: 1px solid black;">NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table> | OK | ▶ | GO TO 5. | NG | ▶ | GO TO 4. | <p>PD</p> |
| OK | ▶ | GO TO 5. | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | |

| | | | | | | |
|----------|-----------------------------------|---|--|---|-------------------------------|--|
| 4 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M67, B101 ● Harness connectors B113, C3 ● 10A fuse ● Harness for open or short between EVAP canister vent control valve and 10A fuse <table style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 20%; border-right: 1px solid black;"></td> <td style="width: 5%; text-align: center;">▶</td> <td>Repair harness or connectors.</td> </tr> </table> | | ▶ | Repair harness or connectors. | <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| | ▶ | Repair harness or connectors. | | | | |

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 5 | CHECK OUTPUT SIGNAL CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 108 and terminal 2.</p> | |
| | |
| SEF241W | |
| <p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 6. |

| | |
|--|--|
| 6 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors B101, M67 ● Harness connectors M81, F36 ● Harness connectors B113, C3 ● Harness for open or short between EVAP canister vent control valve and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

KA24DE


Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


7 CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

With CONSULT-II

Check air passage continuity.
Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.



SEF143S



| ACTIVE TEST | |
|----------------|---------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| FR O2 MNTR | RICH |
| A/F ALPHA | XXX % |
| THR TL POS SEN | XXX V |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|-----------------------------|---|
| ON | No |
| OFF | Yes |

SEF172X

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.
If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace EVAP canister vent control valve and O-ring. |

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)


KA24DE

Diagnostic Procedure (Cont'd)

8 CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

⊗ Without CONSULT-II

Check air passage continuity under the following conditions.



AEC783A

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| No supply | Yes |

MTBL0297

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace EVAP canister vent control valve and O-ring. |

9 CHECK INTERMITTENT INCIDENT


Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

| | | |
|--|---|-----------------------|
| | ▶ | INSPECTION END |
|--|---|-----------------------|

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE


Component Description



Component Description

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.

NGEC0264



CONSULT-II Reference Value in Data Monitor Mode

NGEC0265

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|-----------------------|---------------|
| EVAP SYS PRES | ● Ignition switch: ON | Approx. 3.4V |

ECM Terminals and Reference Value

NGEC0266

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--|--|--------------------|
| 42 | BR | Sensors' power supply | [Ignition switch ON] | Approximately 5V |
| 43 | B/W | Sensors' ground | [Engine is running] ● Warm-up condition ● Idle speed | Approximately 0V |
| 62 | Y | EVAP control system pres- sure sensor | [Ignition switch ON] | Approximately 3.4V |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0267

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0450 0704 | <ul style="list-style-type: none">● An improper voltage signal from EVAP control system pressure sensor is sent to ECM. | <ul style="list-style-type: none">● Harness or connectors (The EVAP control system pressure sensor circuit is open or shorted.)● Rubber hose to EVAP control system pressure is clogged, vent, kinked, disconnected or improper connection.● EVAP control system pressure sensor● EVAP canister vent control valve● EVAP canister purge volume control solenoid valve● EVAP canister● Rubber hose from EVAP canister vent control valve to water separator |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

DTC Confirmation Procedure

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| TANK F/TMP SE | XXX °C |

PEF886U

DTC Confirmation Procedure

=NGEC0268

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform test at a temperature above 5°C (41°F).
- Before performing the following procedure, confirm battery voltage is more than 11V at idle.

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure that "TANK F/TEMP SE" is more than 0°C (32°F).
- 6) Start engine and wait at least 20 seconds.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-387.



Ⓜ With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
- 3) Turn ignition switch OFF and wait at least 5 seconds.
- 4) Start engine and wait at least 11 seconds.
- 5) Select "MODE 7" with GST.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-387.

Ⓜ No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
- 3) Turn ignition switch OFF and wait at least 5 seconds.
- 4) Start engine and wait at least 11 seconds.
- 5) Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-387.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR









KA24DE

Wiring Diagram

Wiring Diagram

NGEC0269

EC-PRE/SE-01



AEC998A

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE


Diagnostic Procedure

Diagnostic Procedure


NGEC0270

| | | |
|---|--|-------------------------------|
| 1 | CHECK RUBBER TUBE CONNECTED TO THE SENSOR | |
| Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Reconnect, repair or replace. |

GI
MA
EM

| | | |
|---|--------------------------------|------------|
| 2 | RETIGHTEN GROUND SCREWS | |
| <ol style="list-style-type: none"> Turn ignition switch OFF. Loosen and retighten engine ground screws. | | |
|  | | |
| SEF325V | | |
| | | ▶ GO TO 3. |

LC
EC
FE
CL
MT
AT

| | | |
|--|--------------------------------|--------------------------------------|
| 3 | CHECK HARNESS CONNECTOR | |
| 1. Disconnect EVAP control system pressure sensor harness connector. | | |
| <p>View with spare tire removed.</p>  | | |
| SEF341V | | |
| 2. Check sensor harness connector for water. Water should not exist. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair or replace harness connector. |


TF
PD
AX
SU
BR
ST
RS

BT
HA
SC
EL
IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR


KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|---|---------------------------|----------|--|
| 4 | CHECK POWER SUPPLY | | |
| <p>1. Turn ignition switch ON. 2. Check voltage between terminal 3 and engine ground with CONSULT-II or tester.</p> | | | |
|  | | | |
| <p>Voltage: Approximately 5V</p> | | | |
| <p>OK or NG</p> | | | |
| OK | ▶ | GO TO 6. | |
| NG | ▶ | GO TO 5. | |

SEF410Q

| | | | |
|--|-----------------------------------|--|--|
| 5 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C3, B113 ● Harness connectors B101, M67 ● Harness connectors M59, F27 ● Harness connectors M81, F36 ● Harness for open or short between EVAP control system pressure sensor and ECM | | | |
| <p>▶ Repair harness or connectors.</p> | | | |

| | | | |
|---|-----------------------------|----------|--|
| 6 | CHECK GROUND CIRCUIT | | |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between EVAP control system pressure sensor terminal 1 and engine ground.</p> | | | |
|  | | | |
| <p>Continuity should exist.</p> | | | |
| <p>3. Also check harness for short to ground and short to power.</p> | | | |
| <p>OK or NG</p> | | | |
| OK | ▶ | GO TO 8. | |
| NG | ▶ | GO TO 7. | |

SEF411Q

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 7 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C3, B113 ● Harness connectors B101, M67 ● Harness connectors M59, F27 ● Harness connectors M81, F36 ● Harness for open or short between EVAP control system pressure sensor and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM

| | |
|---|-----------------------------------|
| 8 | CHECK INPUT SIGNAL CIRCUIT |
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 62 and terminal 2.</p> | |
| | |
| <p>Continuity should exist.</p> | |
| <p>3. Also check harness for short to ground and short to power.</p> | |
| <p>OK or NG</p> | |
| OK (With CONSULT-II) ▶ | GO TO 10. |
| OK (Without CONSULT-II) ▶ | GO TO 11. |
| NG ▶ | GO TO 9. |

LC
EC
FE
CL
MT
AT

SEF412Q

TF
PD
AX

| | |
|--|--|
| 9 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C3, B113 ● Harness connectors B101, M67 ● Harness connectors M59, F27 ● Harness connectors M81, F36 ● Harness for open or short between EVAP control system pressure sensor and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

SU
BR
ST

RS
BT
HA

SC
EL

IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE



Diagnostic Procedure (Cont'd)

| 10 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | |
|---|--|------------------------------------|---|-----------------|-------|---------|----|---------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening. Check air passage continuity. If OK, inspection end. If NG, go to following step. | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>PURG VOL CONT/V</td><td>XXX %</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS~RPM(REF)</td><td>XXX rpm</td></tr> <tr><td>FR O2 MNTR</td><td>RICH</td></tr> <tr><td>A/F ALPHA</td><td>XXX %</td></tr> <tr><td>THRTL POS SEN</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | ACTIVE TEST | | PURG VOL CONT/V | XXX % | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | XXX % | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| <p>3. Check air passage continuity.</p> | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition PURG VOL CONT/V value</th> <th style="text-align: center;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">100.0%</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">0.0%</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | Condition PURG VOL CONT/V value | Air passage continuity between A and B | 100.0% | Yes | 0.0% | No | | | | | | | | | | | | | | |
| Condition PURG VOL CONT/V value | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | |
| 100.0% | Yes | | | | | | | | | | | | | | | | | | | | |
| 0.0% | No | | | | | | | | | | | | | | | | | | | | |
| PEF190V | | | | | | | | | | | | | | | | | | | | | |
| MTBL0302 | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ GO TO 12. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ Replace EVAP canister purge volume control solenoid valve. | | | | | | | | | | | | | | | | | | | | |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE



Diagnostic Procedure (Cont'd)

| 11 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | <p> Without CONSULT-II Check air passage continuity.</p> <div style="text-align: center;">  <p>SEF660U</p>  <p>SEF661U</p> <table border="1" style="margin: 20px auto; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="padding: 5px;">Condition</th> <th style="padding: 5px;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">12V direct current supply between terminals</td> <td style="padding: 5px;">Yes</td> </tr> <tr> <td style="padding: 5px;">No supply</td> <td style="padding: 5px;">No</td> </tr> </tbody> </table> <p>MTBL0303</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> </div> | Condition | Air passage continuity between A and B | 12V direct current supply between terminals | Yes | No supply | No | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 2px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
|---|--|---|-----------|--|---|-----|-----------|----|--|
| Condition | Air passage continuity between A and B | | | | | | | | |
| 12V direct current supply between terminals | Yes | | | | | | | | |
| No supply | No | | | | | | | | |
| OK | ▶ GO TO 13. | | | | | | | | |
| NG | ▶ Replace EVAP canister purge volume control solenoid valve. | | | | | | | | |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

Diagnostic Procedure (Cont'd)

| 12 | CHECK EVAP CANISTER VENT CONTROL VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|-------------|--|----------------|-----|---------|--|----------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|-----------------------------|---|----|----|-----|-----|
| <p>Ⓟ With CONSULT-II Check air passage continuity. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  <p style="text-align: center;">EVAP canister vent control valve</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF143S | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>VENT CONTROL/V</th> <th>OFF</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> </thead> <tbody> <tr> <td>CMPS-RPM (REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Condition VENT CONTROL/V</th> <th>Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>No</td> </tr> <tr> <td>OFF</td> <td>Yes</td> </tr> </tbody> </table> | ACTIVE TEST | | VENT CONTROL/V | OFF | MONITOR | | CMPS-RPM (REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | | Condition VENT CONTROL/V | Air passage continuity between A and B | ON | No | OFF | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition VENT CONTROL/V | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | No | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF172X | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary. If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ GO TO 14. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ Replace EVAP canister vent control valve. | | | | | | | | | | | | | | | | | | | | | | | | | | |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR


KA24DE

Diagnostic Procedure (Cont'd)

13 CHECK EVAP CANISTER VENT CONTROL VALVE

⊗ Without CONSULT-II

Check air passage continuity under the following conditions.



AEC783A

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| No supply | Yes |

MTBL0297

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.

OK or NG

OK ► GO TO 14.

NG ► Replace EVAP canister vent control valve.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

Diagnostic Procedure (Cont'd)


14 CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



SEF341V

2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
4. Check output voltage between ECM terminal 62 and engine ground.




SEF198V

| Pressure (Relative to atmospheric pressure) | Voltage (V) |
|---|-------------|
| 0 kPa (0 mmHg, 0 inHg) | 3.0 - 3.6 |
| -9.3 kPa (-70 mmHg, -2.76 inHg) | 0.4 - 0.6 |

MTBL0295

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.



Never apply force.

SEF799W

- Never apply force to the air hole protector of the sensor, if equipped.
- Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


OK or NG


| | | |
|----|---|--|
| OK | ▶ | GO TO 15. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|---------------------------------------|--|
| 15 | CHECK RUBBER TUBE FOR CLOGGING | |
| <p>Check obstructed water separator and rubber tube to EVAP canister vent control valve and clean the rubber tube using air blower.</p> <p>Check water separator.</p> <ol style="list-style-type: none"> 1. Check visually for insect nests in the water separator air inlet. 2. Check visually for cracks or flaws in the appearance. 3. Check visually for cracks or flaws in the hose. 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged. | | |
|  | | |
| <p>* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> | | |
| SEF829T | | |
| <p>5. In case of NG in items 2 - 4, replace the parts.</p> <ul style="list-style-type: none"> ● Do not disassemble water separator. | | |
| OK or NG | | |
| OK | ▶ | GO TO 16. |
| NG | ▶ | Clean, repair or replace rubber tube and/or water separator. |

| | | |
|---|--|-----------|
| 16 | CHECK IF EVAP CANISTER SATURATED WITH WATER | |
| <ol style="list-style-type: none"> 1. Remove EVAP canister with EVAP canister vent control valve attached. 2. Check if water will drain from the EVAP canister. | | |
|  | | |
| SEF596U | | |
| Yes or No | | |
| Yes | ▶ | GO TO 17. |
| No | ▶ | GO TO 19. |


| | | |
|--|----------------------------|-----------|
| 17 | CHECK EVAP CANISTER | |
| <p>Weigh the EVAP canister with EVAP canister vent control valve attached.</p> <p>The weight should be less than 1.8 kg (4.0 lb).</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 19. |
| NG | ▶ | GO TO 18. |


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|--|--|---|--|
| 18 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ol style="list-style-type: none"> 1. Visually check the EVAP canister for damage. 2. Check hose connection between EVAP canister and water separator for clogging and poor connection. 3. Check water separator. <ol style="list-style-type: none"> a. Check visually for insect nests in the water separator air inlet. b. Check visually for cracks or flaws in the appearance. c. Check visually for cracks or flaws in the hose. d. Check that A and C are not clogged by blowing air into B with A, and then C plugged. | | | |
|  <p style="text-align: center;">* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> | | | |
| <p>e. In case of NG in items 2 - 4, replace the parts.</p> <ul style="list-style-type: none"> ● Do not disassemble water separator. | | | |
| SEF829T | | | |
| <table border="0" style="margin: auto;"> <tr> <td style="text-align: right;">▶</td> <td>Repair hose or replace EVAP canister or water separator.</td> </tr> </table> | | ▶ | Repair hose or replace EVAP canister or water separator. |
| ▶ | Repair hose or replace EVAP canister or water separator. | | |

| | | | | | | | |
|---|-----------------------------|-----------|---|-----------|----|---|-----------|
| 19 | CHECK SHIELD CIRCUIT | | | | | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Reconnect disconnected harness connectors. 3. Disconnect harness connectors M67. 4. Check harness continuity between harness connector M67 terminal 12 and ground. | | | | | | | |
|  | | | | | | | |
| SEF197V | | | | | | | |
| <p>Continuity should exist.</p> <ol style="list-style-type: none"> 5. Also check harness for short to power. 6. Then reconnect harness connectors. | | | | | | | |
| OK or NG | | | | | | | |
| <table border="0" style="width: 100%;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 21.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 20.</td> </tr> </table> | | OK | ▶ | GO TO 21. | NG | ▶ | GO TO 20. |
| OK | ▶ | GO TO 21. | | | | | |
| NG | ▶ | GO TO 20. | | | | | |

| | | | |
|--|--|---|--|
| 20 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Joint connector-1 (Refer to "HARNES LAYOUT", <i>EL-272</i>.) ● Harness for open or short between harness connector M67 and engine ground | | | |
| <table border="0" style="margin: auto;"> <tr> <td style="text-align: right;">▶</td> <td>Repair open circuit, short to ground or short to power in harness or connectors.</td> </tr> </table> | | ▶ | Repair open circuit, short to ground or short to power in harness or connectors. |
| ▶ | Repair open circuit, short to ground or short to power in harness or connectors. | | |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|-----------------------------|
| 21 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


On Board Diagnosis Logic

NGEC0951

NOTE:

If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See EC-506.)

This diagnosis detects a very large leak (fuel filler cap fell off etc.) in the EVAP system between the fuel tank and the EVAP canister purge volume control solenoid valve.



Malfunction is detected when EVAP control system has a very large leak, such as fuel filler cap fell off, EVAP control system does not operate properly.

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

POSSIBLE CAUSE

NGEC0951S01

- Fuel filler cap remains open or fails to close.
- Incorrect fuel tank vacuum relief valve
- Incorrect fuel filler cap used
- Foreign matter caught in fuel filler cap.
- Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve.
- Foreign matter caught in EVAP canister vent control valve.
- EVAP canister or fuel tank leaks
- EVAP purge line (pipe and rubber tube) leaks
- EVAP purge line rubber tube bent.
- Blocked or bent rubber tube to EVAP control system pressure sensor
- Loose or disconnected rubber tube
- EVAP canister vent control valve and the circuit
- EVAP canister purge volume control solenoid valve and the circuit
- Absolute pressure sensor
- Tank fuel temperature sensor
- O-ring of EVAP canister vent control valve is missing or damaged.
- EVAP control system pressure sensor

DTC Confirmation Procedure

NGEC0952

CAUTION:

Never remove fuel filter cap during the DTC confirmation procedure.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

6 EVAP SML LEAK P0440/P1440

1)FOR BEST RSLT,PERFORM AT FOLLOWING CONDITIONS.
 -FUEL LEVEL: 1/4-3/4
 -AMBIENT TEMP: 0-30 C(32-86F)
 -OPEN ENGINE HOOD.
 2)START ENG WITH VHCL STOPPED. IF ENG IS ON,STOP FOR 5 SEC. THEN RESTART.
 3)TOUCH START.

SEF565X

5 EVAP SML LEAK P0440/P1440

WAIT
2 TO 10 MINUTES.
KEEP ENGINE RUNNING AT IDLE SPEED.

SEF566X

5 EVAP SML LEAK P0440/P1440

MAINTAIN
1600 - 2100 RPM UNTIL FINAL RESULT APPEARS.
(APPROX. 3 MINUTES)

SEF874X

6 EVAP SML LEAK P0440/P1440

OK

SELF-DIAG RESULTS

NO DTC DETECTED.
FURTHER TESTING
MAY BE REQUIRED.

SEF567X

NOTE:

- If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See EC-516.)
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

TESTING CONDITION:

- Perform “DTC WORK SUPPORT” when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Open engine hood before conducting the following procedure.
- It is better that the fuel level is low.

Ⓜ With CONSULT-II

- 1) Tighten fuel filter cap securely until ratcheting sound is heard.
- 2) Turn ignition switch ON.
- 3) Turn ignition switch OFF and wait at least 5 seconds.
- 4) Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
- 5) Make sure that the following conditions are met.
COOLAN TEMP/S: 0 - 70°C (32 - 158°F)
INT/A TEMP SE: 0 - 60°C (32 - 140°F)
- 6) Select “EVAP SML LEAK P0440” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II. Follow the instruction displayed.

NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to “Basic Inspection”, EC-95.

- 7) Make sure that “OK” is displayed.
 If “NG” is displayed, select “SELF-DIAG RESULTS” mode with CONSULT-II and make sure that “EVAP GROSS LEAK [P0455] is displayed. If it is displayed, refer to “Diagnostic Procedure”, EC-400.
 If P0440 is displayed, perform “Diagnostic Procedure” for DTC P0440.

Ⓜ With GST

NOTE:

- Be sure to read the explanation of “Driving Pattern” on EC-63 before driving vehicle.
 - It is better that the fuel level is low.
- 1) Start engine.
 - 2) Drive vehicle according to “Driving Pattern”, EC-63.
 - 3) Stop vehicle.

DTC P0455 EVAP CONTROL SYSTEM (GROSS LEAK)

KA24DE


DTC Confirmation Procedure (Cont'd)

- 4) Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
- 5) Turn ignition switch "OFF" and wait at least 5 seconds.
- 6) Start engine.

It is not necessary to cool engine down before driving.
- 7) Drive vehicle again according to the "Driving Pattern", EC-63.
- 8) Stop vehicle.
- 9) Select "MODE 3" with GST.
 - If P0455 is displayed on the screen, go to "Diagnostic Procedure", EC-400.
 - If P0440 is displayed on the screen, go to "Diagnostic Procedure", EC-354.
 - If P1440 is displayed on the screen, go to "Diagnostic Procedure", EC-486.
 - If P1447 is displayed on the screen, go to "Diagnostic Procedure", EC-507.
 - If P0440, P0455, P1440 and P1447 are not displayed on the screen, go to the following step.
- 10) Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6.

Diagnostic Procedure

NGEC0953

| 1 | CHECK FUEL FILLER CAP DESIGN |
|---|--|
| 1. Turn ignition switch OFF. 2. Check for genuine NISSAN fuel filler cap design. | |
|  | |
| OK or NG | |
| OK | ▶ GO TO 2. |
| NG | ▶ Replace with genuine NISSAN fuel filler cap. |

SEF915U



DTC P0455 EVAP CONTROL SYSTEM (GROSS LEAK)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|---|---|
| 2 | CHECK FUEL FILLER CAP INSTALLATION | |
| Check that the cap is tightened properly by rotating the cap clockwise. | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | <ul style="list-style-type: none"> • Open fuel filler cap, then clean cap and fuel filler neck threads using air blower. • Retighten until ratcheting sound is heard. |

| | | |
|--|---------------------------------------|----------|
| 3 | CHECK FUEL FILLER CAP FUNCTION | |
| Check for air releasing sound while opening the fuel filler cap. | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 4. |

| | | |
|---|---|---|
| 4 | CHECK FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP) | |
| <ol style="list-style-type: none"> 1. Wipe clean valve housing. 2. Check valve opening pressure and vacuum. | | |
|  <p style="text-align: center;">Fuel tank side</p> | | |
| SEF427N | | |
|  | | |
| SEF943S | | |
| <p>Pressure: 16.0 - 20.0 kPa (0.163 - 0.204 kg/cm², 2.32 - 2.90 psi)</p> <p>Vacuum: -6.0 to -3.5 kPa (-0.061 to -0.036 kg/cm², -0.87 to -0.51 psi)</p> <p>CAUTION: Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace fuel filler cap with a genuine one. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0455 EVAP CONTROL SYSTEM (GROSS LEAK)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|------------------------------|-------------------------------|
| 5 | CHECK EVAP PURGE LINE | |
| Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection or disconnection. Refer to "Evaporative Emission System", EC-34. | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Repair or reconnect the hose. |

| | | |
|--|------------------------------|----------|
| 6 | CLEAN EVAP PURGE LINE | |
| Clean EVAP purge line (pipe and rubber tube) using air blower. | | |
| | ▶ | GO TO 7. |


| | | |
|--|---|---|
| 7 | CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT | |
| Refer to "DTC Confirmation Procedure", EC-376. | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | Repair or replace EVAP canister vent control valve and O-ring or harness/connector. |

| | | |
|---|----------------------------------|-----------|
| 8 | INSTALL THE PRESSURE PUMP | |
| To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely. | | |
| <p>The diagram consists of two parts. The top part is a line drawing of the engine compartment, showing the location of the EVAP service port. Labels include 'EVAP canister purge volume control solenoid valve harness connector', 'Vehicle front' (with an arrow pointing left), and 'EVAP service port'. The bottom part is a detailed view of the 'EVAP service port adapter' connected to the 'EVAP service port'. A 'Pressure pump' is attached to the other end of the adapter, which also features a pressure gauge.</p> | | |
| SEF339V | | |
| NOTE: | | |
| Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking. | | |
| Models with CONSULT-II | ▶ | GO TO 9. |
| Models without CON-SULT-II | ▶ | GO TO 10. |
| SEF916U | | |

9 CHECK FOR EVAP LEAK

Ⓟ With CONSULT-II

1. Turn ignition switch ON.
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.




PEF658U

3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.



PEF917U

4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36.

Leak detector



SEF200U

OK or NG


| | | |
|----|---|--------------------|
| OK | ▶ | GO TO 11. |
| NG | ▶ | Repair or replace. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

10 CHECK FOR EVAP LEAK

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)




SEF503V

4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:

- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.

5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36.



SEF200U

OK or NG

| | | |
|----|---|--------------------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Repair or replace. |

| 11 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION | | | | | | | | | | | | | | | | | | | | | |
|---|--|-----------|-------------|--|-----------------|------|---------|--|---------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|--|--|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port. 2. Start engine. 3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode. 4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%. 5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm. | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>PURG VOL CONT/V</th> <th>0.0%</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS~RPM(REF)</th> <th>XXX rpm</th> </tr> </thead> <tbody> <tr> <td>FR O2 MNTR-B2</td> <td>RICH</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XXX %</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | PURG VOL CONT/V | 0.0% | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR-B2 | RICH | FR O2 MNTR-B1 | RICH | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | 0.0% | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | RICH | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| <p>Vacuum should exist.</p> <p style="text-align: right;">PEF882U</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 14. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 13. | | | | | | | | | | | | | | | | | | | | |

| | | |
|---|--|-----------|
| 12 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine. 3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port. 4. Start engine and let it idle for at least 80 seconds. 5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm. <p>Vacuum should exist.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | GO TO 13. |

| | | |
|--|--------------------------|-------------------------------|
| 13 | CHECK VACUUM HOSE | |
| <p>Check vacuum hoses for clogging or disconnection. Refer to "Vacuum Hose Drawing", EC-27.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 14. |
| OK (Without CONSULT-II) | ▶ | GO TO 15. |
| NG | ▶ | Repair or reconnect the hose. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

14 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓟ With CONSULT-II


1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

| ACTIVE TEST | |
|-----------------|---------|
| PURG VOL CONT/V | 0.0% |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 MNTR-B2 | RICH |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B2 | XXX % |
| A/F ALPHA-B1 | XXX % |
| THRTL POS SEN | XXX V |
| | |

PEF882U

If OK, inspection end. If NG, go to following step.

3. Check air passage continuity.



SEF660U

| Condition PURG VOL CONT/V value | Air passage continuity between A and B |
|------------------------------------|---|
| 100.0% | Yes |
| 0.0% | No |


MTBL0241

OK or NG

- | | | |
|----|---|--|
| OK | ▶ | GO TO 16. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

15 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


⊗ Without CONSULT-II
Check air passage continuity.



SEF661U

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No supply | No |

MTBL0242



SEF339V

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 16. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

16 CHECK ABSOLUTE PRESSURE SENSOR

1. Remove absolute pressure sensor with its harness connector connected.




SEF328V

2. Remove hose from absolute pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM terminal 45 and engine ground.
The voltage should be 3.2 to 4.8V.
4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.
The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.




AEC642A

OK or NG

| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 17. |
| NG | ▶ | Replace absolute pressure sensor. |

17 CHECK FUEL TANK TEMPERATURE SENSOR


Check resistance by heating with hot water or heat gun as shown in the figure.



SEF172VA

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.3 - 2.7 |
| 50 (122) | 0.79 - 0.90 |

MTBL0234



SEF334VA


OK or NG

- | | | |
|----|---|---|
| OK | ▶ | GO TO 18. |
| NG | ▶ | Replace fuel tank temperature sensor, FE-4 . |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


18 CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



SEF341V

2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.



SEF894U

| Pressure (Relative to atmospheric pressure) | Voltage (V) |
|---|-------------|
| 0 kPa (0 mmHg, 0 inHg) | 3.0 - 3.6 |
| -9.3 kPa (-70 mmHg, -2.76 inHg) | 0.4 - 0.6 |


MTBL0246

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.

CAUTION:

- Never apply force to the air hole protector of the sensor if equipped.



SEF799W

- Discard and EVAP control system pressure sensor which has been dropped from a height of more than 0.5m (19.7in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

OK ► GO TO 19.

NG ► Replace EVAP control system pressure sensor.

DTC P0455 EVAP CONTROL SYSTEM (GROSS LEAK)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|------------------------------------|----------------------------|
| 19 | CHECK FUEL LEVEL SENSOR | |
| 1. Remove fuel level sensor assembly. Refer to FE-5 . 2. Refer to "FUEL LEVEL SENSOR UNIT CHECK", EL-86 . <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | EC-411 |
| NG | ▶ | Replace fuel level sensor. |
| 20 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| | ▶ | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Component Description



Component Description

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

NGEC0272

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

NGEC0273

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|----------------------|---|------------------------------|
| 29 | G/B | Vehicle speed sensor | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Lift up the vehicle ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH) | <p>1 - 4V</p> <p>SEF003W</p> |

On Board Diagnosis Logic

NGEC0274

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P0500 0104 | <ul style="list-style-type: none"> ● The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven. | <ul style="list-style-type: none"> ● Harness or connector (The vehicle speed sensor circuit is open or shorted.) ● Vehicle speed sensor |

DTC Confirmation Procedure

NGEC0275

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

④ With CONSULT-II

- 1) Start engine
- 2) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
- 3) If NG, go to "Diagnostic Procedure", EC-415.
If OK, go to following step.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Warm engine up to normal operating temperature.

| 6 | DATA MONITOR | |
|---|---------------|----------|
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | B/FUEL SCHDL | XXX msec |
| | PW/ST SIGNAL | OFF |
| | VHCL SPEED SE | XXX km/h |

PEF199V

DTC P0500 VEHICLE SPEED SENSOR (VSS)

KA24DE

DTC Confirmation Procedure (Cont'd)

- 6) Maintain the following conditions for at least 10 consecutive seconds.

| | |
|----------------|---|
| CMPS-RPM (REF) | 1,450 - 2,550 rpm (A/T) 1,800 - 3,000 rpm (2WD M/T) 2,150 - 3,000 rpm (4WD M/T) |
| COOLANT TEMP/S | More than 70°C (158°F) |
| B/FUEL SCHDL | 2.1 - 4.8 msec (A/T) 2.5 - 5.3 msec (M/T) |
| Selector lever | Suitable position |
| PW/ST SIGNAL | OFF |

- 7) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-415.

| | |
|--------------------|--------------|
| FUEL SYS #1 | CLOSED |
| FUEL SYS #2 | CLOSED |
| CALC LOAD | 19% |
| COOLANT TEMP | 93°C |
| SHORT FT #1 | 1% |
| LONG FT #1 | 0% |
| SHORT FT #2 | 3% |
| LONG FT #2 | 0% |
| ENGINE SPD | 2037RPM |
| VEHICLE SPD | 12MPH |
| IGN ADVANCE | 38.0° |
| INTAKE AIR | 43°C |


SEF568P

Overall Function Check

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a 1st trip DTC might not be confirmed.

With GST

- Lift up drive wheels.
- Start engine.
- Read vehicle speed sensor signal in “MODE 1” with GST. The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
- If NG, go to “Diagnostic Procedure”, EC-415.







No Tools

- Lift up drive wheels.
- Start engine.
- Read the voltage signal between ECM terminal 29 (Vehicle speed sensor signal) and ground with oscilloscope.
- Verify that the oscilloscope screen shows the signal wave as shown at “ECM Terminals and Reference Value”, EC-412.
- If NG, go to “Diagnostic Procedure”, EC-415.

Wiring Diagram

NGEC0277

EC-VSS-01



Refer to the following.

M65, E43 - SUPER MULTIPLE JUNCTION (SMJ)

F29 - ELECTRICAL UNITS

Diagnostic Procedure

NGEC0278

| | | | |
|----------|-----------------------------------|--|---|
| 1 | CHECK INPUT SIGNAL CIRCUIT | | |
| | | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector and combination meter harness connector M39. 3. Check harness continuity between ECM terminal 29 and meter terminal 37. | GI MA EM LC EC FE CL MT |
| | | | SEF200V |
| | | <p style="color: blue;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| | | OK ▶ GO TO 3. | |
| | | NG ▶ GO TO 2. | |

| | | | |
|----------|-----------------------------------|---|----------------|
| 2 | DETECT MALFUNCTIONING PART | | |
| | | Check the following. <ul style="list-style-type: none"> ● Harness connectors M58, F28 ● Harness for open or short between ECM and combination meter | AT TF PD |
| | | ▶ Repair open circuit or short to ground or short to power in harness or connectors. | |

| | | | |
|----------|-----------------------------------|--|----------------|
| 3 | CHECK SPEEDOMETER FUNCTION | | |
| | | Make sure that speedometer functions properly. | AX SU BR |
| | | OK or NG | |
| | | OK ▶ GO TO 5. | |
| | | NG ▶ GO TO 4. | |

| | | | |
|----------|-----------------------------------|--|----------|
| 4 | DETECT MALFUNCTIONING PART | | |
| | | Check the following. <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors E32, E202 ● Harness for open or short between combination meter and vehicle speed sensor | ST RS |
| | | ▶ Repair harness or connectors. Check vehicle speed sensor and its circuit. Refer to EL-82 . | |

| | | | |
|----------|------------------------------------|--|-----------------------------|
| 5 | CHECK INTERMITTENT INCIDENT | | |
| | | Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | BT HA SC EL IDX |
| | | ▶ INSPECTION END | |

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

KA24DE

Description


Description SYSTEM DESCRIPTION

NGEC0279

NGEC0279S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|-----------------------------|--------------|----------------|
| Camshaft position sensor | Engine speed | ECM | IACV-AAC valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| PNP switch | Park/Neutral position | | |
| Air conditioner switch | Air conditioner operation | | |
| Power steering oil pressure switch | Power steering load signal | | |
| Battery | Battery voltage | | |
| Vehicle speed sensor | Vehicle speed | | |
| Absolute pressure sensor | Ambient barometric pressure | | |
| Intake air temperature sensor | Intake air temperature | | |

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).



COMPONENT DESCRIPTION

NGEC0279S02

The IAC valve-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

KA24DE

CONSULT-II Reference Value in Data Monitor Mode

CONSULT-II Reference Value in Data Monitor Mode

NGEC0280

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|-----------|---------------|
| IACV-AAC/V | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle | Approx. 30% |
| | | 2,000 rpm | — |

ECM Terminals and Reference Value

NGEC0281

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------|---|---------------------|
| 101 | OR/L | IACV-AAC valve | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>10.5 - 11.5V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm | <p>1 - 13V</p> |

On Board Diagnosis Logic

NGEC0282

| DTC No. | Malfunction is detected when ... | | Check Items (Possible Cause) |
|---------------|----------------------------------|---|--|
| P0505 0205 | A) | The IACV-AAC valve does not operate properly. | <ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open.) ● IACV-AAC valve |
| | B) | The IACV-AAC valve does not operate properly. | <ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is shorted.) ● IACV-AAC valve |

DTC Confirmation Procedure

=NGEC0283

NOTE:

- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- Perform “Procedure for malfunction A” first. If DTC cannot be confirmed, perform “Procedure for malfunction B”.

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | COOLAN TEMP/S | XXX °C |

PEF002P

PROCEDURE FOR MALFUNCTION A

NGEC0283S01

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 10.5V with ignition switch ON.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Start engine and run it at idle at least 2 seconds.
- 4) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-420.

Ⓜ With GST

Follow the procedure “With CONSULT-II”.

| | | |
|---|---------------|---------|
| 4 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |

PEF361V

PROCEDURE FOR MALFUNCTION B

NGEC0283S02

TESTING CONDITION:

- Before performing the following procedure, make sure battery voltage is more than 11V at idle.
- Always perform at a temperature above -10°C (14°F).

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON again and select “DATA MONITOR” mode with CONSULT-II.
- 4) Start engine and run it for at least 6 minute at idle speed.
- 5) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-420.

Ⓜ With GST

Follow the procedure “With CONSULT-II”.

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE


KA24DE

Wiring Diagram

Wiring Diagram

NGEC0284



EC-AAC/V-01



Refer to "EL-POWER".

: Detectable line for DTC
 : Non-detectable line for DTC

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST



RS
BT
HA
SC
EL
IDX

AEC001B



DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0285

| | | | |
|---|---------------------------|---|----------|
| 1 | CHECK POWER SUPPLY | | |
| <p>1. Stop engine. 2. Disconnect IACV-AAC valve harness connector.</p> <div style="text-align: center;"> <p>View with air cleaner removed</p>  </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | | | |
| OK | | ▶ | GO TO 3. |
| NG | | ▶ | GO TO 2. |

SEF342V

SEF247W

| | | | |
|--|-----------------------------------|---|-------------------------------|
| 2 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M58, F28 ● 10A fuse ● Harness for open or short between IACV-AAC valve harness connector and 10A fuse | | | |
| | | ▶ | Repair harness or connectors. |

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 3 | CHECK OUTPUT SIGNAL CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 101 and terminal 1.</p> | |
| | |
| SEF248W | |
| <p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|-----------------------------|
| 4 | CHECK IACV-AAC VALVE |
| <p>Disconnect IACV-AAC valve harness connector.</p> <ul style="list-style-type: none"> ● Check IACV-AAC valve resistance. | |
| | |
| SEF249W | |
| <p>Resistance: Approximately 10 Ω [at 25°C (77°F)]</p> <ul style="list-style-type: none"> ● Check plunger for seizing or sticking. ● Check for broken spring. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ Replace IACV-AAC valve. |


| | |
|---|------------------------------------|
| 5 | CHECK INTERMITTENT INCIDENT |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> | |
| | ▶ INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0510 CLOSED THROTTLE POSITION SWITCH

KA24DE

Component Description



Component Description

NGEC0287

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control.

When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge control valve when the throttle position sensor is malfunctioning.

ECM Terminals and Reference Value

NGEC0288

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---|---|-------------------------------|
| 28 | BR/W | Throttle position switch (Closed position) | [Ignition switch ON] ● Warm-up condition ● Accelerator pedal released | BATTERY VOLTAGE (11 - 14V) |
| | | | [Ignition switch ON] ● Accelerator pedal depressed | Approximately 0V |

On Board Diagnosis Logic

NGEC0289

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P0510 0203 | ● Battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened. | <ul style="list-style-type: none"> ● Harness or connectors (The closed throttle position switch circuit is shorted.) ● Closed throttle position switch ● Throttle position sensor |

4

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| COOLAN TEMP/S | XXX °C |
| VHCL SPEED SE | XXX km/h |
| THRT POS SEN | XXX V |

PEF329U

DTC Confirmation Procedure

=NGEC0290

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "CLSD THL/P SW" in "DATA MONITOR" mode with CONSULT-II and check the value under the following conditions.


| Condition | Voltage |
|--------------|---------|
| At idle | ON |
| At 2,000 rpm | OFF |

If the result is NG, go to "Diagnostic Procedure", EC-425.
If OK, go to following step.

- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Drive the vehicle for at least 5 consecutive seconds under the following condition.

| | |
|-----------------|--|
| THRTL POS SEN | More than 2.5V |
| VHCL SPEED SE | More than 4 km/h (2 MPH) |
| Selector lever | Suitable position |
| Driving pattern | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-425.



Overall Function Check

NGEC0291

Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.

Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the voltage between ECM terminal 28 (Closed throttle position switch signal) and ground under the following conditions.






| Condition | Voltage |
|--------------|----------------------|
| At idle | Battery voltage |
| At 2,000 rpm | Approximately 0 - 1V |

- 3) If NG, go to "Diagnostic Procedure", EC-425.

Wiring Diagram

NGEC0292

EC-TP/SW-01



| | |
|--|-----------------------------------|
| 3 | CHECK INPUT SIGNAL CIRCUIT |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 28 and terminal 6. | |
| | |
| AEC571A | |
| <p style="color: blue;">Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |

| | |
|---|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between throttle position switch and ECM. | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 5 | ADJUST THROTTLE POSITION SWITCH IDLE POSITION | | | | | | | | | | |
|---|--|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|
| 1. Check the following items. Refer to "Basic Inspection", EC-95. | | | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Items</th> <th style="width: 50%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>20° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>800 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> | | Items | Specifications | Ignition timing | 20° ± 2° BTDC | Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | Target idle speed | 800 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | |
| Ignition timing | 20° ± 2° BTDC | | | | | | | | | | |
| Base idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF | | | | | | | | | | |
| Target idle speed | 800 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| MTBL0328 | | | | | | | | | | | |
| ▶ | GO TO 6. | | | | | | | | | | |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

6 CHECK CLOSED THROTTLE POSITION SWITCH

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and turn ignition switch ON.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Check indication of "CLSD THL/P SW" under the following conditions.

| DATA MONITOR | |
|----------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM (REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| CLSD THL/P SW | ON |

| Throttle valve conditions | CLSD THL/P SW |
|-----------------------------------|---------------|
| Completely closed | ON |
| Partially open or completely open | OFF |

SEF173X

NOTE:


Measurement must be made with closed throttle position switch installed in vehicle.

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-95.

5. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect throttle position switch harness connector.
4. Check continuity between terminals 5 and 6 under the following conditions.



SEF159S

| Throttle valve conditions | Continuity |
|-----------------------------------|------------|
| Completely closed | Yes |
| Partially open or completely open | No |

MTBL0299

NOTE:

Continuity measurement must be made with closed throttle position switch installed in vehicle.

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-95.


5. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

OK or NG

| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace throttle position switch. |

| 7 | CHECK THROTTLE POSITION SENSOR | | | | | | | | | | |
|---|---------------------------------------|-----------------------------------|-----------|-------------------|-----------------|----------------|---------------------|-----------------|---------------|---------------|-------|
| <p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Stop engine and turn ignition switch ON. Select "DATA MONITOR" mode with CONSULT-II. Check voltage of "THRTL POS SEN" under the following conditions. | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th>NO FAIL</th> </tr> <tr> <td>CMPS-RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> </table> | | DATA MONITOR | | MONITORING | NO FAIL | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | THRTL POS SEN | XXX V |
| DATA MONITOR | | | | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | |
| PEF765W | | | | | | | | | | | |
| <p>NOTE: Voltage measurement must be made with throttle position sensor installed in vehicle. If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-95.</p> <ol style="list-style-type: none"> If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor. | | | | | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Stop engine and turn ignition switch ON. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground under the following conditions. | | | | | | | | | | | |
| | | | | | | | | | | | |
| SEF767W | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>Throttle valve conditions</th> <th>Voltage V</th> </tr> </thead> <tbody> <tr> <td>Completely closed</td> <td>0.15 - 0.85 (a)</td> </tr> <tr> <td>Partially open</td> <td>Between (a) and (b)</td> </tr> <tr> <td>Completely open</td> <td>3.5 - 4.7 (b)</td> </tr> </tbody> </table> | | Throttle valve conditions | Voltage V | Completely closed | 0.15 - 0.85 (a) | Partially open | Between (a) and (b) | Completely open | 3.5 - 4.7 (b) | | |
| Throttle valve conditions | Voltage V | | | | | | | | | | |
| Completely closed | 0.15 - 0.85 (a) | | | | | | | | | | |
| Partially open | Between (a) and (b) | | | | | | | | | | |
| Completely open | 3.5 - 4.7 (b) | | | | | | | | | | |
| MTBL0329 | | | | | | | | | | | |
| <p>NOTE: Voltage measurement must be made with throttle position sensor installed in vehicle. If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-95.</p> <ol style="list-style-type: none"> If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor. | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | |
| NG | ▶ | Replace throttle position sensor. | | | | | | | | | |

| | |
|--|------------------------------------|
| 8 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |



Component Description

The ECM consists of a microcomputer, diagnostic test mode selector, and connectors for signal input and output and for power supply. The ECM controls the engine.

NGEC0295


GI
MA
EM
LC

On Board Diagnosis Logic

NGEC0296

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P0605 0301 | <ul style="list-style-type: none"> ECM calculation function is malfunctioning. | <ul style="list-style-type: none"> ECM |

EC
FE
CL



PEF375V

DTC Confirmation Procedure

NGEC0297

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine.
- 4) Run engine for at least 30 seconds at idle speed.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-430.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Diagnostic Procedure

NGEC0298

| | | |
|---|-------------------------|-----------------------|
| 1 | INSPECTION START | |
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Select "SELF DIAG RESULTS" mode with CONSULT-II. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See previous page. 5. Is the 1st trip DTC P0605 displayed again? | | |
| <p> With GST</p> <ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Select MODE 4 with GST. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See previous page. 5. Is the 1st trip DTC P0605 displayed again? | | |
| <p> No Tools</p> <ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to EC-68. 3. Perform "DTC Confirmation Procedure". See previous page. 4. Is the 1st trip DTC 0301 displayed again? | | |
| Yes or No | | |
| Yes | ▶ | Replace ECM. |
| No | ▶ | INSPECTION END |

Description
SYSTEM DESCRIPTION


NGEC0299

NGEC0299S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|-----------------------------------|--------------------------------|
| Camshaft position sensor | Engine speed | On board diagnosis of EVAP system | MAP/BARO switch solenoid valve |
| Ignition switch | Start signal | | |

This system allows the absolute pressure sensor to monitor either ambient barometric pressure or intake manifold pressure. The MAP/BARO switch solenoid valve switches between two passages by ON-OFF pulse signals from the ECM. (One passage is from the intake air duct, the other is from the intake manifold.) Either ambient barometric pressure or intake manifold pressure is applied to the absolute pressure sensor.

| Solenoid | Conditions |
|----------|--|
| ON | <ul style="list-style-type: none"> For 5 seconds after turning ignition switch "ON" (Engine is not running) or For 5 seconds after starting engine or More than 5 minutes after the solenoid valve shuts OFF. and Engine running |



COMPONENT DESCRIPTION

NGEC0299S02

The MAP/BARO switch solenoid valve switches its air flow passage according to the voltage signal sent from the ECM. When voltage is supplied from the ECM, the MAP/BARO switch solenoid turns "ON". Then, the absolute pressure sensor can monitor the ambient barometric pressure. When voltage is not supplied from the ECM, the MAP/BARO switch solenoid valve turns "OFF". Then, the sensor monitors intake manifold pressure.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0300

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|---|---------------|
| MAP/BARO SW/V | <ul style="list-style-type: none"> For 5 seconds after starting engine | BARO |
| | <ul style="list-style-type: none"> More than 5 seconds after turning ignition switch "ON" More than 5 seconds after starting engine | MAP |

ECM Terminals and Reference Value

NGEC0301


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|-------------------------------------|---|-------------------------------|
| 118 | LG/B | MAP/BARO switch sole- noid valve | [Ignition switch "ON"] <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch "ON" | 0 - 1V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● For 5 seconds after starting engine | |
| | | | [Ignition switch "ON"] <ul style="list-style-type: none"> ● More than 5 seconds after turning ignition switch "ON" | BATTERY VOLTAGE (11 - 14V) |
| | | | [Engine is running] <ul style="list-style-type: none"> ● More than 5 seconds after starting engine | |

On Board Diagnosis Logic

NGEC0302

| DTC No. | Malfunction is detected when ... | | Check Items (Possible Cause) |
|---------------|----------------------------------|---|---|
| P1105 1302 | A) | MAP/BARO switch solenoid valve receives the voltage supplied though ECM does not supply the voltage to the valve. | <ul style="list-style-type: none"> ● Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.) ● MAP/BARO switch solenoid valve |
| | B) | There is little difference between MAP/BARO switch solenoid valve input voltage at ambient barometric pressure and voltage at intake manifold pressure. | <ul style="list-style-type: none"> ● Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.) ● Hoses (Hoses are clogged, vent, kinked, disconnected or improper connection.) ● Absolute pressure sensor ● MAP/BARO switch solenoid valve |



DTC Confirmation Procedure

NGEC0303

Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NGEC0303S01

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at ignition switch "ON".

④ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Wait at least 10 seconds.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-435.

 **With GST**

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

5

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| TANK F/TMP SE | XXX °C |

PEF398V

PROCEDURE FOR MALFUNCTION B

NGEC0303S02

TESTING CONDITION:

Always perform at a temperature above 5°C (41°F).

 **With CONSULT-II**

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON again and select "DATA MONITOR" mode with CONSULT-II.
- 4) Make sure that "TANK/F/TEMP SE" is more than 0°C (32°F).
- 5) Start engine and let it idle for at least 10 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-435.

EC

FE

CL


MT

AT

TF

PD

AX



 **With GST**

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Check that voltage between ECM terminal 60 and ground is less than 4.2V.
- 5) Start engine and let it idle for at least 10 seconds.
- 6) Select "MODE 7" with GST.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-435.

 **No Tools**

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Check that voltage between ECM terminal 60 and ground is less than 4.2V.
- 5) Start engine and let it idle for at least 10 seconds.
- 6) Turn ignition switch OFF, wait at least 5 seconds and then turn ignition ON.
- 7) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-435.

SU

BR

ST

RS

BT

HA

SC


EL

IDX



Wiring Diagram

NGEC0304

EC-SW/V-01



Refer to the following.
 (M65), (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)





Diagnostic Procedure

If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION A", perform "PROCEDURE A" below. If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE B" on EC-439.

PROCEDURE A

NGEC0305S01

| | | | |
|----------|---------------------------|--|-------------------------------|
| 1 | CHECK POWER SUPPLY | | |
| | | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect MAP/BARO switch solenoid valve harness connector.</p> <div style="text-align: center;">  <p>Vehicle front</p> <p>MAP/BARO switch solenoid valve harness connector</p> <p>Power steering oil reservoir</p> </div> <p>3. Turn ignition switch ON.</p> <p>4. Check voltage between terminal 2 and engine ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>DISCONNECT</p> <p>T.S.</p> <p>ON</p> <p>V</p> </div> <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>SEF338V</p> <p>SEF192V</p> |
| | OK | ▶ | GO TO 3. |
| | NG | ▶ | GO TO 2. |

| | | | |
|----------|-----------------------------------|---|-------------------------------|
| 2 | DETECT MALFUNCTIONING PART | | |
| | | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M59, F27 ● 10A fuse ● Harness for open or short between MAP/BARO switch solenoid valve and 10A fuse | |
| | | ▶ | Repair harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | |
|--|------------------------------------|----------|
| 3 | CHECK OUTPUT SIGNAL CIRCUIT | |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 118 and terminal 1.</p> | | |
| | | |
| SEF205V | | |
| <p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 5. |
| OK (Without CONSULT-II) | ▶ | GO TO 6. |
| NG | ▶ | GO TO 4. |

| | | |
|---|-----------------------------------|--|
| 4 | DETECT MALFUNCTIONING PART | |
| Check the harness for open or short between MAP/BARO switch solenoid valve and ECM. | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

5 CHECK MAP/BARO SWITCH SOLENOID VALVE

Ⓟ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Check the following.
 - Condition: At idle under no-load
 - CONSULT-II display
 - Time for voltage to change

| ACTIVE TEST | |
|----------------|---------|
| MAP/BARO SW/V | MAP |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| MAP/BARO SW/V | MAP |
| ABSOL PRES/SE | XXX V |
| | |
| | |
| | |

| MAP/BARO | AVSOL PRES/SE (Voltage) |
|----------|-------------------------------|
| BARO | More than 2.6V |
| MAP | Less than the voltage at BARO |

| ACTIVE TEST | |
|----------------|---------|
| MAP/BARO SW/V | BARO |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| MAP/BARO SW/V | BARO |
| ABSOL PRES/SE | XXX V |
| | |
| | |
| | |

| MAP/BARO SW/V | Required time to switch |
|---------------|-------------------------|
| BARO to MAP | Less than 1 second |
| MAP to BARO | |

SEF170X

OK or NG


| | | |
|----|---|----------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

6 CHECK MAP/BARO SWITCH SOLENOID VALVE


⊗ Without CONSULT-II

1. Turn ignition switch OFF and remove MAP/BARO switch solenoid valve.



SEF338V

2. Check air passage continuity.



MEC488B

| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

MTBL0283

3. Check the time required for the solenoid valve to switch. It should be less than 1 second.

OK or NG

OK ▶ GO TO 7.

NG ▶ Replace MAP/BARO switch solenoid valve.

7 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.


▶ **INSPECTION END**

PROCEDURE B


NGEC0305S02

1 INSPECTION START

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Connect MAP/BARO switch solenoid valve and absolute pressure sensor with a rubber tube that has vacuum gauge.



SEF338V



SEF676T


Models with CONSULT-II ► GO TO 2.


Models without CONSULT-II ► GO TO 3.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| 2 | CHECK VACUUM SOURCE TO MAP/BARO SWITCH SOLENOID VALVE AND CIRCUIT | | | | | | | | | | | | | | | | | | | | |
|--|--|---------------|--------|---------------|------------------|---------|--------------|---------------|---------|---------------|------|---------------|-------|--|--|--|--|--|--|--|--|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Select "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II. 3. Start engine and let it idle. 4. Touch "MAP" and "BARO" alternately and check for vacuum. | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><th>MAP/BARO SW/V</th><th>MAP</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><th>CMPS~RPM(REF)</th><th>XXX rpm</th></tr> <tr><th>MAP/BARO SW/V</th><th>MAP</th></tr> <tr><th>ABSOL PRES/SE</th><th>XXX V</th></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | ACTIVE TEST | | MAP/BARO SW/V | MAP | MONITOR | | CMPS~RPM(REF) | XXX rpm | MAP/BARO SW/V | MAP | ABSOL PRES/SE | XXX V | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | MAP | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | MAP | | | | | | | | | | | | | | | | | | | | |
| ABSOL PRES/SE | XXX V | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| PEF396V | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><th>MAP/BARO SW/V</th><th>BARO</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><th>CMPS~RPM(REF)</th><th>XXX rpm</th></tr> <tr><th>MAP/BARO SW/V</th><th>BARO</th></tr> <tr><th>ABSOL PRES/SE</th><th>XXX V</th></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | ACTIVE TEST | | MAP/BARO SW/V | BARO | MONITOR | | CMPS~RPM(REF) | XXX rpm | MAP/BARO SW/V | BARO | ABSOL PRES/SE | XXX V | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | BARO | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| MAP/BARO SW/V | BARO | | | | | | | | | | | | | | | | | | | | |
| ABSOL PRES/SE | XXX V | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| PEF397V | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th>MAP/BARO SW/V</th><th>Vacuum</th></tr> <tr><td>BARO</td><td>Should not exist</td></tr> <tr><td>MAP</td><td>Should exist</td></tr> </table> | | MAP/BARO SW/V | Vacuum | BARO | Should not exist | MAP | Should exist | | | | | | | | | | | | | | |
| MAP/BARO SW/V | Vacuum | | | | | | | | | | | | | | | | | | | | |
| BARO | Should not exist | | | | | | | | | | | | | | | | | | | | |
| MAP | Should exist | | | | | | | | | | | | | | | | | | | | |
| MTBL0079 | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ GO TO 13. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ GO TO 4. | | | | | | | | | | | | | | | | | | | | |

| 3 | CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR | | | | | | |
|---|--|-----------|--------|-------------------------------------|------------------|---|--------------|
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and let it idle. 2. Check for vacuum under the following condition. | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th>Condition</th><th>Vacuum</th></tr> <tr><td>For 5 seconds after starting engine</td><td>Should not exist</td></tr> <tr><td>More than 5 seconds after starting engine</td><td>Should exist</td></tr> </table> | | Condition | Vacuum | For 5 seconds after starting engine | Should not exist | More than 5 seconds after starting engine | Should exist |
| Condition | Vacuum | | | | | | |
| For 5 seconds after starting engine | Should not exist | | | | | | |
| More than 5 seconds after starting engine | Should exist | | | | | | |
| MTBL0080 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ GO TO 13. | | | | | | |
| NG | ▶ GO TO 4. | | | | | | |

| | | | |
|----------|--------------------------|---|--|
| 4 | CHECK VACUUM HOSE | <p>1. Turn ignition switch OFF.</p> <p>2. Check hose for clogging, cracks, disconnection or improper connection.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF109L</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 5. | |
| NG | ▶ | Clean, repair or reconnect the hose. | |

| | | | |
|----------|--------------------------|--|--|
| 5 | CHECK VACUUM PORT | <p>Check vacuum port for clogging.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF368U</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 6. | |
| NG | ▶ | Clean or repair the vacuum port. | |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

| | | | |
|---|---------------------------|----------|--|
| 6 | CHECK POWER SUPPLY | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect MAP/BARO switch solenoid valve harness connector. 3. Turn ignition switch ON. 4. Check voltage between terminal 2 and ground with CONSULT-II or tester. | | | |
| | | | |
| SEF192V | | | |
| Voltage: Battery voltage | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 8. | |
| NG | ▶ | GO TO 7. | |

| | | | |
|---|-----------------------------------|-------------------------------|--|
| 7 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M59, F27 ● 10A fuse ● Harness for open or short between MAP/BARO switch solenoid valve and 10A fuse | | | |
| ▶ | | Repair harness or connectors. | |

| | | | |
|--|------------------------------------|-----------|--|
| 8 | CHECK OUTPUT SIGNAL CIRCUIT | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 118 and terminal 1 with CONSULT-II or tester. | | | |
| | | | |
| SEF205V | | | |
| Continuity should exist. | | | |
| OK or NG | | | |
| OK (With CONSULT-II) | ▶ | GO TO 10. | |
| OK (Without CONSULT-II) | ▶ | GO TO 11. | |
| NG | ▶ | GO TO 9. | |

DTC P1105 MAP/BARO SWITCH SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 9 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between MAP/BARO switch solenoid valve and ECM. | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|-----------|---|
| 10 | CHECK MAP/BARO SWITCH SOLENOID VALVE |
|-----------|---|

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II.

| ACTIVE TEST | |
|---------------|---------|
| MAP/BARO SW/V | MAP |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| MAP/BARO SW/V | MAP |
| ABSOL PRES/SE | XXX V |
| | |
| | |
| | |
| | |

PEF396V

| ACTIVE TEST | |
|---------------|---------|
| MAP/BARO SW/V | BARO |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| MAP/BARO SW/V | BARO |
| ABSOL PRES/SE | XXX V |
| | |
| | |
| | |
| | |

PEF397V

3. Check the following.

- Condition: At idle under no-load
- CONSULT-II display

| MAP/BARO | ABSOL PRES/SE (Voltage) |
|----------|-------------------------------|
| BARO | More than 2.6V |
| MAP | Less than the voltage at BARO |

MTBL0281

- Time for voltage to change

| MAP/BARO SW/V | Required time to switch |
|---------------|-------------------------|
| BARO to MAP | Less than 1 second |
| MAP to BARO | |

MTBL0282

4. If NG, check solenoid valve as shown below.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Replace MAP/BARO switch solenoid valve. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX


| 11 | CHECK MAP/BARO SWITCH SOLENOID VALVE | | | | | | | | | |
|--|--|--|--|--|---|-----|----|-----------|----|-----|
| <p>⊗ Without CONSULT-II</p> <p>1. Turn ignition switch OFF and remove MAP/BARO switch solenoid valve.</p> | | | | | | | | | | |
|  | | | | | | | | | | |
| SEF338V | | | | | | | | | | |
| <p>2. Check air passage continuity.</p> | | | | | | | | | | |
|  | | | | | | | | | | |
| MEC488B | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Condition</th> <th style="padding: 5px;">Air passage continuity between A and B</th> <th style="padding: 5px;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">12V direct current supply between terminals 1 and 2</td> <td style="text-align: center; padding: 5px;">Yes</td> <td style="text-align: center; padding: 5px;">No</td> </tr> <tr> <td style="padding: 5px;">No supply</td> <td style="text-align: center; padding: 5px;">No</td> <td style="text-align: center; padding: 5px;">Yes</td> </tr> </tbody> </table> | | Condition | Air passage continuity between A and B | Air passage continuity between A and C | 12V direct current supply between terminals 1 and 2 | Yes | No | No supply | No | Yes |
| Condition | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | No | | | | | | | | |
| No supply | No | Yes | | | | | | | | |
| MTBL0283 | | | | | | | | | | |
| <p>3. Check the time required for the solenoid valve to switch. It should be less than 1 second.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | |
| OK | ▶ GO TO 12. | | | | | | | | | |
| NG | ▶ Replace MAP/BARO switch solenoid valve. | | | | | | | | | |

| | |
|--|----------------------------|
| 12 | CHECK INTAKE SYSTEM |
| <p>Check intake system for air leaks.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 16. |
| NG | ▶ Repair it. |

DTC P1105 MAP/BARO SWITCH SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|---|---------------------------|
| 13 | CHECK HOSE BETWEEN ABSOLUTE PRESSURE SENSOR AND MAP/BARO SWITCH SOLENOID VALVE | |
| <p>Check hose for clogging, cracks, disconnection or improper connection.</p> <div style="text-align: center;">  <p>The diagrams show three types of hose problems: 1. A hose with a longitudinal crack labeled 'Split'. 2. A hose with a bulbous swelling labeled 'Clogging'. 3. A hose that is not properly seated on a fitting labeled 'Improper connection'.</p> </div> <p style="text-align: right;">SEF109L</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | Repair or reconnect hose. |

| | | |
|--|--------------------------------|--------------------------------------|
| 14 | CHECK HARNESS CONNECTOR | |
| <p>1. Disconnect absolute pressure sensor harness connector. 2. Check sensor harness connector for water. Water should not exist.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 15. |
| NG | ▶ | Repair or replace harness connector. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX

| | | | | | | | |
|---|---------------------------------------|-----------------------------------|---|-----------|----|---|-----------------------------------|
| 15 | CHECK ABSOLUTE PRESSURE SENSOR | | | | | | |
| <p>1. Remove absolute pressure sensor with its harness connector connected.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF328V</p> <p>2. Remove hose from absolute pressure sensor.</p> <p>3. Turn ignition switch ON and check output voltage between ECM terminal 45 (Absolute pressure sensor signal) and engine ground.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF132V</p> <p>The voltage should be 3.2 to 4.8V.</p> <p>4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.</p> <p>The voltage should be 1.0 to 1.4V lower than the value measured in step 3.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Always calibrate the vacuum pump gauge when using it. ● Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 5px;">OK</td> <td style="width: 10%; text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">GO TO 16.</td> </tr> <tr> <td style="padding: 5px;">NG</td> <td style="text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">Replace absolute pressure sensor.</td> </tr> </table> | | OK | ▶ | GO TO 16. | NG | ▶ | Replace absolute pressure sensor. |
| OK | ▶ | GO TO 16. | | | | | |
| NG | ▶ | Replace absolute pressure sensor. | | | | | |

| | |
|---|------------------------------------|
| 16 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ INSPECTION END | |

On Board Diagnosis Logic

NGEC0307

★ The closed loop control has the one trip detection logic.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P1148 0307 | <ul style="list-style-type: none"> ● The closed loop control function does not operate even when vehicle is driving in the specified condition. | <ul style="list-style-type: none"> ● The front heated oxygen sensor circuit is open or shorted. ● Front heated oxygen sensor ● Front heated oxygen sensor heater |

DATA MONITOR

| MONITORING | NO FAIL |
|------------------------|---------|
| CMPS~RPM(REF) XXX rpm | |
| FR O2 SENSOR XXX °C | |
| VHCL SPEED SE XXX km/h | |
| B/FUEL SCHDL XXX msec | |

PEF237V

DTC Confirmation Procedure

NGEC0308

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Never raise engine speed above 3,000 rpm during the “DTC Confirmation Procedure”. If the engine speed limit is exceeded, retry the procedure from step 4.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Hold engine speed at 2,000 rpm and check the following.
 - “FR O2 SENSOR” voltage should go above 0.70V at least once.
 - “FR O2 SENSOR” voltage should go below 0.21V at least once.


If the result is NG, perform “Diagnosis Procedure”, EC-448.
If the result is OK, perform the following step.
- 4) Let engine idle at least 3 minutes.
- 5) Maintain the following condition at least 50 consecutive seconds.

| | |
|----------------|----------------------------|
| B/FUEL SCHDL | 1.3 msec or more |
| CMPS-RPM (REF) | 1,650 - 3,000 rpm |
| Selector lever | Suitable position |
| VHCL SPEED SE | More than 70 km/h (44 MPH) |

During this test, P0130 DTC may be displayed on CONSULT-II screen.

- 6) If DTC is detected, go to “Diagnostic Procedure”, EC-448.

Overall Function Check



Overall Function Check

NGEC0309

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.


⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage should go above 0.70V at least once.
 - The voltage should go below 0.21V at least once.
- 4) If NG, go to "Diagnostic Procedure", EC-448.

Diagnostic Procedure

NGEC0310

Refer to "Diagnostic Procedure" for DTC P0133, EC-216.



Component Description

IGNITION COIL & POWER TRANSISTOR

NGEC0319
NGEC0319S01

The ignition signal from the ECM is sent to the power transistor. The power transistor switches the ignition coil primary circuit on and off. As the primary circuit is turned on and off, the proper high voltage is induced in the coil secondary circuit.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

NOTE:

The rotor screw which secures the distributor rotor head to the distributor shaft must be tightened properly.

: 3.3 - 3.9 N·m (0.34 - 0.40 kg·m, 29.5 - 34.7 in·lb)

GI
MA
EM
LC

EC

FE

CL

MT

CONSULT-II Reference Value in Data Monitor Mode

NGEC0320

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|--------------------|
| IGN TIMING | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle | Approx. 20° BTDC |
| | 2,000 rpm | More than 25° BTDC |

AT

TF

PD

ECM Terminals and Reference Value

NGEC0321

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-----------------|---|-------------------|
| 1 | PU/W | Ignition signal | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | 0 - 0.5V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | 0.2 - 1.0V |

SU

BR

ST

RS

BT

HA

SC



EL

IDX

DTC P1320 IGNITION SIGNAL

KA24DE

ECM Terminals and Reference Value (Cont'd)

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|----------------|--|--|
| 2 | B | Ignition check | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>12 - 14V</p>  <p>SEF998V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>12 - 13V</p>  <p>SEF999V</p> |

On Board Diagnosis Logic

NGEC0322

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|--|
| P1320 0201 | <ul style="list-style-type: none"> ● The ignition signal in the primary circuit is not sent to ECM during engine cranking or running. | <ul style="list-style-type: none"> ● Harness or connectors (The ignition primary circuit is open or shorted.) ● Power transistor unit. ● Resistor ● Camshaft position sensor ● Camshaft position sensor circuit |

DTC Confirmation Procedure

NGEC0323

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- If DTC P1320 (0201) is displayed with P0340 (0101), perform trouble diagnosis for DTC P0340 first. Refer to EC-318.

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 4 seconds. (If engine does not run, turn ignition switch to "START" at least 5 seconds.)
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-452.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P1320 IGNITION SIGNAL

KA24DE

Wiring Diagram

Wiring Diagram

NGEC0324

EC-IGN/SG-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS






BT

HA


SC

EL

IDX



Refer to the following.
 (M65, E43) - SUPER
 MULTIPLE JUNCTION (SMJ)





AEC004B

Diagnostic Procedure

NGEC0325

| | | |
|--|---------------------------|----------|
| 1 | CHECK ENGINE START | |
| Turn ignition switch OFF, and restart engine. Is engine running? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 7. |
| No | ▶ | GO TO 2. |

| | | |
|--|---------------------------|----------|
| 2 | CHECK POWER SUPPLY | |
| 1. Turn ignition switch OFF. 2. Disconnect ignition coil harness connector. | | |
|  | | |
| SEF344V | | |
| 3. Turn ignition switch ON. 4. Check voltage between terminal 7 and ground with CONSULT-II or tester. | | |
|  | | |
| AEC698 | | |
| Voltage: Battery voltage | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 3. |

| | | |
|--|-----------------------------------|-------------------------------|
| 3 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M59, F27 ● Harness for open or short between ignition coil and ignition switch | | |
| ▶ | | Repair harness or connectors. |


DTC P1320 IGNITION SIGNAL

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|-----------------------------|--|
| 4 | CHECK GROUND CIRCUIT | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect power transistor harness connector. 3. Check harness continuity between power transistor terminal 2 and engine ground. Refer to the wiring diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC

| | | |
|---|-----------------------------------|--|
| 5 | CHECK INPUT SIGNAL CIRCUIT | |
| <ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 1 and power transistor terminal 1. | | |
|  | | |
| Continuity should exist. | | |
| <ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

EC
FE
CL
MT
AT

AEC700

TF
PD


AX
SU


BR
ST

RS
BT

HA
SC

EL
IDX


| 6 | CHECK IGNITION COIL | <ol style="list-style-type: none"> 1. Disconnect ignition coil harness connector. 2. Remove distributor cap. 3. Check resistance as shown in the figure. <div style="text-align: center; margin: 10px 0;">  </div> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 40%;">Terminal</th> <th style="width: 60%;">Resistance [at 25°C (77°F)]</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">7 - 8</td> <td style="text-align: center;">Less than 1Ω</td> </tr> <tr> <td style="text-align: center;">7 - 9</td> <td style="text-align: center;">7 - 13Ω</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 10px;">AEC150A</p> <p style="text-align: right; margin-top: 10px;">MTBL0300</p> <p style="text-align: center; margin-top: 10px;">If NG, replace distributor assembly as a unit.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | Terminal | Resistance [at 25°C (77°F)] | 7 - 8 | Less than 1Ω | 7 - 9 | 7 - 13Ω |
|----------|-----------------------------|---|----------|-----------------------------|-------|--------------|-------|---------|
| Terminal | Resistance [at 25°C (77°F)] | | | | | | | |
| 7 - 8 | Less than 1Ω | | | | | | | |
| 7 - 9 | 7 - 13Ω | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | |
| NG | ▶ | Replace distributor assembly as a unit. | | | | | | |

| 7 | CHECK POWER TRANSISTOR | <ol style="list-style-type: none"> 1. Disconnect camshaft position sensor & power transistor harness connector and ignition coil harness connector. 2. Check power transistor resistance between terminals 2 and 8. <div style="text-align: center; margin: 10px 0;">  </div> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Terminals</th> <th style="width: 30%;">Resistance</th> <th style="width: 40%;">Result</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2 and 8</td> <td style="text-align: center;">Except 0Ω</td> <td style="text-align: center;">OK</td> </tr> <tr> <td style="text-align: center;">0Ω</td> <td style="text-align: center;">NG</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 10px;">AEC151A</p> <p style="text-align: right; margin-top: 10px;">MTBL0301</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | Terminals | Resistance | Result | 2 and 8 | Except 0Ω | OK | 0Ω | NG |
|-----------|-------------------------------|--|-----------|------------|--------|---------|-----------|----|----|----|
| Terminals | Resistance | Result | | | | | | | | |
| 2 and 8 | Except 0Ω | OK | | | | | | | | |
| | 0Ω | NG | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | |
| NG | ▶ | Replace distributor assembly. | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


8 CHECK INPUT SIGNAL CIRCUIT

1. Stop engine.
2. Disconnect ignition coil harness connector.
3. Strip tape covering resistor.
4. Disconnect resistor harness connector.



SEF344V

5. Disconnect ECM harness connector.
6. Check harness continuity between ignition coil terminal 8 and resistor terminal 1, resistor terminal 2 and ECM terminal 2.




SEF179X

Continuity should exist.

7. Also check harness for short to ground and short to power.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 9. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |



| | | | |
|--|-----------------------|-------------------|--|
| 9 | CHECK RESISTOR | | |
| <p>1. Disconnect resistor harness connector. 2. Check resistance between terminals 1 and 2.</p> | | | |
|  | | | |
| <p>Resistance: Approximately 2.2 kΩ [at 25°C (77°F)]</p> | | | |
| SEF240V | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 10. | |
| NG | ▶ | Replace resistor. | |

| | | | |
|--|------------------------------------|---|-----------------------|
| 10 | CHECK INTERMITTENT INCIDENT | | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | | |
| | | ▶ | INSPECTION END |

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

KA24DE

Component Description



Component Description

NGEC0327

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system.

It is used only for the on board diagnosis.

GI

MA

EM

LC

EC

FE



CL

MT

ECM Terminals and Reference Value

NGEC0328

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (AC Voltage) |
|----------------------|---------------|----------------------------------|---|---|
| 43 | B/W | Sensors' ground | [Engine is running] ● Warm-up condition ● Idle speed | Approximately 0V |
| 53 | L | Crankshaft position sensor (OBD) | [Engine is running] ● Warm-up condition ● Idle speed | Approx. 0V  |
| | | | [Engine is running] ● Engine speed is 2,000 rpm | Approx. 0V  |

TF

PD

AX

SU

BR

ST

RS

BT

HA

On Board Diagnosis Logic

NGEC0329

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P1336 0905 | ● A chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM. | ● Harness or connectors ● Crankshaft position sensor (OBD) ● Drive plate/Flywheel |

SC

EL

IDX

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

KA24DE

DTC Confirmation Procedure

| | | |
|---|---------------|---------|
| 2 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

DTC Confirmation Procedure

NGEC0330

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 2 minutes at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-460.

Ⓜ With GST

Follow the procedure "With CONSULT-II".


DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

KA24DE
Wiring Diagram


Wiring Diagram

NGEC0331

EC-CKPS-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



AEC993A

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)



KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0332

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws. | |
| ▶ | GO TO 2. |

| | | |
|---|-----------------------------------|----------|
| 2 | CHECK INPUT SIGNAL CIRCUIT | |
| 1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors. | | |
|  <p style="margin-left: 300px;">Crankshaft position sensor (OBD)</p> | | |
| 2. Check continuity between ECM terminal 47 and terminal 2. | | |
|  | | |
| <p style="color: blue; margin-left: 40px;">Continuity should exist.</p> | | |
| 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 3. |

SEF335V

SEF175V

| | |
|--|--|
| 3 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors E202, E32 ● Harness connectors E41, F25 ● Harness for open or short between crankshaft position sensor (OBD) and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|---|-----------------------------|----------|
| 4 | CHECK GROUND CIRCUIT | |
| <p>1. Reconnect ECM harness connectors.</p> <p>2. Check harness continuity between crankshaft position sensor (OBD) terminal 1 and engine ground. Refer to the wiring diagram.</p> <p style="color: blue; margin-left: 20px;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |

| | | |
|---|-----------------------------------|--|
| 5 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E202, E32 ● Harness connectors E41, F25 ● Harness for open or short between crankshaft position sensor (OBD) and ECM | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|--|-----------------------------|----------|
| 6 | CHECK SHIELD CIRCUIT | |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect harness connectors E32.</p> <p>3. Check harness continuity between harness connector E32 terminal 2 and ground.</p> | | |
| | | |
| Continuity should exist | | |
| <p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect harness connectors.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

| | | |
|---|-----------------------------------|--|
| 7 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E41, F25 ● Joint connector-1 (Refer to "HARNESS LAYOUT", <i>EL-272</i>.) ● Harness for open or short between harness connector E32 and engine ground | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |



| | | |
|--|------------------------------------|------------|
| 8 | CHECK IMPROPER INSTALLATION | |
| Loosen and retighten the fixing bolt of the crankshaft position sensor (OBD). Then retest. | | |
| Trouble is not fixed. | | ▶ GO TO 9. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

KA24DE

Diagnostic Procedure (Cont'd)


| | | | |
|--|---|---|--|
| 9 | CHECK CRANKSHAFT POSITION SENSOR (OBD) | | |
| <ol style="list-style-type: none"> 1. Disconnect crankshaft position sensor (OBD) harness connector. 2. Loosen the fixing bolt of the sensor. 3. Remove the sensor. 4. Visually check the sensor for chipping. | | | |
|  | | | |
| <ol style="list-style-type: none"> 5. Check resistance as shown in the figure. | | | |
|  | | | |
| Resistance: Approximately 512 - 632Ω [at 20°C (68°F)] | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 10. | |
| NG | ▶ | Replace crankshaft position sensor (OBD). | |

SEF960N

SEF231W

| | | | |
|---|-------------------------|--------------------------------------|--|
| 10 | CHECK GEAR TOOTH | | |
| Visually check for chipping flywheel or drive plate gear tooth (cog). | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 11. | |
| NG | ▶ | Replace the flywheel or drive plate. | |

| | | | |
|--|------------------------------------|--|-------------------------|
| 11 | CHECK INTERMITTENT INCIDENT | | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | | |
| | | | ▶ INSPECTION END |



Component Description

The EGRC-solenoid valve responds to signals from the ECM.^{NGEC0334} When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an ON signal, a plunger will then move to cut the vacuum signal from the throttle body to the EGR valve.

CONSULT-II Reference Value in Data Monitor Mode

^{NGEC0335}

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|---------------|
| EGRC SOL/V | ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" (A/T models) ● No-load | Idle ON |
| | Rev engine up from idle to 3,000 rpm quickly. | OFF |

ECM Terminals and Reference Value

^{NGEC0336}




Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---------------------|--|----------------------------|
| 103 | G/W | EGRC-solenoid valve | [Engine is running] ● Warm-up condition ● Idle speed | 0 - 1V |
| | | | [Engine is running] ● Warm-up condition ● M/T models: Lift up drive wheels and shift to 1st gear position. ● Rev engine up from 2,000 to 4,000 rpm. | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

^{NGEC0337}

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P1400 1005 | ● The improper voltage signal is sent to ECM through EGRC-solenoid valve. | ● Harness or connectors (The EGRC-solenoid valve circuit is open or shorted.) ● EGRC-solenoid valve |



DTC Confirmation Procedure

NGEC0338

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform at a temperature above -10°C (14°F).

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Maintain the following conditions for at least 5 consecutive seconds.

CMPS-RPM (REF): 1,000 - 3,400 rpm

B/FUEL SCHDL: 2 msec or more

VHCL SPEED SE: Suitable speed

- 4) If 1st trip DTC is detected, go to "DIAGNOSTIC PROCEDURE", EC-466.

Ⓜ With GST

- Follow the procedure with "CONSULT-II".

Overall Function Check

NGEC0521

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.

ⓧ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the voltage between ECM terminal 103 and ground at idle.

Voltage: 0 - 1V

- 3) Check that the voltage changes to battery voltage and returns to 0 - 1V when revving the engine from idle to 3,000 rpm quickly.
- 4) If NG, go to "DIAGNOSTIC PROCEDURE", EC-466.


DTC P1400 EGRC-SOLENOID VALVE

KA24DE
Wiring Diagram

Wiring Diagram

NGEC0339

EC-EGRC/V-01



— : Detectable line for DTC
 — : Non-detectable line for DTC


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST

Refer to last page (Foldout page).



(M65), (E43)

RS
 BT
 HA



SC

AEC005B



EL

IDX

Diagnostic Procedure

NGEC0340

| 1 | CHECK EGRC-SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | | | |
|--|----------------------------------|----------|-------------|--|------------|----|---------|--|---------------|---------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| <p> With CONSULT-II</p> <p>1. Turn ignition switch ON.</p> <p>2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.</p> | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>EGRC SOL/V</th> <th>ON</th> </tr> </thead> <tbody> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CKPS~RPM(POS)</th> <th>XXX rpm</th> </tr> <tr><td> </td><td> </td></tr> </tbody> </table> | | | ACTIVE TEST | | EGRC SOL/V | ON | MONITOR | | CKPS~RPM(POS) | XXX rpm | | | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOL/V | ON | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | |
| CKPS~RPM(POS) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| <small>PEF594P</small> | | | | | | | | | | | | | | | | | | | | | | | | |
| <p> Without CONSULT-II</p> <p>1. Start engine and rev engine up to 3,000 rpm quickly.</p> <p>2. When disconnecting and reconnecting the EGRC-solenoid valve harness connector, make sure that the EGRC-solenoid valve makes operating sound. (The DTC or the 1st trip DTC for the EGRC-solenoid valve will be displayed, however, ignore it.)</p> | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | |
| OK (With CONSULT-II) | ▶ | GO TO 5. | | | | | | | | | | | | | | | | | | | | | | |
| OK (Without CONSULT-II) | ▶ | GO TO 6. | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 2. | | | | | | | | | | | | | | | | | | | | | | |

| | | | | | | | | | |
|----------|---------------------------|---|--|---|----------|----|---|----------|--|
| 2 | CHECK POWER SUPPLY | <p>1. Turn ignition switch OFF. 2. Disconnect EGRC-solenoid valve harness connector.</p> <div style="text-align: center;"> <p>View with air cleaner removed</p>  </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> | | | | | | |
| | | <table border="1" style="width: 100%;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 3.</td> </tr> </table> | OK | ▶ | GO TO 4. | NG | ▶ | GO TO 3. | |
| OK | ▶ | GO TO 4. | | | | | | | |
| NG | ▶ | GO TO 3. | | | | | | | |

| | | | | | | |
|----------|-----------------------------------|---|--|---|-------------------------------|--|
| 3 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M59, F27 ● 10A fuse ● Harness for open or short between EGRC-solenoid valve and 10A fuse <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 20%;"></td> <td style="width: 5%; text-align: center;">▶</td> <td style="width: 75%;">Repair harness or connectors.</td> </tr> </table> | | ▶ | Repair harness or connectors. | <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| | ▶ | Repair harness or connectors. | | | | |

| | |
|---|------------------------------------|
| 4 | CHECK OUTPUT SIGNAL CIRCUIT |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 103 and terminal 1.</p> | |
| | |
| SEF243V | |
| <p style="color: blue;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK (With CONSULT-II) | ▶ GO TO 6. |
| OK (Without CONSULT-II) | ▶ GO TO 7. |
| NG | ▶ GO TO 5. |

| | |
|--|--|
| 5 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between EGRC-solenoid valve and ECM. | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 6 | CHECK EGRC-SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|---|--|--|------------------|--------|---------|----------------|---------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|-------------------------------------|---|---|----|-----|----|-----|----|-----|
| <p>Ⓟ With CONSULT-II Check air passage continuity. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="3" style="text-align: center;">ACTIVE TEST</th> </tr> <tr> <th style="width: 30%;">EGRC SOL/V (EGR)</th> <th style="width: 30%;">ON CUT</th> <th style="width: 40%;">MONITOR</th> </tr> <tr> <th>CMPS-RPM (REF)</th> <th>XXX rpm</th> <th></th> </tr> </thead> <tbody> <tr><td> </td><td> </td><td> </td></tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 30%;">Condition EGRC SOLENOID VALVE</th> <th style="width: 30%;">Air passage continuity between A and B</th> <th style="width: 40%;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> <tr> <td>OFF</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | ACTIVE TEST | | | EGRC SOL/V (EGR) | ON CUT | MONITOR | CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | ON | Yes | No | OFF | No | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOL/V (EGR) | ON CUT | MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | Yes | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | No | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF169X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ GO TO 8. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ Replace EGRC-solenoid valve. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

DTC P1400 EGRC-SOLENOID VALVE


KA24DE

Diagnostic Procedure (Cont'd)

| 7 | CHECK EGRC-SOLENOID VALVE | <p> Without CONSULT-II Check air passage continuity shown in the figure.</p> <div style="text-align: center;"> </div> <div style="text-align: right; margin-top: 10px;">AEC919</div> <table border="1" style="margin: 10px auto; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="padding: 5px;">Condition</th> <th style="padding: 5px;">Air passage continuity between A and B</th> <th style="padding: 5px;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">12V direct current supply between terminals 1 and 2</td> <td style="padding: 5px;">Yes</td> <td style="padding: 5px;">No</td> </tr> <tr> <td style="padding: 5px;">No supply</td> <td style="padding: 5px;">No</td> <td style="padding: 5px;">Yes</td> </tr> </tbody> </table> <div style="text-align: right; margin-top: 10px;">MTBL0283</div> <p>If NG or operation takes more than 1 second, replace solenoid valve.</p> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; padding: 5px;">OK</td> <td style="width: 5%; text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">GO TO 8.</td> </tr> <tr> <td style="padding: 5px;">NG</td> <td style="text-align: center; padding: 5px;">▶</td> <td style="padding: 5px;">Replace EGRC-solenoid valve.</td> </tr> </table> | Condition | Air passage continuity between A and B | Air passage continuity between A and C | 12V direct current supply between terminals 1 and 2 | Yes | No | No supply | No | Yes | OK | ▶ | GO TO 8. | NG | ▶ | Replace EGRC-solenoid valve. | GI MA EM LC EC FE CL MT AT TF |
|---|--|---|-----------|--|--|---|-----|----|-----------|----|-----|----|---|----------|----|---|------------------------------|---|
| Condition | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | | | | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | No | | | | | | | | | | | | | | | | |
| No supply | No | Yes | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace EGRC-solenoid valve. | | | | | | | | | | | | | | | | |

| | | | | | | |
|----------|------------------------------------|--|--|---|-----------------------|---|
| 8 | CHECK INTERMITTENT INCIDENT | <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;"></td> <td style="width: 5%; text-align: center;">▶</td> <td>INSPECTION END</td> </tr> </table> | | ▶ | INSPECTION END | PD AX SU BR ST RS BT HA SC EL IDX |
| | ▶ | INSPECTION END | | | | |

Component Description



Component Description

NGEC0342

The EGR temperature sensor detects temperature changes in the EGR passageway. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passageway changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases. This sensor is not used to control the engine system.

It is used only for the on board diagnosis.


<Reference data>

| EGR temperature °C (°F) | Voltage* V | Resistance MΩ |
|----------------------------|---------------|------------------|
| 0 (32) | 4.81 | 7.9 - 9.7 |
| 50 (122) | 2.82 | 0.57 - 0.70 |
| 100 (212) | 0.8 | 0.08 - 0.10 |

*: These data are reference values and are measured between ECM terminal 63 (EGR temperature sensor) and ECM terminal 32 (ECM ground).

When EGR system is operating.

Voltage: 0 - 1.5V



On Board Diagnosis Logic

NGEC0343

| DTC No. | Malfunction is detected when ... | | Check Items (Possible Cause) |
|---------------|----------------------------------|--|--|
| P1401 0305 | A) | An excessively low voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is low. | <ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is shorted.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve |
| | B) | An excessively high voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is high. | <ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is open.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve |

4

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |

PEF779U

DTC Confirmation Procedure

NGEC0344

Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NGEC0344S01

With CONSULT-II


- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Verify that engine coolant temperature is less than 50°C (122°F).

If the engine coolant temperature is above the range, cool the engine down.

- 4) Start engine and let it idle for at least 8 seconds.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-474.

With GST

- Follow the procedure "With CONSULT-II".



9

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| VHCL SPEED SEN | XXX km/h |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF724W

PROCEDURE FOR MALFUNCTION B

NGEC0344S02

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

Always perform the test at a temperature above 5°C (41°F).



With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Run engine at idle for at least 2 minutes.
- 3) Confirm that EGR valve is not lifting.
If the result is NG, perform trouble diagnosis for DTC P1402. Refer to EC-476.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Read "EGR TEMP SEN" at about 1,500 rpm while holding the EGR valve in full open position by hand.
Voltage should decrease to less than 1.0V.
If the result is NG, go to "Diagnostic Procedure", EC-474.
If the result is OK, go to following step.
- 6) Turn ignition switch OFF and wait at least 5 seconds.
- 7) Turn ignition switch ON.
- 8) Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
- 9) Start engine.

10) Maintain the following conditions for at least 5 consecutive seconds.

| | |
|----------------|---|
| CMPS-RPM (REF) | 2,000 - 2,600 rpm |
| VHCL SPEED SE | 10 km/h (6 MPH) or more |
| B/FUEL SCHDL | 2.5 - 3.5 msec |
| THRTL POS SEN | (X + 0.23) – (X + 0.74) V X = Voltage value measured at step 7 |
| Selector lever | Suitable position |

11) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-474.



Overall Function Check

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.

NGEC0345

PROCEDURE FOR MALFUNCTION B

NGEC0345S01

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Run engine at idle for at least 2 minutes.
- 3) Confirm that EGR valve is not lifting. If NG, perform trouble diagnosis for DTC P1402. Refer to EC-477.
- 4) Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand.
Voltage should decrease to less than 1.0V.
- 5) If NG, go to “Diagnostic Procedure”, EC-474.
If OK, perform trouble diagnoses for DTC P0400 and P1400. Refer to EC-326, 463.

DTC P1401 EGR TEMPERATURE SENSOR


KA24DE

Wiring Diagram

Wiring Diagram

NGEC0346

EC-EGR/TS-01



: Detectable line for DTC
 : Non-detectable line for DTC

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL



IDX




AEC006B

Diagnostic Procedure

NGEC0347

| | | | |
|----------|---------------------------|---|-------------------------------|
| 1 | CHECK POWER SUPPLY | | |
| | | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect EGR temperature sensor harness connector. | |
| | | <p>View with air cleaner removed</p>  <p>Throttle body EGR temperature sensor harness connector EGR temperature sensor</p> | <small>SEF345V</small> |
| | | <ol style="list-style-type: none"> 3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester. | |
| | |  | <small>SEF263W</small> |
| | | <p>Voltage: Approximately 5V</p> | |
| | | <p>OK or NG</p> | |
| OK | | ▶ | GO TO 2. |
| NG | | ▶ | Repair harness or connectors. |

| | | | |
|----------|-----------------------------|---|------------------------|
| 2 | CHECK GROUND CIRCUIT | | |
| | | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check harness continuity between EGR temperature sensor terminal 2 and engine ground. Refer to the wiring diagram. | |
| | |  | <small>SEF264W</small> |
| | | <p>Continuity should exist.</p> | |
| | | <ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. | |
| | | <p>OK or NG</p> | |
| OK | | ▶ | GO TO 4. |
| NG | | ▶ | GO TO 3. |

| | | | |
|----------|-----------------------------------|--|---|
| 3 | DETECT MALFUNCTIONING PART | <p>Check the harness for open or short between EGR temperature sensor and ECM.</p> | |
| | | ▶ | Repair open circuit or short to ground or short to power in harness or connector. |

DTC P1401 EGR TEMPERATURE SENSOR


KA24DE

Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

4 CHECK EGR TEMPERATURE SENSOR

Check resistance change and resistance value.




SEF643Q

<Reference data>

| EGR temperature °C (°F) | Voltage V | Resistance MΩ |
|-------------------------|-----------|---------------|
| 0 (32) | 4.81 | 7.9 - 9.7 |
| 50 (122) | 2.82 | 0.57 - 0.70 |
| 100 (212) | 0.8 | 0.08 - 0.10 |

MTBL0294



SEF526Q

OK or NG

| | | |
|----|---|---------------------------------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace EGR temperature sensor. |

5 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

▶ **INSPECTION END**

Description
SYSTEM DESCRIPTION



NGEC0349

NGEC0349S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|----------------------------|--------------|---------------------|
| Camshaft position sensor | Engine speed | EGR control | EGRC-solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current through the solenoid valve is cut. This causes the vacuum to be cut. The EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



COMPONENT DESCRIPTION

NGEC0349S02

Exhaust Gas Recirculation (EGR) Valve


NGEC0349S0201

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.

DTC P1402 EGR FUNCTION (OPEN)

KA24DE

Description (Cont'd)




EGRC-solenoid Valve

NGEC0349S0202

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal passes through the solenoid valve. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve).

When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the throttle body to the EGR valve.



On Board Diagnosis Logic


NGEC0350

If EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

NOTE:

Diagnosis for this DTC will occur when engine coolant temperature is approx. 50 to 60°C (122 to 140°F). Therefore, it will be better to turn ignition switch "ON" (Start engine) at the engine coolant temperature below 40°C (104°F) when starting DTC confirmation procedure.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P1402 0514 | <ul style="list-style-type: none"> EGR flow is detected under conditions that do not call for EGR. | <ul style="list-style-type: none"> EGRC-solenoid valve EGR valve leaking or stuck open EGR temperature sensor EGRC-BPT valve |



DTC Confirmation Procedure

NGEC0351

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Engine coolant temperature and EGR temperature must be verified in "DATA MONITOR" mode with CONSULT-II before starting DTC WORK SUPPORT test. If it is out of range below, the test cannot be conducted.
COOLAN TEMP/S: -10 to 40°C (14 to 104°F)*
EGR TEMP SEN: Less than 4.8V

If the values are out of the ranges indicated above, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to reduce the engine coolant or EGR temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

*: Although CONSULT-II screen displays "-10 to 40°C (14 to 104°F)" as a range of engine coolant temperature, ignore it.



DTC P1402 EGR FUNCTION (OPEN)

KA24DE

DTC Confirmation Procedure (Cont'd)

4

| | |
|------------------|----------|
| EGR SYSTEM P1402 | |
| OUT OF CONDITION | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF245V

4


| | |
|------------------|----------|
| EGR SYSTEM P1402 | |
| TESTING | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF246V

4

| | |
|------------------|--|
| EGR SYSTEM P1402 | |
| COMPLETED | |

PEF897U



With CONSULT-II

- 1) Turn ignition switch OFF and wait at least 5 seconds, then turn ignition switch ON.
- 2) Select "EGR SYSTEM P1402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 3) Touch "START". Follow instruction of CONSULT-II.
- 4) Start engine and let it idle until "TESTING" on CONSULT-II screen is turned to "COMPLETED". (It will take 60 seconds or more.)

If "TESTING" is not displayed after 5 minutes, turn ignition "OFF" and cool the engine coolant temperature to the range of -10 to 40°C (14 to 104°F). Retry from step 1.

- 5) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-480.

With GST

- 1) Turn ignition switch ON and select "MODE 1" with GST.
- 2) Check that engine coolant temperature is within the range of -10 to 35°C (14 to 95°F).
- 3) Check that voltage between ECM terminal 63 (EGR temperature sensor signal) and ground is less than 4.8V.
- 4) Start engine and let it idle for at least 60 seconds.
- 5) Stop engine.
- 6) Perform from step 1 to 4.
- 7) Select "MODE 3" with GST.
- 8) If DTC is detected, go to "Diagnostic Procedure", EC-480.

No Tools

- 1) Turn ignition switch ON.
- 2) Check the following voltages.

ECM terminal 59 (Engine coolant temperature sensor signal) and ground: 2.7 - 4.4V

ECM terminal 63 (EGR temperature sensor signal) and ground: Less than 4.8V

- 3) Start engine and let it idle for at least 60 seconds.
- 4) Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If DTC is detected, go to "Diagnostic Procedure", EC-480.

When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II or ECM (Diagnostic Test Mode II) is recommended.

DTC P1402 EGR FUNCTION (OPEN)


KA24DE

Wiring Diagram



Wiring Diagram

NGEC0352

EC-EGRC1-01




GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST



Refer to the following.
 (M65), (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)

RS
BT
HA




AEC995A

IDX

Diagnostic Procedure

NGENC0353

| | | |
|---|--------------------------|--------------------------------|
| 1 | CHECK VACUUM HOSE | |
| Check vacuum hose for clogging, cracks or improper connection. Refer to "Vacuum Hose Drawing", EC-27. | | |
|  | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 2. |
| OK (Without CONSULT-II) | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace vacuum hose. |

SEF109L

| 2 | CHECK EGRC-SOLENOID VALVE CIRCUIT | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|----------|-------------|--|------------|----|-------|------|---------|--|---------------|---------|--|--|--|--|--|--|--|--|--|--|--|--|
| (P) With CONSULT-II 1. Turn ignition switch ON. 2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound. | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>EGRC SOL/V</th> <th>ON</th> </tr> <tr> <th>(EGR)</th> <th>FLOW</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS-RPM(REF)</th> <th>XXX rpm</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> | | | ACTIVE TEST | | EGRC SOL/V | ON | (EGR) | FLOW | MONITOR | | CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOL/V | ON | | | | | | | | | | | | | | | | | | | | | | | |
| (EGR) | FLOW | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| Clicking noise should be heard. | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 5. | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | | | |

PEF788U

| | | |
|--|--|----------|
| 3 | CHECK EGRC-SOLENOID VALVE CIRCUIT | |
| (X) Without CONSULT-II 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Turn ignition switch ON. 4. Check operating sound of the solenoid valve when disconnecting and reconnecting EGRC-solenoid valve harness connector. (The DTC or the 1st trip DTC for the EGRC-solenoid valve will be displayed, however, ignore it.) | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 4. |


DTC P1402 EGR FUNCTION (OPEN)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|-----------------------------------|--|
| 4 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M59, F27 ● 10A fuse ● Harness for open or short between fuse block and EGRC-solenoid valve ● Harness for open or short between ECM and EGRC-solenoid valve <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair open circuit or short to power in harness or connector. |

GI
MA
EM
LC

| 5 | CHECK EGRC-SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|---|-------------|--|-----------------|--------|---------|--|----------------|---------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|-------------------------------------|---|---|----|-----|----|-----|----|-----|
| <p>Ⓟ With CONSULT-II Check air passage continuity. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  </div> <div style="flex: 1;"> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2" style="text-align: center;">ACTIVE TEST</th> </tr> <tr> <th style="text-align: center;">EGRC SOLV (EGR)</th> <th style="text-align: center;">ON CUT</th> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <th style="text-align: center;">CMPS-RPM (REF)</th> <th style="text-align: center;">XXX rpm</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> </div> <div style="flex: 2; margin-left: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition EGRC SOLENOID VALVE</th> <th style="text-align: center;">Air passage continuity between A and B</th> <th style="text-align: center;">Air passage continuity between A and C</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">OFF</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> </div> </div> | | | ACTIVE TEST | | EGRC SOLV (EGR) | ON CUT | MONITOR | | CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | ON | Yes | No | OFF | No | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOLV (EGR) | ON CUT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition EGRC SOLENOID VALVE | Air passage continuity between A and B | Air passage continuity between A and C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | Yes | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | No | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF169X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace EGRC-solenoid valve. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1402 EGR FUNCTION (OPEN)


KA24DE

Diagnostic Procedure (Cont'd)

6 CHECK EGRC-SOLENOID VALVE

⊗ Without CONSULT-II

Check air passage continuity shown in the figure.



AEC919

| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

MTBL0283

If NG or operation takes more than 1 second, replace solenoid valve.


OK or NG

OK ► GO TO 7.

NG ► Replace EGRC-solenoid valve.

7 CHECK EGR VALVE

- Apply vacuum to EGR vacuum port with a hand vacuum pump.



MEF137D

EGR valve spring should lift.

- Check for sticking.

OK or NG


OK ► GO TO 8.

NG ► Replace EGR valve.

DTC P1402 EGR FUNCTION (OPEN)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|-----------------------------|
| 8 | CHECK EGRC-BPT VALVE |
| <ol style="list-style-type: none">1. Plug one of two ports of EGRC-BPT valve.2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve. | |
|  <p data-bbox="1380 640 1477 661">SEF083P</p> | |
| 3. If a leakage is noted, replace the valve. | |
| OK or NG | |
| OK | ▶ GO TO 9. |
| NG | ▶ Replace EGRC-BPT valve. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P1402 EGR FUNCTION (OPEN)

KA24DE

Diagnostic Procedure (Cont'd)

9 CHECK EGR TEMPERATURE SENSOR

Check resistance change and resistance value.




<Reference data>

| EGR temperature °C (°F) | Voltage V | Resistance MΩ |
|-------------------------|-----------|---------------|
| 0 (32) | 4.81 | 7.9 - 9.7 |
| 50 (122) | 2.82 | 0.57 - 0.70 |
| 100 (212) | 0.8 | 0.08 - 0.10 |

SEF643Q

MTBL0294



SEF526Q

OK or NG

OK



GO TO 10.

NG



Replace EGR temperature sensor.

10 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.



INSPECTION END

DTC P1440 EVAP CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

KA24DE

On Board Diagnosis Logic

On Board Diagnosis Logic


NGEC0355

NOTE:

If DTC P1440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. Refer to EC-515.

This diagnosis detects leaks in the EVAP purge line using vapor pressure in the fuel tank. The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge control valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank.

If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge control valve.



| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|---|
| P1440 0213 | <ul style="list-style-type: none"> ● EVAP control system has a leak. ● EVAP control system does not operate properly. | <ul style="list-style-type: none"> ● Fuel filler cap remains open or fails to close. ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve ● Absolute pressure sensor ● Fuel tank temperature sensor ● MAP/BARO switch solenoid valve ● Blocked or bent rubber tube to MAP/BARO switch solenoid valve ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water. ● Fuel level sensor |

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC P1440 EVAP CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

KA24DE

DTC Confirmation Procedure

DTC Confirmation Procedure

NGEC0356

NOTE:

Refer to "P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)", EC-352.

Diagnostic Procedure

NGEC0357

NOTE:

Refer to "P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)", EC-354.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


KA24DE
Description

Description SYSTEM DESCRIPTION

NGEC0359
NGEC0359S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|--|----------------------------------|---|
| Camshaft position sensor | Engine speed | EVAP canister purge flow control | EVAP canister purge volume control solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| Throttle position switch | Closed throttle position | | |
| Front heated oxygen sensors | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | | |
| Fuel tank temperature sensor | Fuel temperature in fuel tank | | |
| Vehicle speed sensor | Vehicle speed | | |

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|---------------|
| PURG VOL C/V | Idle (Vehicle stopped) | 0% |
| | 2,000 rpm (200 seconds after starting engine) | — |

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE



KA24DE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NGEC0361

Specification data are reference values and are measured between each terminal and 32 (ECCS ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---|---|---|
| 4 | LG/R | ECCS relay (Self-shut-off) | [Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch "OFF" | 0 - 1V |
| | | | [Ignition switch "OFF"] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch "OFF" | BATTERY VOLTAGE (11 - 14V) |
| 5 | R/Y | EVAP canister purge volume control solenoid valve | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V)  |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | BATTERY VOLTAGE (11 - 14V)  |
| 67 | B/P | Power supply for ECM | [Ignition switch "ON"] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 117 | B/P | Current return | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0362

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P1444 0214 | The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control solenoid valve is completely closed. | <ul style="list-style-type: none"> ● EVAP control system pressure sensor ● EVAP canister purge volume control solenoid valve (The valve is stuck open.) ● EVAP canister vent control valve ● EVAP canister ● Hoses (Hoses are connected incorrectly or clogged.) |

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE

DTC Confirmation Procedure

DTC Confirmation Procedure

=NGEC0363

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| TANK F/TMP SE | XXX °C |

PEF195V

| PURG VOL CN/V P1444 | |
|---------------------|----------|
| OUT OF CONDITION | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF900U

| PURG VOL CN/V P1444 | |
|---------------------|----------|
| TESTING | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF901U

| PURG VOL CN/V P1444 | |
|---------------------|--|
| COMPLETED | |

PEF902U

④ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Check that TANK F/TEMP SE is 0°C (32°F) or more.
- 6) Select "PURG VOL C/V P1444" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 7) Touch "START".
- 8) Start engine and let it idle until "TESTING" on CONSULT-II changes to "COMPLETED". (It will take for at least 10 seconds.)
If "TESTING" is not displayed after 5 minutes, retry from step 2.
- 9) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-491.

④ With GST

Follow the procedure "With CONSULT-II".

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE






KA24DE

Wiring Diagram

Wiring Diagram

NGEC0504

EC-PGC/V-01



AEC996A



DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE

Diagnostic Procedure

Diagnostic Procedure

=NGEC0364

| | | | |
|----------|---------------------------|---|---|
| 1 | CHECK POWER SUPPLY | | |
| | | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect EVAP canister purge volume control solenoid valve harness connector.</p> <div style="text-align: center;">  <p>EVAP canister purge volume control solenoid valve harness connector</p> <p>Vehicle front</p> <p>EVAP service port</p> </div> <p>3. Turn ignition switch ON.</p> <p>4. Check voltage between terminal 2 and engine ground with CONSULT-II or tester.</p> <p style="color: blue;">Voltage: Battery voltage</p> <div style="text-align: center;">  <p>DISCONNECT</p> <p>T.S.</p> <p>2 1</p> <p>V</p> </div> <p>OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> |
| | OK | ▶ | GO TO 3. |
| | NG | ▶ | GO TO 2. |

SEF339V

SEF192V

| | | | |
|----------|-----------------------------------|--|---|
| 2 | DETECT MALFUNCTIONING PART | | |
| | | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM | <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> |
| | | ▶ | Repair harness or connectors. |

IDX


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

3 CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 5 and terminal 1.
Continuity should exist.



If OK, check harness for short to ground and short to power.

SEF193V

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

4 DETECT MALFUNCTIONING PART

Check the harness for open or short between EVAP canister purge volume control solenoid valve and ECM.

| | |
|---|--|
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |
|---|--|


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)


5 CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



SEF341V

2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
4. Check output voltage between ECM terminal 62 and engine ground.




SEF198V

| Pressure (Relative to atmospheric pressure) | Voltage (V) |
|---|-------------|
| 0 kPa (0 mmHg, 0 inHg) | 3.0 - 3.6 |
| -9.3 kPa (-70 mmHg, -2.76 inHg) | 0.4 - 0.6 |

MTBL0295

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.



SEF799W

- Never apply force to the air hole protector of the sensor, if equipped.
- Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

| | | |
|-------------------------|---|--|
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

| 6 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | |
|--|--|--|------------------------------------|---|-----------------|-------|---------|----|---------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|
| <p>Ⓟ With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening. Check air passage continuity. If OK, inspection end. If NG, go to following step.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>PURG VOL CONT/V</td><td>XXX %</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS~RPM(REF)</td><td>XXX rpm</td></tr> <tr><td>FR O2 MNTR</td><td>RICH</td></tr> <tr><td>A/F ALPHA</td><td>XXX %</td></tr> <tr><td>THRTL POS SEN</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | | ACTIVE TEST | | PURG VOL CONT/V | XXX % | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | XXX % | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| <p>3. Check air passage continuity.</p> | | | | | | | | | | | | | | | | | | | | | | |
| PEF190V | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition PURG VOL CONT/V value</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">100.0%</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">0.0%</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | | Condition PURG VOL CONT/V value | Air passage continuity between A and B | 100.0% | Yes | 0.0% | No | | | | | | | | | | | | | | |
| Condition PURG VOL CONT/V value | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | |
| 100.0% | Yes | | | | | | | | | | | | | | | | | | | | | |
| 0.0% | No | | | | | | | | | | | | | | | | | | | | | |
| MTBL0302 | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. | | | | | | | | | | | | | | | | | | | | |



DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

7 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

⊗ Without CONSULT-II
Check air passage continuity.



SEF660U

SEF661U

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals | Yes |
| No supply | No |

MTBL0303

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE


Diagnostic Procedure (Cont'd)

8 CHECK EVAP CANISTER VENT CONTROL VALVE


With CONSULT-II

Check air passage continuity.

Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.



SEF143S



| ACTIVE TEST | |
|----------------|---------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| FR O2 MNTR | RICH |
| A/F ALPHA | XXX % |
| THRTL POS SEN | XXX V |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|-----------------------------|---|
| ON | No |
| OFF | Yes |

SEF172X

OK or NG

OK ► GO TO 10.

NG ► Replace EVAP canister vent control valve.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


KA24DE

Diagnostic Procedure (Cont'd)

9 CHECK EVAP CANISTER VENT CONTROL VALVE

⊗ Without CONSULT-II

Check air passage continuity shown in the figure.



AEC783A

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| No supply | Yes |

MTBL0297

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.

OK or NG


OK ▶ GO TO 10.

NG ▶ Replace EVAP canister vent control valve.

10 CHECK RUBBER TUBE

Check for obstructed water separator and rubber tube connected to EVAP canister vent control valve and clean the rubber tube using air blower. Check water separator.

1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.



- * **(A)** : Bottom hole (To atmosphere)
- (B)** : Emergency tube (From EVAP canister)
- (C)** : Inlet port (To member)

SEF829T

5. In case of NG in items 2 - 4, replace the parts.

● **Do not disassemble water separator.**

OK or NG

OK ▶ GO TO 11.


NG ▶ Clean, repair or replace rubber tube and/or water separator.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|--|-----------|
| 11 | CHECK IF EVAP CANISTER SATURATED WITH WATER | |
| <p>1. Remove EVAP canister with EVAP canister vent control valve attached.</p> <p>2. Check if water will drain from the EVAP canister.</p> | | |
|  | | |
| SEF596U | | |
| Yes or No | | |
| Yes | ▶ | GO TO 12. |
| No | ▶ | GO TO 14. |

| | | |
|--|----------------------------|-----------|
| 12 | CHECK EVAP CANISTER | |
| <p>Weigh the EVAP canister with the EVAP canister vent control valve attached.</p> <p>The weight should be less than 1.8 kg (4.0 lb).</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | GO TO 13. |


| | | |
|---|-----------------------------------|---------------------------------------|
| 13 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● EVAP canister for damage ● EVAP hose between EVAP canister and water separator for clogging or poor connection | | |
| ▶ | | Repair hose or replace EVAP canister. |

| | | |
|--|------------------------------------|-----------------------|
| 14 | CHECK INTERMITTENT INCIDENT | |
| <p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> | | |
| ▶ | | INSPECTION END |


DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

KA24DE

Component Description



SEF378Q



SEF143S

Component Description

NGEC0366

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

GI

MA

EM

LC

EC

FE

CL

MT

AT

CONSULT-II Reference Value in Data Monitor Mode

NGEC0367

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|---------------|
| VENT CONT/V | ● Ignition switch: ON | OFF |

TF

PD

ECM Terminals and Reference Value

NGEC0368

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------------|------------------------|----------------------------|
| 108 | R/G | EVAP canister vent control valve | [Ignition switch "ON"] | BATTERY VOLTAGE (11 - 14V) |

AX

SU

BR

On Board Diagnosis Logic

NGEC0369

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|------------|---|---|
| P1446 0215 | ● EVAP canister vent control valve remains closed under specified driving conditions. | <ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water. |

ST

RS

BT

HA

SC

EL

IDX


DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

KA24DE

DTC Confirmation Procedure

| | | |
|---|----------------|----------|
| 4 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS~RPM(REF) | XXX rpm |
| | COOLANT TEMP/S | XXX °C |
| | VHCL SPEED SEN | XXX km/h |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF724W



DTC Confirmation Procedure

NGEC0370

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform at a temperature above 0°C (32°F).

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Check that TANK F/TMP SE is 0°C (32°F) or more.
- 6) Drive vehicle at a speed of approximately 80 km/h (50 MPH) for a maximum of 15 minutes.
- 7) If 1st trip DTC is detected, go to "DIAGNOSTIC PROCEDURE" on EC-501.

NOTE:

If a malfunction exists, NG result may be displayed quicker.

With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check that voltage between ECM terminal 60 (fuel tank temperature sensor signal) and ground is less than 4.2V.
- 3) Drive vehicle at a speed of approximately 80 km/h (50 MPH) for 15 minutes.
- 4) Select "MODE 7" with GST.
- 5) If 1st trip DTC is detected, go to "DIAGNOSTIC PROCEDURE" on EC-501.

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check that voltage between ECM terminal 60 (fuel tank temperature sensor signal) and ground is less than 4.2V.
- 3) Drive vehicle at a speed of approximately 80 km/h (50 MPH) for 15 minutes.
- 4) Turn ignition switch OFF and wait at least 5 seconds.
- 5) Turn ignition switch ON and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "DIAGNOSTIC PROCEDURE" on next page.

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

KA24DE

Diagnostic Procedure

Diagnostic Procedure

=NGEC0371

| | | |
|-------------------------|--|--|
| 1 | CHECK RUBBER TUBE FOR CLOGGING | |
| | <p>Check obstructed water separator and rubber tube to EVAP canister vent control valve and clean the rubber tube using air blower.</p> <p>Check water separator.</p> <ol style="list-style-type: none"> 1. Check visually for insect nests in the water separator air inlet. 2. Check visually for cracks or flaws in the appearance. 3. Check visually for cracks or flaws in the hose. 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged. <div style="text-align: center;"> <p>* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> </div> <p>5. In case of NG in items 2 - 4, replace the parts.</p> <ul style="list-style-type: none"> ● Do not disassemble water separator. <p style="text-align: right;">SEF829T</p> | |
| | OK or NG | |
| OK (With CONSULT-II) | ▶ | GO TO 2. |
| OK (Without CONSULT-II) | ▶ | GO TO 3. |
| NG | ▶ | Clean, repair or replace rubber tube and/or water separator. |

GI

MA

EM

LC

EC

FE

CL

SEF829T

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)

| 2 | CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|-------------|--|----------------|-----|---------|--|----------------|---------|------------|------|-----------|-------|----------------|-------|--|--|--|--|--|--|-----------------------------|---|----|----|-----|-----|
| <p>Ⓟ With CONSULT-II Check air passage continuity. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.</p> <div style="text-align: right; margin-right: 50px;">  <p>EVAP canister vent control valve</p> </div> <div style="display: flex; justify-content: space-between; align-items: flex-start; margin-top: 20px;"> <div style="width: 25%;">  <p style="margin-left: 20px;">CONNECT </p> <p style="margin-left: 20px;">O-ring </p> <p style="margin-left: 20px;">A</p> <p style="margin-left: 20px;">B</p> </div> <div style="width: 20%; text-align: center;"> <table border="1" style="border-collapse: collapse; width: 100%;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>VENT CONTROL/V</td> <td>OFF</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS-RPM (REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td>XXX %</td> </tr> <tr> <td>THR TL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> </div> <div style="width: 45%; text-align: center;"> <table border="1" style="border-collapse: collapse; width: 100%;"> <thead> <tr> <th style="width: 50%;">Condition VENT CONTROL/V</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>No</td> </tr> <tr> <td>OFF</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> <div style="text-align: right; margin-top: 10px;">SEF143S</div> | | ACTIVE TEST | | VENT CONTROL/V | OFF | MONITOR | | CMPS-RPM (REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THR TL POS SEN | XXX V | | | | | | | Condition VENT CONTROL/V | Air passage continuity between A and B | ON | No | OFF | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | | | | | | |
| THR TL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition VENT CONTROL/V | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | No | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ GO TO 4. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ Replace EVAP canister vent control valve and O-ring. | | | | | | | | | | | | | | | | | | | | | | | | | | |

SEF172X

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)

3 CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

⊗ Without CONSULT-II
Check air passage continuity shown in the figure.

AEC783A

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| No supply | Yes |

MTBL0297

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.
If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Replace EVAP canister vent control valve and O-ring. |

4 CHECK IF EVAP CANISTER IS SATURATED WITH WATER

- Remove EVAP canister with EVAP canister vent control valve attached.
- Check if water will drain from the EVAP canister.

SEF596U

Yes or No

| | | |
|-----|---|----------|
| Yes | ▶ | GO TO 5. |
| No | ▶ | GO TO 7. |

5 CHECK EVAP CANISTER

Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG


| | | |
|----|---|----------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |

GI
MA
EM
LC
EC
FE
CL
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 6 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ol style="list-style-type: none"> 1. Visually check the EVAP canister for damage. 2. Check hose connection between EVAP canister and water separator for clogging and poor connection. 3. Check water separator. <ol style="list-style-type: none"> a. Check visually for insect nests in the water separator air inlet. b. Check visually for cracks or flaws in the appearance. c. Check visually for cracks or flaws in the hose. d. Check that A and C are not clogged by blowing air into B with A, and then C plugged. | |
|  <p style="text-align: center;">* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> | |
| <p>e. In case of NG in items 2 - 4, replace the parts.</p> <ul style="list-style-type: none"> ● Do not disassemble water separator. | |
| ▶ | Repair hose or replace EVAP canister or water separator. |

SEF829T

| | |
|--|---|
| 7 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE |
| <p>Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ Install hose properly or replace it. |

| | |
|--|--|
| 8 | CHECK HARNESS CONNECTOR |
| <ol style="list-style-type: none"> 1. Disconnect EVAP control system pressure sensor harness connector. 2. Check harness connector for water. Water should not exist. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 9. |
| NG | ▶ Replace EVAP control system pressure sensor. |

| | |
|--|--|
| 9 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT |
| <p>Refer to "DTC Confirmation Procedure", EC-385.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 10. |
| NG | ▶ Replace EVAP control system pressure sensor and repair or replace harness and connector. |

| | |
|---|------------------------------------|
| 10 | CHECK INTERMITTENT INCIDENT |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> | |
| ▶ | INSPECTION END |

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE


System Description

System Description

NGEC0373

NOTE:

If both DTC P0510 and P1447 are displayed, perform trouble diagnosis for “DTC P0510” first. (See EC-422.)



In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control solenoid valve is open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

On Board Diagnosis Logic

NGEC0374




Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a fault is determined.

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|---|--|
| P1447 0111 | <ul style="list-style-type: none"> ● EVAP control system does not operate properly. ● EVAP control system has a leak between intake manifold and EVAP control system pressure sensor. | <ul style="list-style-type: none"> ● EVAP canister purge volume control solenoid valve stuck closed ● EVAP control system pressure sensor and the circuit ● Loose, disconnected or improper connection of rubber tube ● Blocked rubber tube ● Blocked or bent rubber tube to MAP/BARO switch solenoid valve ● Cracked EVAP canister ● Closed throttle position switch ● Blocked purge port ● EVAP canister vent control valve |

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

On Board Diagnosis Logic (Cont'd)



DTC Confirmation Procedure

NGEC0375

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- For best results perform test at a temperature of 5°C (41°F) or more.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓟ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Start engine and let it idle for at least 60 seconds.
- 4) Select "PURG FLOW P1447" of "EVAPORATIVE SYSTEM" in "DTC CONFIRMATION" mode with CONSULT-II.
- 5) Touch "START".
If "COMPLETED" is displayed, go to step 7.
- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)

| | |
|----------------------------|-----------------------------|
| Selector lever | Suitable position |
| Vehicle speed | 32 - 120 km/h (20 - 75 MPH) |
| CMPS-RPM (POS) | 500 - 3,600 rpm |
| Engine coolant temperature | 70 - 100°C (158 - 212°F) |

If "TESTING" is not changed for a long time, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure".


Overall Function Check

NGEC0376

Use this procedure to check the overall monitoring function of the EVAP control system purge flow monitoring. During this check, a 1st trip DTC might not be confirmed.

ⓧ Without CONSULT-II

- 1) Lift up drive wheels.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Turn ignition switch OFF, wait at least 5 seconds.
- 4) Start engine and wait at least 60 seconds.
- 5) Set voltmeter probes to ECM terminals 62 (EVAP control system pressure sensor signal) and 43 (ground).



DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

Overall Function Check (Cont'd)

- 6) Check EVAP control system pressure sensor value at idle speed and note it.
- 7) Establish and maintain the following conditions for at least 1 minute.

- Air conditioner switch: ON**
- Steering wheel: Fully turned**
- Headlamp switch: ON**
- Rear window defogger switch: ON**
- Engine speed: Approx. 3,000 rpm**
- Gear position:**
Any position other than "Neutral" or "Reverse"

Verify that EVAP control system pressure sensor value stays 0.1V less than the value at idle speed (measured at step 6) for at least 1 second.

GI
MA
EM
LC
EC

FE
CL
MT

Diagnostic Procedure

NGEC0377

| | | | |
|--|----------------------------|------------------------|--|
| 1 | CHECK EVAP CANISTER | | |
| 1. Turn ignition switch OFF. 2. Check EVAP canister for cracks. | | | |
| OK or NG | | | |
| OK (With CONSULT-II) | ▶ | GO TO 2. | |
| OK (Without CONSULT-II) | ▶ | GO TO 3. | |
| NG | ▶ | Replace EVAP canister. | |

AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING


KA24DE

Diagnostic Procedure (Cont'd)

2 CHECK PURGE FLOW

Ⓟ With CONSULT-II

1. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge.



SEF339V

2. Start engine and let it idle.
3. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.

| ACTIVE TEST | |
|-----------------|---------|
| PURG VOL CONT/V | 0.0% |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 MNTR-B2 | LEAN |
| FR O2 MNTR-B1 | LEAN |
| A/F ALPHA-B2 | XXX % |
| A/F ALPHA-B1 | XXX % |
| THRTL POS SEN | XXX V |
| | |

PEF908U

4. Rev engine up to 2,000 rpm.
5. Touch "Qd" and "Qu" on CONSULT-II screen to adjust "PURG VOL CONT/V" opening.
 - 100.0%: Vacuum should exist.**
 - 0.0%: Vacuum should not exist.**

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 4. |

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

Diagnostic Procedure (Cont'd)

| | | | | | | | | | |
|----------|-------------------------|--|----|---|----------|----|---|----------|---|
| 3 | CHECK PURGE FLOW | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine. 3. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge. <div style="text-align: center; margin: 10px 0;"> <p style="font-size: small;">EVAP canister purge volume control solenoid valve harness connector</p> <p style="font-size: small;">Vehicle front</p> <p style="font-size: small;">EVAP service port</p> </div> <ol style="list-style-type: none"> 4. Start engine and let it idle for at least 60 seconds. 5. Check vacuum gauge indication when revving engine up to 2,000 rpm. Vacuum should exist. 6. Release the accelerator pedal fully and let idle. Vacuum should not exist. <p style="text-align: center; margin-top: 10px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table> | OK | ▶ | GO TO 8. | NG | ▶ | GO TO 4. | GI MA EM LC EC FE CL MT AT |
| OK | ▶ | GO TO 8. | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | |

SEF339V

| | | | | | | | | | |
|----------|------------------------------|---|----|---|----------|----|---|------------|---|
| 4 | CHECK EVAP PURGE LINE | <p>Check EVAP purge line for improper connection or disconnection. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair it.</td> </tr> </table> | OK | ▶ | GO TO 5. | NG | ▶ | Repair it. | TF PD AX SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 5. | | | | | | | |
| NG | ▶ | Repair it. | | | | | | | |


DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

Diagnostic Procedure (Cont'd)


5 CHECK EVAP PURGE HOSE AND PURGE PORT

1. Disconnect purge hoses connected to EVAP service port **A** and EVAP canister purge volume control solenoid valve **B**.



SEF367U

2. Blow air into each hose and EVAP purge port **C**.
3. Check that air flows freely.



SEF368U

OK or NG

| | | |
|-------------------------|---|--|
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | Repair or clean hoses and/or purge port. |

6 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓟ With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.
3. Check air passage continuity.

| ACTIVE TEST | |
|-----------------|---------|
| PURG VOL CONT/V | 0.0 % |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| FR O2 MNTR | RICH |
| A/F ALPHA | XXX % |
| THRTL POS SEN | XXX V |
| | |
| | |
| | |

| Condition PURG VOL CONT/V value | Air passage continuity between A and B |
|------------------------------------|---|
| 100.0% | Yes |
| 0.0% | No |

SEF175X



OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

Diagnostic Procedure (Cont'd)

| 7 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | |
|---|--|--|--|-----------|--|---|-----|-----------|----|
| <p> Without CONSULT-II Check air passage continuity.</p> | | | | | | | | | |
|  | | | | | | | | | |
| SEF660U | | | | | | | | | |
|  | | | | | | | | | |
| SEF661U | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Condition</th> <th style="padding: 5px;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">12V direct current supply between terminals</td> <td style="padding: 5px; text-align: center;">Yes</td> </tr> <tr> <td style="padding: 5px;">No supply</td> <td style="padding: 5px; text-align: center;">No</td> </tr> </tbody> </table> | | | | Condition | Air passage continuity between A and B | 12V direct current supply between terminals | Yes | No supply | No |
| Condition | Air passage continuity between A and B | | | | | | | | |
| 12V direct current supply between terminals | Yes | | | | | | | | |
| No supply | No | | | | | | | | |
| MTBL0303 | | | | | | | | | |
| OK or NG | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. | | | | | | | |


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

| | | | |
|---|---|------------|--|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE | | |
| <p>1. Turn ignition switch OFF. 2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.</p> | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 9. | |
| NG | ▶ | Repair it. | |

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|---|------------------------|---|--|
| 9 | CHECK CONNECTOR | | |
| <p>1. Disconnect EVAP control system pressure sensor harness connector.</p> <div style="text-align: center;"> <p>View with spare tire removed.</p>  <p>The diagram is a line drawing of the rear engine compartment area. It shows the EVAP canister, the EVAP control system pressure sensor, and the rear shock absorber (RH). An arrow labeled 'Vehicle front' points towards the left side of the diagram. The EVAP canister is located towards the front of the vehicle, and the pressure sensor is connected to it. The rear shock absorber is located towards the rear of the vehicle.</p> </div> | | | |
| <p>2. Check connectors for water. Water should not exist.</p> <p style="text-align: right;">SEF341V</p> | | | |
| OK or NG | | | |
| OK | | ▶ | GO TO 10. |
| NG | | ▶ | Replace EVAP control system pressure sensor. |

| | | | |
|--|--|---|--|
| 10 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT | | |
| <p>Refer to "DTC Confirmation Procedure" for DTC P0450, EC-385.</p> <p style="text-align: center;">OK or NG</p> | | | |
| OK (With CONSULT-II) | | ▶ | GO TO 11. |
| OK (Without CONSULT-II) | | ▶ | GO TO 12. |
| NG | | ▶ | Replace EVAP control system pressure sensor. |

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

Diagnostic Procedure (Cont'd)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

11 CHECK EVAP CANISTER VENT CONTROL VALVE


With CONSULT-II

Check air passage continuity.

Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.



SEF143S



| ACTIVE TEST | |
|----------------|---------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| FR O2 MNTR | RICH |
| A/F ALPHA | XXX % |
| THRTL POS SEN | XXX V |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|-----------------------------|---|
| ON | No |
| OFF | Yes |

SEF172X

OK or NG

OK ► GO TO 13.

NG ► Replace EVAP canister vent control valve.

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

KA24DE

Diagnostic Procedure (Cont'd)

| 12 | CHECK EVAP CANISTER VENT CONTROL VALVE | | | | | | |
|--|--|-----------|--|---|----|-----------|-----|
| <p> Without CONSULT-II Check air passage continuity shown in the figure.</p> | | | | | | | |
| | | | | | | | |
| AEC783A | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">No</td> </tr> <tr> <td>No supply</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | | Condition | Air passage continuity between A and B | 12V direct current supply between terminals 1 and 2 | No | No supply | Yes |
| Condition | Air passage continuity between A and B | | | | | | |
| 12V direct current supply between terminals 1 and 2 | No | | | | | | |
| No supply | Yes | | | | | | |
| MTBL0297 | | | | | | | |
| <p>If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary. If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.</p> | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ GO TO 13. | | | | | | |
| NG | ▶ Replace EVAP canister vent control valve. | | | | | | |

| | |
|--|------------------------------|
| 13 | CHECK EVAP PURGE LINE |
| Inspect EVAP purge line (pipe and rubber tube). Check for evidence of leaks. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-36. | |
| OK or NG | |
| OK | ▶ GO TO 14. |
| NG | ▶ Replace it. |


| | |
|--|------------------------------|
| 14 | CLEAN EVAP PURGE LINE |
| Clean EVAP purge line (pipe and rubber tube) using air blower. | |
| ▶ | GO TO 15. |

| | |
|---|------------------------------------|
| 15 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| ▶ | INSPECTION END |


DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

KA24DE

Component Description



SEF378Q



SEF143S

Component Description

NGEC0379

NOTE:

If DTC P1448 is displayed with P0440 or P1440, perform trouble diagnosis for DTC P1448 first.

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0380

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|---------------|
| VENT CONT/V | ● Ignition switch: ON | OFF |

ECM Terminals and Reference Value

NGEC0381

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|----------------------------------|------------------------|----------------------------|
| 108 | R/G | EVAP canister vent control valve | [Ignition switch "ON"] | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0382

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|------------|---|---|
| P1448 0309 | ● EVAP canister vent control valve remains opened under specified driving conditions. | <ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water. ● Vacuum cut valve |

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

KA24DE

On Board Diagnosis Logic (Cont'd)

5

EVAP V/S LEAK P0440

1)PERFORM TEST AT A LOCATION OF 0-30C (32-86F)
 2)OPEN ENGINE HOOD.
 3)START ENGINE WITH VEHICLE STOPPED. IF ENG IS ON, STOP FOR 5 SEC. THEN RESTART.
 4)TOUCH START.

PEF405W

5

EVAP SML LEAK P0440

WAIT
 2 TO 10 MINUTES
 KEEP ENGINE RUNNING AT IDLE SPEED.

PEF929V

5

EVAP SML LEAK P0440

CAN NOT BE DIAGNOSED

FUEL TEMPERATURE IS TOO HIGH. RETEST AFTER FUEL HAS COOLED.

PEF669U

6

EVAP SML LEAK P0440

OK

PEF297U

DTC Confirmation Procedure

NGEC0383

NOTE:

- If DTC P1448 is displayed with P0440 or P1440, perform trouble diagnosis for DTC P1448 first.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

TESTING CONDITION:

- Perform “DTC WORK SUPPORT” when the fuel level is less than 3/4 full and vehicle is placed on flat level surface.
 - Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
- 1) Turn ignition switch ON.
 - 2) Turn ignition switch OFF and wait at least 5 seconds.
 - 3) Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
 - 4) Check that the following conditions are met.

| | |
|---------------|-----------------------|
| COOLAN TEMP/S | 0 - 70°C (32 - 158°F) |
| INT/A TEMP SE | 0 - 60°C (32 - 140°F) |

- 5) Select “EVAP SML LEAK P0440” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II. Follow the instruction displayed.

NOTE:

- If the CONSULT-II screen shown at left is displayed, stop the engine and stabilize the vehicle temperature at 25°C (77°F) or cooler. After “TANK F/TMP SE” becomes less than 30°C (86°F), retest. (Use a fan to reduce the stabilization time.)
 - If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to “Basic Inspection”, EC-95.
 - The engine idle portion of this test (See illustration at left.) will take approximately 5 minutes.
- 6) Make sure that “OK” is displayed. If “NG” is displayed, go to following step.

NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

- 7) Stop engine and wait at least 5 seconds, then turn “ON”.
- 8) Disconnect hose from water separator.
- 9) Select “VENT CONTROL/V” of “ACTIVE TEST” mode with CONSULT-II.
- 10) Touch “ON” and “OFF” alternately.

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

KA24DE

DTC Confirmation Procedure (Cont'd)

10

| ACTIVE TEST | |
|----------------|--------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B1 | XXX% |
| THRTL POS SEN | XXXV |
| | |
| | |
| | |

SEF157X

11) Make sure of the following.

| Condition | Air passage continuity between A and B |
|----------------|--|
| Touching "ON" | No |
| Touching "OFF" | Yes |

If the result is NG, go to "Diagnostic Procedure", EC-518.
If the result is OK, go to "Diagnostic Procedure" for DTC P0440, EC-354.

AEC783A

Overall Function Check

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a DTC might not be confirmed.

Without CONSULT-II

- 1) Disconnect hose from water separator.
- 2) Disconnect EVAP canister vent control valve harness connector.
- 3) Verify the following.

| Condition | Air passage continuity |
|---|------------------------|
| 12V direct current supply between terminals 1 and 2 | No |
| No supply | Yes |

If the result is NG, go to "Diagnostic Procedure", EC-518.
If the result is OK, perform trouble diagnosis for DTC P0440. Refer to EC-351.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)



KA24DE

Diagnostic Procedure

Diagnostic Procedure

NGEC0385

| | | |
|---|--------------------------|------------------------------|
| 1 | CHECK RUBBER TUBE | |
| 1. Turn ignition switch OFF. 2. Check disconnection or obstruction of rubber tube connected to EVAP canister vent control valve. | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 2. |
| OK (Without CONSULT-II) | ▶ | GO TO 3. |
| NG | ▶ | Repair or clean rubber tube. |

| 2 | CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|--|-------------|--|----------------|-----|---------|--|----------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|-----------------------------|---|----|----|-----|-----|
| Ⓟ With CONSULT-II Check air passage continuity. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  <p style="text-align: center;">EVAP canister vent control valve</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF143S | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;">  </div> <div style="width: 30%;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>VENT CONTROL/V</td> <td>OFF</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS-RPM (REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> </div> <div style="width: 30%;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Condition VENT CONTROL/V</th> <th>Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>No</td> </tr> <tr> <td>OFF</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> | | | ACTIVE TEST | | VENT CONTROL/V | OFF | MONITOR | | CMPS-RPM (REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | | Condition VENT CONTROL/V | Air passage continuity between A and B | ON | No | OFF | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition VENT CONTROL/V | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | No | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF172X | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace EVAP canister vent control valve and O-ring. | | | | | | | | | | | | | | | | | | | | | | | | | | |

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)


KA24DE

Diagnostic Procedure (Cont'd)

3 CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

⊗ Without CONSULT-II

Check air passage continuity shown in the figure.



AEC783A

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| No supply | Yes |

MTBL0297

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Replace EVAP canister vent control valve and O-ring. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL


IDX

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

KA24DE

Diagnostic Procedure (Cont'd)

| | | | | | | | | |
|----------|-------------------------------|--|----|---|----------|----|---|---------------------------|
| 4 | CHECK VACUUM CUT VALVE | <p>Check vacuum cut valve as follows:</p> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF186S</p> <p style="text-align: right;">SEF379Q</p> <ol style="list-style-type: none"> 1. Plug port C and D with fingers. 2. Apply vacuum to port A and check that there is no suction from port B. 3. Apply vacuum to port B and check that there is suction from port A. 4. Blow air in port B and check that there is a resistance to flow out of port A. 5. Open port C and D. 6. Blow air in port A check that air flows freely out of port C. 7. Blow air in port B check that air flows freely out of port D. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace vacuum cut valve.</td> </tr> </table> | OK | ▶ | GO TO 5. | NG | ▶ | Replace vacuum cut valve. |
| OK | ▶ | GO TO 5. | | | | | | |
| NG | ▶ | Replace vacuum cut valve. | | | | | | |


| | | | | | | | | |
|----------|---|--|-----|---|----------|----|---|----------|
| 5 | CHECK IF EVAP CANISTER IS SATURATED WITH WATER | <ol style="list-style-type: none"> 1. Remove EVAP canister with the vent control valve attached. 2. Check if water will drain from the EVAP canister. <div style="text-align: center;">  </div> <p style="text-align: right;">SEF596U</p> <p style="text-align: center;">Yes or No</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Yes</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>No</td> <td style="text-align: center;">▶</td> <td>GO TO 6.</td> </tr> </table> | Yes | ▶ | GO TO 8. | No | ▶ | GO TO 6. |
| Yes | ▶ | GO TO 8. | | | | | | |
| No | ▶ | GO TO 6. | | | | | | |

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|----------------------------|----------|
| 6 | CHECK EVAP CANISTER | |
| Weigh the EVAP canister with EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0lb). | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

| | | |
|--|-----------------------------------|--|
| 7 | DETECT MALFUNCTIONING PART | |
| Check the following. | | |
| <ol style="list-style-type: none"> 1. Visually check the EVAP canister for damage. 2. Check hose connection between EVAP canister and water separator for clogging and poor connection. 3. Check water separator. <ol style="list-style-type: none"> a. Check visually for insect nests in the water separator air inlet. b. Check visually for cracks or flaws in the appearance. c. Check visually for cracks or flaws in the hose. d. Check that A and C are not clogged by blowing air into B with A, and then C plugged. | | |
|  | | |
| <p>* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> | | |
| SEF829T | | |
| e. In case of NG in items 2 - 4, replace the parts. | | |
| ● Do not disassemble water separator. | | |
| | | ▶ Repair hose or replace EVAP canister or water separator. |

| | | |
|--|---|--------------------------------------|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE | |
| Check disconnection or improper connection of hose connected to EVAP control system pressure sensor. | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Install hose property or replace it. |

| | | |
|--|--------------------------------|--|
| 9 | CHECK HARNESS CONNECTOR | |
| <ol style="list-style-type: none"> 1. Disconnect EVAP control system pressure sensor harness connector. 2. Check harness connector for water. Water should not exist. | | |
| OK or NG | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

KA24DE


Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 10 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR |
| Perform "DTC Confirmation Procedure", EC-385. | |
| OK or NG | |
| OK | ▶ GO TO 11. |
| NG | ▶ Replace EVAP control system pressure sensor and repair or replace harness and connector. |

| | |
|--|------------------------------------|
| 11 | CHECK INTERMITTENT INCIDENT |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| | ▶ INSPECTION END |

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) KA24DE

Description



Description

NGEC0387

COMPONENT DESCRIPTION

NGEC0387S01

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

EVAPORATIVE EMISSION SYSTEM DIAGRAM

NGEC0387S02



CONSULT-II Reference Value in Data Monitor Mode

NGEC0388

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|-----------------------|---------------|
| VC/V BYPASS/V | ● Ignition switch: ON | OFF |

ECM Terminals and Reference Value

NGEC0389

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|-------------------------------|----------------------|----------------------------|
| 120 | P/B | Vacuum cut valve bypass valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) KA24DE

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0390

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|--|
| P1490 0801 | <ul style="list-style-type: none"> An improper voltage signal is sent to ECM through vacuum cut valve bypass valve. | <ul style="list-style-type: none"> Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted.) Vacuum cut valve bypass valve |

DTC Confirmation Procedure


NGEC0391

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.



With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-526.

With GST

Follow the procedure "With CONSULT-II".

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) KA24DE

Wiring Diagram

Wiring Diagram

NGEC0392

EC-BYPS/V-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC




EL

IDX




Refer to "EL-POWER".

— : Detectable line for DTC
 — : Non-detectable line for DTC



Refer to the following.
 M65, E43 - SUPER
 MULTIPLE JUNCTION (SMJ)



AEC007B

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) KA24DE

Diagnostic Procedure

Diagnostic Procedure



NGEC0393

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

| 2 | CHECK VACUUM CUT VALVE BYPASS VALVE CIRCUIT | | | | | | | | | | | | | | | | | | | | | |
|---|--|----------|-------------|--|---------------|--|---------|--|---------------|---------|------------|------|-----------|-------|---------------|-------|--|--|--|--|--|--|
| <p>1. Turn ignition switch ON.</p> <p>2. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <td>VC/V BYPASS/V</td> <td></td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS~RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table> | | | ACTIVE TEST | | VC/V BYPASS/V | | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR | RICH | A/F ALPHA | XXX % | THRTL POS SEN | XXX V | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| VC/V BYPASS/V | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| PEF364U | | | | | | | | | | | | | | | | | | | | | | |
| 3. Make sure that clicking sound is heard from the vacuum cut valve bypass valve. | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 3. | | | | | | | | | | | | | | | | | | | | |

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) KA24DE

Diagnostic Procedure (Cont'd)

| | | | | | | | | | |
|---|---------------------------|--|---|----------|----|---|----------|--|-----------|
| 3 | CHECK POWER SUPPLY | <p>1. Turn ignition switch OFF. 2. Disconnect vacuum cut valve bypass valve harness connector.</p> <div style="text-align: center;">  </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table> | | OK | ▶ | GO TO 5. | NG | ▶ | GO TO 4. | | <p>AX</p> |
| OK | ▶ | GO TO 5. | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | |

| | | | | | | |
|----------|-----------------------------------|---|--|---|-------------------------------|--|
| 4 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M67, B101 ● Harness connectors B113, C3 ● 10A fuse ● Harness for open or short between vacuum cut valve bypass valve and 10A fuse <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 15%;"></td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">Repair harness or connectors.</td> </tr> </table> | | ▶ | Repair harness or connectors. | <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| | ▶ | Repair harness or connectors. | | | | |

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|------------------------------------|
| 5 | CHECK OUTPUT SIGNAL CIRCUIT |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 120 and terminal 1.</p> | |
| | |
| SEF253V | |
| <p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 7. |
| NG | ▶ GO TO 6. |

| | |
|---|--|
| 6 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M67, B101 ● Harness connectors B113, C3 ● Harness for open or short between vacuum cut valve bypass valve and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |


DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT) KA24DE

Diagnostic Procedure (Cont'd)

7 CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II

Check air passage continuity.
Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.




| ACTIVE TEST | |
|----------------|---------|
| VC/V BYPASS/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| FR O2 MNTR | RICH |
| A/F ALPHA | XXX % |
| THRTL POS SEN | XXX V |
| | |
| | |
| | |

| Condition VC/V BYPASS/V | Air passage continuity between A and B |
|----------------------------|---|
| ON | Yes |
| OFF | No |

SEF171X

Without CONSULT-II

Check air passage continuity shown in the figure.



| Condition | Air passage continuity between A and B |
|---|---|
| 12V direct current supply between terminals | Yes |
| No supply | No |

SEF351Q

MTBL0303

If NG or operation takes more than 1 second, replace vacuum cut valve bypass valve.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace vacuum cut valve bypass valve. |


8 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.

▶ **INSPECTION END**

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Description



Description

COMPONENT DESCRIPTION

NGEC0395

NGEC0395S01

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

EVAPORATIVE EMISSION SYSTEM DIAGRAM

NGEC0395S02



CONSULT-II Reference Value in Data Monitor Mode

NGEC0396

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|-----------------------|---------------|
| VC/V BYPASS/V | ● Ignition switch: ON | OFF |

ECM Terminals and Reference Value

NGEC0397

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|-------------------------------|----------------------|----------------------------|
| 120 | P/B | Vacuum cut valve bypass valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0398

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P1491 0311 | Vacuum cut valve bypass valve does not operate properly. | <ul style="list-style-type: none"> ● Vacuum cut valve bypass valve ● Vacuum cut valve ● Bypass hoses for clogging ● EVAP control system pressure sensor ● EVAP canister vent control valve ● Hose between fuel tank and vacuum cut valve clogged ● Hose between vacuum cut valve and EVAP canister clogged ● EVAP canister ● EVAP purge port of fuel tank for clogging |

GI
MA
EM
LC
EC

7

| | |
|---------------------|----------|
| VC CUT/V BP/V P1491 | |
| OUT OF CONDITION | |
| MONITOR | |
| CMPS~RPM(POS) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF618W

7

| | |
|---------------------|----------|
| VC CUT/V BP/V P1491 | |
| TESTING | |
| MONITOR | |
| CMPS~RPM(POS) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF619W

7

| | |
|---------------------|--|
| VC CUT/V BP/V P1491 | |
| COMPLETED | |

PEF912U

DTC Confirmation Procedure

NGEC0399

CAUTION:
Always drive vehicle at a safe speed.

NOTE:
If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform test at a temperature of 5 to 30°C (41 to 86°F).
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓟ **With CONSULT-II**


- 1) Turn ignition switch ON.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Turn ignition switch OFF and wait at least 5 seconds.
- 4) Start engine and let it idle for at least 60 seconds.
- 5) Select "VC CUT/V BP/V P1491" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 6) Touch "START".
- 7) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)

| | |
|----------------|-----------------------------|
| CMPS-RPM (POS) | 1,000 - 3,200 rpm |
| Selector lever | Suitable position |
| Vehicle speed | 36 - 120 km/h (22 - 75 MPH) |
| B/FUEL SCHDL | Less than 4.5 msec |

FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

If "TESTING" is not displayed after 5 minutes, retry from step 3.

- 8) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure".



Overall Function Check

Use this procedure to check the overall function of vacuum cut valve bypass valve. During this check, the 1st trip DTC might not be confirmed.

NGEC0400


⊗ Without CONSULT-II

1. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Supply battery voltage to the terminal.
6. Blow air in port **A** and check that air flows freely out of port **B**.
7. Blow air in port **B** and check that air flows freely out of port **A**.
8. If NG, go to "DIAGNOSTIC PROCEDURE" on EC-534.

Wiring Diagram


NGEC0505

EC-BYPS/V-01






Refer to "EL-POWER".
 — : Detectable line for DTC
 — : Non-detectable line for DTC

- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST



Refer to the following.
 M65, E43 - SUPER
 MULTIPLE JUNCTION (SMJ)




- RS
- BT
- HA
- SC
- EL
- IDX


Diagnostic Procedure

NGENC0401

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

| 2 | CHECK COMPONENT | | | | | | | | | | | | | | | | | | | |
|--|------------------------|----------|-------------|--|---------------|----|---------|--|---------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|
| <p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly. 3. Apply vacuum to port A and check that there is no suction from port B. 4. Apply vacuum to port B and check that there is suction from port A. 5. Blow air in port B and check that there is a resistance to flow out of port A. 6. Turn ignition switch ON. 7. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II and touch "ON". 8. Blow air in port A and check that air flows freely out of port B. 9. Blow air in port B and check that air flows freely out of port A. | | | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>VC/V BYPASS/V</th> <th>ON</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> </thead> <tbody> <tr> <td>CMPS~RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR-B2</td> <td>LEAN</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td>LEAN</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XXX %</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> </tbody> </table> | | | ACTIVE TEST | | VC/V BYPASS/V | ON | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR-B2 | LEAN | FR O2 MNTR-B1 | LEAN | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | |
| VC/V BYPASS/V | ON | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | LEAN | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | LEAN | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 5. | | | | | | | | | | | | | | | | | | |

PEF913U

| | | | |
|----------|------------------------|---|--|
| 3 | CHECK COMPONENT | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly. 3. Apply vacuum to port A and check that there is no suction from port B. 4. Apply vacuum to port B and check that there is suction from port A. 5. Blow air in port B and check that there is a resistance to flow out of port A. 6. Disconnect vacuum cut valve bypass valve harness connector. 7. Supply battery voltage to the terminal. 8. Blow air in port A and check that air flows freely out of port B. 9. Blow air in port B and check that air flows freely out of port A. <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">SEF914U</p> | |
| | | OK or NG | |
| OK | ▶ | GO TO 4. | |
| NG | ▶ | GO TO 5. | |

| | | | |
|-------------|------------------------------|--|--|
| 4 | CHECK EVAP PURGE LINE | <ol style="list-style-type: none"> 1. Check EVAP purge line between EVAP canister and fuel tank for clogging or disconnection. 2. Check EVAP purge port of fuel tank for clogging. 3. Check EVAP canister. Refer to EC-34. <p style="text-align: center; margin: 10px 0;">OK or NG</p> | |
| OK | ▶ | GO TO 8. | |
| NG (Step 1) | ▶ | Repair it. | |
| NG (Step 2) | ▶ | Clean EVAP purge port. | |
| NG (Step 3) | ▶ | Replace EVAP canister. | |

| | | | |
|----------|--------------------------|--|--|
| 5 | CHECK BYPASS HOSE | <p>Check bypass hoses for clogging.</p> <p style="text-align: center; margin: 10px 0;">OK or NG</p> | |
| OK | ▶ | GO TO 6. | |
| NG | ▶ | Repair or replace hoses. | |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

6 CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II

Check air passage continuity.
Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.

| ACTIVE TEST | |
|---------------|---------|
| VC/V BYPASS/V | OFF |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 MNTR | RICH |
| A/F ALPHA | XXX % |
| THRTL POS SEN | XXX V |
| | |
| | |
| | |


PEF395V

| Condition VC/V BYPASS/V | Air passage continuity between A and B |
|----------------------------|---|
| ON | Yes |
| OFF | No |

MTBL0304

Without CONSULT-II

Check air passage continuity shown in the figure.



SEF351Q



| Condition | Air passage continuity between A and B |
|---|---|
| 12V direct current supply between terminals | Yes |
| No supply | No |

MTBL0303

If NG or operation takes more than 1 second, replace vacuum cut valve bypass valve.


OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace vacuum cut valve bypass valve. |

| | | | | | | | | |
|----------|-------------------------------|--|----|---|----------|----|---|---------------------------|
| 7 | CHECK VACUUM CUT VALVE | <p>Check vacuum cut valve as follows:</p> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF186S</p> <p style="text-align: right;">SEF379Q</p> <ol style="list-style-type: none"> 1. Plug port C and D with fingers. 2. Apply vacuum to port A and check that there is no suction from port B. 3. Apply vacuum to port B and check that there is suction from port A. 4. Blow air in port B and check that there is a resistance to flow out of port A. 5. Open port C and D. 6. Blow air in port A check that air flows freely out of port C. 7. Blow air in port B check that air flows freely out of port D. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace vacuum cut valve.</td> </tr> </table> | OK | ▶ | GO TO 8. | NG | ▶ | Replace vacuum cut valve. |
| OK | ▶ | GO TO 8. | | | | | | |
| NG | ▶ | Replace vacuum cut valve. | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | | | | | | | |
|----------|---|--|----|---|----------|----|---|-----------|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair it</td> </tr> </table> | OK | ▶ | GO TO 9. | NG | ▶ | Repair it |
| OK | ▶ | GO TO 9. | | | | | | |
| NG | ▶ | Repair it | | | | | | |

| | | | |
|----------|------------------------|---|--|
| 9 | CHECK CONNECTOR | <p>1. Disconnect EVAP control system pressure sensor harness connector.</p> <div style="text-align: center;"> <p>View with spare tire removed.</p>  </div> <p style="text-align: right;">SEF341V</p> | |
| | | <p>2. Check connectors for water. Water should not exist.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | | ▶ | GO TO 10. |
| NG | | ▶ | Replace EVAP control system pressure sensor. |


| | | | |
|-------------------------|------------------------------------|--|--|
| 10 | CHECK COMPONENT AND CIRCUIT | <p>(EVAP control system pressure sensor) Refer to "DTC Confirmation Procedure" for DTC P0450, EC-385.</p> <p style="text-align: center;">OK or NG</p> | |
| OK (With CONSULT-II) | | ▶ | GO TO 11. |
| OK (Without CONSULT-II) | | ▶ | GO TO 12. |
| NG | | ▶ | Replace EVAP control system pressure sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


11 CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

Check air passage continuity.
Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.



SEF143S



| ACTIVE TEST | |
|----------------|---------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXX rpm |
| FR O2 MNTR | RICH |
| A/F ALPHA | XXX % |
| THRTL POS SEN | XXX V |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|-----------------------------|---|
| ON | No |
| OFF | Yes |

SEF172X

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 13. |
| NG | ▶ | Replace EVAP canister vent control valve. |


| 12 | CHECK EVAP CANISTER VENT CONTROL VALVE | | | | | | |
|--|--|---|--|---|----|-----------|-----|
| <p> Without CONSULT-II Check air passage continuity shown in the figure.</p> | | | | | | | |
| | | | | | | | |
| AEC783A | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">No</td> </tr> <tr> <td>No supply</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | | Condition | Air passage continuity between A and B | 12V direct current supply between terminals 1 and 2 | No | No supply | Yes |
| Condition | Air passage continuity between A and B | | | | | | |
| 12V direct current supply between terminals 1 and 2 | No | | | | | | |
| No supply | Yes | | | | | | |
| MTBL0297 | | | | | | | |
| <p>If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary. If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.</p> | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ | GO TO 13. | | | | | |
| NG | ▶ | Replace EVAP canister vent control valve. | | | | | |

| | | |
|---|------------------------------------|----------------|
| 13 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| | ▶ | INSPECTION END |

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

KA24DE

Component Description



Component Description

When the gear position is "N", park/neutral position (PNP) switch is "ON".
ECM detects the park/neutral position when continuity with ground exists.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

NGEC0425

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|------------------------|
| P/N POSI SW | ● Ignition switch: ON | Shift lever: "N" ON |
| | | Except above OFF |

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

NGEC0426

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|------------|---|-------------------|
| 22 | L/B | PNP switch | [Ignition switch "ON"] ● Gear position is "Neutral position" | Approximately 0V |
| | | | [Ignition switch "ON"] ● Except the above gear position | Approximately 5V |

On Board Diagnosis Logic

NGEC0427

| DTC No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|---------------|--|---|
| P1706 1003 | ● The signal of the PNP switch is not changed in the process of engine starting and driving. | ● Harness or connectors (The PNP switch circuit is open or shorted.) ● PNP switch |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC Confirmation Procedure

=NGEC0428

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

④ With CONSULT-II

1) Turn ignition switch ON.

5

| DATA MONITOR | |
|------------------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) XXX rpm | |
| COOLAN TEMP/S XXX °C | |
| VHCL SPEED SE XXX km/h | |
| P/N POSI SW OFF | |
| B/FUEL SCHDL XXX msec | |

PEF726W

2) Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.

| Position (Selector lever) | Known good signal |
|---------------------------|-------------------|
| "N" | ON |
| Except the above position | OFF |

If NG, go to "Diagnostic Procedure", EC-545.

If OK, go to following step.

3) Select "DATA MONITOR" mode with CONSULT-II.

4) Start engine and warm it up to normal operating temperature.

5) Maintain the following conditions for at least 60 consecutive seconds.


| | |
|----------------|-----------------------------|
| CMPS-RPM (REF) | 1,800 - 3,200 rpm |
| COOLAN TEMP/S | More than 70°C (158°F) |
| B/FUEL SCHDL | 1.0 - 5.3 msec |
| VHCL SPEED SE | 70 - 100 km/h (43 - 62 MPH) |
| Selector lever | Suitable position |

6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-545.

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

KA24DE

Overall Function Check



Overall Function Check

Use this procedure to check the overall function of the park/neutral position switch circuit. During this check, a 1st trip DTC might not be confirmed. =NGEC0429

⊗ Without CONSULT-II

- 1) Turn ignition switch ON.
- 2) Check voltage between ECM terminal 22 (PNP switch signal) and body ground under the following conditions.

| Condition (Gear position) | Voltage (V) (Known good data) |
|---------------------------|-------------------------------|
| "N" position | Approx. 0 |
| Except the above position | Approx. 5 |

- 3) If NG, go to "Diagnostic Procedure", EC-545.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX


Wiring Diagram

NGEC0430


EC-PNP/SW-01



: Detectable line for DTC
 : Non-detectable line for DTC





Refer to the following.
 (M65) (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)



Diagnostic Procedure For M/T Models

NGE0431

| | | | |
|----------|-----------------------------|--|---------|
| 1 | CHECK GROUND CIRCUIT | | |
| | | 1. Turn ignition switch OFF. 2. Disconnect PNP switch harness connector. | |
| | |  <p>Park/neutral position (PNP) switch</p> | AEC877A |
| | | 3. Check harness continuity between terminal 2 and body ground. | |
| | |  | SEF218V |
| | | <p>Continuity should exist.</p> 4. Also check harness for short to ground and short to power. | |
| | | OK or NG | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | GO TO 2. | |

| | | | |
|----------|-----------------------------------|---|--|
| 2 | DETECT MALFUNCTIONING PART | | |
| | | Check the following. <ul style="list-style-type: none"> ● Harness connectors E33, E201 ● Harness for open or short between PNP switch and body ground | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

 GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

| | | | |
|---|-----------------------------------|----------|--|
| 3 | CHECK INPUT SIGNAL CIRCUIT | | |
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 22 and terminal 1.</p> | | | |
| | | | |
| SEF219V | | | |
| <p style="color: blue;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | | |
| OK | ▶ | GO TO 5. | |
| NG | ▶ | GO TO 4. | |

| | | | |
|--|-----------------------------------|---|--|
| 4 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F36, M81 ● Harness connectors M65, E43 ● Harness connectors E33, E201 ● Harness for open or short between ECM and PNP switch | | | |
| | | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | | |
|------------------------|-------------------------|---------------------|--|
| 5 | CHECK PNP SWITCH | | |
| Refer to MT-8 . | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 6. | |
| NG | ▶ | Replace PNP switch. | |

| | | | |
|--|------------------------------------|---|-----------------------|
| 6 | CHECK INTERMITTENT INCIDENT | | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | | |
| | | ▶ | INSPECTION END |

On Board Diagnosis Logic

NGEC0488


If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.
When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

| Diagnostic Trouble Code No. | Malfunction is detected when ... | Check Items (Possible Cause) |
|-----------------------------|--|--|
| OVERHEAT 0208 | <ul style="list-style-type: none"> ● Engine coolant temperature reaches an abnormally high temperature. | <ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted.) ● Cooling fan ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", EC-551.</p> |

CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- 1) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED FLUIDS AND LUBRICANTS").
- 2) After refilling coolant, run engine to ensure that no water-flow noise is emitted.



Overall Function Check

NGEC0489

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.


Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.


Ⓜ With CONSULT-II


- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-548.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-548.

Diagnostic Procedure

NGE0491


| | | |
|--|--------------------------------------|---|
| 1 | CHECK COOLING SYSTEM FOR LEAK | |
| Apply pressure to the cooling system with a tester, and check if the pressure drops. Testing pressure: 157 kPa (1.6 kg/cm², 23 psi) CAUTION: Higher than the specified pressure may cause radiator damage. | | |
|  | | |
| SLC754A | | |
| Pressure should not drop. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Check the following for leak. <ul style="list-style-type: none"> ● Hose ● Radiator ● Water pump Refer to LC section ("Water Pump"). |

| | | |
|---|---------------------------|-----------------------|
| 2 | CHECK RADIATOR CAP | |
| Apply pressure to cap with a tester. | | |
|  | | |
| SLC755A | | |
| Radiator cap relief pressure: 78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi) | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Replace radiator cap. |

| | | | | |
|----------|-------------------------|---|---|--|
| 3 | CHECK THERMOSTAT | <p>1. Check valve seating condition at normal room temperatures. It should seat tightly.</p> <p>2. Check valve opening temperature and valve lift.</p> <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: right; margin-right: 20px;">SLC343</p> <p>Valve opening temperature: 76.5°C (170°F) [standard]</p> <p>Valve lift: More than 8 mm/90°C (0.31 in/194°F)</p> <p>3. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC section ("Thermostat").</p> <p style="text-align: center; margin-top: 20px;">OK or NG</p> | GI MA EM LC <div style="background-color: black; color: white; padding: 5px; font-weight: bold;">EC</div> FE CL MT AT TF PD AX SU BR ST RS BT HA SC EL IDX | |
| | OK | ▶ | GO TO 4. | |
| | NG | ▶ | Replace thermostat | |

4 CHECK ENGINE COOLANT TEMPERATURE SENSOR


Check resistance as shown in the figure.



<Reference data>

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.1 - 2.9 |
| 50 (122) | 0.68 - 1.00 |
| 90 (194) | 0.236 - 0.260 |

SEF152P



MTBL0285

SEF012P

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace engine coolant temperature sensor. |

5 CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-551.

▶ **INSPECTION END**

Perform FINAL CHECK by the following procedure after repair is completed.

1. Warm up engine. Run the vehicle for at least 20 minutes. Pay attention to engine coolant temperature gauge on the instrument panel. If the reading shows an abnormally high temperature, another part may be malfunctioning.
2. Stop vehicle and let engine idle. Check the intake and exhaust systems for leaks by listening for noise or visually inspecting the components.
3. Allow engine to cool and visually check for oil and coolant leaks. Then, perform "OVERALL FUNCTION CHECK".

TROUBLE DIAGNOSIS FOR OVERHEAT

KA24DE

Main 11 Causes of Overheating

Main 11 Causes of Overheating

NGEC0492

| Engine | Step | Inspection item | Equipment | Standard | Reference page |
|--------|------|--|--|---|---|
| OFF | 1 | <ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper | <ul style="list-style-type: none"> Visual | No blocking | — |
| | 2 | <ul style="list-style-type: none"> Coolant mixture | <ul style="list-style-type: none"> Coolant tester | 50 - 50% coolant mixture | See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section. |
| | 3 | <ul style="list-style-type: none"> Coolant level | <ul style="list-style-type: none"> Visual | Coolant up to MAX level in reservoir tank and radiator filler neck | See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section. |
| | 4 | <ul style="list-style-type: none"> Radiator cap | <ul style="list-style-type: none"> Pressure tester | 78 - 98 kPa (0.8 - 1.0 kg/cm ² , 11 - 14 psi) 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit) | See "System Check", "ENGINE COOLING SYSTEM" in LC section. |
| ON*2 | 5 | <ul style="list-style-type: none"> Coolant leaks | <ul style="list-style-type: none"> Visual | No leaks | See "System Check", "ENGINE COOLING SYSTEM" in LC section. |
| ON*2 | 6 | <ul style="list-style-type: none"> Thermostat | <ul style="list-style-type: none"> Touch the upper and lower radiator hoses | Both hoses should be hot | See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section. |
| OFF | 7 | <ul style="list-style-type: none"> Combustion gas leak | <ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer | Negative | — |
| ON*3 | 8 | <ul style="list-style-type: none"> Coolant temperature gauge | <ul style="list-style-type: none"> Visual | Gauge less than 3/4 when driving | — |
| | | <ul style="list-style-type: none"> Coolant overflow to reservoir tank | <ul style="list-style-type: none"> Visual | No overflow during driving and idling | See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section. |
| OFF*4 | 9 | <ul style="list-style-type: none"> Coolant return from reservoir tank to radiator | <ul style="list-style-type: none"> Visual | Should be initial level in reservoir tank | See "ENGINE MAINTENANCE" in MA section. |
| OFF | 10 | <ul style="list-style-type: none"> Cylinder head | <ul style="list-style-type: none"> Straight gauge feeler gauge | 0.1 mm (0.004 in) Maximum distortion (warping) | See "Inspection", "CYLINDER HEAD" in EM section. |
| | 11 | <ul style="list-style-type: none"> Cylinder block and pistons | <ul style="list-style-type: none"> Visual | No scuffing on cylinder walls or piston | See "Inspection", "CYLINDER BLOCK" in EM section. |

*1: Turn the ignition switch ON.


*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.

Component Description



Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.

NGEC0435

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

NGEC0437

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------|---|--|
| 102 | W/B | Injector No. 1 | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | BATTERY VOLTAGE (11 - 14V) SEF011W |
| 104 | W/R | Injector No. 3 | | |
| 109 | W/L | Injector No. 2 | | |
| 111 | W/PU | Injector No. 4 | | |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm | BATTERY VOLTAGE (11 - 14V) SEF012W |





INJECTOR

KA24DE
Wiring Diagram

Wiring Diagram

NGEC0434

EC-INJECT-01




AEC009B

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Diagnostic Procedure

NGENC0438

| 1 | CHECK OVERALL FUNCTION | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------|-------------|--|--------------------|-------|---------|--|----------------|---------|---------------|--------|--------------|-------|-----------|-------|--|--|--|--|--|--|
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II. | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>SELF-LEARN CONTROL</td> <td>XXX %</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS~RPM (REF)</td> <td>XXX rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>FR O2 SENSOR</td> <td>XXX V</td> </tr> <tr> <td>A/F ALPHA</td> <td>XXX %</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | ACTIVE TEST | | SELF-LEARN CONTROL | XXX % | MONITOR | | CMPS~RPM (REF) | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SENSOR | XXX V | A/F ALPHA | XXX % | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN CONTROL | XXX % | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | |
| FR O2 SENSOR | XXX V | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA | XXX % | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| <ol style="list-style-type: none"> 3. Make sure that each circuit produces a momentary engine speed drop. | | | | | | | | | | | | | | | | | | | | | |
| <p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Listen to each injector operating sound. | | | | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | | | |
| <p style="text-align: center;">Clicking noise should be heard.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ INSPECTION END | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ GO TO 2. | | | | | | | | | | | | | | | | | | | | |

PEF839V

MEC703B


| | | | |
|----------|---------------------------|---|---|
| 2 | CHECK POWER SUPPLY | <p>1. Stop engine. 2. Disconnect injector harness connector. 3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;"> </div> <p style="color: blue; font-weight: bold;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | GI MA EM LC EC FE CL |
| OK | | ▶ GO TO 4. | |
| NG | | ▶ GO TO 3. | |

| | | | |
|----------|-----------------------------------|--|--|
| 3 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse ● Harness connectors F27, M59 ● 10A fuse ● Harness for open or short between injector and fuse | |
| | | ▶ Repair harness or connectors. | |

| | | | |
|----------|------------------------------------|---|---|
| 4 | CHECK OUTPUT SIGNAL CIRCUIT | <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between injector harness connector terminal 1 and ECM terminals 102, 104, 109, 111.</p> <div style="text-align: center;"> </div> <p style="color: blue; font-weight: bold;">Continuity should exist.</p> <p style="text-align: center;">OK or NG</p> | PD AX SU BR ST RS BT HA |
| OK | | ▶ GO TO 6. | |
| NG | | ▶ GO TO 5. | |

| | | | |
|----------|-----------------------------------|--|--|
| 5 | DETECT MALFUNCTIONING PART | <p>Check the harness for open or short between ECM and injector.</p> | |
| | | ▶ Repair open circuit or short to ground or short to power in harness or connectors. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | | |
|---|-----------------------|-------------------|--|
| 6 | CHECK INJECTOR | | |
| <p>1. Disconnect injector harness connector.</p> <p>2. Check resistance between terminals as shown in the figure.</p> | | | |
|  | | | |
| <p>Resistance: 10 - 14Ω [at 25°C (77°F)]</p> | | | |
| <p>OK or NG</p> | | | |
| OK | ▶ | GO TO 7. | |
| NG | ▶ | Replace injector. | |

SEF273W

| | | | |
|--|------------------------------------|---|-----------------------|
| 7 | CHECK INTERMITTENT INCIDENT | | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | | |
| | | ▶ | INSPECTION END |

START SIGNAL

KA24DE

CONSULT-II Reference Value in Data Monitor Mode

CONSULT-II Reference Value in Data Monitor Mode

NGEC0441

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|------------------------------------|----------------|
| START SIGNAL | ● Ignition switch: ON → START → ON | OFF → ON → OFF |

ECM Terminals and Reference Value

NGEC0442

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|--------------|-------------------------|-------------------------------|
| 20 | L/OR | Start signal | [Ignition switch ON] | Approximately 0V |
| | | | [Ignition switch START] | BATTERY VOLTAGE (11 - 14V) |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC





EL

IDX

Wiring Diagram

NGEC0440

EC-S/SIG-01



START SIGNAL

KA24DE

Diagnostic Procedure

Diagnostic Procedure


=NGEC0443

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

GI
MA
EM

| 2 | CHECK OVERALL FUNCTION | | | | | | | | | | | | | |
|---|-------------------------------|-----------------------|--------------|----------------|------------|---------|--------------|-----|--------------|----|--------------|-----|-------------|----|
| <p> With CONSULT-II</p> <p>1. Turn ignition switch ON.</p> <p>2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p> | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th>NO FAIL</th> </tr> </thead> <tbody> <tr> <td>START SIGNAL</td> <td>OFF</td> </tr> <tr> <td>CLSD TH/P SW</td> <td>ON</td> </tr> <tr> <td>AIR COND SIG</td> <td>OFF</td> </tr> <tr> <td>P/N POSI SW</td> <td>ON</td> </tr> </tbody> </table> | | | DATA MONITOR | | MONITORING | NO FAIL | START SIGNAL | OFF | CLSD TH/P SW | ON | AIR COND SIG | OFF | P/N POSI SW | ON |
| DATA MONITOR | | | | | | | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | | | | | | | |
| START SIGNAL | OFF | | | | | | | | | | | | | |
| CLSD TH/P SW | ON | | | | | | | | | | | | | |
| AIR COND SIG | OFF | | | | | | | | | | | | | |
| P/N POSI SW | ON | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>"START SIGNAL"</th> </tr> </thead> <tbody> <tr> <td>IGN "ON"</td> <td>OFF</td> </tr> <tr> <td>IGN "START"</td> <td>ON</td> </tr> </tbody> </table> | | | Condition | "START SIGNAL" | IGN "ON" | OFF | IGN "START" | ON | | | | | | |
| Condition | "START SIGNAL" | | | | | | | | | | | | | |
| IGN "ON" | OFF | | | | | | | | | | | | | |
| IGN "START" | ON | | | | | | | | | | | | | |
| SEF176X | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | | | | | | |

LC
EC
FE
CL
MT
AT


| 3 | CHECK OVERALL FUNCTION | | | | | | | |
|--|-------------------------------|-----------------------|-----------|---------|-------------------------|-----------------|--------------|------------------|
| <p> Without CONSULT-II</p> <p>1. Turn ignition switch to START.</p> <p>2. Check voltage between ECM terminal 20 and ground under the following conditions.</p> | | | | | | | | |
|  | | | | | | | | |
| SEF109P | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "START"</td> <td>Battery voltage</td> </tr> <tr> <td>Except above</td> <td>Approximately 0V</td> </tr> </tbody> </table> | | | Condition | Voltage | Ignition switch "START" | Battery voltage | Except above | Approximately 0V |
| Condition | Voltage | | | | | | | |
| Ignition switch "START" | Battery voltage | | | | | | | |
| Except above | Approximately 0V | | | | | | | |
| MTBL0143 | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |

PD
AX
SU
BR
ST
RS
BT
HA

SC
EL

IDX

| | | |
|----------------------|-----------------------------------|--------------------|
| 4 | DETECT MALFUNCTIONING PART | |
| Check the 7.5A fuse. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace 7.5A fuse. |

| | | |
|---|-----------------------------------|----------|
| 5 | CHECK INPUT SIGNAL CIRCUIT | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector and 7.5A fuse. 3. Check harness continuity between ECM terminal 20 and fuse block. | | |
|  | | |
| SEF224V | | |
| <p style="color: blue;">Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |

| | | |
|---|-----------------------------------|--|
| 6 | DETECT MALFUNCTIONING PART | |
| Check the following. | | |
| <ul style="list-style-type: none"> ● Harness connectors M81, F36 ● Harness for open or short between ECM and fuse block | | |
| OK or NG | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|--|------------------------------------|-----------------------|
| 7 | CHECK INTERMITTENT INCIDENT | |
| Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | | |
| ▶ | | INSPECTION END |


System Description

NGEC0444

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|--------------|-----------------|
| Camshaft position sensor | Engine speed | ECM | Fuel pump relay |
| Ignition switch | Start signal | | |

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 180° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to perform. If the 180° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

| Condition | Fuel pump operation |
|----------------------------------|-------------------------|
| Ignition switch is turned to ON. | Operates for 5 seconds. |
| Engine running and cranking | Operates. |
| Except as shown above | Stops. |



Component Description

NGEC0501

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).

CONSULT-II Reference Value in Data Monitor Mode

NGEC0445

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|---|---------------|
| FUEL PUMP RLY | <ul style="list-style-type: none"> Ignition switch is turned to ON (Operates for 5 seconds) Engine running and cranking | ON |
| | <ul style="list-style-type: none"> Except as shown above | OFF |

ECM Terminals and Reference Value

NGEC0446




Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-----------------|---|----------------------------|
| 11 | W/R | Fuel pump relay | [Ignition switch "ON"] <ul style="list-style-type: none"> For 5 seconds after turning ignition switch "ON" [Engine is running] | 0 - 1V |
| | | | [Ignition switch "ON"] <ul style="list-style-type: none"> More than 5 seconds after turning ignition switch "ON" | BATTERY VOLTAGE (11 - 14V) |

Wiring Diagram


NGEC0447



EC-F/PUMP-01





Diagnostic Procedure

NGE0448

| | | | |
|----------|-------------------------------|--|---|
| 1 | CHECK OVERALL FUNCTION | <p>1. Turn ignition switch ON. 2. Pinch fuel feed hose with two fingers.</p> <div style="text-align: center;"> <p>View with air cleaner removed</p>  </div> <p style="text-align: right;">SEF348V</p> <p>Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned "ON".</p> <p style="text-align: center;">OK or NG</p> | GI MA EM LC EC FE CL MT |
| OK | ▶ | INSPECTION END | |
| NG | ▶ | GO TO 2. | |

| | | | |
|----------|---------------------------|---|---|
| 2 | CHECK POWER SUPPLY | <p>1. Turn ignition switch OFF. 2. Disconnect fuel pump relay.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF349V</p> <p>3. Turn ignition switch ON. 4. Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF225V</p> <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | AT TF PD AX SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 4. | |
| NG | ▶ | GO TO 3. | |

| | |
|---|-----------------------------------|
| 3 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● 15A fuse ● Harness for open or short between fuse and fuel pump relay | |
| | Repair harness or connectors. |

| | | |
|--|-----------------------------------|----------|
| 4 | CHECK POWER GROUND CIRCUIT | |
| 1. Turn ignition switch OFF. 2. Disconnect fuel pump harness connector. | | |
|  | | |
| AFE095 | | |
| 3. Check harness continuity between terminal P2 and body ground, terminal P1 and fuel pump relay connector terminal 3. | | |
|  | | |
| SEF226V | | |
| <p style="color: blue; margin-left: 20px;">Continuity should exist.</p> 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | | GO TO 6. |
| NG | | GO TO 5. |

FUEL PUMP

KA24DE

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 5 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors B101, M67 ● Harness for open or short between fuel pump and body ground ● Harness for open or short between fuel pump and fuel pump relay | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|------------------------------------|
| 6 | CHECK OUTPUT SIGNAL CIRCUIT |
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 11 and fuel pump relay connector terminal 1.</p> | |
| | |
| <p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 7. |

| | |
|--|--|
| 7 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F36, M81 ● Harness for open or short between ECM and fuel pump relay | |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

8 CHECK FUEL PUMP RELAY

With CONSULT-II


1. Reconnect fuel pump relay, fuel pump harness connector and ECM harness connector.
2. Turn ignition switch ON.
3. Turn fuel pump relay "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.

| ACTIVE TEST | |
|-----------------|---------|
| FUEL PUMP RELAY | ON |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

SEF385X

Without CONSULT-II

Check continuity between terminals 3 and 5.



SEF511P

| Conditions | Continuity |
|---|------------|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No current supply | No |

MTBL0306

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 9. |
|----|---|----------|

| | | |
|----|---|--------------------------|
| NG | ▶ | Replace fuel pump relay. |
|----|---|--------------------------|

| | | | |
|----------|------------------------|--|--------------------|
| 9 | CHECK FUEL PUMP | <p>1. Disconnect fuel pump harness connector.</p> <div style="text-align: center;"> </div> | |
| | | <p>2. Check resistance between terminals P1 and P2. Resistance: 0.2 - 5.0Ω [at 25°C (77°F)]</p> <p style="text-align: center;">OK or NG</p> | |
| | OK | ▶ | GO TO 10. |
| | NG | ▶ | Replace fuel pump. |

SEF228V

GI

MA

EM

LC

EC

FE

CL

| | | | |
|-----------|------------------------------------|--|-----------------------|
| 10 | CHECK INTERMITTENT INCIDENT | Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128. | |
| | | ▶ | INSPECTION END |

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Component Description



Component Description

NGEC0451

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0452

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|--|---------------|
| PW/ST SIGNAL | <ul style="list-style-type: none"> Engine: After warming up, idle the engine Steering wheel in neutral position (forward direction) | OFF |
| | The steering wheel is fully turned | ON |

ECM Terminals and Reference Value

NGEC0453

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|------------------------------------|---|-------------------|
| 39 | GY/R | Power steering oil pressure switch | [Engine is running] <ul style="list-style-type: none"> Steering wheel is fully turned | Approximately 0V |
| | | | [Engine is running] <ul style="list-style-type: none"> Steering wheel is not turned | Approximately 5V |

POWER STEERING OIL PRESSURE SWITCH

KA24DE
Wiring Diagram

Wiring Diagram


NGEC0450

EC-PST/SW-01



— : Detectable line for DTC
— : Non-detectable line for DTC

- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX



AEC012B

Diagnostic Procedure

=NGEC0454

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

| 2 | CHECK OVERALL FUNCTION | | | | | | | |
|--|-------------------------------|-----------------------|---------------------------------|-----|--------------------|---------|--------------|-----|
| Ⓜ With CONSULT-II 1. Start engine. 2. Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions. | | | | | | | | |
| <table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITORING</th><th>NO FAIL</th></tr> <tr><td>PW/ST SIGNAL</td><td>OFF</td></tr> </table> | | | DATA MONITOR | | MONITORING | NO FAIL | PW/ST SIGNAL | OFF |
| DATA MONITOR | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | |
| PW/ST SIGNAL | OFF | | | | | | | |
| <table border="1" style="margin: auto;"> <tr><td>Steering is in neutral position</td><td>OFF</td></tr> <tr><td>Steering is turned</td><td>ON</td></tr> </table> | | | Steering is in neutral position | OFF | Steering is turned | ON | | |
| Steering is in neutral position | OFF | | | | | | | |
| Steering is turned | ON | | | | | | | |
| SEF177X | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |

| 3 | CHECK OVERALL FUNCTION | | | | | | | |
|--|-------------------------------|-----------------------|-----------|---------|---------------------------------------|------------------|--------------|------------------|
| ⓧ Without CONSULT-II 1. Start engine. 2. Check voltage between ECM terminal 39 and ground under the following conditions. | | | | | | | | |
| | | | | | | | | |
| SEF662P | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr><th>Condition</th><th>Voltage</th></tr> </thead> <tbody> <tr><td>When steering wheel is turned quickly</td><td>Approximately 0V</td></tr> <tr><td>Except above</td><td>Approximately 5V</td></tr> </tbody> </table> | | | Condition | Voltage | When steering wheel is turned quickly | Approximately 0V | Except above | Approximately 5V |
| Condition | Voltage | | | | | | | |
| When steering wheel is turned quickly | Approximately 0V | | | | | | | |
| Except above | Approximately 5V | | | | | | | |
| MTBL0142 | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |

POWER STEERING OIL PRESSURE SWITCH

KA24DE

Diagnostic Procedure (Cont'd)

| | | |
|--|-----------------------------------|----------|
| 4 | CHECK INPUT SIGNAL CIRCUIT | |
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 39 and terminal 1.</p> | | |
| | | |
| SEF662P | | |
| <p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |

GI
MA
EM
LC
EC

| | | |
|--|-----------------------------------|--|
| 5 | DETECT MALFUNCTIONING PART | |
| <p>Check the harness for open or short between ECM and power steering oil pressure switch.</p> | | |
| ▶ Repair open circuit or short to ground or short to power in harness or connectors. | | |

FE
CL
MT
AT

| 6 | CHECK POWER STEERING OIL PRESSURE SWITCH | | | | | | | |
|--|---|---|------------|------------|--------------------------------|-----|------------------------------------|----|
| <p>1. Disconnect power steering oil pressure switch harness connector then start engine. 2. Check continuity between terminals 1 and ground.</p> | | | | | | | | |
| | | | | | | | | |
| SEF230V | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Conditions</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Steering wheel is being turned</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>Steering wheel is not being turned</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | | Conditions | Continuity | Steering wheel is being turned | Yes | Steering wheel is not being turned | No |
| Conditions | Continuity | | | | | | | |
| Steering wheel is being turned | Yes | | | | | | | |
| Steering wheel is not being turned | No | | | | | | | |
| MTBL0307 | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | |
| NG | ▶ | Replace power steering oil pressure switch. | | | | | | |

TF
PD
AX
SU
BR
ST
RS

| | | |
|---|------------------------------------|--|
| 7 | CHECK INTERMITTENT INCIDENT | |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> | | |
| ▶ INSPECTION END | | |


BT
HA
SC
EL

IDX

IACV-FICD SOLENOID VALVE

KA24DE

Component Description



Component Description

When the air conditioner is on, the IAC valve-FICD solenoid valve supplies additional air to adjust to the increased load. NGEC0462

ECM Terminals and Reference Value


Specification data are reference values and are measured between each terminal and 32 (ECM ground). NGEC0463

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---|--|-------------------------------|
| 12 | P | Air conditioner relay | [Engine is running] ● Both A/C switch and blower switch are ON★ | Approximately 0V |
| | | | [Engine is running] ● A/C switch is OFF | BATTERY VOLTAGE (11 - 14V) |
| 21 | G/R | Air conditioner dual-pres- sure switch | [Engine is running] ● Both air conditioner switch and blower switch are ON (Compressor operates) | Approximately 0V |
| | | | [Engine is running] ● Air conditioner switch is OFF | BATTERY VOLTAGE (11 - 14V) |

★ Ambient air temperature above 10°C (50°F) and in any mode except OFF.

Diagnostic Procedure

=NGEC0464

| | | |
|----------|-------------------------------|--|
| 1 | CHECK OVERALL FUNCTION | <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Check idle speed. 800±50 rpm If NG, adjust idle speed.</p> <p>3. Push air conditioner switch ON and turn fan switch to 4-speed.</p> <p>4. Recheck idle speed.</p> <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: right; margin-top: 20px;"><small>MEF634E</small></p> |
| | | OK or NG |
| OK | ▶ | INSPECTION END |
| NG | ▶ | GO TO 2. |

| | | |
|----------|---------------------------------------|---|
| 2 | CHECK AIR CONDITIONER FUNCTION | <p>Check if air conditioner compressor functions normally.</p> <p style="text-align: center; margin-top: 20px;">OK or NG</p> |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Refer to "Symptom Table" in "TROUBLE DIAGNOSIS", HA-26 . |


IACV-FICD SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|----------|---------------------------|--|--|
| 3 | CHECK POWER SUPPLY | <p>1. Stop engine. 2. Disconnect IACV-FICD solenoid valve harness connector.</p> <div style="text-align: center;"> <p>View with air cleaner removed</p> </div> <p>3. Start engine, then push A/C switch ON and turn fan switch to 4-speed. 4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;"> </div> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> |
| | | SEF342V | |
| | | SEF133V | |
| OK | ▶ | GO TO 5. | PD |
| NG | ▶ | GO TO 4. | AX |

| | | | |
|----------|-----------------------------------|--|---------------------|
| 4 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M81, F36 ● Harness connector M59, F27 ● Harness for open or short between IACV-FICD solenoid valve harness connector and air conditioner relay | <p>SU</p> <p>BR</p> |
| | ▶ | Repair open circuit, short to ground or short to power in harness or connectors. | ST |



| | | |
|--|-----------------------------|----------|
| 5 | CHECK GROUND CIRCUIT | |
| <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Disconnect ambient air temperature switch harness connector. 4. Check harness continuity between solenoid valve terminal 1 and body ground. | | |
|  | | |
| SEF134V | | |
| <p>Continuity should exist.</p> <p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |

| | | |
|---|-----------------------------------|--|
| 6 | DETECT MALFUNCTIONING PART | |
| Check the harness for open or short between IACV-FICD solenoid valve and body ground. | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

IACV-FICD SOLENOID VALVE

KA24DE

Diagnostic Procedure (Cont'd)

| | | | |
|----------|---------------------------------------|---|-----------------------------------|
| 7 | CHECK IACV-FICD SOLENOID VALVE | <p>Disconnect IACV-FICD solenoid valve harness connector.</p> <div style="text-align: center;">  </div> <ul style="list-style-type: none"> ● Check for clicking sound when applying 12V direct current to terminals. ● Check plunger for seizing or sticking. ● Check for broken spring. <div style="text-align: center;">  </div> <p style="text-align: right;">SEF231V</p> <p style="text-align: right;">SEF097K</p> | |
| | | OK or NG | |
| OK | | ▶ | GO TO 8. |
| NG | | ▶ | Replace IACV-FICD solenoid valve. |



| | | | |
|----------|------------------------------------|---|-----------------------|
| 8 | CHECK INTERMITTENT INCIDENT | <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-128.</p> | |
| | | ▶ | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Wiring Diagram

NGEC0466

EC-MIL/DL-01



Fuel Pressure Regulator

NGEC0467

| | | |
|---|-----------------------------|-----------------------------|
| Fuel pressure at idling kPa (kg/cm ² , psi) | Vacuum hose is connected | Approximately 235 (2.4, 34) |
| | Vacuum hose is disconnected | Approximately 294 (3.0, 43) |

Idle Speed and Ignition Timing

NGEC0468

| | | |
|-------------------------|------------------------------------|-------------|
| Base idle speed*1 rpm | No-load*4 (in "P" or "N" position) | 750±50 |
| Target idle speed*2 rpm | No-load*4 (in "P" or "N" position) | 800±50 |
| Air conditioner: ON rpm | In "P" or "N" position | 875 or more |
| Ignition timing*1 | In "P" or "N" position | 20°±2° BTDC |

*1: Throttle position sensor harness connector disconnected or using CONSULT-II "WORK SUPPORT" mode

*2: Throttle position sensor harness connector connected

*3: Throttle position sensor harness connector disconnected

*4: Under the following conditions:

- Air conditioner switch: OFF
- Electrical load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Coil

NGEC0469

| | |
|--|--------------------|
| Primary voltage V | Battery voltage 12 |
| Primary resistance [at 20°C (68°F)] Ω | Approximately 1.0 |
| Secondary resistance [at 20°C (68°F)] kΩ | Approximately 10 |

Mass Air Flow Sensor

NGEC0470

| | |
|--|--|
| Supply voltage V | Battery voltage (11 - 14) |
| Output voltage V | 0.9 - 1.8* |
| Mass air flow (Using CONSULT-II or GST) g-m/sec | 0.9 - 5.8 at idle* 7.5 - 13.2 at 2,500 rpm* |

*: Engine is warmed up to normal operating temperature and idling under no-load.

Engine Coolant Temperature Sensor

NGEC0471

| | |
|---------------------|---------------|
| Temperature °C (°F) | Resistance kΩ |
| 20 (68) | 2.1 - 2.9 |
| 50 (122) | 0.68 - 1.00 |
| 90 (194) | 0.236 - 0.260 |

EGR Temperature Sensor

NGEC0472

| | | |
|-------------------------|-------------|-----------------|
| EGR temperature °C (°F) | Voltage (V) | Resistance (MΩ) |
| 0 (32) | 4.81 | 7.9 - 9.7 |
| 50 (122) | 2.82 | 0.57 - 0.70 |
| 100 (212) | 0.8 | 0.08 - 0.10 |

Fuel Pump

NGEC0473

| | |
|-------------------------------|-----------|
| Resistance [at 25°C (77°F)] Ω | 0.2 - 5.0 |
|-------------------------------|-----------|

IACV-AAC Valve

IACV-AAC Valve

NGEC0474

| | |
|-------------------------------|--------------------|
| Resistance [at 25°C (77°F)] Ω | Approximately 10.0 |
|-------------------------------|--------------------|

Injector

NGEC0475

| | |
|-------------------------------|---------|
| Resistance [at 25°C (77°F)] Ω | 10 - 14 |
|-------------------------------|---------|

Resistor

NGEC0476

| | |
|-------------------------------|-------------------|
| Resistance [at 25°C (77°F)] Ω | Approximately 2.2 |
|-------------------------------|-------------------|

Throttle Position Sensor

NGEC0477

| Throttle valve conditions | Voltage (at normal operating temp., engine off, ignition switch on) |
|---------------------------|---|
| Completely closed (a) | 0.15 - 0.85V |
| Partially open | Between (a) and (b) |
| Completely open (b) | 3.5 - 4.7V |

Front Heated Oxygen Sensor Heater

NGEC0478

| | |
|-------------------------------|-----------|
| Resistance [at 25°C (77°F)] Ω | 2.3 - 4.3 |
|-------------------------------|-----------|

Calculated Load Value

NGEC0479

| | Calculated load value % (Using CONSULT or GST) |
|--------------|---|
| At idle | 9.5 - 34.0% |
| At 2,500 rpm | 13.9 - 24.9% |

Intake Air Temperature Sensor

NGEC0480

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.1 - 2.9 |
| 80 (176) | 0.27 - 0.38 |

Rear Heated Oxygen Sensor Heater

NGEC0483

| | |
|-------------------------------|-----------|
| Resistance [at 25°C (77°F)] Ω | 2.3 - 4.3 |
|-------------------------------|-----------|

Crankshaft Position Sensor (OBD)

NGEC0484

| | |
|-------------------------------|-----------|
| Resistance [at 20°C (68°F)] Ω | 512 - 632 |
|-------------------------------|-----------|

Fuel Tank Temperature Sensor

NGEC0485

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.3 - 2.7 |
| 50 (122) | 0.79 - 0.90 |

Alphabetical & P No. Index for DTC

NGEC0522

NGEC0522S01

ALPHABETICAL INDEX FOR DTC

| Items (CONSULT-II screen terms) | DTC*6 | | Reference page |
|---------------------------------------|-------|---------------------|----------------|
| | ECM*1 | CONSULT-II GST*2 | |
| Unable to access ECM | — | — | EC-687 |
| ABSL PRES SEN/CIRC | 0803 | P0105 | EC-722 |
| AIR TEMP SEN/CIRC | 0401 | P0110 | EC-734 |
| A/T 1ST GR FNCTN | 1103 | P0731 | AT-120 |
| A/T 2ND GR FNCTN | 1104 | P0732 | AT-126 |
| A/T 3RD GR FNCTN | 1105 | P0733 | AT-132 |
| A/T 4TH GR FNCTN | 1106 | P0734 | AT-138 |
| A/T COMM LINE | — | P0600 | EC-1006 |
| A/T DIAG COMM LINE | 0804 | P1605 | EC-1121 |
| A/T TCC S/V FNCTN | 1107 | P0744 | AT-152 |
| ATF TEMP SEN/CIRC | 1208 | P0710 | AT-105 |
| CAM POS SEN/CIRC | 0101 | P0340 | EC-912 |
| CLOSED LOOP-B1 | 0307 | P1148 | EC-1026 |
| CLOSED LOOP-B2 | 0308 | P1168 | EC-1026 |
| CLOSED TP SW/CIRC | 0203 | P0510 | EC-998 |
| COOLANT T SEN/CIRC*3 | 0103 | P0115 | EC-739 |
| *COOLANT T SEN/CIRC | 0908 | P0125 | EC-758 |
| CPS/CIRC (OBD) COG | 0905 | P1336 | EC-1036 |
| CPS/CIRCUIT (OBD) | 0802 | P0335 | EC-906 |
| CYL 1 MISFIRE | 0608 | P0301 | EC-893 |
| CYL 2 MISFIRE | 0607 | P0302 | EC-893 |
| CYL 3 MISFIRE | 0606 | P0303 | EC-893 |
| CYL 4 MISFIRE | 0605 | P0304 | EC-893 |
| CYL 5 MISFIRE | 0604 | P0305 | EC-893 |
| CYL 6 MISFIRE | 0603 | P0306 | EC-893 |
| ECM | 0301 | P0605 | EC-1011 |
| EGR SYSTEM (If so equipped) | 0302 | P0400 | EC-919 |
| EGR SYSTEM (If so equipped) | 0514 | P1402 | EC-1055 |
| EGR TEMP SEN/CIRC (If so equipped) | 0305 | P1401 | EC-1048 |
| EGRC SOLENOID/V (If so equipped) | 1005 | P1400 | EC-1043 |
| EGRC-BPT VALVE (If so equipped) | 0306 | P0402 | EC-933 |

TROUBLE DIAGNOSIS — INDEX

VG33E

Alphabetical & P No. Index for DTC (Cont'd)

| Items (CONSULT-II screen terms) | DTC*6 | | Reference page |
|---|-------------|---------------------|----------------|
| | ECM*1 | CONSULT-II GST*2 | |
| ENGINE SPEED SIG | 1207 | P0725 | AT-116 |
| ENG OVER TEMP | 0211 | P0217 | EC-880 |
| EVAP GROSS LEAK | 0715 | P0455 | EC-974 |
| EVAP PURG FLOW/MON | 0111 | P1447 | EC-1086 |
| EVAP SYS PRES SEN | 0704 | P0450 | EC-963 |
| EVAP SMALL LEAK | 0705 | P0440 | EC-947 |
| EVAP SMALL LEAK | 0213 | P1440 | EC-1065 |
| FR O2 SE HEATER-B1 | 0901 | P0135 | EC-809 |
| FR O2 SE HEATER-B2 | 1001 | P0155 | EC-809 |
| FRONT O2 SENSOR-B1 | 0503 | P0130 | EC-763 |
| FRONT O2 SENSOR-B1 | 0415 | P0131 | EC-772 |
| FRONT O2 SENSOR-B1 | 0414 | P0132 | EC-780 |
| FRONT O2 SENSOR-B1 | 0413 | P0133 | EC-788 |
| FRONT O2 SENSOR-B1 | 0509 | P0134 | EC-801 |
| FRONT O2 SENSOR-B2 | 0303 | P0150 | EC-763 |
| FRONT O2 SENSOR-B2 | 0411 | P0151 | EC-772 |
| FRONT O2 SENSOR-B2 | 0410 | P0152 | EC-780 |
| FRONT O2 SENSOR-B2 | 0409 | P0153 | EC-788 |
| FRONT O2 SENSOR-B2 | 0412 | P0154 | EC-801 |
| FUEL SYS LEAN/BK1 | 0115 | P0171 | EC-860 |
| FUEL SYS LEAN/BK2 | 0210 | P0174 | EC-860 |
| FUEL SYS RICH/BK1 | 0114 | P0172 | EC-868 |
| FUEL SYS RICH/BK2 | 0209 | P0175 | EC-868 |
| FUEL TEMP SEN/CIRC | 0402 | P0180 | EC-875 |
| IACV/AAC VLV/CIRC | 0205 | P0505 | EC-992 |
| IGN SIGNAL-PRIMARY | 0201 | P1320 | EC-1028 |
| KNOCK SENSOR | 0304 | P0325 | EC-902 |
| L/PRES SOL/CIRC | 1205 | P0745 | AT-160 |
| MAP/BARO SW SOL/CIR | 1302 | P1105 | EC-1013 |
| MAF SEN/CIRCUIT*3 | 0102 | P0100 | EC-713 |
| MULTI CYL MISFIRE | 0701 | P0300 | EC-893 |
| NO SELF DIAGNOSTIC FAILURE INDICATED | 0505 | P0000 | — |
| NO SELF DIAGNOSTIC FAILURE INDICATED | Flashing*5 | No DTC | EC-643 |
| OVER HEAT | 0208 | — | EC-1132 |
| O/R CLTCH S/CIRC | 1203 | P1760 | AT-184 |
| P-N POS SW/CIRCUIT | 1003 | P0705 | EC-1124 |

TROUBLE DIAGNOSIS — INDEX

VG33E

Alphabetical & P No. Index for DTC (Cont'd)

| Items (CONSULT-II screen terms) | DTC*6 | | Reference page |
|------------------------------------|-------|---------------------|----------------|
| | ECM*1 | CONSULT-II GST*2 | |
| PNP SW/CIRC | 1101 | P0705 | AT-99 |
| PURG VOLUME CONT/V | 1008 | P0443 | EC-950 |
| PURG VOLUME CONT/V | 0214 | P1444 | EC-1067 |
| REAR O2 SENSOR-B1 | 0511 | P0137 | EC-815 |
| REAR O2 SENSOR-B1 | 0510 | P0138 | EC-825 |
| REAR O2 SENSOR-B1 | 0707 | P0139 | EC-835 |
| REAR O2 SENSOR-B1 | 0512 | P0140 | EC-845 |
| REAR O2 SENSOR-B2 | 0314 | P0157 | EC-815 |
| REAR O2 SENSOR-B2 | 0313 | P0158 | EC-825 |
| REAR O2 SENSOR-B2 | 0708 | P0159 | EC-835 |
| REAR O2 SENSOR-B2 | 0315 | P0160 | EC-845 |
| RR O2 SE HEATER-B1 | 0902 | P0141 | EC-853 |
| RR O2 SE HEATER-B2 | 1002 | P0161 | EC-853 |
| SFT SOL A/CIRC*3 | 1108 | P0750 | AT-165 |
| SFT SOL B/CIRC*3 | 1201 | P0755 | AT-170 |
| TCC SOLENOID/CIRC | 1204 | P0740 | AT-147 |
| TP SEN/CIRC A/T*3 | 1206 | P1705 | AT-175 |
| TRTL POS SEN/CIRC*3 | 0403 | P0120 | EC-744 |
| TW CATALYST SYS-B1 | 0702 | P0420 | EC-941 |
| TW CATALYST SYS-B2 | 0703 | P0430 | EC-941 |
| VC CUT/V BYPASS/V | 0311 | P1491 | EC-1112 |
| VC/V BYPASS/V | 0801 | P1490 | EC-1106 |
| VEH SPEED SEN/CIRC*4 | 0104 | P0500 | EC-988 |
| VEH SPD SEN/CIRC*4 | 1102 | P0720 | AT-111 |
| VENT CONTROL VALVE | 0903 | P0446 | EC-957 |
| VENT CONTROL VALVE | 0215 | P1446 | EC-1079 |
| VENT CONTROL VALVE | 0309 | P1448 | EC-1098 |

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

*5: While engine is running.

*6: 1st trip DTC No. is the same as DTC No.

NOTE:

Regarding D22 models, "-B1" and "BK1" indicate right bank and "-B2" and "BK2" indicate left bank.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — INDEX

VG33E

Alphabetical & P No. Index for DTC (Cont'd)

P NO. INDEX FOR DTC

=NGEC0522S02

| DTC*6 | | Items (CONSULT-II screen terms) | Reference page |
|---------------------|-------------|---|----------------|
| CONSULT-II GST*2 | ECM*1 | | |
| — | — | Unable to access ECM | EC-687 |
| No DTC | Flashing*5 | NO SELF DIAGNOSTIC FAILURE INDICATED | EC-643 |
| P0000 | 0505 | NO SELF DIAGNOSTIC FAILURE INDICATED | — |
| P0100 | 0102 | MAF SEN/CIRCUIT*3 | EC-713 |
| P0105 | 0803 | ABSL PRES SEN/CIRC | EC-722 |
| P0110 | 0401 | AIR TEMP SEN/CIRC | EC-734 |
| P0115 | 0103 | COOLANT T SEN/CIRC*3 | EC-739 |
| P0120 | 0403 | THRTL POS SEN/CIRC*3 | EC-744 |
| P0125 | 0908 | *COOLANT T SEN/CIRC | EC-758 |
| P0130 | 0503 | FRONT O2 SENSOR-B1 | EC-763 |
| P0131 | 0415 | FRONT O2 SENSOR-B1 | EC-772 |
| P0132 | 0414 | FRONT O2 SENSOR-B1 | EC-780 |
| P0133 | 0413 | FRONT O2 SENSOR-B1 | EC-788 |
| P0134 | 0509 | FRONT O2 SENSOR-B1 | EC-801 |
| P0135 | 0901 | FR O2 SE HEATER-B1 | EC-809 |
| P0137 | 0511 | REAR O2 SENSOR-B1 | EC-815 |
| P0138 | 0510 | REAR O2 SENSOR-B1 | EC-825 |
| P0139 | 0707 | REAR O2 SENSOR-B1 | EC-835 |
| P0140 | 0512 | REAR O2 SENSOR-B1 | EC-845 |
| P0141 | 0902 | RR O2 SE HEATER-B1 | EC-853 |
| P0150 | 0303 | FRONT O2 SENSOR-B2 | EC-763 |
| P0151 | 0411 | FRONT O2 SENSOR-B2 | EC-772 |
| P0152 | 0410 | FRONT O2 SENSOR-B2 | EC-780 |
| P0153 | 0409 | FRONT O2 SENSOR-B2 | EC-788 |
| P0154 | 0412 | FRONT O2 SENSOR-B2 | EC-801 |
| P0155 | 1001 | FR O2 SE HEATER-B2 | EC-809 |
| P0157 | 0314 | REAR O2 SENSOR-B2 | EC-815 |
| P0158 | 0313 | REAR O2 SENSOR-B2 | EC-825 |
| P0159 | 0708 | REAR O2 SENSOR-B2 | EC-835 |
| P0160 | 0315 | REAR O2 SENSOR-B2 | EC-845 |
| P0161 | 1002 | RR O2 SE HEATER-B2 | EC-853 |
| P0171 | 0115 | FUEL SYS LEAN/BK1 | EC-860 |
| P0172 | 0114 | FUEL SYS RICH/BK1 | EC-868 |
| P0174 | 0210 | FUEL SYS LEAN/BK2 | EC-860 |
| P0175 | 0209 | FUEL SYS RICH/BK2 | EC-868 |

TROUBLE DIAGNOSIS — INDEX

VG33E

Alphabetical & P No. Index for DTC (Cont'd)

| DTC*6 | | Items (CONSULT-II screen terms) | Reference page | |
|---------------------|-------|------------------------------------|----------------|-----------|
| CONSULT-II GST*2 | ECM*1 | | | |
| P0180 | 0402 | FUEL TEMP SEN/CIRC | EC-875 | GI |
| P0217 | 0211 | ENG OVER TEMP | EC-880 | MA |
| P0300 | 0701 | MULTI CYL MISFIRE | EC-893 | EM |
| P0301 | 0608 | CYL 1 MISFIRE | EC-893 | |
| P0302 | 0607 | CYL 2 MISFIRE | EC-893 | LC |
| P0303 | 0606 | CYL 3 MISFIRE | EC-893 | |
| P0304 | 0605 | CYL 4 MISFIRE | EC-893 | EC |
| P0305 | 0604 | CYL 5 MISFIRE | EC-893 | |
| P0306 | 0603 | CYL 6 MISFIRE | EC-893 | FE |
| P0325 | 0304 | KNOCK SENSOR | EC-902 | |
| P0335 | 0802 | CPS/CIRCUIT (OBD) | EC-906 | CL |
| P0340 | 0101 | CAM POS SEN/CIRC | EC-912 | |
| P0400 | 0302 | EGR SYSTEM (If so equipped) | EC-919 | MT |
| P0402 | 0306 | EGRC-BPT VALVE (If so equipped) | EC-933 | AT |
| P0420 | 0702 | TW CATALYST SYS-B1 | EC-941 | TF |
| P0430 | 0703 | TW CATALYST SYS-B2 | EC-941 | |
| P0440 | 0705 | EVAP SMALL LEAK | EC-947 | PD |
| P0443 | 1008 | PURG VOLUME CONT/V | EC-950 | |
| P0455 | 0715 | EVAP GROSS LEAK | EC-974 | AX |
| P0446 | 0903 | VENT CONTROL VALVE | EC-957 | |
| P0450 | 0704 | EVAP SYS PRES SEN | EC-963 | SU |
| P0455 | 0715 | EVAP GROSS LEAK | EC-974 | |
| P0500 | 0104 | VEH SPEED SEN/CIRC*4 | EC-988 | BR |
| P0505 | 0205 | IACV/AAC VLV/CIRC | EC-992 | |
| P0510 | 0203 | CLOSED TP SW/CIRC | EC-998 | ST |
| P0600 | — | A/T COMM LINE | EC-1006 | |
| P0605 | 0301 | ECM | EC-1011 | RS |
| P0705 | 1101 | PNP SW/CIRC | AT-99 | |
| P0710 | 1208 | ATF TEMP SEN/CIRC | AT-105 | BT |
| P0720 | 1102 | VEH SPD SEN/CIRC A/T*4 | AT-111 | |
| P0725 | 1207 | ENGINE SPEED SIG | AT-116 | HA |
| P0731 | 1103 | A/T 1ST GR FNCTN | AT-120 | |
| P0732 | 1104 | A/T 2ND GR FNCTN | AT-126 | SC |
| P0733 | 1105 | A/T 3RD GR FNCTN | AT-132 | |
| P0734 | 1106 | A/T 4TH GR FNCTN | AT-138 | EL |

TROUBLE DIAGNOSIS — INDEX

VG33E

Alphabetical & P No. Index for DTC (Cont'd)

| DTC*6 | | Items (CONSULT-II screen terms) | Reference page |
|---------------------|-------|---------------------------------------|----------------|
| CONSULT-II GST*2 | ECM*1 | | |
| P0740 | 1204 | TCC SOLENOID/CIRC | AT-147 |
| P0744 | 1107 | A/T TCC S/V FNCTN | AT-152 |
| P0745 | 1205 | L/PRESS SOL/CIRC | AT-160 |
| P0750 | 1108 | SFT SOL A/CIRC*3 | AT-165 |
| P0755 | 1201 | SFT SOL B/CIRC*3 | AT-170 |
| P1105 | 1302 | MAP/BARO SW SOL/CIR | EC-1013 |
| P1148 | 0307 | CLOSED LOOP-B1 | EC-1026 |
| P1168 | 0308 | CLOSED LOOP-B2 | EC-1026 |
| P1320 | 0201 | IGN SIGNAL-PRIMARY | EC-1028 |
| P1336 | 0905 | CPS/CIRC (OBD) COG | EC-1036 |
| P1400 | 1005 | EGRC SOLENOID/V (If so equipped) | EC-1043 |
| P1401 | 0305 | EGR TEMP SEN/CIRC (If so equipped) | EC-1048 |
| P1402 | 0514 | EGR SYSTEM (If so equipped) | EC-1055 |
| P1440 | 0213 | EVAP SMALL LEAK | EC-1065 |
| P1444 | 0214 | PURG VOLUME CONT/V | EC-1067 |
| P1446 | 0215 | VENT CONTROL VALVE | EC-1079 |
| P1447 | 0111 | EVAP PURG FLOW/MON | EC-1086 |
| P1448 | 0309 | VENT CONTROL VALVE | EC-1098 |
| P1490 | 0801 | VC/V BYPASS/V | EC-1106 |
| P1491 | 0311 | VC CUT/V BYPASS/V | EC-1112 |
| P1605 | 0804 | A/T DIAG COMM LINE | EC-1121 |
| P1705 | 1206 | TP SEN/CIRC A/T*3 | AT-175 |
| P1706 | 1003 | P-N POS SW/CIRCUIT | EC-1124 |
| P1760 | 1203 | O/R CLUTCH SOL/CIRC | AT-184 |
| — | 0208 | OVER HEAT | EC-1132 |

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

*5: While engine is running.

*6: 1st trip DTC No. is the same as DTC No.

NOTE:

Regarding D22 models, "-B1" and "BK1" indicate right bank and "-B2" and "BK2" indicate left bank.

PRECAUTIONS

VG33E

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NGEC0523

The supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, a crash zone sensor (4WD models), warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses (except "SEAT BELT PRE-TENSIONER") covered with yellow insulation either just before the harness connectors or for the complete harness are related to the SRS.

Precautions for On Board Diagnostic (OBD) System of Engine and A/T

NGEC0524

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to EL section, "Description", "HARNESS CONNECTOR".
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.

Engine Fuel & Emission Control System


NGEC0525

ECM

- Do not disassemble ECM.
- Do not turn on board diagnostic test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value.
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
 - 1) Keep the antenna as far away as possible from the electronic control units.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls.
Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

ECM PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor or crankshaft position sensor (OBD).







FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque. (Refer to MA section.)

ECM HARNESS HANDLING

- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in.) away from adjacent harnesses to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

AEC045B



Precautions

NGEC0526

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.

GI
MA
EM

- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.

 : 3 - 5 N·m (0.3 - 0.5 kg·m, 26 - 43 in·lb)

LC
EC

- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.

FE
CL
MT

- Before replacing ECM, perform “ECM Terminals and Reference Value” inspection and make sure ECM functions properly. Refer to EC-697.

AT
TF
PD
AX


- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”. The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.

SU
BR
ST
RS


BT
HA
SC

EL
IDX

Precautions (Cont'd)



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.



- Regarding model D22, “-B1” indicates the right bank and “-B2” indicates the left bank as shown in the figure.

Wiring Diagrams and Trouble Diagnosis

NGEC0527

When you read Wiring diagrams, refer to the followings:

- “HOW TO READ WIRING DIAGRAMS” in GI section
- “POWER SUPPLY ROUTING” for power distribution circuit in EL section



When you perform trouble diagnosis, refer to the followings:

- “HOW TO FOLLOW TEST GROUP IN TROUBLE DIAGNOSIS” in GI section
- “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT” in GI section

Special Service Tools




NGEC0528

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description | |
|---|---|---|
| KV10117100 (J36471-A) Heated oxygen sensor wrench |  | Loosening or tightening front heated oxygen sensor with 22 mm (0.87 in) hexagon nut |
| | NT379 | |
| KV10114400 (J-38365) Heated oxygen sensor wrench |  | Loosening or tightening rear heated oxygen sensor a: 22 mm (0.87 in) |
| | NT636 | |

Commercial Service Tools





NGEC0529

| Tool name (Kent-Moore No.) | Description | |
|--|---|--|
| Leak detector (J41416) |  | Locating the EVAP leak |
| | NT703 | |
| EVAP service port adapter (J41413-OBID) |  | Applying positive pressure through EVAP service port |
| | NT704 | |
| Hose clipper |  <p style="text-align: center;">Approx. 20 mm (0.79 in)</p> | Clamping the EVAP purge hose between the fuel tank and EVAP canister applied to DTC P1440 [EVAP control system (small leak-positive pressure)] |
| | NT720 | |

PREPARATION


VG33E

Commercial Service Tools (Cont'd)

| Tool name (Kent-Moore No.) | Description | |
|---|---|--|
| Fuel filler cap adapter |  | Checking fuel tank vacuum relief valve opening pressure |
| Socket wrench |  | Removing and installing engine coolant temperature sensor |
| Oxygen sensor thread cleaner (J-43897-18) (J-43897-12) |  | Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown in "Commercial Service Tools". a: J-43897-18 18 mm diameter, for Zirconia Oxygen Sensor b: J-43897-12 12 mm diameter, for Titania Oxygen Sensor |
| Anti-seize lubricant (Permatex [®] 133AR or equivalent meeting MIL specification MIL-A-907) |  | Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads. |

Engine Control Component Parts Location

NGEC0530



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL







IDX

AEC065B

ENGINE AND EMISSION CONTROL OVERALL SYSTEM


VG33E

Engine Control Component Parts Location (Cont'd)



AEC066B


Circuit Diagram

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Vacuum Hose Drawing

Refer to "System Diagram", EC-596 for Vacuum Control System.

NGEC0533



MAP/BARO switch solenoid valve

AEC069B

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

System Chart

NGEC0534

| Input (Sensor) | ECM Function | Output (Actuator) |
|--|---|---|
| <ul style="list-style-type: none"> ● Camshaft position sensor ● Mass air flow sensor ● Engine coolant temperature sensor ● Front heated oxygen sensor ● Ignition switch ● Throttle position sensor ● Closed throttle position switch *4 ● Park/neutral position (PNP) switch ● Air conditioner switch ● Knock sensor ● EGR temperature sensor *1 (If so equipped) ● Intake air temperature sensor ● Absolute pressure sensor ● EVAP control system pressure sensor *1 ● Battery voltage ● Power steering oil pressure switch ● Vehicle speed sensor ● Fuel tank temperature sensor *1 ● Crankshaft position sensor (OBD) *1 ● Rear heated oxygen sensor *3 ● TCM (Transmission control module) *2 ● Ambient air temperature switch | Fuel injection & mixture ratio control | Injectors |
| | Distributor ignition system | Power transistor |
| | Idle air control system | IACV-AAC valve and IACV-FICD solenoid valve |
| | Fuel pump control | Fuel pump relay |
| | Front heated oxygen sensor monitor & on board diagnostic system | MIL (On the instrument panel) |
| | EGR control (If so equipped) | EGRC-solenoid valve (If so equipped) |
| | Front heated oxygen sensor heater control | Front heated oxygen sensor heater |
| | Rear heated oxygen sensor heater control | Rear heated oxygen sensor heater |
| | EVAP canister purge flow control | EVAP canister purge volume control solenoid valve |
| | Air conditioning cut control | Air conditioner relay |
| | Cooling fan control | Cooling fan relays |
| | ON BOARD DIAGNOSIS for EVAP system | <ul style="list-style-type: none"> ● EVAP canister vent control valve ● Vacuum cut valve bypass valve ● MAP/BARO switch solenoid valve |

*1: These sensors are not used to control the engine system. They are used only for the on board diagnosis.

*2: The DTC related to A/T will be sent to ECM.

*3: This sensor is not used to control the engine system under normal conditions.

*4: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

VG33E

Multiport Fuel Injection (MFI) System

Multiport Fuel Injection (MFI) System

DESCRIPTION

Input/Output Signal Chart

NGEC0535

NGEC0535S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|---|--|-----------|
| Camshaft position sensor | Engine speed and piston position | Fuel injection & mixture ratio control | Injectors |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Front heated oxygen sensor | Density of oxygen in exhaust gas | | |
| Throttle position sensor | Throttle position Throttle valve idle position | | |
| Park/neutral position (PNP) switch | Gear position | | |
| Vehicle speed sensor | Vehicle speed | | |
| Ignition switch | Start signal | | |
| Air conditioner switch | Air conditioner operation | | |
| Knock sensor | Engine knocking condition | | |
| Battery | Battery voltage | | |
| Absolute pressure sensor | Manifold absolute pressure Ambient air barometric pressure | | |
| Power steering oil pressure switch | Power steering operation | | |
| Rear heated oxygen sensor* | Density of oxygen in exhaust gas | | |

* Under normal conditions, this sensor is not for engine control operation.

Basic Multiport Fuel Injection System

NGEC0535S02

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

Various Fuel Injection Increase/Decrease Compensation

NGEC0535S03

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

<Fuel increase>


- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from "N" to "D"
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

Mixture Ratio Feedback Control (Closed loop control)

NGEC0535S04



SEF932V

The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The warm-up three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a front heated oxygen sensor in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the front heated oxygen sensor, refer to EC-763. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Rear heated oxygen sensor is located downstream of the warm-up three way catalyst. Even if the switching characteristics of the front heated oxygen sensor shift, the air-fuel ratio is controlled to stoichiometric by the signal from the rear heated oxygen sensor.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

NGEC0535S05

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of front heated oxygen sensor or its circuit
- Insufficient activation of front heated oxygen sensor at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- When starting the engine

Mixture Ratio Self-learning Control

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the front heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.

NGEC0535S06

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the front heated oxygen sensor indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.


ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

VG33E

Multiport Fuel Injection (MFI) System (Cont'd)

Fuel Injection Timing

NGEC0535S07



SEF179U

Two types of systems are used.

Sequential Multiport Fuel Injection System

NGEC0535S0701

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

NGEC0535S0702

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

Fuel Shut-off

NGEC0535S08

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Distributor Ignition (DI) System

DESCRIPTION

Input/Output Signal Chart


NGEC0536

NGEC0536S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|---|-------------------------|------------------|
| Camshaft position sensor | Engine speed and piston position | Ignition timing control | Power transistor |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Throttle position sensor | Throttle position Throttle valve idle position | | |
| Vehicle speed sensor | Vehicle speed | | |
| Ignition switch | Start signal | | |
| Knock sensor | Engine knocking | | |
| Park/neutral position (PNP) switch | Gear position | | |
| Battery | Battery voltage | | |

System Description

NGEC0536S02



The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec
A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioning Cut Control

DESCRIPTION

NGEC0537

Input/Output Signal Chart

NGEC0537S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|------------------------------|-----------------------------|-----------------------|
| Air conditioner switch | Air conditioner "ON" signal | Air conditioner cut control | Air conditioner relay |
| Throttle position sensor | Throttle valve opening angle | | |
| Camshaft position sensor | Engine speed | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Vehicle speed sensor | Vehicle speed | | |
| Power steering oil pressure switch | Power steering operation | | |

System Description

NGEC0537S02

This system improves engine operation when the air conditioner is used.

Under the following conditions, the air conditioner is turned OFF.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

VG33E

Fuel Cut Control (at no load & high engine speed)

Fuel Cut Control (at no load & high engine speed)

DESCRIPTION

Input/Output Signal Chart

NGEC0538

NGEC0538S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|----------------------------|------------------|-----------|
| Vehicle speed sensor | Vehicle speed | Fuel cut control | Injectors |
| Park/neutral position (PNP) switch | Neutral position | | |
| Throttle position sensor | Throttle position | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Camshaft position sensor | Engine speed | | |

If the engine speed is above 2,500 rpm with no load (for example, in neutral and engine speed over 2,500 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 2,000 rpm, then fuel cut is cancelled.


NOTE:

This function is different from deceleration control listed under "Multiport Fuel Injection (MFI) System", EC-599.

Evaporative Emission System


DESCRIPTION

NGEC0539



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases. EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

Evaporative Emission System (Cont'd)



INSPECTION


EVAP Canister

Check EVAP canister as follows:

1. Pinch the fresh air hose.
2. Blow air into port **A** and check that it flows freely out of port **B**.

NGEC0540

NGEC0540S01




Tightening Torque

Tighten EVAP canister as shown in the figure.

Make sure new O-ring is installed properly between EVAP canister and EVAP canister vent control valve.

NGEC0540S02



Fuel Tank Vacuum Relief Valve (Built into fuel filler cap)

NGEC0540S03

1. Wipe clean valve housing.
2. Check valve opening pressure and vacuum.

Pressure:

15.3 - 20.0 kPa (0.156 - 0.204 kg/cm², 2.22 - 2.90 psi)


Vacuum:

-6.0 to -3.3 kPa (-0.061 to -0.034 kg/cm², -0.87 to -0.48 psi)

3. If out of specification, replace fuel filler cap as an assembly.

CAUTION:

Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come ON



Vacuum Cut Valve and Vacuum Cut Valve Bypass Valve

NGEC0540S04

Refer to EC-1112.

Evaporative Emission (EVAP) Canister Purge Volume Control Solenoid Valve

NGEC0540S05

Refer to EC-950.

Tank Fuel Temperature Sensor


NGEC0540S06

Refer to EC-875.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

VG33E


Evaporative Emission System (Cont'd)



Evap Service Port

NGEC0540S07

Positive pressure is delivered to the EVAP system through the EVAP service port. If fuel vapor leakage in the EVAP system occurs, use a leak detector to locate the leak.



How to Detect Fuel Vapor Leakage

NGEC0540S08

CAUTION:



- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in EVAP system.

NOTE:

- Do not start engine.
- Improper installation of EVAP service port adapter to the EVAP service port may cause a leak.

Ⓜ With CONSULT-II

- 1) Attach the EVAP service port adapter securely to the EVAP service port.
- 2) Also attach the pressure pump and hose to the EVAP service port adapter.
- 3) Turn ignition switch ON.
- 4) Select the "EVAP SYSTEM CLOSE" of "WORK SUPPORT MODE" with CONSULT-II.
- 5) Touch "START". A bar graph (Pressure indicating display) will appear on the screen.
- 6) Apply positive pressure to the EVAP system until the pressure indicator reaches the middle of the bar graph.
- 7) Remove EVAP service port adapter and hose with pressure pump.
- 8) Locate the leak using a leak detector. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-607.





GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

VG33E

Evaporative Emission System (Cont'd)



⊗ Without CONSULT-II

- 1) Attach the EVAP service port adapter securely to the EVAP service port.
- 2) Also attach the pressure pump with pressure gauge to the EVAP service port adapter.
- 3) Apply battery voltage to between the terminals of both EVAP canister vent control valve and vacuum cut valve bypass valve to make a closed EVAP system.
- 4) To locate the leak, deliver positive pressure to the EVAP system until pressure gauge points reach 1.38 - 2.76 kPa (0.014 - 0.028 kg/cm², 0.2 - 0.4 psi).
- 5) Remove EVAP service port adapter and hose with pressure pump.
- 6) Locate the leak using a leak detector. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-607.


ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

VG33E

Evaporative Emission System (Cont'd)

EVAPORATIVE EMISSION LINE DRAWING

NGEC0541



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

AEC070B

SC


EL

IDX





ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

VG33E

Evaporative Emission System (Cont'd)



AEC886A



Positive Crankcase Ventilation DESCRIPTION

NGEC0542

This system returns blow-by gas to the intake manifold. The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.

INSPECTION

NGEC0543

PCV (Positive Crankcase Ventilation) Valve

NGEC0543S01

With engine running at idle, remove PCV valve ventilation hose from PCV valve; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.




PCV Valve Ventilation Hose

NGEC0543S02

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Fuel Pressure Release



Fuel Pressure Release

NGEC0544

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

Ⓜ WITH CONSULT-II

NGEC0544S01

1. Turn ignition switch ON.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.

ⓧ WITHOUT CONSULT-II


NGEC0544S02

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.
5. Reinstall fuel pump fuse after servicing fuel system.

Fuel Pressure Check

NGEC0545

- When reconnecting fuel line, always use new clamps.
 - Make sure that clamp screw does not contact adjacent parts.
 - Use a torque driver to tighten clamps.
 - Use Pressure Gauge to check fuel pressure.
 - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
1. Release fuel pressure to zero.
 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).



3. Install pressure gauge between fuel filter and fuel tube.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

At idling:


With vacuum hose connected

Approximately 235 kPa (2.4 kg/cm², 34 psi)

With vacuum hose disconnected

Approximately 294 kPa (3.0 kg/cm², 43 psi)


If results are unsatisfactory, perform Fuel Pressure Regulator Check.



Fuel Pressure Regulator Check


NGEC0546

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a blind cap.
3. Connect variable vacuum source to fuel pressure regulator.



4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.




Injector


REMOVAL AND INSTALLATION

NGEC0547


1. Release fuel pressure to zero. Refer to EC-610.
2. Drain coolant by removing drain plugs from both sides of cylinder block.
3. Separate ASCD and accelerator control wire from intake manifold collector.
4. Remove intake manifold collector from engine. The following parts should be disconnected or removed.
 - a. Harness connectors for
 - IACV-AAC valve
 - IACV-FICD solenoid valve
 - Throttle position sensor and closed throttle position switch assembly
 - EGRC-solenoid valve (If so equipped)
 - EGR temperature sensor (If so equipped)
 - Ground harness
 - b. PCV valve ventilation hoses
 - c. Vacuum hoses for
 - Brake booster
 - EGRC-solenoid valve (If so equipped)



- Fuel pressure regulator
- EGRC-BPT valve (If so equipped)
- d. Air hoses from
 - Air duct
 - IACV-AAC valve
- e. Water hoses for
 - Throttle body
 - Air relief plug
- f. EVAP canister purge hose
- g. EGR flare tube (If so equipped)
- 5. Remove injector fuel tube assembly.
The following parts should be disconnected or removed.
 - Vacuum hose for fuel pressure regulator
 - Fuel feed and return hose
 - All injectors harness connectors
 - **Push injector tail piece.**
 - **Do not pull on connector.**
 - **Do not extract injector by pinching.**




6. Push out any malfunctioning injector from injector fuel tube.
7. Replace or clean injector as necessary.
 - **Always replace O-rings with new ones.**
 - **Lubricate O-rings with engine oil.**
8. Install injector to injector fuel tube assembly.



9. Install injectors with fuel tube assembly to intake manifold.
Tighten in numerical order shown in the figure.
 - a. First, tighten all bolts to 4.9 to 6.0 N-m (0.5 to 0.61 kg-m, 3.6 to 4.4 ft-lb).
 - b. Then, tighten all bolts to 10.8 to 14.7 N-m (1.1 to 1.5 kg-m, 8 to 11 ft-lb).
10. Reinstall any part removed in reverse order of removal.

CAUTION:
After properly connecting fuel hose to injector and fuel tube, check connection for fuel leakage.








Fast Idle Cam (FIC) INSPECTION AND ADJUSTMENT

With CONSULT-II

1. Turn ignition switch ON.
2. See "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
3. When engine coolant temperature is 20 to 30°C (68 to 86°F), make sure that the center of mark **A** is aligned with mark **B** as shown in the figure.

NGEC0548

NGEC0548S01



- If NG, adjust by turning adjusting screw.

Lock nut:

 : 0.98 - 1.96 N·m (10 - 20 kg·cm, 8.7 - 17.4 in·lb)

4. Start engine and warm it up.
5. When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.
 - The center of mark A is aligned with mark C.
 - The cam follower lever's roller is not touching the fast idle cam.
 - If NG, replace thermo-element and perform the above inspection and adjustment again.

⊗ Without CONSULT-II
NGEC0548S02

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 59 (Engine coolant temperature sensor signal) and ground.
3. When the voltage is between 3.12 to 3.52V, make sure that the center of mark A is aligned with mark B as shown in the figure.

- If NG, adjust by turning adjusting screw.

Lock nut:

 : 0.98 - 1.96 N·m (10 - 20 kg·cm, 8.7 - 17.4 in·lb)

4. Start engine and warm it up.
5. When the voltage is between 1.10 to 1.36V, check the following.
 - The center of mark A is aligned with mark C.
 - The cam follower lever's roller is not touching the fast idle cam.
 - If NG, replace thermo-element and perform the above inspection and adjustment again.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment

NGEC0549


NGEC0549S01

PREPARATION

- 1) Make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels
 - Fuses
 - ECM harness connector
 - Vacuum hoses
 - Air intake system
(Oil filler cap, oil level gauge, etc.)
 - Fuel pressure
 - Engine compression
 - EGR valve operation (If so equipped)
 - Throttle valve
 - Evaporative emission system
- 2) On air conditioner equipped models, checks should be carried out while the air conditioner is OFF.
- 3) On automatic transmission equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
- 4) When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- 5) Turn off headlamps, heater blower, rear defogger.
- 6) Keep front wheels pointed straight ahead.
- 7) Make the check after the cooling fan has stopped.

Overall Inspection Sequence

NGEC0549S0101



SEF117W

NOTE:

If a vehicle contains a part which is operating outside of design specifications with no MIL illumination, the part shall not be replaced prior to emission testing unless it is determined that the part has been tampered with or abused in such a way that the diagnostic system cannot reasonably be expected to detect the resulting malfunction.


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

INSPECTION PROCEDURE

=NGEC0549S02


1 INSPECTION START

1. Visually check the following:
 - Air cleaner clogging
 - Hoses and ducts for leaks
 - EGR valve operation (If so equipped)
 - Electrical connectors
 - Gasket
 - Throttle valve and throttle position sensor operation
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. Ensure engine stays below 1,000 rpm.



SEF976U

3. Open engine hood and run engine at about 2,000 rpm for about 2 minutes under no-load.



SEF977U

4. Perform diagnostic test mode II (Self-diagnostic results). Refer to EC-644.



SEF217U

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 2. |
| NG | ▶ | 1. Repair or replace components as necessary. 2. GO TO 2. |


BASIC SERVICE PROCEDURE

VG33E


Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

2 CHECK IGNITION TIMING


1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.



3. Turn off engine and disconnect throttle position sensor harness connector.



4. Start and rev engine (2,000 - 3,000 rpm) two or three times under no-load, then run at idle speed.
5. Check ignition timing with a timing light.



15°±2° BTDC (in "P" or "N" position)

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 3. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

3 ADJUST IGNITION TIMING

1. Adjust ignition timing by turning distributor after loosening securing bolts.
2. Turn off engine and connect throttle position sensor harness connector to throttle position sensor.



SEF972R

▶ GO TO 2.

4 CHECK BASE IDLE SPEED

Ⓟ With CONSULT-II

1. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |

700±50 rpm (in "P" or "N" position)

PEF356V


ⓧ Without CONSULT-II

1. Check idle speed.

700±50 rpm (in "P" or "N" position)

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |

| | |
|---|-------------------------------|
| 5 | ADJUST BASE IDLE SPEED |
| <ol style="list-style-type: none"> 1. Rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run engine at idle speed. 2. Adjust idle speed by turning idle speed adjusting screw. | |
|  | |
| 700±50 rpm (in "P" or "N" position) | |
| SEF973R | |
| ▶ GO TO 6. | |

| 6 | CHECK TARGET IDLE SPEED | | | | | | |
|--|--------------------------------|--------------|--|------------|---------|---------------|---------|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn off engine and connect throttle position sensor harness connector. 2. Start and rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run at idle speed. 3. Read idle speed in "DATA MONITOR" mode with CONSULT-II. | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;">NO FAIL</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">CMPS-RPM(REF)</td> <td style="text-align: center;">XXX rpm</td> </tr> </tbody> </table> | | DATA MONITOR | | MONITORING | NO FAIL | CMPS-RPM(REF) | XXX rpm |
| DATA MONITOR | | | | | | | |
| MONITORING | NO FAIL | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | |
| 750±50 rpm (in "P" or "N" position) | | | | | | | |
| PEF356V | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn off engine and connect throttle position sensor harness connector. 2. Start and rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run at idle speed. 3. Check idle speed. | | | | | | | |
| 750±50 rpm (in "P" or "N" position) | | | | | | | |
| OK or NG | | | | | | | |
| OK (With CONSULT-II) | ▶ GO TO 8. | | | | | | |
| OK (Without CONSULT-II) | ▶ GO TO 9. | | | | | | |
| NG | ▶ GO TO 7. | | | | | | |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


BASIC SERVICE PROCEDURE

VG33E

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

| | | |
|--|-----------------------------------|----------|
| 7 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ol style="list-style-type: none"> 1. Check IACV-AAC valve and replace if necessary. Refer to EC-992. 2. Check IACV-AAC valve harness and repair if necessary. Refer to EC-992. 3. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.) | | |
| With CONSULT-II | ▶ | GO TO 8. |
| Without CONSULT-II | ▶ | GO TO 9. |

| 8 | CHECK FRONT HEATED OXYGEN SENSOR LH SIGNAL | | | | | | | | | | | |
|--|---|---|--------------|--|------------|---------|---------------|---------|---------------|------|---------------|------|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Run engine at about 2,000 rpm for about 2 minutes under no-load. 2. See "FR O2 MNTR-B2" in "DATA MONITOR" mode. 3. Running engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds. | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th>NO FAIL</th> </tr> </thead> <tbody> <tr> <td>CMPS-RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td>LEAN</td> </tr> <tr> <td>FR O2 MNTR-B2</td> <td>RICH</td> </tr> </tbody> </table> | | | DATA MONITOR | | MONITORING | NO FAIL | CMPS-RPM(REF) | XXX rpm | FR O2 MNTR-B1 | LEAN | FR O2 MNTR-B2 | RICH |
| DATA MONITOR | | | | | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | |
| FR O2 MNTR-B1 | LEAN | | | | | | | | | | | |
| FR O2 MNTR-B2 | RICH | | | | | | | | | | | |
| PEF358V | | | | | | | | | | | | |
| <p>1 time: RICH → LEAN → RICH 2 times: RICH → LEAN → RICH → LEAN → RICH</p> <p>OK or NG</p> | | | | | | | | | | | | |
| OK | ▶ | GO TO 12. | | | | | | | | | | |
| NG (Monitor does not fluctuate.) | ▶ | GO TO 17. | | | | | | | | | | |
| NG (Monitor fluctuates less than 5 times.) | ▶ | <ol style="list-style-type: none"> 1. Replace front heated oxygen sensor LH. 2. GO TO 10. | | | | | | | | | | |

| | | | | | | | | | | | | |
|------------------------------------|---|--|---|---|-----------|--------------------------|---|-----------|------------------------------------|---|---|--|
| 9 | CHECK FRONT HEATED OXYGEN SENSOR LH SIGNAL | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Run engine at about 2,000 rpm for about 2 minutes under no-load. 2. Set "Left bank front heated oxygen sensor monitor" in the Diagnostic Test Mode II. Refer to EC-644. <div style="text-align: center; margin: 10px 0;">  </div> <ol style="list-style-type: none"> 3. Make sure that MIL goes on more than 5 times during 10 seconds at 2,000 rpm. <div style="text-align: center; margin: 20px 0;">  <p style="margin-top: 5px;">OK or NG</p> </div> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 5px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> | | | | | | | | | |
| | | <p>SEF979U</p> <p>SEF217U</p> | | | | | | | | | | |
| | | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td style="width: 70%;">GO TO 12.</td> </tr> <tr> <td>NG (MIL does not blink.)</td> <td style="text-align: center;">▶</td> <td>GO TO 17.</td> </tr> <tr> <td>NG (MIL blinks less than 5 times.)</td> <td style="text-align: center;">▶</td> <td> <ol style="list-style-type: none"> 1. Replace front heated oxygen sensor LH. 2. GO TO 10. </td> </tr> </table> | OK | ▶ | GO TO 12. | NG (MIL does not blink.) | ▶ | GO TO 17. | NG (MIL blinks less than 5 times.) | ▶ | <ol style="list-style-type: none"> 1. Replace front heated oxygen sensor LH. 2. GO TO 10. | |
| OK | ▶ | GO TO 12. | | | | | | | | | | |
| NG (MIL does not blink.) | ▶ | GO TO 17. | | | | | | | | | | |
| NG (MIL blinks less than 5 times.) | ▶ | <ol style="list-style-type: none"> 1. Replace front heated oxygen sensor LH. 2. GO TO 10. | | | | | | | | | | |

| | | | | | | | | | | | | |
|-------------------------|---|--|---|---|-----------|-------------------------|---|-----------|----|---|-----------|--|
| 10 | CHECK FRONT HEATED OXYGEN SENSOR LH SIGNAL | <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Warm engine to normal operating temperature. 2. Run engine at approx. 2000 rpm for approx. 2 minutes under no-load. 3. See "FR O2 MNTR-B2" in "DATA MONITOR" mode. 4. Running engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds. 1 time: RICH → LEAN → RICH 2 times: RICH → LEAN → RICH → LEAN → RICH <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Warm engine to normal operating temperature. 2. Run engine at approx. 2000 rpm for approx. 2 minutes under no-load. 3. Set "Left bank front heated oxygen sensor monitor" in the Diagnostic Test Mode II. Refer to EC-644. 4. Make sure that MIL goes on more than 5 times during 10 seconds at 2,000 rpm. <p style="text-align: center;">OK or NG</p> | <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> | | | | | | | | | |
| | | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">OK (With CONSULT-II)</td> <td style="width: 5%; text-align: center;">▶</td> <td style="width: 70%;">GO TO 12.</td> </tr> <tr> <td>OK (Without CONSULT-II)</td> <td style="text-align: center;">▶</td> <td>GO TO 13.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 11.</td> </tr> </table> | OK (With CONSULT-II) | ▶ | GO TO 12. | OK (Without CONSULT-II) | ▶ | GO TO 13. | NG | ▶ | GO TO 11. | |
| OK (With CONSULT-II) | ▶ | GO TO 12. | | | | | | | | | | |
| OK (Without CONSULT-II) | ▶ | GO TO 13. | | | | | | | | | | |
| NG | ▶ | GO TO 11. | | | | | | | | | | |


BASIC SERVICE PROCEDURE

VG33E

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

| | |
|---|-----------------------------------|
| 11 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ol style="list-style-type: none"> 1. Check fuel pressure regulator. Refer to EC-611. 2. Check mass air flow sensor and its circuit. Refer to EC-713. 3. Check injector and its circuit. Refer to EC-1145. Clean or replace if necessary. 4. Check engine coolant temperature sensor and its circuit. Refer to EC-758. 5. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.) | |
| | GO TO 2. |

| 12 | CHECK FRONT HEATED OXYGEN SENSOR RH SIGNAL | | | | | | | | | | |
|--|---|--------------|--|------------|---------|---------------|---------|---------------|------|---------------|------|
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. See "FR O2 MNTR-B1" in "DATA MONITOR" mode. 2. Maintaining engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds. | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="padding: 2px;">DATA MONITOR</th> </tr> <tr> <th style="padding: 2px;">MONITORING</th> <th style="padding: 2px;">NO FAIL</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">CMPS-RPM(REF)</td> <td style="padding: 2px;">XXX rpm</td> </tr> <tr> <td style="padding: 2px;">FR O2 MNTR-B1</td> <td style="padding: 2px;">LEAN</td> </tr> <tr> <td style="padding: 2px;">FR O2 MNTR-B2</td> <td style="padding: 2px;">RICH</td> </tr> </tbody> </table> | | DATA MONITOR | | MONITORING | NO FAIL | CMPS-RPM(REF) | XXX rpm | FR O2 MNTR-B1 | LEAN | FR O2 MNTR-B2 | RICH |
| DATA MONITOR | | | | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | |
| FR O2 MNTR-B1 | LEAN | | | | | | | | | | |
| FR O2 MNTR-B2 | RICH | | | | | | | | | | |
| PEF358V | | | | | | | | | | | |
| <p>1 time: RICH → LEAN → RICH 2 times: RICH → LEAN → RICH → LEAN → RICH</p> <p>OK or NG</p> | | | | | | | | | | | |
| OK | INSPECTION END | | | | | | | | | | |
| NG (Monitor does not fluctuate.) | GO TO 16. | | | | | | | | | | |
| NG (Monitor fluctuates less than 5 times.) | <ol style="list-style-type: none"> 1. Replace front heated oxygen sensor RH. 2. GO TO 14. | | | | | | | | | | |

| | |
|--|---|
| 13 | CHECK FRONT HEATED OXYGEN SENSOR RH SIGNAL |
| <p>⊗ Without CONSULT-II</p> <p>1. Set "Right bank front heated oxygen sensor monitor" in the Diagnostic Test Mode II. Refer to EC-644.</p> <div style="text-align: center;">  </div> <p>2. Make sure that MIL goes on more than 5 times during 10 seconds at 2,000 rpm.</p> <div style="text-align: center;">  <p>OK or NG</p> </div> | |
| SEF979U | |
| SEF217U | |
| OK | ▶ INSPECTION END |
| NG (MIL does not blink.) | ▶ GO TO 16. |
| NG (MIL blinks less than 5 times.) | ▶ 1. Replace front heated oxygen sensor RH. 2. GO TO 14. |

| | |
|--|---|
| 14 | CHECK FRONT HEATED OXYGEN SENSOR RH SIGNAL |
| <p>Ⓜ With CONSULT-II</p> <p>1. Warm engine to normal operating temperature.</p> <p>2. Run engine at approx. 2000 rpm for approx. 2 minutes under no-load.</p> <p>3. See "FR O2 MNTR-B1" in "DATA MONITOR" mode.</p> <p>4. Maintaining engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.</p> <p style="margin-left: 20px;">1 time: RICH → LEAN → RICH</p> <p style="margin-left: 20px;">2 times: RICH → LEAN → RICH → LEAN → RICH</p> | |
| <p>⊗ Without CONSULT-II</p> <p>1. Warm engine to normal operating temperature.</p> <p>2. Run engine at approx. 2000 rpm for approx. 2 minutes under no-load.</p> <p>3. Set "Right bank front heated oxygen sensor monitor" in the Diagnostic Test Mode II. Refer to EC-644.</p> <p>4. Make sure that MIL goes on more than 5 times during 10 seconds at 2,000 rpm.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ INSPECTION END |
| NG | ▶ GO TO 15. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | |
|---|-----------------------------------|
| 15 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ol style="list-style-type: none"> 1. Check fuel pressure regulator. Refer to EC-611. 2. Check mass air flow sensor and its circuit. Refer to EC-713. 3. Check injector and its circuit. Refer to EC-1145. Clean or replace if necessary. 4. Check engine coolant temperature sensor and its circuit. Refer to EC-758. 5. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.) | |
| | GO TO 2. |

| | |
|---|--|
| 16 | CHECK FRONT HEATED OXYGEN SENSOR RH HARNESS |
| <ol style="list-style-type: none"> 1. Turn off engine and disconnect battery ground cable. 2. Disconnect ECM harness connector. 3. Disconnect front heated oxygen sensor RH harness connector. 4. Check harness continuity between ECM terminal 50 and front heated oxygen sensor RH harness connector. | |
| | |
| <p>Continuity should exist.</p> <p>OK or NG</p> | |
| OK | <ol style="list-style-type: none"> 1. Connect ECM harness connector. 2. GO TO 18. |
| NG | <ol style="list-style-type: none"> 1. Repair or replace harness. 2. GO TO 8. (With CONSULT-II) GO TO 9. (Without CONSULT-II) |



SEF980U

| | |
|---|---|
| 17 | CHECK FRONT HEATED OXYGEN SENSOR LH HARNESS |
| <ol style="list-style-type: none"> 1. Turn off engine and disconnect battery ground cable. 2. Disconnect ECM harness connector. 3. Disconnect front heated oxygen sensor LH harness connector. 4. Check harness continuity between ECM terminal 51 and front heated oxygen sensor LH harness connector. | |
| | |
| <p>Continuity should exist.</p> <p>OK or NG</p> | |
| OK | <ol style="list-style-type: none"> 1. Connect ECM harness connector. 2. GO TO 18. |
| NG | <ol style="list-style-type: none"> 1. Repair or replace harness. 2. GO TO 8. (With CONSULT-II) GO TO 9. (Without CONSULT-II) |

| 18 | PREPARATION FOR "CO" % CHECK | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------------|-------------|--|--------------|-----|---------|--|---------------|---------|--------------|----------|--------------|----------|------------|----------|--|--|--|--|--|--|
| <p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Select "COOLANT TEMP" in "ACTIVE TEST" mode. 2. Set "COOLANT TEMP" to 5°C (41°F) by touching "DWN" and "Qd". | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>COOLANT TEMP</td> <td style="text-align: center;">5°C</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS-RPM(REF)</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td>INJ PULSE-B2</td> <td style="text-align: center;">XXX msec</td> </tr> <tr> <td>INJ PULSE-B1</td> <td style="text-align: center;">XXX msec</td> </tr> <tr> <td>IGN TIMING</td> <td style="text-align: center;">XXX BTDC</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | ACTIVE TEST | | COOLANT TEMP | 5°C | MONITOR | | CMPS-RPM(REF) | XXX rpm | INJ PULSE-B2 | XXX msec | INJ PULSE-B1 | XXX msec | IGN TIMING | XXX BTDC | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| COOLANT TEMP | 5°C | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| INJ PULSE-B2 | XXX msec | | | | | | | | | | | | | | | | | | | | |
| INJ PULSE-B1 | XXX msec | | | | | | | | | | | | | | | | | | | | |
| IGN TIMING | XXX BTDC | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |

| | |
|---|--|
| <p>Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Disconnect engine coolant temperature sensor harness connector. 2. Connect a resistor (4.4 kΩ) between terminals of engine coolant temperature sensor harness connector. | |
| | |
| <p>GO TO 19.</p> | |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

| | | |
|---|---------------------|--|
| 19 | CHECK "CO" % | |
| <p>1. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge.</p> <div style="text-align: center;">  <p>TEMP </p> </div> | | |
| <p>2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.</p> <div style="text-align: center;">  <p>x1000 r/min</p> </div> | | |
| <p>3. Check "CO" %.</p> <p style="margin-left: 20px;">Idle CO: 1.5 - 9%</p> <p>4. Without CONSULT-II After checking CO%,</p> <p style="margin-left: 20px;">a. Disconnect the resistor from terminals of engine coolant temperature sensor.</p> <p style="margin-left: 20px;">b. Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | <p>1. Replace front heated oxygen sensor LH.</p> <p>2. GO TO 10.</p> |
| NG | ▶ | GO TO 20. |

SEF976U

SEF978U

| | | |
|---|-----------------------------------|----------|
| 20 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ol style="list-style-type: none"> 1. Connect front heated oxygen sensor harness connectors to front heated oxygen sensors. 2. Check fuel pressure regulator. Refer to EC-611. 3. Check mass air flow sensor and its circuit. Refer to EC-713. 4. Check injector and its circuit. Refer to EC-1145. Clean or replace if necessary. 5. Check engine coolant temperature sensor and its circuit. Refer to EC-758. 6. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.) | | |
| | ▶ | GO TO 2. |

Introduction

NGEC0550

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

| Emission-related diagnostic information | SAE Mode |
|---|---------------------|
| Diagnostic Trouble Code (DTC) | Mode 3 of SAE J1979 |
| Freeze Frame data | Mode 2 of SAE J1979 |
| System Readiness Test (SRT) code | Mode 1 of SAE J1979 |
| 1st Trip Diagnostic Trouble Code (1st Trip DTC) | Mode 7 of SAE J1979 |
| 1st Trip Freeze Frame data | |
| Test values and Test limits | Mode 6 of SAE J1979 |

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

| | DTC | 1st trip DTC | Freeze Frame data | 1st trip Freeze Frame data | SRT code | Test value |
|------------|-----|--------------|-------------------|----------------------------|----------|------------|
| ECM*3 | X | X*1 | — | — | — | — |
| CONSULT-II | X | X | X | X | X | — |
| GST | X | X*2 | X | — | X | X |

*1: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

*2: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

*3: In diagnostic test mode II (Self-diagnostic results)

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to EC-687.)

Two Trip Detection Logic

NGEC0551

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

X: Applicable —: Not applicable

| Items | MIL | | | | DTC | | 1st trip DTC | |
|--|----------|-------------|----------|-------------|---------------------|---------------------|---------------------|---------------------|
| | 1st trip | | 2nd trip | | 1st trip displaying | 2nd trip displaying | 1st trip displaying | 2nd trip displaying |
| | Blinking | Lighting up | Blinking | Lighting up | | | | |
| Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 (0701, 0603 - 0608) is being detected | X | — | — | — | — | — | X | — |
| Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 (0701, 0603 - 0608) is being detected | — | — | X | — | — | X | — | — |
| Closed loop control — DTC: P1148 (0307) | — | X | — | — | X | — | X | — |
| Fail-safe items | — | X | — | — | X*1 | — | X*1 | — |
| Except above | — | — | — | X | — | X | X | — |

*1: Except “ECM”.

Emission-related Diagnostic Information

NGEC0552

DTC AND 1ST TRIP DTC

NGEC0552S01

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640.

For malfunctions in which 1st trip DTCs are displayed, refer to EC-638. These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of SAE J1979. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to EC-667. Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

How to Read DTC and 1st Trip DTC

NGEC0552S0101

DTC and 1st trip DTC can be read by the following methods.

1)  **No Tools**

The number of blinks of the MIL in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 0101, 0201, 1003, 1104, etc.

These DTCs are controlled by NISSAN.

2)  **With CONSULT-II**

 **With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P1320, P0705, P0750, etc.

These DTCs are prescribed by SAE J2012.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, Mode II and GST do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

| DTC display | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>FAILURE DETECTED</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">IACV-AAC VALVE [P0505]</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | SELF DIAG RESULTS | | FAILURE DETECTED | TIME | IACV-AAC VALVE [P0505] | 0 | | | | | 1st trip DTC display | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>FAILURE DETECTED</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">IACV-AAC VALVE [P0505]</td> <td style="text-align: center;">1t</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | SELF DIAG RESULTS | | FAILURE DETECTED | TIME | IACV-AAC VALVE [P0505] | 1t | | | | |
|---------------------------|--|-------------------|--|------------------|------|---------------------------|---|--|--|--|--|----------------------|---|-------------------|--|------------------|------|---------------------------|----|--|--|--|--|
| | SELF DIAG RESULTS | | | | | | | | | | | | | | | | | | | | | | |
| | FAILURE DETECTED | TIME | | | | | | | | | | | | | | | | | | | | | |
| | IACV-AAC VALVE [P0505] | 0 | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| SELF DIAG RESULTS | | | | | | | | | | | | | | | | | | | | | | | |
| FAILURE DETECTED | TIME | | | | | | | | | | | | | | | | | | | | | | |
| IACV-AAC VALVE [P0505] | 1t | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |

AEC037B

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

NGEC0552S02

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed and absolute pressure at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see EC-654.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

| Priority | Items | |
|----------|----------------------------|--|
| 1 | Freeze frame data | Misfire — DTC: P0300 - P0306 (0701, 0603 - 0608) Fuel Injection System Function — DTC: P0171 (0115), P0172 (0114) |
| 2 | | Except the above items (Includes A/T related items) |
| 3 | 1st trip freeze frame data | |

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640.

SYSTEM READINESS TEST (SRT) CODE

NGEC0552S03

System Readiness Test (SRT) code is specified in Mode 1 of SAE J1979.

As part of enhanced emissions test for Inspection and Maintenance (I/M), certain states require that the status of srt be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "incomplete", use the information in this service manual to set the SRT to "complete".

In most cases, the ECM will automatically complete its self-diagnosis cycle during normal usage and the SRT status will indicate "complete" for each application system. Once set as "complete", the SRT status remains "complete" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern and the SRT will indicate "incomplete" for these items.

NOTE:

The SRT will also indicate "incomplete" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "complete" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "incomplete" for one or more of the SRT items, the vehicle is returned to the customer untested.

NOTE:

If MIL is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "complete" for all test items. Therefore, it is important to check SRT ("complete") and DTC (No DTCs) before the inspection.

This service manual contains the service procedure and support information to perform a comprehensive road test that enables the ECM to complete the SRT.

The following table shows required self-diagnostic items to set the SRT to "complete".

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

Emission-related Diagnostic Information (Cont'd)

| SRT item (CONSULT-II indication) | Performance Priority *1 | Required self-diagnostic items to set the SRT to "complete" | Corresponding DTC No. |
|-------------------------------------|----------------------------|---|--------------------------|
| CATALYST | 3 | Three way catalyst function | P0420, P0430 |
| EVAP SYSTEM | 2 | EVAP control system (small leak) (negative pressure) | P0440 |
| | – | EVAP control system (small leak) (positive pressure) | P1440 *2 |
| | 3 | EVAP control system purge flow monitoring | P1447 |
| O2 SENSOR | 3 | Front heated oxygen sensor (circuit) | P0130, P0150 |
| | | Front heated oxygen sensor (lean shift monitoring) | P0131, P0151 |
| | | Front heated oxygen sensor (rich shift monitoring) | P0132, P0152 |
| | | Front heated oxygen sensor (response monitoring) | P0133, P0153 |
| | | Front heated oxygen sensor (high voltage) | P0134, P0154 |
| | | Rear heated oxygen sensor (min. voltage monitoring) | P0137, P0157 |
| | | Rear heated oxygen sensor (max. voltage monitoring) | P0138, P0158 |
| | | Rear heated oxygen sensor (response monitoring) | P0139, P0159 |
| | | Rear heated oxygen sensor (high voltage) | P0140, P0160 |
| O2 SEN HEATER | 3 | Front heated oxygen sensor heater | P0135, P0155 |
| | | Rear heated oxygen sensor heater | P0141, P0161 |
| EGR SYSTEM (If so equipped) | 3 | EGR function (close) | P0400 |
| | | EGRC-BPT valve function | P0402 |
| | 1 | EGR function (open) | P1402 |

*1: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure) one by one based on the priority for models with CONSULT-II.

*2: P1440 [EVAP control system (small leak) (positive pressure) diagnosis] is a kind of the SRT related diagnosis. This diagnosis, however, does not contribute to setting the SRT as "complete" when no malfunction exists in the EVAP system. Therefore, P0440 must be used instead of P1440.

SRT Set Timing

SRT is set as "complete" after self-diagnosis has been performed one or more times. Completion of SRT will occur if the result is OK or NG. The set timing is different between them and is shown in the following table. NGEC0552S0301

| Self-diagnosis result | | Example | | | | |
|-----------------------|--------|----------------|-------------------------------|-------------------------------|-------------------------------|-------------------------------|
| | | Diagnosis | Ignition OFF – ON – OFF |
| All OK | Case 1 | P0400 | OK (1) | – (1) | OK (2) | – (2) |
| | | P0402 | OK (1) | – (1) | – (1) | OK (2) |
| | | P1402 | OK (1) | OK (2) | – (2) | – (2) |
| | | SRT of EGR | “complete” | “complete” | “complete” | “complete” |
| | Case 2 | P0400 | OK (1) | – (1) | – (1) | – (1) |
| | | P0402 | – (0) | – (0) | OK (1) | – (1) |
| | | P1402 | OK (1) | OK (2) | – (2) | – (2) |
| | | SRT of EGR | “incomplete” | “incomplete” | “complete” | “complete” |
| NG exists | Case 3 | P0400 | OK | OK | – | – |
| | | P0402 | – | – | – | – |
| | | P1402 | NG | – | NG | NG (Consecutive NG) |
| | | (1st trip) DTC | 1st trip DTC | – | 1st trip DTC | DTC (=MIL “ON”) |
| | | SRT of EGR | “incomplete” | “incomplete” | “incomplete” | “complete” |

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is OK.

–: Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a same cycle (Ignition OFF – ON – OFF), the SRT will indicate “complete”.

→ Case 1 above

When all SRT related self-diagnoses show OK results through several different cycles, the SRT will indicate “complete” at the time the respective self-diagnoses have at least one OK result.

→ Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate “complete”.

→ Case 3 above

The previous table shows that the minimum number of cycles for setting SRT as “incomplete” is one (1) for each self-diagnosis (Case 1 and 2) or two (2) for one self-diagnosis (Case 3). However, in preparation for the State emissions inspection, it is unnecessary of each self-diagnosis to be executed twice (Case 3) because of the following reasons;

- The SRT will indicate “complete” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “complete” of the SRT only with OK self-diagnosis result.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to “complete” of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “incomplete”.

NOTE:

SRT can be set as “complete” together with the DTC(s). Therefore, DTC check must always be carried out prior to the State emission inspection even though the SRT indicates “complete”.

How to Display SRT Code

1. **With CONSULT-II**
 Selecting “SRT STATUS” in “DTC CONFIRMATION” mode with CONSULT-II.
 For items whose SRT codes are set, a “CMLPT” is displayed on the CONSULT-II screen; for items whose SRT codes are not set, “INCMP” is displayed.
2. **With GST**
 Selecting Mode 1 with GST (Generic Scan Tool)

NGEC0552S0303

Emission-related Diagnostic Information (Cont'd)

A sample of CONSULT-II display for SRT code is shown below.

"INCMP" means the self-diagnosis is incomplete and SRT is not set. "CMPLT" means the self-diagnosis is complete and SRT is set.


| SRT STATUS | |
|---------------|-------|
| CATALYST | CMPLT |
| EVAP SYSTEM | INCMP |
| O2 SENSOR | CMPLT |
| O2 SEN HEATER | CMPLT |
| EGR SYSTEM | INCMP |

PEF215U

SRT Service Procedure

If a vehicle has been rejected for the State emissions inspection due to one or more SRT items indicating "incomplete", review the following flowchart diagnostic sequence.

NGEC0552S0302



*1 EC-628

*2 EC-631

*3 EC-633

How to Set SRT Code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

☑ With CONSULT-II

Perform corresponding DTC confirmation procedure one by one based on "Performance Priority" in the table on EC-629.

☒ Without CONSULT-II


The most efficient driving pattern in which SRT codes can be properly set is explained on EC-634. The driving pattern should be performed one or more times to set all SRT codes.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Driving Pattern

NGEC0552S0305

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.



- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time required, for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminals 59 and 43 is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminals 59 and 43 is lower than 1.4V).**
- **The engine is started at the tank fuel temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 60 and ground is less than 4.1V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- The driving pattern outlined in *2 must be repeated at least 3 times.


Pattern 4:

- Tests are performed after the engine has been operated for at least 17 minutes.
- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted all over again.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Operate the vehicle in the following driving pattern.

- 1) Decelerate vehicle to 0 km/h (0 MPH) and let engine idle.
- 2) Repeat driving pattern shown below at least 10 times.
- **During acceleration, hold the accelerator pedal as steady as possible.**
- 3) Repeat steps 1 and 2 until the EGR system SRT is set.



*3: Checking the vehicle speed with CONSULT-II or GST is advised.

Suggested Transmission Gear Position for A/T Models

Set the selector lever in the "D" position with the overdrive switch turned ON.

Emission-related Diagnostic Information (Cont'd)

Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.

| Gear change | For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]: | | For quick acceleration in low altitude areas and high altitude areas [over 1,219 m (4,000 ft)]: |
|-------------|--|----------------------------------|---|
| | ACCEL shift point km/h (MPH) | CRUISE shift point km/h (MPH) | km/h (MPH) |
| 1st to 2nd | 24 (15) | 24 (15) | 24 (15) |
| 2nd to 3rd | 40 (25) | 29 (18) | 40 (25) |
| 3rd to 4th | 58 (36) | 48 (30) | 64 (40) |
| 4th to 5th | 64 (40) | 63 (39) | 72 (45) |

Suggested Maximum Speed in Each Gear

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate. Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits and drive according to the road conditions to ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

| Gear | km/h (MPH) 2WD (AUTO mode) |
|------|-------------------------------|
| 1st | 50 (30) |
| 2nd | 95 (60) |

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

NGEC0552S04

The following is the information specified in Mode 6 of SAE J1979. The test value is a parameter used to determine whether a system/circuit diagnostic test is "OK" or "NG" while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (30 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

X: Applicable —: Not applicable

| SRT item | Self-diagnostic test item | Test value (GST display) | | Test limit | Application |
|-------------|--|--------------------------|-----|------------|-------------|
| | | TID | CID | | |
| CATALYST | Three way catalyst function (Right bank) | 01H | 01H | Max. | X |
| | Three way catalyst function (Left bank) | 03H | 02H | Max. | X |
| EVAP SYSTEM | EVAP control system (Small leak) | 05H | 03H | Max. | X |
| | EVAP control system purge flow monitoring | 06H | 83H | Min. | X |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

Emission-related Diagnostic Information (Cont'd)

| SRT item | Self-diagnostic test item | Test value (GST display) | | Test limit | Application |
|--|--|--------------------------|------|------------|-------------|
| | | TID | CID | | |
| O2 SENSOR | Front heated oxygen sensor (Right bank) | 09H | 04H | Max. | X |
| | | 0AH | 84H | Min. | X |
| | | 0BH | 04H | Max. | X |
| | | 0CH | 04H | Max. | X |
| | | 0DH | 04H | Max. | X |
| | Front heated oxygen sensor (Left bank) | 11H | 05H | Max. | X |
| | | 12H | 85H | Min. | X |
| | | 13H | 05H | Max. | X |
| | | 14H | 05H | Max. | X |
| | | 15H | 05H | Max. | X |
| | Rear heated oxygen sensor (Right bank) | 19H | 86H | Min. | X |
| | | 1AH | 86H | Min. | X |
| | | 1BH | 06H | Max. | X |
| | | 1CH | 06H | Max. | X |
| | Rear heated oxygen sensor (Left bank) | 21H | 87H | Min. | X |
| | | 22H | 87H | Min. | X |
| 23H | | 07H | Max. | X | |
| 24H | | 07H | Max. | X | |
| O2 SENSOR HEATER | Front heated oxygen sensor heater (Right bank) | 29H | 08H | Max. | X |
| | | 2AH | 88H | Min. | X |
| | Front heated oxygen sensor heater (Left bank) | 2BH | 09H | Max. | X |
| | | 2CH | 89H | Min. | X |
| | Rear heated oxygen sensor heater (Right bank) | 2DH | 0AH | Max. | X |
| | | 2EH | 8AH | Min. | X |
| Rear heated oxygen sensor heater (Left bank) | 2FH | 0BH | Max. | X | |
| | 30H | 8BH | Min. | X | |
| EGR SYSTEM (If so equipped) | EGR function | 31H | 8CH | Min. | X |
| | | 32H | 8CH | Min. | X |
| | | 33H | 8CH | Min. | X |
| | | 34H | 8CH | Min. | X |
| | | 35H | 0CH | Max. | X |
| | EGRC-BPT valve function | 36H | 0CH | Max. | X |
| | | 37H | 8CH | Min. | X |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

Emission-related Diagnostic Information (Cont'd)

EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

NGEC055ZS05
X: Applicable —: Not applicable

| Items (CONSULT-II screen terms) | DTC*4 | | SRT code | Test value/ Test limit (GST only) | 1st trip DTC*4 | Reference page |
|---|---------------------|-------------|----------|---|----------------|-------------------|
| | CONSULT-II GST*2 | ECM*1 | | | | |
| NO SELF DIAGNOSTIC FAILURE INDICATED | P0000 | 0505 | — | — | — | — |
| MAF SEN/CIRCUIT | P0100 | 0102 | — | — | X | EC-713 |
| ABSL PRES SEN/CIRC | P0105 | 0803 | — | — | X | EC-722 |
| AIR TEMP SEN/CIRC | P0110 | 0401 | — | — | X | EC-734 |
| COOLANT T SEN/CIRC | P0115 | 0103 | — | — | X | EC-739 |
| THRTL POS SEN/CIRC | P0120 | 0403 | — | — | X | EC-744 |
| *COOLAN T SEN/CIRC | P0125 | 0908 | — | — | X | EC-758 |
| FRONT O2 SENSOR-B1 | P0130 | 0503 | X | X | X*3 | EC-763 |
| FRONT O2 SENSOR-B1 | P0131 | 0415 | X | X | X*3 | EC-772 |
| FRONT O2 SENSOR-B1 | P0132 | 0414 | X | X | X*3 | EC-780 |
| FRONT O2 SENSOR-B1 | P0133 | 0413 | X | X | X*3 | EC-788 |
| FRONT O2 SENSOR-B1 | P0134 | 0509 | X | X | X*3 | EC-801 |
| FR O2 SE HEATER-B1 | P0135 | 0901 | X | X | X*3 | EC-809 |
| REAR O2 SENSOR-B1 | P0137 | 0511 | X | X | X*3 | EC-815 |
| REAR O2 SENSOR-B1 | P0138 | 0510 | X | X | X*3 | EC-825 |
| REAR O2 SENSOR-B1 | P0139 | 0707 | X | X | X*3 | EC-835 |
| REAR O2 SENSOR-B1 | P0140 | 0512 | X | X | X*3 | EC-845 |
| RR O2 SE HEATER-B1 | P0141 | 0902 | X | X | X*3 | EC-853 |
| FRONT O2 SENSOR-B2 | P0150 | 0303 | X | X | X*3 | EC-763 |
| FRONT O2 SENSOR-B2 | P0151 | 0411 | X | X | X*3 | EC-772 |
| FRONT O2 SENSOR-B2 | P0152 | 0410 | X | X | X*3 | EC-780 |
| FRONT O2 SENSOR-B2 | P0153 | 0409 | X | X | X*3 | EC-788 |
| FRONT O2 SENSOR-B2 | P0154 | 0412 | X | X | X*3 | EC-801 |
| FR O2 SE HEATER-B2 | P0155 | 1001 | X | X | X*3 | EC-809 |
| REAR O2 SENSOR-B2 | P0157 | 0314 | X | X | X*3 | EC-815 |
| REAR O2 SENSOR-B2 | P0158 | 0313 | X | X | X*3 | EC-825 |
| REAR O2 SENSOR-B2 | P0159 | 0708 | X | X | X*3 | EC-835 |
| REAR O2 SENSOR-B2 | P0160 | 0315 | X | X | X*3 | EC-845 |
| RR O2 SE HEATER-B2 | P0161 | 1002 | X | X | X*3 | EC-853 |
| FUEL SYS LEAN/BK1 | P0171 | 0115 | — | — | X | EC-860 |
| FUEL SYS RICH/BK1 | P0172 | 0114 | — | — | X | EC-868 |
| FUEL SYS LEAN/BK2 | P0174 | 0210 | — | — | X | EC-860 |
| FUEL SYS RICH/BK2 | P0175 | 0209 | — | — | X | EC-868 |
| FUEL TEMP SEN/CIRC | P0180 | 0402 | — | — | X | EC-875 |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

Emission-related Diagnostic Information (Cont'd)

| Items (CONSULT-II screen terms) | DTC*4 | | SRT code | Test value/ Test limit (GST only) | 1st trip DTC*4 | Reference page | |
|------------------------------------|---------------------|-------|----------|---|----------------|-------------------|-----------|
| | CONSULT-II GST*2 | ECM*1 | | | | | |
| ENG OVER TEMP | P0217 | 0211 | — | — | X | EC-880 | GI |
| MULTI CYL MISFIRE | P0300 | 0701 | — | — | X | EC-893 | MA |
| CYL 1 MISFIRE | P0301 | 0608 | — | — | X | EC-893 | EM |
| CYL 2 MISFIRE | P0302 | 0607 | — | — | X | EC-893 | |
| CYL 3 MISFIRE | P0303 | 0606 | — | — | X | EC-893 | LC |
| CYL 4 MISFIRE | P0304 | 0605 | — | — | X | EC-893 | |
| CYL 5 MISFIRE | P0305 | 0604 | — | — | X | EC-893 | EC |
| CYL 6 MISFIRE | P0306 | 0603 | — | — | X | EC-893 | |
| KNOCK SEN/CIRC | P0325 | 0304 | — | — | — | EC-902 | FE |
| CPS/CIRCUIT (OBD) | P0335 | 0802 | — | — | X | EC-906 | |
| CAM POS SEN/CIRC | P0340 | 0101 | — | — | X | EC-912 | CL |
| EGR SYSTEM (If so equipped) | P0400 | 0302 | X | X | X*3 | EC-919 | MT |
| EGRC-BPT VALVE (If so equipped) | P0402 | 0306 | X | X | X*3 | EC-933 | AT |
| TW CATALYST SYS-B1 | P0420 | 0702 | X | X | X*3 | EC-941 | |
| TW CATALYST SYS-B2 | P0430 | 0703 | X | X | X*3 | EC-941 | TF |
| EVAP SMALL LEAK | P0440 | 0705 | X | X | X*3 | EC-947 | |
| PURG VOLUME CONT/V | P0443 | 1008 | — | — | X | EC-950 | PD |
| VENT CONTROL VALVE | P0446 | 0903 | — | — | X | EC-957 | |
| EVAP SYS PRES SEN | P0450 | 0704 | — | — | X | EC-963 | AX |
| EVAP GROSS LEAK | P0455 | 0715 | X | X | X | EC-974 | |
| VEH SPEED SEN/CIRC | P0500 | 0104 | — | — | X | EC-988 | SU |
| IACV/AAC VLV/CIRC | P0505 | 0205 | — | — | X | EC-992 | |
| CLOSED TP SW/CIRC | P0510 | 0203 | — | — | X | EC-998 | BR |
| A/T COMM LINE | P0600 | — | — | — | — | EC-1006 | |
| ECM | P0605 | 0301 | — | — | X | EC-1011 | ST |
| PNP SW/CIRC | P0705 | 1101 | — | — | X | AT-99 | |
| ATF TEMP SEN/CIRC | P0710 | 1208 | — | — | X | AT-105 | RS |
| VEH SPD SEN/CIR AT | P0720 | 1102 | — | — | X | AT-111 | |
| ENGINE SPEED SIG | P0725 | 1207 | — | — | X | AT-116 | BT |
| A/T 1ST GR FNCTN | P0731 | 1103 | — | — | X | AT-120 | |
| A/T 2ND GR FNCTN | P0732 | 1104 | — | — | X | AT-126 | HA |
| A/T 3RD GR FNCTN | P0733 | 1105 | — | — | X | AT-132 | |
| A/T 4TH GR FNCTN | P0734 | 1106 | — | — | X | AT-138 | SC |
| TCC SOLENOID/CIRC | P0740 | 1204 | — | — | X | AT-147 | EL |
| A/T TCC S/V FNCTN | P0744 | 1107 | — | — | X | AT-152 | |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

Emission-related Diagnostic Information (Cont'd)

| Items (CONSULT-II screen terms) | DTC*4 | | SRT code | Test value/ Test limit (GST only) | 1st trip DTC*4 | Reference page |
|---------------------------------------|---------------------|-------|----------|---|----------------|-------------------|
| | CONSULT-II GST*2 | ECM*1 | | | | |
| L/PRESS SOL/CIRC | P0745 | 1205 | — | — | X | AT-160 |
| SFT SOL A/CIRC | P0750 | 1108 | — | — | X | AT-165 |
| SFT SOL B/CIRC | P0755 | 1201 | — | — | X | AT-170 |
| MAP/BARO SW SOL/CIR | P1105 | 1302 | — | — | X | EC-1013 |
| CLOSED LOOP-B1 | P1148 | 0307 | — | — | X | EC-1026 |
| CLOSED LOOP-B2 | P1168 | 0308 | — | — | X | EC-1026 |
| IGN SIGNAL-PRIMARY | P1320 | 0201 | — | — | X | EC-1028 |
| CPS/CIRC (OBD) COG | P1336 | 0905 | — | — | X | EC-1036 |
| EGRC SOLENOID/V (If so equipped) | P1400 | 1005 | — | — | X | EC-1043 |
| EGR TEMP SEN/CIRC (If so equipped) | P1401 | 0305 | — | — | X | EC-1048 |
| EGR SYSTEM (If so equipped) | P1402 | 0514 | X | X | X*3 | EC-1055 |
| EVAP SMALL LEAK | P1440 | 0213 | X | X | X*3 | EC-1065 |
| PURG VOLUME CONT/V | P1444 | 0214 | — | — | X | EC-1067 |
| VENT CONTROL VALVE | P1446 | 0215 | — | — | X | EC-1079 |
| EVAP PURG FLOW/MON | P1447 | 0111 | X | X | X*3 | EC-1086 |
| VENT CONTROL VALVE | P1448 | 0309 | — | — | X | EC-1098 |
| VC/V BYPASS/V | P1490 | 0801 | — | — | X | EC-1106 |
| VC CUT/V BYPASS/V | P1491 | 0311 | — | — | X | EC-1112 |
| A/T DIAG COMM LINE | P1605 | 0804 | — | — | X | EC-1121 |
| TP SEN/CIRC A/T | P1705 | 1206 | — | — | X | AT-175 |
| P-N POS SW/CIRCUIT | P1706 | 1003 | — | — | X | EC-1124 |
| O/R CLTCH SOL/CIRC | P1760 | 1203 | — | — | X | AT-184 |

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: These are not displayed with GST.

*4: 1st trip DTC No. is the same as DTC No.

NOTE:

Regarding D22 models, “-B1” and “BK1” indicate right bank and “-B2” and “BK2” indicate left bank.

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC (Ⓢ With CONSULT-II)

NGEC0552S06


NOTE:

NGEC0552S0601

If the DTC is not for A/T related items (see EC-581), skip steps 2 through 4.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Turn CONSULT-II “ON” and touch “A/T”.
3. Touch “SELF-DIAG RESULTS”.
4. Touch “ERASE”. [The DTC in the TCM (Transmission control module) will be erased.] Then touch “BACK” twice.
5. Touch “ENGINE”.
6. Touch “SELF-DIAG RESULTS”.

7. Touch "ERASE". (The DTC in the ECM will be erased.)
- If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).



The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

How to Erase DTC (🔧) With GST

NGEC0552S0602

NOTE:

If the DTC is not for A/T related items (see EC-581), skip step 2.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with GST (Generic Scan Tool).

The emission related diagnostic information in the ECM can be erased by selecting Mode 4 with GST.

How to Erase DTC (🚫) No Tools

NGEC0552S0603

NOTE:

If the DTC is not for A/T related items (see EC-581), skip step 2.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it "ON" again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis".
(The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)

Emission-related Diagnostic Information (Cont'd)

3. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. (See EC-644.)

The emission related diagnostic information in the ECM can be erased by changing the diagnostic test mode from Diagnostic Test Mode II to Mode I by turning the mode selector on the ECM.


- **If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.**
- **Erasing the emission-related diagnostic information using CONSULT-II or GST is easier and quicker than switching the mode selector on the ECM.**
- **The following data are cleared when the ECM memory is erased.**
 - 1) Diagnostic trouble codes
 - 2) 1st trip diagnostic trouble codes
 - 3) Freeze frame data
 - 4) 1st trip freeze frame data
 - 5) System readiness test (SRT) codes
 - 6) Test values
 - 7) Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

Malfunction Indicator Lamp (MIL)

DESCRIPTION

NGEC0553



The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to EL section ("WARNING LAMPS") or see EC-1170.
2. When the engine is started, the MIL should go OFF.
 - If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.

On Board Diagnostic System Function

=NGEC0553S01

The on board diagnostic system has the following four functions.

| Diagnostic Test Mode | KEY and ENG. Status | Function | Explanation of Function |
|----------------------|--|------------------------------------|--|
| Mode I | Ignition switch in ON position  Engine stopped  | BULB CHECK | This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit and ECM test mode selector. (See EC-644.) |
| | Engine running  | MALFUNCTION WARNING | This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MIL in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (Possible three way catalyst damage)" ● "Closed loop control" ● Fail-safe mode |
| Mode II | Ignition switch in ON position  Engine stopped  | SELF-DIAGNOSTIC RESULTS | This function allows DTCs and 1st trip DTCs to be read. |
| | Engine running  | FRONT HEATED OXYGEN SENSOR MONITOR | This function allows the fuel mixture condition (lean or rich), monitored by front heated oxygen sensor, to be read. |

MIL Flashing without DTC

NGEC0553S0101


If the ECM is in Diagnostic Test Mode II, MIL may flash when engine is running. In this case, check ECM test mode selector following "How to Switch Diagnostic Test Modes", EC-644.

How to switch the diagnostic test (function) modes, and details of the above functions are described later. (Refer to EC-644.)

The following emission-related diagnostic information is cleared when the ECM memory is erased.

- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Others

How to Switch Diagnostic Test Modes



- Switching the modes is not possible when the engine is running.
- When ignition switch is turned off during diagnosis, power to ECM will drop after approx. 5 seconds. The diagnosis will automatically return to Diagnostic Test Mode I.
- Turn back diagnostic test mode selector to the fully counterclockwise position whenever vehicle is in use.

*1 EC-1170

*3 EC-1170

*4 EC-687

*2 EC-642

Diagnostic Test Mode I — Bulb Check

NGEC0553S03

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to "WARNING LAMPS", **EL-87** or see EC-1170.

Diagnostic Test Mode I — Malfunction Warning

NGEC0553S04



| MIL | Condition |
|-----|--|
| ON | When the malfunction is detected or the ECM's CPU is malfunctioning. |
| OFF | No malfunction. |

- These DTC Numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS).

Diagnostic Test Mode II — Self-diagnostic Results

NGEC0553S05

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MIL. The DTC and 1st trip DTC are displayed at the same time. If the MIL does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTC's. If only one code is displayed when the MIL illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTC's or 1st trip DTC's. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-II or GST. A DTC will be used as an example for how to read a code.



Long (0.6 second) blinking indicates the two LH digits of number and short (0.3 second) blinking indicates the two RH digits of number. For example, the MIL blinks 10 times for 6 seconds (0.6 sec x 10 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "1003" and refers to the malfunction of the park/neutral position (PNP) switch.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC "0505" refers to no malfunction. (See TROUBLE DIAGNOSIS — INDEX, EC-581.)

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

NGEC0553S0501

The DTC can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "How to Switch Diagnostic Test Modes", EC-644.)

- If the battery is disconnected, the DTC will be lost from the backup memory after approx. 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

Diagnostic Test Mode II — Front Heated Oxygen Sensor Monitor

=NGEC0553S06

In this mode, the MIL displays the condition of the fuel mixture (lean or rich) which is monitored by the front heated oxygen sensor.

| | | |
|--------------------|---|---|
| MIL | Fuel mixture condition in the exhaust gas | Air fuel ratio feedback control condition |
| ON | Lean | Closed loop system |
| OFF | Rich | |
| *Remains ON or OFF | Any condition | Open loop system |

*: Maintains conditions just before switching to open loop.

To check the front heated oxygen sensor function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MIL comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

OBD System Operation Chart

NGEC0554

RELATIONSHIP BETWEEN MIL, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

NGEC0554S01

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to “Two Trip Detection Logic” on EC-627.
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The “TIME” in “SELF-DIAGNOSTIC RESULTS” mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in “OK” for the 2nd trip.

SUMMARY CHART

NGEC0554S02

| Items | Fuel Injection System | Misfire | Other |
|-------------------------------------|-----------------------|-------------------|----------------|
| MIL (goes off) | 3 (pattern B) | 3 (pattern B) | 3 (pattern B) |
| DTC, Freeze Frame Data (no display) | 80 (pattern C) | 80 (pattern C) | 40 (pattern A) |
| 1st Trip DTC (clear) | 1 (pattern C), *1 | 1 (pattern C), *1 | 1 (pattern B) |
| 1st Trip Freeze Frame Data (clear) | *1, *2 | *1, *2 | 1 (pattern B) |

For details about patterns “B” and “C” under “Fuel Injection System” and “Misfire”, see EC-648.


For details about patterns “A” and “B” under “Other”, see EC-650.

*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MISFIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"

NGEC0554S03



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame

- data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: The 1st trip DTC and the 1st trip

- freeze frame data will be cleared at the moment OK is detected.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

NGEC0554S04

<Driving Pattern B>

NGEC0554S0401

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MIL will go off when the B counter reaches 3. (*2 in “OBD SYSTEM OPERATION CHART”)

<Driving Pattern C>

NGEC0554S0402

Driving pattern C means the vehicle operation as follows:

1) The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), “T” should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), “T” should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)


To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NGEC0554S05



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC

- and the 1st trip freeze frame data will be stored in ECM.
- *6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NGEC0554S06

<Driving Pattern A>

NGEC0554S0601



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.


<Driving Pattern B>

NGEC0554S0602

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


=NGEC0555

NGEC0555S01


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to data link connector for CONSULT-II. (Data link connector for CONSULT-II is located under LH dash panel near the fuse box cover.)



3. Turn ignition switch ON.
4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

NGEC0555S02

| Item | | DIAGNOSTIC TEST MODE | | | | | | |
|--------------------------------|---|--------------------------|-------------------------|---------------------|---------------|-------------|------------------|-------------------|
| | | WORK SUP-PORT | SELF-DIAGNOSTIC RESULTS | | DATA MONI-TOR | ACTIVE TEST | DTC CONFIRMATION | |
| | | | DTC*1 | FREEZE FRAME DATA*2 | | | SRT STATUS | DTC WORK SUP-PORT |
| ENGINE CONTROL COMPONENT PARTS | INPUT | Camshaft position sensor | X | X | X | | | |
| | Mass air flow sensor | X | | X | | | | |
| | Engine coolant temperature sensor | X | X | X | X | | | |
| | Front heated oxygen sensor | X | | X | | X | X | |
| | Rear heated oxygen sensor | X | | X | | X | X | |
| | Vehicle speed sensor | X | X | X | | | | |
| | Throttle position sensor | X | | X | | | | |
| | Fuel tank temperature sensor | X | | X | X | | | |
| | EVAP control system pressure sensor | X | | X | | | | |
| | Absolute pressure sensor | X | | X | | | | |
| | EGR temperature sensor (If so equipped) | X | | X | | | | |
| | Intake air temperature sensor | X | | X | | | | |
| | Crankshaft position sensor (OBD) | X | | | | | | |
| | Knock sensor | X | | | | | | |
| | Ignition switch (start signal) | | | | X | | | |
| | Closed throttle position switch | X | | | X | | | |
| | Closed throttle position switch (throttle position sensor signal) | | | | X | | | |
| | Air conditioner switch | | | | X | | | |
| | Park/neutral position (PNP) switch | X | | | X | | | |
| | Power steering oil pressure switch | | | | X | | | |
| Battery voltage | | | | X | | | | |
| Ambient air temperature switch | | | | X | | | | |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

CONSULT-II (Cont'd)

| Item | | DIAGNOSTIC TEST MODE | | | | | | |
|---------------------------------------|---|----------------------|-------------------------|---------------------|--------------|-------------|------------------|-------------------|
| | | WORK SUP-PORT | SELF-DIAGNOSTIC RESULTS | | DATA MONITOR | ACTIVE TEST | DTC CONFIRMATION | |
| | | | DTC*1 | FREEZE FRAME DATA*2 | | | SRT STATUS | DTC WORK SUP-PORT |
| ENGINE CONTROL COMPONENT PARTS | OUTPUT | | | | X | X | | GI |
| | Injectors | | | | X | X | | MA |
| | Power transistor (Ignition timing) | | X (Ignition signal) | | X | X | | EM |
| | IACV-AAC valve | X | X | | X | X | | LC |
| | EVAP canister purge volume control solenoid valve | | X | | X | X | X | EC |
| | Air conditioner relay | | | | X | | | FE |
| | Fuel pump relay | X | | | X | X | | CL |
| | Cooling fan | | X | | X | X | | MT |
| | EGRC-solenoid valve (If so equipped) | | X | | X | X | | AT |
| | Front heated oxygen sensor heater | | X | | X | | X | AT |
| | Rear heated oxygen sensor heater | | X | | X | | X | TF |
| | EVAP canister vent control valve | | X | | X | X | | TF |
| | Vacuum cut valve bypass valve | | X | | X | X | X | PD |
| MAP/BARO switch solenoid valve | | X | | X | X | | PD | |
| Calculated load value | | | X | X | | | AX | |

X: Applicable

*1: This item includes 1st trip DTCs.

*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-629.

FUNCTION

=NGEC0555S03

| Diagnostic test mode | Function |
|-------------------------|---|
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit. |
| Self-diagnostic results | Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly. *1 |
| Data monitor | Input/Output data in the ECM can be read. |
| Active test | Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range. |
| DTC & SRT confirmation | The status of system monitoring tests and the self-diagnosis status/result can be confirmed. |
| ECM part number | ECM part number can be read. |

*1 The following emission-related diagnostic information is cleared when the ECM memory is erased.

- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Others

WORK SUPPORT MODE

NGEC0555S04

| WORK ITEM | CONDITION | USAGE |
|-----------------------|--|---|
| IACV-AAC VALVE ADJ | SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● ENGINE WARMED UP ● NO-LOAD | When adjusting initial ignition timing and idle speed |
| FUEL PRESSURE RELEASE | <ul style="list-style-type: none"> ● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. ● CRANK A FEW TIMES AFTER ENGINE STALLS. | When releasing fuel pressure from fuel line |
| EVAP SYSTEM CLOSE | OPEN THE VACUUM CUT VALVE BYPASS VALVE AND CLOSE THE EVAP CANISTER VENT CONTROL VALVE IN ORDER TO MAKE EVAP SYSTEM CLOSE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● IGN SW ON ● ENGINE NOT RUNNING ● AMBIENT TEMPERATURE IS ABOVE 0°C (32°F). ● NO VACUUM AND NO HIGH PRESSURE IN EVAP SYSTEM ● FUEL TANK TEMP. IS MORE THAN 0°C (32°F). ● WITHIN 10 MINUTES AFTER STARTING "EVAP SYSTEM CLOSE" ● WHEN TRYING TO EXECUTE "EVAP SYSTEM CLOSE" UNDER THE CONDITION EXCEPT ABOVE, CONSULT-II WILL DISCONTINUE IT AND DISPLAY APPROPRIATE INSTRUCTION. <p>NOTE: WHEN STARTING ENGINE, CONSULT-II MAY DISPLAY "BATTERY VOLTAGE IS LOW. CHARGE BATTERY", EVEN IN USING CHARGED BATTERY.</p> | When detecting EVAP vapor leak point of EVAP system |

SELF-DIAGNOSTIC MODE

NGEC0555S05

DTC and 1st Trip DTC

NGEC0555S0501

Regarding items of "DTC and 1st trip DTC", refer to "TROUBLE DIAGNOSIS — INDEX" (See EC-581.)

Freeze Frame Data and 1st Trip Freeze Frame Data

NGEC0555S0502

| Freeze frame data item *1 | Description | |
|---|---|----------|
| DIAG TROUBLE CODE [PXXXX] | <ul style="list-style-type: none"> The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to "TROUBLE DIAGNOSIS — INDEX", EC-581.) | GI MA |
| FUEL SYS-B1 *2 | <ul style="list-style-type: none"> "Fuel injection system status" at the moment a malfunction is detected is displayed. One mode in the following is displayed. <ul style="list-style-type: none"> "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop | EM LC |
| FUEL SYS-B2 *2 | | EC |
| CAL/LD VALUE [%] | <ul style="list-style-type: none"> The calculated load value at the moment a malfunction is detected is displayed. | FE |
| COOLANT TEMP [°C] or [°F] | <ul style="list-style-type: none"> The engine coolant temperature at the moment a malfunction is detected is displayed. | CL |
| S-FUEL TRIM-B1 [%] | <ul style="list-style-type: none"> "Short-term fuel trim" at the moment a malfunction is detected is displayed. The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule. | MT |
| S-FUEL TRIM-B2 [%] | | AT |
| L-FUEL TRIM-B1 [%] | <ul style="list-style-type: none"> "Long-term fuel trim" at the moment a malfunction is detected is displayed. The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim. | TF |
| L-FUEL TRIM-B2 [%] | | PD |
| ENGINE SPEED [rpm] | <ul style="list-style-type: none"> The engine speed at the moment a malfunction is detected is displayed. | AX |
| VHCL SPEED [km/h] or [mph] | <ul style="list-style-type: none"> The vehicle speed at the moment a malfunction is detected is displayed. | SU |
| ABSOL PRESS [kPa] or [kg/cm ²] or [psi] | <ul style="list-style-type: none"> The absolute pressure at the moment a malfunction is detected is displayed. | BR |
| B/FUEL SCHDL [msec] | <ul style="list-style-type: none"> The base fuel schedule at the moment a malfunction is detected is displayed. | ST |
| INT/A TEMP SE [°C] or [°F] | <ul style="list-style-type: none"> The intake air temperature at the moment a malfunction is detected is displayed. | RS |

*1: The items are the same as those of 1st trip freeze frame data.

*2: Regarding D22 model, "-B1" indicates right bank and "-B2" indicates left bank.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DATA MONITOR MODE

=NGEC0555S06

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks |
|-----------------------------------|-------------------|--------------|--|---|
| CMPS-RPM (POS) [rpm] | ○ | ○ | <ul style="list-style-type: none"> Indicates the engine speed computed from the POS signal (1° signal) of the camshaft position sensor. | |
| CMPS-RPM (REF) [rpm] | ○ | | <ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (120° signal) of the camshaft position sensor. | |
| MAS AIR/FL SE [V] | ○ | ○ | <ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. |
| COOLAN TEMP/S [°C] or [°F] | ○ | ○ | <ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. | <ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed. |
| FR O2 SEN-B2 [V] | ○ | ○ | <ul style="list-style-type: none"> The signal voltage of the front heated oxygen sensor is displayed. | |
| FR O2 SEN-B1 [V] | ○ | | | |
| RR O2 SEN-B1 [V] | ○ | ○ | <ul style="list-style-type: none"> The signal voltage of the rear heated oxygen sensor is displayed. | |
| RR O2 SEN-B2 [V] | ○ | | | |
| FR O2 MNTR-B2 [RICH/LEAN] | ○ | ○ | <ul style="list-style-type: none"> Display of front heated oxygen sensor signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. | <ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously. |
| FR O2 MNTR-B1 [RICH/LEAN] | ○ | ○ | | |
| RR O2 MNTR-B1 [RICH/LEAN] | ○ | | <ul style="list-style-type: none"> Display of rear heated oxygen sensor signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. |
| RR O2 MNTR-B2 [RICH/LEAN] | ○ | ○ | | |
| VHCL SPEED SE [km/h] or [mph] | ○ | ○ | <ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. | |
| BATTERY VOLT [V] | ○ | ○ | <ul style="list-style-type: none"> The power supply voltage of ECM is displayed. | |
| THRTL POS SEN [V] | ○ | ○ | <ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. | |
| TANK F/TMP SE [°C] or [°F] | ○ | | <ul style="list-style-type: none"> The fuel temperature judged from the fuel tank temperature sensor signal voltage is displayed. | |
| EGR TEMP SEN [V] (If so equipped) | ○ | | <ul style="list-style-type: none"> The signal voltage of the EGR temperature sensor is displayed. | |
| INT/A TEMP SE [°C] or [°F] | ○ | | <ul style="list-style-type: none"> The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated. | |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

CONSULT-II (Cont'd)

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks | |
|------------------------|-------------------|--------------|---|--|----|
| START SIGNAL [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. | <ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal. | GI |
| CLSD THL/P SW [ON/OFF] | | | <ul style="list-style-type: none"> Indicates mechanical contact [ON/OFF] condition of the closed throttle position switch. | | MA |
| CLSD THL POS [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal. | | EM |
| AIR COND SIG [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. | | LC |
| P/N POSI SW [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal. | | EC |
| PW/ST SIGNAL [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure signal is indicated. | | FE |
| AMB TEMP SW [ON/OFF] | ○ | ○ | <ul style="list-style-type: none"> Indicates [ON/OFF] condition from the ambient air temperature switch signal. | | CL |
| IGNITION SW [ON/OFF] | ○ | | <ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. | | MT |
| INJ PULSE-B2 [msec] | | ○ | <ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. | <ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated. | AT |
| INJ PULSE-B1 [msec] | | | | | TF |
| B/FUEL SCHDL [msec] | | ○ | <ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. | | PD |
| IGN TIMING [BTDC] | | ○ | <ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. | AX |
| IACV-AAC/V [%] | | ○ | <ul style="list-style-type: none"> Indicates the IACV-AAC valve control value computed by ECM according to the input signals. | | SU |
| PURG VOL C/V [%] | | ○ | <ul style="list-style-type: none"> Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. | | BR |
| A/F ALPHA-B2 [%] | | | <ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control. | ST |
| A/F ALPHA-B1 [%] | | | | | RS |
| EVAP SYS PRES [V] | | | <ul style="list-style-type: none"> The signal voltage of EVAP control system pressure sensor is displayed. | | BT |
| AIR COND RLY [ON/OFF] | | | <ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. | | HA |
| | | | | | SC |
| | | | | | EL |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

| |
|--------------|
| VG33E |
|--------------|

CONSULT-II (Cont'd)

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks |
|--|-------------------|--------------|--|---------|
| FUEL PUMP RLY [ON/OFF] | | | <ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. | |
| COOLING FAN [ON/OFF] | | | <ul style="list-style-type: none"> Indicates the control condition of the cooling fan (determined by ECM according to the input signal). ON ... Operation OFF ... Stop | |
| EGRC SOL/V [ON/OFF] (FLOW/CUT) (If so equipped) | | | <ul style="list-style-type: none"> The control condition of the EGRC-solenoid valve (determined by ECM according to the input signal) is indicated. ON ... EGR is operational OFF ... EGR operation is cut-off | |
| VENT CONT/V [ON/OFF] | | | <ul style="list-style-type: none"> The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is indicated. ON ... Closed OFF ... Open | |
| FR O2 HTR-B1 [ON/OFF] | | | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of front heated oxygen sensor heater determined by ECM according to the input signals. | |
| FR O2 HTR-B2 [ON/OFF] | | | | |
| RR O2 HTR-B1 [ON/OFF] | | | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of rear heated oxygen sensor heater determined by ECM according to the input signals. | |
| RR O2 HTR-B2 [ON/OFF] | | | | |
| VC/V BYPASS/V [ON/OFF] | | | <ul style="list-style-type: none"> The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ON ... Open OFF ... Closed | |
| CAL/LD VALUE [%] | | | <ul style="list-style-type: none"> "Calculated load value" indicates the value of the current airflow divided by peak airflow. | |
| ABSOL TH-P/S [%] | | | <ul style="list-style-type: none"> "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. | |
| MASS AIRFLOW [g·m/s] | | | <ul style="list-style-type: none"> Indicates the mass airflow computed by ECM according to the signal voltage of the mass airflow sensor. | |
| MAP/BARO SW/V [MAP/BARO] | | | <ul style="list-style-type: none"> The control condition of the MAP/BARO switch solenoid valve (determined by ECM according to the input signal) is indicated. MAP ... Intake manifold absolute pressure BARO ... Ambient air barometric pressure | |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

CONSULT-II (Cont'd)

| Monitored item [Unit] | ECM input signals | Main signals | Description | Remarks |
|-----------------------------|-------------------|--------------|---|---|
| ABSOL PRES/SE [V] | | | <ul style="list-style-type: none"> The signal voltage of the absolute pressure sensor is displayed. | |
| VOLTAGE [V] | | | <ul style="list-style-type: none"> Voltage measured by the voltage probe. | |
| PULSE [msec] or [Hz] or [%] | | | <ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. | <ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured. |

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
- Regarding D22 model, “-B1” indicates right bank and “-B2” indicates left bank.

ACTIVE TEST MODE

NGEC0555S07

| TEST ITEM | CONDITION | JUDGEMENT | CHECK ITEM (REMEDY) |
|--------------------------------------|---|--|--|
| FUEL INJECTION | <ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Harness and connector Fuel injectors Front heated oxygen sensor |
| IACV-AAC/ OPENING | <ul style="list-style-type: none"> Engine: After warming up, idle the engine. Change the IACV-AAC valve opening percent using CONSULT-II. | Engine speed changes according to the opening percent. | <ul style="list-style-type: none"> Harness and connector IACV-AAC valve |
| ENG COOLANT TEMP | <ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT-II. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor Fuel injectors |
| IGNITION TIMING | <ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Adjust initial ignition timing |
| POWER BALANCE | <ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch “OFF” Shift lever “N” Cut off each injector signal one at a time using CONSULT-II. | Engine runs rough or dies. | <ul style="list-style-type: none"> Harness and connector Compression Injectors Power transistor Spark plugs Ignition coils |
| COOLING FAN | <ul style="list-style-type: none"> Ignition switch: ON Turn the cooling fan “ON” and “OFF” using CONSULT-II. | Cooling fan moves and stops. | <ul style="list-style-type: none"> Harness and connector Cooling fan motor Cooling fan relay |
| FUEL PUMP RELAY | <ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay “ON” and “OFF” using CONSULT-II and listen to operating sound. | Fuel pump relay makes the operating sound. | <ul style="list-style-type: none"> Harness and connector Fuel pump relay |
| EGRC SOLENOID VALVE (If so equipped) | <ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn solenoid valve “ON” and “OFF” with the CONSULT-II and listen to operating sound. | Solenoid valve makes an operating sound. | <ul style="list-style-type: none"> Harness and connector Solenoid valve |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

VG33E

CONSULT-II (Cont'd)

| TEST ITEM | CONDITION | JUDGEMENT | CHECK ITEM (REMEDY) |
|--------------------|--|--|---|
| SELF-LEARNING CONT | <ul style="list-style-type: none"> In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. | | |
| PURG VOL CONT/V | <ul style="list-style-type: none"> Engine: After warming up, run engine at 1,500 rpm. Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. | Engine speed changes according to the opening percent. | <ul style="list-style-type: none"> Harness and connector Solenoid valve |
| TANK F/TEMP SEN | <ul style="list-style-type: none"> Change the fuel tank temperature using CONSULT-II. | | |
| VENT CONTROL/V | <ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. | Solenoid valve makes an operating sound. | <ul style="list-style-type: none"> Harness and connector Solenoid valve |
| VC/V BYPASS/V | <ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. | Solenoid valve makes an operating sound. | <ul style="list-style-type: none"> Harness and connector Solenoid valve |
| MAP/BARO SW/V | <ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the MAP/BARO switch solenoid valve between "MAP" and "BARO" using CONSULT-II and listen to operating sound. | Solenoid valve makes an operating sound. | <ul style="list-style-type: none"> Harness and connector Solenoid valve |

DTC CONFIRMATION MODE

SRT STATUS Mode

NGEC0555S08

For details, refer to "SYSTEM READINESS TEST (SRT) CODE", EC-629.

SRT WORK SUPPORT Mode

NGEC0555S0803

SRT status and some of the data monitor item can be read.

DTC Work Support Mode

NGEC0555S0802

| Test mode | Test item | Condition | Reference page |
|--------------------------------|---------------------|---|----------------|
| EVAPORATIVE SYSTEM | EVAP SML LEAK P0440 | Refer to corresponding trouble diagnosis for DTC. | EC-947 |
| | EVAP SML LEAK P1440 | | EC-1065 |
| | PURG VOL CN/V P1444 | | EC-1067 |
| | PURGE FLOW P1447 | | EC-1086 |
| | VC CUT/V BP/V P1491 | | EC-1112 |
| FR O2 SENSOR | FR O2 SEN-B1 P0130 | | EC-763 |
| | FR O2 SEN-B1 P0131 | | EC-772 |
| | FR O2 SEN-B1 P0132 | | EC-780 |
| | FR O2 SEN-B1 P0133 | | EC-788 |
| | FR O2 SEN-B2 P0150 | | EC-763 |
| | FR O2 SEN-B2 P0151 | | EC-772 |
| | FR O2 SEN-B2 P0152 | | EC-780 |
| | FR O2 SEN-B2 P0153 | | EC-788 |
| RR O2 SENSOR | RR O2 SEN-B1 P0137 | | EC-815 |
| | RR O2 SEN-B1 P0138 | | EC-825 |
| | RR O2 SEN-B1 P0139 | EC-835 | |
| | RR O2 SEN-B2 P0157 | EC-815 | |
| | RR O2 SEN-B2 P0158 | EC-825 | |
| | RR O2 SEN-B2 P0159 | EC-835 | |
| EGR SYSTEM (If so equipped) | EGR SYSTEM P0400 | EC-919 | |
| | EGRC-BPT/VLV P0402 | EC-933 | |
| | EGR SYSTEM P1402 | EC-1055 | |

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

NGEC0555S09

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

- 1) "AUTO TRIG" (Automatic trigger):
 - The malfunction will be identified on the CONSULT-II screen in real time.
In other words, DTC/1st trip DTC and malfunction item will be displayed at the moment the malfunction is detected by ECM. DATA MONITOR can be performed continuously until a malfunction is detected. However, DATA MONITOR cannot continue any longer after the malfunction detection.
- 2) "MANU TRIG" (Manual trigger):
 - DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.
DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

- 1) "AUTO TRIG"
 - While trying to detect the DTC/1st trip DTC by performing the


“DTC Confirmation Procedure”, be sure to select to “DATA MONITOR (AUTO TRIG)” mode. You can confirm the malfunction at the moment it is detected.


- While narrowing down the possible causes, CONSULT-II should be set in “DATA MONITOR (AUTO TRIG)” mode, especially in case the incident is intermittent.

When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the “DTC Confirmation Procedure”, the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to “Incident Simulation Tests” in “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT”, **GI-24**.)

2) “MANU TRIG”

- If the malfunction is displayed as soon as “DATA MONITOR” is selected, reset CONSULT-II to “MANU TRIG”. By selecting “MANU TRIG” you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.





Generic Scan Tool (GST)

=NGEC0556


DESCRIPTION

NGE0556S01

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 7 different functions explained on the next page.

ISO9141 is used as the protocol.


The name "GST" or "Generic Scan Tool" is used in this service manual.



GST INSPECTION PROCEDURE


NGE0556S02

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector for GST. (Data link connector for GST is located under LH dash panel near the fuse box cover.)



3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.

 GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION




VG33E

Generic Scan Tool (GST) (Cont'd)

FUNCTION

NGEC0556S03

| Diagnostic test mode | | Function |
|----------------------|------------------|---|
| MODE 1 | READINESS TESTS | This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information. |
| MODE 2 | (FREEZE DATA) | This mode gains access to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze Frame Data" (EC-654).] |
| MODE 3 | DTCs | This mode gains access to emission-related power train trouble codes which were stored by ECM. |
| MODE 4 | CLEAR DIAG INFO | This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7) |
| MODE 6 | (ON BOARD TESTS) | This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored. |
| MODE 7 | (ON BOARD TESTS) | This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions. |
| MODE 8 | — | This mode can close EVAP system in ignition switch "ON" position (Engine stopped). When this mode is performed, the following parts can be opened or closed. <ul style="list-style-type: none"> ● EVAP canister vent control valve open ● Vacuum cut valve bypass valve closed In the following conditions, this mode cannot function. <ul style="list-style-type: none"> ● Low ambient temperature ● Low battery voltage ● Engine running ● Ignition switch OFF ● Low fuel temperature ● Too much pressure is applied to EVAP system |
| MODE 9 | CALIBRATION ID | This mode is to enable the off-board to request vehicle specific vehicle information such as Vehicle Identification Number (VIN) and calibration IDs. |



KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

SEF907L

Introduction

NGEC0557

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on EC-667.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

DIAGNOSTIC WORKSHEET

NGEC0557S01

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.


Some conditions may cause the MIL to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere [for the models with EVAP (SMALL LEAK) diagnosis].

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Work Flow

NGEC0558



*1 EC-687

*2 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

*3 If the incident cannot be verified,

perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

*4 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to "TROUBLE DIAGNOSIS FOR POWER SUPPLY", EC-707.

*5 If malfunctioning part cannot be detected, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

*6 EC-634

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

SEF935V

DESCRIPTION FOR WORK FLOW

NGEC0558S01

| STEP | DESCRIPTION |
|----------|---|
| STEP I | Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-666. |
| STEP II | Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-640.) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-688.) Also check related service bulletins for information. |
| STEP III | Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. If the malfunction code is detected, skip STEP IV and perform STEP V. |
| STEP IV | Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection. |
| STEP V | Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-669.) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-688.) |
| STEP VI | Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-692, EC-697. The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT", "Circuit Inspection", GI-26 . Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. |
| STEP VII | Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000 or 0505] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-640.) |


Basic Inspection

NGEC0559

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

| 1 | INSPECTION START | |
|---|--|-------------|
| | <p>1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.</p> <p>2. Open engine hood and check the following:</p> <ul style="list-style-type: none"> ● Harness connectors for improper connections ● Vacuum hoses for splits, kinks, or improper connections ● Wiring for improper connections, pinches, or cuts | |
| |  | |
| | <small>SEF983U</small> | |
| | Models with CONSULT-II | ▶ GO TO 2. |
| | Models with GST | ▶ GO TO 2. |
| | Models with No Tools | ▶ GO TO 16. |

| 2 | CONNECT CONSULT-II OR GST TO THE VEHICLE | |
|---|--|-------------|
| | <p> With CONSULT-II Connect "CONSULT-II" to the data link connector for CONSULT-II and select "ENGINE" from the menu. Refer to EC-651.</p> | |
| | <p> With GST Connect "GST" to the data link connector for GST. Refer to EC-663.</p> | |
| | Models with CONSULT-II | ▶ GO TO 3. |
| | Models with GST | ▶ GO TO 15. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

3 CHECK FI CAM FUNCTION

Ⓜ With CONSULT-II


1. Turn ignition switch ON.
2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
3. Start engine and warm it up.

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| COOLAN TEMP/S | XXX °C |
| | |

PEF002P

4. When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.

- The center of mark **A** is aligned with mark **C**.
- The cam follower lever's roller is not touching the fast idle cam.



SEF971R

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Check FI cam. Refer to "Fast Idle Cam (FIC)", EC-612. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


4 CHECK IGNITION TIMING

With CONSULT-II

- Warm up engine to normal operating temperature.
- Select "IACV-AAC/V ADJ" in "WORK SUPPORT" mode and touch "START".

| | |
|-------------------|---------|
| IACV-AAC/V ADJ | |
| ADJ MONITOR | |
| CMPS-RPM(POS) | 700 rpm |
| CONDITION SETTING | |
| IACV-ACC/V | FIXED |
| | |
| MONITOR | |
| COOLAN TEMP/S | XXX C |
| CLSD THL POS | XXX N |
| | |

3. Check ignition timing at idle using a timing light.



Ignition timing: 15°±2° BTDC

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 5. |
| NG | ▶ | 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 5. |

PEF120W
SEF984U

5 CHECK BASE IDLE SPEED

With CONSULT-II

- Select "IACV-AAC/V ADJ" in "WORK SUPPORT" mode and touch "START".

| | |
|-------------------|---------|
| IACV-AAC/V ADJ | |
| ADJ MONITOR | |
| CMPS-RPM(POS) | 700 rpm |
| CONDITION SETTING | |
| IACV-ACC/V | FIXED |
| | |
| MONITOR | |
| COOLAN TEMP/S | XXX C |
| CLSD THL POS | XXX N |
| | |

2. Check idle speed.

700±50 rpm (in "P" or "N" position)


OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 6. |
| NG | ▶ | 1. Adjust engine speed by turning idle speed adjusting screw. Refer to "Idle Speed/Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 6. |

PEF120W

6 CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-I**With CONSULT-II****NOTE:****Always check ignition timing and base idle speed before performing the following.**

1. Warm up engine to normal operating temperature.
2. Check FI cam, refer to procedure 3.
3. Stop engine.
4. Remove the vacuum hose connected to the throttle opener (If so equipped).
5. Connect suitable vacuum hose to vacuum pump as shown below.



SEF793W


6. Apply vacuum [more than -40.0 kPa (-300 mmHg, -11.81 inHg)]



GO TO 7.

7 CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Turn ignition switch ON.
2. Select "CLSD THL/P SW" in "DATA MONITOR" mode.
3. Read "CLSD THL/P SW" signal under the following conditions.
 - Insert a 0.3 mm (0.012 in) and 0.4 mm (0.016 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure and check the signal.



AEC887A

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CLSD THL/P SW | ON |

PEF577W

"CLSD THL/P SW" signal should remain "ON" while inserting 0.3 mm (0.012 in) feeler gauge.
 "CLSD THL/P SW" signal should remain "OFF" while inserting 0.4 mm (0.016 in) feeler gauge.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | GO TO 8. |


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

8 ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION

④ With CONSULT-II

NOTE:

- Never adjust throttle adjust screw (TAS).
 - Do not touch throttle drum when checking "CLSD THL/P SW" signal, doing so may cause an incorrect adjustment.
1. Warm up engine to normal operating temperature.
 2. Check FI cam. Refer to procedure 3.
 3. Stop engine.
 4. Loosen throttle position sensor fixing bolts.
 5. Remove the vacuum hose connected to the throttle opener (If so equipped).
 6. Connect suitable vacuum hose to vacuum pump as shown below.



SEF793W


7. Apply vacuum [more than -40.0 kPa (-300 mmHg, -11.82 inHg)] until the throttle drum becomes free from the rod of the throttle opener. During adjustment procedure, vacuum should be applied.



GO TO 9.

9 ADJUSTMENT CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Turn ignition switch ON.
2. Select "CLSD THL/P SW" in "DATA MONITOR" mode.
3. Insert 0.35 mm (0.0138 in) feeler gauge between throttle adjust screw and throttle drum as shown in the figure.



4. Open throttle valve and then close.
5. Check "CLSD THL/P SW" signal.

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CLSD THL/P SW | OFF |

"CLSD THL/P SW" signal should remain "OFF" when the throttle valve is closed.


OK or NG

- | | | |
|----|---|-----------|
| OK | ▶ | GO TO 10. |
| NG | ▶ | GO TO 8. |

10 ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-III

Ⓟ With CONSULT-II

Turn throttle position sensor body clockwise until "CLSD THL/P SW" signal switches to "OFF".



- | | |
|---|-----------|
| ▶ | GO TO 11. |
|---|-----------|


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Basic Inspection (Cont'd)

11 ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-IV

④ With CONSULT-II

1. Remove 0.35 mm (0.0138 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
2. Temporarily tighten sensor body fixing bolts as follows.
 - Gradually move the sensor body counterclockwise and stop it when "CLSD THL/P SW" signal switches from "OFF" to "ON", then temporarily tighten sensor body fixing bolts.




SEF689W

3. Make sure two or three times that the signal is "ON" when the throttle valve is closed and "OFF" when it is opened.
4. Remove 0.3 mm (0.012 in) feeler gauge then insert 0.4 mm (0.016 in) feeler gauge.
5. Make sure two or three times that the signal remains "OFF" when the throttle valve is closed.
6. Tighten throttle position sensor.
7. Check the "CLSD THL/P SW" signal again.

The signal remains "OFF" while closing throttle valve.

OK or NG


| | | |
|----|---|-----------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | GO TO 8. |



| 12 | RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY | | | | | | |
|---|--|--------------|--|------------|---------|--------------|----|
| <p> With CONSULT-II</p> <p>NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <ol style="list-style-type: none"> 1. Remove feeler gauge. 2. Start engine. 3. Warm up engine to normal operating temperature. 4. Select "CLSD THL POS" in "DATA MONITOR" mode. 5. Stop engine. (Turn ignition switch OFF.) 6. Turn ignition switch ON and wait at least 5 seconds. <div style="text-align: center; margin: 10px 0;">  </div> <ol style="list-style-type: none"> 7. Turn ignition switch OFF and wait at least 5 seconds. 8. Repeat steps 5 and 6 until "CLSD THL POS" signal changes to "ON". <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse; width: 150px;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;">NO FAIL</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">CLSD THL POS</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table> </div> | | DATA MONITOR | | MONITORING | NO FAIL | CLSD THL POS | ON |
| DATA MONITOR | | | | | | | |
| MONITORING | NO FAIL | | | | | | |
| CLSD THL POS | ON | | | | | | |
| <p>SEF864V</p> <p>PEF123W</p> | | | | | | | |
| <p>▶ GO TO 13.</p> | | | | | | | |



| | |
|--|---------------------------|
| 13 | REMOVE VACUUM PUMP |
| <ol style="list-style-type: none"> 1. Release vacuum from the throttle opener. 2. Remove vacuum pump and vacuum hose from the throttle opener. 3. Reinstall the original vacuum hose to the throttle opener securely. | |
| <p>▶ GO TO 14.</p> | |

| | |
|---|---|
| 14 | CHECK TARGET IDLE SPEED |
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "CMPS-RPM (REF)" in "DATA MONITOR" mode. 3. Check idle speed. <p style="text-align: center; color: blue;">750±50 rpm (in "P" or "N" position)</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ INSPECTION END |
| NG | ▶ Adjust idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-614. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

| | |
|--|---|
| 15 | CHECK FI CAM FUNCTION |
| <p> With GST</p> <ol style="list-style-type: none"> Turn ignition switch ON. Select "MODE 1" with GST. Start engine and warm it up. When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following. <ul style="list-style-type: none"> The center of mark A is aligned with mark C. The cam follower lever's roller is not touching the fast idle cam. <div style="text-align: center;">  </div> <p style="text-align: right;">SEF971R</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 17. |
| NG | ▶ Check FI cam. Refer to "Fast Idle Cam (FIC)", EC-612. |

| | |
|---|---|
| 16 | CHECK FI CAM FUNCTION |
| <p> No Tools</p> <ol style="list-style-type: none"> Set the voltmeter between ECM terminal 59 (Engine coolant temperature sensor signal) and ground. Start engine and warm it up. <div style="text-align: center;">  </div> <p style="text-align: right;">SEF119W</p> <ol style="list-style-type: none"> When the voltage is between 1.10 to 1.36V, check the following. <ul style="list-style-type: none"> The center of mark A is aligned with mark C. The cam follower lever's roller is not touching the fast idle cam. <div style="text-align: center;">  </div> <p style="text-align: right;">SEF971R</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 17. |
| NG | ▶ Check FI cam. Refer to "Fast Idle Cam (FIC)", EC-612. |

| | | | | | | | | | |
|-----------|------------------------------|--|---|---|-----------|----|---|--|--|
| 17 | CHECK IGNITION TIMING | | | | | | | | |
| | | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Warm up engine to normal operating temperature. 2. Stop engine and disconnect throttle position sensor harness connector. <div style="text-align: center;">  </div> <ol style="list-style-type: none"> 3. Start engine. 4. Check ignition timing at idle using a timing light. <div style="text-align: center;">  </div> <p style="color: blue; font-weight: bold;">Ignition timing: 15°±2° BTDC</p> <p style="text-align: center; font-weight: bold;">OK or NG</p> | <p style="text-align: right;">GI</p> <p style="text-align: right;">MA</p> <p style="text-align: right;">EM</p> <p style="text-align: right;">LC</p> <p style="text-align: right; background-color: black; color: white; padding: 2px;">EC</p> <p style="text-align: right;">FE</p> <p style="text-align: right;">CL</p> <p style="text-align: right;">MT</p> <p style="text-align: right;">AT</p> <p style="text-align: right;">TF</p> <p style="text-align: right;">PD</p> <p style="text-align: right;">AX</p> <p style="text-align: right;">SU</p> <p style="text-align: right;">BR</p> <p style="text-align: right;">ST</p> <p style="text-align: right;">RS</p> <p style="text-align: right;">BT</p> <p style="text-align: right;">HA</p> <p style="text-align: right;">SC</p> <p style="text-align: right;">EL</p> <p style="text-align: right;">IDX</p> | | | | | | |
| | | <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; border-right: 1px solid black; padding: 5px;">OK</td> <td style="width: 10%; text-align: center; border-right: 1px solid black; padding: 5px;">▶</td> <td style="padding: 5px;">GO TO 18.</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 5px;">NG</td> <td style="text-align: center; border-right: 1px solid black; padding: 5px;">▶</td> <td style="padding: 5px;"> <ol style="list-style-type: none"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/ Ignition Timing/ Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 18. </td> </tr> </table> | OK | ▶ | GO TO 18. | NG | ▶ | <ol style="list-style-type: none"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/ Ignition Timing/ Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 18. | |
| OK | ▶ | GO TO 18. | | | | | | | |
| NG | ▶ | <ol style="list-style-type: none"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/ Ignition Timing/ Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 18. | | | | | | | |

| | | | | | | | | | |
|-----------|------------------------------|---|----|---|-----------|----|---|--|--|
| 18 | CHECK BASE IDLE SPEED | | | | | | | | |
| | | <p>⊗ Without CONSULT-II</p> <p>Does engine speed fall to the following speed?</p> <p style="color: blue; font-weight: bold;">700±50 rpm (in "P" or "N" position)</p> <p style="text-align: center; font-weight: bold;">OK or NG</p> | | | | | | | |
| | | <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; border-right: 1px solid black; padding: 5px;">OK</td> <td style="width: 10%; text-align: center; border-right: 1px solid black; padding: 5px;">▶</td> <td style="padding: 5px;">GO TO 19.</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 5px;">NG</td> <td style="text-align: center; border-right: 1px solid black; padding: 5px;">▶</td> <td style="padding: 5px;"> <ol style="list-style-type: none"> 1. Adjust engine speed by turning idle speed adjusting screw. Refer to "Idle Speed/ Ignition Timing/ Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 19. </td> </tr> </table> | OK | ▶ | GO TO 19. | NG | ▶ | <ol style="list-style-type: none"> 1. Adjust engine speed by turning idle speed adjusting screw. Refer to "Idle Speed/ Ignition Timing/ Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 19. | |
| OK | ▶ | GO TO 19. | | | | | | | |
| NG | ▶ | <ol style="list-style-type: none"> 1. Adjust engine speed by turning idle speed adjusting screw. Refer to "Idle Speed/ Ignition Timing/ Idle Mixture Ratio Adjustment", EC-614. 2. GO TO 19. | | | | | | | |


Basic Inspection (Cont'd)

19 CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION

⊗ Without CONSULT-II

NOTE:**Always check ignition timing and base idle speed before performing the following.**

1. Warm up engine to normal operating temperature.
2. Check FI cam, refer to procedure 12 or 13.
3. Stop engine.
4. Remove the vacuum hose connected to the throttle opener (If so equipped).
5. Connect suitable vacuum hose to vacuum pump as shown below.



SEF793W



6. Apply vacuum [more than -40.0 kPa (-300 mmHg, -11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener. During checking procedure, vacuum should be applied.




GO TO 20.

20 CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-I

1. Disconnect closed throttle position switch harness connector.
2. Check continuity between closed throttle position switch terminals 5 and 6 under the following conditions.



- Insert the 0.3 mm (0.012 in) and 0.4 mm (0.016 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure.



“Continuity should exist” while inserting 0.3 mm (0.012 in) feeler gauge.
 “Continuity should not exist” while inserting 0.4 mm (0.016 in) feeler gauge.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 25. |
| NG | ▶ | GO TO 21. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


21 | ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION

⊗ Without CONSULT-II

NOTE:

- Never adjust throttle adjust screw (TAS).
- Do not touch throttle drum when checking "continuity", doing so may cause an incorrect adjustment.

1. Warm up engine to normal operating temperature.
2. Check FI cam. Refer to procedure 12 or 13.
3. Stop engine.
4. Loosen throttle position sensor fixing bolts.
5. Remove the vacuum hose connected to the throttle opener (If so equipped).
6. Connect suitable vacuum hose to vacuum pump as shown below.



SEF793W

7. Apply vacuum [more than -40.0 kPa (-300 mmHg, -11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener. During adjustment procedure, vacuum should be applied.




GO TO 22.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



22 ADJUSTMENT CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Disconnect closed throttle position switch harness connector.
2. Insert 0.35 mm (0.0138 in) feeler gauge between the throttle adjust screw and throttle drum as shown in the figure.



AEC887A

3. Open throttle valve then close.
4. Check continuity between closed throttle position switch terminals 5 and 6.



SEF862V


Continuity should not exist while closing the throttle position sensor.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 24. |
| NG | ▶ | GO TO 23. |

23 ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-III

- ⊗ Without CONSULT-II
Turn throttle position sensor body clockwise until continuity does not exist.




SEF689W

| | |
|---|-----------|
| ▶ | GO TO 24. |
|---|-----------|

24 ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-IV

⊗ Without CONSULT-II

1. Remove 0.35 mm (0.0138 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
2. Temporarily tighten sensor body fixing bolts as follows.
 - Gradually move the sensor body counterclockwise and stop it when the continuity comes to exist, then temporarily tighten sensor body fixing bolts.



SEF689W

3. Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened.
4. Remove 0.3 mm (0.012 in) feeler gauge then insert 0.4 mm (0.016 in) feeler gauge.
5. Make sure two or three times that the continuity does not exist when the throttle valve is closed.
6. Tighten throttle position sensor.
7. Check the continuity again.

Continuity does not exist while closing the throttle valve.

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 25. |
| NG | ▶ | GO TO 21. |


25 RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY

⊗ Without CONSULT-II

NOTE:

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

1. Remove feeler gauge.
2. Start engine.
3. Warm up engine to normal operating temperature.
4. Stop engine. (Turn ignition switch OFF.)
5. Turn ignition switch ON and wait at least 5 seconds.



SEF864V

6. Turn ignition switch OFF and wait at least 5 seconds.
7. Repeat steps 4 and 5, 20 times.

| | |
|---|-----------|
| ▶ | GO TO 26. |
|---|-----------|

| | |
|--|-----------------------|
| 26 | REINSTALLATION |
| <p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Release vacuum from the throttle opener (If so equipped). 2. Remove vacuum pump and vacuum hose from the throttle opener. 3. Reinstall the original vacuum hose to the throttle opener securely. 4. Reconnect throttle position sensor harness connector and closed throttle position switch harness connector. 5. Start engine and rev it (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed. | |
| ▶ | GO TO 27. |

GI

MA

EM

| | |
|--|---|
| 27 | CHECK TARGET IDLE SPEED |
| <p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Check idle speed. 750±50 rpm (in "P" or "N" position) <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 28. |
| NG | ▶ Adjust idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-614. |

LC

EC

FE

CL

| | |
|---|------------------------------|
| 28 | ERASE UNNECESSARY DTC |
| <p>After this inspection, unnecessary DTC No. might be displayed. Erase the stored memory in ECM and TCM (Transmission control module). Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640 and "HOW TO ERASE DTC", AT-35.</p> | |
| ▶ | INSPECTION END |

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC Inspection Priority Chart

NGEC0560

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | Detected items (DTC) |
|----------|--|
| 1 | <ul style="list-style-type: none"> ● P0100 Mass air flow sensor (0102) ● P0110 Intake air temperature sensor (0401) ● P0115 P0125 Engine coolant temperature sensor (0103) (0908) ● P0120 Throttle position sensor (0403) ● P0180 Fuel tank temperature sensor (0402) ● P0325 Knock sensor (0304) ● P0335 P1336 Crankshaft position sensor (OBD) (0802) (0905) ● P0340 Camshaft position sensor (0101) ● P0500 Vehicle speed sensor (0104) ● P0600 A/T communication line ● P0605 ECM (0301) ● P1320 Ignition signal (0201) ● P1400 EGRC-solenoid valve (1005) (If so equipped) ● P1605 A/T diagnosis communication line (0804) ● P1706 Park/Neutral position (PNP) switch (1003) |
| 2 | <ul style="list-style-type: none"> ● P0105 Absolute pressure sensor (0803) ● P0130-P0134, P0150-P0154 Front heated oxygen sensor (0413-0415) (0503)(0509), (0303) (0409-0412) ● P0135 P0155 Front heated oxygen sensor heater (0901) (1001) ● P0137-P0140, P0157-P0160 Rear heated oxygen sensor (0510-0512) (0707), (0313-0315) (0708) ● P0141 P0161 Rear heated oxygen sensor heater (0902) (1002) ● P0443 P1444 EVAP canister purge volume control solenoid valve (1008) (0214) ● P0446 P1446 P1448 EVAP canister vent control valve (0903) (0215) (0309) ● P0450 EVAP control system pressure sensor (0704) ● P0510 Closed throttle position switch (0203) ● P0705-P0755 P1705 P1760 A/T related sensors, solenoid valves and switches (1101-1208) ● P1105 MAP/BARO switch solenoid valve (1302) ● P1401 EGR temperature sensor (0305) (If so equipped) ● P1447 EVAP control system purge flow monitoring (0111) ● P1490 P1491 Vacuum cut valve bypass valve (0801) (0311) |
| 3 | <ul style="list-style-type: none"> ● P0171 P0172 P0174 P0175 Fuel injection system function (0115) (0114) (0210) (0209) ● P0217 Engine coolant overtemperature enrichment protection (0211) ● P0306 - P0300 Misfire (0603 - 0701) ● P0400 P1402 EGR function (0302) (0514) (If so equipped) ● P0402 EGRC-BPT valve function (0306) (If so equipped) ● P0420 P0430 Three way catalyst function (0702) (0703) ● P0440, P1440, P0455 EVAP control system (SMALL LEAK) (0705), (0213), (GROSS LEAK) (0715) ● P0505 IACV-AAC valve (0205) ● P0731-P0734 P0744 A/T function (1103 - 1106) (1107) ● P1148 P1168 Closed loop control (0307) (0308) |

Fail-safe Chart

=NGEC0561

The ECM enters fail-safe mode, if any of the following malfunctions is detected due to the open or short circuit. When the ECM enters the fail-safe mode, the MIL illuminates.

| DTC No. | | Detected items | Engine operating condition in fail-safe mode | |
|----------------------|--|---|---|---|
| CONSULT-II GST | ECM*1 | | | |
| P0100 | 0102 | Mass air flow sensor circuit | Engine speed will not rise more than 2,400 rpm due to the fuel cut. | |
| P0115 | 0103 | Engine coolant temperature sensor circuit | Engine coolant temperature will be determined by ECM based on the time after turning ignition switch ON or START. CONSULT-II displays the engine coolant temperature decided by ECM. | |
| | | | Condition | Engine coolant temperature decided (CONSULT-II display) |
| | | | Just as ignition switch is turned ON or Start | 40°C (104°F) |
| | | | More than approx. 4 minutes after ignition ON or Start | 80°C (176°F) |
| | | | Except as shown above | 40 - 80°C (104 - 176°F) (Depends on the time) |
| P0120 | 0403 | Throttle position sensor circuit | Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor. | |
| | | | Condition | Driving condition |
| | | | When engine is idling | Normal |
| | | | When accelerating | Poor acceleration |
| Unable to access ECM | Unable to access Diagnostic Test Mode II | ECM | ECM fail-safe activating condition The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MIL on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed. | |
| | | | Engine control with fail-safe When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation, and IACV-AAC valve operation are controlled under certain limitations. | |
| | | | ECM fail-safe operation | |
| | | | Engine speed | Engine speed will not rise more than 3,000 rpm |
| | | | Fuel injection | Simultaneous multiport fuel injection system |
| | | | Ignition timing | Ignition timing is fixed at the preset value |
| | | | Fuel pump | Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls |
| | | | IACV-AAC valve | Full open |
| | | | Replace ECM, if ECM fail-safe condition is confirmed. | |

*1: In Diagnostic Test Mode II (Self-diagnostic results)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

Symptom Matrix Chart

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

NGEC0562

NGEC0562S01

| | | SYMPTOM | | | | | | | | | | | | Reference page | |
|--------------------------------------|---------------------------------------|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|-------------------|-----------------------------|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Fuel | Fuel pump circuit | 1 | 1 | 2 | 3 | 2 | | 3 | | | | | 3 | 1 | EC-1153 |
| | Injector circuit | | | | | | 2 | 2 | | | | | | | |
| | Fuel pressure regulator system | | | | | | | | | | | | | | EC-611 |
| | Evaporative emission system | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 3 | 3 | | 4 | | | EC-603 |
| Air | Positive crankcase ventilation system | | | | | | | | | | | | 1 | | EC-609 |
| | Incorrect idle speed adjustment | 3 | 3 | | | | 1 | 1 | 1 | 1 | | 1 | | | EC-614 |
| | IACV-AAC valve circuit | | 1 | | | | 2 | 2 | | | | | | 1 | EC-992 |
| | IACV-FICD solenoid valve circuit | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 2 | 2 | | 3 | | | EC-1165 |
| Ignition | Incorrect ignition timing adjustment | 3 | 3 | 1 | 1 | 1 | | 1 | 1 | | | 1 | | | EC-614 |
| | Ignition circuit | 1 | 1 | | 2 | 2 | | 2 | 2 | | | 2 | | | EC-1028 |
| EGR (If so equipped) | EGRC-solenoid valve circuit | | 2 | 2 | 3 | 3 | | | | | | 3 | | | EC-1043 |
| | EGR system | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 3 | 3 | | 4 | | | EC-919, 1055 |
| Main power supply and ground circuit | | 1 | | | | | | | | | 1 | | | | EC-707 |
| Air conditioner circuit | | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 2 | 2 | | 3 | | 1 | HA-22 |

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

Symptom Matrix Chart (Cont'd)

| | SYMPTOM | | | | | | | | | | | | Reference page | |
|---|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|-------------------|-----------------------------|
| | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Camshaft position sensor circuit | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | EC-912 |
| Mass air flow sensor circuit | | | | 3 | | | | | | | | | | 2 |
| Front heated oxygen sensor circuit | | | | 3 | | | | | | | | | | EC-763 |
| Engine coolant temperature sensor circuit | 1 | 2 | 3 | | 3 | 3 | | | | | 3 | | | EC-739, 758 |
| Throttle position sensor circuit | | 1 | 2 | | 2 | 2 | | | | 2 | 2 | | | EC-744 |
| Incorrect throttle position sensor adjustment | | 3 | 1 | | 1 | 1 | 1 | 1 | 1 | | 1 | | | EC-669 |
| Vehicle speed sensor circuit | | 2 | | | | | | | | | | | | EC-988 |
| Knock sensor circuit | | | 3 | 3 | 3 | | | | | | 3 | | | EC-902 |
| ECM | 2 | 2 | | 3 | | 3 | 3 | 2 | 2 | 1 | | | | EC-1011, 687 |
| Start signal circuit | 1 | | | | | | | | | | | | | EC-1150 |
| Park/neutral position (PNP) switch circuit | | | 3 | | 3 | | | | | | 3 | | | EC-1124 |
| Power steering oil pressure switch circuit | | 2 | | | | | 3 | 2 | | | | | | EC-1160 |

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

Symptom Matrix Chart (Cont'd)

SYSTEM — ENGINE MECHANICAL & OTHER

NGEC0562S02

| | | SYMPTOM | | | | | | | | | | | | Reference section | | |
|-----------------------|--|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|-------------------|-----------------------------|---------------|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) | |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | | |
| Fuel | Fuel tank | 5 | 5 | | | | | | | | | | | | FE-4 | |
| | Fuel piping | | | 5 | 5 | 5 | | 5 | 4 | | 5 | | | | | |
| | Vapor lock | | | | | | | | | | | | | | | |
| | Valve deposit | | | | | | | | | | | | | | | |
| | Poor fuel (Heavy weight gasoline, Low octane) | 5 | | 5 | 5 | 5 | | 5 | 4 | | 5 | | | | | |
| Air | Air duct | | | | | | | | | | | | | | | |
| | Air cleaner | | | | | | | | | | | | | | | |
| | Air leakage from air duct (Mass air flow sensor — throttle body) | | 5 | 5 | 5 | 5 | | 5 | 4 | | | 5 | | | | |
| | Throttle body, Throttle wire | 5 | | | | | 5 | | | 4 | | | | | FE-3 | |
| | Air leakage from intake manifold/Collector/Gasket | | | | 5 | | | | | | | | | | | |
| Cranking | Battery | 1 | 1 | 1 | | 1 | | 1 | 1 | | | 1 | | 1 | SC-3 | |
| | Generator circuit | | | | | | | | | | | | | | | |
| | Starter circuit | | | | | | | | | | | | | | | |
| | Park/neutral position (PNP) switch | | | | | | | | | | | | | | | AT-99 |
| | Drive plate/Flywheel | | 6 | | | | | | | | | | | | | EM-110 |

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

Symptom Matrix Chart (Cont'd)

| | | SYMPTOM | | | | | | | | | | | | Reference section | |
|-----------------------|--|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|-------------------|--------------------------------|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Engine | Cylinder head | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | <i>EM-75, EM-84 and EM-102</i> |
| | Cylinder head gasket | | | | | | | | | | 2 | | 2 | | |
| | Cylinder block | | | | | | | | | | | | | | |
| | Piston | | | | | | | | | | | | 3 | | |
| | Piston ring | | | | | | | | | | | | | | |
| | Connecting rod | 6 | 6 | 6 | 6 | 6 | | 6 | 6 | | | 6 | | | |
| | Bearing | | | | | | | | | | | | | | |
| | Crankshaft | | | | | | | | | | | | | | |
| Valve mechanism | Timing chain | | | | | | | | | | | | | | <i>FE-8</i> |
| | Camshaft | | | | | | | | | | | | | | |
| | Intake valve | 6 | 6 | 6 | 6 | 6 | | 6 | 6 | | | 6 | 2 | | |
| | Exhaust valve | | | | | | | | | | | | | | |
| | Hydraulic lash adjuster | | | | | | | | | | | | | | |
| Exhaust | Exhaust manifold/Tube/Muffler/Gasket | 6 | 6 | 6 | 6 | 6 | | 6 | 6 | | | 6 | | | <i>MA-30, EM-72 and LC-20</i> |
| | Three way catalyst | | | | | | | | | | | | | | |
| Lubrication | Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery | 6 | 6 | 6 | 6 | 6 | | 6 | 6 | | | 6 | 2 | | <i>MA-30</i> |
| | Oil level (Low/Filthy) oil | | | | | | | | | | | | | | |
| Cooling | Radiator/Hose/Radiator filler cap | | | | | | | | | | | | | | <i>LC-26</i> |
| | Thermostat | | | | | | 5 | | | 5 | | | | | |
| | Water pump | | | | | | | | | | | | | | |
| | Water gallery | 6 | 6 | 6 | 6 | 6 | | 6 | 6 | | 2 | 6 | | | |
| | Cooling fan | | | | | | 5 | | | 5 | | | | | |
| | Coolant level (low)/Contaminated coolant | | | | | | | | | | | | | | |

1 - 6: The numbers refer to the order of inspection.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

CONSULT-II Reference Value in Data Monitor Mode

NGEC0563

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
 - * Specification data may not be directly related to their components signals/values/operations.
 - i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.
- If the real-time diagnosis results are NG and the on board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|----------------------------------|--|---|
| CMPS-RPM (POS) CMPS-RPM (REF) | <ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value. | Almost the same speed as the CONSULT-II value. |
| MAS AIR/FL SE | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle 1.0 - 1.7V |
| | | 2,500 rpm 1.7 - 2.3V |
| COOLAN TEMP/S | <ul style="list-style-type: none"> ● Engine: After warming up | More than 70°C (158°F) |
| FR O2 SEN-B2 FR O2 SEN-B1 | <ul style="list-style-type: none"> ● Engine: After warming up | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR-B2 FR O2 MNTR-B1 | | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |
| RR O2 SEN-B1 RR O2 SEN-B2 | <ul style="list-style-type: none"> ● Engine: After warming up | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR-B1 RR O2 MNTR-B2 | | LEAN ↔ RICH |
| VHCL SPEED SE | <ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value | Almost the same speed as the CONSULT-II value |
| BATTERY VOLT | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) | 11 - 14V |
| THRTL POS SEN | <ul style="list-style-type: none"> ● Engine: After warming up, idle the engine | Throttle valve: fully closed (a) 0.15 - 0.85V |
| | <ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) | Throttle valve: Partially open Between (a) and (b) |
| | | Throttle valve: fully opened (b) 3.5 - 4.7V |
| EGR TEMP SEN (If so equipped) | <ul style="list-style-type: none"> ● Engine: After warming up | Less than 4.5V |
| START SIGNAL | <ul style="list-style-type: none"> ● Ignition switch: ON → START → ON | OFF → ON → OFF |
| CLSD THL POS CLSD THL/P SW | <ul style="list-style-type: none"> ● Engine: After warming up, idle the engine | Throttle valve: Idle position ON |
| | | Throttle valve: Slightly open OFF |
| AIR COND SIG | <ul style="list-style-type: none"> ● Engine: After warming up, idle the engine | Air conditioner switch: OFF OFF |
| | | Air conditioner switch: ON (Compressor operates.) ON |
| P/N POSI SW | <ul style="list-style-type: none"> ● Ignition switch: ON | Shift lever: "P" or "N" ON |
| | | Except above OFF |
| PW/ST SIGNAL | <ul style="list-style-type: none"> ● Engine: After warming up, idle the engine | Steering wheel in neutral position (forward direction) OFF |
| | | The steering wheel is turned ON |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

| MONITOR ITEM | CONDITION | SPECIFICATION | | |
|--------------------------------|--|---|--------------------|-----------|
| AMB TEMP SW | <ul style="list-style-type: none"> ● Ignition switch: ON ● Compare ambient air temperature with the following: | Below 19°C (66°F) | OFF | GI |
| | | Above 25°C (77°F) | ON | |
| IGNITION SW | <ul style="list-style-type: none"> ● Ignition switch: ON → OFF → ON | | ON → OFF → ON | MA |
| INJ PULSE-B2 INJ PULSE-B1 | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle | 2.4 - 3.7 msec | EM |
| | | 2,000 rpm | 1.9 - 3.3 msec | |
| B/FUEL SCHDL | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle | 1.0 - 1.6 msec | LC |
| | | 2,000 rpm | 0.7 - 1.4 msec | EC |
| IGN TIMING | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle | 15° BTDC | FE |
| | | 2,000 rpm | More than 25° BTDC | |
| IACV-AAC/V | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle | 10 - 20% | CL |
| | | 2,000 rpm | — | MT |
| PURG VOL C/V | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle | 0 % | AT |
| | | 2,000 rpm | — | |
| A/F ALPHA-B2 A/F ALPHA-B1 | <ul style="list-style-type: none"> ● Engine: After warming up | Maintaining engine speed at 2,000 rpm | 54 - 155% | TF |
| EVAP SYS PRES | <ul style="list-style-type: none"> ● Ignition switch: ON | | Approx. 3.4V | PD |
| AIR COND RLY | <ul style="list-style-type: none"> ● Air conditioner switch: OFF → ON | | OFF → ON | |
| FUEL PUMP RLY | <ul style="list-style-type: none"> ● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking | | ON | AX |
| | Except as shown above | | OFF | |
| COOLING FAN | <ul style="list-style-type: none"> ● After warming up engine, idle the engine. ● Air conditioner switch: OFF | Engine coolant temperature is 94°C (201°F) or less | OFF | SU |
| | | Engine coolant temperature is 95°C (203°F) or more | ON | BR |
| EGRC SOL/V (If so equipped) | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle | OFF (CUT) | ST |
| | | Engine speed: Revving from idle up to 3,000 rpm quickly | ON (FLOW) | RS |
| VENT CONT/V | <ul style="list-style-type: none"> ● Ignition switch: ON | | OFF | |
| FR O2 HTR-B1 FR O2 HTR-B2 | <ul style="list-style-type: none"> ● Engine speed: Below 3,200 rpm | | ON | BT |
| | <ul style="list-style-type: none"> ● Engine speed: Above 3,200 rpm | | OFF | |
| RR O2 HTR-B1 RR O2 HTR-B2 | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Engine speed: Above 3,200 rpm | | OFF | HA |
| | <ul style="list-style-type: none"> ● Engine speed: Below 3,200 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] | | ON | SC |
| VC/V BYPASS/V | <ul style="list-style-type: none"> Ignition switch: ON | | OFF | EL |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

| MONITOR ITEM | CONDITION | SPECIFICATION | |
|---------------|--|---|--------------|
| CAL/LD VALUE | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle 18.5 - 26.0% | |
| | | 2,500 rpm 18.0 - 21.0% | |
| ABSOL TH·P/S | <ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. | Throttle valve: fully closed 0.0% | |
| | <ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) | Throttle valve: fully opened Approx. 80% | |
| MASS AIRFLOW | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load | Idle 3.3 - 4.8 g·m/s | |
| | | 2,500 rpm 12.0 - 14.9 g·m/s | |
| MAP/BARO SW/V | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) | MAP | |
| | <ul style="list-style-type: none"> ● Engine speed: Idle | For 5 seconds after starting engine | BARO |
| | | More than 5 seconds after starting engine | MAP |
| ABSOL PRES/SE | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) | | Approx. 4.4V |
| | <ul style="list-style-type: none"> ● Engine speed: Idle | For 5 seconds after starting engine | Approx. 4.4V |
| | | More than 5 seconds after starting engine | Approx. 1.3V |

Major Sensor Reference Graph in Data Monitor Mode


NGEC0564

The following are the major sensor reference graphs in "DATA MONITOR" mode. (Select "HI SPEED" in "DATA MONITOR" with CONSULT-II.)

THRTL POS SEN, ABSOL TH·P/S, CLSD THL POS

NGEC0564S01

Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch ON. The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".



CMPS-RPM (REF), MAS AIR/FL SE, THRTL POS SEN, RR O2 SEN-B1, FR O2 SEN-B1, INJ PULSE-B1

NGEC0564S02


Below is the data for "CMPS-RPM (REF)", "MAS AIR/FL SE", "THRTL POS SEN", "RR O2 SEN-B1", "FR O2 SEN-B1" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.

Each value is for reference, the exact value may vary.

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




SEF935QA

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




•“THRTL POS SEN” should increase while depressing the accelerator pedel and should decrease while releasing it.



•“RR O2 SEN-B1” may increase immediately after depressing the accelerator pedel and may decrease after releasing the pedal.




•“FR O2 SEN-B1” may increase immediately after depressing the accelerator pedel and may decrease after releasing the pedal.



•“INJ PULSE-B1” should increase when depressing the accelerator pedal and should decrease when the pedal is released.

SEF936Q



ECM Terminals and Reference Value


NGEC0565

PREPARATION


NGEC0565S01

1. ECM is located behind the instrument lower cover. For this inspection:

- Remove instrument lower cover.



2. Remove ECM harness protector.




3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.

- Open harness securing clip to make testing easier.
- Use extreme care not to touch 2 pins at one time.
- Data is for comparison and may not be exact.

ECM HARNESS CONNECTOR TERMINAL LAYOUT

NGEC0565S02



ECM INSPECTION TABLE

NGEC0565S03







Specification data are reference values and are measured between each terminal and 32 (ECM ground).

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E



ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-----------------|---|--|
| 1 | PU/W | Ignition signal | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed | <p>Approximately 0.7V</p>  <p style="text-align: right;">SEF988U</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>1.1 - 1.5V</p>  <p style="text-align: right;">SEF989U</p> |
| 2 | B | Ignition check | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>Approximately 12V</p>  <p style="text-align: right;">SEF990U</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>Approximately 11V</p>  <p style="text-align: right;">SEF991U</p> |
| 3 | R/L | Tachometer | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>1 - 2V</p>  <p style="text-align: right;">SEF992U</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>3 - 5V</p>  <p style="text-align: right;">SEF993U</p> |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---|---|---|
| 4 | OR/B | ECM relay (Self shut-off) | [Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> For a few seconds after turning ignition switch OFF | 0 - 1.5V |
| | | | [Ignition switch OFF] <ul style="list-style-type: none"> A few seconds passed after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 5 | R/Y | EVAP canister purge volume control solenoid valve | [Engine is running] <ul style="list-style-type: none"> Idle speed | BATTERY VOLTAGE (11 - 14V)  SEF994U |
| | | | [Engine is running] <ul style="list-style-type: none"> Engine speed is 2,000 rpm (More than 100 seconds after starting engine) | BATTERY VOLTAGE (11 - 14V)  SEF995U |
| 7 | Y/G | A/T check signal | [Ignition switch ON] [Engine is running] | 0 - 3.0V |
| 9 | B/Y | Ambient air temperature switch | [Engine is running] <ul style="list-style-type: none"> Idle speed Ambient air temperature is above 25°C (77°F) Air conditioner is operating | 0V |
| | | | [Engine is running] <ul style="list-style-type: none"> Idle speed Ambient air temperature is below 19°C (66°F) Air conditioner is operating | BATTERY VOLTAGE (11 - 14V) |
| | | | [Engine is running] <ul style="list-style-type: none"> Idle speed Ambient air temperature is below 19°C (66°F) Air conditioner is not operating | Approximately 5V |
| 10 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> Idle speed | Engine ground |
| 11 | W/R | Fuel pump relay | [Ignition switch ON] <ul style="list-style-type: none"> For 5 seconds after turning ignition switch ON | 0 - 1V |
| | | | [Engine is running] <ul style="list-style-type: none"> More than 5 seconds after turning ignition switch ON | BATTERY VOLTAGE (11 - 14V) |
| 12 | P | Air conditioner relay | [Engine is running] <ul style="list-style-type: none"> Both A/C switch and blower switch are ON* | 0 - 1V |
| | | | [Engine is running] <ul style="list-style-type: none"> A/C switch is OFF | BATTERY VOLTAGE (11 - 14V) |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E




ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--|---|-------------------------------|
| 18 | R/W | Malfunction indicator lamp | [Ignition switch ON] | 0 - 1V |
| | | | [Engine is running] ● Idle speed | BATTERY VOLTAGE (11 - 14V) |
| 19 | B/R | ECM ground | [Engine is running] ● Idle speed | Engine ground |
| 20 | L/OR | Start signal | [Ignition switch ON] | Approximately 0V |
| | | | [Ignition switch START] | 9 - 12V |
| 21 | G/R | Air conditioner switch | [Engine is running] ● Both A/C switch and blower switch are ON (Compressor operates)* | Approximately 0V |
| | | | [Engine is running] ● A/C switch is OFF | BATTERY VOLTAGE (11 - 14V) |
| 22 | L/B | Park/neutral position (PNP) switch | [Ignition switch ON] ● Gear position is "N" or "P" | Approximately 0V |
| | | | [Ignition switch ON] ● Except the above gear position | Approximately 5V |
| 23 | L | Throttle position sensor | [Engine is running] ● Warm-up condition ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. ● Accelerator pedal fully released | 0.15 - 0.85V |
| | | | [Ignition switch ON] ● Accelerator pedal fully depressed | 3.5 - 4.7V |
| 24 | W/L | Ignition switch | [Ignition switch OFF] | 0V |
| | | | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 25 | B/Y | ECM ground | [Engine is running] ● Idle speed | Engine ground |
| 26 | PU/W | A/T signal No. 1 | [Ignition switch ON] [Engine is running] ● Idle speed | 6 - 8V |
| 27 | P/B | A/T signal No. 2 | [Ignition switch ON] [Engine is running] ● Idle speed | 6 - 8V |
| 28 | BR/W | Throttle position switch (Closed position) | [Engine is running] ● Warm-up condition ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. ● Accelerator pedal fully released | BATTERY VOLTAGE (11 - 14V) |
| | | | [Ignition switch ON] ● Accelerator pedal depressed | Approximately 0V |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E







ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) | |
|---------------|------------|---|--|---|----------------------------------|
| 29 | G/B | Vehicle speed sensor | [Engine is running] <ul style="list-style-type: none"> ● Lift up the vehicle. ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH) | 2 - 3V  | GI MA EM LC |
| 32 | B/Y | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground (Probe this terminal with (-) tester probe when measuring) | EC |
| 35 | G/R | A/T signal No. 3 | [Ignition switch ON] | 0V | FE |
| 36 | LG/R | Cooling fan relay | [Engine is running] <ul style="list-style-type: none"> ● Cooling fan is not operating | BATTERY VOLTAGE (11 - 14V) | CL |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Cooling fan is operating | 0 - 1V | |
| 39 | GY/R | Power steering oil pressure switch | [Engine is running] <ul style="list-style-type: none"> ● Steering wheel is being turned | Approximately 0V | MT |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Steering wheel is not being turned | Approximately 5V | AT |
| 42 | B/W | Sensors' power supply | [Ignition switch ON] | Approximately 5V | TF |
| 43 | BR | Sensors' ground | [Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | Approximately 0V | PD |
| 44 48 | PU PU | Camshaft position sensor (Reference signal) | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | 0.3 - 0.5V  | AX SU BR |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | 0.3 - 0.5V  | ST RS BT |
| 45 | B/R | Absolute pressure sensor | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine is not running | Approximately 4.4V | HA |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle (for 5 seconds after engine start) | | |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle (More than 5 seconds after engine start) | Approximately 1.3V | SC |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--|--|---|
| 47 | L | Crankshaft position sensor (OBD) | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>1 - 2V (AC range)</p>  <p style="text-align: right; font-size: small;">SEF690W</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>3 - 4V (AC range)</p>  <p style="text-align: right; font-size: small;">SEF691W</p> |
| 49 | LG | Camshaft position sensor (Position signal) | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>Approximately 2.5V</p>  <p style="text-align: right; font-size: small;">SEF999U</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>Approximately 2.5V</p>  <p style="text-align: right; font-size: small;">SEF001V</p> |
| 50 | B | Front heated oxygen sensor RH | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm | <p>0 - Approximately 1.0V</p>  <p style="text-align: right; font-size: small;">SEF002V</p> |
| 51 | G | Front heated oxygen sensor LH | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm | <p>0 - Approximately 1.0V</p>  <p style="text-align: right; font-size: small;">SEF002V</p> |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E





ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) | |
|---------------|------------|-------------------------------------|---|---|-----------|
| 54 | R | Mass air flow sensor | [Engine is running] ● Warm-up condition ● Idle speed | 1.0 - 1.7V | GI |
| | | | [Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm | 1.7 - 2.3V | MA EM |
| 55 | G | Mass air flow sensor ground | [Engine is running] ● Warm-up condition ● Idle speed | Approximately 0V | LC |
| 56 | OR | Rear heated oxygen sensor RH | [Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm | 0 - Approximately 1.0V | EC |
| 57 | Y | Rear heated oxygen sensor LH | [Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm | 0 - Approximately 1.0V | FE CL |
| 59 | LG/R | Engine coolant temperature sensor | [Engine is running] | Approximately 0 - 4.8V Output voltage varies with engine coolant temperature | MT |
| 60 | Y/B | Fuel tank temperature sensor | [Engine is running] | Approximately 0 - 4.8V Output voltage varies with fuel temperature | AT |
| 61 | PU/R | Intake air temperature sensor | [Engine is running] | Approximately 0 - 4.8V Output voltage varies with intake air temperature. | TF |
| 62 | Y | EVAP control system pressure sensor | [Ignition switch ON] | Approximately 3.4V | PD |
| **63 | G/OR | EGR temperature sensor | [Ignition switch ON] | Less than 4.5V | AX |
| | | | [Engine is running] ● Warm-up condition ● EGR system is operating | 0 - 1.5V | SU |
| 64 | W | Knock sensor | [Engine is running] ● Idle speed | Approximately 2.5V | BR |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) | ST |
| 69 | LG/R | Data link connector for GST | [Engine is running] ● Idle speed (GST is disconnected) | 6 - 10V | RS |
| 72 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) | BT |
| 75 | Y/R | Data link connector for CONSULT-II | [Engine is running] | 0 - 4V | HA |
| 76 | GY/L | | ● Idle speed (Connect CONSULT-II and turned on.) | 3 - 9V | SC |
| 80 | SB | Power supply (Back-up) | [Ignition switch OFF] | BATTERY VOLTAGE (11 - 14V) | EL IDX |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--|---------------------------------------|--|---|---|
| 101 | OR/L | IACV-AAC valve | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>8 - 11V</p>  <p style="text-align: right;">SEF005V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 3,000 rpm | <p>7 - 10V</p>  <p style="text-align: right;">SEF692W</p> |
| 102 104 106 109 111 113 | W/B W/R W/G W/L W/PU W | Injector No. 1 Injector No. 3 Injector No. 5 Injector No. 2 Injector No. 4 Injector No. 6 | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>BATTERY VOLTAGE (11 - 14V)</p>  <p style="text-align: right;">SEF007V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm | <p>BATTERY VOLTAGE (11 - 14V)</p>  <p style="text-align: right;">SEF008V</p> |
| **103 | G/W | EGRC-solenoid valve | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>BATTERY VOLTAGE (11 - 14V)</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is revving from idle up to 3,000 rpm quickly | <p>0 - 1.5V</p> |
| 108 | R/G | EVAP canister vent control valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 116 | B/R | ECM ground | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 117 | B/P | Current return | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) |

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

VG33E

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) | |
|---------------|------------|--------------------------------------|---|----------------------------|----|
| 118 | Y/B | MAP/BARO switch solenoid valve | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine is not running ● For 5 seconds after ignition switch is turned ON | 0 - 1V | GI |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle (for 5 seconds after engine start) | | MA |
| 119 | BR/Y | Front heated oxygen sensor heater RH | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine is not running ● More than 5 seconds after ignition switch is turned ON | BATTERY VOLTAGE (11 - 14V) | EM |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle (More than 5 seconds after engine start) | | LC |
| 120 | P/B | Vacuum cut valve bypass valve | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine speed is below 3,200 rpm | Approximately 0.4V | EC |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm | BATTERY VOLTAGE (11 - 14V) | FE |
| 121 | BR | Front heated oxygen sensor heater LH | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine speed is below 3,200 rpm | Approximately 0.4V | CL |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm | BATTERY VOLTAGE (11 - 14V) | MT |
| 122 | R/B | Rear heated oxygen sensor heater RH | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,200 rpm ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. | Approximately 0.4V | AT |
| | | | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm | BATTERY VOLTAGE (11 - 14V) | TF |
| 123 | R/Y | Rear heated oxygen sensor heater LH | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,200 rpm ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. | Approximately 0.4V | PD |
| | | | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm | BATTERY VOLTAGE (11 - 14V) | AX |
| 124 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground | SU |

*: Any mode except OFF, ambient air temperature is above 25°C (77°F).

**: If equipped with EGR valve.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Description

Description

NGEC0566

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

COMMON I/I REPORT SITUATIONS

NGEC0566S01

| STEP in Work Flow | Situation |
|-------------------|--|
| II | The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]". |
| III | The symptom described by the customer does not recur. |
| IV | (1st trip) DTC does not appear during the DTC Confirmation Procedure. |
| VI | The Diagnostic Procedure for PXXXX does not indicate the problem area. |

Diagnostic Procedure

NGEC0567

| | |
|--|-------------------------|
| 1 | INSPECTION START |
| Erase (1st trip) DTCs. Refer to "HOW TO ERASE EMISSION — RELATED INFORMATION", EC-640. | |
| | ▶ GO TO 2. |

| | |
|---|-------------------------------|
| 2 | CHECK GROUND TERMINALS |
| Check ground terminals for corroding or loose connection. Refer to "Circuit Inspection", "GROUND INSPECTION", <i>GI-29</i> . | |
| OK or NG | |
| OK | ▶ GO TO 3. |
| NG | ▶ Repair or replace. |




| | |
|---|---------------------------------------|
| 3 | SEARCH FOR ELECTRICAL INCIDENT |
| Perform "Incident Simulation Tests", <i>GI-24</i> . | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair or replace. |

| | |
|---|----------------------------------|
| 4 | CHECK CONNECTOR TERMINALS |
| Refer to "How to Check Enlarged Contact Spring of Terminal", <i>GI-21</i> . | |
| OK or NG | |
| OK | ▶ INSPECTION END |
| NG | ▶ Repair or replace connector. |

Main Power Supply and Ground Circuit WIRING DIAGRAM

NGEC0568

EC-MAIN-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY

VG33E

Main Power Supply and Ground Circuit (Cont'd)

ECM TERMINALS AND REFERENCE VALUE

NGEC0569


Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|--------------------------|---|---|
| 4 | OR/B | ECM relay (Self-shutoff) | [Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF | 0 - 1.5V |
| | | | [Ignition switch OFF] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 10 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 19 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 24 | W/L | Ignition switch | [Ignition switch OFF] | 0V |
| | | | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 25 | B/Y | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 32 | B/Y | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground (Probe this terminal with (-) tester probe when measuring) |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 80 | SB | Power supply (Back-up) | [Ignition switch OFF] | BATTERY VOLTAGE (11 - 14V) |
| 116 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |
| 117 | B/P | Current return | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) |
| 124 | B/R | ECM ground | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | Engine ground |

DIAGNOSTIC PROCEDURE

NGEC0570


| | | | |
|---------------------------|-------------------------|----------|--|
| 1 | INSPECTION START | | |
| Start engine. | | | |
| Is engine running? | | | |
| Yes or No | | | |
| Yes | ▶ | GO TO 6. | |
| No | ▶ | GO TO 2. | |

| | | | | |
|----------|---|---|-----------------------------------|----|
| 2 | CHECK ECM POWER SUPPLY CIRCUIT-I | <p>1. Turn ignition switch OFF and then ON. 2. Check voltage between ECM terminal 24 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue; margin-left: 20px;">Voltage: Battery voltage</p> <p style="text-align: center; margin-top: 20px;">OK or NG</p> | GI MA EM LC EC | |
| | OK | ▶ | GO TO 4. | FE |
| | NG | ▶ | GO TO 3. | CL |


| | | | | |
|----------|-----------------------------------|--|-------------------------------|----|
| 3 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M59, F27 ● Fuse block (J/B) connector E49 ● 10A fuse ● Harness for open or short between ECM and fuse | MT AT TF | |
| | | ▶ | Repair harness or connectors. | PD |



| | | | | |
|----------|--|--|----------------|----|
| 4 | CHECK ECM GROUND CIRCUIT-I FOR OPEN AND SHORT | <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 10, 19, 25, 32, 116, 124 and engine ground. Refer to WIRING DIAGRAM. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> <p style="text-align: center; margin-top: 20px;">OK or NG</p> | AX SU BR | |
| | OK | ▶ | GO TO 15. | ST |
| | NG | ▶ | GO TO 5. | RS |

| | | | | |
|----------|-----------------------------------|--|--|--|
| 5 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-2 ● Harness for open or short between ECM and engine ground | BT HA SC EL IDX | |
| | | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

| | | |
|---|--|----------|
| 6 | CHECK ECM POWER SUPPLY CIRCUIT-II | |
| <p>1. Stop engine. 2. Check voltage between ECM terminal 80 and ground with CONSULT-II or tester.</p> | | |
|  | | |
| <p>Voltage: Battery voltage</p> <p style="text-align: right;">SEF678U</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

| | | |
|---|-----------------------------------|--|
| 7 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Fuse block (J/B) connector M27 ● 10A fuse ● Harness for open or short between ECM and fuse | | |
| ▶ Repair harness or connectors. | | |

| | | |
|---|---|-----------|
| 8 | CHECK ECM POWER SUPPLY CIRCUIT-III | |
| <p>1. Turn ignition switch ON and then OFF. 2. Check voltage between ECM terminals 67, 72, 117 and ground with CONSULT-II or tester.</p> | | |
|  | | |
| <p>Voltage: After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop to approximately 0V.</p> <p style="text-align: right;">SEF679U</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG (Battery voltage does not exist.) | ▶ | GO TO 9. |
| NG (Battery voltage exists for more than a few seconds.) | ▶ | GO TO 13. |

| | | | | |
|----------|--|---|-------------------------------|--|
| 9 | CHECK ECM POWER SUPPLY CIRCUIT-IV | <p>1. Disconnect ECM relay.</p> <div style="text-align: center;"> <p>View from passenger side</p>  </div> <p>2. Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>AEC927A</p> <p>SEF625W</p> | |
| | OK | ▶ | GO TO 11. | |
| | NG | ▶ | GO TO 10. | |

| | | | |
|-----------|-----------------------------------|---|--|
| 10 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ECM relay and harness connector F27 | |
| | | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | | |
|-----------|---|--|--|
| 11 | CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | <p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 4 and ECM relay terminal 1. Refer to WIRING DIAGRAM. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| | OK | ▶ | GO TO 12. |
| | NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | | |
|-----------|--|---|--|
| 12 | CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM FOR OPEN AND SHORT | <p>1. Check harness continuity between ECM terminals 67, 72, 117 and ECM relay terminal 3. Refer to WIRING DIAGRAM. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| | OK | ▶ | GO TO 13. |
| | NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY


VG33E

Main Power Supply and Ground Circuit (Cont'd)

| | |
|---|------------------------|
| 13 | CHECK ECM RELAY |
| <p>1. Apply 12V direct current between relay terminals 1 and 2. 2. Check continuity between relay terminals 3 and 5.</p> <div style="text-align: center;"> </div> <p style="color: blue; margin-top: 10px;">12V (1 - 2) applied: Continuity exists. No voltage applied: No continuity</p> <p style="text-align: right;">SEF039W</p> | |
| OK or NG | |
| OK | ▶ GO TO 14. |
| NG | ▶ Replace ECM relay. |

| | |
|--|---|
| 14 | CHECK ECM GROUND CIRCUIT-II FOR OPEN AND SHORT |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 10, 19, 25, 32, 116, 124 and engine ground. Refer to WIRING DIAGRAM. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> <p style="text-align: right;">OK or NG</p> | |
| OK | ▶ GO TO 15. |
| NG | ▶ GO TO 5. |

| | |
|---|------------------------------------|
| 15 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |



Component Description

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|---------------|--|-----------|-------------------|
| MAS AIR/FL SE | <ul style="list-style-type: none"> Engine: After warming up Air conditioner switch: OFF Shift lever: "N" No-load | Idle | 1.0 - 1.7V |
| | | 2,500 rpm | 1.7 - 2.3V |
| CAL/LD VALUE | ditto | Idle | 18.5 - 26.0% |
| | | 2,500 rpm | 18.0 - 21.0% |
| MASS AIRFLOW | ditto | Idle | 3.3 - 4.8 g·m/s |
| | | 2,500 rpm | 12.0 - 14.9 g·m/s |

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|-----------------------------|---|-------------------|
| 54 | R | Mass air flow sensor | [Engine is running] <ul style="list-style-type: none"> Warm-up condition Idle speed | 1.0 - 1.7V |
| | | | [Engine is running] <ul style="list-style-type: none"> Warm-up condition Engine speed is 2,500 rpm | 1.7 - 2.3V |
| 55 | G | Mass air flow sensor ground | [Engine is running] <ul style="list-style-type: none"> Warm-up condition Idle speed | Approximately 0V |

On Board Diagnosis Logic

Malfunction is detected when
 (Malfunction A) an excessively high voltage from the sensor is sent to ECM when engine is not running,
 (Malfunction B) an excessively low voltage from the sensor is sent to ECM when engine is running,
 (Malfunction C) a high voltage from the sensor is sent to ECM under light load driving condition,
 (Malfunction D) a low voltage from the sensor is sent to ECM under heavy load driving condition.

POSSIBLE CAUSE

Malfunction A or C

NGEC0574S01

NGEC0574S0101

- Harness or connectors
(The sensor circuit is open or shorted.)
- Mass air flow sensor

Malfunction B or D

NGEC0574S0102

- Harness or connectors
(The sensor circuit is open or shorted.)
- Intake air leaks
- Mass air flow sensor

FAIL-SAFE MODE

NGEC0574S02

When the malfunction B is detected, the ECM enters fail-safe mode and the MIL lights up.

| Detected items | Engine operating condition in fail-safe mode |
|------------------------------|---|
| Mass air flow sensor circuit | Engine speed will not rise more than 2,400 rpm due to the fuel cut. |


DTC Confirmation Procedure

NGEC0575

Perform "PROCEDURE FOR MALFUNCTION A" first.
If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".
If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".
If there is no problem on "PROCEDURE FOR MALFUNCTION C", perform "PROCEDURE FOR MALFUNCTION D".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.



PROCEDURE FOR MALFUNCTION A

NGEC0575S01

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-718.

With GST

Follow the procedure "With CONSULT-II".

| | | |
|----------|-----------------------|----------------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) XXX rpm | |

PEF357V

PROCEDURE FOR MALFUNCTION B

NGEC0575S02

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait 5 seconds at most.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-718.

With GST

Follow the procedure "With CONSULT-II".

| | | |
|----------|---|----------------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) XXX rpm COOLAN TEMP/S XXX °C | |

PEF361V

PROCEDURE FOR MALFUNCTION C

NGEC0575S03

NOTE:

If engine will not start or stops soon, wait at least 10 seconds with engine stopped (Ignition switch ON) instead of running engine at idle speed.

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and warm it up to normal operating temperature.
- 4) Run engine for at least 10 seconds at idle speed.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-718.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX




7

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| VHCL SPEED SE | XXX km/h |
| THRTL POS SEN | XXX V |

PEF362V

| | |
|--------------|-------------------|
| CALC LOAD | 20% |
| COOLANT TEMP | 95°C |
| SHORT FT #1 | 2% |
| LONG FT #1 | 0% |
| SHORT FT #2 | 4% |
| LONG FT #2 | 0% |
| ENGINE SPD | 2637RPM |
| VEHICLE SPD | 0MPH |
| IGN ADVANCE | 41.0° |
| INTAKE AIR | 41°C |
| MAF | 14.1gm/sec |
| THROTTLE POS | 3% |

SEF534P



PROCEDURE FOR MALFUNCTION D

NGEC0575S04

CAUTION:

Always drive vehicle at a safe speed.

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up to normal operating temperature. **If engine cannot be started, go to "Diagnostic Procedure", EC-718.**
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Check the voltage of MAS AIR/FL SE with "DATA MONITOR".
- 5) Increases engine speed to about 4,000 rpm.
- 6) Monitor the linear voltage rise in response to engine speed increases.
If NG, go to "Diagnostic Procedure", EC-718.
If OK, go to following step.
- 7) Maintain the following conditions for at least 10 consecutive seconds.

| | |
|------------------|--|
| CMPS-RPM (REF) | More than 2,000 rpm |
| THRTL POS SEN | More than 3V |
| Selector lever | Suitable position |
| Driving location | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-718.

Overall Function Check

NGEC0576

PROCEDURE FOR MALFUNCTION D

NGEC0576S01

Use this procedure to check the overall function of the mass air flow sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Ⓜ With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MODE 1" with GST.
- 3) Check the mass air flow sensor signal with "MODE 1".
- 4) Check for linear mass air flow sensor signal value rise in response to increases to about 4,000 rpm in engine speed.
- 5) If NG, go to "Diagnostic Procedure", EC-718.




Ⓜ No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.
- 3) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.
- 4) If NG, go to "Diagnostic Procedure", EC-718.

Wiring Diagram

NGEC0577

EC-MAFS-01



AEC939A


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX



Diagnostic Procedure

NGEC0578

| 1 | INSPECTION START | | | | | | | |
|---|-------------------------|----------|-------------|------|------------|---|------------|----|
| Which malfunction (A, B, C or D) is duplicated? | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">MALFUNCTION</th> <th style="width: 50%;">Type</th> </tr> </thead> <tbody> <tr> <td>A and/or C</td> <td style="text-align: center;">I</td> </tr> <tr> <td>B and/or D</td> <td style="text-align: center;">II</td> </tr> </tbody> </table> | | | MALFUNCTION | Type | A and/or C | I | B and/or D | II |
| MALFUNCTION | Type | | | | | | | |
| A and/or C | I | | | | | | | |
| B and/or D | II | | | | | | | |
| MTBL0063 | | | | | | | | |
| Type I or Type II | | | | | | | | |
| Type I | ▶ | GO TO 3. | | | | | | |
| Type II | ▶ | GO TO 2. | | | | | | |

| | | |
|--|----------------------------|----------------------|
| 2 | CHECK INTAKE SYSTEM | |
| Check the following for connection. | | |
| <ul style="list-style-type: none"> ● Air duct ● Vacuum hoses ● Intake air passage between air duct to intake manifold collector | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Reconnect the parts. |

| | | |
|--|--------------------------------|------------|
| 3 | RETIGHTEN GROUND SCREWS | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws. | | |
|  <p style="text-align: center;">Engine ground</p> <p style="text-align: right;"><small>AEC640A</small></p> | | |
| | | ▶ GO TO 4. |

| | |
|--|--|
| 4 | CHECK MAFS POWER SUPPLY CIRCUIT |
| <p>1. Disconnect mass air flow sensor harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 400px;">Air cleaner</p> <p style="margin-left: 350px;">Mass air flow sensor harness connector</p> </div> | |
| <p>2. Turn ignition switch ON.</p> <p>3. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Voltage: Battery voltage</p> <p style="margin-left: 200px;">OK or NG</p> </div> | |
| OK | ▶ GO TO 6. |
| NG | ▶ GO TO 5. |

AEC641A

SEF627W

| | |
|--|-----------------------------------|
| 5 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ECM relay and mass air flow sensor ● Harness for open or short between mass air flow sensor and ECM | |
| ▶ | Repair harness or connectors. |

| | |
|--|--|
| 6 | CHECK MAFS GROUND CIRCUIT FOR OPEN AND SHORT |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between MAFS terminal 3 and ECM terminal 55. Refer to Wiring Diagram.</p> <p style="color: blue;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 7. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|---|--|
| 7 | CHECK MAFS INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Check harness continuity between MAFS terminal 4 and ECM terminal 54. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 8 | CHECK MASS AIR FLOW SENSOR | | | | | | | | | | | |
|---|-----------------------------------|-------------------------------|-----------|-----------|--|---------------|---|-----------|--|-----------|--------------------------|--------------------------|
| <p>1. Reconnect harness connectors disconnected.</p> <p>2. Start engine and warm it up to normal operating temperature.</p> <p>3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.</p> | | | | | | | | | | | | |
|  | | | | | | | | | | | | |
| SEF747U | | | | | | | | | | | | |
| <table border="1" style="width: 100%;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th style="width: 40%;">Voltage V</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "ON" (Engine stopped.)</td> <td>Less than 1.0</td> </tr> <tr> <td>Idle (Engine is warmed-up to normal operating temperature.)</td> <td>1.0 - 1.7</td> </tr> <tr> <td>2,500 rpm (Engine is warmed-up to normal operating temperature.)</td> <td>1.7 - 2.3</td> </tr> <tr> <td>Idle to about 4,000 rpm*</td> <td>1.0 - 1.7 to Approx. 4.0</td> </tr> </tbody> </table> | | | Condition | Voltage V | Ignition switch "ON" (Engine stopped.) | Less than 1.0 | Idle (Engine is warmed-up to normal operating temperature.) | 1.0 - 1.7 | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.7 - 2.3 | Idle to about 4,000 rpm* | 1.0 - 1.7 to Approx. 4.0 |
| Condition | Voltage V | | | | | | | | | | | |
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 | | | | | | | | | | | |
| Idle (Engine is warmed-up to normal operating temperature.) | 1.0 - 1.7 | | | | | | | | | | | |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.7 - 2.3 | | | | | | | | | | | |
| Idle to about 4,000 rpm* | 1.0 - 1.7 to Approx. 4.0 | | | | | | | | | | | |
| MTBL0227 | | | | | | | | | | | | |
| <p>4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Then repeat above check.</p> <p>5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.</p> | | | | | | | | | | | | |
|  | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | |
| OK | ▶ | GO TO 9. | | | | | | | | | | |
| NG | ▶ | Replace mass air flow sensor. | | | | | | | | | | |

SEF030T

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|----------|---|--|
| 9 | CHECK MAFS SHIELD CIRCUIT FOR OPEN AND SHORT | |
| | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect joint connector-2.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between joint connector terminal 1 and ground Refer to Wiring Diagram. ● Joint connector (Refer to "HARNESS LAYOUT", <i>EL-292</i>.) Continuity should exist. <p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect joint connector-2.</p> <p style="text-align: center;">OK or NG</p> | |
| | OK | ▶ GO TO 10. |
| | NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|-----------|---|-----------------------|
| 10 | CHECK INTERMITTENT INCIDENT | |
| | Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT



HA

SC

EL

IDX

Component Description



Component Description

The absolute pressure sensor is connected to the MAP/BARO ^{NGEC0579} switch solenoid valve by a hose. The sensor detects ambient barometric pressure and intake manifold absolute pressure and sends the voltage signal to the ECM. As the pressure increases, the voltage rises.

On Board Diagnosis Logic

NGEC0580

Malfunction is detected when
 (Malfunction A) an excessively low or high voltage from the sensor is sent to ECM,
 (Malfunction B) a high voltage from the sensor is sent to ECM under light load driving conditions,
 (Malfunction C) a low voltage from the sensor is sent to ECM under heavy load driving conditions.

POSSIBLE CAUSE

NGEC0580S01

Malfunction A

NGEC0580S0101

- Harness or connectors
(Absolute pressure sensor circuit is open or shorted.)
- Absolute pressure sensor

Malfunction B

NGEC0580S0102

- Hoses
(Hoses between the intake manifold and absolute pressure sensor are disconnected or clogged.)
- Intake air leaks
- MAP/BARO switch solenoid valve
- Absolute pressure sensor

Malfunction C

NGEC0580S0103

- Absolute pressure sensor

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

If the 1st trip DTC is not confirmed on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

| | | |
|----------|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | COOLAN TEMP/S | XXX °C |

PEF002P

| | | |
|----------|---------------|---------|
| 4 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |

PEF361V

| | | |
|----------|---------------|----------|
| 7 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | VHCL SPEED SE | XXX km/h |
| | B/FUEL SCHDL | XXX msec |
| | ABSOL PRES/SE | XXX V |

PEF127V

PROCEDURE FOR MALFUNCTION A

NGEC0581S01

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-726.

With GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION B

NGEC0581S02

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine and let it idle.
- 5) Wait at least 15 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-726.

With GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION C

NGEC0581S03

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
The voltage of "ABSOL PRES/SE" should be more than 1.74 [V].
If the check result is NG, go to "Diagnostic Procedure", EC-726.

If the check result is OK, go to following step.

- 3) Start engine and warm it up to normal operating temperature.
- 4) Turn ignition switch OFF and wait at least 5 seconds.
- 5) Start engine and let it idle for at least 13 seconds.
- 6) Select "DATA MONITOR" mode with CONSULT-II.
- 7) Drive the vehicle at least 3 consecutive seconds under the following conditions,

| | |
|------------------|--|
| CMPS-RPM (REF) | 3,000 - 4,800 rpm |
| B/FUEL SCHDL | More than 4.6 msec |
| Selector lever | Suitable position |
| Driving location | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-726.

| | |
|--------------------|---------------|
| ENGINE SPD | 0RPM |
| COOLANT TEMP | 69°C |
| VEHICLE SPD | 0MPH |
| IGN ADVANCE | 3.0° |
| CALC LOAD | 0.0% |
| MAP | 101kPa |
| MAF | 0.25gm/s |
| THROTTLE POS | 0.0% |
| INTAKE AIR | 27°C |
| FUEL SYS #1 | OL |
| FUEL SYS #2 | UNUSED |
| SHORT FT #1 | 0.0% |
| LONG FT #1 | 0.0% |
| O2S B1 S1 | 0.000V |
| O2FT B1 S1 | 0.0% |
| O2S B1 S2 | 0.000V |

SEF518R

Overall Function Check

NGEC0582

PROCEDURE FOR MALFUNCTION C

NGEC0582S01


Use this procedure to check the overall function of the absolute pressure sensor circuit. During this check, a 1st trip DTC might not be confirmed.

With GST

- 1) Turn ignition switch ON.
- 2) Select absolute pressure sensor signal in "MODE 1" with GST.
- 3) Make sure that the signal is more than 46 kPa (0.47 kg/cm², 6.7 psi).
- 4) If NG, go to "Diagnostic Procedure", EC-726.

No Tools

- 1) Turn ignition switch ON.
- 2) Make sure that the voltage between ECM terminal 45 (Absolute pressure sensor signal) and ground is more than 1.74 [V].
- 3) If NG, go to "Diagnostic Procedure", EC-726.



DTC P0105 ABSOLUTE PRESSURE SENSOR


VG33E

Wiring Diagram

Wiring Diagram

NGEC0583

EC-AP/SEN-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



AEC940A


Diagnostic Procedure


If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION A or C", perform "PROCEDURE A" below. If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE B", EC-730.

NGEC0584

PROCEDURE A

NGEC0584S01

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws. | |
|  <p style="text-align: center;">Engine ground</p> | |
| AEC640A | |
| ▶ | GO TO 2. |

| | |
|---|---|
| 2 | CHECK ABSOLUTE PRESSURE SENSOR CONNECTOR FOR WATER |
| <ol style="list-style-type: none"> 1. Disconnect absolute pressure sensor harness connector. | |
|  <p style="text-align: center;">Absolute pressure sensor Air cleaner</p> | |
| AEC642A | |
| <ol style="list-style-type: none"> 2. Check sensor harness connector for water. Water should not exist. | |
| OK or NG | |
| OK | ▶ GO TO 3. |
| NG | ▶ Repair or replace harness connector. |

DTC P0105 ABSOLUTE PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|--|----------|
| 3 | CHECK ABSOLUTE PRESSURE SENSOR POWER SUPPLY CIRCUIT | |
| <p>1. Turn ignition switch ON. 2. Check voltage between sensor terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;"> </div> <p style="color: blue; font-weight: bold;">Voltage: Approximately 5V</p> <p style="text-align: right;">SEF200W</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

| | | |
|--|-----------------------------------|-------------------------------|
| 4 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M59, F27 ● Harness for open or short between ECM and absolute pressure sensor | | |
| | ▶ | Repair harness or connectors. |

| | | |
|---|---|----------|
| 5 | CHECK ABSOLUTE PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between sensor terminal 3 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |

| | | |
|--|-----------------------------------|--|
| 6 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M59, F27 ● Harness connectors F28, M58 ● Joint connector-4 ● Harness for open or short between ECM and absolute pressure sensor ● Harness for open or short between TCM (Transmission Control Module) and absolute pressure sensor | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0105 ABSOLUTE PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|---|----------|
| 7 | CHECK ABSOLUTE PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 45 and sensor terminal 2. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | GO TO 8. |

| | | |
|--|-----------------------------------|--|
| 8 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M59, F27 ● Harness for open or short between ECM and absolute pressure sensor | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|--|---------------------------------------|-----------------------------------|
| 9 | CHECK ABSOLUTE PRESSURE SENSOR | |
| <p>1. Remove absolute pressure sensor with its harness connector connected.</p> <p>2. Remove hose from absolute pressure sensor.</p> <p>3. Turn ignition switch ON and check output voltage between ECM terminal 45 and engine ground.</p> | | |
| <p>The diagram illustrates the test setup. A vacuum pump is connected to the absolute pressure sensor. The sensor's harness is connected to the ECM terminal 45. A voltmeter is connected between terminal 45 and engine ground. The ignition switch is turned ON.</p> | | |
| <p>The voltage should be 3.2 to 4.8V.</p> <p>4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.</p> <p>The voltage should be 1.0 to 1.4V lower than the value measured in step 3.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Always calibrate the vacuum pump gauge when using it. ● Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure. <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace absolute pressure sensor. |

SEF749U

DTC P0105 ABSOLUTE PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|-----------|---|--|
| 10 | CHECK ABSOLUTE PRESSURE SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT | |
| | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect joint connector-1.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between joint connector terminal 1 and ground Refer to Wiring Diagram. ● Joint connector (Refer to "HARNESS LAYOUT", <i>EL-292</i>.) Continuity should exist. <p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect joint connector-1.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 11. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|-----------|---|-----------------------|
| 11 | CHECK INTERMITTENT INCIDENT | |
| | Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

PROCEDURE B


=NGEC0584S02

1 INSPECTION START

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Attach the vacuum gauge between the absolute pressure sensor and the rubber tube connected to the MAP/BARO switch solenoid valve.



AEC642A



SEF385U

Models with CONSULT-II ► GO TO 2.

Models without CONSULT-II ► GO TO 3.

2 CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR

(With CONSULT-II)

1. Start engine and let it idle.
2. Select "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "MAP" and "BARO" alternately and check for vacuum.

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | MAP |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | MAP |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | BARO |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | BARO |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| | |
|---------------|------------------|
| MAP/BARO SW/V | Vacuum |
| BARO | Should not exist |
| MAP | Should exist |

SEF183X

OK or NG

OK ► GO TO 8.

NG ► GO TO 4.


DTC P0105 ABSOLUTE PRESSURE SENSOR

VG33E


Diagnostic Procedure (Cont'd)

| 3 | CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR | | | | | | | |
|--|--|----------|-----------|--------|-------------------------------------|------------------|---|--------------|
| <p>⊗ (Without CONSULT-II)</p> <p>1. Start engine and let it idle.</p> <p>2. Check for vacuum under the following condition.</p> | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Vacuum</th> </tr> </thead> <tbody> <tr> <td>For 5 seconds after starting engine</td> <td>Should not exist</td> </tr> <tr> <td>More than 5 seconds after starting engine</td> <td>Should exist</td> </tr> </tbody> </table> | | | Condition | Vacuum | For 5 seconds after starting engine | Should not exist | More than 5 seconds after starting engine | Should exist |
| Condition | Vacuum | | | | | | | |
| For 5 seconds after starting engine | Should not exist | | | | | | | |
| More than 5 seconds after starting engine | Should exist | | | | | | | |
| MTBL0080 | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |

GI
MA
EM
LC
EC

| | | |
|---|--------------------------|------------------------------------|
| 4 | CHECK VACUUM HOSE | |
| <p>1. Turn ignition switch OFF.</p> <p>2. Check vacuum hose for clogging, cracks, disconnection or improper connection.</p> | | |
|  | | |
| SEF109L | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Clean, repair or replace the hose. |

FE
CL
MT
AT
TF
PD
AX
SU

| | | |
|--|--------------------------|----------------------------------|
| 5 | CHECK VACUUM PORT | |
| <p>Check vacuum port for clogging.</p> | | |
|  | | |
| SEF368U | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Clean or repair the vacuum port. |

BR
ST
RS
BT
HA
SC
EL


DTC P0105 ABSOLUTE PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|---|
| 6 | CHECK MAP/BARO SWITCH SOLENOID VALVE |
| Refer to "Component Inspection", EC-669. | |
| OK or NG | |
| OK | ▶ GO TO 7. |
| NG | ▶ Replace MAP/BARO switch solenoid valve. |

| | |
|------------------------------------|----------------------------|
| 7 | CHECK INTAKE SYSTEM |
| Check intake system for air leaks. | |
| OK or NG | |
| OK | ▶ GO TO 11. |
| NG | ▶ Repair it. |


| | |
|---|---|
| 8 | CHECK HOSE BETWEEN ABSOLUTE PRESSURE SENSOR AND MAP/BARO SWITCH SOLENOID VALVE |
| 1. Turn ignition switch OFF. 2. Check hose for clogging, cracks, disconnection or improper connection. | |
|  | |
| SEF109L | |
| OK or NG | |
| OK | ▶ GO TO 9. |
| NG | ▶ Repair or reconnect hose. |

| | |
|---|---|
| 9 | CHECK ABSOLUTE PRESSURE SENSOR HARNESS CONNECTOR FOR WATER |
| 1. Disconnect absolute pressure sensor harness connector. 2. Check sensor harness connector for water. Water should not exist. | |
| OK or NG | |
| OK | ▶ GO TO 10. |
| NG | ▶ Repair or replace harness connector. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

10 CHECK ABSOLUTE PRESSURE SENSOR

1. Remove absolute pressure sensor with its harness connector connected.
2. Remove hose from absolute pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM terminal 45 and engine ground.



SEF749U

The voltage should be 3.2 to 4.8V.

4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG



| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 11. |
| NG | ▶ | Replace absolute pressure sensor. |

11 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

▶ **INSPECTION END**

Component Description



Component Description

NGEC0585

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

<Reference data>

| Intake air temperature °C (°F) | Voltage* (V) | Resistance kΩ |
|--------------------------------|--------------|---------------|
| 20 (68) | 3.5 | 2.1 - 2.9 |
| 80 (176) | 1.23 | 0.27 - 0.38 |

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ECM terminal 32 (ECM ground).

On Board Diagnosis Logic

NGEC0586

Malfunction is detected when
 (Malfunction A) an excessively low or high voltage from the sensor is sent to ECM,
 (Malfunction B) rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.

POSSIBLE CAUSE

NGEC0586S01

- Harness or connectors
(The sensor circuit is open or shorted.)
- Intake air temperature sensor

DTC Confirmation Procedure

NGEC0587

Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

| | | |
|----------|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF356V

PROCEDURE FOR MALFUNCTION A

NGEC0587S01

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-737.

With GST

Follow the procedure "With CONSULT-II".

No Tools

- 1) Turn ignition switch ON and wait at least 5 seconds.
- 2) Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-737.

| | | |
|---------------|---------------|---------|
| 5 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | COOLAN TEMP/S | XXX °C |
| VHCL SPEED SE | XXX km/h | |

PEF233U

PROCEDURE FOR MALFUNCTION B

NGEC0587S02

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

With CONSULT-II

- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - a) Turn ignition switch ON.
 - b) Select "DATA MONITOR" mode with CONSULT-II.
 - c) Check the engine coolant temperature.
 - d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch OFF and cool down engine.
 - Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 2) Turn ignition switch ON.
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine.
- 5) Hold vehicle speed at more than 70 km/h (43 MPH) for 100 consecutive seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-737.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

Wiring Diagram



NGEC0588

EC-IATS-01



Diagnostic Procedure

NGEC0589

| | | |
|--|---|----------|
| 1 | CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect intake air temperature sensor harness connector.</p> <div style="text-align: center;">  </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

AEC930A
SEF203W

| | | |
|---|-----------------------------------|-------------------------------|
| 2 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M81, F36 ● Harness for open or short between ECM and intake air temperature sensor | | |
| ▶ | | Repair harness or connectors. |

| | | |
|---|--|----------|
| 3 | CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between sensor terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | |
|---|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M81, F36 ● Harness connectors F28, M58 ● Joint connector-4 ● Harness for open or short between ECM and intake air temperature sensor ● Harness for open or short between TCM (Transmission Control Module) and intake air temperature sensor | |
| | Repair open circuit or short to ground or short to power in harness or connectors. |



| 5 | CHECK INTAKE AIR TEMPERATURE SENSOR | | | | | | |
|---|--|--------------------------------|---------------|---------|-----------|----------|-------------|
| Check resistance as shown in the figure. | | | | | | | |
| | | | | | | | |
| SEF947Q | | | | | | | |
| <Reference data> | | | | | | | |
| <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Intake air temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">80 (176)</td> <td style="text-align: center;">0.27 - 0.38</td> </tr> </tbody> </table> | | Intake air temperature °C (°F) | Resistance kΩ | 20 (68) | 2.1 - 2.9 | 80 (176) | 0.27 - 0.38 |
| Intake air temperature °C (°F) | Resistance kΩ | | | | | | |
| 20 (68) | 2.1 - 2.9 | | | | | | |
| 80 (176) | 0.27 - 0.38 | | | | | | |
| MTBL0228 | | | | | | | |
| | | | | | | | |
| SEF012P | | | | | | | |
| OK or NG | | | | | | | |
| OK | GO TO 6. | | | | | | |
| NG | Replace intake air temperature sensor. | | | | | | |

| | |
|---|------------------------------------|
| 6 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | INSPECTION END |

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

VG33E

Component Description



Component Description

NGEC0590

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

GI
MA
EM
LC

<Reference data>

| Engine coolant temperature °C (°F) | Voltage* (V) | Resistance (kΩ) |
|------------------------------------|--------------|-----------------|
| -10 (14) | 4.4 | 7.0 - 11.4 |
| 20 (68) | 3.5 | 2.1 - 2.9 |
| 50 (122) | 2.2 | 0.68 - 1.00 |
| 90 (194) | 0.9 | 0.236 - 0.260 |

EC

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ECM terminal 32 (ECM ground).

FE

CL

MT

On Board Diagnosis Logic

NGEC0591

Malfunction is detected when an excessively high or low voltage from the sensor is sent to ECM.

AT

POSSIBLE CAUSE

NGEC0591S01

- Harness or connectors (The sensor circuit is open or shorted.)
- Engine coolant temperature sensor

TF

PD

FAIL-SAFE MODE

NGEC0591S02

When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

AX

| Detected items | Engine operating condition in fail-safe mode | |
|---|---|---|
| Engine coolant temperature sensor circuit | Engine coolant temperature will be determined by ECM based on the time after turning ignition switch ON or START. CONSULT-II displays the engine coolant temperature decided by ECM. | |
| | Condition | Engine coolant temperature decided (CONSULT-II display) |
| | Just as ignition switch is turned ON or Start | 40°C (104°F) |
| | More than approx. 4 minutes after ignition ON or Start | 80°C (176°F) |
| | Except as shown above | 40 - 80°C (104 - 176°F) (Depends on the time) |

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

VG33E

DTC Confirmation Procedure

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF360V

DTC Confirmation Procedure

=NGEC0592

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

④ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-742.

④ With GST

Follow the procedure "With CONSULT-II".

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)


VG33E

Wiring Diagram


Wiring Diagram

NGEC0593

EC-ECTS-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST



RS
BT
HA
SC

AEC942A

EL
IDX



DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0594

| | | | | | | | | |
|----------|--|--|---|----------|----|---|--|--|
| 1 | CHECK ECTS POWER SUPPLY CIRCUIT | <p>1. Turn ignition switch OFF. 2. Disconnect engine coolant temperature sensor harness connector.</p> <div style="text-align: center;">  <p>Engine coolant temperature sensor harness connector Distributor</p> </div> <p style="text-align: right;">AEC643A</p> <p>3. Turn ignition switch ON. 4. Check voltage between ECTS terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: center; color: blue;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 2.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table> | OK | ▶ | GO TO 2. | NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |
| OK | ▶ | GO TO 2. | | | | | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | |

| | | | | | | | | |
|----------|--|--|---|----------|----|---|----------|--|
| 2 | CHECK ECTS GROUND CIRCUIT FOR OPEN AND CIRCUIT | <p>1. Turn ignition switch OFF. 2. Check harness continuity between ECTS terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 3.</td> </tr> </table> | OK | ▶ | GO TO 4. | NG | ▶ | GO TO 3. | |
| OK | ▶ | GO TO 4. | | | | | | |
| NG | ▶ | GO TO 3. | | | | | | |

| | | | | | |
|----------|--|--|---|--|--|
| 3 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F28, M58 ● Joint connector-4 ● Harness for open or short between ECM and engine coolant temperature sensor ● Harness for open or short between TCM (Transmission Control Module) and engine coolant temperature sensor | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;"></td> <td style="width: 5%; text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table> | | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | |

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)


VG33E

Diagnostic Procedure (Cont'd)

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

4 CHECK ENGINE COOLANT TEMPERATURE SENSOR


Check resistance as shown in the figure.



<Reference data>

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.1 - 2.9 |
| 50 (122) | 0.68 - 1.00 |
| 90 (194) | 0.236 - 0.260 |

SEF152P



MTBL0229

SEF012P

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace engine coolant temperature sensor. |

5 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

▶ **INSPECTION END**

Description

NGEC0595
NOTE:


If DTC P0120 (0403) is displayed with DTC P0510 (0203), first perform the trouble diagnosis for DTC P0510. Refer to EC-998.

COMPONENT DESCRIPTION

NGEC0595S01

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.


SEF349X

CONSULT-II Reference Value in Data Monitor Mode

NGEC0596

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|--|---|
| THRTL POS SEN | <ul style="list-style-type: none"> Engine: After warming up, idle the engine | Throttle valve: fully closed (a) 0.15 - 0.85V |
| | <ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) | Throttle valve: Partially open Between (a) and (b) |
| | | Throttle valve: fully opened (b) 3.5 - 4.7V |
| ABSOL TH-P/S | <ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. | Throttle valve: fully closed 0.0% |
| | <ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) | Throttle valve: fully opened Approx. 80% |

DTC P0120 THROTTLE POSITION SENSOR

VG33E

ECM Terminals and Reference Value

ECM Terminals and Reference Value

=NGEC0597

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|--------------------------|--|-------------------|
| 23 | L | Throttle position sensor | [Engine is running] ● Warm-up condition ● Accelerator pedal fully released | 0.15 - 0.85V |
| | | | [Ignition switch ON] ● Accelerator pedal fully depressed | 3.5 - 4.7V |
| 42 | B/W | Sensors' power supply | [Ignition switch ON] | Approximately 5V |
| 43 | BR | Sensors' ground | [Engine is running] ● Warm-up condition ● Idle speed | Approximately 0V |

GI

MA

EM

LC

EC

FE

CL

MT

On Board Diagnosis Logic

NGEC0598

Malfunction is detected when
(Malfunction A) an excessively low or high voltage from the sensor is sent to ECM,
(Malfunction B) a high voltage from the sensor is sent to ECM under light load driving conditions,
(Malfunction C) a low voltage from the sensor is sent to ECM under heavy load driving conditions.

AT

TF

PD

POSSIBLE CAUSE

Malfunction A

NGEC0598S01

NGEC0598S0101

- Harness or connectors
(The throttle position sensor circuit is open or shorted.)
- Throttle position sensor

AX

SU

Malfunction B

NGEC0598S0102

- Harness or connectors
(The throttle position sensor circuit is open or shorted.)
- Throttle position sensor
- Fuel injector
- Camshaft position sensor
- Mass air flow sensor

BR

ST

RS

Malfunction C

NGEC0598S0103

- Harness or connectors
(The throttle position sensor circuit is open or shorted.)
- Intake air leaks
- Throttle position sensor

BT

HA

FAIL-SAFE MODE

NGEC0598S02

When the malfunction A is detected, the ECM enters fail-safe mode and the MIL lights up.

SC

EL

IDX

| | | |
|----------------------------------|--|-------------------|
| Detected items | Engine operating condition in fail-safe mode | |
| Throttle position sensor circuit | Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor. | |
| | Condition | Driving condition |
| | When engine is idling | Normal |
| | When accelerating | Poor acceleration |

DTC Confirmation Procedure

NGEC0599

NOTE:

- Perform “PROCEDURE FOR MALFUNCTION A” first. If the 1st trip DTC cannot be confirmed, perform “PROCEDURE FOR MALFUNCTION B”.
- If there is no problem on “PROCEDURE FOR MALFUNCTION B”, perform “PROCEDURE FOR MALFUNCTION C”.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NGEC0599S01

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 10V at idle.
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

2

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| VHCL SPEED SE | XXX km/h |
| P/N POSI SW | OFF |

PEF775U

With CONSULT-II

- 1) Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 5 consecutive seconds.

| | |
|----------------|--|
| Vehicle speed | More than 5 km/h (3 MPH) |
| Selector lever | Suitable position except “P” or “N” position |

- 3) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-750.

With GST

Follow the procedure “With CONSULT-II”.

| | | |
|----------|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

PROCEDURE FOR MALFUNCTION B

NGEC0599S02

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and let it idle for at least 10 seconds.
If idle speed is over 1,000 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,000 rpm.

| | |
|----------------|-------------------------------------|
| Selector lever | Suitable position except "P" or "N" |
| Brake pedal | Depressed |
| Vehicle speed | 0 km/h (0 MPH) |

- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-750.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

| | | |
|----------|---------------------|---------|
| 6 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | THRTL POS SEN | XXX V |
| | ABSOL TH~P/S | XXX % |

PEF024P



| | | |
|----------|---------------------|---------|
| 9 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | MAS AIR/FL SE | XXX V |
| | COOLAN TEMP/S | XXX °C |
| | IACV-AAC/V | XXX % |

PEF776U

PROCEDURE FOR MALFUNCTION C

NGEC0599S03

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II.
- 5) Select "THRTL POS SEN" and "ABSOL TH~P/S" in "DATA MONITOR" mode with CONSULT-II.
- 6) Press RECORD on CONSULT-II SCREEN at the same time accelerator pedal is depressed.
- 7) Print out the recorded graph and check the following:
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal is fully depressed is approximately 4V.
 If NG, go to "Diagnostic Procedure", EC-750.
 If OK, go to following step.
- 8) Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT-II.
- 9) Maintain the following conditions for at least 10 consecutive seconds.

| | |
|------------------|--|
| CMPS-RPM (REF) | More than 2,000 rpm |
| MAS AIR/FL SE | More than 3V |
| COOLAN TEMP/S | More than 70°C (158°F) |
| IACV-AAC/V | Less than 80% |
| Selector lever | Suitable position |
| Driving location | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 10) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-750.

With GST

Follow the procedure "With CONSULT-II".

DTC P0120 THROTTLE POSITION SENSOR



VG33E

Wiring Diagram

Wiring Diagram

NGEC0600

EC-TPS-01



AEC943A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


Diagnostic Procedure



NGEC0601

| 1 | INSPECTION START | | | | | | | | | |
|---|-------------------------|----------|-------------|------|---|---|---|---|---|---|
| Which malfunction A, B or C is duplicated? | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">MALFUNCTION</th> <th style="width: 50%;">Type</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">A</td> <td style="text-align: center;">A</td> </tr> <tr> <td style="text-align: center;">B</td> <td style="text-align: center;">B</td> </tr> <tr> <td style="text-align: center;">C</td> <td style="text-align: center;">C</td> </tr> </tbody> </table> | | | MALFUNCTION | Type | A | A | B | B | C | C |
| MALFUNCTION | Type | | | | | | | | | |
| A | A | | | | | | | | | |
| B | B | | | | | | | | | |
| C | C | | | | | | | | | |
| <small>MTBL0066</small> | | | | | | | | | | |
| Type A, B or C | | | | | | | | | | |
| Type A or B | ▶ | GO TO 4. | | | | | | | | |
| Type C | ▶ | GO TO 2. | | | | | | | | |

| 2 | ADJUST THROTTLE POSITION SENSOR | | | | | | | | | | | |
|--|--|----------|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|
| Check the following items. Refer to "Basic Inspection", EC-669. | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Items</th> <th style="width: 50%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>15° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>700 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> | | | Items | Specifications | Ignition timing | 15° ± 2° BTDC | Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | Target idle speed | 750 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | | |
| Ignition timing | 15° ± 2° BTDC | | | | | | | | | | | |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | | | | | | | | | | | |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| <small>MTBL0226</small> | | | | | | | | | | | | |
| ▶ | | GO TO 3. | | | | | | | | | | |

| | | |
|---|-----------------------------|----------------------|
| 3 | CHECK INTAKE SYSTEM. | |
| 1. Turn ignition switch OFF. 2. Check the following for connection. <ul style="list-style-type: none"> ● Air duct ● Vacuum hoses ● Intake air passage between air duct to intake manifold collector | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Reconnect the parts. |

| | | |
|---|--------------------------------|----------|
| 4 | RETIGHTEN GROUND SCREWS | |
| 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws. | | |
|  <p style="text-align: center;">Engine ground</p> <p>The diagram shows a close-up of the engine's electrical system. Two ground screws are labeled F11 and F12. They are connected to various wires and components. The screws are shown being tightened onto a metal surface.</p> | | |
| <small>AEC640A</small> | | |
| ▶ | | GO TO 5. |

| | | | | | | | | | |
|----------|--|---|----|---|----------|----|---|--|--|
| 5 | CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT | <p>1. Disconnect throttle position sensor harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 150px;">Throttle position sensor harness connector</p> <p style="margin-left: 100px;">Distributor</p> </div> <p style="text-align: right;">AEC638A</p> <p>2. Turn ignition switch ON.</p> <p>3. Check voltage between sensor terminal 3 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: center; color: blue;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 6.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table> | OK | ▶ | GO TO 6. | NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> |
| OK | ▶ | GO TO 6. | | | | | | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | |

| | | | | | | | | | |
|----------|---|---|----|---|----------|----|---|----------|---|
| 6 | CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT | <p>1. Turn ignition switch OFF.</p> <p>2. Check harness continuity between sensor terminal 1 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 7.</td> </tr> </table> | OK | ▶ | GO TO 8. | NG | ▶ | GO TO 7. | <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> |
| OK | ▶ | GO TO 8. | | | | | | | |
| NG | ▶ | GO TO 7. | | | | | | | |

| | | | | | | |
|----------|-----------------------------------|---|--|---|--|--|
| 7 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F28, M58 ● Joint connector-4 ● Harness for open or short between ECM and throttle position sensor ● Harness for open or short between TCM (Transmission Control Module) and throttle position sensor <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;"></td> <td style="width: 5%; text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table> | | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | |

DTC P0120 THROTTLE POSITION SENSOR

VG33E


Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 8 | CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 23 and sensor terminal 2. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> | |
| OK (With CONSULT-II) ▶ | GO TO 9. |
| OK (Without CONSULT-II) ▶ | GO TO 10. |
| NG ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

9 CHECK THROTTLE POSITION SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Remove the vacuum hose connected to the throttle opener (If so equipped).
4. Connect suitable vacuum hose to the vacuum pump and the opener.
5. Apply vacuum [more than -40.0kPa (-300mmHg, 11.81inHG)] until the throttle drum becomes free from the rod of the throttle opener.



6. Turn ignition switch ON.
7. Select "DATA MONITOR" mode with CONSULT-II.
8. Check voltage of "THRTL POS SEN".

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| THRTL POS SEN | XXX V |

Voltage measurement must be made with throttle position sensor installed in vehicle.

| Throttle valve conditions | THRTL POS SEN |
|---------------------------|---------------------|
| Completely closed (a) | 0.15 - 0.85V |
| Partially open | Between (a) and (b) |
| Completely open (b) | 3.5 - 4.7V |

OK or NG

- | | | |
|----|---|-----------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | GO TO 11. |

GI

MA

EM

LC

EC

FE

SEF793W

CL

MT

AT

TF

PD

PEF765W

AX

SU

BR

MTBL0230

ST

RS

BT

HA

SC

EL

IDX

DTC P0120 THROTTLE POSITION SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| 10 | CHECK THROTTLE POSITION SENSOR | | | | | | | | |
|---|---------------------------------------|---------------------------|---------|-----------------------|--------------|----------------|---------------------|---------------------|------------|
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine (ignition switch OFF). 3. Remove the vacuum hose connected to the throttle opener (If so equipped). 4. Connect suitable vacuum hose to the vacuum pump and the opener. 5. Apply vacuum [more than -40.0kPa (-300mmHg, 11.81inHG)] until the throttle drum becomes free from the rod of the throttle opener. | | | | | | | | | |
| | | | | | | | | | |
| SEF793W | | | | | | | | | |
| <ol style="list-style-type: none"> 6. Turn ignition switch ON. 7. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground. <p>Voltage measurement must be made with throttle position sensor installed in vehicle.</p> | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Throttle valve conditions</th> <th style="padding: 5px;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">Completely closed (a)</td> <td style="padding: 5px;">0.15 - 0.85V</td> </tr> <tr> <td style="padding: 5px;">Partially open</td> <td style="padding: 5px;">Between (a) and (b)</td> </tr> <tr> <td style="padding: 5px;">Completely open (b)</td> <td style="padding: 5px;">3.5 - 4.7V</td> </tr> </tbody> </table> | | Throttle valve conditions | Voltage | Completely closed (a) | 0.15 - 0.85V | Partially open | Between (a) and (b) | Completely open (b) | 3.5 - 4.7V |
| Throttle valve conditions | Voltage | | | | | | | | |
| Completely closed (a) | 0.15 - 0.85V | | | | | | | | |
| Partially open | Between (a) and (b) | | | | | | | | |
| Completely open (b) | 3.5 - 4.7V | | | | | | | | |
| MTBL0231 | | | | | | | | | |
| OK or NG | | | | | | | | | |
| OK | ▶ | GO TO 12. | | | | | | | |
| NG | ▶ | GO TO 11. | | | | | | | |

| 11 | ADJUST CLOSED THROTTLE POSITION SWITCH | | | | | | | | | | |
|--|--|---|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|
| <p>Adjust closed throttle position switch. Refer to "Basic Inspection", EC-669.</p> | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Items</th> <th style="padding: 5px;">Specifications</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">Ignition timing</td> <td style="padding: 5px;">15° ± 2° BTDC</td> </tr> <tr> <td style="padding: 5px;">Base idle speed</td> <td style="padding: 5px;">700 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td style="padding: 5px;">Closed throttle position switch idle position adjustment</td> <td style="padding: 5px;">Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF</td> </tr> <tr> <td style="padding: 5px;">Target idle speed</td> <td style="padding: 5px;">750 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> | | Items | Specifications | Ignition timing | 15° ± 2° BTDC | Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | Target idle speed | 750 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | |
| Ignition timing | 15° ± 2° BTDC | | | | | | | | | | |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | | | | | | | | | | |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| MTBL0226 | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | |
| OK | ▶ | GO TO 12. | | | | | | | | | |
| NG | ▶ | Replace throttle position sensor. To adjust it, perform "Basic Inspection", EC-669. | | | | | | | | | |


DTC P0120 THROTTLE POSITION SENSOR

VG33E

Diagnostic Procedure (Cont'd)

12 CHECK MASS AIR FLOW SENSOR

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.




SEF747U

| Condition | Voltage V |
|--|--------------------------|
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 |
| Idle (Engine is warmed-up to normal operating temperature.) | 1.0 - 1.7 |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.7 - 2.3 |
| Idle to about 4,000 rpm* | 1.0 - 1.7 to Approx. 4.0 |

MTBL0227

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Then repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



SEF030T

OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 13. |
| NG | ▶ | Replace mass air flow sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

13 CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.



Terminal 44 or 48 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|------------|------------|
| Voltage | 0.3 - 0.5V | 0.3 - 0.5V |
| Pulse signal | | |

Terminal 49 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|--------------------|--------------------|
| Voltage | Approximately 2.5V | Approximately 2.5V |
| Pulse signal | | |


AEC072B

OK or NG

- | | | |
|----|---|---|
| OK | ▶ | GO TO 14. |
| NG | ▶ | Replace distributor assembly with camshaft position sensor. |

14 CHECK FUEL INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.



Resistance: 10 - 14Ω [at 25°C (77°F)]

SEF625V

OK or NG

- | | | |
|----|---|------------------------|
| OK | ▶ | GO TO 15. |
| NG | ▶ | Replace fuel injector. |

DTC P0120 THROTTLE POSITION SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|-----------|--|--|
| 15 | CHECK THROTTLE POSITION SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT | |
| | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect joint connector-2.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between joint connector terminal 1 and ground ● Joint connector (Refer to "HARNES LAYOUT", <i>EL-292</i>) <p style="margin-left: 20px;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect joint connector-2.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 16. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|-----------|---|-----------------------|
| 16 | CHECK INTERMITTENT INCIDENT | |
| | Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0125 ENGINE COOLANT TEMPERATURE SENSOR (ECTS)

VG33E



Description

Description

NGEC0602

NOTE:

If DTC P0125 (0908) is displayed with P0115 (0103), first perform the trouble diagnosis for DTC P0115. Refer to EC-739.



COMPONENT DESCRIPTION

NGEC0602S01

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

| Engine coolant temperature °C (°F) | Voltage* (V) | Resistance (kΩ) |
|------------------------------------|--------------|-----------------|
| -10 (14) | 4.4 | 9.2 |
| 20 (68) | 3.5 | 2.1 - 2.9 |
| 50 (122) | 2.2 | 0.68 - 1.00 |
| 90 (194) | 0.9 | 0.236 - 0.260 |

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ECM terminal 32 (ECM ground).

On Board Diagnosis Logic

NGEC0603

Malfunction is detected when voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine, or engine coolant temperature is insufficient for closed loop fuel control.

POSSIBLE CAUSE

NGEC0603S01

- Harness or connectors (High resistance in the circuit)
- Engine coolant temperature sensor
- Thermostat

DTC P0125 ENGINE COOLANT TEMPERATURE SENSOR (ECTS)

VG33E

DTC Confirmation Procedure

4

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |

PEF779U

DTC Confirmation Procedure

=NGEC0604

CAUTION:

Be careful not to overheat engine.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Check that "COOLAN TEMP/S" is above 10°C (50°F).
If it is above 10°C (50°F), the test result will be OK.
If it is below 10°C (50°F), go to following step.
- 4) Start engine and run it for 65 minutes at idle speed.
If "COOLAN TEMP/S" increases to more than 10°C (50°F) within 65 minutes, stop engine because the test result will be OK.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-761.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0125 ENGINE COOLANT TEMPERATURE SENSOR (ECTS)



VG33E

Wiring Diagram

Wiring Diagram

NGEC0605

EC-ECTS-01



AEC942A



DTC P0125 ENGINE COOLANT TEMPERATURE SENSOR (ECTS)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0606

| | | | |
|----------|--|--|-------------------------------|
| 1 | CHECK ECTS POWER SUPPLY CIRCUIT | <p>1. Turn ignition switch OFF. 2. Disconnect engine coolant temperature sensor harness connector.</p> <div style="text-align: center;">  <p>Engine coolant temperature sensor harness connector Distributor</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between ECTS terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> | <p>AEC643A</p> <p>SEF206W</p> |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

| | | | |
|----------|---|---|--|
| 2 | CHECK ECTS GROUND CIRCUIT FOR OPEN AND SHORT | <p>1. Turn ignition switch OFF. 2. Check harness continuity between ECTS terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 4. | |
| NG | ▶ | GO TO 3. | |



| | | | |
|----------|-----------------------------------|--|--|
| 3 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F28, M58 ● Joint connector-4 ● Harness for open or short between ECM and engine coolant temperature sensor ● Harness for open or short between TCM (Transmission Control Module) and engine coolant temperature sensor | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0125 ENGINE COOLANT TEMPERATURE SENSOR (ECTS)

VG33E

Diagnostic Procedure (Cont'd)

| 4 | CHECK ENGINE COOLANT TEMPERATURE SENSOR | | | | | | | | |
|--|--|--|---------------|---------|-----------|----------|-------------|----------|---------------|
| <p>Check resistance as shown in the figure.</p> <div style="text-align: center;">  </div> | | | | | | | | | |
| <p><Reference data></p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">50 (122)</td> <td style="text-align: center;">0.68 - 1.00</td> </tr> <tr> <td style="text-align: center;">90 (194)</td> <td style="text-align: center;">0.236 - 0.260</td> </tr> </tbody> </table> | | Temperature °C (°F) | Resistance kΩ | 20 (68) | 2.1 - 2.9 | 50 (122) | 0.68 - 1.00 | 90 (194) | 0.236 - 0.260 |
| Temperature °C (°F) | Resistance kΩ | | | | | | | | |
| 20 (68) | 2.1 - 2.9 | | | | | | | | |
| 50 (122) | 0.68 - 1.00 | | | | | | | | |
| 90 (194) | 0.236 - 0.260 | | | | | | | | |
| SEF152P | | | | | | | | | |
| MTBL0229 | | | | | | | | | |
| <div style="display: flex; justify-content: center; align-items: center;">  </div> | | | | | | | | | |
| SEF012P | | | | | | | | | |
| OK or NG | | | | | | | | | |
| OK | ▶ | GO TO 5. | | | | | | | |
| NG | ▶ | Replace engine coolant temperature sensor. | | | | | | | |


| | | |
|---|-----------------------------------|--|
| 5 | CHECK THERMOSTAT OPERATION | |
| <p>When the engine is cold [lower than 70°C (158°F)] condition, grasp lower radiator hose and confirm the engine coolant does not flow.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Repair or replace thermostat. Refer to "Thermostat", "ENGINE COOLING SYSTEM", LC-13 . |

| | | |
|--|------------------------------------|-----------------------|
| 6 | CHECK INTERMITTENT INCIDENT | |
| <p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.</p> | | |
| | ▶ | INSPECTION END |

DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E

Component Description




SEF463R

Component Description

The front heated oxygen sensor is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0607



SEF288D

CONSULT-II Reference Value in Data Monitor Mode

NGEC0608

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|---|
| FR O2 SEN-B1 FR O2 SEN-B2 | <ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR-B1 FR O2 MNTR-B2 | | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0609

Specification data are reference values and are measured between each terminal and 32 (ECM ground).


| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-------------------------------|--|------------------------|
| 50 | B | Front heated oxygen sensor RH | [Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | 0 - Approximately 1.0V |
| 51 | G | Front heated oxygen sensor LH | | |

SEF002V

DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0610
Under the condition in which the front heated oxygen sensor signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.

Malfunction is detected when the voltage from the sensor is constantly approx. 0.3V.

POSSIBLE CAUSE

- Harness or connectors
(The sensor circuit is open or shorted.)
- Front heated oxygen sensor

NGEC0610S01

DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E

On Board Diagnosis Logic (Cont'd)

=NGEC0611

| | | |
|---|--------------------|----------|
| 5 | FR O2 SENSOR P0130 | |
| | OUT OF CONDITION | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF138V

| | | |
|---|--------------------|----------|
| 5 | FR O2 SENSOR P0130 | |
| | TESTING | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF139V

| | | |
|---|--------------------|--|
| 5 | FR O2 SENSOR P0130 | |
| | COMPLETED | |

PEF210V

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓟ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "FR O2 SEN-B1 (-B2) P0130 (P0150)" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 3) Touch "START".
- 4) Let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 4.

- 5) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

| | |
|----------------|--|
| CMPS-RPM (POS) | 1,800 - 2,600 rpm (A/T models) 1,900 - 2,700 rpm (M/T models) |
| Vehicle speed | 70 - 100 km/h (43 - 62 MPH) |
| B/FUEL SCHDL | 1.6 - 6.5 msec (A/T models) 1.4 - 5.5 msec (M/T models) |
| Selector lever | Suitable position |

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 6) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-769.

During this test, P1148 and P1168 may be stored in ECM.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E

Overall Function Check



Overall Function Check

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed. =NGEC0612

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
- 4) If NG, go to "Diagnostic Procedure", EC-769.

DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E
Wiring Diagram


Wiring Diagram

RIGHT BANK






NGEC0613

NGEC0613S01

EC-FRO2RH-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



AEC944A



DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0614

| | |
|---|-------------------------|
| 1 | INSPECTION START |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Engine ground</p> </div> <p>3. Make sure front HO2S harness protector color, and disconnect corresponding front heated oxygen sensor harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">AEC640A</p> | |
| AEC644A | |
| ▶ GO TO 2. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| 2 | CHECK FRONT HO2S INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|--------|-----------|--|------|-----|--------|-------|----|---|-------|-------|----|---|------|-----|-----------|--|------|---------------|--------|-------|---------|--------|-------|-------|---------|--------|------|
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal and FRONT HO2S terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0130</td> <td style="text-align: center;">50</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0150</td> <td style="text-align: center;">51</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> <p style="text-align: right;">AEC888A</p> <p style="color: blue;">Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal or FRONT HO2S terminal and ground as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0130</td> <td style="text-align: center;">50 or 2</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0150</td> <td style="text-align: center;">51 or 2</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> <p style="text-align: right;">AEC889A</p> <p style="color: blue;">Continuity should not exist.</p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p> | | DTC | Terminals | | Bank | ECM | Sensor | P0130 | 50 | 2 | Right | P0150 | 51 | 2 | Left | DTC | Terminals | | Bank | ECM or sensor | Ground | P0130 | 50 or 2 | Ground | Right | P0150 | 51 or 2 | Ground | Left |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0130 | 50 | 2 | Right | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0150 | 51 | 2 | Left | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ECM or sensor | Ground | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0130 | 50 or 2 | Ground | Right | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0150 | 51 or 2 | Ground | Left | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK (With CONSULT-II) | ▶ GO TO 3. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK (Without CONSULT-II) | ▶ GO TO 4. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E

Diagnostic Procedure (Cont'd)

3 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II, and select "FR O2 SEN-B1 (-B2)" and "FR O2 MNTR-B1 (-B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 MNTR-B1 | LEAN |
| INJ PULSE-B1 | XXX msec |
| A/F ALPHA-B1 | XXX % |
| FR O2 HTR-B1 | ON |

PEF365V

5. Check the following.

- "FR O2 MNTR-B1 (-B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Right bank

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B1 R-L-R-L-R-L-R-L-R-L-R

Left bank


cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B2 R-L-R-L-R-L-R-L-R-L-R

R means FR O2 MNTR-B1(-B2) indicates RICH

L means FR O2 MNTR-B1(-B2) indicates LEAN

SEF702W

- "FR O2 SEN-B1 (-B2)" voltage goes above 0.6V at least once.
- "FR O2 SEN-B1 (-B2)" voltage goes below 0.3V at least once.
- "FR O2 SEN-B1 (-B2)" voltage never exceeds 1.0V.



- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.3V at least one time.

SEF154X

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

DTC P0130 (RIGHT, -B1), P0150 (LEFT, -B2) FRONT HO2S (CIRCUIT)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 4 | CHECK FRONT HEATED OXYGEN SENSOR |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground. Check the following with engine speed held at 2,000 rpm constant under no load. | |
| | |
| <ul style="list-style-type: none"> MIL goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). The maximum voltage is over 0.6V at least one time. The minimum voltage is below 0.3V at least one time. The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: right;">SEF919U</p> | |
| OK or NG | |
| OK | ▶ GO TO 5. |
| NG | ▶ Replace malfunctioning front heated oxygen sensor. |

| | |
|--|--|
| 5 | CHECK FRONT HO2S SHIELD CIRCUIT FOR OPEN AND SHORT |
| <ol style="list-style-type: none"> Turn ignition switch OFF. Disconnect joint connector-2. Check the following. <ul style="list-style-type: none"> Continuity between joint connector terminal 1 and ground Joint connector (Refer to "HARNES LAYOUT", EL-9.) Continuity should exist. Also check harness for short to ground and short to power. Then reconnect joint connector-2. | |
| OK or NG | |
| OK | ▶ GO TO 6. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |


| | |
|---|------------------------------------|
| 6 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E


Component Description



Component Description

The front heated oxygen sensor is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0615



CONSULT-II Reference Value in Data Monitor Mode

NGEC0616

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------------------------|--|---------------------------------------|---|
| FR O2 SEN-B1 FR O2 SEN-B2 | <ul style="list-style-type: none"> Engine: After warming up | Maintaining engine speed at 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR-B1 FR O2 MNTR-B2 | | | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0617

Specification data are reference values and are measured between each terminal and 32 (ECM ground).


| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-------------------------------|---|------------------------|
| 50 | B | Front heated oxygen sensor RH | [Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | 0 - Approximately 1.0V |
| 51 | G | Front heated oxygen sensor LH | | |

SEF002V

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0618

To judge the malfunction, the output from the front heated oxygen sensor is monitored to determine whether the “rich” output is sufficiently high and whether the “lean” output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.

Malfunction is detected when the maximum and minimum voltage from the sensor are not reached to the specified voltages.

POSSIBLE CAUSE

NGEC0618S01

- Front heated oxygen sensor
- Front heated oxygen sensor heater
- Fuel pressure
- Injectors
- Intake air leaks

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E

DTC Confirmation Procedure

DTC Confirmation Procedure

=NGEC0619

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing following procedure, confirm that battery voltage is more than 11V at idle.

| | | |
|---|--------------------|----------|
| 6 | FR O2 SENSOR P0131 | |
| | OUT OF CONDITION | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF143V

| | | |
|---|--------------------|----------|
| 6 | FR O2 SENSOR P0131 | |
| | TESTING | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF144V

| | | |
|---|--------------------|--|
| 6 | FR O2 SENSOR P0131 | |
| | COMPLETED | |

PEF211V

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "FR O2 SEN-B1 (-B2) P0131 (P0151)" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

| | |
|----------------|--|
| CMPS-RPM (POS) | 1,800 - 2,800 rpm (A/T models) 1,900 - 3,100 rpm (M/T models) |
| Vehicle speed | 80 - 100 km/h (50 - 62 MPH) |
| B/FUEL SCHDL | 1.6 - 6.5 msec (A/T models) 1.4 - 5.5 msec (M/T models) |
| Selector lever | Suitable position |


If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-775.

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E

Overall Function Check



Overall Function Check

NGEC0620

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground.
- 3) Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
- 4) If NG, go to “Diagnostic Procedure”, EC-775.

Diagnostic Procedure

NGEC0621

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> | |
| | |
| AEC640A | |
| ▶ GO TO 2. | |

| | |
|--|---|
| 2 | RETIGHTEN FRONT HEATED OXYGEN SENSOR |
| <p>Loosen and retighten corresponding front heated oxygen sensor.</p> <p>Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)</p> | |
| ▶ GO TO 3. | |

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E


Diagnostic Procedure (Cont'd)

| | | | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------------|--|-------------|--|------------|-----------|---------|-----------|---------|--|---------------|---------|---------------|--------|--------------|-------|--------------|-------|--------------|-------|--------------|-------|
| 3 | CLEAR THE SELF-LEARNING DATA | | | | | | | | | | | | | | | | | | | | | |
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR". | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;">SELF-LEARN</td><td style="text-align: center;">B1: XXX %</td></tr> <tr><td style="text-align: center;">CONTROL</td><td style="text-align: center;">B2: XXX %</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">CMPS-RPM(REF)</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">COOLAN TEMP/S</td><td style="text-align: center;">XXX °C</td></tr> <tr><td style="text-align: center;">FR O2 SEN-B1</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">FR O2 SEN-B2</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">A/F ALPHA-B1</td><td style="text-align: center;">XXX %</td></tr> <tr><td style="text-align: center;">A/F ALPHA-B2</td><td style="text-align: center;">XXX %</td></tr> </table> | | | ACTIVE TEST | | SELF-LEARN | B1: XXX % | CONTROL | B2: XXX % | MONITOR | | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SEN-B1 | XXX V | FR O2 SEN-B2 | XXX V | A/F ALPHA-B1 | XXX % | A/F ALPHA-B2 | XXX % |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN | B1: XXX % | | | | | | | | | | | | | | | | | | | | | |
| CONTROL | B2: XXX % | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B1 | XXX V | | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B2 | XXX V | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| PEF921U | | | | | | | | | | | | | | | | | | | | | | |
| <ol style="list-style-type: none"> 4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171 or P0174 detected? Is it difficult to start engine? | | | | | | | | | | | | | | | | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640. 7. Make sure DTC No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0115 or 0210 detected? Is it difficult to start engine? <p style="text-align: center;">Yes or No</p> | | | | | | | | | | | | | | | | | | | | | | |
| Yes | ▶ | Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-860. | | | | | | | | | | | | | | | | | | | | |
| No | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | |

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|--|--|
| 4 | CHECK FRONT HEATED OXYGEN SENSOR HEATER | |
| <p>Check resistance between FRONT HO2S terminals 3 and 1.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">    </div> <div style="text-align: center;">  </div> </div> <p style="text-align: right;">AEC158A</p> <p>Resistance: 2.3 - 4.3Ω at 25°C (77°F)</p> <p>Check continuity between FRONT HO2S terminals 2 and 1, 3 and 2.</p> <p>Continuity should not exist.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 5. |
| OK (Without CONSULT-II) | ▶ | GO TO 6. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

5 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II, and select "FR O2 SEN-B1 (-B2)" and "FR O2 MNTR-B1 (-B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 MNTR-B1 | LEAN |
| INJ PULSE-B1 | XXX msec |
| A/F ALPHA-B1 | XXX % |
| FR O2 HTR-B1 | ON |

PEF365V

5. Check the following.

- "FR O2 MNTR-B1 (-B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Right bank

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B1 R-L-R-L-R-L-R-L-R-L-R

Left bank


cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B2 R-L-R-L-R-L-R-L-R-L-R

R means FR O2 MNTR-B1(-B2) indicates RICH

L means FR O2 MNTR-B1(-B2) indicates LEAN

SEF702W

- "FR O2 SEN-B1 (-B2)" voltage goes above 0.6V at least once.
- "FR O2 SEN-B1 (-B2)" voltage goes below 0.3V at least once.
- "FR O2 SEN-B1 (-B2)" voltage never exceeds 1.0V.



SEF154X

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

DTC P0131 (RIGHT, -B1), P0151 (LEFT, -B2) FRONT HO2S (LEAN SHIFT MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | | | |
|----------|---|--|---|
| 6 | CHECK FRONT HEATED OXYGEN SENSOR | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground. 3. Check the following with engine speed held at 2,000 rpm constant under no load. <div style="text-align: center; margin: 10px 0;"> </div> <ul style="list-style-type: none"> ● MIL goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: right; margin-right: 20px;">SEF919U</p> <p style="text-align: center;">OK or NG</p> | GI MA EM LC EC FE CL MT AT TF |
| OK | ▶ | GO TO 7. | |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. | |

| | | | |
|----------|---|---|----------------------------|
| 7 | CHECK FRONT HO2S SHIELD CIRCUIT FOR OPEN AND SHORT | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect joint connector. 3. For circuit, refer to "DTC P0130 (RIGHT BANK, -B1), P0150 (LEFT BANK, -B2) FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)", EC-763. 4. Check the following. <ul style="list-style-type: none"> ● Continuity between joint connector terminal 1 and ground ● Joint connector (Refer to "HARNES LAYOUT", <i>EL-292</i>.) <p style="margin-left: 20px; color: blue;">Continuity should exist.</p> 5. Also check harness for short to ground and short to power. 6. Then reconnect joint connector. <p style="text-align: center;">OK or NG</p> | AX SU BR ST RS |
| OK | ▶ | GO TO 8. | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |


| | | | |
|----------|------------------------------------|--|----------|
| 8 | CHECK INTERMITTENT INCIDENT | <p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.</p> <p>For circuit, refer to "DTC P0130 (RIGHT BANK, -B1), P0150 (LEFT BANK, -B2) FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)", EC-763.</p> | HA SC |
| ▶ | INSPECTION END | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E


Component Description



Component Description

The front heated oxygen sensor is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0622



CONSULT-II Reference Value in Data Monitor Mode

NGEC0623

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|---|
| FR O2 SEN-B1 FR O2 SEN-B2 | <ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR-B1 FR O2 MNTR-B2 | | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0624

Specification data are reference values and are measured between each terminal and 32 (ECM ground).


| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-------------------------------|---|------------------------|
| 50 | B | Front heated oxygen sensor RH | [Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | 0 - Approximately 1.0V |
| 51 | G | Front heated oxygen sensor LH | | |

SEF002V

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0625

To judge the malfunction, the output from the front heated oxygen sensor is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.

Malfunction is detected when the maximum and minimum voltages from the sensor are beyond the specified voltages.

POSSIBLE CAUSE

NGEC0625S01

- Front heated oxygen sensor
- Fuel pressure
- Injectors
- Front heated oxygen sensor heater

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E

DTC Confirmation Procedure

DTC Confirmation Procedure

=NGEC0626

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

| | | |
|---|--------------------|----------|
| 6 | FR O2 SENSOR P0132 | |
| | OUT OF CONDITION | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF146V

| | | |
|---|--------------------|----------|
| 6 | FR O2 SENSOR P0132 | |
| | TESTING | |
| | MONITOR | |
| | CMPS~RPM(REF) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF147V

| | | |
|---|--------------------|--|
| 6 | FR O2 SENSOR P0132 | |
| | COMPLETED | |

PEF212V

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and wait at least 5 seconds.
- 3) Turn ignition switch ON and select "FR O2 SEN-B1 (-B2) P0132 (P0152)" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

| | |
|----------------|--|
| CMPS-RPM (POS) | 1,800 - 2,800 rpm (A/T models) 1,900 - 3,100 rpm (M/T models) |
| Vehicle speed | 80 - 100 km/h (50 - 62 MPH) |
| B/FUEL SCHDL | 1.6 - 6.5 msec (A/T models) 1.4 - 5.5 msec (M/T models) |
| Selector lever | Suitable position |


If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-783.

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E

Overall Function Check



Overall Function Check

NGEC0627

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground.
- 3) Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.35V at least one time.
- 4) If NG, go to “Diagnostic Procedure”, EC-783.

Diagnostic Procedure

NGEC0628

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> | |
| | |
| AEC640A | |
| ▶ GO TO 2. | |

| | |
|--|---|
| 2 | RETIGHTEN FRONT HEATED OXYGEN SENSOR |
| <p>Loosen and retighten corresponding front heated oxygen sensor.</p> <p>Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)</p> | |
| ▶ GO TO 3. | |

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E

Diagnostic Procedure (Cont'd)


| | | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------------|--|--|------------|-----------|---------|-----------|---------|--|---------------|---------|---------------|--------|--------------|-------|--------------|-------|--------------|-------|--------------|-------|
| 3 | CLEAR THE SELF-LEARNING DATA | | | | | | | | | | | | | | | | | | | | |
| <p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR". | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;">SELF-LEARN</td><td style="text-align: center;">B1: XXX %</td></tr> <tr><td style="text-align: center;">CONTROL</td><td style="text-align: center;">B2: XXX %</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">CMPS-RPM(REF)</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">COOLAN TEMP/S</td><td style="text-align: center;">XXX °C</td></tr> <tr><td style="text-align: center;">FR O2 SEN-B1</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">FR O2 SEN-B2</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">A/F ALPHA-B1</td><td style="text-align: center;">XXX %</td></tr> <tr><td style="text-align: center;">A/F ALPHA-B2</td><td style="text-align: center;">XXX %</td></tr> </table> | | ACTIVE TEST | | SELF-LEARN | B1: XXX % | CONTROL | B2: XXX % | MONITOR | | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SEN-B1 | XXX V | FR O2 SEN-B2 | XXX V | A/F ALPHA-B1 | XXX % | A/F ALPHA-B2 | XXX % |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN | B1: XXX % | | | | | | | | | | | | | | | | | | | | |
| CONTROL | B2: XXX % | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B1 | XXX V | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B2 | XXX V | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | |
| PEF921U | | | | | | | | | | | | | | | | | | | | | |
| <ol style="list-style-type: none"> 4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0172 or P0175 detected? Is it difficult to start engine? | | | | | | | | | | | | | | | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640. 7. Make sure DTC No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114 or 0209 detected? Is it difficult to start engine? <p style="text-align: center;">Yes or No</p> | | | | | | | | | | | | | | | | | | | | | |
| Yes | ▶ | Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-868. | | | | | | | | | | | | | | | | | | | |
| No | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | |

| | | |
|--|---|--|
| 4 | CHECK FRONT HO2S CONNECTOR FOR WATER | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect front heated oxygen sensor harness connector. 3. Check connectors for water. Water should not exist. <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair or replace harness or connectors. |

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|--|--|
| 5 | CHECK FRONT HEATED OXYGEN SENSOR HEATER | |
| <p>Check resistance between FRONT HO2S terminals 3 and 1.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">    </div> <div style="text-align: center;">  </div> </div> <p style="text-align: right;">AEC158A</p> <p>Resistance: 2.3 - 4.3Ω at 25°C (77°F)</p> <p>Check continuity between FRONT HO2S terminals 2 and 1, 3 and 2.</p> <p>Continuity should not exist.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

6 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II, and select "FR O2 SEN-B1 (-B2)" and "FR O2 MNTR-B1 (-B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 MNTR-B1 | LEAN |
| INJ PULSE-B1 | XXX msec |
| A/F ALPHA-B1 | XXX % |
| FR O2 HTR-B1 | ON |

PEF365V

5. Check the following.

- "FR O2 MNTR-B1 (-B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Right bank

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B1 R-L-R-L-R-L-R-L-R-L-R

Left bank


cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B2 R-L-R-L-R-L-R-L-R-L-R

R means FR O2 MNTR-B1(-B2) indicates RICH

L means FR O2 MNTR-B1(-B2) indicates LEAN

SEF702W

- "FR O2 SEN-B1 (-B2)" voltage goes above 0.6V at least once.
- "FR O2 SEN-B1 (-B2)" voltage goes below 0.3V at least once.
- "FR O2 SEN-B1 (-B2)" voltage never exceeds 1.0V.



SEF154X

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

DTC P0132 (RIGHT, -B1), P0152 (LEFT, -B2) FRONT HO2S (RICH SHIFT MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 7 | CHECK FRONT HEATED OXYGEN SENSOR |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground. 3. Check the following with engine speed held at 2,000 rpm constant under no load. <div style="text-align: center; margin: 10px 0;"> </div> <ul style="list-style-type: none"> ● MIL goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: right; margin-right: 20px;">SEF919U</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ Replace malfunctioning front heated oxygen sensor. |

| | |
|--|--|
| 8 | CHECK FRONT HO2S SHIELD CIRCUIT FOR OPEN AND SHORT |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect joint connector. For circuit, refer to "DTC P0130 (RIGHT BANK, -B1), P0150 (LEFT BANK, -B2) FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)", EC-763. 3. Check the following. <ul style="list-style-type: none"> ● Continuity between joint connector terminal 1 and ground ● Joint connector (Refer to "HARNES LAYOUT", EL-292.) <p style="margin-left: 20px; color: blue;">Continuity should exist.</p> 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. <p style="text-align: center; margin-top: 10px;">OK or NG</p> | |
| OK | ▶ GO TO 9. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |


| | |
|---|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| <p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. For circuit, refer to "DTC P0130 (RIGHT BANK, -B1), P0150 (LEFT BANK, -B2) FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)", EC-763.</p> | |
| ▶ | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
HA
SC
EL
IDX

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E


Component Description



Component Description

The front heated oxygen sensor is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0629



CONSULT-II Reference Value in Data Monitor Mode

NGEC0630

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|---|
| FR O2 SEN-B1 FR O2 SEN-B2 | <ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR-B1 FR O2 MNTR-B2 | | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0631


Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-------------------------------|---|------------------------|
| 50 | B | Front heated oxygen sensor RH | [Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | 0 - Approximately 1.0V |
| 51 | G | Front heated oxygen sensor LH | | <p>SEF002V</p> |

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0632

To judge the malfunction of front heated oxygen sensor, this diagnosis measures response time of front heated oxygen sensor signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and front heated oxygen sensor temperature index. Judgment is based on whether the compensated time (front heated oxygen sensor cycling time index) is inordinately long or not.

Malfunction is detected when the response of the voltage signal from the sensor takes more than the specified time.

POSSIBLE CAUSE

NGEC0632S01

- Harness or connectors (The sensor circuit is open or shorted.)
- Front heated oxygen sensor
- Front heated oxygen sensor heater
- Fuel pressure
- Injectors
- Intake air leaks
- Exhaust gas leaks
- PCV valve
- Mass air flow sensor

DTC Confirmation Procedure

NGEC0633

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

DTC Confirmation Procedure (Cont'd)

6

| | |
|--------------------|----------|
| FR O2 SENSOR P0133 | |
| OUT OF CONDITION | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF148V

6


| | |
|--------------------|----------|
| FR O2 SENSOR P0133 | |
| TESTING | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF149V

6

| | |
|--------------------|--|
| FR O2 SENSOR P0133 | |
| COMPLETED | |

PEF213V



With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and wait at least 5 seconds.
- 3) Turn ignition switch ON and select "FR O2 SEN-B1 (-B2) P0133 (P0153)" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 40 to 50 seconds.)

| | |
|----------------|--|
| CMPS-RPM (POS) | 1,800 - 2,800 rpm (A/T models) 1,900 - 3,300 rpm (M/T models) |
| Vehicle speed | 80 - 120 km/h (50 - 75 MPH) |
| B/FUEL SCHDL | 1.6 - 6.5 msec (A/T models) 1.4 - 5.5 msec (M/T models) |
| Selector lever | Suitable position |

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-793.

Overall Function Check

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

NGEC0634

Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - MIL goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
- 4) If NG, go to "Diagnostic Procedure", EC-793.

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)






VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0635S02

EC-FRO2LH-01



AEC945A


DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure

Diagnostic Procedure


NGEC0636

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Engine ground</p> </div> <p style="text-align: right;">AEC640A</p> | |
| ▶ GO TO 2. | |

GI
MA
EM
LC
EC

| | |
|--|---|
| 2 | RETIGHTEN FRONT HEATED OXYGEN SENSOR |
| <p>Loosen and retighten corresponding front heated oxygen sensor. Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)</p> | |
| ▶ GO TO 3. | |

FE
CL
MT
AT

| | |
|---|-----------------------------------|
| 3 | CHECK FOR EXHAUST AIR LEAK |
| <p>1. Start engine and run it at idle. 2. Listen for an exhaust air leak before three way catalyst.</p> <div style="text-align: center;">  </div> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEF099P</p> | |
| OK ▶ GO TO 4. | |
| NG ▶ Repair or replace. | |

TF
PD
AX
SU
BR
ST
RS

| | |
|--|----------------------------------|
| 4 | CHECK FOR INTAKE AIR LEAK |
| <p>Listen for an intake air leak after the mass air flow sensor.</p> <p style="text-align: center;">OK or NG</p> | |
| OK ▶ GO TO 5. | |
| NG ▶ Repair or replace. | |

BT
HA
SC
EL

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | | | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------------|---|-------------|--|------------|-----------|---------|-----------|---------|--|---------------|---------|---------------|--------|--------------|-------|--------------|-------|--------------|-------|--------------|-------|
| 5 | CLEAR THE SELF-LEARNING DATA | | | | | | | | | | | | | | | | | | | | | |
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR". | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;">SELF-LEARN</td><td style="text-align: center;">B1: XXX %</td></tr> <tr><td style="text-align: center;">CONTROL</td><td style="text-align: center;">B2: XXX %</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">CMPS-RPM(REF)</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">COOLAN TEMP/S</td><td style="text-align: center;">XXX °C</td></tr> <tr><td style="text-align: center;">FR O2 SEN-B1</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">FR O2 SEN-B2</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;">A/F ALPHA-B1</td><td style="text-align: center;">XXX %</td></tr> <tr><td style="text-align: center;">A/F ALPHA-B2</td><td style="text-align: center;">XXX %</td></tr> </table> | | | ACTIVE TEST | | SELF-LEARN | B1: XXX % | CONTROL | B2: XXX % | MONITOR | | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SEN-B1 | XXX V | FR O2 SEN-B2 | XXX V | A/F ALPHA-B1 | XXX % | A/F ALPHA-B2 | XXX % |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN | B1: XXX % | | | | | | | | | | | | | | | | | | | | | |
| CONTROL | B2: XXX % | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B1 | XXX V | | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B2 | XXX V | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| PEF921U | | | | | | | | | | | | | | | | | | | | | | |
| <ol style="list-style-type: none"> 4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected? Is it difficult to start engine? | | | | | | | | | | | | | | | | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640. 7. Make sure DTC No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114, 0115, 0209 or 0210 detected? Is it difficult to start engine? <p style="text-align: center;">Yes or No</p> | | | | | | | | | | | | | | | | | | | | | | |
| Yes | ▶ | Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-860, 868. | | | | | | | | | | | | | | | | | | | | |
| No | ▶ | GO TO 6. | | | | | | | | | | | | | | | | | | | | |


DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

6 CHECK FRONT HO2S INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding front heated oxygen sensor harness connector.



3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and FRONT HO2S terminal as follows. Refer to Wiring Diagram.

| DTC | Terminals | | Bank |
|-------|-----------|--------|-------|
| | ECM | Sensor | |
| P0133 | 50 | 2 | Right |
| P0153 | 51 | 2 | Left |

Continuity should exist.

5. Check harness continuity between ECM terminal or FRONT HO2S terminal and ground as follows. Refer to Wiring Diagram.

| DTC | Terminals | | Bank |
|-------|---------------|--------|-------|
| | ECM or sensor | Ground | |
| P0133 | 50 or 2 | Ground | Right |
| P0153 | 51 or 2 | Ground | Left |

Continuity should not exist.

6. Also check harness for short to power.

OK or NG


| | | |
|----|---|--|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 7 | CHECK FRONT HEATED OXYGEN SENSOR HEATER |
| <p>Check resistance between FRONT HO2S terminals 3 and 1.</p> <div style="display: flex; justify-content: space-around; align-items: center; margin: 10px 0;"> <div style="text-align: center;">    </div> <div style="text-align: center;">  </div> </div> <p style="text-align: right; margin-top: 10px;">AEC158A</p> <p>Resistance: 2.3 - 4.3Ω at 25°C (77°F)</p> <p>Check continuity between FRONT HO2S terminals 2 and 1, 3 and 2.</p> <p>Continuity should not exist.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center; margin-top: 10px;">OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ Replace malfunctioning front heated oxygen sensor. |


DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

8 CHECK MASS AIR FLOW SENSOR

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.




SEF747U

| Condition | Voltage V |
|--|--------------------------|
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 |
| Idle (Engine is warmed-up to normal operating temperature.) | 1.0 - 1.7 |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.7 - 2.3 |
| Idle to about 4,000 rpm* | 1.0 - 1.7 to Approx. 4.0 |

MTBL0227

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Then repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



SEF030T

OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace mass air flow sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| 9 | CHECK PCV VALVE |
|---|--------------------|
| <p>With engine running at idle, remove PCV valve ventilation hose from PCV valve; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.</p> <div data-bbox="649 315 974 630"></div> <p data-bbox="747 672 876 703">OK or NG</p> <p data-bbox="1380 630 1477 661">SEC137A</p> | |
| OK (With CONSULT-II) ▶ | GO TO 10. |
| OK (Without CONSULT-II) ▶ | GO TO 11. |
| NG ▶ | Replace PCV valve. |

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

10 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II, and select "FR O2 SEN-B1 (-B2)" and "FR O2 MNTR-B1 (-B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 MNTR-B1 | LEAN |
| INJ PULSE-B1 | XXX msec |
| A/F ALPHA-B1 | XXX % |
| FR O2 HTR-B1 | ON |

PEF365V

5. Check the following.

- "FR O2 MNTR-B1 (-B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Right bank

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B1 R-L-R-L-R-L-R-L-R-L-R

Left bank


cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B2 R-L-R-L-R-L-R-L-R-L-R

R means FR O2 MNTR-B1(-B2) indicates RICH

L means FR O2 MNTR-B1(-B2) indicates LEAN

SEF702W

- "FR O2 SEN-B1 (-B2)" voltage goes above 0.6V at least once.
- "FR O2 SEN-B1 (-B2)" voltage goes below 0.3V at least once.
- "FR O2 SEN-B1 (-B2)" voltage never exceeds 1.0V.



SEF154X

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0133 (RIGHT, -B1), P0153 (LEFT, -B2) FRONT HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | | | | | | | |
|---|---|--|---|-----------|----|---|--|
| 11 | CHECK FRONT HEATED OXYGEN SENSOR | | | | | | |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground. 3. Check the following with engine speed held at 2,000 rpm constant under no load. <div style="text-align: center; margin: 10px 0;"> <p style="margin: 0;">50: Right bank 51: Left bank</p> </div> <ul style="list-style-type: none"> ● MIL goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: right; margin-right: 20px;">SEF919U</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 15%; padding: 2px;">OK</td> <td style="width: 10%; text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">GO TO 12.</td> </tr> <tr> <td style="padding: 2px;">NG</td> <td style="text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">Replace malfunctioning front heated oxygen sensor.</td> </tr> </table> | | OK | ▶ | GO TO 12. | NG | ▶ | Replace malfunctioning front heated oxygen sensor. |
| OK | ▶ | GO TO 12. | | | | | |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. | | | | | |


| | | | | | | | |
|--|---|--|---|-----------|----|---|--|
| 12 | CHECK FRONT HO2S SHIELD CIRCUIT FOR OPEN AND SHORT | | | | | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect joint connector. 3. Check the following. <ul style="list-style-type: none"> ● Continuity between joint connector terminal 1 and ground ● Joint connector (Refer to "HARNES LAYOUT", <i>EL-9</i>.) <p style="margin-left: 20px; color: blue;">Continuity should exist.</p> 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 15%; padding: 2px;">OK</td> <td style="width: 10%; text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">GO TO 13.</td> </tr> <tr> <td style="padding: 2px;">NG</td> <td style="text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table> | | OK | ▶ | GO TO 13. | NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |
| OK | ▶ | GO TO 13. | | | | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | |

| | | |
|---|------------------------------------|-----------------------|
| 13 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| | ▶ | INSPECTION END |

DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)

VG33E


Component Description



Component Description

The front heated oxygen sensor is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NGEC0637



CONSULT-II Reference Value in Data Monitor Mode

NGEC0638

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|---|
| FR O2 SEN-B1 FR O2 SEN-B2 | <ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| FR O2 MNTR-B1 FR O2 MNTR-B2 | | LEAN ↔ RICH Changes more than 5 times during 10 seconds. |

ECM Terminals and Reference Value

NGEC0639


Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-------------------------------|---|------------------------|
| 50 | B | Front heated oxygen sensor RH | [Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm | 0 - Approximately 1.0V |
| 51 | G | Front heated oxygen sensor LH | | <p>SEF002V</p> |

DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)

VG33E

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0640

To judge the malfunction, the diagnosis checks that the front heated oxygen sensor output is not inordinately high. Malfunction is detected when an excessively high voltage from the sensor is sent to ECM.

POSSIBLE CAUSE

NGEC0640S01

- Harness or connectors (The sensor circuit is open or shorted.)
- Front heated oxygen sensor

5

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |

PEF361V

DTC Confirmation Procedure

NGEC0641

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Restart engine and let it idle for 20 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-805.

With GST

Follow the procedure "With CONSULT-II".

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Restart engine and let it idle for 20 seconds.
- 4) Turn ignition switch OFF, wait at least 5 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-805.

- When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II or ECM (Diagnostic Test Mode II) is recommended.

DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)

VG33E

Wiring Diagram


Wiring Diagram

NGEC0642

NGEC0642S01






RIGHT BANK

EC-FRO2RH-01



: Detectable line for DTC
 : Non-detectable line for DTC

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



AEC944A

DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)







VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0642S02

EC-FRO2LH-01



AEC945A


DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0643

| | | | |
|----------|-------------------------|---|---|
| 1 | INSPECTION START | <p>1. Turn ignition switch OFF. 2. Disconnect corresponding front heated oxygen sensor harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">AEC644A</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 5px;">EC</p> <p>FE</p> <p>CL</p> |
| ▶ | | GO TO 2. | |

| | | | |
|----------|---|---|---------------------|
| 2 | RETIGHTEN FRONT HEATED OXYGEN SENSOR | <p>1. Loosen and retighten corresponding front heated oxygen sensor. Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)</p> | <p>MT</p> <p>AT</p> |
| ▶ | | GO TO 3. | |

| 3 | CHECK FRONT HO2S INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal and FRONT HO2S terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0134</td> <td style="text-align: center;">50</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0154</td> <td style="text-align: center;">51</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> <p style="text-align: right;">AEC892A</p> <p>Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal or FRONT HO2S terminal and ground as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0134</td> <td style="text-align: center;">50 or 2</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0154</td> <td style="text-align: center;">51 or 2</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> <p style="text-align: right;">AEC893A</p> <p>Continuity should not exist.</p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p> | DTC | Terminals | | Bank | ECM | Sensor | P0134 | 50 | 2 | Right | P0154 | 51 | 2 | Left | DTC | Terminals | | Bank | ECM or sensor | Ground | P0134 | 50 or 2 | Ground | Right | P0154 | 51 or 2 | Ground | Left | <p>TF</p> <p>PD</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> |
|----------|---|--|-------|-----------|--|------|-----|--------|-------|----|---|-------|-------|----|---|------|-----|-----------|--|------|---------------|--------|-------|---------|--------|-------|-------|---------|--------|------|---|
| DTC | Terminals | | | Bank | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0134 | 50 | 2 | Right | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0154 | 51 | 2 | Left | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ECM or sensor | Ground | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0134 | 50 or 2 | Ground | Right | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0154 | 51 or 2 | Ground | Left | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ▶ | | GO TO 4. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|---|--|
| 4 | CHECK FRONT HO2S CONNECTOR FOR WATER | |
| 1. Disconnect front heated oxygen sensor harness connector. 2. Check connectors for water. Water should not exist. | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 5. |
| OK (Without CONSULT-II) | ▶ | GO TO 6. |
| NG | ▶ | Repair or replace harness or connectors. |

DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)

VG33E

Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

5 CHECK FRONT HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II, and select "FR O2 SEN-B1 (-B2)" and "FR O2 MNTR-B1 (-B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 MNTR-B1 | LEAN |
| INJ PULSE-B1 | XXX msec |
| A/F ALPHA-B1 | XXX % |
| FR O2 HTR-B1 | ON |

PEF365V

5. Check the following.

- "FR O2 MNTR-B1 (-B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown left:

Right bank

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B1 R-L-R-L-R-L-R-L-R-L-R

Left bank


cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B2 R-L-R-L-R-L-R-L-R-L-R

R means FR O2 MNTR-B1(-B2) indicates RICH

L means FR O2 MNTR-B1(-B2) indicates LEAN

SEF702W

- "FR O2 SEN-B1 (-B2)" voltage goes above 0.6V at least once.
- "FR O2 SEN-B1 (-B2)" voltage goes below 0.3V at least once.
- "FR O2 SEN-B1 (-B2)" voltage never exceeds 1.0V.



- Maximum voltage should be over 0.6V at least one time.

- Minimum voltage should be below 0.3V at least one time.

SEF154X

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

DTC P0134 (RIGHT, -B1), P0154 (LEFT, -B2) FRONT HO2S (HIGH VOLTAGE)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|---|--|
| 6 | CHECK FRONT HEATED OXYGEN SENSOR | |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground. 3. Check the following with engine speed held at 2,000 rpm constant under no load. | | |
|  <p style="margin-left: 100px;">50: Right bank 51: Left bank</p> | | |
| SEF919U | | |
| <ul style="list-style-type: none"> ● MIL goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

| | | |
|---|------------------------------------|-----------------------|
| 7 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| ▶ | | INSPECTION END |

DTC P0135 (RIGHT, -B1), P0155 (LEFT, -B2) FRONT HO2S HEATER

VG33E
Description

Description

SYSTEM DESCRIPTION

NGEC0644

NGEC0644S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|---|------------------------------------|
| Camshaft position sensor | Engine speed | Front heated oxygen sensor heater control | Front heated oxygen sensor heaters |

The ECM performs ON/OFF control of the front heated oxygen sensor heaters corresponding to the engine speed.

OPERATION

NGEC0644S02

| Engine speed rpm | Front heated oxygen sensor heaters |
|------------------|------------------------------------|
| Above 3,200 | OFF |
| Below 3,200 | ON |

CONSULT-II Reference Value in Data Monitor Mode

NGEC0645

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|------------------------------|---------------------------------|---------------|
| FR O2 HTR-B1 FR O2 HTR-B2 | ● Engine speed: Below 3,200 rpm | ON |
| | ● Engine speed: Above 3,200 rpm | OFF |

ECM Terminals and Reference Value

NGEC0646

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------------|------------|-----------------------------------|---|-------------------------------|
| 119 (Right bank) | BR/Y | Front heated oxygen sensor heater | [Engine is running] ● Engine speed is below 3,200 rpm | Approximately 0.4V |
| 121 (Left bank) | BR | | [Engine is running] ● Engine speed is above 3,200 rpm | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0647

Malfunction is detected when the current amperage in the front heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM through the front heated oxygen sensor heater.)

POSSIBLE CAUSE

NGEC0647S01

- Harness or connectors
(The front heated oxygen sensor heater circuit is open or shorted.)
- Front heated oxygen sensor heater

DTC P0135 (RIGHT, -B1), P0155 (LEFT, -B2) FRONT HO2S HEATER

VG33E

DTC Confirmation Procedure

| | | |
|---|---------------|---------|
| 2 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

DTC Confirmation Procedure

NGEC0648

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 6 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-813.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

Ⓜ No Tools

- 1) Start engine and run it for at least 6 seconds at idle speed.
- 2) Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-813.

- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II or ECM (Diagnostic Test Mode II) is recommended.**

DTC P0135 (RIGHT, -B1), P0155 (LEFT, -B2) FRONT HO2S HEATER

VG33E

Wiring Diagram






Wiring Diagram

NGEC0649

NGEC0649S01

RIGHT BANK

EC-FO2H-R-01



AEC946A

EC-811

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0135 (RIGHT, -B1), P0155 (LEFT, -B2) FRONT HO2S HEATER




VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0649S02

EC-FO2H-L-01



AEC947A



DTC P0135 (RIGHT, -B1), P0155 (LEFT, -B2) FRONT HO2S HEATER

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0650

| | |
|---|--|
| 1 | CHECK FRONT HO2S POWER SUPPLY CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect corresponding front heated oxygen sensor harness connector.</p> <div style="text-align: center;">  <p>Oil filler cap Front heated oxygen sensor LH harness connector Front heated oxygen sensor RH harness connector</p> </div> <p style="text-align: right;">AEC644A</p> <p>3. Turn ignition switch ON. 4. Check voltage between FRONT HO2S terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="text-align: right;">SEF633W</p> </div> <p style="text-align: center; color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 3. |
| NG | ▶ GO TO 2. |

| | |
|--|-----------------------------------|
| 2 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Fuse block (J/B) connector M26 ● 10A fuse ● Harness for open or short between front heated oxygen sensor and fuse | |
| | ▶ Repair harness or connectors. |


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0135 (RIGHT, -B1), P0155 (LEFT, -B2) FRONT HO2S HEATER

VG33E

Diagnostic Procedure (Cont'd)

| 3 | CHECK FRONT HO2S GROUND CIRCUIT FOR OPEN AND SHORT | | | | | | | | | | | | | | | |
|--|---|--|-------|-----------|--|------|-----|--------|-------|-----|---|-------|-------|-----|---|------|
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal and FRONT HO2S terminal as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0135</td> <td style="text-align: center;">119</td> <td style="text-align: center;">3</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0155</td> <td style="text-align: center;">121</td> <td style="text-align: center;">3</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> | | | DTC | Terminals | | Bank | ECM | Sensor | P0135 | 119 | 3 | Right | P0155 | 121 | 3 | Left |
| DTC | Terminals | | | Bank | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | |
| P0135 | 119 | 3 | Right | | | | | | | | | | | | | |
| P0155 | 121 | 3 | Left | | | | | | | | | | | | | |
| AEC894A | | | | | | | | | | | | | | | | |
| <p style="color: blue; font-weight: bold;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | | | | | | | | |


| | | |
|--|--|--|
| 4 | CHECK FRONT HEATED OXYGEN SENSOR HEATER | |
| <p>Check resistance between FRONT HO2S terminals 3 and 1.</p> | | |
|  | | |
| AEC158A | | |
| <p style="color: blue; font-weight: bold;">Resistance: 2.3 - 4.3Ω at 25°C (77°F)</p> <p>Check continuity between FRONT HO2S terminals 2 and 1, 3 and 2.</p> <p style="color: blue; font-weight: bold;">Continuity should not exist.</p> <p style="color: red; font-weight: bold;">CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

| | | |
|--|------------------------------------|-----------------------|
| 5 | CHECK INTERMITTENT INCIDENT | |
| <p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.</p> | | |
| ▶ | | INSPECTION END |

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

Component Description



Component Description

NGEC0651

The rear heated oxygen sensor, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0652

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|-------------------------------|
| RR O2 SEN-B1 RR O2 SEN-B2 | ● Engine: After warming up Revsing engine from idle up to 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR-B1 RR O2 MNTR-B2 | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0653

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------------|------------|---------------------------|--|------------------------|
| 56 (Right bank) | OR | Rear heated oxygen sensor | [Engine is running] ● Warm-up condition ● Revving engine from idle up to 2,000 rpm | 0 - Approximately 1.0V |
| 57 (Left bank) | Y | | | |



On Board Diagnosis Logic

NGEC0654

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.

Malfunction is detected when the minimum voltage from the sensor is not reached to the specified voltage.

POSSIBLE CAUSE

NGEC0654S01

- Harness or connectors (The sensor circuit is open or shorted.)
- Rear heated oxygen sensor
- Fuel pressure
- Injectors

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

On Board Diagnosis Logic (Cont'd)

6

RR O2 SENSOR P0137

WAIT
OPEN ENGINE HOOD.
KEEP ENGINE RUNNING AT
IDLE SPEED FOR MAXIMUM
OF 5 MINUTES.

SEF548X

8

RR O2 SENSOR P0137

MAINTAIN
1800 - 2800 RPM UNTIL FINAL
RESULT APPEARS.

1800 rpm 2300 rpm 2800 rpm

SEF549X

8

RR O2 SENSOR P0137

COMPLETED

SELF-DIAG RESULTS

SEF550X

DTC Confirmation Procedure

NGEC0655

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Open engine hood before conducting following procedure With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure that "COOLANT TEMP/S" is more than 70°C (158°F).
- 6) Select "RR O2 SEN -B1 (-B2), P0137 (P0157) of "RR O2 SENSOR" in DTC WORK SUPPORT" mode with CONSULT.
- 7) Start engine and follow the instructions of CONSULT-II.
- 8) Make sure that "OK" is displayed after touching "SELF_DIAG RESULTS".
If NG is displayed, refer to "DIAGNOSTIC PROCEDURE", EC-820.
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a) Stop engine and cool down "COOLANT TEMP/SE" to less than 70°C 158°F).
 - b) Turn ignition switch ON.
 - c) Select "DATA MONITOR" mode with CONSULT-II.
 - d) Perform from step 6) again when the "COOLANT TEMP/S" reaches to 70°C 158°F)

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

Overall Function Check



Overall Function Check

=NGEC0656

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

⊗ Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)
The voltage should be below 0.54V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "O/D" OFF (A/T).
The voltage should be below 0.54V at least once during this procedure.
- 6) If NG, go to "Diagnostic Procedure", EC-820.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

Wiring Diagram







Wiring Diagram

NGEC0657

NGEC0657S01

RIGHT BANK

EC-RRO2RH-01



AEC948A

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)


VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0657S02

EC-RRO2LH-01



— : Detectable line for DTC
 — : Non-detectable line for DTC

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS






BT

HA

SC

EL

IDX



AEC949A


DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0658

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Engine ground</p> </div> <p style="text-align: right;">AEC640A</p> | |
| <p>▶ GO TO 2.</p> | |

| 2 | CLEAR THE SELF-LEARNING DATA | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------------|--|---|--|-----------|---------|-----------|---------|--|---------------|---------|---------------|--------|--------------|-------|--------------|-------|--------------|-------|--------------|-------|
| <p> With CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR".</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>SELF-LEARN</td> <td>B1: XXX %</td> </tr> <tr> <td>CONTROL</td> <td>B2: XXX %</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS-RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>FR O2 SEN-B1</td> <td>XXX V</td> </tr> <tr> <td>FR O2 SEN-B2</td> <td>XXX V</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td>XXX %</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XXX %</td> </tr> </tbody> </table> <p style="text-align: right;">PEF921U</p> <p>4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0172 or P0175 detected? Is it difficult to start engine?</p> | | ACTIVE TEST | | SELF-LEARN | B1: XXX % | CONTROL | B2: XXX % | MONITOR | | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SEN-B1 | XXX V | FR O2 SEN-B2 | XXX V | A/F ALPHA-B1 | XXX % | A/F ALPHA-B2 | XXX % |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN | B1: XXX % | | | | | | | | | | | | | | | | | | | | |
| CONTROL | B2: XXX % | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B1 | XXX V | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B2 | XXX V | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | |
| <p> Without CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640. 7. Make sure DTC No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114 or 0209 detected? Is it difficult to start engine?</p> <p style="text-align: center;">Yes or No</p> | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Yes</td> <td style="width: 5%; text-align: center;">▶</td> <td>Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-869.</td> </tr> <tr> <td>No</td> <td style="text-align: center;">▶</td> <td>GO TO 3.</td> </tr> </table> | | Yes | ▶ | Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-869. | No | ▶ | GO TO 3. | | | | | | | | | | | | | | |
| Yes | ▶ | Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-869. | | | | | | | | | | | | | | | | | | | |
| No | ▶ | GO TO 3. | | | | | | | | | | | | | | | | | | | |


DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

3 CHECK REAR HO2S INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect corresponding rear heated oxygen sensor harness connector.



AEC645A

- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal and REAR HO2S terminal as follows. Refer to Wiring Diagram.

| DTC | Terminals | | Bank |
|-------|-----------|--------|-------|
| | ECM | Sensor | |
| P0137 | 56 | 1 | Right |
| P0157 | 57 | 1 | Left |

AEC895A

Continuity should exist.

- Check harness continuity between ECM terminal or REAR HO2S terminal and ground as follows. Refer to Wiring Diagram.

| DTC | Terminals | | Bank |
|-------|---------------|--------|-------|
| | ECM or sensor | Ground | |
| P0137 | 56 or 1 | Ground | Right |
| P0157 | 57 or 1 | Ground | Left |

AEC896A

Continuity should not exist.

- Also check harness for short to power.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

4 CHECK REAR HO2S GROUND CIRCUIT FOR OPEN AND SHORT

- Check harness continuity between REAR HO2S terminal 4 and engine ground. Refer to Wiring Diagram. **Continuity should exist.**
- Also check harness for short to ground and short to power.

OK or NG

| | | |
|-------------------------|---|----------|
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | GO TO 5. |

5 DETECT MALFUNCTIONING PART

Check the following.

- Joint connector-3
- Harness for open or short between rear heated oxygen sensor and engine ground.

| | | |
|--|---|--|
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |
|--|---|--|

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|---|
| 6 | CHECK REAR HEATED OXYGEN SENSOR |
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SEN-B1 (-B2)" as the monitor item with CONSULT-II. 4. Check "RR O2 SEN-B1 (-B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$. | |
| (Reference data) | |
| <p style="text-align: right; margin-right: 50px;">} The voltage should be above 0.56V at least one time.</p> <p style="text-align: right; margin-right: 50px;">} The voltage should be below 0.54V at least one time.</p> <p style="text-align: right; margin-right: 50px;">SEF989RB</p> | |
| <p>"RR O2 SEN-B1 (-B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "RR O2 SEN-B1 (-B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG | ▶ Replace malfunctioning rear heated oxygen sensor. |

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)


VG33E

Diagnostic Procedure (Cont'd)


7 CHECK REAR HEATED OXYGEN SENSOR

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
4. Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)



SEF923U



SEF924U

The voltage should be above 0.56V at least once during this procedure.

If the voltage is above 0.56V at step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "O/D" OFF (A/T).

The voltage should be below 0.54V at least once during this procedure.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace malfunctioning rear heated oxygen sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0137 (RIGHT, -B1), P0157 (LEFT, -B2) REAR HO2S (MIN. VOLTAGE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)


| | |
|---|--|
| 8 | CHECK REAR HO2S SHIELD CIRCUIT FOR OPEN AND SHORT |
| 1. Turn ignition switch OFF. 2. Disconnect joint connector-3. 3. Check the following. <ul style="list-style-type: none">● Continuity between joint connector terminal 1 and ground● Joint connector (Refer to "HARNES LAYOUT", <i>EL-292</i>) Continuity should exist. 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector-3. | |
| OK or NG | |
| OK | ▶ GO TO 9. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

Component Description



Component Description

NGEC0659

The rear heated oxygen sensor, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0660

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|-------------------------------|
| RR O2 SEN-B1 RR O2 SEN-B2 | ● Engine: After warming up Revsing engine from idle up to 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR-B1 RR O2 MNTR-B2 | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0661

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|-----------------------|---------------|---------------------------|--|------------------------|
| 56 (Right bank) | OR | Rear heated oxygen sensor | [Engine is running] ● Warm-up condition ● Revsing engine from idle up to 2,000 rpm | 0 - Approximately 1.0V |
| 57 (Left bank) | Y | | | |



On Board Diagnosis Logic

NGEC0662

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.

Malfunction is detected when the maximum voltage from the sensor is not reached to the specified voltage.

POSSIBLE CAUSE

NGEC0662S01

- Harness or connectors (The sensor circuit is open or shorted.)
- Rear heated oxygen sensor
- Fuel pressure
- Injectors
- Intake air leaks

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

On Board Diagnosis Logic (Cont'd)

6

| |
|--|
| RR O2 SENSOR P0138 |
| WAIT OPEN ENGINE HOOD. KEEP ENGINE RUNNING AT IDLE SPEED FOR MAXIMUM OF 5 MINUTES. |

SEF551X

8

| |
|---|
| RR O2 SENSOR P0138 |
| MAINTAIN 1800 - 2800 RPM UNTIL FINAL RESULT APPEARS. |
|  |

SEF552X

8

| |
|--------------------|
| RR O2 SENSOR P0138 |
| COMPLETED |
| SELF-DIAG RESULTS |

SEF553X

DTC Confirmation Procedure

NGEC0663

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Open engine hood before conducting following procedure With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure that "COOLANT TEMP/S" is more than 70°C (158°F).
- 6) Select "RR O2 SEN -B1 (-B2), P0138 (P0158) of "RR O2 SENSOR" in DTC WORK SUPPORT" mode with CONSULT.
- 7) Start engine and follow the instructions of CONSULT-II.
- 8) Make sure that "OK" is displayed after touching "SELF_DIAG RESULTS".
If NG is displayed, refer to "DIAGNOSTIC PROCEDURE", EC-830.
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a) Stop engine and cool down "COOLANT TEMP/SE" to less than 70°C 158°F).
 - b) Turn ignition switch ON.
 - c) Select "DATA MONITOR" mode with CONSULT-II.
 - d) Perform from step 6) again when the "COOLANT TEMP/S" reaches to 70°C 158°F)

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

Overall Function Check



Overall Function Check

=NGEC0664

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

⊗ Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)
The voltage should be above 0.56V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "O/D" OFF (A/T).
The voltage should be above 0.56V at least once during this procedure.
- 6) If NG, go to "Diagnostic Procedure", EC-830.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

Wiring Diagram






Wiring Diagram

NGEC0665

NGEC0665S01

RIGHT BANK

EC-RRO2RH-01



AEC948A

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0665S02

EC-RRO2LH-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS







BT

HA

SC

EL


IDX



AEC949A

Diagnostic Procedure

NGEC0666

| | |
|---|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Engine ground</p> </div> <p style="text-align: right;">AEC640A</p> | |
| <p>▶ GO TO 2.</p> | |

| 2 | CLEAR THE SELF-LEARNING DATA | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------------|--|---|--|-----------|---------|-----------|---------|--|---------------|---------|---------------|--------|--------------|-------|--------------|-------|--------------|-------|--------------|-------|
| <p> With CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR".</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">SELF-LEARN</td> <td style="text-align: center;">B1: XXX %</td> </tr> <tr> <td style="text-align: center;">CONTROL</td> <td style="text-align: center;">B2: XXX %</td> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <td style="text-align: center;">CMPS-RPM(REF)</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">COOLAN TEMP/S</td> <td style="text-align: center;">XXX °C</td> </tr> <tr> <td style="text-align: center;">FR O2 SEN-B1</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">FR O2 SEN-B2</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">A/F ALPHA-B1</td> <td style="text-align: center;">XXX %</td> </tr> <tr> <td style="text-align: center;">A/F ALPHA-B2</td> <td style="text-align: center;">XXX %</td> </tr> </tbody> </table> <p style="text-align: right;">PEF921U</p> <p>4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171 or P0174 detected? Is it difficult to start engine?</p> | | ACTIVE TEST | | SELF-LEARN | B1: XXX % | CONTROL | B2: XXX % | MONITOR | | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SEN-B1 | XXX V | FR O2 SEN-B2 | XXX V | A/F ALPHA-B1 | XXX % | A/F ALPHA-B2 | XXX % |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN | B1: XXX % | | | | | | | | | | | | | | | | | | | | |
| CONTROL | B2: XXX % | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B1 | XXX V | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B2 | XXX V | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | |
| <p> Without CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640. 7. Make sure DTC No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0115 or 0210 detected? Is it difficult to start engine?</p> <p style="text-align: center;">Yes or No</p> | | | | | | | | | | | | | | | | | | | | | |
| <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; border-right: 1px solid black;">Yes</td> <td style="border-right: 1px solid black; text-align: center;">▶</td> <td>Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-861.</td> </tr> <tr> <td style="border-right: 1px solid black;">No</td> <td style="border-right: 1px solid black; text-align: center;">▶</td> <td>GO TO 3.</td> </tr> </table> | | Yes | ▶ | Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-861. | No | ▶ | GO TO 3. | | | | | | | | | | | | | | |
| Yes | ▶ | Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-861. | | | | | | | | | | | | | | | | | | | |
| No | ▶ | GO TO 3. | | | | | | | | | | | | | | | | | | | |

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| 3 | CHECK REAR HO2S INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | | | | | | | | | | | | | | | |
|--|--|--|-------|-----------|--|------|---------------|--------|-------|---------|--------|-------|-------|---------|--------|------|
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect corresponding rear heated oxygen sensor harness connector.</p> <p>3. Disconnect ECM harness connector.</p> <p>4. Check harness continuity between ECM terminal and REAR HO2S terminal as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0138</td> <td style="text-align: center;">56</td> <td style="text-align: center;">1</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0158</td> <td style="text-align: center;">57</td> <td style="text-align: center;">1</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> | | | DTC | Terminals | | Bank | ECM | Sensor | P0138 | 56 | 1 | Right | P0158 | 57 | 1 | Left |
| DTC | Terminals | | | Bank | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | |
| P0138 | 56 | 1 | Right | | | | | | | | | | | | | |
| P0158 | 57 | 1 | Left | | | | | | | | | | | | | |
| AEC897A | | | | | | | | | | | | | | | | |
| <p style="color: blue;">Continuity should exist.</p> <p>5. Check harness continuity between ECM terminal or REAR HO2S terminal and ground as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0138</td> <td style="text-align: center;">56 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0158</td> <td style="text-align: center;">57 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> | | | DTC | Terminals | | Bank | ECM or sensor | Ground | P0138 | 56 or 1 | Ground | Right | P0158 | 57 or 1 | Ground | Left |
| DTC | Terminals | | | Bank | | | | | | | | | | | | |
| | ECM or sensor | Ground | | | | | | | | | | | | | | |
| P0138 | 56 or 1 | Ground | Right | | | | | | | | | | | | | |
| P0158 | 57 or 1 | Ground | Left | | | | | | | | | | | | | |
| AEC898A | | | | | | | | | | | | | | | | |
| <p style="color: blue;">Continuity should not exist.</p> <p>6. Also check harness for short to power.</p> | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | | | | | | | | |

| | | |
|--|--|----------|
| 4 | CHECK REAR HO2S GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Check harness continuity between REAR HO2S terminal 4 and engine ground. Refer to Wiring Diagram.</p> <p style="color: blue;">Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | GO TO 5. |

| | | |
|---|-----------------------------------|--|
| 5 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-3 ● Harness for open or short between rear heated oxygen sensor and engine ground. | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|--|---|
| 6 | CHECK REAR HEATED OXYGEN SENSOR | |
| <p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SEN-B1 (-B2)" as the monitor item with CONSULT-II. 4. Check "RR O2 SEN-B1 (-B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$. | | |
| (Reference data) | | |
| <p style="text-align: right; margin-right: 50px;">} The voltage should be above 0.56V at least one time.</p> <p style="text-align: right; margin-right: 50px;">} The voltage should be below 0.54V at least one time.</p> <p style="text-align: right; margin-right: 50px;">SEF989RB</p> | | |
| <p>"RR O2 SEN-B1 (-B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "RR O2 SEN-B1 (-B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.</p> <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace malfunctioning rear heated oxygen sensor. |

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)


VG33E

Diagnostic Procedure (Cont'd)


7 CHECK REAR HEATED OXYGEN SENSOR

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
4. Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)



SEF923U



SEF924U

The voltage should be above 0.56V at least once during this procedure.

If the voltage is above 0.56V at step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "O/D" OFF (A/T).

The voltage should be below 0.54V at least once during this procedure.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace malfunctioning rear heated oxygen sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0138 (RIGHT, -B1), P0158 (LEFT, -B2) REAR HO2S (MAX. VOLTAGE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)


| | |
|---|--|
| 8 | CHECK REAR HO2S SHIELD CIRCUIT FOR OPEN AND SHORT |
| 1. Turn ignition switch OFF. 2. Disconnect joint connector. 3. Check the following. <ul style="list-style-type: none">● Continuity between joint connector terminal 1 and ground● Joint connector (Refer to "HARNES LAYOUT", <i>EL-9</i>.) Continuity should exist. | |
| 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. | |
| OK or NG | |
| OK | ▶ GO TO 9. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)

VG33E

Component Description



Component Description

NGEC0667

The rear heated oxygen sensor, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0668

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|-------------------------------|
| RR O2 SEN-B1 RR O2 SEN-B2 | ● Engine: After warming up Revsing engine from idle up to 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR-B1 RR O2 MNTR-B2 | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0669

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------------|------------|---------------------------|---|------------------------|
| 56 (Right bank) | OR | Rear heated oxygen sensor | [Engine is running] ● Revsing engine from idle up to 2,000 rpm | 0 - Approximately 1.0V |
| 57 (Left bank) | Y | | | |



On Board Diagnosis Logic

NGEC0670

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut. Malfunction is detected when it takes more time for the sensor to respond between rich and lean than the specified time.

POSSIBLE CAUSE

NGEC0670S01

- Harness or connectors (The sensor circuit is open or shorted.)
- Rear heated oxygen sensor
- Fuel pressure
- Injectors
- Intake air leaks

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)

VG33E

On Board Diagnosis Logic (Cont'd)

6

| |
|--|
| RR O2 SENSOR P0139 |
| WAIT OPEN ENGINE HOOD. KEEP ENGINE RUNNING AT IDLE SPEED FOR MAXIMUM OF 5 MINUTES. |

SEF554X

8

| |
|---|
| RR O2 SENSOR P0139 |
| MAINTAIN 1800 - 2800 RPM UNTIL FINAL RESULT APPEARS. |
|  |

SEF555X

8

| |
|--------------------|
| RR O2 SENSOR P0139 |
| COMPLETED |
| SELF-DIAG RESULTS |

SEF556X

DTC Confirmation Procedure

NGEC0671

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Open engine hood before conducting following procedure With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure that "COOLANT TEMP/S" is more than 70°C (158°F).
- 6) Select "RR O2 SEN -B1 (-B2), P0139 (P0159) of "RR O2 SENSOR" in DTC WORK SUPPORT" mode with CONSULT.
- 7) Start engine and follow the instructions of CONSULT-II.
- 8) Make sure that "OK" is displayed after touching "SELF_DIAG RESULTS".
If NG is displayed, refer to "DIAGNOSTIC PROCEDURE", EC-840.
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a) Stop engine and cool down "COOLANT TEMP/SE" to less than 70°C 158°F).
 - b) Turn ignition switch ON.
 - c) Select "DATA MONITOR" mode with CONSULT-II.
 - d) Perform from step 6) again when the "COOLANT TEMP/S" reaches to 70°C 158°F)

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)

VG33E

Overall Function Check



Overall Function Check

=NGEC0672

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "O/D" OFF (A/T)..
The voltage should change at more than 0.06V for 1 second during this procedure.
- 6) IF NG, go to "Diagnostic Procedure", EC-840.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)

VG33E

Wiring Diagram







Wiring Diagram

NGEC0673

NGEC0673S01

RIGHT BANK

EC-RRO2RH-01



AEC948A

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)


VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0673S02





EC-RRO2LH-01



— : Detectable line for DTC
 - - - : Non-detectable line for DTC

- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST

- RS
- BT
- HA
- SC
- EL
- IDX



AEC949A


DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0674

| | |
|--|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Engine ground</p> </div> <p style="text-align: right;">AEC640A</p> | |
| ▶ | GO TO 2. |

| 2 | CLEAR THE SELF-LEARNING DATA | | | | | | | | | | | | | | | | | | | | |
|--|---|-------------|--|------------|-----------|---------|-----------|---------|--|---------------|---------|---------------|--------|--------------|-------|--------------|-------|--------------|-------|--------------|-------|
| <p> With CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR".</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>SELF-LEARN</td> <td>B1: XXX %</td> </tr> <tr> <td>CONTROL</td> <td>B2: XXX %</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS-RPM(REF)</td> <td>XXX rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>FR O2 SEN-B1</td> <td>XXX V</td> </tr> <tr> <td>FR O2 SEN-B2</td> <td>XXX V</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td>XXX %</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XXX %</td> </tr> </tbody> </table> <p style="text-align: right;">PEF921U</p> <p>4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected? Is it difficult to start engine?</p> | | ACTIVE TEST | | SELF-LEARN | B1: XXX % | CONTROL | B2: XXX % | MONITOR | | CMPS-RPM(REF) | XXX rpm | COOLAN TEMP/S | XXX °C | FR O2 SEN-B1 | XXX V | FR O2 SEN-B2 | XXX V | A/F ALPHA-B1 | XXX % | A/F ALPHA-B2 | XXX % |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| SELF-LEARN | B1: XXX % | | | | | | | | | | | | | | | | | | | | |
| CONTROL | B2: XXX % | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| COOLAN TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B1 | XXX V | | | | | | | | | | | | | | | | | | | | |
| FR O2 SEN-B2 | XXX V | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | |
| <p> Without CONSULT-II</p> <p>1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-640. 7. Make sure DTC No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114, 0115, 0209 or 0210 detected? Is it difficult to start engine?</p> <p style="text-align: center;">Yes or No</p> | | | | | | | | | | | | | | | | | | | | | |
| Yes | ▶ Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-860, 868. | | | | | | | | | | | | | | | | | | | | |
| No | ▶ GO TO 3. | | | | | | | | | | | | | | | | | | | | |


DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)

3 CHECK REAR HO2S INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding rear heated oxygen sensor harness connector.



GI
MA
EM
LC
EC

3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and REAR HO2S terminal as follows. Refer to Wiring Diagram.

AEC645A

| DTC | Terminals | | Bank |
|-------|-----------|--------|-------|
| | ECM | Sensor | |
| P0139 | 56 | 1 | Right |
| P0159 | 57 | 1 | Left |

AEC899A

Continuity should exist.

5. Check harness continuity between ECM terminal or REAR HO2S terminal and ground as follows. Refer to Wiring Diagram.

| DTC | Terminals | | Bank |
|-------|---------------|--------|-------|
| | ECM or sensor | Ground | |
| P0139 | 56 or 1 | Ground | Right |
| P0159 | 57 or 1 | Ground | Left |

AEC900A

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

FE
CL
MT
AT
TF
PD

| | | |
|----|---|--|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

AX
SU

4 CHECK REAR HO2S GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between REAR HO2S terminal 4 and engine ground. Refer to Wiring Diagram.
Continuity should exist.
2. Also check harness for short to ground and short to power.

OK or NG

| | | |
|-------------------------|---|----------|
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | GO TO 5. |

BR
ST
RS
BT
HA

5 DETECT MALFUNCTIONING PART

- Check the following.
- Joint connector-3
 - Harness for open or short between rear heated oxygen sensor and engine ground.

| | | |
|--|---|--|
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |
|--|---|--|

SC
EL

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)


VG33E

Diagnostic Procedure (Cont'd)

6 CHECK REAR HEATED OXYGEN SENSOR

With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SEN-B1 (-B2)" as the monitor item with CONSULT-II.
4. Check "RR O2 SEN-B1 (-B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“RR O2 SEN-B1 (-B2)” should be above 0.56V at least once when the “FUEL INJECTION” is +25%.

“RR O2 SEN-B1 (-B2)” should be below 0.54V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK



GO TO 8.

NG



Replace malfunctioning rear heated oxygen sensor.

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)


VG33E

Diagnostic Procedure (Cont'd)


7 CHECK REAR HEATED OXYGEN SENSOR

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
4. Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)



SEF923U



SEF924U

The voltage should be above 0.56V at least once during this procedure.

If the voltage is above 0.56V at step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "O/D" OFF (A/T).

The voltage should be below 0.54V at least once during this procedure.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace malfunctioning rear heated oxygen sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0139 (RIGHT, -B1), P0159 (LEFT, -B2) REAR HO2S (RESPONSE MONITORING)

VG33E

Diagnostic Procedure (Cont'd)


| | |
|---|--|
| 8 | CHECK REAR HO2S SHIELD CIRCUIT FOR OPEN AND SHORT |
| 1. Turn ignition switch OFF. 2. Disconnect joint connector. 3. Check the following. <ul style="list-style-type: none">● Continuity between joint connector terminal 1 and ground● Joint connector (Refer to "HARNESS LAYOUT", <i>EL-9</i>.) Continuity should exist. 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. | |
| OK or NG | |
| OK | ▶ GO TO 9. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)

VG33E

Component Description



Component Description

NGEC0675

The rear heated oxygen sensor, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0676

Specification data are reference values.


| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------------------------|--|-------------------------------|
| RR O2 SEN-B1 RR O2 SEN-B2 | ● Engine: After warming up Revving engine from idle up to 2,000 rpm | 0 - 0.3V ↔ Approx. 0.6 - 1.0V |
| RR O2 MNTR-B1 RR O2 MNTR-B2 | | LEAN ↔ RICH |

ECM Terminals and Reference Value

NGEC0677

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------------|------------|---------------------------|--|------------------------|
| 56 (Right bank) | OR | Rear heated oxygen sensor | [Engine is running] ● Warm-up condition ● Revving engine from idle up to 2,000 rpm | 0 - Approximately 1.0V |
| 57 (Left bank) | Y | | | |



On Board Diagnosis Logic

NGEC0678

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.

Malfunction is detected when an excessively high voltage from the sensor is sent to ECM.

POSSIBLE CAUSE

NGEC0678S01

- Harness or connectors (The sensor circuit is open or shorted.)
- Rear heated oxygen sensor

DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)

VG33E

DTC Confirmation Procedure

5

| DATA MONITOR | |
|----------------|----------|
| MONITORING | NO FAIL |
| CMPS~RPM (REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| VHCL SPEED SE | XXX km/h |
| P/N POSI SW | ON |
| B/FUEL SCHDL | XXX msec |

SEF375X

DTC Confirmation Procedure

NGEC0679

CAUTION:

Always drive vehicle at a safe speed.

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 3) Stop vehicle with engine running.
- 4) Let engine idle for 1 minute.
- 5) Maintain the following conditions for at least 5 consecutive seconds.

| | |
|----------------|--|
| CMPS-RPM (REF) | 1,300 - 3,100 rpm (A/T models) 1,500 - 3,600 rpm (M/T models) |
| VHCL SPEED SE | 64 - 130 km/h (40 - 80 MPH) |
| B/FUEL SCHDL | 0.5 - 6.4 msec (A/T models) 0.5 - 5.9 msec (M/T models) |
| COOLAN TEMP/S | 70 - 100°C (158 - 212°F) |
| Selector lever | Suitable position |

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-849.



Overall Function Check

NGEC0680

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)
The voltage should be below 2V during this procedure.
- 5) If NG, go to "Diagnostic Procedure", EC-849.

DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)

VG33E

Wiring Diagram


Wiring Diagram

NGEC0681





NGEC0681S01

RIGHT BANK

EC-RRO2RH-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



AEC948A

DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)







VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0681S02

EC-RRO2LH-01



AEC949A


DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0682

| | | | |
|----------|-------------------------|--|---|
| 1 | INSPECTION START | <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Engine ground</p> </div> <p>3. Disconnect corresponding rear heated oxygen sensor harness connector. 4. Disconnect ECM harness connector.</p> <p style="text-align: right;">AEC640A</p> | GI MA EM LC EC FE CL |
| ▶ | | GO TO 2. | |

| 2 | CHECK REAR HO2S INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | <p>1. Check harness continuity between ECM terminal and REAR HO2S terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0140</td> <td style="text-align: center;">56</td> <td style="text-align: center;">1</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0160</td> <td style="text-align: center;">57</td> <td style="text-align: center;">1</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> <p style="text-align: right;">AEC901A</p> <p style="color: blue;">Continuity should exist.</p> <p>2. Check harness continuity between ECM terminal or REAR HO2S terminal and ground as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0140</td> <td style="text-align: center;">56 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0160</td> <td style="text-align: center;">57 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> <p style="text-align: right;">AEC902A</p> <p style="color: blue;">Continuity should not exist.</p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p> | DTC | Terminals | | Bank | ECM | Sensor | P0140 | 56 | 1 | Right | P0160 | 57 | 1 | Left | DTC | Terminals | | Bank | ECM or sensor | Ground | P0140 | 56 or 1 | Ground | Right | P0160 | 57 or 1 | Ground | Left | MT AT TF PD AX SU BR ST |
|----------|--|---|-------|-----------|--|------|-----|--------|-------|----|---|-------|-------|----|---|------|-----|-----------|--|------|---------------|--------|-------|---------|--------|-------|-------|---------|--------|------|--|
| DTC | Terminals | | | Bank | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0140 | 56 | 1 | Right | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0160 | 57 | 1 | Left | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ECM or sensor | Ground | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0140 | 56 or 1 | Ground | Right | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P0160 | 57 or 1 | Ground | Left | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK ▶ | | GO TO 3. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| | | | |
|----------|--|---|----------------------|
| 3 | CHECK REAR HO2S GROUND CIRCUIT FOR OPEN AND SHORT | <p>1. Check harness continuity between REAR HO2S terminal 4 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | RS BT HA SC |
| OK ▶ | | GO TO 5. | |
| NG ▶ | | GO TO 4. | |

DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|--|--|
| 4 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Joint connector-3 ● Harness for open or short between rear heated oxygen sensor and engine ground. | | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

| | | |
|--|---|--|
| 5 | CHECK REAR HO2S CONNECTORS FOR WATER | |
| Check rear heated oxygen sensor connector and harness connector for water. Water should not exist. | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | Repair or replace harness or connectors. |

| | | |
|---|--|---|
| 6 | CHECK REAR HEATED OXYGEN SENSOR | |
| (i) With CONSULT-II <ol style="list-style-type: none"> 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SEN-B1 (-B2)" as the monitor item with CONSULT-II. 4. Check "RR O2 SEN-B1 (-B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$. | | |
| (Reference data) | | |
| <p style="font-size: small;">The voltage should be above 0.56V at least one time.</p> <p style="font-size: small;">The voltage should be below 0.54V at least one time.</p> <p style="text-align: right; font-size: x-small;">SEF989RB</p> | | |
| "RR O2 SEN-B1 (-B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "RR O2 SEN-B1 (-B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%. | | |
| CAUTION: | | |
| <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace malfunctioning rear heated oxygen sensor. |

DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)


VG33E

Diagnostic Procedure (Cont'd)


7 CHECK REAR HEATED OXYGEN SENSOR

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 56 (right bank sensor signal) or 57 (left bank sensor signal) and engine ground.
4. Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)



SEF923U



SEF924U

The voltage should be above 0.56V at least once during this procedure.

If the voltage is above 0.56V at step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "O/D" OFF (A/T).

The voltage should be below 0.54V at least once during this procedure.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0140 (RIGHT, -B1), P0160 (LEFT, -B2) REAR HO2S (HIGH VOLTAGE)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 8 | CHECK REAR HO2S SHIELD CIRCUIT FOR OPEN AND SHORT |
| 1. Turn ignition switch OFF. 2. Disconnect joint connector. 3. Check the following. <ul style="list-style-type: none">● Continuity between joint connector terminal 1 and ground● Joint connector (Refer to "HARNES LAYOUT", <i>EL-292</i>.) Continuity should exist. | |
| 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. | |
| OK or NG | |
| OK | ▶ GO TO 9. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) REAR HO2S HEATER

VG33E
Description

Description

SYSTEM DESCRIPTION

NGEC0683

NGEC0683S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|--|-----------------------------------|
| Camshaft position sensor | Engine speed | Rear heated oxygen sensor heater control | Rear heated oxygen sensor heaters |

The ECM performs ON/OFF control of the rear heated oxygen sensor heaters corresponding to the engine speed.

OPERATION

NGEC0683S02

| Engine speed rpm | Rear heated oxygen sensor heaters |
|------------------|-----------------------------------|
| Above 3,200 | OFF |
| Below 3,200 | ON |

CONSULT-II Reference Value in Data Monitor Mode

NGEC0684

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|------------------------------|---|---------------|
| RR O2 HTR-B1 RR O2 HTR-B2 | <ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Engine is running above 3,200 rpm. | OFF |
| | <ul style="list-style-type: none"> ● Engine is running below 3,200 rpm after driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. | ON |

ECM Terminals and Reference Value

NGEC0685

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------------|------------|----------------------------------|---|-------------------------------|
| 122 (Right bank) | R/B | Rear heated oxygen sensor heater | [Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm | BATTERY VOLTAGE (11 - 14V) |
| 123 (Left bank) | R/Y | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,200 rpm ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more | Approximately 0.4V |

On Board Diagnosis Logic

NGEC0686

Malfunction is detected when the current amperage in the rear heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM through the rear heated oxygen sensor heater.)

POSSIBLE CAUSE

NGEC0686S01

- Harness or connectors
(The rear heated oxygen sensor heater circuit is open or shorted.)
- Rear heated oxygen sensor heater

DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) REAR HO2S HEATER

VG33E

DTC Confirmation Procedure

| | | |
|---|---------------|---------|
| 4 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

DTC Confirmation Procedure

NGEC0687

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine.
- 3) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 4) Stop vehicle and let engine idle for at least 6 seconds.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-857.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) REAR HO2S HEATER

VG33E

Wiring Diagram


Wiring Diagram

NGEC0688





NGEC0688S01

RIGHT BANK

EC-RO2H-R-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



AEC950A

EC-855

DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) REAR HO2S HEATER






VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0688S02

EC-RO2H-L-01



AEC951A



DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) REAR HO2S HEATER

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0689

| | |
|--|---|
| 1 | CHECK REAR HO2S POWER SUPPLY CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect corresponding rear heated oxygen sensor harness connector.</p> <div style="text-align: center;">  </div> <p>3. Turn ignition switch ON. 4. Check voltage between REAR HO2S terminal 3 and ground.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | |
| AEC645A | |
| SEF637W | |
| OK | ▶ GO TO 3. |
| NG | ▶ GO TO 2. |

| | |
|---|-----------------------------------|
| 2 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Fuse block (J/B) connector M26 ● 10A fuse ● Harness for open or short between rear heated oxygen sensor and fuse | |
| ▶ | Repair harness or connectors. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) REAR HO2S HEATER

VG33E

Diagnostic Procedure (Cont'd)

| 3 | CHECK REAR HO2S GROUND CIRCUIT FOR OPEN AND SHORT | | | | | | | | | | | | | | | | |
|--|--|----------|-------|-----|-----------|--|------|-----|--------|-------|-----|---|-------|-------|-----|---|------|
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal and REAR HO2S terminal as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0141</td> <td style="text-align: center;">122</td> <td style="text-align: center;">4</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0161</td> <td style="text-align: center;">123</td> <td style="text-align: center;">4</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> | | | | DTC | Terminals | | Bank | ECM | Sensor | P0141 | 122 | 4 | Right | P0161 | 123 | 4 | Left |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | | |
| P0141 | 122 | 4 | Right | | | | | | | | | | | | | | |
| P0161 | 123 | 4 | Left | | | | | | | | | | | | | | |
| AEC903A | | | | | | | | | | | | | | | | | |
| <p style="color: blue; margin-left: 40px;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 5. | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | | | | | | | | | |

| | | | |
|---|-----------------------------------|---|--|
| 4 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-3 ● Harness for open or short between rear heated oxygen sensor and engine ground. | | | |
| | | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P0141 (RIGHT, -B1), P0161 (LEFT, -B2) REAR HO2S HEATER

VG33E


Diagnostic Procedure (Cont'd)

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

5 CHECK REAR HEATED OXYGEN SENSOR HEATER

Check the following.

1. Check resistance between REAR HO2S terminals 2 and 3.



Resistance: 2.3 - 4.3Ω at 25°C (77°F)

2. Check continuity.

| Terminal No. | Continuity |
|---------------|------------|
| 1 and 2, 3, 4 | No |
| 4 and 1, 2, 3 | |

SEF716W

MTBL0233

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace malfunctioning front heated oxygen sensor. |

6 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

▶ **INSPECTION END**

DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensors. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).

NGEC0690

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------|--|------------------------|-----------|
| Front heated oxygen sensors | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | Fuel injection control | Injectors |

Malfunction is detected when fuel injection system does not operate properly, the amount of mixture ratio compensation is too large. (The mixture ratio is too lean.)

POSSIBLE CAUSE

- Intake air leaks
- Front heated oxygen sensor
- Injectors
- Exhaust gas leaks
- Incorrect fuel pressure
- Lack of fuel
- Mass air flow sensor

NGEC0690S01

DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

DTC Confirmation Procedure

4

| ACTIVE TEST | |
|---------------|-----------|
| SELF-LEARN | B1: 100 % |
| CONTROL | B2: 100% |
| MONITOR | |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 SEN-B2 | XXX V |
| A/F ALPHA-B1 | XXX % |
| A/F ALPHA-B2 | XXX % |

PEF717W

DTC Confirmation Procedure

=NGEC0691

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT-II.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT-II.
- 6) Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-864.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
- 8) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-864. If engine does not start, check exhaust and intake air leak visually.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

Wiring Diagram



Wiring Diagram

NGEC0692

NGEC0692S01

RIGHT BANK

EC-FUELRH-01



AEC952A








DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

Wiring Diagram (Cont'd)

LEFT BANK

NGEC0692S02



AEC953A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0693

| | | | |
|---|-------------------------------|--------------------|--|
| 1 | CHECK EXHAUST AIR LEAK | | |
| <p>1. Start engine and run it at idle. 2. Listen for an exhaust air leak before three way catalyst.</p> | | | |
|  | | | |
| SEF099P | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Repair or replace. | |

| | | | |
|---|----------------------------------|--------------------|--|
| 2 | CHECK FOR INTAKE AIR LEAK | | |
| Listen for an intake air leak after the mass air flow sensor. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Repair or replace. | |

| 3 | CHECK FRONT HEATED OXYGEN SENSOR CIRCUIT FOR OPEN AND SHORT | | | | | | | | | | | | | | | | |
|--|--|--|-------|-----|-----------|--|------|---------------|--------|-------|---------|--------|-------|-------|---------|--------|------|
| <p>1. Turn ignition switch OFF. 2. Disconnect corresponding front heated oxygen sensor harness connector. 3. Disconnect ECM harness connector. 4. Check harness continuity between ECM terminal and FRONT HO2S terminal as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0171</td> <td style="text-align: center;">50</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0174</td> <td style="text-align: center;">51</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> | | | | DTC | Terminals | | Bank | ECM | Sensor | P0171 | 50 | 2 | Right | P0174 | 51 | 2 | Left |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | | |
| P0171 | 50 | 2 | Right | | | | | | | | | | | | | | |
| P0174 | 51 | 2 | Left | | | | | | | | | | | | | | |
| AEC904A | | | | | | | | | | | | | | | | | |
| <p>Continuity should exist.</p> <p>5. Check harness continuity between ECM terminal or FRONT HO2S terminal and ground as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0171</td> <td style="text-align: center;">50 or 2</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Right</td> </tr> <tr> <td>P0174</td> <td style="text-align: center;">51 or 2</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Left</td> </tr> </tbody> </table> | | | | DTC | Terminals | | Bank | ECM or sensor | Ground | P0171 | 50 or 2 | Ground | Right | P0174 | 51 or 2 | Ground | Left |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | |
| | ECM or sensor | Ground | | | | | | | | | | | | | | | |
| P0171 | 50 or 2 | Ground | Right | | | | | | | | | | | | | | |
| P0174 | 51 or 2 | Ground | Left | | | | | | | | | | | | | | |
| AEC905A | | | | | | | | | | | | | | | | | |
| <p>Continuity should not exist.</p> <p>6. Also check harness for short to power.</p> | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | | | | | | | | | |

DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|----------------------------|----------|
| 4 | CHECK FUEL PRESSURE | |
| <p>1. Release fuel pressure to zero. Refer to EC-610.</p> <p>2. Install fuel pressure gauge and check fuel pressure.</p> <p style="margin-left: 20px;">At idling:</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm², 34 psi)</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm², 43 psi)</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |

GI
MA
EM
LC
EC

| | | |
|--|-----------------------------------|--------------------|
| 5 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuel pump and circuit (Refer to EC-1153.) ● Fuel pressure regulator (Refer to EC-611.) ● Fuel lines (Refer to "ENGINE MAINTENANCE", MA-29.) ● Fuel filter for clogging | | |
| ▶ | | Repair or replace. |

FE
CL
MT

| | | |
|---|-----------------------------------|--|
| 6 | CHECK MASS AIR FLOW SENSOR | |
| <p> With CONSULT-II</p> <p>1. Install all parts removed.</p> <p>2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.</p> <p style="margin-left: 20px;">3.3 - 4.8 g-m/sec: at idling</p> <p style="margin-left: 20px;">12.0 - 14.9 g-m/sec: at 2,500 rpm</p> | | |
| <p> With GST</p> <p>1. Install all parts removed.</p> <p>2. Check mass air flow sensor signal in MODE 1 with GST.</p> <p style="margin-left: 20px;">3.3 - 4.8 g-m/sec: at idling</p> <p style="margin-left: 20px;">12.0 - 14.9 g-m/sec: at 2,500 rpm</p> | | |
| <p> No Tools</p> <p>1. Install all parts removed.</p> <p>2. Check voltage between ECM terminal 54 and ground.</p> <p style="margin-left: 20px;">1.0 - 1.7V: at idling</p> <p style="margin-left: 20px;">1.7 - 2.3V: at 2,500 rpm</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-713. |

AT
TF
PD
AX
SU
BR
ST
RS

BT
HA
SC
EL
IDX

DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

Diagnostic Procedure (Cont'd)

7 CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.


| ACTIVE TEST | |
|---------------|---------|
| POWER BALANCE | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| IACV-AAC/V | XXX % |
| | |
| | |
| | |
| | |

PEF389V

3. Make sure that each circuit produces a momentary engine speed drop.

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.



MEC703B

Clicking noise should be heard.

OK or NG


OK ► GO TO 8.

NG ► Perform trouble diagnosis for "INJECTORS", EC-1145.

DTC P0171 (RIGHT, -B1), P0174 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|-----------------------|--|
| 8 | CHECK INJECTOR | |
| <ol style="list-style-type: none"> 1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle. 2. Turn ignition switch OFF. 3. Disconnect injector harness connectors on left bank (for DTC P0171), right bank (for DTC P0174). 4. Remove injector gallery assembly. Refer to EC-611. Keep fuel hose and all injectors connected to injector gallery. The injector harness connectors on right bank (for DTC P0171), left bank (for DTC P0174) should remain connected. 5. Disconnect all ignition coil harness connectors. 6. Prepare pans or saucers under each injector. 7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors. | | |
|  | | |
| <p style="color: blue;">Fuel should be sprayed evenly for each injector.</p> | | |
| SEF595Q | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace injectors from which fuel does not spray out. Always replace O-ring with new ones. |

| | | |
|---|------------------------------------|-----------------------|
| 9 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| ▶ | | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0172 (RIGHT, -B1), P0175 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (RICH)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0694

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensors. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------|--|------------------------|-----------|
| Front heated oxygen sensors | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | Fuel injection control | Injectors |

Malfunction is detected when fuel injection system does not operate properly, the amount of mixture ratio compensation is too large. (The mixture ratio is too rich.)

POSSIBLE CAUSE

NGEC0694S01

- Front heated oxygen sensor
- Injectors
- Exhaust gas leaks
- Incorrect fuel pressure
- Mass air flow sensor

DTC P0172 (RIGHT, -B1), P0175 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (RICH)

VG33E

DTC Confirmation Procedure

4

| ACTIVE TEST | |
|---------------|-----------|
| SELF-LEARN | B1: 100 % |
| CONTROL | B2: 100% |
| MONITOR | |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 SEN-B2 | XXX V |
| A/F ALPHA-B1 | XXX % |
| A/F ALPHA-B2 | XXX % |

PEF717W

DTC Confirmation Procedure

=NGEC0695

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT-II.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT-II.
- 6) Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172, P0175 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-872.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
- 8) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-872. If engine does not start, remove ignition plugs and check for fouling, etc.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P0172 (RIGHT, -B1), P0175 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (RICH)

VG33E


Wiring Diagram (Cont'd)

LEFT BANK


NGEC0696S02



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST



RS
BT
HA



SC
EL


DTC P0172 (RIGHT, -B1), P0175 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (RICH)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0697

| | | | |
|---|-------------------------------|--------------------|--|
| 1 | CHECK EXHAUST AIR LEAK | | |
| <p>1. Start engine and run it at idle. 2. Listen for an exhaust air leak before three way catalyst.</p> | | | |
|  | | | |
| SEF099P | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Repair or replace. | |

| | | | |
|---|----------------------------------|--------------------|--|
| 2 | CHECK FOR INTAKE AIR LEAK | | |
| Listen for an intake air leak after the mass air flow sensor. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Repair or replace. | |

| 3 | CHECK FRONT HEATED OXYGEN SENSOR CIRCUIT FOR OPEN AND SHORT | | | | | | | | | | | | | | | | |
|--|--|--|-------|-----|-----------|--|------|---------------|--------|-------|---------|--------|-------|-------|---------|--------|------|
| <p>1. Turn ignition switch OFF. 2. Disconnect corresponding front heated oxygen sensor harness connector. 3. Disconnect ECM harness connector. 4. Check harness continuity between ECM terminal and FRONT HO2S terminal as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0172</td> <td>50</td> <td>2</td> <td>Right</td> </tr> <tr> <td>P0175</td> <td>51</td> <td>2</td> <td>Left</td> </tr> </tbody> </table> | | | | DTC | Terminals | | Bank | ECM | Sensor | P0172 | 50 | 2 | Right | P0175 | 51 | 2 | Left |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | |
| | ECM | Sensor | | | | | | | | | | | | | | | |
| P0172 | 50 | 2 | Right | | | | | | | | | | | | | | |
| P0175 | 51 | 2 | Left | | | | | | | | | | | | | | |
| AEC906A | | | | | | | | | | | | | | | | | |
| <p>Continuity should exist.</p> <p>5. Check harness continuity between ECM terminal or FRONT HO2S terminal and ground as follows. Refer to Wiring Diagram.</p> | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0172</td> <td>50 or 2</td> <td>Ground</td> <td>Right</td> </tr> <tr> <td>P0175</td> <td>51 or 2</td> <td>Ground</td> <td>Left</td> </tr> </tbody> </table> | | | | DTC | Terminals | | Bank | ECM or sensor | Ground | P0172 | 50 or 2 | Ground | Right | P0175 | 51 or 2 | Ground | Left |
| DTC | Terminals | | Bank | | | | | | | | | | | | | | |
| | ECM or sensor | Ground | | | | | | | | | | | | | | | |
| P0172 | 50 or 2 | Ground | Right | | | | | | | | | | | | | | |
| P0175 | 51 or 2 | Ground | Left | | | | | | | | | | | | | | |
| AEC907A | | | | | | | | | | | | | | | | | |
| <p>Continuity should not exist.</p> <p>6. Also check harness for short to power.</p> | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | | | | | | | | | | | | | | |

DTC P0172 (RIGHT, -B1), P0175 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (RICH)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|----------------------------|----------|
| 4 | CHECK FUEL PRESSURE | |
| <p>1. Release fuel pressure to zero. Refer to EC-610.</p> <p>2. Install fuel pressure gauge and check fuel pressure.</p> <p style="margin-left: 20px;">At idling:</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm², 34 psi)</p> <p style="margin-left: 40px;">When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm², 43 psi)</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |

| | | |
|---|-----------------------------------|--------------------|
| 5 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuel pump and circuit (Refer to EC-1153.) ● Fuel pressure regulator (Refer to EC-611.) | | |
| ▶ | | Repair or replace. |


| | | |
|---|-----------------------------------|--|
| 6 | CHECK MASS AIR FLOW SENSOR | |
| <p> With CONSULT-II</p> <p>1. Install all parts removed.</p> <p>2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.</p> <p style="margin-left: 20px;">3.3 - 4.8 g-m/sec: at idling</p> <p style="margin-left: 20px;">12.0 - 14.9 g-m/sec: at 2,500 rpm</p> | | |
| <p> With GST</p> <p>1. Install all parts removed.</p> <p>2. Check mass air flow sensor signal in MODE 1 with GST.</p> <p style="margin-left: 20px;">3.3 - 4.8 g-m/sec: at idling</p> <p style="margin-left: 20px;">12.0 - 14.9 g-m/sec: at 2,500 rpm</p> | | |
| <p> No Tools</p> <p>1. Install all parts removed.</p> <p>2. Check voltage between ECM terminal 54 and ground.</p> <p style="margin-left: 20px;">1.0 - 1.7V: at idling</p> <p style="margin-left: 20px;">1.7 - 2.3V: at 2,500 rpm</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-713. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0172 (RIGHT, -B1), P0175 (LEFT, -B2) FUEL INJECTION SYSTEM FUNCTION (RICH)



VG33E

Diagnostic Procedure (Cont'd)

| 7 | CHECK FUNCTION OF INJECTORS | | | | | | | | | | | | | | | | | | | | |
|---|---|-------------|--|---------------|--|---------|--|---------------|---------|---------------|-------|------------|-------|--|--|--|--|--|--|--|--|
| <p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> Start engine. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II. | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><th colspan="2">POWER BALANCE</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS~RPM(REF)</td><td>XXX rpm</td></tr> <tr><td>MAS AIR/FL SE</td><td>XXX V</td></tr> <tr><td>IACV-AAC/V</td><td>XXX %</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> | | ACTIVE TEST | | POWER BALANCE | | MONITOR | | CMPS~RPM(REF) | XXX rpm | MAS AIR/FL SE | XXX V | IACV-AAC/V | XXX % | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| POWER BALANCE | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| MAS AIR/FL SE | XXX V | | | | | | | | | | | | | | | | | | | | |
| IACV-AAC/V | XXX % | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| PEF389V | | | | | | | | | | | | | | | | | | | | | |
| <ol style="list-style-type: none"> Make sure that each circuit produces a momentary engine speed drop. | | | | | | | | | | | | | | | | | | | | | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> Start engine. Listen to each injector operating sound. | | | | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | | | |
| <p style="color: blue;">Clicking noise should be heard.</p> | | | | | | | | | | | | | | | | | | | | | |
| <p>OK or NG</p> | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ GO TO 8. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ Perform trouble diagnosis for "INJECTORS", EC-1145. | | | | | | | | | | | | | | | | | | | | |

| | |
|---|--|
| 8 | CHECK INJECTOR |
| <ol style="list-style-type: none"> Remove injector assembly. Refer to EC-611. Keep fuel hose and all injectors connected to injector gallery. Confirm that the engine is cooled down and there are no fire hazards near the vehicle. Disconnect injector harness connectors left bank (for DTC P0172), right bank (for P0175). The injector harness connectors on right bank (for P0172), left bank (for P0175) should remain connected. Disconnect all ignition coil harness connectors. Prepare pans or saucers under each injectors. Crank engine for about 3 seconds. Make sure fuel does not drip from injector. | |
| <p>OK or NG</p> | |
| OK (Does not drip) | ▶ GO TO 9. |
| NG (Drips) | ▶ Replace the injectors from which fuel is dripping. Always replace O-ring with new one. |

| | |
|---|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |



Component Description

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

| Fluid temperature °C (°F) | Voltage* (V) | Resistance (kΩ) |
|---------------------------|--------------|-----------------|
| 20 (68) | 3.5 | 2.3 - 2.7 |
| 50 (122) | 2.2 | 0.79 - 0.90 |

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ECM terminal 32 (ECM ground).

On Board Diagnosis Logic

Malfunction is detected when an excessively high or low voltage is sent to ECM, rationally incorrect voltage is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor.

POSSIBLE CAUSE

- Harness or connectors (The sensor circuit is open or shorted.)
- Tank fuel temperature sensor

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC Confirmation Procedure

=NGEC0700

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | INT/A TEMP/S | XXX °C |

PEF609W

 **With CONSULT-II**

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 10 seconds.
If the result is NG, go to "Diagnostic Procedure", EC-878.
If the result is OK, go to following step.
- 4) Check "COOLAN TEMP/S" value.
If "COOLAN TEMP/S" is less than 60°C (140°F), the result will be OK.
If "COOLAN TEMP/S" is above 60°C (140°F), go to the following step.
- 5) Cool engine down until "COOLAN TEMP/S" is less than 60°C (140°F).
- 6) Wait at least 10 seconds.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-878.

 **With GST**

Follow the procedure "With CONSULT-II".

DTC P0180 FUEL TANK TEMPERATURE SENSOR


VG33E

Wiring Diagram

Wiring Diagram

NGEC0701





EC-TFTS-01



: Detectable line for DTC
 : Non-detectable line for DTC

- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST



- RS
- BT
- HA
- SC
- EL
- IDX



AEC954A

Diagnostic Procedure

NGEC0702

| | | | | | | | | |
|---|--|----------|----|---|----------|----|---|----------|
| 1 | CHECK FUEL TANK TEMPERATURE SENSOR POWER SUPPLY CIRCUIT | | | | | | | |
| <p>1. Turn ignition switch OFF. 2. Disconnect fuel tank gauge unit harness connector.</p> <div style="text-align: center;">  <p>Fuel tank gauge unit harness connector</p> <p>Front</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 3.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table> | | | OK | ▶ | GO TO 3. | NG | ▶ | GO TO 2. |
| OK | ▶ | GO TO 3. | | | | | | |
| NG | ▶ | GO TO 2. | | | | | | |

AEC933A

SEF639W

| | | |
|---|-----------------------------------|------------------------------|
| 2 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C1, M67 ● Harness connectors M81, F36 ● Harness for open or short between ECM and fuel tank temperature sensor | | |
| ▶ | | Repair harness or connector. |


| | | | | | | | | |
|--|---|----------|----|---|----------|----|---|----------|
| 3 | CHECK FUEL TANK TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT | | | | | | | |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between sensor terminal 4 and body ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table> | | | OK | ▶ | GO TO 5. | NG | ▶ | GO TO 4. |
| OK | ▶ | GO TO 5. | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |

DTC P0180 FUEL TANK TEMPERATURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors C1, M67 ● Harness for open or short between fue tank temperature sensor and body ground | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 5 | CHECK FUEL TANK TEMPERATURE SENSOR | | | | | | |
|--|---|---------------------|---------------|---------|-----------|----------|-------------|
| Check resistance by heating with hot water or heat gun as shown in the figure. | | | | | | | |
|  | | | | | | | |
| SEF641W | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Temperature °C (°F)</th> <th style="padding: 5px;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 5px;">20 (68)</td> <td style="text-align: center; padding: 5px;">2.3 - 2.7</td> </tr> <tr> <td style="text-align: center; padding: 5px;">50 (122)</td> <td style="text-align: center; padding: 5px;">0.79 - 0.90</td> </tr> </tbody> </table> | | Temperature °C (°F) | Resistance kΩ | 20 (68) | 2.3 - 2.7 | 50 (122) | 0.79 - 0.90 |
| Temperature °C (°F) | Resistance kΩ | | | | | | |
| 20 (68) | 2.3 - 2.7 | | | | | | |
| 50 (122) | 0.79 - 0.90 | | | | | | |
| MTBL0234 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ GO TO 6. | | | | | | |
| NG | ▶ Replace tank fuel temperature sensor. | | | | | | |

| | |
|---|------------------------------------|
| 6 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

On Board Diagnosis Logic


On Board Diagnosis Logic

NGEC0703

This diagnosis checks whether the engine coolant temperature is extraordinarily high, even though the driving condition is not high load.

When malfunction is detected, the malfunction indicator lamp (MIL) will light up even in the first trip.

| Diagnostic Trouble | Malfunction is detected when... | Check Items |
|--------------------|---|---|
| P0217 | Engine coolant temperature is excessively high under normal engine speed. | <ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted) ● Cooling fan ● Thermostat ● Improper ignition timing ● Engine coolant temperature sensor ● Blocked radiator ● Blocked front end (Improper fitting of front end cover) ● Crushed vehicle frontal area (Vehicle frontal area has been damaged from a collision but not repaired) ● Blocked air passage by improper installation of front fog lamp or fog lamps. ● Improper mixture ratio of coolant ● Damaged bumper <p>For more information, refer to "Main 12 Causes of Overheating", EC-892.</p> |



SEF666W


Overall Function Check

Use this procedure to check the overall function of the engine coolant over temperature enrichment protection check, a DTC might not be confirmed. =NGEC0704

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high-pressure fluid escaping from the radiator.

Wrap a thick cloth around the cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.



Ⓜ WITH CONSULT-II

1. Check the coolant level and mixture ratio (Using coolant tester) in the reservoir tank and radiator. NGEC0704S01

Allow engine to cool before checking coolant level and mixture ratio.

- If the coolant level in the reservoir and/or the radiator is below the proper range, skip following steps and go to "Diagnostic Procedure", EC-885.
- If the coolant mixture ratio is out of range between 45 to 55%, replace the coolant. Refer to "Changing Engine Coolant", **MA-27**.

- a) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to "Anti-freeze Coolant Mixture Ratio", **MA-16**.
 - b) After refilling coolant, run engine to ensure that no water-flow noise is emitted. After checking or replacing coolant, go to step 3) below.
2. Confirm whether customer filled the engine coolant or not. If customer filled the engine coolant, skip following steps and go to "Diagnostic Procedure", EC-885.
 3. Turn ignition switch ON.

| | | |
|----------|--------------------|----------|
| 4 | ACTIVE TEST | |
| | COOLANT TEMP | 95° C |
| | MONITOR | |
| | CMPS~RPM(POS) | XXX rpm |
| | INJ PULSE-B1 | XXX msec |
| | IGN TIMING | XXX BTDC |
| | | |

SEF383X

4. Perform "COOLANT TEMP" in "ACTIVE TEST" mode with CONSULT-II.

- 1) Set "COOLANT TEMP" to 95°C (194°F) and make sure that cooling fan operates at low speed. If NG, go to "Diagnostic Procedure", EC-885.
- 2) Set "COOLANT TEMP" to 105°C (221°F) and make sure that cooling fan operates at high speed. If NG, go to "Diagnostic Procedure", EC-885. After repair, go to next step.

5. Check for blocked coolant passage.
Warm up engine to normal operating temperature, then grasp upper and lower radiator hoses and make sure that coolant flows.

If NG, go to step 6 of "Diagnostic Procedure", EC-885. After repair, go to next step.

Be extremely careful not to touch any moving or adjacent parts.

6. Check radiator for blocked air passage
Check for blocked condenser or radiator (condenser or radiator fins damaged, condenser or radiator clogged), after market fog lamps ...etc. Check for condenser or radiator fin damage, shroud damage, vehicle front end for clogging of debris or insects ...etc.

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION


VG33E

Overall Function Check (Cont'd)


Check for improper fitting of front end cover, damaged radiator grille or bumper, vehicle frontal area damaged by collision but not repaired.

If NG, take appropriate action and then go to next step.

7. Check ECT sensor for proper operation. Refer to step 7 of "Diagnostic Procedure", EC-885. If NG, replace ECT sensor and go to next step.



8. Check ignition timing. Refer to "Basic Inspection", EC-669. Make sure that ignition timing is $15^\circ \pm 2^\circ$ at 700 ± 50 rpm. If NG, adjust ignition timing and then recheck.



⊗ WITHOUT CONSULT-II


NGEC0704S02

1. Check the coolant level and mixture ratio (Using coolant tester) in the reservoir tank and radiator.
Allow engine to cool before checking coolant level and mixture ratio.
 - If the coolant level in the reservoir and/or radiator is below the proper range, skip the following steps and go to step 3 of "Diagnostic Procedure", EC-885.
 - If the coolant mixture ratio is out of range between 45 to 55%, replace the coolant. Refer to "Changing Engine Coolant", **MA-27**.
- a) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to "Anti-freeze Coolant Mixture Ratio", **MA-16**.
- b) After refilling coolant, run engine to ensure that no water-flow noise is emitted. After checking or replacing coolant, go to step 3) below.
2. Confirm whether customer filled the engine coolant or not. If customer filled engine coolant, skip following steps and go to "Diagnostic Procedure", EC-885.
3. Turn ignition switch OFF.
4. Disconnect engine coolant temperature sensor harness connector.


DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Overall Function Check (Cont'd)



5. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
6. Start engine and make sure that cooling fan operates.
Be careful not to overheat engine.
If NG, go to step 9 of "Diagnostic Procedure", EC-885. After repair, go to next step.
7. Check for blocked coolant passage.
Warm up engine to normal operating temperature, then grasp upper and lower radiator hoses and make sure that coolant flows.
If NG, go to step 6 of "Diagnostic Procedure", EC-885. After repair, go to next step.
Be extremely careful not to touch any moving or adjacent parts.
8. Check radiator for blocked air passage
Check for blocked condenser or radiator (condenser or radiator fins damaged, condenser or radiator clogged), after market fog lamps,...etc. Check for condenser or radiator fin damage, shroud damage, vehicle front end for clogging of debris or insects ...etc.
Check for improper fitting of front end cover, damaged radiator grille or bumper, vehicle frontal area damaged by collision but not repaired.
If NG, take appropriate action and then go to next step.
9. Check ECT sensor for proper operation. Refer to step 6 of "Diagnostic Procedure", EC-885. If NG, replace ECT sensor and go to next step.



10. Check ignition timing. Refer to "Basic Inspection", EC-669. Make sure that ignition timing is $15^\circ \pm 2^\circ$ at 700 ± 50 rpm. If NG, adjust ignition timing and then recheck.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION


VG33E

Wiring Diagram



Wiring Diagram

NGEC0705

EC-COOL/F-01



Refer to the following.
 (M65), (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)



AEC973A

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0706

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

GI
MA
EM

| 2 | CHECK COOLING FAN OPERATION | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|------------------------------------|----------|-------------|--|-------------|-----|---------|--|----------------|--------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| <p> With CONSULT-II</p> <p>1. Turn ignition switch ON.</p> <p>2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II (Low speed).</p> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>COOLING FAN</th> <th>OFF</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>COOLANT TEMP/S</th> <th>XXX °C</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> | | | ACTIVE TEST | | COOLING FAN | OFF | MONITOR | | COOLANT TEMP/S | XXX °C | | | | | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | |
| COOLING FAN | OFF | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | |
| COOLANT TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Does cooling fan rotate?</p> <p style="text-align: center;">Yes or No</p> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Yes | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | | | | | |
| No | ▶ | GO TO 9. | | | | | | | | | | | | | | | | | | | | | | | | |

LC
EC
FE
CL
MT
AT

SEF376X

| | | |
|---|------------------------------------|----------|
| 3 | CHECK COOLING FAN OPERATION | |
| <p> Without CONSULT-II</p> <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect engine coolant temperature sensor harness connector.</p> <p>3. Connect 150Ω resistor to engine coolant temperature sensor harness connector.</p> <p>4. Start engine and make sure that cooling fan operates.</p> | | |
| | | |
| <p>OK or NG</p> | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 9. |

AX
SU
BR
ST
RS
BT
HA
SC


SEF085T


EL
IDX

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|--------------------------------------|--|
| 4 | CHECK COOLING SYSTEM FOR LEAK | |
| <p>Apply pressure to the cooling system with a tester, and check if the pressure drops.</p> <p>CAUTION: Higher than the specified pressure may cause radiator damage.</p> <p style="color: blue;">Testing pressure: 157 kPa (1.6 kg/cm², 23 psi)</p> | | |
|  | | |
| SLC754A | | |
| <p>Pressure should not drop.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | <p>Check the following for leak:</p> <ul style="list-style-type: none"> ● Hose ● Radiator ● Water pump <p>Refer to "Water Pump", LC-12.</p> |

| | | |
|---|---------------------------|-----------------------|
| 5 | CHECK RADIATOR CAP | |
| <p>Apply pressure to cap with a tester and check radiator cap relief pressure.</p> | | |
|  | | |
| SLC755A | | |
| <p style="color: blue;">Radiator cap relief pressure: 59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace radiator cap. |


DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Diagnostic Procedure (Cont'd)

6 CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures.
It should seat tightly.
2. Check valve opening temperature and valve lift.



Valve opening temperature:
82°C (170°F) [standard]

Valve lift:
More than 10 mm/95°C (0.31 in/194°F)

3. Check if valve is closed at 5°C (9°F) below valve opening temperature.
For details, refer to "Thermostat", **LC-13**.

OK or NG

SLC343

| | | |
|----|---|---------------------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace thermostat. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Diagnostic Procedure (Cont'd)

7 CHECK ENGINE COOLANT TEMPERATURE SENSOR


Check resistance as shown in the figure.



<Reference data>

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.1 - 2.9 |
| 50 (122) | 0.68 - 1.00 |
| 90 (194) | 0.236 - 0.260 |

SEF152P



MTBL0229

SEF012P

OK or NG

OK ▶ GO TO 8.

NG ▶ Replace engine coolant temperature sensor.

8 CHECK MAIN 12 CAUSES



If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-892.

▶ **INSPECTION END**

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Diagnostic Procedure (Cont'd)

| | | | |
|--|---|-----------|--|
| 9 | CHECK COOLING FAN RELAY POWER SUPPLY CIRCUIT | | |
| <p>1. Turn ignition switch OFF. 2. Disconnect cooling fan relay.</p> <div style="text-align: center;">  </div> | | | |
| <p>3. Turn ignition switch ON. 4. Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> | | | |
| AEC932A | | | |
| <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | | | |
| OK | ▶ | GO TO 11. | |
| NG | ▶ | GO TO 10. | |


| | | | |
|---|-----------------------------------|--|--|
| 10 | DETECT MALFUNCTIONING PART | | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuse block (J/B) connector E49 ● 10A fuse ● 40A fusible link ● Harness for open or short between cooling fan relay and fuse ● Harness for open or short between cooling fan relay and battery | | | |
| Repair open circuit or short to ground or short to power in harness or connectors. | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|---|--|
| 11 | CHECK COOLING FAN MOTOR POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect cooling fan motor harness connector.</p> <div style="text-align: center;">  <p style="text-align: center; margin-top: -10px;">Cooling fan motor</p> </div> <p style="text-align: right; margin-right: 20px;">AEC931A</p> <p>3. Check harness continuity between relay terminal 3 and motor terminal 2, motor terminals 3, 4 and body ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 12. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |



| | | |
|---|---|-----------|
| 12 | CHECK COOLING FAN RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 36 and relay terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | GO TO 13. |

| | | |
|---|-----------------------------------|--|
| 13 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M58, F28 ● Harness for open or short between cooling fan relay and ECM | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |


DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Diagnostic Procedure (Cont'd)

| 14 | CHECK COOLING FAN RELAY | | | | | | |
|--|--------------------------------|------------|------------|---|-----|-------------------|----|
| <p>Check continuity between terminals 3 and 5.</p> <div style="display: flex; justify-content: center; gap: 20px;">   </div> | | | | | | | |
| SEF511P | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Conditions</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>No current supply</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | Conditions | Continuity | 12V direct current supply between terminals 1 and 2 | Yes | No current supply | No |
| Conditions | Continuity | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | | | | | | |
| No current supply | No | | | | | | |
| MTBL0252 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ GO TO 15. | | | | | | |
| NG | ▶ Replace cooling fan relay. | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| 15 | CHECK COOLING FAN MOTOR | | | | | | | | |
|--|--------------------------------|------|-----------|--|-----|-----|-------------------|---|------|
| <p>1. Disconnect cooling fan motor harness connector. 2. Supply cooling fan motor terminals with battery voltage and check operation.</p> | | | | | | | | | |
| MTBL0253 | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Cooling fan motor</td> <td style="text-align: center;">2</td> <td style="text-align: center;">3, 4</td> </tr> </tbody> </table> | | | Terminals | | (+) | (-) | Cooling fan motor | 2 | 3, 4 |
| | Terminals | | | | | | | | |
| | (+) | (-) | | | | | | | |
| Cooling fan motor | 2 | 3, 4 | | | | | | | |
|  | | | | | | | | | |
| SEF670W | | | | | | | | | |
| <p>Cooling fan motor should operate.</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | | |
| OK | ▶ GO TO 16. | | | | | | | | |
| NG | ▶ Replace cooling fan motor. | | | | | | | | |

| | |
|---|------------------------------------|
| 16 | CHECK INTERMITTENT INCIDENT |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.</p> | |
| ▶ | INSPECTION END |

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

VG33E

Main 12 Causes of Overheating

Main 12 Causes of Overheating

NGEC0707

| Engine | Step | Inspection item | Equipment | Standard | Reference page |
|--------|------|--|--|--|---|
| OFF | 1 | <ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper | ● Visual | No blocking | — |
| | 2 | ● Coolant mixture | ● Coolant tester | 50 - 50% coolant mixture | See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA-14 . |
| | 3 | ● Coolant level | ● Visual | Coolant up to MAX level in reservoir tank and radiator filler neck | See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA-27 . |
| | 4 | ● Radiator cap | ● Pressure tester | 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit) | See "System Check", "ENGINE COOLING SYSTEM" in LC-11 . |
| ON*2 | 5 | ● Coolant leaks | ● Visual | No leaks | See "System Check", "ENGINE COOLING SYSTEM" in LC-11 . |
| ON*2 | 6 | ● Thermostat | ● Touch the upper and lower radiator hoses | Both hoses should be hot | See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC-13, LC-14 . |
| ON*1 | 7 | ● Cooling fan | ● CONSULT-II | Operating | See "TROUBLE DIAGNOSIS FOR OVERHEAT" (EC-1132). |
| OFF | 8 | ● Combustion gas leak | ● Color checker chemical tester 4 Gas analyzer | Negative | — |
| ON*3 | 9 | ● Coolant temperature gauge | ● Visual | Gauge less than 3/4 when driving | — |
| | | ● Coolant overflow to reservoir tank | ● Visual | No overflow during driving and idling | See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA-27 . |
| OFF*4 | 10 | ● Coolant return from reservoir tank to radiator | ● Visual | Should be initial level in reservoir tank | See "ENGINE MAINTENANCE" in MA-27 . |
| OFF | 11 | ● Cylinder head | ● Straight gauge feeler gauge | 0.1 mm (0.004 in) Maximum distortion (warping) | See "Inspection", "CYLINDER HEAD" in EM-88 . |
| | 12 | ● Cylinder block and pistons | ● Visual | No scuffing on cylinder walls or piston | See "Inspection", "CYLINDER BLOCK" in EM-104 . |

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS", **LC-34**.

On Board Diagnosis Logic

NGEC0708

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the CKP sensor signal to vary, ECM can determine that a misfire is occurring.

| Sensor | Input Signal to ECM | ECM function |
|----------------------------------|---------------------|-------------------------------|
| Crankshaft position sensor (OBD) | Engine speed | On board diagnosis of misfire |

The misfire detection logic consists of the following two conditions.

- 1. One Trip Detection Logic (Three Way Catalyst Damage)**
 On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MIL will blink. When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change. When the misfire condition decreases to a level that will not damage the TWC, the MIL will turn off. If another misfire condition occurs that can damage the TWC on a second trip, the MIL will blink. When the misfire condition decreases to a level that will not damage the TWC, the MIL will remain on. If another misfire condition occurs that can damage the TWC, the MIL will begin to blink again.
- 2. Two Trip Detection Logic (Exhaust quality deterioration)**
 For misfire conditions that will not damage the TWC (but will affect vehicle emission), the MIL will only light when the misfire is detected on a second trip. During this condition, ECM monitors the CKP sensor signal every 1000 revolutions. A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

Malfunction is detected when multiple cylinders misfire, No. 1 cylinder misfires, No. 2 cylinder misfires, No. 3 cylinder misfires, No. 4 cylinder misfires, No. 5 cylinder misfires and No. 6 cylinder misfires.

POSSIBLE CAUSE

NGEC0708S01

- Improper spark plug
- Insufficient compression
- Incorrect fuel pressure
- EGR valve
- The injector circuit is open or shorted
- Injectors
- Intake air leak
- The ignition secondary circuit is open or shorted
- Lack of fuel
- Drive plate
- Front heated oxygen sensor
- Incorrect distributor rotor

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E

DTC Confirmation Procedure

| | | |
|---------------|---------------------|----------|
| 4 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM (REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | VHCL SPEED SE | XXX km/h |
| | THRTL POS SEN | XXX V |
| CLSD THL/P SW | OFF | |
| P/N POSI SW | OFF | |

PEF869U

DTC Confirmation Procedure

=NGEC0709

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Turn ignition switch ON, and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Turn ignition switch OFF and wait at least 5 seconds.
- 4) Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.

Hold the accelerator pedal as steady as possible.

NOTE:

Refer to the freeze frame data for the test driving conditions.

- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-894.

With GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

NGEC0710

| | | |
|--|----------------------------------|--|
| 1 | CHECK FOR INTAKE AIR LEAK | |
| 1. Start engine and run it at idle speed. 2. Listen for the sound of the intake air leak. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Discover air leak location and repair. |

| | | |
|--|--|-----------------------|
| 2 | CHECK FOR EXHAUST SYSTEM CLOGGING | |
| Stop engine and visually check exhaust tube, three way catalyst and muffler for dents. | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace it. |

| | | |
|--|---------------------------|--------------------|
| 3 | CHECK EGR FUNCTION | |
| Perform "DTC Confirmation Procedure" of "DTC P1402 EGR FUNCTION (OPEN)". Refer to EC-1056. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair EGR system. |

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E

Diagnostic Procedure (Cont'd)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

4 PERFORM POWER BALANCE TEST

With CONSULT-II

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.


| ACTIVE TEST | |
|---------------|---------|
| POWER BALANCE | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| IACV-AAC/V | XXX % |
| | |
| | |
| | |
| | |
| | |

PEF389V

2. Is there any cylinder which does not produce a momentary engine speed drop?

Without CONSULT-II

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?




AEC646A

Yes or No

| | | |
|-----|---|----------|
| Yes | ▶ | GO TO 5. |
| No | ▶ | GO TO 8. |

5 CHECK INJECTOR

Does each injector make an operating sound at idle?



MEC703B


Yes or No


| | | |
|-----|---|---|
| Yes | ▶ | GO TO 6. |
| No | ▶ | Check injector(s) and circuit(s). Refer to EC-1145. |

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E

Diagnostic Procedure (Cont'd)


| | | |
|---|-----------------------------|----------|
| 6 | CHECK IGNITION SPARK | |
| <ol style="list-style-type: none"> 1. Disconnect ignition wire from spark plug. 2. Connect a known good spark plug to the ignition wire. 3. Place end of spark plug against a suitable ground and crank engine. 4. Check for spark. | | |
|  | | |
| SEF282G | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

| 7 | CHECK IGNITION WIRES | | | | | | | | | | | | | | | |
|---|--------------------------------|--|--------------|--------------------------------|---|-------------------|---|--------------------|---|-------------------|---|--------------------|---|-------------------|---|--------------------|
| <ol style="list-style-type: none"> 1. Inspect wires for cracks, damage, burned terminals and for improper fit. 2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks. | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | |
| SEF174P | | | | | | | | | | | | | | | | |
| Resistance: | | | | | | | | | | | | | | | | |
| <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Cylinder No.</th> <th style="text-align: center;">Resistance kΩ [at 25°C (77°F)]</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Approximately 6.5</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Approximately 10.0</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Approximately 8.5</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">Approximately 12.5</td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">Approximately 8.5</td> </tr> <tr> <td style="text-align: center;">6</td> <td style="text-align: center;">Approximately 11.0</td> </tr> </tbody> </table> | | | Cylinder No. | Resistance kΩ [at 25°C (77°F)] | 1 | Approximately 6.5 | 2 | Approximately 10.0 | 3 | Approximately 8.5 | 4 | Approximately 12.5 | 5 | Approximately 8.5 | 6 | Approximately 11.0 |
| Cylinder No. | Resistance kΩ [at 25°C (77°F)] | | | | | | | | | | | | | | | |
| 1 | Approximately 6.5 | | | | | | | | | | | | | | | |
| 2 | Approximately 10.0 | | | | | | | | | | | | | | | |
| 3 | Approximately 8.5 | | | | | | | | | | | | | | | |
| 4 | Approximately 12.5 | | | | | | | | | | | | | | | |
| 5 | Approximately 8.5 | | | | | | | | | | | | | | | |
| 6 | Approximately 11.0 | | | | | | | | | | | | | | | |
| MTBL0235 | | | | | | | | | | | | | | | | |
| <p>If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.</p> | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | |
| OK | ▶ | Check the following: <ul style="list-style-type: none"> ● Distributor rotor head for incorrect parts ● Ignition coil, power transistor and their circuits Refer to EC-1028. | | | | | | | | | | | | | | |
| NG | ▶ | Replace. | | | | | | | | | | | | | | |

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E


Diagnostic Procedure (Cont'd)

| | | |
|---|--------------------------|---|
| 8 | CHECK SPARK PLUGS | |
| Remove the spark plugs and check for fouling, etc. | | |
|  | | |
| SEF156I | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to "ENGINE MAINTENANCE", MA-31 . |

GI
MA
EM
LC
EC

| | | |
|--|-----------------------------------|---|
| 9 | CHECK COMPRESSION PRESSURE | |
| Refer to EM-70 . | | |
| <ul style="list-style-type: none"> Check compression pressure. <ul style="list-style-type: none"> Standard: 1,196 kPa (12.2 kg/cm², 173 psi)/300 rpm Minimum: 883 kPa (9.0 kg/cm², 128 psi)/300 rpm Difference between each cylinder: 98 kPa (1.0 kg/cm², 14 psi)/300 rpm | | |
| OK or NG | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | Check pistons, piston rings, valves, valve seats and cylinder head gaskets. |

FE
CL
MT
AT
TF
PD
AX

| | | |
|---|----------------------------|-----------|
| 10 | CHECK FUEL PRESSURE | |
| <ol style="list-style-type: none"> Install any parts removed. Release fuel pressure to zero. Refer to EC-610. Install fuel pressure gauge and check fuel pressure. | | |
|  | | |
| AEC064B | | |
| <p>At idle: Approx. 235 kPa (2.4 kg/cm², 34 psi)</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 12. |
| NG | ▶ | GO TO 11. |

SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|-----------------------------------|
| 11 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuel pump and circuit (Refer to EC-1153.) ● Fuel pressure regulator (Refer to EC-611.) ● Fuel lines (Refer to "ENGINE MAINTENANCE", <i>MA-28</i>.) ● Fuel filter for clogging | |
| | Repair or replace. |

| 12 | CHECK IGNITION TIMING | | | | | | | | | | |
|--|---|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|---|---|-------------------|---------------------------------------|
| <p>Check the following items. Refer to "Basic Inspection", EC-669.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Items</th> <th style="text-align: center;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>15° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>700 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0226</p> <p style="text-align: center;">OK or NG</p> | | Items | Specifications | Ignition timing | 15° ± 2° BTDC | Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | Target idle speed | 750 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | |
| Ignition timing | 15° ± 2° BTDC | | | | | | | | | | |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | | | | | | | | | | |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | |
| OK (With CONSULT-II) | GO TO 13. | | | | | | | | | | |
| OK (Without CONSULT-II) | GO TO 14. | | | | | | | | | | |
| NG | Adjust ignition timing. | | | | | | | | | | |

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E

Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

13 CHECK FRONT HEATED OXYGEN SENSOR LH/RH

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II, and select "FR O2 SEN-B1 (-B2)" and "FR O2 MNTR-B1 (-B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| MAS AIR/FL SE | XXX V |
| COOLAN TEMP/S | XXX °C |
| FR O2 SEN-B1 | XXX V |
| FR O2 MNTR-B1 | LEAN |
| INJ PULSE-B1 | XXX msec |
| A/F ALPHA-B1 | XXX % |
| FR O2 HTR-B1 | ON |

PEF365V

5. Check the following.

- "FR O2 MNTR-B1 (-B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown left:

Right bank

cycle | 1 | 2 | 3 | 4 | 5 |

FR O2 MNTR-B1 R-L-R-L-R-L-R-L-R-L-R

Left bank

cycle | 1 | 2 | 3 | 4 | 5 |


FR O2 MNTR-B2 R-L-R-L-R-L-R-L-R-L-R

R means FR O2 MNTR-B1(-B2) indicates RICH

L means FR O2 MNTR-B1(-B2) indicates LEAN

SEF702W

- "FR O2 SEN-B1 (-B2)" voltage goes above 0.6V at least once.
- "FR O2 SEN-B1 (-B2)" voltage goes below 0.3V at least once.
- "FR O2 SEN-B1 (-B2)" voltage never exceeds 1.0V.



• Maximum voltage should be over 0.6V at least one time.

• Minimum voltage should be below 0.3V at least one time.

SEF154X

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK ► GO TO 15.

NG ► Replace front heated oxygen sensor.

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|---|
| 14 | CHECK FRONT HEATED OXYGEN SENSOR LH/RH |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Set voltmeter probes between ECM terminal 50 (right bank sensor signal) or 51 (left bank sensor signal) and engine ground. 3. Check the following with engine speed held at 2,000 rpm constant under no load. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; margin-right: 20px;">SEF919U</p> <ul style="list-style-type: none"> ● MIL goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR). ● The maximum voltage is over 0.6V at least one time. ● The minimum voltage is below 0.3V at least one time. ● The voltage never exceeds 1.0V. <p>CAUTION:</p> <ul style="list-style-type: none"> ● Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. ● Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 15. |
| NG | ▶ Replace front heated oxygen sensor. |

| | |
|---|--|
| 15 | CHECK MASS AIR FLOW SENSOR |
| <p>Ⓜ With CONSULT-II</p> <p>Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II.</p> <p style="color: blue;">3.3 - 4.8 g·m/sec: at idling</p> <p style="color: blue;">12.0 - 14.9 g·m/sec: at 2,500 rpm</p> | |
| <p>Ⓜ With GST</p> <p>Check mass air flow sensor signal in MODE 1 with GST.</p> <p style="color: blue;">3.3 - 4.8 g·m/sec: at idling</p> <p style="color: blue;">12.0 - 14.9 g·m/sec: at 2,500 rpm</p> | |
| <p>Ⓜ No Tools</p> <p>Check voltage between ECM terminal 54 and ground.</p> <p style="color: blue;">1.0 - 1.7V: at idling</p> <p style="color: blue;">1.7 - 2.3V: at 2,500 rpm</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 16. |
| NG | ▶ Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-713. |

DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|-----------------------------------|--------------------|
| 16 | CHECK SYMPTOM MATRIX CHART | |
| Check items on the rough idle symptom in "Symptom Matrix Chart", EC-688. | | |
| OK or NG | | |
| OK | ▶ | GO TO 17. |
| NG | ▶ | Repair or replace. |

GI

MA

EM

| | | |
|---|-------------------------------|-----------|
| 17 | ERASE THE 1ST TRIP DTC | |
| Some tests may cause a 1st trip DTC to be set. Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to EC-640. | | |
| | ▶ | GO TO 18. |

LC

EC

| | | |
|---|------------------------------------|-----------------------|
| 18 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| | ▶ | INSPECTION END |

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Component Description



Component Description

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM. **Freeze frame data will not be stored in the ECM for the knock sensor. The MIL will not light for knock sensor malfunction. The knock sensor has one trip detection logic.**

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).


| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|--------------|-------------------------------------|--------------------|
| 64 | W | Knock sensor | [Engine is running] ● Idle speed | Approximately 2.5V |

On Board Diagnosis Logic

Malfunction is detected when an excessively low or high voltage from the knock sensor is sent to ECM.

POSSIBLE CAUSE

- Harness or connectors
(The knock sensor circuit is open or shorted.)
- Knock sensor



DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 5 seconds at idle speed.
- 3) If DTC is detected, go to "Diagnostic Procedure", EC-904.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P0325 KNOCK SENSOR (KS)

VG33E

Wiring Diagram

Wiring Diagram

NGEC0715

EC-KS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX



AEC955A


Diagnostic Procedure

NGEC0716


| | | |
|--|---|----------|
| 1 | CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I | |
| 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check resistance between ECM terminal 64 and engine ground. NOTE: It is necessary to use an ohmmeter which can measure more than 10 MΩ. Resistance: Approximately 500 - 620 kΩ [at 25°C (77°F)] | | |
| 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 2. |

| | | |
|---|--------------------------------------|----------|
| 2 | CHECK INPUT SIGNAL CIRCUIT-II | |
| 1. Disconnect knock sensor harness connector. 2. Check harness continuity between ECM terminal 64 and knock sensor terminal 1. Refer to Wiring Diagram. Continuity should exist. | | |
| 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 3. |

| | | |
|--|-----------------------------------|--|
| 3 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness connector F37, F101 ● Harness for open or short between ECM and knock sensor | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|--|---------------------------|-----------------------|
| 4 | CHECK KNOCK SENSOR | |
| <ul style="list-style-type: none"> ● Use an ohmmeter which can measure more than 10 MΩ. 1. Disconnect knock sensor harness connector. 2. Check resistance between terminal 2 and ground. | | |
|  | | |
| Resistance: 500 - 620 kΩ [at 25°C (77°F)] | | |
| CAUTION: | | |
| Do not use any knock sensors that have been dropped or physically damaged. Use only new ones. | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace knock sensor. |

SEF643W

| | |
|--|--------------------------------|
| 5 | RETIGHTEN GROUND SCREWS |
| Loose and retighten engine ground screws. | |
|  <p style="text-align: center;">Engine ground</p> | |
| AEC640A | |
| ▶ | GO TO 6. |

GI
MA
EM
LC
EC

| | |
|---|---|
| 6 | CHECK KNOCK SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT |
| 1. Disconnect harness connectors F37, F101. 2. Check harness continuity between harness connector F37 terminal 6 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 7. |

FE
CL
MT
AT

| | |
|--|--|
| 7 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors F37, F101 ● Joint connectors - 1 ● Harness for open or short between harness connector F37 and engine ground | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

TF
PD
AX

| | |
|---|------------------------------------|
| 8 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

SU
BR

ST

RS

BT

HA

SC



EL

IDX

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)

VG33E

Component Description



Component Description

NGEC0717

The crankshaft position sensor (OBD) is located on the transaxle housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.

ECM Terminals and Reference Value

NGEC0718

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (AC Voltage) |
|----------------------|---------------|----------------------------------|--|---|
| 47 | L | Crankshaft position sensor (OBD) | <p>[Engine is running]</p> <ul style="list-style-type: none"> • Warm-up condition • Idle speed | <p>1 - 2V (AC range)</p> <p>SEF690W</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> • Engine speed is 2,000 rpm | <p>3 - 4V (AC range)</p> <p>SEF691W</p> |

On Board Diagnosis Logic

Malfunction is detected when the proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed.

POSSIBLE CAUSE

- Harness or connectors
(The crankshaft position sensor (OBD) circuit is open.)
- Crankshaft position sensor (OBD)

| | | |
|---|-----------------------|---------|
| 2 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) XXX rpm | |

PEF357V

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 15 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-909.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) VG33E

Wiring Diagram

Wiring Diagram

NGEC0721


EC-CKPS-01




AEC956A

Diagnostic Procedure

NGEC0722

| | | | |
|----------|--------------------------------|--|---|
| 1 | RETIGHTEN GROUND SCREWS | <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Engine ground</p> </div> <p style="text-align: right;">AEC640A</p> | GI MA EM LC EC FE |
| ▶ | | GO TO 2. | |

| | | | |
|----------|---|--|--|
| 2 | CHECK CKPS (OBD) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | <p>1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.</p> <div style="text-align: center;">  <p>Rear heated oxygen sensor LH Crankshaft position sensor (OBD) Transmission Engine front</p> </div> <p style="text-align: right;">SEF997R</p> <p>2. Check continuity between ECM terminal 47 and sensor terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | MT AT TF PD AX SU BR |
| OK | | ▶ | GO TO 4. |
| NG | | ▶ | GO TO 3. |

| | | | |
|----------|-----------------------------------|--|----------------|
| 3 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F38, F102 ● Harness for open or short between ECM and crankshaft position sensor (OBD) | ST RS BT |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|---|
| 4 | CHECK CKPS (OBD) GROUND CIRCUIT FOR OPEN AND SHORT |
| 1. Reconnect ECM harness connector. 2. Check harness continuity between sensor terminal 1 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. | |
| OK or NG | |
| OK | ▶ GO TO 6. |
| NG | ▶ GO TO 5. |

| | |
|---|--|
| 5 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none">● Harness connectors F38, F102● Harness connectors F28, M58● Joint connector-4● Harness for open or short between crankshaft position sensor (OBD) and ECM● Harness for open or short between crankshaft position sensor (OBD) and TCM (Transmission Control Module) | |
| | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|---|
| 6 | CHECK CRANKSHAFT POSITION SENSOR (OBD) |
| 1. Disconnect crankshaft position sensor (OBD) harness connector. 2. Loosen the fixing bolt of the sensor. 3. Remove the sensor. 4. Visually check the sensor for chipping. | |
|  | |
| SEF960N | |
| 5. Check resistance as shown in the figure. | |
|  | |
| SEF504V | |
| Resistance: Approximately 512 - 632Ω [at 20°C (68°F)] | |
| OK or NG | |
| OK | ▶ GO TO 7. |
| NG | ▶ Replace crankshaft position sensor (OBD). |

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) VG33E

Diagnostic Procedure (Cont'd)



| | | |
|---|---|----------|
| 7 | CHECK CKPS (OBD) SHIELD CIRCUIT FOR OPEN AND SHORT | |
| 1. Disconnect harness connectors F38, F102. 2. Check harness continuity between harness connector F38 terminal 6 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | GO TO 8. |

| | | |
|---|-----------------------------------|--|
| 8 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors F38, F102 ● Joint connector-1 ● Harness for open or short between harness connector F38 and engine ground | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|---|------------------------------------|-----------------------|
| 9 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| ▶ | | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Component Description



Component Description

NGEC0723

The camshaft position sensor is a basic component of the engine control system. It monitors engine speed and piston position. These input signals to the ECM are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° (POS) signal and 6 slits for a 120° (REF) signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.

The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

NOTE:



The rotor screw which secures the distributor rotor head to the distributor shaft must be torqued properly.

: 3.6±0.3 N·m (37±3 kg-cm, 32±3 in-lb)

ECM Terminals and Reference Value

NGEC0724

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|---|---|---|
| 4 | OR/B | ECM relay (Self shut-off) | [Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF | 0 - 1.5V |
| | | | [Ignition switch OFF] ● A few seconds passed after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 44 | PU | Camshaft position sensor (Reference signal) | [Engine is running] ● Idle speed | 0.3 - 0.5V  |
| 48 | PU | | [Engine is running] ● Engine speed is 2,000 rpm | 0.3 - 0.5V  |

DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

VG33E

ECM Terminals and Reference Value (Cont'd)

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--|--|----------------------------|
| 49 | LG | Camshaft position sensor (Position signal) | [Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed | Approximately 2.5V |
| | | | [Engine is running] <ul style="list-style-type: none"> • Engine speed is 2,000 rpm | Approximately 2.5V |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 117 | B/P | Current return | [Engine is running] <ul style="list-style-type: none"> • Idle speed | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0725

Malfunction is detected when
 (Malfunction A) either 1° or 120° signal is not sent to ECM for the first few seconds during engine cranking,
 (Malfunction B) either 1° or 120° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed,
 (Malfunction C) the relation between 1° and 120° signal is not in the normal range during the specified engine speed.

POSSIBLE CAUSE

NGEC0725S01

- Harness or connectors (The camshaft position sensor circuit is open or shorted.)
- Camshaft position sensor
- Starter motor (Refer to **SC-6**.)
- Starting system circuit (Refer to **SC-6**.)
- Dead (Weak) battery

DTC Confirmation Procedure

NGEC0726

NOTE:

- Perform “PROCEDURE FOR MALFUNCTION A” first. If DTC cannot be confirmed, perform “PROCEDURE FOR MALFUNCTION B AND C”.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

PROCEDURE FOR MALFUNCTION A

NGEC0726S01

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Crank engine for at least 2 seconds.
- 4) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-916.

With GST

Follow the procedure “With CONSULT-II”.

| | | |
|----------|---------------------|----------------|
| 2 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | COOLAN TEMP/S | XXX °C |

PEF002P

| | | |
|----------|---------------------|----------------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

PROCEDURE FOR MALFUNCTION B AND C

NGEC0726S02

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-916.




With GST

Follow the procedure “With CONSULT-II”.

Wiring Diagram

NGEC0727

EC-CMPS-01






AEC957A

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Diagnostic Procedure

NGEC0728

| | |
|--|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws. | |
|  <p style="margin-left: 100px;">Engine ground</p> | |
| <small>AEC640A</small> | |
| ▶ GO TO 2. | |

| | |
|--|---|
| 2 | CHECK CMPS POWER SUPPLY CIRCUIT |
| <ol style="list-style-type: none"> 1. Disconnect camshaft position sensor harness connector. | |
|  <p style="margin-left: 300px;"><small>Distributor</small></p> <p style="margin-left: 350px;"><small>Camshaft position sensor harness connector</small></p> | |
| <small>AEC647A</small> | |
| <ol style="list-style-type: none"> 2. Turn ignition switch ON. 3. Check voltage between terminal 5 and ground with CONSULT or tester. | |
|  | |
| Voltage: Battery voltage | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ GO TO 3. |

| | |
|---|-----------------------------------|
| 3 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness for open or short between camshaft position sensor and ECM relay ● Harness for open or short between camshaft position sensor and ECM | |
| ▶ Repair harness or connectors. | |

DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|---|--|
| 4 | CHECK CMPS INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between sensor terminal 4 and ECM terminal 49, sensor terminal 3 and ECM terminals 44, 48. Refer to Wiring Diagram.</p> <p style="padding-left: 20px;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA
EM
LC

| | | |
|--|---|----------|
| 5 | CHECK CMPS GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF.</p> <p>2. Check harness continuity between sensor terminal 6 and engine ground.</p> <p style="padding-left: 20px;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |

EC
FE
CL
MT

| | | |
|---|-----------------------------------|---|
| 6 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-2 ● Harness for open or short between camshaft position sensor and engine ground | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connector. |

AT
TF

PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

VG33E

Diagnostic Procedure (Cont'd)

7 CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.



Terminal 44 or 48 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|------------|------------|
| Voltage | 0.3 - 0.5V | 0.3 - 0.5V |
| Pulse signal | | |

Terminal 49 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|--------------------|--------------------|
| Voltage | Approximately 2.5V | Approximately 2.5V |
| Pulse signal | | |

AEC072B

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace distributor assembly with camshaft position sensor. |

8 CHECK CMPS SHIELD CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect joint connector-1.
3. Check the following.
 - Continuity between joint connector terminal 1 and ground
 - Joint connector
(Refer to "HARNES LAYOUT", *EL-292*)

Continuity should exist.
4. Also check harness for short to ground and short to power.
5. Then reconnect joint connector-1.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 9. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

9 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

▶ INSPECTION END

DTC P0400 EGR FUNCTION (CLOSE)

VG33E

Description (If Equipped with EGR Valve)

Description (If Equipped with EGR Valve) SYSTEM DESCRIPTION


NGEC0729

NGEC0729S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|----------------------------|--------------|---------------------|
| Camshaft position sensor | Engine speed | EGR control | EGRC-solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |


This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current does not flow through the solenoid valve. This causes the intake manifold vacuum to be discharged into the atmosphere. The EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



SEF317U

Description (If Equipped with EGR Valve) (Cont'd)




COMPONENT DESCRIPTION

-NGEC0729S02

Exhaust Gas Recirculation (EGR) Valve

NGEC0729S0201


The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening and EGRC-BPT valve operation. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.



EGRC-solenoid Valve

NGEC0729S0202

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal (from the intake manifold collector to the EGR valve) passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal.



On Board Diagnosis Logic

NGEC0730

If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed. Malfunction is detected when no EGR flow is detected under condition that calls for EGR.

POSSIBLE CAUSE

NGEC0730S01

- EGR valve stuck closed
- EGRC-BPT valve
- Vacuum hoses
- EGRC-solenoid valve
- EGR passage
- EGR temperature sensor
- Exhaust gas leaks

NGENC0731

| | | |
|----------|------------------|----------|
| 5 | EGR SYSTEM P0400 | |
| | OUT OF CONDITION | |
| | MONITOR | |
| | CMPS~RPM(POS) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF603W

| | | |
|----------|------------------|----------|
| 8 | EGR SYSTEM P0400 | |
| | TESTING | |
| | MONITOR | |
| | CMPS~RPM(POS) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF604W

| | | |
|----------|------------------|--|
| 8 | EGR SYSTEM P0400 | |
| | COMPLETED | |

PEF785U

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- P0400 will not be displayed at "SELF-DIAG RESULTS" mode with CONSULT-II even though DTC work support test result is NG.

TESTING CONDITION:

For best results, perform the test at a temperature of 5°C (41°F) or higher.

⑧ With CONSULT-II

- 1) Turn ignition switch ON
- 2) Check "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
Confirm COOLAN TEMP/S value is within the range listed below.

COOLAN TEMP/S: Less than 40°C (104°F)

If the value is out of range, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to lower the engine coolant temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

- 3) Start engine and let it idle monitoring "COOLAN TEMP/S" value. When the "COOLAN TEMP/S" value reaches 70°C (158°F), immediately go to the next step.
- 4) Select "EGR SYSTEM P0400" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 5) Touch "START".
- 6) Accelerate vehicle to a speed of 40 km/h (25 MPH) once and then stop vehicle with engine running.
If "COMPLETED" appears on CONSULT-II screen, go to step 9.
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
- 7) Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
- 8) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds or more.)

| | |
|----------------|--|
| CMPS-RPM (POS) | 1,600 - 2,400 rpm (A/T models) 1,800 - 2,600 rpm (M/T models) |
| B/FUEL SCHDL | 3.0 - 4.5 msec |
| THRTL POS SEN | X - (X + 0.7) V X = Voltage value measured at step 7 |
| Selector lever | Suitable position |

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 9) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-924.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT



HA

SC

EL

IDX

Overall Function Check



Overall Function Check

NGEC0732

Use this procedure to check the overall EGR function. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the EGR valve lifting when revving engine from idle up to 3,000 rpm quickly under no load.
EGR valve should lift up and down without sticking.
 If NG, go to "Diagnostic Procedure", EC-924.
- 3) Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at idle speed.
Less than 4.5V should exist.
 If NG, go to next step.
- 4) Turn ignition switch OFF.
- 5) Disconnect EGR temperature sensor harness connector.
- 6) Check harness continuity between EGR temperature sensor harness connector terminal 2 and ground.
Continuity should exist.
- 7) Perform "CHECK EGR TEMPERATURE SENSOR" in "Diagnostic Procedure".

Overall function check

Check the EGR valve lifting when revving engine from idle up to 3,000 rpm quickly.

Diagram SEF863U: A hand is shown checking the EGR valve. The RPM gauge shows 1000 rpm (x1000 r/min).

DTC P0400 EGR FUNCTION (CLOSE)


VG33E

Wiring Diagram

Wiring Diagram


NGEC0733

EC-EGRC1-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST


RS
BT
HA
SC
EL
IDX



AEC958A

Diagnostic Procedure

NGEC0734

| | | |
|---|-----------------------------|-----------------------------------|
| 1 | CHECK EXHAUST SYSTEM | |
| <p>1. Start engine. 2. Check exhaust pipes and muffler for leaks.</p> <div style="text-align: center;">  </div> | | |
| SEF099P | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 2. |
| OK (Without CONSULT-II) | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace exhaust system. |

DTC P0400 EGR FUNCTION (CLOSE)


VG33E

Diagnostic Procedure (Cont'd)

2 CHECK VACUUM SOURCE TO EGR VALVE

Ⓟ With CONSULT-II

1. Warm engine up to normal operating temperature.
2. Disconnect vacuum hose to EGR valve.
3. Check for vacuum existence at idle.



AEC648A

Vacuum should not exist at idle.

4. Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT-II and turn the solenoid valve "ON".
5. Check for vacuum existence when revving engine from idle up to 3,000 rpm.

| ACTIVE TEST | |
|---------------|---------|
| EGRC SOL/V | ON |
| (EGR) | FLOW |
| MONITOR | |
| CMPS-RPM(REF) | XXX rpm |
| | |
| | |
| | |
| | |

PEF788U

Vacuum should exist when revving engine.

OK or NG


| | | |
|----|---|----------|
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 5. |


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0400 EGR FUNCTION (CLOSE)

VG33E

Diagnostic Procedure (Cont'd)

| | | | | | | | | | |
|----------|---|--|--|----|---|----------|----|---|----------|
| 3 | CHECK VACUUM SOURCE TO EGR VALVE | <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Warm engine up to normal operating temperature. 2. Disconnect vacuum hose to EGR valve. 3. Check for vacuum existence at idle. <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">AEC648A</p> <p>Vacuum should not exist at idle.</p> <ol style="list-style-type: none"> 4. Check for vacuum existence when revving engine from idle up to 3,000 rpm quickly. <p>Vacuum should exist when revving engine.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 5.</td> </tr> </table> | | OK | ▶ | GO TO 4. | NG | ▶ | GO TO 5. |
| OK | ▶ | GO TO 4. | | | | | | | |
| NG | ▶ | GO TO 5. | | | | | | | |

| | | | | | | | | | |
|----------|------------------------|---|--|----|---|-----------|----|---|--------------------|
| 4 | CHECK EGR VALVE | <p>Apply vacuum to EGR vacuum port with a hand vacuum pump.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">MEF137D</p> <p>EGR valve spring should lift.</p> <ul style="list-style-type: none"> ● Check for sticking. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 11.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace EGR valve.</td> </tr> </table> | | OK | ▶ | GO TO 11. | NG | ▶ | Replace EGR valve. |
| OK | ▶ | GO TO 11. | | | | | | | |
| NG | ▶ | Replace EGR valve. | | | | | | | |

DTC P0400 EGR FUNCTION (CLOSE)

VG33E

Diagnostic Procedure (Cont'd)

5 CHECK VACUUM HOSE

- Turn ignition switch OFF.
- Check vacuum hose for clogging, cracks or improper connection.

The diagrams illustrate three types of vacuum hose problems: 1. A hose with a longitudinal crack labeled 'Split'. 2. A hose that is swollen and blocked, labeled 'Clogging'. 3. A hose that is not fully inserted into its fitting, labeled 'Improper connection'.

SEF109L

OK or NG

| | | |
|-------------------------|---|--------------------------------|
| OK (With CONSULT-II) | ▶ | GO TO 6. |
| OK (Without CONSULT-II) | ▶ | GO TO 7. |
| NG | ▶ | Repair or replace vacuum hose. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

6 CHECK EGRC-SOLENOID VALVE OPERATION

Ⓟ With CONSULT-II

- Turn ignition switch ON.
- Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.

| ACTIVE TEST | |
|------------------|---------|
| EGRC SOL/V (EGR) | ON FLOW |
| MONITOR | |
| CMPS-RPM(REF) | XXX rpm |
| | |
| | |
| | |
| | |
| | |

PEF789U

Clicking noise should be heard.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Repair or replace EGRC-solenoid valve or repair circuit. |

| | |
|--|--|
| 7 | CHECK EGRC-SOLENOID VALVE OPERATION |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Turn ignition switch ON. 3. Connect a suitable jumper wire between ECM terminal 103 and engine ground. <div style="text-align: center; margin: 10px 0;"> </div> <p>4. Check operating sound of EGRC-solenoid valve when disconnecting and connecting the jumper wire. Clicking noise should be heard.</p> <p style="text-align: right; margin-right: 20px;">SEF354V</p> | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG | ▶ Repair or replace EGRC-solenoid valve or repair circuit. |

DTC P0400 EGR FUNCTION (CLOSE)


VG33E

Diagnostic Procedure (Cont'd)

8 CHECK EGRC-SOLENOID VALVE

With CONSULT-II

1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.




| ACTIVE TEST | |
|------------------|---------|
| EGRC SOL/V (EGR) | ON FLOW |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Conditions | Air passage continuity between A and B | Air passage continuity between A and C |
|------------|--|--|
| ON | Yes | No |
| OFF | No | Yes |

SEF155X

Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.



AEC919

| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

MTBL0237

OK or NG

OK ► GO TO 9.

NG ► Replace EGRC-solenoid valve.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P0400 EGR FUNCTION (CLOSE)

VG33E

Diagnostic Procedure (Cont'd)

9 CHECK EGRC-BPT VALVE

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve.



Leakage should not exist.

SEF083P

OK or NG

OK ► GO TO 10.

NG ► Replace EGRC-BPT valve.


DTC P0400 EGR FUNCTION (CLOSE)

VG33E

Diagnostic Procedure (Cont'd)

10 CHECK EGR TEMPERATURE SENSOR

Check resistance change and resistance value.




<Reference data>

SEF643Q

| EGR temperature °C (°F) | Voltage (V) | Resistance (MΩ) |
|-------------------------|-------------|-----------------|
| 0 (32) | 4.56 | 0.62 - 1.05 |
| 50 (122) | 2.25 | 0.065 - 0.094 |
| 100 (212) | 0.59 | 0.011 - 0.015 |

AEC039B



SEF320U

OK or NG

| | | |
|----|---|---------------------------------|
| OK | ▶ | GO TO 11. |
| NG | ▶ | Replace EGR temperature sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0400 EGR FUNCTION (CLOSE)


VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 11 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

Description (If Equipped with EGR Valve)

NGEC0735



SEF864U

SYSTEM DESCRIPTION

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling intake manifold vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

NGEC0735S01

On Board Diagnosis Logic

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is large, then the vacuum to the EGR valve is interrupted through the EGRC-solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated. Malfunction is detected when the EGRC-BPT valve does not operate properly.


NGEC0736

POSSIBLE CAUSE

- EGRC-BPT valve
- EGR valve
- Loose or disconnected rubber tube
- Blocked rubber tube
- Camshaft position sensor
- Blocked exhaust system
- Orifice
- Mass air flow sensor
- EGRC-solenoid valve

NGEC0736S01

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



DTC Confirmation Procedure

NGEC0737

CAUTION:

Always drive vehicle at a safe speed.

NOTE:





If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION

For best results, perform the test at a temperature of 5°C (41°F) or higher.

With CONSULT-II

- 1) Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Stop engine and wait at least 5 seconds.
- 4) Turn ignition switch ON and select "EGRC-BPT/V P0402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 5) Start engine and let it idle.
- 6) Touch "START".
- 7) Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
- 8) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen and the bar chart may increase. Maintain the conditions many times until "COMPLETED" appears.



| | |
|----------------|---|
| CMPS-RPM (POS) | 1,400 - 2,000 rpm (A/T models) 1,400 - 1,800 rpm (M/T models) |
| Vehicle speed | 30 - 60 km/h (19 - 37 MPH) (A/T models) 30 - 100 km/h (19 - 62 MPH) (M/T models) |
| B/FUEL SCHDL | 2.3 - 2.8 msec |
| THRTL POS SEN | $X - (X + 0.44) V$ X = Voltage value measured at step 7 |
| Selector lever | Suitable position |

- The bar chart on CONSULT-II screen indicates the status of this test. However, the test may be finished before the bar chart becomes full scale.
 - If the bar chart indication does not continue to progress, completely release accelerator pedal once and try to meet the conditions again.
 - If "TESTING" does not appear on CONSULT-II screen, retry from step 3.
- 9) If CONSULT-II instructs to carry out "OVERALL FUNCTION CHECK", go to next step. If "NG" is displayed, refer to "Diagnostic Procedure", EC-935.
 - 10) Open engine hood.
 - 11) Raise engine speed to 2,000 to 2,800 rpm under no-load and hold it. Then touch "NEXT" on CONSULT-II screen.

DTC P0402 EGRC-BPT VALVE FUNCTION

VG33E

DTC Confirmation Procedure (Cont'd)

12 EGRC-BPT VLV P0402


MAINTAIN ENGINE SPEED
2000 TO 2800 RPM.
VACUUM SHOULD BE
BETWEEN -5.91 in. Hg AND
0 in. Hg WITH VACUUM
GAUGE. IS VACUUM OK?

NG
OK

XXX psi XXX psi XXX psi

PEF035W

- 12) Check vacuum gauge while keeping engine speed 2,000 to 2,800 rpm.
Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).
 If NG, go to "Diagnostic Procedure", EC-935.
 If OK, touch "YES" on the CONSULT-II screen.
- 13) Check the rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for cracks, blockages or twist.
 If NG, repair or replace.
 If OK, touch "YES" on the CONSULT-II screen.



Overall Function Check

Use this procedure to check the overall function of the EGRC-BPT valve. During this check, a 1st trip DTC might not be confirmed.

Without CONSULT-II

- 1) Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
- 2) Lift up vehicle.
- 3) Start engine and shift to "1st" gear or "1" position.
- 4) Check vacuum gauge while keeping engine speed 2,000 to 2,800 rpm.
Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).
 If NG, go to "Diagnostic Procedure", EC-935.
 If OK, go to next step.
- 5) Check rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for misconnections, cracks or blockages.
 If NG, repair or replace.

Diagnostic Procedure

NGEC0739

| | | |
|--|-------------------|--------------------------------|
| 1 | CHECK HOSE | |
| 1. Turn ignition switch OFF. 2. Check vacuum hose for clogging and improper connection. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Repair or replace vacuum hose. |


| | | |
|------------------------------------|-----------------------------|-----------------------------------|
| 2 | CHECK EXHAUST SYSTEM | |
| Check exhaust system for collapse. | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace exhaust system. |

DTC P0402 EGRC-BPT VALVE FUNCTION

VG33E

Diagnostic Procedure (Cont'd)


| | |
|--|------------------------|
| 3 | CHECK ORIFICE |
| Check if orifice is installed in vacuum hose between EGRC-BPT valve and EGRC-solenoid valve. | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ Replace vacuum hose. |

| | |
|--|-----------------------------|
| 4 | CHECK EGRC-BPT VALVE |
| 1. Plug one of two ports of EGRC-BPT valve. 2. Vacuum from the other port and check leakage without applying any pressure from under EGR-BPT valve. | |
|  | |
| Leakage should exist. | |
| OK or NG | |
| OK | ▶ GO TO 5. |
| NG | ▶ Replace EGRC-BPT valve. |

SEF172P

5 CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.



Terminal 44 or 48 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|------------|------------|
| Voltage | 0.3 - 0.5V | 0.3 - 0.5V |
| Pulse signal | | |

Terminal 49 and engine ground

| Condition | Idle | 2,000 rpm |
|--------------|--------------------|--------------------|
| Voltage | Approximately 2.5V | Approximately 2.5V |
| Pulse signal | | |

AEC072B

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace distributor assembly with camshaft position sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

6 CHECK MASS AIR FLOW SENSOR

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.




SEF747U

| Condition | Voltage (V) |
|--|--------------------------|
| Ignition switch "ON" (Engine stopped.) | Less than 1.0 |
| Idle (Engine is warmed-up to normal operating temperature.) | 1.0 - 1.7 |
| 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.7 - 2.3 |
| Idle to about 4,000 rpm | 1.0 - 1.7 to Approx. 4.0 |

AEC040B

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Then repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



SEF030T


OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace mass air flow sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

7 CHECK EGRC-SOLENOID VALVE
With CONSULT-II

1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.




| ACTIVE TEST | |
|------------------|---------|
| EGRC SOL/V (EGR) | ON FLOW |
| MONITOR | |
| CMPS-RPM (REF) | XXrpm |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Conditions | Air passage continuity between A and B | Air passage continuity between A and C |
|------------|--|--|
| ON | Yes | No |
| OFF | No | Yes |

SEF155X

Without CONSULT-II

Check air passage continuity and operation delay time under the following conditions.




AEC919

| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

MTBL0237

OK or NG

| | | |
|----|---|------------------------------|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace EGRC-solenoid valve. |


| | | | |
|---|------------------------|--------------------|--|
| 8 | CHECK EGR VALVE | | |
| Apply vacuum to EGR vacuum port with a hand vacuum pump. | | | |
|  | | | |
| <p>EGR valve spring should lift.</p> <ul style="list-style-type: none"> ● Check for sticking. | | | |
| MEF137D | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 9. | |
| NG | ▶ | Replace EGR valve. | |

| | | | |
|---|------------------------------------|-----------------------|--|
| 9 | CHECK INTERMITTENT INCIDENT | | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | | |
| | ▶ | INSPECTION END | |

DTC P0420 (RIGHT BANK, -B1), P0430 (LEFT BANK, -B2) THREE WAY CATALYST FUNCTION

VG33E

On Board Diagnosis Logic



On Board Diagnosis Logic

NGEC0740

The ECM monitors the switching frequency ratio of front and rear heated oxygen sensors.

A warm-up three way catalyst with high oxygen storage capacity will indicate a low switching frequency of rear heated oxygen sensor. As oxygen storage capacity decreases, the rear heated oxygen sensor switching frequency will increase.

When the frequency ratio of front and rear heated oxygen sensors approaches a specified limit value, the warm-up three way catalyst malfunction is diagnosed.

Malfunction is detected when warm-up three way catalyst does not operate properly, warm-up three way catalyst does not have enough oxygen storage capacity.

POSSIBLE CAUSE

NGEC0740S01

- Warm-up three way catalyst
- Exhaust tube
- Intake air leaks
- Injectors
- Injector leaks
- Spark plug
- Improper ignition timing

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0420 (RIGHT BANK, -B1), P0430 (LEFT BANK, -B2) THREE WAY CATALYST FUNCTION

VG33E

On Board Diagnosis Logic (Cont'd)

DTC Confirmation Procedure

NGEC0741

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DTC & SRT CONFIRMATION" the SRT WORK SUPPORT mode with CONSULT-II.
- 3) Start engine.
- 4) Rev engine up to 2,500 to 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely.
- 5) Wait 5 seconds at idle.
- 6) Rev engine up to 2,500 to 3,000 rpm and hold it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take maximum of approximately 5 minute.).
- 7) Select "SELF-DIAG RESULTS" mode with CONSULT-II.
If the 1st trip DTC is detected, go to "DIAGNOSTIC PROCEDURE", EC-944. If not "CMPLT", stop engine and cool down "COOLANT TEMP/SE" to less than 70°C (158°F) and retest from step 1).

| SRT WORK SUPPORT | |
|------------------|----------|
| CATALYST | INCMP |
| EVAP SYSTEM | CMPLT |
| O2 SEN HEATER | CMPLT |
| O2 SENSOR | CMPLT |
| MONITOR | |
| ENG SPEED | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

AEC061B

| SRT WORK SUPPORT | |
|------------------|----------|
| CATALYST | INCMP |
| EVAP SYSTEM | INCMP |
| O2 SEN HEATER | INCMP |
| O2 SENSOR | INCMP |
| MONITOR | |
| ENG SPEED | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

SEF558X

| SRT WORK SUPPORT | |
|------------------|----------|
| CATALYST | CMPLT |
| EVAP SYSTEM | INCMP |
| O2 SEN HEATER | CMPLT |
| O2 SENSOR | INCMP |
| MONITOR | |
| ENG SPEED | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

SEF559X



| SELF DIAG RESULTS | |
|--|------|
| DTC RESULTS | TIME |
| NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED. | |
| | |
| | |

SEF560X

DTC P0420 (RIGHT BANK, -B1), P0430 (LEFT BANK, -B2) THREE WAY CATALYST FUNCTION

VG33E

Overall Function Check



Overall Function Check

NGEC0742

Use this procedure to check the overall function of the warm-up three way catalyst. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

Without CONSULT-II

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeters probes between ECM terminals 50 (front heated oxygen sensor right bank signal), 51 (front heated oxygen sensor left bank signal) and engine ground, and ECM terminals 56 (rear heated oxygen sensor right bank signal), 57 (rear heated oxygen sensor left bank signal) and engine ground.
- 4) Keep engine speed at 2,000 rpm constant under no load.
- 5) Make sure that the voltage switching frequency (high & low) between ECM terminals 56 and engine ground, or 57 and engine ground is very less than that of ECM terminals 50 and engine ground, or 51 and engine ground.

Switching frequency ratio = A/B

A: Rear heated oxygen sensor voltage switching frequency

B: Front heated oxygen sensor voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means warm-up three way catalyst does not operate properly. Go to "Diagnostic Procedure", EC-944.

NOTE:

If the voltage at terminal 50 or 51 does not switch periodically more than 5 times within 10 seconds at step 5, perform trouble diagnosis for "DTC P0133, P0153" first. (See EC-788.)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0420 (RIGHT BANK, -B1), P0430 (LEFT BANK, -B2) THREE WAY CATALYST FUNCTION


VG33E

Diagnostic Procedure

Diagnostic Procedure

=NGEC0743

| | | |
|--|-----------------------------|-----------------------|
| 1 | CHECK EXHAUST SYSTEM | |
| Visually check exhaust tubes and muffler for dent. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Repair or replace it. |

| | | |
|---|-------------------------------|--------------------|
| 2 | CHECK EXHAUST AIR LEAK | |
| 1. Start engine and run it at idle. 2. Listen for an exhaust air leak before the warm-up three way catalyst. | | |
|  | | |
| SEF099P | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Repair or replace. |


| | | |
|---|------------------------------|--------------------|
| 3 | CHECK INTAKE AIR LEAK | |
| Listen for an intake air leak after the mass air flow sensor. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair or replace. |


| 4 | CHECK IGNITION TIMING | | | | | | | | | | | |
|--|--|-------------------------|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|
| Check the following items. Refer to "Basic Inspection", EC-669. | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Items</th> <th style="text-align: center;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>15° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>700 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> | | | Items | Specifications | Ignition timing | 15° ± 2° BTDC | Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | Target idle speed | 750 ± 50 rpm (in "P" or "N" position) |
| Items | Specifications | | | | | | | | | | | |
| Ignition timing | 15° ± 2° BTDC | | | | | | | | | | | |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | | | | | | | | | | | |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | |
| MTBL0226 | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | |
| OK | ▶ | GO TO 5. | | | | | | | | | | |
| NG | ▶ | Adjust ignition timing. | | | | | | | | | | |

DTC P0420 (RIGHT BANK, -B1), P0430 (LEFT BANK, -B2) THREE WAY CATALYST FUNCTION

VG33E

Diagnostic Procedure (Cont'd)


| | | | |
|----------|------------------------|---|-----------------------------------|
| 5 | CHECK INJECTORS | <ol style="list-style-type: none"> 1. Refer to WIRING DIAGRAM for Injectors, EC-1145. 2. Stop engine and then turn ignition switch ON. 3. Check voltage between ECM terminals 102, 104, 106, 109, 111 and 113 and ground with CONSULT-II or tester. <div style="text-align: center; margin: 10px 0;">  </div> <p style="color: blue; font-weight: bold;">Battery voltage should exist.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | GI MA EM LC EC |
| OK | ▶ | GO TO 6. | FE |
| NG | ▶ | Perform "Diagnostic Procedure", "INJECTOR", EC-1146. | CL |

| | | | |
|----------|-----------------------------|--|---|
| 6 | CHECK IGNITION SPARK | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ignition wire from spark plug. 3. Connect a known good spark plug to the ignition wire. 4. Place end of spark plug against a suitable ground and crank engine. 5. Check for spark. <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | MT AT TF PD AX SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 8. | ST |
| NG | ▶ | GO TO 7. | RS |

DTC P0420 (RIGHT BANK, -B1), P0430 (LEFT BANK, -B2) THREE WAY CATALYST FUNCTION

VG33E

Diagnostic Procedure (Cont'd)

| 7 | CHECK IGNITION WIRES | | | | | | | | | | | | | | | |
|---|--------------------------------|---|--------------|--------------------------------|---|-------------------|---|--------------------|---|-------------------|---|--------------------|---|-------------------|---|--------------------|
| <ol style="list-style-type: none"> 1. Inspect wires for cracks, damage, burned terminals and for improper fit. 2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks. | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | |
| <p>Resistance:</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Cylinder No.</th> <th style="text-align: center;">Resistance kΩ [at 25°C (77°F)]</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Approximately 6.5</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Approximately 10.0</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Approximately 8.5</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">Approximately 12.5</td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">Approximately 8.5</td> </tr> <tr> <td style="text-align: center;">6</td> <td style="text-align: center;">Approximately 11.0</td> </tr> </tbody> </table> | | | Cylinder No. | Resistance kΩ [at 25°C (77°F)] | 1 | Approximately 6.5 | 2 | Approximately 10.0 | 3 | Approximately 8.5 | 4 | Approximately 12.5 | 5 | Approximately 8.5 | 6 | Approximately 11.0 |
| Cylinder No. | Resistance kΩ [at 25°C (77°F)] | | | | | | | | | | | | | | | |
| 1 | Approximately 6.5 | | | | | | | | | | | | | | | |
| 2 | Approximately 10.0 | | | | | | | | | | | | | | | |
| 3 | Approximately 8.5 | | | | | | | | | | | | | | | |
| 4 | Approximately 12.5 | | | | | | | | | | | | | | | |
| 5 | Approximately 8.5 | | | | | | | | | | | | | | | |
| 6 | Approximately 11.0 | | | | | | | | | | | | | | | |
| SEF174P | | | | | | | | | | | | | | | | |
| MTBL0235 | | | | | | | | | | | | | | | | |
| <p>If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>Check ignition coil, power transistor and their circuits. Refer to EC-1028.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace.</td> </tr> </table> | | | OK | ▶ | Check ignition coil, power transistor and their circuits. Refer to EC-1028. | NG | ▶ | Replace. | | | | | | | | |
| OK | ▶ | Check ignition coil, power transistor and their circuits. Refer to EC-1028. | | | | | | | | | | | | | | |
| NG | ▶ | Replace. | | | | | | | | | | | | | | |

| | | | | | | | | |
|---|-----------------------|--|--------------------|---|----------|------------|---|--|
| 8 | CHECK INJECTOR | | | | | | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove injector assembly. Refer to EC-611. Keep fuel hose and all injectors connected to injector gallery. 3. Disconnect all ignition coil harness connectors. 4. Turn ignition switch ON. Make sure fuel does not drip from injector. | | | | | | | | |
| OK or NG | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK (Does not drip)</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG (Drips)</td> <td style="text-align: center;">▶</td> <td>Replace the injector(s) from which fuel is dripping.</td> </tr> </table> | | | OK (Does not drip) | ▶ | GO TO 9. | NG (Drips) | ▶ | Replace the injector(s) from which fuel is dripping. |
| OK (Does not drip) | ▶ | GO TO 9. | | | | | | |
| NG (Drips) | ▶ | Replace the injector(s) from which fuel is dripping. | | | | | | |

| | | | | | | | | |
|--|------------------------------------|-------------------------------------|------------------|---|-----------------------|----------------------|---|-------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT | | | | | | | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Trouble is fixed</td> <td style="width: 5%; text-align: center;">▶</td> <td>INSPECTION END</td> </tr> <tr> <td>Trouble is not fixed</td> <td style="text-align: center;">▶</td> <td>Replace warm-up three way catalyst.</td> </tr> </table> | | | Trouble is fixed | ▶ | INSPECTION END | Trouble is not fixed | ▶ | Replace warm-up three way catalyst. |
| Trouble is fixed | ▶ | INSPECTION END | | | | | | |
| Trouble is not fixed | ▶ | Replace warm-up three way catalyst. | | | | | | |

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0744


NOTE:

If DTC P0440 or P1440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See EC-1098.)

This diagnosis detects leaks in the EVAP purge line using engine intake manifold vacuum.

If pressure does not increase, the ECM will check for leaks in the line between the fuel tank and EVAP canister purge volume control solenoid valve, under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control solenoid valve is opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge volume control solenoid valve will be closed.



Malfunction is detected when EVAP control system has a leak, EVAP control system does not operate properly.

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

POSSIBLE CAUSE

NGEC0744S01

- Incorrect fuel tank vacuum relief valve
- Incorrect fuel filler cap used
- Fuel filler cap remains open or fails to close.
- Foreign matter caught in fuel filler cap.
- Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve.
- Foreign matter caught in EVAP canister vent control valve.
- EVAP canister or fuel tank leaks
- EVAP purge line (pipe and rubber tube) leaks
- EVAP purge line rubber tube bent.
- Blocked or bent rubber tube to EVAP control system pressure sensor
- Loose or disconnected rubber tube
- EVAP canister vent control valve and the circuit
- EVAP canister purge volume control solenoid valve and the circuit
- Absolute pressure sensor
- Fuel tank temperature sensor

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

VG33E

On Board Diagnosis Logic (Cont'd)

- MAP/BARO switch solenoid valve and the circuit
- Blocked or bent rubber tube to MAP/BARO switch solenoid valve and the circuit
- O-ring of EVAP canister vent control valve is missing or damaged.
- Water separator
- EVAP canister is saturated with water.
- EVAP control system pressure sensor
- Fuel level sensor

| | | |
|---|---|---------|
| 5 | <p>EVAP SML LEAK P0440/P1440</p> <p>1)FOR BEST RSLT,PERFORM AT FOLLOWING CONDITIONS. -FUEL LEVEL: 1/4-3/4 -AMBIENT TEMP: 0-30 C(32-86F) -OPEN ENGINE HOOD. 2)START ENG WITH VHCL STOPPED. IF ENG IS ON,STOP FOR 5 SEC. THEN RESTART. 3)TOUCH START.</p> | SEF565X |
|---|---|---------|

| | | |
|---|---|---------|
| 5 | <p>EVAP SML LEAK P0440/P1440</p> <p>WAIT 2 TO 10 MINUTES. KEEP ENGINE RUNNING AT IDLE SPEED.</p> | SEF566X |
|---|---|---------|

| | | |
|---|--|---------|
| 5 | <p>EVAP SML LEAK P0440/P1440</p> <p style="text-align: center;">OK</p> <hr/> <p>SELF-DIAG RESULTS</p> <hr/> <p>NO DTC DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> | SEF567X |
|---|--|---------|

DTC Confirmation Procedure

NGEC0745

NOTE:

- If DTC P0440 or P1440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See EC-1098.)
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Perform “DTC WORK SUPPORT” when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Always perform test at a temperature of 0 to 30°C (32 to 86°F).

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
- 4) Make sure that the following conditions are met.
COOLAN TEMP/S: 0 - 70°C (32 - 158°F)
INT/A TEMP SE: 0 - 60°C (32 - 140°F)
- 5) Select “EVAP SML LEAK P0440” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II. Follow the instruction displayed.

NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to “Basic Inspection”, EC-669.

- 6) Make sure that “OK” is displayed.
 If “NG” is displayed, refer to “Diagnostic Procedure”, EC-949.

NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

Ⓜ With GST

NOTE:

Be sure to read the explanation of “Driving Pattern” on EC-634 before driving vehicle.

- 1) Start engine.
- 2) Drive vehicle according to “Driving Pattern”, EC-634.
- 3) Stop vehicle.
- 4) Select “MODE 1” with GST.
- If SRT of EVAP system is not set yet, go to the following step.
- If SRT of EVAP system is set, the result will be OK.
- 5) Turn ignition switch OFF and wait at least 5 seconds.

DTC P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

VG33E

DTC Confirmation Procedure (Cont'd)

- 6) Start engine.
It is not necessary to cool engine down before driving.
- 7) Drive vehicle again according to the "Driving Pattern", EC-634. GI
- 8) Stop vehicle.
- 9) Select "MODE 3" with GST. MA
 - If P0440 is displayed on the screen, go to "Diagnostic Procedure", EC-949.
 - If P1440 is displayed on the screen, go to "Diagnostic Procedure" for "DTC P1440", EC-1066. EM
 - If P1447 is displayed on the screen, go to "Diagnostic Procedure" for "DTC P1447", EC-1089. LC
 - If P0440, P1440 and P1447 are not displayed on the screen, go to the following step.
- 10) Select "MODE 1" with GST. **EC**
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6. FE

Diagnostic Procedure

NGEC0746

NOTE:

Refer to "P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)", EC-949. AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

VG33E

Description


Description SYSTEM DESCRIPTION

NGEC0747

NGEC0747S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|--|----------------------------------|---|
| Camshaft position sensor | Engine speed | EVAP canister purge flow control | EVAP canister purge volume control solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| Throttle position switch | Closed throttle position | | |
| Front heated oxygen sensors | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | | |
| Tank fuel temperature sensor | Fuel temperature in fuel tank | | |
| Vehicle speed sensor | Vehicle speed | | |

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



COMPONENT DESCRIPTION

NGEC0747S02

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0748

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|------------------------|
| PURG VOL C/V | ● Engine: After warming up ● Air conditioner switch OFF ● Shift lever: "N" ● No-load | Idle (Vehicle stopped) |
| | | 2,000 rpm |
| | | 0% |
| | | — |

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)



VG33E

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NGEC0749

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---|--|---|
| 4 | OR/B | ECM relay (Self shut-off) | [Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF | 0 - 1.5V |
| | | | [Ignition switch OFF] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 5 | R/Y | EVAP canister purge volume control solenoid valve | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) <div style="text-align: center;">  </div> |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm (More than 100 seconds after starting engine) | BATTERY VOLTAGE (11 - 14V) <div style="text-align: center;">  </div> |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 117 | B/P | Current return | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V) |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

Malfunction is detected when an improper voltage signal is sent to ECM through the valve. =NGEC0750

POSSIBLE CAUSE

- Harness or connectors
(The valve circuit is open or shorted.)
 - EVAP canister purge volume control solenoid valve
- NGEC0750S01

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test. NGEC0751

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and let it idle for at least 13 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-954.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)


VG33E

Wiring Diagram


Wiring Diagram

NGEC0752

EC-PGC/V-01



— : Detectable line for DTC
 — : Non-detectable line for DTC



AEC959A

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX



DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0753

| | |
|--|---|
| 1 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect EVAP canister purge volume control solenoid valve harness connector.</p> | |
|  <p>Brake fluid reservoir</p> <p>EVAP canister purge volume control solenoid valve harness connector</p> | |
| AEC652A | |
| <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> | |
|  | |
| SEF646W | |
| <p>Voltage: Battery voltage</p> <p>OK or NG</p> | |
| OK | ▶ GO TO 3. |
| NG | ▶ GO TO 2. |

| | |
|---|-----------------------------------|
| 2 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F36, M81 ● Harness connectors M82, E74 ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay | |
| ▶ | Repair harness or connectors. |

| | |
|---|---|
| 3 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 5 and solenoid terminal 2. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> | |
| <p>OK or NG</p> | |
| OK (With CONSULT-II) | ▶ GO TO 5. |
| OK (Without CONSULT-II) | ▶ GO TO 6. |
| NG | ▶ GO TO 4. |

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 4 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M81, F36 ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM | |
| | Repair open circuit or short to ground or short to power in harness or connectors. |

| 5 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | |
|---|--|-------------|--|-----------------|------|---------|--|---------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|--|--|
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening. | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>PURG VOL CONT/V</td><td style="text-align: center;">0.0%</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS~RPM(REF)</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td>FR O2 MNTR-B2</td><td style="text-align: center;">RICH</td></tr> <tr><td>FR O2 MNTR-B1</td><td style="text-align: center;">RICH</td></tr> <tr><td>A/F ALPHA-B2</td><td style="text-align: center;">XXX %</td></tr> <tr><td>A/F ALPHA-B1</td><td style="text-align: center;">XXX %</td></tr> <tr><td>THRTL POS SEN</td><td style="text-align: center;">XXX V</td></tr> <tr><td> </td><td> </td></tr> </table> | | ACTIVE TEST | | PURG VOL CONT/V | 0.0% | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR-B2 | RICH | FR O2 MNTR-B1 | RICH | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | 0.0% | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | RICH | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| PEF882U | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | |
| OK | GO TO 7. | | | | | | | | | | | | | | | | | | | | |
| NG | GO TO 6. | | | | | | | | | | | | | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)


VG33E

Diagnostic Procedure (Cont'd)

6 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓟ With CONSULT-II

1. Check air passage continuity under the following conditions.




SEF660U

| Condition PURG VOL CONT/V value | Air passage continuity between A and B |
|------------------------------------|---|
| 100.0% | Yes |
| 0.0% | No |

MTBL0241

ⓧ Without CONSULT-II

1. Check air passage continuity under the following conditions.



SEF661U

| Condition | Air passage continuity between A and B |
|--|---|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No supply | No |

MTBL0242

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

7 CHECK INTERMITTENT INCIDENT



Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

▶ **INSPECTION END**

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

VG33E

Component Description



Component Description

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent. NGEC0754

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

GI

MA

EM

LC

EC

FE

CL

MT

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

NGEC0755

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|---------------|
| VENT CONT/V | ● Ignition switch: ON | OFF |

TF

PD

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground). NGEC0756

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|----------------------------------|----------------------|----------------------------|
| 108 | R/G | EVAP canister vent control valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

Malfunction is detected when an improper voltage signal is sent to ECM through EVAP canister vent control valve. =NGEC0757

POSSIBLE CAUSE

- Harness or connectors
(The valve circuit is open or shorted.)
- EVAP canister vent control valve

NGEC0757S01

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test. NGEC0758

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

| | | |
|---|---------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |

PEF357V

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 8 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-960.

With GST

Follow the procedure "With CONSULT-II".

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

VG33E

Wiring Diagram

Wiring Diagram

NGEC0759

EC-VENT/V-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS




BT

HA

SC

EL

IDX



AEC960A

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0760

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |



| 2 | CHECK EVAP CANISTER VENT CONTROL VALVE CIRCUIT | | | | | | | | | | | | | | | | | | | | | |
|---|---|----------|-------------|--|----------------|----|---------|--|----------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|--|--|
| <p>1. Turn ignition switch OFF and then turn ON. 2. Select "VENT CONTROL/V" in "ACTIVE TEST" mode with CONSULT-II. 3. Touch "ON/OFF" on CONSULT-II screen.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>VENT CONTROL/V</td><td>ON</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXX rpm</td></tr> <tr><td>FR O2 MNTR-B2</td><td>LEAN</td></tr> <tr><td>FR O2 MNTR-B1</td><td>LEAN</td></tr> <tr><td>A/F ALPHA-B2</td><td>XXX %</td></tr> <tr><td>A/F ALPHA-B1</td><td>XXX %</td></tr> <tr><td>THRTL POS SEN</td><td>XXX V</td></tr> <tr><td> </td><td> </td></tr> </table> | | | ACTIVE TEST | | VENT CONTROL/V | ON | MONITOR | | CMPS-RPM (REF) | XXX rpm | FR O2 MNTR-B2 | LEAN | FR O2 MNTR-B1 | LEAN | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | ON | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| <p>4. Check for operating sound of the valve. Clicking noise should be heard.</p> | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 3. | | | | | | | | | | | | | | | | | | | | |

PEF883U

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

VG33E

Diagnostic Procedure (Cont'd)

| | | | | | | | | | |
|--|--|---|---|----------|----|---|----------|-------------------------------|--|
| 3 | CHECK EVAP CANISTER VENT CONTROL VALVE POWER SUPPLY CIRCUIT | <p>1. Turn ignition switch OFF. 2. Disconnect EVAP canister vent control valve harness connector.</p> <div style="text-align: center;">  <p>EVAP canister vent control valve</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table> | | OK | ▶ | GO TO 5. | NG | ▶ | GO TO 4. | <p>SEF143S</p> <p>SEF648W</p> | |
| OK | ▶ | GO TO 5. | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | |

| | | | |
|----------|-----------------------------------|--|---|
| 4 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M67, C1 ● Fuse block (J/B) connector E49 ● 10A fuse ● Harness for open or short between EVAP canister vent control valve and fuse <p style="text-align: right;">▶ Repair harness or connectors.</p> | <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> |
|----------|-----------------------------------|--|---|

| | | | | | | | | | |
|--|--|--|---|----------|----|---|----------|--|--|
| 5 | CHECK EVAP CANISTER VENT CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 108 and valve terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 7.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 6.</td> </tr> </table> | | OK | ▶ | GO TO 7. | NG | ▶ | GO TO 6. | | |
| OK | ▶ | GO TO 7. | | | | | | | |
| NG | ▶ | GO TO 6. | | | | | | | |

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 6 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C1, M67 ● Harness connectors M81, F36 ● Harness for open or short between EVAP canister vent control valve and ECM | |
| | Repair open circuit or short to ground or short to power in harness or connectors. |

| 7 | CHECK EVAP CANISTER VENT CONTROL VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|-------------|--|----------------|-----|---------|--|----------------|--------|---------------|------|--------------|------|---------------|------|--|--|--|--|--|--|-----------------------------|---|----|----|-----|-----|
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode. 2. Check air passage continuity and operation delay time. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>VENT CONTROL/V</td><td>OFF</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>CMPS-RPM (REF)</td><td>XXXrpm</td></tr> <tr><td>FR O2 MNTR-B1</td><td>RICH</td></tr> <tr><td>A/F ALPHA-B1</td><td>XXX%</td></tr> <tr><td>THRTL POS SEN</td><td>XXXV</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <th style="width: 50%;">Condition VENT CONTROL/V</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> <tr> <td>ON</td> <td>No</td> </tr> <tr> <td>OFF</td> <td>Yes</td> </tr> </table> | ACTIVE TEST | | VENT CONTROL/V | OFF | MONITOR | | CMPS-RPM (REF) | XXXrpm | FR O2 MNTR-B1 | RICH | A/F ALPHA-B1 | XXX% | THRTL POS SEN | XXXV | | | | | | | Condition VENT CONTROL/V | Air passage continuity between A and B | ON | No | OFF | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXXrpm | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX% | | | | | | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXXV | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition VENT CONTROL/V | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | No | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF156X | | | | | | | | | | | | | | | | | | | | | | | | | | | |


| <p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Check air passage continuity and operation delay time under the following conditions. | | | | | | | |
|--|---|---|---|----|-----|-----|--|
| <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td>No</td> </tr> <tr> <td>OFF</td> <td>Yes</td> </tr> </table> | Condition | Air passage continuity between A and B | 12V direct current supply between terminals 1 and 2 | No | OFF | Yes | |
| Condition | Air passage continuity between A and B | | | | | | |
| 12V direct current supply between terminals 1 and 2 | No | | | | | | |
| OFF | Yes | | | | | | |
| <p>If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary. If portion B is rusted, replace control valve.</p> | | | | | | | |
| <p style="text-align: right; margin-right: 50px;">5.3 - 12 N·m (0.54 - 1.2 kg-m, 46.9 - 104 in-lb)</p> | | | | | | | |
| <p>Make sure new O-ring is installed properly.</p> <p>OK or NG</p> | | | | | | | |
| OK | GO TO 8. | | | | | | |
| NG | Replace EVAP canister vent control valve. | | | | | | |

| | |
|---|------------------------------------|
| 8 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | INSPECTION END |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

VG33E


Component Description



Component Description

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.

NGEC0761



CONSULT-II Reference Value in Data Monitor Mode

NGEC0762

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|-----------------------|---------------|
| EVAP SYS PRES | ● Ignition switch: ON | Approx. 3.4V |

ECM Terminals and Reference Value

NGEC0763

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-------------------------------------|--|--------------------|
| 42 | B/W | Sensors' power supply | [Ignition switch ON] | Approximately 5V |
| 43 | BR | Sensors' ground | [Engine is running] ● Warm-up condition ● Idle speed | Approximately 0V |
| 62 | Y | EVAP control system pressure sensor | [Ignition switch ON] | Approximately 3.4V |

On Board Diagnosis Logic

Malfunction is detected when an improper voltage signal from EVAP control system pressure sensor is sent to ECM. =NGEC0764

POSSIBLE CAUSE

NGEC0764S01

- Harness or connectors
(The EVAP control system pressure sensor circuit is open or shorted.)
- Rubber hose to EVAP control system pressure sensor is clogged, vent, kinked, disconnected or improper connection.
- EVAP control system pressure sensor
- EVAP canister vent control valve
- EVAP canister purge volume control solenoid valve
- EVAP canister
- Rubber hose from EVAP canister vent control valve to water separator

DTC Confirmation Procedure

NGEC0765

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

| 6 | DATA MONITOR | |
|----------|---------------|---------|
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | TANK F/TMP SE | XXX °C |

PEF886U

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Make sure that "TANK F/TEMP SE" is more than 0°C (32°F).
- 6) Start engine and wait at least 20 seconds.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-966.

With GST

Follow the procedure "With CONSULT-II".

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

VG33E

Wiring Diagram

Wiring Diagram

NGEC0766

EC-PRE/SE-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX



AEC961A


DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR


VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0767

| | | | |
|--|--------------------------|-------------------------------|--|
| 1 | CHECK RUBBER TUBE | | |
| <p>1. Turn ignition switch OFF. 2. Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.</p> | | | |
|  | | | |
| AEC651A | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Reconnect, repair or replace. | |


| | | | |
|---|--------------------------------|---|----------|
| 2 | RETIGHTEN GROUND SCREWS | | |
| <p>1. Loosen and retighten engine ground screws.</p> | | | |
|  | | | |
| AEC640A | | | |
| | | ▶ | GO TO 3. |

| | | | |
|---|------------------------|--------------------------------------|--|
| 3 | CHECK CONNECTOR | | |
| <p>1. Disconnect EVAP control system pressure sensor harness connector. 2. Check sensor harness connector for water. Water should not exist.</p> | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 4. | |
| NG | ▶ | Repair or replace harness connector. | |

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|---|----------|
| 4 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT | |
| <p>1. Turn ignition switch ON. 2. Check voltage between terminal 3 and ground with CONSULT-II or tester.</p> | | |
|  | | |
| <p>Voltage: Approximately 5V</p> <p style="text-align: right;">SEF889U</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |

GI
MA
EM
LC
EC

| | | |
|--|-----------------------------------|-------------------------------|
| 5 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C1, M67 ● Harness connectors M59, F27 ● Harness for open or short between EVAP control system pressure sensor and ECM | | |
| ▶ | | Repair harness or connectors. |

FE
CL
MT
AT

| | | |
|---|--|----------|
| 6 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between sensor terminal 1 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

TF
PD
AX
SU

| | | |
|---|-----------------------------------|--|
| 7 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C1, M67 ● Harness connectors M59, F27 ● Harness connectors F28, M58 ● Joint connector-4 ● Harness for open or short between EVAP control system pressure sensor and ECM ● Harness for open or short between EVAP control system pressure sensor and TCM (Transmission Control Module) | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

BR
ST
RS
BT

HA
SC
EL

IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|--|-----------|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 62 and sensor terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK (With CONSULT-II) ▶ | | GO TO 10. |
| OK (Without CONSULT-II) ▶ | | GO TO 11. |
| NG ▶ | | GO TO 9. |

| | | |
|--|-----------------------------------|--|
| 9 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors C1, M67 ● Harness connectors M59, F27 ● Harness for open or short between ECM and EVAP control system pressure sensor | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

| 10 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | | | | | | | | | | |
|---|--|-----------|-------------|--|-----------------|------|---------|--|---------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|--|--|
| <p>Ⓜ With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>PURG VOL CONT/V</td> <td style="text-align: center;">0.0%</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS~RPM(REF)</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td>FR O2 MNTR-B2</td> <td style="text-align: center;">RICH</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td style="text-align: center;">RICH</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td style="text-align: center;">XXX %</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td style="text-align: center;">XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | PURG VOL CONT/V | 0.0% | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR-B2 | RICH | FR O2 MNTR-B1 | RICH | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | 0.0% | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | RICH | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK ▶ | | GO TO 12. | | | | | | | | | | | | | | | | | | | | |
| NG ▶ | | GO TO 11. | | | | | | | | | | | | | | | | | | | | |

PEF882U

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR


VG33E

Diagnostic Procedure (Cont'd)

11 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Check air passage continuity under the following conditions.




| Condition PURG VOL CONT/V value | Air passage continuity between A and B |
|------------------------------------|---|
| 100.0% | Yes |
| 0.0% | No |

SEF660U

MTBL0241

Without CONSULT-II


1. Check air passage continuity under the following conditions.



| Condition | Air passage continuity between A and B |
|--|---|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No supply | No |

SEF661U

MTBL0242



AEC652A

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR


VG33E

Diagnostic Procedure (Cont'd)

12 CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.



| ACTIVE TEST | |
|----------------|--------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B1 | XXX% |
| THRTL POS SEN | XXXV |
| | |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|-----------------------------|---|
| ON | No |
| OFF | Yes |

SEF156X


Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.

| Condition | Air passage continuity between A and B |
|--|---|
| 12V direct current supply between terminals 1 and 2 | No |
| OFF | Yes |

MTBL0240

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.
If portion **B** is rusted, replace control valve.



AEC783A

Make sure new O-ring is installed properly.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 13. |
| NG | ▶ | Replace EVAP canister vent control valve. |


DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

13 CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.



| Pressure (Relative to atmospheric pressure) | Voltage (V) |
|---|-------------|
| 0 kPa (0 mmHg, 0 inHg) | 3.0 - 3.6 |
| -9.3 kPa (-70 mmHg, -2.76 inHg) | 0.4 - 0.6 |

SEF894U


MTBL0246

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.

CAUTION:

- Never apply force to the air hole protector of the sensor if equipped.



SEF799W

- Discard and EVAP control system pressure sensor which has been dropped from a height of more than 0.5m (19.7in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 14. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

14 CHECK RUBBER TUBE

Check obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

| | | |
|----|---|---------------------------------------|
| OK | ▶ | GO TO 15. |
| NG | ▶ | Clean, repair or replace rubber tube. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | | | | | | | |
|---|------------------------------|--------------------------|---|-----------|----|---|--------------------------|
| 15 | CHECK WATER SEPARATOR | | | | | | |
| <p>1. Check visually for insect nests in the water separator air inlet. 2. Check visually for cracks or flaws in the appearance. 3. Check visually for cracks or flaws in the hose. 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged.</p> <div style="text-align: center;"> <p>* (A) : Bottom hole (To atmosphere) * (B) : Emergency tube (From EVAP canister) * (C) : Inlet port (To member)</p> </div> <p style="text-align: right;">SEF829T</p> <p>5. In case of NG in items 2 - 4, replace the parts. NOTE: • Do not disassemble water separator.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 16.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace water separator.</td> </tr> </table> | | OK | ▶ | GO TO 16. | NG | ▶ | Replace water separator. |
| OK | ▶ | GO TO 16. | | | | | |
| NG | ▶ | Replace water separator. | | | | | |

| | | | | | | | |
|--|--|-----------|---|-----------|----|---|-----------|
| 16 | CHECK IF EVAP CANISTER SATURATED WITH WATER | | | | | | |
| <p>1. Remove EVAP canister with EVAP canister vent control valve attached. 2. Check if water will drain from the EVAP canister.</p> <div style="text-align: center;"> <p>EVAP canister Water EVAP canister vent control valve</p> </div> <p style="text-align: right;">SEF596U</p> <p style="text-align: center;">Yes or No</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Yes</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 17.</td> </tr> <tr> <td>No</td> <td style="text-align: center;">▶</td> <td>GO TO 19.</td> </tr> </table> | | Yes | ▶ | GO TO 17. | No | ▶ | GO TO 19. |
| Yes | ▶ | GO TO 17. | | | | | |
| No | ▶ | GO TO 19. | | | | | |

| | | | | | | | |
|---|----------------------------|-----------|---|-----------|----|---|-----------|
| 17 | CHECK EVAP CANISTER | | | | | | |
| <p>Weigh the EVAP canister with the EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0 lb).</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 19.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 18.</td> </tr> </table> | | OK | ▶ | GO TO 19. | NG | ▶ | GO TO 18. |
| OK | ▶ | GO TO 19. | | | | | |
| NG | ▶ | GO TO 18. | | | | | |


On Board Diagnosis Logic

NGEC0954

NOTE:

If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See EC-1102.)

This diagnosis detects a very large leak (fuel filler cap fell off etc.) in the EVAP system between the fuel tank and the EVAP canister purge volume control solenoid valve.



Malfunction is detected when EVAP control system has a very large leak, such as fuel filler cap fell off, EVAP control system does not operate properly.

CAUTION:

- Fuel filler cap remains open or fails to close.
- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

POSSIBLE CAUSE

NGEC0954S01

- Fuel filler cap remains open or fails to close.
- Incorrect fuel tank vacuum relief valve
- Incorrect fuel filler cap used
- Foreign matter caught in fuel filler cap.
- Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve.
- Foreign matter caught in EVAP canister vent control valve.
- EVAP canister or fuel tank leaks
- EVAP purge line (pipe and rubber tube) leaks
- EVAP purge line rubber tube bent.
- Blocked or bent rubber tube to EVAP control system pressure sensor
- Loose or disconnected rubber tube
- EVAP canister vent control valve and the circuit
- EVAP canister purge volume control solenoid valve and the circuit
- Absolute pressure sensor
- Fuel tank temperature sensor
- O-ring of EVAP canister vent control valve is missing or damaged.
- EVAP control system pressure sensor

DTC Confirmation Procedure

NGEC0955

CAUTION:

Never remove fuel filter cap during the DTC confirmation procedure.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

6 EVAP SML LEAK P0440/P1440

1) FOR BEST RESULT, PERFORM AT FOLLOWING CONDITIONS.

- FUEL LEVEL: 1/4-3/4
- AMBIENT TEMP: 0-30 C (32-86F)
- OPEN ENGINE HOOD.

2) START ENG WITH VHCL STOPPED. IF ENG IS ON, STOP FOR 5 SEC. THEN RESTART.

3) TOUCH START.

SEF565X

6 EVAP SML LEAK P0440/P1440

WAIT
2 TO 10 MINUTES.
KEEP ENGINE RUNNING
AT IDLE SPEED.

SEF566X

6 EVAP SML LEAK P0440/P1440

OK

SELF-DIAG RESULTS

NO DTC DETECTED.
FURTHER TESTING
MAY BE REQUIRED.

SEF567X

6 EVAP SML LEAK P0440/P1440

MAINTAIN
1600 - 2100 RPM UNTIL FINAL
RESULT APPEARS.
(APPROX. 3 MINUTES)



1600 rpm 1850 rpm 2100 rpm

SEF874X

NOTE:

- If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See EC-1102.)
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Perform “DTC WORK SUPPORT” when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Always perform test at a temperature of 0 to 30°C (32 to 86°F). Open engine hood before conducting the following procedure.

With CONSULT-II

- 1) Tighten fuel filter cap securely until ratcheting sound is heard.
- 2) Turn ignition switch ON.
- 3) Turn ignition switch OFF and wait at least 5 seconds.
- 4) Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
- 5) Make sure that the following conditions are met.
COOLANT TEMP/S: 0 - 70°C (32 - 158°F)
INT/A TEMP SE: 0 - 60°C (32 - 140°F)
- 6) Select “EVAP SML LEAK P0440” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II. Follow the instruction displayed.

NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to “Basic Inspection”, EC-669.

- 7) Make sure that “OK” is displayed.
 If “NG” is displayed, select “SELF-DIAG RESULTS” mode with CONSULT-II and make sure that “EVAP GROSS LEAK [P0455] is displayed, refer to “Diagnostic Procedure”, EC-976. If P0440 is displayed, perform “Diagnostic Procedure” for DTC P0440.

With GST

NOTE:

Be sure to read the explanation of “Driving Pattern” on EC-634 before driving vehicle.


- 1) Start engine.
0956
- 2) Drive vehicle according to “Driving Pattern”, EC-634.
- 3) Stop vehicle.

- 4) Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
- 5) Turn ignition switch "OFF" and wait at least 5 seconds.
- 6) Start engine.

It is not necessary to cool engine down before driving.
- 7) Drive vehicle again according to the "Driving Pattern", EC-634.
- 8) Stop vehicle.
- 9) Select "MODE 3" with GST.
 - If P0440 is displayed on the screen, go to "Diagnostic Procedure", EC-949.
 - If P1447 is displayed on the screen, go to "Diagnostic Procedure" for "DTC P1447", EC-1089.
 - If P0440, P1440 and P1447 are not displayed on the screen, go to the following step.
- 10) Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6.

Diagnostic Procedure



NGEC0956

| | | |
|---|-------------------------------------|--|
| 1 | CHECK FUEL FILLER CAP DESIGN | |
| 1. Turn ignition switch OFF. 2. Check for genuine NISSAN fuel filler cap design. | | |
|  | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Replace with genuine NISSAN fuel filler cap. |

SEF915U

| | | |
|---|---|---|
| 2 | CHECK FUEL FILLER CAP INSTALLATION | |
| Check that the cap is tightened properly by rotating the cap clockwise. | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | <ul style="list-style-type: none"> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower. ● Retighten until ratcheting sound is heard. |

| | | |
|--|---------------------------------------|----------|
| 3 | CHECK FUEL FILLER CAP FUNCTION | |
| Check for air releasing sound while opening the fuel filler cap. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

| | | |
|---|---|---|
| 4 | CHECK FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP) | |
| 1. Wipe clean valve housing. 2. Check valve opening pressure and vacuum. | | |
|  | | |
| SEF105W | | |
|  | | |
| SEF943S | | |
| <p>Pressure: 15.3 - 20.0 kPa (0.156 - 0.204 kg/cm², 2.22 - 2.90 psi)</p> <p>Vacuum: -6.0 to -3.3 kPa (-0.061 to -0.034 kg/cm², -0.87 to -0.48 psi)</p> <p>CAUTION: Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace fuel filler cap with a genuine one. |

| | | |
|--|------------------------------|-------------------------------|
| 5 | CHECK EVAP PURGE LINE | |
| Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks, improper connection or disconnection. Refer to "Evaporative Emission System", EC-604. | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Repair or reconnect the hose. |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX



DTC P0455 EVAP CONTROL SYSTEM (GROSS LEAK)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|------------------------------|
| 6 | CLEAN EVAP PURGE LINE |
| Clean EVAP purge line (pipe and rubber tube) using air blower. | |
| ▶ | GO TO 7. |

| | |
|--|---|
| 7 | CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT |
| Refer to "DTC Confirmation Procedure", EC-958. | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG | ▶ Repair or replace EVAP canister vent control valve and O-ring or harness/connector. |

| | |
|--|----------------------------------|
| 8 | INSTALL THE PRESSURE PUMP |
| To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely. | |
|  | |
| AEC649A | |
|  | |
| SEF916U | |
| NOTE: Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking. | |
| Models with CONSULT-II | ▶ GO TO 9. |
| Models without CONSULT-II | ▶ GO TO 10. |


9 CHECK FOR EVAP LEAK

Ⓟ With CONSULT-II

1. Turn ignition switch ON.
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.



PEF917U

4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-607.

Leak detector



SEF200U

OK or NG


| | | |
|----|---|--------------------|
| OK | ▶ | GO TO 11. |
| NG | ▶ | Repair or replace. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

10 CHECK FOR EVAP LEAK

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)



AEC632A


4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:

- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.

5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-607.

Leak detector



SEF200U

OK or NG

| | | |
|----|---|--------------------|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Repair or replace. |

| 11 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION | | | | | | | | | | | | | | | | | | | | | |
|---|--|-----------|-------------|--|-----------------|------|---------|--|---------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|--|--|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port. 2. Start engine. 3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode. 4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%. 5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm. | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <td>PURG VOL CONT/V</td> <td style="text-align: center;">0.0%</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS~RPM(REF)</th> <th>XXX rpm</th> </tr> </thead> <tbody> <tr> <td>FR O2 MNTR-B2</td> <td style="text-align: center;">RICH</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td style="text-align: center;">RICH</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td style="text-align: center;">XXX %</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td style="text-align: center;">XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | PURG VOL CONT/V | 0.0% | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR-B2 | RICH | FR O2 MNTR-B1 | RICH | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | 0.0% | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | RICH | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| <p>Vacuum should exist.</p> <p>OK or NG</p> | | | | | | | | | | | | | | | | | | | | | | |
| PEF882U | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 14. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 13. | | | | | | | | | | | | | | | | | | | | |

| | | |
|--|--|-----------|
| 12 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION | |
| <p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine. 3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port. 4. Start engine and let it idle for at least 80 seconds. 5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm. <p>Vacuum should exist.</p> | | |
| <p>OK or NG</p> | | |
| OK | ▶ | GO TO 15. |
| NG | ▶ | GO TO 13. |

| | | |
|--|--------------------------|-------------------------------|
| 13 | CHECK VACUUM HOSE | |
| <p>Check vacuum hoses for clogging or disconnection. Refer to "Vacuum Hose Drawing", EC-597.</p> | | |
| <p>OK or NG</p> | | |
| OK (With CONSULT-II) | ▶ | GO TO 14. |
| OK (Without CONSULT-II) | ▶ | GO TO 15. |
| NG | ▶ | Repair or reconnect the hose. |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

14 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓟ With CONSULT-II


1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

| ACTIVE TEST | |
|-----------------|---------|
| PURG VOL CONT/V | 0.0% |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 MNTR-B2 | RICH |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B2 | XXX % |
| A/F ALPHA-B1 | XXX % |
| THRTL POS SEN | XXX V |
| | |

PEF882U

If OK, inspection end. If NG, go to following step.

3. Check air passage continuity.



SEF660U

| Condition PURG VOL CONT/V value | Air passage continuity between A and B |
|------------------------------------|---|
| 100.0% | Yes |
| 0.0% | No |


MTBL0241

OK or NG

- | | | |
|----|---|--|
| OK | ▶ | GO TO 16. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

15 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


⊗ Without CONSULT-II
Check air passage continuity.



SEF661U

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No supply | No |

MTBL0242



AEC652A


OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 16. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

16 CHECK ABSOLUTE PRESSURE SENSOR

1. Remove absolute pressure sensor with its harness connector connected.
2. Remove hose from absolute pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM terminal 45 and engine ground.



SEF749U


The voltage should be 3.2 to 4.8V.

4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.




AEC642A

OK or NG

| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 17. |
| NG | ▶ | Replace absolute pressure sensor. |

17 CHECK FUEL TANK TEMPERATURE SENSOR


Check resistance by heating with hot water or heat gun as shown in the figure.



AEC052B

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.3 - 2.7 |
| 50 (122) | 0.79 - 0.90 |

MTBL0234



AEC933A

OK or NG

| | | |
|----|---|---------------------------------------|
| OK | ▶ | GO TO 18. |
| NG | ▶ | Replace fuel tank temperature sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

18 CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.



SEF894U

| Pressure (Relative to atmospheric pressure) | Voltage (V) |
|---|-------------|
| 0 kPa (0 mmHg, 0 inHg) | 3.0 - 3.6 |
| -9.3 kPa (-70 mmHg, -2.76 inHg) | 0.4 - 0.6 |


MTBL0246

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.


CAUTION:

- Never apply force to the air hole protector of the sensor if equipped.



SEF799W

- Discard and EVAP control system pressure sensor which has been dropped from a height of more than 0.5m (19.7in) onto a hard surface such as a concrete floor; use a new one.



AEC651A

OK or NG

OK ► GO TO 19.

NG ► Replace EVAP control system pressure sensor.

DTC P0455 EVAP CONTROL SYSTEM (GROSS LEAK)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 19 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Component Description



Component Description

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM. NGEC0768

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground). NGEC0769

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|----------------------|--|-------------------|
| 29 | G/B | Vehicle speed sensor | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Lift up the vehicle ● In 1st gear position ● Vehicle speed is 40 km/h (25 MPH) | <p>2 - 3V</p> |

On Board Diagnosis Logic

Malfunction is detected when the almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven. NGEC0770

POSSIBLE CAUSE

- Harness or connector (The vehicle speed sensor circuit is open or shorted.)
 - Vehicle speed sensor
- NGEC0770S01

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed. NGEC0771

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

DTC P0500 VEHICLE SPEED SENSOR (VSS)

VG33E

DTC Confirmation Procedure (Cont'd)

| 5 | DATA MONITOR | |
|---|---------------|----------|
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | B/FUEL SCHDL | XXX msec |
| | PW/ST SIGNAL | OFF |
| | VHCL SPEED SE | XXX km/h |

PEF199V

With CONSULT-II

- 1) Start engine
- 2) Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
If NG, go to "Diagnostic Procedure", EC-991.
If OK, go to following step.
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Warm engine up to normal operating temperature.
- 5) Maintain the following conditions for at least 10 consecutive seconds.

| | |
|----------------|--|
| CMPS-RPM (REF) | 1,400 - 2,800 rpm (A/T models) 2,000 - 3,000 rpm (M/T models) |
| COOLAN TEMP/S | More than 70°C (158°F) |
| B/FUEL SCHDL | 2.3 - 4.5 msec (A/T models) 3.1 - 5.5 msec (M/T models) |
| Selector lever | Suitable position |
| PW/ST SIGNAL | OFF |

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-991.

Overall Function Check

Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a 1st trip DTC might not be confirmed.

With GST

- 1) Lift up drive wheels.
- 2) Start engine.
- 3) Read vehicle speed sensor signal in "MODE 1" with GST. The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
- 4) If NG, go to "Diagnostic Procedure", EC-991.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0500 VEHICLE SPEED SENSOR (VSS)





VG33E

Wiring Diagram

Wiring Diagram

NGEC0773

EC-VSS-01



Refer to the following.
 (F29) - ELECTRICAL UNITS

AEC962A

Diagnostic Procedure

NGEC0774

| | | |
|--|---|----------|
| 1 | CHECK VEHICLE SPEED SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector and combination meter harness connector. 3. Check harness continuity between ECM terminal 29 and meter terminal 34. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. <div style="text-align: center;">OK or NG</div> | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

GI
MA
EM
LC

| | | |
|--|-----------------------------------|--|
| 2 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors M81, F36 ● Harness for open or short between ECM and combination meter | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

EC
FE
CL

| | | |
|--|-----------------------------------|----------|
| 3 | CHECK SPEEDOMETER FUNCTION | |
| Make sure that speedometer functions properly. <div style="text-align: center;">OK or NG</div> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

MT
AT
TF

| | | |
|--|---|--|
| 4 | CHECK SPEEDOMETER CIRCUIT FOR OPEN AND SHORT | |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors M58, F28 ● Harness connectors F43, F201 ● Harness for open or short between combination meter and vehicle speed sensor <div style="text-align: center;">OK or NG</div> | | |
| OK | ▶ | Check combination meter and vehicle speed sensor. Refer to EL section. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

PD
AX
SU
BR

| | | |
|---|------------------------------------|-----------------------|
| 5 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. <div style="text-align: center;">▶</div> | | |
| | | INSPECTION END |

ST
RS

BT
HA
SC
EL

IDX

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

VG33E

Description


Description SYSTEM DESCRIPTION

NGEC0775

NGEC0775S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|------------------------------------|-----------------------------|------------------|----------------|
| Camshaft position sensor | Engine speed | Idle air control | IACV-AAC valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| Park/neutral position (PNP) switch | Park/neutral position | | |
| Air conditioner switch | Air conditioner operation | | |
| Power steering oil pressure switch | Power steering load signal | | |
| Battery | Battery voltage | | |
| Vehicle speed sensor | Vehicle speed | | |
| Ambient air temperature switch | Ambient air temperature | | |
| Intake air temperature sensor | Intake air temperature | | |
| Absolute pressure sensor | Ambient barometric pressure | | |

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner and power steering).



COMPONENT DESCRIPTION IACV-AAC Valve

NGEC0775S02

NGEC0775S0201

The IACV-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

VG33E

CONSULT-II Reference Value in Data Monitor Mode

CONSULT-II Reference Value in Data Monitor Mode

NGEC0776

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|-----------|---------------|
| IACV-AAC/V | <ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load | Idle | 10 - 20% |
| | | 2,000 rpm | — |

ECM Terminals and Reference Value

NGEC0777

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|----------------|---|-------------------------------|
| 101 | OR/L | IACV-AAC valve | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>8 - 11V</p> <p>SEF005V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 3,000 rpm | <p>7 - 10V</p> <p>SEF692W</p> |

On Board Diagnosis Logic

NGEC0778

Malfunction is detected when
 (Malfunction A) the IACV-AAC valve does not operate properly,
 (Malfunction B) the IACV-AAC valve does not operate properly.

POSSIBLE CAUSE

NGEC0778S01

- Harness or connectors
(The IACV-AAC valve circuit is open.)
- Harness or connectors
(The IACV-AAC valve circuit is shorted.)
- IACV-AAC valve

DTC Confirmation Procedure

NGEC0779

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

VG33E

DTC Confirmation Procedure (Cont'd)

2

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| COOLAN TEMP/S | XXX °C |

PEF002P

PROCEDURE FOR MALFUNCTION A

NGEC0779S01

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch "ON".

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 2 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-996.

With GST

Follow the procedure "With CONSULT-II".

4

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |

PEF361V

PROCEDURE FOR MALFUNCTION B

NGEC0779S02

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON again and select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine and run it for at least 1 minute at idle speed.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-996.

With GST

Follow the procedure "With CONSULT-II".

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE


VG33E

Wiring Diagram

Wiring Diagram

NGEC0780



EC-AAC/V-01



Refer to "EL-POWER".

— : Detectable line for DTC
 — : Non-detectable line for DTC

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST



RS
 BT
 HA
 SC

AEC963A



DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0781

| | |
|--|--|
| 1 | CHECK IACV-AAC VALVE POWER SUPPLY CIRCUIT |
| <p>1. Stop engine. 2. Disconnect IACV-AAC valve harness connector.</p> <div style="text-align: center;">  </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 3. |
| NG | ▶ GO TO 2. |

SEF007S

SEF651W

| | |
|--|-----------------------------------|
| 2 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M81, F36 ● Harness connectors F37, F101 ● Fuse block (J/B) connector M27 ● 10A fuse ● Harness for open or short between IACV-AAC valve and fuse | |
| ▶ | Repair harness or connectors. |

| | |
|--|--|
| 3 | CHECK IACV-AAC VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 101 and IACV-AAC valve terminal 1. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |


DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors F101, F37 ● Harness for open or short between IACV-AAC valve and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
MA


| | |
|---|-----------------------------|
| 5 | CHECK IACV-AAC VALVE |
| 1. Disconnect IACV-AAC valve harness connector. 2. Remove IACV-AAC valve. <ul style="list-style-type: none"> ● Check IACV-AAC valve resistance. | |
|  | |
| SEF202V | |
| <p>Resistance: Approximately 10Ω [at 20°C (68°F)]</p> <ul style="list-style-type: none"> ● Check plunger for seizing or sticking. ● Check for broken spring. 3. Supply battery voltage between IACV-AAC valve connector terminals. Plunger should move. | |
| OK or NG | |
| OK | ▶ GO TO 6. |
| NG | ▶ Replace IACV-AAC valve. |

EM
LC
EC
FE
CL
MT
AT
TF
PD
AX

| | |
|---|------------------------------------|
| 6 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

SU
BR
ST
RS
BT
HA
SC
EL
IDX

Component Description



Component Description

NGEC0782

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control.

When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge volume control solenoid valve when the throttle position sensor is malfunctioning.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0783

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|---|--------------------------------------|
| CLSD THL/P SW | ● Engine: After warming up, idle the engine | Throttle valve: Idle position ON |
| | | Throttle valve: Slightly open OFF |

ECM Terminals and Reference Value

NGEC0784

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TER-MINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|--|---|----------------------------|
| 28 | BR/W | Throttle position switch (Closed position) | [Engine is running] ● Warm-up condition ● Accelerator pedal fully released | BATTERY VOLTAGE (11 - 14V) |
| | | | [Ignition switch "ON"] ● Accelerator pedal depressed | Approximately 0V |

On Board Diagnosis Logic

NGEC0785

Malfunction is detected when battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened.

POSSIBLE CAUSE

NGEC0785S01

- Harness or connectors (The closed throttle position switch circuit is shorted.)
- Closed throttle position switch
- Throttle position sensor

NGEC0786

4

| DATA MONITOR | |
|----------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM (REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| CLSD THL/PS | ON |

SEF377X

6

| DATA MONITOR | |
|---------------|----------|
| MONITORING | NO FAIL |
| COOLAN TEMP/S | XXX °C |
| VHCL SPEED SE | XXX km/h |
| THRT POS SEN | XXX V |

PEF329U

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

④ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF, wait at least 5 seconds and then start engine.
- 3) Select "CLSD THL/P SW" in "DATA MONITOR" mode.
- 4) Check the signal under the following conditions.

| Condition | Signal indication |
|-------------------------------|-------------------|
| Throttle valve: Idle position | ON |
| Throttle valve: Slightly open | OFF |

If the result is NG, go to "Diagnostic Procedure", EC-1001.
If OK, go to following step.

- 5) Select "DATA MONITOR" mode with CONSULT-II.
- 6) Drive the vehicle for at least 5 consecutive seconds under the following condition.

| | |
|------------------|--|
| THRTL POS SEN | More than 2.5V |
| VHCL SPEED SE | More than 5 km/h (3 MPH) |
| Selector lever | Suitable position |
| Driving location | Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test. |

- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1001.

Overall Function Check

Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.


⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the voltage between ECM terminal 28 (Closed throttle position switch signal) and ground under the following conditions.

At idle: Battery voltage

At 2,000 rpm: Approximately 0V

- 3) If NG, go to "Diagnostic Procedure", EC-1001.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0510 CLOSED THROTTLE POSITION SWITCH






VG33E

Wiring Diagram

Wiring Diagram

NGEC0788



EC-TP/SW-01



AEC964A

Diagnostic Procedure

NGE0789

| | | |
|---|---|----------|
| 1 | CHECK CLOSED THROTTLE POSITION SWITCH POWER SUPPLY CIRCUIT | |
| 1. Turn ignition switch OFF. 2. Disconnect throttle position switch harness connector. | | |
|  <p style="text-align: right; margin-right: 50px;">Throttle position switch harness connector</p> | | |
| 3. Turn ignition switch ON. 4. Check voltage between terminal 5 and engine ground with CONSULT-II or tester. | | |
| AEC653A | | |
|  | | |
| SEF715U | | |
| Voltage: Battery voltage | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

| | | |
|---|-----------------------------------|-------------------------------|
| 2 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness for open or short between throttle position switch and ECM relay ● Harness for open or short between throttle position switch and ECM | | |
| ▶ | | Repair harness or connectors. |

| | | |
|---|--|--|
| 3 | CHECK CLOSED THROTTLE POSITION SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 28 and switch terminal 4. Refer to Wiring Diagram. Continuity should exist. | | |
| 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

 GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


DTC P0510 CLOSED THROTTLE POSITION SWITCH

VG33E

Diagnostic Procedure (Cont'd)

| 4 | | ADJUST THROTTLE POSITION SWITCH | | | | | | | | | | | | |
|---|--|--|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|--|--|
| Check the following items. Refer to "Basic Inspection", EC-669. | | | | | | | | | | | | | | |
| | | <table border="1"><thead><tr><th>Items</th><th>Specifications</th></tr></thead><tbody><tr><td>Ignition timing</td><td>15° ± 2° BTDC</td></tr><tr><td>Base idle speed</td><td>700 ± 50 rpm (in "P" or "N" position)</td></tr><tr><td>Closed throttle position switch idle position adjustment</td><td>Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF</td></tr><tr><td>Target idle speed</td><td>750 ± 50 rpm (in "P" or "N" position)</td></tr></tbody></table> | Items | Specifications | Ignition timing | 15° ± 2° BTDC | Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | |
| Items | Specifications | | | | | | | | | | | | | |
| Ignition timing | 15° ± 2° BTDC | | | | | | | | | | | | | |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | | | | | | | | | | | | | |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | | | |
| MTBL0226 | | | | | | | | | | | | | | |
| with CONSULT-II | ▶ | GO TO 5. | | | | | | | | | | | | |
| without CONSULT-II | ▶ | GO TO 6. | | | | | | | | | | | | |

| 5 | | CHECK CLOSED THROTTLE POSITION SWITCH | | | | | | | | |
|---|------------|---|---------------------------|------------|-------------------|-----|-----------------------------------|----|--|--|
|  With CONSULT-II | | | | | | | | | | |
| <ol style="list-style-type: none">1. Start engine and warm it up to normal operating temperature.2. Turn ignition switch OFF.3. Remove vacuum hose connected to throttle opener (If so equipped).4. Connect suitable vacuum hose to vacuum pump and the throttle opener.5. Apply vacuum [more than -40.0kPa (-300mmHg, -11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener.6. Turn ignition switch ON.7. Select "DATA MONITOR" mode with CONSULT-II.8. Check indication of "CLSD THL/P SW". | | | | | | | | | | |
| Measurement must be made with closed throttle position switch installed in vehicle. | | | | | | | | | | |
| | | <table border="1"><thead><tr><th>Throttle valve conditions</th><th>Continuity</th></tr></thead><tbody><tr><td>Completely closed</td><td>Yes</td></tr><tr><td>Partially open or completely open</td><td>No</td></tr></tbody></table> | Throttle valve conditions | Continuity | Completely closed | Yes | Partially open or completely open | No | | |
| Throttle valve conditions | Continuity | | | | | | | | | |
| Completely closed | Yes | | | | | | | | | |
| Partially open or completely open | No | | | | | | | | | |
| MTBL0247 | | | | | | | | | | |
| OK or NG | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | |
| NG | ▶ | GO TO 7. | | | | | | | | |

| 6 | CHECK CLOSED THROTTLE POSITION SWITCH | <p>Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Remove vacuum hose connected to throttle opener (If so equipped). 4. Connect suitable vacuum hose to vacuum pump and the throttle opener. 5. Apply vacuum [more than -40.0kPa (-300mmHg, -11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener. 6. Disconnect closed throttle position switch harness connector. 7. Check continuity between closed throttle position switch terminals 4 and 5. <p>Resistance measurement must be made with closed throttle position switch installed in vehicle.</p> <div style="text-align: center;">  <p style="text-align: right; margin-right: 50px;">Throttle position switch harness connector</p> </div> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Throttle valve conditions</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>Completely closed</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>Partially open or completely open</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | Throttle valve conditions | Continuity | Completely closed | Yes | Partially open or completely open | No |
|-----------------------------------|--|---|---------------------------|------------|-------------------|-----|-----------------------------------|----|
| Throttle valve conditions | Continuity | | | | | | | |
| Completely closed | Yes | | | | | | | |
| Partially open or completely open | No | | | | | | | |

AEC654A

| 7 | ADJUST THROTTLE POSITION SWITCH | <p>Check the following items. Refer to "Basic Inspection", EC-669.</p> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Items</th> <th style="width: 50%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>15° ± 2° BTDC</td> </tr> <tr> <td>Base idle speed</td> <td>700 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>750 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 10px;">MTBL0226</p> <p>If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="margin-top: 10px; border-collapse: collapse;"> <tr> <td>OK (with CONSULT-II)</td> <td style="text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>OK (without CONSULT-II)</td> <td style="text-align: center;">▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace throttle position switch.</td> </tr> </table> | Items | Specifications | Ignition timing | 15° ± 2° BTDC | Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | OK (with CONSULT-II) | ▶ | GO TO 8. | OK (without CONSULT-II) | ▶ | GO TO 9. | NG | ▶ | Replace throttle position switch. |
|--|--|--|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|----------------------|---|----------|-------------------------|---|----------|----|---|-----------------------------------|
| Items | Specifications | | | | | | | | | | | | | | | | | | | | |
| Ignition timing | 15° ± 2° BTDC | | | | | | | | | | | | | | | | | | | | |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | | | | | | | | | | | | | | | | | | | | |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | | | | | | | | | | |
| OK (with CONSULT-II) | ▶ | GO TO 8. | | | | | | | | | | | | | | | | | | | |
| OK (without CONSULT-II) | ▶ | GO TO 9. | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace throttle position switch. | | | | | | | | | | | | | | | | | | | |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0510 CLOSED THROTTLE POSITION SWITCH


VG33E

Diagnostic Procedure (Cont'd)

8 CHECK THROTTLE POSITION SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Remove the vacuum hose connected to the throttle opener (If so equipped).
4. Connect suitable vacuum hose to the vacuum pump and the opener.
5. Apply vacuum [more than -40.0kPa (-300mmHg, -11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener.



SEF793W

6. Turn ignition switch ON.
7. Select "DATA MONITOR" mode with CONSULT-II.
8. Check voltage of "THRTL POS SEN".

| DATA MONITOR | |
|----------------|---------|
| MONITORING | NO FAIL |
| CMPS-RPM (REF) | XXXrpm |
| COOLAN TEMP/S | XXX°C |
| THRTL POS SEN | XXXV |

| Throttle valve conditions | THRTL POS SEN |
|---------------------------|---------------------|
| Completely closed (a) | 0.15 - 0.85V |
| Partially open | Between (a) and (b) |
| Completely open (b) | 3.5 - 4.7V |

SEF182X

Voltage measurement must be made with throttle position sensor installed in vehicle.

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-669.


OK or NG

| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace throttle position sensor. |

9 CHECK THROTTLE POSITION SENSOR

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Remove the vacuum hose connected to the throttle opener (If so equipped).
4. Connect suitable vacuum hose to the vacuum pump and the opener.
5. Apply vacuum [more than -40.0kPa (-300mmHg, -11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener.



SEF793W

6. Turn ignition switch ON.
7. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground.
Voltage measurement must be made with throttle position sensor installed in vehicle.

| Throttle valve conditions | Voltage |
|---------------------------|---------------------|
| Completely closed (a) | 0.15 - 0.85V |
| Partially open | Between (a) and (b) |
| Completely open (b) | 3.5 - 4.7V |

MTBL0231

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-669.

OK or NG

| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace throttle position sensor. |

10 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

| | | |
|--|---|-----------------------|
| | ▶ | INSPECTION END |
|--|---|-----------------------|

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

System Description

System Description

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/ deceleration. NGEC0790

Voltage signals are exchanged between ECM and TCM (Transmission Control Module).

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground). NGEC0791


| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|------------------|---|-------------------|
| 26 | PU/W | A/T signal No. 1 | [Ignition switch "ON"] [Engine is running] ● Idle speed | 6 - 8V |
| 27 | P/B | A/T signal No. 2 | [Ignition switch "ON"] [Engine is running] ● Idle speed | 6 - 8V |
| 35 | G/R | A/T signal No. 3 | [Ignition switch "ON"] | 0V |

On Board Diagnosis Logic

Malfunction is detected when ECM receives incorrect voltage from TCM (Transmission Control Module) continuously. NGEC0792

POSSIBLE CAUSE

- Harness or connectors
[The circuit between ECM and TCM (Transmission Control Module) is open or shorted.] NGEC0792S01



DTC Confirmation Procedure


=NGEC0793

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine, and rev engine more than 1,000 rpm once, then let it idle for more than 40 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-1009.



Overall Function Check

NGEC0794

Use this procedure to check the overall function of the A/T control circuit. During this check, a DTC might not be confirmed.

ⓧ Without CONSULT-II

- 1) Start engine.
- 2) Check voltage between ECM terminal 26 and ground.
ECM terminal 27 and ground.
Voltage: 6 - 8V
- 3) If NG, go to "Diagnostic Procedure", EC-1009.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

Wiring Diagram

NGEC0795

EC-AT/C-01



: Detectable line for DTC
 : Non-detectable line for DTC



AEC965A

Diagnostic Procedure

NGE0796

| | | | |
|----------|--|--|----------|
| 1 | CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR OPEN | | |
| | | 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector. | |
| | | Driver side  | SEF324V |
| | | View with instrument lower panel LH removed  | AEC655A |
| | | 3. Check harness continuity between ECM terminal 26 and terminal 5, ECM terminal 27 and terminal 6, ECM terminal 35 and terminal 7. Refer to Wiring Diagram. Continuity should exist. | |
| | | OK or NG | |
| | OK | ▶ | GO TO 3. |
| | NG | ▶ | GO TO 2. |

| | | | |
|----------|-----------------------------------|---|-------------------------------|
| 2 | DETECT MALFUNCTIONING PART | | |
| | | Check the following. <ul style="list-style-type: none"> ● Harness connectors M58, F28 ● Harness for open or short between ECM and TCM (Transmission Control Module) | |
| | | ▶ | Repair harness or connectors. |

| | | | |
|----------|---|--|----------|
| 3 | CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR SHORT | | |
| | | 1. Check harness continuity between ECM terminal 26 and ground, ECM terminal 27 and ground, ECM terminal 35 and ground. Refer to Wiring Diagram. Continuity should not exist. | |
| | | 2. Also check harness for short to power. | |
| | | OK or NG | |
| | OK | ▶ | GO TO 5. |
| | NG | ▶ | GO TO 4. |


 GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0600 A/T CONTROL

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the harness for open or short between ECM and TCM (Transmission Control Module). | |
| ▶ | Repair open circuit or short to ground or short to power in harness. |
| 5 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |



Component Description

The ECM consists of a microcomputer, diagnostic test mode selector, and connectors for signal input and output and for power supply. The unit controls the engine.

NGEC0797

GI

MA

EM

LC

On Board Diagnosis Logic

Malfunction is detected when ECM calculation function is malfunctioning.

NGEC0798

EC

POSSIBLE CAUSE

- ECM

NGEC0798S01

FE

CL

MT

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


NGEC0799

AT

TF

PD

AX



With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Start engine.
- 4) Run engine for at least 2 seconds at idle speed.
- 5) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-1012.

With GST

Follow the procedure “With CONSULT-II”.

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Diagnostic Procedure

NGEC0800

| | | |
|---|-------------------------|-----------------------|
| 1 | INSPECTION START | |
| <p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Select "SELF DIAG RESULTS" mode with CONSULT-II. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See EC-1011. 5. Is the 1st trip DTC P0605 displayed again? | | |
| <p> With GST</p> <ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Select MODE 4 with GST. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See EC-1011. 5. Is the 1st trip DTC P0605 displayed again? | | |
| <p> No Tools</p> <ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to EC-640. 3. Perform "DTC Confirmation Procedure". See EC-1011. 4. Is the 1st trip DTC 0301 displayed again? | | |
| Yes or No | | |
| Yes | ▶ | Replace ECM. |
| No | ▶ | INSPECTION END |


Description SYSTEM DESCRIPTION

NGEC0801
NGEC0801S01

| Sensor | Input Signal to ECM | ECM func-tion | Actuator |
|--------------------------|---------------------|--------------------|--------------------------------|
| Camshaft position sensor | Engine speed | On board diagnosis | MAP/BARO switch solenoid valve |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| Vehicle speed sensor | Vehicle speed | | |

This system allows the absolute pressure sensor to monitor either ambient barometric pressure or intake manifold pressure. The MAP/BARO switch solenoid valve switches between two passages by ON-OFF pulse signals from the ECM. (One passage is from the intake air duct, the other is from the intake manifold.) Either ambient barometric pressure or intake manifold pressure is applied to the absolute pressure sensor.

| Solenoid | Conditions |
|----------|---|
| ON | <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch ON (Engine is not running.) <li style="text-align: center;">or ● For 5 seconds after starting engine <li style="text-align: center;">or ● More than 5 minutes after the solenoid valve shuts OFF. |



COMPONENT DESCRIPTION

NGEC0801S02

The MAP/BARO switch solenoid valve switches its air flow passage according to the voltage signal sent from the ECM. When voltage is supplied from the ECM, the MAP/BARO switch solenoid turns "ON". Then, the absolute pressure sensor can monitor the ambient barometric pressure. When voltage is not supplied from the ECM, the MAP/BARO switch solenoid valve turns "OFF". Then, the sensor monitors intake manifold pressure.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0802

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION | |
|---------------|--|---|------|
| MAP/BARO SW/V | ● Ignition switch: ON (Engine stopped) | MAP | |
| | ● Engine speed: Idle | For 5 seconds after starting engine | BARO |
| | | More than 5 seconds after starting engine | MAP |

ECM Terminals and Reference Value

NGEC0803

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|-------------------------------------|---|-------------------------------|
| 118 | Y/B | MAP/BARO switch sole- noid valve | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine is not running ● For 5 seconds after ignition switch is turned ON | 0 - 1V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle (for 5 seconds after engine start) | |
| | | | [Ignition switch ON] <ul style="list-style-type: none"> ● Engine is not running ● More than 5 seconds after ignition switch is turned ON | BATTERY VOLTAGE (11 - 14V) |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle (More than 5 seconds after engine start) | |

On Board Diagnosis Logic

NGEC0804

Malfunction is detected when (Malfunction A) MAP/BARO switch solenoid valve receives the voltage supplied though ECM does not supply the voltage to the valve, (Malfunction B) There is little difference between MAP/BARO switch solenoid valve input voltage at ambient barometric pressure and voltage at intake manifold pressure.

POSSIBLE CAUSE

NGEC0804S01

Malfunction A

NGEC0804S0101

- Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.)
- MAP/BARO switch solenoid valve

Malfunction B

NGEC0804S0102

- Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.)
- Hoses (Hoses are clogged, vent, kinked, disconnected or improper connection.)
- Absolute pressure sensor
- MAP/BARO switch solenoid valve

DTC Confirmation Procedure

NGEC0805

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

| | | |
|----------|---------------|---------|
| 1 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | | |

PEF360V

PROCEDURE FOR MALFUNCTION A

NGEC0805S01

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at ignition switch "ON".

 **With CONSULT-II**

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Wait at least 10 seconds.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1017.

 **With GST**

Follow the procedure "With CONSULT-II".

GI
MA
EM
LC

EC

FE

CL

MT

| | | |
|----------|---------------|---------|
| 5 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | TANK F/TMP SE | XXX °C |

PEF398V

PROCEDURE FOR MALFUNCTION B

NGEC0805S02

 **With CONSULT-II**

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON again and select "DATA MONITOR" mode with CONSULT-II.
- 4) Make sure that "TANK F/TMP SE" is more than 0°C (32°F).
- 5) Start engine and let it idle for at least 10 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1017.

 **With GST**

Follow the procedure "With CONSULT-II".

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

Wiring Diagram

NGEC0806

EC-SW/V-01





Diagnostic Procedure

If the trouble is duplicated after “PROCEDURE FOR MALFUNCTION A”, perform “PROCEDURE A” below. If the trouble is duplicated after “PROCEDURE FOR MALFUNCTION B”, perform “PROCEDURE B” on next page.

PROCEDURE A

NGEC0807

NGEC0807S01

| | | |
|---|--|----------|
| 1 | CHECK MAP/BARO SWITCH SOLENOID VALVE POWER SUPPLY CIRCUIT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect MAP/BARO switch solenoid valve harness connector.</p> <div style="text-align: center;">  <p>MAP/BARO switch solenoid valve harness connector Air duct</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>DISCONNECT T.S.</p> </div> <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

AEC650A

SEF653W

| | | |
|---|-----------------------------------|--|
| 2 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuse block (J/B) connector E49 ● 10A fuse ● Harness for open or short between MAP/BARO switch solenoid valve and fuse | | |
| ▶ | Repair harness or connectors. | |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1105 MAP/BARO SWITCH SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 3 | CHECK MAP/BARO SWITCH SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| 1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 118 and solenoid valve terminal 2. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |

| | |
|---|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none">● Harness connectors E74, M82● Harness connectors M81, F36● Harness for open or short between MAP/BARO switch solenoid valve and ECM | |
| | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

5 CHECK MAP/BARO SWITCH SOLENOID VALVE

Ⓟ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Check the following.
 - Condition: At idle under no-load
 - CONSULT-II display

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | MAP |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | MAP |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | BARO |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | BARO |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| MAP/BARO | ABSOL PRES/SE (Voltage) |
|----------|-------------------------------|
| BARO | More than 2.6V |
| MAP | Less than the voltage at BARO |

- Time for voltage to change

| MAP/BARO SW/V | Required time to switch |
|---------------|-------------------------|
| BARO to MAP | Less than 1 second |
| MAP to BARO | |


SEF181X

MTBL0244

4. If NG, check solenoid valve as shown below.

ⓧ Without CONSULT-II

1. Remove MAP/BARO switch solenoid valve.
2. Check air passage continuity.



MEC488B

| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

MTBL0237

3. If NG or operation takes more than 1 second, replace solenoid valve.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace MAP/BARO switch solenoid valve. |

6 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.



| | | |
|--|---|-----------------------|
| | ▶ | INSPECTION END |
|--|---|-----------------------|

PROCEDURE B

=NGEC0807S02

1 INSPECTION START

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Attach the vacuum gauge between MAP/BARO switch solenoid valve and rubber tube connected to absolute pressure sensor.


AEC650A

SEF676T

Models with CONSULT-II ► GO TO 2.

Models without CON-SULT-II ► GO TO 3.

2 CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR

Ⓟ With CONSULT-II

1. Start engine and let it idle.
2. Select "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "MAP" and "BARO" alternately and check for vacuum.

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | MAP |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | MAP |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | BARO |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | BARO |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| | |
|---------------|------------------|
| MAP/BARO SW/V | Vacuum |
| BARO | Should not exist |
| MAP | Should exist |

SEF183X


OK or NG

OK ► GO TO 12.


NG ► GO TO 4.

| 3 | CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR | | | | | | | |
|--|--|-----------|-----------|--------|-------------------------------------|------------------|---|--------------|
| <p>⊗ Without CONSULT-II</p> <p>1. Start engine and let it idle.</p> <p>2. Check for vacuum under the following condition.</p> | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Vacuum</th> </tr> </thead> <tbody> <tr> <td>For 5 seconds after starting engine</td> <td>Should not exist</td> </tr> <tr> <td>More than 5 seconds after starting engine</td> <td>Should exist</td> </tr> </tbody> </table> | | | Condition | Vacuum | For 5 seconds after starting engine | Should not exist | More than 5 seconds after starting engine | Should exist |
| Condition | Vacuum | | | | | | | |
| For 5 seconds after starting engine | Should not exist | | | | | | | |
| More than 5 seconds after starting engine | Should exist | | | | | | | |
| MTBL0080 | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | GO TO 12. | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |


GI
MA
EM
LC
EC

| | | |
|--|--------------------------|--------------------------------------|
| 4 | CHECK VACUUM HOSE | |
| <p>1. Turn ignition switch OFF.</p> <p>2. Check hose for clogging, cracks, disconnection or improper connection.</p> | | |
|  | | |
| SEF109L | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Clean, repair or reconnect the hose. |

FE
CL
MT
AT
TF
PD
AX
SU

| | | |
|--|--------------------------|----------------------------------|
| 5 | CHECK VACUUM PORT | |
| Check vacuum port for clogging. | | |
|  | | |
| SEF368U | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Clean or repair the vacuum port. |

BR
ST
RS
BT
HA
SC
EL

| | | |
|--|--|----------|
| 6 | CHECK MAP/BARO SWITCH SOLENOID VALVE POWER SUPPLY CIRCUIT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect MAP/BARO switch solenoid valve harness connector. 3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> | | |
|  | | |
| <p>Voltage: Battery voltage</p> <p>OK or NG</p> | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | GO TO 7. |

SEF653W

| | | |
|---|-----------------------------------|-------------------------------|
| 7 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Fuse block (J/B) connector E49 ● 10A fuse ● Harness for open or short between MAP/BARO switch solenoid valve and fuse | | |
| ▶ | | Repair harness or connectors. |

| | | |
|--|--|-----------|
| 8 | CHECK MAP/BARO SWITCH SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 118 and solenoid valve terminal 2. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> | | |
| <p>OK or NG</p> | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | GO TO 9. |

| | | |
|--|-----------------------------------|--|
| 9 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M81, F36 ● Harness for open or short between MAP/BARO switch solenoid valve and ECM | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

10 CHECK MAP/BARO SWITCH SOLENOID VALVE

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Check the following.
 - Condition: At idle under no-load
 - CONSULT-II display

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | MAP |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | MAP |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| ACTIVE TEST | |
|----------------|--------|
| MAP/BARO SW/V | BARO |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| MAP/BARO SW/V | BARO |
| ABSOL PRES/SE | XXXV |
| | |
| | |
| | |
| | |

| MAP/BARO | ABSOL PRES/SE (Voltage) |
|----------|-------------------------------|
| BARO | More than 2.6V |
| MAP | Less than the voltage at BARO |

- Time for voltage to change

| MAP/BARO SW/V | Required time to switch |
|---------------|-------------------------|
| BARO to MAP | Less than 1 second |
| MAP to BARO | |


SEF181X

MTBL0244

4. If NG, check solenoid valve as shown below.

Without CONSULT-II

1. Remove MAP/BARO switch solenoid valve.
2. Check air passage continuity.



MEC488B

| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

MTBL0237

3. If NG or operation takes more than 1 second, replace solenoid valve.

OK or NG


| | | |
|----|---|---|
| OK | ▶ | GO TO 11. |
| NG | ▶ | Replace MAP/BARO switch solenoid valve. |

DTC P1105 MAP/BARO SWITCH SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|------------------------------------|----------------------------|------------|
| 11 | CHECK INTAKE SYSTEM | |
| Check intake system for air leaks. | | |
| OK or NG | | |
| OK | ▶ | GO TO 15. |
| NG | ▶ | Repair it. |


| | | |
|--|---|---------------------------|
| 12 | CHECK HOSE BETWEEN ABSOLUTE PRESSURE SENSOR AND MAP/BARO SWITCH SOLENOID VALVE | |
| Check hose for clogging, cracks, disconnection or improper connection. | | |
|  | | |
| SEF109L | | |
| OK or NG | | |
| OK | ▶ | GO TO 13. |
| NG | ▶ | Repair or reconnect hose. |

| | | |
|---|--------------------------------|--------------------------------------|
| 13 | CHECK HARNESS CONNECTOR | |
| <ol style="list-style-type: none"> 1. Disconnect absolute pressure sensor harness connector. 2. Check sensor harness connector for water. <p>Water should not exist.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | Repair or replace harness connector. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

14 CHECK ABSOLUTE PRESSURE SENSOR

1. Remove absolute pressure sensor with its harness connector connected.
2. Remove hose from absolute pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM terminal 45 and engine ground.



SEF749U

The voltage should be 3.2 to 4.8V.

4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

| | | |
|----|---|-----------------------------------|
| OK | ▶ | GO TO 15. |
| NG | ▶ | Replace absolute pressure sensor. |

15 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

▶ **INSPECTION END**

DTC P1148 (RIGHT BANK, -B1), P1168 (LEFT BANK, -B2) CLOSED LOOP CONTROL

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

★ The closed loop control has the one trip detection logic. NGEC0808

Malfunction is detected when the closed loop control function for right bank does not operate even when vehicle is driving in the specified condition, the closed loop control function for left bank does not operate even when vehicle is driving in the specified condition.

POSSIBLE CAUSE

- The front heated oxygen sensor circuit is open or shorted. NGEC0808S01
- Front heated oxygen sensor
- Front heated oxygen sensor heater

DTC Confirmation Procedure

NGEC0809

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Never raise engine speed above 3,200 rpm during the “DTC Confirmation Procedure”. If the engine speed limit is exceeded, retry the procedure from step 2.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

| 3 | DATA MONITOR | |
|---------------|---------------|---------|
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | MAS AIR/FL SE | XXX V |
| | FR O2 SEN-B1 | XXX V |
| | FR O2 SEN-B2 | XXX V |
| | FR O2 MNTR-B1 | RICH |
| FR O2 MNTR-B2 | RICH | |

PEF392V

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Hold engine speed at 2,000 rpm and check one of the following.
 - “FR O2 SEN-B1 (-B2)” voltage should go above 0.70V at least once.
 - “FR O2 SEN-B1 (-B2)” voltage should go below 0.21V at least once.If the check result is NG, perform “Diagnosis Procedure”, EC-1027.

EC-1026

DTC P1148 (RIGHT BANK, -B1), P1168 (LEFT BANK, -B2) CLOSED LOOP CONTROL

VG33E

DTC Confirmation Procedure (Cont'd)


If the check result is OK, perform the following step.

- 4) Let engine idle at least 5 minutes.
- 5) Maintain the following condition at least 50 consecutive seconds.

| | |
|----------------|--|
| B/FUEL SCHDL | 1.6 msec or more (A/T models) 2.0 msec or more (M/T models) |
| CMPS-RPM (POS) | 1,600 rpm or more (A/T models) 1,900 rpm or more (M/T models) |
| Selector lever | Suitable position |
| VHCL SPEED SE | More than 71 km/h (44 MPH) |

During this test, P0130 and/or P0150 may be displayed on CONSULT-II screen.

- 6) If DTC is detected, go to "Diagnostic Procedure", EC-1027.



Overall Function Check

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.


⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 50 (front heated oxygen sensor right bank signal) or 51 (front heated oxygen sensor left bank signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no-load.
 - The voltage should go above 0.70V at least once.
 - The voltage should go below 0.21V at least once.
- 4) If NG, go to "Diagnostic Procedure", EC-1027.

Diagnostic Procedure

Perform trouble diagnosis for "DTC P0133, P0153", EC-788.

Component Description



Component Description

NGEC0812

IGNITION COIL & POWER TRANSISTOR

NGEC0812S01

The power transistor switches on and off the ignition coil primary circuit according to the ECM signal. As the primary circuit is turned on and off, the proper high voltage is induced in the secondary circuit. The distributor is not repairable except for the distributor cap and rotor head.

NOTE:

The rotor screw which secures the distributor rotor head to the distributor shaft must be torqued properly.

: **3.6±0.3 N·m (37±3 kg-cm, 32±3 in-lb)**

ECM Terminals and Reference Value

NGEC0813

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|-----------------|---|---------------------------|
| 1 | PU/W | Ignition signal | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed | <p>Approximately 0.7V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>1.1 - 1.5V</p> |
| 2 | B | Ignition check | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>Approximately 12V</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. | <p>Approximately 11V</p> |

On Board Diagnosis Logic

Malfunction is detected when the ignition signal in the primary circuit is not sent to ECM during engine cranking or running.

NGEC0814

GI

POSSIBLE CAUSE

- Harness or connectors (The ignition primary circuit is open or shorted.)
- Power transistor unit.
- Resistor
- Camshaft position sensor
- Camshaft position sensor circuit

NGEC0814S01

MA

EM

LC

DTC Confirmation Procedure

NGEC0815

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- **If DTC P1320 (0201) is displayed with DTC P0340 (0101), perform trouble diagnosis for DTC P0340 first. Refer to EC-912.**

EC

FE

CL

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine. (If engine does not run, turn ignition switch to START for at least 5 seconds.)
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1031.

MT

AT

TF

With GST

Follow the procedure "With CONSULT-II".

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

| | | |
|---|-----------------------|---------|
| 3 | DATA MONITOR | |
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) XXX rpm | |

PEF357V

DTC P1320 IGNITION SIGNAL




VG33E

Wiring Diagram



Wiring Diagram

NGEC0816

EC-IGN/SG-01



Refer to the following.
 M65, E43 - SUPER
 MULTIPLE JUNCTION (SMJ)





AEC967A

Diagnostic Procedure

NGE0817

| | | |
|--|---------------------------|----------|
| 1 | CHECK ENGINE START | |
| Turn ignition switch OFF, and restart engine. Is engine running? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 7. |
| No | ▶ | GO TO 2. |

 GI
MA
EM

| | | |
|--|---|----------|
| 2 | CHECK IGNITION COIL POWER SUPPLY CIRCUIT | |
| 1. Turn ignition switch OFF. 2. Disconnect ignition coil harness connector. | | |
|  | | |
| 3. Turn ignition switch ON. 4. Check voltage between terminal 7 and ground with CONSULT-II or tester. | | |
|  | | |
| Voltage: Battery voltage OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 3. |

 LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR

| | | |
|---|-----------------------------------|-------------------------------|
| 3 | DETECT MALFUNCTIONING PART | |
| Check the following. | | |
| <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M59, F27 ● Harness for open or short between ignition coil and ignition switch | | |
| | ▶ | Repair harness or connectors. |

 RS
BT
HA

 SC
EL

IDX

DTC P1320 IGNITION SIGNAL

VG33E


Diagnostic Procedure (Cont'd)

| 4 | | CHECK POWER TRANSISTOR GROUND CIRCUIT FOR OPEN AND SHORT |
|--|---|--|
| 1. Turn ignition switch OFF. 2. Disconnect power transistor harness connector. 3. Check harness continuity between power transistor terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |


| 5 | | CHECK POWER TRANSISTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
|--|---|--|
| 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 1 and power transistor terminal 1. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

6 CHECK IGNITION COIL

1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.



SEF013S



AEC657A

| Terminal | Resistance [at 25°C (77°F)] |
|------------------------|-----------------------------|
| 7 - 8 (Primary coil) | 0.5 - 1.0Ω |
| 7 - 9 (Secondary coil) | Approximately 12 kΩ |


MTBL0248

For checking secondary coil, remove distributor cap and measure resistance between coil tower metal tip 9 and terminal 7.

OK or NG

| | | |
|----|---|-------------------------------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace distributor assembly. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


| 7 | CHECK POWER TRANSISTOR | <ol style="list-style-type: none"> 1. Disconnect camshaft position sensor & power transistor harness connector and ignition coil harness connector. 2. Check power transistor resistance between terminals 2 and 8. | | | | | | | | | |
|-----------|-------------------------------|--|-----------|------------|--------|---------|-----------|----|--|----|----|
| | |  | | | | | | | | | |
| | | SEF015S | | | | | | | | | |
| | | <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Terminals</th> <th style="padding: 5px;">Resistance</th> <th style="padding: 5px;">Result</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 5px;">2 and 8</td> <td style="text-align: center; padding: 5px;">Except 0Ω</td> <td style="text-align: center; padding: 5px;">OK</td> </tr> <tr> <td></td> <td style="text-align: center; padding: 5px;">0Ω</td> <td style="text-align: center; padding: 5px;">NG</td> </tr> </tbody> </table> | Terminals | Resistance | Result | 2 and 8 | Except 0Ω | OK | | 0Ω | NG |
| Terminals | Resistance | Result | | | | | | | | | |
| 2 and 8 | Except 0Ω | OK | | | | | | | | | |
| | 0Ω | NG | | | | | | | | | |
| | | MTBL0249 | | | | | | | | | |
| | | OK or NG | | | | | | | | | |
| OK | ▶ | GO TO 11. | | | | | | | | | |
| NG | ▶ | Replace distributor assembly. | | | | | | | | | |

| | | |
|----------|--|--|
| 8 | CHECK IGNITION COIL INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | <ol style="list-style-type: none"> 1. Stop engine. 2. Disconnect ignition coil harness connector. 3. Strip tape covering resistor. 4. Disconnect resistor harness connector. 5. Disconnect ECM harness connector. 6. Check harness continuity between ignition coil terminal 8 and resistor terminal 1, resistor terminal 2 and ECM terminal 2. Refer to Wiring Diagram. Continuity should exist. 7. Also check harness for short to ground and short to power. |
| | | OK or NG |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

DTC P1320 IGNITION SIGNAL

VG33E

Diagnostic Procedure (Cont'd)

| | | | | |
|----------|-----------------------|---|--|--|
| 9 | CHECK RESISTOR | <p>1. Disconnect resistor harness connector. 2. Check resistance between terminals 1 and 2.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Resistance: Approximately 2.2 kΩ [at 25°C (77°F)]</p> <p style="text-align: center;">OK or NG</p> | | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> |
| OK | ▶ | GO TO 10. | | |
| NG | ▶ | Replace resistor. | | |

SEF757U

| | | | | |
|-----------|--|---|--|---|
| 10 | CHECK SHIELD CIRCUIT FOR OPEN AND SHORT | <p>1. Turn ignition switch OFF. 2. Disconnect joint connector-2. 3. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between joint connector terminal 1 and ground ● Joint connector (Refer to "HARNESS LAYOUT", <i>EL-292</i>.) Continuity should exist. <p>4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector-2.</p> <p style="text-align: center;">OK or NG</p> | | <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> |
| OK | ▶ | GO TO 11. | | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | | |

| | | | | |
|-----------|------------------------------------|--|--|---------------------|
| 11 | CHECK INTERMITTENT INCIDENT | <p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.</p> | | <p>SU</p> <p>BR</p> |
| | ▶ | INSPECTION END | | |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

VG33E

Component Description



Component Description

NGEC0818

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system.

It is used only for the on board diagnosis.

ECM Terminals and Reference Value

NGEC0819

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (AC Voltage) |
|----------------------|---------------|----------------------------------|--|---|
| 47 | L | Crankshaft position sensor (OBD) | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>1 - 2V (AC range)</p> <p>SEF690W</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | <p>3 - 4V (AC range)</p> <p>SEF691W</p> |

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

Malfunction is detected when a chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM. NGEC0820

POSSIBLE CAUSE


- Harness or connectors
- Crankshaft position sensor (OBD)
- Drive plate/Flywheel

NGEC0820S01

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test. NGEC0821



Ⓟ With CONSULT-II

- 1) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 2 minutes at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1039.

Ⓢ With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

VG33E


Diagnostic Procedure

Diagnostic Procedure

NGEC0823

| | |
|--|--------------------------------|
| 1 | RETIGHTEN GROUND SCREWS |
| <p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p> | |
|  <p>The diagram shows a close-up of the engine ground area. Two screws are labeled F11 and F12. The text 'Engine ground' is written above the screws. Various wires and hoses are visible in the background.</p> | |
| AEC640A | |
| ▶ | GO TO 2. |

GI
MA
EM
LC
EC

| | |
|---|---|
| 2 | CHECK CKPS (OBD) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| <p>1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.</p> | |
|  <p>The diagram shows the engine front view. Labels include 'Rear heated oxygen sensor LH', 'Crankshaft position sensor (OBD)', 'Transmission', and 'Engine front'. An arrow points to the crankshaft position sensor.</p> | |
| SEF997R | |
| <p>2. Check continuity between ECM terminal 47 and sensor terminal 2. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 4. |
| NG | ▶ GO TO 3. |

FE
CL
MT
AT
TF
PD
AX
SU
BR
ST

| | |
|--|--|
| 3 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F38, F102 ● Harness for open or short between ECM and crankshaft position sensor (OBD) | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

RS
BT
HA
SC
EL
IDX

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

VG33E

Diagnostic Procedure (Cont'd)

| 4 CHECK CKPS (OBD) GROUND CIRCUIT FOR OPEN AND SHORT | | |
|--|---|----------|
| 1. Reconnect ECM harness connectors. | | |
| 2. Check harness continuity between CKPS (OBD) terminal 1 and engine ground. Refer to Wiring Diagram. Continuity should exist. | | |
| 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 5. |



| 5 DETECT MALFUNCTIONING PART | | |
|--|---|--|
| Check the following. | | |
| <ul style="list-style-type: none">● Harness connectors F38, F102● Harness connectors F28, M58● Joint connector-4● Harness for open or short between crankshaft position sensor (OBD) and ECM● Harness for open or short between crankshaft position sensor (OBD) and TCM (Transmission Control Module) | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 6 CHECK IMPROPER INSTALLATION | | |
|--|---|-----------------------|
| 1. Loosen and retighten the fixing bolt of the crankshaft position sensor (OBD). | | |
| 2. Perform "DTC Confirmation Procedure", EC-1037 again. | | |
| Is a 1st trip DTC P1336 (0905) detected? | | |
| Yes | ▶ | GO TO 7. |
| No | ▶ | INSPECTION END |

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

VG33E

Diagnostic Procedure (Cont'd)

| | | | |
|----------|---|---|---|
| 7 | CHECK CRANKSHAFT POSITION SENSOR (OBD) | <ol style="list-style-type: none"> 1. Disconnect crankshaft position sensor (OBD) harness connector. 2. Loosen the fixing bolt of the sensor. 3. Remove the sensor. 4. Visually check the sensor for chipping. <div style="text-align: center; margin: 10px 0;">  </div> <ol style="list-style-type: none"> 5. Check resistance as shown in the figure. <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: center; color: blue; margin: 5px 0;">Resistance: Approximately 512 - 632Ω [at 20°C (68°F)]</p> <p style="text-align: center; margin: 5px 0;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center; padding: 2px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> |
| OK | ▶ | GO TO 8. | |
| NG | ▶ | Replace crankshaft position sensor (OBD). | |

| | | | |
|----------|---|---|---|
| 8 | CHECK CKPS (OBD) SHIELD CIRCUIT FOR OPEN AND SHORT | <ol style="list-style-type: none"> 1. Disconnect harness connectors F38, F102. 2. Check harness continuity between harness connector F38 terminal 6 and engine ground. Continuity should exist. 3. Also check harness for short to ground and short to power. <p style="text-align: center; margin: 5px 0;">OK or NG</p> | <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> |
| OK | ▶ | GO TO 10. | |
| NG | ▶ | GO TO 9. | |

| | | | |
|----------|-----------------------------------|--|--|
| 9 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F38, F102 ● Joint connector-1 ● Harness for open or short between harness connector F38 and engine ground | <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

VG33E

Diagnostic Procedure (Cont'd)


| | |
|---|--|
| 10 | CHECK GEAR TOOTH |
| Visually check for chipping flywheel or drive plate gear tooth (cog). | |
| OK or NG | |
| OK | ▶ GO TO 11. |
| NG | ▶ Replace the flywheel or drive plate. |

| | |
|---|------------------------------------|
| 11 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

DTC P1400 EGRC-SOLENOID VALVE

VG33E

Component Description (If Equipped with EGR Valve)



Component Description (If Equipped with EGR Valve)

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal (from the intake manifold collector) passes through the solenoid valve. The signal then reaches the EGR valve.

When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

NGEC0825

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|--------------|--|---|---------------|
| EGRC SOL/V | <ul style="list-style-type: none"> Engine: After warming up Air conditioner switch: "OFF" Shift lever: "N" No-load | Idle | OFF |
| | | Engine speed: Revving from idle up to 3,000 rpm quickly | ON |

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

NGEC0826

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---------------------|--|-------------------------------|
| 103 | G/W | EGRC-solenoid valve | [Engine is running] <ul style="list-style-type: none"> Warm-up condition Idle speed | BATTERY VOLTAGE (11 - 14V) |
| | | | [Engine is running] <ul style="list-style-type: none"> Warm-up condition Revving engine from idle up to 3,000 rpm quickly | 0 - 1.5V |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

On Board Diagnosis Logic

Malfunction is detected when the improper voltage signal is sent to ECM through EGRC-solenoid valve. =NGEC0827

POSSIBLE CAUSE

- Harness or connectors
(The EGRC-solenoid valve circuit is open or shorted.)
- EGRC-solenoid valve

NGEC0827S01

2

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| COOLAN TEMP/S | XXX °C |
| | |

PEF002P

DTC Confirmation Procedure

NGEC0828

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select “DATA MONITOR” mode with CONSULT-II and wait at least 5 seconds.
- 3) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-1046.

With GST

Follow the procedure “With CONSULT-II”.

DTC P1400 EGRC-SOLENOID VALVE


VG33E

Wiring Diagram

Wiring Diagram

NGEC0829


EC-EGRC/V-01



Refer to "EL-POWER".
— : Detectable line for DTC
— : Non-detectable line for DTC

- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST



- RS
- BT
- HA
- SC
- EL
- IDX



AEC968A

Diagnostic Procedure

NGENC0830

| | |
|---|---|
| 1 | CHECK EGRC-SOLENOID VALVE POWER SUPPLY CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect EGRC-solenoid valve harness connector.</p> <div style="text-align: center;">  <p style="text-align: center;">Air duct EGRC solenoid valve harness connector</p> </div> <p style="text-align: right;">AEC659A</p> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> </div> <p style="text-align: right;">SEF657W</p> | |
| OK | ▶ GO TO 3. |
| NG | ▶ GO TO 2. |


| | |
|--|-----------------------------------|
| 2 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M59, F27 ● Fuse block (J/B) connector E49 ● 10A fuse ● Harness for open or short between EGRC-solenoid valve and fuse <p style="text-align: right;">▶ Repair harness or connectors.</p> | |

| | |
|---|--|
| 3 | CHECK EGRC-SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 103 solenoid valve and terminal 2. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

4 CHECK EGRC-SOLENOID VALVE

④ With CONSULT-II

1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.




| ACTIVE TEST | |
|------------------|---------|
| EGRC SOL/V (EGR) | ON FLOW |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Conditions | Air passage continuity between A and B | Air passage continuity between A and C |
|------------|--|--|
| ON | Yes | No |
| OFF | No | Yes |

SEF155X

⊗ Without CONSULT-II

Check air passage continuity and operation delay time under the following conditions.



| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

AEC919

MTBL0237

OK or NG

- | | | |
|----|---|------------------------------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace EGRC-solenoid valve. |


5 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.

▶ **INSPECTION END**

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Component Description (If Equipped with EGR Valve)



Component Description (If Equipped with EGR Valve)

NGEC0831

The EGR temperature sensor detects temperature changes in the EGR passage way. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passage way changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.


<Reference data>

| EGR temperature °C (°F) | Voltage* (V) | Resistance (MΩ) |
|-------------------------|--------------|-----------------|
| 0 (32) | 4.56 | 0.62 - 1.05 |
| 50 (122) | 2.25 | 0.065 - 0.094 |
| 100 (212) | 0.59 | 0.011 - 0.015 |

*: These data are reference values and are measured between ECM terminal 63 (EGR temperature sensor) and ECM terminal 32 (ECM ground).

When EGR system is operating.

Voltage: 0 - 1.5V



On Board Diagnosis Logic

NGEC0832

Malfunction is detected when

(Malfunction A) an excessively low voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is low,

(Malfunction B) an excessively high voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is high.

POSSIBLE CAUSE

NGEC0832S01

Malfunction A

NGEC0832S0101

- Harness or connectors (The EGR temperature sensor circuit is shorted.)
- EGR temperature sensor
- Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve

Malfunction B

NGEC0832S0102


- Harness or connectors (The EGR temperature sensor circuit is open.)
- EGR temperature sensor
- Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.




PROCEDURE FOR MALFUNCTION A

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Verify that "COOLAN TEMP/S" is less than 40°C (104°F).
If the engine coolant temperature is above the range, cool the engine down.
- 4) Start engine and let it idle for at least 8 seconds.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1052.

Ⓜ With GST

Follow the procedure "With CONSULT-II".



PROCEDURE FOR MALFUNCTION B

CAUTION:


Always drive vehicle at a safe speed.

TESTING CONDITION:

Always perform the test at a temperature of 5°C (41°F) or higher.

Ⓜ With CONSULT-II



- 1) Start engine and warm it up to normal operating temperature.
- 2) Confirm that EGR valve is not lifting at idle.
If the check result is NG, go to trouble diagnoses for "DTC P1402". (See page EC-1055.)
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Read "EGR TEMP SEN" at about 1,500 rpm while holding the EGR valve in full open position by hand.
Voltage should decrease to less than 1.5V.
If the check result is NG, go to "Diagnostic Procedure", EC-1052.
If the check result is OK, go to following step.
- 5) Turn ignition switch OFF and wait at least 5 seconds.
- 6) Turn ignition switch ON.
- 7) Check the output voltage of "THRTL POS SEN" at closed throttle position and note it.



- 8) Start engine.
- 9) Maintain the following conditions for at least 5 consecutive seconds.

| | |
|----------------|--|
| CMPS-RPM (REF) | 1,600 - 2,400 rpm (A/T models) 1,800 - 2,600 rpm (M/T models) |
| COOLAN TEMP/S | Above 70°C (158°F) |
| B/FUEL SCHDL | 3.0 - 4.5 msec |
| THRTL POS SEN | $X - (X + 0.70) V$ X = Voltage value measured at step 7 |
| Selector lever | Suitable position |

- 10) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1052.



Overall Function Check

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.

NGEC0834

PROCEDURE FOR MALFUNCTION B

NGEC0834S01

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Confirm that EGR valve is not lifting at idle. If NG, go to trouble diagnoses for DTC P0400 and P0402 (See pages EC-919 and 933).
- 3) Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand.
Voltage should decrease to less than 1.5V.
If NG, go to "Diagnostic Procedure", EC-1052.
- 4) If step 4 is OK, perform trouble diagnoses for "DTC P0400, P1400" (See pages EC-919 and 1043).

DTC P1401 EGR TEMPERATURE SENSOR



VG33E

Wiring Diagram

Wiring Diagram

NGEC0835



EC-EGR/TS-01



AEC969A

Diagnostic Procedure

NGEC0836

| | |
|---|--|
| 1 | CHECK EGR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT |
| <p>1. Turn ignition switch OFF. 2. Disconnect EGR temperature sensor harness connector.</p> <div style="text-align: center;">  <p style="text-align: center;">EGR temperature sensor harness connector</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> </div> | |
| OK | ▶ GO TO 2. |
| NG | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

AEC660A
SEF728U

| | |
|---|---|
| 2 | CHECK EGR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT |
| <p>1. Turn ignition switch OFF. 2. Check harness continuity between sensor terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground or short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 4. |
| NG | ▶ GO TO 3. |

| | |
|--|---|
| 3 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F28, M58 ● Joint connector-4 ● Harness for open or short between ECM and EGR temperature sensor ● Harness for open or short between TCM (Transmission Control Module) and EGR temperature sensor | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connector. |


DTC P1401 EGR TEMPERATURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)


4 CHECK EGR TEMPERATURE SENSOR

Check resistance change and resistance value.



<Reference data>

| EGR temperature °C (°F) | Voltage (V) | Resistance (MΩ) |
|-------------------------|-------------|-----------------|
| 0 (32) | 4.56 | 0.62 - 1.05 |
| 50 (122) | 2.25 | 0.065 - 0.094 |
| 100 (212) | 0.59 | 0.011 - 0.015 |



OK or NG

| | | |
|----|---|---------------------------------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace EGR temperature sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

SEF643Q

AEC039B

TF

PD

AX

SU

BR

ST

RS

BT

SEF320U

HA

SC

EL

IDX

DTC P1401 EGR TEMPERATURE SENSOR

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 5 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

DTC P1402 EGR FUNCTION (OPEN)

VG33E

Description (If Equipped with EGR Valve)

Description (If Equipped with EGR Valve) SYSTEM DESCRIPTION



NGEC0837

NGEC0837S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|----------------------------|--------------|---------------------|
| Camshaft position sensor | Engine speed | EGR control | EGRC-solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current does not flow through the solenoid valve. This causes the intake manifold vacuum to be discharged into the atmosphere. The EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



COMPONENT DESCRIPTION

Exhaust Gas Recirculation (EGR) Valve

NGEC0837S02


NGEC0837S0201

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening and EGRC-BPT valve operation. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.

DTC P1402 EGR FUNCTION (OPEN)

VG33E

Description (If Equipped with EGR Valve) (Cont'd)




EGRC-solenoid Valve

NGEC0837S0202

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal (from the intake manifold collector) passes through the solenoid valve. The signal then reaches the EGR valve.

When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal.



On Board Diagnosis Logic

NGEC0838

If the EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

Malfunction is detected when EGR flow is detected under condition that does not call for EGR.


NOTE:

Diagnosis for this DTC will occur when engine coolant temperature is below 50-60°C (122-140°F). Therefore, it will be better to turn ignition switch "ON" (start engine) at the engine coolant temperature below 30°C (86°F) when starting DTC confirmation procedure.

POSSIBLE CAUSE

NGEC0838S01

- EGRC-solenoid valve
- EGR valve leaking or stuck open
- EGR temperature sensor
- EGRC-BPT valve



DTC Confirmation Procedure

NGEC0839

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


- Always perform the test at a temperature of -10°C (14°F) or higher.
- Engine coolant temperature and EGR temperature must be verified in "DATA MONITOR" mode with CONSULT-II before starting DTC WORK SUPPORT test. If it is out of range below, the test cannot be conducted.

COOLAN TEMP/S: -10 to 30°C (14 to 86°F)*

EGR TEMP SEN: Less than 4.8V

If the values are out of the ranges indicated above, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to reduce the engine coolant temperature or EGR temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

*: Although CONSULT-II screen displays "-10 to 40°C (14 to 104°F)" as a range of engine coolant temperature, ignore it.



DTC P1402 EGR FUNCTION (OPEN)

VG33E

DTC Confirmation Procedure (Cont'd)

4

| EGR SYSTEM P1402 | |
|------------------|----------|
| OUT OF CONDITION | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF245V

4


| EGR SYSTEM P1402 | |
|------------------|----------|
| TESTING | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF246V

4

| EGR SYSTEM P1402 | |
|------------------|--|
| COMPLETED | |

PEF897U



With CONSULT-II

- 1) Turn ignition switch OFF, and wait at least 5 seconds, and then turn "ON".
- 2) Select "EGR SYSTEM P1402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 3) Follow the CONSULT-II instructions.
- 4) Start engine and let it idle until "TESTING" on CONSULT-II screen is turned to "COMPLETED". (It will take 60 seconds or more.)

If "TESTING" is not displayed after 5 minutes, turn ignition "OFF" and cool the engine coolant temperature to the range of -10 to 30°C (14 to 86°F). Retry from step 1.

- 5) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-1059.

With GST

- 1) Turn ignition switch ON and select "MODE 1" with GST.
- 2) Check that engine coolant temperature is within the range of -10 to 30°C (14 to 86°F).
- 3) Check that voltage between ECM terminal 63 (EGR temperature sensor signal) and ground is less than 4.8V.
- 4) Start engine and let it idle for at least 60 seconds.
- 5) Stop engine.
- 6) Perform from step 1 to 4.
- 7) Select "MODE 3" with GST.
- 8) If DTC is detected, go to "Diagnostic Procedure", EC-1059.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1402 EGR FUNCTION (OPEN)



VG33E

Wiring Diagram

Wiring Diagram

NGEC0840


EC-EGRC1-01



AEC958A

Diagnostic Procedure

NGEC0841

| | | |
|--|--------------------------|--------------------------------|
| 1 | CHECK VACUUM HOSE | |
| <p>1. Turn ignition switch OFF. 2. Check vacuum hose for clogging, cracks or improper connection. Refer to "Vacuum Hose Drawing", EC-597.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Split</p> <p style="margin-left: 100px;">Clogging</p> <p style="margin-left: 100px;">Improper connection</p> </div> <p style="text-align: right;">SEF109L</p> <p style="text-align: center;">OK or NG</p> | | |
| OK (with CONSULT-II) ▶ | | GO TO 2. |
| OK (without CONSULT-II) ▶ | | GO TO 3. |
| NG ▶ | | Repair or replace vacuum hose. |

| 2 | CHECK EGRC-SOLENOID VALVE CIRCUIT | | | | | | | | | | | | | | | | | | | | | |
|--|--|----------|-------------|--|------------|----|-------|------|---------|--|---------------|---------|--|--|--|--|--|--|--|--|--|--|
| <p>Ⓟ With CONSULT-II 1. Turn ignition switch ON. 2. Turn EGRC-solenoid valve ON and OFF in "ACTIVE TEST" mode with CONSULT-II and check operating sound.</p> <div style="text-align: center;"> <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>EGRC SOL/V</th> <th>ON</th> </tr> <tr> <th>(EGR)</th> <th>FLOW</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS-RPM(REF)</th> <th>XXX rpm</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> </div> <p style="text-align: right;">PEF789U</p> <p>Clicking noise should be heard.</p> <p style="text-align: center;">OK or NG</p> | | | ACTIVE TEST | | EGRC SOL/V | ON | (EGR) | FLOW | MONITOR | | CMPS-RPM(REF) | XXX rpm | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| EGRC SOL/V | ON | | | | | | | | | | | | | | | | | | | | | |
| (EGR) | FLOW | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| OK ▶ | | GO TO 5. | | | | | | | | | | | | | | | | | | | | |
| NG ▶ | | GO TO 4. | | | | | | | | | | | | | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1402 EGR FUNCTION (OPEN)


VG33E

Diagnostic Procedure (Cont'd)

3 CHECK EGRC-SOLENOID VALVE CIRCUIT

⊗ Without CONSULT-II

1. Disconnect ECM harness connector.
2. Turn ignition switch ON.
3. Connect a suitable jumper wire between ECM terminal 103 and engine ground.



SEF937V

4. Check operating sound of EGRC-solenoid valve when disconnecting and connecting the jumper wire.
Clicking noise should be heard.

OK or NG

OK



GO TO 4.

NG



Repair or replace EGRC-solenoid valve or repair circuit.

DTC P1402 EGR FUNCTION (OPEN)


VG33E

Diagnostic Procedure (Cont'd)

4 CHECK EGRC-SOLENOID VALVE

With CONSULT-II

1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.




| ACTIVE TEST | |
|------------------|---------|
| EGRC SOL/V (EGR) | ON FLOW |
| MONITOR | |
| CMPS-RPM (REF) | XXrpm |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Conditions | Air passage continuity between A and B | Air passage continuity between A and C |
|------------|--|--|
| ON | Yes | No |
| OFF | No | Yes |

SEF155X

Without CONSULT-II

Check air passage continuity and operation delay time under the following conditions.



AEC919


| Condition | Air passage continuity between A and B | Air passage continuity between A and C |
|---|--|--|
| 12V direct current supply between terminals 1 and 2 | Yes | No |
| No supply | No | Yes |

MTBL0237


OK or NG

| | | |
|----|---|------------------------------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace EGRC-solenoid valve. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | | |
|---|------------------------|--------------------|--|
| 5 | CHECK EGR VALVE | | |
| Apply vacuum to EGR vacuum port with a hand vacuum pump. | | | |
|  | | | |
| <p>EGR valve spring should lift.</p> <ul style="list-style-type: none"> ● Check for sticking. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 6. | |
| NG | ▶ | Replace EGR valve. | |

MEF137D

| | | | |
|---|-----------------------------|-------------------------|--|
| 6 | CHECK EGRC-BPT VALVE | | |
| <ol style="list-style-type: none"> 1. Plug one of two ports of EGRC-BPT valve. 2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve. | | | |
|  | | | |
| <p>Leakage should not exist.</p> | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 7. | |
| NG | ▶ | Replace EGRC-BPT valve. | |

SEF083P


DTC P1402 EGR FUNCTION (OPEN)

VG33E

Diagnostic Procedure (Cont'd)

7 CHECK EGR TEMPERATURE SENSOR

Check resistance change and resistance value.




<Reference data>

SEF643Q

| EGR temperature °C (°F) | Voltage (V) | Resistance (MΩ) |
|-------------------------|-------------|-----------------|
| 0 (32) | 4.56 | 0.62 - 1.05 |
| 50 (122) | 2.25 | 0.065 - 0.094 |
| 100 (212) | 0.59 | 0.011 - 0.015 |

AEC039B



SEF320U

OK or NG

| | | |
|----|---|---------------------------------|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace EGR temperature sensor. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1402 EGR FUNCTION (OPEN)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 8 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

DTC P1440 EVAP CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

NGEC0842


NOTE:

If DTC P1440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See EC-1098.)

This diagnosis detects leaks in the EVAP purge line using of vapor pressure in the fuel tank.

The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank.

If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge volume control solenoid valve.



Malfunction is detected when EVAP control system has a leak, EVAP control system does not operate properly.

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

POSSIBLE CAUSE

NGEC0842S01

- Incorrect fuel tank vacuum relief valve
- Incorrect fuel filler cap used
- Fuel filler cap remains open or fails to close.
- Foreign matter caught in fuel filler cap.
- Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve.
- Foreign matter caught in EVAP canister vent control valve.
- EVAP canister or fuel tank leaks
- EVAP purge line (pipe and rubber tube) leaks
- EVAP purge line rubber tube bent.
- Blocked or bent rubber tube to EVAP control system pressure sensor
- Loose or disconnected rubber tube
- EVAP canister vent control valve and the circuit
- EVAP canister purge volume control solenoid valve
- Absolute pressure sensor
- Fuel tank temperature sensor
- MAP/BARO switch solenoid valve

DTC P1440 EVAP CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

VG33E

On Board Diagnosis Logic (Cont'd)

- Blocked or bent rubber tube to MAP/BARO switch solenoid valve
- O-ring of EVAP canister vent control valve is missing or damaged.
- Water separator
- EVAP canister is saturated with water.
- EVAP control system pressure sensor

DTC Confirmation Procedure

NGEC0843

NOTE:

Refer to "P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)", EC-948.

Diagnostic Procedure

NGEC0844

NOTE:

Refer to "P0440 EVAP CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)", EC-949.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E
Description


Description SYSTEM DESCRIPTION

NGEC0845

NGEC0845S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|--|----------------------------------|---|
| Camshaft position sensor | Engine speed | EVAP canister purge flow control | EVAP canister purge volume control solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Throttle position sensor | Throttle position | | |
| Throttle position switch | Closed throttle position | | |
| Front heated oxygen sensors | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | | |
| Tank fuel temperature sensor | Fuel temperature in fuel tank | | |
| Vehicle speed sensor | Vehicle speed | | |

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



COMPONENT DESCRIPTION

NGEC0845S02

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0846

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|---------------|
| PURG VOL C/V | ● Engine: After warming up ● Air conditioner switch OFF ● Shift lever: "N" ● No-load Idle (Vehicle stopped) | 0% |
| | 2,000 rpm | — |

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE



VG33E

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NGEC0847

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---|---|---|
| 4 | OR/B | ECM relay (Self shut-off) | [Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF | 0 - 1.5V |
| | | | [Ignition switch OFF] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14V) |
| 5 | R/Y | EVAP canister purge volume control solenoid valve | [Engine is running] <ul style="list-style-type: none"> ● Idle speed | BATTERY VOLTAGE (11 - 14V)  <p style="text-align: right; margin-top: 5px;"><small>SEF994U</small></p> |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm | BATTERY VOLTAGE (11 - 14V)  <p style="text-align: right; margin-top: 5px;"><small>SEF995U</small></p> |
| 67 | B/P | Power supply for ECM | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |
| 72 | B/P | | | |
| 117 | B/P | Current return | [Engine is running] ● Idle speed | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0848

Malfunction is detected when the canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control solenoid valve is completely closed.

POSSIBLE CAUSE

NGEC0848S01

- EVAP control system pressure sensor
- EVAP canister purge volume control solenoid valve (The valve is stuck open.)
- EVAP canister vent control valve
- EVAP canister

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E

DTC Confirmation Procedure

- Hoses
(Hoses are connected incorrectly or clogged.)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| DATA MONITOR | |
|---------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM(REF) | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| TANK F/TMP SE | XXX °C |

PEF195V

DTC Confirmation Procedure

NGEC0849

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

6

| PURG VOL CN/V P1444 | |
|---------------------|----------|
| OUT OF CONDITION | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF900U

Ⓟ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Turn ignition switch ON.
- 4) Select "PURG VOL CN/V P1444" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 5) Touch "START".
- 6) Start engine and let it idle until "TESTING" on CONSULT-II changes to "COMPLETED". (It will take for approximately 10 seconds.)

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-1071.

6

| PURG VOL CN/V P1444 | |
|---------------------|----------|
| TESTING | |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF901U

Ⓢ With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Start engine and let it idle for at least 20 seconds.
- 4) Select "MODE 7" with GST.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1071.

6

| PURG VOL CN/V P1444 | |
|---------------------|--|
| COMPLETED | |

PEF902U

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE




VG33E

Wiring Diagram

Wiring Diagram

NGEC0850

EC-PGC/V-01



AEC959A



DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0851

| | | |
|--|---|----------|
| 1 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect EVAP canister purge volume control solenoid valve harness connector.</p> <div style="text-align: center;">  <p>Brake fluid reservoir</p> <p>EVAP canister purge volume control solenoid valve harness connector</p> </div> <p>3. Turn ignition switch ON. 4. Check voltage between terminal 1 and engine ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>Voltage: Battery voltage</p> <p>OK or NG</p> </div> | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

AEC652A

SEF646W

| | | |
|--|-----------------------------------|-------------------------------|
| 2 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F36, M81 ● Harness connectors M82, E74 ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM | | |
| ▶ | | Repair harness or connectors. |

| | | |
|--|---|----------|
| 3 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 5 and solenoid valve terminal 2. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors E74, M82 ● Harness connectors M81, F36 ● Harness for open or short between EVAP canister purge volume control solenoid valve and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|---|
| 5 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE |
| Check disconnection or improper connection of hose connected to EVAP control system pressure sensor. | |
| OK or NG | |
| OK | ▶ GO TO 6. |
| NG | ▶ Repair it. |

| | |
|---|--|
| 6 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR |
| 1. Disconnect EVAP control system pressure sensor harness connector. | |
|  | |
| AEC651A | |
| 2. Check connectors for water. Water should not exist. | |
| OK or NG | |
| OK | ▶ GO TO 7. |
| NG | ▶ Replace EVAP control system pressure sensor. |


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

7 CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.



| Pressure (Relative to atmospheric pressure) | Voltage (V) |
|---|-------------|
| 0 kPa (0 mmHg, 0 inHg) | 3.0 - 3.6 |
| -9.3 kPa (-70 mmHg, -2.76 inHg) | 0.4 - 0.6 |

SEF894U


MTBL0246

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.

CAUTION:

- Never apply force to the air hole protector of the sensor if equipped.



SEF799W

- Discard and EVAP control system pressure sensor which has been dropped from a height of more than 0.5m (19.7in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

| | | |
|-------------------------|---|--|
| OK (with CONSULT-II) | ▶ | GO TO 8. |
| OK (without CONSULT-II) | ▶ | GO TO 9. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

8 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II


1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

| ACTIVE TEST | |
|-----------------|---------|
| PURG VOL CONT/V | 0.0% |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 MNTR-B2 | RICH |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B2 | XXX % |
| A/F ALPHA-B1 | XXX % |
| THRTL POS SEN | XXX V |
| | |

PEF882U

If OK, inspection end. If NG, go to following step.

3. Check air passage continuity.



SEF660U

| Condition PURG VOL CONT/V value | Air passage continuity between A and B |
|------------------------------------|---|
| 100.0% | Yes |
| 0.0% | No |

MTBL0241

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

9 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

⊗ Without CONSULT-II
Check air passage continuity.



SEF661U

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No supply | No |

MTBL0242

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E


Diagnostic Procedure (Cont'd)

10 CHECK EVAP CANISTER VENT CONTROL VALVE

Check air passage continuity.

 **With CONSULT-II**

Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.



| ACTIVE TEST | |
|----------------|--------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B1 | XXX% |
| THRTL POS SEN | XXXV |
| | |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|--------------------------|--|
| ON | No |
| OFF | Yes |

SEF156X


 **Without CONSULT-II**

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| OFF | Yes |

MTBL0240

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.



AEC783A

Make sure new O-ring is installed properly.

OK or NG

OK ► GO TO 11.

NG ► Replace EVAP canister vent control valve.

11 CHECK RUBBER TUBE

Check for obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

OK ► GO TO 12.

NG ► Clean, repair or replace rubber tube.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

| 12 | CHECK WATER SEPARATOR | |
|----|--|--|
| | <ol style="list-style-type: none"> 1. Check visually for insect nests in the water separator air inlet. 2. Check visually for cracks or flaws in the appearance. 3. Check visually for cracks or flaws in the hose. 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged. <div style="text-align: center;"> <p>* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> </div> <p style="text-align: right;">SEF829T</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center;">EC</p> <p>FE</p> <p>CL</p> |
| | <p>5. In case of NG in items 2 - 4, replace the parts.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Do not disassemble water separator. <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 13. |
| NG | ▶ | Replace water separator. |

| 13 | CHECK IF EVAP CANISTER SATURATED WITH WATER | |
|-----|--|---|
| | <ol style="list-style-type: none"> 1. Remove EVAP canister with EVAP canister vent control valve attached. 2. Check if water will drain from the EVAP canister. <div style="text-align: center;"> <p>EVAP canister</p> <p>Water</p> <p>EVAP canister vent control valve</p> </div> <p style="text-align: right;">SEF596U</p> <p style="text-align: center;">Yes or No</p> | <p>TF</p> <p>PD</p> <p>AX</p> <p>SU</p> <p>BR</p> |
| Yes | ▶ | GO TO 14. |
| No | ▶ | GO TO 16. |

| 14 | CHECK EVAP CANISTER | |
|----|---|---------------------|
| | <p>Weigh the EVAP canister with the EVAP canister vent control valve attached.</p> <p>The weight should be less than 1.8 kg (4.0 lb).</p> <p style="text-align: center;">OK or NG</p> | <p>BT</p> <p>HA</p> |
| OK | ▶ | GO TO 16. |
| NG | ▶ | GO TO 15. |

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

VG33E



Diagnostic Procedure (Cont'd)

| | |
|---|---------------------------------------|
| 15 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none">● EVAP canister for damage● EVAP hose between EVAP canister and water separator for clogging or poor connection | |
| ▶ | Repair hose or replace EVAP canister. |
| 16 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

VG33E

Component Description



Component Description

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent. NGEC0852

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

GI

MA

EM

LC

EC

FE

CL

MT

CONSULT-II Reference Value in Data Monitor Mode

NGEC0853

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|---------------|
| VENT CONT/V | ● Ignition switch: ON | OFF |

TF

PD

ECM Terminals and Reference Value

NGEC0854

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|----------------------------------|----------------------|----------------------------|
| 108 | R/G | EVAP canister vent control valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

VG33E

On Board Diagnosis Logic

On Board Diagnosis Logic

Malfunction is detected when EVAP canister vent control valve remains closed under specified driving conditions. =NGEC0855

POSSIBLE CAUSE

- EVAP canister vent control valve
- EVAP control system pressure sensor and the circuit
- Blocked rubber tube to EVAP canister vent control valve
- Water separator
- EVAP canister is saturated with water.

NGEC0855S01

| 4 | DATA MONITOR | |
|---|---------------|----------|
| | MONITORING | NO FAIL |
| | CMPS-RPM(REF) | XXX rpm |
| | COOLAN TEMP/S | XXX °C |
| | VHCL SPEED SE | XXX km/h |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF403V

DTC Confirmation Procedure

NGEC0856

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine.
- 4) Drive vehicle at a speed of approximately 80 km/h (50 MPH) for a maximum of 15 minutes.

NOTE:

If a malfunction exists, NG result may be displayed quicker.

- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1082.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)


VG33E

Wiring Diagram

Wiring Diagram

NGEC0857

EC-VENT/V-01





Refer to "EL-POWER".

: Detectable line for DTC
 : Non-detectable line for DTC

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST

RS
BT
HA
SC
EL
IDX



AEC017B


DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)


VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0858

| | | | |
|--|--------------------------|---------------------------------------|--|
| 1 | CHECK RUBBER TUBE | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check obstructed rubber tube connected to EVAP canister vent control valve. | | | |
|  | | | |
| SEF143S | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Clean, repair or replace rubber tube. | |

| | | | |
|--|------------------------------|--------------------------|--|
| 2 | CHECK WATER SEPARATOR | | |
| <ol style="list-style-type: none"> 1. Check visually for insect nests in the water separator air inlet. 2. Check visually for cracks or flaws in the appearance. 3. Check visually for cracks or flaws in the hose. 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged. | | | |
|  | | | |
| <p>* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> | | | |
| SEF829T | | | |
| 5. In case of NG in items 2 - 4, replace the parts. | | | |
| NOTE: | | | |
| <ul style="list-style-type: none"> ● Do not disassemble water separator. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Replace water separator. | |

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

VG33E


Diagnostic Procedure (Cont'd)

3 CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

Check air passage continuity.

With CONSULT-II

Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.



| ACTIVE TEST | |
|----------------|--------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B1 | XXX% |
| THRTL POS SEN | XXXV |
| | |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|--------------------------|--|
| ON | No |
| OFF | Yes |


SEF156X

Without CONSULT-II

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| OFF | Yes |

MTBL0240

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.
If portion **B** is rusted, replace control valve.



AEC783A

Make sure new O-ring is installed properly.

OK or NG


| | | |
|----|---|--|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Replace EVAP canister vent control valve and O-ring. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|--|----------|
| 4 | CHECK IF EVAP CANISTER SATURATED WITH WATER | |
| <p>1. Remove EVAP canister with EVAP canister vent control valve attached.</p> <p>2. Check if water will drain from the EVAP canister.</p> | | |
|  | | |
| SEF596U | | |
| Yes or No | | |
| Yes | ▶ | GO TO 5. |
| No | ▶ | GO TO 7. |

| | | |
|--|----------------------------|----------|
| 5 | CHECK EVAP CANISTER | |
| <p>Weigh the EVAP canister with the EVAP canister vent control valve attached.</p> <p>The weight should be less than 1.8 kg (4.0 lb).</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |


| | | |
|---|-----------------------------------|--|
| 6 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● EVAP canister for damage ● EVAP hose between EVAP canister and water separator for clogging or poor connection | | |
| ▶ Repair hose or replace EVAP canister. | | |

| | | |
|---|---|------------|
| 7 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE | |
| <p>Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | Repair it. |

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|--|--|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR | |
| 1. Disconnect EVAP control system pressure sensor harness connector. | | |
|  <p style="text-align: center;">Rear shock absorber RH Front EVAP control system pressure sensor harness connector</p> | | |
| 2. Check connectors for water. Water should not exist. | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

AEC651A

| | | |
|--|---|--|
| 9 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION | |
| Refer to "DTC Confirmation Procedure" for DTC P0450, EC-964. | | |
| OK or NG | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

| | | |
|---|------------------------------------|-----------------------|
| 10 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| | ▶ | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E


System Description

System Description

NGEC0859

NOTE:

If DTC P1447 is displayed with P0510, perform trouble diagnosis for DTC P0510 first. (See EC-998.)



In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control solenoid valve is open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

On Board Diagnosis Logic

NGEC0860

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a fault is determined.

Malfunction is detected when EVAP control system does not operate properly, EVAP control system has a leak between intake manifold and EVAP control system pressure sensor.

POSSIBLE CAUSE

NGEC0860S01

- EVAP canister purge volume control solenoid valve stuck closed
- EVAP control system pressure sensor and the circuit
- Loose, disconnected or improper connection of rubber tube
- Blocked rubber tube
- Blocked or bent rubber tube to MAP/BARO switch solenoid valve
- Cracked EVAP canister
- EVAP canister purge volume control solenoid valve circuit
- Closed throttle position switch
- Blocked purge port
- EVAP canister vent control valve

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E

On Board Diagnosis Logic (Cont'd)

| | | |
|----------|------------------|----------|
| 5 | PURG FLOW P1447 | |
| | OUT OF CONDITION | |
| | MONITOR | |
| | CMPS~RPM(POS) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF616W

| | | |
|----------|-----------------|----------|
| 6 | PURG FLOW P1447 | |
| | TESTING | |
| | MONITOR | |
| | CMPS~RPM(POS) | XXX rpm |
| | THRTL POS SEN | XXX V |
| | B/FUEL SCHDL | XXX msec |

PEF617W

| | | |
|----------|-----------------|--|
| 6 | PURG FLOW P1447 | |
| | COMPLETED | |

PEF905U

DTC Confirmation Procedure

NGEC0861

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch OFF and wait at least 5 seconds.
- 3) Start engine and let it idle for at least 70 seconds.
- 4) Select "PURG FLOW P1447" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 5) Touch "START".
If "COMPLETED" is displayed, go to step 7.
- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 35 seconds.)

| | |
|----------------------------|-----------------------------|
| Selector lever | Suitable position |
| Vehicle speed | 32 - 120 km/h (20 - 75 MPH) |
| CMPS-RPM (POS) | 500 - 3,400 rpm |
| B/FUEL SCHDL | Less than 4 msec |
| Engine coolant temperature | 70 - 100°C (158 - 212°F) |

If "TESTING" is not changed for a long time, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-1089.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E


Diagnostic Procedure

Diagnostic Procedure

=NGEC0863

| | | |
|--|----------------------------|------------------------|
| 1 | CHECK EVAP CANISTER | |
| 1. Turn ignition switch OFF. 2. Check EVAP canister for cracks. | | |
| OK or NG | | |
| OK (With CONSULT-II) | ▶ | GO TO 2. |
| OK (Without CONSULT-II) | ▶ | GO TO 3. |
| NG | ▶ | Replace EVAP canister. |

GI
MA
EM
LC


| 2 | CHECK PURGE FLOW | | | | | | | | | | | | | | | | | | | | | |
|---|-------------------------|----------|-------------|--|-----------------|------|---------|--|---------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|--|--|
| Ⓟ With CONSULT-II 1. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge. | | | | | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | | | | |
| AEC649A | | | | | | | | | | | | | | | | | | | | | | |
| 2. Start engine and let it idle. 3. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. 4. Rev engine up to 2,000 rpm. 5. Touch "Qd" and "Qu" on CONSULT-II screen to adjust "PURG VOL CONT/V" opening. | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">PURG VOL CONT/V</td> <td style="text-align: center;">0.0%</td> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <td style="text-align: center;">CMPS~RPM(REF)</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">FR O2 MNTR-B2</td> <td style="text-align: center;">LEAN</td> </tr> <tr> <td style="text-align: center;">FR O2 MNTR-B1</td> <td style="text-align: center;">LEAN</td> </tr> <tr> <td style="text-align: center;">A/F ALPHA-B2</td> <td style="text-align: center;">XXX %</td> </tr> <tr> <td style="text-align: center;">A/F ALPHA-B1</td> <td style="text-align: center;">XXX %</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | PURG VOL CONT/V | 0.0% | MONITOR | | CMPS~RPM(REF) | XXX rpm | FR O2 MNTR-B2 | LEAN | FR O2 MNTR-B1 | LEAN | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| PURG VOL CONT/V | 0.0% | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| PEF908U | | | | | | | | | | | | | | | | | | | | | | |
| 100.0%: Vacuum should exist. 0.0%: Vacuum should not exist. | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | |

EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E

Diagnostic Procedure (Cont'd)

| | | | |
|--|-------------------------|----------|--|
| 3 | CHECK PURGE FLOW | | |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine. 3. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge. | | | |
|  | | | |
| AEC649A | | | |
| <ol style="list-style-type: none"> 4. Start engine and let it idle for at least 80 seconds. 5. Check vacuum gauge indication when revving engine up to 2,000 rpm. Vacuum should exist. 6. Release the accelerator pedal fully and let idle. Vacuum should not exist. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 7. | |
| NG | ▶ | GO TO 4. | |

| | | | |
|--|------------------------------|------------|--|
| 4 | CHECK EVAP PURGE LINE | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check EVAP purge line for improper connection or disconnection. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-607. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 5. | |
| NG | ▶ | Repair it. | |


DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E


Diagnostic Procedure (Cont'd)

5 CHECK EVAP PURGE HOSE AND PURGE PORT

1. Disconnect purge hoses connected to EVAP service port **A** and EVAP canister purge volume control solenoid valve **B**.



2. Blow air into each hose and EVAP purge port **C**.
3. Check that air flows freely.



OK or NG

SEF367U

SEF368U

| | |
|---------------------------|--|
| OK (with CONSULT-II) ► | GO TO 6. |
| OK (without CONSULT-II) ► | GO TO 7. |
| NG ► | Repair or clean hoses and/or purge port. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E

Diagnostic Procedure (Cont'd)

6 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓟ With CONSULT-II


1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

| ACTIVE TEST | |
|-----------------|---------|
| PURG VOL CONT/V | 0.0% |
| MONITOR | |
| CMPS~RPM(REF) | XXX rpm |
| FR O2 MNTR-B2 | RICH |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B2 | XXX % |
| A/F ALPHA-B1 | XXX % |
| THRTL POS SEN | XXX V |
| | |

PEF882U

If OK, inspection end. If NG, go to following step.

3. Check air passage continuity.



SEF660U

| Condition PURG VOL CONT/V value | Air passage continuity between A and B |
|------------------------------------|---|
| 100.0% | Yes |
| 0.0% | No |

MTBL0241

If NG, replace the EVAP canister purge volume control solenoid valve.


OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 8. |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |


DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E

Diagnostic Procedure (Cont'd)

| 7 | CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | | | | | | | | | | | | |
|---|--|--|--|---|-----|-----------|----|----|---|----------|----|---|--|
| <p>⊗ Without CONSULT-II Check air passage continuity.</p> <div style="text-align: center;">  </div> <div style="text-align: right; margin-top: 10px;">SEF661U</div> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>No supply</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> <div style="text-align: right; margin-top: 10px;">MTBL0242</div> <p>If NG, replace the EVAP canister purge volume control solenoid valve.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace EVAP canister purge volume control solenoid valve.</td> </tr> </table> | | Condition | Air passage continuity between A and B | 12V direct current supply between terminals 1 and 2 | Yes | No supply | No | OK | ▶ | GO TO 8. | NG | ▶ | Replace EVAP canister purge volume control solenoid valve. |
| Condition | Air passage continuity between A and B | | | | | | | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | | | | | | | | | | | | |
| No supply | No | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | | |
| NG | ▶ | Replace EVAP canister purge volume control solenoid valve. | | | | | | | | | | | |

| | | | | | | | |
|---|---|------------|---|----------|----|---|------------|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE | | | | | | |
| <p>1. Turn ignition switch OFF. 2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair it.</td> </tr> </table> | | OK | ▶ | GO TO 9. | NG | ▶ | Repair it. |
| OK | ▶ | GO TO 9. | | | | | |
| NG | ▶ | Repair it. | | | | | |

| | | | | | | | |
|---|--|--|---|-----------|----|---|--|
| 9 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR | | | | | | |
| <p>1. Disconnect EVAP control system pressure sensor harness connector.</p> <div style="text-align: center;">  </div> <div style="text-align: right; margin-top: 10px;">AEC651A</div> <p>2. Check connectors for water. Water should not exist.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 10.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace EVAP control system pressure sensor.</td> </tr> </table> | | OK | ▶ | GO TO 10. | NG | ▶ | Replace EVAP control system pressure sensor. |
| OK | ▶ | GO TO 10. | | | | | |
| NG | ▶ | Replace EVAP control system pressure sensor. | | | | | |


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E

Diagnostic Procedure (Cont'd)


| | | |
|--|---|--|
| 10 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION | |
| Refer to "DTC Confirmation Procedure" for DTC P0450, EC-964. | | |
| OK or NG | | |
| OK | ▶ | GO TO 11. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

| 11 | CHECK EVAP CANISTER VENT CONTROL VALVE | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|-------------|--|----------------|-----|---------|--|----------------|--------|---------------|------|--------------|------|---------------|------|--|--|--|--|---|-----------|--|----|----|-----|-----|
| Check air passage continuity. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| E With CONSULT-II Perform "VENT CONTROL/V" in "ACTIVE TEST" mode. | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">VENT CONTROL/V</td> <td style="text-align: center;">OFF</td> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <td style="text-align: center;">CMPS-RPM (REF)</td> <td style="text-align: center;">XXXrpm</td> </tr> <tr> <td style="text-align: center;">FR O2 MNTR-B1</td> <td style="text-align: center;">RICH</td> </tr> <tr> <td style="text-align: center;">A/F ALPHA-B1</td> <td style="text-align: center;">XXX%</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXXV</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | ACTIVE TEST | | VENT CONTROL/V | OFF | MONITOR | | CMPS-RPM (REF) | XXXrpm | FR O2 MNTR-B1 | RICH | A/F ALPHA-B1 | XXX% | THRTL POS SEN | XXXV | | | | | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">OFF</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> | Condition | Air passage continuity between A and B | ON | No | OFF | Yes |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | OFF | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXXrpm | | | | | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX% | | | | | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXXV | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | No | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | Yes | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF156X | | | | | | | | | | | | | | | | | | | | | | | | | | |

| | |
|---|--|
| X Without CONSULT-II | |
| Condition | Air passage continuity between A and B |
| 12V direct current supply between terminals 1 and 2 | No |
| OFF | Yes |

MTBL0240

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.
 If portion **B** is rusted, replace control valve.



AEC783A

Make sure new O-ring is installed properly.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Replace EVAP canister vent control valve. |

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E

Diagnostic Procedure (Cont'd)

| 12 | CHECK CLOSED THROTTLE POSITION SWITCH | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|---|---------------------------|------------|-------------------|-----|-----------------------------------|----|-------|----------------|-----------------|---------------|-----------------|---------------------------------------|--|--|-------------------|---------------------------------------|----|---|-----------|----|---|---|
| <p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch OFF. 3. Remove vacuum hose connected to throttle opener. 4. Connect suitable vacuum hose to vacuum pump and the throttle opener (If so equipped). 5. Apply vacuum [more than -40.0kPa (-300mmHg, 11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener. 6. Turn ignition switch ON. 7. Select "DATA MONITOR" mode with CONSULT-II. 8. Check indication of "CLSD THL/P SW". <p>Measurement must be made with closed throttle position switch installed in vehicle.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Throttle valve conditions</th> <th style="text-align: center;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Completely closed</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">Partially open or completely open</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0247</p> <p>If NG, adjust closed throttle position switch. Check the following items. Refer to "Basic Inspection", EC-669.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Items</th> <th style="text-align: center;">Specifications</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition timing</td> <td style="text-align: center;">15° ± 2° BTDC</td> </tr> <tr> <td style="text-align: center;">Base idle speed</td> <td style="text-align: center;">700 ± 50 rpm (in "P" or "N" position)</td> </tr> <tr> <td style="text-align: center;">Closed throttle position switch idle position adjustment</td> <td style="text-align: center;">Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF</td> </tr> <tr> <td style="text-align: center;">Target idle speed</td> <td style="text-align: center;">750 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0226</p> <p>9. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; text-align: center;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 14.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>Replace throttle position switch with throttle position sensor.</td> </tr> </table> | | | Throttle valve conditions | Continuity | Completely closed | Yes | Partially open or completely open | No | Items | Specifications | Ignition timing | 15° ± 2° BTDC | Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | OK | ▶ | GO TO 14. | NG | ▶ | Replace throttle position switch with throttle position sensor. |
| Throttle valve conditions | Continuity | | | | | | | | | | | | | | | | | | | | | | | |
| Completely closed | Yes | | | | | | | | | | | | | | | | | | | | | | | |
| Partially open or completely open | No | | | | | | | | | | | | | | | | | | | | | | | |
| Items | Specifications | | | | | | | | | | | | | | | | | | | | | | | |
| Ignition timing | 15° ± 2° BTDC | | | | | | | | | | | | | | | | | | | | | | | |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | | | | | | | | | | | | | |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF | | | | | | | | | | | | | | | | | | | | | | | |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 14. | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace throttle position switch with throttle position sensor. | | | | | | | | | | | | | | | | | | | | | | |

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E


Diagnostic Procedure (Cont'd)

13 CHECK CLOSED THROTTLE POSITION SWITCH



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Remove vacuum hose connected to throttle opener (If so equipped).
4. Connect suitable vacuum hose to vacuum pump and the throttle opener.
5. Apply vacuum [more than -40.0kPa (-300mmHg, 11.81 inHg)] until the throttle drum becomes free from the rod of the throttle opener.
6. Disconnect closed throttle position switch harness connector.
7. Check continuity between closed throttle position switch terminals 4 and 5.
Resistance measurement must be made with closed throttle position switch installed in vehicle.



AEC654A

| Throttle valve conditions | Continuity |
|-----------------------------------|------------|
| Completely closed | Yes |
| Partially open or completely open | No |

MTBL0247

If NG, adjust closed throttle position switch.
Check the following items. Refer to "Basic Inspection", EC-669.

| Items | Specifications |
|--|--|
| Ignition timing | 15° ± 2° BTDC |
| Base idle speed | 700 ± 50 rpm (in "P" or "N" position) |
| Closed throttle position switch idle position adjustment | Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF |
| Target idle speed | 750 ± 50 rpm (in "P" or "N" position) |

MTBL0226

8. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 14. |
| NG | ▶ | Replace throttle position switch with throttle position sensor. |

14 CHECK EVAP PURGE LINE

Inspect EVAP purge line (pipe and rubber tube). Check for evidence of leaks.
Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-607.

OK or NG

| | | |
|----|---|-------------|
| OK | ▶ | GO TO 15. |
| NG | ▶ | Replace it. |

15 CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

| | | |
|--|---|-----------|
| | ▶ | GO TO 16. |
|--|---|-----------|

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 16 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

VG33E

Component Description



Component Description

NGEC0864

NOTE:

If DTC P1448 is displayed with P0440, perform trouble diagnosis for DTC P1448 first.

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0865

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|---------------|
| VENT CONT/V | ● Ignition switch: ON | OFF |

ECM Terminals and Reference Value

NGEC0866

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|----------------------------------|----------------------|----------------------------|
| 108 | R/G | EVAP canister vent control valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

NGEC0867

Malfunction is detected when EVAP canister vent control valve remains opened under specified driving conditions.

POSSIBLE CAUSE

NGEC0867S01

- EVAP canister vent control valve
- EVAP control system pressure sensor and circuit
- Blocked rubber tube to EVAP canister vent control valve
- Water separator
- EVAP canister is saturated with water.
- Vacuum cut valve

EC-1098

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

VG33E

DTC Confirmation Procedure

DTC Confirmation Procedure

NGEC0868

NOTE:

- If DTC P1448 is displayed with P0440, perform trouble diagnosis for DTC P1448 first.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

EVAP V/S LEAK P0440

1)PERFORM TEST AT A LOCATION OF 0-30C (32-86F)
 2)OPEN ENGINE HOOD.
 3)START ENGINE WITH VEHICLE STOPPED.
 IF ENG IS ON, STOP FOR 5 SEC. THEN RESTART.
 4)TOUCH START.

PEF405W

EVAP SML LEAK P0440

WAIT
 2 TO 10 MINUTES
 KEEP ENGINE RUNNING AT IDLE SPEED.

PEF929V

EVAP SML LEAK P0440

CAN NOT BE DIAGNOSED

FUEL TEMPERATURE IS TOO HIGH. RETEST AFTER FUEL HAS COOLED.

PEF669U

EVAP SML LEAK P0440

OK

PEF297U

Ⓜ With CONSULT-II TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is less than 3/4 full and vehicle is placed on flat level surface.
 - Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
- 1) Turn ignition switch ON.
 - 2) Turn ignition switch OFF and wait at least 5 seconds.
 - 3) Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
 - 4) Make sure that the following conditions are met.

| | |
|---------------|-----------------------|
| COOLAN TEMP/S | 0 - 70°C (32 - 158°F) |
| INT/A TEMP SE | 0 - 60°C (32 - 140°F) |

- 5) Select "EVAP SML LEAK P0440" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II. Follow the instruction displayed.

NOTE:

- If the CONSULT-II screen shown at left is displayed, stop the engine and stabilize the vehicle temperature at 25°C (77°F) or cooler. After "TANK F/TMP SE" becomes less than 30°C (86°F), retest. (Use a fan to reduce the stabilization time.)
 - If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to "Basic Inspection", EC-669.
 - The engine idle portion of this test (See illustration at left.) will take approximately 5 minutes.
- 6) Make sure that "OK" is displayed. If "NG" is displayed, go to the following step.

NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

- 7) Stop engine and wait at least 5 seconds, then turn ON.
- 8) Disconnect hose from water separator.
- 9) Select "VENT CONTROL/V" of "ACTIVE TEST" mode with CONSULT-II.
- 10) Touch ON and OFF alternately.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

VG33E

DTC Confirmation Procedure (Cont'd)

11

| ACTIVE TEST | |
|----------------|--------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B1 | XXX% |
| THRTL POS SEN | XXXV |
| | |
| | |
| | |

SEF157X

11) Make sure the following.

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|-----------------------------|---|
| ON | No |
| OFF | Yes |

If the result is NG, go to "Diagnostic Procedure", EC-1102.
If the result is OK, go to "Diagnostic Procedure" for DTC P0440, EC-949.

AEC783A

Overall Function Check

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a DTC might not be confirmed. NGEC0869

Without CONSULT-II

- 1) Disconnect hose from water separator.
- 2) Disconnect EVAP canister vent control valve harness connector.
- 3) Verify the following.

| Condition | Air passage continuity |
|---|------------------------|
| 12V direct current supply between terminals 1 and 2 | No |
| No supply | Yes |

If the result is NG, go to "Diagnostic Procedure", EC-1102.
If the result is OK, go to "Diagnostic Procedure" for DTC P0440, EC-949.

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)


VG33E

Wiring Diagram

Wiring Diagram

NGEC0870

EC-VENT/V-01





Refer to "EL-POWER".

: Detectable line for DTC
 : Non-detectable line for DTC

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST

RS
BT
HA

SC
EL
IDX



AEC017B


DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)


VG33E

Diagnostic Procedure

Diagnostic Procedure

NGEC0871

| | | | |
|--|--------------------------|---------------------------------------|--|
| 1 | CHECK RUBBER TUBE | | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check obstructed rubber tube connected to EVAP canister vent control valve. | | | |
|  | | | |
| SEF143S | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Clean, repair or replace rubber tube. | |

| | | | |
|--|------------------------------|--------------------------|--|
| 2 | CHECK WATER SEPARATOR | | |
| <ol style="list-style-type: none"> 1. Check visually for insect nests in the water separator air inlet. 2. Check visually for cracks or flaws in the appearance. 3. Check visually for cracks or flaws in the hose. 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged. | | | |
|  | | | |
| <p>* (A) : Bottom hole (To atmosphere) (B) : Emergency tube (From EVAP canister) (C) : Inlet port (To member)</p> | | | |
| SEF829T | | | |
| 5. In case of NG in items 2 - 4, replace the parts. | | | |
| NOTE: | | | |
| <ul style="list-style-type: none"> ● Do not disassemble water separator. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Replace water separator. | |

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

VG33E


Diagnostic Procedure (Cont'd)

3 CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

Check air passage continuity.

With CONSULT-II

Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.



| ACTIVE TEST | |
|----------------|--------|
| VENT CONTROL/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B1 | XXX% |
| THRTL POS SEN | XXXV |
| | |
| | |
| | |

| Condition VENT CONTROL/V | Air passage continuity between A and B |
|--------------------------|--|
| ON | No |
| OFF | Yes |


SEF156X

Without CONSULT-II

| Condition | Air passage continuity between A and B |
|---|--|
| 12V direct current supply between terminals 1 and 2 | No |
| OFF | Yes |

MTBL0240

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.
If portion **B** is rusted, replace control valve.



AEC783A

Make sure new O-ring is installed properly.

OK or NG


| | | |
|----|---|--|
| OK | ▶ | GO TO 4. |
| NG | ▶ | Replace EVAP canister vent control valve and O-ring. |


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

VG33E

Diagnostic Procedure (Cont'd)

| | | | | | | | |
|--|-------------------------------|---------------------------|---|----------|----|---|---------------------------|
| 4 | CHECK VACUUM CUT VALVE | | | | | | |
| <p>Check vacuum cut valve as follows:</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF379Q</p> <ol style="list-style-type: none"> 1. Plug port C and D with fingers. 2. Apply vacuum to port A and check that there is no suction from port B. 3. Apply vacuum to port B and check that there is suction from port A. 4. Blow air in port B and check that there is a resistance to flow out of port A. 5. Open port C and D. 6. Blow air in port A check that air flows freely out of port C. 7. Blow air in port B check that air flows freely out of port D. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace vacuum cut valve.</td> </tr> </table> | | OK | ▶ | GO TO 5. | NG | ▶ | Replace vacuum cut valve. |
| OK | ▶ | GO TO 5. | | | | | |
| NG | ▶ | Replace vacuum cut valve. | | | | | |

| | | | | | | | |
|--|--|----------|---|----------|----|---|----------|
| 5 | CHECK IF EVAP CANISTER SATURATED WITH WATER | | | | | | |
| <ol style="list-style-type: none"> 1. Remove EVAP canister with EVAP canister vent control valve attached. 2. Check if water will drain from the EVAP canister. <div style="text-align: center;">  </div> <p style="text-align: right;">SEF596U</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 6.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 8.</td> </tr> </table> | | OK | ▶ | GO TO 6. | NG | ▶ | GO TO 8. |
| OK | ▶ | GO TO 6. | | | | | |
| NG | ▶ | GO TO 8. | | | | | |

| | | | | | | | |
|--|----------------------------|----------------------------|---|----------|----|---|----------------------------|
| 6 | CHECK EVAP CANISTER | | | | | | |
| <p>Weigh the EVAP canister with the EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0 lb).</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace the EVAP canister.</td> </tr> </table> | | OK | ▶ | GO TO 8. | NG | ▶ | Replace the EVAP canister. |
| OK | ▶ | GO TO 8. | | | | | |
| NG | ▶ | Replace the EVAP canister. | | | | | |

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

VG33E

Diagnostic Procedure (Cont'd)


| | |
|--|---------------------------------------|
| 7 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● EVAP canister for damage ● EVAP hose between EVAP canister and water separator for clogging or poor connection | |
| ▶ | Repair hose or replace EVAP canister. |

GI
MA

| | |
|--|---|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE |
| Check disconnection or improper connection of hose connected to EVAP control system pressure sensor. | |
| OK or NG | |
| OK | ▶ GO TO 9. |
| NG | ▶ Repair it. |

EM
LC

EC

| | |
|---|--|
| 9 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR |
| 1. Disconnect EVAP control system pressure sensor harness connector. | |
|  | |
| 2. Check connectors for water. Water should not exist. | |
| OK or NG | |
| OK | ▶ GO TO 10. |
| NG | ▶ Replace EVAP control system pressure sensor. |

FE
CL
MT
AT
TF

AEC651A

PD

AX

| | |
|--|---|
| 10 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION |
| Refer to "DTC Confirmation Procedure" for DTC P0450, EC-964. | |
| OK or NG | |
| OK | ▶ GO TO 11. |
| NG | ▶ Replace EVAP control system pressure sensor. |

SU
BR

ST

| | |
|---|------------------------------------|
| 11 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

RS
BT

HA

SC


EL

IDX

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)

VG33E

Description



Description

COMPONENT DESCRIPTION


The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.

The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

NGEC0873

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|-----------------------|---------------|
| VC/V BYPASS/V | ● Ignition switch: ON | OFF |

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

NGEC0874

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|-------------------------------|----------------------|----------------------------|
| 120 | P/B | Vacuum cut valve bypass valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

Malfunction is detected when an improper voltage signal is sent to ECM through vacuum cut valve bypass valve. NGEC0875

POSSIBLE CAUSE

- Harness or connectors
(The vacuum cut valve bypass valve circuit is open or shorted.)
- Vacuum cut valve bypass valve


DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test. NGEC0876

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle speed.



Ⓟ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1109.

Ⓢ With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)


VG33E

Wiring Diagram



Wiring Diagram

NGEC0877

EC-BYPS/V-01



— : Detectable line for DTC
— : Non-detectable line for DTC



AEC970A

Diagnostic Procedure

NGENC0878

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

 GI
MA
EM

| 2 | CHECK VACUUM CUT VALVE BYPASS VALVE CIRCUIT | | | | | | | | | | | | | | | | | | | | | |
|--|--|----------|-------------|--|---------------|----|---------|--|---------------|---------|---------------|------|---------------|------|--------------|-------|--------------|-------|---------------|-------|--|--|
| <p> With CONSULT-II</p> <p>1. Turn ignition switch OFF and then ON. 2. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II. 3. Touch "ON/OFF" on CONSULT-II screen.</p> | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>VC/V BYPASS/V</th> <th>ON</th> </tr> </thead> <tbody> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS-RPM(REF)</th> <th>XXX rpm</th> </tr> <tr> <td>FR O2 MNTR-B2</td> <td>LEAN</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td>LEAN</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XXX %</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td>XXX %</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | VC/V BYPASS/V | ON | MONITOR | | CMPS-RPM(REF) | XXX rpm | FR O2 MNTR-B2 | LEAN | FR O2 MNTR-B1 | LEAN | A/F ALPHA-B2 | XXX % | A/F ALPHA-B1 | XXX % | THRTL POS SEN | XXX V | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| VC/V BYPASS/V | ON | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX % | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXX V | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| <p>4. Make sure that clicking sound is heard from the vacuum cut valve bypass valve.</p> <p style="text-align: right;">PEF909U</p> | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 3. | | | | | | | | | | | | | | | | | | | | |

 LC
EC

 FE
CL
MT
AT

 TF
PD

 AX
SU

 BR
ST

 RS
BT

 HA
SC

 EL
IDX

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)


VG33E

Diagnostic Procedure (Cont'd)

3 CHECK VACUUM CUT VALVE BYPASS VALVE POWER SUPPLY CIRCUIT


Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect vacuum cut valve bypass valve harness connector.



SEF186S

3. Turn ignition switch ON.
4. Check voltage between terminal 1 and ground with CONSULT-II or tester.



SEF659W

Voltage: Battery voltage

OK or NG

| | | |
|----|---|----------|
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

4 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E74, M82
- Harness connectors M67, C1
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between vacuum cut valve bypass valve and fuse

▶ Repair harness or connectors.

5 CHECK VACUUM CUT VALVE BYPASS VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 120 and valve terminal 2. Refer to Wiring Diagram.
Continuity should exist.
4. Also check harness for short to ground and short to power.

OK or NG


| | | |
|----|---|----------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | GO TO 6. |


DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|--|
| 6 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors C1, M67 ● Harness connectors M81, F36 ● Harness for open or short between vacuum cut valve bypass valve and ECM | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |


| 7 | CHECK VACUUM CUT VALVE BYPASS VALVE | | | | | | | | | | | | | | | | | | | | |
|--|---|----------------------------|---|---------------|-----|---------|----|----------------|--------|---------------|------|--------------|------|---------------|------|--|--|--|--|--|--|
| (P) With CONSULT-II 1. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode. 2. Check air passage continuity and operation delay time under the following conditions. | | | | | | | | | | | | | | | | | | | | | |
|  | <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>VC/V BYPASS/V</th> <th>OFF</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS-RPM (REF)</th> <th>XXXrpm</th> </tr> <tr> <th>FR O2 MNTR-B1</th> <th>RICH</th> </tr> <tr> <th>A/F ALPHA-B1</th> <th>XXX%</th> </tr> <tr> <th>THRTL POS SEN</th> <th>XXXV</th> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </thead> </table> | ACTIVE TEST | | VC/V BYPASS/V | OFF | MONITOR | | CMPS-RPM (REF) | XXXrpm | FR O2 MNTR-B1 | RICH | A/F ALPHA-B1 | XXX% | THRTL POS SEN | XXXV | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | |
| VC/V BYPASS/V | OFF | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXXrpm | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX% | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXXV | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Condition VC/V BYPASS/V</th> <th>Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Yes</td> </tr> <tr> <td>OFF</td> <td>No</td> </tr> </tbody> </table> | | Condition VC/V BYPASS/V | Air passage continuity between A and B | ON | Yes | OFF | No | | | | | | | | | | | | | | |
| Condition VC/V BYPASS/V | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | |
| ON | Yes | | | | | | | | | | | | | | | | | | | | |
| OFF | No | | | | | | | | | | | | | | | | | | | | |
| SEF158X | | | | | | | | | | | | | | | | | | | | | |

| (X) Without CONSULT-II 1. Check air passage continuity and operation delay time under the following conditions. | | | | | | | |
|---|---|-----------|---|---|-----|-----------|----|
|  | | | | | | | |
| SEF351Q | | | | | | | |
| <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Condition</th> <th>Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td>Yes</td> </tr> <tr> <td>No supply</td> <td>No</td> </tr> </tbody> </table> | | Condition | Air passage continuity between A and B | 12V direct current supply between terminals 1 and 2 | Yes | No supply | No |
| Condition | Air passage continuity between A and B | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | | | | | | |
| No supply | No | | | | | | |
| MTBL0242 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ GO TO 8. | | | | | | |
| NG | ▶ Replace vacuum cut valve bypass valve. | | | | | | |

| | |
|---|------------------------------------|
| 8 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

Description



Description

COMPONENT DESCRIPTION

NGEC0879

NGEC0879S01

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

EVAPORATIVE EMISSION SYSTEM DIAGRAM

NGEC0879S02



CONSULT-II Reference Value in Data Monitor Mode

NGEC0880

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|-----------------------|---------------|
| VC/V BYPASS/V | ● Ignition switch: ON | OFF |

ECM Terminals and Reference Value

NGEC0881

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|-------------------------------|----------------------|----------------------------|
| 120 | P/B | Vacuum cut valve bypass valve | [Ignition switch ON] | BATTERY VOLTAGE (11 - 14V) |

On Board Diagnosis Logic

Malfunction is detected when vacuum cut valve bypass valve does not operate properly. NGEC0882

POSSIBLE CAUSE

- Vacuum cut valve bypass valve NGEC0882S01
- Vacuum cut valve
- Bypass hoses for clogging
- EVAP control system pressure sensor and circuit
- EVAP canister vent control valve
- Hose between fuel tank and vacuum cut valve clogged
- Hose between vacuum cut valve and EVAP canister clogged
- EVAP canister
- EVAP purge port of fuel tank for clogging

| | |
|------------------|---------------------|
| 7 | VC CUT/V BP/V P1491 |
| OUT OF CONDITION | |
| MONITOR | |
| CMPS~RPM(POS) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF618W

| | |
|---------------|---------------------|
| 7 | VC CUT/V BP/V P1491 |
| TESTING | |
| MONITOR | |
| CMPS~RPM(POS) | XXX rpm |
| THRTL POS SEN | XXX V |
| B/FUEL SCHDL | XXX msec |

PEF619W

| | |
|-----------|---------------------|
| 7 | VC CUT/V BP/V P1491 |
| COMPLETED | |

PEF912U

DTC Confirmation Procedure

CAUTION:
Always drive vehicle at a safe speed. NGEC0883

NOTE:
If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test. AT

TESTING CONDITION:
Always perform test at a temperature of 5 to 30°C (41 to 86°F). TF

With CONSULT-II

- 1) Turn ignition switch ON. PD
- 2) Start engine and warm it up to normal operating temperature. AX
- 3) Turn ignition switch OFF and wait at least 5 seconds. SU
- 4) Start engine and let it idle for at least 70 seconds. BR
- 5) Select "VC CUT/V BP/V P1491" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II. ST
- 6) Touch "START". RS
- 7) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)


| | |
|----------------|--|
| CMPS-RPM (POS) | 500 - 3,000 rpm (A/T models) 500 - 3,300 rpm (M/T models) |
| Selector lever | Suitable position |
| Vehicle speed | 36 - 120 km/h (22 - 75 MPH) |
| B/FUEL SCHDL | Less than 5 msec |

If "TESTING" is not displayed after 5 minutes, retry from step 3. HA

- 8) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-1116. SC

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Overall Function Check



Overall Function Check

NGEC0884

Use this procedure to check the overall function of vacuum cut valve bypass valve. During this check, the 1st trip DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
- 2) Apply vacuum to port **A** and check that there is no suction from port **B**.
- 3) Apply vacuum to port **B** and check that there is suction from port **A**.
- 4) Blow air in port **B** and check that there is a resistance to flow out of port **A**.
- 5) Supply battery voltage to the terminal.
- 6) Blow air in port **A** and check that air flows freely out of port **B**.
- 7) Blow air in port **B** and check that air flows freely out of port **A**.
- 8) If NG, go to "Diagnostic Procedure", EC-1116.

DTC P1491 VACUUM CUT VALVE BYPASS VALVE


VG33E

Wiring Diagram

Wiring Diagram


NGEC0885

EC-BYPS/V-01



Refer to "EL-POWER".
 — : Detectable line for DTC
 — : Non-detectable line for DTC

- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX




AEC019B


Diagnostic Procedure

NGEC0886

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

| 2 | CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION | | | | | | | | | | | | | | | | | | | | | |
|--|--|----------|-------------|--|---------------|----|---------|--|----------------|--------|---------------|------|---------------|------|--------------|------|--------------|------|---------------|------|--|--|
| <p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly. 3. Apply vacuum to port A and check that there is no suction from port B. 4. Apply vacuum to port B and check that there is suction from port A. 5. Blow air in port B and check that there is a resistance to flow out of port A. 6. Turn ignition switch ON. 7. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II and touch "ON". 8. Blow air in port A and check that air flows freely out of port B. 9. Blow air in port B and check that air flows freely out of port A. | | | | | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>VC/V BYPASS/V</th> <th>ON</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS-RPM (REF)</th> <th>XXXrpm</th> </tr> </thead> <tbody> <tr> <td>FR O2 MNTR-B2</td> <td>LEAN</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td>LEAN</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XXX%</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td>XXX%</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXXV</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | VC/V BYPASS/V | ON | MONITOR | | CMPS-RPM (REF) | XXXrpm | FR O2 MNTR-B2 | LEAN | FR O2 MNTR-B1 | LEAN | A/F ALPHA-B2 | XXX% | A/F ALPHA-B1 | XXX% | THRTL POS SEN | XXXV | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | |
| VC/V BYPASS/V | ON | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXXrpm | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B2 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | LEAN | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B2 | XXX% | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX% | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXXV | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 5. | | | | | | | | | | | | | | | | | | | | |

SEF159X

| | |
|---|--|
| 3 | CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION |
| <p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly. 3. Apply vacuum to port A and check that there is no suction from port B. 4. Apply vacuum to port B and check that there is suction from port A. 5. Blow air in port B and check that there is a resistance to flow out of port A. 6. Disconnect vacuum cut valve bypass valve harness connector. 7. Supply battery voltage to the terminal. 8. Blow air in port A and check that air flows freely out of port B. 9. Blow air in port B and check that air flows freely out of port A. | |
|  | |
| OK or NG | |
| OK | ▶ GO TO 4. |
| NG | ▶ GO TO 5. |

| | |
|--|------------------------------|
| 4 | CHECK EVAP PURGE LINE |
| <ol style="list-style-type: none"> 1. Check EVAP purge line between EVAP canister and fuel tank for clogging or disconnection. 2. Check EVAP purge port of fuel tank for clogging. 3. Check EVAP canister. Refer to EC-604. | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG (Step 1) | ▶ Repair it. |
| NG (Step 2) | ▶ Clean EVAP purge port. |
| NG (Step 3) | ▶ Replace EVAP canister. |


| | |
|----------------------------------|----------------------------|
| 5 | CHECK BYPASS HOSE |
| Check bypass hoses for clogging. | |
| OK or NG | |
| OK | ▶ GO TO 6. |
| NG | ▶ Repair or replace hoses. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

6 **CHECK VACUUM CUT VALVE BYPASS VALVE**

With CONSULT-II

1. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.




| ACTIVE TEST | |
|----------------|--------|
| VC/V BYPASS/V | OFF |
| MONITOR | |
| CMPS-RPM (REF) | XXXrpm |
| FR O2 MNTR-B1 | RICH |
| A/F ALPHA-B1 | XXX% |
| THRRL POS SEN | XXXV |
| | |
| | |
| | |

| Condition VC/V BYPASS/V | Air passage continuity between A and B |
|----------------------------|---|
| ON | Yes |
| OFF | No |

SEF158X

1. Check air passage continuity and operation delay time under the following conditions.

Without CONSULT-II




| Condition | Air passage continuity between A and B |
|--|---|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No supply | No |

SEF351Q

MTBL0242


OK or NG

| | | |
|----|---|--|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace vacuum cut valve bypass valve. |

| | | | | | | | | | |
|----------|-------------------------------|---|----|---|----------|----|---|---------------------------|---|
| 7 | CHECK VACUUM CUT VALVE | <p>Check vacuum cut valve as follows:</p> <div style="text-align: center;">  </div> <ol style="list-style-type: none"> 1. Plug port C and D with fingers. 2. Apply vacuum to port A and check that there is no suction from port B. 3. Apply vacuum to port B and check that there is suction from port A. 4. Blow air in port B and check that there is a resistance to flow out of port A. 5. Open port C and D. 6. Blow air in port A check that air flows freely out of port C. 7. Blow air in port B check that air flows freely out of port D. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace vacuum cut valve.</td> </tr> </table> | OK | ▶ | GO TO 8. | NG | ▶ | Replace vacuum cut valve. | GI MA EM LC EC FE CL MT AT |
| OK | ▶ | GO TO 8. | | | | | | | |
| NG | ▶ | Replace vacuum cut valve. | | | | | | | |

SEF379Q

| | | | | | | | | | |
|----------|---|---|----|---|----------|----|---|-----------|----------------|
| 8 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE | <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair it</td> </tr> </table> | OK | ▶ | GO TO 9. | NG | ▶ | Repair it | TF PD AX |
| OK | ▶ | GO TO 9. | | | | | | | |
| NG | ▶ | Repair it | | | | | | | |

| | | | | | | | | | |
|----------|--|--|----|---|-----------|----|---|--|---|
| 9 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR | <ol style="list-style-type: none"> 1. Disconnect EVAP control system pressure sensor harness connector. <div style="text-align: center;">  </div> <ol style="list-style-type: none"> 2. Check connectors for water. Water should not exist. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 10.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace EVAP control system pressure sensor.</td> </tr> </table> | OK | ▶ | GO TO 10. | NG | ▶ | Replace EVAP control system pressure sensor. | SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 10. | | | | | | | |
| NG | ▶ | Replace EVAP control system pressure sensor. | | | | | | | |

AEC651A


| | | |
|--|---|--|
| 10 | CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION | |
| Refer to "DTC Confirmation Procedure" for DTC P0450, EC-964. | | |
| OK or NG | | |
| OK | ▶ | GO TO 11. |
| NG | ▶ | Replace EVAP control system pressure sensor. |

| 11 | CHECK EVAP CANISTER VENT CONTROL VALVE | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|-------------|--|----------------|-----|---------|--|----------------|--------|---------------|------|--------------|------|---------------|------|--|--|--|--|--|--|---|-----------|--|-------------------|----|--------------------|-----|
| Check air passage continuity. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| E With CONSULT-II Perform "VENT CONTROL/V" in "ACTIVE TEST" mode. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>VENT CONTROL/V</td> <td>OFF</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS-RPM (REF)</td> <td>XXXrpm</td> </tr> <tr> <td>FR O2 MNTR-B1</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA-B1</td> <td>XXX%</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXXV</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | ACTIVE TEST | | VENT CONTROL/V | OFF | MONITOR | | CMPS-RPM (REF) | XXXrpm | FR O2 MNTR-B1 | RICH | A/F ALPHA-B1 | XXX% | THRTL POS SEN | XXXV | | | | | | | <table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>VENT CONTROL/V ON</td> <td>No</td> </tr> <tr> <td>VENT CONTROL/V OFF</td> <td>Yes</td> </tr> </tbody> </table> | Condition | Air passage continuity between A and B | VENT CONTROL/V ON | No | VENT CONTROL/V OFF | Yes |
| | ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS-RPM (REF) | XXXrpm | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FR O2 MNTR-B1 | RICH | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/F ALPHA-B1 | XXX% | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| THRTL POS SEN | XXXV | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condition | Air passage continuity between A and B | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V ON | No | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VENT CONTROL/V OFF | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SEF156X | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| X Without CONSULT-II | | | | | | | | |
|--|--|--|---|----|-----|-----|--|--|
| <table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>Air passage continuity between A and B</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td>No</td> </tr> <tr> <td>OFF</td> <td>Yes</td> </tr> </tbody> </table> | Condition | Air passage continuity between A and B | 12V direct current supply between terminals 1 and 2 | No | OFF | Yes | | |
| Condition | Air passage continuity between A and B | | | | | | | |
| 12V direct current supply between terminals 1 and 2 | No | | | | | | | |
| OFF | Yes | | | | | | | |

MTBL0240

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.
 If portion **B** is rusted, replace control valve.



AEC783A

Make sure new O-ring is installed properly.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 12. |
| NG | ▶ | Replace EVAP canister vent control valve. |

| | | |
|---|------------------------------------|-----------------------|
| 12 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| ▶ | | INSPECTION END |

Component Description

The malfunction information related to A/T (Automatic Transmission) is transferred through the line (circuit) from TCM (Transmission control module) to ECM. Therefore, be sure to erase the malfunction information such as DTC not only in TCM (Transmission control module) but also ECM after the A/T related repair.

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|------------------|---|-------------------|
| 7 | G/B | A/T check signal | [Ignition switch ON] [Engine is running] | 0 - 3.0V |

On Board Diagnosis Logic

Malfunction is detected when an incorrect signal from TCM (Transmission control module) is sent to ECM.

POSSIBLE CAUSE

- Harness or connectors
[The communication line circuit between ECM and TCM (Transmission control module) is open or shorted.]
- Dead (Weak) battery
- TCM (Transmission control module)

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

Ⓔ With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 40 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1123.

Ⓔ With GST



Follow the procedure "With CONSULT-II".



Wiring Diagram



NGEC0891

EC-ATDIAG-01



Diagnostic Procedure

NGEC0892

| | | |
|--|---|----------|
| 1 | CHECK A/T DIAGNOSIS COMMUNICATION LINE INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.</p> <div style="text-align: center;"> <p>Driver side</p>  </div> <div style="text-align: center;"> <p>View with instrument lower panel LH removed</p>  </div> <p style="text-align: right;"><small>SEF324V</small></p> <p>3. Check harness continuity between ECM terminal 7 and TCM (Transmission Control Module) terminal 15. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

| | | |
|--|-----------------------------------|--|
| 2 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M58, F28 ● Harness for open or short between ECM and TCM (Transmission Control Module) | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |


| | | |
|---|------------------------------------|-----------------------|
| 3 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| ▶ | | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

VG33E

Component Description



Component Description

When the gear position is "P" (A/T models only) or "N", park/neutral position (PNP) switch is "ON". NGEC0893

ECM detects the position because the continuity of the line (the "ON" signal) exists.

For A/T models, the park/neutral position (PNP) switch assembly also includes a transmission range switch to detect selector lever position.

CONSULT-II Reference Value in Data Monitor Mode

NGEC0894

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|-----------------------|---------------|
| P/N POSI SW | ● Ignition switch: ON | ON |
| | Except above | OFF |

ECM Terminals and Reference Value

NGEC0895

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|------------------------------------|---|-------------------|
| 22 | L/B | Park/neutral position (PNP) switch | [Ignition switch ON] ● Gear position is "N" or "P" (A/T models) ● Gear position is neutral (M/T models) | Approximately 0V |
| | | | [Ignition switch ON] ● Except the above gear position | Approximately 5V |

On Board Diagnosis Logic

NGEC0896

Malfunction is detected when the signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.

POSSIBLE CAUSE

NGEC0896S01

- Harness or connectors
[The park/neutral position (PNP) switch circuit is open or shorted.]
- Park/neutral position (PNP) switch

DTC Confirmation Procedure

NGEC0897

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

VG33E

DTC Confirmation Procedure (Cont'd)

2

| DATA MONITOR | |
|--------------|---------|
| MONITORING | NO FAIL |
| P/N POSI SW | ON |

PEF963N

5

| DATA MONITOR | |
|------------------------|---------|
| MONITORING | NO FAIL |
| CMPS~RPM (POS) XXX rpm | |
| COOLAN TEMP/S XXX°C | |
| VHCL SPEED SE XXX km/h | |
| P/N POSI SW | OFF |
| B/FUEL SCHDL | XXX ms |

SEF381X

With CONSULT-II

- 1) Turn ignition switch ON.
- 2) Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.


| Position (Selector lever) | Known good signal |
|---------------------------|-------------------|
| "N" and "P" position | ON |
| Except the above position | OFF |

If NG, go to "Diagnostic Procedure", EC-1127.
If OK, go to following step.

- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine and warm it up to normal operating temperature.
- 5) Maintain the following conditions for at least 60 consecutive seconds.

| | |
|----------------|--|
| CMPS-RPM (POS) | 1,600 - 2,650 rpm (A/T models) 1,700 - 2,700 rpm (M/T models) |
| COOLAN TEMP/S | More than 70°C (158°F) |
| B/FUEL SCHDL | 1.6 - 6.5 msec (A/T models) 1.9 - 5.5 msec (M/T models) |
| VHCL SPEED SE | 71 - 100 km/h (44 - 62 MPH) |
| Selector lever | Suitable position |

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-1127.



Overall Function Check

Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

Without CONSULT-II

- 1) Turn ignition switch ON.
- 2) Check voltage between ECM terminal 22 and body ground under the following conditions.

| Condition (Gear position) | Voltage (V) (Known good data) |
|---------------------------|-------------------------------|
| "P" and "N" position | Approx. 0 |
| Except the above position | Approx. 5 |

- 3) If NG, go to "Diagnostic Procedure", EC-1127.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

VG33E

Wiring Diagram



Wiring Diagram

NGEC0899

EC-PNP/SW-01

- : With theft warning system
- : Without theft warning system
- : With A/T
- : With M/T

- : Detectable line for DTC
- : Non-detectable line for DTC




AEC972A

Diagnostic Procedure FOR M/T MODELS

NGE0900

NGE0900S01

| | | |
|--|---|----------|
| 1 | CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT | |
| 1. Turn ignition switch OFF. 2. Disconnect park/neutral position (PNP) switch harness connector. | | |
|  <p>Park/neutral position (PNP) switch</p> | | |
| 3. Check harness continuity between PNP switch terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist. | | |
| 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

AEC877A

| | | |
|---|-----------------------------------|--|
| 2 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors F201, F43 ● Harness for open or short between park/neutral position (PNP) switch and engine ground | | |
| ▶ Repair open circuit or short to ground or short to power in harness or connectors. | | |

| | | |
|--|---|----------|
| 3 | CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 22 and PNP switch terminal 1. Refer to Wiring Diagram. Continuity should exist. | | |
| 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

| | | |
|---|-----------------------------------|--|
| 4 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors F43, F201 ● Harness for open or short between ECM and park/neutral position (PNP) switch | | |
| ▶ Repair open circuit or short to ground or short to power in harness or connectors. | | |

| | | |
|---|---|---|
| 5 | CHECK PARK/NEUTRAL POSITION (PNP) SWITCH | |
| Refer to "Position Switch Check", "ON-VEHICLE SERVICE", <i>MT-8</i> . | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace park/neutral position (PNP) switch. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH



VG33E


Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 6 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |

FOR A/T MODELS

=NGEC0900S02

| | | | |
|----------|--|--|---|
| 1 | CHECK PNP SWITCH POWER SUPPLY CIRCUIT-I | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect park/neutral position (PNP) relay.</p> <div style="text-align: center;">  <p>Throttle position sensor connector</p> </div> <p style="text-align: right;">AEC665A</p> <p>3. Turn ignition switch ON.</p> <p>4. Shift selector lever to "P" or "N" position.</p> <p>5. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF661W</p> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> | GI MA EM LC EC FE CL MT AT TF PD AX |
| OK | ▶ | GO TO 6. | |
| NG | ▶ | GO TO 2. | |

| | | | |
|----------|---|--|---|
| 2 | CHECK PNP SWITCH POWER SUPPLY CIRCUIT-II | <p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect park/neutral position (PNP) switch harness connector.</p> <div style="text-align: center;">  <p>Relay box</p> <p>PNP switch harness connector</p> </div> <p style="text-align: right;">AEC662A</p> <p>3. Check harness continuity between park/neutral position (PNP) switch terminal 2 and park/neutral position (PNP) relay terminal 2. Refer to Wiring Diagram.</p> <p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | SU BR ST RS BT HA SC EL IDX |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. | |

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|--|
| 3 | CHECK PNP SWITCH POWER SUPPLY CIRCUIT-III |
| 1. Turn ignition switch OFF. 2. Check voltage between park/neutral position (PNP) switch terminal 1 and ground with CONSULT-II or tester. Refer to Wiring Diagram. Voltage: Battery voltage | |
| OK or NG | |
| OK | ▶ GO TO 5. |
| NG | ▶ GO TO 4. |

| | |
|--|--|
| 4 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none">● Fuse block (J/B) connector E49● 10A fuse● Harness for open or short between park/neutral position (PNP) switch and fuse | |
| | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|--|---|
| 5 | CHECK PARK/NEUTRAL POSITION (PNP) SWITCH |
| Refer to "Component Inspection", AT-104 . | |
| OK or NG | |
| OK | ▶ GO TO 11. |
| NG | ▶ Replace park/neutral position (PNP) switch. |

| | |
|--|--|
| 6 | CHECK PNP RELAY GROUND CIRCUIT FOR OPEN AND SHORT |
| 1. Turn ignition switch OFF. 2. Check harness continuity between relay terminals 1, 6 and body ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG (With theft warning system) | ▶ GO TO 7. |
| NG (Without theft warning system) | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|-----------------------------------|
| 7 | DETECT MALFUNCTIONING PART |
| Check the circuit between park/neutral position (PNP) relay and body ground. Refer to "STARTING SYSTEM", SC-6 . | |
| OK or NG | |
| OK | ▶ GO TO 11. |
| NG | ▶ Repair or replace. |


DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|--|--|-----------|
| 8 | CHECK PNP RELAY INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 22 and relay terminal 7. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | GO TO 9. |

| | | |
|--|-----------------------------------|--|
| 9 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors F36, M81 ● Harness connectors M65, E43 ● Harness for open or short between ECM and park/neutral position (PNP) relay | | |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|---|--|--|
| 10 | CHECK PARK/NEUTRAL POSITION (PNP) RELAY | |
| 1. Apply 12V direct current between park/neutral position (PNP) relay terminals 1 and 2. 2. Check continuity between park/neutral position (PNP) relay terminals 3 and 5, 6 and 7. | | |
|  | | |
| 12V (1 and 2) applied: Continuity should exist. No voltage applied: Continuity should not exist. | | |
| OK or NG | | |
| OK | ▶ | GO TO 11. |
| NG | ▶ | Replace park/neutral position (PNP) relay. |

| | | |
|---|------------------------------------|-----------------------|
| 11 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | |
| ▶ | | INSPECTION END |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

VG33E

System Description

System Description

NGEC0901

COOLING FAN CONTROL


NGEC0901S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|----------------------------|---------------------|----------------------|
| Vehicle speed sensor | Vehicle speed | Cooling fan control | Cooling fan relay(s) |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Ignition switch | Start signal | | |
| Camshaft position sensor | Engine speed | | |

The ECM controls the cooling fan corresponding to the signals sent from the vehicle speed and engine coolant temperature. The control system has 2-step control [ON/OFF].

OPERATION

NGEC0901S02



CONSULT-II Reference Value in Data Monitor Mode

NGEC0902

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|--|
| COOLING FAN | <ul style="list-style-type: none"> Engine: Idling, after warming up Air conditioner switch: OFF | Engine coolant temperature is 94°C (201°F) or less. OFF |
| | | Engine coolant temperature is 95°C (203°F) or more. ON |

ECM Terminals and Reference Value

NGEC0903

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|-------------------|--|----------------------------|
| 36 | LG/R | Cooling fan relay | [Engine is running] <ul style="list-style-type: none"> Cooling fan is not operating | BATTERY VOLTAGE (11 - 14V) |
| | | | [Engine is running] <ul style="list-style-type: none"> Cooling fan is operating | 0 - 0.6V |

On Board Diagnosis Logic

NGEC0904

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

Malfunction is detected when engine coolant temperature reaches an abnormally high temperature.

CAUTION:

When a malfunction is indicated be sure to replace the coolant, follow the procedure in “Changing Engine Coolant”, “ENGINE MAINTENANCE”, MA-27. Also, replace the engine oil.

- 1) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to “Anti-freeze Coolant Mixture Ratio”, “RECOMMENDED FLUIDS AND LUBRICANTS”, MA-16.
- 2) After refilling coolant, run engine to ensure that no water-flow noise is emitted.

POSSIBLE CAUSE

NGEC0904S01

- Harness or connectors
(The cooling fan circuit is open or shorted.)
- Cooling fan
- Radiator hose
- Radiator
- Radiator cap
- Water pump
- Thermostat

For more information, refer to “MAIN 12 CAUSES OF OVERHEATING”, EC-1143.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL


IDX



4

| ACTIVE TEST | |
|----------------|--------|
| COOLING FAN | OFF |
| MONITOR | |
| COOLANT TEMP/S | XXX °C |
| | |
| | |
| | |
| | |
| | |
| | |

SEF376X



Overall Function Check

NGEC0905

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

With CONSULT-II

- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-1136.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-1136.
- 3) Turn ignition switch ON.
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
- 5) Make sure that cooling fan operates.
- 6) If NG, go to "Diagnostic Procedure", EC-1136.

Without CONSULT-II

- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-1136.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-1136.
- 3) Turn ignition switch OFF.
- 4) Disconnect engine coolant temperature sensor harness connector.
- 5) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
- 6) Start engine and make sure that cooling fan operates.
Be careful not to overheat engine.
- 7) If NG, go to "Diagnostic Procedure", EC-1136.

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)


VG33E

Wiring Diagram


Wiring Diagram

NGEC0906

EC-COOL/F-01



Refer to the following.
 (M65), (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)



AEC973A

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


Diagnostic Procedure

NGEC0907


| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

| 2 | CHECK COOLING FAN OPERATION | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|------------------------------------|----------|-------------|--|-------------|-----|---------|--|----------------|--------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Ⓜ With CONSULT-II 1. Turn ignition switch ON. 2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II (Low speed). | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>COOLING FAN</th> <th>OFF</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>COOLANT TEMP/S</th> <th>XXX °C</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> | | | ACTIVE TEST | | COOLING FAN | OFF | MONITOR | | COOLANT TEMP/S | XXX °C | | | | | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | |
| COOLING FAN | OFF | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | |
| COOLANT TEMP/S | XXX °C | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Does cooling fan rotate? Yes or No | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Yes | ▶ | GO TO 4. | | | | | | | | | | | | | | | | | | | | | | | | |
| No | ▶ | GO TO 9. | | | | | | | | | | | | | | | | | | | | | | | | |


SEF376X

| | | |
|---|------------------------------------|----------|
| 3 | CHECK COOLING FAN OPERATION | |
| ⓧ Without CONSULT-II 1. Turn ignition switch OFF. 2. Disconnect engine coolant temperature sensor harness connector. 3. Connect 150Ω resistor to engine coolant temperature sensor harness connector. 4. Start engine and make sure that cooling fan operates. | | |
|  | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 9. |

SEF085T

| | | |
|---|--------------------------------------|---|
| 4 | CHECK COOLING SYSTEM FOR LEAK | |
| <p>Apply pressure to the cooling system with a tester, and check if the pressure drops.</p> <p>CAUTION: Higher than the specified pressure may cause radiator damage.</p> <p style="color: blue;">Testing pressure: 157 kPa (1.6 kg/cm², 23 psi)</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Hose adapter</p> <p style="margin-left: 100px;">EG17650301 (J33984-A)</p> </div> <p style="text-align: right;">SLC754A</p> <p>Pressure should not drop.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | <p>Check the following for leak</p> <ul style="list-style-type: none"> ● Hose ● Radiator ● Water pump <p>Refer to "Water Pump", LC-28.</p> |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

| | | |
|--|---------------------------|-----------------------|
| 5 | CHECK RADIATOR CAP | |
| <p>Apply pressure to cap with a tester and check radiator cap relief pressure.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">EG17650301 (J33984-A)</p> </div> <p style="text-align: right;">SLC755A</p> <p style="color: blue;">Radiator cap relief pressure: 59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Replace radiator cap. |


TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

VG33E

Diagnostic Procedure (Cont'd)

6 CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures.
It should seat tightly.
2. Check valve opening temperature and valve lift.



SLC343



Valve opening temperature:
82°C (180°F) [standard]

Valve lift:
More than 10 mm/95°C (0.39 in/203°F)

3. Check if valve is closed at 5°C (9°F) below valve opening temperature.
For details, refer to "Thermostat", **LC-29**.

OK or NG

| | | |
|----|---|--------------------|
| OK | ▶ | GO TO 7. |
| NG | ▶ | Replace thermostat |

| 7 | CHECK ENGINE COOLANT TEMPERATURE SENSOR | <p>Check resistance as shown in the figure.</p> <div style="text-align: center;">  </div> <p><Reference data></p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">50 (122)</td> <td style="text-align: center;">0.68 - 1.00</td> </tr> <tr> <td style="text-align: center;">90 (194)</td> <td style="text-align: center;">0.236 - 0.260</td> </tr> </tbody> </table> <div style="text-align: center; margin-top: 20px;">  </div> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border-right: 1px solid black; padding: 5px;">OK</td> <td style="width: 5%; text-align: center; border-right: 1px solid black;">▶</td> <td style="padding: 5px;">GO TO 8.</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 5px;">NG</td> <td style="text-align: center; border-right: 1px solid black;">▶</td> <td style="padding: 5px;">Replace engine coolant temperature sensor.</td> </tr> </table> | Temperature °C (°F) | Resistance kΩ | 20 (68) | 2.1 - 2.9 | 50 (122) | 0.68 - 1.00 | 90 (194) | 0.236 - 0.260 | OK | ▶ | GO TO 8. | NG | ▶ | Replace engine coolant temperature sensor. | <p style="text-align: center;">SEF152P</p> <p style="text-align: center;">MTBL0229</p> <p style="text-align: center;">SEF012P</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 2px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> <p>SU</p> |
|---------------------|--|--|---------------------|---------------|---------|-----------|----------|-------------|----------|---------------|----|---|----------|----|---|--|---|---|
| Temperature °C (°F) | Resistance kΩ | | | | | | | | | | | | | | | | | |
| 20 (68) | 2.1 - 2.9 | | | | | | | | | | | | | | | | | |
| 50 (122) | 0.68 - 1.00 | | | | | | | | | | | | | | | | | |
| 90 (194) | 0.236 - 0.260 | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 8. | | | | | | | | | | | | | | | | |
| NG | ▶ | Replace engine coolant temperature sensor. | | | | | | | | | | | | | | | | |

| | | | | | | | |
|----------|-----------------------------|--|--|---|-----------------------|--|--|
| 8 | CHECK MAIN 12 CAUSES | <p>If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-1143.</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border-right: 1px solid black; padding: 5px;"></td> <td style="width: 5%; text-align: center; border-right: 1px solid black;">▶</td> <td style="padding: 5px;">INSPECTION END</td> </tr> </table> | | ▶ | INSPECTION END | | <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p> |
| | ▶ | INSPECTION END | | | | | |


TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

VG33E

Diagnostic Procedure (Cont'd)


9 CHECK COOLING FAN RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect cooling fan relay.



AEC932A

3. Turn ignition switch ON.
4. Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.



SEF667W

Voltage: Battery voltage

OK or NG

| | | |
|----|---|-----------|
| OK | ▶ | GO TO 11. |
| NG | ▶ | GO TO 10. |

10 DETECT MALFUNCTIONING PART

Check the following.


- Fuse block (J/B) connector E49
- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay and fuse
- Harness for open or short between cooling fan relay and battery

▶ Repair open circuit or short to ground or short to power in harness or connectors.

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|---|--|
| 11 | CHECK COOLING FAN MOTOR POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect cooling fan motor harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">AEC931A</p> <p>3. Check harness continuity between relay terminal 3 and motor terminal 2, motor terminals 3, 4 and body ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 12. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | | |
|--|---|-----------|
| 12 | CHECK COOLING FAN RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 36 and relay terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | GO TO 13. |



| | | |
|---|-----------------------------------|--|
| 13 | DETECT MALFUNCTIONING PART | |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E43, M65 ● Harness connectors M58, F28 ● Harness for open or short between cooling fan relay and ECM | | |
| | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

VG33E

Diagnostic Procedure (Cont'd)

| 14 | CHECK COOLING FAN RELAY | | | | | | |
|--|--------------------------------|------------|------------|---|-----|-------------------|----|
| <p>Check continuity between terminals 3 and 5.</p> <div style="display: flex; justify-content: space-around; align-items: center;">   </div> | | | | | | | |
| SEF511P | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Conditions</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>No current supply</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | Conditions | Continuity | 12V direct current supply between terminals 1 and 2 | Yes | No current supply | No |
| Conditions | Continuity | | | | | | |
| 12V direct current supply between terminals 1 and 2 | Yes | | | | | | |
| No current supply | No | | | | | | |
| MTBL0252 | | | | | | | |
| OK or NG | | | | | | | |
| OK | ▶ GO TO 15. | | | | | | |
| NG | ▶ Replace cooling fan relay. | | | | | | |

| 15 | CHECK COOLING FAN MOTOR | | | | | | | | |
|--|--------------------------------|------|-----------|--|-----|-----|-------------------|---|------|
| <p>1. Disconnect cooling fan motor harness connector. 2. Supply cooling fan motor terminals with battery voltage and check operation.</p> | | | | | | | | | |
| MTBL0253 | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Cooling fan motor</td> <td style="text-align: center;">2</td> <td style="text-align: center;">3, 4</td> </tr> </tbody> </table> | | | Terminals | | (+) | (-) | Cooling fan motor | 2 | 3, 4 |
| | Terminals | | | | | | | | |
| | (+) | (-) | | | | | | | |
| Cooling fan motor | 2 | 3, 4 | | | | | | | |
|  | | | | | | | | | |
| SEF670W | | | | | | | | | |
| <p>Cooling fan motor should operate.</p> | | | | | | | | | |
| OK or NG | | | | | | | | | |
| OK | ▶ GO TO 16. | | | | | | | | |
| NG | ▶ Replace cooling fan motor. | | | | | | | | |

| | |
|---|------------------------------------|
| 16 | CHECK INTERMITTENT INCIDENT |
| <p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706.</p> | |
| ▶ | INSPECTION END |

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM) VG33E

Main 12 Causes of Overheating

Main 12 Causes of Overheating

NGEC0908

| Engine | Step | Inspection item | Equipment | Standard | Reference page |
|--------|------|--|--|--|---|
| OFF | 1 | <ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper | <ul style="list-style-type: none"> Visual | No blocking | — |
| | 2 | <ul style="list-style-type: none"> Coolant mixture | <ul style="list-style-type: none"> Coolant tester | 50 - 50% coolant mixture | See "RECOMMENDED FLUIDS AND LUBRICANTS", MA-14 . |
| | 3 | <ul style="list-style-type: none"> Coolant level | <ul style="list-style-type: none"> Visual | Coolant up to MAX level in reservoir tank and radiator filler neck | See "Changing Engine Coolant", "ENGINE MAINTENANCE", MA-27 . |
| | 4 | <ul style="list-style-type: none"> Radiator cap | <ul style="list-style-type: none"> Pressure tester | 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit) | See "System Check", "ENGINE COOLING SYSTEM", LC-26 . |
| ON*2 | 5 | <ul style="list-style-type: none"> Coolant leaks | <ul style="list-style-type: none"> Visual | No leaks | See "System Check", "ENGINE COOLING SYSTEM", LC-26 . |
| ON*2 | 6 | <ul style="list-style-type: none"> Thermostat | <ul style="list-style-type: none"> Touch the upper and lower radiator hoses | Both hoses should be hot | See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM", LC-29, LC-31 . |
| ON*1 | 7 | <ul style="list-style-type: none"> Cooling fan | <ul style="list-style-type: none"> CONSULT-II | Operating | See "TROUBLE DIAGNOSIS FOR OVERHEAT" EC-1132. |
| OFF | 8 | <ul style="list-style-type: none"> Combustion gas leak | <ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer | Negative | — |
| ON*3 | 9 | <ul style="list-style-type: none"> Coolant temperature gauge | <ul style="list-style-type: none"> Visual | Gauge less than 3/4 when driving | — |
| | | <ul style="list-style-type: none"> Coolant overflow to reservoir tank | <ul style="list-style-type: none"> Visual | No overflow during driving and idling | See "Changing Engine Coolant", "ENGINE MAINTENANCE", MA-27 . |
| OFF*4 | 10 | <ul style="list-style-type: none"> Coolant return from reservoir tank to radiator | <ul style="list-style-type: none"> Visual | Should be initial level in reservoir tank | See "ENGINE MAINTENANCE", MA-26 . |
| OFF | 11 | <ul style="list-style-type: none"> Cylinder head | <ul style="list-style-type: none"> Straight gauge feeler gauge | 0.1 mm (0.004 in) Maximum distortion (warping) | See "Inspection", "CYLINDER HEAD DISTORTION", EM-88 . |
| | 12 | <ul style="list-style-type: none"> Cylinder block and pistons | <ul style="list-style-type: none"> Visual | No scuffing on cylinder walls or piston | See "Inspection", "CYLINDER BLOCK DISTORTION AND WEAR", EM-105 . |

*1: Turn the ignition switch ON.


*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "Engine Cooling System", "OVERHEATING CAUSE ANALYSIS", **LC-34**.

Component Description



Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

NGEC0910

| MONITOR ITEM | CONDITION | SPECIFICATION |
|------------------------------|--|----------------|
| INJ PULSE-B2 INJ PULSE-B1 | ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load Idle | 2.4 - 3.7 msec |
| | 2,000 rpm | 1.9 - 3.3 msec |
| B/FUEL SCHDL | ditto Idle | 1.0 - 1.6 msec |
| | 2,000 rpm | 0.7 - 1.4 msec |

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).






NGEC0911

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--|---------------------------------------|--|---|---------------------------------------|
| 102 104 106 109 111 113 | W/B W/R W/G W/L W/PU W | Injector No. 1 Injector No. 3 Injector No. 5 Injector No. 2 Injector No. 4 Injector No. 6 | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed | <p>BATTERY VOLTAGE (11 - 14V)</p> |
| | | | <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm | <p>BATTERY VOLTAGE (11 - 14V)</p> |

Wiring Diagram

NGEC0912


EC-INJECT-01


 GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


Diagnostic Procedure

NGE0913

| | | |
|---|-------------------------|----------|
| 1 | INSPECTION START | |
| Turn ignition switch to START. Is any cylinder ignited? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

| 2 | CHECK OVERALL FUNCTION | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-------------------------------|-----------------------|-------------|--|---------------|--|---------|--|---------------|---------|---------------|-------|------------|-------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| <p> With CONSULT-II</p> <p>1. Start engine. 2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th colspan="2">POWER BALANCE</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS~RPM(REF)</th> <th>XXX rpm</th> </tr> <tr> <th>MAS AIR/FL SE</th> <th>XXX V</th> </tr> <tr> <th>IACV-AAC/V</th> <th>XXX %</th> </tr> <tr> <td> </td> <td> </td> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> | | | ACTIVE TEST | | POWER BALANCE | | MONITOR | | CMPS~RPM(REF) | XXX rpm | MAS AIR/FL SE | XXX V | IACV-AAC/V | XXX % | | | | | | | | | | | | | | |
| ACTIVE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POWER BALANCE | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MONITOR | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMPS~RPM(REF) | XXX rpm | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAS AIR/FL SE | XXX V | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| IACV-AAC/V | XXX % | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PEF389V | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3. Make sure that each circuit produces a momentary engine speed drop. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p> Without CONSULT-II</p> <p>1. Start engine. 2. Listen to each injector operating sound.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Clicking noise should be heard. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 3. | | | | | | | | | | | | | | | | | | | | | | | | | | |

MEC703B


| | | | | | | | | | |
|---|--|---|-----------------------------------|----------|----|---|----------|--|----------|
| 3 | CHECK INJECTOR POWER SUPPLY CIRCUIT | <p>1. Turn ignition switch OFF.</p> <p>2. Disconnect injector harness connector.</p> <p>3. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="color: blue; margin-top: 10px;">Voltage: Battery voltage</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | GI MA EM LC EC | | | | | | |
| <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table> | | OK | ▶ | GO TO 5. | NG | ▶ | GO TO 4. | | FE CL |
| OK | ▶ | GO TO 5. | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | |

| | | | |
|----------|-----------------------------------|--|----------------|
| 4 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M59, F27 ● Harness connectors F37, F101 ● Fuse block (J/B) connector M26 ● 10A fuse ● Harness for open or short between injector and fuse | MT AT TF |
| ▶ | | Repair harness or connectors. | |

| | | | | | | | | | |
|---|--|--|----------------|----------|----|---|----------|--|----------|
| 5 | CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT | <p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between injector harness connector terminal 2 and ECM terminals 102, 104, 106, 109, 111, 113. Refer to Wiring Diagram.</p> <p style="color: blue; margin-left: 20px;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | PD AX SU | | | | | | |
| ▶ | | Repair harness or connectors. | | | | | | | |
| <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 7.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 6.</td> </tr> </table> | | OK | ▶ | GO TO 7. | NG | ▶ | GO TO 6. | | BR ST |
| OK | ▶ | GO TO 7. | | | | | | | |
| NG | ▶ | GO TO 6. | | | | | | | |

| | | | |
|----------|-----------------------------------|--|----------|
| 6 | DETECT MALFUNCTIONING PART | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F37, F101 ● Harness connectors F38, F102 ● Harness for open or short between ECM and injector | RS BT |
| ▶ | | Repair open circuit or short to ground or short to power in harness or connectors. | |

HA
SC
EL
IDX

| | | | |
|---|-----------------------|---|-------------------|
| 7 | CHECK INJECTOR | | |
| <p>1. Disconnect injector harness connector.</p> <p>2. Check resistance between terminals as shown in the figure.</p> | | | |
|  | | | |
| <p>Resistance: 10 - 14Ω [at 25°C (77°F)]</p> <p>OK or NG</p> | | | |
| OK | | ▶ | GO TO 8. |
| NG | | ▶ | Replace injector. |

SEF625V

| | | | |
|---|------------------------------------|---|-----------------------|
| 8 | CHECK INTERMITTENT INCIDENT | | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | | | |
| | | ▶ | INSPECTION END |

START SIGNAL

VG33E

CONSULT-II Reference Value in Data Monitor Mode

CONSULT-II Reference Value in Data Monitor Mode

NGEC0914

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|------------------------------------|----------------|
| START SIGNAL | ● Ignition switch: ON → START → ON | OFF → ON → OFF |

ECM Terminals and Reference Value

NGEC0915

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|--------------|-------------------------|-------------------------------|
| 20 | L/OR | Start signal | [Ignition switch ON] | Approximately 0V |
| | | | [Ignition switch START] | BATTERY VOLTAGE (11 - 14V) |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

START SIGNAL


VG33E

Wiring Diagram

Wiring Diagram




NGEC0916

EC-S/SIG-01



Refer to "EL-POWER".

- : Detectable line for DTC
- : Non-detectable line for DTC



AEC975A

START SIGNAL

VG33E

Diagnostic Procedure

Diagnostic Procedure


NGEC0917

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

GI
MA
EM

| 2 | CHECK OVERALL FUNCTION | | | | | | | | | | | | | |
|---|-------------------------------|-----------------------|--------------|----------------|----------------------|---------|-------------------------|-----|--------------|----|--------------|-----|-------------|----|
| <p> With CONSULT-II</p> <p>1. Turn ignition switch ON.</p> <p>2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p> | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>Monitoring</th> <th>NO FAIL</th> </tr> </thead> <tbody> <tr> <td>START SIGNAL</td> <td>OFF</td> </tr> <tr> <td>CLSD TH/P SW</td> <td>ON</td> </tr> <tr> <td>AIR COND SIG</td> <td>OFF</td> </tr> <tr> <td>P/N POSI SW</td> <td>ON</td> </tr> </tbody> </table> | | | DATA MONITOR | | Monitoring | NO FAIL | START SIGNAL | OFF | CLSD TH/P SW | ON | AIR COND SIG | OFF | P/N POSI SW | ON |
| DATA MONITOR | | | | | | | | | | | | | | |
| Monitoring | NO FAIL | | | | | | | | | | | | | |
| START SIGNAL | OFF | | | | | | | | | | | | | |
| CLSD TH/P SW | ON | | | | | | | | | | | | | |
| AIR COND SIG | OFF | | | | | | | | | | | | | |
| P/N POSI SW | ON | | | | | | | | | | | | | |
| PEF111P | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>"START SIGNAL"</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "ON"</td> <td>OFF</td> </tr> <tr> <td>Ignition switch "START"</td> <td>ON</td> </tr> </tbody> </table> | | | Condition | "START SIGNAL" | Ignition switch "ON" | OFF | Ignition switch "START" | ON | | | | | | |
| Condition | "START SIGNAL" | | | | | | | | | | | | | |
| Ignition switch "ON" | OFF | | | | | | | | | | | | | |
| Ignition switch "START" | ON | | | | | | | | | | | | | |
| MTBL0147 | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | | | | | | | |

LC
EC
FE
CL
MT
AT
TF
PD
AX

| 3 | CHECK OVERALL FUNCTION | | | | | | | |
|---|-------------------------------|-----------------------|-----------|---------|-------------------------|-----------------|-----------------|------------------|
| <p> Without CONSULT-II</p> <p>Check voltage between ECM terminal 20 and ground under the following conditions.</p> | | | | | | | | |
|  | | | | | | | | |
| SEF733U | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "START"</td> <td>Battery voltage</td> </tr> <tr> <td>Other positions</td> <td>Approximately 0V</td> </tr> </tbody> </table> | | | Condition | Voltage | Ignition switch "START" | Battery voltage | Other positions | Approximately 0V |
| Condition | Voltage | | | | | | | |
| Ignition switch "START" | Battery voltage | | | | | | | |
| Other positions | Approximately 0V | | | | | | | |
| MTBL0148 | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |

SU
BR
ST
RS
BT
HA
SC
EL
IDX

START SIGNAL

VG33E

Diagnostic Procedure (Cont'd)

| | |
|--|---|
| 4 | CHECK STARTING SYSTEM |
| Turn ignition switch OFF, then turn it to START. Does starter motor operate? | |
| Yes or No | |
| Yes | ▶ GO TO 5. |
| No | ▶ Refer to "STARTING SYSTEM", SC-6 . |

| | |
|--|----------------------|
| 5 | CHECK FUSE |
| 1. Turn ignition switch OFF. 2. Disconnect 7.5A fuse. 3. Check if 7.5A fuse is OK. | |
| OK or NG | |
| OK | ▶ GO TO 6. |
| NG | ▶ Replace 7.5A fuse. |

| | |
|--|---|
| 6 | CHECK START SIGNAL INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 20 and fuse block. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 7. |

| | |
|---|--|
| 7 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none">● Harness connectors M81, F36● Harness for open or short between ECM and fuse | |
| | ▶ Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|------------------------------------|
| 8 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ INSPECTION END |


System Description

NGE0918

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--------------------------|---------------------|-------------------|-----------------|
| Camshaft position sensor | Engine speed | Fuel pump control | Fuel pump relay |
| Ignition switch | Start signal | | |

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 120° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to operate. If the 120° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

| Condition | Fuel pump operation |
|----------------------------------|------------------------|
| Ignition switch is turned to ON. | Operates for 5 seconds |
| Engine running and cranking | Operates |
| When engine is stopped | Stops in 1.5 seconds |
| Except as shown above | Stops |



Component Description

NGE0919

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).

CONSULT-II Reference Value in Data Monitor Mode

NGE0920

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|---------------|---|---------------|
| FUEL PUMP RLY | <ul style="list-style-type: none"> Ignition switch is turned to ON. (Operates for 5 seconds.) Engine running and cranking | ON |
| | Except as shown above | OFF |

ECM Terminals and Reference Value

NGE0921

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|-----------------|---|----------------------------|
| 11 | W/R | Fuel pump relay | [Ignition switch ON] <ul style="list-style-type: none"> For 5 seconds after turning ignition switch "ON" [Engine is running] | 0 - 1V |
| | | | [Ignition switch ON] <ul style="list-style-type: none"> More than 5 seconds after turning ignition switch ON | BATTERY VOLTAGE (11 - 14V) |

FUEL PUMP




VG33E

Wiring Diagram

Wiring Diagram

NGEC0922


EC-F/PUMP-01





AEC976A

Diagnostic Procedure


NGE0923

| | | |
|---|-------------------------------|-----------------------|
| 1 | CHECK OVERALL FUNCTION | |
| 1. Turn ignition switch ON. 2. Pinch fuel feed hose with fingers. | | |
|  | | |
| AEC663A | | |
| Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned ON. | | |
| OK or NG | | |
| OK | ▶ | INSPECTION END |
| NG | ▶ | GO TO 2. |

| | | |
|--|---|----------|
| 2 | CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT | |
| 1. Turn ignition switch OFF. 2. Disconnect fuel pump relay. | | |
|  | | |
| SEF349V | | |
| 3. Turn ignition switch ON. 4. Check voltage between terminals 2, 5 and ground with CONSULT-II or tester. | | |
|  | | |
| SEF674W | | |
| Voltage: Battery voltage | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | GO TO 3. |

 GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

| | |
|---|-----------------------------------|
| 3 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Fuse block (J/B) connector M31 ● 15A fuse ● Harness for open or short between fuse and fuel pump relay | |
| ▶ | Repair harness or connectors. |

| | |
|--|---|
| 4 | CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT |
| 1. Turn ignition switch OFF. 2. Disconnect fuel pump harness connector. | |
|  | |
| 3. Check harness continuity between fuel pump terminal 2 and body ground, fuel pump terminal 1 and fuel pump relay terminal 3. Refer to Wiring Diagram. Continuity should exist. | |
| 4. Also check harness for short to ground and short to power. | |
| OK or NG | |
| OK | ▶ GO TO 6. |
| NG | ▶ GO TO 5. |

AEC933A

| | |
|---|--|
| 5 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors M67, C1 ● Harness for open or short between fuel pump and body ground ● Harness for open or short between fuel pump and fuel pump relay | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| | |
|---|---|
| 6 | CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT |
| 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 11 and fuel pump relay terminal 1. Refer to Wiring Diagram. Continuity should exist. | |
| 3. Also check harness for short to ground and short to power. | |
| OK or NG | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 7. |

| | |
|---|--|
| 7 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors M81, F36 ● Harness for open or short between ECM and fuel pump relay | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

8 CHECK FUEL PUMP RELAY
Ⓜ With CONSULT-II


1. Reconnect fuel pump relay, fuel pump harness connector and ECM harness connector.
2. Turn ignition switch ON.
3. Turn fuel pump relay "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.

| ACTIVE TEST | |
|-----------------|---------|
| FUEL PUMP RELAY | ON |
| MONITOR | |
| CMPS~RPM | XXX rpm |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

SEF380X

ⓧ Without CONSULT-II

Check continuity between terminals 3 and 5.



SEF511P

12V direct current supply between terminals 1 and 2
Continuity exists
No current supply
Continuity does not exist
OK or NG

OK ► GO TO 9.

NG ► Replace fuel pump relay.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX

| | | | |
|----------|------------------------|--|--|
| 9 | CHECK FUEL PUMP | <p>1. Disconnect fuel pump harness connector. 2. Check resistance between terminals 1 and 2.</p> <div style="text-align: center;">  </div> <p style="color: blue;">Resistance: 0.2 - 5.0Ω [at 25°C (77°F)]</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ | GO TO 10. | |
| NG | ▶ | Replace fuel pump. | |


SEF022S

| | | | |
|-----------|------------------------------------|---|--|
| 10 | CHECK INTERMITTENT INCIDENT | Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| | ▶ | INSPECTION END | |

POWER STEERING OIL PRESSURE SWITCH

VG33E

Component Description



Component Description

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|--------------|---|---|
| PW/ST SIGNAL | <ul style="list-style-type: none"> Engine: After warming up, idle the engine | Steering wheel in neutral position (forward direction) OFF |
| | | The steering wheel is fully turned. ON |

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

| TERMI-NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|---------------|------------|------------------------------------|---|-------------------|
| 39 | GY/R | Power steering oil pressure switch | [Engine is running] <ul style="list-style-type: none"> Steering wheel is being fully turned | 0V |
| | | | [Engine is running] <ul style="list-style-type: none"> Steering wheel is not being turned | Approximately 5V |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER STEERING OIL PRESSURE SWITCH




VG33E

Wiring Diagram

Wiring Diagram

NGEC0927

EC-PST/SW-01



AEC977A

Diagnostic Procedure

NGEC0928

| | | |
|-------------------------|-------------------------|----------|
| 1 | INSPECTION START | |
| Do you have CONSULT-II? | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

GI
MA
EM

| 2 | CHECK OVERALL FUNCTION | | | | | | | |
|--|-------------------------------|-----------------------|--------------|----------------|------------------------------|---------|-------------------------------------|-----|
| <p> With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II.</p> | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;">NO FAIL</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">PW/ST SIGNAL</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table> | | | DATA MONITOR | | MONITORING | NO FAIL | PW/ST SIGNAL | OFF |
| DATA MONITOR | | | | | | | | |
| MONITORING | NO FAIL | | | | | | | |
| PW/ST SIGNAL | OFF | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">"PW/ST SIGNAL"</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Steering is neutral position</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td style="text-align: center;">Steering is turned to full position</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table> | | | Condition | "PW/ST SIGNAL" | Steering is neutral position | OFF | Steering is turned to full position | ON |
| Condition | "PW/ST SIGNAL" | | | | | | | |
| Steering is neutral position | OFF | | | | | | | |
| Steering is turned to full position | ON | | | | | | | |
| SEF184X | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |

LC
EC
FE
CL
MT
AT

| 3 | CHECK OVERALL FUNCTION | | | | | | | |
|--|-------------------------------|-----------------------|-----------|---------|------------------------------|------------------|-------------------------------------|------------------|
| <p> Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between ECM terminal 39 and ground.</p> | | | | | | | | |
| | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Steering is neutral position</td> <td style="text-align: center;">Approximately 5V</td> </tr> <tr> <td style="text-align: center;">Steering is turned to full position</td> <td style="text-align: center;">Approximately 0V</td> </tr> </tbody> </table> | | | Condition | Voltage | Steering is neutral position | Approximately 5V | Steering is turned to full position | Approximately 0V |
| Condition | Voltage | | | | | | | |
| Steering is neutral position | Approximately 5V | | | | | | | |
| Steering is turned to full position | Approximately 0V | | | | | | | |
| SEF739U | | | | | | | | |
| OK or NG | | | | | | | | |
| MTBL0145 | | | | | | | | |
| OK | ▶ | INSPECTION END | | | | | | |
| NG | ▶ | GO TO 4. | | | | | | |


PD
AX
SU
BR
ST
RS
BT
HA
SC

EL
IDX

POWER STEERING OIL PRESSURE SWITCH


VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|---|--|
| 4 | CHECK POWER STEERING OIL PRESSURE SWITCH GROUND CIRCUIT FOR OPEN AND SHORT | |
| <p>1. Turn ignition switch OFF. 2. Disconnect power steering oil pressure switch harness connector.</p> | | |
|  <p style="text-align: center;">Battery — Power steering oil pressure switch harness connector</p> | | |
| <p>3. Check harness continuity between switch terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

AEC664A

| | | |
|---|--|--|
| 5 | CHECK POWER STEERING OIL PRESSURE SWITCH INPUT SIGNAL CIRCUIT | |
| <p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 39 and switch terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

| 6 | CHECK POWER STEERING OIL PRESSURE SWITCH | | | | | | | |
|--|---|---|------------|------------|--------------------------------------|-----|------------------------------------|----|
| <p>1. Disconnect power steering oil pressure switch harness connector then start engine. 2. Check continuity between terminals 1 and 2.</p> | | | | | | | | |
|  | | | | | | | | |
| SEF679W | | | | | | | | |
| <table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Conditions</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Steering wheel is being fully turned</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>Steering wheel is not being turned</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> | | | Conditions | Continuity | Steering wheel is being fully turned | Yes | Steering wheel is not being turned | No |
| Conditions | Continuity | | | | | | | |
| Steering wheel is being fully turned | Yes | | | | | | | |
| Steering wheel is not being turned | No | | | | | | | |
| <p style="text-align: right;">MTBL0254</p> <p style="text-align: center;">OK or NG</p> | | | | | | | | |
| OK | ▶ | GO TO 7. | | | | | | |
| NG | ▶ | Replace power steering oil pressure switch. | | | | | | |

POWER STEERING OIL PRESSURE SWITCH

VG33E

Diagnostic Procedure (Cont'd)

| | |
|---|------------------------------------|
| 7 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ | INSPECTION END |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

IACV-FICD SOLENOID VALVE

VG33E

Component Description



Component Description

When the air conditioner is on, the IACV-FICD solenoid valve supplies additional air to adjust to the increased load. For more information, refer to "FAST IDLE CONTROL DEVICE (FICD)", **HA-79**.

NGEC0929

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 32 (ECM ground).

NGEC0930

| TERMINAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|--------------|------------|--------------------------------|---|----------------------------|
| 9 | B/Y | Ambient air temperature switch | [Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is above 25°C (77°F) ● Air conditioner is operating | 0V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is operating | BATTERY VOLTAGE (11 - 14V) |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is not operating | Approximately 5V |
| 12 | P | Air conditioner relay | [Engine is running] <ul style="list-style-type: none"> ● Both A/C switch and blower fan switch are "ON"* | 0 - 1V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● A/C switch is "OFF" | BATTERY VOLTAGE (11 - 14V) |
| 21 | G/R | Air conditioner switch | [Engine is running] <ul style="list-style-type: none"> ● Both A/C switch and blower fan switch are "ON" (Compressor operates)* | Approximately 0V |
| | | | [Engine is running] <ul style="list-style-type: none"> ● Air conditioner switch is "OFF" | Approximately 5V |

*: Any mode except "OFF", ambient air temperature is above 25°C (77°F).

IACV-FICD SOLENOID VALVE

VG33E

Wiring Diagram

Wiring Diagram

NGEC0931

EC-FICD-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX





AEC978A

Diagnostic Procedure

NGEC0932

| | | |
|----------|-------------------------------|---|
| 1 | CHECK OVERALL FUNCTION | <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Check idle speed. 750±50 rpm (in "N" position) If NG, adjust idle speed.</p> <p>3. Turn air conditioner switch and blower fan switch ON.</p> <p>4. Recheck idle speed.</p> <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: center; color: blue;">850 rpm or more (in "P" or "N" position)</p> <p style="text-align: right;">SEF742U</p> <p style="text-align: center;">OK or NG</p> |
| OK | ▶ | INSPECTION END |
| NG | ▶ | GO TO 2. |

| | | |
|----------|---------------------------------------|--|
| 2 | CHECK AIR CONDITIONER FUNCTION | <p>Check if air conditioner compressor functions normally.</p> <p style="text-align: center;">OK or NG</p> |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Refer to "Symptom Table", "TROUBLE DIAGNOSES", HA-26 . |

| | | |
|--|--|----------|
| 3 | CHECK IACV-FICD SOLENOID VALVE POWER SUPPLY CIRCUIT | |
| <ol style="list-style-type: none"> 1. Turn air conditioner switch and blower fan switch OFF. 2. Stop engine. 3. Disconnect IACV-FICD solenoid valve harness connector. | | |
|  | | |
| SEF024SA | | |
| <ol style="list-style-type: none"> 4. Start engine, then turn air conditioner switch and blower fan switch ON. 5. Check voltage between terminal 2 and ground with CONSULT-II or tester. | | |
|  | | |
| SEF680W | | |
| Voltage: Battery voltage | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | GO TO 4. |

| | |
|---|-----------------------------------|
| 4 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors F38, F102 ● Harness for open or short between IACV-FICD solenoid valve and harness connector F27 | |
| ▶ | |
| Repair harness or connectors. | |

| | | |
|---|--|----------|
| 5 | CHECK IACV-FICD SOLENOID VALVE GROUND CIRCUIT | |
| <ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ambient air temperature switch harness connector. 3. Check harness continuity between switch terminal 1 and body ground. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 6. |
| NG | ▶ | GO TO 7. |

 GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX



| | |
|---|---|
| 6 | CHECK IACV-FICD SOLENOID VALVE GROUND CIRCUIT WITH DIODE |
| <p>1. Check harness continuity between switch terminal 2 and solenoid valve terminal 1.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEF160X</p> <p>Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 7. |

| | |
|--|--|
| 7 | DETECT MALFUNCTIONING PART |
| <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F38, F102 ● Harness connectors F36, M81 ● Harness connectors M65, E43 ● Diode F35 ● Harness for open or short between ambient air temperature switch and body ground ● Harness for open or short between IACV-FICD solenoid valve and ambient air temperature switch | |
| ▶ | Repair open circuit or short to ground or short to power in harness or connectors. |

IACV-FICD SOLENOID VALVE

VG33E

Diagnostic Procedure (Cont'd)

| | | |
|---|---------------------------------------|-----------------------------------|
| 8 | CHECK IACV-FICD SOLENOID VALVE | |
| <p>Disconnect IACV-FICD solenoid valve harness connector.</p> <ul style="list-style-type: none"> ● Check for clicking sound when applying 12V direct current to terminals. | | |
|  | | |
| <ul style="list-style-type: none"> ● Check plunger for seizing or sticking. ● Check for broken spring. | | |
|  | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace IACV-FICD solenoid valve. |

SEF682W

SEF097K




| | |
|---|------------------------------------|
| 9 | CHECK INTERMITTENT INCIDENT |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-706. | |
| ▶ INSPECTION END | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Wiring Diagram

NGEC0933

EC-MIL/DL-01



Refer to the following.
 F29 - ELECTRICAL UNITS



Fuel Pressure Regulator

NGEC0934

| | | |
|--|--|-----------------------------|
| Fuel pressure at idling kPa (kg/cm ² , psi) | | |
| Vacuum hose is connected | | Approximately 235 (2.4, 34) |
| Vacuum hose is disconnected | | Approximately 294 (3.0, 43) |

Idle Speed and Ignition Timing

NGEC0935

| | | |
|--|-----------------------------------|-----------------|
| Base idle speed*1 | No-load*4 (in "P" or N" position) | 700±50 rpm |
| Target idle speed*2 | No-load*4 (in "P" or N" position) | 750±50 rpm |
| Air conditioner: ON | In "P" or N" position | 850 rpm or more |
| Ignition timing*3 | In "P" or N" position | 15°±2° BTDC |
| Throttle position sensor idle position | | 0.15 - 0.85V |

*1: Throttle position sensor harness connector disconnected or using CONSULT-II "WORK SUPPORT" mode

*2: Throttle position sensor harness connector connected

*3: Throttle position sensor harness connector disconnected

*4: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Coil

NGEC0936

| | | |
|---------------------------------------|--|---------------------|
| Primary voltage | | 12V |
| Primary resistance [at 20°C (68°F)] | | Approximately 1.0Ω |
| Secondary resistance [at 20°C (68°F)] | | Approximately 10 kΩ |

Mass Air Flow Sensor

NGEC0937

| | | |
|---|--|---|
| Supply voltage | | Battery voltage (11 - 14)V |
| Output voltage at idle | | 1.0 - 1.7*V |
| Mass air flow (Using CONSULT-II or GST) | | 3.3 - 4.8 g-m/sec at idle* 12.0 - 14.9 g-m/sec at 2,500 rpm* |

*: Engine is warmed up to normal operating temperature and running under no-load.

Engine Coolant Temperature Sensor

NGEC0938

| | | |
|---------------------|--|---------------|
| Temperature °C (°F) | | Resistance kΩ |
| 20 (68) | | 2.1 - 2.9 |
| 50 (122) | | 0.68 - 1.00 |
| 90 (194) | | 0.236 - 0.260 |

EGR Temperature Sensor (If So Equipped)

NGEC0939

| | | |
|-------------------------|-------------|-----------------|
| EGR temperature °C (°F) | Voltage (V) | Resistance (MΩ) |
| 0 (32) | 4.56 | 0.62 - 1.05 |
| 50 (122) | 2.25 | 0.065 - 0.094 |
| 100 (212) | 0.59 | 0.011 - 0.015 |

Front Heated Oxygen Sensor Heater

NGEC0940

| | | |
|-----------------------------|--|------------|
| Resistance [at 25°C (77°F)] | | 2.3 - 4.3Ω |
|-----------------------------|--|------------|

Fuel Pump

| Fuel Pump | | <small>NGEC0941</small> |
|---|--|-------------------------|
| Resistance [at 25°C (77°F)] | 0.2 - 5.0Ω | |
| IACV-AAC Valve | | <small>NGEC0942</small> |
| Resistance [at 20°C (68°F)] | Approximately 10.0Ω | |
| Injector | | <small>NGEC0943</small> |
| Resistance [at 25°C (77°F)] | 10 - 14Ω | |
| Resistor | | <small>NGEC0944</small> |
| Resistance [at 25°C (77°F)] | Approximately 2.2 kΩ | |
| Throttle Position Sensor | | <small>NGEC0945</small> |
| Throttle valve conditions | Voltage [at normal operating temperature, engine off, ignition switch ON, (throttle opener disengaged, if so equipped)] | |
| Completely closed (a) | 0.15 - 0.85V | |
| Partially open | Between (a) and (b) | |
| Completely open (b) | 3.5 - 4.7V | |
| Calculated Load Value | | <small>NGEC0946</small> |
| | Calculated load value % (Using CONSULT or GST) | |
| At idle | 18.0 - 26.0 | |
| At 2,500 rpm | 18.0 - 21.0 | |
| Intake Air Temperature Sensor | | <small>NGEC0947</small> |
| Temperature °C (°F) | Resistance kΩ | |
| 20 (68) | 2.1 - 2.9 | |
| 80 (176) | 0.27 - 0.38 | |
| Rear Heated Oxygen Sensor Heater | | <small>NGEC0948</small> |
| Resistance [at 25°C (77°F)] | 2.3 - 4.3Ω | |
| Crankshaft Position Sensor (OBD) | | <small>NGEC0949</small> |
| Resistance [at 20°C (68°F)] | 512 - 632Ω | |
| Fuel Tank Temperature Sensor | | <small>NGEC0950</small> |
| Temperature °C (°F) | Resistance kΩ | |
| 20 (68) | 2.3 - 2.7 | |
| 50 (122) | 0.79 - 0.90 | |