

NISSAN STANZA

MODEL U12 SERIES

QUICK REFERENCE INDEX

GENERAL INFORMATION _____	GI
MAINTENANCE _____	MA
ENGINE MECHANICAL _____	EM
ENGINE LUBRICATION & COOLING SYSTEMS _____	LC
ENGINE FUEL & EMISSION CONTROL SYSTEM _____	EF & EC
ACCELERATOR CONTROL, FUEL & EXHAUST SYSTEMS _____	FE
CLUTCH _____	CL
MANUAL TRANSAXLE _____	MT
AUTOMATIC TRANSAXLE _____	AT
FRONT AXLE & FRONT SUSPENSION _____	FA
REAR AXLE & REAR SUSPENSION _____	RA
BRAKE SYSTEM _____	BR
STEERING SYSTEM _____	ST
BODY _____	BF
HEATER & AIR CONDITIONER _____	HA
ELECTRICAL SYSTEM _____	EL

FOREWORD

This manual contains maintenance and repair procedures for the 1992 NISSAN STANZA.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first completely satisfy himself that neither his safety nor the vehicle's safety will be jeopardized by the service method selected.



NISSAN MOTOR CO., LTD.

Overseas Service Department

Tokyo, Japan

GENERAL INFORMATION


SECTION **GI**



CONTENTS


PRECAUTIONS	GI- 2
HOW TO USE THIS MANUAL	GI- 4
HOW TO READ WIRING DIAGRAMS	GI- 6
HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES	GI- 9
CONSULT CHECKING SYSTEM	GI-12
IDENTIFICATION INFORMATION	GI-13
LIFTING POINTS AND TOW TRUCK TOWING	GI-17
TIGHTENING TORQUE OF STANDARD BOLTS	GI-20

PRECAUTIONS




Observe the following precautions to ensure safe and proper servicing. These precautions are not described in each individual section.

1. Do not operate the engine for an extended period of time without proper exhaust ventilation. Keep the work area well ventilated and free of any inflammable materials. Special care should be taken when handling any inflammable or poisonous materials, such as gasoline, refrigerant gas, etc. When working in a pit or other enclosed area, be sure to properly ventilate the area before working with hazardous materials. Do not smoke while working on the vehicle.




2. Before jacking up the vehicle, apply wheel chocks or other tire blocks to the wheels to prevent the vehicle from moving. After jacking up the vehicle, support the vehicle weight with safety stands at the points designated for proper lifting and towing before working on the vehicle. These operations should be done on a level surface.


3. When removing a heavy component such as the engine or transaxle/transmission, be careful not to lose your balance and drop them. Also, do not allow them to strike adjacent parts, especially the brake tubes and master cylinder.



4. Before starting repairs which do not require battery power, always turn off the ignition switch, then disconnect the ground cable from the battery to prevent accidental short circuit.





5. To prevent serious burns, avoid contact with hot metal parts such as the radiator, exhaust manifold, tail pipe and muffler. Do not remove the radiator cap when the engine is hot.



6. Before servicing the vehicle, protect fenders, upholstery and carpeting with appropriate covers. Take care that keys, buckles or buttons on your person do not scratch the paint.

PRECAUTIONS

7. Clean all disassembled parts in the designated liquid or solvent prior to inspection or assembly.
8. Replace oil seals, gaskets, packings, O-rings, locking washers, cotter pins, self-locking nuts, etc. with new ones.
9. Replace inner and outer races of tapered roller bearings and needle bearings as a set.
10. Arrange the disassembled parts in accordance with their assembled locations and sequence.
11. Do not touch the terminals of electrical components which use microcomputers (such as electronic control units. Static electricity may damage internal electronic components.
12. After disconnecting vacuum or air hoses, attach a tag to indicate the proper connection.
13. Use only the lubricants specified in MA section.
14. Use approved bonding agent, sealants or their equivalents when required.
15. Use tools and recommended special tools where specified for safe and efficient service repairs.
16. When repairing the fuel, oil, water, vacuum or exhaust systems, check all affected lines for leaks.
17. Dispose of drained oil or the solvent used for cleaning parts in an appropriate manner.



Precautions for E.F.I. or E.C.C.S. Engine

1. Before connecting or disconnecting E.F.I. or E.C.C.S. harness connector to or from any E.F.I. or E.C.C.S. control unit, be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal. Otherwise, there may be damage to control unit.
2. Before disconnecting pressurized fuel line from fuel pump to injectors, be sure to release fuel pressure to eliminate danger.
3. Be careful not to jar components such as control unit and air flow meter.

Precautions for Catalyst

If a large amount of unburned fuel flows into the converter, the converter temperature will be excessively high. To prevent this, follow the procedure below:

1. Use unleaded gasoline only. Leaded gasoline will seriously damage the catalytic converter.
2. When checking for ignition spark or measuring engine compression, make tests quickly and only when necessary.
3. Do not run engine when the fuel tank level is low, otherwise the engine may misfire causing damage to the converter.
4. Do not place the vehicle on inflammable material. Keep inflammable material off the exhaust pipe.

Precautions for Fuel


Use unleaded gasoline with an octane rating of at least 87 AKI (Anti-Knock Index) number (research octane number 91).

CAUTION:

Do not use leaded gasoline. Using leaded gasoline will damage the catalytic converter.

HOW TO USE THIS MANUAL

1. **A QUICK REFERENCE INDEX**, a black tab (e.g. **BR**) is provided on the first page. You can quickly find the first page of each section by mating it to the section's black tab.
2. **THE CONTENTS** are listed on the first page of each section.
3. **THE TITLE** is indicated on the upper portion of each page and shows the part or system.
4. **THE PAGE NUMBER** of each section consists of two letters which designate the particular section and a number (e.g. "BR-5").
5. **THE LARGE ILLUSTRATIONS** are exploded views (See below.) and contain tightening torques, lubrication points and other information necessary to perform repairs.
The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.



6. **THE SMALL ILLUSTRATIONS** show the important steps such as inspection, use of special tools, knacks of work and hidden or tricky steps which are not shown in the previous large illustrations. Assembly, inspection and adjustment procedures for the complicated units such as the automatic transaxle or transmission, etc. are presented in a step-by-step format where necessary.

HOW TO USE THIS MANUAL

7. The following **SYMBOLS AND ABBREVIATIONS** are used:



: Tightening torque
: Should be lubricated with grease.
Unless otherwise indicated, use
recommended multi-purpose grease.



: Should be lubricated with oil.



: Sealing point



: Checking point



: Always replace after every disas-
sembly.



: Apply petroleum jelly.



: Apply A.T.F.



: Select with proper thickness.



: Adjustment is required.

S.D.S. : Service Data and Specifications

L.H., R.H. : Left-Hand, Right-Hand

M/T : Manual Transaxle/Transmission

A/T : Automatic Transaxle/Transmission

Tool : Special Service Tools

L.H.D. : Left-Hand Drive

R.H.D. : Right-Hand Drive

A.T.F. : Automatic Transmission Fluid

D₁ : Drive range 1st gear

D₂ : Drive range 2nd gear

D₃ : Drive range 3rd gear

D₄ : Drive range 4th gear

O.D. : Overdrive

2₂ : 2nd range 2nd gear

2₁ : 2nd range 1st gear

1₂ : 1st range 2nd gear

1₁ : 1st range 1st gear

8. The **UNITS** given in this manual are primarily expressed as the SI UNIT (International System of Unit), and alternatively expressed in the metric system and in the yard/pound system.

“Example”

Tightening torque:

59 - 78 N·m (6.0 - 8.0 kg-m, 43 - 58 ft-lb)

9. **TROUBLE DIAGNOSES** are included in sections dealing with complicated components.

10. **SERVICE DATA AND SPECIFICATIONS** is contained at the end of each section for quick reference of data.

11. The captions **WARNING** and **CAUTION** warn you of steps that must be followed to prevent personal injury and/or damage to some part of the vehicle.


- **WARNING** indicates the possibility of personal injury if instructions are not followed.
- **CAUTION** indicates the possibility of component damage if instructions are not followed.
- **BOLD TYPED STATEMENTS** except **WARNING** and **CAUTION** give you helpful information.

HOW TO READ WIRING DIAGRAMS


WIRING DIAGRAM

Symbols used in WIRING DIAGRAM are shown below:

Example



SG1543




SWITCH POSITIONS

Wiring diagram switches are shown with the vehicle in the following condition.

- Ignition switch "OFF".
- Doors, hood and trunk lid/back door closed.
- Pedals are not depressed and parking brake is released.

HOW TO READ WIRING DIAGRAMS


Example



CONNECTOR SYMBOLS

- All connector symbols in wiring diagrams are shown from the terminal side.

Example




- Male and female terminals
Connector guides for male terminals are shown in black and female terminals in white in wiring diagrams.

MULTIPLE SWITCH

The continuity of the multiple switch is identified in the switch chart in wiring diagrams.

Example



Example: Wiper switch in LO position

Continuity circuit: Red wire - (A) terminal - (3) terminal - Wiper switch (● - ●): LO) - (6) terminal - (E) terminal - Black wire



SGI365

HOW TO READ WIRING DIAGRAMS

SUPER MULTIPLE JUNCTION (S.M.J.)

- The "S.M.J." indicated in wiring diagrams is shown in a simplified form. The terminal arrangement should therefore be referred to in the foldout at the end of the Service Manual.
- The foldout should be spread to read the entire wiring diagram.


Example



SEL653F

HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

Example



NOTICE

The flow chart indicates work procedures required to diagnose problems effectively. Observe the following instructions before diagnosing.


- 1) Use the flow chart after locating probable causes of a problem following the "Preliminary Check" or the "Symptom Chart".
- 2) After repairs, re-check that the problem has been completely eliminated.
- 3) Refer to Component Parts Location and Harness Layout for the Systems described in each section for identification/location of components and harness connectors.
- 4) Refer to the Circuit Diagram for Quick Pinpoint Check. If you must check circuit continuity between harness connectors in more detail, such as when a sub-harness is used, refer to Wiring Diagram and Harness Layout in EL section for identification of harness connectors.
- 5) When checking circuit continuity, ignition switch should be "OFF".
- 6) Before checking voltage at connectors, check battery voltage.
- 7) After accomplishing the Diagnostic Procedures and Electrical Components Inspection, make sure that all harness connectors are reconnected as they were.

HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

HOW TO FOLLOW THIS FLOW CHART

1 Work and diagnostic procedure

Start to diagnose a problem using procedures indicated in enclosed blocks, as shown in the following example.



2 Measurement results

Required results are indicated in bold type in the corresponding block, as shown below:

These have the following meanings:

Battery voltage → 11 - 14V or approximately 12V

Voltage: Approximately 0V → Less than 1V

3 Cross reference of work symbols in the text and illustrations

Illustrations are provided as visual aids for work procedures. For example, symbol **A** indicated in the left upper portion of each illustration corresponds with the symbol in the flow chart for easy identification. More precisely, the procedure under the "CHECK POWER SUPPLY" outlined previously is indicated by an illustration **A**.

4 Symbols used in illustrations

Symbols included in illustrations refer to measurements or procedures. Before diagnosing a problem, familiarize yourself with each symbol.

Direction mark

A direction mark is shown to clarify the side of connector (terminal side or harness side).

Direction marks are mainly used in the illustrations indicating terminal inspection.




: View from terminal side ... T.S.

- All connector symbols shown from the terminal side are enclosed by a single line.



: View from harness side ... H.S.

- All connector symbols shown from the harness side are enclosed by a double line.



HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

Key to symbols signifying measurements or procedures

Symbol	Symbol explanation	Symbol	Symbol explanation
	Check after disconnecting the connector to be measured.		Current should be measured with an ammeter.
	Check after connecting the connector to be measured.		Procedure with CONSULT
	Insert key into ignition switch.		Procedure without CONSULT
	Turn ignition switch to "OFF" position.		A/C switch is "OFF".
	Turn ignition switch to "ON" position.		A/C switch is "ON".
	Turn ignition switch to "START" position.		Fan switch is "ON". (At any position except for "OFF" position)
	Turn ignition switch from "OFF" to "ACC" position.		Fan switch is "OFF".
	Turn ignition switch from "ACC" to "OFF" position.		Apply battery voltage directly to components.
	Turn ignition switch from "OFF" to "ON" position.		Drive vehicle
	Turn ignition switch from "ON" to "OFF" position.		Disconnect battery negative cable.
	Do not start engine, or check with engine stopped.		Depress brake pedal.
	Start engine, or check with engine running.		Release brake pedal.
	Apply parking brake.		Depress accelerator pedal.
	Release parking brake.		Release accelerator pedal.
	Check after engine is warmed up sufficiently.	Pin terminal check for S.M.J. type E.C.U. and A/T control unit connectors. For details regarding the terminal arrangement, refer to the foldout page.	
	Voltage should be measured with a voltmeter.		
	Circuit resistance should be measured with an ohmmeter.		


CONSULT CHECKING SYSTEM

Function and System Application

Diagnostic mode	Function	E.C.C.S.	A/T
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT.	X	—
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.	X	X
Data monitor	Input/Output data in the control unit can be read.	X	X
Active test	Mode in which CONSULT drives some actuators apart from the control units and also shifts some parameters in a specified range.	X	—
E.C.U. part number	E.C.U. part number can be read.	X	X
Function test	E.C.C.S. faults can be isolated to a general area, semi-automatically and in a short time, by following the directions on the screen.	X	—

X: Applicable

Checking Equipment

Tool name	Description
NISSAN CONSULT kit ① CONSULT unit and accessories ② Program card (UE900) ③ Operation manuals ④ Binder ⑤ Carrying case ⑥ Thermal paper (Rolls)	


When ordering the above equipment, contact your NISSAN distributor.

IDENTIFICATION INFORMATION

Model Variation

Destination	Grade	Model	Engine	Transaxle
Non-California	SE & XE	FLU12WFEU	KA24E	RS5F50A
		FLU12WAEU		RE4F02A
	GXE	FLU12YFEU		RS5F50V
		FLU12YAEU		RE4F02V
California	SE & XE	FLU12WFEV		RS5F50A
		FLU12WAEV		RE4F02A
	GXE	FLU12YFEV		RS5F50V
		FLU12YAEV		RE4F02V
Canada	SE & XE	FLU12WFEN		RS5F50A
		FLU12WAEN		RE4F02A
	GXE	FLU12YFEN		RS5F50V
		FLU12YAEN		RE4F02V

Prefix and suffix designations



Identification Number



Left Side of VIN:

- JN1**: Manufacturer (Nissan, Passenger vehicle)
- F**: Engine type (KA24E engine)
- U**: Vehicle line (Nissan Stanza)
- 2**: Model change
- 1**: Body type (Sedan)

Right Side of VIN:

- S**: Restraint system (Standard)
- ***: Check digit (0 to 9 or X)
- N**: Model year (1992 year model)
- T**: Manufacturing plant (Oppama)
- 400101**: Vehicle serial number

IDENTIFICATION INFORMATION


Identification Number (Cont'd) IDENTIFICATION PLATE

NISSAN MOTOR CO., LTD. JAPAN			
型式	TYPE TIPO	△	
CHASSIS NO		△	
NO. DE CHASIS			
MODEL		△	
MODELO			
○ カラー-COLOR TRIM トリムCOLOR GUARNICION		△ △	○
エンジン ENGINE ン MOTOR		△ △	CC
ミッション TRANS. AXLE アクスル TRANS. EJE		△ △	
	工場	PLANT PLANTA	
日産自動車株式会社		MADE IN JAPAN	


SGI315

- 1 Type
- 2 Vehicle identification number (Chassis number)
- 3 Model
- 4 Body color code
- 5 Trim color code
- 6 Engine model
- 7 Engine displacement
- 8 Transaxle model
- 9 Axle model


ENGINE SERIAL NUMBER



MANUAL TRANSAXLE NUMBER



AUTOMATIC TRANSAXLE NUMBER



IDENTIFICATION INFORMATION

Dimensions

Unit: mm (in)

	Sedan
Overall length	4,570 (179.9)
Overall width	1,697 (66.8)
Overall height	1,375 (54.1)
Front tread	1,460 (57.5)
Rear tread	1,440 (56.7)
Wheelbase	2,525 (99.4)

Wheels and Tires

			SE & XE grades	GXE grade
Road Wheel	Conventional	Steel	14 x 5-1/2JJ	—
		Aluminum	14 x 5-1/2JJ*1	—
			14 x 6JJ*1	14 x 6JJ
	Spare		15 x 4T	16 x 4T
			16 x 4T*1	—
	Offset	mm (in)	40 (1.57) 35 (1.38)*2	40 (1.57) 35 (1.38)*2
Tire size	Conventional	All season tire	P195/65R14 89H	P195/65R14 89H*3
		Summer tire	P195/65R14 89H*1	P195/65R14 89H
	Spare		T125/70D15	T135/70D16
			T135/70D16*1	—

*1: Option

*2: For 16 x 4T

*3: Standard for Canada


Garage Jack and Safety Stand

WARNING:

- Never get under the vehicle while it is supported only by the jack. Always use safety stands to support the frame when you have to get under the vehicle.
- Place wheel chocks at both front and back of the wheels on the ground.

CAUTION:

Place a wooden or rubber block between safety stand and vehicle body when the supporting body is flat.




LIFTING POINTS AND TOW TRUCK TOWING

2-pole Lift

WARNING:

When lifting the vehicle, open the lift arms as wide as possible and ensure that the front and rear of the vehicle are well balanced.


When setting the lift arm, do not allow the arm to contact the brake tubes and fuel lines.



Tow Truck Towing

CAUTION:

- All applicable state or Provincial (in Canada) laws and local laws regarding the towing operation must be obeyed.
- It is necessary to use proper towing equipment to avoid possible damage to the vehicle during towing operation. Towing is in accordance with Towing Procedure Manual at dealer.
- When towing with the rear wheels on the ground, release the parking brake and move the gearshift lever to neutral.



NISSAN recommends that vehicle be towed with the driving (front) wheels off the ground as illustrated.

LIFTING POINTS AND TOW TRUCK TOWING

Tow Truck Towing (Cont'd)

TOWING AN AUTOMATIC TRANSAXLE MODEL WITH FOUR WHEELS ON GROUND

Observe the following restricted towing speeds and distances.

Speed:


Below 50 km/h (30 MPH)

Distance:

Less than 65 km (40 miles)


CAUTION:

Never tow an automatic transaxle model from the rear (i.e., backward) with four wheels on the ground as this may cause serious and expensive damage to the transaxle.



TOWING AN AUTOMATIC TRANSAXLE MODEL WITH REAR WHEELS RAISED (With front wheels on ground)

Never tow an automatic transaxle model with rear wheels raised (with front wheels on ground) as this may cause serious and expensive damage to the transaxle. If it is necessary to tow it with rear wheels raised, always use a towing dolly under the front wheels.



TOWING POINT

Always pull the cable straight out from the vehicle. Never pull on the hook at a sideways angle.


TIGHTENING TORQUE OF STANDARD BOLTS

Grade	Bolt size	Bolt diameter* mm	Pitch mm	Tightening torque (Without lubricant)					
				Hexagon head bolt			Hexagon flange bolt		
				N·m	kg-m	ft-lb	N·m	kg-m	ft-lb
4T	M6	6.0	1.0	5.1	0.52	3.8	6.1	0.62	4.5
	M8	8.0	1.25	13	1.3	9	15	1.5	11
			1.0	13	1.3	9	16	1.6	12
	M10	10.0	1.5	25	2.5	18	29	3.0	22
			1.25	25	2.6	19	30	3.1	22
	M12	12.0	1.75	42	4.3	31	51	5.2	38
			1.25	46	4.7	34	56	5.7	41
M14	14.0	1.5	74	7.5	54	88	9.0	65	
7T	M6	6.0	1.0	8.4	0.86	6.2	10	1.0	7
	M8	8.0	1.25	21	2.1	15	25	2.5	18
			1.0	22	2.2	16	26	2.7	20
	M10	10.0	1.5	41	4.2	30	48	4.9	35
			1.25	43	4.4	32	51	5.2	38
	M12	12.0	1.75	71	7.2	52	84	8.6	62
			1.25	77	7.9	57	92	9.4	68
M14	14.0	1.5	127	13.0	94	147	15.0	108	
9T	M6	6.0	1.0	12	1.2	9	15	1.5	11
	M8	8.0	1.25	29	3.0	22	35	3.6	26
			1.0	31	3.2	23	37	3.8	27
	M10	10.0	1.5	59	6.0	43	70	7.1	51
			1.25	62	6.3	46	74	7.5	54
	M12	12.0	1.75	98	10.0	72	118	12.0	87
			1.25	108	11.0	80	137	14.0	101
M14	14.0	1.5	177	18.0	130	206	21.0	152	

1. Special parts are excluded.
2. This standard is applicable to bolts having the following marks embossed on the bolt head.

*: Nominal diameter

Grade	Mark
4T	4
7T	7
9T	9



MAINTENANCE

SECTION **MA**

MA

CONTENTS

GENERAL MAINTENANCE	MA- 2
PERIODIC MAINTENANCE	MA- 4
RECOMMENDED FLUIDS AND LUBRICANTS	MA- 7
ENGINE MAINTENANCE	MA- 8
CHASSIS AND BODY MAINTENANCE	MA-14
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	MA-20

GENERAL MAINTENANCE

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owners can perform the checks and inspections themselves or they can have their NISSAN dealers do them.

Item	Reference page
OUTSIDE THE VEHICLE	
The maintenance items listed here should be performed from time to time, unless otherwise specified.	
Tires Check the pressure with a gauge periodically when at a service station, including the spare, and adjust to the specified pressure if necessary. Check carefully for damage, cuts or excessive wear.	—
Wheel nuts When checking the tires, make sure no nuts are missing, and check for any loose nuts. Tighten if necessary.	—
Tire rotation Tires should be rotated every 12,000 km (7,500 miles).	MA-17
Wheel alignment and balance If the vehicle should pull to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.	MA-17 FA-6
Windshield wiper blades Check for cracks or wear if they do not wipe properly.	—
Doors and engine hood Check that all doors and the engine hood operate smoothly as well as the trunk lid and back hatch. Also ensure, that all latches lock securely. Lubricate hinges, latches, rollers and links if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-19
INSIDE THE VEHICLE	
The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.	
Lights Make sure that the headlights, stop lights, tail lights, turn signal lights, and other lights are all operating properly and installed securely. Also check headlight aim.	—
Warning lights and buzzers/chimes Make sure that all warning lights and buzzers/chimes are operating properly.	—
Windshield wiper and washer Check that the wipers and washer operate properly and that the wipers do not streak.	—
Windshield defroster Check that the air comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioner.	—
Steering wheel Check that it has the specified free play. Be sure to check for changes in the steering condition, such as excessive free play, hard steering or strange noises. Free play: Less than 35 mm (1.38 in)	—
Seats Check seat position controls such as seat adjusters, seatback recliner, etc. to ensure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if so equipped) hold securely in all latched positions. Check that the latches lock securely for folding-down rear seatbacks.	—
Seat belts Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly, and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-19
Clutch pedal Make sure the pedal operates smoothly and check that it has the proper free travel.	CL-4

GENERAL MAINTENANCE

Item	Reference page
Brakes Check that the brake does not pull the vehicle to one side when applied.	—
Brake pedal Check the pedal for smooth operation and make sure it has the proper distance under it when depressed fully. Check the brake booster function. Be certain to keep floor mats away from the pedal.	BR-7
Parking brake Check that the lever has the proper travel and confirm that your vehicle is held securely on a fairly steep hill with only the parking brake applied.	BR-23
Automatic transaxle "Park" mechanism Check that the lock release button on the selector lever operates properly and smoothly. On a fairly steep hill check that your vehicle is held securely with the selector lever in the "P" position without applying any brakes.	—
UNDER THE HOOD AND VEHICLE	
The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).	
Windshield washer fluid Check that there is adequate fluid in the tank.	—
Engine coolant level Check the coolant level when the engine is cold.	MA-10
Radiator and hoses Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure the hoses have no cracks, deformation, rot or loose connections.	—
Brake and clutch fluid levels Make sure that the brake and clutch fluid levels are between the "MAX" and "MIN" lines on the reservoir.	MA-14, 15
Battery Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines.	—
Engine drive belts Make sure that no belt is frayed, worn, cracked or oily.	MA-8
Engine oil level Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-12
Power steering fluid level and lines Check the level when the fluid is cold and the engine is turned off. Check the lines for proper attachment, leaks, cracks, etc.	MA-18
Automatic transaxle fluid level Check the level on the dipstick after putting the selector lever in "P" with the engine idling.	MA-15
Exhaust system Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-18
Underbody The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	—
Fluid leaks Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or gasoline fumes are evident, check for the cause and correct it immediately.	—

PERIODIC MAINTENANCE

Two different maintenance schedules are provided, and should be used, depending upon the conditions in which the vehicle is mainly operated. **After 60,000 miles (96,000 km) or 48 months, continue the periodic maintenance at the same mileage/time intervals.**

SCHEDULE 1

Follow Periodic Maintenance Schedule 1 if your driving habits frequently includes one or more of the following driving conditions:

- Repeated short trips of less than 5 miles (8 km).
- Repeated short trips of less than 10 miles (16 km) with outside temperatures remaining below freezing.
- Operating in hot weather in stop-and-go "rush hour" traffic.
- Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery use.
- Driving in dusty conditions.
- Driving on rough, muddy, or salt spread roads.
- Towing a trailer, using a camper or a car-top carrier.

SCHEDULE 2

Follow Periodic Maintenance Schedule 2 if none of the driving conditions shown in Schedule 1 apply to your driving habits.

Schedule 1

[]: At the mileage intervals only

Abbreviations: R = Replace I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL															
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	3.75 (6) 3	7.5 (12) 6	11.25 (18) 9	15 (24) 12	18.75 (30) 15	22.5 (36) 18	26.25 (42) 21	30 (48) 24	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36	48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48
Emission control system maintenance																	
Drive belts	See NOTE (1)															I*	MA-8
Air cleaner filter	See NOTE (2)								[R]							[R]	MA-11
Vapor lines									I*							I*	MA-13
Fuel lines									I*							I*	MA-10
Fuel filter	See NOTE (3)*																MA-10
Engine coolant																	R*
Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Engine oil filter (Use Nissan PREMIUM type or equivalent.)		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	MA-12
Spark plugs									[R]							[R]	MA-12
Chassis and body maintenance																	
Brake lines & cables						I				I							I
Brake pads, discs, drums & linings			I		I		I		I		I		I		I		I
Manual & automatic trans-axle oil	See NOTE (4)								I								I
Steering gear & linkage, axle & suspension parts			I		I		I		I		I		I		I		I
Steering linkage ball joints & front suspension ball joints			I		I		I		I		I		I		I		I
Exhaust system			I		I		I		I		I		I		I		I
Drive shaft boots			I		I		I		I		I		I		I		I

NOTE: (1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months.

(2) If operating mainly in dusty conditions, more frequent maintenance may be required.

(3) If vehicle is operated under extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high, the filters might become clogged. In such an event, replace them immediately.

(4) If towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads, change (not just inspect) oil at every 30,000 miles (48,000 km) or 24 months.

(5) Maintenance items and intervals with "..." are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

Schedule 2

[] : At the mileage intervals only

Abbreviations: R = Replace I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL										Reference page
Perform at number of miles, kilometers or months, whichever comes first.	Miles × 1,000 (km × 1,000) Months	7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48			
Emission control system maintenance												
Drive belts	See NOTE (1)									I*	MA-8	
Air cleaner filter					[R]					[R]	MA-11	
Vapor lines					I*					I*	MA-13	
Fuel lines					I*					I*	MA-10	
Fuel filter	See NOTE (2)*										MA-10	
Engine coolant						R*				R*	MA-9	
Engine oil		R	R	R	R	R	R	R	R	R	MA-11	
Engine oil filter (Use Nissan PREMIUM type or equivalent.)		R		R		R		R			MA-12	
Spark plugs					[R]					[R]	MA-12	
Chassis and body maintenance												
Brake lines & cables			I		I		I			I	MA-16	
Brake pads, discs, drums & linings			I		I		I			I	MA-16	
Manual & automatic transaxle oil			I		I		I			I	MA-14	
Steering gear linkage, axle & suspension parts						I				I	MA-17, FA-4	
Exhaust system			I		I		I			I	MA-18	
Drive shaft boots			I		I		I			I	FA-8	

NOTE: (1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months.
(2) If vehicle is operated under extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high, the filters might become clogged. In such an event, replace them immediately.
(3) Maintenance items and intervals with "*" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

RECOMMENDED FLUIDS AND LUBRICANTS

Fluids and Lubricants

	Capacity (Approximate)			Recommended fluids and lubricants
	US measure	Imp measure	Liter	
Engine oil (Refill)				
With oil filter	3-3/4 qt	3-1/8 qt	3.5	Energy Conserving Oils of API SG *2, *3
Without oil filter	3-3/8 qt	2-7/8 qt	3.2	
Cooling system	7-7/8 qt	6-1/2 qt	7.4	Anti-freeze coolant (Ethylene glycol base)
Manual transaxle gear oil	10 pt	8-1/4 pt	4.7	API GL-4*2
Automatic transaxle fluid	7-7/8 qt	6-1/2 qt	7.4	Genuine Nissan ATF*1 or equivalent Type DEXRON™
Power steering fluid	—	—	—	Type DEXRON™
Brake fluid	—	—	—	Genuine Nissan Brake Fluid*1 or equivalent DOT 3 (US FMVSS No. 116)
Multi-purpose grease	—	—	—	NLGI No. 2 (Lithium soap base)


*1: Available in mainland U.S.A. through your Nissan dealer.

*2: For further details, see "Recommended SAE viscosity number".

*3: Energy conserving oils


These oils can be identified by such labels as EC-I, EC-II energy conserving, energy saving, improved fuel economy, etc.

SAE Viscosity Number



T10008


5W-30 is preferable for ambient temperatures above -18°C (0°F). 20W-40 and 20W-50 are usable for ambient temperatures above 10°C (50°F) for all seasons.



T10003

80W-90 is preferable for ambient temperatures below 40°C (104°F).

Checking Drive Belts



1. Inspect for cracks, fraying, wear or oil adhesion. If necessary, replace with a new one.
2. Inspect drive belt deflections by pushing on the belt midway between pulleys.






Adjust if belt deflections exceed the limit.

Belt deflection:

Inspect drive belt deflections when engine is cold.

Unit: mm (in)

	Used belt deflection		Deflection of new belt
	Limit	Deflection after adjustment	
Alternator Power steering oil pump	8 (0.31)	6 - 7 (0.24 - 0.28)	5 - 6 (0.20 - 0.24)
Air conditioner compressor	8 (0.31)	5 - 6 (0.20 - 0.24)	4 - 5 (0.16 - 0.20)
Applied pushing force	98 N (10 kg, 22 lb)		



Changing Engine Coolant

WARNING:

To avoid being scalded, never change the coolant when the engine is hot.


1. Move heater "TEMP" control lever all the way to "HOT" position.
2. Open drain cock at the bottom of radiator, and remove radiator cap.
3. Remove cylinder block drain plug.
4. Close drain cock and tighten drain plug securely.
 - **Apply sealant to the thread of drain plug.**
 - ⌚: 34 - 44 N·m
 - (3.5 - 4.5 kg-m, 25 - 33 ft-lb)
5. Open air relief plug.
6. Fill radiator with water and close air relief plug and radiator cap.
7. Run engine and warm it up sufficiently.
8. Race engine 2 or 3 times under no-load.
9. Stop engine and wait until it cools down.
10. Drain water.
11. Repeat step 2 through step 10 until clear water begins to drain from radiator.
12. Open radiator cap and air relief plug.
13. Fill radiator with coolant up to specified level. Follow instructions attached to anti-freeze container for mixing ratio of anti-freeze to water.
 - **Coolant capacity (With reservoir tank):**
 - 7.4 ℓ (7-7/8 US qt, 6-1/2 Imp qt)

ENGINE MAINTENANCE


Changing Engine Coolant (Cont'd)

Pour coolant through coolant filler neck slowly to allow air in system to escape.

After radiator is filled with coolant, attach radiator cap, and shake radiator upper hose up and down. Open radiator cap, and see if coolant level has dropped. Add coolant if any drop in coolant level is found.




14. Close air relief plug.
15. Remove reservoir tank, drain coolant, then clean reservoir tank.
16. Install reservoir tank and fill it with coolant up to "MAX" level and then install radiator cap.
17. Run engine and warm it up sufficiently.
18. Race engine 2 or 3 times under no-load.
19. Stop engine and cool it down, then add coolant as necessary.



Checking Fuel Lines

Inspect fuel lines and tank for improper attachment and for leaks, cracks, damage, loose connections, chafing and deterioration.


If necessary, repair or replace faulty parts.



CAUTION:

Tighten high-pressure rubber hose clamp so that clamp end is 3 mm (0.12 in) from hose end.

Ensure that screw does not contact adjacent parts.



Changing Fuel Filter


WARNING:

Before removing fuel filter, release fuel pressure from fuel line.

1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank engine two or three times to make sure that fuel pressure is released.
4. Turn ignition switch off and install fuse for fuel pump.

ENGINE MAINTENANCE


Changing Fuel Filter (Cont'd)



5. Loosen fuel hose clamps.
 6. Replace fuel filter.
- Use a high-pressure type fuel filter. Do not use a synthetic resinous fuel filter.
 - When tightening fuel hose clamps, refer to "Checking Fuel Lines".

Changing Air Cleaner Filter

The viscous paper type filter does not need cleaning between renewals.



Changing Engine Oil

WARNING:

Be careful not to burn yourself, as the engine oil is hot.

1. Warm up engine, and check for oil leakage from engine components.
2. Remove drain plug and oil filler cap.
3. Drain oil and refill with new engine oil.

Oil grade: API SG

Viscosity:

See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section.

Refill oil capacity (Approximately):

Unit: liter (US qt, Imp qt)

With oil filter change	3.5 (3-3/4, 3-1/8)
Without oil filter change	3.2 (3-3/8, 2-7/8)

CAUTION:


- Be sure to clean drain plug and install with new washer.

Drain plug:

☐: 29 - 39 N·m


(3.0 - 4.0 kg-m, 22 - 29 ft-lb)

The refill capacity changes depending on the oil temperature and drain time, use these values as a reference and be certain to check with the dipstick when changing the oil.



ENGINE MAINTENANCE

Changing Engine Oil (Cont'd)




4. Check oil level.
5. Start engine and check area around drain plug and oil filter for oil leakage.
6. Run engine for a few minutes, then turn it off. After several minutes, check oil level.

Changing Oil Filter


1. Remove oil filter with a suitable tool.

WARNING:

Be careful not to burn yourself, as the engine and the engine oil are hot.




2. Before installing new oil filter, clean the oil filter mounting surface on cylinder block, and coat the rubber seal of oil filter with a little engine oil.



3. Screw in the oil filter until a slight resistance is felt, then tighten additionally more than 2/3 turn.
4. Add engine oil.


Refer to Changing Engine Oil.



Changing Spark Plugs

1. Disconnect ignition wires from spark plugs at boot. Do not pull on the wire.

Changing Spark Plugs (Cont'd)



2. Remove spark plugs with spark plug wrench.

Spark plug:

Standard type


ZFR5E-11

Hot type

ZFR4E-11

Cold type

ZFR6E-11



3. Check plug gap of each new spark plug.


Gap: 1.0 - 1.1 mm (0.039 - 0.043 in)

4. Install spark plugs. Reconnect ignition wires according to nos. indicated on them.

Spark plug:

⚙: 20 - 29 N·m


(2.0 - 3.0 kg-m, 14 - 22 ft-lb)



Checking Vapor Lines


1. Visually inspect vapor lines for improper attachment and for cracks, damage, loose connections, chafing and deterioration.
2. Inspect vacuum relief valve of fuel tank filler cap for clogging, sticking, etc.

Refer to EVAPORATIVE EMISSION CONTROL SYSTEM INSPECTION in EF & EC section.




Checking Clutch Fluid Level and Leaks

If fluid level is extremely low, check clutch system for leaks.




Checking M/T Oil

1. Check for oil leaks.



2. Check oil level.


Never start engine while checking oil level.



Changing M/T Oil

Oil capacity:

4.7 liters (10 US pt, 8-1/4 Imp pt)




Checking A/T Fluid Level

1. Check for fluid leakage.

CHASSIS AND BODY MAINTENANCE

Checking A/T Fluid Level (Cont'd)



2. Check fluid level.

Fluid level should be checked using "HOT" range on dipstick at fluid temperatures of 50 to 80°C (122 to 176°F) after vehicle has been driven approximately 5 minutes in urban areas after engine is warmed up. But it can be checked at fluid temperatures of 30 to 50°C (86 to 122°F) using "COLD" range on dipstick for reference after engine is warmed up and before driving. However, fluid level must be rechecked using "HOT" range.

- 1) Park vehicle on level surface and set parking brake.
- 2) Start engine and then move selector lever through each gear range, ending in "P".
- 3) Check fluid level with engine idling.
- 4) Remove dipstick and wipe it clean with lint-free paper.
- 5) Re-insert dipstick into charging pipe as far as it will go.
- 6) Remove dipstick and note reading. If level is at low side of either range, add fluid to the charging pipe.

Do not overfill.



3. Check fluid condition.


Check fluid for contamination. If fluid is very dark or smells burned, or contains frictional material (clutches, band, etc.), check operation of A/T.

Refer to section AT for checking operation of A/T.

Changing A/T Fluid


Oil capacity (With torque converter):

7.4 liters (7-7/8 US qt, 6-1/2 Imp qt)




Checking Brake Fluid Level and Leaks

If fluid level is extremely low, check brake system for leaks.



Checking Brake Lines and Cables

Check brake fluid lines and parking brake cables for improper attachment and for leaks, chafing, abrasions, deterioration, etc.




Checking Disc Brake

ROTOR

Check condition and thickness.


Unit: mm (in)

	CL25VA	CL9H
Standard	22.0 (0.866)	10.0 (0.394)
Minimum	20.0 (0.787)	9.0 (0.354)



CALIPER

Check operation and for leakage.




PAD

Check for wear or damage.

Unit: mm (in)

	CL25VA	CL9H
Standard	11.0 (0.433)	9.0 (0.354)
Minimum	2.0 (0.079)	2.0 (0.079)



Checking Drum Brake

WHEEL CYLINDER

Check operation and for leakage.

Checking Drum Brake (Cont'd)

DRUM


Check condition of inner surface.

Standard inner diameter:

228.6 mm (9 in)

Maximum diameter:

230.0 mm (9.06 in)



LINING


Check for wear or damage.

Standard thickness:

4.5 mm (0.177 in)


Minimum thickness:

1.5 mm (0.059 in)



TEMPORARY METHOD FOR CHECKING LINING WEAR

Remove inspection hole plug and check for lining wear.




Balancing Wheels

- Adjust wheel balance using road wheel center.

Wheel balance (Maximum allowable unbalance):

Refer to S.D.S.



Tire Rotation

- Do not include the T-type spare tire when rotating the tires.

Wheel nuts:

98 - 118 N·m

(10.0 - 12.0 kg-m, 72 - 87 ft-lb)


Checking Steering Gear and Linkage


STEERING GEAR

- Check gear housing and boots for looseness, damage or grease leakage.
- Check connection with steering column for looseness.

STEERING LINKAGE

- Check ball joint, dust cover and other component parts for looseness, wear, damage or grease leakage.







Checking Power Steering Fluid and Lines

Check fluid level.

Fluid level should be checked using "HOT" range on dipstick at fluid temperatures of 50 to 80°C (122 to 176°F) or using "COLD" range on dipstick at fluid temperatures of 0 to 30°C (32 to 86°F).

CAUTION:


- Do not overfill.
- Recommended fluid is Automatic Transmission Fluid "DEXRON™" type.
- Check lines for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.



Checking Exhaust System

Check exhaust pipes, muffler and mounting for proper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

Lubricating Locks, Hinges and Hood Latches




Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters

CAUTION:

1. All seat belt assemblies, including retractors and attaching hardware such as guide rail set, etc., should be inspected after any collision. Nissan recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Seat belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.
2. If the condition of any component of seat belt assembly is questionable, do not have it repaired, but replaced as seat belt assembly.
3. If webbing is cut, frayed, or damaged, replace belt assembly.
4. Do not spill drinks, oil, etc. on inner lap belt buckle. Never oil tongue and buckle.
5. Use a NISSAN genuine seat belt assembly.

Anchor bolt
43 - 55 N·m
(4.4 - 5.6 kg-m,
32 - 41 ft-lb)

For automatic seat belt details, refer to BF section.



SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Engine Maintenance

INSPECTION AND ADJUSTMENT

Drive belt deflection

Unit: mm (in)

	Used belt deflection		Deflection of new belt
	Limit	Deflection after adjustment	
Alternator Power steering oil pump	8 (0.31)	6 - 7 (0.24 - 0.28)	5 - 6 (0.20 - 0.24)
Air conditioner compressor	8 (0.31)	5 - 6 (0.20 - 0.24)	4 - 5 (0.16 - 0.20)
Applied pushing force	98 N (10 kg, 22 lb)		

Oil capacity (Refill)

Unit: ℓ (US qt, Imp qt)

With oil filter	3.5 (3-3/4, 3-1/8)
Without oil filter	3.2 (3-3/8, 2-7/8)

Oil capacity

Unit: ℓ (US qt, Imp qt)

With reservoir tank	7.4 (7-7/8, 6-1/2)
---------------------	--------------------

Spark plug

Standard type	ZFR5E-11
Hot type	ZFR4E-11
Cold type	ZFR6E-11
Plug gap	1.0 - 1.1 mm (0.039 - 0.043 in)

Ignition wire

Resistance	kΩ/m (kΩ/ft)	Less than 30 (9.1)
------------	--------------	--------------------

TIGHTENING TORQUE

Unit	N·m	kg·m	ft-lb
Spark plug	20 - 29	2.0 - 3.0	14 - 22
Drain plug			
Engine block	34 - 44	3.5 - 4.5	25 - 33
Oil pan	29 - 39	3.0 - 4.0	22 - 29

Chassis and Body Maintenance

INSPECTION AND ADJUSTMENT

Clutch

Unit: mm (in)

Pedal free height	163 - 173 (6.42 - 6.81)
Pedal free play	1 - 3 (0.04 - 0.12)

Front axle and front suspension (Unladen)*

Chamber	degree	-30' to 1°00'
Caster	degree	35' - 2°05'
Kingpin inclination	degree	13°45' - 15°15'
Toe-in		
A — B	mm (in)	1 - 3 (0.04 - 0.12)
Total angle 2θ	degree	6' - 18'
Front wheel turning angle		
Full turn		
Inside/outside	degree	34° - 38°/27° - 31°

*: Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

Rear axle and rear suspension (Unladen)*

Camber	degree	-1°20' to 10'
Toe-in		
A — B	mm (in)	-4 to 0 (-0.16 to 0)
Total angle 2θ	degree	-23' to 0'

*: Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

Brake

Disc brake	mm (in)	
Pad		
Standard thickness		
CL25VA		11.0 (0.433)
CL9H		9.0 (0.354)
Minimum thickness		
CL25VA		2.0 (0.079)
CL9H		2.0 (0.079)
Rotor		
Standard thickness		
CL25VA		22.0 (0.866)
CL9H		10.0 (0.394)
Minimum thickness		
CL25VA		20.0 (0.787)
CL9H		9.0 (0.354)

Drum brake	mm (in)	
Lining		
Standard thickness		4.5 (0.177)
Minimum thickness		1.5 (0.059)
Drum		
Standard diameter		228.6 (9)
Maximum diameter		230.0 (9.06)

Wheel balance

Maximum allowable unbalance	Dynamic (at rim flange) g (oz)	10 (0.35) (One side)
	Static g (oz)	20 (0.71)

Wheel bearing

	Front	Rear
Wheel bearing axle end play mm (in)	0.05 (0.0020) or less	
Wheel bearing lock nut		
Tightening torque N·m (kg-m, ft-lb)	235 - 314 (24 - 32, 174 - 231)	186 - 255 (19 - 26, 137 - 188)

TIGHTENING TORQUE

Unit	N·m	kg-m	ft-lb
Clutch			
Pedal stopper lock nut	16 - 22	1.6 - 2.2	12 - 16
Clutch switch lock nut	12 - 15	1.2 - 1.5	9 - 11
Manual transaxle			
Filler plug	25 - 34	2.5 - 3.5	18 - 25
Drain plug	20 - 29	2.0 - 3.0	14 - 22
Automatic transaxle			
Drain plug	25 - 34	2.5 - 3.5	18 - 25
Front axle and front suspension			
Tie-rod lock nut	37 - 46	3.8 - 4.7	27 - 34
Rear axle and rear suspension			
Toe adjusting lock nut	78 - 98	8.0 - 10.0	58 - 72
Brake system			
Air bleed valve	7 - 9	0.7 - 0.9	5.1 - 6.5
Wheel and tire			
Wheel nut	98 - 118	10 - 12	72 - 87

ENGINE MECHANICAL


SECTION **EM**



CONTENTS

PRECAUTIONS	EM- 2
PREPARATION	EM- 3
OUTER COMPONENT PARTS	EM- 6
COMPRESSION PRESSURE	EM- 8
OIL PAN	EM- 9
TIMING CHAIN	EM-10
OIL SEAL REPLACEMENT	EM-14
CYLINDER HEAD	EM-16
ENGINE REMOVAL	EM-29
CYLINDER BLOCK	EM-31
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	EM-43

PRECAUTIONS



Liquid Gasket Application Procedure





- a. Before applying liquid gasket, use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves, and then completely clean any oil stains from these portions.
- b. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) wide (in areas except oil pan).
- c. Apply liquid gasket to inner surface around hole perimeter area.
(Assembly should be done within 5 minutes after coating.)
- d. Wait at least 30 minutes before refilling engine oil and engine coolant.

Parts Requiring Angular Tightening






- Some important engine parts are tightened using an angular-tightening method rather than a torque setting method.
- If these parts are tightened using a torque setting method, dispersal of the tightening force (axial bolt force) will be two or three times that of the dispersal produced by using the correct angular-tightening method.
- Although the torque setting values (described in this manual) are equivalent to those used when bolts and nuts are tightened with an angular-tightening method, they should be used for reference only.
- To assure the satisfactory maintenance of the engine, bolts and nuts must be tightened using an angular-tightening method.
- Before tightening the bolts and nuts, ensure that the thread and seating surfaces are clean and then coated with engine oil.
- The bolts and nuts which require the angular-tightening method are as follows:
 - (1) Cylinder head bolts
 - (2) Connecting rod bearing cap nuts

PREPARATION

SPECIAL SERVICE TOOLS





Tool number (Kent-Moore No.) Tool name	Description
ST0501S000 (—) Engine stand assembly ① ST05011000 (—) Engine stand ② ST05012000 (—) Base	 Disassembling and assembling
KV10114300 (—) Engine sub-attachment	
KV101065001 (—) Engine stand shaft	
KV101092S0 (—) Valve spring compressor ① KV10109210 (—) Compressor ② KV10109220 (—) Adapter	 Disassembling and assembling valve components
KV109B0010 (—) Valve oil seal drift	 Installing valve oil seal

PREPARATION


Tool number (Kent-Moore No.) Tool name	Description
KV10110300 (—) Piston pin press stand assembly ① KV10110310 (—) Cap ② KV10110330 (—) Spacer ③ ST13030020 (—) Press stand ④ ST13030030 (—) Spring ⑤ KV10110340 (—) Drift ⑥ KV10110320 (—) Center shaft	 Disassembling and assembling piston with connecting rod
EM03470000 (J8037) Piston ring compressor	 Installing piston assembly into cylinder bore
(J36467) Valve oil seal remover	 Displacement valve oil seal
KV10111100 (—) Seal cutter	 Removing oil pan
WS39930000 (—) Tube presser	 Pressing the tube of liquid gasket
ST16610001 (J23907) Pilot bushing puller	

PREPARATION

COMMERCIAL SERVICE TOOLS


Tool name	Description													
Spark plug wrench	 16 mm (0.63 in)	Removing and installing spark plug												
Pulley holder		Holding camshaft pulley while tightening or loosening camshaft bolt												
Valve seat cutter set		Finishing valve seat dimensions												
Piston ring expander		Removing and installing piston ring												
Valve guide drift		Removing and installing valve guide <table border="1"><thead><tr><th colspan="2">Diameter:</th><th>mm (in)</th></tr><tr><th></th><th>Intake</th><th>Exhaust</th></tr></thead><tbody><tr><td>A</td><td>10.5 (0.413)</td><td>11.5 (0.453)</td></tr><tr><td>B</td><td>6.6 (0.260)</td><td>7.6 (0.299)</td></tr></tbody></table>	Diameter:		mm (in)		Intake	Exhaust	A	10.5 (0.413)	11.5 (0.453)	B	6.6 (0.260)	7.6 (0.299)
Diameter:		mm (in)												
	Intake	Exhaust												
A	10.5 (0.413)	11.5 (0.453)												
B	6.6 (0.260)	7.6 (0.299)												
Valve guide reamer		Reaming valve guide (①) or hole for oversize valve guide (②) <table border="1"><thead><tr><th colspan="2">Diameter:</th><th>mm (in)</th></tr><tr><th></th><th>Intake</th><th>Exhaust</th></tr></thead><tbody><tr><td>D₁</td><td>7 (0.28)</td><td>8 (0.31)</td></tr><tr><td>D₂</td><td>11.2 (0.441)</td><td>12.2 (0.480)</td></tr></tbody></table>	Diameter:		mm (in)		Intake	Exhaust	D ₁	7 (0.28)	8 (0.31)	D ₂	11.2 (0.441)	12.2 (0.480)
Diameter:		mm (in)												
	Intake	Exhaust												
D ₁	7 (0.28)	8 (0.31)												
D ₂	11.2 (0.441)	12.2 (0.480)												

OUTER COMPONENT PARTS



□ : N·m (kg·m, ft·lb)
SEM549C


OUTER COMPONENT PARTS



Tightening Procedure of each Part


INTAKE MANIFOLD

☐: 16 - 21 N·m (1.6 - 2.1 kg-m, 12 - 15 ft-lb)




EXHAUST MANIFOLD

☐: 16 - 21 N·m (1.6 - 2.1 kg-m, 12 - 15 ft-lb)



INTAKE MANIFOLD COLLECTOR

☐: 16 - 21 N·m (1.6 - 2.1 kg-m, 12 - 15 ft-lb)



THROTTLE CHAMBER

☐: Bolts should be tightened twice.

1st:

9 - 11 N·m (0.9 - 1.1 kg-m, 6.5 - 8.0 ft-lb)


2nd:

18 - 22 N·m (1.8 - 2.2 kg-m, 13 - 16 ft-lb)

COMPRESSION PRESSURE

Measurement of Compression Pressure

1. Warm up engine.
2. Turn ignition switch off.
3. Disconnect fusible link for injectors.
4. Remove all spark plugs.
5. Disconnect distributor center cable.



6. Attach a compression tester to No. 1 cylinder.
 7. Depress accelerator pedal fully to keep throttle valve wide open.
 8. Crank engine and record highest gauge indication.
 9. Repeat the measurement on each cylinder as shown above.
- **Always use a fully-charged battery to obtain specified engine revolution.**

Compression pressure:

kPa (kg/cm², psi)/rpm

Standard

1,206 (12.3, 175)/250

Minimum


1,010 (10.3, 146)/250

Difference limit between cylinders

98 (1.0, 14)/250


10. If cylinder compression in one or more cylinders is low, pour a small amount of engine oil into cylinders through spark plug holes and retest compression.
- **If adding oil helps compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.**
 - **If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. (Refer to S.D.S.) If valve or valve seat is damaged excessively, replace them.**
 - **If compression in any two adjacent cylinders is low and if adding oil does not help compression, there is leakage past the gasket surface. If so, replace cylinder head gasket.**

OIL PAN




Removal

1. Remove the following parts:
 - Front exhaust tube
 - Front side gusset
 - Center member (2WD model)
2. Remove oil pan bolts.




3. Remove oil pan.
 - (1) Insert Tool between cylinder block and oil pan.
 - **Do not drive seal cutter into oil pump or rear oil seal retainer portion, or aluminum mating face will be damaged.**
 - **Do not insert screwdriver, or oil pan flange will be deformed.**
 - (2) Slide Tool by tapping its side with a hammer, and remove oil pan.




Installation

1. Before installing oil pan, remove all traces of liquid gasket from mating surface using a scraper.
 - Also remove traces of liquid gasket from mating surface of cylinder block.
2. Apply a continuous bead of liquid gasket to mating surface of oil pan.
 - **Use Genuine Liquid Gasket or equivalent.**



- Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide.
3. Apply liquid gasket to inner sealing surface as shown in figure.
 - Attaching should be done within 5 minutes after coating.
 4. Install oil pan.
 - **Wait at least 30 minutes before refilling engine oil.**

TIMING CHAIN



CAUTION:

- After removing timing chain, do not turn crankshaft and camshaft separately, or valves will strike piston heads.




Removal

1. Place wheel chocks at both front and back of rear wheels.
2. Place safety stands under designated front supporting points. Remove front right side wheel.
3. Remove dust cover and under cover.
4. Drain engine oil.

TIMING CHAIN

Removal (Cont'd)


5. Set No. 1 piston at T.D.C. on its compression stroke.



6. Remove the alternator and compressor drive belts.

7. Remove the following parts.


- ① Alternator and adjusting bar
- ② Oil separator
- ③ Power steering pump pulley, pump stay and bracket.
- ④ Compressor and bracket.
- ⑤ Crankshaft pulley and oil pump drive boss.



8. Remove oil pan. (Refer to OIL PAN.)

9. Remove oil strainer securing bolt.

10. Remove front cover securing bolts (cover to block and head to cover).




11. Remove rocker cover.

12. Support engine with hoist or chain block.

13. Remove right-side engine mounting bracket and lower the engine.

TIMING CHAIN


Removal (Cont'd)



14. Remove front cover.
15. Remove the following parts:
 - Chain tensioner
 - Chain guides
 - Timing chain and sprocket


Inspection

Check for cracks and excessive wear at roller links. Replace if necessary.




Installation

1. Install crankshaft sprocket.
 - **Make sure that mating marks of crankshaft sprocket face engine front.**
2. Install camshaft sprocket.
3. Confirm that No. 1 piston is set at T.D.C. on its compression stroke.
4. Install timing chain.
 - **Set timing chain by aligning its mating marks with those of crankshaft sprocket and camshaft sprocket.**




TIMING CHAIN


Installation (Cont'd)




5. Tighten camshaft sprocket bolt.



6. Install chain guide and chain tensioner.




7. Apply liquid gasket to front cover.



8. Install front cover.
- Be careful not to damage cylinder head gasket.
 - Do not forget oil seal.

9. Install rubber plug onto cylinder head. (Refer to "Installation" of CYLINDER HEAD.)
10. Install oil pan. (Refer to OIL PAN.)
11. Install engine mounting.
12. Install any parts removed.


OIL SEAL REPLACEMENT





VALVE OIL SEAL

1. Remove rocker cover.
2. Remove rocker shaft assembly.
3. Remove valve spring and valve oil seal with Tool or a suitable tool.


Piston concerned should be set at T.D.C. to prevent valve from falling.



4. Apply engine oil to new valve oil seal and install it with Tool. **Before installing valve oil seal, install valve spring seat.**



OIL SEAL INSTALLING DIRECTION




FRONT OIL SEAL


1. Remove crankshaft pulley.
2. Remove front oil seal.

Be careful not to damage crankshaft.

OIL SEAL REPLACEMENT




3. Apply engine oil to new oil seal and install it using a suitable tool.




REAR OIL SEAL


1. Remove transaxle.
2. Remove flywheel or drive plate.
3. Remove rear oil seal retainer.
4. Remove traces of liquid gasket using scraper.



5. Remove rear oil seal from retainer.




6. Apply engine oil to new oil seal and install it using a suitable tool.



7. Apply liquid gasket to rear oil seal retainer.

CYLINDER HEAD





 : N·m (kg·m, ft·lb)

SEM554C

CYLINDER HEAD

CAUTION:

- When installing sliding parts such as rocker arms, camshaft and oil seal, be sure to apply new engine oil on their sliding surfaces.
- When tightening cylinder head bolts and rocker shaft bolts, apply new engine oil to thread portions and seat surfaces of bolts.



- Hydraulic valve lifters are installed in each rocker arm. If hydraulic valve lifter is kept on its side, even when installed in rocker arm, there is a possibility of air entering it. After removal, always set rocker arm straight up, or when laying it on its side, have it soak in new engine oil.

- Do not disassemble hydraulic valve lifter.
- Attach tags to valve lifters so as not to mix them up.

Removal

1. Drain coolant from radiator.
2. Relieve fuel pressure to zero.


Refer to EF & EC section "FUEL INJECTION CONTROL SYSTEM INSPECTION".

3. Remove the following parts:

- Exhaust manifold
- Air duct
- Intake manifold collector
- Intake manifold stay

4. Disconnect hoses.

- Vacuum gallery hoses, which are installed on intake manifold.
 - Fuel tube hoses
5. Disconnect water hoses as shown in figure.






CYLINDER HEAD

Removal (Cont'd)


6. Remove intake manifold.
7. Remove rocker cover.

When removing rocker cover, do not knock rocker cover against rocker arms.

8. Set No. 1 piston at T.D.C. on its compression stroke.




9. Loosen camshaft sprocket bolt.
 - Support timing chain by using Tool as shown in figure.




10. Remove camshaft sprocket.

CYLINDER HEAD

Removal (Cont'd)




11. Remove front cover tightening bolts to cylinder head.



12. Remove cylinder head.

- Head warpage or cracking could result from removing in incorrect order.
- Cylinder head bolts should be loosened in two or three steps.




Disassembly

1. Remove rocker shaft assembly.

- a. When loosening bolts, evenly loosen from outside in sequence.
- b. Bolts should be loosened in two or three steps.

2. Remove camshaft.


- Before removing camshaft, measure camshaft end play. (Refer to "Inspection".)



3. Remove valve components with Tool.

4. Remove valve oil seals. (Refer to OIL SEAL REPLACEMENT.)

CYLINDER HEAD



Inspection

CYLINDER HEAD DISTORTION

Head surface flatness:

Less than 0.1 mm (0.004 in)

If beyond the specified limit, replace it or resurface it.

Resurfacing limit:

The resurfacing limit of cylinder head is determined by the cylinder block resurfacing in an engine.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

$A + B = 0.2 \text{ mm (0.008 in)}$


After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, cylinder head must be replaced.

Nominal cylinder head height:

98.8 - 99.0 mm (3.890 - 3.898 in)

CAMSHAFT VISUAL CHECK

Check camshaft for scratches, seizure and wear.




CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.

Runout (Total indicator reading):

0 - 0.02 mm (0 - 0.0008 in)

2. If it exceeds the limit, replace camshaft.



CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.


Standard cam height:

44.839 - 45.029 mm (1.7653 - 1.7728 in)

Cam wear limit:

0.2 mm (0.008 in)

2. If wear is beyond the limit, replace camshaft.



CAMSHAFT JOURNAL CLEARANCE


1. Install camshaft bracket and rocker shaft and tighten bolts to the specified torque.
2. Measure inner diameter of camshaft bearing.

Standard inner diameter:


33.000 - 33.025 mm (1.2992 - 1.3002 in)

CYLINDER HEAD

Inspection (Cont'd)




3. Measure outer diameter of camshaft journal.
Standard outer diameter:
32.935 - 32.955 mm (1.2967 - 1.2974 in)
4. If clearance exceeds the limit, replace camshaft and/or cylinder head.
Camshaft journal clearance:
Standard
0.045 - 0.090 mm (0.0018 - 0.0035 in)
Limit
0.12 mm (0.0047 in)




CAMSHAFT END PLAY

1. Install camshaft in cylinder head.
2. Measure camshaft end play.
Camshaft end play:
Standard
0.07 - 0.15 mm (0.0028 - 0.0059 in)
Limit
0.2 mm (0.008 in)



CAMSHAFT SPROCKET RUNOUT


1. Install sprocket on camshaft.
2. Measure camshaft sprocket runout.
Runout (Total indicator reading):
Limit 0.12 mm (0.0047 in)
3. If it exceeds the limit, replace camshaft sprocket.



VALVE GUIDE CLEARANCE

1. Measure valve deflection in a right-angled direction with camshaft. (Valve and valve guide mostly wear in this direction.)

Valve deflection limit (Dial gauge reading):
0.15 mm (0.0059 in)








2. If it exceeds the limit, check valve to valve guide clearance.
 - a. Measure valve stem diameter and valve guide inner diameter.
 - b. Check that clearance is within specification.
Valve to valve guide clearance:
Standard 0.020 - 0.053 mm
(0.0008 - 0.0021 in) (Intake)
0.040 - 0.070 mm
(0.0016 - 0.0028 in) (Exhaust)
Limit 0.1 mm (0.004 in)
 - c. If it exceeds the limit, replace valve or valve guide.

CYLINDER HEAD

Inspection (Cont'd)

VALVE GUIDE REPLACEMENT



1. To remove valve guide, heat cylinder head to 150 to 160°C (302 to 320°F).

2. Drive out valve guide with a press [under a 20 kN (2 t, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and a suitable tool.

3. Ream cylinder head valve guide hole.

**Valve guide hole diameter
(for service parts):**

Intake

11.175 - 11.196 mm (0.4400 - 0.4408 in)

Exhaust

12.175 - 12.196 mm (0.4793 - 0.4802 in)

4. Heat cylinder head to 150 to 160°C (302 to 320°F) and press service valve guide onto cylinder head.

Projection "L":

14.9 - 15.1 mm (0.587 - 0.594 in)

5. Ream valve guide.

Finished size:

Intake

7.000 - 7.018 mm (0.2756 - 0.2763 in)

Exhaust

8.000 - 8.018 mm (0.3150 - 0.3157 in)






CYLINDER HEAD

Inspection (Cont'd)

VALVE SEATS

Check valve seats for any evidence of pitting at valve contact surface, and reseal or replace if it has worn out excessively.

- **Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.**
- **Cut with both hands to uniform the cutting surface.**



REPLACING VALVE SEAT FOR SERVICE PARTS

1. Bore out old seat until it collapses. The machine depth stop should be set so that boring cannot continue beyond the bottom face of the seat recess in cylinder head.
2. Ream cylinder head recess.

Reaming bore for service valve seat

Oversize [0.5 mm (0.020 in)]:

Intake 36.500 - 36.516 mm (1.4370 - 1.4376 in)

Exhaust 42.500 - 42.516 mm (1.6732 - 1.6739 in)

Reaming should be done to the concentric circles to valve guide center so that valve seat will have the correct fit.

3. Heat cylinder head to 150 to 160°C (302 to 320°F).

4. Cut or grind valve seat using a suitable tool to the specified dimensions as shown in S.D.S.
5. After cutting, lap valve seat with abrasive compound.
6. Check valve seating condition.

Seat face angle " α ":

45 deg.

Contacting width "W":

Intake

1.6 - 1.7 mm (0.063 - 0.067 in)

Exhaust

1.7 - 2.1 mm (0.067 - 0.083 in)

VALVE DIMENSIONS


Check dimensions in each valve. For dimensions, refer to S.D.S.

When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.

CYLINDER HEAD

Inspection (Cont'd)



VALVE SPRING

Squareness

1. Measure "S" dimension.

Out-of-square:

Outer

Intake

Less than 2.5 mm (0.098 in)

Exhaust

Less than 2.3 mm (0.091 in)

Inner

Intake

Less than 2.3 mm (0.091 in)

Exhaust

Less than 2.1 mm (0.083 in)

2. If it exceeds the limit, replace spring.

Pressure

Check valve spring pressure.

Pressure: N (kg, lb) at height mm (in)

Standard

Outer Intake 604.1 (61.6, 135.8) at 37.6 (1.480)

Exhaust 640.4 (65.3, 144.0) at 34.1 (1.343)

Inner Intake 284.4 (29.0, 63.9) at 32.6 (1.283)

Exhaust 328.5 (33.5, 73.9) at 29.1 (1.146)

Limit



Outer Intake 567.8 (57.9, 127.7) at 37.6 (1.480)

Exhaust 620.8 (63.3, 139.6) at 34.1 (1.343)

Inner Intake 266.8 (27.2, 60.0) at 32.6 (1.283)

Exhaust 318.7 (32.5, 71.7) at 29.1 (1.146)

If it exceeds the limit, replace spring.




ROCKER SHAFT AND ROCKER ARM

1. Check rocker shafts for scratches, seizure and wear.
2. Check outer diameter of rocker shaft.

Diameter:

21.979 - 22.000 mm (0.8653 - 0.8661 in)



3. Check inner diameter of rocker arm.

Diameter:


22.012 - 22.029 mm (0.8666 - 0.8673 in)

Rocker arm to shaft clearance:

0.012 - 0.050 mm (0.0005 - 0.0020 in)


- Keep rocker arm with hydraulic valve lifter standing to prevent air from entering hydraulic valve lifter when checking.

CYLINDER HEAD




Assembly

1. Install valve component parts.
 - Always use new valve oil seal. Refer to OIL SEAL REPLACEMENT.
 - Before installing valve oil seal, install inner valve spring seat.
 - Install outer valve spring (uneven pitch type) with its narrow pitch side toward cylinder head side.
 - After installing valve component parts, use plastic hammer to lightly tap valve stem tip to assure a proper fit.




2. Mount camshaft onto cylinder head, placing knock pin at front end to top position.

Apply engine oil to camshaft when mounting onto cylinder head.



3. Install camshaft brackets.


Front mark is punched on the camshaft bracket.




4. Install rocker shaft with rocker arms.

CYLINDER HEAD


Assembly (Cont'd)



- Install retainer with cutout facing direction shown in figure at left.





5. Tighten bolts as shown in figure at left.



Installation


1. Set No. 1 piston at T.D.C. on its compression stroke as follows:
 - (1) Align mark on crankshaft pulley with "0°" position and confirm that distributor rotor head is set as shown in figure.



- (2) Confirm that knock pin on camshaft is set at the top.

CYLINDER HEAD

Installation (Cont'd)




2. Install cylinder head with new gasket and tighten cylinder head bolts in numerical order.


- **Do not rotate crankshaft and camshaft separately, or valves will hit piston heads.**

- **Tightening procedure**


- (1) Tighten all bolts to 29 N-m (3.0 kg-m, 22 ft-lb).
- (2) Tighten all bolts to 78 N-m (8.0 kg-m, 58 ft-lb).
- (3) Loosen all bolts completely.
- (4) Tighten all bolts to 29 N-m (3.0 kg-m, 22 ft-lb).
- (5) Turn all bolts 80 to 85 degrees clockwise with an angle wrench, or if an angle wrench is not available, tighten all bolts to 74 to 83 N-m (7.5 to 8.5 kg-m, 54 to 61 ft-lb).



3. Set chain on camshaft sprocket by aligning each mating mark. Then install camshaft sprocket to camshaft.



4. Tighten camshaft sprocket bolt.








5. Install rubber plugs as follows:

- (1) Apply liquid gasket to rubber plugs.

- **Rubber plugs should be replaced with new ones.**
- **Rubber plugs should be installed within 5 minutes of applying liquid gasket.**

CYLINDER HEAD

Installation (Cont'd)



(2) Install rubber plugs, then move them with your fingers to uniformly spread the gasket on cylinder head surface.

- Rubber plugs should be installed flush with the surface.
- Do not start the engine for 30 minutes after installing rocker cover.
- Wipe clean excessive liquid gasket from cylinder head top surface.

6. Check hydraulic valve lifter.

(1) Push hydraulic valve lifter forcefully with your finger.

- Be sure to check it with rocker arm in its free position.

(2) If valve lifter moves more than 1 mm (0.04 in), air may be inside of it.

(3) Bleed air off by running engine at 1,000 rpm under no-load for about 20 minutes.

(4) If hydraulic valve lifters are still noisy, replace them and bleed air off again in the same manner as in step (3).

7. Install rocker cover.

- Be sure to avoid interference between rocker cover and rocker arm.


8. Tighten bolts as follows:

(1) Tighten 2 bolts to 3 N·m (0.3 kg-m, 2.2 ft-lb) temporarily in order shown in figure.

(2) Then tighten all bolts to 7 to 10 N·m (0.7 to 1.0 kg-m, 5.1 to 7.2 ft-lb) in order shown in figure.

9. Install any parts removed.

ENGINE REMOVAL




ENGINE REMOVAL

WARNING:

- a. Situate vehicle on a flat and solid surface.
- b. Do not remove engine until exhaust system has completely cooled off.
Otherwise, you may burn yourself and/or fire may break out in fuel line.
- c. For safety during subsequent steps, the tension of wires should be slackened against the engine.
- d. Before disconnecting fuel hose, release fuel pressure from fuel line.
Refer to "Releasing Fuel Pressure" in section EF & EC.
- e. Before removing front axle from transaxle, place safety stands under designated front supporting points. Refer to GI section for lifting points and towing.
- f. Be sure to hoist engine and transaxle in a safe manner.
- g. For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.

CAUTION:


- When lifting engine, be careful not to strike adjacent parts, especially accelerator wire casing, brake lines, and brake master cylinder.
- In hoisting the engine, always use engine slingers in a safe manner.
- In removing drive shaft, be careful not to damage grease seal of transaxle.



Removal


1. Drain coolant.
2. Disconnect adjacent wires, harness, pipes and hoses.
3. Remove the following parts:
 - Drive belts
 - Power steering pump
 - A/C compressor
 - Alternator and adjusting bar
 - Drive shafts
 - Front exhaust tube
4. Lift up engine slightly with engine slingers and disconnect or remove all engine mountings.
5. Support engine and transaxle assembly by placing suitable jacks under oil pan and transaxle.
6. Lower engine and transaxle assembly.
7. Remove engine from transaxle.

CYLINDER BLOCK



SEM564C




CYLINDER BLOCK



Disassembly

PISTON AND CRANKSHAFT

1. Place engine on a work stand.
2. Drain oil.
3. Remove oil pan.
4. Remove water pump.
5. Remove cylinder head.
6. Remove timing chain.
7. Remove pistons.
 - When disassembling piston and connecting rod, remove snap rings, then heat piston to 60 to 70°C (140 to 158°F) or use piston pin press stand at room temperature.




8. Remove main bearing beam and crankshaft.
 - Before removing main bearing beam, measure crankshaft end play.
 - Bolts should be loosened in two or three steps.

Inspection

PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".
Standard diameter "dp":
20.987 - 20.999 mm (0.8263 - 0.8267 in)



CYLINDER BLOCK

Inspection (Cont'd)

2. Measure outer diameter of piston pin "Dp".



Standard diameter "Dp":

20.989 - 21.001 mm (0.8263 - 0.8268 in)

3. Calculate interference fit of piston pin to piston.

$dp - Dp = 0 - 0.004 \text{ mm (0 - 0.0002 in)}$

If it exceeds the above value, replace piston assembly with pin.



PISTON RING SIDE CLEARANCE

Side clearance:

Top ring

0.04 - 0.08 mm (0.0016 - 0.0031 in)


2nd ring

0.03 - 0.07 mm (0.0012 - 0.0028 in)

Max. limit of side clearance:

0.1 mm (0.004 in)

If out of specification, replace piston and/or piston ring assembly.



PISTON RING END GAP

End gap:

Top ring

0.28 - 0.52 mm (0.0110 - 0.0205 in)

2nd ring

0.45 - 0.69 mm (0.0177 - 0.0272 in)

(For rings punched with R or T.)

0.55 - 0.70 mm (0.0217 - 0.0276 in)

(For rings punched with N.)

Oil ring


0.20 - 0.69 mm (0.0079 - 0.0272 in)

Max. limit of ring gap:

0.5 mm (0.020 in)

If out of specification, replace piston ring. If gap still exceeds the limit even with a new ring, rebore cylinder and use oversized piston and piston rings.

Refer to S.D.S.



CONNECTING ROD BEND AND TORSION

Bend:

Limit 0.15 mm (0.0059 in)

per 100 mm (3.94 in) length

Torsion:

Limit 0.30 mm (0.0118 in)

per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.

CYLINDER BLOCK

Inspection (Cont'd)

CYLINDER BLOCK DISTORTION AND WEAR

1. Clean upper face of cylinder block and measure the distortion.

Limit:

0.10 mm (0.0039 in)

2. If out of specification, resurface it.

The resurfacing limit is determined by cylinder head resurfacing in engine.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:



$A + B = 0.2 \text{ mm (0.008 in)}$

Nominal cylinder block height

from crankshaft center:

246.95 - 247.05 mm (9.7224 - 9.7264 in)

3. If necessary, replace cylinder block.



PISTON-TO-BORE CLEARANCE

1. Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

Standard inner diameter:

89.000 - 89.030 mm (3.5039 - 3.5051 in)

Wear limit:

0.2 mm (0.008 in)

Out-of-round (X - Y) limit:


0.015 mm (0.0006 in)

Taper (A - B) limit:

0.015 mm (0.0006 in)

If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.


2. Check for scratches and seizure. If seizure is found, hone it.



- If both cylinder block and piston are replaced with new ones, select piston of the same grade number punched on cylinder block upper surface.

CYLINDER BLOCK

Inspection (Cont'd)



3. Measure piston skirt diameter.
Piston diameter "A":
Refer to S.D.S.
Measuring point "a" (Distance from the top):
Approximately 52 mm (2.05 in)
4. Check that piston-to-bore clearance is within specification.
Piston-to-bore clearance "B":
0.020 - 0.040 mm (0.0008 - 0.0016 in)

5. Determine piston oversize according to amount of cylinder wear.

Oversize pistons are available for service. Refer to S.D.S.

6. Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation:

$$D = A + B - C$$

where,


D: Bored diameter

A: Piston diameter as measured

B: Piston-to-bore clearance

C: Honing allowance 0.02 mm (0.0008 in)

7. Install main bearing caps, and tighten to the specified torque to prevent distortion of cylinder bores in final assembly.
8. Cut cylinder bores.
 - **When any cylinder needs boring, all other cylinders must also be bored.**
 - **Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.**
9. Hone cylinders to obtain specified piston-to-bore clearance.
10. Measure finished cylinder bore for out-of-round and taper.
 - **Measurement should be done after cylinder bore cools down.**



CRANKSHAFT

1. Check crankshaft main and pin journals for score, wear or cracks.
2. With a micrometer, measure journals for taper and out-of-round.

Out-of-round (X - Y):

Main journal Less than 0.01 mm (0.0004 in)

Crank pin Less than 0.005 mm (0.0002 in)

Taper (A - B):

Main journal Less than 0.01 mm (0.0004 in)


Crank pin Less than 0.005 mm (0.0002 in)

CYLINDER BLOCK

Inspection (Cont'd)

3. Measure crankshaft runout.

Runout (Total indicator reading):
Less than 0.10 mm (0.0039 in)






BEARING CLEARANCE

Either of the following two methods may be used, however, method "A" gives more reliable results and is preferred.

Method A (Using bore gauge and micrometer)

Main bearing


1. Set main bearings in their proper positions on cylinder block and main bearing cap.
2. Install main bearing cap to cylinder block.
3. Measure inner diameter "A" of each main bearing.




4. Measure outer diameter "Dm" of each crankshaft main journal.
5. Calculate main bearing clearance.
Main bearing clearance = A - Dm
Standard:
0.020 - 0.047 mm (0.0008 - 0.0019 in)
Limit:
0.1 mm (0.004 in)
6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing.

CYLINDER BLOCK

Inspection (Cont'd)




- a. When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.
"L": 0.1 mm (0.004 in)
- b. Refer to S.D.S. for grinding crankshaft and available service parts.



8. If crankshaft, is reused, measure main bearing clearance and thickness of main bearing.
If crankshaft is replaced with a new one, it is necessary to select thickness of main bearings as follows:

- a. Grade number of each cylinder block main journal is punched on the respective cylinder block.



- b. Grade number of each crankshaft main journal is punched on crankshaft.

- c. Select main bearing with suitable thickness according to the following table.

Main bearing grade number:

Main journal grade number Crankshaft journal grade number	Main journal grade number		
	0	1	2
0	0	1	2
1	1	2	3
2	2	3	4

For example:

Main journal grade number: 1

Crankshaft journal grade number: 2

Main bearing grade number = 1 + 2 = 3

CYLINDER BLOCK



Inspection (Cont'd)

Connecting rod bearing (Big end)

1. Install connecting rod bearing to connecting rod and cap.
2. Install connecting rod cap to connecting rod.

Tighten bolts to the specified torque.

3. Measure inner diameter "C" of each bearing.



4. Measure outer diameter "Dp" of each crankshaft pin journal.

5. Calculate connecting rod bearing clearance.

$$\text{Connecting rod bearing clearance} = C - Dp$$

Standard:


0.010 - 0.035 mm (0.0004 - 0.0014 in)

Limit:

0.09 mm (0.0035 in)

6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing.

Refer to step 7 of "BEARING CLEARANCE — Main bearing".



8. If crankshaft is replaced with a new one, select connecting rod bearing according to the following table.


Connecting rod bearing grade number:

Crank pin grade number	Connecting rod bearing grade number
0	0
1	1
2	2

Method B (Using plastigage)

CAUTION:

- Do not turn crankshaft or connecting rod while plastigage is being inserted.
- When bearing clearance exceeds the specified limit, ensure that the proper bearing has been installed. Then if excessive bearing clearance exists, use a thicker main bearing or undersized bearing so that the specified bearing clearance is obtained.




CYLINDER BLOCK

Inspection (Cont'd)

CONNECTING ROD BUSHING CLEARANCE (Small end)

1. Measure inner diameter "C" of bushing.




2. Measure outer diameter "Dp" of piston pin.
3. Calculate connecting rod bearing clearance.

$$C - Dp =$$

0.005 - 0.017 mm (0.0002 - 0.0007 in) (Standard)

0.023 mm (0.0009 in) (Limit)

If it exceeds the limit, replace connecting rod assembly and/or piston set with pin.



REPLACEMENT OF CONNECTING ROD BUSHING (Small end)


1. Drive in small end bushing until it is flush with end surface of rod.

Be sure to align the oil holes.

2. After driving in small end bushing, ream the bushing so that clearance between small end bushing and piston pin is specified value.

Clearance between small end bushing and piston pin:

0.005 - 0.017 mm (0.0002 - 0.0007 in)



FLYWHEEL/DRIVE PLATE RUNOUT


Runout (Total indicator reading):

Flywheel (M/T model)

Less than 0.1 mm (0.004 in)

Drive plate (A/T model)


Less than 0.1 mm (0.004 in)



Assembly




PISTON

1. Install new snap ring on one side of piston pin hole.



CYLINDER BLOCK

Assembly (Cont'd)





2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin, connecting rod and new snap ring.

- Align the direction of piston and connecting rod.
- Numbers stamped on connecting rod and cap correspond to each cylinder.
- After assembly, make sure connecting rod swings smoothly.

3. Set piston rings as shown.

CAUTION:

- When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
- When piston rings are being replaced and no punchmark is present, piston rings can be mounted with either side up.




CRANKSHAFT

1. Set main bearings in their proper positions on cylinder block and main bearing beam.


- Confirm that correct main bearings are used. Refer to "Inspection" of this section.

CYLINDER BLOCK

Assembly (Cont'd)



2. Install crankshaft and main bearing beam and tighten bolts to the specified torque.
 - Prior to tightening bearing cap bolts, place bearing cap in its proper position by shifting crankshaft in the axial direction.
 - Tighten bearing cap bolts gradually in two or three stages. Start with center bearing and move outward sequentially.
 - After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.




3. Measure crankshaft end play.

Crankshaft end play:

Standard
0.05 - 0.18 mm (0.0020 - 0.0071 in)

Limit
0.3 mm (0.012 in)


If beyond the limit, replace bearing with a new one.




4. Install connecting rod bearings in connecting rods and connecting rod caps.
 - Confirm that correct bearings are used.

Refer to "Inspection".

 - Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.



5. Install pistons with connecting rods.
 - a. Install them into corresponding cylinders with Tool.
 - Be careful not to scratch cylinder wall by connecting rod.
 - Arrange so that front mark on piston head faces toward front of engine.



- b. Install connecting rod bearing caps. Tighten connecting rod bearing cap nuts to the specified torque.

Connecting rod bearing nut:

 - (1) Tighten to 14 to 16 N·m (1.4 to 1.6 kg-m, 10 to 12 ft-lb).
 - (2) Tighten bolts 60 to 65 degrees clockwise with an angle wrench, or if an angle wrench is not available, tighten them to 38 to 44 N·m (3.9 to 4.5 kg-m, 28 to 33 ft-lb).

CYLINDER BLOCK

Assembly (Cont'd)

6. Measure connecting rod side clearance.

Connecting rod side clearance:



Standard

0.2 - 0.4 mm (0.008 - 0.016 in)

Limit

0.6 mm (0.024 in)


If beyond the limit, replace connecting rod and/or crankshaft.



REPLACING PILOT BUSHING

1. Remove pilot bushing (M/T) or pilot converter (A/T).

2. Install pilot bushing (M/T) or pilot converter (A/T).



General Specifications


Engine model	KA24E
Cylinder arrangement	4, in-line
Displacement	cm ³ (cu in) 2,389 (145.78)
Bore x stroke	mm (in) 89 x 96 (3.50 x 3.78)
Valve arrangement	O.H.C.
Firing order	1-3-4-2
Number of piston rings	
Compression	2
Oil	1
Number of main bearings	5
Compression ratio	8.6

Unit: kPa (kg/cm², psi)/rpm

Compression pressure	
Standard	1,206 (12.3, 175)/250
Minimum	1,010 (10.3, 146)/250
Differential limit between cylinders	98 (1.0, 14)/250

Inspection and Adjustment

CYLINDER BLOCK



SEM447C

Unit: mm (in)

			Standard	Limit
Distortion			—	0.1 (0.004)
Cylinder bore	Inner diameter	Grade 1	89.000 - 89.010 (3.5039 - 3.5043)	0.2 (0.008)*
		Grade 2	89.010 - 89.020 (3.5043 - 3.5047)	
		Grade 3	89.020 - 89.030 (3.5047 - 3.5051)	
	Out-of-round (X – Y)		Less than 0.015 (0.0006)	—
	Taper (A – B)		Less than 0.010 (0.0004)	—
Difference in inner diameter between cylinders			Less than 0.05 (0.0020)	0.2 (0.008)
Piston-to-cylinder clearance			0.020 - 0.040 (0.0008 - 0.0016)	—
Cylinder block height (From crankshaft center)			246.95 - 247.05 (9.7224 - 9.7264)	0.2 (0.008)**

* Wear limit

** Total amount of cylinder head resurfacing and cylinder block resurfacing

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)



CYLINDER HEAD

Unit: mm (in)

	Standard	Limit
Height (H)	98.8 - 99.0 (3.890 - 3.898)	0.2 (0.008)*
Surface distortion	0.03 (0.0012)	0.1 (0.004)

* Total amount of cylinder head resurfacing and cylinder block resurfacing

VALVE GUIDE



SEM225C

SEM571B


Unit: mm (in)

	Standard		Service		Limit
	Intake	Exhaust	Intake	Exhaust	
Length (L)	52.6 (2.071)	56.0 (2.205)	52.6 (2.071)	56.0 (2.205)	—
Outer diameter (D)	11.023 - 11.034 (0.4340 - 0.4344)	12.023 - 12.034 (0.4733 - 0.4738)	11.223 - 11.234 (0.4418 - 0.4423)	12.223 - 12.234 (0.4812 - 0.4817)	—
Inner diameter (d) (Finished size)	7.000 - 7.018 (0.2756 - 0.2763)	8.000 - 8.018 (0.3150 - 0.3157)	7.000 - 7.018 (0.2756 - 0.2763)	8.000 - 8.018 (0.3150 - 0.3157)	—
Cylinder head hole diameter	10.975 - 10.996 (0.4321 - 0.4329)	11.975 - 11.996 (0.4715 - 0.4723)	11.175 - 11.196 (0.4400 - 0.4408)	12.175 - 12.196 (0.4793 - 0.4802)	—
Interference fit	0.027 - 0.059 (0.0011 - 0.0023)				—
Stem to guide clearance	0.020 - 0.053 (0.0008 - 0.0021)	0.040 - 0.070 (0.0016 - 0.0028)	0.020 - 0.053 (0.0008 - 0.0021)	0.040 - 0.070 (0.0016 - 0.0028)	0.1 (0.004)
Tapping length (ℓ)	14.9 - 15.1 (0.587 - 0.594)				—


SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

Standard



Service



SEM177

SEM178

Unit: mm (in)


	Standard		Service	
	Intake	Exhaust	Intake	Exhaust
Cylinder head seat recess diameter	36.000 - 36.016 (1.4173 - 1.4179)	42.000 - 42.016 (1.6535 - 1.6542)	36.500 - 36.516 (1.4370 - 1.4376)	42.500 - 42.516 (1.6732 - 1.6739)
Valve seat outer diameter (D ₁)	36.080 - 36.096 (1.4205 - 1.4211)	42.080 - 42.096 (1.6567 - 1.6573)	36.580 - 36.596 (1.4402 - 1.4408)	42.580 - 42.596 (1.6764 - 1.6770)
Face angle (α)	45°	45°	45°	45°
Contacting width (W)	1.6 - 1.7 (0.063 - 0.067)	1.7 - 2.1 (0.067 - 0.083)	1.6 - 1.7 (0.063 - 0.067)	1.7 - 2.1 (0.067 - 0.083)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

VALVE

T (Margin thickness)



SEM188A

Unit: mm (in)

		Standard	Limit
Valve head diameter (D)	In.	34.0 - 34.2 (1.339 - 1.346)	—
	Ex.	40.0 - 40.2 (1.575 - 1.583)	—
Valve length (L)	In.	119.9 - 120.2 (4.720 - 4.732)	—
	Ex.	120.67 - 120.97 (4.7508 - 4.7626)	—
Valve stem diameter (d)	In.	6.965 - 6.980 (0.2742 - 0.2748)	—
	Ex.	7.948 - 7.960 (0.3129 - 0.3134)	—
Valve face angle (α)	In.	45°30'	—
	Ex.	45°30'	—
Valve head margin (T)	In.	1.15 - 1.45 (0.0453 - 0.0571)	0.5 (0.020)
	Ex.	1.35 - 1.65 (0.0531 - 0.0650)	

VALVE SPRING


Unit: mm (in)

		Standard		Limit	
		Intake	Exhaust	Intake	Exhaust
Free height (H)	Outer	57.44 (2.2614)	53.21 (2.0949)	—	—
	Inner	53.34 (2.1000)	47.95 (1.8878)	—	—
Pressure N (kg, lb) at height	Outer	604.1 (61.6, 135.8) at 37.6 (1.480)	640.4 (65.3, 144.0) at 34.1 (1.343)	567.8 (57.9, 127.7) at 37.6 (1.480)	620.8 (63.3, 139.6) at 34.1 (1.343)
	Inner	284.4 (29.0, 63.9) at 32.6 (1.283)	328.5 (33.5, 73.9) at 29.1 (1.146)	266.8 (27.2, 60.0) at 32.6 (1.283)	318.7 (32.5, 71.7) at 29.1 (1.146)
Out-of-square	Outer	—	—	2.5 (0.098)	2.3 (0.091)
	Inner	—	—	2.3 (0.091)	2.1 (0.083)


SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

CAMSHAFT AND CAMSHAFT BEARING



SEM568A



EM120

Unit: mm (in)

		Standard	Limit
Cam height (A)		44.839 - 45.029 (1.7653 - 1.7728)	—
Valve lift (h)		10.4 (0.409)	—
Wear limit of cam height		—	0.2 (0.008)
Camshaft journal to bearing clearance		0.045 - 0.090 (0.0018 - 0.0035)	0.12 (0.0047)
Inner diameter of camshaft bearing		33.000 - 33.025 (1.2992 - 1.3002)	—
Outer diameter of camshaft journal (D)		32.935 - 32.955 (1.2967 - 1.2974)	—
Camshaft runout		0 - 0.02 (0 - 0.0008)	—
Camshaft end play		0.07 - 0.15 (0.0028 - 0.0059)	0.2 (0.008)
Valve timing (Degree on crankshaft)	a	248	—
	b	240	—
	c	3	—
	d	57	—
	e	12	—
	f	56	—

ROCKER ARM AND ROCKER SHAFT

Unit: mm (in)

Rocker arm to shaft clearance	0.012 - 0.050 (0.0005 - 0.0020)
Rocker shaft diameter	21.979 - 22.000 (0.8653 - 0.8661)
Rocker arm rocker shaft hole diameter	22.012 - 22.029 (0.8666 - 0.8673)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)


Inspection and Adjustment (Cont'd)

PISTON, PISTON RING AND PISTON PIN

Piston ring

Piston

Unit: mm (in)



SEM444C

Unit: mm (in)


Piston skirt diameter (A)	Standard	Grade No. 1	88.970 - 88.980 (3.5027 - 3.5031)
		Grade No. 2	88.980 - 88.990 (3.5031 - 3.5035)
		Grade No. 3	88.990 - 89.000 (3.5035 - 3.5039)
	Service (Oversize)	0.5 (0.020)	89.470 - 89.500 (3.5224 - 3.5236)
		1.0 (0.039)	89.970 - 90.000 (3.5421 - 3.5433)
Dimensions (a)		Approximately 52 (2.05)	
Piston pin hole diameter (d)		20.987 - 20.999 (0.8263 - 0.8267)	
Piston-to-cylinder bore clearance		0.020 - 0.040 (0.0008 - 0.0016)	

		Standard	Limit
Side clearance	Top	0.040 - 0.080 (0.0016 - 0.0031)	0.1 (0.004)
	2nd	0.030 - 0.070 (0.0012 - 0.0028)	0.1 (0.004)
Ring gap	Top	0.28 - 0.52 (0.0110 - 0.0205)	0.5 (0.020)
	2nd	0.45 - 0.69 (0.0177 - 0.0272)*1	0.5 (0.020)
		0.55 - 0.70 (0.0217 - 0.0276)*2	
	Oil (rail ring)	0.20 - 0.69 (0.0079 - 0.0272)	0.5 (0.020)

*1: For rings punched with R or T.

*2: For rings punched with N.

CONNECTING ROD



SEM570A

Unit: mm (in)

Piston pin

Unit: mm (in)

	Standard	Limit
Piston pin outer diameter	20.989 - 21.001 (0.8263 - 0.8268)	—
Interference fit of piston pin to piston pin hole	0 - 0.004 (0 - 0.0002)	—
Piston pin to connecting rod bearing clearance	0.005 - 0.017 (0.0002 - 0.0007)	0.023 (0.0009)


	Standard	Limit
Center distance (S)	164.95 - 165.05 (6.4941 - 6.4980)	—
Bend [per 100 mm (3.94 in)]	—	0.15 (0.0059)
Torsion [per 100 mm (3.94 in)]	—	0.3 (0.012)
Piston pin bushing inner diameter (d)*	21.000 - 21.012 (0.8268 - 0.8272)	—
Connecting rod big end inner diameter (D)*	53.000 - 53.013 (2.0866 - 2.0871)	—
Side clearance	0.2 - 0.4 (0.008 - 0.016)	0.6 (0.024)

* Without bearing


SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

CRANKSHAFT



SEM394



EM715

Unit: mm (in)

Main journal diameter (Dm)	Grade	No. 0	59.967 - 59.975 (2.3609 - 2.3612)	
		No. 1	59.959 - 59.967 (2.3606 - 2.3609)	
		No. 2	59.951 - 59.959 (2.3603 - 2.3606)	
Pin journal diameter (Dp)	Grade	No. 0	46.968 - 49.974 (1.8491 - 1.9675)	
		No. 1	49.962 - 49.968 (1.9670 - 1.9672)	
		No. 2	49.956 - 49.962 (1.9668 - 1.9670)	
Center distance (r)		47.97 - 48.03 (1.8886 - 1.8909)		
		Standard	Limit	
Taper of journal and pin [(A) - (B)]	Journal	—	0.01 (0.0004)	
	Pin	—	0.005 (0.0002)	
Out-of-round of journal and pin [(X) - (Y)]	Journal	—	0.01 (0.0004)	
	Pin	—	0.005 (0.0002)	
Runout [T.I.R.]*		—	0.10 (0.0039)	
Free end play		0.05 - 0.18 (0.0020 - 0.0071)	0.3 (0.012)	
Fillet roil		More than 0.1 (0.004)		

* Total indicator reading

BEARING CLEARANCE

Unit: mm (in)

	Standard	Limit
Main bearing clearance	0.020 - 0.047 (0.0008 - 0.0019)	0.1 (0.004)
Connecting rod bearing clearance	0.010 - 0.035 (0.0004 - 0.0014)	0.09 (0.0035)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

AVAILABLE MAIN BEARING

Standard

Grade number	Thickness mm (in)	Identification color
0	1.821 - 1.825 (0.0717 - 0.0719)	Black
1	1.825 - 1.829 (0.0719 - 0.0720)	Brown
2	1.829 - 1.833 (0.0720 - 0.0722)	Green
3	1.833 - 1.837 (0.0722 - 0.0723)	Yellow
4	1.837 - 1.841 (0.0723 - 0.0725)	Blue

Undersize (service)

Unit: mm (in)

	Thickness	Main journal diameter "Dm"
0.25 (0.0098)	1.952 - 1.960 (0.0769 - 0.0772)	Grind so that bearing clearance is the specified value.

AVAILABLE CONNECTING ROD BEARING

Standard

Grade number	Thickness mm (in)	Identification color
0	1.505 - 1.508 (0.0593 - 0.0594)	—
1	1.508 - 1.511 (0.0594 - 0.0595)	Brown
2	1.511 - 1.514 (0.0595 - 0.0596)	Green

Undersize (service)

Unit: mm (in)

	Thickness	Crank pin journal diameter "Dp"
0.08 (0.0031)	1.540 - 1.548 (0.0606 - 0.0609)	Grind so that bearing clearance is the specified value.
0.12 (0.0047)	1.560 - 1.568 (0.0614 - 0.0617)	
0.25 (0.0098)	1.625 - 1.633 (0.0640 - 0.0643)	

MISCELLANEOUS COMPONENTS

Unit: mm (in)

Camshaft sprocket runout [T.I.R.]*	Less than 0.12 (0.0047)
Flywheel runout [T.I.R.]*	Less than 0.1 (0.004)
Drive plate runout [T.I.R.]*	Less than 0.1 (0.004)

* Total indicator reading

ENGINE LUBRICATION & COOLING SYSTEMS

SECTION **LC**







CONTENTS


PREPARATION AND PRECAUTIONS	LC- 2
ENGINE LUBRICATION SYSTEM	LC- 3
ENGINE COOLING SYSTEM	LC- 6
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	LC-10

PREPARATION AND PRECAUTIONS

Preparation

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
ST25051001 (J25695-1) Oil pressure gauge	
ST25052000 (J25695-2) Hose	
WS39930000 (—) Tube presser	
EG17650301 (—) Radiator cap tester adapter	




Precautions

LIQUID GASKET APPLICATION PROCEDURE

- Before applying liquid gasket, use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves, and then completely clean any oil stains from these portions.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) wide (in areas except oil pan).
- Apply liquid gasket to inner surface around hole perimeter area.
(Assembly should be done within 5 minutes after coating.)
- Wait at least 30 minutes before refilling engine oil and engine coolant.

ENGINE LUBRICATION SYSTEM


Lubrication Circuit



Oil Pressure Check

WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
- Oil pressure check should be done in "Neutral" gear position.



1. Check oil level.
2. Remove oil pressure switch.

ENGINE LUBRICATION SYSTEM

Oil Pressure Check (Cont'd)

3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Engine rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000	412 - 481 (4.2 - 4.9, 60 - 70)

If difference is extreme, check oil passage and oil pump for oil leaks.


6. Install oil pressure switch with sealant.

Oil Pump

REMOVAL

1. Drain oil.
2. Remove front cover. (Refer to EM section.)
3. Remove oil pump assembly.

DISASSEMBLY AND ASSEMBLY



- Always replace with new oil seal and gasket.
- When installing oil pump, apply engine oil to inner and outer gears.
- Be sure that O-ring is properly installed.

ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)

INSPECTION


Using a feeler gauge, check the following clearances:

Standard clearance:


Unit: mm (in)

Body to outer gear clearance ①	0.11 - 0.20 (0.0043 - 0.0079)
Inner gear to crescent clearance ②	0.22 - 0.33 (0.0087 - 0.0130)
Outer gear to crescent clearance ③	0.21 - 0.32 (0.0083 - 0.0126)
Housing to inner gear clearance ④	0.05 - 0.09 (0.0020 - 0.0035)
Housing to outer gear clearance ⑤	0.05 - 0.11 (0.0020 - 0.0043)


If any clearance exceeds the limit, replace gear set or entire oil pump assembly.



SLC309A



SLC310A




SLC295

REGULATOR VALVE INSPECTION

1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil and check to make sure that it falls smoothly into the valve hole by its own weight.

If damaged, replace regulator valve set or oil pump assembly.



SLC185A


OIL PRESSURE RELIEF VALVE INSPECTION

Inspect oil pressure relief valve for movement, cracks and breaks by pushing the ball. If replacement is necessary, remove valve by prying it out with a suitable tool.

Install a new valve by tapping it in place.

ENGINE COOLING SYSTEM

Cooling Circuit



System Check

WARNING:

Never remove the radiator cap when the engine is hot; serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around the cap and carefully remove by turning it a quarter turn to allow built-up pressure to escape. Then continue to turn the cap until it can be removed safely.

CHECKING COOLING SYSTEM HOSES

Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

ENGINE COOLING SYSTEM

System Check (Cont'd)

CHECKING COOLING SYSTEM FOR LEAKS


To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure:

98 kPa (1.0 kg/cm², 14 psi)

CAUTION:

Higher than the specified pressure may cause radiator damage.




CHECKING RADIATOR CAP

To check radiator cap, apply pressure to cap with a tester.

Radiator cap relief pressure:



78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)



Water Pump

REMOVAL AND INSTALLATION

Drain coolant from drain cocks on both cylinder block and radiator.




ENGINE COOLING SYSTEM

Water Pump (Cont'd)

CAUTION:

- When removing water pump assembly, be careful not to get coolant on timing belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- To avoid damaging timing cover, make sure there is adequate clearance between it and the hose clamp.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.




INSPECTION

1. Check for badly rusted or corroded vanes and body assembly.
2. Check for rough operation due to excessive end play.

Thermostat

INSPECTION

1. Check valve seating condition at ordinary room temperatures. It should seat tightly.



2. Check valve opening temperature and maximum valve lift.


		Standard
Valve opening temperature	°C (°F)	76.5 (170)
Maximum valve lift	mm/°C (in/°F)	8/90 (0.31/194)

3. Then check if valve is 5°C (9°F) below valve opening temperature.
- After installation, run engine for a few minutes, and check for leaks.
 - Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

ENGINE COOLING SYSTEM

Radiator

REMOVAL AND INSTALLATION



Electric Cooling Fan Control System

Radiator fan and condenser fan are both controlled by E.C.C.S. control unit.

For details, refer to EF & EC section.


SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Engine Lubrication System

Oil pressure check

Engine rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000	412 - 481 (4.2 - 4.9, 60 - 70)

Oil pump



Unit: mm (in)

Height	H ₁	H ₂
	11.5 (0.453)	17.25 (0.6791)

Unit: mm (in)

Body to outer gear clearance ①	0.11 - 0.20 (0.0043 - 0.0079)
Inner gear to crescent clearance ②	0.22 - 0.33 (0.0087 - 0.0130)
Outer gear to crescent clearance ③	0.21 - 0.32 (0.0083 - 0.0126)
Housing to inner gear side clearance ④	0.05 - 0.09 (0.0020 - 0.0035)
Housing to outer gear side clearance ⑤	0.05 - 0.11 (0.0020 - 0.0043)

Engine Cooling System

Thermostat

	Standard
Valve opening temperature °C (°F)	76.5 (170)
Maximum valve lift mm/°C (in/°F)	8/90 (0.31/194)

Radiator

Unit: kPa (kg/cm², psi)

Cap relief pressure	78 - 98 (0.8 - 1.0, 11 - 14)
Leakage test pressure	98 (1.0, 14)

ENGINE FUEL & EMISSION CONTROL SYSTEM

SECTION **EF & EC**

EF & EC

CONTENTS

PREPARATION	EF & EC- 2
PRECAUTIONS	EF & EC- 3
ENGINE AND EMISSION CONTROL OVERALL SYSTEM	EF & EC- 4
ENGINE AND EMISSION CONTROL PARTS DESCRIPTION	EF & EC- 12
ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION	EF & EC- 18
IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION	EF & EC- 29
TROUBLE DIAGNOSES	EF & EC- 34
FUEL INJECTION CONTROL SYSTEM INSPECTION	EF & EC-179
EVAPORATIVE EMISSION CONTROL SYSTEM	EF & EC-182
CRANKCASE EMISSION CONTROL SYSTEM	EF & EC-184
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	EF & EC-185


When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

PREPARATION

SPECIAL SERVICE TOOL


Tool number (Kent-Moore No.) Tool name	Description
EG11160000 (—) Ignition coil adapter harness	 Measuring engine speed

PRECAUTIONS

E.C.U.


- Do not disassemble E.C.C.S. control unit. (E.C.U.)
- Do not turn diagnosis mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ROM value. The E.C.C.S. will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

- Do not apply undue force to mounting bracket.
- Before connecting or disconnecting E.C.U. connector, make sure red and green LEDs are off after turning ignition key off.
- Always install the properly specified E.C.U. on car; otherwise, erroneous engine operation may result.




INJECTOR

- Do not disconnect injector harness connectors with engine running.
- Do not apply battery power directly to injectors; otherwise injectors will be damaged.




WIRELESS EQUIPMENT

- When installing a C.B. ham radio or a mobile phone, be sure to observe the following, as installation location may affect the electronic control systems.
- 1) Keep antenna as far as possible away from electronic control units.
 - 2) Keep antenna feeder line more than 20 cm (7.9 in) away from harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust antenna and feeder line so that standing-wave ratio can be kept smaller.
 - 4) Be sure to ground radio to vehicle body.



FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.



E.C.C.S. PARTS HANDLING

- Handle air flow meter carefully to avoid damage.
- Do not disassemble air flow meter.
- Do not clean air flow meter with detergent.
- Do not jolt or jar the crank angle sensor.
- Even a slight leak in the air intake system can cause serious problems.
- Do not disassemble auxiliary air control valve.

BATTERY

- Always use a 12 volt battery as a power source.
- Do not disconnect battery cables while the engine is running.
- Do not reverse polarity of battery when connecting it. Otherwise, E.C.U. and/or injectors may be burned.



E.C.C.S. HARNESS HANDLING


- Securely connect E.C.C.S. harness connectors. A poor connection can cause extremely high voltage to develop in the coil and condenser, resulting in damage to ICs.
- Keep E.C.C.S. harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an E.C.C.S. system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep E.C.C.S. parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.




ENGINE AND EMISSION CONTROL OVERALL SYSTEM

E.C.C.S. Component Parts Location



ENGINE AND EMISSION CONTROL OVERALL SYSTEM


E.C.C.S. Component Parts Location (Cont'd)



SEF234J


ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Diagram




SEF405J

ENGINE AND EMISSION CONTROL OVERALL SYSTEM



ENGINE AND EMISSION CONTROL OVERALL SYSTEM


Vacuum Hose Drawing



SEF412J


ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram




Wiring Diagram (Cont'd)





E.C.C.S. Control Unit (E.C.U.)

The E.C.U. consists of a microcomputer, inspection lamps, a diagnostic mode selector, and connectors for signal input and output and for power supply. The unit controls the engine.





Crank Angle Sensor

The crank angle sensor is a basic component of the entire E.C.C.S. It monitors engine speed and piston position, and sends signals to the E.C.U. to control fuel injection, ignition timing and other functions.

The crank angle sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 4 slits for 180° signal. Light Emitting Diodes (L.E.D.) and photo diodes are built in the wave-forming circuit.


When the rotor plate passes between the L.E.D. and the photo diode, the slits in the rotor plate continually cut the light being transmitted to the photo diode from the L.E.D. This generates rough-shaped pulses which are converted into on-off signals by the wave-forming circuit, which are then sent to the E.C.U.




Air Flow Meter

The air flow meter measures the mass flow rate of intake air. Measurements are made so that the control circuit will emit an electrical output signal corresponding to the amount of heat dissipated from a hot wire placed in the stream of intake air.

The airflow past the hot wire removes the heat from the hot wire. The temperature of the hot wire is very sensitive to the mass flow rate. The higher the temperature of the hot wire, the greater its resistance value. This temperature change (resistance) is determined by the mass air flow rate. The control circuit accurately regulates current (I) in relation to the varying resistance value (R_H) so that V_A always equals V_B . The air flow meter transmits a voltage value V_A to the control unit where the output is converted into an intake air signal.






Engine Temperature Sensor

The engine temperature sensor detects the engine temperature, which is dependent on engine coolant temperature, and transmits a signal to the E.C.U.



The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



Throttle Sensor & Soft/Hard Idle Switch

The throttle sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle valve position into output voltage, and emits the voltage signal to the E.C.U. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the E.C.U.


Idle position of the throttle valve is determined by the E.C.U. receiving the signal from the throttle sensor. This system is called "soft idle switch" and controls engine operation such as fuel cut. On the other hand, "hard idle switch", which is built in the throttle sensor unit, is used not for engine control but for self-diagnosis.



Fuel Injector


The fuel injector is a small, elaborate solenoid valve. As the E.C.U. sends injection signals to the injector, the coil in the injector pulls the needle valve back and fuel is released into the intake manifold through the nozzle. The injected fuel is controlled by the E.C.U. in terms of injection pulse duration.

Brass wire is used in the injector coil and thus the resistance is higher than a conventional injector.





Pressure Regulator

The pressure regulator maintains the fuel pressure at 299.1 kPa (3.05 kg/cm², 43.4 psi). Since the injected fuel amount depends on injection pulse duration, it is necessary to maintain the pressure at the above value.




Exhaust Gas Sensor

The exhaust gas sensor, which is placed into the exhaust manifold, monitors the amount of oxygen in the exhaust gas. The sensor has a closed-end tube made of ceramic zirconia. The outer surface of the tube is exposed to exhaust gas, and the inner surface to atmosphere. The zirconia of the tube compares the oxygen density of exhaust gas with that of atmosphere, and generates electricity. In order to improve the generating power of the zirconia, its tube is coated with platinum. The voltage is approximately 1V in a richer condition of the mixture ratio than the ideal air-fuel ratio, while approximately 0V in leaner conditions. The radical change from 1V to 0V occurs at around the ideal mixture ratio. In this way, the exhaust gas sensor detects the amount of oxygen in the exhaust gas and sends the signal of approximately 1V or 0V to the E.C.U.




Fuel Pump

The fuel pump with a fuel damper is a submergible type, and are located in the fuel tank.



Power Transistor


The ignition signal from the E.C.U. is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit. The ignition coil is a small, molded type.



Idle Air Adjusting (I.A.A.) Unit

The I.A.A. unit is made up of the A.A.C. valve and air cut valve. It receives the signal from the E.C.U. and controls the idle speed at the preset value under various conditions.


The air cut valve prevents an abnormal rise of idle rpm when A.A.C. valve operates abnormally.



Auxiliary Air Control (A.A.C.) Valve


The E.C.U. actuates the A.A.C. valve by an ON/OFF pulse. The longer that ON pulse is received, the larger the amount of air that will flow through the A.A.C. valve.

This air flow also varies with the temperature of the engine coolant flowing through the A.A.C. valve. The higher the coolant temperature, the less the amount of air flow.



Power Steering Oil Pressure Switch


The power steering oil pressure switch is attached to the power steering high-pressure tube and detects the power steering load, sending the load signal to the E.C.U. The E.C.U. then sends the idle-up signal to the A.A.C. valve.



Vehicle Speed Sensor


The vehicle speed sensor provides a vehicle speed signal to the E.C.U.

The speed sensor consists of a reed switch, which is installed on the transmission unit and transforms vehicle speed into a pulse signal.




E.G.R. Control Valve

The E.G.R. control valve controls the quantity of exhaust gas to be led to the intake manifold through vertical movement of the taper valve connected to the diaphragm, to which vacuum is applied in response to the opening of the throttle valve.




B.P.T. Valve

The B.P.T. valve monitors exhaust pressure to activate the diaphragm, controlling throttle chamber vacuum applied to the E.G.R. control valve. In other words, recirculated exhaust gas is controlled in response to positioning of the E.G.R. control valve or to engine operation.



Air Induction Valve (A.I.V.)

The air induction valve sends secondary air to the exhaust manifold, using a vacuum created by exhaust pulsation in the exhaust manifold. When the exhaust pressure is below atmospheric pressure (negative pressure), secondary air is sent to the exhaust manifold. When the exhaust pressure is above atmospheric pressure, the reed valves prevent secondary air from being sent back to the air cleaner.



A.I.V. Control Solenoid Valve

The A.I.V. control solenoid valve cuts the intake manifold vacuum signal for A.I.V. control. It responds to the ON/OFF signal from the E.C.U. When the solenoid is off, the vacuum signal from the intake manifold is cut. When the control unit sends an ON signal, the coil pulls the plunger downward and feeds the vacuum signal to the A.I.V. control valve.

E.G.R. Control Solenoid Valve


The E.G.R. system is controlled only by the E.C.U. At both low- and high-speed engine revolutions, the solenoid valve turns on and accordingly the E.G.R. valve cuts the exhaust gas leading to the intake manifold.

Pressure Regulator (P.R.) Control Solenoid Valve

The solenoid valve responds to the ON/OFF signal from the E.C.U. When it is off, a vacuum signal from the intake manifold is fed into the pressure regulator. When the control unit sends an ON signal, the coil pulls the plunger downward and cuts the vacuum signal.

S.C.V. Control Solenoid Valve

The S.C.V. control solenoid valve cuts the intake manifold vacuum signal for swirl control valve. It responds to the ON/OFF signal from the E.C.U. When the solenoid is off, the vacuum signal from the intake manifold is cut. When the control unit sends an ON signal the coil pulls the plunger and feeds the vacuum signal to the swirl control valve actuator.



Fuel Filter


The specially designed fuel filter has a metal case in order to withstand high fuel pressure.

Carbon Canister

The carbon canister is filled with active charcoal to absorb evaporative gases produced in the fuel tank. These absorbed gases are then delivered to the intake manifold by manifold vacuum for combustion purposes.


The vacuum in the intake passage upstream of the throttle valve increases in response to the amount of the intake air.

When the vacuum of the intake passage is higher than a preset value, the 2nd purge control valve opens and the absorbed gases are sucked into the intake passage for combustion purposes.



Exhaust Gas Temperature Sensor (For California model)

The exhaust gas temperature sensor monitors in exhaust gas temperature and transmits a signal to the E.C.U. The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electric resistance of the thermistor decreases in response to the temperature rise.




Air Temperature Sensor

The air temperature sensor controls ignition timing when the temperature of the intake air is extremely high, in order not to cause knocking.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Fuel Injection Control

INPUT/OUTPUT SIGNAL LINE



BASIC FUEL INJECTION CONTROL

The amount of fuel injected from the fuel injector, or the length of time the valve remains open, is determined by the E.C.U. The basic amount of fuel injected is a programmable value mapped in the E.C.U. ROM memory. In other words, the programmable value is preset by engine operating conditions determined by input signals (for engine rpm and air intake) from both the crank angle sensor and the air flow meter.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION


In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below:

< Fuel increase >


- 1) During warm-up
- 2) When starting the engine
- 3) During acceleration
- 4) Hot-engine operation

< Fuel decrease >

- 1) During deceleration



ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION



Fuel Injection Control (Cont'd)

MIXTURE RATIO FEEDBACK CONTROL

Mixture ratio feedback system is designed to precisely control the mixture ratio to the stoichiometric point so that the three-way catalyst can reduce CO, HC and NO_x emissions. This system uses an exhaust gas sensor in the exhaust manifold to check the air-fuel ratio. The control unit adjusts the injection pulse width according to the sensor voltage so the mixture ratio will be within the range of the stoichiometric air-fuel ratio.


This stage refers to the closed-loop control condition. The open-loop control condition refers to that under which the E.C.U. detects any of the following conditions and feedback control stops in order to maintain stabilized fuel combustion.

- 1) Deceleration
- 2) High-load, high-speed operation
- 3) Engine idling
- 4) Malfunctioning of exhaust gas sensor or its circuit
- 5) Insufficient activation of exhaust gas sensor at low engine temperature
- 6) Engine starting

MIXTURE RATIO SELF-LEARNING CONTROL


The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the exhaust gas sensor. This feedback signal is then sent to the E.C.U. to control the amount of fuel injection to provide a basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. This is due to manufacturing errors (e.g., air flow meter hot wire) and changes during operation (injector clogging, etc.) of E.C.C.S. parts which directly affect the mixture ratio.

Accordingly, a difference between the basic and theoretical mixture ratios is quantitatively monitored in this system. It is then computed in terms of "fuel injection duration" to automatically compensate for the difference between the two ratios.



FUEL INJECTION TIMING

Fuel is injected once a cycle for each cylinder in the firing order.



When engine starts, fuel is injected into all four cylinders simultaneously twice a cycle.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION


Fuel Injection Control (Cont'd)

FUEL SHUT-OFF

Fuel to all cylinders is cut off during deceleration or high-speed operation.

Ignition Timing Control

INPUT/OUTPUT SIGNAL LINE



ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Ignition Timing Control (Cont'd)

SYSTEM DESCRIPTION

The ignition timing is controlled by the E.C.U. in order to maintain the best air-fuel ratio in response to every running condition of the engine. The ignition timing data is stored in the ROM located in the E.C.U., in the form of the map shown below.


The E.C.U. detects information such as the injection pulse width and crank angle sensor signal which varies every moment. Then responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, Tp: 1.50 msec
A °B.T.D.C.

In addition to this,


- 1 At starting
- 2 During warm-up
- 3 At idle
- 4 At low battery voltage
- 5 During swirl control valve operates
- 6 During hot engine operation
- 7 At acceleration
- 8 When intake air temperature is extremely high

the ignition timing is revised by the E.C.U. according to the other data stored in the ROM.



Idle Speed Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION


This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via A.A.C. valve. The A.A.C. valve repeats ON/OFF operation according to the signal sent from the E.C.U. The crank angle sensor detects the actual engine speed and sends a signal to the E.C.U. The E.C.U.

then controls the ON/OFF time of the A.A.C. valve so that engine speed coincides with the target value memorized in ROM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ROM is determined by taking into consideration various engine conditions, such as noise and vibration transmitted to the compartment, fuel consumption, and engine load.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Fuel Pump Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

The E.C.U. activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the E.C.U. receives a 1° signal from the crank angle sensor, it knows that the engine is rotating, and causes the pump to perform. If the 1° signal is not received when the ignition switch is on, the engine stalls. The E.C.U. stops pump operation and prevents battery discharging, thereby improving safety. The E.C.U. does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1 second
Except as shown above	Stops

Air Induction Valve (A.I.V.) Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

The air induction system is designed to send secondary air to the exhaust manifold, utilizing the vacuum caused by exhaust pulsation in the exhaust manifold.

The exhaust pressure in the exhaust manifold usually pulsates in response to the opening and closing of the exhaust valve and decreases below atmospheric pressure periodically.

If a secondary air intake pipe is opened to the

atmosphere under vacuum conditions, secondary air can be drawn into the exhaust manifold in proportion to the vacuum.

The air induction valve is controlled by the E.C.C.S. control unit, corresponding to the engine temperature. When the engine is cold, the A.I.V. control system operates to reduce HC and CO.


In extremely cold conditions, A.I.V. control system does not operate to reduce after-burning. This system also operates during deceleration for the purpose of blowing off water around the air induction valve.

Engine condition	Water temperature °C (°F)	A.I.V. control solenoid valve	A.I.V. control system
Idle or deceleration	Between 28 (82) and 115 (239)	ON	Operates

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

E.G.R. (Exhaust Gas Recirculation) Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

In addition, a system is provided which precisely cuts and controls port vacuum applied to the E.G.R. valve to suit engine operating conditions. This cut-and-control operation is accomplished through the E.C.U. When the E.C.U. detects any of the following conditions, current flows through the solenoid valve in the E.G.R. control vacuum line. This causes the port vacuum to be discharged into the atmosphere so that the E.G.R. control valve remains closed.

- 1) Low engine temperature
- 2) Engine starting
- 3) High-speed engine operation
- 4) Engine idling

E.G.R. control solenoid valve operation

Condition		E.G.R. control solenoid valve
When starting		ON
Water temperature	°C (°F)	
	Below 60 (140)	
	Above 115 (239)	
Idle & heavy load conditions		OFF
Other conditions		


E.G.R. system operation

E.G.R. system operates under only the following conditions.

Water temperature °C (°F)	B.P.T. valve		Throttle position	E.G.R. control solenoid valve	E.G.R. system
	Exhaust gas pressure	Operation			
Between 60 (140) and 115 (239)	High	Closed	Partially open	OFF	Operates


Fuel Pressure Regulator Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

The fuel "pressure-up" control system briefly increases fuel pressure for improved starting performance of a hot engine. Under normal operating conditions, manifold vacuum is applied to the fuel pressure regulator. When starting the engine, however, the E.C.U. allows current to flow through the ON/OFF solenoid valve in the control vacuum line, opening this line to the atmosphere. As a result, atmospheric pressure is applied, throttling the fuel passage to increase fuel pressure.



Swirl Control Valve (S.C.V.) Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

This system has a swirl control valve (S.C.V.) in the intake passage of each cylinder.

While idling and when engine is running at low speed, the S.C.V. closes. Thus the velocity of the air in the intake passage increases, promoting the vaporization of the fuel and producing a swirl in the combustion chamber.

Because of this operation, this system tends to increase the burning speed of the gas mixture, improve fuel consumption, and increase the stability in running conditions.

Also, except when idling and when engine is running at low speed, this system opens the S.C.V. In this condition, this system tends to increase power by improving intake efficiency via reduction of intake flow resistance.

The solenoid valve controls S.C.V.'s shut/open condition. This solenoid valve is operated by the E.C.U.

SYSTEM OPERATION


Idle switch	Engine speed rpm	Solenoid valve	S.C.V.
ON	Below 3,600	ON	Close
OFF	Less than 2,000	ON	Close
	More than 3,600	OFF	Open

S.C.V. is kept open, when engine temperature is below 0°C (32°F).

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Acceleration Cut Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

When accelerator pedal is fully depressed, air conditioner is turned off for a few seconds.

This system improves acceleration when air conditioner is used.

Radiator Fan Control

INPUT/OUTPUT SIGNAL LINE



The E.C.U. performs ON/OFF control and LOW/HIGH speed control of the radiator fan corresponding to the vehicle speed, engine temperature, and air conditioner ON signal.

OPERATION

Air conditioner switch is "OFF"

Engine temperature °C (°F)	Radiator fan	Radiator fan control relay		Remarks
Below 94 (201)	OFF	Relay-1	OFF	—
		Relay-2	OFF	
Between 95 (203) and 99 (210)	LOW	Relay-1	ON	—
		Relay-2	OFF	
Above 100 (212)	HIGH	Relay-1	ON	—
		Relay-2	ON	

The radiator fan operates at HIGH if the self-diagnosing engine temperature sensor system results in "N.G.".

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Radiator Fan Control (Cont'd)

Air conditioner switch and blower fan switch are "ON"

[Evaporator outlet air temperature is over 8°C (46°F).]

Engine temperature °C (°F)	Radiator fan	Radiator fan control relay		Remarks
Below 94 (201)	*HIGH	Relay-1	ON	*OFF if vehicle speed is above 80 km/h (50 MPH).
		Relay-2	ON	
Between 95 (203) and 99 (210)	*HIGH	Relay-1	ON	*LOW if vehicle speed is above 80 km/h (50 MPH).
		Relay-2	ON	
Above 100 (212)	HIGH	Relay-1	ON	—
		Relay-2	ON	

The radiator fan operates at HIGH if the self-diagnosing engine temperature sensor system results in "N.G.".

Air conditioner switch and blower fan switch are "ON"

[Evaporator outlet air temperature is between 3°C (37°F) and 8°C (46°F).]

Engine temperature °C (°F)	Radiator fan	Radiator fan control relay		Remarks
Below 94 (201)	*LOW	Relay-1	ON	*OFF if vehicle speed is above 80 km/h (50 MPH).
		Relay-2	OFF	
Between 95 (203) and 99 (210)	LOW	Relay-1	ON	—
		Relay-2	OFF	
Above 100 (212)	HIGH	Relay-1	ON	—
		Relay-2	ON	

The radiator fan operates at HIGH if the self-diagnosing engine temperature sensor system results in "N.G.".

Fail-safe System

AIR FLOW METER MALFUNCTION

If the air flow meter output voltage is above or below the specified value, the E.C.U. senses an air flow meter malfunction. In case of a malfunction, the throttle sensor substitutes for the air flow meter.

Though air flow meter is malfunctioning, it is possible to drive the vehicle and start the engine. But engine speed will not rise more than 2,400 rpm in order to inform the driver of fail-safe system operation while driving.

Operation

System	Fixed condition
E.G.R. control system	OFF
Idle speed control system	A duty ratio is fixed at the preprogrammed value.
Fuel injection control system	Fuel is shut off above 2,400 rpm. (Engine speed does not exceed 2,400 rpm.)

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Fail-safe System (Cont'd)

ENGINE TEMPERATURE SENSOR MALFUNCTION

When engine temperature sensor output voltage is below or above the specified value, water temperature is fixed at the preset value as follows:

Operation

Condition	Engine temperature decided
Just as ignition switch is turned ON or Start	20°C (68°F)
More than 6 minutes after ignition ON or Start	80°C (176°F)
Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)

THROTTLE SENSOR MALFUNCTION

When throttle sensor output voltage is below or above the specified value, throttle sensor output is fixed at the preset value.

AIR TEMPERATURE SENSOR MALFUNCTION

When air temperature sensor is below or above the specified value, air temperature value is fixed at the preset value [20°C (68°F)].

VEHICLE SPEED SENSOR MALFUNCTION

When the vehicle speed sensor circuit is opened, fuel is temporarily shut off at 2,000 rpm during high-load operations. After this has occurred once, during all other types of driving operation fuel is shut off at 2,500 rpm. This fail-safe condition is released when the ignition switch is turned off.

NEUTRAL SWITCH MALFUNCTION

When the neutral switch (M/T) or inhibitor switch (A/T) is shorted and the vehicle speed exceeds 60 km/h (37 MPH), fuel is shut off above 2,500 rpm.

The L.E.D. in the E.C.U. and the check engine light do not indicate a neutral switch (M/T) or inhibitor switch malfunction. This fail-safe condition is released when the ignition switch is turned off.

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION


PREPARATION

1. Make sure that the following parts are in good order.


- Battery
- Ignition system
- Engine oil and coolant levels
- Fuses
- E.C.U. harness connector
- Vacuum hoses
- Air intake system (Oil filler cap, oil level gauge, etc.)
- Fuel pressure
- A.I.V. hose
- Engine compression
- E.G.R. control valve operation

- Throttle valve and idle switch
2. On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
 3. On automatic transaxle equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
 4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
 5. Turn off headlamps, heater blower, rear defogger.
 6. Keep front wheels pointed straight ahead.
 7. Make the check after the radiator fan has stopped.


Overall inspection sequence




IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



- Check exhaust gas sensor harness:
- 1) Turn off engine and disconnect battery ground cable.
 - 2) Disconnect harness connector from E.C.U.
 - 3) Disconnect exhaust gas sensor harness connector and connect terminal for exhaust gas sensor harness connector to ground with a jumping wire.
 - 4) Check for continuity between terminal No. 19 of E.C.U. harness connector and ground metal on vehicle body.


Continuity exists. O.K.
Continuity does not exist N.G.

O.K.

N.G.

Repair or replace E.C.C.S. harness and connect battery ground cable.

Connect harness connector to E.C.U. and disconnect jumping wire from exhaust gas sensor.



- Disconnect engine temperature sensor harness connector.
- Connect a resistor (2.5 kΩ) between terminals of engine temperature sensor harness connector.
- Disconnect A.I.V. hose and install a suitable plug in A.I.V. pipe.
- Connect battery ground cable.

Start engine and warm it up until water temperature indicator points to the middle of gauge. (Wait more than 5 minutes after starting.)

Race engine two or three times under no-load then run engine at idle speed.

Check "CO"% and if engine runs smoothly.

Idle CO: Less than 5%

After checking CO%

- 1) Turn off engine.
- 2) Disconnect the resistor (2.5 kΩ) from terminals of engine temperature sensor harness connector.
- 3) Connect engine temperature sensor harness connector to engine temperature sensor.
- 4) Connect A.I.V. hose.

O.K.


N.G.

E

F

C

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



*: E.C.U. may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES




Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair	EF & EC- 36
Self-diagnosis	EF & EC- 40
Self-diagnosis — Mode I	EF & EC- 42
Self-diagnosis — Mode II (Self-diagnostic results)	EF & EC- 43
Self-diagnosis — Mode II (Exhaust gas sensor monitor)	EF & EC- 45
Consult	EF & EC- 46
Diagnostic Procedure	EF & EC- 55
Basic Inspection	EF & EC- 57
Diagnostic Procedure 1 — High Idling after Warm-up	EF & EC- 60
Diagnostic Procedure 2 — Hunting	EF & EC- 61
Diagnostic Procedure 3 — Unstable Idle	EF & EC- 63
Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold ..	EF & EC- 67
Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot	EF & EC- 69
Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions	EF & EC- 71
Diagnostic Procedure 7 — Hesitation when the Engine is Hot	EF & EC- 73
Diagnostic Procedure 8 — Hesitation when the Engine is Cold	EF & EC- 74
Diagnostic Procedure 9 — Hesitation under Normal Conditions	EF & EC- 75
Diagnostic Procedure 10 — Engine Stalls when turning	EF & EC- 76
Diagnostic Procedure 11 — Engine Stalls when the Engine is ot	EF & EC- 78
Diagnostic Procedure 12 — Engine Stalls when the Engine is old	EF & EC- 80
Diagnostic Procedure 13 — Engine Stalls when Stepping on he Accelerator Momentarily	EF & EC- 82
Diagnostic Procedure 14 — Engine Stalls after Decelerating	EF & EC- 85
Diagnostic Procedure 15 — Engine Stalls when ccelerating or when Driving at Constant Speed	EF & EC- 89
Diagnostic Procedure 16 — Engine Stalls when the Electrical oad is Heavy	EF & EC- 91
Diagnostic Procedure 17 — Lack of Power and Stumble	EF & EC- 93
Diagnostic Procedure 18 — Detonation	EF & EC- 94
Diagnostic Procedure 19 — Surge	EF & EC- 95
Diagnostic Procedure 20 — Backfire through the Intake	EF & EC- 96
Diagnostic Procedure 21 — Backfire through the Exhaust	EF & EC- 96
Diagnostic Procedure 22	
MAIN POWER SUPPLY AND GROUND CIRCUIT	EF & EC- 97
Diagnostic Procedure 23	
CRANK ANGLE SENSOR	EF & EC-100
Diagnostic Procedure 24	
AIR FLOW METER	EF & EC-103
Diagnostic Procedure 25	
ENGINE TEMPERATURE SENSOR	EF & EC-106
Diagnostic Procedure 26	
VEHICLE SPEED SENSOR	EF & EC-109
Diagnostic Procedure 27	
IGNITION SIGNAL	EF & EC-112
Diagnostic Procedure 28	
E.C.C. CONTROL UNIT	EF & EC-114

TROUBLE DIAGNOSES

Contents (Cont'd)

Diagnostic Procedure 29	
E.G.R. FUNCTION	EF & EC-115
Diagnostic Procedure 30	
EXHAUST GAS SENSOR	EF & EC-119
Diagnostic Procedure 31	
EXHAUST GAS TEMPERATURE SENSOR	EF & EC-121
Diagnostic Procedure 32	
AIR TEMPERATURE	EF & EC-124
Diagnostic Procedure 33	
THROTTLE SENSOR	EF & EC-127
Diagnostic Procedure 34	
INJECTOR LEAK	EF & EC-130
Diagnostic Procedure 35	
THROTTLE VALVE SWITCH	EF & EC-132
Diagnostic Procedure 36	
START SIGNAL	EF & EC-134
Diagnostic Procedure 37	
A.I.V. CONTROL	EF & EC-136
Diagnostic Procedure 38	
P.R.V.R. CONROL	EF & EC-139
Diagnostic Procedure 39	
INJECTOR	EF & EC-143
Diagnostic Procedure 40	
FUEL PUMP	EF & EC-145
Diagnostic Procedure 41	
S.C.V. CONTROL	EF & EC-148
Diagnostic Procedure 42	
A.A.C. VALVE	EF & EC-151
Diagnostic Procedure 43	
RATIATOR FAN CONTROL	EF & EC-154
Diagnostic Procedure 44	
POWER STEERING OIL PRESSRUE SWITCH	EF & EC-160
Diagnostic Procedure 45	
NEUTRAL/INHIBITOR SWITCH	EF & EC-163
Electrical Components Inspection	EF & EC-168



How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION

The engine has an electronic control unit to control major systems such as fuel control, ignition control, idle speed control, etc. The control unit accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the problems. A road test with a circuit tester connected to a suspected circuit should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd) WORK FLOW



*1: If the self-diagnosis cannot be performed, check main power supply and ground circuit. (See Diagnostic Procedure 22.)

*2: If the trouble is not duplicated, see INTERMITTENT PROBLEM SIMULATION (EF & EC-39).

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

KEY POINTS

WHAT		Vehicle & engine model
WHEN		Date, Frequencies
WHERE		Road conditions
HOW		Operating conditions, Weather conditions, Symptoms

DIAGNOSTIC WORKSHEET



There are many kinds of operating conditions that lead to malfunctions on engine components.

A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, feelings for a problem depend on each customer. It is important to fully understand the symptoms or under what conditions a customer complains.


Make good use of a diagnostic worksheet such as the one shown below in order to utilize all the complaints for troubleshooting.

Worksheet sample

Customer name MR/MS		Model & Year	VIN
Engine #		Trans.	Mileage
Incident Date		Manuf. Date	In Service Date
Symptoms	☐ Startability	☐ Impossible to start ☐ No combustion ☐ Partial combustion ☐ Partial combustion affected by throttle position ☐ Partial combustion NOT affected by throttle position ☐ Possible but hard to start ☐ Others []	
	☐ Idling	☐ No fast idle ☐ Unstable ☐ High idle ☐ Low idle ☐ Others []	
	☐ Driveability	☐ Stumble ☐ Surge ☐ Detonation ☐ Lack of power ☐ Intake backfire ☐ Exhaust backfire ☐ Others []	
	☐ Engine stall	☐ At the time of start ☐ While idling ☐ While accelerating ☐ While decelerating ☐ Just after stopping ☐ While loading	
Incident occurrence		☐ Just after delivery ☐ Recently ☐ In the morning ☐ At night ☐ In the daytime	
Frequency		☐ All the time ☐ Under certain conditions ☐ Sometimes	
Weather conditions		☐ Note effected	
Weather		☐ Fine ☐ Raining ☐ Snowing ☐ Others []	
Temperature		☐ Hot ☐ Warm ☐ Cool ☐ Cold ☐ Humid °F	
Engine conditions		☐ Cold During warm-up ☐ After warm-up Engine speed 	
Road conditions		☐ In town ☐ In suburbs ☐ Highway ☐ Off road (up/down)	
Driving conditions		☐ Not affected ☐ At starting ☐ While idling ☐ At racing ☐ While accelerating ☐ While cruising ☐ While decelerating ☐ While turning (RH/LH) Vehicle speed 	
Check engine light		☐ Turned on ☐ Not turned on	

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)




INTERMITTENT PROBLEM SIMULATION

In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.

Perform the activity listed under Service procedure and note the result.

	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Distributor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3	Mixture ratio feed-back control	Exhaust gas sensor	Suspended	Disconnect exhaust gas sensor harness connector.
		Control unit	Operation check	Perform self-diagnosis (Mode I/II) at 2,000 rpm.
4	Idle speed	I.A.A. unit	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electric connection (Electric continuity)	Harness connectors and wires	Poor electric connection or faulty wiring	Tap or wiggle.
				Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
6	Temperature	Control unit	Cooled	Cool with an icing spray or similar device.
			Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
7	Moisture	Electric parts	Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
8	Electric loads	Load switches	Loaded	Turn on headlights, air conditioner, rear defogger, etc.
9	Idle switch condition	Control unit	ON-OFF switching	Perform self-diagnosis (Mode IV).
10	Ignition spark	Timing light	Spark power check	Try to flash timing light for each cylinder.


TROUBLE DIAGNOSES



Self-diagnosis

CHECK ENGINE LIGHT

A check engine light has been adopted on the California, Federal and Canada models. This light blinks simultaneously with the RED L.E.D. on the E.C.U.



E.C.U. L.E.D.

In the E.C.U., the Green and Red L.E.D.'s have now been permanently changed to one RED L.E.D.


SELF-DIAGNOSTIC FUNCTION

Mode		Mode I	Mode II
Condition			
Ignition switch in "ON" position	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	EXHAUST GAS SENSOR MONITOR

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

HOW TO SWITCH MODES



- Switching the modes is not possible when the engine is running.
- When the ignition switch is turned off during diagnosis in each mode, and then turned back on again after power to the E.C.U. has dropped off completely, the diagnosis will automatically return to Mode I.

TROUBLE DIAGNOSES

Self-diagnosis — Mode I

MODE I — BULB CHECK

In this mode, the RED L.E.D. in the E.C.U. and the CHECK ENGINE LIGHT in the instrument panel stay "ON".

If either remain "OFF", check the bulb in the CHECK ENGINE LIGHT or the RED L.E.D.

MODE I — MALFUNCTION WARNING

FOR CALIFORNIA MODEL

CHECK ENGINE LIGHT AND RED L.E.D.	CONDITION
ON	WHEN THE FOLLOWING MALFUNCTION (CHECK ENGINE LIGHT ITEM) IS DETECTED OR THE E.C.U.'S C.P.U. IS MALFUNCTIONING.
OFF	O.K.

CODE NO.	MALFUNCTION
12	AIR FLOW METER CIRCUIT
13	ENGINE TEMPERATURE SENSOR CIRCUIT
14	VEHICLE SPEED SENSOR CIRCUIT
31	E.C.U.(E.C.C.S. CONTROL UNIT)
32	E.G.R. FUNCTION
33	EXHAUST GAS SENSOR CIRCUIT
35	EXHAUST GAS TEMPERATURE SENSOR CIRCUIT
43	THROTTLE SENSOR CIRCUIT
45	INJECTOR LEAK

- These Code Numbers are clarified in Mode II — SELF-DIAGNOSTIC RESULTS.
- The RED L.E.D. and the CHECK ENGINE LIGHT will turn off when normal condition is detected. At this time, the Mode II — SELF-DIAGNOSTIC RESULTS memory must be cleared as the contents remain stored.

FOR NON-CALIFORNIA MODEL

RED L.E.D.	CONDITION
ON	WHEN THE E.C.U.'S C.P.U. IS MALFUNCTIONING.
OFF	O.K.


TROUBLE DIAGNOSES

Self-diagnosis — Mode II (Self-diagnostic results)

DESCRIPTION

In this mode, a malfunction code is indicated by the number of flashes from the RED L.E.D. or the CHECK ENGINE LIGHT as shown below:

Example: Code No. 12 and Code No. 33



Long (0.6 second) blinking indicates the number of ten digits and short (0.3 second) blinking indicates the number of single digits.

For example, the red L.E.D. flashes once for 0.6 seconds and then it flashes twice for 0.3 seconds. This indicates the number "12" and refers to a malfunction in the air flow meter. In this way, all the problems are classified by their code numbers. The diagnostic results will remain in E.C.U. memory.

Display code table

Code No.	Detected items	California model	Non-California model
11	Crank angle sensor circuit	X	X
12 	Air flow meter circuit	X	X
13 	Engine temperature sensor circuit	X	X
14 	Vehicle speed sensor circuit	X	X
21	Ignition signal circuit	X	X
31 	E.C.U.	X	X
32 	E.G.R. function	X	—
33 	Exhaust gas sensor circuit (Left side)	X	X
35 	Exhaust gas temperature sensor circuit	X	—
41	Air temperature sensor circuit	X	X
43	Throttle sensor circuit	X	X
45	Injector leak	X	—
55	No malfunction in the above circuits	X	X

X: Available

—: Not available

: Check engine light item

TROUBLE DIAGNOSES

Self-diagnosis — Mode II (Self-diagnostic results) (Cont'd)

Code No.	Detected items	Malfunction is detected when ...	Check item (remedy)
*11	Crank angle sensor circuit	- Either 1° or 180° signal is not entered for the first few seconds during engine cranking. - Either 1° or 180° signal is not input often enough while the engine speed is higher than the specified rpm.	Harness and connector (If harness and connector are normal, replace crank angle sensor.)
12	Air flow meter circuit	The air flow meter circuit is open or shorted. (An abnormally high or low voltage is entered.)	Harness and connector (If harness and connector are normal, replace air flow meter.)
13	Engine temperature sensor circuit	The engine temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)	- Harness and connector - Engine temperature sensor
14	Vehicle speed sensor circuit	The vehicle speed sensor circuit is open or shorted.	- Harness and connector - Vehicle speed sensor (reed switch)
*21	Ignition signal circuit	The ignition signal in the primary circuit is not entered during engine cranking or running.	- Harness and connector - power transistor unit
31	E.C.U.	E.C.U. calculation function is malfunctioning.	(Replace E.C.C.S. control unit.)
32	E.G.R. function	E.G.R. control valve does not operate. (E.G.R. control valve spring does not lift.)	- E.G.R. control valve - E.G.R. control solenoid valve
33	Exhaust gas sensor circuit	The exhaust gas sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)	- Harness and connector - Exhaust gas sensor - Fuel pressure - Injectors - Intake air leaks
35	Exhaust gas temperature sensor circuit	The exhaust gas temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)	- Harness and connector - Exhaust gas temperature sensor
41	Air temperature sensor circuit	The air temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)	- Harness and connector - Air temperature sensor
43	Throttle sensor circuit	The throttle sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)	- Harness and connector - Throttle sensor
45	injector leak	Fuel leaks from injector.	Injector

*: Check items causing a malfunction of crank angle sensor circuit first, if both code No. 11 and 21 come out at the same time.

TROUBLE DIAGNOSES

Self-diagnosis — Mode II (Self-diagnostic results) (Cont'd)

HOW TO ERASE SELF-DIAGNOSTIC RESULTS

The malfunction code is erased from the backup memory on the E.C.U. when the diagnostic mode is changed from Mode II to Mode I. (Refer to "HOW TO SWITCH MODES".)

- **When the battery terminal is disconnected, the malfunction code will be lost from the backup memory within 24 hours.**
- **Before starting self-diagnosis, do not erase the stored memory before beginning self-diagnosis.**

Self-diagnosis — Mode II (Exhaust gas sensor monitor)

DESCRIPTION

In this mode, the CHECK ENGINE LIGHT and RED L.E.D. display the condition of the fuel mixture (lean or rich) which is monitored by the exhaust gas sensor.

CHECK ENGINE LIGHT and RED L.E.D.	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop control
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop control

*: Maintains conditions just before switching to open loop.

HOW TO CHECK EXHAUST GAS SENSOR



1. Set Mode II. (Refer to "HOW TO SWITCH MODES".)
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of the gauge.
3. Run engine at about 2,000 rpm for about 2 minutes under no-load conditions.
4. Make sure RED L.E.D. or CHECK ENGINE LIGHT goes ON and OFF more than 5 times every 10 seconds; measured at 2,000 rpm under no-load.

TROUBLE DIAGNOSES


Consult

CONSULT INSPECTION PROCEDURE


1. Turn off ignition switch.
2. Connect "CONSULT" to diagnostic connector.
(Diagnostic connector is located in left dash side panel.)



3. Turn on ignition switch.
4. Touch "START".




5. Touch "ENGINE".



6. Perform each diagnostic mode according to the inspection sheet as follows:

For further information, read the CONSULT Operation Manual.



TROUBLE DIAGNOSES

Consult (Cont'd)

E.C.C.S. COMPONENT PARTS APPLICATION

MODE E.C.C.S. COMPONENT PARTS		WORK SUPPORT	SELF- DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	FUNCTION TEST
INPUT	Crank angle sensor		X	X		
	Air flow meter		X	X		
	Engine temperature sensor		X	X	X	
	Exhaust gas sensors		X	X		X
	Vehicle speed sensors		X	X		X
	Throttle sensor	X	X	X		X
	Exhaust gas temperature sensor*		X	X		
	Ignition switch (start signal)			X		X
	Air conditioner switch			X		
	Neutral switch			X		X
	Power steering oil pressure switch			X		X
	Battery			X		
	Air temperature sensor			X		
OUTPUT	Injectors		X	X	X	X
	Power transistor (ignition timing)		X (Ignition signal)	X	X	X
	A.A.C. valve	X		X	X	X
	Swirl control solenoid valve			X	X	X
	A.I.V. control solenoid valve			X	X	
	P.R.V.R. control solenoid valve			X	X	X
	E.G.R. control solenoid valve			X	X	X
	Air conditioner relay			X		
	Fuel pump relay	X		X	X	X
	Radiator fan relay			X	X	X

*: The E.C.C.S. component part marked * is applicable to vehicles for California only.

X: Applicable

CAUTION:

- When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.
- Be sure to set gears to "Neutral" before conducting "Active Test" on idle adjustment or A.A.C. valve.

TROUBLE DIAGNOSES

Consult (Cont'd)

FUNCTION

Diagnostic mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the control unit can be read.
Active test	Mode in which CONSULT drives some actuators apart from the control units and also shifts some parameters in a specified range.
E.C.U. part numbers	E.C.U. part numbers can be read.
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".

WORK SUPPORT MODE

WORK ITEM	CONDITION	USAGE
THROTTLE SENSOR ADJUSTMENT	CHECK THE THROTTLE SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. ● IGN SW "ON" ● ENG NOT RUNNING ● ACC PEDAL NOT PRESSED	When adjusting throttle sensor initial position,
IGNITION TIMING ADJUSTMENT*	● IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANK ANGLE SENSOR.	When adjusting initial ignition timing,
AAC VALVE ADJUSTMENT	SET ENGINE RPM AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. ● ENGINE WARMED UP ● NO-LOAD	When adjusting idle speed,
FUEL PRESSURE RELEASE	● FUEL PUMP WILL STOP BY TOUCHING "START" WHEN IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.	When releasing fuel pressure from fuel line,

TROUBLE DIAGNOSES

Consult (Cont'd)

SELF-DIAGNOSTIC RESULTS MODE

DIAGNOSTIC ITEM	DIAGNOSTIC ITEM IS DETECTED WHEN ...	CHECK ITEM (REMEDY)
CRANK ANGLE SENSOR*	- Either 1° or 180° signal is not entered for the first few seconds during engine cranking. - Either 1° or 180° signal is not input often enough while the engine speed is higher than the specified rpm.	Harness and connector (If harness and connector are normal, replace crank angle sensor.)
AIR FLOW METER	The air flow meter circuit is open or shorted. (An abnormally high or low voltage is entered.)	Harness and connector (If harness and connector are normal, replace air flow meter.)
ENGINE TEMP SENSOR	The engine temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)	- Harness and connector - Engine temperature sensor
CAR SPEED SENSOR	The vehicle speed sensor circuit is open or shorted.	- Harness and connector - Vehicle speed sensor (reed switch)
IGN SIGNAL-PRIMARY*	The ignition signal in primary circuit is not entered during engine cranking or running.	- Harness and connector - Power transistor unit
CONTROL UNIT	E.C.U. calculation function is malfunctioning.	(Replace E.C.C.S. control unit.)
EGR SYSTEM*, **	E.G.R. control valve does not operate. (E.G.R. control valve spring does not lift.)	- E.G.R. control valve - E.G.R. control solenoid valve
EXH GAS SENSOR	The exhaust gas sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)	- Harness and connector - Exhaust gas sensor - Fuel pressure - Injectors - Intake air leaks
EXH GAS TEMP SENSOR**	The exhaust gas temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)	- Harness and connector - Exhaust gas temperature sensor
AIR TEMP SENSOR	The air temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)	- Harness and connector - Air temperature sensor
THROTTLE SENSOR	The throttle sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)	- Harness and connector - Throttle sensor
INJECTOR LEAK**	Fuel leaks from injector.	Injector

* : Check items causing a malfunction of crank angle sensor circuit first, if both "CRANK ANGLE SENSOR" and "IGN SIGNAL-PRIMARY" come out at the same time.

** : The diagnostic item marked ** is applicable to vehicles for California only.

TROUBLE DIAGNOSES

Consult (Cont'd)

DATA MONITOR MODE

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
CAS, RPM (REF)	● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT value.		Almost the same speed as the CONSULT value.	● Harness and connector ● Crank angle sensor
AIR FLOW MTR	● Engine: After warming up, idle the engine ● A/C switch "OFF" ● Shift lever "N" ● No load	Idle	1.3 - 1.8V	● Harness and connector ● Air flow meter
		2,000 rpm	1.8 - 2.2V	
ENG TEMP SEN	● Engine: After warming up		More than 70°C (158°F)	● Harness and connector ● Engine temperature sensor
EXH GAS SEN	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V	● Harness and connector ● Exhaust gas sensor ● Intake air leaks ● Injectors
M/R F/C MNT			LEAN ↔ RICH Changes more than 5 times during 10 seconds.	
CAR SPEED SEN	● Turn drive wheels and compare speedometer indication with the CONSULT value		Almost the same speed as the CONSULT value	● Harness and connector ● Vehicle speed sensor
BATTERY VOLT	● Ignition switch: ON (Engine stopped)		11 - 14V	● Battery ● E.C.U. power supply circuit
THROTTLE SEN	● Ignition switch: ON (Engine stopped)	Throttle valve fully closed	0.4 - 0.5V	● Harness and connector ● Throttle sensor ● Throttle sensor adjustment
		Throttle valve fully opened	Approx. 4.0V	
AIR TEMP SEN	● Engine: After warming up		20 - 60°C (68 - 140°F)	● Harness and connector ● Fuel temp. sensor
EGR TEMP SEN*	● Engine: After warming up		Less than 4.5V	● Harness and connector ● Exhaust gas temperature sensor
START SIGNAL	● Ignition switch: ON → START		OFF → ON	● Harness and connector ● Starter switch
IDLE POSITION	● Ignition switch: ON (Engine stopped)	Throttle valve: Idle position	ON	● Harness and connector ● Throttle sensor ● Throttle sensor adjustment
		Throttle valve: Slightly open	OFF	
AIR COND SIG	● Engine: After warming up, idle the engine	A/C switch "OFF"	OFF	● Harness and connector ● Air conditioner switch
		A/C switch "ON"	ON	
NEUTRAL SW	● Ignition switch: ON	Shift lever "P" or "N"	ON	● Harness and connector ● Neutral switch
		Except above	OFF	
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral (forward direction)	OFF	● Harness and connector ● Power steering oil pressure switch
		The steering wheel is turned	ON	
INJ PULSE	Idle		2.9 - 3.6 msec.	● Harness and connector ● Injector ● Air flow meter
	2,000 rpm		2.6 - 3.3 msec.	

TROUBLE DIAGNOSES

Consult (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
IGN TIMING	Idle	15 deg.	● Harness and connector ● Crank angle sensor
	2,000 rpm	More than 25 deg.	
ACC VALVE	Idle	15° - 40°	● Harness and connector ● ACC valve
	2,000 rpm	—	

Remarks:

- The monitor item marked * is applicable to vehicles for California only.
- Specifications are reference values.
- Specification data are out-put/in-put values which are detected or supplied by the E.C.U. at the connector.
- * Specification data may not be directly related to their components signals/values/operations.
i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the E.C.U. according to the input signals from the crank angle sensor and other ignition timing related sensors.

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION TEST	● Engine: Return to the original trouble condition ● Change the amount of fuel injection with the CONSULT.	If trouble symptom disappears, see CHECK ITEM.	● Harness and connector ● Fuel injectors ● Exhaust gas sensors
AAC/V OPENING TEST	● Engine: After warming up, idle the engine. ● Change the AAC valve opening percent with the CONSULT.	Engine speed changes according to the opening percent.	● Harness and connector ● AAC valve
ENGINE TEMP TEST	● Engine: Return to the original trouble condition ● Change the engine coolant temperature with the CONSULT.	If trouble symptom disappears, see CHECK ITEM.	● Harness and connector ● Engine temperature sensor ● Fuel injectors
IGN TIMING TEST	● Engine: Return to the original trouble condition ● Timing light: Set ● Retard the ignition timing with the CONSULT.	If trouble symptom disappears, see CHECK ITEM.	● Adjust initial ignition timing
POWER BALANCE TEST	● Engine: After warming up, idle the engine. ● A/C switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time with the CONSULT.	Engine runs rough or dies.	● Harness and connector ● Compression ● Injectors ● Power transistor ● Spark plugs ● Ignition coils
RADIATOR FAN TEST	● Ignition switch: ON ● Turn the radiator fan "ON" and "OFF" with the CONSULT.	Radiator fan moves and stops.	● Harness and connector ● Radiator fan motor
FUEL PUMP RLY TEST	● Ignition switch: ON (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" with the CONSULT and listen to operating sound.	Fuel pump relay makes the operating sound.	● Harness and connector ● Fuel pump relay
EGR CONT SOLV/V TEST	● Ignition switch: ON ● Turn solenoid valve "ON" and "OFF" with the CONSULT and listen to operating sound.	Each solenoid valve makes an operating sound.	● Harness and connector ● Solenoid valve
PRVR CONT SOL/V TEST			
AIV CONT SOL/V TEST			
SWIRL CONT SOL/V TEST			
SELF-LEARN CONT TEST	● In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen.		

TROUBLE DIAGNOSES

Consult (Cont'd)

FUNCTION TEST MODE

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
SELF-DIAG RESULTS	● Ignition switch: ON (Engine stopped) ● Displays the results of self-diagnosis.	—		Objective system
IDLE POSITION (IDLE SWITCH CIRCUIT)	● Ignition switch: ON (Engine stopped) ● Idle switch circuit is tested when throttle is opened and closed fully. ("IDLE POSITION" is the test item name for the vehicles in which idle is selected by throttle sensor.)	Throttle valve: opened	OFF	● Harness and connector ● Throttle sensor (Idle switch) ● Throttle sensor (Idle switch) adjustment ● Throttle linkage ● Verify operation in DATA MONITOR mode.
		Throttle valve: closed	ON	
THROTTLE SENSOR CKT	● Ignition switch: ON (Engine stopped) ● Throttle sensor circuit is tested when throttle is opened and closed fully.	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	● Harness and connector ● Throttle sensor ● Throttle sensor adjustment ● Throttle linkage ● Verify operation in DATA MONITOR mode.
NEUTRAL SW CIRCUIT	● Ignition switch: ON (Engine stopped) ● Neutral switch circuit is tested when shift lever is manipulated.	OUT OF N/P-RANGE	OFF	● Harness and connector ● Neutral switch/Inhibitor switch ● Linkage + Inhibitor switch adjustment
		IN N-RANGE	ON	
FUEL PUMP CIRCUIT	● Ignition switch: ON (Engine stopped) ● Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched.	There is pressure pulsation on the fuel feed hose.		● Harness and connector ● Fuel pump ● Fuel pump relay ● Fuel filter clogging ● Fuel level
EGR CONT S/V CIRCUIT	● Ignition switch: ON (Engine stopped) ● EGR control S/V circuit is tested by checking solenoid valve operating noise.	The solenoid valve makes an operating sound every 3 seconds.		● Harness and connector ● EGR control solenoid valve
PRVR CONT S/V CIRCUIT	● Ignition switch: ON (Engine stopped) ● PRVR CONT S/V circuit is tested by checking solenoid valve operating noise.	The solenoid valve makes an operating sound every 3 seconds.		● Harness and connector ● P.R.V.R. control solenoid valve
RADIATOR FAN CIRCUIT	● Ignition switch: ON (Engine stopped) ● Radiator fan circuit is tested by checking radiator fan operation.	● The radiator fan rotates and stops every 3 seconds.		● Harness and connector ● Radiator fan motor ● Radiator fan relay

TROUBLE DIAGNOSES






Consult (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
START SIGNAL CIRCUIT	● Ignition switch: ON → START ● Start signal circuit is tested when engine is started by perating the starter. Battery voltage and water temperature before ranking, and average battery voltage, air flow meter output voltage nd cranking speed during cranking are displayed.	Start signal: OFF → ON		● Harness and connector ● Ignition switch
PW/ST SIGNAL CIRCUIT	● Ignition switch: ON (Engine running) ● Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position.	Locked position	ON	● Harness and connector ● Power steering oil pressure switch ● Power steering oil pump
		Neutral	OFF	
SWIRL CONTROL S/V CIRCUIT	● Ignition switch: ON (Engine stopped) ● Swirl control S/V circuit is tested by checking swirl control actuator operation.	● The swirl control actuator moves every 3 seconds.		● Harness and connector ● Swirl control solenoid valve ● Swirl control actuator ● Vacuum hose
CAR SPEED SEN CIRCUIT	● Car speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 mph) or higher.	Car speed sensor input signal is greater than 4 km/h (2 MPH)		● Harness and connector ● Car speed sensor ● Electric speedometer
IGN TIMING ADJ	● After warming up, idle the engine. ● Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications.	The timing light indicates the same value on the screen.		● Adjust ignition timing (by moving crank angle sensor or distributor) ● Crank angle sensor drive mechanism

TROUBLE DIAGNOSES

Consult (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
MIXTURE RATIO TEST	● Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the O₂ sensor output at 2,000 rpm under non-loaded state.	● O₂ SEN COUNT: More than 5 times during 10 seconds (O₂ SEN-R COUNT: More than 5 times during 10 seconds)	● INJECTION SYS (Injector, fuel pressure regulator, harness or connector) ● IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector) ● VACUUM SYS (Intake air leaks) ● O₂ sensor circuit ● O₂ sensor operation ● Fuel pressure high or low ● Air flow meter
POWER BALANCE	● After warming up, idle the engine. ● Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential injection system is used.)	Difference in engine rpm is greater than 25 rpm before and after cutting off the injector of each cylinder.	● Injector circuit (Injector, harness or connector) ● Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector) ● Compression ● Valve timing
AAC VALVE SYSTEM	● After warming up, idle the engine. ● AAC valve system is tested by detecting change in engine rpm when AAC valve opening is changed to 0%, 20% and 80%.	Difference in engine rpm is greater than 150 rpm between when valve opening is at 80% (102 steps) and at 20% (25 steps).	● Harness and connector ● AAC valve ● Air passage restriction between air inlet and AAC valve ● IAS (Idle adjusting screw) adjustment



Diagnostic Procedure

CAUTION:


1. Before connecting or disconnecting the E.C.U. harness connector to or from any E.C.U., be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage E.C.U. as battery voltage is applied to E.C.U. even if ignition switch is turned off. Failure to do so may damage the E.C.U.
2. When connecting E.C.U. harness connector, tighten securing bolt until red projection is in line with connector face.
3. When connecting or disconnecting pin connectors into or from E.C.U., take care not to damage pin terminals (bend or break).
4. Make sure that there are not any bends or breaks on E.C.U. pin terminal, when connecting pin connectors.
5. Before replacing E.C.U., perform E.C.U. input/output signal inspection and make sure whether E.C.U. functions properly or not. (See page EF & EC-168.)
6. After performing this "Diagnostic Procedure", perform E.C.C.S. self-diagnosis and driving test.

TROUBLE DIAGNOSES





Diagnostic Procedure (Cont'd)

7. When measuring E.C.U. controlled components supply voltage with a circuit tester, separate one tester probe from the other.

If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the control unit power transistor.



Basic Inspection



- 1**
- BEFORE STARTING**
1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
 2. Open engine hood and check the following:
 - Harness connectors for proper connections
 - Vacuum hoses for splits, kinks, and proper connections
 - Wiring for proper connections, pinches, and cuts

2

CONNECT CONSULT TO THE VEHICLE.
Connect "CONSULT" to the diagnostic connector and select "ENGINE" from the menu. (Refer to page EF & EC-46.)

3

DOES ENGINE START?

No → Go to **6**.

Yes

4

CHECK IGNITION TIMING.
Warm up engine sufficiently and check ignition timing at idle using timing light. (Refer to page EF & EC-30.)
Ignition timing: $15^{\circ} \pm 2^{\circ}$
B.T.D.C.

N.G. → Adjust ignition timing by turning crank angle sensor.

O.K.

(Go to **A** on next page.)

TROUBLE DIAGNOSES

Basic Inspection (Cont'd)

5

■ AAC VALVE ADJ ■

SET ENGINE RPM AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITION

- ENG WARMED UP
- NO LOAD

START

SEF372I

5

Throttle sensor harness connector

DISCONNECT

SEF408J

6

■ THROTTLE SEN ADJ ■

**** ADJ MONITOR ****

THROTTLE SEN 0.46V

=== MONITOR ===

CAS-RPM (POS) 800rpm

IDLE POSITION ON

SEF147I

6

CONNECT

H.S.

SEF148I

5

CHECK IDLE ADJ. SCREW INITIAL SET RPM.

1. Select "A.A.C. VALVE ADJ" in "WORK SUPPORT" mode.

2. When touching "START", does engine rpm fall to the following values?

M/T: 650 ± 50 rpm
A/T: 650 ± 50 rpm
("N" position)

OR

When disconnecting throttle sensor harness connector, does engine rpm fall to the following values?

M/T: 650 ± 50 rpm
A/T: 650 ± 50 rpm
("N" position)

No → Adjust engine rpm by turning idle adjusting screw.

CAUTION
Be sure to set gears to "Neutral".

Yes

6

CHECK THROTTLE SENSOR IDLE POSITION.

1. Perform "THROTTLE SEN. ADJ." in "WORK SUPPORT" mode.

2. Check that output voltage of throttle sensor is 0.4 to 0.5V. (Throttle valve fully closes.) and "IDLE POSITION" stays "ON".

OR

Measure output voltage of throttle sensor using voltmeter, and check that it is 0.4 to 0.5V. (Throttle valve fully closed.)

N.G. → 1. Adjust output voltage by rotating throttle sensor body.
2. Disconnect throttle sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "IDLE POSITION" stays "ON".

O.K. → (Go to ⑥ on next page.)

TROUBLE DIAGNOSES

Basic Inspection (Cont'd)


7

☆ MONITOR ☆ NO FAIL ☐

START SIGNAL	OFF
IDLE POSITION	ON
AIR COND SIG	OFF
NEUTRAL SW	ON

RECORD

SEF149I



7

ⓑ

CHECK SWITCH INPUT SIGNAL.

Select the following switches in "DATA MONITOR" mode,

- Start signal,
- Idle position,
- Air conditioner signal,
- Neutral (Parking) switch,

and check the switches' ON-OFF operation.

OR

Remove E.C.U. from front floor panel and check the above switches' ON-OFF operation using voltmeter at each E.C.U. terminal.

Switch	Condition	Voltage (V)
Start signal	IGN ON → IGN START	0 → Battery voltage
Idle position	—	—
A/C signal	A/C OFF → A/C ON (Engine running)	Battery voltage → 0.5 - 0.7
Neutral (Parking) switch	Shift lever is "N" or "P" position → Except "N" and "P"	0 → 8.0 - 9.0

N.G. → Repair or replace the malfunctioning switch or its circuit.


8

■ SELF DIAG RESULTS ■ ☐

FAILURE DETECTED TIME
ENGINE TEMP SENSOR 0

ERASE PRINT

SEF151I



8

O.K.

READ SELF-DIAGNOSTIC RESULTS.

- Perform "SELF-DIAG RESULTS" mode.
- Read out self-diagnostic results.
- Is a failure detected?

OR




- Set "Self-diagnostic results mode" in Mode II. (Refer to page EF & EC-41.)
- Count the number of RED L.E.D. flashes and read out the codes.
- Are the codes being output?

Yes → Go to the relevant inspection procedure.


No

INSPECTION END






TROUBLE DIAGNOSES



Diagnostic Procedure 1 — High Idling after Warm-up






Diagnostic Procedure 2 — Hunting









TROUBLE DIAGNOSES

Diagnostic Procedure 2 — Hunting (Cont'd)






Diagnostic Procedure 3 — Unstable Idle



TROUBLE DIAGNOSES

Diagnostic Procedure 3 — Unstable Idle (Cont'd)



CAUTION:

When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.

TROUBLE DIAGNOSES




Diagnostic Procedure 3 — Unstable Idle (Cont'd)

7

☆MONITOR	☆NO FAIL	☐
CAS-RPM(POS)	2087rpm	
M/R F/C MNT	LEAN	

RECORD

SEF265J



TROUBLE DIAGNOSES

Diagnostic Procedure 3 — Unstable Idle (Cont'd)

9

■ AAC VALVE ADJ ■ □

**** ADJ MONITOR ****

CAS-RPM (POS) 712rpm

— — CONDITION SETTING — —

AAC VALVE FIXED

== == MONITOR == ==

ENG TEMP SEN 177°C

IDLE POSITION ON

AIR COND SIG OFF

SEF145I

9

Throttle sensor harness connector

DISCONNECT

SEF408J

10

COMPRESSION PRESSURE

SEF309G

9

CHECK IDLE ADJ. SCREW CLOGGING.

1. Perform "AAC VALVE ADJ" in "WORK SUPPORT" mode.

2. Can you set engine rpm as follows by turning idle adjusting screw?

M/T: 650 ± 50 rpm

A/T: 650 ± 50 rpm

("N" position)

OR

1. Disconnect throttle sensor harness connector.

2. Can you set engine rpm as follows by turning idle adjusting screw?

M/T: 650 ± 50 rpm

A/T: 650 ± 50 rpm

("N" position)

10

CHECK COMPRESSION PRESSURE.

- Check compression pressure.

Standard: kPa (kg/cm², psi)/rpm

1,206 (12.3, 175)/250

Minimum: kPa (kg/cm², psi)/rpm

1,010 (10.3, 146)/250

Difference between each cylinder:

kPa (kg/cm², psi)/rpm

98 (1.0, 14)/250

11

CHECK E.C.U. HARNESS CONNECTOR.

Check the E.C.U. pin terminals for damage or poor connection of E.C.U. harness connector

12

TRY A KNOWN GOOD E.C.U.







INSPECTION END

No → Check for IAS clogging or throttle valve clogging.

N.G. → Check pistons, piston rings, valves, valve seats and cylinder head gas-kets.



N.G. → Repair or replace.

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold




TROUBLE DIAGNOSES

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot



1

CHECK FUEL PRESSURE.

1. Pinch fuel feed hose with fingers.
2. When cranking the engine, is there any pressure on the fuel feed hose?

No

Check fuel pump and circuit. (See page EF & EC-145.)

Yes

2

CHECK FUEL VAPOR.



1. Select "PRVR CONT SOL VALVE" in "ACTIVE TEST" mode.
2. After touching "ON", can you start the engine?

Yes



Check fuel properties.

OR



1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Can you start engine?

No



3

CHECK INJECTOR.

1. Remove crank angle sensor from engine. (Harness connector should remain connected.)
2. Disconnect each ignition wire.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating crank angle sensor shaft, does each injector make an operating sound?

No

Check injector(s) and circuit(s).

Yes

4

CHECK IGNITION SPARK.



1. Disconnect each spark plug cap.
2. Connect a known good spark plug to each spark plug cap.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G.

Check ignition coil, power transistor unit and circuits. (See page EF & EC-112.)


O.K.

(Go to Ⓐ on next page.)









TROUBLE DIAGNOSES

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot (Cont'd)






TROUBLE DIAGNOSES

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions






TROUBLE DIAGNOSES

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 7 — Hesitation when the Engine is Hot



1

CHECK FUEL VAPOR.



1. Select "PRVR CONT SOL VALVE" in "ACTIVE TEST" mode.
2. After touching "ON", perform cruise test.
3. Does the hesitation disappear?

Yes → Check fuel properties.

OR



1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

No

2

CHECK CANISTER PURGE.



1. Disconnect canister purge line hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

Yes → Install suitable small size orifice into the purge line hose.


No

INSPECTION END







TROUBLE DIAGNOSES








Diagnostic Procedure 8 — Hesitation when the Engine is Cold




Diagnostic Procedure 9 — Hesitation under Normal Conditions



TROUBLE DIAGNOSES




Diagnostic Procedure 10 — Engine Stalls when Turning



TROUBLE DIAGNOSES

Diagnostic Procedure 10 — Engine Stalls when Turning (Cont'd)








CAUTION:

When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.

TROUBLE DIAGNOSES

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot



1 CHECK FUEL VAPOR.

1. Select "PRVR CONT SOL VALVE" in "ACTIVE TEST" mode
2. After touching "ON", perform cruise test
3. Does the engine stall disappear?

Yes → Check fuel properties.

OR

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Perform cruise test.
3. Does the engine stall disappear?

No

2 PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 5.

OR

- When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes

3 CHECK INJECTOR.

1. Remove crank angle sensor from engine. (Harness connector should remain connected.)
2. Disconnect each ignition wire.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating crank angle sensor shaft, does each injector make an operating sound?


No → Check injector(s) and circuit(s).

Yes

(Go to A on next page)

TROUBLE DIAGNOSES


Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot (Cont'd)



CAUTION:

When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.

TROUBLE DIAGNOSES



Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold

1

CHECK A.A.C. VALVE.

When the engine is cold, can you start the engine when pressing accelerator pedal fully?

N.G.

Check A.A.C. valve and circuits. (See pages EF & EC-151.)

O.K.

2

PERFORM POWER BALANCE TEST.



1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR





When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

N.G.

Go to **6**.

O.K.



3

CHECK INJECTOR.

1. Remove crank angle sensor from engine. (Harness connector should remain connected.)
2. Disconnect each ignition wire.
3. Turn Ignition switch ON. (Do not start engine.)
4. When rotating crank angle sensor shaft, does each injector make an operating sound?

N.G.

Check injector(s) and circuit(s).

O.K.

4

CHECK IGNITION SPARK.



1. Disconnect each spark plug cap.
2. Connect a known good spark plug to each spark plug cap.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G.

Check ignition coil, power transistor unit and circuits. (See page EF & EC-112.)




O.K.

(Go to **A** on next page.)








TROUBLE DIAGNOSES

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)




CAUTION:

When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.







Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily




TROUBLE DIAGNOSES

Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)







TROUBLE DIAGNOSES

Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)




CAUTION:

When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.








Diagnostic Procedure 14 — Engine Stalls after Decelerating




TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)








CAUTION:

When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.


TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)








Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed



TROUBLE DIAGNOSES







Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed (Cont'd)



CAUTION:


When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy





TROUBLE DIAGNOSES

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)




CAUTION:

When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.



Diagnostic Procedure 17 — Lack of Power and Stumble









CAUTION:




When servicing fuel system after performing "Fuel Pressure Release" in "Work Support" mode, turn off ignition key with CONSULT set in "Work Support" mode.

TROUBLE DIAGNOSES


Diagnostic Procedure 18 — Detonation





TROUBLE DIAGNOSES




Diagnostic Procedure 19 — Surge




TROUBLE DIAGNOSES



Diagnostic Procedure 20 — Backfire through the Intake




Diagnostic Procedure 21 — Backfire through the Exhaust





TROUBLE DIAGNOSES

Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)









Harness layout






TROUBLE DIAGNOSES

Diagnostic Procedure 22 (Cont'd)



TROUBLE DIAGNOSES


Diagnostic Procedure 22 (Cont'd)





TROUBLE DIAGNOSES

Diagnostic Procedure 23

CRANK ANGLE SENSOR (Code No. 11)








Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 23 (Cont'd)




TROUBLE DIAGNOSES

Diagnostic Procedure 23 (Cont'd)




Perform FINAL CHECK by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure 24

AIR FLOW METER (Code No. 12) (CHECK ENGINE LIGHT ITEM)





Harness layout




TROUBLE DIAGNOSES



Diagnostic Procedure 24 (Cont'd)




N.G.





O.K.




N.G.





O.K.




N.G.




O.K.



N.G.




O.K.



TROUBLE DIAGNOSES

Diagnostic Procedure 24 (Cont'd)


Perform FINAL CHECK by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure 25

ENGINE TEMPERATURE SENSOR (Code No. 13)  (CHECK ENGINE LIGHT ITEM)






Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 25 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Start engine.
- 2) Read engine temperature sensor signal in "DATA MONITOR" mode with CONSULT.

Engine temperature should gradually rise and reach more than 70°C (158°F) after engine warm-up.

N.G. → Repair harness or connectors.

OR

- 1) Disconnect engine temperature sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal **b** and ground.

Voltage: Approximately 5V

O.K.

Turn ignition switch "OFF".

Disconnect engine temperature sensor harness connector.

B

CHECK GROUND CIRCUIT.

- 1) Check harness continuity between terminal **a** and engine ground.

Continuity should exist.

N.G. → Repair harness or connectors.

O.K.

CHECK COMPONENT
(Engine temperature sensor).
Refer to "Electrical Components Inspection". (See page EF & EC-173.)

N.G. → Replace engine temperature sensor.


O.K.

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 25 (Cont'd)


Perform **FINAL CHECK** by the following procedure after repair is completed.




TROUBLE DIAGNOSES

Diagnostic Procedure 26

VEHICLE SPEED SENSOR (Code No. 14) (CHECK ENGINE LIGHT ITEM)



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)

A

■ CAR SPEED SEN CIRCUIT ■

AFTER TOUCH START,
DRIVE VEHICLE
AT 10 km/h (6 mph) OR
(MORE WITHIN 15 sec

NEXT START

SEF631L



A

☆ MONITOR ☆ NO FAIL ☐

CAR SPEED SEN 0mph

RECORD


SEF587I



TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)


Perform **FINAL CHECK** by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure 27

IGNITION SIGNAL (Code No. 21)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Disconnect ignition coil harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal ① and ground.

Voltage: Battery voltage

N.G. → Check the following:

- Harness connectors (F1), (E1)
- Harness continuity between ignition switch and ignition coil

If N.G., repair harness or connectors.

O.K. →

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect power transistor harness connector and resistor and condenser harness connector.

B 3) Check harness continuity between terminal ⑤ and terminals ⑥, ⑦.

Continuity should exist.

C 4) Check harness continuity between terminal ④ and engine ground.

Continuity should exist.

N.G. → Repair harness or connectors.

O.K. →

D

CHECK INPUT SIGNAL CIRCUIT.

- 1) Disconnect E.C.U. harness connector.
- 2) Check harness continuity between E.C.U. terminal ③ and terminal ⑧.

Continuity should exist.

N.G. → Repair harness or connectors.

O.K. →

E

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Check harness continuity between E.C.U. terminal ① and terminal ②.

Continuity should exist.


N.G. → Repair harness or connectors.

O.K. →


Ⓐ

TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)




Perform FINAL CHECK by the following procedure after repair is completed.



Diagnostic Procedure 28


E.C.C.S. CONTROL UNIT (Code No. 31)  (CHECK ENGINE LIGHT ITEM)





TROUBLE DIAGNOSES

Diagnostic Procedure 29

E.G.R. FUNCTION (Code No. 32)  **[CHECK ENGINE LIGHT ITEM (For California model)]**
E.G.R. CONTROL [Not self-diagnostic item (For non-California model)]









Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



G

■ EGR CONT S/V CIRCUIT ■

DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT NO YES

SEF239L

G


■ ACTIVE TEST ■

EGR CONT SOL/V ON

MONITOR CAS•RPM (POS) 750rpm

ON ON/OFF OFF

SEF588I



TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed. (California model)


ROAD TEST

Test condition

Drive vehicle under the following conditions with a suitable shift position.

- (1) Engine speed:
M/T: $2,200 \pm 200$ rpm
A/T: $2,100 \pm 300$ rpm
- (2) Intake manifold vacuum:
M/T: -41.3 ± 4.0 kPa
(-310 ± 30 mmHg, -12.20 ± 1.18 inHg)
A/T: -32.0 ± 8.0 kPa
(-240 ± 60 mmHg, -9.45 ± 2.36 inHg)


Driving mode



- ① Start engine and warm it up sufficiently.
- ② Turn off ignition switch and keep it off until red L.E.D. goes off.
- ③ Start engine and make sure that air conditioner switch and rear defogger are turned "OFF" during driving test.
- ④ Keep engine running for at least 3 minutes.
- ⑤ Shift to suitable gear position and drive in "Test condition" for at least 21 seconds.
- ⑥ Decrease engine revolution to less than 2,000 rpm.
- ⑦ Repeat steps ⑤ through ⑥ at least 1 time.

SEF302H

I



CHECK ENGINE LIGHT

SEF924F

FINAL CHECK

Erase the self-diagnosis memory.

Perform driving test under the following conditions.

- 1) Warm up engine sufficiently.
- 2) Use test driving modes indicated in figure H.

Make sure that check engine light does not come on during driving test.

Comes on.

Recheck E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.


Does not come on.

INSPECTION END



TROUBLE DIAGNOSES

Diagnostic Procedure 30

EXHAUST GAS SENSOR (Code No. 33) (CHECK ENGINE LIGHT ITEM)



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 30 (Cont'd)

A

■ MIXTURE RATIO TEST ■

ACCELERATE TO 2000 RPM AND HOLD THEN TOUCH START

1800 2000 2200

NEXT START

SEF632L



A

☆ MONITOR ☆ NO FAIL ☐


CAS-RPM(POS) 2087rpm
M/R F/C MNT LEAN

RECORD

SEF410J




Perform FINAL CHECK by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure 31

EXHAUST GAS TEMPERATURE SENSOR (Code No. 35)  (CHECK ENGINE LIGHT ITEM): CALIFORNIA MODEL ONLY







Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 31 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 31 (Cont'd)


Perform **FINAL CHECK** by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure 32

AIR TEMPERATURE SENSOR (Code No. 41)



Harness layout



TROUBLE DIAGNOSES




Diagnostic Procedure 32 (Cont'd)

A

☆ MONITOR	☆ NO FAIL	▲
INT/A TEMP SE	24°C	
START SIGNAL	OFF	
IDLE POSITION	ON	
AIR COND SIG	OFF	
NEUTRAL SW	ON	
PW/ST SIGNAL	OFF	
LOAD SIGNAL	OFF	

RECORD


SEF5901



TROUBLE DIAGNOSES

Diagnostic Procedure 32 (Cont'd)


Perform FINAL CHECK by the following procedure after repair is completed.



TROUBLE DIAGNOSES



Diagnostic Procedure 33

THROTTLE SENSOR (Code No. 43)  (CHECK ENGINE LIGHT ITEM)









MEF259A

Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 33 (Cont'd)




TROUBLE DIAGNOSES

Diagnostic Procedure 33 (Cont'd)







Perform FINAL CHECK by the following procedure after repair is completed.



TROUBLE DIAGNOSES

Diagnostic Procedure 34


INJECTOR LEAK (Code No. 45)  (CHECK ENGINE LIGHT ITEM); CALIFORNIA MODEL ONLY



TROUBLE DIAGNOSES

Diagnostic Procedure 34 (Cont'd)


Perform **FINAL CHECK** by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure 35

THROTTLE VALVE SWITCH (Not self-diagnostic item)







Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 35 (Cont'd)




TROUBLE DIAGNOSES

Diagnostic Procedure 36

START SIGNAL (Not self-diagnostic item)



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 36 (Cont'd)

A

■ START SIGNAL CKT ■

- 1 CLOSE THROTTLE, SHIFT TO P OR N RANGE
- 2 TOUCH START AND START ENGINE IMMEDIATELY

NEXT START

SEF191L

A

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
IDLE POSITION	ON
AIR COND SIG	OFF
NEUTRAL SW	ON

RECORD

SEF149I

A

C/UNIT CONNECTOR

34

V

CONNECT

SEF958I

B

DISCONNECT

C/UNIT CONNECTOR

34

Ω

DISCONNECT

SEF392J

INSPECTION START

A

CHECK OVERALL FUNCTION.

- 1) Turn ignition switch "ON".
- 2) Perform "START SIGNAL CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

O.K. INSPECTION END

OR

- 1) Turn ignition switch "ON".
- 2) Check start signal in "DATA MONITOR" mode with CONSULT.

IGN "ON"	OFF
IGN "START"	ON

OR

- 1) Turn ignition switch to "START".
- 2) Check voltage between E.C.U. terminal 34 and ground.

Voltage:

Ignition switch "START"

Battery voltage

Except above

Approximately 0V

N.G.

B

CHECK INPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect E.C.U. harness connector and ignition switch harness connector.
- 3) Check harness continuity between E.C.U. terminal 34 and terminal 1.

Continuity should exist.

O.K.

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.

N.G.

Check the following:


- Harness connectors (F51), (R24)
- S.M.J. connectors (H12), (E10)
- 10A fuse
- Harness continuity between E.C.U. and ignition switch

If N.G., repair harness or connectors.



TROUBLE DIAGNOSES

Diagnostic Procedure 37

A.I.V. CONTROL (Not self-diagnostic item)









Harness layout












TROUBLE DIAGNOSES

Diagnostic Procedure 37 (Cont'd)



TROUBLE DIAGNOSES


Diagnostic Procedure 37 (Cont'd)





TROUBLE DIAGNOSES

Diagnostic Procedure 38

P.R.V.R. CONTROL (Not self-diagnostic item)









Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 38 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 38 (Cont'd)



E

CHECK POWER SUPPLY.

- 1) Stop engine.
- 2) Disconnect pressure regulator control solenoid valve harness connector.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminal ① and ground.

Voltage: Battery voltage

N.G.

Check the following:

- Harness connectors (F51), (H24)
- 10A fuse
- Harness continuity between fuse and pressure regulator control solenoid valve

If N.G., repair harness or connectors.

O.K.

G

■ PRVR CONT S/V CIRCUIT ■

DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS ?

NEXT NO YES

SEF623L

F

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect E.C.U. harness connector.
- 3) Check harness continuity between E.C.U. terminal ⑩ and terminal ①.

Continuity should exist.

N.G.

Repair harness or connectors.

O.K.

G

■ ACTIVE TEST ■

PRVR CONT SOL/V OFF

== MONITOR ==

CAS-RPM(POS) 750rpm

ENG TEMP SEN 179°F

EXH GAS SEN 0.92V

INJ PULSE 2.6msec

AAC VALVE 16%

ON ON/OFF OFF

SEF411J

G

CHECK COMPONENT (Pressure regulator control solenoid valve).

Perform "P.R.V.R. CONT S/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

- 1) Reconnect E.C.U. harness connector and pressure regulator control solenoid valve harness connector.
- 2) Start engine.
- 3) Perform "P.R.V.R. CONTROL SOLENOID VALVE TEST" in "ACTIVE TEST" mode with CONSULT.

N.G.

Replace pressure regulator control solenoid valve.

OR



Refer to "Electrical Components Inspection". (See page EF & EC-175.)

O.K.

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 38 (Cont'd)


*NOTE

If engine cannot be warmed up sufficiently for some reason (Extreme cold, etc.), disconnect engine temperature sensor harness connector, and connect a resistor (0.1 k Ω) to engine temperature sensor harness connector.



1) Do not perform this test for a long time.

2) Perform self-diagnosis after this test. If code No. 13 is displayed, erase it.




0.1 k Ω

SEF9711



TROUBLE DIAGNOSES

Diagnostic Procedure 39

INJECTOR (Not self-diagnostic item)









Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 39 (Cont'd)






TROUBLE DIAGNOSES

Diagnostic Procedure 40

FUEL PUMP (Not self-diagnostic item)







Harness layout





TROUBLE DIAGNOSES



Diagnostic Procedure 40 (Cont'd)



- S.M.J. connectors (E101), (M12)
 - Joint connector-3 (E48)
 - 10A fuse
 - Harness continuity between fuse and fuel pump relay
- If N.G., repair harness or connectors.




- S.M.J. connectors (E101), (M13)
 - Harness continuity between fuel pump and body ground
 - Harness continuity between fuel pump and fuel pump relay
- If N.G., repair harness or connectors.



- Harness connectors (F1), (E1)
 - Harness continuity between E.C.U. and fuel pump relay
- If N.G., repair harness or connectors.

TROUBLE DIAGNOSES


Diagnostic Procedure 40 (Cont'd)





TROUBLE DIAGNOSES

Diagnostic Procedure 41

S.C.V. CONTROL (Not self-diagnostic item)









Harness layout





TROUBLE DIAGNOSES

Diagnostic Procedure 41 (Cont'd)




TROUBLE DIAGNOSES

Diagnostic Procedure 41 (Cont'd)





Diagnostic Procedure 42

A.A.C. VALVE (Not self-diagnostic item)









Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 42 (Cont'd)



TROUBLE DIAGNOSES


Diagnostic Procedure 42 (Cont'd)







TROUBLE DIAGNOSES

Diagnostic Procedure 43

RADIATOR FAN CONTROL (Not self-diagnostic item)






Harness layout





TROUBLE DIAGNOSES

Diagnostic Procedure 43 (Cont'd)




TROUBLE DIAGNOSES

Diagnostic Procedure 43 (Cont'd)



PROCEDURE A

INSPECTION START




N.G.

Check the following:

- Joint connector-2 (E47), -4 (E49)
 - S.M.J. connectors (E101), (M12)
 - "G" fusible link
 - 10A fuse
 - Harness continuity between battery and radiator fan relay-1, -2
 - Harness continuity between fuse and radiator fan relay-1, -2
- If N.G., repair harness or connectors.

O.K.



N.G.

Check the following:

- Joint connector-4 (E49)
 - Harness continuity between radiator fan relay-1 and radiator fan motor-1, -2
 - Harness continuity between radiator fan relay-2 and radiator fan motor-1, -2
 - Harness continuity between radiator fan motor-1, -2 and body ground
- If N.G., repair harness or connectors.

O.K.

A

TROUBLE DIAGNOSES

Diagnostic Procedure 43 (Cont'd)

E

■ RADIATOR FAN CIRCUIT ■

DOES
RADIATOR FAN
ROTATE AND STOP
EVERY 3 SECONDS?

NEXT NO YES

SEF5961

E

■ ACTIVE TEST ■


RADIATOR FAN OFF

== MONITOR ==

ENG TEMP SEN 177°F

HI LOW OFF

SEF5961



SEF238J

E

DISCONNECT H.S. DISCONNECT T.S.

C/UNIT CONNECTOR

5 3 2 1

OFF

Ω

SEF9991

E

Ⓐ

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Reconnect radiator fan relay-1 and -2, radiator fan motor-1 harness connector and radiator fan motor-2 harness connector.
- 2) Start engine.
- 3) Turn radiator fan relay "ON" in "ACTIVE TEST" mode with CONSULT.
- 4) Check voltage between terminals Ⓑ, Ⓓ and ground.
Voltage:
Battery voltage
— OR —

1) Disconnect E.C.U. harness connector.
2) Check harness continuity between E.C.U. terminal Ⓖ and terminal Ⓐ.
Continuity should exist.

N.G. → Check the following:

- Harness connectors (F2), (E2)
- Joint connector-1 (E46)
- Harness continuity between E.C.U. and radiator fan relay- 1, -2

If N.G., repair harness or connectors.

OR

1) Check COMPONENTS (Radiator fan relay-1 and -2). Perform "RADIATOR FAN TEST CIRCUIT" in "ACTIVE TEST" mode with CONSULT.

OR

1) Perform "RADIATOR FAN TEST" in "ACTIVE TEST" mode with CONSULT. If N.G., replace malfunctioning component(s).

O.K. →

CHECK COMPONENTS (Radiator fan relay-1, -2, radiator fan motor-1 and -2). Refer to "Electrical Components Inspection". (See page EF & EC-177.)



N.G. → Replace malfunctioning component(s).

O.K. →

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 43 (Cont'd)



PROCEDURE B

INSPECTION START

F

CHECK POWER SUPPLY.

- 1) Stop engine.
- 2) Disconnect radiator fan relay-3.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminal ② and ground.

Voltage: Battery voltage

O.K.

N.G.

Check the following:

- Joint connector-2 (E47)
 - S.M.J. connectors (E101), (M12)
 - 10A fuse
 - Harness continuity between fuse and radiator fan relay-3
- If N.G., repair harness or connectors.

G

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect radiator fan motor-1 harness connector and radiator fan motor-2 harness connector.
- 3) Check harness continuity between terminal ③ and terminal ③, terminal ⑤ and body ground.

Continuity should exist.

O.K.

N.G.




Check the following:

- Joint connector-3 (E48)
 - Harness continuity between radiator fan relay-3 and radiator fan motor-1, -2
 - Harness continuity between radiator fan relay-3 and body ground
- If N.G., repair harness or connectors.

Ⓐ

TROUBLE DIAGNOSES


Diagnostic Procedure 43 (Cont'd)





TROUBLE DIAGNOSES

Diagnostic Procedure 44

POWER STEERING OIL PRESSURE SWITCH (Not self-diagnostic item)









Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 44 (Cont'd)



TROUBLE DIAGNOSES


Diagnostic Procedure 44 (Cont'd)






TROUBLE DIAGNOSES

Diagnostic Procedure 45

NEUTRAL/INHIBITOR SWITCH (Not self-diagnostic item)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 45 (Cont'd)



Neutral switch

INSPECTION START

A

CHECK OVERALL FUNCTION.

- 1) Turn ignition switch "ON".
- 2) Perform "NEUTRAL SW CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

O.K. → INSPECTION END

OR

- 1) Turn ignition switch "ON".
- 2) Check neutral switch signal in "DATA MONITOR" mode with CONSULT.

Neutral position: ON

Except above: OFF

OR

- 1) Set shift lever to the neutral position.
- 2) Disconnect E.C.U. harness connector.
- 3) Check harness continuity between E.C.U. terminal 35 and body ground.

Continuity should exist.

N.G.

Turn ignition switch "OFF".

B

CHECK GROUND CIRCUIT.

- 1) Disconnect neutral switch harness connector.
- 2) Check harness continuity between terminal ④ and body ground.

Continuity should exist.

O.K.

Disconnect E.C.U. harness connector.

Ⓐ


N.G. → Check the following:

- Harness connectors (E38, A3)
- Harness continuity between neutral switch and body ground

If N.G., repair harness or connectors.







TROUBLE DIAGNOSES

Diagnostic Procedure 45 (Cont'd)







TROUBLE DIAGNOSES


Diagnostic Procedure 45 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 45 (Cont'd)







Electrical Components Inspection

E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

1. E.C.U. is located behind front passenger side dash. For this inspection, remove the front passenger side dash.



2. Remove E.C.U. harness protector.



3. Perform all voltage measurements with the connectors connected. Extend tester probe as shown to perform tests easily.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

E.C.U. inspection table

*Data are reference values.

TER-MINAL NO.	ITEM	CONDITION	*DATA
1	Ignition signal	Engine is running. └ Idle speed	0.3 - 0.6V
		Engine is running. └ Engine speed is 2,000 rpm	Approximately 1.0V
3	Ignition check	Engine is running. └ Idle speed	9 - 12V
4	E.C.C.S. relay (Main relay)	Engine is running. ↓ Ignition switch "OFF" └ Within approximately 1 second after turning ignition switch "OFF"	0 - 1V
		Ignition switch "OFF" └ For approximately 1 second after turning Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
8	Exhaust gas temperature sensor (Only for California model)	Engine is running. └ Idle speed	1.0 - 2.0V
		Engine is running. └ E.G.R. system is operating.	0 - 1.0V
11	Air conditioner relay	Engine is running. └ Both A/C switch and blower switch are "ON".	0 - 1.0V
		Engine is running └ A/C switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
12	S.C.V. control solenoid valve	Engine is running. └ Idle speed	0 - 1.0V
		Engine is running. └ Engine speed is 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)
16	Air flow meter	Engine is running.	1.0 - 3.0V Output voltage varies with engine revolution.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

*Data are reference values.

TER-MINAL NO.	ITEM	CONDITION	*DATA
18	Engine temperature sensor	Engine is running.	1.0 - 5.0V Output voltage varies with engine water temperature.
19	Exhaust gas sensor	Engine is running. └ After warming up sufficiently.	0 - Approximately 1.0V
20	Throttle sensor	Ignition switch "ON"	0.4 - Approximately 4V Output voltage varies with the throttle valve opening angle.
22 30	Crank angle sensor (Reference signal)	Engine is running. Do not run engine at high speed under no-load.	0.2 - 0.5V
26	Air temperature sensor	Ignition switch "ON" └ Temperature of intake air is 20°C (68°F)	Approximately 1.0 - 1.5V
		Ignition switch "ON" └ Temperature of intake air is 80°C (176°F)	Approximately 0.3V
31 40	Crank angle sensor (Position signal)	Engine is running. Do not run engine at high speed under no-load.	2.0 - 3.0V
33	Idle switch (⊖ side)	Ignition switch "ON" └ Throttle valve: idle position	Approximately 9 - 10V
		Ignition switch "ON" └ Throttle valve: Any position except idle position	0V
34	Start signal	Cranking	8 - 12V
35	Neutral switch & Inhibitor switch	Ignition switch "ON" └ Neutral/Parking	0V
		Ignition switch "ON" └ Except the above gear position	Approximately 6V
36	Ignition switch	Ignition switch "OFF"	0V
		Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
37	Throttle sensor power supply	Ignition switch "ON"	Approximately 5V
38 47	Power supply for E.C.U.	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

*Data are reference values.

TER-MINAL NO.	ITEM	CONDITION	*DATA
41	Air conditioner switch	Engine is running. Both air conditioner switch and blower switch are "ON".	0V
		Engine is running. Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
43	Power steering oil pressure switch	Engine is running. Steering wheel is being turned.	0V
		Engine is running. Steering wheel is not being turned.	8 - 9V
44	Idle switch (⊕ side)	Ignition switch "ON" Throttle valve: idle position	Approximately 9 - 10V
		Ignition switch "ON" Throttle valve: Except idle position	BATTERY VOLTAGE (11 - 14V)
45	Thermo control amp.	Engine is running Air conditioner is operating. Evaporator outlet air temperature is between 3.0 - 8.0°C (37 - 46°F)	Approximately 8 - 9V
		Engine is running. Air conditioner is operating. Evaporator outlet air temperature is over 8°C (46°F)	Approximately 0V
46	Power supply (Back-up)	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
101	Injector No. 1	Engine is running	BATTERY VOLTAGE (11 - 14V)
103	Injector No. 3		
110	Injector No. 2		
112	Injector No. 4		
102	A.I.V. control solenoid valve	Engine is running. Idle speed	0 - 1.0V
		Engine is running. Accelerator pedal is depressed. After warming up	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

*Data are reference values.

TER-MINAL NO.	ITEM	CONDITION	*DATA
104	Fuel pump relay	Ignition switch "ON" For 5 seconds after turning ignition switch "ON" Engine is running.	0.7 - 0.9V
		Ignition switch "ON" Within 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
105	E.G.R. control solenoid valve	Engine is running. Engine is cold. Water temperature is below 60°C (140°F).	0.7 - 0.9V
		Engine is running. After warming up Water temperature is between 60°C (140°F) and 105°C (221°F)	BATTERY VOLTAGE (11 - 14V)
106	Pressure regulator control solenoid valve	Stop and restart engine after warming it up. Water temperature is above 90°C (194°F)	0 - 1.0V (for 3 minutes after ignition switch is turned off.) BATTERY VOLTAGE (After 3 minutes)
		Stop and restart engine after warming it up. Water temperature is below 90°C (194°F)	BATTERY VOLTAGE (11 - 14V)
113	A.A.C. valve	Engine is running. Idle speed	7 - 10V
		Engine is running. Steering wheel is being turned. Air conditioner is operating Rear defogger is "ON". Headlamp are in high position.	4 - 7V

E.C.U. HARNESS CONNECTOR TERMINAL LAYOUT

101	102	103	104	105	106	107	108	1	2	3	4	5	6	7	15	16	17	18	19	20	21	22	31	32	33	34	35	36	37	38	39
109	110	111	112	113	114	115	116	8	9	10	11	12	13	14	23	24	25	26	27	28	29	30	40	41	42	43	44	45	46	47	48




SEF419H

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

E.C.C.S. RELAY

Check continuity between terminals ③ and ⑤.




Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No supply	No


CRANK ANGLE SENSOR

1. Remove distributor from engine. (crank angle sensor harness connector is connected.)
2. Turn ignition switch "ON".
3. Rotate crank angle sensor shaft slowly and check voltage between terminals ①, ② and ground.

Voltage fluctuates between 5V and 0V.




4. Visually check rotor plate for damage or dust.



AIR FLOW METER


- Visually check hot wire air passage for dust.



ENGINE TEMPERATURE SENSOR

Check engine temperature sensor resistance.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.30 - 0.33




TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

IGNITION COIL


Check ignition coil resistance.




Terminal	Resistance
① - ②	Approximately 0.7Ω

POWER TRANSISTOR

Check continuity between power transistor terminals.




Terminal No.	Tester polarity	Continuity
①	⊕	No
②	⊖	
③	⊖	Yes
④	⊕	
⑤	⊕	No
⑥	⊖	
⑦	⊖	Yes
⑧	⊕	



E.G.R. CONTROL VALVE

Apply vacuum to E.G.R. vacuum port with a hand vacuum pump.

E.G.R. control valve spring should lift.




B.P.T. VALVE

Plug one of two ports of B.P.T. valve.

Apply a pressure above 0.490 kPa (50 mmH₂O, 1.97 inH₂O) to check for leakage. If a leak is noted, replace valve.

TROUBLE DIAGNOSES




Electrical Components Inspection (Cont'd)

E.G.R. CONTROL SOLENOID VALVE, A.I.V. CONTROL SOLENOID VALVE, P.R. CONTROL SOLENOID VALVE AND S.C.V. CONTROL SOLENOID VALVE

Check air passages continuity.

Condition	Air passage continuity between ① and ②	Air passage continuity between ① and ③
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes



EXHAUST GAS SENSOR

Refer to "Diagnostic Procedure 30". (See page EF & EC-119.)

EXHAUST GAS TEMPERATURE SENSOR


Check resistance change and resistance value at 100°C (212°F).

- Resistance should decrease in response to temperature increase.

Resistance: 100°C (212°F)

85.3 ± 8.53 kΩ

If N.G., replace exhaust gas temperature sensor.



AIR TEMPERATURE SENSOR

Check air temperature sensor resistance.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

POWER STEERING OIL PRESSURE SWITCH

1. Disconnect power steering oil pressure switch harness connector.
2. Check resistance between terminals.

Resistance: Approximately 2 - 3Ω

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

THROTTLE SENSOR



1. Disconnect throttle sensor harness connector.
2. Make sure that resistance between terminals ② and ③ changes when opening throttle valve manually.

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9

If N.G., replace throttle sensor.

Adjustment


If throttle sensor is replaced or removed, it is necessary to install it in the proper position, by following the procedure as shown below:




1. Install throttle sensor body in throttle chamber. Do not tighten bolts.
2. Connect throttle sensor and idle switch harness connector.
3. Start engine and warm it up sufficiently.
4. Perform "THROTTLE SEN. ADJ." in "WORK SUPPORT" mode.



Measure output voltage of throttle sensor using voltmeter.



5. Adjust by rotating throttle sensor body so that output voltage is 0.4 to 0.5V.
6. Tighten mounting bolts.
7. Disconnect throttle sensor harness connector for a few seconds and then reconnect it.



FUEL PUMP

Check continuity between terminals ④ and ⑤.


Continuity should exist.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

FUEL PUMP RELAY, RADIATOR FAN REAY-1, -2 AND-3

Check continuity between terminals ① and ②.



Condition	Continuity
12V direct current supply between terminals ③ and ④	Yes
No supply	No


INJECTORS

- Check injector resistance.

Resistance:

Approximately 10 - 15Ω


- Remove injector and check nozzle for clogging.



SWIRL CONTROL VALVE

Supply vacuum to actuator and check swirl control valve operation.

Condition	Swirl control valve
Supply vacuum to actuator	Close
No supply	Open




A.A.C. VALVE


- Check A.A.C. valve resistance.

Resistance:

Approximately 10Ω [at 20°C (68°F)]



- Check plunger for seizure or sticking.
- Check spring for broken.




TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

AIR INDUCTION VALVE


Apply vacuum to vacuum motor, suck or blow hose to make sure that air flows only towards the air induction side.



THROTTLE VALE SWITCH (Idle position)

Unit check


- Check continuity between terminals ② and ③ while moving throttle valve.



Throttle valve condition	Continuity
Fully closed	Yes
Open	No

NEUTRAL SWITCH


- Check continuity between terminals ③ and ④.



Conditions	Continuity
Shift to Neutral	Yes
Shift to other position	No

INHIBITOR SWITCH


Check continuity between terminals ② and ③.



Conditions	Continuity
Shift to "P" position	Yes
Shift to "N" position	Yes
Shift to positions other than "P" and "N"	No

INHIBITOR RELAY


Check continuity between terminals ③ and ⑤.



Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If N.G., replace relay.

FUEL INJECTION CONTROL SYSTEM INSPECTION



Releasing Fuel Pressure


Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.



Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.




1. Remove fuel pump relay.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch off and reconnect fuel pump relay.



Fuel Pressure Check

- a. When reconnecting fuel line, always use new clamps.
 - b. Make sure that clamp screw does not contact adjacent parts.
 - c. Use a torque driver to tighten clamps.
 - d. Use Pressure Gauge to check fuel pressure.
 - e. Do not perform fuel pressure check while fuel pressure regulator control system is operating; otherwise, fuel pressure gauge might indicate incorrect readings.
1. Release fuel pressure to zero.
 2. Remove air duct.
 3. Disconnect fuel hose between fuel filter and fuel tube (engine side).
 4. Install pressure gauge between fuel filter and fuel tube.
 5. Install air duct.
 6. Start engine and check for fuel leakage.



7. Read the fuel pressure gauge indication.

At idling:

When fuel pressure regulator valve vacuum hose is connected
More than 226 kPa (2.3 kg/cm², 33 psi)


When fuel pressure regulator valve vacuum hose is disconnected
Approximately 294 kPa (3.0 kg/cm², 43 psi)

8. Stop engine and disconnect vacuum hose from fuel pressure regulator.
9. Plug vacuum hose.

FUEL INJECTION CONTROL SYSTEM INSPECTION

Fuel Pressure Check (Cont'd)


10. Connect variable vacuum source to fuel pressure regulator.



11. Start engine and read fuel pressure gauge indication as vacuum changes.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.

Injector Removal and Installation




REMOVAL

1. Release fuel pressure to zero.
2. Remove or disconnect the following:
 - Air duct
 - Fuel hoses
 - Fuel pressure regulator.
 - Accelerator wire bracket
 - Fuel injector harness connectors


FUEL INJECTION CONTROL SYSTEM INSPECTION

Injector Removal and Installation (Cont'd)

3. Remove fuel tube securing bolts.



4. Move fuel tube as shown and take out injectors from #4 injector.



INSTALLATION


1. Clean exterior of injector tail piece.
2. Replace O-rings and insulators with new ones.
3. Install injectors.
4. Install any parts removed.

CAUTION:

After properly connecting injectors to fuel tube, check connections for fuel leakage.

EVAPORATIVE EMISSION CONTROL SYSTEM

Description




The evaporative emission control system is used to reduce hydrocarbons emitted to the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.

Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum increases, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.



Inspection

CARBON CANISTER

Check carbon canister as follows:


- Ⓐ : Blow air and ensure that there is no leakage.
- Ⓑ : Blow air and ensure that there is leakage.

EVAPORATIVE EMISSION CONTROL SYSTEM

Inspection (Cont'd)


FUEL TANK VACUUM RELIEF VALVE

1. Wipe valve housing clean.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. If valve is clogged or if no resistance is felt, replace cap as an assembly.




FUEL CHECK VALVE

1. Blow air through connector on fuel tank side.
A considerable resistance should be felt and a portion of air flow should be directed toward the canister.
2. Blow air through connector on canister side.
Air flow should be smoothly directed toward fuel tank.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.



CRANKCASE EMISSION CONTROL SYSTEM



Description

This system returns blow-by gas to both the intake manifold and air cleaner.

The positive crankcase ventilation (P.C.V.) valve is provided to conduct crankcase blow-by gas to the intake manifold.


During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the P.C.V. valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air cleaner, through the hose connecting the air cleaner to rocker cover, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and its flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by some of the flow will go through the hose connection to the air cleaner under all conditions.



Inspection

P.C.V. (Positive Crankcase Ventilation)

With engine running at idle, remove ventilation hose from P.C.V. valve; if valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

IGNITION TIMING	B.T.D.C.	$15^{\circ} \pm 2^{\circ}$
IDLE SPEED	rpm	M/T $700 \pm 50^*1$, $750 \pm 50^*2$ A/T $700 \pm 50^*1$, $750 \pm 50^*2$ (in "N" position)

*1: For U.S.A.

*2: For Canada

Inspection and Adjustment

IGNITION COIL

Primary voltage	V	12
Primary resistance [at 20°C (68°F)]	Ω	Approximately 0.7
Secondary resistance [at 20°C (68°F)]	k Ω	Approximately 8

ENGINE TEMPERATURE SENSOR

Temperature °C (°F)	Resistance k Ω
20 (68)	2.1 - 2.9
80 (176)	0.30 - 0.33

AIR TEMPERATURE SENSOR

Temperature °C (°F)	Resistance k Ω
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

FUEL PRESSURE (at idling)

Unit: kPa (kg/cm², psi)

(Measuring point: between fuel filter and fuel pipe)	
Vacuum hose is connected	Approximately 226 (2.3, 33)
Vacuum hose is disconnected	Approximately 294 (3.0, 43)

IDLE SWITCH

Engine speed when idle switch is changed from "OFF" to "ON"	M/T $1,000 \pm 150$ A/T $1,000 \pm 150$ (in "N" position)
rpm	

EXHAUST GAS TEMPERATURE SENSOR

Resistance [at 100°C (212°F)]	k Ω	85.3 ± 8.53
----------------------------------	------------	-----------------

A.A.C. VALVE

Resistance	Ω	Approximately 10
------------	----------	------------------

INJECTOR

Resistance	Ω	10 - 15
------------	----------	---------

THROTTLE SENSOR

Accelerator pedal conditions	Resistance k Ω
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9

ACCELERATOR CONTROL, FUEL & EXHAUST SYSTEMS

SECTION **FE**

CONTENTS



ACCELERATOR CONTROL SYSTEM	FE-2
FUEL SYSTEM	FE-3
EXHAUST SYSTEM	FE-4



ACCELERATOR CONTROL SYSTEM

CAUTION:

- When removing accelerator cable, make a mark to indicate lock nut's initial position.
- Check that throttle valve opens fully when accelerator pedal is fully depressed and that it returns to idle position when pedal is released.
- Check accelerator control parts for improper contact with any adjacent parts.
- When connecting accelerator cable, be careful not to twist or scratch its inner wire.
- Refer to EL section for A.S.C.D. cable adjustment.



Adjusting Accelerator Cable

1. Loosen lock nut, and tighten adjusting nut until throttle drum starts to move.
2. From that position turn back adjusting nut 1.5 to 2 turns, and fasten it with lock nut.

FUEL SYSTEM


WARNING:

When replacing fuel line parts, be sure to observe the following:

- Put a "CAUTION: INFLAMMABLE" sign in workshop.
- Be sure to furnish workshop with a CO₂ fire extinguisher.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to disconnect battery ground cable before conducting operations.
- Drain fuel from fuel tank and put drained fuel in an explosion-proof container and put lid on securely.


CAUTION:

- Before disconnecting fuel hose, release fuel pressure from fuel line. Refer to "Changing Fuel Filter" in MA section.
- Do not disconnect any fuel line unless absolutely necessary.
- Plug hose and pipe openings to prevent entry of dust or dirt.
- Always replace O-ring and clamps with new ones.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose clamps excessively to avoid damaging hoses.
- Tighten bolts to specified torque.
- When installing fuel check valve, be careful of its designated direction. (Refer to section EF & EC.)
- After installation, run engine and check for fuel leaks at connections.



SFE066A


EXHAUST SYSTEM



SFE180A

CAUTION:

- Always replace exhaust gaskets with new ones when reassembling.
If gasket is left on flange surface, scrape off completely as shown at left.
- With engine running, check all tube connections for exhaust gas leaks, and entire system for unusual noises.
- After installation, check to ensure that mounting brackets and mounting insulators are free from undue stress. If any of the above parts are not installed properly, excessive noise or vibration may be transmitted to the vehicle body.



: N·m (kg-m, ft-lb)

SFE245A

CLUTCH


SECTION **CL**

CONTENTS

PRECAUTIONS AND PREPARATION	CL- 2
CLUTCH SYSTEM — Hydraulic Type	CL- 3
INSPECTION AND ADJUSTMENT	CL- 4
HYDRAULIC CLUTCH CONTROL	CL- 6
CLUTCH RELEASE MECHANISM	CL- 8
CLUTCH DISC AND CLUTCH COVER	CL- 9
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	CL-11



PRECAUTIONS AND PREPARATION



Precautions




- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use Tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. It will ruin the rubber parts of the hydraulic system.

WARNING:



After cleaning clutch disc, wipe it with a dust collector. Do not use compressed air.

Preparation

SPECIAL SERVICE TOOLS


Tool number (Kent-Moore No.) Tool name	Description	
GG94310000 (-) Flare nut torque wrench	Removing and installing clutch piping	
KV30101000 (J33213) Clutch aligning bar	Installing clutch cover and clutch disc	
ST20050010 (-) Base plate	Inspecting diaphragm spring of clutch cover	
ST20050100 (-) Distance piece	Inspecting diaphragm spring of clutch cover	
ST20050240 (-) Diaphragm spring adjusting wrench	Adjusting unevenness of diaphragm spring of clutch cover	

CLUTCH SYSTEM — Hydraulic Type



(L) · Apply lithium-based grease including molybdenum disulphide.
N·m (kg·m, ft·lb)

SCL387




Adjusting Clutch Pedal

1. Adjust pedal height with pedal stopper or clutch switch.

Pedal height "H":

165 - 175 mm (6.50 - 6.89 in)



2. Adjust pedal free play with master cylinder push rod. Then tighten lock nut.

Pedal free play "A₁":

1.0 - 3.0 mm (0.039 - 0.118 in)

Pedal free play means the following total, measured at position of pedal pad:

- Play due to clevis pin and clevis pin hole in clutch pedal.

INSPECTION AND ADJUSTMENT



Adjusting Clutch Pedal (Cont'd)

For U.S.A. model only

3. Adjust clearance "C" between pedal stopper rubber and threaded end of clutch interlock switch while depressing clutch pedal fully.

Clearance C:

0.1 - 1.0 mm (0.004 - 0.039 in)




Bleeding Procedure

Bleed air according to the following procedure.


- **Carefully monitor fluid level at master cylinder during bleeding operation.**
1. Top up reservoir with recommended brake fluid.
 2. Connect a transparent vinyl tube to air bleeder valve of clutch operating cylinder.
 3. Fully depress clutch pedal several times.
 4. With clutch pedal depressed, open bleeder valve to release air.
 5. Close bleeder valve.
 6. Repeat steps 3 through 5 above until clear brake fluid comes out of air bleeder valve.

Clutch Master Cylinder



DISASSEMBLY AND ASSEMBLY

- Push piston into cylinder body with screwdriver when removing and installing valve stopper.



- Align groove of piston assembly and valve stopper when installing valve stopper.
- Check direction of piston cups.

HYDRAULIC CLUTCH CONTROL


Clutch Master Cylinder (Cont'd)

INSPECTION

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Return spring, for wear or damage
- Dust cover, for cracks, deformation or damage
- Reservoir, for deformation or damage

Operating Cylinder




INSPECTION

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Piston spring, for wear or damage
- Dust cover, for cracks, deformation or damage


CLUTCH RELEASE MECHANISM



INSPECTION

Check the following items, and replace if necessary.



- Release bearing, to see that it rolls freely and is free from noise, cracks, pitting or wear
- Release sleeve and withdrawal lever rubbing surface, for wear, rust or damage



LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.
- **Too much lubricant might damage clutch disc facing.**

CLUTCH DISC AND CLUTCH COVER



Clutch Disc


INSPECTION

Check the following items, and replace if necessary.

- Clutch disc, for burns, discoloration, oil or grease leakage
- Clutch disc, for wear of facing

Wear limit of facing surface to rivet head:

0.3 mm (0.012 in)



- Clutch disc, for backlash of spline

Maximum backlash of spline (at outer edge of disc):

0.9 mm (0.035 in)

- Clutch disc, for runout of facing

Runout limit:

1.0 mm (0.039 in)

Distance of runout check point (from hub center)

107.5 mm (4.23 in)

INSTALLATION

- Apply recommended grease to contact surface of spline portion.
- Too much lubricant might damage clutch facing.

Clutch Cover and Flywheel


INSPECTION AND ADJUSTMENT

- Set Tool and check height and unevenness of diaphragm spring.
- Set 0.4 mm (0.016 in) feeler gauges on distance pieces (ST20050100) when checking diaphragm spring height.

Diaphragm spring height "A":

33.0 - 35.0 mm (1.299 - 1.378 in)


- Check thrust rings for wear or damage by shaking cover assembly and listening for chattering noise, or lightly hammering on rivets for a slightly cracked noise. Replace clutch cover assembly if necessary.
- Check pressure plate and clutch disc contact surface for slight burns or discoloration. Repair pressure plate with emery paper.
- Check pressure plate and clutch disc contact surface for deformation or damage. Replace if necessary.



- Adjust unevenness of diaphragm spring with Tool.

Uneven limit:

0.7 mm (0.028 in)




FLYWHEEL INSPECTION

- Check contact surface of flywheel for slight burns or discoloration. Repair flywheel with emery paper.
- Check flywheel runout.


Runout (Total indicator reading):

Less than 0.15 mm (0.0059 in)



INSTALLATION

- Insert Tool into clutch disc hub when installing clutch cover and disc.
- Tighten bolts in numerical order.
- Be careful not to allow grease to contaminate clutch facing.



SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

CLUTCH CONTROL SYSTEM

Type of clutch control	Hydraulic
------------------------	-----------

CLUTCH MASTER CYLINDER

Inner diameter	mm (in)	15.87 (5/8)
----------------	---------	-------------

CLUTCH OPERATING CYLINDER

Inner diameter	mm (in)	19.05 (3/4)
----------------	---------	-------------

CLUTCH DISC

Unit: mm (in)

Model	225TBL
Facing size (Outer dia. x inner dia. x thickness)	225 x 150 x 3.5 (8.86 x 5.91 x 0.138)
Thickness of disc assembly With load	8.0 - 8.4 (0.315 - 0.331) with 5,394 N (550 kg, 1,213 lb)

CLUTCH COVER

Model	C225S
Full-load	N (kg, lb) 4,413 (450, 992)

Inspection and Adjustment

CLUTCH PEDAL

Unit: mm (in)

Pedal height*	165 - 175 (6.50 - 6.89)
Pedal free play	1.0 - 3.0 (0.039 - 0.118)
Clearance between pedal stopper rubber and clutch interlock switch threaded end while clutch pedal is fully depressed.	0.1 - 1.0 (0.004 - 0.039)

*: Measured from surface of melt sheet to pedal pad

CLUTCH DISC

Unit: mm (in)

Model	225TBL
Wear limit of facing surface to rivet head	0.3 (0.012)
Runout limit of facing	1.0 (0.039)
Distance of runout check point (from the hub center)	107.5 (4.23)
Maximum backlash of spline (at outer edge disc)	0.9 (0.035)

CLUTCH COVER

Unit: mm (in)

Model	C225S
Diaphragm spring height	33.0 - 35.0 (1.299 - 1.378)
Uneven limit of diaphragm spring toe height	0.7 (0.028)

MANUAL TRANSAXLE

SECTION **MT**






CONTENTS

PREPARATION	MT- 2
ON-VEHICLE SERVICE	MT- 5
REMOVAL AND INSTALLATION	MT- 7
TRANSAXLE GEAR CONTROL	MT- 9
MAJOR OVERHAUL	MT-10
DISASSEMBLY	MT-13
REPAIR FOR COMPONENT PARTS	MT-16
ADJUSTMENT	MT-30
ASSEMBLY	MT-34
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	MT-38









PREPARATION



SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
KV38106500 (J34284) Preload adapter	Measuring turning torque of final drive assembly Measuring total turning torque Measuring clearance between side gear and differential case with washer Selecting differential side bearing adjusting shim 
KV32101000 (J25689-A) Pin punch	Removing and installing retaining pin 
ST22730000 (J25681) Puller	Removing mainshaft front and rear bearing inner race 
ST30031000 (J22912-01) Puller	Removing input shaft front and rear bearing Removing 4th & 5th main gear 
ST30021000 (J22912-01) Puller	Removing 5th synchronizer Removing 3rd & 4th synchronizer Removing 2nd & 3rd main gear 
ST3306S001 (—) Differential side bearing puller set ① ST33051001 (—) Puller ② ST33061000 (J8107-2) Adapter	Removing differential side bearing inner race  a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.
ST33290001 (J34286) Puller	Removing differential oil seal Removing mainshaft rear bearing outer race Removing differential side bearing outer race 



PREPARATION


Tool number (Kent-Moore No.) Tool name	Description
ST33400001 (J26082) Drift	Installing differential oil seal  a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.
ST30600000 (J25863-01) Drift	Installing input shaft front bearing  a: 36 mm (1.42 in) dia. b: 31 mm (1.22 in) dia.
ST22452000 (—) Drift	Installing 3rd, 4th and 5th main gear  a: 45 mm (1.77 in) dia. b: 36 mm (1.42 in) dia.
ST30621000 (J25742-5) Drift	Installing mainshaft rear bearing outer race (Use with ST30611000.)  a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.
ST30611000 (J25742-1) Drift	Installing mainshaft rear bearing outer race (Use with ST30621000.) 
ST307200000 (—) Drift	Installing differential side bearing outer race  a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.
(J34290) Shim selecting tool set	Selecting differential side bearing ad- justing shim 

PREPARATION

Tool number (Kent-Moore No.) Tool name	Description
(J34305) Snap ring remover and installer	Removing and installing stopper ring of shift fork 
(J25407-2)	Measuring reverse baulk ring wear 

COMMERCIAL SERVICE TOOLS



Tool name	Description
Drift	Installing differential side bearing in- ner race  a: 45 mm (1.77 in) dia. b: 41 mm (1.61 in) dia.
Drift	Installing striking rod oil seal  a: 38 mm (1.50 in) dia. b: 20 mm (0.79 in) dia.



Replacing Oil Seal


DIFFERENTIAL OIL SEAL

1. Drain gear oil from transaxle.
 2. Remove drive shafts — Refer to section FA.
 3. Remove differential oil seal.
 4. Install differential oil seal.
- **Apply multi-purpose grease to seal lip of oil seal before installing.**
5. Install drive shafts — Refer to section FA.




STRIKING ROD OIL SEAL


1. Remove transaxle control rod from yoke.
 2. Remove retaining pin of yoke.
- **Be careful not to damage boot.**



3. Remove striking rod oil seal.



4. Install striking rod oil seal.
- **Apply multi-purpose grease to seal lip of oil seal before installing.**




Position Switch Check

BACK-UP LAMP SWITCH AND NEUTRAL SWITCH

- Check continuity.

Gear position	Continuity
Reverse	② — ④
Neutral	① — ③
Except reverse and neutral	No



Viscous Coupling Check

1. Apply parking brake firmly and place shift lever in the neutral position.
2. Jack up front wheels.
3. Rotate one front wheel and check turning direction of the other front wheel.


Turning direction of the two wheels is opposite:

The viscous coupling is not functioning normally.

Turning direction of the two wheels is the same:




If differential side gear and pinion mate gear thrust washers are O.K., viscous coupling is functioning normally.

REMOVAL AND INSTALLATION



Removal


1. Remove battery and bracket.
2. Remove air cleaner box with air flow meter.
3. Remove air duct.
4. Remove A.I.V. unit.
5. Remove clutch operating cylinder from transaxle.
6. Remove clutch hose clamp.
7. Disconnect speedometer pinion and position switch connectors.
8. Remove transaxle breather hose clamp.
9. Remove starter motor from transaxle.
10. Remove shift control rod from transaxle.
11. Drain gear oil from transaxle.
12. Remove exhaust front tube.



REMOVAL AND INSTALLATION

Removal (Cont'd)

13. Draw out drive shafts from transaxle.



14. Support engine by placing a jack under oil pan.


CAUTION:

Do not place jack under oil pan drain plug.

15. Remove rear and L.H. mounts.


16. Remove bolts securing transaxle.

17. Lower transaxle while supporting it with a jack.




Installation

1. Tighten bolts securing transaxle.



Bolt No.	Tightening torque N·m (kg-m, ft-lb)	mm (in)
1	39 - 49 (4.0 - 5.0, 29 - 36)	45 (1.77)
2	39 - 49 (4.0 - 5.0, 29 - 36)	25 (0.98)
3	30 - 40 (3.1 - 4.1, 22 - 30)	30 (1.18)
4	30 - 40 (3.1 - 4.1, 22 - 30)	40 (1.57)

Case Components




SMT463B

Gear Components

Apply gear oil to gears, shafts, synchronizers and bearings when assembling.


-  : N·m (kg·m, ft·lb)
- ★ : Select with proper thickness.
- ☆ : Pay attention to its direction.
-  : Apply recommended sealant (Nissan genuine part: KP610-00250) or equivalent.




SMT555B




DISASSEMBLY




1. Before removing transmission case, remove bolts and plugs as shown left.
2. Remove transmission case.




3. Remove position switch.



4. Mesh 4th gear, and then remove reverse idler shaft and reverse idler gear.




5. Pull out retaining pin from clutch housing.




6. Remove reverse lever spring and reverse lock spring from reverse lever assembly.


DISASSEMBLY




7. Remove reverse arm shaft while rotating it.




8. Remove reverse lever assembly.



9. Remove 5th & reverse check plug, spring and ball.




10. Remove stopper rings and retaining pins from 5th & reverse and 3rd & 4th fork rods.
11. Remove 5th & reverse and 3rd & 4th fork rods. Then remove forks and brackets.




12. Remove both input and mainshafts with 1st & 2nd fork and fork rod as a set.
13. Remove final drive assembly.



DISASSEMBLY




14. Remove reverse check assembly.








15. Remove retaining pin and detach the selector.



16. Remove drain plug for convenience in removing retaining pin which holds striking lever to striking rod.



17. Remove retaining pin and then withdraw striking lever and striking rod.



Input Shaft and Gears

DISASSEMBLY

1. Before disassembly, check 3rd, 4th and 5th input gear end plays.

Gear end play

Gears	End play mm (in)
3rd input gear	0.23 - 0.43 (0.0091 - 0.0169)
4th input gear	0.25 - 0.55 (0.0098 - 0.0217)
5th input gear	0.23 - 0.48 (0.0091 - 0.0189)

- If not within specification, disassemble and check contact surface of gear, shaft and hub. Then check clearance of snap ring and thrust washer — Refer to "Assembly".

2. Remove input shaft rear bearing.


3. Remove 5th & reverse synchronizer and 5th input gear.

4. Remove thrust washer ring, thrust washers and 4th input gear.


REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



5. Remove snap ring.



6. Remove 3rd & 4th synchronizer and 3rd input gear.



7. Remove input shaft front bearing.




INSPECTION

Gear and shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.


Synchronizer

- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for wear or deformation.



REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



- Measure clearance between baulk ring and gear (4th and 5th).


Clearance between baulk ring and gear:

Standard

1.0 - 1.35 mm (0.0394 - 0.0531 in)

Wear limit

0.7 mm (0.028 in)



- **Measure wear of reverse baulk ring.**

- Place reverse baulk ring on Tool and then place reverse synchronizer cone on reverse baulk ring.

- **Make sure projection of synchronizer cone is positioned over the recess on Tool.**


- While holding reverse synchronizer cone against reverse baulk ring as firmly as possible, measure dimension "A" with dial indicator.

Wear limit:

Dimension "A"

1.2 mm (0.047 in)


- If dimension "A" is smaller than the wear limit, replace baulk ring.



Bearing


- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.

ASSEMBLY




REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



1. Place inserts in three grooves on coupling sleeve (3rd & 4th synchronizer).




2. Install 3rd input gear and 3rd baulk ring.
3. Press on 3rd & 4th synchronizer hub.
- **Pay attention to its direction.**
4. Select proper snap ring of 3rd & 4th synchronizer hub to minimize clearance of groove, and then install it.

Allowable clearance of groove:

0 - 0.1 mm (0 - 0.004 in)

Snap ring of 3rd & 4th synchronizer hub:

Refer to S.D.S.



5. Install 4th input gear.
6. Select proper thrust washers to minimize clearance of groove.


Then install them and thrust washer ring.

Allowable clearance of groove:

0 - 0.06 mm (0 - 0.0024 in)

Input shaft thrust washer:


Refer to S.D.S.




7. Install 5th & reverse synchronizer assembly.
 - a. Hook insert springs on reverse baulk ring.

REPAIR FOR COMPONENT PARTS


Input Shaft and Gears (Cont'd)




- b. Install insert springs with reverse baulk ring onto coupling sleeve.
- **Pay attention to position of insert springs.**
- c. Place 5th baulk ring on 5th input gear.
- d. Install reverse synchronizer cone on reverse baulk ring.




- e. Place reverse synchronizer assembly on 5th input gear.
- **Mesh recesses of 5th input gear with projections of reverse synchronizer cone.**
- **Put insert spring mounts on reverse baulk ring upon those on 5th baulk ring.**




- f. Press on 5th & reverse synchronizer assembly with 5th input gear.



- 8. Install input shaft front and rear bearings.
- 9. Measure gear end play as the final check — Refer to "Disassembly".



REPAIR FOR COMPONENT PARTS



Mainshaft and Gears


DISASSEMBLY

- Before disassembly, check 1st and 2nd main gear end plays.


Gear end play

Gears	End play mm (in)
1st main gear	0.23 - 0.43 (0.0091 - 0.0169)
2nd main gear	0.23 - 0.58 (0.0091 - 0.0228)


If not within specification, disassemble and check contact surface of gear, shaft and hub. Then check clearance of snap ring — Refer to "Assembly".



- Press out mainshaft rear bearing.



- Remove thrust washer and snap ring.




- Press out 5th main gear and 4th main gear.


REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)


5. Press out 3rd main gear and 2nd main gear.




6. Remove snap ring.



7. Remove 1st & 2nd synchronizer and 1st main gear.




8. Remove mainshaft front bearing.



INSPECTION

Gear and shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.





REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)

Synchronizer

- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for deformation.



- Measure clearance between baulk ring and gear (1st & 2nd).


Clearance between baulk ring and gear:

Standard

1.0 - 1.35 mm (0.0394 - 0.0531 in)

Wear limit



0.7 mm (0.028 in)



Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- When replacing tapered roller bearing, replace outer and inner race as a set.


ASSEMBLY





1. Place inserts in three grooves on coupling sleeve (1st & 2nd synchronizer).

REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




2. Install 1st main gear and 1st baulk ring.
3. Press on 1st & 2nd synchronizer hub.
- Pay attention to its direction.



4. Install coupling sleeve with three inserts and 2nd baulk ring.
5. Select proper snap ring of 1st & 2nd synchronizer hub to minimize clearance of groove and then install it.
Allowable clearance of groove:
0 - 0.1 mm (0 - 0.004 in)
Snap ring of 1st & 2nd synchronizer hub:
Refer to S.D.S.




6. Install 2nd main gear.
7. Press on 3rd main gear.



8. Press on 4th main gear.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




9. Press on 5th main gear.
10. Select proper snap ring of 5th main gear to minimize clearance of groove and then install it.

Allowable clearance of groove:


0 - 0.15 mm (0 - 0.0059 in)

Snap ring of 5th main gear:


Refer to S.D.S.



11. Press on thrust washer and press on mainshaft rear bearing.




12. Press on mainshaft front bearing.
13. Measure gear end play as the final check — Refer to "Disassembly".



Final Drive

DISASSEMBLY



1. Remove final gear.
 2. Remove speedometer drive gear by cutting it.
 3. Press out differential side bearings.
- **Be careful not to mix up the right and left bearings.**
4. Remove viscous coupling (RS5F50V).



REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)

5. Drive out retaining pin and draw out pinion mate shaft.
6. Remove pinion mate gears and side gears.




INSPECTION

Gear, washer, shaft and case

- Check mating surfaces of differential case, side gears and pinion mate gears.
- Check washers for wear.

Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- When replacing tapered roller bearing, replace outer and inner race as a set.







REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)

Viscous coupling — RS5F50V

- Check case for cracks.
- Check silicone oil for leakage.



ASSEMBLY

1. Attach side gear thrust washers to side gears, then install pinion mate washers and pinion mate gears in place.

2. Insert pinion mate shaft.

- **When inserting, be careful not to damage pinion mate thrust washers.**

3. Measure clearance between side gear and differential case with washers following the procedure below:

- a. Set Tool and dial indicator on side gear.
- b. Move side gear up and down to measure dial indicator deflection. Always measure indicator deflection on both side gears.

Clearance between side gear and differential case with washers:

0.1 - 0.2 mm (0.004 - 0.008 in)


REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)


- c. If not within specification, adjust clearance by changing thickness of side gear thrust washers.

Side gear thrust washer:


Refer to S.D.S.




50A



50V



4. Install retaining pin.
- **Make sure that retaining pin is flush with case.**




5. Install final gear.
6. Install speedometer drive gear.

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)


7. Press on differential side bearings.



Shift Control Components

INSPECTION


- Check contact surface and sliding surface for wear, scratches, projections or other damage.




Case Components

REMOVAL AND INSTALLATION

Input shaft oil seal




- Apply multi-purpose grease to seal lip of oil seal before installing.



Mainshaft front bearing outer race

Mainshaft rear bearing outer race — Refer to "ADJUSTMENT".
Differential side bearing outer race — Refer to "ADJUSTMENT".



ADJUSTMENT


Input Shaft End Play and Differential Side Bearing Preload

If any of the following parts are replaced, adjust input shaft end play.


- Input shaft
- Input shaft bearing
- Clutch housing
- Transmission case

If any of the following parts are replaced, adjust differential side bearing preload.


- Differential case
- Differential side bearing
- Clutch housing
- Transmission case



1. Remove differential side bearing outer race (transmission case side) and shim(s).




2. Reinstall differential side bearing outer race without shim(s).
3. Install input shaft and final drive assembly on clutch housing.
4. Install transmission case without input shaft bearing shim(s). Then tighten it to the specified torque.




5. Using the following procedures, measure clearance between bearings and transmission case.
 - **Differential side**
 - a. Attach dial indicator. If clamp diameter of dial indicator is too small or too large, attach dial indicator using a magnetic stand.

ADJUSTMENT


Input Shaft End Play and Differential Side Bearing Preload (Cont'd)




- b. Insert Tool all the way into differential side gear. Move Tool up and down and measure dial indicator deflection.



- **Input shaft side**
 - a. Set dial indicator on rear end of input shaft.
 - b. Move input shaft up and down and measure dial indicator deflection.
- 6. Select shims with proper thickness with S.D.S. table as a guide.
- 7. Install selected differential side bearing adjusting shim and differential side bearing outer race.



8. Check differential side bearing turning torque.
 - a. Install final drive assembly on clutch housing.
 - b. Install transmission case on clutch housing.
- **Tighten transmission case fixing bolts to the specified torque.**



- c. Measure turning torque of final drive assembly.

**Turning torque of final drive assembly
(New bearing):**
4.9 - 7.8 N·m (50 - 80 kg-cm, 43 - 69 in-lb)

 - When old bearing is used again, turning torque will be slightly less than the above.
 - Make sure torque is close to the specified range.






Mainshaft Bearing Preload

If any of the following parts are replaced, adjust mainshaft bearing preload.

- **Mainshaft**
- **Mainshaft bearings**
- **Clutch housing**
- **Transmission case**

ADJUSTMENT

Mainshaft Bearing Preload (Cont'd)



1. Remove mainshaft rear bearing outer race and shim(s).
2. Reinstall mainshaft rear bearing outer race without shims.
3. Clean mating surfaces of clutch housing and transmission case with solvent.
4. Install mainshaft and mainshaft front bearing outer race into transmission case. Turn mainshaft while holding bearing outer race so that bearings are properly seated.
5. Place Tools (bridge and gauging cylinder) onto machined surface of transmission case, allowing gauging cylinder to rest on surface of mainshaft front bearing outer race. Use proper screw in bridge to lock gauging cylinder in place.
6. Turn bridge over and place Tool (gauging plunger) into gauging cylinder.
7. Place bridge, legs up, onto machined surface of clutch housing and allow gauging plunger to rest upon mating surface where mainshaft front bearing outer race fits.

ADJUSTMENT



Mainshaft Bearing Preload (Cont'd)

8. Measure with feeler gauge distance between gauging cylinder and shoulder of gauging plunger.
9. Use feeler gauge reading to select correct mainshaft preload shim(s).


Mainshaft bearing adjusting shim:

Refer to S.D.S.


10. Install selected mainshaft bearing adjusting shim and mainshaft bearing outer race.
11. Check total turning torque after assembly — Refer to "ASSEMBLY".




ASSEMBLY




1. Install striking lever and striking rod.




2. Install selector and retaining pin.



3. Install reverse gate assembly.




4. Install final drive assembly.
 5. Install input shaft and mainshaft with 1st & 2nd shift fork assembly.
- **Be careful not to damage input shaft oil seal.**





6. Install interlock balls and plunger.


ASSEMBLY




7. Install 3rd & 4th shift fork and bracket, then install 3rd & 4th shift rod, stopper ring and retaining pin.



8. Install interlock balls.




9. Install 5th shift fork and bracket, then install shift rod, stopper ring and retaining pin.




10. Install 5th & reverse check plug, spring and ball.


ASSEMBLY




11. Install reverse lock spring on 5th & reverse bracket.
- Pay attention to its direction.




12. Install check ball and reverse lever spring on reverse lever assembly.
- Apply multi-purpose grease to check ball.
 - Pay attention to direction of reverse lever spring.




13. Install reverse lever assembly on clutch housing.




14. Install reverse arm shaft and retaining pin.




15. Hook reverse lock spring and reverse lever spring on reverse lever assembly.




16. Mesh 4th gear, then install reverse idler gear and shaft.
 - Pay attention to direction of tapped hole.




17. Place magnet on clutch housing.



18. If bearing preload was adjusted, install selected shim(s) into transmission case.
 - To aid in installation of transmission case, place shift selector in the 1st & 2nd shift bracket or between 1st & 2nd bracket and 3rd & 4th bracket.
19. Apply sealant to mating surface of transmission case and install it.
20. Install position switch.



21. Apply sealant to threads of check plugs. Install balls, springs and plugs.
22. After assembly, check that you can shift into each gear smoothly.



23. Measure total turning torque.
 - Total turning torque (New bearing):**
8.8 - 21.6 N·m (90 - 220 kg-cm, 78 - 191 in-lb)
 - When old bearing is used again, preload will be slightly less than the above. Make sure torque is close to the specified range.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

TRANSAXLE

Engine		KA24E		
Transaxle model		RS5F50A	RS5F50V	
Number of speeds		5		
Synchronesh type		Warner		
Shift pattern		135 N 24R		
Gear ratio		1st	3.400	3.285
		2nd	1.955	1.850
		3rd	1.272	1.206
		4th	0.954	0.954
		5th	0.740	0.740
		Rev.	3.428	3.428
Number of teeth	Input gear	1st	15	14
		2nd	22	20
		3rd	33	29
		4th	44	44
		5th	50	50
		Rev.	14	14
	Main gear	1st	51	46
		2nd	43	37
		3rd	42	35
		4th	42	42
		5th	37	37
		Rev.	48	48
	Reverse idler gear		29	29
Oil capacity ℓ (US pt, Imp pt)		4.7 (10, 8-1/4)		

FINAL GEAR

Transaxle model	RS5F50A	RS5F50V
Final gear ratio	3.650	3.895
Number of teeth		
Final gear/Pinion	73/20	74/19
Side gear/Pinion	16/10	16/10

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment

GEAR END PLAY


Gear	End play mm (in)
1st main gear	0.23 - 0.43 (0.0091 - 0.0169)
2nd main gear	0.23 - 0.58 (0.0091 - 0.0228)
3rd input gear	0.23 - 0.43 (0.0091 - 0.0169)
4th input gear	0.25 - 0.55 (0.0098 - 0.0217)
5th input gear	0.23 - 0.48 (0.0091 - 0.0189)

CLEARANCE BETWEEN BAULK RING AND GEAR

Unit: mm (in)

	Standard	Wear limit
1st & 2nd	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)
3rd & 4th	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)
5th	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)

REVERSE BAULK RING



SMT581B

Dimension	Wear limit
A	1.2 mm (0.047 in)

AVAILABLE SNAP RING

3rd & 4th synchronizer hub (At input shaft)

Allowable clearance 0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number
1.95 (0.0768)	32269-03E03
2.00 (0.0787)	32269-03E00
2.05 (0.0807)	32269-03E01
2.10 (0.0827)	32269-03E02

1st & 2nd synchronizer hub

Allowable clearance 0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number
1.95 (0.0768)	32269-03E03
2.00 (0.0787)	32269-03E00
2.05 (0.0807)	32269-03E01
2.10 (0.0827)	32269-03E02

5th main gear

Allowable clearance 0 - 0.15 mm (0 - 0.0059 in)	
Thickness mm (in)	Part number
1.95 (0.0768)	32348-05E00
2.05 (0.0807)	32348-05E01
2.15 (0.0846)	32348-05E02
2.25 (0.0886)	32348-05E03

AVAILABLE WASHER

Input shaft thrust washer

Allowable clearance 0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number
4.500 (0.1772)	32278-03E01
4.525 (0.1781)	32278-03E02
4.550 (0.1791)	32278-03E03
4.575 (0.1801)	32278-03E04

Differential side gear thrust washer — RS5F50A

Allowable clearance between side gear and differential case with washer 0.1 - 0.2 mm (0.004 - 0.008 in)	
Thickness mm (in)	Part number
0.75 - 0.80 (0.0295 - 0.0315)	38424-E3000 38424-E3020
0.80 - 0.85 (0.0315 - 0.0335)	38424-E3001 38424-E3021
0.85 - 0.90 (0.0335 - 0.0354)	38424-E3002 38424-E3022
0.90 - 0.95 (0.0354 - 0.0374)	38424-E3003 38424-E3023

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

Differential side gear thrust washer — RS5F50V

Allowable clearance between side gear and (differential case or viscous coupling) with washer		0.1 - 0.2 mm (0.004 - 0.008 in)
	Thickness mm (in)	Part number
Differential case side	0.75 - 0.80 (0.0295 - 0.0315)	38424-E3000
	0.80 - 0.85 (0.0315 - 0.0335)	38424-E3001
	0.85 - 0.90 (0.0335 - 0.0354)	38424-E3002
	0.90 - 0.95 (0.0354 - 0.0374)	38424-E3003
Viscous coupling side	0.43 - 0.45 (0.0169 - 0.0177)	38424-51E10
	0.52 - 0.54 (0.0205 - 0.0213)	38424-51E11
	0.61 - 0.63 (0.0240 - 0.0248)	38424-51E12
	0.70 - 0.72 (0.0276 - 0.0283)	38424-51E13
	0.79 - 0.81 (0.0311 - 0.0319)	38424-51E14

Mainshaft bearing adjusting shim

Thickness mm (in)	Part number
0.40 (0.0157)	32139-03E11
0.44 (0.0173)	32139-03E00
0.48 (0.0189)	32139-03E01
0.52 (0.0205)	32139-03E12
0.56 (0.0220)	32139-03E02
0.60 (0.0236)	32139-03E03
0.64 (0.0252)	32139-03E04
0.68 (0.0268)	32139-03E05
0.72 (0.0283)	32139-03E06
0.76 (0.0299)	32139-03E07
0.80 (0.0315)	32139-03E08
1.20 (0.0472)	32139-03E13

AVAILABLE SHIM

— INPUT SHAFT END PLAY AND MAINSHAFT AND DIFFERENTIAL SIDE BEARING PRELOAD AND ADJUSTING SHIM

Bearing preload and end play

Unit: mm (in)

Mainshaft bearing preload	0.25 - 0.31 (0.0098 - 0.0122)
Input shaft end play	-0.06 to 0 (-0.0024 to 0)
Differential side bearing preload	0.40 - 0.46 (0.0157 - 0.0181)

Turning torque (New bearing)

Unit: N·m (kg-cm, in-lb)


Final drive only	4.9 - 7.8 (50 - 80, 43 - 69)
Total	8.8 - 21.6 (90 - 220, 78 - 191)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

Table for selecting mainshaft adjusting shim

Unit: mm (in)



SMT467B

Dimension "C"	Suitable shim(s)
0.30 - 0.34 (0.0118 - 0.0134)	0.60 (0.0236)
0.34 - 0.38 (0.0134 - 0.0150)	0.64 (0.0252)
0.38 - 0.42 (0.0150 - 0.0165)	0.68 (0.0268)
0.42 - 0.46 (0.0165 - 0.0181)	0.72 (0.0283)
0.46 - 0.50 (0.0181 - 0.0197)	0.76 (0.0299)
0.50 - 0.54 (0.0197 - 0.0213)	0.80 (0.0315)
0.54 - 0.58 (0.0213 - 0.0228)	0.40 + 0.44 (0.0157 + 0.0173)
0.58 - 0.62 (0.0228 - 0.0244)	0.44 + 0.44 (0.0173 + 0.0173)
0.62 - 0.66 (0.0244 - 0.0260)	0.44 + 0.48 (0.0173 + 0.0189)
0.66 - 0.70 (0.0260 - 0.0276)	0.48 + 0.48 (0.0189 + 0.0189)
0.70 - 0.74 (0.0276 - 0.0291)	0.48 + 0.52 (0.0189 + 0.0205)
0.74 - 0.78 (0.0291 - 0.0307)	0.52 + 0.52 (0.0205 + 0.0205)
0.78 - 0.82 (0.0307 - 0.0323)	0.52 + 0.56 (0.0205 + 0.0220)
0.82 - 0.86 (0.0323 - 0.0339)	0.56 + 0.56 (0.0220 + 0.0220)
0.86 - 0.90 (0.0339 - 0.0354)	0.56 + 0.60 (0.0220 + 0.0236)
0.90 - 0.94 (0.0354 - 0.0370)	0.60 + 0.60 (0.0236 + 0.0236)
0.94 - 0.98 (0.0370 - 0.0386)	0.60 + 0.64 (0.0236 + 0.0252)
0.98 - 1.02 (0.0386 - 0.0402)	0.64 + 0.64 (0.0252 + 0.0252)
1.02 - 1.06 (0.0402 - 0.0417)	0.64 + 0.68 (0.0252 + 0.0268)
1.06 - 1.10 (0.0417 - 0.0433)	0.68 + 0.68 (0.0268 + 0.0268)
1.10 - 1.14 (0.0433 - 0.0449)	0.68 + 0.72 (0.0268 + 0.0283)
1.14 - 1.18 (0.0449 - 0.0465)	0.72 + 0.72 (0.0283 + 0.0283)
1.18 - 1.22 (0.0465 - 0.0480)	0.72 + 0.76 (0.0283 + 0.0299)
1.22 - 1.26 (0.0480 - 0.0496)	0.76 + 0.76 (0.0299 + 0.0299)
1.26 - 1.30 (0.0496 - 0.0512)	0.76 + 0.80 (0.0299 + 0.0315)
1.30 - 1.34 (0.0512 - 0.0528)	0.80 + 0.80 (0.0315 + 0.0315)
1.34 - 1.38 (0.0528 - 0.0543)	0.44 + 1.20 (0.0173 + 0.0472)
1.38 - 1.42 (0.0543 - 0.0559)	0.48 + 1.20 (0.0189 + 0.0472)
1.42 - 1.46 (0.0559 - 0.0575)	0.52 + 1.20 (0.0205 + 0.0472)
1.46 - 1.50 (0.0575 - 0.0591)	0.56 + 1.20 (0.0220 + 0.0472)

Input shaft bearing adjusting shim

Thickness mm (in)	Part number
0.40 (0.0157)	32225-08E00
0.44 (0.0173)	32225-08E01
0.48 (0.0189)	32225-08E02
0.52 (0.0205)	32225-08E03
0.56 (0.0220)	32225-08E04
0.60 (0.0236)	32225-08E05
0.64 (0.0252)	32225-08E06
0.68 (0.0268)	32225-08E07
0.72 (0.0283)	32225-08E08
0.76 (0.0299)	32225-08E09
0.80 (0.0315)	32225-08E10
1.20 (0.0472)	32225-08E11

Table for selecting input shaft bearing adjusting shim

Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.65 - 0.69 (0.0256 - 0.0272)	0.64 (0.0252)
0.69 - 0.73 (0.0272 - 0.0287)	0.68 (0.0268)
0.73 - 0.77 (0.0287 - 0.0303)	0.72 (0.0283)
0.77 - 0.81 (0.0303 - 0.0319)	0.76 (0.0299)
0.81 - 0.85 (0.0319 - 0.0335)	0.80 (0.0315)
0.85 - 0.89 (0.0335 - 0.0350)	0.40 + 0.44 (0.0157 + 0.0173)
0.89 - 0.93 (0.0350 - 0.0366)	0.44 + 0.44 (0.0173 + 0.0173)
0.93 - 0.97 (0.0366 - 0.0382)	0.44 + 0.48 (0.0173 + 0.0189)
0.97 - 1.01 (0.0382 - 0.0398)	0.48 + 0.48 (0.0189 + 0.0189)
1.01 - 1.05 (0.0398 - 0.0413)	0.48 + 0.52 (0.0189 + 0.0205)
1.05 - 1.09 (0.0413 - 0.0429)	0.52 + 0.52 (0.0205 + 0.0205)
1.09 - 1.13 (0.0429 - 0.0445)	0.52 + 0.56 (0.0205 + 0.0220)
1.13 - 1.17 (0.0445 - 0.0461)	0.56 + 0.56 (0.0220 + 0.0220)
1.17 - 1.21 (0.0461 - 0.0476)	0.56 + 0.60 (0.0220 + 0.0236)
1.21 - 1.25 (0.0476 - 0.0492)	0.60 + 0.60 (0.0236 + 0.0236)
1.25 - 1.29 (0.0492 - 0.0508)	0.60 + 0.64 (0.0236 + 0.0252)
1.29 - 1.33 (0.0508 - 0.0524)	0.64 + 0.64 (0.0252 + 0.0252)
1.33 - 1.37 (0.0524 - 0.0539)	0.64 + 0.68 (0.0252 + 0.0268)
1.37 - 1.41 (0.0539 - 0.0555)	0.68 + 0.68 (0.0268 + 0.0268)
1.41 - 1.45 (0.0555 - 0.0571)	0.68 + 0.72 (0.0268 + 0.0283)
1.45 - 1.49 (0.0571 - 0.0587)	0.72 + 0.72 (0.0283 + 0.0283)
1.49 - 1.53 (0.0587 - 0.0602)	0.72 + 0.76 (0.0283 + 0.0299)
1.53 - 1.57 (0.0602 - 0.0618)	0.76 + 0.76 (0.0299 + 0.0299)
1.57 - 1.61 (0.0618 - 0.0634)	0.76 + 0.80 (0.0299 + 0.0315)
1.61 - 1.65 (0.0634 - 0.0650)	0.80 + 0.80 (0.0315 + 0.0315)
1.65 - 1.69 (0.0650 - 0.0665)	0.44 + 1.20 (0.0173 + 0.0472)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

Differential side bearing adjusting shim — RS5F50A

Thickness mm (in)	Part number
0.40 (0.0157)	38453-03E11
0.44 (0.0173)	38453-03E00
0.48 (0.0189)	38453-03E01
0.52 (0.0205)	38453-03E12
0.56 (0.0220)	38453-03E02
0.60 (0.0236)	38453-03E03
0.64 (0.0252)	38453-03E04
0.68 (0.0268)	38453-03E05
0.72 (0.0283)	38453-03E06
0.76 (0.0299)	38453-03E07
0.80 (0.0315)	38453-03E08
1.20 (0.0472)	38453-03E13

Table for selecting differential side bearing adjusting shim(s) — RS5F50A

Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.47 - 0.51 (0.0185 - 0.0201)	0.44 + 0.48 (0.0173 + 0.0189)
0.51 - 0.55 (0.0201 - 0.0217)	0.48 + 0.48 (0.0189 + 0.0189)
0.55 - 0.59 (0.0217 - 0.0232)	0.48 + 0.52 (0.0189 + 0.0205)
0.59 - 0.63 (0.0232 - 0.0248)	0.52 + 0.52 (0.0205 + 0.0205)
0.63 - 0.67 (0.0248 - 0.0264)	0.52 + 0.56 (0.0205 + 0.0220)
0.67 - 0.71 (0.0264 - 0.0280)	0.56 + 0.56 (0.0220 + 0.0220)
0.71 - 0.75 (0.0280 - 0.0295)	0.56 + 0.60 (0.0220 + 0.0236)
0.75 - 0.79 (0.0295 - 0.0311)	0.60 + 0.60 (0.0236 + 0.0236)
0.79 - 0.83 (0.0311 - 0.0327)	0.60 + 0.64 (0.0236 + 0.0252)
0.83 - 0.87 (0.0327 - 0.0343)	0.64 + 0.64 (0.0252 + 0.0252)
0.87 - 0.91 (0.0343 - 0.0358)	0.64 + 0.68 (0.0252 + 0.0268)
0.91 - 0.95 (0.0358 - 0.0374)	0.68 + 0.68 (0.0268 + 0.0268)
0.95 - 0.99 (0.0374 - 0.0390)	0.68 + 0.72 (0.0268 + 0.0283)
0.99 - 1.03 (0.0390 - 0.0406)	0.72 + 0.72 (0.0283 + 0.0283)
1.03 - 1.07 (0.0406 - 0.0421)	0.72 + 0.76 (0.0283 + 0.0299)
1.07 - 1.11 (0.0421 - 0.0437)	0.76 + 0.76 (0.0299 + 0.0299)
1.11 - 1.15 (0.0437 - 0.0453)	0.76 + 0.80 (0.0299 + 0.0315)
1.15 - 1.19 (0.0453 - 0.0469)	0.80 + 0.80 (0.0315 + 0.0315)
1.19 - 1.23 (0.0469 - 0.0484)	0.44 + 1.20 (0.0173 + 0.0472)
1.23 - 1.27 (0.0484 - 0.0500)	0.48 + 1.20 (0.0189 + 0.0472)
1.27 - 1.31 (0.0500 - 0.0516)	0.52 + 1.20 (0.0205 + 0.0472)

Differential side bearing adjusting shim — RS5F50V

Thickness mm (in)	Part number
0.36 (0.0142)	38753-56E00
0.40 (0.0157)	38753-56E01
0.44 (0.0173)	38753-56E02
0.48 (0.0189)	38753-56E03
0.52 (0.0205)	38753-56E04
0.56 (0.0220)	38753-56E05
0.60 (0.0236)	38753-56E06
0.64 (0.0252)	38753-56E07
0.68 (0.0268)	38753-56E08
0.72 (0.0283)	38753-56E09
0.76 (0.0299)	38753-56E10
0.80 (0.0315)	38753-56E11
0.84 (0.0331)	38753-56E12
0.88 (0.0346)	38753-56E13
0.92 (0.0362)	38753-56E14

Table for selecting differential side bearing adjusting shim(s) — RS5F50V

Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.47 - 0.51 (0.0185 - 0.0201)	0.44 + 0.48 (0.0173 + 0.0189)
0.51 - 0.55 (0.0201 - 0.0217)	0.48 + 0.48 (0.0189 + 0.0189)
0.55 - 0.59 (0.0217 - 0.0232)	0.48 + 0.52 (0.0189 + 0.0205)
0.59 - 0.63 (0.0232 - 0.0248)	0.52 + 0.52 (0.0205 + 0.0205)
0.63 - 0.67 (0.0248 - 0.0264)	0.52 + 0.56 (0.0205 + 0.0220)
0.67 - 0.71 (0.0264 - 0.0280)	0.56 + 0.56 (0.0220 + 0.0220)
0.71 - 0.75 (0.0280 - 0.0295)	0.56 + 0.60 (0.0220 + 0.0236)
0.75 - 0.79 (0.0295 - 0.0311)	0.60 + 0.60 (0.0236 + 0.0236)
0.79 - 0.83 (0.0311 - 0.0327)	0.60 + 0.64 (0.0236 + 0.0252)
0.83 - 0.87 (0.0327 - 0.0343)	0.64 + 0.64 (0.0252 + 0.0252)
0.87 - 0.91 (0.0343 - 0.0358)	0.64 + 0.68 (0.0252 + 0.0268)
0.91 - 0.95 (0.0358 - 0.0374)	0.68 + 0.68 (0.0268 + 0.0268)
0.95 - 0.99 (0.0374 - 0.0390)	0.68 + 0.72 (0.0268 + 0.0283)
0.99 - 1.03 (0.0390 - 0.0406)	0.72 + 0.72 (0.0283 + 0.0283)
1.03 - 1.07 (0.0406 - 0.0421)	0.72 + 0.76 (0.0283 + 0.0299)
1.07 - 1.11 (0.0421 - 0.0437)	0.76 + 0.76 (0.0299 + 0.0299)
1.11 - 1.15 (0.0437 - 0.0453)	0.76 + 0.80 (0.0299 + 0.0315)
1.15 - 1.19 (0.0453 - 0.0469)	0.80 + 0.80 (0.0315 + 0.0315)
1.19 - 1.23 (0.0469 - 0.0484)	0.72 + 0.92 (0.0283 + 0.0362)
1.23 - 1.27 (0.0484 - 0.0500)	0.76 + 0.92 (0.0299 + 0.0362)
1.27 - 1.31 (0.0500 - 0.0516)	0.80 + 0.92 (0.0315 + 0.0362)

AUTOMATIC TRANSAXLE

SECTION **AT**

CONTENTS

PREPARATION AND PRECAUTIONS	AT- 2
A/T CONTROL DIAGRAM	AT- 4
ON-VEHICLE SERVICE	AT- 6
TROUBLE DIAGNOSES	AT- 8
REMOVAL AND INSTALLATION	AT- 99
MAJOR OVERHAUL	AT-101
DISASSEMBLY	AT-106
REPAIR FOR COMPONENT PARTS	AT-111
ASSEMBLY	AT-141
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	AT-160

AT






When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".



PREPARATION AND PRECAUTIONS

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
ST25420001 (J34285) Clutch spring compressor	Removing and installing clutch springs. 
ST2505S001 (J25695-A) Oil pressure gauge set ① ST25051001 (J25695-1) Oil pressure gauge ② ST25052000 (J25695-2) Hose ③ ST25053000 (J25695-3) Joint pipe ④ ST25054000 (J25695-4) Adapter ⑤ ST25055000 (J25695-5) Adapter	Measuring oil pressure 
KV31101200 (J34282) Oil pressure gauge adapter	Measuring oil pressure 
KV38106500 (J34284) Preload adapter	Checking differential side bearing preload 
ST33290001 (J34286) Side bearing outer race puller	Removing differential side bearing outer race 
ST3127S000 (See J25765-A) Preload gauge ① GG91030000 (J25765-A) Torque wrench ② HT62940000 (—) Socket adapter ③ HT62900000 (—) Socket adapter	Checking differential side bearing preload 

PREPARATION AND PRECAUTIONS

Tool number (Kent-Moore No.) Tool name	Description
(J34290) Shim selecting tool	Selecting oil pump housing bearing race Selecting clutch pack thrust washer Selecting differential side bearing adjusting shim Selecting output shaft bearing adjusting shim Selecting idler gear bearing adjusting shim
(J26774-A) Seal installation tool	Installing piston




Service Notice

- Before proceeding with disassembly, thoroughly clean the outside of the transaxle. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transaxle.
- When disassembling parts, place them in order in a parts rack so that they can be put back into the unit in their proper positions.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the transaxle is disassembled.
- It is very important to perform functional tests whenever they are indicated.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place removed parts in order on a parts rack so they can be put back in the valve body in the same positions and sequences. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along their bores in the valve body under their own weight.
- Before assembly, apply a coat of recommended A.T.F. to all parts. Petroleum jelly may be applied to O-rings and seals and used to hold small bearings and washers in place during reassembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- After overhaul, refill the transaxle with new A.T.F.

A/T CONTROL DIAGRAM


Hydraulic Control Circuits



SAT716B

A/T CONTROL DIAGRAM

Electrical Control Chart




Mechanical Operation

Range		Reverse clutch	High clutch	Low clutch	Band servo		Low & reverse brake	One-way clutch	Parking pawl	Lock-up
					Operation	Release				
Park									on	
Reverse		on					on			
Neutral										
Drive	D ₁ Low			on				on		
	D ₂ Second			on	on					
	D ₃ Top (3rd)		on	on	(on)	on				on*1
	D ₄ O.D. (4th)		on		on					on*2
2	2 ₁ Low			on				on		
	2 ₂ Second			on	on					
1	1 ₁ Low			on			on	on		
	1 ₂ Second			on	on					

*1: Lock-up operates in 3rd speed (lock-up) range when O.D. control switch is "OFF" (Overdrive not allowed).


*2: Lock-up operates in 4th speed (lock-up) range when O.D. control switch is "ON" (Overdrive allowed).




Control Valve Assembly

1. Remove air cleaner, battery and its bracket.
2. Remove control valve cover.
3. Remove control valve assembly by removing fixing bolts and disconnecting harness connector.

Be careful not to drop manual valve out of valve body.




4. Disassemble, inspect and assemble control valve assembly. Refer to "Control Valve Body".
- Set manual shaft in "N" position, then align manual plate with groove in manual valve of control valve assembly.
 - After installing control valve to transmission case, make sure that selector lever can be moved to all positions.



Revolution Sensor Replacement


1. Remove under cover.
2. Remove revolution sensor from A/T.
3. Reinstall any part removed.

Always use new sealing parts.




Inhibitor Switch Adjustment

1. Remove control cable from manual shaft.
2. Set manual shaft in "N" position.
3. Loosen inhibitor switch fixing bolts.



4. Insert pin into adjustment holes in both inhibitor switch and manual shaft as near vertical as possible.
5. Reinstall any part removed.
6. Check continuity of inhibitor switch. — Refer to "Electrical Components Inspection".




Control Cable Adjustment


Move selector lever from "P" range to "1" range. You should be able to feel the detents in each range.

If the detents cannot be felt or the pointer indicating the range is improperly aligned, the linkage needs adjustment.

1. Place selector lever in "P" range.
2. Loosen lock nuts.




3. Screw lock nut X until it touches select rod end while holding select rod horizontal, and tighten lock nut Y.
4. Move selector lever from "P" range to "1" range again. Make sure selector lever moves smoothly.



Differential Side Oil Seal Replacement

1. Remove drive shaft assembly. — Refer to section FA.
2. Remove oil seal.



3. Install oil seal.
- Apply A.T.F. before installing.**
4. Reinstall any part removed.

TROUBLE DIAGNOSES

Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair	AT-10
Preliminary Check	AT-11
Diagnosis by CONSULT	AT-28
A/T Electrical Parts Location	AT-29
Circuit Diagram for Quick Pinpoint Check	AT-31
Wiring Diagram	AT-32
Self-diagnosis	AT-34
SELF-DIAGNOSTIC PROCEDURE	AT-34
JUDGEMENT OF SELF-DIAGNOSIS CODE	AT-36
REVOLUTION SENSOR CIRCUIT CHECK	AT-40
SPEED SENSOR CIRCUIT CHECK	AT-41
THROTTLE SENSOR CIRCUIT CHECK	AT-42
SHIFT SOLENOID A CIRCUIT CHECK	AT-43
SHIFT SOLENOID B CIRCUIT CHECK	AT-44
TIMING SOLENOID CIRCUIT CHECK	AT-45
LOCK-UP SOLENOID CIRCUIT CHECK	AT-46
FLUID TEMPERATURE SENSOR CIRCUIT AND A/T CONTROL UNIT POWER SOURCE CIRCUIT CHECKS	AT-47
ENGINE REVOLUTION SIGNAL CIRCUIT CHECK	AT-49
LINE PRESSURE SOLENOID CIRCUIT CHECK	AT-50
INHIBITOR, OVERDRIVE AND THROTTLE VALVE SWITCH CIRCUIT CHECKS	AT-51
Diagnostic Procedure 1	
(SYMPTOM: Power indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".)	AT-55
Diagnostic Procedure 2	
(SYMPTOM: Power indicator lamp or comfort indicator lamp does not come on when turning A/T mode switch to the appropriate position.)	AT-56
Diagnostic Procedure 3	
(SYMPTOM: O.D. OFF indicator lamp does not come on when setting overdrive switch in "OFF" position.)	AT-56
Diagnostic Procedure 4	
(SYMPTOM: Power indicator lamp does not come on for about 3 seconds when depressing and releasing accelerator pedal fully.)	AT-57
Diagnostic Procedure 5	
(SYMPTOM: Engine cannot be started with selector lever in "P" or "N" range or engine can be started with selector lever in "D", "2", "1" or "R" range.)	AT-57
Diagnostic Procedure 6	
(SYMPTOM: Vehicle moves when it is pushed forward or backward with selector lever in "P" range.)	AT-58
Diagnostic Procedure 7	
(SYMPTOM: Vehicle moves forward or backward when selecting "N" range.)	AT-58
Diagnostic Procedure 8	
(SYMPTOM: There is large shock when changing from "N" to "R" range.)	AT-59
Diagnostic Procedure 9	
(SYMPTOM: Vehicle does not creep backward when selecting "R" range.)	AT-60
Diagnostic Procedure 10	
(SYMPTOM: Vehicle does not creep forward when selecting "D", "2" or "1" range.)	AT-61
Diagnostic Procedure 11	
(SYMPTOM: Vehicle cannot be started from D ₁ .)	AT-62

TROUBLE DIAGNOSES

Contents (Cont'd)

Diagnostic Procedure 12

(SYMPTOM: A/T does not shift from D_1 to D_2 at the specified speed.
A/T does not shift from D_4 to D_2 when depressing accelerator pedal
fully at the specified speed.) AT-63

Diagnostic Procedure 13

(SYMPTOM: A/T does not shift from D_2 to D_3 at the specified speed.) AT-64

Diagnostic Procedure 14

(SYMPTOM: A/T does not shift from D_3 to D_4 at the specified speed.) AT-65

Diagnostic Procedure 15

(SYMPTOM: A/T does not perform lock-up at the specified speed.) AT-72

Diagnostic Procedure 16

(SYMPTOM: A/T does not hold lock-up condition for more than 30 seconds.) AT-66

Diagnostic Procedure 17

(SYMPTOM: Lock-up is not released when accelerator pedal is released.) AT-67

Diagnostic Procedure 18

(SYMPTOM: A/T does not shift from D_4 to D_3 when changing
overdrive switch to "OFF" position.) AT-68

Diagnostic Procedure 19

(SYMPTOM: A/T does not shift from D_3 to 2_2 when changing
selector lever from "D" to "2" range.) AT-69

Diagnostic Procedure 20

(SYMPTOM: A/T does not shift from 2_2 to 1_1 when changing selector
lever from "2" to "1" range.
Vehicle does not decelerate by engine brake when shifting from 2_2 (1_2) to 1_1 .) AT-69

Electrical Components Inspection AT-70

Final Check AT-77


Symptom Chart AT-81


A/T Shift Lock System AT-84

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW





Preliminary Check

A/T FLUID CHECK

Fluid leakage check

1. Clean area suspected of leaking. — for example, mating surface of converter housing and transmission case.
2. Start engine, apply foot brake, place selector lever in "D" range and wait a few minutes.
3. Stop engine.


4. Check for fresh leakage.

Fluid condition check

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown any tacky	Oxidation — Over or under filling — Overheating

Fluid level check

Refer to section MA.



ROAD TEST PROCEDURE

1. Check before engine is started.



2. Check at idle.




3. Cruise test.

SAT786A

ROAD TESTING

Description






- The purpose of this road test is to determine overall performance of automatic transaxle and analyze causes of problems.
- The road test consists of the following three parts:
 1. Check before engine is started
 2. Check at idle
 3. Cruise test
- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items. Troubleshoot items which check out No Good after road test. Refer to "Self-diagnosis" and "Diagnostic Procedure".



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)


1. Check before engine is started



1
Park vehicle on flat surface.

2
Set A/T mode switch in "AUTO" position.

3
Move selector lever to "P" range.



4
Does power indicator lamp come on for about 2 seconds?

No
Go to Diagnostic Procedure 1.

5
Does power indicator lamp flicker for about 8 seconds?

Yes
Perform self-diagnosis. — Refer to SELF-DIAGNOSIS PROCEDURE.

6
Set A/T mode switch in "POWER" position.

Does power indicator lamp come on?

No
Go to Diagnostic Procedure 2.

7
Set A/T mode switch in "COMFORT" position.







Does comfort indicator lamp come on?

No
Go to Diagnostic Procedure 2.

Ⓐ

TROUBLE DIAGNOSES





Preliminary Check (Cont'd)



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

2. Check at idle



1
Park vehicle on flat surface.



2
Move selector lever to "P" or "N" range.



Is engine started?

No

Go to Diagnostic Procedure 5.

Yes



3
Move selector lever to "D", "1", "2" or "R" range.



Is engine started?

Yes

Go to Diagnostic Procedure 5.

No








4
Move selector lever to "P" range.

Ⓐ




TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



TROUBLE DIAGNOSES


Preliminary Check (Cont'd)

3. Cruise test




With CONSULT

- Using CONSULT, conduct a cruise test and record the result.
- Print the result and ensure that shifts and lock-ups take place as per "Shift Schedule."
- Check all items listed in Parts 1 through 3.




CONSULT setting procedure


1. Turn off ignition switch.
2. Connect "CONSULT" to diagnostic connector. (Diagnostic connector is located in left dash side panel.)



3. Turn on ignition switch.
4. Touch "START".




5. Touch "A/T".




6. Touch "DATA MONITOR".

TROUBLE DIAGNOSES


Preliminary Check (Cont'd)



7. Touch "SETTING" to set recording condition.




8. Touch "LONG TIME" and "ENTER" key.




9. Go back to SELECT MONITOR ITEM and touch "MAIN SIGNALS".

10. Touch "START".



11. When performing cruise test, touch "RECORD".



12. After finishing cruise test part 1, touch "STOP".


TROUBLE DIAGNOSES

Preliminary Check (Cont'd)


13. Touch "DISPLAY".



14. Touch "PRINT".





15. Touch "PRINT" again.



16. Check the monitor data printed out.

17. Continue cruise test part 2 and 3.




Without CONSULT

- Throttle position can be controlled by voltage across terminals ③④ and ③⑤ of A/T control unit.

TROUBLE DIAGNOSES


Preliminary Check (Cont'd)

Cruise test — Part 1



Warm up engine until engine oil and A.T.F. reach operating temperature after vehicle has been driven approx. 10 minutes.

A.T.F. operating temperature:
50 - 80°C (122 - 176°F)




Park vehicle on flat surface.


1
Set A/T mode switch in "AUTO" position.

2
Set overdrive switch in "ON" position.

3
Move selector lever to "P" range.



4
Move selector lever to "D" range.



5
Accelerate vehicle to half throttle.

Does vehicle start from D₁?

Read gear position.




No → Go to Diagnostic Procedure 11.

Yes

A





TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



Cruise test — Part 2

Confirm A/T mode switch is in "AUTO" position and overdrive switch is in "ON" position.





Confirm selector lever is in "D" range.

1 Accelerate vehicle to about 80 km/h (50 MPH) using half-throttle.

A

TROUBLE DIAGNOSES





Preliminary Check (Cont'd)



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

Cruise test — Part 3



Confirm A/T mode switch is in "AUTO" position and overdrive switch is in "ON" position.

Confirm selector lever is in "D" range.

1 Accelerate vehicle to D_4 using half-throttle.

2 Release accelerator pedal.

3 Set overdrive switch in "OFF" position while driving in D_4 range.

4 Does A/T shift from D_4 to D_3 ?
Read gear position and vehicle speed.

No Go to Diagnostic Procedure 18.

5 Move selector lever from "D" to "2" range while driving in D_3 .


6 Does A/T shift from D_3 to 2_2 ?
Read gear position.

No Go to Diagnostic Procedure 19.

Yes
A

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)




TROUBLE DIAGNOSES


Preliminary Check (Cont'd)

SHIFT SCHEDULE

27 X 63 model (COMFORT pattern)




27 X 63 model (POWER pattern)




TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

27 X 70 model (COMFORT pattern)



27 X 70 model (POWER pattern)



TROUBLE DIAGNOSES

Diagnosis by CONSULT

NOTICE

- The CONSULT electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid). When a noticeable time difference occurs between shift timing which is manifested by shift shock and the CONSULT display, mechanical parts (except solenoids, sensors, etc.) are considered to be malfunctioning. Check mechanical parts using applicable diagnostic procedures.
- Shift schedule (which implies gear position) displayed on CONSULT and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:
 - Actual shift schedule has more or less tolerance or allowance,
 - Shift schedule indicated in Service Manual refers to the point where shifts starts, and
 - Gear position displayed on CONSULT indicates the point where shifts are completed.
- Shift solenoid "A" or "B" is displayed on CONSULT at the start of shifting while gear position is displayed upon completion of shifting (which is computed by A/T control unit).

DATA MONITOR APPLICATION

Item	Application	Item	Application
Vehicle speed sensor 1 (A/T)	×	Timing solenoid	×
Vehicle speed sensor 2 (meter)	×	*Shift solenoid A (feedback)	×
Throttle sensor	×	*Shift solenoid B (feedback)	×
Fluid temperature sensor	×	*Timing solenoid (feedback)	×
Battery voltage	×	Hold mode switch (A/T mode switch — COMFORT)	×
Engine rpm	×	1 range switch	×
Selector lever switch (O.D. switch)	×	2 range switch	×
A.S.C.D. — cruise signal	×	D range switch	×
A.S.C.D. — O.D. cut signal	×	N range switch	×
Kickdown switch	—	R range switch	×
Power shift switch (A/T mode switch — POWER)	×	Gear position	×
Idle switch	×	Range position	×
Full throttle switch	×	Vehicle speed	×
Shift solenoid A	×	Throttle opening	×
Shift solenoid B	×	Line-pressure solenoid	×
		Lock-up solenoid	×










× : Applicable - : Not applicable

DATA ANALYSIS

Item	Display	Condition
Lock-up duty	Approximately 4% → Approximately 94%	Lock-up "OFF" → Lock-up "ON"
Line pressure duty	Approximately 20% → Approximately 94%	Low line-pressure (Small throttle opening) ↓ High line-pressure (Large throttle opening)
Throttle sensor	Approximately 0.5V	Fully-closed throttle
	Approximately 4V	Fully-open throttle
Fluid temperature sensor	Approximately 1.5V → Approximately 0.5V	Cold [20°C (68°F)] → Hot [80°C (176°F)]

Gear position	1	2	3	4
Shift solenoid A	ON	OFF	OFF	ON
Shift solenoid B	ON	ON	OFF	OFF

A/T Electrical Parts Location




SAT502C

TROUBLE DIAGNOSES

NOTE


TROUBLE DIAGNOSES

Circuit Diagram for Quick Pinpoint Check





TROUBLE DIAGNOSES

Wiring Diagram



Wiring Diagram (Cont'd)







Self-diagnosis


SELF-DIAGNOSTIC PROCEDURE (CONSULT)

1. Turn on CONSULT.
2. Touch "A/T".

3. Touch "SELF-DIAGNOSIS".
CONSULT performs REAL-TIME SELF-DIAGNOSIS.







SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)



Does power indicator lamp come on for about 2 seconds?

No → Go to Diagnostic Procedure 1.


Yes



3
Push shift lock release button.

4
Move selector lever to "D" range.

5
Set overdrive switch in "OFF" position.



6
Move selector lever to "2" range.

7
Set overdrive switch in "ON" position.

8
Move selector lever to "1" range.

9
Set overdrive switch in "OFF" position.

10
Depress accelerator pedal fully and release it.






Check power indicator lamp.
Refer to JUDGEMENT OF SELF-DIAGNOSIS CODE on next page.

DIAGNOSIS END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)









JUDGEMENT OF SELF-DIAGNOSIS CODE

Power indicator lamp:	Damaged circuit
All judgement flickers are same.  SAT755A	All circuits that can be confirmed by self-diagnosis are O.K.
1st judgement flicker is longer than others.  SAT756A	Revolution sensor circuit is short-circuited or disconnected.  ➡ Go to revolution sensor circuit check. SAT965B
2nd judgement flicker is longer than others.  SAT757A	Speed sensor circuit is short-circuited or disconnected.  ➡ Go to speed sensor circuit check. SAT966B

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second









TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

Power indicator lamp: 3rd judgement flicker is longer than others.  SAT758A	Damaged circuit Throttle sensor circuit is short-circuited or disconnected.  ➡ Go to throttle sensor circuit check. SAT967B
4th judgement flicker is longer than others.  Self-diagnosis start SAT762A	Shift solenoid A circuit is short-circuited or disconnected.  ➡ Go to shift solenoid A circuit check. SAT968B
5th judgement flicker is longer than others.  SAT763A	Shift solenoid B circuit is short-circuited or disconnected.  ➡ Go to shift solenoid B circuit check. SAT969B
6th judgement flicker is longer than others.  SAT764A	Timing solenoid circuit is short-circuited or disconnected.  ➡ Go to timing solenoid circuit check. SAT970B




TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

Power indicator lamp:	Damaged circuit
7th judgement flicker is longer than others.  SAT765A	Lock-up solenoid circuit is short-circuited or disconnected.  ➡ Go to lock-up solenoid circuit check. SAT971B
8th judgement flicker is longer than others.  SAT770A	Fluid temperature sensor is disconnected or A/T control unit power source circuit is damaged.  ➡ Go to fluid temperature sensor circuit and A/T control unit power source circuit check. SAT972B
9th judgement flicker is longer than others.  SAT771A	Engine revolution signal circuit is short-circuited or disconnected.  ➡ Go to engine revolution signal circuit check. SAT973B
10th judgement flicker is longer than others.  SAT772A	Line pressure solenoid circuit is short-circuited or disconnected.  ➡ Go to line pressure solenoid circuit check. SAT974B

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)


Power indicator lamp:	Damaged circuit
Flickers as shown below.  SAT773A	Battery power is low. Battery has been disconnected for a long time. Battery is connected conversely. (When reconnecting A/T control unit connectors. — This is not a problem.)
Does not come on.  SAT146B	Inhibitor switch, overdrive switch or throttle valve switch circuit is disconnected or A/T control unit is damaged.  ► Go to inhibitor, overdrive and throttle valve switch circuit checks. SAT975B

$t_4 = 1.0$ second

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

REVOLUTION SENSOR CIRCUIT CHECK



CHECK REVOLUTION SENSOR. —
Refer to "Electrical Components Inspection".

N.G.

Repair or replace revolution sensor.


O.K.

A

CHECK INPUT SIGNAL.

N.G.

Check harness continuity between A/T control unit and revolution sensor.



- Select "E.C.U. INPUT SIGNALS".
- Read out the value of "CAR SPEED SENSOR 1" while driving.
- Check the value changes according to driving speed.

OR

Check voltage between A/T control unit terminal 25 and ground while driving.
(Measure with A.C. range.)

Voltage:

At 0 km/h (0 MPH):

0V

At 30 km/h (19 MPH):

1V or more

(Voltage rises gradually in response to vehicle speed.)

O.K.



Perform self-diagnosis again after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.

O.K.

INSPECTION END



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

A




☆MONITOR ☆NO FAIL	
CAR/S SE1-A/T	0km/h
CAR/S SE2-MTR	5km/h
THROTTLE SEN	0.4V
FLUID TEMP SE	1.2V
BATTERY VOLT	13.4V
ENG REV	1024rpm
SLCT LEVER SW	0 N
R-RANGE SW	OFF
N-RANGE SW	0 N

RECORD

SAT320C

A SPEED SENSOR CIRCUIT CHECK

CHECK INPUT SIGNAL.

1. 
2. 
 - Select "E.C.U. INPUT SIGNALS".
 - Read out the value of "CAR SPEED SENSOR 2" while driving.
 - Check the value changes according to driving speed.

OR

-  Check voltage between A/T control unit terminal 27 and ground while driving at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.

Voltage:

Varies from 0V to 5V

N.G.

Check the following items.

- Speed sensor and ground circuit for speed sensor — Refer to section EL.
- Harness continuity between A/T control unit and speed sensor

O.K.

Perform self-diagnosis again after driving for a while.


N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.


O.K.

INSPECTION END

A



At 2 - 3 km/h (1 - 2 MPH)





SAT977B

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

THROTTLE SENSOR CIRCUIT CHECK




A

Depress slowly.

MONITOR		FIND FAIL	
CAR/S SE1-A/T	0km/h		
CAR/S SE2-MTR	5km/h		
THROTTLE SEN	0.4V		
FLUID TEMP SE	1.2V		
BATTERY VOLT	13.4V		
ENG REV	1024rpm		
SLCT LEVER SW	0 N		
P-RANGE SW	OFF		
N-RANGE SW	0 N		

RECORD

SAT321C



Perform self-diagnosis (Mode III) for engine control.

N.G.

Check throttle sensor circuit for engine control. — Refer to section EF & EC.

O.K.

A

CHECK INPUT SIGNAL.

- 1.
- 2.

N.G.

Check harness continuity between E.C.U. and A/T control unit regarding throttle sensor circuit.



- Select "E.C.U. INPUT SIGNALS".
- Read out the value of "THROTTLE SENSOR"

Voltage:

Fully-closed throttle:

Approximately
0.5V

Fully-open throttle:

Approximately
4V

—OR—



- Check voltage between A/T control unit terminals ③④ and ③⑤ while accelerator pedal is depressed slowly.

Voltage:

Fully-closed throttle:

Approximately
0.5V

Fully-open throttle:

Approximately
4V

(Voltage rises gradually in response to throttle valve opening.)

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.





O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)





SHIFT SOLENOID A CIRCUIT CHECK



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)




SHIFT SOLENOID B CIRCUIT CHECK



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

TIMING SOLENOID CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

- 1.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑧ and ground.

Resistance: 20 - 40Ω

N.G.

1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items.
 - Timing solenoid. — Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

- 1.
 2. Disconnect A/T control unit connector.
 3. Check resistance between terminal ⑧ and A/T control unit terminal ⑧.
- Resistance:**
Approximately 0Ω
4. Reinstall any part removed.

N.G.

1. Repair or replace harness between A/T control unit and terminal cord assembly.

O.K.

Perform self-diagnosis after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.





O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)








LOCK-UP SOLENOID CIRCUIT CHECK



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)


FLUID TEMPERATURE SENSOR CIRCUIT AND A/T CONTROL UNIT POWER SOURCE CIRCUIT CHECKS



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

C




MONITOR	FAIL
CAR'S SE1-A/T	0km/h
CAR'S SE2-MTR	5km/h
THROTTLE SEN	0.4V
FLUID TEMP SE	1.2V
BATTERY VOLT	13.4V
ENG REV	1024r/min
SLCT LEVER SW	0 N
P-RANGE SW	OFF
N-RANGE SW	0 N

RECORD

SAT330C

C



CONNECT


UNIT CONNECTOR

33

PU

V




SAT990B



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

ENGINE REVOLUTION SIGNAL CIRCUIT CHECK



Check ignition circuit condition for engine.

N.G.

Repair or replace. —
Refer to section EF & EC.

O.K.

A

CHECK INPUT SIGNAL.

1.



2.



- Select "E.C.U. INPUT SIGNALS".
- Read out the value of "ENGINE REVOLUTION".
- Check engine revolution changes according to throttle opening.

OR



- Check voltage between A/T control unit terminal ②④ and ground.

Voltage: 0.9 - 4.5V

N.G.

Check harness continuity between A/T control unit and E.C.C.S. control unit.

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

LINE PRESSURE SOLENOID CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

- 1.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ① and ground.

Resistance: 2.5 - 5Ω

N.G.

1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items.
 - Line pressure solenoid — Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

- 1.
2. Disconnect A/T control unit connector.
3. Check resistance between terminal ① and A/T control unit terminal ②.

Resistance: 11.2 - 12.8Ω

N.G.

- Check the following items.
- Dropping resistor — Refer to "Electrical Components Inspection".
 - Harness continuity between A/T control unit ② and terminal cord assembly

O.K.

C

CHECK POWER SOURCE CIRCUIT.

- 1.
2. Check resistance between terminal ① and A/T control unit terminal ①.

Resistance: Approximately 0Ω

3. Reinstall any part removed.

N.G.

- Repair or replace harness between A/T control unit ① and terminal cord assembly.

O.K.

Perform self-diagnosis after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

INHIBITOR, OVERDRIVE AND THROTTLE VALVE SWITCH CIRCUIT CHECKS



A

CHECK INHIBITOR SWITCH CIRCUIT.

1.



2.



- Select "E.C.U. INPUT signals".
- Read out "R, N, D, 1 and 2 range switches" moving selector lever to each range.
- Check the selector lever position is indicated properly.

OR



- Check voltage between A/T control unit terminals ⑯, ⑰, ⑱, ⑲, ⑳ and ground while moving selector lever through each range.

Voltage:

B: Battery voltage

0: 0V

Lever position \ Terminal No	⑲	⑲	⑱	⑰	⑯
	⑲	⑲	⑱	⑰	⑯
P, N	B	0	0	0	0
R	0	B	0	0	0
D	0	0	B	0	0
2	0	0	0	B	0
1	0	0	0	0	B

N.G.

Check the following items.

- Inhibitor switch — Refer to "Electrical Components Inspection".
- Harness continuity between ignition switch and inhibitor switch
- Harness continuity between inhibitor switch and A/T control unit


O.K.

A

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

B



OVER DRIVE
4ON 4OFF

ON
OFF


```

MONITOR 17ND FAIL
ADP 3 SE1-AT 0.4V
ADP 3 SE2-ATP 5.0V
THROTTLE SEN 0.4V
FLUID TEMP SE 1.2V
BATTERY VOLT 13.4V
ENG REV 1034rpm
SLD: LOWER SW 0.1V
P-RANGE SW OFF
N-RANGE SW 0.1V
    
```

REC'D

SAT335C

B



OVER DRIVE
4ON 4OFF

ON
OFF

CONNECT

UNIT CONNECTOR

39


G/Y

V

SAT995B

B

CHECK OVERDRIVE SWITCH CIRCUIT.

1. 

2. 

- Select "E.C.U. INPUT SIGNALS".
- Read out "SELECTOR LEVER SWITCH (Overdrive switch)".
- Check the selector lever switch position is indicated properly.
(Selector lever switch "ON" displayed on CONSULT means overdrive "OFF".)

OR



- Check voltage between A/T control unit terminal ③ and ground when overdrive switch is in "ON" position and in "OFF" position.

Switch position	Voltage
ON	Battery voltage
OFF	1V or less

N.G. → Check the following items.

- Overdrive switch — Refer to "Electrical Components Inspection".
- Harness continuity between A/T control unit and overdrive switch
- Harness continuity of ground circuit for overdrive switch

O.K. → **B**

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

C




☆MONITOR	☆NO FAIL	↕
D-RANGE SW	OFF	
1-RANGE SW	OFF	
2-RANGE SW	OFF	
ASCD-CRUISE	OFF	
ASCD-OD CUT	OFF	
KICKDOWN SW	OFF	
POWERSHIFT SW	OFF	
IDLE SW	ON	
FULL THRTL SW	OFF	
RECORD		

SAT338C


C



H.S.
CONNECT



SAT339C



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

D




☆MONITOR ☆NO FAIL	
D-RANGE SW	OFF
1-RANGE SW	OFF
2-RANGE SW	OFF
ASCD-CRUISE	OFF
ASCD-OD CUT	OFF
KICKDOWN SW	OFF
POWERSHIFT SW	OFF
IDLE SW	ON
FULL THRTL SW	OFF

RECORD

SAT338C

D

SAT505C

D

CHECK FULL THROTTLE SWITCH CIRCUIT.

- 
- 

- Select "E.C.U. INPUT SIGNALS".
- Read out "FULL THROTTLE SWITCH" depressing and releasing accelerator pedal.
- Check full throttle switch changes ON or OFF.

OR

- Check voltage between A/T control unit terminal ②① and ground while depressing accelerator pedal slowly.

Voltage:

When releasing accelerator pedal:

1V or less

When depressing accelerator pedal fully:

8 - 15V

O.K.

Perform self-diagnosis again after driving for a while.

O.K.





INSPECTION END

N.G.

Check harness continuity between A/T control unit and full throttle switch.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.



Diagnostic Procedure 1

SYMPTOM:

Power indicator lamp does not come on for about 2 seconds when turning ignition switch in "ON".

1

CHECK A/T CONTROL UNIT POWER SOURCE.

- 1.
2. Check voltage between A/T control unit terminals ④, ⑨ and ground. **Battery voltage should exist.**

N.G.

Check the following items.

- Harness continuity between ignition switch and A/T control unit
- Ignition switch and fuse — Refer to section EL.

O.K.

2

CHECK A/T CONTROL UNIT GROUND CIRCUIT.

- 1.
2. Disconnect A/T control unit connector.
3. Check resistance between A/T control unit terminals ⑮, ④⑧ and ground. **Resistance: Approximately 0Ω**

N.G.

Check harness continuity between A/T control unit and ground.

O.K.

3

CHECK LAMP CIRCUIT.

- 1.
2. Disconnect A/T control unit connector.
3. Check resistance between A/T control unit terminals ③ and ④. **Resistance: 5 - 20Ω**
4. Reinstall any part removed.

N.G.


Check the following items.

- Power indicator lamp — Refer to section EL.
- Harness continuity between ignition switch and power indicator lamp
- Harness continuity between power indicator lamp and A/T control unit

O.K.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.



TROUBLE DIAGNOSES



Diagnostic Procedure 2

SYMPTOM:


Power indicator lamp or comfort indicator lamp does not come on when turning A/T mode switch to the appropriate position.





Diagnostic Procedure 3

SYMPTOM:

O.D. OFF indicator lamp does not come on when setting overdrive switch in "OFF" position.








Diagnostic Procedure 4

SYMPTOM:


Power indicator lamp does not come on for about 3 seconds when depressing and releasing accelerator pedal fully.




Diagnostic Procedure 5

SYMPTOM:

Engine cannot be started with selector lever in "P" or "N" range or engine can be started with selector lever in "D", "2", "1" or "R" range.







Diagnostic Procedure 6

SYMPTOM:



Vehicle moves when it is pushed forward or backward with selector lever in "P" range.



Diagnostic Procedure 7

SYMPTOM:






Vehicle moves forward or backward when selecting "N" range.




Diagnostic Procedure 8

SYMPTOM:

There is large shock when changing from "N" to "R" range.








Diagnostic Procedure 9

SYMPTOM:

Vehicle does not creep backward when selecting "R" range.









Diagnostic Procedure 10

SYMPTOM:

Vehicle does not creep forward when selecting "D", "2" or "1" range.









Diagnostic Procedure 11

SYMPTOM:

Vehicle cannot be started from D₁.








Diagnostic Procedure 12

SYMPTOM:

A/T does not shift from D₁ to D₂ at the specified speed.

A/T does not shift from D₄ to D₂ when depressing accelerator pedal fully at the specified speed.








Diagnostic Procedure 13

SYMPTOM:

A/T does not shift from D_2 to D_3 at the specified speed.








Diagnostic Procedure 14

SYMPTOM:

A/T does not shift from D₃ to D₄ at the specified speed.







Diagnostic Procedure 15

SYMPTOM:

A/T does not perform lock-up at the specified speed.







Diagnostic Procedure 16

SYMPTOM:


A/T does not hold lock-up condition for more than 30 seconds.




Diagnostic Procedure 17

SYMPTOM:

Lock-up is not released when accelerator pedal is released.







Diagnostic Procedure 18

SYMPTOM:

A/T does not shift from D₄ to D₃ when changing overdrive switch to "OFF" position.







Diagnostic Procedure 19

SYMPTOM:

A/T does not shift from D_3 to 2_2 when changing selector lever from "D" to "2" range.





Diagnostic Procedure 20


SYMPTOM:

A/T does not shift from 2_2 to 1_1 when changing selector lever from "2" to "1" range.

Vehicle does not decelerate by engine brake when shifting from 2_2 (1_2) to 1_1 .



TROUBLE DIAGNOSES



Electrical Components Inspection

INSPECTION OF A/T CONTROL UNIT

- Measure voltage between each terminal and terminal ⑮ or ④⑧ by following "A/T CONTROL UNIT INSPECTION TABLE".
- Pin connector terminal layout.

1	2	3	4	9	10	11	12	13	14	15		23	24	25	26	27	28	29	30	31	32	33	34	35
5	6	7	8	16	17	18	19	20	21	22		36	37	38	39	40	41	42	43	44	45	46	47	48



SAT011C

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)





A/T CONTROL UNIT INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition		Judgement standard	
1	Line pressure solenoid		When accelerator pedal is released after warming up engine.	1.5 - 2.5V	
			When accelerator pedal is depressed fully after warming up engine.	0.5V or less	
2	Line pressure solenoid (with dropping resistor)		When accelerator pedal is released after warming up engine.	5 - 14V	
			When accelerator pedal is depressed fully after warming up engine.	0.5V or less	
3	Power indicator lamp			When A/T mode switch is set in "POWER" position.	1V or less
				When A/T mode switch is set in any position except in "POWER" position.	Battery voltage
4	Power source			When ignition switch is turned to "ON".	Battery voltage
				When ignition switch is turned to "OFF".	1V or less
5	Lock-up solenoid			When A/T is performing lock-up.	8 - 15V
				When A/T is not performing lock-up.	1V or less
6	Shift solenoid A			When shift solenoid A is operating. (When driving in "D ₁ " or "D ₄ ".)	Battery voltage
				When shift solenoid A is not operating. (When driving in "D ₂ " or "D ₃ ".)	1V or less
7	Shift solenoid B		When shift solenoid B is operating. (When driving in "D ₁ " or "D ₂ ".)	Battery voltage	
			When shift solenoid B is not operating. (When driving in "D ₃ " or "D ₄ ".)	1V or less	
8	Timing solenoid		When timing solenoid is operating. (When driving in "D ₁ " or "D ₄ ".)	Battery voltage	
			When timing solenoid is not operating. (When driving in "D ₂ " or "D ₃ ".)	1V or less	

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition		Judgement standard
9	Power source		Same as No. 4	
10*	—		—	—
11	—		—	—
12	—		—	—
13	—		—	—
14	Idle switch (in throttle valve switch)		When accelerator pedal is released after warming up engine.	8 - 15V
			When accelerator pedal is depressed after warming up engine.	1V or less
15	Ground		—	—
16	Inhibitor "1" range switch		When selector lever is set to "1" range.	Battery voltage
			When selector lever is set to other ranges.	1V or less
17	Inhibitor "2" range switch		When selector lever is set to "2" range.	Battery voltage
			When selector lever is set to other ranges.	1V or less
18	Inhibitor "D" range switch		When selector lever is set to "D" range.	Battery voltage
			When selector lever is set to other ranges.	1V or less
19	Inhibitor "N" or "P" range switch		When selector lever is set to "N" range.	Battery voltage
			When selector lever is set to other ranges.	1V or less
20	Inhibitor "R" range switch		When selector lever is set to "R" range.	Battery voltage
			When selector lever is set to other ranges.	1V or less
21	Full throttle switch		When accelerator pedal is depressed more than half-way after warming up engine.	8 - 15V
			When accelerator pedal is released after warming up engine.	1V or less
22	—		—	—
23	Power source (Back-up)		When ignition switch is turned to "OFF".	Battery voltage
			When ignition switch is turned to "ON".	Battery voltage
24	Engine revolution signal		When engine is running at idle speed.	0.9V
			When engine is running at 3,000 rpm.	Approximately 3.7V

*: This terminal is connected to terminal No. 36 of E.C.C.S. control unit.

When code No. 54 appears during engine self-diagnosis, check line between above terminals for proper continuity.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition		Judgement standard
25	Revolution sensor (Measure in AC range)		When vehicle is cruising at 30 km/h (19 MPH).	1V or more Voltage rises gradually in response to vehicle speed.
26	—		When vehicle is parked.	0V
27	Speed sensor		When vehicle is moving at 2 to 3 km/h (1 to 2 MPH) for 1m (3 ft) or more.	Vary from 0 to 5V
28	—		—	—
29	—		—	—
30	—		—	—
31	Throttle sensor (Power source)		—	4.5 - 5.5V
32	—		—	—
33	Fluid temperature sensor		When A.T.F. temperature is 20°C (68°F).	Approximately 1.5V
			When A.T.F. temperature is 80°C (176°F).	Approximately 0.5V
34	Throttle sensor		When accelerator pedal is depressed slowly after warming up engine.	Fully-closed throttle: Approximately 0.5V
			Voltage rises gradually in response to throttle opening angle.	Fully-open throttle: Approximately 4V
35	Throttle sensor (Ground)		—	—
36	A/T mode switch "POWER"		When A/T mode switch is set in "POWER" position.	Battery voltage
			When A/T mode switch is set in any position except in "POWER" position.	1V or less
37	A.S.C.D. cruise signal		When A.S.C.D. cruise is being performed. ("CRUISE" light comes on.)	Battery voltage
			When A.S.C.D. cruise is not being performed. ("CRUISE" light does not come on.)	1V or less

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)



Terminal No.	Item	Condition		Judgement standard
38	—		—	—
39	Overdrive switch		When overdrive switch is set in "ON" position.	Battery voltage
			When overdrive switch is set in "OFF" position.	1V or less
40	A.S.C.D. O.D. cut signal		When "ACCEL" set switch on A.S.C.D. cruise is released.	5 - 8V
			When "ACCEL" set switch on A.S.C.D. cruise is applied.	1V or less
41	—		—	—
42	A/T mode switch "COMFORT"		When A/T mode switch is set in "COMFORT" position.	Battery voltage
			When A/T mode switch is set in any position except in "COMFORT" position.	1V or less
43	—		—	—
44	—		—	—
45	—		—	—
46	—		—	—
47	—		—	—
48	Ground		—	—

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)



INHIBITOR SWITCH

1. Disconnect control cable from manual shaft.




2. Check continuity between terminals ① and ② and between terminals ③ and ④, ⑤, ⑥, ⑦, ⑧, ⑨ while moving selector lever through each range.

Terminal No.	①	②	③	④	⑤	⑥	⑦	⑧	⑨
Lever position									
P	○	○	○	○					
R			○	○	○				
N	○	○	○	○	○	○			
D			○	○	○	○	○		
2			○	○	○	○	○	○	
1			○	○	○	○	○	○	○



3. If N.G., adjust inhibitor switch.
4. Check terminal continuity again.
5. If N.G., replace inhibitor switch.



FLUID TEMPERATURE SENSOR

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between two terminals while changing temperature as shown at left.

Temperature °C (°F)	Resistance kΩ
20 (68)	Approximately 2.5
80 (176)	Approximately 0.3


TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

REVOLUTION SENSOR

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between terminals ①, ② and ③.

Terminal No.		Resistance
①	②	500 - 650Ω
②	③	No continuity
①	③	No continuity




TIMING SOLENOID

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between two terminals.

Resistance:

Timing solenoid 20 - 40Ω




4-UNIT SOLENOID ASSEMBLY

(Shift solenoid A, B, lock-up solenoid and line pressure solenoid)


- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between terminals of each solenoid.

Solenoid	Terminal No.		Resistance Ω
Shift solenoid A	①	Ground terminal	20 - 40
Shift solenoid B	②		
Lock-up solenoid	③		10 - 20
Line pressure solenoid	④		2.5 - 5



DROPPING RESISTOR

- Check resistance between two terminals.
- Resistance: 11.2 - 12.8Ω**





TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

OVERDRIVE SWITCH

- Check continuity between two terminals.

O.D. switch position	Continuity
ON	No
OFF	Yes



Final Check

STALL TESTING



Stall test procedure

- Check A/T and engine fluid levels. If necessary, add.
- Warm up engine until engine oil and A.T.F. reach operating temperature after vehicle has been driven approx. 10 minutes.


A.T.F. operating temperature:
50 - 80°C (122 - 176°F)

- Set parking brake and block wheels.
- Install a tachometer where it can be seen by driver during test.

- It is good practice to put a mark on point of specified engine rpm on indicator.



- Start engine, apply foot brake, and place selector lever in "D" range.



- Accelerate to wide-open throttle gradually while applying foot brake.
- Quickly note the engine stall revolution and immediately release throttle.

- During test, never hold throttle wide-open for more than 5 seconds.

Stall revolution:
1,950 - 2,250 rpm

TROUBLE DIAGNOSES


Final Check (Cont'd)

8. Shift selector lever to "N".


9. Cool off A.T.F.

Run engine at idle for at least one minute.

10. Perform stall tests in the same manner as in steps 5 through 9 with selector lever in "1" and "R", respectively.



JUDGEMENT OF STALL TEST





If converter one-way clutch is frozen, vehicle will have poor high-speed performance and low engine rpm when it is raced in "N" range. If converter one-way clutch is slipping, vehicle will be sluggish up to 50 or 60 km/h (30 or 40 MPH).

TROUBLE DIAGNOSES

Final Check (Cont'd)

PRESSURE TESTING

- Location of line pressure test port
- **Always replace line pressure plugs as they are self-sealing bolts.**




Line pressure test procedure


1. Check A/T and engine fluid levels. If necessary, add.
2. Warm up engine until engine oil and A.T.F. reach operating temperature after vehicle has been driven approx. 10 minutes.

A.T.F. operating temperature:
50 - 80°C (122 - 176°F)


3. Install pressure gauge to line pressure port.



4. Set parking brake and block wheels.
- **Continue to depress brake pedal fully while line pressure test at stall speed is performed.**



TROUBLE DIAGNOSES



Final Check (Cont'd)


5. Start engine and measure line pressure at idle and stall speed.
- **When measuring line pressure at stall speed, follow the stall test procedure.**

Line pressure:

Engine speed rpm	Line pressure kPa (kg/cm ² , psi)
	D, 2, 1 and R ranges
Idle	382 - 422 (3.9 - 4.3, 55 - 61)
Stall	1,285 - 1,363 (13.1 - 13.9, 186 - 198)

JUDGEMENT OF LINE PRESSURE TEST

Judgement		Suspected parts
At idle	Line pressure is low in all ranges.	● Oil pump wear ● Control piston damage ● Pressure regulator valve or plug sticking ● Spring for pressure regulator valve damaged ● Fluid pressure leakage between oil strainer and pressure regulator valve
	Line pressure is low in particular range.	● Fluid pressure leakage between manual valve and particular clutch. ● For example; If line pressure is low in "R" and "1" ranges but is normal in "D" and "2" range, fluid leakage exists at or around low & reverse brake circuit.
	Line pressure is high.	● Mal-adjustment of throttle sensor ● Fluid temperature sensor damaged ● Line pressure solenoid sticking ● Short circuit of line pressure solenoid circuit ● Pressure regulator valve or plug sticking
At stall speed	Line pressure is low.	● Mal-adjustment of throttle sensor ● Control position damaged ● Line pressure solenoid sticking ● Short circuit of line pressure solenoid circuit ● Pressure regulator valve or plug sticking ● Pilot valve sticking



LOCK-UP TEST

Install pressure gauge to lock-up pressure port. Shift selector lever in "D" range.

Condition	Torque converter lock-up pressure kPa (kg/cm ² , psi)
Lock-up "ON"	49 (0.5, 7) or less
Lock-up "OFF"	196 (2, 28) or more

If lock-up pressure is not within specifications, refer to Diagnostic Procedures 15 and 16.

TROUBLE DIAGNOSES

Symptom Chart

Reference page(AT-)		ON vehicle										OFF vehicle					
		-	7, 11	75	75, 76	79	76, 115	76	76	106, 132	-	77	99, 111	126, 130	109, 129	131, 132	132 156
Reference page(AT-)	Numbers are arranged in order of probability Perform inspections starting with number one and working up.	Fuse	Fluid level Control linkage	Inhibitor switch Throttle sensor (Adjustment)	Revolution sensor and speed sensor Engine revolution signal Fluid temperature sensor	Engine idling rpm Line pressure	Control valve assembly Shift solenoid A	Shift solenoid B Line pressure solenoid	Lock-up solenoid Timing solenoid	Low clutch accumulator Band servo accumulator	Ignition switch and starter	Overdrive switch A/T mode switch	Torque converter Oil pump	Reverse clutch High clutch	Low clutch One-way clutch	Low & reverse brake Brake band	Band servo piston Parking components
57	Engine does not start in "N", "P" ranges.	1	3	4	.	.	.	.	.	.	2	.	.	.	.	.	.
57	Engine starts in range other than "N" and "P".	.	1	2	.	.	.	.	.	.	.	.	.	.	.	.	.
-	Transaxle noise in "P" and "N" ranges.	.	1	.	3	4	5	.	2	.	.	.	7	6	.	.	.
58	Vehicle moves when changing into "P" range or parking gear does not disengage when shifted out of "P" range.	.	1	.	.	.	.	.	.	.	.	.	.	.	.	.	2
58	Vehicle runs in "N" range	.	1	.	.	.	.	.	.	.	.	.	.	3	2	.	.
60	Vehicle will not run in "R" range (but runs in "D", "2" and "1" ranges). Clutch slips. Very poor acceleration.	.	1	.	.	2	4	.	3	.	.	.	.	5	6	7	8
-	Vehicle braked when shifting into "R" range.	.	1	2	.	3	5	.	4	.	.	.	.	6	8	.	7
-	Sharp shock in shifting from "N" to "D" range.	.	.	2	6	5	1	3	8	.	7	4	9	.	10	.	.
-	Vehicle will not run in "D" and "2" ranges (but runs in "1" and "R" ranges).	.	1	.	.	.	.	.	.	.	.	.	.	.	2	.	.
61	Vehicle will not run in "D", "1", "2" ranges (but runs in "R" range). Clutch slips. Very poor acceleration.	.	1	.	.	2	4	.	3	.	6	.	.	6	7	8	9
-	Clutches or brakes slip somewhat in starting.	.	1	3	4	.	5	7	.	6	.	8	.	13	12	10	9
-	Excessive creep.	.	.	.	.	1	.	.	.	.	.	.	.	.	.	.	.
60,61	No creep at all.	.	1	.	.	2	3	.	.	.	.	.	6	5	.	4	.
-	Failure to change gear.	1	.	5	2	.	3	4	.	.	.	.	.	.	.	.	.
-	Failure to change gear from "D ₁ " to "D ₂ ".	.	2	1	5	.	4	3	.	.	.	.	.	.	.	6	.
-	Failure to change gear from "D ₂ " to "D ₃ ".	.	2	1	5	.	4	3	.	.	.	.	.	6	.	7	.
-	Failure to change gear from "D ₃ " to "D ₄ ".	.	3	1	5	6	.	4	.	.	2	.	.	.	.	7	.
63,64, 65	Too high a gear change point from "D ₁ " to "D ₂ ", from "D ₂ " to "D ₃ ", from "D ₃ " to "D ₄ ".	.	.	1	2	.	4	5	.	.	.	3	.	.	.	.	.
-	Gear change directly from "D ₁ " to "D ₃ " occurs.	.	3	.	.	.	.	.	.	2	.	.	.	.	.	1	.

TROUBLE DIAGNOSES

Symptom Chart (Cont'd)

		ON vehicle										OFF vehicle						
Reference page(AT-)	Reference page (AT-)	-	7, 11	75	75, 76	79	76, 115	76	76	106, 132	-	77	99, 111	126, 130	109, 129	131, 132	132	156
	Numbers are arranged in order of probability. Perform inspections starting with number one and working up.	Fuse	Fluid level Control linkage	Inhibitor switch Throttle sensor (Adjustment)	Revolution sensor and speed sensor Engine revolution signal Fluid temperature sensor	Engine idling rpm Line pressure	Control valve assembly Shift solenoid A	Shift solenoid B Line pressure solenoid	Lock-up solenoid Timing solenoid	Low clutch accumulator Band servo accumulator	Ignition switch and starter	Overdrive switch A/T mode switch	Torque converter Oil pump	Reverse clutch High clutch	Low clutch One-way clutch	Low & reverse brake Brake band	Band servo piston	Parking components
-	Engine stops when shifting lever into "R", "D", "2" and "1".	.	.	.	.	1 2	4	.	3	.	.	.	5	.	.	.	.	.
-	Too sharp a shock in change from "D ₁ " to "D ₂ ".	.	.	1	7 8	2	5	3	4	6	.	.	.	.	.	9	.	.
-	Too sharp a shock in change from "D ₂ " to "D ₃ ".	.	.	1	.	2	4	3	.	.	.	.	.	5	.	.	6	.
-	Too sharp a shock in change from "D ₃ " to "D ₄ ".	.	.	1	.	2	4	3	.	.	.	.	.	.	.	.	5	.
-	Almost no shock or clutches slipping in change from "D ₁ " to "D ₂ ".	.	1	.	2	.	3	7	.	4	6	.	.	.	.	8	5	.
-	Almost no shock or slipping in change from "D ₂ " to "D ₃ ".	.	1	.	2	.	3	6	4	.	.	.	.	7	.	.	5	.
-	Almost no shock or slipping in change from "D ₃ " to "D ₄ ".	.	1	.	2	.	3	4	8	.	.	.	.	6	.	7	5	.
-	Vehicle braked by gear change from "D ₁ " to "D ₂ ".	.	1	.	.	.	.	.	.	.	.	.	.	2 4	5	3	.	.
-	Vehicle braked by gear change from "D ₂ " to "D ₃ ".	.	1	.	.	.	.	.	.	.	.	.	.	.	.	.	2	.
-	Vehicle braked by gear change from "D ₃ " to "D ₄ ".	.	1	.	.	.	.	.	.	.	.	.	.	3	2	.	.	.
-	Maximum speed not attained. Acceleration poor.	.	1	2	.	.	5 3	4	.	.	6	12 11	7 8	.	10 9	.	.	.
-	Failure to change gear from "D ₄ " to "D ₃ ".	.	1	.	2	.	6 4	5	3	.	.	.	.	8	7	.	.	.
-	Failure to change gear from "D ₃ " to "D ₂ " or from "D ₄ " to "D ₂ ".	.	1	.	2	.	5 3	4	.	.	.	.	7	.	8	6	.	.
-	Failure to change gear from "D ₂ " to "D ₁ " or from "D ₃ " to "D ₁ ".	.	1	.	2	.	5 3	4	.	.	.	.	7	6	8	.	.	.
-	Gear change shock felt during deceleration by releasing accelerator pedal.	.	.	1	.	2	4	.	3	.	.	.	.	6	5	.	.	.
-	Too high a change point from "D ₄ " to "D ₃ ", from "D ₃ " to "D ₂ ", from "D ₂ " to "D ₁ ".	.	.	1	2	.	.	.	.	.	3	.	.	.	.	.	.	.
-	Kickdown does not operate when depressing pedal in "D ₄ " within kickdown vehicle speed.	.	.	1	2	.	3	4	.	.	.	.	.	.	.	.	.	.
-	Kickdown operates or engine overruns when depressing pedal in "D ₄ " beyond kickdown vehicle speed limit.	.	.	2	1	.	3	4	.	.	.	.	.	.	.	.	.	.
-	Races extremely fast or slips in changing from "D ₄ " to "D ₃ " when depressing pedal.	.	1	3	.	4	6	5	2	.	.	.	.	7	.	.	.	.

TROUBLE DIAGNOSES



Symptom Chart (Cont'd)

		ON vehicle										OFF vehicle						
Reference page(AT-)	Reference page (AT-)	-	7, 11	75	75, 76	79	76, 115	76	76	106, 132	-	77	99, 111	126, 130	109, 129	131, 132	132	156
	Numbers are arranged in order of probability. Perform inspections starting with number one and working up.	Fuse	Fluid level Control linkage	Inhibitor switch Throttle sensor (Adjustment)	Revolution sensor and speed sensor Engine revolution signal Fluid temperature sensor	Engine idling rpm Line pressure	Control valve assembly Shift solenoid A	Shift solenoid B Line pressure solenoid	Lock-up solenoid Timing solenoid	Low clutch accumulator Band servo accumulator	Ignition switch and starter	Overdrive switch A/T mode switch	Torque converter Oil pump	Reverse clutch High clutch	Low clutch One-way clutch	Low & reverse brake Brake band	Band servo piston	Parking components
-	Races extremely fast or slips in changing from "D ₄ " to "D ₂ " when depressing pedal.	1		3		4	7 6	5	2							8		
-	Races extremely fast or slips in changing from "D ₃ " to "D ₂ " when depressing pedal.	1		3		4	6	5	2					8		7		
-	Races extremely fast or slips in changing from "D ₄ " or "D ₃ " to "D ₁ " when depressing pedal.	1		2		3	5	4							6 7			
-	Vehicle will not run in any range.	1 2				3		4					10 6	7	9 8		5	11
-	Transaxle noise in "D", "2", "1" and "R" ranges.	1											2					
69	Failure to change from "D ₃ " to "2 ₃ " when changing lever into "2" range		6	1 2			5 4	3							8	7		
-	Gear change from "2 ₂ " to "2 ₃ " in "2" range.		2	1														
69	Engine brake does not operate in "1" range.		2	1	3		5 4								6	7		
-	Gear change from "1 ₁ " to "1 ₂ " in "1" range.		2	1														
-	Does not change from "1 ₂ " to "1 ₁ " in "1" range			1	2		4 3								5	6		
-	Large shock changing from "1 ₂ " to "1 ₁ " in "1" range						1									2		
-	Transaxle overheats.	1		3		2 4	6	5					13 7	8 9	11	12 10		
-	A.T.F. shoots out during operation White smoke emitted from exhaust pipe during operation.	1												2 3	5	6 4		
-	Offensive smell at fluid charging pipe	1											2 3	4 5	7	8 6		
-	Torque converter is not locked up.			3 1	2 4 5	6	8		7				9					
-	Lock-up piston slip.	1		2		3	6	5 4					7					
66	Lock-up point is extremely high or low.			1	2 4		5		3									
-	A/T does not shift to "D ₄ " when setting overdrive switch to "ON" position.			3 2	4 8	9	7 5		6			1						
-	Engine is stopped at "R", "D", "2" and "1" ranges.	1					5 4 3	2										
-	Lock-up judder occurs.			5	4	1		2	3				7 6					
-	Engine uses too much gasoline.	4		3		5						1 2						


TROUBLE DIAGNOSES

A/T Shift Lock System

SHIFT LOCK ELECTRICAL PARTS LOCATION



*: When ignition key cannot be removed, even if selector lever is in "P" position, push emergency button and remove ignition key.




SAT508C

TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)


CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)

WIRING DIAGRAM






TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM:

Selector lever cannot be moved from "P" range when applying brake pedal or can be moved when releasing brake pedal.
Selector lever can be moved from "P" range when key is removed from key cylinder.



1

CHECK POWER SOURCE.

1.



2. Check voltage between control unit harness terminals ②, ④ and ground.

Battery voltage should exist.

N.G.

Check the following items:

1. Harness continuity between battery and control unit harness terminals ②, ④
2. Fuse

O.K.

2

CHECK IGNITION SIGNAL.

1.



2. Check voltage between control unit harness terminal ⑥ and ground.

0V

3.



4. Check voltage between control unit harness terminal ⑥ and ground.

Battery voltage should exist.

N.G.

Check the following items:

1. Harness continuity between battery and control unit harness terminal ⑥
2. Fuse
3. Ignition switch

O.K.

3

CHECK GROUND CIRCUIT FOR CONTROL UNIT.

1.



2. Disconnect control unit harness connector.

3. Check continuity between control unit harness terminal ⑨ and ground.

Continuity should exist.

N.G.






Repair harness or connector.

O.K.

Ⓐ


TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)



TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)




CHECK INPUT SIGNAL (DETENTION SWITCH—SHIFT).

- 1.
- 8** 2. Check voltage between control unit harness terminal ⑤ and ground with brake pedal depressed and selector lever button pushed.
Battery voltage should exist.
- 9** 3. Check voltage between control unit harness terminal ⑤ and ground with selector lever set in any position except "P".
When selector lever cannot be moved from "P" position with brake pedal depressed, push shift lock release knob. Battery voltage should exist.

N.G.

Check the following items:

1. Harness continuity between control unit harness terminal ⑤ and detention switch harness terminal ⑤
2. Harness continuity between detention switch harness terminal ⑪ and key switch harness terminal ⑪
3. Detention switch—shift (Refer to "COMPO-NENT CHECK".)



CHECK INPUT SIGNAL (STOP LAMP SWITCH).

- Check voltage between control unit harness terminal ③ and ground.


Brake pedal	Voltage
Depressed	Battery voltage
Released	0V

O.K.

N.G.

Check the following items:

1. Harness continuity between control unit harness terminal ③ and stop lamp switch harness terminal ③
2. Harness continuity between stop lamp switch harness terminal ② and fuse
3. Stop lamp switch (Refer to "COMPO-NENT CHECK".)







11 Set selector lever in "P" position.

⑥

TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)







TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)

DIAGNOSTIC PROCEDURE 2





SYMPTOM:

Ignition key cannot be removed when selector lever is set to "P" position or can be removed when selector lever is set to any position except "P".



TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)



4

CHECK INPUT SIGNAL (KEY SWITCH).

1. Reconnect control unit harness connector.
- 2.

When ignition key cannot be removed, even if selector lever is in "P" position, use emergency button.

3. Check voltage between control unit terminal ⑪ and ground.
0V

N.G. Check key switch.
(Refer to "COMPONENT CHECK".)

5

- 1.
2. Check voltage between control unit harness terminal ⑪ and ground.
Battery voltage should exist.

N.G. Check the following items:

1. Harness continuity between control unit harness terminal ⑪ and key switch harness terminal ⑪.
2. Harness continuity between key switch harness terminal ④ and fuse
3. Key switch (Refer to "COMPONENT CHECK".)

CHECK INPUT SIGNAL (DETENTION SWITCH—KEY).

- 1.
2. Set selector lever in "P" position and release selector lever button.
3. Check voltage between control unit harness terminal ⑫ and ground.
0V


N.G. Check detention switch—key.
(Refer to "COMPONENT CHECK".)

O.K.

B

TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)



CHECK INPUT SIGNAL (DETENTION SWITCH—KEY).



- 8** 1. Check voltage between control unit harness terminal ⑫ and ground with brake pedal depressed and selector lever pushed.

Battery voltage should exist.

- 9** 2. Check voltage between control unit harness terminal ⑫ and ground with selector lever set in any position except "P".

Battery voltage should exist.

N.G.

Check the following items:

1. Harness continuity between control unit harness terminal ⑫ and detention switch harness terminal ⑪


2. Harness continuity between detention switch harness terminal ⑪ and key switch harness terminal ⑪

3. Detention switch—key (Refer to "COMPONENT CHECK".)

O.K.

10

Set selector lever in "P" position and release selector lever button.



11

CHECK OUTPUT SIGNAL (KEY LOCK SIGNAL).



Check voltage between key lock solenoid harness terminal ⑧ and ground at the moment ignition key is turned from OFF to ON.

Battery voltage should exist for approximately 0.1 seconds.

N.G.

Check harness continuity between shift lock solenoid harness terminal ⑧ and control unit harness terminal ⑧.

O.K.


N.G.

Repair harness or connector.





Replace control unit.

O.K.

①





TROUBLE DIAGNOSES A/T Shift Lock System (Cont'd)



TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)



SHIFT LOCK CONTROL UNIT INSPECTION

- Measure voltage between each terminal and terminal ⑨ by following "SHIFT LOCK CONTROL UNIT INSPECTION TABLE".
- Pin connector terminal layout.

TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)

SHIFT LOCK CONTROL UNIT INSPECTION TABLE (Data are reference values.)

Terminal No.		Item	Condition	Judgment standard
⊕	⊖			
1	9	Shift lock signal	 When selector lever is set in "P" position and brake pedal is depressed.	Battery voltage
			Except above	0V
2		Power source	Any condition	Battery voltage
3		Stop lamp switch	When brake pedal is depressed.	Battery voltage
			When brake pedal is released.	0V
4		Power source	Any condition	Battery voltage
5		Detention switch (Shift)	- When key is inserted into key cylinder and selector lever is set in "P" position with selector lever button pushed. - When selector lever is set in any position except "P".	Battery voltage
			Except above	0V
6		Ignition signal		Battery voltage
			Except above	0V
8	10	Key lock signal	When ignition switch is turned from LOCK, OFF or ACC to ON.	Battery voltage (Approximately 0.1 seconds)
			Except above	0V
9	—	Ground	—	—
10	8	Key unlock signal	When selector lever is set in "P" position and ignition key is turned from ON to LOCK, OFF or ACC with selector lever button released.	Battery voltage (Approximately 0.1 seconds)
			Except above	0V
11	9	Key switch	When key is inserted into key cylinder.	Battery voltage
			When key is removed from key cylinder.	0V
12		Detention switch (Key)	- When key is inserted into key cylinder and selector lever is set in "P" position with selector lever button pushed. - When selector lever is set in any position except "P".	Battery voltage
			Except above	0V


TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)

COMPONENT CHECK

Shift lock solenoid


- Check operation by applying battery voltage to shift lock harness connector.



Detention switch—shift

- Check continuity between terminals ⑤ and ⑪ of shift lock harness connector.


Condition	Continuity
When selector lever is set in "P" position and selector lever button is released	No
Except above	Yes



Detention switch—key

- Check continuity between terminals ⑪ and ⑫ of shift lock harness connector.


Condition	Continuity
When selector lever is set in "P" position and selector lever button is released	No
Except above	Yes



Key lock solenoid

- Operation of locking mechanism
- Check operation by applying battery voltage to key lock solenoid harness connector.

Operating sound must be emitted.





TROUBLE DIAGNOSES

A/T Shift Lock System (Cont'd)

- Operation of unlocking mechanism
- Check operation by applying battery voltage to key lock solenoid harness connector.


Operating sound must be emitted.



Key switch

- Check continuity between terminals ④ and ⑪ of key switch harness connector.

Condition	Continuity
When key is inserted into key cylinder	Yes
When key is removed from key cylinder	No








Stop lamp switch

- Check continuity between terminals ② and ③ of stop lamp switch harness connector.

Condition	Continuity
When brake pedal is depressed	Yes
When brake pedal is released	No

Check stop lamp switch after adjusting brake pedal — refer to section BR.

REMOVAL AND INSTALLATION



Removal

- Disconnect drive shafts. Refer to Drive Shaft (section FA) for removal.
- Support transaxle with transmission jack.
- Place wooden blocks between engine and center member to support engine.
- Remove bolts securing rear mounting to transaxle.
- Remove drive plate cover.
- Remove bolts securing torque converter to drive plate.
 - Remove those bolts by turning crankshaft.**
 - Immediately after transaxle is disconnected, inscribe matching marks on torque converter and drive plate so that they may be reinstalled in their original positions.**
- Plug up openings such as oil charging pipe, etc.

Installation

- Drive plate runout
Maximum allowable runout:
0.5 mm (0.020 in)
 If this runout is out of allowance, replace drive plate and ring gear.
- When connecting torque converter to transaxle, measure distance "A" to be certain that they are correctly assembled.
Distance "A":
19 mm (0.75 in) or more
- Install converter to drive plate.
After converter is installed, rotate crankshaft several turns and check to be sure that transaxle rotates freely without binding.


- Tighten bolt securing transaxle.

Bolt No.	Tightening torque N·m (kg-m, ft-lb)	ℓ mm (in)
1	39 - 49 (4.0 - 5.0, 29 - 36)	45 (1.77)
2	30 - 40 (3.1 - 4.1, 22 - 30)	20 (0.79)

- Reinstall any part removed.


REMOVAL AND INSTALLATION

Installation (Cont'd)




- Reinstall any part removed.
- Refill transaxle with A.T.F. and check fluid level.
- Adjust control cable and inhibitor switch. — Refer to "ON-VEHICLE SERVICE".
- Check continuity of inhibitor switch. — Refer to "Electrical Components Inspection".
- Move selector lever through all positions to be sure that transaxle operates correctly.
With parking brake applied, rotate engine at idling. Move selector lever through "N" to "D", to "2", to "1" and to "R". A slight shock should be felt by hand gripping selector each time transaxle is shifted.
- Perform road test — Refer to "Road Testing".


MAJOR OVERHAUL



Without viscous coupling




With viscous coupling




SAT573C

MAJOR OVERHAUL



*: Always replace when disassembled.
 ★: Select with proper thickness.
 ☆: Adjustment is required.

- Q** : N·m (kg-m, ft-lb)
- A** : 44 - 59 (4.5 - 6.0, 33 - 43)
- B** : 6.3 - 8.3 (0.64 - 0.85, 4.6 - 6.1)
- C** : Refer to section "ASSEMBLY"
- D** : 20 - 26 (2.0 - 2.7, 14 - 20)
- E** : 5 - 7 (0.5 - 0.7, 3.6 - 5.1)
- F** : 6.3 - 8.3 (0.64 - 0.85, 4.6 - 6.1)
- G** : 74 - 88 (7.5 - 9.0, 54 - 65)
- H** : 16 - 21 (1.6 - 2.1, 12 - 15)
- J** : 31 - 42 (3.2 - 4.3, 23 - 31)
- K** : 7 - 9 (0.7 - 0.9, 5.1 - 6.5)
- L** : 3.7 - 5.0 (0.38 - 0.51, 2.7 - 3.7)
- M** : 5 - 7 (0.5 - 0.7, 3.6 - 5.1)
- N** : 118 - 132 (12.0 - 13.5, 87 - 98)




SAT574C


MAJOR OVERHAUL

Oil Channel


OIL CHANNELS IN OIL PUMP COVER



OIL CHANNELS IN TRANSMISSION CASE




OIL CHANNELS IN CONVERTER HOUSING



MAJOR OVERHAUL

Shift Control Components




SAT019E

- ① Selector lever release knob
- ② Return spring
- ③ Selector lever knob
- ④ Position indicator lamp
- ⑤ O.D. control switch and position indicator lamp harness connector


- ⑥ Position indicator
- ⑦ Shift lock release knob
- ⑧ Washer
- ⑨ Control cable
- ⑩ Collar

- ⑪ Detention switch (Shift and key)
- ⑫ Shift lock solenoid
- ⑬ Shift lock solenoid and detention switch harness connector
- ⑭ Selector lever assembly


DISASSEMBLY



1. Drain A.T.F. through drain hole.
2. Remove torque converter.



3. Remove control cylinder.
4. Remove control valve cover.




5. Disconnect harness connectors on control valve and remove control valve assembly.




6. Remove terminal assembly.

The terminal retrieving hooks will break if they are forced inward too far. Bend them gently inward while pulling carefully outward on the terminal. Do not pull on the wires.




7. Remove accumulator.


DISASSEMBLY




8. Remove side cover.




9. Remove output gear.



10. Draw out idler gear.




11. Remove parking pawl, return spring, parking shaft and spacer.




12. Remove speedometer and speedometer gear.


DISASSEMBLY




13. Remove governor shaft.




14. Put transaxle assembly on wooden block and remove converter housing.



15. Remove final drive assembly and reduction pinion gear.
16. After removing O-ring from input shaft, extract input shaft from converter housing.




17. Remove oil strainer.




18. Remove differential lubrication tube and gutter.


DISASSEMBLY




19. Loosen band brake stem lock nut, then back off piston stem.




20. Remove brake band and high clutch & reverse clutch pack.



- To prevent brake linings from cracking or peeling, do not stretch the flexible band unnecessarily. Before removing the brake band, always secure it with a clip as shown in the figure at left. Leave the clip in position after removing the brake band.




21. Remove one-way clutch, front carrier, rear carrier and low clutch as a set.




22. Remove low & reverse brake clutches, and detach low & reverse brake retainer snap ring pushing retainer.


DISASSEMBLY




23. Remove low and reverse brake piston with compressed air.




24. Remove bearing retainer assembly.



25. Remove band servo snap ring.





26. Remove band brake servo, retainer and return spring.



27. Loosen manual shaft lock nuts and remove manual plate.


28. Pull out retaining pin, then remove manual shaft.

Oil Pump



DISASSEMBLY

1. Remove oil pump cover.



2. Remove return spring taking care not to damage converter housing.

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)

INSPECTION

1. Inspect oil pump cover, cam ring, rotor and vanes for damage and visible wear.
2. Measure clearance between oil pump cover and cam ring, rotor and vanes in at least four places along their circumstances. The maximum measured value should be within the specified range.

- **Be sure to remove friction ring and vane ring when measuring clearance.**

Standard clearance:

0.010 - 0.024 mm

(0.0004 - 0.0009 in) (Cam ring to oil pump cover)

0.017 - 0.031 mm

(0.0007 - 0.0012 in) (Rotor to oil pump cover)



0.017 - 0.031 mm

(0.0007 - 0.0012 in) (Vane to oil pump cover)

Wear limit:

0.034 mm (0.0013 in)

If the clearance is out of above specification, replace oil pump as an assembly.




3. Measure clearance between seal ring and ring groove.

Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)


Wear limit:

0.25 mm (0.0098 in)



ASSEMBLY


1. Install cam ring, O-ring and friction ring.




2. Install return spring and spring retainer.

Oil Pump (Cont'd)

3. Assemble rotor, vanes and vane rings. Pay attention to direction of rotor.




4. Install oil pump cover.
Tighten down cover evenly in a criss-cross type pattern.




5. Rotate the pump when it has been assembled to ensure that all parts have been correctly assembled.
6. Install seal rings.

Refer to the figure at left for proper locations of the two different types of seal rings.




- These seal rings can be cut or deformed if they are improperly seated in their grooves when the drum is installed. Clean the ring grooves carefully and fill them with petroleum jelly. Then install the rings making sure they fit into the grooves as tightly as possible.

Control Cylinder




SAT869B



SAT870B

INSPECTION AND ASSEMBLY


- Inspect control cylinder body, control piston and cylinder plug for scratches or damage. Replace if necessary.
- When assembling, pay attention to the direction of lip seal.



SAT812

- After assembling, check the operation.

Control Valve Assembly





SAT871B

REPAIR FOR COMPONENT PARTS



Control Valve Assembly (Cont'd)

DISASSEMBLY


1. Remove solenoids.
 - a. Remove timing solenoid.
 - b. Remove O-ring from solenoid.
 - c. Remove shift solenoid A, shift solenoid B, line pressure solenoid and lock-up solenoid.
 - d. Remove O-rings from solenoids.



2. Remove solenoid body.
 - a. Place lower body facedown and remove bolts.
- Be careful not to drop solenoid body.**




- b. Place upper body face down, and remove solenoid body with separator gaskets and separator plate.
 - c. Remove separator gaskets, separator plate and oil filter from solenoid body.




3. Disassemble upper and lower bodies.
 - a. Place lower body facedown, and remove bolts, reamer bolts and support plate.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)




- b. Position upper body downward. Remove lower body with separator plate and separator gasket attached to upper body.




- c. Remove oil filter, separator gaskets and separator plate from upper body.



- d. Check to see that steel balls are properly positioned in upper body and then remove them from upper body.




Control Valve Upper Body



SAT597C

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)



SAT598C



REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)

DISASSEMBLY


1. Remove valves at parallel pins.

Do not use a magnetic hand.




- a. Remove parallel pins while pressing their corresponding plugs and sleeves.

Remove plug slowly to prevent internal parts from jumping out.




- b. Place mating surface of valve facedown, and remove internal parts.

- If a valve is hard to remove, place valve body facedown and lightly tap it with a soft hammer.
- Be careful not to drop or damage valves and sleeves.



2. Remove valves at retainer plates.

- a. Remove retainer plates while pressing their corresponding plugs, sleeves or springs.



- b. Place mating surface of valve facedown, and remove internal parts.

- If a valve is hard to remove, lightly tap valve body with a soft hammer.
- Be careful not to drop or damage valves, sleeves, etc.


REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)

INSPECTION

Valve springs

- Measure free length and outer diameter of each valve spring. Also check for damage or deformation.
- Numbers of each valve spring listed in table below are the same as those in the figure on page AT-118.



Inspection standard


Unit: mm (in)

Parts	Item	Part No.	ℓ	D
① Pilot valve spring		31742-27X60	56.6 (2.228)	10.9 (0.429)
② Lock-up shuttle valve spring		31742-27X65	28.8 (1.134)	9.0 (0.354)
③ Pressure modifier accumulator valve spring		31742-27X72	30.84 (1.2142)	9.8 (0.386)
④ Pressure regulator valve outer spring		31742-27X61	37.3 (1.469)	12.9 (0.508)
⑤ Pressure regulator valve inner spring		31742-27X62	37.7 (1.484)	7.95 (0.3130)
⑥ 1 - 2 shift valve spring		31742-27X61	24.9 (0.980)	7.0 (0.276)
⑦ 2 - 3 shift valve spring		31762-27X61	24.9 (0.980)	7.0 (0.276)
⑧ 3 - 4 shift valve spring		31762-27X61	24.9 (0.980)	7.0 (0.276)
⑨ Low clutch timing valve spring		31736-01X02	21.7 (0.854)	6.65 (0.2618)
⑩ 3 - 2 timing valve spring		31736-01X02	21.7 (0.854)	6.65 (0.2618)
⑪ Torque converter relief valve spring		31742-27X01	44.7 (1.760)	7.0 (0.276)
⑫ 1st reducing valve spring		31742-27X67	48.8 (1.921)	6.8 (0.268)
⑬ Feedback accumulator valve spring		31742-27X	33.75 (1.3287)	6.35 (0.2500)
⑭ Lock-up control valve spring		31742-27X69	41.8 (1.646)	7.0 (0.276)

- Replace valve springs if deformed or fatigued.

Control valves

- Check sliding surfaces of valves, sleeves and plugs.



ASSEMBLY


1. Lubricate the control valve body and all valves with A.T.F. Install control valves by sliding them carefully into their bores.

Be careful not to scratch or damage valve body.

REPAIR FOR COMPONENT PARTS


Control Valve Upper Body (Cont'd)

- Wrap a small screwdriver with vinyl tape and use it to insert the valves into proper position.




— Pressure regulator valve —


Position plug in sleeve and install pressure regulator valve on upper body.




2. Install parallel pins and retainer plates.



- While pushing plug, install parallel pin.



- Insert retainer plate while pressing their corresponding plugs, sleeves or springs.




REPAIR FOR COMPONENT PARTS

Control Valve Assembly

INSPECTION


Separator plates

Check to make sure that separator plate is free of damage and not deformed and oil holes are clean.




Oil filter

Check to make sure that filter is not clogged or damaged.




Timing solenoid

Measure resistance — Refer to "Electrical Components Inspection".




4-unit solenoid assembly (Line pressure solenoid, lock-up solenoid and shift solenoids A and B)

- Check that filter is not clogged or damaged (line pressure solenoid and lock-up solenoid).
- Measure resistance of each solenoid — Refer to "Electrical Components Inspection".



Fluid temperature sensor

Measure resistance — Refer to "Electrical Components Inspection".




REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)

ASSEMBLY


1. Assemble upper and lower bodies.
 - a. Place oil circuit of upper body face up. Install steel balls in their proper positions.



- b. Install upper body separator gasket, separator plate and lower body separator gasket on upper body.




- c. Fit oil filter and install lower body on upper body.




- d. Temporarily assemble lower and upper bodies, using reamer bolt as a guide.

Be careful not to dislocate or drop steel balls and oil filter.




REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)



2. Install solenoid body on control valve body.
- a. Fit oil filter and install solenoid body separator gaskets and separator plate on solenoid body.



- b. Install solenoid body on control valve body and temporarily tighten bolts.




- c. Install accumulator support plate and harness clips in their proper locations, and tighten all bolts.

Bolt (A):

: 3.4 - 4.4 N·m (0.35 - 0.45 kg-m, 2.5 - 3.3 ft-lb)


Other bolts:

: 7 - 9 N·m (0.7 - 0.9 kg-m, 5.1 - 6.5 ft-lb)



3. Install solenoids.
- a. Attach O-ring and install 4-unit solenoid assembly on solenoid body.


: 7 - 9 N·m (0.7 - 0.9 kg-m, 5.1 - 6.5 ft-lb)



- b. Attach O-ring, and install and tighten timing solenoid firmly.

High Clutch

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.




*: Select with proper thickness.

SAT211C

DISASSEMBLY

- Compress clutch springs and remove snap ring from spring retainer.
- Place clutch drum onto oil pump, and withdraw clutch piston with compressed air.



REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)




INSPECTION AND ASSEMBLY

1. Check clutch drive plate facing for wear or damage.

Standard drive plate thickness:

1.6 mm (0.063 in)


2. Check for wear on snap ring, weak or broken coil springs, and warped spring retainer.
 3. Lubricate clutch drum bushing, and install inner seal and piston seal as illustrated. Be careful not to stretch seals during installation.
- Never assemble clutch dry; always lubricate its components thoroughly.
 - Always install piston seal in direction shown in figure at left.



4. Assemble piston, being careful not to allow seal to kink or become damaged during installation.

Use Tool, which does not damage lip seal, to make sure the lip seal goes into place.

- After installing piston, turn piston by hand to ensure that there is no binding.




5. Install clutch springs.
6. Reinstall snap ring. Be sure snap ring is properly seated.

REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)

7. Install driven plates, drive plates, and secure with snap ring.



8. Measure clearance between retaining plate and snap ring. Always measure the existing minimum clearance, since snap ring is a wave type.

Specified clearance:

Standard


1.4 - 1.8 mm (0.055 - 0.071 in)

Allowable limit


2.6 mm (0.102 in)

Available retaining plates:

Refer to S.D.S.




9. Check high clutch operation using compressed air.




Low Clutch

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.




★: Select with proper thickness.

SAT212C



- Use Tool to remove the clutch spring snap ring.




SAT826

- Service procedures for low clutch are essentially the same as those for high clutch, with the following exception:
Specified clearance between retaining plate and snap ring:
Standard
 0.5 - 0.8 mm (0.020 - 0.031 in)
Allowable limit
 1.8 mm (0.071 in)
Available retaining plates:
 Refer to S.D.S.

REPAIR FOR COMPONENT PARTS


Low Clutch (Cont'd)

- After assembly, check the operation of clutch.



Reverse Clutch

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.



★: Select with proper thickness.

SAT067C

Service procedures for reverse clutch are essentially the same as those for high clutch, with the following exception:

- Remove reverse clutch piston.



REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)

Specified clearance between retaining plate and snap ring:

Standard



0.5 - 0.8 mm (0.020 - 0.031 in)

Allowable limit

1.2 mm (0.047 in)

Available retaining plates:


Refer to S.D.S.



- After assembly, check the operation of clutch.

Low & Reverse Brake

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.



★: Select with proper thickness.

SAT213C

REPAIR FOR COMPONENT PARTS

Low & Reverse Brake (Cont'd)

INSPECTION

- Examine low and reverse brake for damaged clutch drive plate facing and worn snap ring.
- Check drive plate facing for wear or damage; if necessary, replace.

Specified clearance between retaining plate and snap ring:

Standard

1.2 - 1.6 mm (0.047 - 0.063 in)


Allowable limit

2.8 mm (0.110 in)

Available retaining plates:

Refer to S.D.S.

Brake Band and Band Servo




REPAIR FOR COMPONENT PARTS

Brake Band and Band Servo (Cont'd)

INSPECTION

- Inspect band friction material for wear. If cracked, chipped or burnt spots are apparent, replace the band.
- Check band servo components for wear and scoring.



Planetary Carrier

INSPECTION

- Check clearance between pinion washer and planetary carrier with a feeler gauge.

Standard clearance:

Front carrier



0.15 - 0.70 mm (0.0059 - 0.0276 in)

Rear carrier

0.20 - 0.70 mm (0.0079 - 0.0276 in)

Replace if the clearance exceeds 0.80 mm (0.0315 in).

- Check planetary gear sets and bearings for damaged or worn gears.



Bearing Retainer and Output Shaft

INSPECTION


Measure clearance between seal ring and ring groove.

Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Wear limit:

0.25 mm (0.0098 in)





Converter Housing and Transmission Case

BEARING OUTER RACE



- Reduction pinion gear front bearing outer race.

REPAIR FOR COMPONENT PARTS

Converter Housing and Transmission Case (Cont'd)




- Differential side bearing outer race





OIL SEAL

- Torque converter oil seal




- Differential side oil seal

Final Drive (Without viscous coupling)



DISASSEMBLY

1. Remove final gear.





2. Drive out pinion mate shaft lock pin and draw out pinion mate shaft.


REPAIR FOR COMPONENT PARTS

Final Drive (Without viscous coupling) (Cont'd)

3. Remove governor shaft drive gear.




4. Drive out differential side bearing outer race and inner cone.




INSPECTION

1. Check mating surface of differential case, side gears and pinion mate gears. Replace as required.



2. Check clearance between side gear and differential case with washer following the procedure below.
 - a. Set Tool and dial gauge on side gear.



- b. Move side gear up and down to measure dial gauge deflection. Always measure gauge deflection on both side gears.


Clearance between side gear and differential case with washer:

0.1 - 0.2 mm (0.004 - 0.008 in)


- c. If clearance exceeds the specified value, check for wear and replace necessary parts.
3. Check tapered roller bearings for wear, scratches, pitching or flaking.

REPAIR FOR COMPONENT PARTS

Final Drive (Without viscous coupling) (Cont'd) ASSEMBLY



1. Install the side gear and thrust washer in the differential case.
2. Install the pinion mate gear and thrust washer in the differential case while rotating them.



3. Insert pinion mate shaft.
- When inserting, be careful not to damage pinion mate washers.**

4. Measure clearance between side gear and pinion mate gear, referring to "Inspection". If necessary, adjust.

Side gear to pinion mate clearance:


0.1 - 0.2 mm (0.004 - 0.008 in)

Side gear thrust washer:


Refer to S.D.S.

5. Install pinion mate shaft lock pin using a punch.

Make sure that lock pin is flush with case.





6. Install governor shaft drive gear.




7. Press on differential side bearing inner cone and outer race.
8. Install final gear.

Final Drive (With viscous coupling)



DISASSEMBLY


1. Remove final gear.
2. Remove differential side bearings.




3. Remove viscous coupling.

REPAIR FOR COMPONENT PARTS

Final Drive (With viscous coupling) (Cont'd)




4. Drive out pinion mate shaft lock pin and draw out pinion mate shaft.




INSPECTION

1. Check viscous coupling case for cracks and silicone oil leakage.




2. Check mating surface of differential case, side gears and pinion mate gears. Replace as required.



3. Check clearance between side gear and differential case with washer following the procedure below.
 - a. Set Tool and dial gauge on side gear.

REPAIR FOR COMPONENT PARTS

Final Drive (With viscous coupling) (Cont'd)




- b. Move side gear up and down to measure dial gauge deflection. Always measure gauge deflection on both side gears.

Clearance between side gear and differential case with washer:

0.1 - 0.2 mm (0.004 - 0.008 in)


- c. If clearance exceeds the specified value, check for wear and replace necessary parts.
4. Check tapered roller bearings for wear, scratches, pitching or flaking.



ASSEMBLY

1. Install the side gear and thrust washer in the differential case.
2. Install the pinion mate gear and thrust washer in the differential case while rotating them.
3. Insert pinion mate shaft.

When inserting, be careful not to damage pinion mate washers.



4. Measure clearance between side gear and pinion mate gear, referring to "Inspection". If necessary, adjust.

Side gear to pinion mate clearance:


0.1 - 0.2 mm (0.004 - 0.008 in)

Side gear thrust washer:


Refer to S.D.S.

5. Install pinion mate shaft lock pin using a punch.


Make sure that lock pin is flush with case.



6. Install viscous coupling and final gear.




7. Press on differential side bearings.




SAT586C


ASSEMBLY




1. Install differential lubrication tube and differential gutter to converter housing.




2. Install oil strainer.



3. Install detent spring assembly.




4. Pass parking rod into the hole in the manual plate and then install manual plate on manual shaft.




5. Install band brake servo, retainer and return spring and secure with snap ring.


ASSEMBLY




6. Install reduction gear.
 - a. Position reduction gear in transmission case so that it meshes with idler gear.
 - b. Press reduction gear into place using a drift, and install idler gear.




7. Install bearing retainer assembly.
 - a. Install seal rings onto bearing retainer with great care. Clean the grooves and liberally apply petroleum jelly to hold the rings in place. Otherwise, they could be cut or deformed when the low clutch and carrier assembly are installed.



- b. Install bearing retainer assembly.




8. Install parking pawl and parking shaft.




9. Install spacer and return spring.


ASSEMBLY



10. Install output gear.



11. Temporarily install side cover and gasket.




12. Lubricate low and reverse brake piston seal, then install piston by tapping it evenly with Tool.



13. Install low and reverse brake retainer, and secure with snap ring.

14. Install low and reverse brake driven & drive plates and retaining plate, then secure with snap ring.

ASSEMBLY



15. After low and reverse brake has been completely assembled, measure clearance between snap ring and retainer plate. If measurement exceeds specifications, it can be adjusted by replacing retainer plate with one of a different thickness.

Low and reverse brake clearance:

Standard


1.2 - 1.6 mm (0.047 - 0.063 in)

Allowable limit


3.0 mm (0.118 in)

Retaining plate of low & reverse brake:

Refer to S.D.S.




- Check low & reverse brake operation using air.




16. Assemble front carrier, rear carrier and low clutch.


ASSEMBLY




17. Install carrier set.




18. Install one-way clutch assembly while rotating front carrier with high clutch hub.




19. Remove high clutch hub, and install clutch snap ring.




20. Assemble reverse clutch and high clutch.



21. Install reverse and high clutch as a pack.




22. Install brake band and anchor pin. Temporarily tighten anchor bolt by hand.




23. Adjust total end play and clutch pack end play as follows:

— Total end play —


a. Remove thrust bearing race from high clutch drum.




b. Install needle bearing on top of oil pump cover.




ASSEMBLY




- c. Place Tools (bridge and gauging cylinder) on machined gasket surface of converter housing. Allow gauging cylinder to rest on needle bearing and lock it in place with thumbscrew.



- d. Insert Tool (total end play gauging plunger) into gauging cylinder.




- e. Place bridge, legs up, onto machined gasket surface of transaxle case, allowing gauging plunger to rest on surface where bearing race was removed. Lock plunger in place.



- f. Remove bridge and use feeler gauge to measure gap between gauging cylinder and shoulder of gauging plunger.
g. Use your feeler gauge reading to select appropriate bearing race thickness.


Oil pump housing bearing races:
Refer to S.D.S.




— Clutch pack end play —

- a. Place Tools (bridge and gauging cylinder) onto machined gasket surface of transaxle case and allow cylinder to rest on high clutch drum. Lock cylinder into place.


ASSEMBLY



- You are now measuring dimension "C".





- b. Now, insert Tool (clutch pack gauging plunger) into gauging cylinder.




- c. Place bridge, gauging cylinder, and gauging plunger onto machined gasket surface of converter housing. Make sure thrust washer is removed. Lock gauging plunger in place.
- d. Use feeler gauge to measure gap between gauging cylinder and shoulder of gauging plunger.
- e. Use your feeler gauge measurement to select correct washer thickness to give proper clutch pack end play.

Clutch pack thrust washers:
Refer to S.D.S.




- 24. Adjust differential side bearing preload as follows:

ASSEMBLY





— Without viscous coupling —

- a. Remove left side bearing inner cone from transmission case.




- b. Place Tools (bridge and gauging cylinder) on machined gasket surface of transmission case and allow gauging cylinder to rest on bearing mating surface. Lock gauging cylinder in place.

- You are now measuring dimension "E".




- c. Put final drive assembly into converter housing, then put side bearing inner cone on differential case.
- d. Hold inner bearing cone in place while spinning final drive assembly in order to seat bearings.



- e. Insert Tool (differential side bearing gauging plunger) into gauging cylinder.



ASSEMBLY




- f. Place bridge, gauging cylinder, and gauging plunger onto machined gasket surface of converter housing and allow gauging plunger to rest on surface of bearing inner cone. Lock plunger in place.
- g. Use feeler gauge to measure clearance between gauging cylinder and shoulder of the gauging plunger.
- h. Use your feeler gauge reading to select appropriate side bearing preload shim(s).

Differential side bearing adjusting shims:

Refer to S.D.S.




- i. Install selected shims and left side bearing inner cone.




— With viscous coupling —

- a. Remove left side bearing outer race and preload adjusting shims from transmission case.




- b. Place Tools (bridge and gauging cylinder) on machined gasket surface of transmission case and allow gauging cylinder to drop into bearing race bore until it bottoms. Lock gauging cylinder in place.


ASSEMBLY




- You are now measuring dimension "F".




- c. Put final drive assembly into converter housing, then put side bearing outer race on differential side bearing.
- d. Turn outer race to seat bearing.



- e. Insert Tool (differential side bearing gauging plunger) into gauging cylinder.




- f. Place bridge, gauging cylinder, and gauging plunger onto machined gasket surface of converter housing and allow gauging plunger to drop onto rear surface of side bearing outer race. Lock plunger in place.




- g. Use feeler gauge to measure clearance between gauging cylinder and shoulder of the gauging plunger.
- h. Use your feeler gauge reading to select appropriate side bearing preload shim(s).

**Available differential side bearing adjusting shims:
Refer to S.D.S.**


ASSEMBLY




- i. Install selected shims and left side bearing outer race.



25. Install input shaft.




26. Install selected thrust washer and bearing on oil pump cover.




27. Place gasket on transmission case and install converter housing.

Bolt	Tightening torque N·m (kg-m, ft-lb)	ℓ mm (in)
(A)	21 - 23 (2.1 - 2.3, 15 - 17)	31.5 (1.240)
(B)		27 (1.06)
(C)	19 - 23 (1.9 - 2.3, 14 - 17)	31.5 (1.240)
(D)		35 (1.38)
(E)	43 - 47 (4.4 - 4.8, 32 - 35)	50 (1.97)
(F)	21 - 25 (2.1 - 2.6, 15 - 19)	39 (1.54)
(G)	43 - 47 (4.4 - 4.8, 32 - 35)	
(H)	45 - 47 (4.6 - 4.8, 33 - 35)	35 (1.38)
(I)		35 (1.38)

Always use new bolts at portions (A), (B), (H) and (I) as they are self-sealing bolts. Apply A.T.F. to thread of other bolts by that fix converter housing to transmission case when installing them.




28. Install O-ring onto input shaft.




29. Adjust output shaft and idler gear bearing preload as follows:


- a. Remove side cover temporarily installed.
- b. Remove output gear and idler gear bearing outer races and shims. (The races will interchange, so be sure to keep each race with its correct bearing.)



c. Place Tools (bridge and gauging cylinder) onto machined gasket surface of side cover. Allow gauging cylinder to drop into output gear bearing race bore until it bottoms. Lock cylinder in place with the thumbscrew.




- You are now measuring dimension "H".
- d. Put correct bearing races on the output gear and idler gear bearings, and turn races to seat bearings.




e. Place Tool (output gauging plunger) into the gauging cylinder.

ASSEMBLY




- f. Now, place bridge onto machined gasket surface of transmission case and allow gauging plunger to drop onto rear surface of output gear bearing race.



- g. Lock gauging plunger in place with thumbscrew. Use feeler gauge to measure gap between gauging cylinder and shoulder of gauging plunger.
- h. Use feeler gauge reading to select the correct shim(s).


Output shaft bearing adjusting shims:

Refer to S.D.S.




- i. Now, measure for the correct preload shims at the idler gear bearing in the same way. Place bridge onto machined surface of side cover and allow gauging cylinder to drop until it contacts idler bearing race mating surface.

- You are now measuring dimension "K".



- j. Lock gauging cylinder in place. Insert Tool (gauging plunger) into gauging cylinder and place bridge onto machined surface of case, so that gauging plunger meets idler bearing race rear surface.


ASSEMBLY




- k. Lock gauging plunger in place and use feeler gauge to measure gap between gauging cylinder and gauging plunger.
- l. Use your measured distance to select correct shim(s) for idler gear bearing preload.

Idler gear bearing adjusting shims:

Refer to S.D.S.




- m. Install selected shim(s) and bearing outer races.



30. Move manual lever until parking pawl engages idler gear. Measure clearance between parking pawl and parking actuator.

If clearance is outside specifications, replace parking pawl.

Part number	Identification letter
31989-21X00	D
31989-21X01	E
31989-21X02	F



Example:


When parking pawl with identification letter "E" is used:

Clearance "L" is larger.

→ Replace with parking pawl with identification letter "D".

Clearance "L" is smaller.

→ Replace with parking pawl with identification letter "F".



31. Install side cover and gasket.

Always use new bolts at portions ② and ④ as they are self-sealing bolts. Apply A.T.F. to thread of other bolts by that fix side cover to transmission case when installing them.


Bolts ① and ③:

⌚: 19 - 23 N·m (1.9 - 2.3 kg-m, 14 - 17 ft-lb)

Bolts ② and ④:

⌚: 21 - 23 N·m (2.1 - 2.3 kg-m, 15 - 17 ft-lb)


ASSEMBLY



32. Insert Tool into final drive portion to see if internal parts rotates smoothly. Rotating in direction "B" is slightly harder than in direction "A".

If abnormalities are noted, proceed with the following:

- Disassemble parts to see if they are properly assembled.
- Readjust bearing preloads of final drive, output shaft and idler gear.



33. Adjust brake band.

- a. First tighten anchor end pin.

Anchor end pin:

⌚: 4 - 6 N·m (0.4 - 0.6 kg-m, 2.9 - 4.3 ft-lb)

- b. Back off anchor end pin "N" turns.


Number of returning revolutions for anchor end pin "N":

5.25 turn


- c. Tighten lock nut while holding anchor end pin stationary.

Lock nut:


⌚: 31 - 42 N·m (3.2 - 4.3 kg-m, 23 - 31 ft-lb)



34. Install terminal assembly, paying attention to the direction of its hook.



35. Install accumulator and spring.



36. Insert manual valve to control valve body, then assemble them to transmission case.


Bolt A :

⌚: 3.7 - 5.0 N·m (0.38 - 0.51 kg-m, 2.7 - 3.7 ft-lb)


Other bolts:

⌚: 7 - 9 N·m (0.7 - 0.9 kg-m, 5.1 - 6.5 ft-lb)


ASSEMBLY




- Pay attention to the direction of manual valve groove.




37. Connect harness connectors between terminal assembly and solenoids.



38. Put gasket on transmission case and install valve cover.
Always use new bolts as they are self-sealing bolts.




39. Install control cylinder.




40. Install revolution sensor.


ASSEMBLY



41. Install governor shaft.



42. Install speedometer parts.



43. Pour approximately 2 liters (2-1/8 US qt, 1-3/4 Imp qt) of automatic transmission fluid into converter housing.

44. Install torque converter to converter housing.

Be careful not to scratch front oil seal.

45. Apply sealant to threads of drain plug and install it in place.

46. Install inhibitor switch to transmission case.

47. Adjust inhibitor switch. Refer to On-vehicle Service.

48. Make sure that manual lever operates smoothly.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

Automatic transaxle model	RE4F02A	RE4F02V
Automatic transaxle assembly Model code number	27 X 63 (Without viscous coupling)	27 X 70 (With viscous coupling)
Transaxle gear ratio		
1st	2.785	
2nd	1.545	
3rd	1.000	
4th	0.694	
Reverse	2.272	
Final drive (Center differential gear)	3.642	3.876
Recommended oil	Automatic transmission fluid Type DEXRON™	
Oil capacity (Approximately) ℓ (US qt, Imp qt)	7.4 (7-7/8, 6-1/2)	

Specifications and Adjustment

CLUTCHES AND BRAKES

High clutch		
Number of drive plates	4	
Number of driven plates	3 + 1	
Thickness of drive plate mm (in)		
Standard	1.6 (0.063)	
Allowable limit	1.4 (0.055)	
Clearance mm (in)		
Standard	1.4 - 1.8 (0.055 - 0.071)	
Allowable limit	2.6 (0.102)	
Thickness of retaining plate	Thickness mm (in)	Part number
	3.6 (0.142)	31537-41X61
	3.8 (0.150)	31537-41X62
	4.0 (0.157)	31537-41X63
	4.2 (0.165)	31537-41X64
	4.4 (0.173)	31537-41X65
	4.6 (0.181)	31537-41X66
	4.8 (0.189)	31537-41X67
	5.0 (0.197)	31537-41X68

Reverse clutch		
Number of drive plates	2	
Number of drive plates	2	
Thickness of drive plate mm (in)		
Standard	2.0 (0.079)	
Allowable limit	1.8 (0.071)	
Clearance mm (in)		
Standard	0.5 - 0.8 (0.020 - 0.031)	
Allowable limit	1.2 (0.047)	
Thickness of retaining plate	Thickness mm (in)	Part number
	4.6 (0.181)	31537-21X60
	4.8 (0.189)	31537-21X61
	5.0 (0.197)	31537-21X62
	5.2 (0.205)	31537-21X63
	5.4 (0.213)	31537-21X64
Low clutch		
Number of drive plates	5	
Number of drive plates	6	
Thickness of drive plate mm (in)		
Standard	2.0 (0.079)	
Allowable limit	1.8 (0.071)	
Clearance mm (in)		
Standard	0.5 - 0.8 (0.020 - 0.031)	
Allowable limit	1.8 (0.071)	
Thickness of retaining plate	Thickness mm (in)	Part number
	4.8 (0.189)	31597-21X00
	5.0 (0.197)	31597-21X01
	5.2 (0.205)	31597-21X02
	5.4 (0.213)	31597-21X03
	5.6 (0.220)	31597-21X04
	5.8 (0.228)	31597-21X05
	6.0 (0.236)	31597-21X06

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Specifications and Adjustment (Cont'd)

Brake band		
Piston size	mm (in)	
Big dia.	75 (2.95)	
Small dia.	43 (1.69)	
Anchor end pin tightening torque	4 - 6 (0.4 - 0.6, 2.9 - 4.3) N·m (kg-m, ft-lb)	
Number of returning revolutions for anchor end pin	5.0 - 5.5	
Lock nut tightening torque	31 - 42 (3.2 - 4.3, 23 - 31) N·m (kg-m, ft-lb)	
Low & reverse brake		
Number of drive plates	6	
Number of driven plates	6	
Thickness of drive plate	mm (in)	
Standard	2.0 (0.079)	
Allowable limit	1.8 (0.071)	
Clearance	mm (in)	
Standard	1.2 - 1.6 (0.047 - 0.063)	
Allowable limit	2.8 (0.110)	
Thickness of retaining plate	Thickness mm (in)	Part number
	3.4 (0.134)	31667-23X00
	3.6 (0.142)	31667-23X01
	3.8 (0.150)	31667-23X02
	4.0 (0.157)	31667-23X03
	4.2 (0.165)	31667-23X04
	4.4 (0.173)	31667-23X05
	4.6 (0.181)	31667-23X06
	4.8 (0.189)	31667-23X07
	5.0 (0.197)	31667-23X08

PLANETARY CARRIER

Unit: mm (in)

	Front carrier	Rear carrier
Clearance between pinion washer and planetary carrier		
Standard	0.15 - 0.70 (0.0059 - 0.0276)	0.20 - 0.70 (0.0079 - 0.0276)
Allowable limit	0.80 (0.0315)	

OIL PUMP, BEARING RETAINER AND OUTPUT SHAFT

Unit: mm (in)

Oil pump clearance	
Cam ring — oil pump cover	
Standard	0.010 - 0.024 (0.0004 - 0.0009)
Allowable limit	0.034 (0.0013)
Rotor — oil pump cover	
Standard	0.017 - 0.031 (0.0007 - 0.0012)
Allowable limit	0.034 (0.0013)
Vane — oil pump cover	
Standard	0.017 - 0.031 (0.0007 - 0.0012)
Allowable limit	0.034 (0.0013)
Seal ring clearance	
Standard	0.10 - 0.25 (0.0039 - 0.0098)
Allowable limit	0.25 (0.098)

TOTAL END PLAY

Total end play	0.25 - 0.55 mm (0.0098 - 0.0217 in)	
Thickness of oil pump housing bearing race	Thickness mm (in)	Part number
	0.8 (0.031)	31429-21X00
	1.0 (0.039)	31429-21X01
	1.2 (0.047)	31429-21X02
	1.4 (0.055)	31429-21X03
	1.6 (0.063)	31429-21X04
	1.8 (0.071)	31429-21X05
	2.0 (0.079)	31429-21X06

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Specifications and Adjustment (Cont'd)

CLUTCH PACK END PLAY

Clutch pack end play	0.4 - 0.8 mm (0.016 - 0.031 in)	
Thickness of clutch pack thrust washer	Thickness mm (in)	Part number
	0.7 (0.028)	31528-21X00
	0.9 (0.035)	31528-21X01
	1.1 (0.043)	31528-21X02
	1.3 (0.051)	31528-21X03
	1.5 (0.059)	31528-21X04
	1.7 (0.067)	31528-21X05
	1.9 (0.075)	31528-21X06

DIFFERENTIAL SIDE GEAR THRUST WASHER

Without viscous coupling

Allowable clearance between side gear and differential case with washer	0.1 - 0.2 mm (0.004 - 0.008 in)
Thickness mm (in)	Part number
0.75 - 0.80 (0.0295 - 0.0315)	38424-E3000 or 38424-E3020
0.80 - 0.85 (0.0315 - 0.0335)	38424-E3001 or 38424-E3021
0.85 - 0.90 (0.0335 - 0.0354)	38424-E3002 or 38424-E3022
0.90 - 0.95 (0.0354 - 0.0374)	38424-E3003 or 38424-E3023

DIFFERENTIAL SIDE BEARING PRELOAD

Differential side bearing adjusting shim (Without viscous coupling)

Thickness mm (in)	Part number
0.12 (0.0047)	38453-21X13
0.16 (0.0063)	38453-21X14
0.20 (0.0079)	38453-21X15
0.24 (0.0094)	38453-21X16
0.28 (0.0110)	38453-21X17
0.32 (0.0126)	38453-21X18
0.36 (0.0142)	38453-21X19
0.40 (0.0157)	38453-21X20
0.44 (0.0173)	38453-21X00
0.48 (0.0189)	38453-21X01
0.52 (0.0205)	38453-21X02
0.56 (0.0220)	38453-21X03
0.60 (0.0236)	38453-21X04
0.64 (0.0252)	38453-21X05
0.68 (0.0268)	38453-21X06
0.72 (0.0283)	38453-21X07
0.76 (0.0299)	38453-21X08
0.80 (0.0315)	38453-21X09
0.84 (0.0331)	38453-21X10
0.88 (0.0346)	38453-21X11
0.92 (0.0362)	38453-21X12

With viscous coupling (L.H. side gear)

Allowable clearance between side gear and viscous coupling with washer	0.1 - 0.2 mm (0.004 - 0.008 in)
Thickness mm (in)	Part number
0.43 - 0.45 (0.0169 - 0.0177)	38424-51E10
0.52 - 0.54 (0.0205 - 0.0213)	38424-51E11
0.61 - 0.63 (0.0240 - 0.0248)	38424-51E12
0.70 - 0.72 (0.0276 - 0.0283)	38424-51E13
0.79 - 0.81 (0.0311 - 0.0319)	38424-51E14

With viscous coupling (R.H. side gear)

Allowable clearance between side gear and differential case with washer	0.1 - 0.2 mm (0.004 - 0.008 in)
Thickness mm (in)	Part number
0.75 - 0.80 (0.0295 - 0.0315)	38424-21X00
0.80 - 0.85 (0.0315 - 0.0335)	38424-21X01
0.85 - 0.90 (0.0335 - 0.0354)	38424-21X02
0.90 - 0.95 (0.0354 - 0.0374)	38424-21X03

Differential side bearing adjusting shim (With viscous coupling)

Thickness mm (in)	Part number
0.12 (0.0047)	38753-56E15
0.16 (0.0063)	38753-56E16
0.20 (0.0079)	38753-56E17
0.24 (0.0094)	38753-56E18
0.28 (0.0110)	38753-56E19
0.32 (0.0126)	38753-56E20
0.36 (0.0142)	38753-56E00
0.40 (0.0157)	38753-56E01
0.44 (0.0173)	38753-56E02
0.48 (0.0189)	38753-56E03
0.52 (0.0205)	38753-56E04
0.56 (0.0220)	38753-56E05
0.60 (0.0236)	38753-56E06
0.64 (0.0252)	38753-56E07
0.68 (0.0268)	38753-56E08
0.72 (0.0283)	38753-56E09
0.76 (0.0299)	38753-56E10
0.80 (0.0315)	38753-56E11
0.84 (0.0331)	38753-56E12
0.88 (0.0346)	38753-56E13
0.92 (0.0362)	38753-56E14

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Specifications and Adjustment (Cont'd)

OUTPUT SHAFT PRELOAD

Output shaft preload adjusting shim

Thickness mm (in)	Part number
0.12 (0.0047)	31499-21X00
0.16 (0.0063)	31499-21X01
0.20 (0.0079)	31499-21X02
0.24 (0.0094)	31499-21X03
0.28 (0.0110)	31499-21X04
0.32 (0.0126)	31499-21X05
0.36 (0.0142)	31499-21X06
0.40 (0.0157)	31499-21X07
0.44 (0.0173)	31499-21X08
0.48 (0.0189)	31499-21X09
0.52 (0.0205)	31499-21X10
0.56 (0.0220)	31499-21X11
0.60 (0.0236)	31499-21X12
0.64 (0.0252)	31499-21X13
0.68 (0.0268)	31499-21X14
0.72 (0.0283)	31499-21X15
0.76 (0.0299)	31499-21X16
0.80 (0.0315)	31499-21X17
0.84 (0.0331)	31499-21X18
0.88 (0.0346)	31499-21X19
0.92 (0.0362)	31499-21X20
1.44 (0.0567)	31499-21X21
1.96 (0.0772)	31499-21X22


IDLER GEAR PRELOAD

Idler gear preload adjusting shim

Thickness mm (in)	Part number
0.36 (0.0142)	31499-21X06
0.40 (0.0157)	31499-21X07
0.44 (0.0173)	31499-21X08
0.48 (0.0189)	31499-21X09
0.52 (0.0205)	31499-21X10
0.56 (0.0220)	31499-21X11
0.60 (0.0236)	31499-21X12
0.64 (0.0252)	31499-21X13
0.68 (0.0268)	31499-21X14
0.72 (0.0283)	31499-21X15
0.76 (0.0299)	31499-21X16
0.80 (0.0315)	31499-21X17
0.84 (0.0331)	31499-21X18
0.88 (0.0346)	31499-21X19
0.92 (0.0362)	31499-21X20
1.44 (0.0567)	31499-21X21
1.96 (0.0772)	31499-21X22

PARKING PAWL

Clearance "L"	0.25 - 0.50 mm (0.0098 - 0.0197 in)
Identification letter	Part number
D	31989-21X00
E	31989-21X01
F	31989-21X02



SAT914

REMOVAL AND INSTALLATION

Throttle wire	
Stroke "L"	39 - 43 mm (1.54 - 1.69 in)
Number of returning revolution for lock nut	2.75 - 3.25
Lock nut tightening torque	8 - 10 N·m (0.8 - 1.0 kg-m, 5.8 - 7.2 ft-lb)
Distance between end of clutch housing and torque converter	19.0 mm (0.748 in) or more
Drive plate runout limit	0.5 mm (0.020 in)

FRONT AXLE & FRONT SUSPENSION

SECTION **FA**


CONTENTS

PRECAUTIONS AND PREPARATION	FA- 2
FRONT AXLE AND FRONT SUSPENSION	FA- 3
ON-VEHICLE SERVICE	FA- 4
FRONT AXLE	FA- 9
FRONT AXLE — Wheel Hub and Knuckle	FA-10
FRONT AXLE — Drive Shaft	FA-14
FRONT SUSPENSION	FA-22
FRONT SUSPENSION — Coil Spring and Strut Assembly	FA-23
FRONT SUSPENSION — Stabilizer Bar	FA-24
FRONT SUSPENSION — Transverse Link and Transverse Link Gusset	FA-25
FRONT SUSPENSION — Lower Ball Joint	FA-26
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	FA-27



FA

PRECAUTIONS AND PREPARATION








Precautions

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- When removing each suspension part, check wheel alignment and adjust if necessary.
- Use Tool when removing or installing brake tubes.

Preparation


SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
HT72520000 (J25730-A) Ball joint remover	 Removing tie-rod outer end and lower ball joint
HT71780000 (—) Spring compressor	 Removing and installing coil spring
ST35652000 (—) Strut attachment	 Fixing strut assembly
GG94310000 (—) Flare nut torque wrench	 Removing and installing brake piping
KV38106700 (J34296) KV38106800 (J34297) Differential side oil seal protector	 Installing drive shaft L.H.: KV38106700 R.H.: KV38106800


FRONT AXLE AND FRONT SUSPENSION

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.




SFA791A



Front Axle and Front Suspension Parts

Check front axle and front suspension parts for looseness, cracks, wear or other damage.



- Shake each front wheel to check for excessive play.



- Make sure that cotter pin is inserted.
- Retighten all nuts and bolts to the specified torque.

Tightening torque:


Refer to FRONT SUSPENSION.



- Check strut (shock absorber) for oil leakage or other damage.

ON-VEHICLE SERVICE

Front Axle and Front Suspension Parts (Cont'd)




- Check spring height from the top of the wheelarch to the ground.
- (1) Vehicle must be unladen*, parked on a level surface, and tires checked for proper inflation and wear (tread wear indicator must not be showing).
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
 - (2) Bounce the vehicle up and down several times before measuring.

Standard height:


Front (Hf): 676 mm (26.61 in)

Rear (Hr): 645 mm (25.39 in)

- (3) Spring height is not adjustable. If out of specification, check for worn springs or suspension parts.



- Check suspension ball joint for grease leakage and ball joint dust cover for cracks or other damage.




- Check suspension ball joint end play.
- (1) Jack up front of vehicle and set the stands.
 - (2) Clamp dial indicator onto transverse link and place indicator tip on lower edge of brake caliper.
 - (3) Make sure front wheels are straight and brake pedal is depressed.
 - (4) Place a pry bar between transverse link and inner rim of road wheel.
 - (5) While raising and releasing pry bar, observe maximum dial indicator value.

Vertical end play:


0 mm (0 in)

- (6) If ball joint movement is beyond specifications, remove and recheck it.



Front Wheel Bearing

- Check that wheel bearings operate smoothly.
- Check axial end play.
Axial end play:
0.05 mm (0.0020 in) or less
- If axial end play is not within specification or wheel bearing does not turn smoothly, replace wheel bearing assembly. Refer to FRONT AXLE — Wheel Hub and Knuckle.



Front Wheel Alignment

Before checking front wheel alignment, be sure to make a preliminary inspection (Unladen*).

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.



PRELIMINARY INSPECTION

1. Check tires for wear and improper inflation.
2. Check wheel runout.
Wheel runout:
Refer to S.D.S.
3. Check front wheel bearings for looseness.
4. Check front suspension for looseness.
5. Check steering linkage for looseness.
6. Check that front shock absorbers work properly by using the standard bounce test.
7. Check vehicle posture (Unladen).

CAMBER, CASTER AND KINGPIN INCLINATION

Camber, caster and kingpin inclination are preset at factory and cannot be adjusted.

1. Measure camber, caster and kingpin inclination of both right and left wheels with a suitable alignment gauge.
Camber, Caster and Kingpin inclination:
Refer to S.D.S.
2. If camber, caster and kingpin inclination are not within specification, inspect and replace any damaged or worn front suspension parts.




TOE-IN

1. Draw a base line across the tread.
 - After lowering front of vehicle, move it up and down to eliminate friction, and set steering wheel in straight-ahead position.

ON-VEHICLE SERVICE


Front Wheel Alignment (Cont'd)



2. Measure toe-in.
- Measure distance "A" and "B" at the same height as hub center.

Toe-in :

Refer to S.D.S.



3. Adjust toe-in by varying the length of steering tie-rods.
- (1) Loosen lock nuts.
- (2) Adjust toe-in by screwing tie-rods in and out.


Standard length "L":

Refer to ST section.

- (3) Tighten lock nuts to specified torque.


Lock nut tightening torque:

Refer to ST section.



FRONT WHEEL TURNING ANGLE

1. Set wheels in straight-ahead position and then move vehicle forward until front wheels rest on turning radius gauge properly.




2. Rotate steering wheel all the way right and left; measure turning angle.

Wheel turning angle (Full turn):

Inside wheel: 34° - 38°

Outside wheel: 27° - 31°





ON-VEHICLE SERVICE

Front Wheel Alignment (Cont'd)

3. Adjust with stopper bolt if necessary.

Stopper bolt lock nut tightening torque:


54 - 72 N·m (5.5 - 7.3 kg-m, 40 - 53 ft-lb)



Drive Shaft


Check for grease leakage or other damage.

FRONT AXLE




SFA827A

FRONT AXLE — Wheel Hub and Knuckle




Removal

- Remove wheel bearing lock nut.




- Remove brake caliper assembly.

Brake hose need not be disconnected from brake caliper. Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.




- Separate tie-rod from knuckle with Tool.

Install stud nut conversely on stud bolt to prevent damage to stud bolt.




- Separate drive shaft from knuckle by lightly tapping it. If it is hard to remove, use a puller.

When removing drive shaft, cover boots with shop towel to prevent damage to them.




- Remove bolts and nuts as shown at left.

FRONT AXLE — Wheel Hub and Knuckle




Installation

- Install knuckle with wheel hub.
- Tighten wheel bearing lock nut.
□: 235 - 314 N·m
(24 - 32 kg-m, 174 - 231 ft-lb)



- Check wheel bearing axial end play.
Axial end play:
0.05 mm (0.0020 in) or less.




Disassembly

CAUTION:

When removing wheel hub or wheel bearing from knuckle, replace wheel bearing assembly (outer race, inner races and grease seals) with a new one.

WHEEL HUB


Drive out hub with inner race (outside) from knuckle with a suitable tool.



WHEEL BEARING

When replacing wheel bearing, replace wheel bearing assembly (inner races and outer race).

- Remove bearing inner race (outside), then remove outer grease seal.





- Remove inner grease seal from knuckle.

FRONT AXLE — Wheel Hub and Knuckle

Disassembly (Cont'd)

- Remove inner and outer snap rings.



- Press out bearing outer race.

Inspection

WHEEL HUB AND KNUCKLE

Check wheel hub and knuckle for cracks by using a magnetic exploration or dyeing test.

SNAP RING

Check snap ring for wear or cracks. Replace if necessary.

Assembly



1. Install inner snap ring into groove of knuckle.
2. Press new wheel bearing assembly into knuckle.

Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)

CAUTION:


- Do not press inner race of wheel bearing assembly.
 - Do not apply oil or grease to mating surfaces of wheel bearing outer race and knuckle.
3. Install outer snap ring into groove of knuckle.
 4. Pack grease seal lip with multi-purpose grease.




FRONT AXLE — Wheel Hub and Knuckle

Assembly (Cont'd)

5. Install outer grease seal.



6. Install inner grease seal.




7. Press wheel hub into knuckle.

Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)

Be careful not to damage grease seal.



8. Check bearing operation.

- (1) Add load P with press.



Load P:


34.3 - 49.0 kN

(3.5 - 5.0 ton, 3.9 - 5.5 US ton, 3.44 - 4.92 Imp ton)

- (2) Spin knuckle several turns in both directions.

- (3) Make sure that wheel bearings operate smoothly.






Removal


- Remove wheel bearing lock nut.
- Remove brake caliper assembly.

Brake hose need not be disconnected from brake caliper.
Be careful not to depress brake pedal, or piston will pop out.
Make sure brake hose is not twisted.




- Remove tie-rod ball joint.
 - Separate drive shaft from knuckle by slightly tapping it.
- When removing drive shaft, cover boots with shop towel to prevent damage to them.**

Refer to FRONT AXLE — Wheel Hub and Knuckle.





1. Remove right drive shaft from transaxle.



2. Remove left drive shaft from transaxle.
- FOR M/T MODELS —

FRONT AXLE — Drive Shaft

A/T model



SFA730


Removal (Cont'd)

— FOR A/T MODELS —

- Remove left drive shaft with a suitable tool.


Be careful not to damage pinion mate shaft and side gear.

R.H.



SFA482

L.H.



SFA483

Installation

TRANSAXLE SIDE

1. Drive a new oil seal to transaxle. Refer to section MT or AT.
2. Set Tool along the inner circumference of oil seal (transaxle side).

3. Insert drive shaft into transaxle. Be sure to properly align the serrations and then withdraw Tool.
4. Push drive shaft, then press-fit circular clip on the drive shaft into circular clip groove of side gear.
5. After its insertion, try to pull the flange out of the slide joint by hand. If it pulls out, the circular clip is not properly meshed with the side gear.

WHEEL SIDE



- Install drive shaft into knuckle.
- Tighten wheel bearing lock nut.

Components

Circular clip:

Make sure circular clip is properly meshed with side gear (transaxle side) and joint assembly (wheel side), and will not come out.


Be careful not to damage boots. Use suitable protector or cloth during removal and installation.



Disassembly

TRANSAXLE SIDE

1. Remove boot bands.
2. Put matchmarks on slide joint housing and inner race, before separating joint assembly.
3. Pry off snap ring "A" with a screwdriver, and pull out slide joint housing.



4. Put matchmarks on inner race and drive shaft.
5. Pry off snap ring "C", then remove ball cage, inner race and balls as a unit.
6. Pry off snap ring "B".
7. Draw out boot.

Cover drive shaft serrations with tape so as not to damage the boot.

FRONT AXLE — Drive Shaft

Disassembly (Cont'd)

WHEEL SIDE


CAUTION:

The joint on the wheel side cannot be disassembled.

- Before separating joint assembly, put matchmarks on drive shaft and joint assembly.
- Separate joint assembly with a suitable tool.



Be careful not to damage threads on drive shaft.

- Remove boot bands.




SUPPORT BEARING


- Remove dust shield.



- Pry off snap ring.




- Press support bearing assembly out of drive shaft.



FRONT AXLE — Drive Shaft

Disassembly (Cont'd)

- Press support bearing out of retainer.



Inspection

Thoroughly clean all parts in cleaning solvent, and dry with compressed air. Check parts for evidence of deformation or other damage.

DRIVE SHAFT

Replace drive shaft if it is twisted or cracked.

BOOT

Check boot for fatigue, cracks, or wear. Replace boot with new boot bands.

JOINT ASSEMBLY (Transaxle side)

- Replace any parts of double offset joint which show signs of scorching, rust, wear or excessive play.
- Check serration for deformation. Replace if necessary.
- Check slide joint housing for any damage. Replace if necessary.

JOINT ASSEMBLY (Wheel side)

Replace joint assembly if it is deformed or damaged.

SUPPORT BEARING

Make sure wheel bearing rolls freely and is free from noise, cracks, pitting or wear.

SUPPORT BEARING BRACKET

Check support bearing bracket for cracks with a magnetic exploration or dyeing test.

Assembly

- After drive shaft has been assembled, ensure that it moves smoothly over its entire range without binding.
- Use NISSAN GENUINE GREASE or equivalent after every overhaul.



FRONT AXLE — Drive Shaft

Assembly (Cont'd)


WHEEL SIDE

1. Install boot and new small boot band on drive shaft.

Cover drive shaft serration with tape so as not to damage boot during installation.




2. Set joint assembly onto drive shaft by lightly tapping it. Install joint assembly securely, ensuring marks which were made during disassembly are properly aligned.



3. Pack drive shaft with specified amount of grease.

Specified amount of grease:

205 - 225 g (7.23 - 7.94 oz)




4. Make sure that boot is properly installed on the drive shaft groove.

Set boot so that it does not swell and deform when its length is "L₁".

Length "L₁":



96 - 98 mm (3.78 - 3.86 in)



5. Lock new larger and smaller boot bands securely with a suitable tool.


FRONT AXLE — Drive Shaft

Assembly (Cont'd)




TRANSAXLE SIDE


1. Install boot and new small boot band on drive shaft.
Cover drive shaft serration with tape so as not to damage boot during installation.



2. Install new snap ring "B", then securely install ball cage, inner race and balls as a unit, making sure the marks which were made during disassembly are properly aligned.
3. Install new snap ring "C".



4. Pack drive shaft with specified amount of grease.
Specified amount of grease:
160 - 180 g (5.64 - 6.35 oz)
5. Install slide joint housing, then install new snap ring "A".
6. Make sure that boot is properly installed on the drive shaft groove.
Set boot so that it does not swell and deform when its length is " L_2 ".
Length " L_2 ":
97 - 99 mm (3.82 - 3.90 in)





7. Lock new larger and smaller boot bands securely with a suitable tool.

FRONT AXLE — Drive Shaft


Assembly (Cont'd)

SUPPORT BEARING


- Press bearing into retainer.



- Press drive shaft into bearing.




- Install snap ring.
- Install new dust shield.



FRONT SUSPENSION


When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.



SFA109B


FRONT SUSPENSION — Coil Spring and Strut Assembly



Removal and Installation

- Remove strut assembly fixing bolts and nuts (to hoodledge).


Do not remove piston rod lock nut on vehicle.




Disassembly

1. Set strut assembly on vise with Tool, then loosen piston rod lock nut.

Do not remove piston rod lock nut.



2. Compress spring with Tool so that the strut mounting insulator can be turned by hand.



3. Remove piston rod lock nut.

Inspection

STRUT ASSEMBLY


- Check for smooth operation through a full stroke, both compression and extension.
- Check for oil leakage occurring on welded or gland packing portion.
- Check piston rod for cracks, deformation or other damage.
- Replace if necessary.

STRUT MOUNTING INSULATOR

- Check cemented rubber-to-metal portion for separation or cracks.
- Check rubber parts for deterioration.


COIL SPRING

Check for cracks, deformation or other damage. Replace if necessary.




Assembly

- When installing coil spring on strut, it must be positioned as shown in the figure at left.




- Install upper spring seat with its cutout facing the outer side of vehicle.




Stabilizer Bar — Removal and Installation

- Remove stabilizer bar.




- When installing stabilizer, make sure that paint mark and clamp face in their correct directions.


FRONT SUSPENSION — Stabilizer Bar/Transverse Link and Transverse Link Gusset



- When removing and installing stabilizer bar, fix portion A.



- Install stabilizer bar with ball joint socket properly placed.



Transverse Link and Transverse Link Gusset — Removal and Installation

- Remove stabilizer bar.
- Remove fixing bolts.
- Install bolts in order of number.

Tightening torque:


Refer to FRONT SUSPENSION.

- During installation, final tightening must be carried out at curb weight with tires on the ground.
- After installation, check wheel alignment. Refer to ON-VEHICLE SERVICE.

Inspection


- Check transverse link for damage, cracks or deformation. Replace it if necessary.
- Check rubber bushing for damage, cracks and deformation. Replace transverse link if necessary.
- Check transverse link gusset for damage, cracks or deformation. Replace it if necessary.

FRONT SUSPENSION — Lower Ball Joint




Removal and Installation

1. Remove wheel bearing lock nut.
2. Remove tie-rod ball joint.
3. Loosen (do not remove) strut mounting nuts.




4. Remove nut securing lower ball joint to transverse link.
5. Separate drive shaft from knuckle by slightly tapping drive shaft end.

Cover boots with shop towel so as not to damage them when removing drive shaft.



6. Remove lower ball joint from knuckle with Tool.



Inspection

- Check ball joint for play. If ball stud is worn, play in axial direction is excessive or joint is hard to swing, replace lower ball joint.

Before checking, turn ball joint at least 10 revolutions so that ball joint is properly broken in.

Swinging force "A":

(measuring point: cotter pin hole of ball stud)

7.8 - 54.9 N (0.8 - 5.6 kg, 1.8 - 12.3 lb)


Turning torque "B":

0.49 - 3.43 N·m (5.0 - 35 kg-cm, 4.3 - 30.4 in-lb)

Vertical end play:

0 mm (0 in)

- Check dust cover for damage. Replace it and cover clamp if necessary.



SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

COIL SPRING

Applied model		M/T	A/T
Wire diameter	mm (in)	12.3 (0.484)	12.7 (0.500)
Coil diameter	mm (in)	130 (5.12)	
Free length	mm (in)	344 (13.54)	361 (14.21)
Spring constant	N/mm (kg/mm, lb/in)	23.5 (2.4, 134)	
Identification color		Red x 1, Blue x 2	Yellow x 1, Blue x 2

STRUT

Applied model		All
Piston rod diameter	mm (in)	22 (0.87)
Damping force [at 0.3 m (1.0 ft)/sec.]	N (kg, lb)	
Expansion		1,089 - 1,461 (111 - 149, 245 - 329)
Compression		471 - 706 (48 - 72, 106 - 159)

FRONT STABILIZER BAR

Applied model		All
Stabilizer diameter	mm (in)	26.5 (1.043)
Identification color		Blue

WHEELARCH HEIGHT (Unladen*)



SFA818A


Applied model		All
Front (Hf)	mm (in)	676 (26.61)
Rear (Hr)	mm (in)	645 (25.39)

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

DRIVE SHAFT


Applied model		All
Joint type		
Transaxle side		DS90
Wheel side		ZF100
Diameter	mm (in)	
Transaxle side D ₁		28 (1.10)
Wheel side D ₂		28 (1.10)
Grease		Nissan genuine grease or equivalent
Capacity	g (oz)	
Transaxle side		160 - 180 (5.64 - 6.35)
Wheel side		205 - 225 (7.23 - 7.94)

Wheel side



SFA562

Transaxle side



SFA563

Inspection and Adjustment

WHEEL ALIGNMENT (Unladen*1)

Applied model		All
Camber	degree	- 30' to 1° 00'
Caster	degree	35' - 2° 05'
Kingpin inclination	degree	13°45' - 15°15'
Toe-in		
A - B	mm (in)	1 - 3 (0.04 - 0.12)
Total angle 2θ	degree	6' - 18'
Front wheel turning angle		
Full turn*2	Inside	34° - 38°
	Outside	27° - 31°

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

WHEEL BEARING

Wheel bearing axial end play limit	mm (in)	0.05 (0.0020)
Wheel bearing lock nut tightening torque	N·m (kg-m, ft-lb)	235 - 314 (24 - 32, 174 - 231)

LOWER BALL JOINT

Swinging force (Measured at cotter pin hole)	N (kg, lb)	7.8 - 54.9 (0.8 - 5.6, 1.8 - 12.3)
Turning torque	N·m (kg-cm, in-lb)	0.49 - 3.43 (5.0 - 35, 4.3 - 30.4)
Vertical end play limit	mm (in)	0 (0)

WHEEL RUNOUT

Unit: mm (in)

Wheel type	Aluminum wheel	Steel wheel
Maximum radial runout limit	0.3 (0.012) or less	0.5 (0.020) or less
Maximum lateral runout limit	0.3 (0.012) or less	0.8 (0.031) or less

REAR AXLE & REAR SUSPENSION


SECTION **RA**

CONTENTS

PRECAUTIONS AND PREPARATION	RA- 2
REAR AXLE AND REAR SUSPENSION	RA- 3
ON-VEHICLE SERVICE	RA- 4
REAR AXLE — Wheel Hub	RA- 7
REAR SUSPENSION	RA- 9
REAR SUSPENSION — Coil Spring and Strut Assembly	RA-11
REAR SUSPENSION — Stabilizer Bar	RA-13
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	RA-14

RA

PRECAUTIONS AND PREPARATION








Precautions

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
- *: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Use Tool when removing or installing brake tubes.
- When removing each suspension part, check wheel alignment and adjust if necessary.
- Do not jack up at the parallel links.

Preparation


SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
ST35490000 (J26083) Gland packing wrench	 Removing and installing gland packing
KV401021S0 (-) Bearing race drift	 Installing wheel bearing outer race
HT71780000 (-) Spring compressor	 Removing and installing coil spring
ST35652000 (-) Strut attachment	 Fixing strut assembly
GG94310000 (-) Flare nut torque wrench	 Removing and installing brake piping


REAR AXLE AND REAR SUSPENSION

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.



SRA265A





Rear Axle and Rear Suspension Parts


Check axle and suspension parts for looseness, wear or damage.

- Shake each rear wheel to check for excessive play.

- Retighten all nuts and bolts to the specified torque.
Tightening torque: Refer to REAR SUSPENSION.



- Check strut (shock absorber) for oil leakage or other damage.
- Check wheelarch height. Refer to ON-VEHICLE SERVICE in section FA.




Rear Wheel Bearing

- Check axial end play.

Axial end play:

0.05 mm (0.0020 in) or less

- Check that wheel bearings operate smoothly.
- Check tightening torque of wheel bearing lock nut.
**[C]: 186 - 255 N·m
(19 - 26 kg-m, 137 - 188 ft-lb)**
- If there is any axial end play or wheel bearing does not turn smoothly, replace wheel bearing assembly. Refer to REAR AXLE — Wheel Hub.



Rear Wheel Alignment

PRELIMINARY INSPECTION

Make following checks. Adjust, repair or replace if necessary.

- Check tires for wear and for improper inflation.
- Check rear wheel bearings for looseness.
- Check wheel runout.

Wheel runout: Refer to S.D.S. in FA section.

- Check that rear strut (shock absorber) works properly.
- Check rear axle and rear suspension parts for looseness.
- Check vehicle posture (Unladen*).

*: Fuel, radiator and engine oil full. Spare tire, jack, hand tools and mats in designated positions.


CAMBER

Camber is preset at factory and cannot be adjusted.

Camber:


Refer to S.D.S.

- If the camber is not within specification, inspect and replace any damaged or worn rear suspension parts.



TOE-IN


1. Draw a base line across the tread.
- After lowering rear of vehicle, move it up and down to eliminate friction.



2. Measure toe-in.
- Measure distance "A" and "B" at the same height as hub center.


Toe-in:

Refer to S.D.S.



3. Adjust toe-in by varying the lengths of rear parallel links.

Rear Wheel Alignment (Cont'd)




- Adjust left and right rear parallel links to the same length "A".
- Tighten lock nut while holding rear parallel link with wrench to prevent bushing from twisting.

Standard length "A":

50 - 55 mm (1.97 - 2.17 in)

REAR AXLE — Wheel Hub




Removal

CAUTION:

Wheel hub bearing usually does not require maintenance. If any of the following symptoms are noted, replace wheel hub bearing assembly.


- Growling noise is emitted from wheel hub bearing during operation.
- Wheel hub bearing drags or turns roughly when hub is turned with your hand after bearing lock nut is tightened to specified torque.
- After wheel hub bearing is removed from knuckle spindle.



- 1) Remove brake caliper assembly.
- 2) Remove wheel bearing lock nut.


Brake hose does not need to be disconnected from brake caliper.

Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.



Installation

- Install wheel hub bearing.
- Tighten wheel bearing lock nut.
□: 186 - 255 N·m
(19 - 26 kg-m, 137 - 188 ft-lb)
- Check that wheel bearings operate smoothly.




- Check wheel bearing axial end play.
Axial end play:
0.05 mm (0.0020 in) or less

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.


CAUTION:

Do not jack up at the parallel links or radius rods.



: N·m (kg-m, ft-lb)

REAR SUSPENSION




Removal and Installation


CAUTION:

Do not jack up at the parallel links or radius rods.

- Disconnect brake hydraulic line and parking brake cable at equalizer.




- Remove suspension assembly.
 - 1) Remove parallel link fixing bolt, radius rod fixing bolt, stabilizer fixing bolt, stabilizer connecting rod brackets and parking brake cable fixing bolts.



- 2) Remove rear seat and parcel shelf. Refer to section BF.
- 3) Remove strut securing nuts (Upper side). Then pull out strut assembly.


REAR SUSPENSION — Coil Spring and Strut Assembly




Disassembly

1. Set strut assembly on vise with attachment, then loosen piston rod lock nut.


Do not remove piston rod lock nut.



2. Compress spring with Tool so that the strut mounting insulator can be turned by hand.



3. Remove piston rod lock nut.



4. Remove gland packing with Tool.

Avoid getting dirt and dust into gland packing portion.

5. Retract piston rod by pushing it down until it bottoms. Then, slowly withdraw piston rod from cylinder together with piston guide.

Inspection

STRUT ASSEMBLY

- Check for smooth operation through a full stroke, both compression and extension.
- Check for oil leakage occurring on welded or gland packing portions.
- Check piston rod for cracks, deformation or other damage. Replace if necessary.

REAR SUSPENSION — Coil Spring and Strut Assembly

Inspection (Cont'd)

UPPER RUBBER SEAT AND BUSHING


Check rubber parts for deterioration or cracks.
Replace if necessary.

STRUT MOUNTING INSULATOR

- Check cemented rubber-to-metal portion for melting or cracks.
- Check rubber parts for deterioration.


COIL SPRING

Check for cracks, deformation or other damage.
Replace if necessary.




Assembly

1. Locate upper spring seat as shown.





2. After placing coil spring in position on lower spring seat, release spring compressor gradually.



Removal and Installation

- Remove stabilizer bar.
- When installing stabilizer, refer to paint marks to mount it even.
- When installing connecting rod, make sure that parts are in their correct position.



SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

COIL SPRING

Applied model		All
Wire diameter	mm (in)	12 (0.47)
Coil diameter	mm (in)	130 (5.12)
Free length	mm (in)	299 (11.77)
Spring constant		
N/mm (kg/mm, lb/in)		21.6 (2.2, 123)
Identification color		Purple x 1, Pink x 1

STRUT

Applied model		All
Piston rod diameter	mm (in)	22 (0.87)
Damping force		
[at 0.3 m (1.0 ft)/sec.]		
N (kg, lb)		
Expansion		667 - 902 (68 - 92, 150 - 203)
Compression		226 - 363 (23 - 37, 51 - 82)

STABILIZER BAR

Applied model		All
Diameter	mm (in)	12 (0.47)

Inspection and Adjustment

WHEEL ALIGNMENT (Unladen*)

Applied model		All
Camber	degree	- 1°20' to 0°10'
Toe-in		
A - B	mm (in)	- 4 to 0 (- 0.16 to 0)
Total angle 2θ	degree	- 23' to 0'

WHEEL BEARING

Applied model		All
Wheel bearing axial end play		
mm (in)		0.05 (0.0020) or less
Wheel bearing lock nut tightening torque		
N·m (kg-m, ft-lb)		186 - 255 (19 - 26, 137 - 188)

- * Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated position.

BRAKE SYSTEM

SECTION **BR**

CONTENTS


PRECAUTIONS AND PREPARATION	BR- 2
CHECK AND ADJUSTMENT	BR- 3
BRAKE HYDRAULIC LINE	BR- 4
BRAKE PEDAL AND BRACKET	BR- 6
BRAKE BOOSTER	BR- 8
VACUUM PIPING	BR-10
MASTER CYLINDER	BR-11
FRONT DISC BRAKE	BR-12
REAR DRUM BRAKE	BR-15
REAR DISC BRAKE	BR-17
PARKING BRAKE CONTROL	BR-22
ANTI-LOCK BRAKING SYSTEM	BR-24
TROUBLE DIAGNOSES	BR-28
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	BR-50

BR

PRECAUTIONS AND PREPARATION

Precautions

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- To clean or wash all parts of master cylinder, disc brake caliper and wheel cylinder, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of the hydraulic system.







- Use Tool when removing and installing brake tube.

WARNING:


- Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.

Preparation

SPECIAL SERVICE TOOL

Tool number (Kent-Moore No.) Tool name	Description
GG94310000 (—) Flare nut torque wrench	 Removing and installing each brake piping
KV991V0010 (—) Brake fluid pressure gauge	 Measuring brake fluid pressure
KV999P1000 (—) ABS checker	 Checking ABS actuator operation
KV999P1010 (—) ABS checker adapter harness	

CHECK AND ADJUSTMENT




Checking Brake Fluid Level

- Check fluid level in reservoir tank. It should be between Max. and Min. lines on reservoir tank.
- If fluid level is extremely low, check brake system for leaks.

Checking Brake System

- Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts. If leakage occurs around joints, retighten or, if necessary, replace damaged parts.
- Check for oil leakage by fully depressing brake pedal.




Changing Brake Fluid

1. Drain brake fluid from each air bleeder valve.
 2. Refill until new brake fluid comes out of each air bleeder valve.
- Use same procedure as in bleeding hydraulic system to refill brake fluid.
Refer to Bleeding Procedure.
- **Refill with recommended brake fluid "DOT 3".**
 - **Never reuse drained brake fluid.**
 - **Be careful not to splash brake fluid on painted areas.**


BRAKE HYDRAULIC LINE

Without anti-lock braking system






SBR446A

With anti-lock braking system



SBR894A



Bleeding Procedure

CAUTION:

- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- Fill reservoir with recommended brake fluid. Make sure it is full at all times while bleeding air out of system.
- Place a container beneath master cylinder to avoid spillage of brake fluid.
- Bleed air according to the following order.
Left rear wheel cylinder (or caliper) → Right front caliper → Right rear wheel cylinder (or caliper) → Left front caliper
- To bleed air out of lines, wheel cylinders and calipers, use the following procedure.

WITHOUT ANTI-LOCK BRAKING SYSTEM

- 1) Connect a transparent vinyl tube to air bleeder valve.
- 2) Fully depress brake pedal several times.
- 3) With brake pedal depressed, open air bleeder valve to release air.
- 4) Close air bleeder valve.
- 5) Release brake pedal slowly.
- 6) Repeat steps 2) through 5) until clear brake fluid comes out of air bleeder valve.

WITH ANTI-LOCK BRAKING SYSTEM

- 1) Turn ignition switch to "OFF" position, and then disconnect ABS actuator connectors.
- 2) Connect a transparent vinyl tube to air bleeder valve.
- 3) Fully depress brake pedal several times.
- 4) With brake pedal depressed, open air bleeder valve to release air.
- 5) Close air bleeder valve.
- 6) Release brake pedal slowly.
- 7) Repeat steps 3) through 6) until clear brake fluid comes out of air bleeder valve.

Removal and Installation

1. To remove brake hose, first remove flare nut securing brake tube to hose, then withdraw lock spring.
2. Cover openings to prevent entrance of dirt whenever disconnecting hydraulic line.
3. All hoses must be free from excessive bending, twisting and pulling.
4. After installing brake lines, check for oil leakage by fully depressing brake pedal.


Inspection

Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

BRAKE PEDAL AND BRACKET

Removal and Installation




Inspection

Check brake pedal for the following items.

- Brake pedal bend
- Clevis pin deformation
- Crack of any welded portion

BRAKE PEDAL AND BRACKET



Pedal Adjustment

Check brake pedal free height from melt sheet. Adjust if necessary.

H: Free height

Refer to S.D.S.

D: Depressed height

Refer to S.D.S.

Under force of 490 N (50 kg, 110 lb) with engine running

C₁: Clearance between pedal stopper and threaded end of stop lamp switch


0.3 - 1.0 mm (0.012 - 0.039 in)

C₂: Clearance between pedal stopper and threaded end of A.S.C.D. cancel switch

0.3 - 1.0 mm (0.012 - 0.039 in)

A: Pedal free play

1 - 3 mm (0.04 - 0.12 in)



1. Adjust pedal free height with brake booster input rod. Then tighten lock nut.

Make sure that tip of input rod stays inside.

2. Adjust clearance "C₁" and "C₂" with stop lamp switch and A.S.C.D. cancel switch respectively. Then tighten lock nuts.
3. Check pedal free play.



Make sure that stop lamp is off when pedal is released.

4. Check brake pedal's depressed height while engine is running.

If depressed height is below specified value, check brake system for leaks, accumulation of air or any damage to components (master cylinder, wheel cylinder, etc.); then make necessary repairs.

BRAKE BOOSTER


Removal and Installation



Inspection


OPERATING CHECK

- Depress brake pedal several times with engine off, and check that there is no change in pedal stroke.
- Depress brake pedal, then start engine. If pedal goes down slightly, operation is normal.



AIRTIGHT CHECK

- Start engine, and stop it after one or two minutes. Depress brake pedal several times slowly. If pedal goes further down the first time and gradually rises after second or third time, booster is airtight.
- Depress brake pedal while engine is running, and stop engine with pedal depressed. If there is no change in pedal stroke after holding pedal down **30 seconds**, brake booster is airtight.



OUTPUT ROD LENGTH CHECK

1. Supply brake booster with vacuum of -66.7 kPa (-500 mmHg , -19.69 inHg) using a handy vacuum pump.
2. Check output rod length.


Specified length:

10.275 - 10.525 mm (0.4045 - 0.4144 in)


BRAKE BOOSTER

Inspection (Cont'd)

3. Adjust rod length if necessary.
4. If rod length is without specification, replace brake booster.



VACUUM PIPING




Removal and Installation

CAUTION:

Do not apply any oil or lubricants to vacuum hoses and check valve.


- Insert vacuum tube into vacuum hose more than 24 mm (0.94 in).
- Install check valve, paying attention to its direction.



Inspection

HOSES AND CONNECTORS

- Check vacuum lines, connections and check valve for airtightness, chafing and deterioration.





CHECK VALVE


- When pressure is applied to brake booster side of check valve and valve does not open, replace check valve with a new one.

MASTER CYLINDER

Removal and Installation




- Replace stopper cap if claw is damaged or deformed.
- Bend claws inward when installing stopper cap.



- Pay attention to direction of piston cups in figure at left.
- Check parts for wear or damage. Replace if necessary.

FRONT DISC BRAKE


CL25VA



SBR927A

Pad Replacement


1. Remove pin bolt.




2. Swing cylinder body upward. Then remove pad retainer, and inner and outer shims.

CAUTION:


- When cylinder body is swung up, do not depress brake pedal because piston will pop out.
- Be careful not to damage dust seal or get oil on rotor. Always replace shims when replacing pads or if shims are rusted or rubber coat is separated.






Removal and Installation

- Remove torque member fixing bolts and connecting bolt.




- Install brake hose to caliper at protrusions securely.



Disassembly

- Push out piston with dust seal using compressed air.



Inspection

DISC PAD

Check disc pad for wear or damage.

Pad standard thickness (A):

11.0 mm (0.433 in)

Pad wear limit (A):

2.0 mm (0.079 in)

CYLINDER BODY

- Check inside surface of cylinder for scoring, rust, wear, damage or foreign materials. Replace if any such condition exists.
- Eliminate minor damage from rust or foreign materials by polishing surface with fine emery paper.

CAUTION:

Use brake fluid to clean.

FRONT DISC BRAKE

Inspection (Cont'd)

PISTON


Check piston for scoring, rust, wear, damage or foreign materials. Replace if any condition exists.

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign materials are stuck to sliding surface.

PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks or other damage. Replace if any condition exists.



ROTOR RUNOUT


1. Secure rotor to wheel hub with at least two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to section FA.

Maximum runout:

0.07 mm (0.0028 in)

3. If the runout is out of specification, find minimum runout position as follows:
 - a. Remove nuts and rotor from wheel hub.
 - b. Shift the rotor one hole and secure rotor to wheel hub with nuts.
 - c. Measure runout.
 - d. Repeat steps a. to c. so that minimum runout position can be found.
4. If the runout is still out of specification, turn rotor with on-car brake lathe ("MAD, DL-8700", "AMMCO 700 and 705" or equivalent).



ROTOR THICKNESS


Thickness variation (At least 8 positions):

Maximum 0.01 mm (0.0004 in)

If thickness variation exceeds the specification, turn rotor with on-car brake lathe.

Rotor repair limit:

20.0 mm (0.787 in)





Assembly

- Insert piston seal into groove on cylinder body.
- With dust seal fitted to piston, install piston into cylinder body.

CAUTION:


- Secure dust seal properly.

REAR DRUM BRAKE



Brake Drum Removal

- Release parking brake control lever fully.
- Tighten two bolts gradually if brake drum is hard to remove.



Shoe Replacement

- Measure lining thickness.
Standard thickness:
4.5 mm (0.177 in)
Lining wear limit (A):
1.5 mm (0.059 in)


Before installing new shoes, rotate nut until adjuster rod is at its shortest point.

After installation, adjust shoe-to-drum clearance. Refer to Removal and Installation.

REAR DRUM BRAKE

Wheel Cylinder Inspection

- Check wheel cylinder for leakage.
- Check for wear, damage and loose conditions.
Replace if any such condition exists.




Removal and Installation

When installing, measure brake drum inside diameter and diameter of brake shoes. Check that difference between diameters is correct shoe clearance.

Shoe clearance:

0.35 - 0.55 mm (0.0138 - 0.0217 in)

If necessary, adjust by rotating adjuster.



Drum Inspection

Standard inner diameter:

228.6 mm (9 in)


Maximum inner diameter:

230.0 mm (9.06 in)

Out-of-roundness (Ellipticity):


0.03 mm (0.0012 in) or less

- Contact surface should be finefinished with No. 120 to 150 emery paper.
- Using a drum lathe, lathe brake drum if it shows scoring, partial wear or stepped wear.
- After brake drum has been completely reconditioned or replaced, check drum and shoes for proper contact pattern.



BR-17

REAR DISC BRAKE




Pad Replacement

1. Remove parking cable stay fixing bolt, pin bolt and lock spring. Then remove pad retainers, pads and shims.

CAUTION:

When cylinder body is swung up, do not depress brake pedal because piston will pop out.




2. When installing pads, retract piston into cylinder body by turning piston clockwise.

CAUTION:


Be careful not to damage piston boot or get oil on rotor.

Always replace shims when replacing pads.




Removal and Installation

Disconnect parking brake cable and brake hose, then remove caliper assembly.



Disassembly


1. Remove piston by turning it counterclockwise with suitable long nose pliers.



2. Pry off ring A from piston with suitable pliers and remove adjusting nut.


REAR DISC BRAKE

Disassembly (Cont'd)




3. Disassemble cylinder body.

- (1) Pry off ring B with suitable pliers, then remove spring cover, spring and seat.




- (2) Pry off ring C, then remove key plate, push rod and rod.



- (3) Remove piston seal.

Be careful not to damage cylinder body.



4. Remove return spring and lever.

Inspection

CAUTION:

Use brake fluid to clean cylinder. Never use mineral oil.

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign materials. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign materials may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

REAR DISC BRAKE

Inspection (Cont'd)

TORQUE MEMBER

Check for wear, cracks or other damage. Replace if necessary.

PISTON

Check piston for score, rust, wear, damage or presence of foreign materials.

Replace if any of the above conditions are observed.


CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign matter is stuck to sliding surface.

PIN AND PIN BOOT

Check for wear, cracks or other damage.

Replace if any of the above conditions are observed.



RUNOUT

Make sure that axial end play is within the specifications before measuring. Refer to section RA.


Then check runout with a dial indicator.

Rotor repair limit:

Maximum runout

(Total indicator reading at center of rotor pad contact surface)

0.07 mm (0.0028 in)



THICKNESS

Rotor repair limit:


Minimum thickness

9.0 mm (0.354 in)

Thickness variation (At least 8 portions)

Maximum 0.02 mm (0.0008 in)

Replace rotor if any of the above do not meet the specifications.




Assembly


1. Install cup in the specified direction.

REAR DISC BRAKE


Assembly (Cont'd)



2. Fit push rod into square hole in key plate. Also match convex portion of key plate with concave portion of cylinder.




3. Install ring C with a suitable tool.



4. Install seat, spring, spring cover and ring B with suitable press and drift.

PARKING BRAKE CONTROL

Removal and Installation



- Before removing parking brake control assembly, remove console box.
- Make sure there is no free play after installing.


Inspection

1. Check control lever for wear or other damage. Replace if necessary.
2. Check parking brake cables and lamp switch. Replace if necessary.
3. Check parts at each connecting portion for deformation or damage, and if found, replace.


PARKING BRAKE CONTROL

Adjustment

Adjust control lever stroke as follows:




1. Adjust control lever by turning adjusting nut.



2. Pull control lever with specified amount of force. Check lever stroke and ensure smooth operation.

Number of notches

Center lever type: 9 - 11




3. Bend parking brake warning lamp switch plate so that brake warning lamp comes on when ratchet at parking brake lever is pulled "A" notches and goes out when fully released.


Number of "A" notches: 1

ANTI-LOCK BRAKING SYSTEM

System Components




Hydraulic Circuit



ANTI-LOCK BRAKING SYSTEM

Wiring Diagram



J/C Joint connector
(Refer to last page
(Foldout page).)


ANTI-LOCK BRAKING SYSTEM

Removal and Installation

CAUTION:


Be careful not to damage sensor edge and sensor rotor teeth.

FRONT WHEEL SENSOR



- Remove sensor rotor with front wheel hub, referring to FA section.

REAR WHEEL SENSOR




ANTI-LOCK BRAKING SYSTEM

Removal and Installation (Cont'd)

ACTUATOR

- Disconnect 4 connectors and brake tubes.
- Remove 3 nuts fixing actuator to bracket.



TROUBLE DIAGNOSES


Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair	BR-29
Symptom Chart	BR-31
Preliminary Check 1	BR-32
Preliminary Check 2	BR-33
Preliminary Check 3, 4	BR-34
Self-diagnosis	BR-35
Component Parts and Harness Connector Location	BR-36
Ground Circuit Check	BR-37
Circuit Diagram for Quick Pinpoint Check	BR-38
Diagnostic Procedure 1	BR-39
Diagnostic Procedure 2	BR-40
Diagnostic Procedure 3	BR-41
Diagnostic Procedure 4	BR-41
Diagnostic Procedure 5	BR-42
Diagnostic Procedure 6	BR-42
Diagnostic Procedure 7	BR-43
Diagnostic Procedure 8	BR-44
Diagnostic Procedure 9	BR-45
Diagnostic Procedure 10	BR-46
Diagnostic Procedure 11	BR-47
Diagnostic Procedure 12	BR-47
Electrical Components Inspection	BR-48

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW



TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

KEY POINTS

WHAT Vehicle model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

DIAGNOSTIC WORKSHEET

There are many kinds of operating conditions that lead to customer complaints, even if the system is normal.

A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, feelings for a problem depend on each customer's information. It is therefore important to fully understand the symptoms or under what conditions a customer complains.

Make good use of a diagnostic worksheet such as the one shown below in order to utilize all the complaints for trouble-shooting.

Worksheet sample

Customer name MR/MS		Model & Year			VIN		
Engine #		Trans.			Mileage		
Incident Date		Manuf. Date			In Service Date		
Symptoms	☐ Pedal vibration and noise	☐ Warning activates	☐ Long stopping distance	☐ Abnormal pedal action	☐ ABS doesn't work	☐ ABS works but warning activates	☐ ABS works frequently
Engine conditions		☐ When starting ☐ After starting ☐ Engine speed: 5,000 rpm or more					
Road conditions		☐ Low friction road (☐ Snow ☐ Gravel ☐ Other) ☐ Protrusion					
Driving conditions		☐ High speed cornering ☐ Vehicle speed: Greater than 10 km/h (6 MPH) ☐ Vehicle speed: 10 km/h (6 MPH) or less ☐ Vehicle is stopped					
Applying brake conditions		☐ Suddenly ☐ Gradually					
Other conditions		☐ Operation of electrical equipment ☐ Large pedal stroke ☐ Operation of clutch					


TROUBLE DIAGNOSES

Symptom Chart

[illegible]

TROUBLE DIAGNOSES


Preliminary Check 1



Check brake fluid level in reservoir tank.

N.G. → Fill up brake fluid.

O.K. →




Check brake system.
Refer to CHECK AND ADJUSTMENT.

O.K. →


Repair or replace booster system. ← N.G.

O.K. →





Check brake pads and rotor.
Refer to "Inspection" of FRONT and REAR
DISC BRAKE.

N.G. → Replace malfunctioning parts.



Check brake booster operation and airtightness.
Refer to "Inspection" of BRAKE BOOSTER.

Preliminary Check 2




Check sensor clearance.

Clearance:

0.2 - 1.0 mm
(0.008 - 0.039 in)

O.K.



Check sensor rotor for teeth damage.

N.G.

Check sensor for the following items:

- Dust, foreign materials, etc., at fastening portion
- Improper installation
- Breakage

O.K.

N.G.

Repair or replace malfunctioning sensor.


N.G.

Replace sensor rotor with wheel hub or companion flange as a set.

TROUBLE DIAGNOSES

Preliminary Check 3

CHECK



Measure each sensor resistance.
0.8 - 1.2 kΩ


N.G. → Replace.

O.K. →

Preliminary Check 3, 4

Preliminary Check 4

CHECK




Check warning lamp activation.
When ignition switch is turned on, warning lamp turns on.

O.K. →

N.G. ↓

Check fuse.
Check bulb condition and remedy.


CHECK



Check warning lamp for deactivation.
When engine starts, warning lamp deactivates.


O.K. ↓

DRIVE



Drive vehicle at 30 km/h (19 MPH) for at least one minute.

CHECK




Ensure warning lamp remains off while driving.

N.G. →

O.K. →

If Preliminary Check 2 is not performed
and there is abnormal ABS operation,
perform Preliminary Check 2.



- Keep engine on and running.
- Count the number of L.E.D. flashes during 5 to 10 second "OFF" period.

Go to Self-diagnosis.
(See next page.)

TROUBLE DIAGNOSES

Self-diagnosis

CHECKING THE NUMBER OF L.E.D. FLASHES

When a problem occurs in the ABS, the warning light on the instrument panel comes on. As shown in the Table, the control unit performs self-diagnosis.

To obtain satisfactory self-diagnosing results, the vehicle must be driven above 30 km/h (19 MPH) for at least one minute before the self-diagnosis is performed. After the vehicle is stopped, the number of L.E.D. flashes is counted while the engine is running.


The L.E.D. is located on the control unit, identifying a malfunctioning part or unit by the number of flashes. Both the warning light and the L.E.D. persistently activate, even after a malfunctioning part or unit has been repaired, unless the ignition switch is turned "OFF". After repairs, turn the ignition switch "OFF". Then start the engine and drive the vehicle over 30 km/h (19 MPH) for at least one minute to ensure that the malfunctioning part or unit has been repaired properly.

If more than two circuits malfunction at the same time, the L.E.D. will flash to indicate one of the malfunctioning circuits. After the circuit has been repaired, the L.E.D. will then flash to indicate that the other circuit is malfunctioning.

No. of L.E.D. flashes	Malfunctioning part or unit
1	Left front actuator solenoid circuit
2	Right front actuator solenoid circuit
3	Right rear actuator solenoid circuit
4	Left rear actuator solenoid circuit
5	Left front wheel sensor circuit
6	Right front wheel sensor circuit
7	Right rear wheel sensor circuit
8	Left rear wheel sensor circuit
9	Motor and motor relay
10	Solenoid valve relay
16 or continuous	Control unit
Warning activates and L.E.D. "OFF"	Power supply or ground circuit for control unit

Example

Improper operation of left front rotor sensor circuit




SBR531A


Go to Diagnostic Procedures 7-12, where malfunction portion is concerned.

TROUBLE DIAGNOSES

Component Parts and Harness Connector Location



SBR907A




Ground Circuit Check

ACTUATOR MOTOR GROUND

- Check resistance between both terminals.
Resistance: 0Ω

Circuit Diagram for Quick Pinpoint Check





- The unit side connectors with a double circle "⊖" are connected to the harness side connectors shown in the "Component Parts and Harness Connector Location". (See page BR-36.)
- The terminal numbers in the connector coincide with the circuit numbers surrounded by a single circle "○".



Diagnostic Procedure 1



SYMPTOM: Pedal vibration and noise

Refer to worksheet result.



TROUBLE DIAGNOSES


Diagnostic Procedure 1 (Cont'd)




Diagnostic Procedure 2

SYMPTOM: Long stopping distance

Refer to worksheet results.







Diagnostic Procedure 3

SYMPTOM: Abnormal pedal action


Refer to worksheet results.



Diagnostic Procedure 4



SYMPTOM: ABS doesn't work.

Refer to worksheet results.






Diagnostic Procedure 5

SYMPTOM: ABS works but warning activates.





Diagnostic Procedure 6

SYMPTOM: ABS works frequently.



TROUBLE DIAGNOSES



Diagnostic Procedure 7

ACTUATOR SOLENOID (L.E.D. flashing number 1 - 4)

INSPECTION START
Remove battery negative terminal connector.

A

CHECK SOLENOID VALVE RESISTANCE.
Check resistance between control unit connector (vehicle side) terminals.

Flashing number 1:
Terminals ③② and ②

Flashing number 2:
Terminals ③② and ③⑤

Flashing number 3:
Terminals ③② and ①⑨ ←

Flashing number 4:
Terminals ③② and ①⑧ ←

Resistance: 0.7 - 1.6Ω

O.K. → Replace control unit.

B

Check resistance between actuator connector (actuator side) terminals.

Flashing number 1:
Terminals ①② and ①

Flashing number 2:
Terminals ①② and ③

Flashing number 3:
Terminals ①② and ⑦


Flashing number 4:
Terminals ①② and ⑤

Resistance: 0.7 - 1.6Ω

O.K. → Repair harness between actuator connector and control unit connector.

Replace actuator.

TROUBLE DIAGNOSES



Diagnostic Procedure 8

WHEEL SPEED SENSOR (L.E.D. flashing number 5 - 8)

INSPECTION START

Remove battery negative terminal connector.

A

CHECK SPEED SENSOR RESISTANCE.

Check resistance between control unit connector (vehicle side) terminals.

Flashing number 5 (Fr. L.H.):

Terminals ④ and ⑤

Flashing number 6 (Fr. R.H.):

Terminals ⑪ and ⑫

Flashing number 7 (Rr. R.H.):

Terminals ⑳ and ㉑

Flashing number 8 (Rr. L.H.):

Terminals ⑦ and ⑧

Resistance: 0.8 - 1.2k Ω

O.K.

Replace control unit.

N.G.

Refer to Preliminary Check 3 result.





Check whether sensor has 0.8 to 1.2 k Ω resistance.

N.G.

Replace sensor.

O.K.

Repair harness between sensor connector and control unit connector.



Diagnostic Procedure 9

ACTUATOR MOTOR RELAY (L.E.D. flashing number 9)

INSPECTION START

Remove battery negative terminal connector.

A CHECK MOTOR RELAY SOLENOID RESISTANCE.
Check resistance between control unit connector (vehicle side) terminals ①⑦ and ②⑧.
Resistance: 45 - 55Ω

O.K.

B CHECK MOTOR RELAY DEACTIVATION.
Check continuity between actuator connector (actuator side) terminals ①③ and ②⑨.

No

Check if motor fusible link is blown.

No

Perform Electrical Components Inspection — ACTUATOR.
(See page BR-48.)

O.K.

Replace control unit.

D Check resistance between actuator connector (actuator side) terminals ② and ①①.
Resistance: 45 - 55Ω

N.G.

O.K.

N.G.

Repair harness between actuator and control unit.

C Replace motor relay.

C Replace motor relay.





Yes

Yes

N.G.

Replace fusible link.

Replace actuator.



Diagnostic Procedure 10

ACTUATOR SOLENOID VALVE RELAY (L.E.D. flashing number 10)

INSPECTION START

Remove battery negative terminal connector.

A

CHECK SOLENOID VALVE RELAY RESISTANCE.
Check resistance between control unit connector (vehicle side) terminals ②⑦ and ①⑦.
Resistance: 80 - 90Ω

N.G.

Check resistance between actuator connector (actuator side) terminals ⑥ and ②.
Resistance: 80 - 90Ω

O.K.

N.G.

Repair harness between actuator and control unit.

C

Replace solenoid valve relay.

B

CHECK SOLENOID VALVE RELAY MOVEMENT.
Disconnect actuator connector. Check continuity between actuator connector (actuator side) terminals ④ and ⑫.

Yes

C

Replace solenoid valve relay.

No

D

Check if solenoid valve relay 30A fusible link is melted ("ANTI-SKID" written on cover).

Yes

Repair harness between terminal ④ and fusible link box. Then replace 30A fusible link.

No

Perform Electrical Components Inspection — ACTUATOR.
(See page BR-48.)

N.G.





Replace actuator.

O.K.

Replace control unit.


Diagnostic Procedure 11


CONTROL UNIT (L.E.D. flashing number 16 or continuous)



Diagnostic Procedure 12

CONTROL UNIT OR POWER SUPPLY AND GROUND CIRCUIT (Warning activates but L.E.D. comes off.)





Electrical Components Inspection

ACTUATOR (Not self-diagnostic item)

INSPECTION START

A
Connect ABS checker to actuator connector and vehicle harness with battery terminal connected and all checker switches turned off.
Use harness for 4 channel.
Set channel select switch to 4 channel.

B
Turn checker main switch on.
Check power supply indicator for coming on.

No → Replace battery with fully charged new one, if checker connection is correct.

B
Check checker valve relay indicator for coming on.

No → Replace solenoid valve relay, if checker connection is correct.

B step A
Select one valve — FL, FR, RL or RR. (valves corresponding to each wheel position.)
Select brake circuit pressure decreasing position by switch then turn motor switch on.
Select pressure increasing position.




B
Check motor relay indicator for coming on while motor switch is turned on.

No → Replace motor relay, if checker connection is correct.

Check motor for operational sound beside the actuator in a quiet place



No → Replace actuator as assembly, if Diagnostic Procedures 7 - 12 are already performed and checker connection is correct.

Yes → **B**



TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)



CAUTION:

Do not set checker at pressure decrease position for more than 5 seconds at a time. Actuator solenoid valve may be damaged.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

Item \ Model	Without ABS	With ABS
Front brake		
Brake model	CL25VA disc brake	
Cylinder bore diameter mm (in)	57.2 (2.252)	
Pad mm (in)	125.6 x 45.3 x 11.0 (4.94 x 1.783 x 0.433)	
Length x width x thick- ness	257 x 22 (10.12 x 0.87)	
Rotor outer diameter x thickness mm (in)		
Rear brake		
Brake model	LT23B drum brake	CL9H disc brake
Cylinder bore diameter mm (in)	20.64 (13/16)	33.96 (1.3370)
Lining or pad mm (in)	219.4 x 40.0 x 4.5 (8.64 x 1.575 x 0.177)	75 x 40.0 x 9 (2.95 x 1.575 x 0.35)
Length x width x thick- ness		
Drum inner diameter or rotor outer diameter x thickness mm (in)	228.6 (9)	258 x 10 (10.16 x 0.39)

Item \ Model	Without ABS	With ABS
Master cylinder		
Cylinder bore diameter mm (in)	23.81 (15/16)	25.40 (1)
Control valve		
Valve model	Dual proportioning valve (within master cylinder)	Dual proportioning valve
Split point kPa (kg/cm ² , psi) x reducing ratio	2,452 (25, 356) x 0.2	2,452 (25, 356) x 0.4
Brake booster		
Booster model	M195T	M215T
Diaphragm diameter mm (in)	Primary: 205 (8.07) Secondary: 180 (7.09)	Primary: 230 (9.06) Secondary: 205 (8.07)
Recommended brake fluid	DOT 3	

Inspection and Adjustment BRAKE PEDAL

DISC BRAKE

Brake model	CL25VA	CL9H
Pad wear limit mm (in)	2.0 (0.079)	
Minimum thickness		
Rotor repair limit mm (in)	20.0 (0.787)	9.0 (0.354)
Minimum thickness		
Maximum runout	0.07 (0.0028)	

Free height "H" mm (in)	M/T	159 - 169 (6.26 - 6.65)
A/T		169 - 179 (6.65 - 7.05)
Depressed height "D" mm (in)	[under force of 490 N (50 kg, 110 lb) with engine running]	90 (3.54)
Clearance between switches and pedal stopper bracket "C" mm (in)		0.3 - 1.0 (0.012 - 0.039)
Pedal free play "A" mm (in)		1 - 3 (0.04 - 0.12)

DRUM BRAKE

Brake model	LT23B
Lining wear limit mm (in)	1.5 (0.059)
Minimum thickness	
Drum repair limit mm (in)	230 (9.06)
Maximum inner diameter	
Out-of-roundness	0.03 (0.0012)
Radial runout	0.05 (0.0020)

PARKING BRAKE

Number of notches	9 - 11
[under force of 196 N (20 kg, 44 lb)]	
Number of notches when warning lamp switch comes on	1

STEERING SYSTEM

SECTION **ST**

CONTENTS

PRECAUTIONS AND PREPARATION	ST- 2
ON-VEHICLE SERVICE	ST- 4
STEERING WHEEL AND STEERING COLUMN	ST- 8
POWER STEERING GEAR AND LINKAGE	ST-12
POWER STEERING OIL PUMP	ST-24
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	ST-27

ST

PRECAUTIONS AND PREPARATION






Precautions

- Before disassembly, thoroughly clean the outside of the unit.
- Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- When disassembling parts, be sure to place them in order on a part rack so they can be reinstalled in their proper positions.
- Use nylon cloths or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
- Before inspection or reassembly, carefully clean all parts with a general purpose, non-flammable solvent.
- Before assembly, apply a coat of recommended A.T.F.* to hydraulic parts. Vaseline may be applied to O-rings and seals. Do not use any grease.
- Replace all gaskets, seals and O-rings. Avoid damaging O-rings, seals and gaskets during installation. Perform functional tests whenever designated.

*: Automatic transmission fluid



Preparation

SPECIAL SERVICE TOOLS




Tool number (Kent-Moore No.) Tool name	Description
KV48100700 (J26364) Torque adapter	 Measuring pinion rotating torque
KV48102500 (—) Pressure gauge adapter	 Measuring oil pressure
St27180001 (J25726-A) Steering wheel puller	 Removing and installing steering wheel
HT72520000 (J25730-A) Ball joint remover	 Removing ball joint
St27091000 (J26357) Pressure gauge	 Measuring oil pressure


PRECAUTIONS AND PREPARATION

Preparation (Cont'd) SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
KV48104400 (—) Rack seal ring reformer	Reforming teflon ring 
ST3127S000 (See J25765-A) ① GG91030000 (J25765-A) Torque wrench ② HT62940000 (—) Socket adapter ③ HT62900000 (—) Socket adapter	Measuring turning torque 

COMMERCIAL SERVICE TOOLS

Tool name	Description
Rear oil seal drift	Installing rear oil seal 
Pinion oil seal drift	Installing pinion oil seal 
Oil pump attachment	Disassembling and assembling oil pump  SST481A Unit: mm (in)




Checking Steering Wheel Play

1. With wheels in a straight-ahead position, check steering wheel play.

Steering wheel play:

35 mm (1.38 in) or less

2. If it is not within specification, check steering gear assembly when front suspension and axle, steering gear assembly and steering column are mounted correctly.



Checking Neutral Position on Steering Wheel

Pre-checking

- Make sure that wheel alignment is correct.


Wheel alignment:

Refer to section FA for S.D.S.

- Verify that the steering gear is centered before removing the steering wheel.

Checking

1. Check that the steering wheel is in the neutral position when driving straight ahead.
2. If it is not in the neutral position, remove the steering wheel and reinstall it correctly.
3. If the neutral position is between two serrated teeth, loosen tie-rod lock nut and move tie-rod in the opposite direction by the same amount on both left and right sides to compensate for error in the neutral position.



Front Wheel Turning Angle

1. Rotate steering wheel all the way right and left; measure turning angle.


Turning angle of full turns:

Refer to section FA for S.D.S.

2. If it is not within specification, check rack stroke.

Rack stroke "L":

Refer to S.D.S.



Checking Gear Housing Movement

1. Check the movement of steering gear housing during stationary steering on a dry paved surface.

- Apply a force of 49 N (5 kg, 11 lb) to steering wheel to check the gear housing movement.

Turn off ignition key while checking.


Movement of gear housing:

±2 mm (±0.08 in) or less

2. If movement exceeds the limit, replace mount insulator after confirming proper installation of gear housing clamps.

Checking and Adjusting Drive Belts

Refer to section MA for Drive Belt Inspection.




Checking Fluid Level

Check fluid level.

Fluid level should be checked using "HOT" range on dipstick at fluid temperatures of 50 to 80°C (122 to 176°F) or using "COLD" range on dipstick at fluid temperatures of 0 to 30°C (32 to 86°F).

CAUTION:

- Do not overfill.
- Recommended fluid is Automatic Transmission Fluid "DEXRON™" type.



Checking Fluid Leakage

Check the lines for improper attachment and for leaks, cracks, damage, loose connections, chafing or deterioration.

1. Run engine between idle speed and 1,000 rpm.

Make sure temperature of fluid in oil tank rises to 60 to 80°C (140 to 176°F).

2. Turn steering wheel right-to-left several times.
3. Hold steering wheel at each "lock" position for five seconds and carefully check for fluid leakage.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.

4. If fluid leakage at connectors is noticed, loosen flare nut and then retighten.

Do not overtighten connector as this can damage O-ring, washer and connector.

Bleeding Hydraulic System




1. Raise front end of vehicle until wheels are clear of the ground.
2. Add fluid into oil tank to specified level. Meanwhile quickly turn steering wheel fully to right and left and lightly touch steering stoppers.
Repeat steering wheel operation until fluid level no longer decreases.
3. Start engine.
Repeat step 2 above.

ON-VEHICLE SERVICE

Bleeding Hydraulic System (Cont'd)

- Incomplete air bleeding will cause the following to occur. When this happens, bleed air again.
 - a. Generation of air bubbles in reservoir tank
 - b. Generation of clicking noise in oil pump
 - c. Excessive buzzing in oil pump

While the vehicle is stationary or while moving the steering wheel slowly, fluid noise may occur in the valve or oil pump. This noise is inherent in this steering system, and it will not affect performance or durability of the system.



Checking Steering Wheel Turning Force

1. Park vehicle on a level, dry surface and set parking brake.
2. Start engine.
3. Bring power steering fluid up to adequate operating temperature. [Make sure temperature of fluid is approximately 60 to 80°C (140 to 176°F).]

Tires need to be inflated to normal pressure.

4. Check steering wheel turning force when steering wheel has been turned 360° from neutral position.

Steering wheel turning force:

39 N (4 kg, 9 lb) or less

5. If steering wheel turning force is out of specifications, check rack sliding force to detect condition of steering gear assembly.
 - a. Disconnect steering column lower joint and knuckle arms from the gear.
 - b. Start and run engine at idle to make sure steering fluid has reached normal operating temperature.
 - c. While pulling tie-rod slowly in the ± 11.5 mm (± 0.453 in) range from the neutral position, make sure rack sliding force is within specification.

Average rack sliding force:


284 N (29 kg, 64 lb)

- d. Check sliding force outside above range.

Maximum rack sliding force:

Not more than 39 N (4 kg, 9 lb) beyond above value

6. If rack sliding force is not within specification, overhaul steering gear assembly.



Checking Hydraulic System

Before starting, check belt tension, driving pulley and tire pressure.

1. Set Tool. Open shut-off valve. Then bleed air. (See "Bleeding Hydraulic System".)
2. Run engine.

Make sure temperature of fluid in tank rises to 60 to 80°C (140 to 176°F).

WARNING:

Warm up engine with shut-off valve fully opened. If engine is started with shut-off valve closed, oil pressure in oil pump will increase to relief pressure, resulting in an abnormal rise in oil temperature.

3. Check pressure with steering wheel fully turned to left and right positions with engine idling at 1,000 rpm.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.

Oil pump maximum standard pressure:

7,649 - 8,238 kPa (78 - 84 kg/cm², 1,109 - 1,194 psi)



4. If oil pressure is below the standard pressure, slowly close shut-off valve and check pressure.
 - When pressure reaches standard pressure, gear is damaged.
 - When pressure remains below standard pressure, pump is damaged.

CAUTION:

Do not close shut-off valve for more than 15 seconds.

5. If oil pressure is higher than standard pressure, check oil pump flow control valve.
6. After checking hydraulic system, remove Tool and add fluid as necessary, then completely bleed air out of system.


STEERING WHEEL AND STEERING COLUMN



Removal

STEERING WHEEL

1. Pull out horn pad.




- If it is hard to pull out horn pad, temporarily loosen fixing screw of horn pad retaining spring.

STEERING WHEEL AND STEERING COLUMN

Removal (Cont'd)


2. Remove steering wheel with Tool.



Installation

STEERING WHEEL

When installing steering wheel, apply multi-purpose grease to entire surface of turn signal cancel pin (both portions) and also to horn contact slip ring.




STEERING COLUMN

- When installing steering column, fingertighten all lower bracket and clamp retaining bolts; then tighten them securely. Do not apply undue stress to steering column.
- When attaching coupling joint, be sure tightening bolt faces cutout portion.


CAUTION:

After installing steering column, turn steering wheel to make sure it moves smoothly and that the number of turns from the straight forward position to left and right locks are equal. Be sure that the steering wheel is in a neutral position when driving straight ahead.




STEERING WHEEL AND STEERING COLUMN

Disassembly and Assembly







- When disassembling and assembling, unlock steering lock with key.
- Ensure that rounded surface of snap ring faces toward bearing when snap ring is installed.



- Install snap ring on upper shaft with a suitable tool.

STEERING WHEEL AND STEERING COLUMN

Disassembly and Assembly (Cont'd)



- Steering lock
 - a. Break self-shear type screws with a drill or other appropriate tool.
 - b. Install self-shear type screws and then cut off self-shear type screw heads.
- After installing steering column, check tilt mechanism operation.

Inspection



- When steering wheel can not be rotated smoothly, check the steering column for the following matters and replace damaged parts.
 - a. Check column bearings for damage or unevenness. Lubricate with recommended multi-purpose grease or replace steering column as an assembly, if necessary.
 - b. Check jacket tube for deformation or breakage. Replace if necessary.
- When the vehicle is involved in a light collision, check column length "L". If it is not within specifications, replace steering column as an assembly.

Column length "L":

581.2 - 582.8 mm (22.88 - 22.94 in)

POWER STEERING GEAR AND LINKAGE


Removal and Installation



- Detach tie-rod outer sockets from knuckle arms with Tool.

POWER STEERING GEAR AND LINKAGE

Removal and Installation (Cont'd)



- Install pipe connector.
- Observe specified tightening torque when tightening high-pressure and low-pressure pipe connectors. Excessive tightening can damage threads or damaged connector O-ring.
- The O-ring in low-pressure pipe connector is larger than that in high-pressure connector. Take care to install the proper O-ring.


Connector tightening torque:

Low-pressure side "1"

27 - 39 N·m (2.8 - 4.0 kg-m, 20 - 29 ft-lb)

High-pressure side "2"


15 - 25 N·m (1.5 - 2.5 kg-m, 11 - 18 ft-lb)




- Initially, tighten nut on tie-rod outer socket and knuckle arm to 29 to 39 N·m (3 to 4 kg-m, 22 to 29 ft-lb). Then tighten further to align nut groove with first pin hole so that cotter pin can be installed.

CAUTION:

Tightening torque must not exceed 49 N·m (5 kg-m, 36 ft-lb).




- Before removing lower joint from gear, set gear in neutral (wheels in straight-ahead position). After removing lower joint, put matching mark on pinion shaft and pinion housing to record neutral position of gear.
- To install, set left and right dust boots to equal deflection, and attach lower joint by aligning matching marks of pinion shaft and pinion housing.




- Tighten gear housing mounting bracket bolts in the order shown.

POWER STEERING GEAR AND LINKAGE



SST369B


POWER STEERING GEAR AND LINKAGE




Disassembly

1. Prior to disassembling, measure pinion rotating torque. Record the pinion rotating torque as a reference.
 - Before measuring, disconnect gear housing tube and drain fluid.
 - Use soft jaws when holding steering gear housing. Handle gear housing carefully, as it is made of aluminum. Do not grip cylinder in a vise.
2. Remove pinion gear.


Be careful not to damage pinion gear when removing pinion seal ring.



3. Remove tie-rod outer sockets and boots.
4. Loosen tie-rod inner socket by prying up staked portion, and remove socket.
5. Remove retainer.
6. Remove pinion assembly.




7. Drill staked portion of gear housing end with drill of 2 to 2.5 mm (0.079 to 0.098 in) diameter, until the staking is eliminated.



8. Remove end cover assembly with a suitable tool.
9. Draw out rack assembly.

POWER STEERING GEAR AND LINKAGE


Disassembly (Cont'd)



10. Remove rack seal ring.

- Using a heat gun, heat rack seal to approximately 40°C (104°F).
- Remove rack seal ring.

Be careful not to damage rack.



11. Remove center bushing and rack oil seal using tape wrapped socket and extension bar.

Do not scratch inner surfaces of pinion housing.

Inspection

Thoroughly clean all parts in cleaning solvent or automatic transmission fluid "Dexron™" type, and blow dry with compressed air, if available.

BOOT

Check condition of boot. If cracked excessively, replace it.

RACK

Thoroughly examine rack gear. If damaged, cracked or worn, replace it.

PINION ASSEMBLY

- Thoroughly examine pinion gear. If pinion gear is damaged, cracked or worn, replace it.
- Inspect bearings to see that they roll freely and are free from cracked, pitted, or worn balls, rollers and races. Replace if necessary.

GEAR HOUSING CYLINDER

Check gear housing cylinder bore for scratches or other damage. Replace if necessary.

POWER STEERING GEAR AND LINKAGE

Inspection (Cont'd)

TIE-ROD OUTER AND INNER SOCKET

- Check ball joint for swinging force.

Tie-rod outer ball joint:


6.9 - 63.7 N

(0.7 - 6.5 kg, 1.5 - 14.3 lb)

Tie-rod inner ball joint:

8.8 - 122.6 N

(0.9 - 12.5 kg, 2.0 - 27.6 lb)




- Check ball joint for rotating torque.

Tie-rod outer ball joint:

0.3 - 2.9 N·m

(3 - 30 kg-cm, 2.6 - 26.0 in-lb)



- Check ball joint for axial end play.


Tie-rod outer ball joint:

0.5 mm (0.020 in) or less

Tie-rod inner ball joint:


0 mm (0 in)

- Check condition of dust cover. If cracked excessively, replace it.




Assembly

1. Using a heat gun, heat new rack seal ring (made of Teflon) to approximately 40°C (104°F) and install it onto rack with your hand.




2. Using Tool, compress periphery of rack seal ring to position and secure it on rack.

Always insert Tool from the rack gear side.




POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)




3. Insert new rack oil seal.


- Place plastic film into rack oil seal to prevent damage by rack teeth.
- Do not forget to remove plastic film after rack oil seal is positioned properly.
- Make sure lips of rack oil seal face each other.




4. Install center bushing and rack oil seal with rack assembly.



5. Tighten end cover assembly with a suitable tool.



6. Fasten end cover assembly to gear housing by staking.




7. Set rack gear in neutral position.

Rack stroke "L":
Refer to S.D.S.


POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)




8. Coat seal lip of new pinion oil seal with multi-purpose grease and install it to pinion housing of gear housing with a suitable tool.


Make sure lip of oil seal faces up when installed.




9. Install pinion bearing adjusting shim(s).
- Whenever pinion assembly, gear housing and rear housing are disassembled, replace shim(s) with new ones. Always use the same number of shim(s) when replacing.



10. Install new pinion seal ring (made of Teflon) on pinion gear assembly.
- Using a heat gun, heat pinion seal ring to approximately 40°C (104°F) before installing it onto pinion gear assembly.
 - Make sure pinion seal ring is properly settled in valve groove.




11. Apply a coat of multi-purpose grease to needle bearing roller and oil seal lip before installing pinion assembly in gear housing.




12. Install pinion assembly to pinion housing.
- Be careful not to damage pinion oil seal.**

POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)




13. Apply a coat of multi-purpose grease to new rear oil seal lip before installing rear housing.




14. Install rear cover cap so that protrusion of rear housing cover is positioned as shown in figure at left.

Be careful not to damage worm ring and oil seal.




15. Install diaphragm spring into gear housing.
- Always install retainer, spring washer and diaphragm spring in that order.
 - Make sure convex end (painted white) of diaphragm spring faces outward when installing.
16. Install retainer spring and adjusting screw temporarily.



17. Install new lock plate.
- Attach lock plate ② to side rod inner socket ①.
 - Apply locking sealant to inner socket threads ③.
 - Screw inner socket into rack ④ and tighten to specified torque.
 - Clinch two places of lock plate at rack's groove.

CAUTION:

To prevent scratching the boot, remove burrs from lock plate.



18. Tighten outer socket lock nut.
- Tie-rod length "L":**
Refer to S.D.S.


POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)


19. Measure rack stroke.

Rack stroke "L":

Refer to S.D.S.




20. Before installing boot, coat the contact surfaces between boot and tie-rod with grease.




21. Install boot clamps.


- To install, wrap boot clamp around boot groove twice. Tighten clamp by twisting rings at both ends 4 to 4-1/2 turns with screwdriver while pulling with a force of approx. 98 N (10 kg, 22 lb).



- Install boot clamp so that it is to the rear of the vehicle when gear housing is attached to the body. (This will prevent interference with other parts.)





- Twist boot clamp in the direction shown in figure at left.



POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)




- After twisting boot clamp, bend twisted and diagonally so it does not contact boot.



Adjustment

Adjust pinion rotating torque as follows:

- Set rack to the neutral position without fluid in the gear.
- Coat the adjusting screw with locking sealant and screw it in.
- Lightly tighten lock nut.
- Tighten adjusting screw to a torque of 4.9 to 5.9 N·m (50 to 60 kg-cm, 43 to 52 in-lb).
- Loosen adjusting screw, then retighten it to 0.2 N·m (2 kg-cm, 1.7 in-lb).
- Move rack over its entire stroke several times.
- Measure pinion rotating torque within the range of 180° from neutral position.
Stop the gear at the point of maximum torque.
- Loosen adjusting screw, then retighten it to 4.9 N·m (50 kg-cm, 43 in-lb).
- Loosen adjusting screw by 40° to 60°.
- Prevent adjusting screw from turning, and tighten lock nut to specified torque.



- Measure pinion rotating torque.

Within $\pm 100^\circ$ from the neutral position:

Average rotating torque

0.8 - 1.3 N·m (8 - 13 kg-cm, 6.9 - 11.3 in-lb)

Maximum torque deviation

0.4 N·m (4 kg-cm, 3.5 in-lb)

Except for above measuring range:

Maximum rotating torque

1.9 N·m (19 kg-cm, 16 in-lb)



Maximum force deviation

0.6 N·m (6 kg-cm, 5.2 in-lb)

POWER STEERING GEAR AND LINKAGE

Adjustment (Cont'd)

- If pinion rotating torque is not within specifications, readjust it starting from procedure 4. If pinion rotating torque is still out of specifications after readjustment, replace steering gear assembly.



12. Check rack sliding force on vehicle as follows:
 - a. Install steering gear onto vehicle, but do not connect tie-rod to knuckle arm.
 - b. Connect all piping and fill with steering fluid.
 - c. Start engine and bleed air completely.
 - d. Disconnect steering column lower joint from the gear.
 - e. Keep engine at idle and make sure steering fluid has reached normal operating temperature.
 - f. While pulling tie-rod slowly in the ± 11.5 mm (± 0.453 in) range from the neutral position, make sure rack sliding force is within specification.

Average rack sliding force:

284 N (29 kg, 64 lb)

- g. Check sliding force outside above range.



Maximum rack sliding force:

Not more than 39 N (4 kg, 9 lb) beyond above value

- If rack sliding force is not within specification, readjust by repeating adjustment procedure from the beginning.
- If rack sliding force is still out of specification after readjustment, gear assembly needs to be replaced.

POWER STEERING OIL PUMP

Disassembly and Assembly



Pre-disassembly Inspection


Disassemble the power steering oil pump only if the following items are found.

- Oil leak from any point shown in the figure.
- Deformed or damaged pulley.
- Poor performance.


Disassembly

CAUTION:


- Parts which can be disassembled are strictly limited. Never disassemble parts other than those specified.
- Disassemble in as clean a place as possible.
- Clean your hands before disassembly.
- Do not use rags; use nylon cloths or paper towels.
- Follow the procedures and cautions in the Service Manual.
- When disassembling and reassembling, do not let foreign matter enter or contact the parts.



- Remove snap ring, then draw drive shaft out.
Be careful not to drop drive shaft.



- Remove oil seal.
Be careful not to damage front housing.




- Remove connector.
Be careful not to drop control valve.

Inspection

Inspect each component part for wear, deformation, scratches, and cracks. If damage is found, replace the part.


POWER STEERING OIL PUMP




Assembly

Assemble oil pump, noting the following instructions.


- Make sure O-rings and oil seal are properly installed.
- Always install new O-rings and oil seal.
- Be careful of oil seal direction.
- Cam ring, rotor and vanes must be replaced as a set if necessary.
- Coat each part with A.T.F. when assembling.



- Pay attention to the direction of rotor.



- When assembling vanes to rotor, rounded surfaces of vanes must face cam ring side.



- Insert pin ② into pin groove ① of front housing and front side plate. Then install cam ring ③ as shown at left.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

Applied model	All
Steering model	Power steering
Steering gear type	PR26SC
Steering overall gear ratio	17.3
Turns of steering wheel (Lock to lock)	3.01
Steering column type	Collapsible, tilt


Inspection and Adjustment

GENERAL

Steering wheel axial play mm (in)	0 (0)
Steering wheel play mm (in)	35 (1.38) or less
Movement of gear housing mm (in)	± 2 (± 0.08) or less

STEERING COLUMN

Steering column length "L" mm (in)	581.2 - 582.8 (22.88 - 22.94)
---------------------------------------	-------------------------------




SST125B

STEERING GEAR AND LINKAGE

Steering gear type	PR26SC
Side rod outer ball joint Swinging force at cotter pin hole N (kg, lb)	6.9 - 63.7 (0.7 - 6.5, 1.5 - 14.3)
Rotating torque N·m (kg·cm, in·lb)	0.3 - 2.9 (3 - 30, 2.6 - 26.0)
Axial end play mm (in)	0.5 (0.020) or less
Side rod inner ball joint Swinging force* N (kg, lb)	8.8 - 122.6 (0.9 - 12.5, 2.0 - 27.6)
Axial end play mm (in)	0 (0)
Side rod standard length "L" mm (in)	179 (7.05)

*: Measuring point




SST371B

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment (Cont'd)

STEERING GEAR AND LINKAGE (Cont'd)

Steering gear type	PR26SC
Rack stroke "L"	72 (2.83)
mm (in)	



SST086B

Pinion gear preload without gear oil	
N·m (kg-cm, in-lb)	
Within $\pm 100^\circ$ from the neutral position	
Average rotating torque	0.78 - 1.27 (8.0 - 13.0, 6.9 - 11.3)
Maximum torque deviation	0.4 (4, 3.5)
Except above range	
Maximum rotating torque	1.9 (19, 16)
Maximum torque deviation	0.6 (6, 5.2)

POWER STEERING

Rack sliding force	N (kg, lb)	
Under normal operating oil pressure		
Range within ± 11.5 mm (± 0.453 in) from the neutral position		284 (29, 64)
Maximum force deviation		39 (4, 9)
Except above range		Not more than 39 (4, 9) beyond above value
Retainer adjustment		
Adjusting screw		
Initial tightening torque		4.9 - 5.9 (50 - 60, 43 - 52)
N·m (kg-cm, in-lb)		
Retightening torque after loosening		0.2 (2, 1.7)
Tightening torque after gear has settled		4.9 (50, 43)
Returning angle	degree	$40^\circ - 60^\circ$
Steering wheel turning force		
(Measured at one full turn from the neutral position)		39 (4, 9) or less
N (kg, lb)		
Fluid capacity (Approximate)		
ℓ (US qt, Imp qt)		0.9 (1, 3/4)
Oil pump maximum pressure		
kPa (kg/cm ² , psi)		7,649 - 8,238 (78 - 84, 1,109 - 1,194)

SECTION BF**CONTENTS****GENERAL SERVICING**

(Including all clips & fasteners) BF- 2

BODY END BF- 5

DOOR

(Including "Power Door Lock" & "Power Window") BF- 8

INSTRUMENT PANEL BF-16

INTERIOR AND EXTERIOR

(In EXTERIOR, including "Weatherstrips") BF-18

SEAT BF-26

AUTOMATIC SEAT BELT SYSTEM BF-28

AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses BF-33

SUN ROOF BF-51

WINDSHIELD AND WINDOWS BF-56

MIRROR BF-59

REAR AIR SPOILER BF-60

BODY ALIGNMENT BF-61

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.


When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".



* For seat belt, refer to MA section.

Precautions

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installation. Be careful not to soil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.



Circuit Breaker Inspection




For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- Power window & power door lock
- Automatic seat belt
- Power sun roof














Clip and Fastener

- Clips and fasteners in BF section correspond to the following numbers and symbols.
- Replace any clips and/or fasteners which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
	 SBF256G	Removal: Remove by bending up with flat-bladed screwdrivers.  SBF367B
	 SBF114B SBF137B	 Removal: Pull up by rotating. SBF115B









GENERAL SERVICING

Clip and Fastener (Cont'd)

Symbol No.	Shapes	Removal & Installation
C103 	 SBF257G	Removal: Remove with a flat-bladed screwdriver or pliers.   SBF292C
C203 	 SBF258G	Push center pin to catching position. (Do not remove center pin by hitting it.)  Installation:  SBF 708E
CE103 	 SBF104B	Removal:  SBF147B
C106	 SBF653B	Removal: Type 1 ① Push ② Then bend up  SBF654B Type 2 Remove molding by cutting off the clip.  SBF914B
CE112	 SBF028C	Removal:  SBF029C

GENERAL SERVICING

Clip and Fastener (Cont'd)

Symbol No.	Shapes	Removal & Installation
CF118 	 Clip-A Clip-B (Grommet) Sealing washer SBF151D	Removal:  Flat-bladed screwdriver Finisher Body panel Clip-B (Grommet) Clip-A Sealing washers SBF259G
CG101 	 SBF145B	Removal  Rotate 45° to remove. Installation  Removal  SBF085B
CS101 	 SBF260G	Removal: Screw out with a Phillips screwdriver.  SBF140B
CR103 	 SBF768B	Removal: Holder portion of clip must be spread out to remove rod.  SBF770B

Body Front End


- Hood adjustment: Adjust at hinge portion.
- Hood lock adjustment: After adjusting, check hood lock control operation. Apply a coat of grease to hood locks engaging mechanism.
- Hood opener: Do not attempt to bend cable forcibly. Doing so increases effort required to unlock hood.

Hood lock adjustment

- Adjust hood so that hood primary lock meshes at position 1 to 1.5 mm (0.039 to 0.059 in) lower than fender.
- After hood lock adjustment, adjust bumper rubber.
- When securing hood lock, ensure it does not tilt. Striker must be positioned at the center of hood primary lock.
- After adjustment, ensure that hood primary and secondary lock operate properly.



Hood lock secondary latch hooking length

More than 5.0 mm (0.197 in)









Bumper rubber adjustment

- Adjust that hood is aligned with fender. At that time deflection is approx. 0.5 mm (0.020 in).
- [Bumper rubber free height is approx. 22.0 mm (0.866 in)]



Body Rear End and Opener

- Trunk lid adjustment: Adjust at hinge-trunk lid portion for proper trunk lid fit.
- Trunk lid lock system adjustment: Adjust striker so that it is in the center of the lock. After adjustment, check trunk lid lock operation.
- Opener cable: Do not attempt to bend cable using excessive force.
- After installation, make sure that trunk lid and fuel filler lid open smoothly.






BODY END

Body Rear End and Opener (Cont'd)

Trunk lid torsion bar removal & installation

WARNING:




When removing and installing torsion bar, be careful as it is under tension. **F**





SBF310G

DOOR

Front Door



Striker adjustment







: N·m (kg-m, ft-lb)


MBF496A

DOOR

Rear Door




Removal:




Turn bell crank-A counter-clockwise (as white arrow) to the position "X".

Installation:



Turn bell crank-A counter-clockwise to the position "Y".

Striker adjustment




MBF497A

DOOR




Power Door Lock

WIRING DIAGRAM



DOOR

Power Door Lock (Cont'd)




Power Door Lock

DOOR LOCK TIMER INSPECTION

Door lock timer

- Carry out the inspections below.
- (1) Power source and ground: Battery voltage should exist between terminals ③ and ①.
 - (2) Input signals: Continuity should exist between terminals ⑤, ⑥, and ⑧ and ground in "ON" condition, and should not exist in "OFF" condition.
 - (3) Output signals: Voltage shown in the chart should exist.



Connections		Operations					
		Main switch			Lock knob switch L H		
		N	Unlock	Lock	Lock → Unlock → Lock	Lock	Lock
3	Power source	12V	12V	12V	12V	12V	12V
1	Ground	Ground	Ground	Ground	Ground	Ground	Ground
5	Input signal	Main switch (Input signal for lock) (D6)	OFF	OFF	ON	OFF	OFF
6		Lock knob switch L H (D11)	—	—	—	OFF	ON
8		Main switch (Input signal for unlock) (D6)	OFF	ON	OFF	OFF	OFF
2	Output signal	Door lock actuator (Lock power source) VOLT METER 1		0V	0V	12V (Approx 1.0 sec) → 0V	12V (Approx 1.0 sec) → 0V
4		Door lock actuator (Unlock power source) VOLT METER 2		0V	12V (Approx 1.0 sec) → 0V	0V	12V (Approx 1.0 sec) → 0V


● Carry out the complete inspection in the chart from left to right

Power Window

POWER WINDOW AMP. INSPECTION

Carry out the inspections below.

- (1) Power source and ground: Battery voltage should exist between terminals 51 and 52.
- (2) Input signals: Battery voltage should exist between terminal 53 and ground (IGN "ON" or "ST").
Continuity should exist between terminal 54, 55 or 56 and ground in "ON" condition, and should not exist in "OFF" condition.
- (3) Output signals: Battery voltage shown in the chart should exist.



AMP OPERATION


	Connections	Operations					
		Manual operation			One-touch (Auto) operation		
		N	UP	Down	N	Down	N
51	Power source (IGN)	12V	12V	12V	12V	12V	12V
52	Ground	Ground	Ground	Ground	Ground	Ground	Ground
53	From ignition SW (ON or ST)	12V	12V	12V	12V	12V	12V
54	To FR driver's side power window SW (AUTO) (1)	OFF	OFF	OFF	OFF	ON	OFF
55	To FR driver's side power window SW (UP) (3)	OFF	ON	OFF	OFF	OFF	OFF
56	To FR driver's side power window SW (DOWN) (2)	OFF	OFF	ON	OFF	ON	OFF
57	FR driver's side regulator (Upward power source) VOLTMETER 1	Approx 0V	Approx over 9V	Approx 0V	Approx 0V	Approx 0V	Approx 0V
58	FR driver's side regulator (Downward power source) VOLTMETER 2	Approx 0V	Approx 0V	Approx over 9V	Approx 0V	Approx over 9V	Approx over 9V
Regulator Operating Condition		Stop	Upward operation	Downward operation	Stop	Starting	Keeping operation until fully open, then stops automatically
						Downward operation	

Carry out the operation check in this chart from left to right continuously

POWER WINDOW AMP — Driver's side door


Power Window

WIRING DIAGRAM



DOOR


Power Window (Cont'd)



SBF144F








INSTRUMENT PANEL

- When removing instrument panel assembly, remove defroster grille, combination meter, A/C or heater control, cluster lid C and S.M.J. first.



★ . Instrument panel assembly mounting bolts and nuts

INSTRUMENT PANEL







SBF088F

INTERIOR AND EXTERIOR

Interior


SIDE AND FLOOR TRIM — Passenger room








INTERIOR AND EXTERIOR

Interior (Cont'd)

Rear door




Front door



INTERIOR AND EXTERIOR

Interior (Cont'd)


LUGGAGE ROOM TRIM — Trunk space



INTERIOR AND EXTERIOR

Interior (Cont'd)

ROOF TRIM




SBF090F

INTERIOR AND EXTERIOR

Exterior

- Apply sealing compound where necessary while installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.



SBF091F


INTERIOR AND EXTERIOR

Exterior (Cont'd)


① Front bumper sight shield

Refer to "Body Front End".


② ③ Hood molding and hood front seal



④ ⑤ ⑥ Cowl top seal, cowl top grille and windshield lower molding




⑦ Sun roof frame weatherstrip and sun roof lid weatherstrip




⑧ Windshield upper molding

Method 1


Cut off top portion of molding and clean glass and panel surfaces.



Apply sealant to top portion of molding.




Cut off lower portion of new molding.



Finish well to give it a good appearance.

Method 2

1. Cut off sealant at glass end.
2. Clean the side on which panel was mounted.
3. Set molding fastener and apply sealant to body panel, and apply primer to molding and body.



4. Install molding by aligning the molding mark located on center with vehicle center. Be sure to install tightly so that there is no gap around the corner.

SBF161E


⑨ Drip molding

It is mounted with screws.

INTERIOR AND EXTERIOR

Exterior (Cont'd)

⑩ Body side welt




⑪ Side guard molding

- Side guard molding is affixed with double-faced adhesive tape.

- Removal:**

- Heat molding portion to 30 to 40°C (86 to 104°F) with a heat gun.



SBF455A


- Raise end of molding and, while cutting off bonding agent, detach molding.

- Installation:**

- Remove all traces of bonding agent from body panel. Then clean contact face of body.
- Heat body panel and molding to 30 to 40°C (86 to 104°F) with a heat gun. Then install molding.

SBF742C


⑫ Roof side molding



⑬ Rear bumper sight shield

Refer to "Body Rear End".


⑭ Door weatherstrip




INTERIOR AND EXTERIOR

Exterior (Cont'd)

15 Door outside molding



16 Door inside seal




17 Rear window upper molding

Basically the same as windshield upper molding.
Refer to ⑦ Windshield upper molding.


18 Rear window lower molding

It is mounted with screws.

19 Trunk lid weatherstrip




20 Rear combination lamp



SEAT

- When removing or installing the seat trim, carefully handle it to keep dirt out and avoid damage.

Front Seat




SBF094F

SEAT


Type 1

Rear Seat



SBF095F


Type 2




SBF104F

AUTOMATIC SEAT BELT SYSTEM

Unit Location






Control unit




: N•m (kg-m, ft-lb)

AUTOMATIC SEAT BELT SYSTEM

Unit Location (Cont'd)



Wiring Diagram



AUTOMATIC SEAT BELT SYSTEM

Description

FUNCTION

Shoulder belt buckle is mainly operated while ignition switch is "ON".

Condition (A): Ignition switch is "ON".

When door is opened, shoulder belt buckle is moved frontward and when door is closed, buckle is moved rearward.

Condition (B): Ignition switch is "OFF".

When door is opened, shoulder belt buckle is moved frontward. When the door is closed, buckle will remain in front position.

(Voltage of output signal is approximate value.)

Input signal	Ignition switch	OFF	OFF	ON	ON	ON	ON	ON	ON	OFF	OFF	OFF
	Door latch switch	OFF	ON	OFF	OFF	OFF	ON	ON	ON	OFF	ON	ON
	Front limit switch	OFF	OFF	OFF	ON	ON	ON	ON	OFF	ON	ON	ON
	Rear limit switch	ON	ON	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON
Output signal	Drive motor power source for frontward operation	0V	0V	0V	0V	0V	12V	12V	0V	0V	12V	12V
	Drive motor power source for rearward operation	0V	0V	12V	12V	0V	0V	0V	0V	0V	0V	0V
Shoulder belt buckle	Function	Stop	Stop	Start to move	Moving	Stop	Start to move	Moving	Stop	Stop	Start to move	Moving
	Position	Front	Front	Front	Between Front & Rear	Rear	Rear	Between Front & Rear	Front	Rear	Rear	Between Front & Rear

TIMER (Ignition switch either "ON" or "OFF")

If limit switch does not operate (when accomplishing frontward operation when door is opened, front limit switch can not be turned "OFF" or when accomplishing rearward operation, rear limit switch can not be turned "OFF"), control unit will continue to supply power to drive motor for 15 seconds.

QUICK WARNING (Ignition switch "ON")

If front limit switch is not turned "OFF" after accomplishing frontward operation (when door is opened), control unit will stop supplying power 15 seconds later and warning lamp will flash and chime will operate rapidly for approximately 6 seconds.

REAR LOCK (Fail safe operation)

If quick warning functions twice successively while ignition switch is "ON", shoulder belt buckle will move to rear position when the door is closed as normal but will remain in rear position even if door is opened. This operation is canceled when ignition switch is "OFF".

AUTOMATIC SEAT BELT SYSTEM

Description (Cont'd)

WARNING

Priority	Warning item	Ignition switch	Indication of warning (Indicating time is approximate value.)
1	Shoulder anchors are not at rear lock position. (All belts are fastened.) Condition: ● Door is opened. ● When closing door within 6 sec.	ON	Lamp ON OFF ON Chime ON OFF
		OFF → ON	Lamp ON OFF ON Chime ON OFF Anchor Not rear Rear
			Lamp ON OFF ON Chime ON OFF Anchor Not rear Rear
2	Either or both shoulder belts are not fastened. Condition: ● Doors are closed. ● When unfastening shoulder belt with doors closed.	ON	Lamp ON OFF ON Chime ON OFF Belts Not fastened Fastened
			Lamp ON OFF ON Chime ON OFF Belts Not fastened Fastened
3	Only driver side lap belt is not fastened. Condition: (● Doors are closed.)	OFF → ON	Lamp ON OFF ON Chime ON OFF Belts Not fastened Fastened
			Lamp ON OFF ON Chime ON OFF Belts Not fastened Fastened
4	Normal (All belts are fastened and shoulder anchors are in rear lock position.) Condition: (● Doors are closed.)	OFF → ON	Lamp ON OFF ON Chime ON OFF

Contents

RF Door Lock System

Symptom Chart	BF-34
Preliminary Check	BF-35
Main Power Supply and Ground Circuit Check	BF-38
Circuit Diagram for Quick Pinpoint Check	BF-39
Diagnostic Procedure 1	
(Check motor circuit and stop signals.)	BF-40
Diagnostic Procedure 2	
(Check door switch circuit.)	BF-43
Diagnostic Procedure 3	
(Check front limit switch circuit.)	BF-44
Diagnostic Procedure 4	
(Check rear limit switch circuit.)	BF-45
Diagnostic Procedure 5	
(Check shoulder belt switch circuit.)	BF-46
Diagnostic Procedure 6	
(Check lap belt switch circuit.)	BF-47
Diagnostic Procedure 7	
(Check warning chime circuit.)	BF-48
Diagnostic Procedure 8	
(Check warning lamp circuit.)	BF-49
Electrical Components Inspection	BF-49

Since left and right component parts are basically the same, harness layout and methods for electrical components inspection are shown for one side only.


For those methods enclosed by double rectangles, component parts on both sides must be checked.

Harness Layout

Refer to EL section.


AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Symptom Chart

Electrical Components Inspection	BF-50	R.H. side	Motor	☐	☐				
	BF-50		Shoulder belt buckle switch	☐				☐	
	BF-50		Door latch switch	☐		☐	☐		
	BF-50		Rear limit switch	☐	☐	☐		☐	
	BF-49		Front limit switch	☐	☐		☐		☐
	BF-50	L.H. side	Lap belt switch	☐				☐	
	BF-50		Motor	☐	☐				
	BF-50		Shoulder belt buckle switch	☐				☐	
	BF-50		Door latch switch	☐		☐	☐		
	BF-50		Rear limit switch	☐	☐	☐		☐	
	BF-49		Front limit switch	☐	☐		☐		☐
	—		Warning chime	☐				☐	
	—		Warning lamp	☐				☐	
Diagnostic Procedure	BF-49		Procedure 8					☐	
	BF-48		Procedure 7					☐	
	BF-47		Procedure 6					☐	
	BF-46		Procedure 5					☐	
	BF-45		Procedure 4	☐	☐	☐		☐	
	BF-44		Procedure 3	☐	☐		☐		☐
	BF-43		Procedure 2			☐	☐		
	BF-40		Procedure 1	☐	☐				
Main Power Supply and Ground Circuit Check	BF-38		Procedure 2		☐				
	BF-38		Procedure 1	☐					
Preliminary Check	BF-36		Procedure 2					☐	
	BF-35		Procedure 1		☐	☐	☐		
Procedure	Reference page 			SYMPTOM					
				No operation has made (No warning indicated and no buckles movement performed)					
				Shoulder belt buckle in L.H. or R.H. side does not move.					
				Shoulder belt buckle moves frontwards only. (not rearwards)					
				Shoulder belt buckle moves rearwards only. (not frontwards)					
				Warnings indicate incorrectly or do not function.					
				Quick warning operates.					


Preliminary Check

PROCEDURE 1




AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Preliminary Check (Cont'd)




PROCEDURE 2




AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Preliminary Check (Cont'd)



AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses




Main Power Supply and Ground Circuit Check

PROCEDURE 1


Main power supply

Terminals	Battery voltage existence condition	
	Ignition switch "ON"	Other than ignition switch "ON"
②1 - Ground	Yes	No
②2 - Ground	Yes	Yes
③9 - Ground	Yes	Yes
④4 - Ground	Yes	Yes



Ground circuit

Terminals	Continuity
②9 - Ground	Yes
③7 - Ground	Yes
④6 - Ground	Yes



PROCEDURE 2


Power supply for motor drive

	Terminals	Battery voltage existence
L.H. side	③9 - Ground	Yes
R.H. side	④4 - Ground	Yes




Ground circuit for motor drive

	Terminals	Continuity
L.H. side	③7 - Ground	Yes
R.H. side	④6 - Ground	Yes


Circuit Diagram for Quick Pinpoint Check



AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses







Diagnostic Procedure 1






AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Diagnostic Procedure 1 (Cont'd)






AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Diagnostic Procedure 1 (Cont'd)



Diagnostic Procedure 2



START

A CHECK DOOR SWITCH CIRCUIT.

- 1) Disconnect 16-pin connector from control unit.
- 2) Check continuity.

	Ter- min- als	Door condition	Con- tinuity
L.H. side	25 - Ground	Open	Yes
		Close	No
R.H. side	26 - Ground	Open	Yes
		Close	No

O.K.

Replace control unit.

Yes

Is this the second time?

No

Reinstall any part removed.

Go to PROCEDURE 1 (START) in Preliminary Check. (See page BF-35)

N.G.

B 1) Disconnect door latch switch connector.

- 2) Check continuity.

	Terminals
L.H. side	25 - (11) 12 - Ground (M40, M120)
R.H. side	26 - (11) 12 - Ground (M40, M120)

Continuity should exist.

N.G.

Repair harness.

O.K.

C Does continuity exist?

	Connector	Terminals
L.H. side	(D10)	(11) - Ground
R.H. side	(D37)	(11) - Ground

Yes

Repair harness. There will be incorrect grounding between terminals 25 and 11 and 26 and 11.

No

Go to DOOR LATCH SWITCH in Electrical Components Inspection. (See page BF-50.)

O.K.

Reinstall any part removed.

N.G.

Go to PROCEDURE 1 (START) in Preliminary Check. (See page BF-35.)

Check door latch switch harness for open and short circuit.





N.G.

Repair door latch switch harness.

O.K.




Replace door lock assembly.

Diagnostic Procedure 3



AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Diagnostic Procedure 4



CHECK REAR LIMIT SWITCH CIRCUIT.

- 1) Disconnect 16-pin connector from control unit.
- 2) Check continuity.

	Ter- minals	Shoulder belt buckle position	Con- tinuity
L.H. side	(36) - Ground	At rear	No
		Not at rear	Yes
R.H. side	(35) - Ground	At rear	No
		Not at rear	Yes

B Refer to figure **C** (BF-40) to move shoulder belt buckle.


C

1) Disconnect connector from rear switch assembly.

2) Check continuity.

	Terminals
L.H. side	(36) - (53) (56) - Ground (M40), (M120)
R.H. side	(35) - (53) (56) - Ground (M40), (M120)

Continuity should exist.



Replace control unit.

Yes

Is this second time?





No

Reinstall any part removed.

Go to PROCEDURE 1 (STEP 3) (See page BF-35.) or PROCEDURE 2 (STEP 3) (See page BF-36.) in Preliminary check.

Repair harness.

Diagnostic Procedure 5



START

A CHECK SHOULDER BELT BUCKLE SWITCH CIRCUIT.

- 1) Disconnect 16-pin connector from control unit.
- 2) Check continuity when shoulder belt buckle is at rear lock position.

	Ter- minals	Shoulder belt	Con- tinuity
L.H. side	(31) - Ground	Fasten	Yes
		Unfasten	No
R.H. side	(32) - Ground	Fasten	Yes
		Unfasten	No

B If shoulder belt buckle is not at rear lock position, check drive motor operation.

C N.G.

- 1) Disconnect connector from rear switch assembly.
- 2) Check continuity.

	Terminals
L.H. side	(31) - (55) (54) - Ground (M40, M120)
	(32) - (55) (54) - Ground (M40, M120)

Continuity should exist.

D O.K.

Does continuity exist?

	Connector	Terminals
L.H. side	(M115)	(55) - Ground
R.H. side	(M101)	(55) - Ground

No

Go to SHOULDER BELT BUCKLE SWITCH in Electrical Components Inspection.
(See page BF-50.)

N.G.

Check shoulder belt buckle switch harness for open or short circuit.

O.K.

Replace rear switch assembly.

Replace control unit.

Yes

Is this the second time?

No

Reinstall any part removed.

Go to PROCEDURE 2 (STEP 4) in Preliminary Check.
(See page BF-37.)

O.K.

A

N.G.

Repair harness.

Yes

Repair harness.




There will be incorrect grounding between terminals (31) and (55) or (32) and (55).

O.K.

(Go to A above.)

N.G.

Repair shoulder belt buckle switch harness.



Diagnostic Procedure 6

START

A CHECK LAP BELT BUCKLE SWITCH CIRCUIT (L.H. only).
1) Disconnect 16-pin connector from control unit.
2) Check continuity.

Terminals	Lap belt	Continuity
30 - Ground	Fasten	No
	Unfasten	Yes

N.G.

B 1) Disconnect lap belt switch connector.
2) Check continuity.

Terminals
30 - 71
72 - Ground (M40, M120)

Continuity should exist.

O.K.

C Does continuity exist?

Terminals
71 - Ground

No

Go to LAP BELT BUCKLE SWITCH in Electrical Components Inspection. (See page BF-50.)

N.G.

Check lap belt buckle switch harness for open and short circuit.

O.K.

Replace shoulder belt buckle assembly.

Replace control unit.

Yes

O.K.

A

Is this the second time?

No

Reinstall any part removed.

Go to PROCEDURE 2 (STEP 6) in Preliminary Check. (See page BF-37.)

N.G.

Repair harness.

Yes

Repair harness. There will be incorrect grounding.





O.K.

(Go to A above.)

N.G.

Repair lap belt buckle switch harness.

Diagnostic Procedure 7



START

A

CHECK WARNING CHIME CIRCUIT.

- 1) Disconnect 16-pin connector from control unit.
- 2) Check warning chime.

Terminals	Method	Result
33 - Ground	Ground intermittently.	Sound

O.K.

→ (Go to **A** below.)

N.G.

B

- 1) Disconnect connector(s) from combination meter.
- 2) Check continuity.

Terminals
33 - 86

Continuity should exist.

N.G.

Repair harness.

O.K.

C

Does continuity exist?

Terminals
86 - Ground

Yes

Repair harness.
There will be incorrect grounding.

No

D

Check battery voltage existence.

Terminals
84 - Ground

Battery voltage should exist.

N.G.

Repair harness.
For details, refer to
POWER SUPPLY ROUTING in EL section.

O.K.

Is this the first time?

Yes

Replace warning chime.

No

Is this the second time?

Yes






Replace control unit.

No

Reinstall any part removed.

Go to PROCEDURE 2 (START) in Preliminary Check.
(See page BF-36.)

Diagnostic Procedure 8



Electrical Components Inspection


FRONT LIMIT SWITCH

Condition	Continuity
Pushed	No
Released	Yes


AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Electrical Components Inspection (Cont'd)

REAR LIMIT SWITCH




Condition	Continuity
Pushed	No
Released	Yes



SHOULDER BELT BUCKLE SWITCH


Condition	Continuity
Move magnet toward buckle switch.	Yes
Move magnet away from buckle switch.	No



DOOR LATCH SWITCH


(Built-in door lock assembly)

Door condition	Continuity
Open	Yes
Closed	No



DRIVE MOTOR ASSEMBLY

Terminals		Drive belt operation
⊕	⊖	
52	51	Lengthen
51	52	Shorten




LAP BELT BUCKLE SWITCH

(L.H. side only)

Condition	Continuity
Fastened	No
Unfastened	Yes


SUN ROOF

- After any adjustment, check sun roof operation and lid alignment.
- Handle finisher plate and glass lid with care so not to damage it.
- It is desirable for easy installation to mark each point before removal.




Finisher plate removal **A**


Remove guide rail cover and pull up pawl by loosening retaining screw, then draw out finisher plate with sun roof lid open.




Removal: Raise pawl of retainer bracket, shift finisher plate and remove locate pins from retainer bracket. Then remove finisher plate.




Link & wire installation-① **C**




Link & wire installation-② **D**



Wind deflector installation **B**




Link & wire adjustment **E**



When installing motor & limit switch assembly, set motor & limit switch assembly to fully closed condition using the vehicle's harness and switch first. And adjust link & wire assembly's position as the roller line up at the marking. Then install the motor & limit switch assembly.



SUN ROOF

Wiring Diagram



SBF148F

Sun Roof Trouble-shooting



Does sun roof motor operating sound exist?

Yes

Disassemble sun roof motor assembly and link & wire assembly, then reassemble them.
For details, refer to "Sun roof replacement".

No

Does power window system operate?

No

- Check fusible link—Green.
- Check power window relay.

Refer to "Power window trouble-shooting procedure 1" of DOOR.

Yes

Remove sun roof switch.

A

Check sun roof switch for continuity.

N.G.

Replace sun roof switch.

Operation	Continuity
Close/tilt up	③ - ②
Open/tilt down	③ - ①

O.K.

Connect sun roof switch connector and disconnect sun roof motor connector.

B

Does battery voltage exist?

No

Disconnect close/up relay and open/down relay connectors.

A

Operation	Terminals	
	⊕	⊖
Close/tilt up	②②	②①
Open/tilt down	②①	②②






Yes

Replace sun roof motor assembly.

END

SUN ROOF

Sun Roof Trouble-shooting (Cont'd)




WINDSHIELD AND WINDOWS

Windshield and Rear Window

REMOVAL

After removing moldings, remove glass.




CAUTION:

Be careful not to scratch glass when removing.





INSTALLATION

- Use genuine Nissan Sealant kit or equivalent. Follow instructions furnished with it.
- After installation, the vehicle should remain stationary for about 24 hours.
- Do not use sealant which is more than 12 months past its production date.
- Do not leave cartridge unattended with its cap open.
- Keep primers and sealant in a cool, dry place. Ideally, they should be stored in a refrigerator.



WARNING:

Keep heat or open flames away as primers are flammable.



CAUTION:

Allow primers to dry for 10 to 15 minutes before proceeding to the next step.

CAUTION:

Do not apply primer A to windshield opening flanges.


WINDSHIELD AND WINDOWS

Windshield and Rear Window (Cont'd)




A

Install spacers with double-faced adhesive tape.

Windshield



Rear window




Unit: mm (in)

SBF117E


B

Apply sealant evenly.

Windshield



Rear window



Unit: mm (in)
SBF097F

CAUTION:

Windshield glass should be installed within 15 minutes of applying sealant: sealant starts to harden 15 minutes after it is applied.

Set glass in position and press glass lightly and evenly.

Check for water leakage.

Install moldings.

CAUTION:

Molding must be installed securely so that it is in position and leaves no gap.

WINDSHIELD AND WINDOWS

Drying Time for Sealant

Reference: Time required for sealant to dry to desired hardness.

Unit: days

Temperature °C (°F)	Relative humidity	Windshield			Rear window		
		90	50	25	90	50	25
40 (104)		1.5	2.5	5.0	2.0	2.5	5.5
25 (77)		2.5	4.0	7.5	2.5	4.5	8.0
5 (41)		5.0	13.0	20.5	5.5	14.0	22.0

CAUTION:


Advise the user of the fact that vehicle should not be driven on rough roads or surfaces until sealant has properly vulcanized.

Repairing Water Leaks for Windshield and Rear Window

Leaks can be repaired without removing and reinstalling glass.

If water is leaking between caulking material and body or between glass and caulking material, determine the extent of the leak by applying water while pushing glass outward.


To stop the leak, apply primer and then sealant to the leak point.




Afterwards, install molding securely.

MIRROR

Door Mirror



WIRING DIAGRAM




MIRROR

Door Mirror (Cont'd)


- When installing, make sure that there are not gaps or waves at ends of air spoiler.
- Before installing spoiler, clean and remove oil from surface where spoiler will be mounted.

REAR AIR SPOILER




BODY ALIGNMENT

- All dimensions indicated in figures are actual ones.
- When a tram tracking gauge is used, adjust both pointers to equal length and check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".




(LH) : L.H. side
(RH) : R.H. side



"X" : Vehicle center
"Y" : Center line of front axle
"Z" : Imaginary base line
[200 mm below datum line
("OZ" at design plan)]

Engine Compartment

MEASUREMENT



Unit: mm
SBF099F


BODY ALIGNMENT

Engine Compartment (Cont'd)


MEASUREMENT POINTS

Unit: mm


Cowl top center




Front side member L.H. side




Cowl top side




Front side member R.H. side




Strut tower




Front side member R.H. side



Radiator core support upper side



Radiator core support




SBF100F

BODY ALIGNMENT

Underbody


MEASUREMENT



BODY ALIGNMENT

Underbody (Cont'd)

MEASUREMENT POINTS



SBF102F

BODY ALIGNMENT


Underbody (Cont'd)

Unit: mm

Radiator core lower support, front side member, front side member extension, front suspension mounting lower member and dash lower cross-member

Coordinates:


(A), (a)
X: 330.0
Y: -655.0
Z: 208.0
(B), (b)
X: 517.0
Y: -560.0
Z: 340.0
(C), (c)
X: 353.0
Y: 106.2
Z: 142.7
(D), (d)
X: 342.5
Y: 139.5
Z: 145.6
(E), (e)
X: 402.0
Y: 378.9
Z: 157.2
(F), (f)
X: 414.5
Y: 700.0
Z: 110.0



Front side member rear extension, rear side member, rear suspension radius rod bracket and rear suspension mounting bolt top

Coordinates:


(G), (g)
X: 412.5
Y: 1,625.0
Z: 109.3
(H), (h)
X: 496.0
Y: 1,969.2
Z: 183.9
(I), (i)
X: 575.0
Y: 2,070.0
Z: 234.0
(J) LH
X: 456.0
Y: 2,525.0
Z: 300.0
(J) RH
X: 454.0
Y: 2,525.0
Z: 300.0
(K) LH
X: 468.0
Y: 2,555.0
Z: 328.0
(K) RH
X: 466.0
Y: 2,555.0
Z: 328.0
(L) LH
X: 493.0
Y: 2,864.0
Z: 328.0
(L) RH
X: 575.0
Y: 2,987.0
Z: 328.0
(M) LH
X: 570.0
Y: 3,080.0
Z: 330.0
(M) RH
X: 575.0
Y: 3,080.0
Z: 330.0
(N) LH
X: 570.0
Y: 3,330.0
Z: 330.0
(N) RH
X: 575.0
Y: 3,330.0
Z: 330.0
(O) LH
X: 570.0
Y: 3,330.0
Z: 330.0
(O) RH
X: 575.0
Y: 3,330.0
Z: 330.0



Front and rear strut tower centers

Coordinate:

(P), (p)
X: 529.0
Y: 13.5
Z: 756.1
(Q), (q)
X: 553.7
Y: 2,598.6
Z: 813.1



SBF103F

HEATER & AIR CONDITIONER

SECTION **HA**

CONTENTS

PRECAUTIONS	HA- 2
DESCRIPTION — Overall System	HA- 5
DESCRIPTION — Refrigeration System	HA- 8
PREPARATION	HA- 9
DISCHARGING, EVACUATING, CHARGING AND CHECKING	HA-16
SERVICE PROCEDURES	HA-27
COMPRESSOR OIL — Checking and Adjusting	HA-29
COMPRESSOR — Model NVR 140S (ATSUGI make)	HA-32
DIAGNOSES — Overall System	HA-34
TROUBLE DIAGNOSES	HA-43
SYSTEM DESCRIPTION — Push Control	HA-77
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	HA-82


When you read wiring diagrams:

- Read GI section, “HOW TO READ WIRING DIAGRAMS”.
- See EL section, “POWER SUPPLY ROUTING” for power distribution circuit.

When you perform trouble diagnoses, read GI section, “HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES”.




PRECAUTIONS



Precautions for the Handling of Refrigerant

- Do not release refrigerant into the air. Use your refrigerant recycling equipment to capture the refrigerant every time you need to discharge an air conditioning system.

The release of refrigerant into the air can cause damage to the Earth's ozone layer.




- Always wear eye protection when working around the system.
- Always be careful that refrigerant does not come in contact with your skin.
- Keep refrigerant containers stored below 40°C (104°F) and never drop from high places.
- Work in well-ventilated area because refrigerant gas evaporates quickly and breathing may become difficult due to the lack of oxygen.
- Keep refrigerant away from open flames because poisonous gas will be produced if it burns.
- Do not increase can temperature beyond 40°C (104°F) in charging.
- Do not heat refrigerant container with an open flame. There is a danger that container will explode.

CAUTION:

- Do not use steam to clean surface of condenser or evaporator. Be sure to use cold water or compressed air.
- Do not use compressed air to clean out a contaminated A/C tube or hose. Shake the line over a clean, white paper towel. If it contains obvious moisture or contaminants, replace it. Do not blow out the line with refrigerant.
- Do not use manifold gauge set whose press point shape is different from that shown. Otherwise, insufficient evacuating may occur.
- Do not over-tightening service valve cap.
- Follow the manufacturer's instructions for discharging into your refrigerant recycling equipment.


CAUTION:

- When installing an air conditioner in the vehicle, the pipes must be connected as the final stage of the operation. The seal caps of the pipes and other components must not be removed until their removal is required for connection.
- Before installing any air conditioner component that has been stored in a cool location to a vehicle that has been exposed to the hot sun, leave the component as it is for some time in a hot location with its seal cap unremoved. This step is necessary to prevent condensation of moisture inside the cold component.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply compressor oil to portions shown in illustration. Be careful not to apply oil to threaded portion.
- O-ring must be closely attached to inflated portion of tube.
- After inserting tube into union until O-ring is no longer visible, tighten nut to specified torque.
- After connecting line, conduct leak test and make sure that there is no leakage from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.



- Pay attention so as not to allow dirt and oil to attach on the **friction surfaces between clutch and pulley**. If the surface is contaminated with oil, wipe it off by **using a clean waste cloth moistened with thinner**.
- After completing the compressor service operation, **be sure to rotate the compressor shaft more than five turns in both directions by hand to equalize oil distribution inside the compressor**, then run the compressor for about one hour by idling the engine.
- When the compressor magnet clutch has been replaced, **be sure to check the magnet clutch for normal operation by applying voltage to the clutch**.

Control Operation



FAN SWITCH

This switch turns the fan ON and OFF, and controls fan speed.

MODE SWITCHES

These switches allow you to select the outlet air flow. When the MODE is set to "DEF" or "F/D", the push control unit sets the intake door to "FRE". In the DEF mode, the compressor turns on.

TEMPERATURE CONTROL LEVER

This lever allows you to adjust the temperature of the outlet air.

RECIRC SWITCH

OFF position:

Outside air is drawn into the passenger compartment when this switch is OFF.

ON position:

Interior air is recirculated inside the vehicle. RECIRC is canceled when DEF or F/D are selected, RECIRC resumes when another mode is chosen.

AIR CONDITIONER SWITCH


Start the engine, move the fan control lever to the desired (1 to 4) position and push the air conditioner switch to turn ON the air conditioner. The indicator light will come on when the air conditioner is ON. To stop the air conditioner, push the switch again to return it to the original position.

The air conditioner cooling function operates only when the engine is running.

FRESH VENT LEVER

In order to prevent unpleasant hot air on the face in the heater mode or especially in the FOOT, FOOT/DEF or DEF modes, this system allows cold air to flow from the ventilator ducts directly (without passing through the heater core) by means of a fresh vent lever beside the push control unit.

Component Layout




*: For removal, it is necessary to remove instrument assembly


RHA153B

DESCRIPTION — Overall System


Air Flow




Ventilation




Bi-level




Floor



Floor and defroster



Defroster



- ← Air passed through heater core
- ← : Mixed air (← + ←)
- ← : Air not passed through heater core

RHA150B

Refrigeration Cycle

REFRIGERANT FLOW

The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the receiver drier, through the evaporator, and back to the compressor.

The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.

FREEZE PROTECTION

When the A/C is switched on, the compressor runs continuously, and the evaporator pressure is controlled by a suction throttle valve (S.T.V.) to prevent freeze up.

REFRIGERANT SYSTEM PROTECTION

Dual-pressure switch


The refrigerant system is protected against excessively high or low pressures by the dual-pressure switch, located on the receiver drier. If the system pressure rises above, or falls below the specifications, the dual-pressure switch opens to interrupt the compressor operation.

Fusible plug

Open at temperature above 105°C (221°F), thereby discharging refrigerant to the atmosphere. If this plug is melted and opened, check the refrigerant line and replace receiver drier.



Pressure relief valve

The refrigerant system is also protected by a pressure relief valve, located on the end of high flexible hose near compressor. When the pressure of refrigerant in the system increases to an abnormal level [more than 3,727 kPa (38 kg/cm², 540 psi)], the release port on the pressure relief valve automatically opens and releases refrigerant into the atmosphere.










PREPARATION

Special Service Tools



Tool number (Kent-Moore No.) Tool name	Description
KV998VR001 (—) Clutch disc puller	 Removing clutch disc
KV99231010 (—) Clutch disc wrench	 Removing shaft nut and clutch disc
KV99235160 (J29751) Nut wrench	 Removing lock nut

PREPARATION

Service Tools

Tool name	Description
Manifold gauge	 SHA899C Discharging, evacuating and charging refrigerant
Manifold gauge	 SHA898C Discharging, evacuating and charging refrigerant
Charging hose	 SHA897C Discharging, evacuating and charging refrigerant
Adapter valve	 RHA573B Two pieces on each high pressure and low pressure line Discharging, evacuating and charging refrigerant
Thermometer and hygrometer	 SHA900C Etched-stem type thermometer Checking temperature and humidity
Vacuum pump	 RHA575B Evacuating
Gas leak detector	 RHA577B Checking refrigerant leaks

PREPARATION **Service Tools (Cont'd)**

Tool name	Description
Charging cylinder	 Checking amount of refrigerant and charging refrigerant RHA578B
Weight scale	 Checking amount of refrigerant RHA579B
Refrigerant recycling equipment	 Capturing and recycling refrigerant SHA732C

For details of such handling methods, refer to the Instruction Manual attached to each of the service tools.

PREPARATION

Service Tools (Cont'd)

HANDLING METHOD AND STRUCTURE


Manifold gauge

The manifold gauge is used to measure the operating pressure accurately in the high pressure and low pressure lines of the refrigerating system.

The high pressure gauge measures from -101.3 kPa (-760 mmHg , -29.92 inHg) to $2,942 \text{ kPa}$ (30 kg/cm^2 , 427 psi), and the low pressure gauge measures generally from -101.3 kPa (-760 mmHg , -29.92 inHg) to $1,471 \text{ kPa}$ (15 kg/cm^2 , 213 psi).

CAUTION:

- When installing the gauge to the refrigerating system, use utmost care not to mistake high pressure and low pressure line connections. (Wrong connections will lead to a damaged gauge.)
- Before evacuating, confirm that the gauge has a negative pressure scale. (If not, the gauge will be damaged.)




Charging hose

1. Completely tighten the high pressure valve, low pressure valve and vacuum pump valve cocks of the gauge manifold.
2. Connect the charging hoses to the high and low pressure lines.
3. Connect the charging hose fitted with a valve core to the charging cylinder.
4. Connect the vacuum pump hose to the vacuum pump.

The high and low pressure hoses are color coded to prevent wrong connection.

High pressure line hose	Red
Low pressure line hose	Yellow
Charging hose	Blue or green (with valve core)
Vacuum pump hose	Blue or green



CAUTION:

- Check each hose for cracks. If found, discard the hose.
- Do not use any hose if bulges are found.
- Check the rubber packing. If any deterioration or cracks are found, replace it with a new one.

PREPARATION

Service Tools (Cont'd)

Installing the adapter valve

Install the adapter valve to each of the high pressure and low pressure service valves so that air purging from the charging hose can be omitted. This also ensures that refrigerant leakage upon disconnection of the hose can be prevented.

1. Before connecting the adapter valve to the on-vehicle service valve, turn the adapter valve handle fully counterclockwise to retract the pin.




CAUTION:

Check the packing for any sign of deterioration or cracks. If any abnormality is found, replace it with a new one.

2. Connect the charging hose to the adapter valve.

Turning the handle clockwise will cause the on-vehicle service valve pin to be pushed open by the adapter valve pin, thus opening the refrigerant passage.


Turning the handle counterclockwise will close the passage. Before removing the adapter valve from the on-vehicle service valve, be sure to fully turn the handle counterclockwise to shut off the refrigerant passage.



Vacuum pump


The vacuum pump is used to purge air and moisture from the inside of the refrigeration system by evacuation, thereby ensuring proper functioning of the air conditioner system.

Check the vacuum pump to see that the vacuum pump capacity is greater than -100.0 kPa (-750 mmHg, -29.53 inHg).



Vacuum pump performance check procedure

1. Connect the vacuum gauge to the system.
2. Run the vacuum pump, and check to see that the needle pointers of the gauge manifold and vacuum gauge move smoothly, indicating a similar value.
3. After running the vacuum pump for two or three minutes, read the vacuum gauge. The measured value indicates the capacity of the vacuum pump.



Gas leak detector


The gas leak detector is used to check whether the refrigeration system is leaking. The features of this gas leak detector are listed on the next page.

PREPARATION

Service Tools (Cont'd)


Type	Detection ability	Features
Electrical	Discharge type (Suction type)	3 - 50 g (0.11 - 1.76 oz)/year
	Positive ion emission type (Suction type)	2 g (0.07 oz)/year
Other simple checking method: Change in vacuum when evacuating		1 kg (2 lb)/month; if 13.3 kPa (100 mmHg, 3.94 inHg) change in vacuum is detected in 10 minutes.
		● Easy handling ● Medium sensitivity ● Each point needs two or more seconds for detection. ● High sensitivity ● High price ● Warm-up time is needed because a heater is incorporated. ● Can be used easily in refrigerant charging operation. ● Detection ability is very low with vacuum gauge in gauge manifold.

- **Leakage inspection of a refrigeration system needs a sensitivity greater than 20 g (0.71 oz)/year.**
- **The actual amount of leak is estimated at 5 to 10 times the detected amount.**
- **Insufficient cooling may be felt if leakage exceeds 150 to 200 g (5.29 to 7.05 oz).**



Temperature gauge

Use to check the air conditioner performance. An etched stem type thermometer may be used. A hygrometer must also be used because the air conditioner performance depends on the humidity.



Scale

Measure the weight of the refrigerant to determine how much the refrigerant is charged.

PREPARATION

Service Tools (Cont'd)

Charging cylinder


The charging cylinder is used to correctly measure the amount of refrigerant to be charged.

Features


- With the charging cylinder, the operator can measure correctly the amount of refrigerant to be charged into the system.
- Change in the refrigerant volume due to a change in temperature and pressure can be supplemented, and this ensures correct charging of refrigerant.

CAUTION:

- **Never attempt to carry the charging cylinder containing refrigerant.**
- **Do not put the charging cylinder in a hot place. If the temperature and pressure of the refrigerant in the cylinder increase, the safety valve will be pushed open and the refrigerant will be released into the atmosphere.**
- **Do not expose the cylinder to the direct sunlight.**
- **Do not over-charge the refrigerant so that it exceeds the maximum limit of the cylinder.**
- **Do not charge the cylinder with more refrigerant than is needed.**




Work Procedure



DISCHARGING, EVACUATING, CHARGING AND CHECKING



Setting of Service Tools (Cont'd)



1. Install adapter valve to each of high pressure and low pressure service valves.

Before connecting adapter valve, turn adapter valve handle fully counterclockwise to retract pin.

2. Connect charging hoses to adapter valves and connect vacuum hose to vacuum pump.
3. Run vacuum pump and open additional valve and both valves on gauge manifold set.
4. After evacuating unwanted air in gauge set, close additional valve and stop vacuum pump.
5. Disconnect vacuum hose from vacuum pump and connect it to refrigerant recycling equipment.



Discharging

WARNING:

Discharge only into your recycling equipment.


Do not release refrigerant into the air.

Use only authorized refillable refrigerant tanks for your recycling equipment.

Use of other tanks could cause personal injury.

REFRIGERANT RECOVERY

1. Connect vacuum hose to refrigerant recycling equipment and open additional valve and adapter valves.
2. Open both valves of manifold gauge set. Make certain refrigerant tank "Gas" and "Liquid" valves are open.
3. Plug unit's power cord into a suitable AC outlet and turn on "Main Power" switch.
4. Turn on "Recovery" switch.
5. Depress "Start" switch. Compressor will start. Compressor will shut off automatically when recovery is complete. Watch for pressure rise to above 0 kPa (0 kg/cm², 0 psi) within two minutes. If this occurs, repeat this step.



DISCHARGING, EVACUATING, CHARGING AND CHECKING

Discharging (Cont'd)

6. To drain A/C system oil accumulator, open "Accumulator Pressurizing" valve for approximately 15 seconds to allow some compressor discharge pressure back into accumulator. Close "Accumulator Pressurizing" valve and open "Oil Drain" valve slowly and drain accumulator. Do not allow accumulator to completely depressurize. When oil stops draining, close "Oil Drain" valve. Be sure to replace oil in A/C system before servicing.
7. Turn off "Recovery" switch.
8. When recovery tank is full, trip switch at the bottom of weight platform will de-energize compressor and "Tank Full" light will come on. Recycle refrigerant in tank before removing.






REFRIGERANT RECYCLING

The recycling of reclaimed refrigerant is essential in order to assure that the refrigerant which meets the standards is re-used.

For maximum efficiency, full tanks of recovered refrigerant should be recycled. As required, tanks containing a minimum of 3.6 kg (8 lb) of refrigerant can be recycled.

For greatest efficiency, recycling full tanks of refrigerant is recommended.

1. Make certain both valves on recovery tank are open.
2. Turn on "Recycling" switch. Recycling solenoid will be energized.
3. Depress start switch. Compressor will start, and "Recycling On" light will come. Refrigerant will be seen going through moisture indicator at start up. The sightglass will not completely fill with refrigerant.
4. Allow the station to operate until moisture indicator turns green. If moisture indicator does not turn green after 40 minutes, remove and replace filter.
5. After recycling for approximately 5 minutes, check air purge indicator. If green pointer on air purge indicator leads red pointer by more than 10 psi (2 small divisions), bleed tank through air purge valve on the back of unit until both pointers are equal. Repeat as necessary.




Evacuation

EVACUATION PROCEDURE

1. Connect vacuum hose to vacuum pump.
2. Open high and low pressure valves of manifold gauge set and additional valve.
3. Run vacuum pump.

DISCHARGING, EVACUATING, CHARGING AND CHECKING

Evacuation (Cont'd)



4. Perform evacuation for more than five minutes to stabilize the vacuum inside the system. Check to ensure that the low pressure gauge indicates -98.6 to -101.3 kPa (-740 to -760 mmHg, -29.13 to -29.92 inHg).
5. Shut off the high and low pressure valves and additional valve.

CHECKING AIRTIGHTNESS


1. Shut off high and low pressure valves and additional valve, and leave the system as it is for 5 to 10 minutes.
2. Make sure that the needle of low pressure gauge will not move back toward the atmospheric pressure side (gauge pressure 0).

If any reverse movement is noted, it indicates poor system airtightness. Service the system until airtightness is complete. If pressure changes approx. 13.3 kPa (100 mmHg, 3.94 inHg) in 10 minutes, the refrigerant in the system will be exhausted in about one month.

EVACUATION

If no abnormality is found during airtightness check, perform evacuation again for more than 20 minutes.

1. Run vacuum pump.
2. Open high and low pressure valve and additional valve.
3. Evacuate for more than 20 minutes.
4. Close high and low pressure valves and additional valve.




Charging Refrigerant

SETTING OF CHARGING CYLINDER

1. Make sure that inlet and outlet valves of charging cylinder are closed.
2. Slowly open liquid line valve of refrigerant tank.
3. Slowly open inlet valve of charging cylinder.


The refrigerant will flow into the sight glass of charging cylinder as inlet valve is opened.



4. Slowly open upper vent valve to release pressure from charging cylinder. While doing so, continue charging until required amount of refrigerant is reached.


The refrigerant volume changes with temperature and pressure. It is necessary to charge refrigerant with a little more than required amount (indicated on sight glass).

5. Close inlet valve and upper vent valve of charging cylinder.



DISCHARGING, EVACUATING, CHARGING AND CHECKING


Charging Refrigerant (Cont'd)



6. Turn on heater switch (charging cylinder is provided with a heater.)

The refrigerant charging time can be reduced by heating refrigerant to increase its pressure. In this case, do not allow the pressure in cylinder to rise higher than 1,030 kPa (10.5 kg/cm², 150 psi). (If pressure rises above this level, turn off the heater.) The pressure in the charging cylinder can be measured by upper pressure gauge.

SETTING OF FLOW METER



1. Rotate charging cylinder main body until scale for R12 is at the correct position on sight glass.
2. Read charging cylinder pressure gauge.
3. Rotate charging cylinder so that scale of charging cylinder agrees with pressure value indicated on pressure gauge.

CALCULATING CHARGING AMOUNT OF REFRIGERANT

1. Record the amount of refrigerant in the sight glass before charging.
2. Subtract the required amount of refrigerant (charge quantity specified for the vehicle) from the amount of refrigerant recorded in step 1. Charge refrigerant into the system until the remaining value equals to the value indicated on the sight glass.

Example:


Level in sight glass: 3 lb 8 oz

Charge specification (from Service Manual) 2.0 - 2.4 lb.

Calculate charge quantity into lb and oz as follows: 1 lb = 16 oz, and 0.1 lb = 1.6 oz, so that 2.0 lb = 32 oz, 2.4 lb = 32 + (4 x 1.6) = 32 + 6.4 = 38.4, round off to 38. Therefore our charge quantity will be between 32 and 38 oz, or 2 lb 0 oz to 2 lb 6 oz.

Subtract 2 lb 6 oz from level in sight glass (3 lb 8 oz) = 1 lb 2 oz.




This will be our ending point.



DISCHARGING, EVACUATING, CHARGING AND CHECKING

Charging Refrigerant (Cont'd)

If a flow meter is not available, the amount of charged refrigerant also can be determined by subtracting the weight of the container measured after charging from its weight measured before charging.



PRELIMINARY CHARGING OF REFRIGERANT

1. Open outlet valve of charging cylinder.
2. Slowly open high pressure side valve of manifold gauge to charge refrigerant from the high pressure side.
3. Close high pressure valve after charging approx. 200 g (7.05 oz) refrigerant.

CAUTION:

The refrigerant in charging cylinder is kept in liquid state, so the refrigerant should be charged from high pressure side. Do not start engine with high pressure valve kept open.

PRELIMINARY CHECK FOR REFRIGERANT LEAKS

1. Make sure that the gauge manifold valve is closed.
2. Check for refrigerant leak from each connector in the system using the leak detector.

At this point, the pressure in the system is not high. Only large amounts of refrigerant leak due to loose pipe joints, etc. can be detected.

CHARGING REFRIGERANT

1. Slowly open high pressure valve of manifold gauge, and charge calculated amount of refrigerant in "CALCULATING CHARGING AMOUNT OF REFRIGERANT".

CAUTION:

The refrigerant in charging cylinder is kept in liquid state, so the refrigerant should be charged from high pressure side. Do not start engine with high pressure valve kept open.

2. Close high pressure valve of manifold gauge.
3. Make sure that the calculated amount of refrigerant remains in sight glass.
4. Close charging cylinder outlet valve.
5. Turn off heater if it is on (when using heater equipped type).

Inspection for Refrigerant Leaks


WORK PROCEDURE

To facilitate inspection for refrigerant leaks, establish the following conditions:

- Start engine.
- Run air conditioner.
- Set blower fan control to MAX.
- Set temperature control to FULL COLD.
- Run the refrigerant system for more than 5 minutes after setting the above-mentioned conditions (to circulate refrigerant through the system).


DISCHARGING, EVACUATING, CHARGING AND CHECKING

Inspection for Refrigerant Leaks (Cont'd)



Refrigerant leaks should be checked immediately after stopping engine, beginning with high pressure line, using a gas leak detector. This is because the pressure in high pressure line drops gradually after refrigerant circulation stops while the pressure in low pressure line rises gradually as shown in the graph at left. Leaks can be detected easily when pressure is high.

To prevent detecting errors, make sure that there is no refrigerant vapor or tobacco smoke in the vicinity of vehicle. It is also necessary to shield vehicle from wind so that leaking refrigerant is not blown away.



INSPECTION POINTS

Check carefully each of tube joints. To check, wipe the portion to be checked with waste cloth, and move tester probe all around the joint.

Compressor

Check shaft seals and bolt holes, and also around magnet clutch.

Receiver drier

Check pressure valve, safety valve and fusible plug mounts.

Service valve

Check all around service valves.

Ensure that valve core is not loose.

Service valve caps must be attached to valves (to prevent leak).

Also check that there are no foreign objects inside the cap.

Inside of cooling unit

To check, insert leak tester probe into drain hose immediately after stopping engine. (Keep probe inserted for more than 10 seconds.)


Confirmation of Amount of Charged Refrigerant

The amount of refrigerant charged into the system can be observed through the sight glass by watching the flow of the refrigerant and by reading the high pressure and low pressure manifold gauges under the following conditions:

CONDITIONS




- Doors:
Close completely.
- Window glasses:
Close completely.
- Intake door position:
RECIRC
- Mode door position:
VENT
- Blower fan:
HI
- TEMP control:
Optional (Set so that intake air temperature is 30 to 35°C (86 to 95°F).
- AIR CON switch:
ON
- Engine speed:
Approx. 1,500 rpm

WORK PROCEDURE




DISCHARGING, EVACUATING, CHARGING AND CHECKING

Confirmation of Amount of Charged Refrigerant (Cont'd)

Amount of charge Check Item	Appropriate	Refrigerant is insufficient	Almost no refrigerant	Overcharged, or air in system
Temperature of high and low pressure pipes	High pressure side is hot while low pressure side is cold.	High pressure side is warm and low pressure side is somewhat cold.	No difference is felt between high and low pressure sides.	High pressure side is very hot.
Flow of refrigerant viewed through sight glass	Mostly transparent. Occasionally some bubbles are seen when engine rpm is increased or decreased. 	Bubbles are always flowing. Refrigerant is cloudy. 	Nothing is visible. 	If overcharged, no bubbles are seen. If there is air in the system, large bubbles are seen.
Pressure	Normal high pressure: 1,373 - 1,765 kPa (14 - 18 kg/cm ² , 199 - 256 psi) Normal low pressure: 147 - 294 kPa (1.5 - 3 kg/cm ² , 21 - 43 psi)	Both high and low pressure values are insufficient.	High pressure value is very small.	Both high and low pressure values are excessive.
Action to take	Bubbles may be generated when the receiver drier strainer is clogged, or when the expansion valve is opened excessively.	Add refrigerant after checking for leaks.	Check the refrigerant system.	Stop the compressor and extract excessive refrigerant. If air is found, perform evacuation, then charge the specified amount of refrigerant.


CAUTION:

The condition of bubbles seen through the sight glass as well as the intake and discharge pressures are influenced by the ambient temperature, wind velocity, weather, and by the air temperature in front of the condenser, etc.





Removal of Service Tools



1. Completely loosen adapter valves of low pressure and high pressure lines.
2. Close additional valve and remove center hose from charging cylinder.
3. Connect center hose to refrigerant recycling equipment.
4. Open additional valve and both valves on gauge manifold.
5. Capture refrigerant in charging system.
6. After recovering refrigerant, remove adapter valves from on-car service valves.



Refrigerant Lines



Compressor Mounting



Thermo Control Amp.

REPLACEMENT

Remove screws, which secure thermistor locating stay, from front of cooling unit. Replace thermo control amp. assembly with a new one. (Cooling unit need not be removed during the replacement.)

Belt Tension

- Refer to MA section.

Fast Idle Control Device (F.I.C.D.)

- Refer to EF & EC section.

General

When replacing any refrigerant cycle component part of a compressor, condenser, receiver drier, cooling unit, etc., it is essential to drain the refrigerant in advance.


The refrigerant has a large affinity for the compressor oil, and a part of the oil is always circulating throughout the cycle together with the refrigerant. In other words, the oil is distributed throughout the cycle. Before draining the refrigerant, it is therefore necessary to collect as much compressor oil as possible by performing the oil return operation. If the compressor oil is not replenished, or added fully after replacing component parts of refrigerant cycle, the following trouble may occur:

- **Insufficient oil: Seized compressor**
- **Excessive oil: Poor cooling (Excess oil attached to parts obstructs normal heat exchange.)**

For this reason, whenever replacing any parts of the refrigerant cycle (except the compressor), it is necessary to replenish the compressor oil removed together with such parts. On the other hand, a new compressor contains a specified amount of compressor oil, and simple installation of the new compressor results in excessive oil quantity in the cycle. To prevent this, the oil must be extracted from the cycle so that the optimum oil quantity can be ensured inside the refrigerant cycle.

Checking and Adjusting

Adjust the oil quantity according to the flowchart shown below.



COMPRESSOR OIL — Checking and Adjusting

Checking and Adjusting (Cont'd)


A
↓

Remove compressor oil from the new compressor according to the following table so that the remaining amount of oil in the new compressor is equal to the amount of recollected oil in the removed compressor.

Unit: ml (US fl oz, Imp fl oz)

	Oil quantity contained in new compressor		Amount of collected oil	Amount of oil extracted from new compressor
Rotary type	DKV14C DKV14B	200 (6.8, 7.0)	70 (2.4, 2.5) or over	200 (6.8, 7.0) — [Amount collected + 20 (0.7, 0.7)]
			Below 70 (2.4, 2.5)	110 (3.7, 3.9)
	NVR140 NVR140S	200 (6.8, 7.0)	90 (3.0, 3.2) or over	200 (6.8, 7.0) — [Amount collected + 20 (0.7, 0.7)]
			Below 90 (3.0, 3.2)	90 (3.0, 3.2)
Swash plate type	DKS16H DKS16N	200 (6.8, 7.0)	130 (4.4, 4.6) or over	200 (6.8, 7.0) — [Amount collected + 20 (0.7, 0.7)]
			Below 130 (4.4, 4.6)	70 (2.4, 2.5)
	MJS170 MJS130	150 (5.1, 5.3)	—	80 (2.7, 2.8)

Precharged amount of oil for some models differs from figures listed above. Refer to S.D.S. of each model when servicing compressor oil.



Is it necessary to replace any parts other than compressor?

Yes

Add oil according to the oil management table for major equipment. Refer to oil management standard.

No

Perform performance test. Refer to **performance test**.

If the result of performance test is N.G., carry out oil return operation again, and check the oil quantity.

COMPRESSOR OIL — Checking and Adjusting

Oil Management Standard for Major Equipment

When any major unit of the air conditioner has been replaced, add the following amount of oil.

Major unit	Amount of oil to be added		Remarks
	ml (US fl oz, Imp fl oz)	Percent (%) ^{*1}	
Cooling unit, evaporator	45 - 75 (1.5 - 2.5, 1.6 - 2.6)	30	Add compressor oil little by little from the low pressure side of the system cycle.
Condenser	30 - 50 (1.0 - 1.7, 1.1 - 1.8)	20	
Receiver drier	15 - 25 (0.5 - 0.8, 0.5 - 0.9)	10	
In case of refrigerant leak	30 - 50 (1.0 - 1.7, 1.1 - 1.8)	—	Add if large of oil leak is indicated. ^{*2}
	—	—	Addition of oil is not required if no oil leak is indicated.

^{*1}: The percentage of the total amount of system oil

^{*2}: Sudden leakage of refrigerant due to fusion of a fusible plug, opening of a relief valve, or damage of a component may accompany oil leak.



Compressor Oil

The recommended brand of compressor oil for a car air conditioner system is shown below. For the oil quantity, refer to the section “**Checking and Adjusting**”.

SUNISO 5GS or equivalent

COMPRESSOR OIL — Checking and Adjusting


Compressor Oil (Cont'd)



Compressor Clutch

REPLACEMENT

- When removing center bolt, hold clutch disc with clutch disc wrench.
- Using clutch disc puller, clutch disc can be removed.



- Bend down pawl of lock washer.
- When removing pulley, remove lock nut with nut wrench.

Compressor Clutch (Cont'd)

INSPECTION

Clutch disc


If the contact surface shows signs of damage due to excessive heat, the drive plate and pulley should be replaced.

Pulley

Check the appearance of the pulley assembly. If the contact surface of the pulley shows signs of excessive grooving due to slippage, both the pulley and drive plate should be replaced. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil

Check coil for loose connection or cracked insulation.




ADJUSTMENT

- When assembling clutch disc, adjust disc-to-pulley clearance with shims.

BREAK-IN OPERATION


When replacing compressor clutch assembly, do not forget break-in operation, accomplished by engaging and disengaging the clutch about thirty times.

Break-in operation raises the level of transmitted torque.




Thermal Protector

- When servicing, do not allow foreign matter to get into compressor.
- Check continuity between two terminals.



How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW



Operational Check

The purpose of the operational check is to confirm that the system operates as it should. The systems which are checked are the blower, mode (discharge air), intake air, temperature decrease, temperature increase.

CONDITIONS:


Engine running at normal operating temperature.

Fresh vent "OFF"

PROCEDURE:


1. Check blower

- 1) Turn Fan switch to 1-speed.
Blower should operate on 1-speed.
- 2) Then turn Fan switch to 2-speed.
- 3) Continue checking blower speed until all four speeds are checked.
- 4) Leave blower on 4-speed.




2. Check discharge air

- 1) Press the VENT button.
VENT indicator should light.
- 2) Confirm that all discharge air comes out of face vents.
- 3) Press the B/L button.
B/L indicator should light.
- 4) Confirm that discharge air comes out of face vents and foot vents.
- 5) Press the FOOT button.
FOOT indicator should light.
- 6) Confirm that discharge air comes out of foot vents, with some air from defroster vents.
- 7) Press the F/D button.
F/D indicator should light.
- 8) Confirm that discharge air comes out of foot vents, with some air from defroster vents, and that intake door position is at FRE.
- 9) Press the DEF button.
DEF indicator should light.
- 10) The discharge air should be coming only from defroster vents. At the same time compressor should turn ON and intake door position be at FRE.



3. Check recirc

- 1) Press RECIRC button.
RECIRC indicator should light.
- 2) Listen for intake door position change (you should hear blower sound change slightly).




DIAGNOSES — Overall System

Operational Check (Cont'd)


4. Check temperature decrease

- 1) Slide temperature control lever to **full cold**.
- 2) Check for cold air at discharge air outlets.



5. Check temperature increase


- 1) Slide temperature control lever to **full hot**.
- 2) Check for hot air at discharge air outlets.



6. Check air conditioner switch


Move the fan switch to the desired (1 to 4-speed) position and push the air conditioner button to turn ON the air conditioner.

The indicator light should come on when air conditioner is ON.



7. Check fresh vent lever

- 1) Press FOOT, FOOT/DEF or DEF.
- 2) Move fresh vent lever in direction of arrow.
- 3) Confirm that discharge air comes out of foot & def vents with a cold air from face vents.



Performance Chart

TEST CONDITION

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well ventilated place)

Doors: Closed

Door window: Open

Hood: Open

TEMP. lever position: Max. COLD

OUTLET air:  (Ventilation)

INTAKE air:  (Recirculation)

FAN speed: Max.

Engine speed: 1,500 rpm

Time required before starting testing after air conditioner starts operating: More than 10 minutes

TEST READING

Recirculating-to-discharge air temperature table


Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	20 (68)	6.0 (43)
	25 (77)	9.0 (48)
	30 (86)	13.8 (57)
	35 (95)	18.2 (65)
	40 (104)	23.0 (73)
60 - 70	20 (68)	6.0 (43)
	25 (77)	10.8 (51)
	30 (86)	15.8 (60)
	35 (95)	21.0 (70)
	40 (104)	26.0 (79)

Ambient air temperature-to-compressor pressure table

Ambient air		High-pressure (Discharge side) kPa (kg/cm ² , psi)	Low-pressure (Suction side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	20 (68)	1,128 (11.5, 164) or less	157 (1.6, 23) or less
	25 (77)	1,275 (13.0, 185)	171.6 (1.75, 24.9)
	30 (86)	1,608 (16.4, 233)	226 (2.3, 33)
	35 (95)	1,961 (20.0, 284)	284 (2.9, 41)
	40 (104)	2,275 (23.2, 330)	343 (3.5, 50)

Performance Test Diagnoses

INSUFFICIENT COOLING



Note:

1) Refer to SIGHT GLASS INSPECTION and TROUBLE DIAGNOSES on next pages for details of 1 and 2.


2) A - F in "Check discharge pressure 2" correspond to those in TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE.

Performance Test Diagnoses

TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE





Whenever abnormal pressure of high and/or low sides of the system is noted, diagnosis must be conducted by using a manifold gauge. The large-line zone on the gauge scale (see illustrations.) shown in the following table refers to the standard (normal) pressure range for the corresponding pressure side (high or low). Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to the "Ambient Temperature-Pressure Characteristics" chart.

Pressure measurements are effective only when ambient temperature is in the range indicated under the heading "INSPECTION DATA (2) Measurement of compressor's high and low pressures".

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
Both high and low-pressure sides are too high.	● Pressure is reduced soon after water is splashed on condenser. ● No air bubbles appear in sight glass when pressure is reduced.	Excessive refrigerant charge in refrigeration cycle	Reduce refrigerant until specified pressure is obtained.
 AC359A	Air suction by radiator or condenser fan is insufficient.	Insufficient condenser cooling performance ↓ ① Condenser fins are clogged. ② Improper rotation of radiator fan or condenser fan	● Clean condenser. ● Check and repair radiator or condenser fan as necessary.
	● Low-pressure pipe is not cold. ● When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm², 28 psi). It then decreases gradually thereafter.	Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.) ↓ Air in refrigeration cycle	Evacuate repeatedly and recharge system.
	Engine tends to overheat.	Engine cooling systems malfunction.	Check and repair each engine cooling system.
	● Areas near low-pressure pipe connection and service valves are considerably cold compared with areas near expansion valve outlet or evaporator. ● Plates are sometimes covered with frost.	● Excessive liquid refrigerant on low-pressure side ● Excessive refrigerant discharge flow ● Expansion valve is open a little compared with the specification. ↓ ① Improper thermal valve installation ② Improper expansion valve adjustment	Replace expansion valve.



DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
High-pressure side is too high and low-pressure side is too low.  AC360A	Upper side of condenser and high-pressure side are hot, however, receiver drier is not so hot.	High-pressure tube or parts located between compressor and condenser are clogged or crushed.	● Check and repair or replace malfunctioning parts. ● Check compressor oil for contamination.
High-pressure side is too low and low-pressure side is too high.  AC356A	High and low-pressure sides become equal soon after compressor operation stops.	Compressor pressure operation is improper. ↓ Damaged inside compressor packings	Replace compressor.
Both high-and low-pressure sides are too low.  AC353A	No temperature difference between high and low-pressure sides	Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)	Replace compressor.
Both high-and low-pressure sides are too low.  AC353A	● There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. ● Receiver drier inlet and expansion valve are frosted. ● Temperature of expansion valve inlet is extremely low as compared with areas near receiver drier. ● Expansion valve inlet may be frosted. ● Temperature difference occurs somewhere in high-pressure side	Receiver drier inside is clogged a little. High-pressure pipe located between receiver drier and expansion valve is clogged.	● Replace receiver drier ● Check compressor oil for contamination. ● Check and repair malfunctioning parts. ● Check compressor oil for contamination.


DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
Both high and low-pressure sides are too low.  AC353A	There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.	Expansion valve closes a little compared with the specification. ↓ ① Improper expansion valve adjustment ② Malfunctioning thermal valve ③ Outlet and inlet may be clogged.	● Remove foreign particles by using compressed air. ● Check compressor oil for contamination.
	Areas near low-pressure pipe connection and service valve are extremely cold as compared with areas near expansion valve outlet and evaporator.	Low-pressure pipe is clogged or crushed.	● Check and repair malfunctioning parts. ● Check compressor oil for contamination.
	Air flow volume is not enough or is too low.	Evaporator is frozen. ↓ Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)	Replace compressor.
Low-pressure side sometimes becomes negative.  AC354A	● Air conditioning system does not function and does not cyclically cool the compartment air. ● The system constantly functions for a certain period of time after compressor is stopped and restarted.	Refrigerant does not discharge cyclically. ↓ Moisture is frozen at expansion valve outlet and inlet. ↓ Water is mixed with refrigerant.	● Drain water from refrigerant or replace refrigerant. ● Replace receiver drier.

DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
Low-pressure side becomes negative.  AC362A	Receiver drier or front/rear side of expansion valve's pipe is frosted or dewed.	High-pressure side is closed and refrigerant does not flow. ↓ Expansion valve or receiver drier is frosted.	After the system is left at rest, start it again in order to confirm whether or not problem is caused by water or foreign particles. ● If the problem is due to water, drain water from refrigerant or replace refrigerant. ● If it is due to foreign particles, remove expansion valve and remove them with dry and compressed air. ● If either of the above methods cannot correct the problem, replace expansion valve. ● Replace receiver drier. ● Check compressor oil for contamination.

TROUBLE DIAGNOSES

Contents

Symptom Chart	HA-44
Preliminary Check	HA-46
PRELIMINARY CHECK 1 (Intake door is not set at "FRESH" in DEF or FOOT mode.)	HA-46
PRELIMINARY CHECK 2 (A/C does not blow cold air.)	HA-47
PRELIMINARY CHECK 3 (Magnet clutch does not engage in DEF mode.)	HA-48
PRELIMINARY CHECK 4 (Air outlet does not change.)	HA-49
PRELIMINARY CHECK 5 (Noise)	HA-50
Harness Layout for A/C System	HA-51
Circuit Diagram for Quick Pinpoint Check	HA-53
Wiring Diagram	HA-54
Main Power Supply and Ground Circuit Check	HA-56
Diagnostic Procedure 1 (SYMPTOM: Blower motor does not rotate.)	HA-57
Diagnostic Procedure 2 (SYMPTOM: Air outlet does not change.)	HA-61
Diagnostic Procedure 3 (SYMPTOM: Intake door does not change in VENT, B/L or FOOT mode.)	HA-63
Diagnostic Procedure 4 (SYMPTOM: Magnet clutch does not engage with A/C switch and fan switch are ON.)	HA-64
Diagnostic Procedure 5 (SYMPTOM: Illumination or indicators of push control unit do not come on.)	HA-68
Electrical Components Inspection	HA-73
Control Cable and Rod Adjustment	HA-75

TROUBLE DIAGNOSES

Symptom Chart

DIAGNOSTIC TABLE

PROCEDURE	Preliminary Check					Diagnostic Procedure					Main Power Supply and Ground Circuit Check			
REFERENCE PAGE	HA-46	HA-47	HA-48	HA-49	HA-50	HA-57 - 60	HA-61 - 62	HA-63	HA-64 - 68	HA-68 - 72	HA-56	HA-56	HA-56	HA-56
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Preliminary check 4	Preliminary check 5	Diagnostic procedure 1	Diagnostic procedure 2	Diagnostic procedure 3	Diagnostic procedure 4	Diagnostic procedure 5	20A Fuses	15A Fuse	Push control unit	Thermo control amp.
A/C does not blow cold air.		①				○			○		○	○		○
Blower motor does not rotate.		①				②					○			
Air outlet does not change.				①			②					○	○	
Intake door does not change in VENT, B/L or FOOT mode.								②				○	○	
Intake door is not set at "FRESH" in DEF or FOOT mode.	①							○				○	○	
Magnet clutch does not operate with A/C switch and fan switch are ON.		①							②			○		○
Magnet clutch does not operate in DEF mode.		①	②						○			○		○
Illumination or indicators of push control unit do not come on.										①		○		
Noise					①									

①, ②: The number means checking order.

○: As for checking order, refer to each flow chart. (It depends on malfunctioning portion.)

TROUBLE DIAGNOSES

Symptom Chart (Cont'd)

Electrical Components Inspection


[illegible]

TROUBLE DIAGNOSES

Preliminary Check

PRELIMINARY CHECK 1

Intake door is not set at "FRESH" in DEF or F/D mode.



Preliminary Check (Cont'd)

A/C does not blow cold air.




TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

PRELIMINARY CHECK 3

Magnet clutch does not engage in DEF mode.

- Perform PRELIMINARY CHECK 2 before referring to the following flow chart.



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

PRELIMINARY CHECK 4

Air outlet does not change.


DOES AIR COME OUT FROM EACH DUCT NORMALLY WHEN EACH MODE SWITCH IS PUSHED WITH IGNITION SWITCH AT ON?

No

Go to **Diagnostic Procedure 2.**

Switch		Indicator illuminates					Air outlet
							
Mode		○					VENT
			○				FOOT & VENT
				○			FOOT & DEF
					○		FOOT & DEF
						○	DEF

Air distribution ratios



Yes


INSPECTION END

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

PRELIMINARY CHECK 5





Noise



TROUBLE DIAGNOSES

Harness Layout for A/C System


Engine compartment




RHA169B

TROUBLE DIAGNOSES

Harness Layout for A/C System (Cont'd)



Circuit Diagram for Quick Pinpoint Check



- All connectors shown in this illustration are unit side connectors.
- The unit side connectors with a double circle "⊙" are connected to the harness side connectors shown in the "Harness Layout for A/C System". (See pages HA-51 - HA-52.)
- The terminal numbers in the connector coincide with the circuit numbers surrounded by a single circle "○".
- The thermal switches are built in push control unit and mechanically linked to corresponding switches.

Wiring Diagram (Cont'd)


[illegible]

Main Power Supply and Ground Circuit Check

POWER SUPPLY CIRCUIT CHECK FOR A/C SYSTEM

Check power supply circuit for air conditioning system.

Refer to "POWER SUPPLY ROUTING" in EL section and A/C ELECTRICAL CIRCUIT.




THERMO CONTROL AMP. CHECK

Check power supply circuit for thermo control amp. with ignition switch ON.

1. Disconnect thermo control amp. harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ③④ and body ground.


Voltmeter terminal		Voltage
⊕	⊖	
③④	Body ground	Approx. 12V



Check body ground circuit for thermo control amp. with ignition switch OFF, A/C switch ON and fan switch ON.

1. Disconnect thermo control amp. harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑬ and body ground.

Ohmmeter terminal		Continuity
⊕	⊖	
⑬	Body ground	Yes




PUSH CONTROL UNIT CHECK

Check power supply circuit for push control unit with ignition switch at ACC.

1. Disconnect push control unit harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑭ and body ground.

Voltmeter terminal		Voltage
⊕	⊖	
⑭	Body ground	Approx. 12V



Check body ground circuit for push control unit with ignition switch ON.

1. Disconnect push control unit harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑰ and body ground.

TROUBLE DIAGNOSES

	INCIDENT	Flow chart No.
1	Fan fails to rotate.	1
2	Fan does not rotate at 1-speed.	2
3	Fan does not rotate at 2-speed.	3
4	Fan does not rotate at 3-speed.	4
5	Fan does not rotate at 4-speed.	5

Diagnostic Procedure 1

SYMPTOM: Blower motor does not rotate.

- Perform **PRELIMINARY CHECK 2** before referring to the following flow chart.

Check if blower motor rotates properly at each fan speed.
Conduct check as per flow chart at left.

A 1
CHECK POWER SUPPLY FOR BLOWER MOTOR.
Disconnect blower motor harness connector.
Do approx. 12 volts exist between blower motor harness terminal No. ③⑩ and body ground?

O.K.

N.G.

2 3 4 5
B C D E

(Go to next page.)

Check 20A fuses at fuse block.
(Refer to "POWER SUPPLY ROUTING" in EL section and A/C ELECTRICAL CIRCUIT.)

B
Check circuit continuity between blower motor harness terminal No. ②④ and body ground.

O.K.

N.G.

Reconnect blower motor harness connector.

CHECK BLOWER MOTOR.
(Refer to Electrical Components Inspection.)

Replace blower motor.

C
CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND RESISTOR.
Do approx. 12 volts exist between resistor harness terminal No. ②④ and body ground?

O.K.





N.G.

Disconnect blower motor and resistor harness connectors.

D Note
Check circuit continuity between blower motor harness terminal No. ②④ and resistor harness terminal No. ②④.




(Go to next page.)

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.



TROUBLE DIAGNOSES

Diagnostic Procedure 1 (Cont'd)









Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES


Diagnostic Procedure 1 (Cont'd)



Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 1 (Cont'd)



L

G




Note

CHECK BODY GROUND CIRCUIT FOR BLOWER RELAY.

Does continuity exist between blower relay harness terminal No. ④② and body ground?

Note:


If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 2

SYMPTOM: Air outlet does not change.

- Perform **PRELIMINARY CHECK 4** and **Main Power Supply and Ground Circuit Check** before referring to the following flow chart.




Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 2 (Cont'd)



Reconnect push control unit and mode door motor harness connectors.

D

CHECK FOR OUTPUT OF PUSH CONTROL UNIT.

Do approx. 12 volts exist between push control unit harness terminal No. ⑦ and ⑧ when mode is switched from "VENT" to "DEF" or when mode is switched from "DEF" to "VENT"?




N.G.

Replace control amp. built-in push control unit.

Terminal No.		Mode door motor	
⑦	⑧	Mode door operation	Direction of linkage rotation
⊖	⊖	Stop	Stop
⊖	⊕	VENT → DEF	Clock-wise
⊕	⊖	DEF → VENT	Counter-clock-wise

O.K.


Replace mode door motor.



Diagnostic Procedure 3

SYMPTOM: Intake door does not change in VENT, B/L or FOOT mode.

- Perform **PRELIMINARY CHECK 1** and **Main Power Supply and Ground Circuit Check** before referring to the following flow chart.



Note:



If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 4

SYMPTOM: Magnet clutch does not engage when A/C switch and fan switch are ON.

- Perform **PRELIMINARY CHECK 2** before referring to the following flow chart.



A

CHECK POWER SUPPLY FOR COMPRESSOR.

Disconnect compressor harness connector.

Do approx. 12 volts exist between compressor harness terminal No. 42 and body ground?

N.G.

A

O.K.

B

CHECK THERMAL PROTECTOR.

Disconnect thermal protector harness connector.

Does continuity exist between thermal protector harness terminal No. 99 and body ground?

N.G.

Replace thermal protector.



O.K.

Check magnet clutch coil.

O.K.

Replace magnet clutch.

Refer to COMPRESSOR — Model NVR 140S (ATSUGI make).



A

Disconnect A/C relay harness connector.

O.K.

D

CHECK POWER SUPPLY FOR A/C RELAY.

Disconnect A/C relay.

Do approx. 12 volts exist between A/C relay harness terminal No. 32, 33 and body ground?

O.K.

N.G.

C

Check circuit continuity between A/C relay harness terminal No. 42 and compressor harness terminal No. 42.

Note

Check 20A fuses at fuse block.

(Refer to "POWER SUPPLY ROUTING" in EL section and A/C ELECTRICAL CIRCUIT.)

B


(Go to next page.)

Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 4 (Cont'd)




B

CHECK A/C RELAY AFTER DISCONNECTING IT.
(Refer to Electrical Components Inspection.)

N.G. → Replace A/C relay.

O.K.

Reconnect A/C relay.




E

CHECK COIL SIDE CIRCUIT OF A/C RELAY.
Do approx. 12 volts exist between E.C.C.S. control unit harness terminal No. ⑪ and body ground?

N.G. **F** Note
Check circuit continuity between A/C relay harness terminal No. ④③ and E.C.C.S. control unit harness terminal No. ⑪.

O.K.



G

CHECK VOLTAGE FOR THERMO CONTROL AMP.
Do more than 8 volts exist between thermo control amp. harness terminal No. ④④ and body ground?

N.G. **H** Note
Check circuit continuity between thermo control amp. harness terminal No. ④④ and dual-pressure switch terminal No. ④④.

O.K.


(Go to next page.)

O.K.

CHECK DUAL-PRESSURE SWITCH.
(Refer to Electrical Components Inspection.)

O.K.


N.G.
Replace dual-pressure switch.



I Note
Check circuit continuity between E.C.C.S. control unit harness terminal No. ④① and dual-pressure switch harness terminal No. ④⑤.

O.K.

CHECK E.C.C.S. CONTROL UNIT.
(Refer to EF & EC section.)






Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 4 (Cont'd)



C

CHECK POWER SUPPLY FOR THERMO CONTROL AMP.
Go to Main Power Supply and Ground Circuit Check.

O.K.

J

CHECK BODY GROUND CIRCUIT FOR THERMO CONTROL AMP.
Disconnect thermo control amp. harness connector.
Does continuity exist between thermo control amp. harness terminal No. ⑬ and body ground?

N.G.

Disconnect A/C switch harness connector.

K Note

Check circuit continuity between thermo control amp. harness terminal No. ⑬ and A/C switch harness terminal No. ⑬.

O.K.

Replace thermo control amp.

CHECK A/C SWITCH.
(Refer to Electrical Components Inspection.)

N.G.

Replace A/C switch.

O.K.

Disconnect fan switch harness connector.

L Note

Check circuit continuity between A/C switch harness terminal No. ⑫ and fan switch harness terminal No. ⑳.







O.K.

⑩
(Go to next page.)

Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 4 (Cont'd)




Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 4 (Cont'd)




R **Note**

CHECK BODY GROUND CIRCUIT FOR BLOWER RELAY.
Does continuity exist between blower relay harness terminal No. 42 and body ground?

Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 5

SYMPTOM: Illumination or indicators of push control unit do not come on.

- Perform Main Power Supply and Ground Circuit Check before referring to the following flow chart.

Turn ignition switch and lighting switch ON.

CHECK ILLUMINATION AND INDICATORS.

- Turn A/C, REC and fan switches ON.
- Push VENT, B/L, FOOT, F/D and DEF switches in order.
- Check for incidents and follow the repairing methods as shown:

INCIDENTS									"How to repair"
ILL.		VENT	B/L	FOOT	F/D	DEF	REC	A/C	
Push control unit	Fresh vent								
X	O	O	O	O	O	O	O		Go to DIAGNOSTIC PROCEDURE 5-1.
O	X	O	O	O	O	O	O		Go to DIAGNOSTIC PROCEDURE 5-2.
		O	O	O	O	O	O	X	Go to DIAGNOSTIC PROCEDURE 5-3.
O		X	X	X	X	X	X		Go to DIAGNOSTIC PROCEDURE 5-4.
		Δ							Replace control amp. built in push control unit.
O		X	X	X	X	X	X	O	Replace control amp. built-in push control unit.
		X	X	X	X	X	X	O	Go to DIAGNOSTIC PROCEDURE 5-5.

o: Illumination or indicator comes on.


x: Illumination or indicator does not come on.

Δ: Some indicators for VENT, B/L, FOOT, F/D, DEF or REC come on.

TROUBLE DIAGNOSES

Diagnostic Procedure 5 (Cont'd)

DIAGNOSTIC PROCEDURE 5-1




CHECK THE OTHER ILLUMINATION SYSTEMS EXCEPT FOR A/C SYSTEM. Do the other illumination come on with ignition switch and lighting switch ON?

N.G.

CHECK ILLUMINATION SYSTEM. Refer to illumination/Wiring Diagram in EL section.

O.K.

Turn ignition switch and lighting switch OFF.



A CHECK ILLUMINATION BULB. Remove push control unit and disconnect harness connectors. Remove illumination bulb(s) and check them.

N.G.

Replace illumination bulb(s).


O.K.

B CHECK POWER SUPPLY FOR ILLUMINATION WITH LIGHTING SWITCH ON. Do approx. 12 volts exist between push control unit harness terminal No. ⑮ and body ground?

N.G.

CHECK POWER SUPPLY FOR A/C ILLUMINATION SYSTEM. Refer to illumination/Wiring Diagram in EL section.

O.K.



C CHECK BODY GROUND CIRCUIT FOR ILLUMINATION. Does continuity exist between push control unit harness terminal No. ⑯ and body ground?

Note




O.K.

Replace control amp. built-in push control unit.

TROUBLE DIAGNOSES

Diagnostic Procedure 5 (Cont'd)

DIAGNOSTIC PROCEDURE 5-2



CHECK THE OTHER ILLUMINATION SYSTEMS EXCEPT FOR A/C SYSTEM.
Do the other illumination come on with ignition switch and lighting switch ON?

N.G.

CHECK ILLUMINATION SYSTEM.
Refer to illumination/Wiring Diagram in EL section.

O.K.

Turn ignition switch and lighting switch OFF.

CHECK ILLUMINATION BULB.
Remove fresh vent assembly and disconnect harness connectors. Remove illumination bulb(s) and check them.

N.G.

Replace illumination bulb(s).

O.K.

CHECK POWER SUPPLY FOR ILLUMINATION WITH LIGHTING SWITCH ON.
Do approx. 12 volts exist between push control unit harness terminal No. ⑩ and body ground?

N.G.

CHECK POWER SUPPLY FOR A/C ILLUMINATION SYSTEM.
Refer to illumination/Wiring Diagram in EL section.

O.K.

CHECK BODY GROUND CIRCUIT FOR ILLUMINATION.
Does continuity exist between push control unit harness terminal No. ⑪ and body ground?

Note

O.K.

Replace control amp. built-in push control unit.

Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 5 (Cont'd)

DIAGNOSTIC PROCEDURE 5-3

CHECK MAGNET CLUTCH ENGAGEMENT.

Does magnet clutch engage normally when engine ON, A/C switch, fan switch are ON?

N.G.



Go to Diagnostic Procedure 4.

O.K.

Check bulb.

N.G.

Replace bulb.



DIAGNOSTIC PROCEDURE 5-4

Turn ignition switch and lighting switch OFF.

Disconnect push control unit harness connector.

A CHECK POWER SUPPLY FOR PUSH CONTROL UNIT.
Do approx. 12 volts exist between push control unit harness terminal No. ⑭ and body ground?

N.G.

Check 10A fuse at fuse block.
(Refer to "POWER SUPPLY ROUTING" in EL section and A/C ELECTRICAL CIRCUIT.)

O.K.

B CHECK BODY GROUND CIRCUIT FOR PUSH CONTROL UNIT.
Does continuity exist between push control unit harness terminal No. ⑰ and body ground?

Note

O.K.

Replace control amp. built-in push control unit.


Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES

Diagnostic Procedure 5 (Cont'd)

DIAGNOSTIC PROCEDURE 5-5



Turn ignition switch and lighting switch OFF.

Disconnect push control unit harness connector.

A Note

CHECK BODY GROUND CIRCUIT FOR PUSH CONTROL UNIT.
Does continuity exist between push control unit harness terminal No. ⑰ and body ground?

O.K.

Replace control amp. built-in push control unit.


Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

Electrical Components Inspection

FAN SWITCH


Check continuity between terminals at each switch position.



BLOWER MOTOR


Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the intake unit.



BLOWER RESISTOR


Check continuity between terminals.



A/C SWITCH

Check continuity between terminals at each switch position.


Switch condition	Terminal No.		Continuity
	⊕	⊖	
ON	⑬	⑫	Yes
OFF			No




TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

DUAL-PRESSURE SWITCH




High-pressure side line pressure kPa (kg/cm ² , psi)	Operation	Continuity
Decreasing to 177 - 216 (1.8 - 2.2, 26 - 31) Increasing to 2,452 - 2,844 (25 - 29, 356 - 412)	Turn OFF	Does not exist
Increasing to 177 - 235 (1.8 - 2.4, 26 - 34) Decreasing to 1,863 - 2,354 (19 - 24, 270 - 341)	Turn ON	Exists



THERMAL PROTECTOR


Temperature of compressor °C (°F)	Operation
Increasing to approx. 135 - 145 (275 - 293)	Turn OFF
Decreasing to approx. 120 - 130 (248 - 266)	Turn ON



THERMO CONTROL AMP.

1. Run engine, and operate A/C system.
2. Connect the voltmeter from harness side.
3. Check thermo control amp. operation shown in the table.

Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 2.5 - 3.5 (37 - 38)	Turn OFF	Approx. 12V
Increasing to 4.0 - 5.0 (39 - 41)	Turn ON	Approx. 0V




RELAYS

Check circuit continuity between terminals by supplying 12 volts to coil side terminals of the relay.

Control Linkage Adjustment

MODE DOOR


1. Move side link with hand and hold mode door in VENT mode.
2. Install mode door motor on heater unit and connect it to body harness.
3. Turn ignition switch to ON.
4. Turn VENT switch ON.
5. Attach mode door motor rod to side link rod holder.
6. Turn DEF switch ON. Check that side link operates at the fully-open position. Also turn VENT switch ON to check that side link operates at the fully-open position.



TEMPERATURE CONTROL CABLE


- Move the temperature control lever to the full hot position. Set the air mix door lever in the full hot position. Pull on the outer cable in the direction of the arrow and then clamp it.

After positioning control cable, check it operates properly.



INTAKE DOOR

1. Connect the intake door motor harness connector before installing to the intake door motor.
2. Turn ignition switch to ON.
3. Turn REC switch ON.
4. Install intake door motor on intake unit.
5. Install intake door lever.
6. Set intake door rod in REC position and fasten door rod to holder on intake door lever.
7. Check that intake door operates properly when REC switch is turned ON and OFF.




TROUBLE DIAGNOSES

Control Linkage Adjustment (Cont'd)


FRESH VENT DOOR

- Set the fresh vent shaft in the direction of the arrow. Pull on the outer cable and then clamp it.

After positioning control cable, check it operates properly.



Push Control System




This push control system operates the intake and mode door motors to activate their corresponding doors.

SWITCHES AND THEIR CONTROL FUNCTIONS

Switch	Indicator illuminates							Air outlet	Intake air	Compressor
	A/C									
A/C	○									ON*1
Mode		○						VENT		
			○					B/L		
				○				FOOT		
					○			F/D	FRE	
						○		DEF	FRE	ON*1
							○*2		REC*2	

*1: Compressor is operated by thermo control amp.


*2: Depending on mode switch position



Intake Door Motor

The intake door motor is installed on the front portion of the intake unit. Using a rod and link it opens and closes the intake door.

When the REC switch is ON (OFF), the ground line of the intake door motor is switched from terminal ⑩ to ⑨ (⑨ to ⑩). This causes the motor to start because the position switch contacts built into it are set to the current flow position. The contacts turn along with the motor. When they reach the non-current flow position, the motor will stop. The motor always turns in the same direction.




Mode Door Motor

The mode door motor is located on the left side of the heater unit. Through the side link it opens and closes the vent, foot and defroster door.

When one mode switch is pushed, the position switch built into it reads the corresponding mode to determine the direction of the motor rotation. As soon as the desired mode is set, the position switch stops the motor.


Terminal No.		Mode door motor	
⑦	⑧	Mode door operation	Direction of linkage rotation
⊖	⊖	Stop	Stop
⊖	⊕	VENT → DEF	Clockwise
⊕	⊖	DEF → VENT	Counter-clockwise

SYSTEM DESCRIPTION — Push Control



Removal and Installation


1. Remove cluster lid C.



2. Remove audio (radio).
3. Remove four screws of push control unit.
4. Remove temperature control cable.
5. Remove fresh vent door cable.
6. Disconnect push control unit harness connectors.
7. Remove push control unit.
8. Installation is in the reverse order of removal.

Refer to "Control Linkage Adjustment" for temperature control cable.


Overhaul — Push control unit assembly




SYSTEM DESCRIPTION — Push Control

Overhaul — Push control unit assembly (Cont'd)

1. Disconnect illumination harness connector.




2. Remove fresh vent assembly.




3. Remove temperature control knob & fan control dial.


Wrap temperature knob & fan control dial with a cloth and pull in direction indicated by arrow as shown in figure at left. Be careful not to scratch knobs during removal.



4. Remove fan switch.



5. Remove control base & control amp. cover.




SYSTEM DESCRIPTION — Push Control


Overhaul — Push control unit assembly (Cont'd)

6. Remove control knobs.

Wrap finisher with a cloth and remove knobs using flat-bladed screwdriver or similar tool. Be careful not to scratch finisher surface.



7. Remove illumination bulbs.



8. Remove control amp.

Be careful not to damage substrate when removing.

9. Remove illumination plate.

10. Remove finisher plate.

11. Disconnect temperature control cable.

12. Installation is in reverse order of removal.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

COMPRESSOR

Model	ATSUGI make NVR 140S
Type	Vane rotary
Displacement cm^3 (cu in)/Rev.	140 (8.54)
Direction of rotation	Clockwise (Viewed from drive end)
Drive belt	Poly V

LUBRICATION OIL

Model	ATSUGI make NVR 140S
Type	SUNISO 5GS or equivalent
Capacity ml (US fl oz, Imp fl oz)	
Total in system	200 (6.8, 7.0)
Amount of oil which can be drained	Approx. 100 (3.4, 3.5)
Compressor (Service parts) charging amount	200 (6.8, 7.0)

REFRIGERANT

Type	R-12
Capacity kg (lb)	0.75 - 0.85 (1.65 - 1.87)

Inspection and Adjustment

ENGINE IDLING SPEED (When A/C is ON.)

- Refer to EF & EC section.

BELT TENSION

- Refer to Checking Drive Belts (MA section).

COMPRESSOR

Model	NVR 140S
Clutch disc-pulley clearance mm (in)	0.3 - 0.6 (0.012 - 0.024)

ELECTRICAL SYSTEM

SECTION **EL**

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

CONTENTS

HARNESS CONNECTOR	EL- 2
STANDARDIZED RELAY	EL- 3
POWER SUPPLY ROUTING	EL- 5
BATTERY	EL- 7
STARTING SYSTEM	EL-15
STARTING SYSTEM — Starter —	EL-17
CHARGING SYSTEM	EL-25
CHARGING SYSTEM — Alternator —	EL-27
COMBINATION SWITCH	EL-32
HEADLAMP	EL-34
EXTERIOR LAMP	EL-39
INTERIOR LAMP	EL-44
METER AND GAUGES	EL-46
WARNING LAMPS AND CHIME	EL-51
TIME CONTROL SYSTEM	EL-55
WIPER AND WASHER	EL-65
HORN, CIGARETTE LIGHTER, CLOCK	EL-69
REAR WINDOW DEFOGGER	EL-70
AUDIO AND POWER ANTENNA	EL-73
AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)	EL-77
LOCATION OF ELECTRICAL UNITS	EL-86
HARNESS LAYOUT	EL-89
SUPER MULTIPLE JUNCTION (S.M.J.)	Foldout page
JOINT CONNECTOR (J/C)	Foldout page

WIRING DIAGRAM REFERENCE CHART

E.C.C.S. (Ignition system)	EF & EC SECTION
AUTOMATIC TRANSAXLE CONTROL SYSTEM, SHIFT LOCK SYSTEM	AT SECTION
ANTI-LOCK BRAKING SYSTEM	BR SECTION
POWER WINDOW AND POWER DOOR LOCK, AUTOMATIC SEAT BELT SYSTEM, SUN ROOF, DOOR MIRROR	BF SECTION
HEATER AND AIR CONDITIONER	HA SECTION



HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]




SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H













TYPE OF STANDARDIZED RELAYS

1M 1 Make 2M 2 Make
 1T 1 Transfer 1M-1B 1 Make 1 Break




SEL882H

STANDARDIZED RELAY


Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE or GREEN
2M				BROWN
1M-1B				GRAY

SEL883H

Wiring Diagram




POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not install fuse in oblique direction; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.



Fusible Link

A melted fusible link can be detected by visual inspection. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap periphery of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness or vinyl or rubber parts.

FUSIBLE LINK (WIRE TYPE) VARIATION

Color	Maximum amperage (A)
Brown	15
Green	20
Red	30
Black	35
Gray	40

*Temperature condition: Less than 80°C (176°F)

BATTERY

CAUTION:




- a. If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- b. After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- c. Never add distilled water through the hole used to check specific gravity.

How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
If the top surface of a battery is wet with electrolyte or water, leakage current will cause the battery to discharge. Always keep the battery clean and dry.
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)
- Check the charge condition of the battery.
Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.



BATTERY


How to Handle Battery (Cont'd)

CHECKING ELECTROLYTE LEVEL


WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

Normally the battery does not require additional water. However, when the battery is used under severe conditions, adding distilled water may be necessary during the battery life.




- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.



SULPHATION


When a battery has been left unattended for a long period of time and has a specific gravity of less than 1.100, it will be completely discharged, resulting in sulphation on the cell plates.

Compared with a battery discharged under normal conditions, the current flow in a "sulphated" battery is not as smooth although its voltage is high during the initial stage of charging, as shown in the figure at the left.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.



- When electrolyte level is too low, tilt battery case to raise it for easy measurement.


BATTERY

How to Handle Battery (Cont'd)

2. Convert into specific gravity at 20°C (68°F).

Example:


- When electrolyte temperature is 35°C (95°F) and specific gravity of electrolyte is 1.230, converted specific gravity at 20°C (68°F) is 1.240.
- When electrolyte temperature is 0°C (32°F) and specific gravity of electrolyte is 1.210, converted specific gravity at 20°C (68°F) is 1.196.



BATTERY

Battery Test and Charging Chart

Chart I




* "STANDARD CHARGE" is recommended in case that the vehicle is in storage after charging.

BATTERY

Battery Test and Charging Chart (Cont'd)


Chart II



- Check battery type and determine the specified current using the following table.

Fig. 1 DISCHARGING CURRENT (Load tester)

Type	Current (A)
28B19R(L)	90
34B19R(L)	99
46B24R(L)	135
55B24R(L)	135
50D23R(L)	150
55D23R(L)	180
65D26R(L)	195
80D26R(L)	195
75D31R(L)	210
95D31R(L)	240
95E41R(L)	300
130E41R(L)	330



SEL697B

BATTERY

Battery Test and Charging Chart (Cont'd)

A: SLOW CHARGE





Fig. 2 INITIAL CHARGING CURRENT SETTING (Slow charge)

BATTERY TYPE CON- VERTED SPECIFIC GRAVITY	28B19R(L) 34B19R(L)	48B24R(L) 58B24R(L)	50D23R(L) 56D23R(L)	65D26R(L) 80D26R(L)	75D31R(L)	95D31R(L) 95E41R(L)	130E41R(L)
Below 1.100	4.0 (A)	5.0 (A)	7.0 (A)	8.0 (A)	9.0 (A)	10.0 (A)	14.0 (A)

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary.

Fig. 3 ADDITIONAL CHARGE (Slow charge)



CAUTION:

- Set charging current to value specified in Fig. 2. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY

Battery Test and Charging Chart (Cont'd)

B: STANDARD CHARGE

Determine initial charging current from specific gravity, referring to Fig. 4.

Charge battery for 8 hours.

CHECKING SPECIFIC GRAVITY
Refer to "Specific Gravity Check".

Conduct additional charge as per Fig. 5, if necessary.


Go to "CAPACITY TEST".

Fig. 4 INITIAL CHARGING CURRENT SETTING
(Standard charge)

BATTERY TYPE CON- VERTED SPECIFIC GRAVITY	28B19R(L) 34B19R(L)	46B24R(L) 55B24R(L)	50D23R(L) 55D23R(L)	65D26R(L) 80D26R(L)	75D31R(L)	95D31R(L) 95E41R(L)	130E41R(L)
1.100 - 1.130	4.0 (A)	5.0 (A)	6.0 (A)	7.0 (A)	8.0 (A)	9.0 (A)	13.0 (A)
1.130 - 1.160	3.0 (A)	4.0 (A)	5.0 (A)	6.0 (A)	7.0 (A)	8.0 (A)	11.0 (A)
1.160 - 1.190	2.0 (A)	3.0 (A)	4.0 (A)	5.0 (A)	6.0 (A)	7.0 (A)	9.0 (A)
1.190 - 1.220	2.0 (A)	2.0 (A)	3.0 (A)	4.0 (A)	5.0 (A)	5.0 (A)	7.0 (A)

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary.

Fig. 5 ADDITIONAL CHARGE (Standard charge)



CAUTION:

- Do not use standard charge method on a battery whose specific gravity is less than 1.100.
- Set charging current to value specified in Fig. 4. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY

Battery Test and Charging Chart (Cont'd)

C: QUICK CHARGE




Fig. 6 INITIAL CHARGING CURRENT SETTING AND CHARGING TIME (Quick charge)

CON- VERTED SPECIFIC GRAVITY	BATTERY TYPE	CUR- RENT [A]	28B19R(L) 34B19R(L)	46B24R(L) 55B24R(L) 50D23R(L)	55D23R(L) 65D26R(L) 80D26R(L)	75D31R(L) 95D31R(L) 95E41R(L)	130E41R(L)
			10 (A)	15 (A)	20 (A)	30 (A)	40 (A)
1.100 - 1.130	2.5 hours						
1.130 - 1.160	2.0 hours						
1.160 - 1.190	1.5 hours						
1.190 - 1.220	1.0 hours						
Above 1.220	0.75 hours (45 min.)						

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary.

CAUTION:


- Do not use quick charge method on a battery whose specific gravity is less than 1.100.
- Set initial charging current to value specified in Fig. 6. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- Be careful of a rise in battery temperature because a large current flow is required during quick-charge operation.
If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).
- Do not exceed the charging time specified in Fig. 6, because charging battery over the charging time can cause deterioration of the battery.

Service Data and Specifications (S.D.S.)

Applied model		For U.S.A.	For Canada
Type		55D23L	65D26L
Capacity	V-AH	12-60	12-65

STARTING SYSTEM

Wiring Diagram




MEL032A

Trouble-shooting



M1T72281A


Construction




Unit: mm (in)
 : N·m (kg·m, ft·lb)
 : High-temperature grease point

SEL628L

S114-525






SEL647J



Removal and Installation


REMOVAL

1. Remove air duct.
2. Remove harness clamps. For A/T model, remove harness connectors from harness connector bracket.
3. Remove starter cable from starter.
4. Remove starter fixing bolts.




INSTALLATION

- Installation is in reverse order of removal.
- Starter upper fixing bolt is shorter than lower bolt.**




Magnetic Switch Check

- Before starting to check, disconnect battery ground cable.
- Disconnect "M" terminal of starter motor.
- 1. Continuity test (between "S" terminal and switch body).
- No continuity ... Replace.




- 2. Continuity test (between "S" terminal and "M" terminal).
- No continuity ... Replace.



Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it does not lock (or locks) in either direction or unusual resistance is evident ... Replace.
3. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)



Brush Check


BRUSH

Check brush for wear.

Wear limit length:

Refer to S.D.S.

- Excessive wear ... Replace.



BRUSH SPRING PRESSURE

Check brush spring pressure with brush spring detached from brush.

Spring pressure (with new brush):



Refer to S.D.S.

- Not within the specified values ... Replace.

Brush Check (Cont'd)


BRUSH HOLDER

1. Perform insulation test between brush holder (positive side) and its base (negative side).
 - Continuity exists. ... Replace.
2. Check brush to see if it moves smoothly.
 - If brush holder is bent, replace it; if sliding surface is dirty, clean.




Pole Piece Check (M1T72281A)

Pole piece is secured to yoke by bonding agent. Check pole piece to see that it is secured to yoke and for any cracks. Replace malfunctioning parts as an assembly. Holder may move slightly as it is only inserted and not bonded.



Yoke Assembly Check (S114-525)

Check magnet for cracks. If there is any crack, replace malfunctioning parts as an assembly.




Armature Check


1. Continuity test (between two segments side by side).
 - No continuity ... Replace.

Armature Check (Cont'd)


2. Insulation test (between each commutator bar and shaft).
 - Continuity exists. ... Replace.




3. Check commutator surface.
 - Rough ... Sand lightly with No. 500 - 600 sandpaper.



4. Check diameter of commutator.
Commutator minimum diameter:
Refer to S.D.S.
 - Less than specified value ... Replace.




5. Check depth of insulating mold from commutator surface.
 - Less than 0.2 mm (0.008 in) ... Undercut to 0.5 to 0.8 mm (0.020 to 0.031 in)



Assembly

Apply high-temperature grease to lubricate the bearing, gears and frictional surface when assembling the starter.
Carefully observe the following instructions.




PINION PROTRUSION LENGTH ADJUSTMENT

M1T72281A


With pinion driven out by magnetic switch, push pinion back to remove slack and measure clearance "ℓ" between the front edge of the pinion and the pinion stopper.

Clearance "ℓ":

Refer to S.D.S.



- Not in the specified value ... Adjust with adjusting plate.




S114-525

Compare movement "ℓ" in height of pinion when it is pushed out with magnetic switch energized and when it is pulled out by hand until it touches stopper.

Movement "ℓ":

Refer to S.D.S.




- Not in the specified value ... Adjust by adjusting plate.

Service Data and Specifications (S.D.S.)

STARTER

Type		M1T72281A	S114-525
		MITSUBISHI make	HITACHI make
		Reduction gear	
System voltage		V	12
No-load	Terminal voltage	V	11.0
	Current	A	50 - 75
	Revolution	rpm	3,000 - 4,000
Minimum length of brush		mm (in)	12.0 (0.472)
Brush spring tension (With new brush)		N (kg, lb)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)
Minimum diameter of commutator		mm (in)	28.8 (1.134)
Clearance "ℓ" between pinion front edge and pinion stopper		mm (in)	0.5 - 2.0 (0.020 - 0.079)
Movement "ℓ" in height of pinion assembly		mm (in)	—
Clearance between bearing metal and armature shaft		mm (in)	—

Wiring Diagram




CHARGING SYSTEM

Trouble-shooting

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.


Before starting trouble-shooting, inspect the fusible link.

WITH IC REGULATOR




- 1) Use fully charged battery.
- 2) Light : Charge warning light
A.C.G. : Alternator parts except IC regulator
IC-RG : IC regulator
O.K. : IC alternator is in good condition.
- 3) When reaching "Damaged A.C.G.", remove alternator from vehicle and disassemble, inspect and correct or replace faulty parts.
- 4) *Method of grounding F terminal (HITACHI make only)

Contact tip of wire with brush and attach wire to alternator body.



- 5) Terminals "S", "L", "B" and "E" are marked on rear cover of alternator.


Construction



REAR BEARING


CAUTION:

Do not reuse bearing or oil seal after removal. Replace with a new one.
 Do not lubricate rear bearing outer race.




Rotor Slip Ring Check

1. Continuity test
 - No continuity ... Replace rotor.




2. Insulator test
 - Continuity exists. ... Replace rotor.
3. Check slip ring for wear.
Slip ring minimum outer diameter:
Refer to S.D.S.



Brush Check

1. Check smooth movement of brush.
 - Not smooth ... Check brush holder and clean.
2. Check brush for wear.
 - Replace brush if it is worn down to the limit line.




3. Check brush lead wire for damage.
 - Damaged ... Replace.
4. Check brush spring pressure.

Measure brush spring pressure with brush projected approximately 2 mm (0.08 in) from brush holder.

Spring pressure:

Refer to S.D.S.

- Not within the specified values ... Replace.




Stator Check


To test the stator or diode, separate them by unsoldering the connecting wires.

CAUTION:

Use only as much heat as required to melt solder. Otherwise, diodes will be damaged by excessive heat.



1. Continuity test
 - No continuity ... Replace stator.



2. Ground test
 - Continuity exists. ... Replace stator.


Diode Check

MAIN DIODES

- Use an ohmmeter to check condition of diodes as indicated in chart below:
- If any of the test results is not satisfactory, replace diode assembly.


	Ohmmeter probes		Continuity
	Positive ⊕	Negative ⊖	
Diodes check (Positive side)	Positive diode plate	Diode terminals	Yes
	Diode terminals	Positive diode plate	No
Diodes check (Negative side)	Negative diode plate	Diode terminals	No
	Diode terminals	Negative diode plate	Yes

[MITSUBISHI make]



SEL385L


[MITSUBISHI make]



SEL494H

SUB-DIODES

- Attach ohmmeter's probe to each end of diode to check for continuity.
- Continuity is N.G. ... Replace diode assembly.




SEL593A

Assembly

Carefully observe the following instructions.


- When soldering each stator coil lead wire to diode assembly terminal, carry out the operation as fast as possible.



WHEN SOLDERING BRUSH LEAD WIRE

[MITSUBISHI make]

- Position brush so that its wear limit line protrudes 2 mm (0.08 in) beyond end face of brush holder.



RING FITTING IN REAR BEARING



- Fix ring into groove in rear bearing so that it is as close to the adjacent area as possible.

Service Data and Specifications (S.D.S.)**ALTERNATOR**

Type		A2T18792
		MITSUBISHI
Nominal rating	V-A	12 - 80
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	1,100
Hot output current	A/rpm	More than 21/1,300 More than 60/2,500
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	8 (0.31)
Brush spring pressure	N (g, oz)	3.138 - 4.315 (320 - 440, 11.29 - 15.52)
Slip ring minimum outer diameter	mm (in)	22.1 (0.870)

COMBINATION SWITCH

Check





LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5									
6									
7									
8									
9									
10									
11									
12									

WIPER SWITCH

	OFF	INT	LO	HI	WASH
13					
14					
15					
16					
17					
18					



TURN SIGNAL SWITCH


	R	N	L
1			
2			
3			

CORNERING LAMP SWITCH

	R	N	L
61			
62			
63			


SEL295N

COMBINATION SWITCH




Replacement

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw and turn after pushing on it.



HEADLAMP


Wiring Diagram (For U.S.A.)



SEL566Q

HEADLAMP

Schematic (For Canada)



Operation (Daytime light system equipped model)

After starting the engine with the lighting switch in the "OFF" position or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
Lighting switch		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	O	X	X	O	O	X	O	△	△	O	△	△	O	O	X	O
	Low beam	X	X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O


O: Lamp "ON"

X: Lamp "OFF"

△: Lamp dims.

■: Added functions

HEADLAMP



Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

CAUTION:

- **Do not leave the bulb out of the headlamp reflector for a long period of time as dust, moisture, smoke, etc. may enter the headlamp body and affect the performance of the headlamp. Thus, the headlamp bulb should not be removed from the headlamp reflector until just before a replacement bulb is to be installed.**


Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. For operating instructions of any aimer, it should be in good repair, calibrated and used according to respective operation manuals supplied with the unit.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- a. **Keep all tires inflated to correct pressures.**
- b. **Place vehicle and tester on one and same flat surface.**
- c. **See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**



AIMER ADJUSTMENT MARK

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

Example:



4H2V
└─ Vertical side: 2
└─ Horizontal side: 4

HEADLAMP

Aiming Adjustment (Cont'd)

LOW BEAM

1. Turn headlamp low beam on.
 2. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**



- **Adjust headlamps so that upper edge and left edge of high intensity zone are within the acceptable range as shown at left.**
 - **Dotted lines in illustration show center of headlamp.**
- "H": Horizontal center line of headlamps
- "W_L": Distance between each headlamp center


Clearance, License, Tail and Stop Lamps/Wiring Diagram




EXTERIOR LAMP

Back-up Lamp/Wiring Diagram

- (M) : M/T model
 (A) : A/T model
 (MU) : M/T model for U.S.A.
 (EX) : Except M/T model for U.S.A.



EXTERIOR LAMP



Combination Flasher Unit Check


- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

Bulb Specifications

	Wattage (12 volt)
Headlamp (Semi-sealed beam)	
High/Low	65/45
Front turn signal lamp	27
Cornering lamp/Front clearance lamp	27/8
Front side marker lamp	3.8
Rear combination lamp	
Turn signal	27
Stop/Tail	27/8
Back-up	27
Rear side marker lamp	3.8
License plate lamp	5
High-mounted stop lamp	18
Interior lamp	10
Spot lamp	8
Trunk room lamp	3.4


INTERIOR LAMP

Illumination/Wiring Diagram



INTERIOR LAMP




Interior, Spot and Trunk Room Lamps/Wiring Diagram



SEL303N


METER AND GAUGES

Combination Meter



SEL304N

Speedometer, Tachometer, Temp., and Fuel Gauges/Wiring Diagram



SEL572Q

METER AND GAUGES

Inspection/Fuel Gauge and Water Temperature Gauge

INSPECTION START

O.K.

CHECK POWER SOURCE

- 1) Turn ignition switch "ON".
- 2) Check voltage between terminal (A) and ground.
Battery voltage should exist.

N.G.

- Check the following items.
- 1) Harness continuity between battery terminal and combination meter
 - 2) Ignition relay
 - 3) Fusible link and fuse
 - 4) Ignition switch

O.K.

CHECK GAUGE OPERATION

- 1) Turn ignition switch "ON".
- 2) Connect terminals (B), (B') and ground with wire through 3.4 W test bulb.
- 3) Check operation of gauge.
Gauge should move smoothly to full scale.

N.G.

Repair or replace gauge.

O.K.

Check harness continuity between component and combination meter (C).

N.G.

Repair or replace.

O.K.

CHECK COMPONENT

Check gauge units and harness.
Refer to "Fuel Tank Gauge Unit Check", "Thermal Transmitter Check".


N.G.

Repair or replace.
Refer to FE section. (Fuel tank gauge unit)


O.K.

Reinstall any part removed.


INSPECTION END




SEL891L



SEL892L




SEL893L



Fuel Tank Gauge Unit Check


Ohmmeter		Float position mm (in)		Resistance value (Ω)
(+)	(-)			
G	E	*3	Full	50 (1.97)
		*2	1/2	111 (4.37)
		*1	Empty	160 (6.30)

- For removal, refer to FE section.
- Check the resistance between terminals ⑨ and ⑩.



Fuel Warning Lamp Sensor Check


- It will take a short time for the bulb to light.



Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.


Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90 Ω
100°C (212°F)	Approx. 21 - 24 Ω



Oil Pressure Switch Check

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	YES

Check the continuity between the terminals of oil pressure switch and body ground.




Speed Sensor Signal Check

1. Remove speed sensor from transmission.
Location: Refer to "Location of Electrical Units"
2. Turn speedometer pinion quickly and measure voltage across ① and ②.


WARNING LAMPS AND CHIME

Warning Lamps/Schematic




SEL306N


Warning Lamps/Wiring Diagram



Warning Chime/Wiring Diagram




WARNING LAMPS AND CHIME




Diode Check

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.



- Diodes for warning lamps are built into the combination meter printed circuit.


Refer to "Combination Meter".



Warning Chime Check

TIME CONTROL SYSTEM

Schematic




Terminal arrangement
of time control unit

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16 17 18 19

(N) : For Canada

TIME CONTROL SYSTEM

Wiring Diagram



TIME CONTROL SYSTEM

Description

FUNCTION

- Time control unit has the following functions.

Item		Details of control
1	Intermittent wiper control	Regulates intermittent time from approximately 3 to 12 seconds depending on the intermittent wiper volume setting.
2	Washer and wiper combination control	Wiper is operated in conjunction with washer switch.
3	Illumination control	Regulates brightness of illumination in 16 stages depending on the illumination control switch setting.
4	Light warning chime timer	When driver's door is opened with light switch "ON" and ignition switch "OFF", warning chime sounds.
5	Seat belt warning lamp timer	Seat-belt warning lamp blinks for about 7 seconds when ignition switch is turned to "ON".
6	Seat belt warning chime timer	Sounds warning chime for about 7 seconds if ignition switch is turned "ON" when seat belt switch is "ON" (seat belt is unfastened).

OPERATING CONDITIONS

Item	Input signal		Power source from battery	Ignition switch	Light switch	Wiper switch "INT"	Washer switch	Driver's side door switch *1	Seat belt switch *2	Illumination control switch
	Input terminal	Output terminal								
Intermittent wiper control	①		ON	ACC or ON		ON				
Washer and wiper combination control	⑫		ON	ACC or ON			ON			
Illumination control	⑪		ON		ON					ON
Light warning chime timer	⑱		ON	OFF or ACC	ON			ON		
Seat belt warning lamp timer	⑯		ON	OFF or ACC → ON						
Seat belt warning chime timer	⑲		ON	OFF or ACC → ON					ON	


*1: Door switch is turned "ON" when door is opened.

*2: Seat belt switch is turned "ON" when driver's side seat belt is unfastened.

TIME CONTROL SYSTEM

Trouble-diagnosis

	Symptom	DIAGNOSTIC PROCEDURE
Wiper & washer	Intermittent wiper does not operate.	1
	Intermittent time of wiper cannot be adjusted.	2
	Wiper and washer activate individually but not in combination.	3
Illumination	Illumination control system does not actuate.	4
Warning	Light warning chime does not activate.	5
	Seat belt warning chime does not activate.	6
	Seat belt warning lamp does not go off nor come on.	7
	Ignition key warning chime does not activate.	8
Rear defogger	Rear defogger does not activate, or does not go off.	9




PREPARATION FOR TROUBLE-DIAGNOSIS

1. Remove lower trim.
2. Remove time control unit with harness connected.

POWER SUPPLY CIRCUIT CHECK

1. Connect ohmmeter from harness side.
2. Check continuity between terminal ⑮ and body ground.

Ohmmeter terminals		Continuity
(+)	(-)	
⑮	Body ground	Yes



3. Connect voltmeter from harness side.
4. Measure voltage across terminal ⑮ and terminals ②, ⑤ or ⑨.

Voltmeter terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
⑨	⑮	Approx. 12V	Approx. 12V	Approx. 12V
⑤	⑮	0V	0V	Approx. 12V
②	⑮	0V	Approx. 12V	Approx. 12V

TIME CONTROL SYSTEM

Trouble-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE-1

Intermittent wiper does not operate.

A T.C.U. OUTPUT FOR WIPER RELAY CIRCUIT CHECK

Measure voltage across (1) and (15).




Wiper switch → "INT"

Needle swings from 0 to 12V every 3 to 12 seconds.

SEL071M


B WIPER SWITCH CIRCUIT CHECK

Check continuity between (12) and (15).




Wiper switch → "INT"

SEL072M



A INTERMITTENT WIPER VOLUME CIRCUIT CHECK

Measure resistance between (14) and (15) while turning intermittent wiper volume.




0Ω at "S" position
Approx.
1 kΩ at "L" position

SEL073M

DIAGNOSTIC PROCEDURE-2

Intermittent time of wiper cannot be adjusted.




TIME CONTROL SYSTEM


Trouble-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE-3

Wiper and washer activate individually but not in combination.




A T.C.U. OUTPUT FOR LIGHT SWITCH CIRCUIT CHECK




SEL074M

B ILLUMINATION CIRCUIT CHECK



SEL075M


C ILLUMINATION CONTROL CIRCUIT CHECK



SEL076M

DIAGNOSTIC PROCEDURE-4

Illumination control system does not actuate.




TIME CONTROL SYSTEM

Trouble-diagnosis (Cont'd)


DIAGNOSTIC PROCEDURE-5

Light warning chime does not activate.



A T.C.U. OUTPUT FOR CHIME CIRCUIT CHECK


Measure voltage across ①⑨ and ①⑤ when driver side door is opened and close.



SEL077M

B SEAT BELT SWITCH CIRCUIT CHECK


1. Unfasten driver side seat belt.
2. Check continuity between ①⑨ and ①⑥.
3. Fasten driver side seat belt.
4. Check to determine if continuity does not exist between ①⑨ and ①⑥.



SEL078M

DIAGNOSTIC PROCEDURE-6

Seat belt warning chime does not activate.



TIME CONTROL SYSTEM


Trouble-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE-7

Seat belt warning lamp does not go off nor comes on.

A T.C.U. OUTPUT FOR BELT WARNING LAMP CIRCUIT CHECK

Measure voltage across ⑮ and ⑮ when
ignition switch is "ON".



Go to "Power Supply Circuit Check".

N.G.

Check harness for T.C.U.
power supply circuit.

O.K.

A

Check T.C.U. output for belt warning
lamp circuit.

N.G.

Replace T.C.U.

Voltmeter needle keeps swinging
(approx. 0 $\leftrightarrow$ 12V) for about 7 sec-
onds after ignition switch is turned
"ON".

O.K.

Check warning lamp, and harness
between T.C.U. and warning lamp.

TIME CONTROL SYSTEM


Trouble-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE-8

Ignition key warning chime does not activate.

A KEY SWITCH CIRCUIT CHECK


Measure voltage across ⑩ and ⑮.



SEL082M

B T.C.U. OUTPUT FOR CHIME CIRCUIT CHECK

Measure voltage across ⑲ and ⑮ when driver side door is opened and closed.




- Approx. 12V when driver side door is opened.

SEL080M

C DRIVER'S DOOR SWITCH CIRCUIT CHECK

Check continuity between ⑱ and ⑮.



Driver side door ... Open

SEL081M

Go to "Power Supply Circuit Check".

N.G.

Check harness for T.C.U. power supply circuit.

O.K.

A

Check key switch circuit.

N.G.

Check key switch or harness.

O.K.

B

Check T.C.U. output for chime circuit.

O.K.

Check chime and harness between T.C.U. and chime.

N.G.

C

Check driver's door switch circuit.

N.G.

Check harness between T.C.U. and driver's door switch.

O.K.

Replace T.C.U.

TIME CONTROL SYSTEM


Trouble-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE-9

Rear defogger does not activate, or does not go off.

A T.C.U. OUTPUT FOR REAR DEFOGGER CIRCUIT CHECK

Measure voltage across ④ and ⑮ while operating rear defogger switch.




Rear defogger switch → ON

- Rear defogger switch "OFF": Approx. 12V
- Rear defogger switch "ON": Approx. 0V


SEL083M

B DEFOGGER SWITCH CIRCUIT CHECK





- Rear defogger switch "OFF": Except 0Ω
- Rear defogger switch "ON": 0Ω

SEL084M




Wiper Removal and Installation



FRONT WIPER REMOVAL

Before removing front wiper motor link, turn wiper switch OFF and disconnect motor leads at connectors.

1. Remove wiper arm.
2. Remove cowl cover.
3. Remove bolts which secure wiper motor.
4. Extract wiper motor so that wiper motor link comes out of hole in front cowl top panel. Then, pull motor straight out to disconnect ball joint which connects motor link and wiper link. Wiper motor can then be removed.
5. Remove wiper link pivot blocks on driver and passenger sides.
6. Extract wiper link and pivot blocks (as one unit) from oblong hole on left side (L.H.D.) of cowl top.



FRONT WIPER INSTALLATION

1. Position wiper link and pivot blocks (as one unit) in cowl top through oblong hole.
2. Before installing pivot blocks on cowl top, hold end (motor link side) of wiper link at hole in front cowl top panel and insert motor link's ball pin into hole in wiper link.
3. Install front wiper in reverse order of above removal procedures.
- Apply a small amount of grease to ball joints before installation.

Installation

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
 2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" or "L₂" immediately before tightening nut.
 3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
 4. Ensure that wiper blades stop within clearance "L₁" & "L₂".
- Tighten windshield wiper arm nuts to specified torque.

Clearance "L₁": 22 - 32 mm (0.87 - 1.26 in)



Clearance "L₂": 43 - 53 mm (1.69 - 2.09 in)

Windshield wiper:


17 - 23 N·m (1.7 - 2.3 kg·m, 12 - 17 ft·lb)

Windshield wiper and washer

Washer nozzle adjustment



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.



Washer Nozzle Adjustment

- Using Tool J36126, adjust windshield washer nozzle to correct its spray pattern.


Special Service tool:

Tool Number: J36126


Tool Name: Washer nozzle adjusting tool

Before attempting to turn the nozzle, gently tap the end of the tool to free the nozzle.




This will prevent “rounding out” the small female square in the center of the nozzle.



Wiring Diagram



REAR WINDOW DEFOGGER



Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.
2. If a filament is burned out, circuit tester registers 0 or 12 volts.
3. To locate burned out point, move probe to left and right along filament to determine point where tester needle swings abruptly.

Filament Repair

REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

REAR WINDOW DEFOGGER

Filament Repair (Cont'd)

REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.




Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.

4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.


Do not touch repaired area while test is being conducted.

5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.



AUDIO AND POWER ANTENNA

Audio/Wiring Diagram



MEL041A


Power Antenna/Wiring Diagram




Diagram illustrating the location of the antenna on the rear window and a detailed view of the antenna assembly.

The main diagram shows the rear window area with labels for the **Main feeder cable** and **Sub-feeder cable**. An arrow points to a detailed view of the antenna assembly.

The detailed view shows the **Antenna** connected to the **Feeder cable**, which is connected to the **Drain hose**. A label **Loosen** indicates the adjustment point for the antenna.




Radio Fuse Check



Antenna Rod Replacement


REMOVAL

1. Remove antenna nut and antenna base.
2. Withdraw antenna rod while raising it by operating antenna motor.



INSTALLATION


1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.





Window Antenna Repair

ELEMENT CHECK


1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.



2. If an element is broken, no continuity will exist.



3. To locate broken point, move probe to left and right along element to determine point where tester needle swings abruptly.




ELEMENT REPAIR

Refer to REAR WINDOW DEFOGGER "Filament Repair".


AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Schematic




AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Wiring Diagram



A.S.C.D. Wire Adjustment



CAUTION:

- Be careful not to twist A.S.C.D. wire when removing it.
- Do not tense A.S.C.D. wire excessively during adjustment.

After confirming that accelerator wire is properly adjusted, adjust the tension of A.S.C.D. wire in the following manner.

- (1) After adjusting the length of the accelerator wire, turn a securing nut by 1/2 to 1 turn from throttle open starting position to the wire loosening direction to fix. (Must be securely carried out to prevent response delay of operation of the A.S.C.D.)
 - (2) Securely tighten lock nut to hold adjusting nut in place.
- For A.S.C.D. cancel switch, stop lamp switch and clutch switch adjustment, refer to BR and CL sections.


AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Trouble Diagnoses

Symptom	DIAGNOSTIC PROCEDURE
A.S.C.D. control unit cannot be set properly.	1
Resume switch will not operate.	2
Cancel switch will not operate.	3
Engine hunts.	4
Large difference between set vehicle speed and actual speed.	5
Set speed cannot be canceled.	6

PREPARATION FOR TROUBLE-DIAGNOSIS

1. Remove lower trim.
2. Remove A.S.C.D. control unit with harness connected.
3. Perform check from harness side using circuit tester, with harness connector connected.





GROUND CIRCUIT CHECK

- Check continuity between ③ and body ground.

AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)



POWER SUPPLY CIRCUIT CHECK

1. Turn A.S.C.D. main switch to "ON".
2. Check voltage between ④ and ③.



CUT-OFF CIRCUIT CHECK



1. Step on brake pedal.
2. Turn A.S.C.D. main switch to "ON".
3. Check voltage between ⑪ and ③.



SEL586Q



SET SWITCH CIRCUIT CHECK

1. Push A.S.C.D. set switch.
2. Check voltage between ② and ③.



SPEED SENSOR CIRCUIT CHECK

1. Disconnect speed sensor from transmission.
 2. Connect a voltmeter between ⑦ and ③.
 3. Slowly turn speed sensor by hand to make sure voltmeter pointer deflects.
- Voltmeter pointer deflects twice per rotation of pinion.



SEL587Q

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE-1

A.S.C.D. control unit cannot be set properly.

Turn A.S.C.D. main switch "OFF" and then "ON" to make sure indicator illuminates.

N.G.

Check indicator bulb, A.S.C.D. main switch and hold relay.

O.K.

Check power supply circuit for A.S.C.D. control unit.

N.G.

Check A.S.C.D. power supply harness.

O.K.

Check cut-off circuit for A.S.C.D. control unit.

N.G.

Check A.S.C.D. cancel switch, clutch switch (M/T model), inhibitor relay and inhibitor switch (A/T model).

O.K.

Check A.S.C.D. set switch circuit for A.S.C.D. control unit.

N.G.

Check A.S.C.D. set switch and harness between control unit and set switch.

O.K.

Check speed sensor circuit.

N.G.

Check speed sensor and harness between A.S.C.D. control unit and speed sensor signal output terminal of combination meter.

O.K.

Check actuator. Refer to "Actuator Check".

N.G.

Replace actuator.

O.K.

Replace A.S.C.D. control unit.

AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE-2

Resume switch will not operate.

RESUME SWITCH CIRCUIT CHECK

1. Turn resume switch to "ON".
2. Check voltage between ① and ③.



SEL588Q

Check resume switch circuit.

N.G.


Check resume switch.

O.K.

Replace A.S.C.D. control unit.

CANCEL SWITCH CIRCUIT CHECK

1. Turn cancel switch to "ON".
2. Check voltage between ② and ③ or ① and ③.



SEL589Q

DIAGNOSTIC PROCEDURE-3

Cancel switch will not operate.

Check cancel switch circuit.

N.G.

Check cancel switch.

O.K.


Replace A.S.C.D. control unit.

AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE-4

Engine hunts.



DIAGNOSTIC PROCEDURE-5

Large difference between set vehicle speed and actual speed.



AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE-6

Set speed cannot be canceled.


CUT-OFF CIRCUIT CHECK

1. Turn A.S.C.D. main switch to "ON".
2. Turn A.S.C.D. main switch to "ON" again.
3. Step on brake pedal.
4. Step on clutch pedal (M/T) or shift in "N" range (A/T).
5. Check voltage between ⑤ and ③.




STOP LAMP CIRCUIT CHECK

1. Step on brake pedal.
2. Check voltage between ⑪ and ③.




SEL590Q



O.D. CANCEL CIRCUIT CHECK FOR A.S.C.D. CONTROL UNIT

1. Turn O.D. control switch to "ON"
2. Measure voltage across ⑫ and ③.




SEL591Q


DIAGNOSTIC PROCEDURE-7

A/T model only:

- When A.S.C.D. is set while vehicle is operating in "O.D." range, O.D. will be canceled and shifting to O.D. cannot be made thereafter.
- O.D. will not be canceled even if actual vehicle speed is 6 km/h (4 MPH) lower than set speed. (Set speed cannot be maintained.)
- O.D. will not be canceled even if accelerator switch is turned "ON".



AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)



Actuator Check

1. Disconnect A.S.C.D. actuator/A.S.C.D. pump connector.
2. Check A.S.C.D. actuator/A.S.C.D. pump operations as shown.

A

Check to see if motor starts when 12V D.C. is applied across ① and ④.

N.G.

Replace A.S.C.D. pump.

O.K.

B

Check to see if A.S.C.D. wire is pulled when 12V D.C. is applied across ①, ②, ③ and ④.

N.G.

Disconnect vacuum hose from A.S.C.D. actuator and check for presence of vacuum pressure at A.S.C.D. pump.

O.K. (Wire is pulled.)

N.G.

Replace A.S.C.D. actuator.

O.K.

C

Check to see if A.S.C.D. wire returns to original position 50 to 60 seconds after disconnecting lead from ④.

N.G.

Replace A.S.C.D. pump.

O.K. (Wire does not return.)

D





Disconnect lead from ① to see if A.S.C.D. wire returns immediately.

N.G.

Replace A.S.C.D. pump.


O.K. (Wire returns.)

A.S.C.D. actuator/A.S.C.D. pump are O.K.



LOCATION OF ELECTRICAL UNITS


Engine Compartment



SEL318N

LOCATION OF ELECTRICAL UNITS


Passenger Compartment



SEL319N

LOCATION OF ELECTRICAL UNITS

Luggage Compartment




HARNESS LAYOUT

NOTE

HARNESS LAYOUT


Outline




HARNESS LAYOUT

Engine Room Harness

PASSENGER COMPARTMENT




Diode (E108)



HARNESS LAYOUT

Engine Room Harness (Cont'd)

ENGINE COMPARTMENT



HARNESS LAYOUT

Engine Room Harness (Cont'd)

E1 : To (F1)	E28 : Headlamp L.H.
E2 : To (F2)	E29 : Dual-pressure switch
E3 : Actuator (For anti-lock brake system)	E30 : Body ground
E4 : Washer sensor	E31 : Wiper relay
E5 : Washer motor	E32 : Bulb check relay
E6 : Body ground	E33 : Interlock relay (M/T model for U.S.A.)
E7 : Alternator	E34 : Fuel pump relay
E8 : Radiator fan relay-1	E35 : Blower relay
E9 : Horn relay	E36 : To (A1)
E10 : Cornering lamp relay	E37 : To (A2)
E11 : Inhibitor relay (A/T model)	E38 : To (A3)
E12 : Air conditioner relay	E39 : Front combination lamp L.H.
E13 : Radiator fan relay-2	E40 : Front turn signal lamp L.H.
E14 : Radiator fan relay-3	E41 : Cornering lamp L.H.
E15 : A.S.C.D. hold relay	E42 : E.C.S.S. relay
E16 : Cornering lamp R.H.	E43 : Fusible link box
E17 : Front turn signal lamp R.H.	E44 : Battery
E18 : Front combination lamp R.H.	E45 : Fusible link
E19 : Headlamp R.H.	E46 : Joint connector-1
E20 : Body ground	E47 : Joint connector-2
E21 : Compressor	E48 : Joint connector-3
E22 : Radiator fan motor-1	E49 : Joint connector-4
E23 : Radiator fan motor-2	E50 : A.S.C.D. pump
E24 : Exhaust gas sensor	E51 : Front sensor L.H.
E25 : Horn R.H.	(For anti-lock brake system)
E26 : Horn ground	E52 : Body ground (For anti-lock brake system)
E27 : Horn L.H.	E53 : Brake fluid level switch

HARNESS LAYOUT

Main Harness



HARNESS LAYOUT

Main Harness (Cont'd)


Engine compartment

(M51) : Front sensor R.H. (For anti-lock brake system)

(M52) : Body ground (For anti-lock brake system)

(M53) : Power steering oil pressure switch

(M54) : Wiper motor



(R1) : Fuse block

(R2) : Power window relay

(R3) : To (D1)

(R4) : To (D2)

(R5) : To (D3)

(R6) : Diode

(R7) : Time control unit

(R8) : Rear window defogger relay

(R9) : To (I1) (S.M.J.)

(R10) : To (E102)

(R11) : To (E103)

(R12) : To (E104) (S.M.J.)

(R13) : Circuit breaker-1

(R14) : Circuit breaker-2

(R15) : Front limit switch L.H. (For U.S.A.)

(R16) : A.S.C.D. clutch switch

(R17) : A.S.C.D. cancel switch

(R18) : Stop lamp switch

(R19) : Combination flasher unit

(R20) : Mode door motor

(R21) : A.S.C.D. control unit

(R22) : Check connector

(R23) : To (F51)

(R24) : To (F52)

(R25) : To (F53)

(R26) : Ash tray illumination

(R27) : Cigarette lighter (For Canada)

(R28) : Cigarette lighter (For U.S.A.)

(R29) : Automatic seat belt control unit (For U.S.A.)

(R30) : Thermo control amp

(R31) : Resistor

(R32) : Push control unit

(R33) : Fan switch

(R34) : Fresh vent control illumination

(R35) : Cassete deck

(R36) : Radio

(R37) : Intake door motor

(R38) : To (R1) (For U.S.A.)

(R39) : To (R2) (For Canada)

(R40) : Body ground

(R41) : Body ground

(R42) : Blower motor

(R43) : Door lock timer


(R44) : To (D32)

(R45) : To (D31)

(R46) : A/C switch

HARNESS LAYOUT

Main Harness (Cont'd)



HARNESS LAYOUT

Main Harness (Cont'd)


Rear sensor harness (For anti-lock brake system)

- (M101) : Rear limit switch and shoulder belt buckle switch R.H.
(For U.S.A.)
- (M102) : To (071)
- (M103) : Drive motor R.H. (For U.S.A.)
- (M104) : Front door switch R.H. (For U.S.A.)
- (M105) : Front door switch R.H. (For Canada)
- (M106) : Overdrive switch and A/T indicator illumination
(A/T model)
- (M107) : Shift lock solenoid and detention switch (A/T model)
- (M108) : A/T mode switch
- (M109) : Parking brake switch
- (M110) : Lap belt buckle switch (For U.S.A.)
Seat belt switch (For Canada)
- (M111) : Front door switch L.H. (For Canada)
- (M112) : Front door switch L.H.
- (M113) : Drive motor L.H. (For U.S.A.)
- (M114) : To (051)
- (M115) : Rear limit switch and shoulder belt buckle switch L.H.
(For U.S.A.)
- (M116) : To (M15) (For anti-lock brake system)
- (M117) : Fuel tank gauge unit
- (M118) : Rear door switch L.H.
- (M119) : Rear window defogger
- (M120) : Body ground
- (M121) : To (T1)
- (M122) : Body ground (For anti-lock brake system)
- (M123) : Anti-lock brake system control unit

- (M151) : To (M119)
- (M152) : Rear sensor R.H.
- (M153) : Rear sensor L.H.



HARNESS LAYOUT

E.F.I. Harness




HARNESS LAYOUT

E.F.I. Harness (Cont'd)




HARNESS LAYOUT

Instrument Harness




Room Lamp and Sun Roof Harness



HARNESS LAYOUT

Door Harness (L.H. side)


FRONT DOOR HARNESS



- D1 : To M3
- D2 : To M4
- D3 : To M5
- D4 : Door speaker
- D5 : Door mirror
- D6 : Main switch
- D7 : Power window amp
- D8 : Main switch illumination
- D9 : Power window regulator

- D10 : Door latch switch (For U.S.A.)
- D11 : Door lock knob switch
- D12 : Door actuator

REAR DOOR HARNESS




- D51 : To M114
- D52 : Sub-switch
- D53 : Power window regulator
- D54 : Door actuator

SEL329N


HARNESS LAYOUT

Door Harness (R.H. side)

FRONT DOOR HARNESS




REAR DOOR HARNESS



SEL584Q


HARNESS LAYOUT

Engine Harness No. 2



HARNESS LAYOUT

Tail Harness




Body ground

- (T1) : To (M12)
- (T2) : Body ground
- (T3) : Rear speaker L.H.
- (T4) : High-mounted stop lamp
- (T5) : Trunk room lamp
- (T6) : Rear speaker R.H.
- (T7) : Rear door switch R.H.
- (T8) : Trunk room lamp switch
- (T9) : Power antenna timer
- (T10) : Power antenna motor
- (T11) : Rear combination lamp L.H.
- (T12) : Rear side marker L.H.
- (T13) : License lamp L.H.
- (T14) : License lamp R.H.
- (T15) : Rear combination lamp R.H.
- (T16) : Rear side marker R.H.

SEL332N

SUPER MULTIPLE JUNCTION (S.M.J.)



INSTALLATION


To install S.M.J., tighten bolts until orange "fulltight" mark appears and then retighten to specified torque as required.

☐: 3 - 5 N·m

(0.3 - 0.5 kg-m, 2.2 - 3.6 ft-lb)

CAUTION:

Do not overtighten bolts, otherwise, they may be damaged.



SUPER MULTIPLE JUNCTION (S.M.J.)

Terminal Arrangement

MAIN HARNESS

J1	J2	J3	J4	J5	J6	J7	J8	J9	J10	J11	J12
H1	H2	H3	H4	H5	H6	H7	H8	H9	H10	H11	H12
G1	G2	G3	G4	G5	G6	G7	G8	G9	G10	G11	G12
F1	F2					F11	F12				
E1	E2					E11	E12				
D1	D2					D11	D12				
C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12
B1	B2	B3	B4	B5	B6	B7	B8	B9	B10	B11	B12
A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12

K1	L1	M1	N1	P1	Q1
K2	L2	M2	N2	P2	Q2
K3	L3	M3	N3	P3	
K4	L4	M4		P4	Q4
K5	L5	M5		P5	Q5
K6					Q6
K7					Q7
K8					Q8
K9					Q9
K10					Q10
K11					Q11
K12	L12	M12		P12	Q12
K13	L13	M13	N14	P13	Q13
K14	L14	M14		P14	
K15	L15	M15	N15	P15	Q15
K16	L16	M16	N16	P16	Q16



A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12
B1	B2	B3	B4	B5	B6	B7	B8	B9	B10	B11	B12
C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12
D1	D2					D11	D12				
E1	E2					E11	E12				
F1	F2					F11	F12				
G1	G2	G3	G4	G5	G6	G7	G8	G9	G10	G11	G12
H1	H2	H3	H4	H5	H6	H7	H8	H9	H10	H11	H12
J1	J2	J3	J4	J5	J6	J7	J8	J9	J10	J11	J12

K16	L16	M16	N16	P16	Q16
K15	L15	M15	N15	P15	Q15
K14	L14	M14	N14	P14	
K13	L13	M13	N14	P13	Q13
K12	L12	M12		P12	Q12
K11					Q11
K10					Q10
K9					Q9
K8					Q8
K7					Q7
K6					Q6
K5	L5	M5		P5	Q5
K4	L4	M4	N3	P4	Q4
K3	L3	M3	N2	P3	
K2	L2	M2	N2	P2	Q2
K1	L1	M1	N1	P1	Q1

ENGINE ROOM HARNESS

INSTRUMENT HARNESS

E. C. C. S. CONTROL UNIT

101	102	103	104	105	106	107	108	1	2	3	4	5	6	7	○	15	16	17	18	19	20	21	22	31	32	33	34	35	36	37	38	39
109	110	111	112	113	114	115	116	8	9	10	11	12	13	14		23	24	25	26	27	28	29	30	40	41	42	43	44	45	46	47	48



View from harness side


A/T CONTROL UNIT

1	2	3	4	9	10	11	12	13	14	15	○	23	24	25	26	27	28	29	30	31	32	33	34	35
5	6	7	8	16	17	18	19	20	21	22		36	37	38	39	40	41	42	43	44	45	46	47	48


View from harness side

JOINT CONNECTOR (J/C)


Location



Terminal Arrangement



1992 NISSAN STANZA CIRCUIT DIAGRAM



INCH TO METRIC CONVERSION TABLE

(Rounded-off for automotive use)

inches	mm	inches	mm
.100	2.54	.610	15.49
.110	2.79	.620	15.75
.120	3.05	.630	16.00
.130	3.30	.640	16.26
.140	3.56	.650	16.51
.150	3.81	.660	16.76
.160	4.06	.670	17.02
.170	4.32	.680	17.27
.180	4.57	.690	17.53
.190	4.83	.700	17.78
.200	5.08	.710	18.03
.210	5.33	.720	18.29
.220	5.59	.730	18.54
.230	5.84	.740	18.80
.240	6.10	.750	19.05
.250	6.35	.760	19.30
.260	6.60	.770	19.56
.270	6.86	.780	19.81
.280	7.11	.790	20.07
.290	7.37	.800	20.32
.300	7.62	.810	20.57
.310	7.87	.820	20.83
.320	8.13	.830	21.08
.330	8.38	.840	21.34
.340	8.64	.850	21.59
.350	8.89	.860	21.84
.360	9.14	.870	22.10
.370	9.40	.880	22.35
.380	9.65	.890	22.61
.390	9.91	.900	22.86
.400	10.16	.910	23.11
.410	10.41	.920	23.37
.420	10.67	.930	23.62
.430	10.92	.940	23.88
.440	11.18	.950	24.11
.450	11.43	.960	24.38
.460	11.68	.970	24.64
.470	11.94	.980	24.89
.480	12.19	.990	25.15
.490	12.45	1.000	25.40
.500	12.70	2.000	50.80
.510	12.95	3.000	76.20
.520	13.21	4.000	101.60
.530	13.46	5.000	127.00
.540	13.72	6.000	152.40
.550	13.97	7.000	177.80
.560	14.22	8.000	203.20
.570	14.48	9.000	228.60
.580	14.73	10.000	254.00
.590	14.99	20.000	508.00
.600	15.24		

METRIC TO INCH CONVERSION TABLE

(Rounded-off for automotive use)

mm	inches	mm	inches
1	.0394	51	2.008
2	.079	52	2.047
3	.118	53	2.087
4	.157	54	2.126
5	.197	55	2.165
6	.236	56	2.205
7	.276	57	2.244
8	.315	58	2.283
9	.354	59	2.323
10	.394	60	2.362
11	.433	61	2.402
12	.472	62	2.441
13	.512	63	2.480
14	.551	64	2.520
15	.591	65	2.559
16	.630	66	2.598
17	.669	67	2.638
18	.709	68	2.677
19	.748	69	2.717
20	.787	70	2.756
21	.827	71	2.795
22	.866	72	2.835
23	.906	73	2.874
24	.945	74	2.913
25	.984	75	2.953
26	1.024	76	2.992
27	1.063	77	3.031
28	1.102	78	3.071
29	1.142	79	3.110
30	1.181	80	3.150
31	1.220	81	3.189
32	1.260	82	3.228
33	1.299	83	3.268
34	1.339	84	3.307
35	1.378	85	3.346
36	1.417	86	3.386
37	1.457	87	3.425
38	1.496	88	3.465
39	1.535	89	3.504
40	1.575	90	3.543
41	1.614	91	3.583
42	1.654	92	3.622
43	1.693	93	3.661
44	1.732	94	3.701
45	1.772	95	3.740
46	1.811	96	3.780
47	1.850	97	3.819
48	1.890	98	3.858
49	1.929	99	3.898
50	1.969	100	3.937

QUICK REFERENCE CHART : STANZA 1992

ENGINE TUNE-UP DATA

Engine model	KA24E		
Firing order	1-3-4-2		
Idle speed rpm	700±50, 750±50*		
M/T			
A/T (in "N" position)	700±50, 750±50*		
Ignition timing (degree B.T.D.C. at idle speed)	15±2		
Idle "CO" (% at idle speed)	Idle mixture screw is preset and sealed at factory.		
High tension cable resistance kΩ/m (kΩ/ft)	Less than 30 (9.14)		
Spark plug			
Standard	ZFR5E-11		
Type	Hot	ZFR4E-11	
	Cold	ZFR6E-11	
Gap mm (in)	1.0 - 1.1 (0.039 - 0.043)		
Drive belt deflection (Cold) mm (in)	Used belt deflection		Deflection of new belt
	Limit	Deflection after adjustment	
Alternator	8 (0.31)	6 - 7 (0.24 - 0.28)	5 - 6 (0.20 - 0.24)
Air conditioner compressor	8 (0.31)	5 - 6 (0.20 - 0.24)	4 - 5 (0.16 - 0.20)
Applied pressed force N (kg, lb)	98 (10, 22)		
Tightening torque	N-m	kg-m	ft-lb
Spark plug	20 - 29	2.0 - 3.0	14 - 22
Oil pan drain plug	29 - 39	3.0 - 4.0	22 - 29

* For Canada

BRAKE

Unit: mm (in)

Disc brake	
Pad minimum thickness	2.0 (0.079)
Rotor repair limit	
Minimum thickness	20.0 (0.787)*1, 9.0 (0.354)*2
Drum brake	
Lining minimum thickness	1.5 (0.059)
Drum repair limit	
Maximum inner diameter	230.0 (9.06)

*1 Front disc brake

*2 Rear disc brake

REFILL CAPACITIES

Unit	Liter	US measure
Fuel tank	62	16-3/8 gal
Coolant	7.4	7-7/8 qt
Engine	With oil filter	3.5
	Without oil filter	3.1
Transaxle	M/T	4.7
	A/T	6.8
Power steering system	0.9	1 qt
Air conditioning system	Compressor oil	0.2
	Refrigerant	0.75 - 0.85
		1.65 - 1.87 lb

CLUTCH PEDAL

Unit: mm (in)

Pedal height	165 - 175 (6.50 - 6.89)
Pedal free play	1 - 3 (0.04 - 0.12)

FRONT WHEEL ALIGNMENT (Unladen*)

Camber	degree	-30' to 1°00'
Caster	degree	35' - 2°05'
Kingpin inclination	degree	13°45' - 15°15'
Toe-in		
A - B	mm (in)	1 - 3 (0.04 - 0.12)
Total angle 2θ	degree	6' - 18'
Turning angle		
Inside		34° - 38°
Outside		27° - 31°

* Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

REAR WHEEL ALIGNMENT (Unladen*)

Camber	degree	-1°20' to 0°10'
Toe-in		
A - B	mm (in)	-4 to 0 (-0.16 to 0)
Total angle 2θ	degree	-23' to 0'

* Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.



NISSAN MOTOR CO., LTD.

Overseas Service Department

Tokyo, Japan

Edition: July 1991

Printing: July 1991 (05)

Publication No. SM2E-0U12U0

Printed in Japan