

SECTION **BR**

BRAKE SYSTEM

PRECAUTIONS	3
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3
Precautions for Brake System	3
PREPARATION	4
Special Service Tools	4
Commercial Service Tools	4
NOISE, VIBRATION, AND HARSHNESS (NVH)	
TROUBLESHOOTING	5
NVH Troubleshooting Chart	5
BRAKE PEDAL	6
On-Vehicle Inspection and Adjustment	6
Components	7
Removal and Installation	7
REMOVAL	7
INSPECTION AFTER REMOVAL	7
INSTALLATION	8
BRAKE FLUID	9
Checking Brake Fluid Level	9
Checking Brake Line	9
Changing Brake Fluid	9
Brake Burnishing Procedure	10
Bleeding Brake System	10
BRAKE PIPING AND HOSE	11
Hydraulic Piping	11
Removal and Installation of Front Brake Piping and Brake Hose	11
REMOVAL	11
INSTALLATION	11
Removal and Installation of Rear Brake Piping and Brake Hose	12
REMOVAL	12
INSTALLATION	12
Inspection	12
BRAKE MASTER CYLINDER	13
Components	13
Removal and Installation	13
REMOVAL	13

INSTALLATION	13
Disassembly and Assembly	14
DISASSEMBLY	14
INSPECTION AFTER REMOVAL	14
ASSEMBLY	15
BRAKE BOOSTER	17
On-Vehicle Inspection and Service	17
FUNCTION INSPECTION	17
AIRTIGHTNESS INSPECTION	17
Removal and Installation	17
REMOVAL	17
INSPECTION AFTER REMOVAL	18
INSTALLATION	18
VACUUM LINES	19
Removal and Installation	19
Inspection	19
VISUAL INSPECTION	19
CHECK VALVE INSPECTION	20
FRONT DISC BRAKE	21
Component	21
Inspection	21
PAD THICKNESS	21
Pad Replacement	22
REMOVAL	22
INSTALLATION	22
Caliper Removal and Installation	22
REMOVAL	22
INSTALLATION	23
Caliper Disassembly and Assembly	23
DISASSEMBLY	23
INSPECTION AFTER DISASSEMBLY	23
DISC ROTOR INSPECTION	24
ASSEMBLY	24
BRAKE BURNISHING PROCEDURE	25
REAR DISC BRAKE	26
Component	26
Inspection	26
PAD WEAR INSPECTION	26
Pad Replacement	27
REMOVAL	27

INSTALLATION	27	SERVICE DATA AND SPECIFICATIONS (SDS)	32
Caliper Removal and Installation	28	General Specifications	32
REMOVAL	28	Brake Pedal	32
INSTALLATION	28	Check Valve	32
Caliper Disassembly and Assembly	28	Brake Booster	32
DISASSEMBLY	28	Front Disc Brake	32
INSPECTION AFTER DISASSEMBLY	29	Rear Disc Brake	33
DISC ROTOR INSPECTION	29		
ASSEMBLY	30		

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EFS002F9

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Precautions for Brake System

EFS000BZ

- Clean dust on brake pads, shoes, drums, and back plates with a vacuum dust collector. Do not blow with compressed air.
- Recommended fluid is brake fluid "DOT 3" or "DOT 4".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas such as the body. If brake fluid is splashed or spilled on paint, wipe it off and flush the area with water immediately.
- Use only clean brake fluid when cleaning master cylinder and disc brake components.
- Never use mineral oils such as gasoline or kerosene to clean. They will ruin the rubber parts and cause improper operation.
- Always use a flare nut torque wrench to securely tighten brake tube flare nuts.
- The brake system is an important safety part. If a brake fluid leak is detected, always disassemble the related parts. If damage, deformation or excessive wear is detected, replace affected parts with new ones.
- Before starting operation, be sure to turn the ignition switch OFF and disconnect the ABS actuator and control module connector or battery cables.
- When installing brake piping, be sure to check torque.




PREPARATION

PREPARATION

PFP:00002


Special Service Tools

EFS00217

Tool number Tool name	Description
GG94310000 Flare nut torque wench a: 10 mm (0.39 in)	 Removing and installing brake piping

Commercial Service Tools

EFS00218

Tool name	Description
Brake fluid pressure gauge	 Measuring fluid pressure

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

EFS000TK

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		Pads - damaged	Pads - uneven wear	Shims damaged	Rotor imbalance	Rotor damage	Rotor runout	Rotor deformation	Rotor deflection	Rotor rust	Rotor thickness variation	Drum out of round	PROPELLER SHAFT	DIFFERENTIAL	AXLE AND SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	STEERING
Possible cause and SUSPECTED PARTS																			
Symptom	BRAKE	Noise	×	×									×	×	×	×	×	×	
		Shake			×								×	×	×	×	×	×	
		Shimmy, Judder				×	×	×	×	×	×								

X: Applicable

A
B
C
D
E
F
G
H
I
J
K
L
M
BR

BRAKE PEDAL


BRAKE PEDAL

PFP:46501

On-Vehicle Inspection and Adjustment

EFS000C1

Adjust clearance between dash panel and brake pedal upper surface to the following dimensions.



H1	Brake pedal height	M/T model	156 - 166 mm (6.10 - 6.54 in)
		A/T model	164 - 174 mm (6.46 - 6.85 in)
H2	Pedal height when depressed [With engine running and at depression force of 490 N (50 kg, 110.6 lb)]	M/T model	80 mm (3.15 in) or more
		A/T model	85 mm (3.35 in) or more
C	Clearance between stopper rubber and threaded end of the stop lamp switch	0.74 - 1.96 mm (0.0291 - 0.0772 in)	
A	Pedal play	3 - 11 mm (0.12 - 0.43 in)	

1. Loosen stop lamp switch by rotating it counter-clockwise by 45°.
2. Loosen input rod lock nut (A), then rotate input rod, set pedal to the specified height, and tighten lock nut (A).

CAUTION:

Confirm threaded end of input rod remains inside the clevis.



: 16 - 21 N·m (1.6 - 2.2 kg-m, 12 - 15 ft-lb)

3. Pull pedal by hand and hold it. Press stop lamp switch until its threaded end contacts the stopper rubber.
4. While holding it against the stopper rubber, turn the switch clockwise by 45° and secure it.

CAUTION:


Be sure stopper rubber to stop lamp switch screw threaded end gap (C) is within specifications.

5. Check pedal free play.
6. Start the engine and check brake pedal depressed height.



Components

EFS001CI



1. Snap pin
2. Stop lamp switch
3. Brake pedal assembly
4. Clevis pin


Removal and Installation

REMOVAL

EFS000C2

Be careful not to deform brake tube.

1. Remove the instrument lower drive panel.
2. Remove stop lamp switch from brake pedal assembly.
3. Remove snap pin and clevis pin from brake booster clevis.
4. Remove brake pedal assembly mounting nuts. Pull brake booster toward the engine compartment. Be careful not to deform the brake tube.
5. Remove brake booster clevis from input rod.
6. Remove steering column assembly from steering member.
7. Push brake pedal assembly toward the right. When removing it, avoid the steering post bracket stay.




INSPECTION AFTER REMOVAL

Check brake pedal for the following.

- Bent brake pedal
- Deformed clevis pin
- Cracks in welded area

BRAKE PEDAL

- Cracked or deformed clevis pin stopper



INSTALLATION

Install in reverse order of removal. Be careful of the following:

- Adjust brake pedal assembly after installing it.


BRAKE FLUID

PFP:KN100

Checking Brake Fluid Level

EFS000C5

- Confirm reservoir tank fluid level is within specifications (between MAX and MIN lines).
- Visually check around reservoir tank for fluid leaks.
- If fluid level is excessively low, check brake system for leaks.
- If warning lamp remains illuminated after parking lever is released, check brake system for fluid leakage.



SFIA0066J


Checking Brake Line

EFS001C5

CAUTION:

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

1. Check brake line (tube and hoses) for cracks, deterioration or other damage. Replace and damaged parts.
2. Check for oil leakage by fully depressing brake pedal while engine is running.



SBR389C


Changing Brake Fluid

EFS000C3

CAUTION:

- Refill with new brake fluid "DOT 3 or DOT 4".
- Always keep fluid level higher than minimum line on reservoir tank.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on spill or splash on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away water immediately.


1. Connect a vinyl tube to the air bleeder.
2. Drain brake fluid gradually from the air bleeder of each wheel while depressing the brake pedal.
3. Turn OFF ignition switch. Remove ABS actuator connector.



BRA0007D

BRAKE FLUID

4. Be sure there is no foreign material in reservoir tank. Refill with new brake fluid.
5. Connect a vinyl tube to the air bleeder.
6. Rest foot on brake pedal. Loosen air bleeder. Slowly depress pedal until it stops. Tighten air bleeder. Release brake pedal. Repeat this process a few times, then pause to add new brake fluid to master cylinder. Continue until new brake fluid flows out. For bleeding procedure. Refer to [BR-10, "Bleeding Brake System"](#).



BRA0006D

EFS001C8

Brake Burnishing Procedure

Burnish the brake contact surfaces according to the following procedure after refinishing or replacing drums or rotors, after replacing pads or linings, or if a soft pedal occurs at very low mileage.

CAUTION:

Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive the vehicle on a straight smooth road at 50 km/h (31 MPH).
2. Use medium brake pedal/foot effort to bring the vehicle to a complete stop from 50 km/h (31 MPH). Adjust brake pedal/foot pressure such that vehicle stopping time equals 3 to 5 seconds.
3. To cool the brake system, drive the vehicle at 50 km/h (31 MPH) for 1 minute without stopping.
4. Repeat steps 1 to 3, 10 times or more to complete the burnishing procedure.

Bleeding Brake System

EFS000C4

CAUTION:

- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- Fill reservoir with new brake fluid "DOT 3" or "DOT 4". Make sure it is full at all times while bleeding air out of system.
- Place a container under master cylinder to avoid spillage of brake fluid.
- While bleeding, pay attention to master cylinder fluid level.
- For models with ABS, turn ignition switch OFF and disconnect ABS actuator connectors or battery ground cable.
- Bleed air in the following order.

Right rear brake, Left front brake, Left rear brake, Right front brake

1. Turn OFF ignition switch. Remove ABS actuator connector.
2. Connect a vinyl tube to the air bleeder.
3. Fully depress the brake pedal 4 to 5 times.
4. With brake pedal depressed, loosen air bleeder and bleed air.
5. Close air bleeder.
6. Slowly release brake pedal.
7. Tighten air bleeder to the specified torque.



: 6.9 - 8.8 N·m (0.7 - 0.9 kg·m, 61- 78 in-lb)


8. Repeat steps 2 - 7. Occasionally refill master cylinder reservoir tank. Be sure to keep it at least half-full.

BRAKE PIPING AND HOSE

PFP:46210

Hydraulic Piping

EFS000C6



Removal and Installation of Front Brake Piping and Brake Hose


EFS000C7

REMOVAL

CAUTION:

- Do not allow brake fluid to spill or splash on painted surfaces. Brake fluid can seriously damage paint. If it gets on a painted surface, wipe it off immediately and wash with water.
- Do not bend or twist the brake hose sharply, or strongly pull it.
- Cover brake fluid line connections to prevent dust and other foreign material from entering.

- Connect a vinyl tube to the air bleeder.
- Drain brake fluid gradually from the air bleeder of each wheel while depressing the brake pedal.
- Using a flare nut wrench, remove brake tube flare nuts and disconnect brake tube from the brake hose.
- Remove union bolts and disconnect caliper assembly from the brake hose.
- First remove lock spring from brake tube and strut mounting positions. Then remove brake hose.



INSTALLATION

CAUTION:

- Refill with new brake fluid "DOT 3" or "DOT4".
- Never reuse drained brake fluid.

- Connect brake hose to caliper assembly and tighten union bolts to the specified torque.

CAUTION:

- Securely connect brake hose to the protrusions on the cylinder body.
- Do not reuse the copper washer for union bolts.

- Connect brake hose to the strut and fix with lock spring.
- Connect brake hose to the brake tube. Temporarily tighten flare nuts by hand as far as they will go. Secure them with the lock spring.
- Using a flare nut torque wrench, tighten to the specified torque.

BRAKE PIPING AND HOSE

 : 15 - 17 N·m (1.5 - 1.8 kg·m, 11 - 13 ft·lb)

5. Refill brake fluid until new brake fluid comes out of each air bleeder.
6. Afterwards, bleed air.

Removal and Installation of Rear Brake Piping and Brake Hose


REMOVAL

EFS000C8

CAUTION:

- Do not allow brake fluid to spill or splash on painted surfaces. Brake fluid can seriously damage paint. If it gets on a painted surface, wipe it off immediately and wash with water.
- Do not bend or twist the brake hose sharply, or strongly pull it.
- Cover brake fluid line connections to prevent dust and other foreign material from entering.

1. Connect a vinyl tube to the air bleeder.
2. Drain brake fluid gradually from the air bleeder of each wheel while depressing the brake pedal.
3. Using a flare nut wrench, remove brake tube flare nuts and disconnect brake tube from the brake hose.
4. Remove lock spring.



INSTALLATION


CAUTION:

- Refill with new brake fluid "DOT 3" or "DOT 4".
- Never reuse drained brake fluid.

1. Connect brake hose to the brake tube. Temporarily tighten flare nut by hand as far as it will go.
2. Fix brake hose by lock plate.
3. Tighten flare nut of brake tube by using a flare nut wrench with specified torque.

 : 15 - 17 N·m (1.5 - 1.8 kg·m, 11 - 13 ft·lb)

4. Refill brake fluid until new brake fluid comes out of each air bleeder.
5. Afterwards, bleed air.



Inspection

EFS000C9

CAUTION:

If any connection leaks, retighten it. Replace any damaged parts.

1. Check hose, tube, and connections for fluid leaks, damage, twist, deformation, contact with other parts, and loose connections.
2. Run the engine. Depress brake pedal and hold it for approximately 5 seconds while checking each part for leaks.


BRAKE MASTER CYLINDER

BRAKE MASTER CYLINDER

PFP:46010

Components

EFS000CB



1. Cap
2. Strainer
3. Reservoir tank
4. Grommet
5. Piston stopper
6. Pin
7. Secondary piston
8. Primary piston assembly
9. Stopper cap

Removal and Installation

EFS001CG

REMOVAL

CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

1. Drain brake fluid.
2. Remove fluid level sensor harness connector.
3. Using a flare nut wrench, disconnect master cylinder assembly and brake tube.
4. First remove master cylinder assembly mounting nuts. Then remove master cylinder assembly.

INSTALLATION

1. Connect brake tube to master cylinder assembly and temporarily tighten flare nut by hand.
2. Connect master cylinder assembly to brake booster assembly and tighten mounting nuts to the specified torque.
3. Tighten brake tube flare nuts.

: 15 - 17 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

4. Connect fluid level sensor harness connector.
5. Refill with new brake fluid and bleed air from the brake piping.

BRAKE MASTER CYLINDER

Disassembly and Assembly


DISASSEMBLY

EFS001CH

CAUTION:

Remove master cylinder reservoir tank only when necessary.


1. Using a slotted screwdriver as shown in the figure, lever stopper cap tabs up and remove stopper cap. While removing, be sure to hold cap securely to prevent the master cylinder piston from popping out.




2. Secure cylinder body flange in a vise as shown in the figure.

CAUTION:


- Secure with chamfered pin insert hole on the cylinder body facing upward.
- When securing in the vise, use copper plates or cloth to protect the flange.



3. Using a pin punch [tool: diameter Approx. 4 mm (0.16 in)], remove reservoir tank mounting pins.
4. Remove master cylinder assembly from the vise.
5. Remove reservoir tank and grommet from the cylinder body.



6. Using a Phillips screwdriver, press and hold piston pin as shown in the figure. Remove piston stopper from the cylinder body.
7. Carefully pull primary piston assembly straight out to prevent damage to the cylinder inner wall.
8. Tap flange against a wood block to loosen secondary piston assembly. Carefully pull secondary piston assembly straight out to prevent damage to the cylinder inner wall.



INSPECTION AFTER REMOVAL

- Check cylinder inner wall for damage, wear, corrosion, and pinholes. Replace cylinder if damage, wear, or corrosion is detected.

BRAKE MASTER CYLINDER

ASSEMBLY


CAUTION:

- Never use mineral oils such as kerosene or gasoline during the cleaning and assembly processes.
- Be sure there is no foreign material on the cylinder inner wall, piston, and cup seal. Be careful not to damage parts with a service tool during assembly.
- Do not drop the parts. Do not use any dropped parts.


1. Apply brake fluid to the inner wall of cylinder body and contact surface of the piston assembly. Then insert secondary piston assembly and primary piston assembly into cylinder body in this order.

CAUTION:

- Do not reuse primary and secondary piston assemblies.
- Always replace the inner kit as an assembly.
- Pay attention to orientation of the piston cup. Insert it straight in order to prevent it from catching on the cylinder's inner wall.



2. Visually check secondary piston slit position through cylinder body secondary tank boss hole and install piston stopper.



3. Hold piston with stopper cap. Press stopper cap in until its tabs fully engage groove on the cylinder body.


CAUTION:

Do not reuse stopper cap.

4. Apply brake fluid to grommet before pressing it into cylinder body.

CAUTION:

Do not reuse grommet.




5. Secure cylinder body flange in a vise as shown in the figure.

CAUTION:

- Secure with chamfered pin insert hole on the cylinder body facing upward.
- When securing in the vise, use copper plates or cloth to protect the flange.

6. Install reservoir tank to the cylinder body. Tilt reservoir tank as shown in the figure and insert mounting pin. When mounting pin passes through pinhole in the master cylinder, return reservoir tank to the upright position. Push mounting pin all the way through the opposite pinhole in the reservoir tank.



CAUTION:

- Do not reuse reservoir tank mounting pin.

BRAKE MASTER CYLINDER

- Do not reuse reservoir tank.
- Be sure to insert pin from the chamfered pinhole on the cylinder body.


BRAKE BOOSTER

PFP:47200

On-Vehicle Inspection and Service
FUNCTION INSPECTION


EFS000CC

With the engine stopped, discharge stored vacuum by depressing brake pedal several times at 5 second intervals. With the brake pedal fully depressed, start the engine. Confirm that clearance between brake pedal and the floor panel decreases when engine vacuum stabilizes.



AIRTIGHTNESS INSPECTION


- Run the engine at idle for approximately 1 minute. Stop it after applying vacuum to the booster. Depress the brake pedal several times with normal force to discharge the stored vacuum. Confirm that clearance between brake pedal and the floor panel gradually increases as the brake pedal is depressed.
- Run the engine. Depress and hold the brake pedal then stop the engine. Keep the brake pedal depressed for 30 seconds or more and make sure the pedal stroke does not change.



Removal and Installation

REMOVAL

EFS000CD



CAUTION:

- Be careful not to deform or bend brake piping while removing and installing the brake booster.
- Replace clevis pin if it is damaged.
- Be careful not to damage brake booster stud bolt threads. If brake booster is tilted or inclined during installation, the dash panel may damage the threads.
- Be sure to install the check valve in the correct orientation.

- Remove vacuum piping from the brake booster.
- Remove master cylinder.
- Remove snap pin and clevis pin on passenger compartment clevis. Remove input rod from the brake pedal.
- Remove brake booster and brake pedal assembly mounting nuts.
- Remove booster assembly from the engine compartment.

A
B
C
D
E

BR

G
H

I

J

K
L

M

BRAKE BOOSTER


INSPECTION AFTER REMOVAL

Output rod length inspection

1. Using a handy vacuum pump, apply a vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg) to the brake booster.
2. Check output rod length.

Reference value at vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg):

10.4 mm (0.409 in)




INSTALLATION

1. Loosen lock nut to adjust input rod length so that length "B" (in the figure) satisfies the specified value.

Length "B" standard : 125 mm (4.92 in)

2. After adjusting B, temporarily tighten lock nut to install booster assembly to vehicle.
3. Connect brake pedal to input rod clevis.
4. Connect brake pedal assembly mounting nuts and tighten to the specified torque.
5. Connect master cylinder to the booster assembly.
6. Adjust brake pedal height and play.
7. Tighten input rod lock nut to the specified torque.
8. Bleed air. Refer to [BR-10, "Bleeding Brake System"](#) .




VACUUM LINES

PFP:41920

Removal and Installation

EFS000CE



SFIA0369E


1. Vacuum hose
4. Clamp

2. Vacuum tube

3. Clip

CAUTION:

- Because vacuum hose contains a check valve, it must be installed in the correct orientation. Refer to the stamp or label to confirm correct installation. The brake booster will not operate normally if the hose is installed in the wrong direction.
- Insert the vacuum hose for at least 24 mm (0.94 in).
- Never use lubricating oil during assembly.



SBR225B

Inspection

VISUAL INSPECTION

Check for improper assembly, damage and aging.

EFS000CF

VACUUM LINES

CHECK VALVE INSPECTION

Airtightness Inspection


Use a hand-held vacuum pump to check.

When connected to booster side (1):

Vacuum decrease should be within 1.3 kPa (10 mmHg, 0.39 inHg) for 15 seconds under a vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg)

When connected to engine side (2):

No vacuum will be applied




FRONT DISC BRAKE

FRONT DISC BRAKE

PFP:41000

Component

EFS000CG



SFIA0328E

1. Torque member	2. Slid pin boot	3. Slid pin
4. Outer shim cover	5. Outer shim	6. Outer pad
7. Pad retainer	8. Inner pad	9. Inner shim
10. Inner shim cover	11. Piston boots	12. Piston
13. piston seal	14. Cylinder body	15. Copper washer
16. Air bleeder	17. Brake hose union bolt	

WARNING:

- Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

CAUTION:


- When cylinder body is open, do not depress brake pedal because piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of the rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.
- Burnish the brake contact surfaces after refinishing or replacing drums or rotors, after replacing pads or linings, or if a soft pedal occurs at very low mileage. Refer to [BR-10, "Brake Burnishing Procedure"](#).

Inspection PAD THICKNESS

EES0000CH

Check pad thickness by lifting vehicle, removing the wheel, and looking through check hole on cylinder body. If necessary, use a scale.

Standard pad thickness : 11 mm (0.43 in)
Pad wear limit : 2.0 mm (0.079 in)



MAA0439D

FRONT DISC BRAKE


Pad Replacement REMOVAL

EFS000CI


CAUTION:

When replacing brake pads, always replace inner shims, outer shims, and shim covers as a set.

1. Remove master cylinder reservoir tank cap.
2. Remove lower sliding pin bolt.



3. Hang cylinder body with a wire, and remove pads, pad retainers, shims and pad return springs.



INSTALLATION

1. Apply brake grease on back of the pad and both sides of the shim. Install inner shim and inner shim cover to inner pad, outer shim to outer pad.
2. Apply brake grease on the pad retainer pad contact surface. Install pad retainers, pads and pad return springs to the torque member.
3. Connect cylinder body to the torque member.

CAUTION:

When replacing pads with new ones, press piston in until the pads can be installed. Carefully monitor brake master cylinder reservoir fluid level. Brake fluid will return, raising master cylinder reservoir tank fluid level.


4. Insert lower sliding pin bolt and tighten to the specified torque.
5. Check brakes for drag.

Caliper Removal and Installation

EFS000CJ

REMOVAL

1. Connect a vinyl tube to the air bleeder.
2. Drain brake fluid gradually from air bleeder while depressing brake pedal.
3. Remove union bolts and torque member mounting bolts, and remove caliper assembly.
4. Remove disc rotor.



INSTALLATION

CAUTION:

- Refill with new brake fluid “DOT 3” or “DOT 4”.
- Never reuse drained brake fluid.

1. Install disc rotor.
2. Install caliper assembly. Tighten mounting bolts to the specified torque.

CAUTION:

Before installing caliper assembly, wipe oil and grease on steering knuckle washer seats and caliper assembly mounting surface.

3. Connect brake hose to caliper assembly and tighten union bolts to the specified torque.

CAUTION:

- Do not reuse the copper washer for union bolts.
- Securely assemble brake hose to protrusions on cylinder body.

4. Bleed air. Refer to [BR-10, "Bleeding Brake System"](#) .

Caliper Disassembly and Assembly

DISASSEMBLY

EFS000CK

BR


WARNING:

Be careful not to pinch your fingers in the piston.


CAUTION:

Be careful not to damage the cylinder inner wall.

1. Place a wooden block as shown in the figure. Blow air into union bolt mounting hole to remove pistons and piston boots.



2. Using flat-bladed screwdriver, remove piston seals.



INSPECTION AFTER DISASSEMBLY

Cylinder Body

CAUTION:

Use new brake fluid to clean. Never use mineral oils such as gasoline or kerosene.

- Check cylinder inner wall for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the cylinder body.
- Minor flaws caused by corrosion or foreign material can be removed by polishing the surface with fine sandpaper. Replace the cylinder body, if necessary.

Torque Member

Check for wear, cracks and damage. If wear, cracks or damage is detected, replace the applicable part.

FRONT DISC BRAKE

Piston

CAUTION:

The piston sliding surface is plated. Do not polish with sandpaper.

Check piston surface for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the applicable part.

Sliding Pin, Pin Bolt, and Pin Boot

Check sliding pin and sliding pin boot for wear, damage and cracks. If corrosion, wear or damage is detected, replace the applicable part.

DISC ROTOR INSPECTION

Visual Inspection

Check surface of the disc rotor for uneven wear, cracks and serious damage. If uneven wear, cracks or serious damage is detected, replace it.

Run Out Inspection

1. Using wheel nuts, fix the disc rotor to the wheels hub. (2 or more positions)
2. Using a dial indicator, check run out.

Measurement point:


At a point 10 mm (0.39 in) from the outer edge of the disc.

Run out limit : 0.04 mm (0.0016 in) or less

CAUTION:

Before measuring, make sure that the axle endplay is 0 mm (0 in).

3. If the run out is outside the limit, find the minimum run out point by shifting the mounting positions of the disc rotor and wheel hub by one hole.



Thickness Inspection


Using a micrometer, check thickness of the disc rotor. If the thickness is outside the standard, replace the disc rotor.

Standard thickness : 28.0 mm (1.102 in)

Wear limit : 26.0 mm (1.024 in)

Maximum uneven wear (measured at 8 positions):

0.02 mm (0.0008 in) or less



ASSEMBLY


CAUTION:

When assembling, do not use rubber grease.

1. Apply rubber lubricant to piston seals, and install them to cylinder body.

CAUTION:

Do not reuse piston seals.




FRONT DISC BRAKE

2. Apply brake fluid or rubber lubricant to piston boots. Cover piston end with piston boot. Install cylinder side lip on piston boot properly into groove on cylinder body.

CAUTION:


Do not reuse piston boot.



3. Apply brake fluid to piston. Press piston into cylinder body by hand. Assemble piston side lip on piston boot properly into groove on piston.

CAUTION:

Press piston evenly and change pressing point to prevent cylinder inner wall from being rubbed.



BRAKE BURNISHING PROCEDURE

Burnish the brake contact surfaces according to the following procedure after refinishing or replacing drums or rotors, after replacing pads or linings, or if a soft pedal occurs at very low mileage.

CAUTION:

Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. **Drive the vehicle on a straight smooth road at 50 km/h (31 MPH).**
2. **Use medium brake pedal/foot effort to bring the vehicle to a complete stop from 50 km/h (31 MPH). Adjust brake pedal/foot pressure such that vehicle stopping time equals 3 to 5 seconds.**
3. **To cool the brake system, drive the vehicle at 50 km/h (31 MPH) for 1 minute without stopping.**
4. **Repeat steps 1 to 3, 10 times or more to complete the burnishing procedure.**


REAR DISC BRAKE

REAR DISC BRAKE

PFP:44000

Component

EFS0017X



SFIA0330E

1. Pad retainer	2. Outer shim cover	3. Outer shim
4. Outer pad	5. Pad retainer	6. Inner pad
7. Inner shim	8. Inner shim cover	9. Sliding pin boot
10. Sliding pin	11. Sliding pin bolt	12. Cylinder body
13. Copper washer	14. Brake hose	15. Union bolt
16. Copper washer	17. Air bleeder	18. Piston seal
19. Piston	20. Piston boot	21. Retaining ring
22. Torque member		

WARNING:

- Clean dust on brake caliper and pad with a vacuum dust collector. Do not blow with compressed air.

CAUTION:

- Never depress brake pedal while removing cylinder body because the piston will pop out.
- Do not remove brake hose and torque member mounting bolts unless disassembling or replacing caliper assembly. Hang the cylinder body with a wire so that the brake hose is not under tension.
- Be careful not to damage the piston boot. Do not allow brake fluid to get on the rotor.
- When replacing brake pads, always replace inner shims, outer shims, and shim covers as a set.


Inspection

PAD WEAR INSPECTION

EFS0017Y

Check pad thickness by lifting vehicle, removing the wheel, and looking through check hole on cylinder body. If necessary, use a scale.

standard thickness : 8.5 mm (0.335 in)
pad wear limit : 2.0 mm (0.079 in)



BRA0010D


Pad Replacement REMOVAL

EFS0017Z


CAUTION:

When replacing brake pads, always replace inner shims, outer shims, and shim covers as a set.

1. Remove master cylinder reservoir tank cap.
2. Remove lower sliding pin bolt.



3. Hang cylinder body with a wire, and remove pads, pad retainers, and shims.



INSTALLATION

1. Apply brake grease on back of the pad and both sides of the shim. Install inner shim and inner shim cover to inner pad, outer shim to outer pad.
2. Install pad retainers to torque member and install pads.
3. Connect cylinder body to the torque member.

CAUTION:

When replacing pads with new ones, press piston in until the pads can be installed. Carefully monitor brake master cylinder reservoir fluid level. Brake fluid will return, raising master cylinder reservoir tank fluid level.


4. Insert lower sliding pin bolt and tighten to the specified torque.
5. Check brakes for drag.

A
B
C
D
E
BR
G
H
I
J
K
L
M

Caliper Removal and Installation

REMOVAL

1. Connect a vinyl tube to the air bleeder.
2. Drain brake fluid gradually from air bleeder while depressing brake pedal.
3. Remove brake hose connected to caliper assembly and union bolts. Remove brake hose from caliper assembly.
4. Remove union bolts and torque member mounting bolts, and remove caliper assembly.
5. Remove disc rotor.



INSTALLATION

CAUTION:

- Refill with new brake fluid "DOT 3 or DOT 4".
- Never reuse drained brake fluid.

1. Install disc rotor.
2. Install caliper assembly. Tighten mounting bolts to the specified torque.

CAUTION:

Wipe oil and grease on axle assembly washer seats and caliper assembly mounting surface. Install caliper assembly.

3. Connect brake hose to caliper assembly and tighten union bolts to the specified torque.

CAUTION:

- Do not reuse the copper washer for union bolts.
- Securely assemble brake hose to protrusions on cylinder body.

4. Bleed air. Refer to [BR-10, "Bleeding Brake System"](#).

Caliper Disassembly and Assembly

DISASSEMBLY

EFS00181


WARNING:

Be careful not to pinch your fingers in the piston.

CAUTION:


Be careful not to damage the cylinder inner wall.

1. Remove caliper assembly from vehicle.
2. Remove sliding pin from cylinder body. Then remove pads, shims, shim covers, and pad retainers from caliper assembly.
3. Remove sliding pin boots from torque member.
4. Using flat-bladed screwdriver (as shown in the figure), remove retaining ring.




REAR DISC BRAKE

5. Place a wooden block as shown in the figure. Blow air into union bolt mounting hole to remove pistons and piston boots.



6. Using flat-bladed screwdriver, remove piston seals.



INSPECTION AFTER DISASSEMBLY

Cylinder Body

CAUTION:

Use new brake fluid to clean. Never use mineral oils such as gasoline or kerosene.

- Check cylinder inner wall for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the cylinder body.
- Minor flaws caused by corrosion or foreign material can be removed by polishing the surface with fine sandpaper. Replace the cylinder body, if necessary.

Torque Member

Check for wear, cracks and damage. If wear, cracks or damage is detected, replace the applicable part.

Piston

CAUTION:

The piston sliding surface is plated. Do not polish with sandpaper.

Check piston surface for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the applicable part.

Sliding Pin, Pin Bolt and Pin Boot

Check sliding pin and sliding pin boot for wear, damage and cracks. If corrosion, wear or damage is detected, replace the applicable part.

DISC ROTOR INSPECTION

Visual Inspection

Check surface of the disc rotor for uneven wear, cracks and serious damage. If uneven wear, cracks or serious damage is detected, replace it.

Run Out Inspection

- Using wheel nuts, fix the disc rotor to the wheels hub. (2 or more positions)

REAR DISC BRAKE

- Using a dial indicator, check run out.

Measurement point:


At a point 10 mm (0.39 in) from the outer edge of the disc.

Run out limit:

0.07 mm (0.0028 in) or less

CAUTION:

Before measuring, make sure that the axle endplay is 0 mm (0 in).



- If the run out is outside the limit, find the minimum run out point by shifting the mounting positions of the disc rotor and wheel hub by one hole.

Thickness Inspection


Using a micrometer, check thickness of the disc rotor. If the thickness is outside the standard, replace the disc rotor.

Standard thickness : 16.0 mm (0.630 in)

Wear limit : 14.0 mm (0.551 in)

Maximum uneven wear (measured at 8 positions):

0.02 mm (0.0008 in) or less




ASSEMBLY

CAUTION:

When assembling, do not use rubber grease.

- Apply rubber lubricant to piston seals, and install them to cylinder body.



- Apply brake fluid to piston boots. Cover piston end with piston boot. Install cylinder side lip on piston boot properly into groove on cylinder body.


CAUTION:

Do not reuse piston boot.

- Press piston into cylinder body by hand. Assemble piston side lip on piston boot properly into groove on the piston.

CAUTION:

Press piston evenly and change pressing point to prevent cylinder inner wall from being rubbed.




REAR DISC BRAKE

4. Fix piston boot with retaining ring.

CAUTION:

- Be sure boot is securely engaged in groove on cylinder body.
- Do not reuse retaining ring.

5. Connect sliding pins and sliding pin boots to torque member.
6. Connect torque member to axle assembly and tighten mounting bolts to specified torque.



CAUTION:

Wipe oil and grease on axle assembly washer seats and torque member mounting surface. Install torque member to axle assembly.

7. Connect pads, pad retainers, shims, and shim covers to torque member and assemble cylinder body.
8. Tighten sliding pin bolts to the specified torque.
9. Connect brake hose to caliper assembly and tighten union bolts to the specified torque.

CAUTION:

Do not reuse union bolt copper washer.

10. After installing caliper assembly, refill with new brake fluid and bleed air. Refer to [BR-10, "Bleeding Brake System"](#)

A
B
C
D
E

BR

G
H
I
J
K
L
M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

General Specifications

EFS000CQ

Unit: mm (in)

Front brake	Brake model	AD31VD	
	Cylinder bore diameter	44.4 × 2 (1.748 × 0.08)	
	Pad Length x width x thickness	132.0 × 52.5 × 11.0 (5.20 × 2.067 × 0.433)	
	Rotor outer diameter x thickness	280 × 28 (11.02 × 1.10)	
Rear brake	Brake model	AD9VA	
	Cylinder bore diameter	34.9 (1.374)	
	Pad Length x width x thickness	83.0 × 33.0 × 8.5 (3.268 × 1.299 × 0.335)	
	Rotor outer diameter x thickness	292 × 16 (11.50 × 0.63)	
Master cylinder	Cylinder bore diameter	25.4 (1)	
Control valve	Valve model	Electronic control type	
Brake booster	Booster model	C215T	
	Diaphragm diameter	Primary	230 (9.06)
		Secondary	205 (8.07)
Recommended brake fluid		DOT 3 or DOT 4	

Brake Pedal

EFS000CR

Free play (at pedal top surface)	3 - 11 mm (0.12 - 0.43 in)
Looseness at clevis pin	1 - 3 mm (0.04 - 0.12 in)
Brake pedal height (from dash panel top surface)	M/T model 156 - 166 mm (6.14 - 6.54 in) A/T model 164 - 174 mm (6.46 - 6.85 in)
Depressed pedal height under force of 490 N (50 kg, 110.6 lb) (from dash panel top surface)	M/T model 80 mm (3.15 in) or more A/T model 85 mm (3.35 in) or more
Clearance between threaded end of stop lamp switch and pedal stopper	0.74 - 1.96 mm (0.0291 - 0.0772 in)

Check Valve

EFS000CS

Vacuum leakage [at vacuum of 66.7 kPa (-500 mmHg, -19.69 inHg)]	Within 1.3 kPa (10 mmHg, 0.39 inHg) of vacuum for 15 seconds
---	--

Brake Booster

EFS000CT

Vacuum type

Vacuum leakage [at vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg)]	Within 3.3 kPa (25 mmHg, 0.98 inHg) of vacuum for 15 seconds
Input rod installation standard dimension	125 mm (4.92 in)

Front Disc Brake

EFS000CU

Brake type	AD31VD	
Brake pad	Standard thickness (new)	11 mm (0.43 in)
	Repair limit thickness	2.0 mm (0.07 in)
Disc rotor	Standard thickness (new)	28 mm (1.10 in)
	Repair limit thickness	26 mm (1.02 in)
	Runout limit	0.04 mm (0.0016 in)

SERVICE DATA AND SPECIFICATIONS (SDS)

Rear Disc Brake

EFS000CV

Brake type	AD9VA	
Brake pad	Standard thickness (new)	8.5 mm (0.335 in)
	Repair limit thickness	2.0 mm (0.079 in)
Disc rotor	Standard thickness (new)	16 mm (0.63 in)
	Repair limit thickness	14 mm (0.55 in)
	Runout limit	0.07 mm (0.0028 in)

A

B

C

D

E

BR

G

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)
