

RSU

SECTION REAR SUSPENSION

A
B
C
D

RSU

CONTENTS

PRECAUTIONS	2	FRONT PARALLEL LINK	10
Caution	2	Removal and Installation	10
PREPARATION	3	REMOVAL	10
Special Service Tool	3	INSPECTION AFTER REMOVAL	10
Commercial Service Tools	3	INSTALLATION	10
NOISE, VIBRATION, AND HARSHNESS (NVH)		REAR PARALLEL LINK	11
TROUBLESHOOTING	4	Removal and Installation	11
NVH Troubleshooting Chart	4	REMOVAL	11
REAR SUSPENSION ASSEMBLY	5	INSPECTION AFTER REMOVAL	11
Components	5	INSTALLATION	11
On-Vehicle Inspection and Service	6	RADIUS ROD	12
Wheel Alignment	6	Removal and Installation	12
DESCRIPTION	6	REMOVAL	12
PRELIMINARY INSPECTION	6	INSPECTION AFTER REMOVAL	12
CAMBER	6	INSTALLATION	12
TOE-IN	6	REAR SUSPENSION MEMBER	13
COIL SPRING AND STRUT	8	Removal and Installation	13
Removal and Installation	8	REMOVAL	13
REMOVAL	8	INSTALLATION	13
INSTALLATION	8	SERVICE DATA AND SPECIFICATIONS (SDS)	14
Disassembly and Assembly	8	General Specification	14
DISASSEMBLY	8	Wheel Alignment (Unladen)	14
INSPECTION AFTER DISASSEMBLY	8	Wheelarch Height (Unladen)	14
ASSEMBLY	9		

A
B
C
D
E
F
G
H
I
J
K
L
M

PRECAUTIONS

PRECAUTIONS

PFP:00001

Caution

EES0007C

- Final tightening of bushings must be carried out under unladen condition with tires on the ground. Oil will shorten life of bushings. Be sure to wipe off any spilled oil.
- “Unladen condition” means that fuel, coolant and lubricant are full and ready for drive. However, spare tire, jack, and hand tools should be unloaded.
- After installing the removed suspension parts, always check wheel alignment and adjust if necessary.
- Replace the caulking nut with a new one. Install a new nut without wiping the oil off before tightening.

PREPARATION

PREPARATION

Special Service Tool

PFP:00002

EES0007D

A

B

C

D

RSU

F

G

H




I

J

K

L

M

Tool number Tool name	Description
GG94310000 Flare nut torque wrench	 <p>Removing and installing each brake piping</p>
ST3565 2000 Strut attachment	 <p>Disassembling and assembling strut</p>
Spring compressor	 <p>Removing and installing coil spring</p>

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

N VH Troubleshooting Chart

EES0001E

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page

Possible cause and SUSPECTED PARTS

Symptom	REAR SUSPENSION	Noise	×	×	Improper installation, looseness	<u>RSU-5</u>
		Shake	×	×	Shock absorber deformation, damage or deflection	<u>RSU-8</u>
		Vibration	×	×	Bushing or mounting deterioration	—
		Shimmy	×	×	Parts interference	—
		Judder	×	×	Spring fatigue	—
		Poor quality ride or handling	×	×	Suspension looseness	<u>RSU-5</u>
					Incorrect wheel alignment	<u>RSU-6</u>
					Stabilizer bar fatigue	<u>RSU-5</u>
					PROPELLER SHAFT	N VH in PR section.
					DIFFERENTIAL	N VH in RFD section.
					FRONT AXLE AND FRONT SUSPENSION	N VH in FAX and FSU sections.
					TIRES	N VH in WT section.
					ROAD WHEEL	N VH in WT section.
					DRIVE SHAFT	N VH in RAX section.
					BRAKES	N VH in BR section.
					STEERING	N VH in PS section.

×: Applicable

REAR SUSPENSION ASSEMBLY


REAR SUSPENSION ASSEMBLY

Components

PFP:55020

EES0007E

SEC. 430•431



: N•m (kg-m, ft-lb)

: Always replace after every disassembly.

SEIA0295E

A
B
C
D
RSU
F
G
H
I
J
K
L
M

REAR SUSPENSION ASSEMBLY

1. Strut spacer	2. Strut mounting insulator	3. Spring upper seat
4. Upper rubber seat	5. Bound bumper	6. Coil spring
7. Strut	8. Rear axle assembly	9. Rear suspension member
10. Stopper	11. Stopper	12. Eccentric disc
13. Rear parallel link	14. Toe-in adjusting bolt	15. Front parallel link
16. Radius rod	17. Stabilizer bar	18. Clamp
19. Bushing	20. Connecting rod	

On-Vehicle Inspection and Service

EES0007F

Check axle and suspension parts for excessive play, wear, and damage.

- Move rear wheels (RH/LH) to check abnormal free play.
- Retighten all nuts and bolts to the specified torque.
- Check strut for oil leakage and damage.

Wheel Alignment

EES0007G

DESCRIPTION

- Measure wheel alignment under unladen conditions. "Unladen conditions" means that fuel, coolant, and lubricant are full. However, spare tire, jack, and hand tools should be unloaded.

PRELIMINARY INSPECTION

- Check the tires for improper air pressure and wear.
- Check road wheels for runout.
- Check wheel bearing axial endplay.
- Check strut operation.
- Check each mounting point of axle and suspension for looseness and deformation.
- Check each link and arm for cracks, deformation, and other damage.
- Check the vehicle posture.

CAMBER

Camber is preset at factory and cannot be adjusted.

Camber : [RSU-14, "SERVICE DATA AND SPECIFICATIONS \(SDS\)"](#)


- If the camber is not within specification, inspect and replace any damaged or worn rear suspension parts.

TOE-IN

Measure toe-in using the following procedure.

- Always perform following procedure on a flat surface.
- Make sure that no person is in front of the vehicle before pushing it.

- Bounce rear of vehicle up and down to stabilize the posture.
- Push the vehicle straight ahead about 5 m (16 ft).
- Put a mark on base line of tread (rear side) of both tires at the same height as hub center. This mark is a measuring points.



AFA050

REAR SUSPENSION ASSEMBLY


4. Measure distance "A" (rear side).
5. Push the vehicle slowly ahead to rotate the wheels 180 degrees (1/2 turn).

If the wheels have rotated more than 180 degrees (1/2 turn), try the above procedure again from the beginning. Never push vehicle backward.

6. Measure distance "B" (front tires).

Total toe-in:


Refer toRSU-14, "SERVICE DATA AND SPECIFICATIONS (SDS)".



7. If measured value is outside standard, adjust it with adjusting bolt on rear parallel link.

CAUTION:

Be sure to adjust equally on RH and LH side with adjusting bolt.



A
B
C
D
RSU
F
G
H
I
J
K
L
M

COIL SPRING AND STRUT

PFP:55302

Removal and Installation

REMOVAL

1. Remove tires.
2. Remove brake hose lock plate and remove brake hose from strut.
3. Remove mounting nuts and washers on upper portion of stabilizer connecting rod.
4. Remove strut-to-axle housing mounting bolts and nuts.
5. Remove luggage side lower finisher in luggage compartment. Remove mounting nuts on strut spacer. Then remove strut from vehicle.

INSTALLATION

- Refer to [RSU-5, "Components"](#) for tightening torque. Install in the reverse order of removal.

Disassembly and Assembly

DISASSEMBLY

1. Install strut attachment to strut and fix it in a vise.

CAUTION:

When installing a strut attachment, cover strut with shop cloth to avoid damage.

2. Remove cap and slightly loosen piston rod lock nut.

CAUTION:

Do not remove piston rod lock nut completely. If it is removed completely, coil spring jumps out and may cause serious damage or injury.

3. Compress coil spring using a spring compressor.

CAUTION:

Be sure spring compressor is securely attached to coil spring. Compress coil spring.

4. After making sure coil spring is free between upper and lower seats after Step 3. Remove piston rod lock nut.

5. Remove small parts on strut.

- Remove strut spacer, strut mount insulator, spring upper seat, upper rubber seat, and bound bumper. Then remove coil spring from strut.

6. Gradually release spring compressor, and remove coil spring.

INSPECTION AFTER DISASSEMBLY

Strut


- Check strut for deformation, cracks, and damage, and replace if necessary.
- Check piston rod for damage, uneven wear, and distortion, and replace if necessary.
- Check welded and sealed areas for oil leakage, and replace if necessary.

Insulator and Rubber parts.

- Check strut mount insulator for cracks and rubber parts for wear. Replace them if necessary.

Coil Spring

- Check coil spring for cracks, deformation, and damage, and replace if necessary.



EES0007I

SEIA0124E


COIL SPRING AND STRUT

ASSEMBLY

1. Compress coil spring using a spring compressor, and install it onto the strut.

CAUTION:

- Install coil spring with its identification paint facing down. Align its lower end with spring seat on strut as shown at left.
- Be sure spring compressor is securely attached to coil spring. Compress coil spring.



2. Install small parts to the strut.

- Attach bound bumper, upper rubber seat, spring upper seat, strut mount insulator and strut spacer. Position piston rod lock nut.

CAUTION:

Do not reuse piston rod lock nut.

3. As shown in the figure, set spring upper seat. "O" Mark on it should face outside of vehicle.


4. Be sure coil spring is properly set in upper and lower rubber seats. Gradually release a spring compressor.

CAUTION:

Be sure upper and lower rubber seats are properly aligned to strut, coil spring, and spring upper seat.

5. Tighten piston rod lock nut to the specified torque.

6. Remove strut attachment.



FRONT PARALLEL LINK

FRONT PARALLEL LINK

PFP:55120

Removal and Installation

REMOVAL

1. Remove tires, Raise vehicle.
2. Remove ABS wheel speed sensor wire (With ABS models).
3. Remove front parallel link mounting bolts and nuts. Remove front parallel link from vehicle.

INSPECTION AFTER REMOVAL

- Replace front parallel link assembly if it is in following condition: deformed, cracked, or damaged, or if the bushing was damaged.

INSTALLATION

- Refer to [RSU-5, "Components"](#) for tightening torque and reverse the removal procedure for installation.

REAR PARALLEL LINK

PFP:55121

Removal and Installation

REMOVAL

1. Remove tires, Raise vehicle.
2. Remove rear parallel link mounting bolts and nuts. Remove it from vehicle.

INSPECTION AFTER REMOVAL

- If rear parallel link has deformation, cracks, or damage, replace rear parallel link assembly. If its busing has damage, also replace rear parallel link assembly.

INSTALLATION

- Refer to [RSU-5, "Components"](#) for tightening torque and reverse the removal procedure for installation.
- Suspension member-side mounting bolt is also used as toe-in adjusting bolt. Tighten bolt with vehicle unladen and tires on the ground. After tightened, be sure to carry out toe-in adjustment. Refer to [RSU-6, "TOE-IN"](#).

CAUTION:

Be sure to adjust equally on RH and LH side with adjusting bolt.

A

B

C

D

RSU

F

G

H

I

J

K

L

M

RADIUS ROD

PFP:55110

Removal and Installation

REMOVAL

1. Remove tires, Raise vehicle.
2. Remove radius rod mounting bolts and nuts and remove radius rod from vehicle.

INSPECTION AFTER REMOVAL

- Check radius rod and busing for deformation, cracks, and damage, and replace if necessary.

INSTALLATION

- Refer to [RSU-5, "Components"](#) for tightening torque and reverse the removal procedure for installation.

REAR SUSPENSION MEMBER

PFP:55501

Removal and Installation

REMOVAL

1. Remove tires. Raise vehicle.
2. Remove cotter pin. Remove wheel hub lock nut by using a wheel hub lock nut wrench.
3. Remove ABS wheel speed sensor and wiring (With ABS models).
4. Remove brake caliper and brake hose lock plate, and hang them aside.
5. Remove mounting bolts and nuts on lower portion of strut.
6. Remove axle-side mounting bolts of parallel link and remove rear drive shaft from axle housing.
7. Remove suspension member-side mounting bolt of parallel link and remove parallel link from suspension member.
8. Remove mounting bolts and nuts on lower portion of strut.

A

B

C

D

RSU

CAUTION:

After removing drive shaft, position axle housing onto strut.

9. Remove propeller shaft.
10. Remove rear exhaust tube.
11. Remove electronically controlled coupling connector and air breather hose from final drive.
12. Set a transmission jack under rear final drive.
13. Remove front and rear mounting bolts from rear final drive.
14. Remove rear final drive from suspension member.
15. Place transmission jack onto rear suspension member. Remove rear suspension member mounting bolts. Lower transmission jack slowly to remove rear suspension member from vehicle.

F

G

H

I

J

K

L

M

INSTALLATION

- Refer to [RSU-5, "Components"](#) for tightening torque. Install in the reverse order of removal.
- After installation, perform final tightening of each part under unladen conditions with tires on ground. Check wheel alignment.[RSU-6, "Wheel Alignment"](#) .

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

General Specification

EES000J7

Suspension type	Parallel link and strut
Shock absorber type	Double-acting hydraulic

★Wheel Alignment (Unladen)


EES0007N

Camber Degree minute (Decimal degree)	Minimum	- 1°25' (- 1.42°)	
	Nominal	- 0°40' (- 0.67°)	
	Maximum	0°05' (0.08°)	
Total Toe-in	Distance (A - B)	Minimum	0 mm (0 in)
		Nominal	1 mm (0.04 in)
		Maximum	2 mm (0.08 in)

★: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

★Wheelarch Height (Unladen)

EES000J8



SFA818A

Applied model	QR20DE and QR25DE engine	YD22DDTi engine
	215/70R15 and 215/65R16	215/65R16
Front (Hf)	773 mm (30.43 in)	771 mm (30.35 in)
Rear (Hr)	786 mm (30.94 in)	785 mm (30.91 in)

★: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.