

SECTION **BR**

BRAKE SYSTEM

PRECAUTIONS	3
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3
Precautions for Brake System	3
PREPARATION	4
Special Service Tools	4
Commercial Service Tools	4
NOISE, VIBRATION AND HARSHNESS (NVH)	
TROUBLESHOOTING	5
NVH Troubleshooting Chart	5
BRAKE PEDAL	6
On-Vehicle Inspection and Adjustment	6
Components	7
Removal and Installation	7
REMOVAL	7
INSPECTION AFTER REMOVAL	7
INSTALLATION	7
BRAKE FLUID	8
Checking Brake Fluid Level	8
Checking Brake Line	8
Changing Brake Fluid	8
Bleeding Brake System	9
BRAKE PIPING AND HOSE	10
Hydraulic Piping	10
Removal and Installation of Front Brake Piping and Brake Hose	11
REMOVAL	11
INSTALLATION	12
Removal and Installation of Rear Brake Piping and Brake Hose	12
REMOVAL	12
INSTALLATION	12
Inspection	13
BRAKE MASTER CYLINDER	14
Components	14
Removal and Installation	14
REMOVAL	14

INSTALLATION	14
Disassembly and Assembly	15
MODELS WITHOUT ESP (PISTON STOPPER APPLIED.)	15
MODELS WITHOUT ESP (PISTON STOPPER NOT APPLIED.)	17
MODELS WITH ESP	19
BRAKE BOOSTER	23
On-Vehicle Inspection and Service	23
FUNCTION INSPECTION	23
AIR TIGHTNESS INSPECTION	23
Removal and Installation	23
REMOVAL	23
INSPECTION AFTER REMOVAL	24
INSTALLATION	24
VACUUM LINES	25
Removal and Installation	25
Inspection	26
VISUAL INSPECTION	26
CHECK VALVE INSPECTION	26
FRONT DISC BRAKE	27
Component	27
Inspection	27
PAD THICKNESS	27
Pad Replacement	28
REMOVAL	28
INSTALLATION	28
Caliper Removal and Installation	28
REMOVAL	28
INSTALLATION	29
Caliper Disassembly and Assembly	29
DISASSEMBLY	29
INSPECTION AFTER DISASSEMBLY	29
DISC ROTOR INSPECTION	30
ASSEMBLY	30
BRAKE BURNISHING PROCEDURE	31
REAR DISC BRAKE	32
Component	32
Inspection	32
PAD WEAR INSPECTION	32

Pad Replacement	33	SERVICE DATA AND SPECIFICATIONS (SDS)	38
REMOVAL	33	General Specifications	38
INSTALLATION	33	Brake Pedal	38
Caliper Removal and Installation	34	Check Valve	38
REMOVAL	34	Brake Booster	38
INSTALLATION	34	Front Disc Brake	38
Caliper Disassembly and Assembly	34	Rear Disc Brake	39
DISASSEMBLY	34		
INSPECTION AFTER DISASSEMBLY	35		
DISC ROTOR INSPECTION	35		
ASSEMBLY	36		

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EFS002F9

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A
B
C
D
E
BR
G
H
I
J
K
L
M

Precautions for Brake System

EFS000BZ

- Clean dust on brake pads, shoes, drums, and back plates with a vacuum dust collector. Do not blow with compressed air.
- Recommended fluid is brake fluid "DOT 3" or "DOT 4".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas such as the body. If brake fluid is splashed or spilled on painted areas, wipe it off and flush the area with water immediately.
- Use only clean brake fluid when cleaning master cylinder and disc brake components.
- Never use mineral oils such as gasoline or kerosene to clean. They will ruin the rubber parts and cause improper operation.
- Always use a flare nut torque wrench to securely tighten brake tube flare nuts.
- Brake system is an important safety part. If a brake fluid leak is detected, always disassemble the related parts. If damage, deformation or excessive wear is detected, replace affected parts with new ones.
- Before starting operation, be sure to turn the ignition switch OFF and disconnect the ABS actuator and control module connector or battery cables.
- When installing brake piping, be sure to check torque.




PREPARATION

PREPARATION

PFP:00002


Special Service Tools

EFS00217

Tool number Tool name	Description
GG94310000 Flare nut torque wench a: 10 mm (0.39 in)/12 mm (0.47 in)	 Removing and installing brake piping

Commercial Service Tools

EFS00218

Tool name	Description
Brake fluid pressure gauge	 Measuring fluid pressure

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

EFS000TK

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		Pads - damaged	Pads - uneven wear	Shims damaged	Rotor imbalance	Rotor damage	Rotor runout	Rotor deformation	Rotor deflection	Rotor rust	Rotor thickness variation	Drum out of round	PROPELLER SHAFT	DIFFERENTIAL	AXLE AND SUSPENSION	TYRES	ROAD WHEEL	DRIVE SHAFT	STEERING
Possible cause and SUSPECTED PARTS																			
Symptom	BRAKE	Noise	×	×									×	×	×	×	×	–	
		Shake			×								×	×	×	×	×	–	
		Shimmy, Judder				×	×	×	×	×	×					–	–	–	

X: Applicable

A

B

C

D

BR

G

H

J

K

L

M

BRAKE PEDAL


BRAKE PEDAL

PFP:46501

On-Vehicle Inspection and Adjustment

EFS000C1

Adjust clearance between dash panel and brake pedal upper surface to the following dimensions.



H1	Brake pedal height	M/T model	156 - 166 mm (6.14 - 6.54 in)
		A/T model	164 - 174 mm (6.46 - 6.85 in)
H2	Pedal height when depressed [With engine running and at a depression force of 490 N (50 kg, 110.6 lb)]	M/T model	80 mm (3.15 in) or more
		A/T model	85 mm (3.35 in) or more
C	Clearance between stopper rubber and threaded end of stop lamp switch		0.74 - 1.96 mm (0.0291 - 0.0772 in)
A	Pedal play		3 - 11 mm (0.12 - 0.43 in)

1. Loosen stop lamp switch by rotating it counter-clockwise by 45°.
2. Loosen input rod lock nut (A), then rotate input rod, set pedal to the specified height, and tighten lock nut (A).

CAUTION:


Confirm threaded end of input rod remains inside the clevis.

 : 16 - 21 N·m (1.6 - 2.2 kg·m, 12 - 15 ft-lb)

3. Pull pedal by hand and hold it. Press stop lamp switch until its threaded end contacts the stopper rubber.
4. While holding it against the stopper rubber, turn the switch clockwise by 45° and secure it.

CAUTION:

Be sure stopper rubber to stop lamp switch screw threaded end gap (C) is within the specifications.




5. Check pedal free play.

CAUTION:

Be sure stop lamps go off when pedal is released.

6. Start engine and check brake pedal depressed height.




BRAKE PEDAL

Components

EFS001CI

SEC 465



SFIA1797E

1. Snap pin

2. Stop lamp switch

3. Clip

4. Clevis pin

5. Brake pedal assembly

A
B
C
D
E
BR

G

EFS000C2

H
I
J

K
L
M

Removal and Installation

REMOVAL


Be careful not to deform brake tube.

1. Remove instrument lower driver panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove steering column assembly from steering member. Refer to [PS-11, "STEERING COLUMN"](#) .
3. Remove stop lamp switch from brake pedal assembly.
4. Remove snap pin and clevis pin from brake booster clevis.
5. Remove brake pedal assembly mounting nuts. Pull brake booster toward engine compartment to the extent that does not deform brake tube.
6. Remove brake booster clevis from input rod.
7. Remove the mounting bolts from the bracket, and remove the pedal assembly from the vehicle.

INSPECTION AFTER REMOVAL

Check brake pedal for the following.

- Bent brake pedal
- Deformed clevis pin
- Cracks in welded area
- Cracked or deformed clevis pin stopper



SBR997

INSTALLATION

Install in reverse order of removal. Be careful of the following:

- Adjust brake pedal assembly after installing it.


BRAKE FLUID

PFP:KN100

Checking Brake Fluid Level

EFS000C5

- Confirm reservoir tank fluid level is within the specifications (between MAX and MIN lines).
- Visually check around reservoir tank for fluid leaks.
- If fluid level is excessively low, check brake system for leaks.
- If warning lamp remains illuminated after parking lever is released, check brake system for fluid leakage.



SFIA0066J


Checking Brake Line

EFS001C5

CAUTION:

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

1. Check brake line (tube and hoses) for cracks, deterioration or other damage. Replace and damaged parts.
2. Check for oil leakage by fully depressing brake pedal while engine is running.



SBR389C


Changing Brake Fluid

EFS000C3

CAUTION:

- Refill with new brake fluid "DOT 3 or DOT 4".
- Always keep fluid level higher than minimum line on reservoir tank.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away water immediately.


1. Connect a vinyl tube to bleed valve.
2. Drain brake fluid gradually from bleed valve of each wheel while depressing brake pedal.
3. Turn OFF ignition switch. Remove ABS actuator connector.



BRA0007D

BRAKE FLUID

4. Be sure there is no foreign material in reservoir tank. Refill with new brake fluid.
5. Connect a vinyl tube to bleed valve.
6. Rest foot on brake pedal. Loosen bleed valve. Slowly depress pedal until it stops. Tighten bleed valve. Release brake pedal. Repeat this process a few times at 2-3 second intervals until new brake fluid flows out.
For bleeding procedure. Refer to [BR-9, "Bleeding Brake System"](#).



BRA0006D

Bleeding Brake System

EFS000C4

CAUTION:

- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- Fill reservoir with new brake fluid "DOT 3" or "DOT 4". Make sure it is full at all times while bleeding air out of system.
- Place a container under master cylinder to avoid spillage of brake fluid.
- While bleeding, pay attention to master cylinder fluid level.
- For models with ABS, turn ignition switch OFF and disconnect ABS actuator connectors or battery ground cable.
- Bleed air in the following order.

Right rear brake, left front brake, left rear brake, right front brake

1. Turn OFF ignition switch. Remove ABS actuator connector.
2. Connect a vinyl tube to bleed valve.
3. Fully depress the brake pedal 4 to 5 times.
4. With brake pedal depressed, loosen air bleeder and bleed air.
5. Close bleed valve.
6. Slowly release brake pedal.
7. Tighten bleed valve to the specified torque.



: 6.9 - 8.8 N·m (0.7 - 0.9 kg·m, 61- 78 in-lb)

8. Repeat steps 2 - 7. Occasionally refill master cylinder reservoir tank. Be sure to keep it at least half-full.

A

B

C

D

E

BR

G

H

I

J

K

L

M

BRAKE PIPING AND HOSE

BRAKE PIPING AND HOSE


PFP:46210

Hydraulic Piping

EFS000C6


RHD MODELS

SEC.462 [Model without ESP]



SFIA1798E

SEC.462 [Model with ESP]




SFIA1799E

BRAKE PIPING AND HOSE


LHD MODELS

SEC.462 [Model without ESP]



SFIA2137E

SEC.462 [Model with ESP]



SFIA2138E

Removal and Installation of Front Brake Piping and Brake Hose REMOVAL

EFS000C7


CAUTION:

- Do not allow brake fluid to spill or splash on painted surfaces. Brake fluid can seriously damage paint. If it gets on a painted surface, wipe it off immediately and wash it away with water.
- Do not bend or twist brake hose sharply, or strongly pull it.
- Cover brake fluid line joints to prevent dust and other foreign material.

- Connect a vinyl tube to bleed valve.
- Drain brake fluid gradually from bleed valve of each wheel while depressing brake pedal.

BRAKE PIPING AND HOSE

3. Using a flare nut wrench, loosen brake tube flare nuts and disconnect brake tube from brake hose.
4. Remove union bolts and disconnect caliper assembly from brake hose.
5. First remove lock spring from brake tube and strut mounting positions. Then remove brake hose.



INSTALLATION

CAUTION:

- Refill with new brake fluid "DOT 3" or "DOT4".
- Never reuse drained brake fluid.

1. Connect brake hose to caliper assembly and tighten union bolt to the specified torque.

CAUTION:

- Securely connect brake hose to the protrusion on the cylinder body.
- Do not reuse the copper washer for union bolt.

2. Connect brake hose to strut and fix with lock spring.
3. Connect brake hose to brake tube. Temporarily tighten flare nuts by hand as far as they will go. Secure them with the lock spring.
4. Using a flare nut torque wrench, tighten to the specified torque.

 : 15 - 17 N·m (1.5 - 1.8 kg·m, 11 - 13 ft·lb)

5. Refill brake fluid until new brake fluid comes out of each bleed valve.
6. Afterwards, bleed air.

Removal and Installation of Rear Brake Piping and Brake Hose


EFS000C8

REMOVAL

CAUTION:

- Do not allow brake fluid to spill or splash on painted surfaces. Brake fluid can seriously damage paint. If it gets on a painted surface, wipe it off immediately and wash it away with water.
- Do not bend or twist brake hose sharply, or strongly pull it.
- Cover brake fluid line joints to prevent dust and other foreign material.

1. Connect a vinyl tube to bleed valve.
2. Drain brake fluid gradually from bleed valve of each wheel while depressing brake pedal.
3. Using a flare nut wrench, remove brake tube flare nuts and disconnect brake tube from brake hose.
4. Remove lock spring.



INSTALLATION


CAUTION:

- Refill with new brake fluid "DOT 3" or "DOT 4".
- Never reuse drained brake fluid.

1. Connect brake hose to the brake tube. Temporarily tighten flare nut by hand as far as it will go.
2. Fix brake hose by lock plate.

BRAKE PIPING AND HOSE

3. Tighten flare nut by using a flare nut wrench with the specified torque.
 : 15 - 17 N·m (1.5 - 1.8 kg·m, 11 - 13 ft-lb)
4. Refill brake fluid until new brake fluid comes out of each bleed valve.
5. Afterwards, bleed air.



EFS000C9

Inspection

CAUTION:

If any leaks on joints, retighten it. Replace any damaged parts.

1. Check hose, tube, and joints for fluid leaks, damage, twist, deformation, contact with other parts, and loose connections.
2. Run engine. Depress brake pedal and hold it for approximately 5 seconds while checking each part for leaks.

A
B
C
D

E
BR

G
H
I
J

K
L
M


BRAKE MASTER CYLINDER

BRAKE MASTER CYLINDER

PFP:46010

Components

EFS000CB



SFIA1800E

1. Reservoir tank	2. Reservoir cap	3. Oil strainer
4. Pin	5. Cylinder body	6. Piston stopper (Some models with ABS does not apply.)
7. Grommet	8. O-ring	9. Secondary piston assembly
10. Primary piston assembly	11. Snap ring	12. Guide assembly
13. Plate	14. Stopper cap	15. Primary piston assembly
16. Secondary piston assembly		

Removal and Installation

EFS001CG

REMOVAL

CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wipe it off immediately and wash it away with water.

1. Drain brake fluid.
2. Remove fluid level sensor harness connector.
3. Using a flare nut wrench, disconnect master cylinder assembly and brake tube.
4. First remove master cylinder assembly mounting nuts. Then remove master cylinder assembly.

INSTALLATION

1. Connect brake tube to master cylinder assembly and temporarily tighten flare nut by hand.
2. Connect master cylinder assembly to brake booster assembly and tighten mounting nuts to the specified torque.
3. Tighten brake tube flare nuts.

: 15 - 17 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

4. Connect fluid level sensor harness connector.

BRAKE MASTER CYLINDER

5. Refill with new brake fluid and bleed air from the brake piping.

Disassembly and Assembly

MODELS WITHOUT ESP (PISTON STOPPER APPLIED.)


EFS001CH

Disassembly

CAUTION:

Remove master cylinder reservoir tank only when necessary.


1. Using a slotted flat-bladed screwdriver as shown in the figure, lever up stopper cap tabs and remove stopper cap. While removing, be sure to hold cap securely to prevent the master cylinder piston from popping out.




2. Secure cylinder body flange in a vise as shown in the figure.

CAUTION:

- Secure cylinder body flange with chamfered pin insert hole, facing upward.
- When securing in the vise, use copper plates or cloth to protect the flange.




3. Using a pin punch [tool: diameter Approx. 4 mm (0.16 in)], remove reservoir tank mounting pins.



4. Remove master cylinder assembly from the vise.

5. Remove reservoir tank and grommet from the cylinder body.



6. Using a Phillips flat-bladed screwdriver, press and hold piston pin as shown in the figure. Remove piston stopper from the cylinder body.

7. Carefully pull primary piston assembly straight out to prevent damage to the cylinder inner wall.

8. Tap flange against a wood block to loosen secondary piston assembly. Carefully pull secondary piston assembly straight out to prevent damage to the cylinder inner wall.

Inspection After Disassembly

- Check cylinder inner wall for damage, wear, corrosion, and pinholes. Replace cylinder if damage, wear, or corrosion is detected.

BRAKE MASTER CYLINDER

Assembly


CAUTION:

- Never use mineral oils such as kerosene or gasoline during the cleaning and assembly processes.
- Be sure there is no foreign material on the cylinder inner wall, piston, and cup seal. Be careful not to damage parts with a service tool during assembly.
- Do not drop the parts. Do not use any dropped parts.


1. Apply brake fluid to the inner wall of cylinder body and contact surface of piston assembly. Then insert secondary piston assembly and primary piston assembly into the cylinder body in this order.

CAUTION:

- Do not reuse primary and secondary piston assemblies.
- Always replace primary and secondary piston assemblies as kit.
- Pay attention to orientation of the piston cup. Insert it straight in order to prevent the cups from catching between the cylinder's inner wall and piston.



2. Visually check secondary piston slit position through cylinder body secondary tank boss hole and install piston stopper.



3. Hold piston with stopper cap. Press stopper cap in until its tabs fully engage groove on the cylinder body.


CAUTION:

Do not reuse stopper cap.

4. Apply brake fluid to grommet before pressing it into cylinder body.

CAUTION:

Do not reuse grommet.




5. Secure cylinder body flange in a vise as shown in the figure.

CAUTION:

- Secure cylinder body flange with chamfered pin insert hole facing upward.
- When securing in the vise, use copper plates or cloth to protect the flange.

6. Install reservoir tank to cylinder body. Tilt reservoir tank as shown in the figure to the extent that the mounting pin can be inserted and insert mounting pin. When mounting pin passes through pinhole in master cylinder, return reservoir tank to the upright position. Push mounting pin all the way through the opposite pinhole in the reservoir tank.



BRAKE MASTER CYLINDER

CAUTION:

- Do not reuse reservoir tank mounting pin.
- Do not reuse reservoir tank.
- Be sure to insert pin from the chamfered pinhole on the cylinder body.

MODELS WITHOUT ESP (PISTON STOPPER NOT APPLIED.)

CAUTION:

Remove reservoir tank only when absolutely necessary.


Disassembly (Piston Assembly)

1. Using a flat-bladed screwdriver as shown in the figure, lift up the tabs on the stopper cap and remove it from the master cylinder.


NOTE:

Remove stopper cap while holding it because the piston in master cylinder may pop out.

2. Carefully pull primary piston assembly straight out to prevent the cylinder inner wall from being damaged.



3. Tap flange using a soft block, such as wood, and carefully pull secondary piston assembly straight out to prevent cylinder body inner wall from being damaged.



Inspection After Disassembly (Piston Assembly)

Cylinder body

- Check inner wall of cylinder for damage, abrasion, corrosion, and pinholes. Replace the cylinder body if detected.

Assembly (Piston Assembly)


CAUTION:

- Do not use mineral oils such as kerosene, gasoline during the cleaning and assembly process.
- Make sure there is no foreign matter such as dirt or dust attached to the inner cylinder walls, the piston, or the cap seal, and use care to avoid damaging parts with the assembly tools.
- Do not drop parts. If a part is dropped, do not use it.

1. Apply fluid to cylinder inner wall body and contact surface of the piston assembly. Then insert secondary piston assembly and primary piston assembly into cylinder body in this order.

CAUTION:

- Pay attention to the orientation of the piston cup, and insert straight to prevent the cup from being caught by cylinder inner wall.
- Be sure to replace the assembly without disassembling the new inner kit.
- Do not reuse the primary and secondary piston assemblies.




BRAKE MASTER CYLINDER

2. Holding down the piston with the stopper cap, push the stopper cap tabs so they are firmly into the cylinder grooves, then attach the stopper cap.

CAUTION:

Do not reuse the stopper cap.




Disassembly (Reservoir Tank)


1. Secure master cylinder assembly into a vise with the chamfered pin insert hole on cylinder body facing upward.

CAUTION:

- When setting the master cylinder assembly in a vise, be sure not to over-tighten.
- When securing in a vise use copper plates or cloth to protect the flange.



2. Using a pin punch [commercial service tool: diameter approximately 4 mm (0.16 in)], remove mounting pins on the reservoir tank.
3. Remove master cylinder assembly from the vise.
4. Remove reservoir tank and grommet from cylinder body.



Assembly (Reservoir Tank)

1. Apply brake fluid or rubber lubricant to a grommet, and then install it into cylinder body after installing grommet to reservoir tank.


CAUTION:

Do not reuse the reservoir tank and grommet.

2. Secure master cylinder assembly into a vise with the chamfered pin insert hole on cylinder body facing upward.

CAUTION:

- When setting the master cylinder assembly in a vise, be sure not to over-tighten.
- When securing in a vise use copper plates or cloth to protect the flange.




BRAKE MASTER CYLINDER

3. Tilt reservoir tank as shown in the figure for the mounting pin to be inserted. Return the reservoir tank to the upright position when mounting pin passes through pinhole in the cylinder body. Push mounting pin to the opposite pinhole of the reservoir tank, so that it is the same condition as the insertion side.

CAUTION:

- Be sure to insert pin from the chamfered pinhole of cylinder body.
- Do not reuse the mounting pin.



MODELS WITH ESP

Disassembly


CAUTION:

- While working, cover primary piston rod with cloth to prevent it from being damaged.
- Only remove reservoir tank when absolutely necessary.

1. Place the side of cylinder body with chamfering around the pin insertion hole up, and secure the cylinder body flange section with a vise as shown in the figure.

CAUTION:


When securing in a vise, use copper plates or cloth to protect flange.




2. Using a pin punch [commercial service tool: approximately 4 mm (0.16 in) dia.], remove reservoir tank mounting pin.

3. Remove master cylinder assembly from the vise.

4. Remove reservoir tank and grommet from cylinder body.



5. Push in the primary piston and remove stopper pin from the cylinder body secondary-side tank boss hole.




BRAKE MASTER CYLINDER

6. Remove the snap ring while pushing primary piston in to prevent piston from popping out.
7. Holding primary piston rod, pull primary piston assembly, plate, and guide straight out.
8. Remove plate and guide from primary piston.


CAUTION:

When removing plate from primary piston rod, make sure the inside of plate does not damage rod.



BRA0561D

9. Tap flange using a soft block such as wood, and carefully pull the secondary piston assembly straight out to prevent cylinder inner wall from being damaged.



BRA0033D

Inspection After Disassembly

Master cylinder

- Make sure there is no damage, friction, rusting, or pinholes on the cylinder inner wall, and replace if there are any non-standard conditions.

Assembly


CAUTION:

- Never use mineral oils such as kerosene, gasoline during the cleaning and assembly process.
- Make sure there is no foreign matter such as dirt or dust attached to the inner cylinder walls, piston, or cap seal, and use care to avoid damaging parts with the assembly tools.
- Do not drop parts. If a part is dropped, do not use it.

1. Apply brake fluid to the inside surface of cylinder body and the contact surface of piston assembly, and apply the silicon grease in the inner kit to primary piston rod.
2. Insert secondary piston and primary piston into cylinder body.

CAUTION:


- Do not reuse the primary and secondary piston assemblies.
- Be sure to replace the assembly without disassembling new inner kit.
- Pay attention to the orientation of piston cup, and insert straight to prevent cup from being caught by cylinder inner wall.



PFIA0263E

BRAKE MASTER CYLINDER


3. Visually inspect the secondary piston slit through the piston stopper mounting hole and then install the piston stopper while pushing in the primary piston.



4. Insert plate and guide into cylinder body.

CAUTION:


- Make sure not to damage primary piston rod.
- Pay attention to the orientation of guide assembly.
- Do not drop O-ring.
- Make sure guide and/or plate are not inserted at an angle.



5. Cover primary piston rod with cloth to prevent it getting damaged, and attach snap ring with primary piston pushed in.

CAUTION:

- Make sure the area around snap ring is snug in the cylinder body bore groove.
- Do not reuse snap ring.




6. Apply brake fluid to grommet and attach reservoir tank to master cylinder.

CAUTION:

Do not reuse grommet.

NOTE:

Attach reservoir tank in the orientation shown in the figure.




BRAKE MASTER CYLINDER

7. Place the side of cylinder body with chamfering around the pin insertion hole up, and secure the cylinder body flange section with a vise.

CAUTION:


When securing in a vise, use copper plates or cloth to protect flange.



8. Tilt reservoir tank so that mounting pin can be inserted as shown in the figure, and insert mounting pin. When mounting pin has passed the master cylinder pinhole, return reservoir tank to a level position. Attach mounting pin to the opposite mounting pin hole of reservoir tank so that it is the same as the insertion side.

CAUTION:

- Be sure to insert pin from the chamfered pinhole of cylinder body.
- Do not reuse reservoir tank and mounting pin.



BRAKE BOOSTER


PFP:47200

On-Vehicle Inspection and Service

FUNCTION INSPECTION


EFS000CC

With engine stopped, discharge stored vacuum by depressing brake pedal several times at 5 second intervals. With brake pedal fully depressed, start the engine. Confirm that clearance between brake pedal and floor panel decreases when engine vacuum stabilizes.



AIRTIGHTNESS INSPECTION

- Run engine at idle for approximately 1 minute. Stop it after applying vacuum to the booster. Depress brake pedal several times with normal force to discharge the stored vacuum. Confirm that clearance between brake pedal and floor panel gradually increases as the brake pedal is depressed.
- Run engine. Depress and hold brake pedal then stop engine. Keep brake pedal depressed for 30 seconds or more and make sure the pedal stroke does not change.



EFS000CD


Removal and Installation

REMOVAL

CAUTION:

- Be careful not to deform or bend brake piping while removing and installing brake booster.
- Replace clevis pin if it is damaged.
- Be careful not to damage brake booster stud bolt threads. If brake booster is tilted or inclined during installation, dash panel may damage the threads.
- Be sure to install check valve in the correct orientation.

- Remove vacuum piping from the brake booster.
- Remove master cylinder.
- Remove snap pin and clevis pin on the clevis of input rod. Remove input rod from the brake pedal.
- Remove brake booster and brake pedal assembly mounting nuts.
- Remove booster assembly from the engine compartment.



BRAKE BOOSTER

INSPECTION AFTER REMOVAL


Output rod length inspection

1. Using a handy vacuum pump, apply a vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg) to the brake booster.
2. Check output rod length.

Reference value at vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg):

Without ESP models : 10.4 mm (0.409 in)

With ESP models : -6.2 mm (-0.244 in)




INSTALLATION

1. Loosen lock nut to adjust input rod length so that length "B" (in the figure) satisfies the specified value.

Length "B" standard : 125 mm (4.92 in)

2. After adjusting "B", temporarily tighten lock nut to install booster assembly to vehicle.
3. Connect brake pedal to input rod clevis.
4. Connect brake pedal assembly mounting nuts and tighten to the specified torque.
5. Connect master cylinder to booster assembly.
6. Adjust brake pedal height and play.
7. Tighten input rod lock nut to the specified torque.
8. Bleed air. Refer to [BR-9, "Bleeding Brake System"](#) .



VACUUM LINES

VACUUM LINES


PFP:41920

Removal and Installation


EFS000CE

RHD MODELS

QR20DE engine
QR25DE engine



YD22DDTi engine



SFIA2093E

1. Vacuum hose


2. Vacuum tube

3. Clip


4. Clamp

LHD MODELS

QR20DE engine
QR25DE engine



YD22DDTi engine



SFIA2094E

1. Vacuum hose

2. Clip


3. Clamp

CAUTION:

- Because vacuum hose contains a check valve, it must be installed in the correct orientation. Refer to the stamp or label to confirm correct installation. Brake booster will not operate normally if hose is installed in the wrong direction.

VACUUM LINES

- Insert the vacuum hose at least 24 mm (0.94 in).
- Never use lubricating oil during assembly.



Inspection

VISUAL INSPECTION

Check for improper assembly, damage and aging.

CHECK VALVE INSPECTION

Airtightness Inspection


Use a hand-held vacuum pump to check.

When connected to booster side (1):

Vacuum decrease should be within 1.3 kPa (10 mmHg, 0.39 inHg) for 15 seconds under a vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg)

When connected to engine side (2):

No vacuum will be applied



FRONT DISC BRAKE


FRONT DISC BRAKE

PFP:41000

Component

EFS000CG

SEC.440



SFIA2142E

1. Torque member	2. Slid pin boot	3. Slid pin
4. Outer shim cover	5. Outer shim	6. Outer pad
7. Pad retainer	8. Inner pad	9. Inner shim
10. Inner shim cover	11. Piston boots	12. Piston
13. piston seal	14. Cylinder body	15. Slid pin bolt
16. Copper washer	17. Bleed valve	18. Brake hose union bolt

WARNING:

- Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

CAUTION:

- When cylinder body is open, do not depress brake pedal because piston will pop out.
- Be careful not to damage piston boot or spill brake fluid oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of the rubber coat, replace them with new shims.
- It is not necessary to remove torque member mounting bolt and brake hose union bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.
- Burnish the brake pad contact surfaces after refinishing or replacing drums or rotors, after replacing pads or linings, or if a soft pedal occurs at very low mileage. Refer to [BR-31, "BRAKE BURNISHING PROCEDURE"](#).


Inspection

PAD THICKNESS

EFS000CH

Check pad thickness by lifting vehicle, removing the wheel, and looking through check hole on cylinder body. If necessary, use a scale.

Standard pad thickness : 11 mm (0.43 in)
Pad wear limit : 2.0 mm (0.079 in)



FRONT DISC BRAKE


Pad Replacement REMOVAL

EFS000CI


CAUTION:

When replacing brake pads, always replace inner shims, outer shims, and shim covers as a set.

1. Remove master cylinder reservoir tank cap.
2. Remove lower sliding pin bolt.



3. Hang cylinder body with a wire, and remove pads, pad retainers, shims and pad return springs.



INSTALLATION

1. Apply brake grease on back of the pad and both sides of the shim. Install inner shim and inner shim cover to inner pad, outer shim to outer pad.
2. Apply brake grease on a pad sliding part of pad retainer. Install pad retainers, pads and pad return springs to torque member.
3. Connect cylinder body to torque member.

CAUTION:

When replacing pads with new ones, press piston in until the pads can be installed. Carefully monitor brake master cylinder reservoir fluid level. Brake fluid will return, raising master cylinder reservoir tank fluid level.


4. Insert lower sliding pin bolt and tighten to the specified torque.
5. Check brakes for drag.

Caliper Removal and Installation

EFS000CJ

REMOVAL

1. Connect a vinyl tube to bleed valve.
2. Drain brake fluid gradually from bleed valve while depressing brake pedal.
3. Remove union bolts and torque member mounting bolts, and remove caliper assembly.
4. Remove disc rotor.



INSTALLATION

CAUTION:

- Refill with new brake fluid “DOT 3” or “DOT 4”.
- Never reuse drained brake fluid.

1. Install disc rotor.
2. Install caliper assembly. Tighten mounting bolts to the specified torque.

CAUTION:

Before installing caliper assembly, wipe brake fluid and grease on steering knuckle washer seats and caliper assembly mounting surface.

3. Connect brake hose to caliper assembly and tighten union bolts to the specified torque.

CAUTION:

- Do not reuse copper washer for union bolts.
- Securely assemble brake hose to protrusions on cylinder body.

4. Bleed air. Refer to [BR-9, "Bleeding Brake System"](#).

Caliper Disassembly and Assembly

DISASSEMBLY

EFS000CK

BR


WARNING:

Be careful not to pinch your fingers in the piston.


CAUTION:

Be careful not to damage the cylinder inner wall.

1. Place a wooden block as shown in the figure. Blow air into union bolt mounting hole to remove pistons and piston boots.



2. Using flat-bladed screwdriver, remove piston seals.



INSPECTION AFTER DISASSEMBLY

Cylinder Body

CAUTION:

Use new brake fluid to clean. Never use mineral oils such as gasoline or kerosene.

- Check cylinder inner wall for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the cylinder body.
- Minor flaws caused by corrosion or foreign material can be removed by polishing the surface with fine sandpaper. Replace the cylinder body, if necessary.

Torque Member

Check for wear, cracks and damage. If wear, cracks or damage is detected, replace the applicable part.

FRONT DISC BRAKE

Piston

CAUTION:

The piston sliding surface is plated. Do not polish with sandpaper.

Check piston surface for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the applicable part.

Sliding Pin, Pin Bolt, and Pin Boot

Check sliding pin and sliding pin boot for wear, damage and cracks. If corrosion, wear or damage is detected, replace the applicable part.

DISC ROTOR INSPECTION

Visual Inspection

Check surface of disc rotor for uneven wear, cracks and serious damage. If uneven wear, cracks or serious damage is detected, replace it.

Run Out Inspection

1. Using wheel nuts, fix disc rotor to wheels hub. (2 or more positions)
2. Using a dial indicator, check run out.


Measurement point:

At a point of 10 mm (0.39 in) from the outer edge of the disc.

Run out limit : 0.04 mm (0.0016 in) or less

NOTE:

Make sure that wheel bearing axial endplay is within the specifications before measuring runout. Refer to [FAX-7, "On-Vehicle Inspection"](#).



3. If the run out is outside the limit, find the minimum run out point by shifting the mounting positions of disc rotor and wheel hub by one hole.

Thickness Inspection


Using a micrometer, check thickness of disc rotor. If the thickness is outside the standard, replace the disc rotor.

Standard thickness : 28.0 mm (1.102 in)

Wear limit : 26.0 mm (1.024 in)

Maximum uneven wear (measured at 8 positions):

0.02 mm (0.0008 in) or less



ASSEMBLY


CAUTION:

When assembling, do not use rubber grease.

1. Apply rubber lubricant to piston seals, and install them to cylinder body.

CAUTION:

Do not reuse piston seals.




FRONT DISC BRAKE

2. Apply brake fluid or rubber lubricant to piston boots. Cover piston end with piston boot. Install cylinder side boot lip properly into groove on cylinder body.

CAUTION:


Do not reuse piston boot.



3. Apply brake fluid to piston. Press piston into cylinder body by hand. Assemble piston side boot lip properly into groove on piston.

CAUTION:

Press piston evenly and change pressing point to prevent cylinder inner wall from being rubbed.



BRAKE BURNISHING PROCEDURE

Burnish the brake pad contact surfaces according to the following procedure after refinishing or replacing drums or rotors, after replacing pads or linings, or if a soft pedal occurs at very low mileage.

CAUTION:

Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. **Drive vehicle on a straight smooth road at 50 km/h (31 MPH).**
2. **Use medium brake pedal/foot effort to bring vehicle to a complete stop from 50 km/h (31 MPH). Adjust brake pedal/foot pressure such that vehicle stopping time equals 3 to 5 seconds.**
3. **To cool the brake system, drive vehicle at 50 km/h (31 MPH) for 1 minute without stopping.**
4. **Repeat steps 1 to 3, 10 times or more to complete the burnishing procedure.**

REAR DISC BRAKE


REAR DISC BRAKE

PFP:44000

Component

EFS0017X

SEC.441



 P: PBC (Poly Butyl Cuprysil) grease or silicone-based grease point

 : N·m (kg·m, ft-lb)

 R: Rubber grease point

 : N·m (kg·m, in-lb)

 B: Brake fluid point

 : Always replace after every disassembly.

SFIA2143E

1. Pad retainer	2. Outer shim cover	3. Outer shim
4. Outer pad	5. Pad retainer	6. Inner pad
7. Inner shim	8. Inner shim cover	9. Sliding pin boot
10. Sliding pin	11. Sliding pin bolt	12. Cylinder body
13. Copper washer	14. Brake hose	15. Union bolt
16. Copper washer	17. Bleed valve	18. Piston seal
19. Piston	20. Piston boot	21. Retaining ring
22. Torque member		

WARNING:

- Clean dust on brake caliper and pad with a vacuum dust collector. Do not blow with compressed air.

CAUTION:

- Never depress brake pedal while removing cylinder body because piston will pop out.
- Do not remove brake hose and torque member mounting bolts unless disassembling or replacing caliper assembly. Hang the cylinder body with a wire so that the brake hose is not under tension.
- Be careful not to damage piston boot. Do not allow brake fluid to get the rotor.
- When replacing brake pads, always replace inner shims, outer shims, and shim covers as a set.

Inspection


PAD WEAR INSPECTION

EFS0017Y

Check pad thickness by lifting vehicle, removing tyre and wheel, and looking through check hole on cylinder body. If necessary, use a scale.

standard thickness : 8.5 mm (0.335 in)

pad wear limit : 2.0 mm (0.079 in)




Pad Replacement REMOVAL

EFS0017Z


CAUTION:

When replacing brake pads, always replace inner shims, outer shims, and shim covers as a set.

1. Remove master cylinder reservoir tank cap.
2. Remove lower sliding pin bolt.



3. Hang cylinder body with a wire, and remove pads, pad retainers, and shims.



INSTALLATION

1. Apply brake grease on back of the pad and both sides of the shim. Install inner shim and inner shim cover to inner pad, outer shim to outer pad.
2. Install pad retainers to torque member and install pads.
3. Connect cylinder body to torque member.


CAUTION:

When replacing pads with new ones, press piston in until the pads can be installed. Carefully monitor brake master cylinder reservoir fluid level. Brake fluid will return, raising master cylinder reservoir tank fluid level.

4. Insert lower sliding pin bolt and tighten to the specified torque.
5. Check brakes for drag.

Caliper Removal and Installation**REMOVAL**

1. Connect a vinyl tube to bleed valve.
2. Drain brake fluid gradually from bleed valve while depressing brake pedal.
3. Remove union bolt and remove brake hose from caliper assembly.
4. Remove union bolts and torque member mounting bolts, and remove caliper assembly.
5. Remove disc rotor.

**INSTALLATION****CAUTION:**

- Refill with new brake fluid "DOT 3 or DOT 4".
- Never reuse drained brake fluid.

1. Install disc rotor.
2. Install caliper assembly. Tighten mounting bolts to the specified torque.

CAUTION:

Wipe brake fluid and grease on axle assembly washer seats and caliper assembly mounting surface. Install caliper assembly.

3. Connect brake hose to caliper assembly and tighten union bolts to the specified torque.

CAUTION:

- Do not reuse the copper washer for union bolts.
- Securely assemble brake hose to protrusions on cylinder body.

4. Bleed air. Refer to [BR-9, "Bleeding Brake System"](#).

Caliper Disassembly and Assembly**DISASSEMBLY**

EFS00181


WARNING:

Be careful not to pinch your fingers in the piston.

CAUTION:


Be careful not to damage the cylinder inner wall.

1. Remove caliper assembly from vehicle.
2. Remove sliding pin from cylinder body. Then remove pads, shims, shim covers, and pad retainers from caliper assembly.
3. Remove sliding pin boots from torque member.
4. Using flat-bladed screwdriver (as shown in the figure), remove retaining ring.




REAR DISC BRAKE

5. Place a wooden block as shown in the figure. Blow air into union bolt mounting hole to remove pistons and piston boots.



6. Using flat-bladed screwdriver, remove piston seals.



INSPECTION AFTER DISASSEMBLY

Cylinder Body

CAUTION:

Use new brake fluid to clean. Never use mineral oils such as gasoline or kerosene.

- Check cylinder inner wall for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the cylinder body.
- Minor flaws caused by corrosion or foreign material can be removed by polishing the surface with fine sandpaper. Replace the cylinder body, if necessary.

Torque Member

Check for wear, cracks and damage. If wear, cracks or damage is detected, replace the applicable part.

Piston

CAUTION:

The piston sliding surface is plated. Do not polish with sandpaper.

Check piston surface for corrosion, wear and damage. If corrosion, wear or damage is detected, replace the applicable part.

Sliding Pin, Pin Bolt and Pin Boot

Check sliding pin and sliding pin boot for wear, damage and cracks. If corrosion, wear or damage is detected, replace the applicable part.

DISC ROTOR INSPECTION

Visual Inspection

Check surface of the disc rotor for uneven wear, cracks and serious damage. If uneven wear, cracks or serious damage is detected, replace it.

Run Out Inspection

- Using wheel nuts, fix the disc rotor to wheels hub. (2 or more positions)

REAR DISC BRAKE

2. Using a dial indicator, check run out.

Measurement point:


At a point of 10 mm (0.39 in) from the outer edge of the disc.

Run out limit:

0.07 mm (0.0028 in) or less

NOTE:

Make sure that wheel bearing axial endplay is within the specification before measuring runout. Refer to [RAX-6, "On-vehicle Inspection and Service" \(2WD\)](#), [RAX-10, "On-Vehicle Inspection" \(4WD\)](#).



3. If the run out is outside the limit, find the minimum run out point by shifting the mounting positions of disc rotor and wheel hub by one hole.

Thickness Inspection


Using a micrometer, check thickness of disc rotor. If the thickness is outside the standard, replace disc rotor.

Standard thickness : 16.0 mm (0.630 in)

Wear limit : 14.0 mm (0.551 in)

Maximum uneven wear (measured at 8 positions):

0.02 mm (0.0008 in) or less



ASSEMBLY


CAUTION:

When assembling, do not use rubber grease.

1. Apply rubber lubricant to piston seals, and install them to the cylinder body.

CAUTION:

Do not reuse piston seals.



2. Apply brake fluid to piston boots. Cover piston end with piston boot. Install cylinder side boot lip properly into groove on cylinder body.


CAUTION:

Do not reuse piston boot.

3. Press piston into cylinder body by hand. Assemble piston side boot lip properly into groove on the piston.

CAUTION:

Press piston evenly and change pressing point to prevent the cylinder inner wall from being rubbed.




REAR DISC BRAKE

4. Fix piston boot with retaining ring.

CAUTION:

- Be sure boot is securely engaged in groove on cylinder body.
- Do not reuse retaining ring.

5. Install sliding pins and sliding pin boots to torque member.
6. Install torque member to axle assembly and tighten mounting bolts to the specified torque.



CAUTION:

Wipe brake fluid and grease on axle assembly washer seats and torque member mounting surface. Install torque member to axle assembly.

7. Install pads, pad retainers, shims, and shim covers to torque member and assemble cylinder body.
8. Tighten sliding pin bolts to the specified torque.
9. Connect brake hose to caliper assembly and tighten union bolts to the specified torque.

CAUTION:

Do not reuse union bolt copper washer.

10. After installing caliper assembly, refill with new brake fluid and bleed air. Refer to [BR-9, "Bleeding Brake System"](#)

A
B
C
D
E

BR

G
H
I
J
K
L
M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

General Specifications

EFS000CQ

Unit: mm (in)

Front brake	Brake model	AD31VD	
	Cylinder bore diameter	44.4 × 2 (1.748 × 0.08)	
	Pad Length x width x thickness	132.0 × 52.5 × 11.0 (5.20 × 2.067 × 0.433)	
	Rotor outer diameter x thickness	280 × 28 (11.02 × 1.10)	
Rear brake	Brake model	AD9VA	
	Cylinder bore diameter	34.9 (1.374)	
	Pad Length x width x thickness	83.0 × 33.0 × 8.5 (3.268 × 1.299 × 0.335)	
	Rotor outer diameter x thickness	292 × 16 (11.50 × 0.63)	
Master cylinder	Cylinder bore diameter	25.4 (1)	
Control valve	Valve model	Electronic control type	
Brake booster	Booster model	C215T	
	Diaphragm diameter	Primary	230 (9.06)
		Secondary	205 (8.07)
Recommended brake fluid		DOT 3 or DOT 4	

Brake Pedal

EFS000CR

Pedal play	3 - 11 mm (0.12 - 0.43 in)	
Looseness at clevis pin	1 - 3 mm (0.04 - 0.12 in)	
Brake pedal height (from dash panel top surface)	M/T model	156 - 166 mm (6.14 - 6.54 in)
	A/T model	164 - 174 mm (6.46 - 6.85 in)
Depressed pedal height under a force of 490 N (50 kg, 110.6 lb) (from dash panel top surface)	M/T model	80 mm (3.15 in) or more
	A/T model	85 mm (3.35 in) or more
Clearance between threaded end of stop lamp switch and pedal stopper	0.74 - 1.96 mm (0.0291 - 0.0772 in)	

Check Valve

EFS000CS

Vacuum leakage [at vacuum of 66.7 kPa (-500 mmHg, -19.69 inHg)]	Within 1.3 kPa (10 mmHg, 0.39 inHg) of vacuum for 15 seconds
---	--

Brake Booster

EFS000CT

Vacuum type

Vacuum leakage [at vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg)]	Within 3.3 kPa (25 mmHg, 0.98 inHg) of vacuum for 15 seconds
Input rod installation standard dimension	125 mm (4.92 in)

Front Disc Brake

EFS000CU

Brake type	AD31VD	
Brake pad	Standard thickness (new)	11 mm (0.43 in)
	Repair limit thickness	2.0 mm (0.079 in)
Disc rotor	Standard thickness (new)	28.0 mm (1.102 in)
	Repair limit thickness	26.0 mm (1.024 in)
	Runout limit	0.04 mm (0.0016 in)

SERVICE DATA AND SPECIFICATIONS (SDS)

Rear Disc Brake

EFS000CV

Brake type	AD9VA	
Brake pad	Standard thickness (new)	8.5 mm (0.335 in)
	Repair limit thickness	2.0 mm (0.079 in)
Disc rotor	Standard thickness (new)	16.0 mm (0.63 in)
	Repair limit thickness	14.0 mm (0.55 in)
	Runout limit	0.07 mm (0.0028 in)

A

B

C

D

E

BR

G

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)
