

SECTION **DI**

DRIVER INFORMATION SYSTEM

CONTENTS

PRECAUTIONS	3	DIAGNOSIS RESULTS	24
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	Fuel Level Sensor Signal Inspection [Gasoline Engine Models]	25
Wiring Diagrams and Trouble Diagnosis	3	FUEL GAUGE	25
COMBINATION METERS	4	LOW-FUEL WARNING LAMP	25
System Description	4	Fuel Level Sensor Signal Inspection [Diesel Engine Models]	26
UNIFIED CONTROL METER	4	FUEL GAUGE	26
HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER	4	LOW-FUEL WARNING LAMP	26
POWER SUPPLY AND GROUND CIRCUIT	4	Engine Speed Signal Inspection	28
WATER TEMPERATURE GAUGE	4	Engine Coolant Temperature Signal Inspection	28
TACHOMETER	5	Vehicle Speed Signal Inspection [With ESP]	28
SPEEDOMETER	5	Vehicle Speed Signal Inspection [Without ESP]	28
FUEL GAUGE	5	The Fuel Gauge Pointer Fluctuates, Indicator Wrong Value or Varies	28
AMBIENT TEMPERATURE INDICATOR	5	The Fuel Gauge Does Not Move to FULL Position..	29
CAN Communication	6	Ambient Temperature Signal Inspection [Without Auto A/C]	30
CAN Communication Unit	6	Ambient Temperature Signal Inspection [With Auto A/C]	31
TYPE 1/TYPE 2	7	Electrical Components Inspection	32
TYPE 3	8	FUEL LEVEL SENSOR UNIT CHECK/GASOLINE ENGINE MODELS	32
TYPE 4/TYPE 5	9	FUEL LEVEL SENSOR UNIT CHECK/DIESEL ENGINE MODELS	32
TYPE 6	10	AMBIENT SENSOR CHECK	33
TYPE 7/TYPE 8	11	Removal and Installation for Combination Meter ..	33
TYPE 9	12	REMOVAL	33
Component Parts and Harness Connector Location.	13	INSTALLATION	33
Combination Meter	14	Disassembly and Assembly for Combination Meter..	34
CHECK	14	DISASSEMBLY	34
Schematic/LHD Models	15	ASSEMBLY	34
Wiring Diagram — METER —/LHD Models	16	WARNING LAMPS	35
Schematic/RHD Models	18	Schematic	35
Wiring Diagram — METER —/RHD Models	19	Wiring Diagram — WARN —/LHD Models	36
Terminals and Reference Value for Combination Meter	21	Wiring Diagram — WARN —/RHD Models	44
Meter/Gauges Operation and Odo/Trip Meter	21	Electrical Components Inspection	52
SELF-DIAGNOSIS FUNCTION	21	OIL PRESSURE SWITCH CHECK	52
HOW TO ALTERNATE DIAGNOSIS MODE	21	DIODE CHECK	52
How to Perform Trouble Diagnosis	22	A/T INDICATOR	53
Diagnosis Flow	22		
Power Supply and Ground Circuit Inspection	23		
Trouble Diagnosis Chart for Symptom	24		

Wiring Diagram — AT/IND —/LHD Models	53
Wiring Diagram — AT/IND —/RHD Models	54
A/T Indicator Does Not Illuminate	55
WARNING CHIME	56
System Description	56
POWER SUPPLY AND GROUND CIRCUIT	56
LIGHT WARNING CHIME	56
SEAT BELT WARNING CHIME	56
KEY REMINDER WARNING CHIME [FOR RHD	
MODELS]	56
Wiring Diagram — CHIME —/LHD Models	57
Wiring Diagram — CHIME —/RHD Models	58
Symptom Chart	60
Power Supply and Ground Circuit Inspection	60
Front Door Switch (Driver Side) Inspection	61
Lighting Switch Input Signal Inspection	62
CLOCK	63
Wiring Diagram — CLOCK —	63

PRECAUTIONS

PRECAUTIONS

PFP:00011

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EKS00367

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Wiring Diagrams and Trouble Diagnosis

EKS00368

When reading wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#) in GI section
- [PG-2, "POWER SUPPLY ROUTING"](#) for power distribution circuit in PG section

When performing trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section
- [GI-23, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section

A

B

C

D

E

F

G

H

I

J

DI

L

M

COMBINATION METERS

COMBINATION METERS

PPF:24814

System Description


UNIFIED CONTROL METER

EKS00EGZ

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled by the unified meter control unit, which is built into the combination meter.
- Digital meter is adopted for odo/trip meter.*
*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segments can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

- The vehicle speed signal and the memory signals from the meter memory circuit are processed by the combination meter and the mileage is displayed.
- Ambient temperature indicator indicates signal from ambient sensor processed by combination meter.
- Depressing the odo/trip meter switch toggles the mode in the following order.



- The odo/trip meter display mode toggling and trip display resetting can be identified by the amount of time that elapses from pressing the odo/trip meter switch to releasing it.
- When resetting with trip A displayed, only trip A display is reset (The same way for trip B).

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 28, located in the fuse block (J/B)]
- to combination meter terminal 1.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminals 2.

Ground is supplied

- to combination meter terminals 21
- through grounds M27 and M70.

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature.

ECM provides an engine coolant temperature signal to combination meter for water temperature gauge with CAN communication line.

COMBINATION METERS

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

ECM provides an engine speed signal to combination meter for tachometer with CAN communication line.

SPEEDOMETER

ESP/TCS/ABS control unit (with ESP) or ABS actuator and electric unit (without ESP) provides a vehicle speed signal to the combination meter for the speedometer with CAN communication line.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- from grounds B8 and B18 (LHD models)
- from grounds B107 and B119 (RHD models)
- through terminal 1 and 4 of the fuel level sensor unit
- through terminal 3 and 1 of the sub fuel level sensor unit and
- to combination meter terminal 8 for the fuel gauge.

AMBIENT TEMPERATURE INDICATOR

The ambient temperature is indicated by the signal from ambient sensor.

Combination meter inputs voltage converted from resistance which ambient sensor detects.

Indication range is between -30 and 55 °C (-22 and 131 °F). When ambient air temperature is less than -30 °C (-22 °F) or more than 55 °C (131 °F), display shows “ $---$ °C”. When indicated temperature becomes less than 3 °C (37 °F), ambient temperature indicator flashes as a sign of warning.

Without Auto A/C

Power is supplied

- through combination meter terminal 27
- to ambient sensor terminal 1.

Ground is supplied

- to combination meter terminal 28
- through ambient sensor terminal 2.

Signal is supplied

- through ambient sensor terminal 1
- to combination meter terminal 27.

With Auto A/C

Power is supplied

- through auto amp terminal 9
- to ambient sensor terminal 1.

Ground is supplied

- to combination meter terminal 28 and auto amp terminal 24
- through ambient sensor terminal 2.

And combination meter receives ambient sensor signal from ambient sensor

- through ambient sensor terminal 1
- to combination meter terminal 27.

NOTE:

Combination meter distinguishes whether or not the combination meter terminal 29 receives voltage (auto A/C recognition signal) from auto amp terminal 28. If the terminal receives, combination meter discerns as auto A/C.

Indication When Turning Ignition Switch OFF

- In a case that temperature detected by ambient sensor is higher than indicated temperature before turning ignition switch OFF.
- In a case of more than 3.5 hours after turning ignition switch OFF, temperature detected by ambient sensor is indicated when turning ignition switch ON.

COMBINATION METERS

- In a case of less than 3.5 hours after turning ignition switch OFF, temperature at the time of turning ignition switch off is indicated.
- In a case that temperature detected by ambient sensor is lower than indicated temperature before turning ignition switch OFF.
- Temperature detected by ambient sensor is indicated when turning ignition switch ON.

Indication During Running

Though temperature detected by ambient sensor temporarily changed, indicating temperature continually indicates.

- In a case that temperature detected by ambient sensor is higher than indicated temperature.
- If vehicle speed is more than 20 km/h (13 MPH), elevation of indicating temperature is limited according to the speed until temperature detected by ambient sensor is indicated.

NOTE:

Vehicle speed 20 km/h (13 MPH): 256 sec., 25 km/h (16 MPH): 238 sec., 35 km/h (22 MPH): 200 sec., 50 km/h (31 MPH): 144 sec., 65 km/h (40 MPH): 88 sec., more than 80 km/h (50 MPH): 32 sec.

- If vehicle speed is more than 20 km/h (13 MPH), and that temperature detected by ambient sensor becomes 8 °C (46 °F) more than indicating temperature, indicating temperature will be elevated until the degree becomes same as temperature detected by ambient sensor with limiting elevation of indicating temperature 1 °C per a minute.
- If vehicle speed is less than 20 km/h (13 MPH), indicating temperature is continually kept.
- In a case that temperature detected by ambient sensor is lower than indicated temperature.
- Temperature detected by ambient sensor is indicated during running.

CAN Communication

EKS00EHO

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit


EKS00OSR

Body type	Wagon					
Axle	4WD				2WD	
Engine	YD22DDTi	QR20DE/QR25DE	YD22DDTi	QR25DE	QR20DE	YD22DDTi
Transmission	M/T		A/T	M/T		A/T
Brake control	ABS		ESP		ABS	
CAN system type	1	2	3	4	5	6
				7	8	9

COMBINATION METERS

TYPE 1/TYPE 2

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	ABS actuator and electric unit (control unit)	4WD control unit	Combination meter
4WD mode indicator lamp signal			T	R
4WD warning lamp signal			T	R
A/C compressor feedback signal	T			R
ABS warning lamp signal		T		R
Accelerator pedal position signal	T		R	
Engine coolant temperature signal	T			R
Engine speed signal	T		R	R
MI signal	T			R
Parking brake switch signal			R	T
Stop lamp switch signal		T	R	
Vehicle speed signal		T	R	R
	R			T
ASCD SET lamp signal	T			R
ASCD CRUISE lamp signal	T			R
Stop lamp switch signal	T			R
Glow indicator lamp signal*	T			R
A/C switch signal*	R			T

*: YD engine models only

COMBINATION METERS

TYPE 3

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	4WD control unit	Combination meter
4WD mode indicator lamp signal				T	R
4WD warning lamp signal				T	R
A/C compressor feedback signal	T				R
A/T position indicator lamp signal		T			R
A/T self-diagnosis signal	R	T			
ABS warning lamp signal			T		R
Accelerator pedal position signal	T				R
Closed throttle position signal	T	R			
Engine A/T integrated control signal	T	R			
	R	T			
Engine coolant temperature signal	T				R
Engine speed signal	T			R	R
MI signal	T				R
O/D OFF indicator signal		T			R
Output shaft revolution signal	R	T			
Overdrive control switch signal			R		T
P-N range signal			R		T
Parking brake switch signal				R	T
Stop lamp switch signal			R		T
				T	R
Vehicle speed signal				T	R
	R				T
Wide open throttle position signal	T	R			

COMBINATION METERS

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	4WD control unit	Combination meter
ASCD SET lamp signal	T				R
ASCD CRUISE lamp signal	T				R

TYPE 4/TYPE 5

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ESP/TCS/ABS control unit	Steering angle sensor	4WD control unit	Combination meter
4WD mode indicator lamp signal				T	R
4WD warning lamp signal				T	R
A/C compressor feedback signal*2	T				R
A/C switch signal*1	R				T
ABS warning lamp signal		T			R
Accelerator pedal position signal	T	R		R	
Brake warning lamp signal		T			R
Engine coolant temperature signal	T				R
Engine speed signal	T	R		R	R
ESP OFF indicator lamp signal		T			R
Glow indicator lamp signal*1	T				R
MI signal	T				R
Stop lamp switch signal		T		R	
Vehicle speed signal	R	T		R	R
SLIP indicator lamp signal		T			R
Parking brake switch signal				R	T
Steering angle sensor signal		R	T		
ASCD SET lamp signal	T				R
ASCD CRUISE lamp signal	T				R


COMBINATION METERS

*1: YD engine models only

*2: QR engine models only

TYPE 6

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ESP/TCS/ ABS control unit	Steering angle sensor	4WD control unit	Combination meter
4WD mode indicator lamp signal					T	R
4WD warning lamp signal					T	R
A/C compressor feedback signal	T					R
A/T position indicator lamp signal		T	R			R
A/T self-diagnosis signal	R	T				
ABS warning lamp signal			T			R
Accelerator pedal position signal	T		R		R	
Brake warning lamp signal			T			R
Closed throttle position signal	T	R				
Engine and A/T integrated	T	R				
	R	T				
Engine coolant temperature signal	T					R
Engine speed signal	T		R		R	R
ESP OFF indicator lamp signal			T			R
MI signal	T					R
O/D OFF indicator signal		T				R
Output shaft revolution signal	R	T				
Overdrive control switch signal		R				T
P-N range signal		R				T
SLIP indicator lamp signal			T			R
Steering angle sensor signal			R	T		

COMBINATION METERS

Signals	ECM	TCM	ESP/TCS/ ABS control unit	Steering angle sensor	4WD control unit	Combination meter
Stop lamp switch signal		R				T
			T		R	
Vehicle speed signal			T		R	R
	R					T
Parking brake switch signal					R	T
Wide open throttle position signal	T	R				
ASCD SET lamp signal	T					R
ASCD CRUISE lamp signal	T					R

TYPE 7/TYPE 8

System diagram



SKIA9999E

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	ABS actuator and electric unit (control unit)	Combination meter
A/C compressor feedback signal	T		R
ABS warning lamp signal		T	R
Engine coolant temperature signal	T		R
Engine speed signal	T		R
MI signal	T		R
Vehicle speed signal		T	R
ASCD SET lamp signal	T		R
ASCD CRUISE lamp signal	T		R
Stop lamp switch signal	T		R
Glow indicator lamp signal*	T		R
A/C switch signal*	R		T

*: YD engine models only

COMBINATION METERS

TYPE 9

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	ESP/TCS/ABS control unit	Steering angle sensor	Combination meter
A/C switch signal	R			T
ABS warning lamp signal		T		R
Accelerator pedal position signal	T	R		
Brake warning lamp signal		T		R
Engine coolant temperature signal	T			R
Engine speed signal	T	R		R
ESP OFF indicator lamp signal		T		R
Glow indicator lamp signal	T			R
MI signal	T			R
Vehicle speed signal		T		R
	R			T
SLIP indicator lamp signal		T		R
Steering angle sensor signal		R	T	
ASCD SET lamp signal	T			R
ASCD CRUISE lamp signal	T			R

COMBINATION METERS

Component Parts and Harness Connector Location

EKS00EH2


A
B
C
D
E
F
G
H
I
J
DI
L
M




COMBINATION METERS

Combination Meter CHECK



EKS00EHO



Diesel engine models



with MPH display



Bulb socket color	Bulb wattage
Brown	1.4W

() : Bulb socket color

(D) : Diesel engine


SKIA8933E

COMBINATION METERS

Schematic/LHD Models

EKS00EH4

A
B
C
D
E
F
G
H
I
J
DI
L
M




TKWB1134E

COMBINATION METERS


Wiring Diagram — METER —/LHD Models

EKS00EH5

DI-METER-01




REFER TO THE FOLLOWING.
M1, M2 -FUSE BLOCK-JUNCTION BOX (J/B)



TKWA1606E

COMBINATION METERS



REFERR TO THE FOLLOWING.

REFER TO THE FOLLOWING
M118, E69, E122
ELECTRICAL UNITS


1	2	3	4	5		6	7	8	9
10	11	12	13	14	15	16	17	18	19

1	2	3	4	5	6		7	8	9	10	11	
12	13	14	15	16	17	18	19	20	21	22	23	24

COMBINATION METERS

Schematic/RHD Models

EKS00EHL




TKWB1135E

COMBINATION METERS


Wiring Diagram — METER —/RHD Models

EKS00EHM

DI-METER-03





REFER TO THE FOLLOWING.
M1, M2 -FUSE BLOCK-JUNCTION BOX (J/B)



TKWA1609E




COMBINATION METERS

DI-METER-04



1 REFER TO THE FOLLOWING

M118, E69, E122
-ELECTRICAL UNITS



COMBINATION METERS

Terminals and Reference Value for Combination Meter

EKS00EH6

Terminal No.	Wire color	Item	Condition		Reference value
			Ignition switch	Operation or condition	
1	L	Battery power supply	OFF	—	Battery voltage
2	Y/G	Ignition switch (ON)	ON	—	Battery voltage
8	G	Fuel level sensor signal	—	—	Refer to DI-32, "FUEL LEVEL SENSOR UNIT CHECK/GASOLINE ENGINE MODELS" or DI-32, "FUEL LEVEL SENSOR UNIT CHECK/DIESEL ENGINE MODELS" .
21	B	Ground	ON	—	Approx. 0 V
22	W	CAN H	—	—	—
23	R	CAN L	—	—	—
27	R/B	Ambient sensor signal	—	—	Refer to DI-33, "AMBIENT SENSOR CHECK" .
28	B/Y	Ambient sensor ground	ON	—	Approx. 0 V
29 ^{*1}	Y	Auto A/C recognition signal	ON	—	Approx. 5 V

NOTE:

*1: With auto A/C

Meter/Gauges Operation and Odo/Trip Meter SELF-DIAGNOSIS FUNCTION

EKS00EH7

- Odo/trip meter segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.

HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn ignition switch ON, and switch the odo/trip meter to "trip A" or "trip B".


NOTE:

If the diagnosis function is activated with the trip meter A displayed, the mileage on the trip meter A will indicate 0.0 miles, but the actual trip mileage will be retained (The same way for trip B).

2. Turn ignition switch OFF.
3. While pushing the odo/trip meter switch, turn ignition switch ON again.
4. Make sure that the trip meter displays "0.0".
5. Push the odo/trip meter switch at least 3 times (Within 7 seconds after the ignition switch is turned ON).
6. All the segments on the odo/trip meter illuminate, and simultaneously the low-fuel warning lamp indicator illuminates. At this time, the unified meter control unit is turned to diagnosis mode.

NOTE:


If any of the segments is not displayed, replace the combination meter.



SKIA8920E

COMBINATION METERS

7. Push the odo/trip meter switch. Each meter/gauge should indicate as shown in the figure while pushing odo/trip meter switch. (At this time, the low-fuel warning lamp goes off.)



EKS00EH8

How to Perform Trouble Diagnosis

1. Confirm the symptom or customer complaint.
2. Perform diagnosis according to diagnosis flow. Refer to [DI-22, "Diagnosis Flow"](#) .
3. According to the trouble diagnosis chart, repair or replace the cause of the symptom. Refer to [DI-24, "Trouble Diagnosis Chart for Symptom"](#) .
4. Does the meter operate normally? If so, GO TO 5. If not, GO TO 2.
5. INSPECTION END

Diagnosis Flow

EKS00EH9

1. CHECK WARNING LAMP ILLUMINATION

1. Turn ignition switch ON.
2. Make sure that warning lamps (such as MIL and oil pressure warning lamp) illuminate.

Does warning lamp illuminate?

YES >> GO TO 2.

NO >> Check ignition power supply circuit of combination meter. Refer to [DI-23, "Power Supply and Ground Circuit Inspection"](#) .

2. CHECK SELF-DIAGNOSIS OPERATION

Perform combination meter self-diagnosis. Refer to [DI-21, "SELF-DIAGNOSIS FUNCTION"](#) .

Does self-diagnosis function operate?

YES >> GO TO 3.

NO >> Check battery power supply of combination meter and ground system. Refer to [DI-23, "Power Supply and Ground Circuit Inspection"](#) .


3. CHECK ODO/TRIP METER OPERATION

Check segment display status of odo/trip meter.

Is the display normal?

YES >> GO TO 4.

NO >> Replace combination meter.



SKIA8920E

COMBINATION METERS

4. CHECK LOW-FUEL WARNING LAMP ILLUMINATION

During fuel warning lamp check, confirm illumination of low-fuel warning lamp.

Condition of odo/trip meter switch	Fuel warning lamp
Pushed	Does not illuminate.
Released	Illuminates.

OK or NG

OK >> GO TO 5.

NG >> Replace combination meter.


5. CHECK METER CIRCUIT

Check indication of each meter/gauge in self-diagnosis mode.

OK or NG

OK >> Go to diagnosis results. Refer to [DI-24, "Trouble Diagnosis Chart for Symptom"](#).

NG >> Replace combination meter.



Power Supply and Ground Circuit Inspection

1. CHECK FUSES

Check for blown combination meter fuses.

Unit	Power source	Fuse No.
Combination meter	Battery	28
	Ignition switch (ON)	11

OK or NG

OK >> GO TO 2.

NG >> Be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-80, "FUSE AND FUSIBLE LINK BOX"](#).

2. CHECK POWER SUPPLY CIRCUIT


Check voltage between combination meter and ground.

Terminals		Ignition switch position	
Connector	Terminal (Wire color)	(+)	(-)
M44	2 (Y/G)	OFF	ON
	1 (L)	Ground	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness between combination meter and fuse.



COMBINATION METERS


3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M44 terminals 21 (B) and ground.

Continuity should exist.

OK or NG

OK >> INSPECTION END
NG >> Check ground harness.



EKS00EHB

Trouble Diagnosis Chart for Symptom DIAGNOSIS RESULTS

Symptom	Possible cause
Tachometer indication is malfunction.	Refer to DI-28, "Engine Speed Signal Inspection" .
Low-fuel warning lamp indication is irregular.	Refer to DI-25, "Fuel Level Sensor Signal Inspection [Gasoline Engine Models]" or DI-26, "Fuel Level Sensor Signal Inspection [Diesel Engine Models]" .
Fuel gauge indication is malfunction.	Refer to DI-28, "Engine Coolant Temperature Signal Inspection" .
Water temperature gauge indication is malfunction.	Refer to DI-28, "Vehicle Speed Signal Inspection [With ESP]" or DI-28, "Vehicle Speed Signal Inspection [Without ESP]" .
Indication is irregular for the speedometer and odo/trip meter.	Refer to DI-28, "Vehicle Speed Signal Inspection [With ESP]" or DI-28, "Vehicle Speed Signal Inspection [Without ESP]" .
A/T position indicator is malfunction.	Refer to DI-55, "A/T Indicator Does Not Illuminate" .
Ambient temperature indicator is malfunction.	Refer to DI-30, "Ambient Temperature Signal Inspection [Without Auto A/C]" or DI-31, "Ambient Temperature Signal Inspection [With Auto A/C]" .

Fuel Level Sensor Signal Inspection [Gasoline Engine Models]

EKS00EHC

The following symptoms are not malfunction.

FUEL GAUGE

- Depending on vehicle posture or driving circumstance, the fuel level changes and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.

LOW-FUEL WARNING LAMP

Depending on vehicle posture or driving circumstance, the fuel level changes and the warning lamp ON timing may change.

1. CHECK HARNESS CONNECTOR

Check combination meter and fuel level sensor unit terminals (meter side, unit side, harness side) for looseness or bent terminals.

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK COMBINATION METER CIRCUIT

- Disconnect combination meter connector and sub fuel level sensor unit connector.
- Check continuity between combination meter harness connector M44 terminal 8 (G) and sub fuel level sensor unit harness connector B125^{*1} or B21^{*2} terminal 1 (G).

Continuity should exist.

- Check continuity between combination meter harness connector M44 terminal 8 (G) and ground.

Continuity should not exist.



NOTE:

*1: LHD models, *2: RHD models

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.


3. CHECK FUEL LEVEL SENSOR CIRCUIT

- Disconnect fuel level sensor unit connector.
- Check continuity between sub fuel level sensor unit harness connector B125^{*1} or B21^{*2} terminal 3 (Y) and fuel level sensor unit harness connector B31^{*1} or B123^{*2} terminal 4 (Y).

Continuity should exist.

- Check continuity between sub fuel level sensor unit harness connector B125^{*1} or B21^{*2} terminal 3 (Y) and ground.

Continuity should not exist.



NOTE:

*1: LHD models, *2: RHD models

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.

COMBINATION METERS

4. CHECK GROUND CIRCUIT

Check continuity between fuel level sensor unit harness connector B31^{*1} terminal 1 (B) or B123^{*2} terminal 1 (B/R) and ground.

Continuity should exist.


NOTE:

*1: LHD models, *2: RHD models

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



5. CHECK FUEL LEVEL SENSOR

Check fuel level sensor units. Refer to [DI-25, "Fuel Level Sensor Signal Inspection \[Gasoline Engine Models\]"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace fuel level sensor unit or sub fuel level sensor unit.

6. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

OK or NG

OK >> Replace combination meter.

NG >> Install fuel level sensor unit properly.

Fuel Level Sensor Signal Inspection [Diesel Engine Models]

EKS00EJA

The following symptoms are not malfunction.

FUEL GAUGE

- Depending on vehicle posture or driving circumstance, the fuel level changes and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.

LOW-FUEL WARNING LAMP

Depending on vehicle posture or driving circumstance, the fuel level changes and the warning lamp ON timing may change.

1. CHECK HARNESS CONNECTOR

Check combination meter and fuel level sensor unit terminals (meter side, unit side, harness side) for looseness or bent terminals.

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

COMBINATION METERS


2. CHECK COMBINATION METER CIRCUIT

1. Disconnect combination meter connector and sub fuel level sensor unit connector.
2. Check continuity between combination meter harness connector M44 terminal 8 (G) and sub fuel level sensor unit harness connector B125^{*1} or B21^{*2} terminal 1 (G).

Continuity should exist.

3. Check continuity between combination meter harness connector M44 terminal 8 (G) and ground.

Continuity should not exist.



NOTE:

*1: LHD models, *2: RHD models

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.


3. CHECK FUEL LEVEL SENSOR CIRCUIT

1. Disconnect fuel level sensor unit connector.
2. Check continuity between sub fuel level sensor unit harness connector B125^{*1} or B21^{*2} terminal 3 (Y) and fuel level sensor unit harness connector B32^{*1} or B124^{*2} terminal 4 (Y).

Continuity should exist.

3. Check continuity between sub fuel level sensor unit harness connector B125^{*1} or B21^{*2} terminal 3 (Y) and ground.

Continuity should not exist.



NOTE:

*1: LHD models, *2: RHD models

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.

4. CHECK GROUND CIRCUIT

Check continuity between fuel level sensor unit harness connector B32^{*1} terminal 1 (B) or B124^{*2} terminal 1 (B/R) and ground.

Continuity should exist.


NOTE:

*1: LHD models, *2: RHD models

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



5. CHECK FUEL LEVEL SENSOR

Check fuel level sensor units. Refer to [DI-26, "Fuel Level Sensor Signal Inspection \[Diesel Engine Models\]"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace fuel level sensor unit or sub fuel level sensor unit.

COMBINATION METERS

6. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

OK or NG

OK >> Replace combination meter.
NG >> Install fuel level sensor unit properly.

Engine Speed Signal Inspection

EKS00EHD

1. CHECK ECM SELF-DIAGNOSIS

Perform ECM self-diagnosis. Refer to [EC-103, "CONSULT-II Function \(ENGINE\)"](#) [QR (WITH EURO-OBD)], [EC-604, "CONSULT-II Function \(ENGINE\)"](#) [QR (WITHOUT EURO -OBD)] or [EC-1034, "CONSULT-II Function \(ENGINE\)"](#) [YD].

OK or NG

OK >> Replace combination meter.
NG >> Perform "Diagnostic Procedure" in displayed DTC.

Engine Coolant Temperature Signal Inspection

EKS00EHE

1. CHECK ECM SELF-DIAGNOSIS

Perform ECM self-diagnosis. Refer to [EC-103, "CONSULT-II Function \(ENGINE\)"](#) [QR (WITH EURO-OBD)], [EC-604, "CONSULT-II Function \(ENGINE\)"](#) [QR (WITHOUT EURO - OBD)] or [EC-1034, "CONSULT-II Function \(ENGINE\)"](#) [YD].

OK or NG

OK >> Replace combination meter.
NG >> Perform "Diagnostic Procedure" in displayed DTC.

Vehicle Speed Signal Inspection [With ESP]

EKS00EHF

1. CHECK ESP/TCS/ABS CONTROL UNIT SELF-DIAGNOSIS

Perform ESP/TCS/ABS control unit self-diagnosis. Refer to [BRC-79, "CONSULT-II Functions"](#) .

OK or NG

OK >> Replace combination meter.
NG >> Check applicable parts.

Vehicle Speed Signal Inspection [Without ESP]

EKS00EJB

1. CHECK ABS ACTUATOR CONTROL UNIT SELF-DIAGNOSIS

Perform ABS actuator and electric unit self-diagnosis. Refer to [BRC-26, "CONSULT-II Functions"](#) .

OK or NG

OK >> Replace combination meter.
NG >> Check applicable parts.

The Fuel Gauge Pointer Fluctuates, Indicator Wrong Value or Varies

EKS00EHG

1. CHECK FUEL GAUGE FLUCTUATION

Test drive vehicle to see if gauge fluctuates only during driving or at the instant of stopping.

Does the indication value vary only during driving or at the instant of stopping?

YES >> The pointer fluctuation may be caused by fuel level change in the fuel tank. Condition is normal.
NO >> Ask the customer about the situation when the symptom occurs in detail, and perform the trouble diagnosis.

COMBINATION METERS

The Fuel Gauge Does Not Move to FULL Position

EKS00EHH

1. QUESTION 1

Does it take a long time for the pointer to move to FULL position?

YES >> GO TO 2.
NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

2. QUESTION 2

Was the vehicle fueled with the ignition switch ON?

YES >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise, it will take a long time to move to FULL position because of the characteristic of the fuel gauge.
NO >> GO TO 3.

3. QUESTION 3

Is the vehicle parked on an incline?

YES >> Check the fuel level indication with vehicle on a level surface.
NO >> GO TO 4.

4. QUESTION 4

During driving, does the fuel gauge pointer move gradually toward EMPTY position?

YES >> Check fuel level sensor unit. Refer to [DI-25, "Fuel Level Sensor Signal Inspection \[Gasoline Engine Models\]"](#) or [DI-26, "Fuel Level Sensor Signal Inspection \[Diesel Engine Models\]"](#).
NO >> The float arm may interfere or bind with any of the components in the fuel tank.

DI

L

M

COMBINATION METERS

Ambient Temperature Signal Inspection [Without Auto A/C]

EKS00EJ6


1. CHECK VOLTAGE BETWEEN AMBIENT SENSOR HARNESS CONNECTOR AND GROUND

1. Turn ignition switch OFF.
2. Disconnect ambient sensor harness connector.
3. Turn ignition switch ON.
4. Check voltage between ambient sensor harness connector E38 terminal 1 (R/B) and ground.

Approx. 5 V

OK or NG

OK >> GO TO 2.
NG >> GO TO 4.




2. CHECK AMBIENT SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND COMBINATION METER

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M44 terminal 28 (B/Y) and ambient sensor harness connector E38 terminal 2 (B/Y).

Continuity should exist.

OK or NG

OK >> GO TO 3.
NG >> Repair harness or connector.



3. CHECK AMBIENT SENSOR

Check ambient sensor. Refer to [DI-33, "AMBIENT SENSOR CHECK"](#) .

OK or NG

OK >> Replace combination meter.
NG >> Replace ambient sensor.

4. CHECK AMBIENT SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND COMBINATION METER

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M44 terminal 27 (R/B) and ambient sensor harness connector E38 terminal 1 (R/B).


Continuity should exist.

4. Check continuity between combination meter harness connector M44 terminal 27 (R/B) and ground.

Continuity should not exist.

OK or NG

OK >> Replace combination.
NG >> Repair harness or connector.



COMBINATION METERS

Ambient Temperature Signal Inspection [With Auto A/C]

EKS00EJ7


1. CHECK AUTO A/C RECOGNITION SIGNAL INPUT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Turn ignition switch ON.
4. Check voltage between combination meter harness connector M44 terminal 29 (Y) and ground.

Approx. 5 V

OK or NG

OK >> GO TO 3.
NG >> GO TO 2.




2. CHECK AUTO A/C RECOGNITION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between combination meter harness connector M44 terminal 29 (Y) and A/C auto amp. harness connector M53 terminal 28(Y).

Continuity should exist.

4. Check continuity between combination meter harness connector M44 terminal 29 (Y) and ground.

Continuity should not exist.



OK or NG

OK >> Replace A/C auto amp.
NG >> Repair harness or connector.


3. CHECK AMBIENT SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND COMBINATION METER

1. Turn ignition switch OFF.
2. Disconnect ambient sensor connector.
3. Check continuity between combination meter harness connector M44 terminal 27 (R/B) and ambient sensor harness connector E38 terminal 1 (R/B).

Continuity should exist.

4. Check continuity between combination meter harness connector M44 terminal 27 (R/B) and ground.

Continuity should not exist.



OK or NG

OK >> GO TO 4.
NG >> Repair harness or connector.

4. CHECK A/C AUTO AMP. CIRCUIT

Check A/C auto amp. circuit. Refer to [ATC-109, "Ambient Sensor Circuit"](#) in ATC section.

OK or NG

OK >> Replace combination meter.
NG >> Check applicable parts, and repair or replace corresponding parts.

COMBINATION METERS

Electrical Components Inspection

FUEL LEVEL SENSOR UNIT CHECK/GASOLINE ENGINE MODELS

EKS001NH

For removal, refer to [FL-4, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#) for Gasoline engine models.


Fuel level sensor unit

Check resistance between terminals 1 and 4.

Terminal		Float position [mm (in)]	Resistance value [Ω]
1	4	*1 Full 24 (0.94)	Approx. 5
		*2 Empty 167 (6.57)	Approx. 80

*1 and *2: When float rod is in contact with stopper.

Gasoline engine models



SKIA0904E


Sub fuel level sensor unit

Check resistance between terminals 1 and 3.

Terminal		Float position [mm (in)]	Resistance value [Ω]
1	3	*1 Full 35 (1.38)	Approx. 1
		*2 Empty 186 (7.32)	Approx. 40

*1 and *2: When float rod is in contact with stopper.

Gasoline engine models



SKIA1032E

FUEL LEVEL SENSOR UNIT CHECK/DIESEL ENGINE MODELS

For removal, refer to [FL-19, "FUEL LEVEL SENSOR UNIT"](#) for Diesel engine models.


Fuel level sensor unit

Check resistance between terminals 1 and 4.

Terminal		Float position [mm (in)]	Resistance value [Ω]
1	4	*1 Full 24 (0.94)	Approx. 5
		*2 Empty 170 (6.69)	Approx. 80

*1 and *2: When float rod is in contact with stopper.

Diesel engine models



SKIA0909E


Sub fuel level sensor unit

Check resistance between terminals 1 and 3.

Terminal		Float position [mm (in)]	Resistance value [Ω]
1	3	*1 Full 34 (1.34)	Approx. 1
		*2 Empty 186 (7.32)	Approx. 40

*1 and *2: When float rod is in contact with stopper.

Diesel engine models



SKIA0910E

COMBINATION METERS


AMBIENT SENSOR CHECK

Ambient Sensor

After disconnecting ambient sensor harness connector, measure resistance between terminals 2 and 1 at sensor harness side, using the table below.

Temperature [°C (°F)]	Resistance [kΩ]
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07


If NG, replace ambient sensor.



Removal and Installation for Combination Meter REMOVAL

EKS00EHJ

1. Remove cluster lid A. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove the screws (4), and pull out combination meter.
3. Disconnect connectors and remove combination meter.



INSTALLATION

Installation is the reverse order of removal.


A
B
C
D
E
F
G
H
I
J
DI
L
M

COMBINATION METERS

Disassembly and Assembly for Combination Meter

EKS00EHK

SEC. 248



SKIA7344J

1. Front cover
2. Upper housing
3. Unified meter control unit assembly
4. Meter cover

DISASSEMBLY

1. Disengage the tabs (8) to separate front cover.
2. Disengage the tabs (8) to separate upper housing.
3. Disengage the tabs (8) to separate meter cover.

ASSEMBLY

Assembly is the reverse order of disassembly.

WARNING LAMPS

WARNING LAMPS

Schematic

PFP:24814

EKS002HE

A

B

C

D

E

F

G


H

I

DI

L

M




WARNING LAMPS


Wiring Diagram — WARN —/LHD Models

EKS002HH

DI-WARN-01



REFER TO THE FOLLOWING.




WARNING LAMPS

DI-WARN-02

■ : DATA LINE

⟨ES⟩ : WITH ESP



⟨OE⟩ : WITHOUT ESP



TKWB1511E


WARNING LAMPS

DI-WARN-03



WARNING LAMPS


DI-WARN-04













1 2 3 4 5 6 — 7 8 9 10 11
12 13 14 15 16 17 18 19 20 21 22 23 24 M61
BR

1 2 3 4 5 — 6 7 8 9
10 11 12 13 14 15 16 17 18 19 20 M75
BR

REFER TO THE FOLLOWING.
M118 -ELECTRICAL UNITS







WARNING LAMPS



WARNING LAMPS

DI-WARN-06






TKWA1617E

WARNING LAMPS

DI-WARN-07

PS : WITH POWER SEAT
OP : WITHOUT POWER SEAT





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWB0070E

WARNING LAMPS

DI-WARN-08



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


TKWB0071E

WARNING LAMPS

Wiring Diagram — WARN —/RHD Models


EKS0031U

DI-WARN-09





WARNING LAMPS

DI-WARN-10





REFER TO THE FOLLOWING.
E69 , **E122** -ELECTRICAL
UNITS



WARNING LAMPS




DI-WARN-11




TKWB1513E

WARNING LAMPS







DI-WARN-12



REFER TO THE FOLLOWING.
M118 - ELECTRICAL UNITS






WARNING LAMPS



WARNING LAMPS

DI-WARN-14





TKWA1623E

WARNING LAMPS

DI-WARN-15

PS : WITH POWER SEAT
OP : WITHOUT POWER SEAT







*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWB0072E

WARNING LAMPS

DI-WARN-16



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWB0073E


WARNING LAMPS

Electrical Components Inspection OIL PRESSURE SWITCH CHECK

EKS002HK

Check continuity between the terminals of oil pressure switch and ground.

Condition	Oil pressure [kPa (bar, kg/cm ² , psi)]	Continuity
Engine running	More than 29 (0.30, 0.3, 4)	No
Engine stopped	Less than 29 (0.30, 0.3, 4)	Yes




ELF0044D

DIODE CHECK

- Check continuity using tester.
- Diode is functioning properly if test results are as shown in the figure.
- Check diodes at the combination meter harness connector instead of on the combination meter assembly. Refer to [DI-36, "Wiring Diagram — WARN —/LHD Models"](#) or [DI-44, "Wiring Diagram — WARN —/RHD Models"](#).

NOTE:

Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



SKIB0607E

A/T INDICATOR



A/T INDICATOR

PFP:24814

Wiring Diagram — AT/IND —/LHD Models

EKS002HL

DI-AT/IND-01





TKWA1624E

A/T INDICATOR

Wiring Diagram — AT/IND —/RHD Models

EKS000EKF

DI-AT/IND-02



TKWA1625E

A/T Indicator Does Not Illuminate

EKS00ES6

1. CHECK TCM SELF-DIAGNOSIS

Perform TCM self-diagnosis. Refer to [AT-40, "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION" \[EURO-OBD\]](#) or [AT-242, "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION" \[EXC.F/EURO-OBD\]](#).

OK or NG

OK >> Replace combination meter.

NG >> Go to TCM trouble diagnosis.

A

B

C

D

E

F

G

H

I

J

DI

L

M

WARNING CHIME

PFP:24814

System Description

POWER SUPPLY AND GROUND CIRCUIT

EKS002XF

Power is supplied at all times

- to combination switch terminal 11 and
- to daytime light control unit terminal 1 (with daytime light system)
- through 10A fuse (No. 31, located in fuse and fusible link box), and
- to key switch terminal 1 (RHD models) and
- to time control unit terminal 1
- through 10A fuse [No. 28, located in the fuse block (J/B)].

With ignition switch in ON or START position, power is supplied

- to time control unit terminal 17
- through 10A fuse [No. 5, located in the fuse block (J/B)].

Ground is supplied

- to time control unit terminal 16
- through grounds M27 and M70.

LIGHT WARNING CHIME

With ignition switch OFF position, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound.

Power is supplied

- from the lighting switch terminal 12 or daytime light control unit terminal 11 (with daytime light system)
- to time control unit terminal 19.

Ground is supplied

- to time control unit terminal 30
- through front door switch (driver side) terminal 2.

Front door switch (driver side) terminal 3 is grounded through grounds B8 and B18.

SEAT BELT WARNING CHIME

When the vehicle speed exceeds 25 km/h (16 MPH) with driver or passenger seat belt unfastened (seat belt switch ON), warning chime will sound. Refer to [SB-6, "SEAT BELT WARNING SYSTEM"](#) .

KEY REMINDER WARNING CHIME [FOR RHD MODELS]

Key reminder chime will sound, at the same time, key reminder system will start operating.

When the following three conditions are simultaneously met.

- Key is inserted in the ignition key cylinder.
- Driver's door is opened.
- The setting of driver's door lock knob is "LOCK".





For information regarding key reminder system, refer to [BL-43, "Key reminder system"](#) in BL section.

WARNING CHIME

Wiring Diagram — CHIME —/LHD Models

EKS002XJ

DI-CHIME-01



REFER TO THE FOLLOWING.
M2 -FUSE BLOCK-JUNCTION BOX (J/B)



TKWA1626E

WARNING CHIME

Wiring Diagram — CHIME —/RHD Models

EKS00EKI

DI-CHIME-02






REFER TO THE FOLLOWING.
M2, E103 -FUSE BLOCK-JUNCTION BOX (J/B)

TKWA1628E

WARNING CHIME

DI-CHIME-03



WARNING CHIME

Symptom Chart

EKS002XQ

Symptom	Diagnosis/Service procedure
Light warning chime does not activate.	<p>Perform the following inspections.</p> <p>1. DI-60, "Power Supply and Ground Circuit Inspection" 2. DI-61, "Front Door Switch (Driver Side) Inspection" 3. DI-62, "Lighting Switch Input Signal Inspection"</p> <p>Replace time control unit, found normal function in the above inspections.</p>
Key reminder warning chime does not activate.	<p>Perform key reminder system trouble diagnosis.</p> <p>Refer to BL-54, "SYMPTOM CHART".</p>
Seat belt warning chime does not activate.	<p>Perform seat belt warning system trouble diagnosis.</p> <p>Refer to SB-16, "Trouble Diagnosis Chart by Symptom".</p>

Power Supply and Ground Circuit Inspection

EKS002YF

1. CHECK FUSES

Check for blown time control unit fuses.

Unit	Power source	Fuse No.
Time control unit	Battery	28 (10A)
	Ignition switch (ON)	5 (10A)

OK or NG

OK >> GO TO 2.

NG >> Be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-79, "FUSE BLOCK - JUNCTION BOX \(J/B\)"](#).

2. CHECK POWER SUPPLY CIRCUIT


Check voltage between time control unit connector and ground.

Terminals		Ignition switch position	
(+) Connector	(+) Terminal (Wire color)	(+) OFF	(+) ON
M30	1 (L)	Ground	Battery voltage
M31	17 (G)	Ground	0 V

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect time control unit connection.
3. Check continuity between time control unit harness connector M30 terminal 16 (B/R) and ground.

Continuity should exist.

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



Front Door Switch (Driver Side) Inspection

EKS002YH

1. CHECK DOOR SWITCH (DRIVER SIDE) INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between time control unit harness connector M31 terminal 30 (SB) and ground.


When driver side door is opened : Approx. 0 V

When driver side door is closed : Approx. 12 V

OK or NG

OK >> Front door switch (driver side) is OK.

NG >> GO TO 2.

**2. CHECK FRONT DOOR SWITCH (DRIVER SIDE)**

1. Disconnect front door switch (driver side) connector.
2. Check continuity between front door switch (driver side) connector B16 terminals 2 and 3.


When door switch is released : Continuity should exist.

When door switch is pushed : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Replace front door switch (driver side).

**3. CHECK FRONT DOOR SWITCH (DRIVER SIDE) CIRCUIT**

1. Disconnect time control unit connector.
2. Check continuity between time control unit harness connector M31 terminal 30 (SB) and front door switch (driver side) harness connector B16 terminal 2 (R).

Continuity should exist.


3. Check continuity between time control unit harness connector M31 terminal 30 (SB) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.

**4. CHECK FRONT DOOR SWITCH (DRIVER SIDE) GROUND CIRCUIT**


Check continuity between front door switch (driver side) harness connector B16 terminal 3 (B) and ground.

Continuity should exist.

OK or NG

OK >> Replace time control unit.

NG >> Repair harness or connector.



WARNING CHIME

Lighting Switch Input Signal Inspection

EKS002XU

1. CHECK LIGHTING SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between time control unit harness connector M31 terminal 19 (R/L) and ground.

Lighting switch (1st or 2nd position) : Approx. 12 V


Lighting switch (OFF) : Approx. 0 V

OK or NG

OK >> Lighting switch is OK.

NG >> ● GO TO 2 (without daytime light control unit).

● GO TO 3 (with daytime light control unit).



2. CHECK LIGHTING SWITCH CIRCUIT (WITHOUT DAYTIME LIGHT SYSTEM)

1. Disconnect time control unit connector and combination switch connector.
2. Check continuity between time control unit harness connector M31 terminal 19 (R/L) and combination switch harness connector E110 terminal 12 (R/L).

Continuity should exist.


3. Check continuity between time control unit harness connector M31 terminal 19 (R/L) and ground.

Continuity should not exist.

OK or NG

OK >> Check combination switch. Refer to [LT-120, "COMBINATION SWITCH"](#).

NG >> Repair harness or connector.



3. CHECK LIGHTING SWITCH CIRCUIT (WITH DAYTIME LIGHT SYSTEM)

1. Disconnect time control unit connector and daytime light control unit connector.
2. Check continuity between time control unit harness connector M31 terminal 19 (R/L) and daytime light control unit harness connector E115 terminal 11 (R/L).

Continuity should exist.


3. Check continuity between time control unit harness connector M31 terminal 19 (R/L) and ground.

Continuity should not exist.

OK or NG

OK >> Check daytime light control unit. Refer to [LT-50, "Trouble Diagnoses"](#) in HEADLAMP (WITH DAYTIME) - XENON TYPE - or [LT-60, "Trouble Diagnoses"](#) in HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -.

NG >> Repair harness or connector.



CLOCK


CLOCK

Wiring Diagram — CLOCK —

PFP:25820

EKS00215

DI-CLOCK-01



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M44)
W

REFER TO THE FOLLOWING.
(M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWA1630E

CLOCK
