

CONTENTS

PRECAUTIONS	2	Removal and Installation	12
Service Notice or Precautions	2	REMOVAL	12
PREPARATION	3	INSTALLATION	12
Special Service Tools	3	Disassembly and Assembly	12
Commercial Service Tools	3	DISASSEMBLY	12
NOISE, VIBRATION AND HARSHNESS (NVH)		INSPECTION AFTER DISASSEMBLY	12
TROUBLESHOOTING	4	ASSEMBLY	12
NVH Troubleshooting Chart	4	CLUTCH PIPING	13
CLUTCH PEDAL	5	Removal and Installation	13
On-Vehicle Inspection and Adjustment	5	CLUTCH RELEASE MECHANISM	14
Removal and Installation	6	Removal and Installation	14
COMPONENTS	6	COMPONENTS	14
REMOVAL	7	REMOVAL	14
INSPECTION AFTER REMOVAL	7	INSPECTION AFTER REMOVAL	15
INSTALLATION	7	INSTALLATION	15
CLUTCH FLUID	8	CLUTCHDISC, CLUTCH COVER AND FLYWHEEL	16
Air Bleeding Procedure	8	Removal and Installation	16
CLUTCH MASTER CYLINDER	9	COMPONENTS	16
Components	9	REMOVAL	16
Removal and Installation	10	INSPECTION AND ADJUSTMENT AFTER	
REMOVAL	10	REMOVAL	17
INSTALLATION	10	INSTALLATION	18
Disassembly and Assembly	10	SERVICE DATA AND SPECIFICATIONS (SDS)	19
DISASSEMBLY	10	Clutch Control System	19
INSPECTION AFTER DISASSEMBLY	10	Clutch Master Cylinder	19
ASSEMBLY	11	Clutch Operating Cylinder	19
OPERATING CYLINDER	12	Clutch Disc	19
Components	12	Clutch Cover	19

PRECAUTIONS

PRECAUTIONS

PFP:00001

Service Notice or Precautions

BCS00099


- Recommended clutch fluid is brake fluid "DOT 3" or "DOT 4". Refer to [MA-17, "Fluids and Lubricants"](#) .
- Do not reuse drained clutch fluid.
- Be careful not to splash clutch fluid on painted areas.
- When removing and installing clutch piping, use Tool.

Tool number : GG94310000 or Commercial equivalent

- Use new clutch fluid to clean or wash all parts of master cylinder and operating cylinder.
- Do not use mineral oils such as gasoline or kerosene. It will corrode the rubber parts of the hydraulic system.

WARNING:

After cleaning clutch disc, clean it with a dust collector. Do not use compressed air.






PREPARATION

PREPARATION

Special Service Tools



PFP:00002

BCS0009A

Tool number Tool name	Description
ST20050240 Diaphragm adjusting wrench	Adjusting unevenness of diaphragm spring of clutch cover
 ZZA0508D	
KV30101600 Clutch aligning bar a: 15.9 mm (0.626 in) dia. b: 17.9 mm (0.705 in) dia. c: 40 mm (1.57 in)	Installing clutch cover and clutch disc (For QR engine models)
 S-NT405	
KV30100100 Clutch aligning bar a: 15.7 mm (0.618 in) dia. b: 22.8 mm (0.898 in) dia.	Installing clutch cover and clutch disc (For YD engine models)
 ZZA1178D	

Commercial Service Tools

BCS0009B

Tool name	Description
Pin punch Tip diameter: 4.5 mm (0.177 in) dia.	Removing and installing master cylinder spring pin
 ZZA0515D	
GG94310000 Flare nut torque wrench a: 10 mm (0.39 in)	Removing and installing clutch piping
 S-NT406	

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

BCS0009C

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

SUSPECTED PARTS (Possible cause)		Reference page																
		CLUTCH PEDAL (Inspection and adjustment)	CLUTCH LINE (Air in line)	MASTER CYLINDER PISTON CUP (Damaged)	OPERATING CYLINDER PISTON CUP (Damaged)	ENGINE MOUNTING (Loose)	RELEASE BEARING (Worn, dirty or damaged)	CLUTCH DISC (Out of true)	CLUTCH DISC (Runout is excessive)	CLUTCH DISC (Lining broken)	CLUTCH DISC (Dirty or burned)	CLUTCH DISC (Oily)	CLUTCH DISC (Worn out)	CLUTCH DISC (Hardened)	CLUTCH DISC (Lack of spline grease)	DIAPHRAGM SPRING (Damaged)	DIAPHRAGM SPRING (Out of tip alignment)	PRESSURE PLATE (Distortion)
Symptom	Clutch grabs/chatters				1			2				2	2	2			2	
	Clutch pedal spongy	1	2	2			1											
	Clutch noisy																	
	Clutch slips	1						5	5	5	5	5	2	2		3	4	5
	Clutch does not disengage	1	2	3	4			5	5	5	5	5			5	6	6	7

CLUTCH PEDAL

PFP:46540


On-Vehicle Inspection and Adjustment

BCS0009D

1. Make sure that clevis pin floats freely in the bore of clutch pedal. It should not be bound by clevis or clutch pedal.
 - a. If clevis pin is not free, make sure that pedal stopper bolt or ASCD clutch switch is not applying pressure to clutch pedal causing clevis pin to bind. To adjust, loosen lock nut and turn pedal stopper bolt or ASCD clutch switch.
 - b. Tighten lock nut.
- c. Make sure that clevis pin floats in the bore of clutch pedal. It should not be bound by clutch pedal.
- d. If clevis pin is still not free, remove clevis pin and check for deformation or damage. Replace clevis pin if necessary. Leave clevis pin removed for step 2.
2. Check clutch pedal stroke for free range of movement.
 - a. With clevis pin removed, manually move clutch pedal up and down to determine if it moves freely.
 - b. If any sticking is found, replace related parts (clutch pedal bracket, assist spring, bushing etc.). Reassemble clutch pedal and again make sure that clevis pin floats freely in the bore of clutch pedal.
3. Check clutch hydraulic and system components (clutch master cylinder, clutch operating cylinder, clutch withdrawal lever, clutch release bearing, etc.) for sticking or binding.
 - a. If any sticking or binding is found, repair or replace related parts as necessary.
 - b. If hydraulic system repair was necessary, bleed the clutch hydraulic system. Refer to [CL-8, "Air Bleeding Procedure"](#).

NOTE:

Do not use a vacuum assist or any other type of power bleeder on this system. Use of a vacuum assist or power bleeder will not purge all the air from the system.




CLUTCH PEDAL

Removal and Installation COMPONENTS

BCS0009E

RHD models

SEC.465



: N·m (kg-m, ft-lb)


(L) : Apply lithium-based grease including molybdenum disulphide.

PCIB0877E

1. Clutch pedal assembly
2. Assist spring
3. Bushing
4. Stopper rubber
5. Clevis pin
6. Bushing
7. Stopper rubber
8. Pedal stopper bolt (Without ASCD)
9. ASCD clutch switch (With ASCD)
10. Snap pin

LHD models

SEC.465



: N·m (kg-m, ft-lb)

(L) : Apply lithium-based grease including molybdenum disulphide.

PCIB1452E

1. Clutch pedal assembly
2. Assist spring
3. Bushing
4. Clevis pin
5. Bushing
6. Stopper rubber
7. Pedal stopper bolt (Without ASCD)
8. ASCD clutch switch (With ASCD)
9. Stopper rubber
10. Snap pin
11. Bracket

CLUTCH PEDAL

REMOVAL

1. Remove instrument driver lower panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Disconnect ASCD clutch switch harness connector (with ASCD).
3. Remove snap pin and clevis pin from clevis of clutch master cylinder.
4. Remove clutch pedal assembly mounting nuts and bolt, and then remove clutch pedal assembly from the vehicle.

INSPECTION AFTER REMOVAL

- Check clutch pedal for bend, damage, or a cracked weld. If bend, damage, or a cracked weld is found, replace clutch pedal.
- Check assist spring for settling. If settling is found, replace assist spring.

INSTALLATION

Installation is the reverse order of removal.

NOTE:

Tighten pedal stopper bolt lock nut (without ASCD) or ASCD clutch switch lock nut (with ASCD) to the specified torque after installing clutch pedal assembly in vehicle and adjusting the pedal free play.

A

B

CL

D

E

F

G

H

I

J

K

L

M

CLUTCH FLUID

PFP:00017

Air Bleeding Procedure

BCS0009F


NOTE:

Do not use a vacuum assist or any other type of power bleeder on this system. Use of a vacuum assist or power bleeder will not purge all the air from the system.


CAUTION:

- Monitor clutch fluid level in reservoir tank to make sure it does not empty.
- Keep painted surface on the body or other parts free of clutch fluid. If it spills, wipe up immediately and wash the affected area with water.
- Bleed the air of operating cylinder.

1. Fill master cylinder reservoir tank with new clutch fluid.
2. Connect a transparent vinyl hose to air bleeder valve.
3. Depress clutch pedal slowly and fully several times at an interval of 2 to 3 seconds and hold it.
4. With clutch pedal depressed, open air bleeder valve to release air.
5. Close air bleeder valve.
6. Release clutch pedal and wait for 5 seconds.



7. Repeat steps 3 to 6 until no bubbles can be observed in clutch fluid.
8. Tighten air bleeder valve to the specified torque. Refer to [CL-12, "Components"](#).



CLUTCH MASTER CYLINDER

CLUTCH MASTER CYLINDER


PFP:30610

Components

BCS0009G

RHD models

SEC. 305




PCIB0763E

1. Nipple	2. Clamp	3. Hose
4. Cylinder body	5. Seat	6. Clevis
7. Clevis pin	8. Snap pin	9. Stopper ring
10. Stopper	11. Push rod	12. Piston assembly
13. Return spring	14. Seal	15. Spring pin

LHD models

SEC. 305



PCIB0764E

1. Nipple	2. Clamp	3. Hose
4. Cylinder body	5. Seat	6. Clevis
7. Clevis pin	8. Snap pin	9. Stopper ring
10. Stopper	11. Push rod	12. Piston assembly
13. Return spring	14. Seal	15. Spring pin

CLUTCH MASTER CYLINDER

Removal and Installation REMOVAL

BCS0009H

1. Using one of the following methods, remove hose from nipple.
 - Drain clutch fluid from reservoir tank and remove hose.
 - Remove hose from nipple. Immediately plug hose and reservoir tank to prevent clutch fluid from dripping.

CAUTION:

Keep painted surface on the body or other parts free of clutch fluid. If it spills, wipe up immediately and wash the affected area with water.

2. Remove clutch tube using a flare nut wrench.
3. Remove snap pin and clevis pin on clevis in passenger compartment to separate clutch pedal.
4. Remove mounting nuts on master cylinder assembly, and then master cylinder assembly from vehicle.

INSTALLATION


1. Check position of clevis and push rod. If measurement is outside the standard length, adjust position of clevis and push rod.

Length "L"

RHD models: 125.5 mm (4.94 in)

LHD models: 122.0 mm (4.80 in)

2. Connect clutch tube to master cylinder assembly and temporarily tighten flare nut.
3. Install master cylinder assembly and tighten mounting nuts to the specified torque. Refer to [CL-9, "Components"](#).
4. Tighten clutch tube flare nut to the specified torque using a flare nut torque wrench. Refer to [CL-13, "Removal and Installation"](#).
5. Set clevis to clutch pedal. Apply recommended grease to clevis pin and insert clevis pin to clevis.
6. Attach snap pin to clevis pin.
7. Install hose to nipple.
8. After completing this procedure, inspect and adjust for clutch pedal and then bleed the air from the clutch hydraulic system. Refer to [CL-5, "On-Vehicle Inspection and Adjustment"](#) and [CL-8, "Air Bleeding Procedure"](#).




Disassembly and Assembly

DISASSEMBLY

BCS0009I

1. Remove spring pin using a pin punch.
2. Remove nipple and seal from cylinder body.
3. Loosen push rod lock nut then remove clevis and lock nut, if necessary.
4. Remove seat from cylinder body.
5. Remove stopper ring and stopper. Remove push rod from cylinder body while holding it securely to prevent piston assembly popping out.
6. Remove piston assembly and return spring.



INSPECTION AFTER DISASSEMBLY

Check for any of the conditions shown below. If any malfunction is found, replace the part concerned.

- Damaged cylinder internal wall, foreign matter, wear, corrosion, or pinhole
- Damaged or deformed nipple or reservoir tank
- Settling of return spring
- Cracked or deformed seat

CLUTCH MASTER CYLINDER

ASSEMBLY

1. Apply rubber lubricant to the internal surface of cylinder body, the sliding surface of piston assembly, and piston cup. Insert return spring and piston assembly to cylinder body.
2. Apply silicon grease to push rod and install stopper. Install stopper ring while holding down push rod by hand to prevent piston assembly from popping out.

CAUTION:

Do not reuse stopper ring.

3. Install seat to cylinder body.
4. Install seal and nipple to cylinder body. Install spring pin using a pin punch.

CAUTION:


Do not reuse seal.

5. Install clevis to push rod.
6. Check and adjust the positions of clevis and push rod. After adjusting "L", tighten lock nut to the specified torque. Refer to [CL-9, "Components"](#).

Length "L"

RHD models: 125.5 mm (4.94 in)

LHD models: 122.0 mm (4.80 in)



OPERATING CYLINDER

OPERATING CYLINDER

PPF:30620

Components

BCS0009J

SEC. 306


: N·m (kg-m, in-lb)

: N·m (kg-m, ft-lb)

: Apply rubber grease.

: Apply rubber lubricant.

: Always replace after every disassembly.



PCIB0765E

1. Air bleeder valve
2. Copper washer
3. Union bolt
4. Clutch hose
5. Cylinder body
6. Dust cover
7. Push rod
8. Piston assembly
9. Piston cup
10. Piston spring

Removal and Installation

BCS0009K

REMOVAL

1. Drain clutch fluid.

CAUTION:

Keep painted surface on the body or other parts free of clutch fluid. If it spills, wipe up immediately and wash the affected area with water.

2. Remove clutch hose from operating cylinder.
3. Remove operating cylinder mounting bolts and remove operating cylinder from the vehicle.

INSTALLATION

Note the following, and install in the reverse order of removal.

- Install hose with care so that it will not be bent or twisted.
- After completing the procedure, bleed the air from the clutch hydraulic system. Refer to [CL-8, "Air Bleeding Procedure"](#).

Disassembly and Assembly

BCS0009L

DISASSEMBLY

- Remove dust cover and push rod. Then remove piston, piston cup, and piston spring from inside cylinder body.

INSPECTION AFTER DISASSEMBLY

Check for any of the conditions shown below. If any malfunction is found, replace the part concerned.

- Damage to cylinder internal surface or piston sliding surface. Foreign matter, wear, corrosion, or pinhole
- Settling of piston spring
- Cracked or deformed dust cover

ASSEMBLY

1. Apply rubber lubricant to cylinder body internal surface and rubber grease to piston cup and piston. Insert piston assembly and piston spring into cylinder body.
2. Apply rubber grease to dust cover and install push rod and dust cover.

CLUTCH PIPING

CLUTCH PIPING

PFP:30650

Removal and Installation

BCS0009M

A

B

CL

D

E

F

G

H


I

J

K

L

M



1. Clutch tube
2. Lock plate
3. Clutch hose
4. Operating cylinder
5. Clutch pedal
6. Master cylinder

Carefully observe the following steps during clutch tube removal and installation.


CAUTION:

Keep painted surface on the body or other parts free of clutch fluid. If it spills, wipe up immediately and wash the affected area with water.

- To fix clutch hose on bracket, position clutch hose clasp on the emboss of bracket and drive lock plate vertically from above. Be careful not to bend or twist clutch hose. Do not scratch or damage clutch hose.
- Tighten clutch tube flare nut to the specified torque.
- Tighten clutch hose union bolt to the specified torque.

CAUTION:
Do not reuse copper washer.

- After installation, bleed the air from the clutch hydraulic system. Refer to [CL-8, "Air Bleeding Procedure"](#).



CLUTCH RELEASE MECHANISM

CLUTCH RELEASE MECHANISM


PFP:30502

Removal and Installation COMPONENTS

BCS0009N

QR engine models

SEC. 321




■ (L) : Apply lithium-based grease including molybdenum disulphide.

PCIB0767E

1. Dust cover
2. Withdrawal lever
3. Retainer spring
4. Release bearing

YD engine models

SEC. 321



■ (L) : Apply lithium-based grease including molybdenum disulphide.

PCIB1453E

1. Dust cover
2. Withdrawal lever
3. Snap spring
4. Release bearing


REMOVAL

1. Remove transaxle assembly from the vehicle. Refer to [MT-19, "Removal and Installation"](#) .
2. Remove release bearing and withdrawal lever from inside clutch housing.
3. Remove dust cover.
4. Remove retainer spring (for QR engine models) or snap spring (for YD engine models) from withdrawal lever.

CLUTCH RELEASE MECHANISM

INSPECTION AFTER REMOVAL

- If release bearing is seized, damaged, not properly centered or does not rotate smoothly, replace it.
- If contact surface of withdrawal lever is excessively worn, replace it.
- If dust cover is cracked, replace it.




INSTALLATION

CAUTION:

- Be sure to apply grease to the points specified. Otherwise, noise, poor disengagement, or damage to the clutch may result. Excessive grease may cause slip or judder. Wipe off any grease oozing from the parts.
- Be careful not to bring any grease to the clutch disk facing, pressure plate surface and flywheel surface.

1. Following the instructions below, apply grease to the specified points.



CAUTION:


Wipe off any old grease, debris, or powdery residue left on the grease applying surfaces.

2. Evenly apply approximately 1 mm (0.04 in) thick coating of recommended grease to withdrawal lever and release bearing sliding surface.
3. Apply recommended grease to withdrawal lever ball pin contact surface and inner slots of release bearing. The grease surface should be level with the surrounding area.
4. Apply a thin coat of recommended grease evenly to release bearing sliding surface. Install release bearing. Wipe off any excess grease that oozes from the parts and then remove release bearing.

2. Note the following, and install in the reverse order of removal.

CAUTION:

- Before installing transaxle assembly to the vehicle, make sure that each sliding surface slides smoothly by operating withdrawal lever.
- When assembling, make sure that both ends of snap spring touch the end face of withdrawal lever (for YD engine models).
- Be careful with the orientation of snap spring (for YD engine models).



CLUTCH DISC, CLUTCH COVER AND FLYWHEEL


CLUTCH DISC, CLUTCH COVER AND FLYWHEEL

PFP:30100

Removal and Installation COMPONENTS


BCS00090

QR engine models



1. Flywheel 2. Clutch disc 3. Clutch cover

YD engine models



1. Flywheel 2. Clutch disc 3. Clutch cover

CAUTION:

Be careful not to bring any grease to the clutch disc facing, pressure plate surface and flywheel surface.

REMOVAL

1. Remove transaxle assembly from the vehicle. Refer to [MT-19, "Removal and Installation"](#)
2. Loosen clutch cover mounting bolts evenly. Then remove clutch cover and clutch disc.

CLUTCH DISC, CLUTCH COVER AND FLYWHEEL

INSPECTION AND ADJUSTMENT AFTER REMOVAL

Clutch Disc


- Measure circumferential runout relative to clutch disc center spline. If it is outside the specification, replace clutch disc.

Runout limit/diameter of the area to be measured:

1.0 mm (0.039 in)/230 mm (9.06 in) dia.

- Measure backlash to clutch disc spline and input shaft spline at the circumference of clutch disc. If outside the specification, replace clutch disc.


Maximum allowable spline backlash: 1.0 mm (0.039 in)



- Using calipers, measure the depth to clutch disc facing rivet heads. If it exceeds the allowable wear limit, replace clutch disc.

Facing wear limit (depth to the rivet head):

0.3 mm (0.012 in)



Clutch Cover

Check diaphragm spring lever claws for unevenness with the lever still on the vehicle. If they exceed the tolerance, adjust lever height using the diaphragm adjusting wrench.

Tolerance for diaphragm spring lever unevenness:


0.7 mm (0.028 in) or less

Tool number : ST20050240

- Check clutch cover thrust ring for wear or breakage. If wear or breakage is found, replace clutch cover.

NOTE:

- Worn thrust ring will generate a beating noise when tapped at the rivet with a hammer.
- Broken thrust ring will make a clinking sound when cover is shaken up and down.
- If a trace of burn or discoloration is found on the clutch cover pressure plate to clutch disc contact surface, repair the surface with sandpaper. If surface is damaged or distorted, replace the assembly.



Flywheel Runout

Using a dial indicator, measure runout at the flywheel clutch contact surface. If runout is outside the specification, replace flywheel. If a trace of burn or discoloration is found on the surface, repair it with sandpaper.


Allowable flywheel runout

QR engine models:

Refer to [EM-116, "FLYWHEEL DEFLECTION \(M/T MODELS\)"](#).

YD engine models:

Refer to [EM-259, "FLYWHEEL DEFLECTION"](#).



CAUTION:

Measure it at flywheel outer face (not on knock pin and clutch cover mounting hole).

CLUTCH DISC, CLUTCH COVER AND FLYWHEEL

INSTALLATION

1. Apply recommended grease to clutch disc and input shaft splines.

CAUTION:

Be sure to apply grease to the points specified. Otherwise, noise, poor disengagement, or damage to the clutch may result. Excessive grease may cause slip or judder. Wipe off any grease oozing from the parts.


2. Install clutch disc and clutch cover. Pre-tighten mounting bolts and install clutch aligning bar.

Tool number

QR engine models : KV30101600

YD engine models : KV30100100

3. Tighten clutch cover mounting bolts evenly in two steps in the order shown in the figure. Refer to [CL-16, "COMPONENTS"](#).
4. Install transaxle assembly. Refer to [MT-19, "Removal and Installation"](#).



SCIA0909E

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Clutch Control System

BCS0009P

Type of clutch control	Hydraulic
------------------------	-----------

Clutch Master Cylinder

BCS0009Q

Inner diameter	15.87 mm (5/8 in)
----------------	-------------------

Clutch Operating Cylinder

BCS0009R

Inner diameter	19.05 mm (3/4 in)
----------------	-------------------

Clutch Disc

BCS0009S

Engine type	QR20DE	QR25DE	YD22DDTi
Model		240	
Facing size (outer dia. x inner dia. x thickness)	240 mm x 160 mm x 3.5 mm (9.45 in x 6.30 in x 0.138 in)		240 mm x 170 mm x 3.5 mm (9.45 in x 6.69 in x 0.138 in)
Thickness of disc assembly with load	7.90 - 8.30 mm (0.3110 - 0.3268 in) with 5,688 N (580 kg, 1,279 lb)		7.70 - 8.10 mm (0.303 - 0.319 in) with 7,845N (800 kg, 1,764 lb)
Wear limit of facing surface to rivet head		0.3 mm (0.012 in)	
Runout limit/diameter of the area to be measured		1.0 mm (0.039 in) / 230 mm (9.06 in) dia.	
Maximum spline backlash (at outer edge of disc)		1.0 mm (0.039 in)	

Clutch Cover

BCS0009T

Engine type	QR20DE	QR25DE	YD22DDTi
Set-load	4,903 N (500 kg, 1,103 lb)	5,884 N (600 kg, 1,323 lb)	7,600 N (775 kg, 1,708 lb)
Diaphragm spring lever height	37.0 - 39.0 mm (1.457 - 1.535 in)		
Uneven limit diaphragm spring toe height	0.7 mm (0.028 in) or less		

SERVICE DATA AND SPECIFICATIONS (SDS)
