

SECTION BCS

BODY CONTROL SYSTEM

CONTENTS

PRECAUTION	3	COMMON ITEM	21
PRECAUTIONS	3	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	21
Precautions for Removing Battery Terminal	3		
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	4	DOOR LOCK	22
Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	4	DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (With Intelligent Key System and Super Lock)	22
SYSTEM DESCRIPTION	6	DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (With Intelligent Key System, With- out Super Lock)	23
COMPONENT PARTS	6	DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (Without Intelligent Key System, With Super Lock)	24
BODY CONTROL SYSTEM	6	DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (Without Intelligent Key System and Super Lock)	25
BODY CONTROL SYSTEM : Component Parts Location	6		
POWER CONSUMPTION CONTROL SYSTEM	7	MULTI REMOTE ENT	26
POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location	7	MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT) (With Super Lock)	26
SYSTEM	10	MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT) (Without Super Lock)	27
BODY CONTROL SYSTEM	10	REAR WINDOW DEFOGGER	29
BODY CONTROL SYSTEM : System Description	10	REAR WINDOW DEFOGGER : CONSULT Func- tion (BCM - REAR DEFOGGER)	29
BODY CONTROL SYSTEM : Fail-safe	12		
COMBINATION SWITCH READING SYSTEM	13	BUZZER	30
COMBINATION SWITCH READING SYSTEM : System Description	13	BUZZER : CONSULT Function (BCM - BUZZER)	30
SIGNAL BUFFER SYSTEM	16	INT LAMP	30
SIGNAL BUFFER SYSTEM : System Description	17	INT LAMP : CONSULT Function (BCM - INT LAMP)	30
POWER CONSUMPTION CONTROL SYSTEM	17	HEADLAMP	31
POWER CONSUMPTION CONTROL SYSTEM : System Description	18	HEADLAMP : CONSULT Function (BCM - HEAD LAMP) (LED Headlamp)	31
SHIPPING MODE CONTROL SYSTEM	19	HEADLAMP : CONSULT Function (BCM - HEAD LAMP) (Halogen Headlamp)	33
SHIPPING MODE CONTROL SYSTEM : System Description	20		
DIAGNOSIS SYSTEM (BCM)	21	WIPER	35

A
B
C
D
E

F
G
H
I
J
K
L

BCS

M
N
O
P

WIPER : CONSULT Function - WIPER	35	BCM	81
FLASHER	36	Wiring Diagram	81
FLASHER : CONSULT Function (BCM - FLASHER) (LED Headlamp)	36	BASIC INSPECTION	104
FLASHER : CONSULT Function (BCM - FLASHER) (Halogen Headlamp)	37	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	104
INTELLIGENT KEY	38	Description	104
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (With Super Lock)	38	Work Procedure	104
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (Without Super Lock)	42	CONFIGURATION (BCM)	106
COMB SW	46	Description	106
COMB SW : CONSULT Function (BCM - COMB SW)	46	Work Procedure	106
COMB SW : CONSULT Function (BCM - COMB SW)	46	Configuration list	107
BCM	47	SHIPPING MODE CANCEL OPERATION	109
BCM : CONSULT Function (BCM - BCM)	47	Work Procedure	109
IMMU	47	DTC/CIRCUIT DIAGNOSIS	110
IMMU : CONSULT Function (BCM - IMMU) (With Intelligent Key System)	47	U1000 CAN COMM	110
IMMU : CONSULT Function (BCM - IMMU) (Without Intelligent Key System)	47	DTC Description	110
BATTERY SAVER	47	Diagnosis Procedure	110
BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)	48	U1010 CONTROL UNIT (CAN)	111
TRUNK	48	DTC Description	111
TRUNK : CONSULT Function (BCM - TRUNK) (With Intelligent Key System and Super Lock)	48	Diagnosis Procedure	111
TRUNK : CONSULT Function (BCM - TRUNK) (With Intelligent Key System, Without Super Lock)	49	U0415 VEHICLE SPEED	112
TRUNK : CONSULT Function (BCM - TRUNK) (Without Intelligent Key System, With Super Lock)	49	DTC Description	112
TRUNK : CONSULT Function (BCM - TRUNK) (Without Intelligent Key System and Super Lock)	50	Diagnosis Procedure	112
THEFT ALM	50	B2562 LOW VOLTAGE	113
THEFT ALM : CONSULT Function (BCM - THEFT) (With Intelligent Key System)	50	DTC Description	113
THEFT ALM : CONSULT Function (BCM - THEFT) (Without Intelligent Key System)	51	Diagnosis Procedure	113
SIGNAL BUFFER	52	POWER SUPPLY AND GROUND CIRCUIT	114
SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)	52	Diagnosis Procedure	114
ECU DIAGNOSIS INFORMATION	53	COMBINATION SWITCH OUTPUT CIRCUIT	115
BCM	53	Diagnosis Procedure	115
Reference Value	53	COMBINATION SWITCH INPUT CIRCUIT	117
Fail-safe	76	Diagnosis Procedure	117
DTC Inspection Priority Chart	77	SYMPTOM DIAGNOSIS	119
DTC Index	78	COMBINATION SWITCH SYSTEM SYPTOMS	119
WIRING DIAGRAM	81	Symptom Table	119
BCM	121	NORMAL OPERATING CONDITION	120
Removal and Installation	121	Description	120
COMBINATION SWITCH	122	REMOVAL AND INSTALLATION	121
Removal and Installation	122	BCM	121
		Removal and Installation	121
		COMBINATION SWITCH	122
		Removal and Installation	122

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:0000000010842517

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

- Open the hood.
- Turn key switch to the OFF position with the driver side door opened.
- Get out of the vehicle and close the driver side door.
- Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

- Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.


INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

- Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

- Open the driver side door.
- Open the hood.
- Close the driver side door.
- Wait at least 3 minutes.



SEF289H

PRECAUTIONS

< PRECAUTION >

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010842518

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000010842519

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition power source and accessory power source to the OFF, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Open driver door.
3. Turn the ignition switch to the ON position.
(At this time, the steering lock will be released.)
4. Turn the ignition switch to OFF position with driver door open.

PRECAUTIONS

< PRECAUTION >

5. Wait for 3 minutes or longer with driver door open.

NOTE:

- Do not close driver door because the steering wheel locks when driver door is closed.
- The auto acc function is adapted to this vehicle. For this reason, even when the ignition switch is turned to OFF position, the accessory power source does not turn OFF and continues to be supplied for a certain amount of time.

6. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
7. Perform the necessary repair operation.
8. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from OFF position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
9. Perform self-diagnosis check of all control units using CONSULT.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION


COMPONENT PARTS

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : Component Parts Location

INFOID:0000000010688574

RHD MODELS




① BCM

Ⓐ Behind of glove box

LHD MODELS

COMPONENT PARTS

< SYSTEM DESCRIPTION >



① BCM

A Behind instrument panel (LH)

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location

BCS

INFOID:000000010688575

RHD models


N

O

P

COMPONENT PARTS

< SYSTEM DESCRIPTION >




JMMIA1813ZZ

- ① Combination meter
- ② IPDM E/R
Refer to [PCS-5, "Component Parts Location"](#).
- ③ BCM
Refer to [BCS-6, "BODY CONTROL SYSTEM : Component Parts Location"](#).
- ④ Electric parking brake control module
Refer to [PB-8, "Component Parts Location"](#).
- ⑤ Automatic back door control module
Refer to [DLK-25, "DOOR LOCK SYSTEM : Component Parts Location"](#) (With Intelligent Key and super lock) or [DLK-335, "DOOR LOCK SYSTEM : Component Parts Location"](#) (With Intelligent Key, without super lock)

LHD models

COMPONENT PARTS

< SYSTEM DESCRIPTION >



JMMIA1812ZZ

① Automatic back door control module
Refer to [DLK-25, "DOOR LOCK SYSTEM : Component Parts Location"](#) (With Intelligent Key and super lock) or [DLK-335, "DOOR LOCK SYSTEM : Component Parts Location"](#) (With Intelligent Key, without super lock)

② Electric parking brake control module
Refer to [PB-8, "Component Parts Location"](#).

③ IPDM E/R
Refer to [PCS-5, "Component Parts Location"](#).

④ BCM
Refer to [BCS-6, "BODY CONTROL SYSTEM : Component Parts Location"](#).

⑤ Combination meter

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS

SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : System Description

INFOID:000000010688576

OUTLINE

- BCM (Body Control Module) controls the various electrical components. It inputs the information required to the control from CAN communication and the signal received from each switch and sensor.
- BCM has combination switch reading function for reading the operation status of combination switches (light, turn signal, wiper and washer) in addition to a function for controlling the operation of various electrical components. It also has the signal transmission function as the passed point of signal and the power saving control function that reduces the power consumption with the ignition switch OFF.
- BCM is equipped with the diagnosis function that performs the diagnosis with CONSULT and various settings.

BCM CONTROL FUNCTION LIST

System	Reference
Combination switch reading system	BCS-13, "COMBINATION SWITCH READING SYSTEM : System Description"
Signal buffer system	BCS-17, "SIGNAL BUFFER SYSTEM : System Description"
Power consumption control system	BCS-18, "POWER CONSUMPTION CONTROL SYSTEM : System Description"
Shipping mode control system	BCS-20, "SHIPPING MODE CONTROL SYSTEM : System Description"
Headlamp system	<ul style="list-style-type: none">EXL-21, "HEADLAMP SYSTEM : System Description" (LED headlamp)EXL-225, "HEADLAMP SYSTEM : System Description" (Halogen headlamp)
Auto light system	<ul style="list-style-type: none">EXL-24, "AUTO LIGHT SYSTEM : System Description" (LED headlamp)EXL-228, "AUTO LIGHT SYSTEM : System Description" (Halogen headlamp)
Daytime running light system	<ul style="list-style-type: none">EXL-30, "DAYTIME RUNNING LIGHT SYSTEM : System Description" (LED headlamp)EXL-234, "DAYTIME RUNNING LIGHT SYSTEM : System Description" (Halogen headlamp)
Turn signal and hazard warning lamp system	<ul style="list-style-type: none">EXL-36, "TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description" (LED headlamp)EXL-236, "TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description" (Halogen headlamp)
Parking, license plate and tail lamps system	<ul style="list-style-type: none">EXL-38, "PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM : System Description" (LED headlamp)EXL-239, "PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM : System Description" (Halogen headlamp)
Stop lamp system	<ul style="list-style-type: none">EXL-42, "STOP LAMP SYSTEM : System Description" (LED headlamp)EXL-243, "STOP LAMP SYSTEM : System Description" (Halogen headlamp)
Front fog lamp system	<ul style="list-style-type: none">EXL-44, "FRONT FOG LAMP SYSTEM : System Description" (LED headlamp)EXL-245, "FRONT FOG LAMP SYSTEM : System Description" (Halogen headlamp)
Rear fog lamp system	<ul style="list-style-type: none">EXL-46, "REAR FOG LAMP SYSTEM : System Description" (LED headlamp)EXL-247, "REAR FOG LAMP SYSTEM : System Description" (Halogen headlamp)

SYSTEM

< SYSTEM DESCRIPTION >

System	Reference
Exterior lamp battery saver system	<ul style="list-style-type: none"> EXL-48, "EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description" (LED headlamp) EXL-249, "EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description" (Halogen headlamp)
Interior room lamp control system	INL-11, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description"
Interior room lamp battery saver system	INL-14, "INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description"
Illumination control system	INL-18, "ILLUMINATION CONTROL SYSTEM : System Description"
Front wiper and washer system	<ul style="list-style-type: none"> WW-13, "FRONT WIPER AND WASHER SYSTEM (WITH LIGHT & RAIN SENSOR) : System Description" (With rain sensor) WW-17, "FRONT WIPER AND WASHER SYSTEM (WITHOUT LIGHT & RAIN SENSOR) : System Description" (Without rain sensor)
Rear wiper and washer system	WW-21, "REAR WIPER AND WASHER SYSTEM : System Description"
Rear window defogger system	DEF-7, "System Description"
Warning chime system	WCS-8, "WARNING CHIME SYSTEM : System Description"
Power door lock system	<ul style="list-style-type: none"> DLK-35, "System Description" (Type 1) DLK-345, "System Description" (Type 2) DLK-646, "System Description" (Type 3) DLK-797, "POWER DOOR LOCK SYSTEM : System Description" (Type 4) <p>NOTE: Refer to DLK-22, "Information" for details of type.</p>
Intelligent Key system	<ul style="list-style-type: none"> DLK-38, "INTELLIGENT KEY SYSTEM : System Description" (Type 1) DLK-348, "INTELLIGENT KEY SYSTEM : System Description" (Type 2) <p>NOTE: Refer to DLK-22, "Information" for details of type.</p>
Remote keyless entry system	<ul style="list-style-type: none"> DLK-649, "REMOTE KEYLESS ENTRY FUNCTION : System Description" (Type 3) DLK-800, "REMOTE KEYLESS ENTRY SYSTEM : System Description" (Type 4) <p>NOTE: Refer to DLK-22, "Information" for details of type.</p>
Back door opener system	<ul style="list-style-type: none"> DLK-62, "System Description" (Type 1) DLK-371, "System Description" (Type 2) DLK-655, "System Description" (Type 3) DLK-803, "BACK DOOR OPENER SYSTEM : System Description" (Type 4) <p>NOTE: Refer to DLK-22, "Information" for details of type.</p>
Intelligent Key system/engine start system	SEC-15, "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description"
Nissan Vehicle Immobilizer System-NATS	<ul style="list-style-type: none"> SEC-25, "NISSAN ANTI-THEFT SYSTEM : System Description" (With Intelligent Key system) SEC-214, "NISSAN ANTI-THEFT SYSTEM : System Description" (Without Intelligent Key system)
Vehicle security system	<ul style="list-style-type: none"> SEC-34, "VEHICLE SECURITY SYSTEM : System Description" (With Intelligent Key system) SEC-217, "VEHICLE SECURITY SYSTEM : System Description" (Without Intelligent Key system)
Power window system	PWC-12, "System Description"
CAN gateway	LAN-110, "System Description"

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

SYSTEM

< SYSTEM DESCRIPTION >

BODY CONTROL SYSTEM : Fail-safe

INFOID:000000011039000

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

Display contents of CONSULT	Fail-safe
B2190-00: CHAIN OF BCM-IMM ANT	Inhibit engine cranking
B2191-00: ID DISCORD, BCM-IMMANT	Inhibit engine cranking
B2192-00: ID DISCORD BCM-ECM	Inhibit engine cranking
B2193-00: CHAIN OF BCM-ECM	Inhibit engine cranking
B2195-00: ANTI-SCANNING	Inhibit engine cranking
B2196-00: DONGLE NG	Inhibit engine cranking
B2198-00: NATS ANTENNA AMP	Inhibit engine cranking
B2557-00: VEHICLE SPEED	Inhibit steering lock
B2602-00: SHIFT POSITION	Inhibit steering lock
B2604-00: PNP/CLUTCH SW	Inhibit steering lock
B2608-00: STARTER RELAY	Inhibit engine cranking
B260F-00: ENG STATE SIG LOST	Inhibit engine cranking
B26F1-00: IGN RELAY OFF	Inhibit engine cranking
B26F2-00: IGN RELAY ON	Inhibit engine cranking
B27D4-00: BCM - S/L SENSOR CIRCUIT	Inhibit steering unlock
B27D5-00: S/L SENSOR TEST OUTPUT	Inhibit steering unlock
B27D6-00: S/L CAN COMM CIRCUIT	Inhibit steering lock
B27D7-00: S/L PWR RELAY	Inhibit steering lock
B27D8-00: S/L VEHICLE SPEED MALFUNCTION	Inhibit steering lock
B27D9-00: S/L IGN MALFUNCTION	Inhibit steering lock/unlock
B27DA-00: IPDM CAN COMM CIRCUIT	Inhibit steering lock
B27DC-00: S/L POWER SUPPLY	Inhibit steering lock
B27DD-00: BCM - S/L ID DISCORD	Inhibit steering lock
B27DE-00: S/L MECHANICAL MALFUNCTION	Inhibit steering lock
B27DF-00: S/L HIGH LEVEL MALFUNCTION	Inhibit steering lock/unlock
B27E0-00: S/L LOW LEVEL MALFUNCTION	Inhibit steering lock
B27E1-00: S/L SAFETY CIRCUIT	Inhibit steering lock
B27E5-00: S/L IGN OFF POSITION	Inhibit steering lock
B27E6-00: S/L ANTI-SCAN MODE	Inhibit steering lock
B27E8-00: S/L UNDETERMINED LOCK POS	Inhibit steering lock
U0415: VEHICLE SPEED	Inhibit steering lock

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

BCM detects the rain sensor serial link error and the rain sensor malfunction.

BCM controls the following fail-safe when rain sensor has a malfunction.

SYSTEM

< SYSTEM DESCRIPTION >

- Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
- Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

NOTE:


When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

COMBINATION SWITCH READING SYSTEM

COMBINATION SWITCH READING SYSTEM : System Description

INFOID:000000010688578

SYSTEM DIAGRAM



JMMIA1753GB

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch status.


COMBINATION SWITCH MATRIX

BCS

SYSTEM

< SYSTEM DESCRIPTION >

Combination switch circuit



JMMIA1754GB

Combination switch INPUT-OUTPUT system list

System	OUTPUT 1	OUTPUT 2	OUTPUT 3	OUTPUT 4	OUTPUT 5
INPUT 1	—	HI BEAM	PASSING	RR FOG	FR FOG
INPUT 2	WIP VOLUME 1	—	HEADLAMP	AUTO LIGHT	TAIL LAMP
INPUT 3	FR WASHER	RR WASHER	—	TURN LH	TURN RH
INPUT 4	FR WIPER LO	FR WIPER HI	FR WIPER INT/AUTO	—	LIGHT OFF
INPUT 5	WIP VOLUME 2	WIP VOLUME 3	RR WIPER INT	RR WIPER ON	—


COMBINATION SWITCH READING FUNCTION

Description

- BCM reads the status of the combination switch at 10 ms interval normally.

NOTE:

BCM reads the status of the combination switch at 60 ms interval when BCM is controlled at low power consumption control mode.




- BCM operates as follows and judges the status of the combination switch.
 - It operates the transistor on OUTPUT side in the following order: OUTPUT 5 → 4 → 3 → 2 → 1, and outputs voltage waveform.
 - The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.

SYSTEM

< SYSTEM DESCRIPTION >

- It reads this change of the voltage as the status signal of the combination switch.




Operation Example

In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TURN RH switch) is turned ON

- The circuit between OUTPUT 5 and INPUT 3 is formed when the TURN RH switch is turned ON.




- BCM detects the combination switch status signal "3E" when the signal of OUTPUT 5 is input to INPUT 3.
- BCM judges that the TURN RH switch is ON when the signal "3E" is detected.

Example 2: When some switches (TURN RH switch, FR WASHER switch) are turned ON

SYSTEM

< SYSTEM DESCRIPTION >

- The circuits between OUTPUT 5 and INPUT 3 and between OUTPUT 1 and INPUT 3 are formed when the TURN RH switch and FR WASHER switch are turned ON.



- BCM detects the combination switch status signal "3AE" when the signals of OUTPUT 1 and OUTPUT 5 are input to INPUT 3.
- BCM judges that the TURN RH switch and FR WASHER switch are ON when the signal "3AE" is detected.

WIPER VOLUME DIAL POSITION

- BCM judges the WIP VOLUME 1 - 4 by the status of WIP VOLUME 1, 2 and 3 switches.

4 clicks type

Wiper volume	Switch status		
	WIP VOLUME 1	WIP VOLUME 2	WIP VOLUME 3
1	ON	ON	OFF
2	ON	OFF	OFF
3	OFF	OFF	OFF
4	OFF	OFF	ON

- BCM judges the WIP VOLUME 1 - 5 by the status of WIP VOLUME 1, 2 and 3 switches.

5 clicks type

Wiper volume	Switch status		
	WIP VOLUME 1	WIP VOLUME 2	WIP VOLUME 3
1	ON	ON	OFF
2	ON	OFF	OFF
3	OFF	OFF	OFF
4	OFF	OFF	ON
5	OFF	ON	ON

NOTE:

For details of wiper volume dial position, refer to [WW-13, "FRONT WIPER AND WASHER SYSTEM \(WITH LIGHT & RAIN SENSOR\) : System Description"](#) (with rain sensor) or [WW-17, "FRONT WIPER AND WASHER SYSTEM \(WITHOUT LIGHT & RAIN SENSOR\) : System Description"](#) (without rain sensor).

SIGNAL BUFFER SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

SIGNAL BUFFER SYSTEM : System Description

INFOID:000000010688579

SYSTEM DIAGRAM



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

OUTLINE

BCM has the signal transmission function that outputs/transmits each input/received signal to each unit.

Signal transmission function list

Signal name	Input	Output	Description
Ignition switch ON signal	Push-button ignition switch (Push switch) (with Intelligent Key system)	<ul style="list-style-type: none">Automatic back door control module (CAN)IPDM E/R (CAN)	Inputs the push-button ignition switch (push switch) signal and transmits the ignition switch status judged with BCM via CAN communication.
	Ignition switch (without Intelligent Key system)		Inputs the ignition switch signal and transmits the ignition switch status judged with BCM via CAN communication.
Door switch signal	Any door switch	<ul style="list-style-type: none">Around view monitor control unit (CAN)Combination meter (CAN)	Inputs the door switch signal and transmits it via CAN communication.

POWER CONSUMPTION CONTROL SYSTEM

BCS

N
O
P


SYSTEM

< SYSTEM DESCRIPTION >

POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:0000000010688580

SYSTEM DIAGRAM



OUTLINE

- BCM incorporates a power saving control function that reduces the power consumption according to the vehicle status.
- BCM switches the status (control mode) by itself with the power saving control function. It performs the sleep request to each unit (IPDM E/R, combination meter, automatic back door control module and electric parking brake control module) that operates with the ignition switch OFF.

Normal mode (wake-up)

- CAN communication is normally performed with other units
- Each control with BCM is operating properly

CAN communication sleep mode (CAN sleep)

- CAN transmission is stopped
- Control with BCM only is operating

Low power consumption mode (BCM sleep)

- Low power consumption control is active
- CAN transmission is stopped

LOW POWER CONSUMPTION CONTROL WITH BCM

BCM reduces the power consumption with the following operation in the low power consumption mode.

- The reading interval of the each switches changes from 10 ms interval to 60 ms interval.

Sleep mode activation

- BCM receives the sleep-ready signal (ready) from IPDM E/R, combination meter and AV control unit via CAN communication.
- BCM transmits the sleep wake up signal (sleep) to each unit when all of the CAN sleep conditions are fulfilled.
- Each unit stops the transmission of CAN communication with the sleep wake up signal. BCM is in CAN communication sleep mode.
- BCM is in the low power consumption mode and perform the low power consumption control when all of the BCM sleep conditions are fulfilled with CAN sleep condition.

SYSTEM

< SYSTEM DESCRIPTION >

Sleep condition

CAN sleep condition	BCM sleep condition
Receiving the sleep-ready signal (ready) from all units	<ul style="list-style-type: none"> • Ignition switch^{*1}: LOCK or OFF • Push-button ignition switch (push switch)^{*2}: No change 2 seconds • Warning chime: Not operation • Intelligent Key warning buzzer^{*2}: Not operation • Stop lamp switch: OFF • Turn signal indicator lamp: Not operation • Exterior lamp: OFF • Door lock status: No change • Meter display signal: Non-transmission • Door switch status: No change 2 seconds • Back door opener switch status: No change 2 seconds • Rear window defogger: OFF • RAP system: OFF • CONSULT communication status: Not communication

*1: Without Intelligent Key system

*2: With Intelligent Key system

Wake-up operation

- BCM transmits sleep wake up signal (wake up) to each unit when any condition listed below is established, and then goes into normal mode from low power consumption mode.
- Each unit starts transmissions with CAN communication by receiving sleep wake up signals.

Wake-up condition

Wake-up condition
<ul style="list-style-type: none"> • Receiving the sleep-ready signal (Not-ready) from any units • Ignition switch^{*1}: OFF → ON or START • Key switch^{*1}: OFF → ON, ON → OFF • Push-button ignition switch (push switch)^{*2}: OFF → ON • Hazard switch: OFF → ON, ON → OFF • HI BEAM switch: OFF → ON, ON → OFF • PASSING switch: OFF → ON, ON → OFF • HEADLAMP switch: OFF → ON, ON → OFF • TAIL LAMP switch: OFF → ON • FR FOG switch: OFF → ON, ON → OFF • RR FOG switch: OFF → ON, ON → OFF • Driver door switch: OFF → ON, ON → OFF • Passenger door switch: OFF → ON, ON → OFF • Rear RH door switch: OFF → ON, ON → OFF • Rear LH door switch: OFF → ON, ON → OFF • Back door switch: OFF → ON, ON → OFF • Driver door request switch: OFF → ON • Passenger door request switch: OFF → ON • Back door opener switch: OFF → ON • Back door opener request switch: OFF → ON • Stop lamp switch: OFF → ON • Front door lock assembly (driver side) (unlock sensor): OFF → ON, ON → OFF • Remote keyless entry receiver communication: Receiving • Door lock and unlock switch: NEUTRAL → LOCK, NEUTRAL → UNLOCK

*1: Without Intelligent Key system

*2: With Intelligent Key system

SHIPPING MODE CONTROL SYSTEM

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P


SYSTEM

< SYSTEM DESCRIPTION >

SHIPPING MODE CONTROL SYSTEM : System Description

INFOID:0000000010688581

SYSTEM DIAGRAM



JMMIA1403GB

DESCRIPTION

- BCM switches the status (shipping mode or normal mode) by itself according to the extended storage fuse switch condition, and transmits shipping mode status signal to combination meter and each unit via CAN communication.
- When shipping mode function operates, each control unit does not detect DTCs.
- BCM control functions are limited in shipping mode. Refer to [BCS-120, "Description"](#).
- The combination meter displays extended storage fuse warning message* on the information display, and turns the turn signal indicator lamp (LH/RH) ON, when BCM is in shipping mode.

*: When shipping mode function operates, "SHIPPING MODE ON PUSH STORAGE FUSE" is displayed.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000010688582

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> • Read and save the vehicle specification. • Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Exterior lamp	HEAD LAMP	×	×	×
Interior room lamp control	INT LAMP		×	
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	
—	AIR CONDITIONER*		×	×
Intelligent Key system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU		×	
Interior room lamp battery saver	BATTERY SAVER		×	
Back door open	TRUNK		×	
Vehicle security	THEFT ALM	×	×	
RAP	RETAINED PWR		×	
Remote keyless entry system	MULTI REMOTE ENT	×	×	
Signal buffer system	SIGNAL BUFFER		×	×

NOTE:

*: This item is displayed, but not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description
BATTERY VOLTAGE	V	Battery voltage of the moment a particular DTC is detected.
VEHICLE SPEED	km/h	Vehicle speed of the moment a particular DTC is detected.
EXTERNAL TEMP	°C	External temperature of the moment a particular DTC is detected
VEHICLE COND	—	NOTE: This item is displayed, but cannot be used this item.
DOOR LOCK STATUS	—	NOTE: This item is displayed, but cannot be used this item.
POWER SUPPLY COUNTER	min	Displays the cumulative time from the time that the battery terminal is connected.

DOOR LOCK

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (With Intelligent Key System and Super Lock)

INFOID:0000000011008704

BCM CONSULT FUNCTION

CONSULT performs the following functions via CAN communication with BCM.

WORK SUPPORT

Monitor item	Description
DOOR LOCK-UNLOCK SET	Anti-hijack function mode can be changed to operation with this mode • On: Operate • Off: Non-operation
AUTO UNLOCK TYPE	NOTE: This item is displayed, but cannot be used
SIGNATURE LIGHT SETTING	Signature light function can be changed to operation with this mode • On: Operate • Off: Non-operation

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
REQ SW-DR	Indicated [On/Off] condition of door request switch (driver side)
REQ SW-AS	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW-BD/TR	Indicated [On/Off] condition of back door request switch
DOOR SW-DR	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK	Indicated [On/Off] condition of back door switch
CDL LOCK SW	Indicated [On/Off] condition of lock signal from door lock unlock switch
CDL UNLOCK SW	Indicated [On/Off] condition of unlock signal from door lock unlock switch
KEY CYL LK-SW	NOTE: This item is displayed, but cannot be monitored
KEY CYL UN-SW	NOTE: This item is displayed, but cannot be monitored

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Contents
SHOCK SENSOR	NOTE: This item is displayed, but cannot be monitored
KEY SW	NOTE: This item is displayed, but cannot be monitored

ACTIVE TEST

Test item	Description
DOOR LOCK	This test is able to check door lock/unlock operation • The all door lock actuators are locked when "ALL LOCK" on CONSULT screen is touched • The all door lock actuators are unlocked when "ALL UNLK" on CONSULT screen is touched
SUPER LOCK	This test is able to check super lock actuator operation • The all door lock actuators are set when "LOCK" on CONSULT screen is touched • The all door lock actuators are released when "UNLOCK" on CONSULT screen is touched
DOOR LOCK IND	This test is able to check door lock status indicator operation • On: Operate • Off: Non-operation

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (With Intelligent Key System, Without Super Lock)

INFOID:0000000011008705

BCM CONSULT FUNCTION

CONSULT performs the following functions via CAN communication with BCM.

WORK SUPPORT

Monitor item	Description
DOOR LOCK-UNLOCK SET	Anti-hijack function mode can be changed to operation with this mode • On: Operate • Off: Non-operation
AUTO UNLOCK TYPE	NOTE: This item is displayed, but cannot be used
SIGNATURE LIGHT SETTING	Signature light function can be changed to operation with this mode • On: Operate • Off: Non-operation

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

BCS

Monitor Item	Contents
REQ SW-DR	Indicated [On/Off] condition of door request switch (driver side)
REQ SW-AS	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW-BD/TR	Indicated [On/Off] condition of back door request switch
DOOR SW-DR	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK	Indicated [On/Off] condition of back door switch
CDL LOCK SW	Indicated [On/Off] condition of lock signal from door lock unlock switch
CDL UNLOCK SW	Indicated [On/Off] condition of unlock signal from door lock unlock switch
KEY CYL LK-SW	NOTE: This item is displayed, but cannot be monitored

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Contents
KEY CYL UN-SW	NOTE: This item is displayed, but cannot be monitored
SHOCK SENSOR	NOTE: This item is displayed, but cannot be monitored
KEY SW	NOTE: This item is displayed, but cannot be monitored

ACTIVE TEST

Test item	Description
DOOR LOCK	This test is able to check door lock/unlock operation <ul style="list-style-type: none"> The all door lock actuators are locked when "ALL LOCK" on CONSULT screen is touched The all door lock actuators are unlocked when "ALL UNLK" on CONSULT screen is touched
SUPER LOCK	NOTE: This item is displayed, but cannot be used
DOOR LOCK IND	NOTE: This item is displayed, but cannot be used

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (Without Intelligent Key System, With Super Lock)

INFOID:000000011008706

WORK SUPPORT

Monitor item	Description
DOOR LOCK-UNLOCK SET	Selective unlock function mode can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
AUTO UNLOCK TYPE	NOTE: This item is displayed, but cannot be used
SIGNATURE LIGHT SETTING	Signature light function can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
DOOR SW-DR	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK	Indicated [On/Off] condition of back door switch
CDL LOCK SW	Indicated [On/Off] condition of lock signal from door lock unlock switch
CDL UNLOCK SW	Indicated [On/Off] condition of unlock signal from door lock unlock switch
KEY CYL LK-SW	NOTE: This item is displayed, but cannot be monitored
KEY CYL UN-SW	NOTE: This item is displayed, but cannot be monitored
SHOCK SENSOR	NOTE: This item is displayed, but cannot be monitored
KEY SW	Indicated [On/Off] condition of key switch

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

ACTIVE TEST

Test item	Description
DOOR LOCK	<p>This test is able to check door lock/unlock operation</p> <ul style="list-style-type: none"> • The all door lock actuators are locked when "ALL LOCK" on CONSULT screen is touched • The all door lock actuators are unlocked when "ALL UNLK" on CONSULT screen is touched
SUPER LOCK	<p>This test is able to check super lock actuator operation</p> <ul style="list-style-type: none"> • The all door lock actuators are set when "LOCK" on CONSULT screen is touched • The all door lock actuators are released when "UNLOCK" on CONSULT screen is touched
DOOR LOCK IND	<p>This test is able to check door lock status indicator operation</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) (Without Intelligent Key System and Super Lock)

INFOID:000000011008707

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

WORK SUPPORT

Monitor item	Description
DOOR LOCK-UNLOCK SET	<p>Selective unlock function mode can be changed to operation with this mode</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
AUTO UNLOCK TYPE	<p>NOTE: This item is displayed, but cannot be used</p>
SIGNATURE LIGHT SETTING	<p>Signature light function can be changed to operation with this mode</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
DOOR SW-DR	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK	Indicated [On/Off] condition of back door switch
CDL LOCK SW	Indicated [On/Off] condition of lock signal from door lock unlock switch
CDL UNLOCK SW	Indicated [On/Off] condition of unlock signal from door lock unlock switch
KEY CYL LK-SW	<p>NOTE: This item is displayed, but cannot be monitored</p>
KEY CYL UN-SW	<p>NOTE: This item is displayed, but cannot be monitored</p>
SHOCK SENSOR	<p>NOTE: This item is displayed, but cannot be monitored</p>
KEY SW	Indicated [On/Off] condition of key switch

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Description
DOOR LOCK	<p>This test is able to check door lock/unlock operation</p> <ul style="list-style-type: none"> The all door lock actuators are locked when "ALL LOCK" on CONSULT screen is touched The all door lock actuators are unlocked when "ALL UNLK" on CONSULT screen is touched
SUPER LOCK	<p>NOTE: This item is displayed, but cannot be monitored</p>
DOOR LOCK IND	<p>NOTE: This item is displayed, but cannot be monitored</p>

MULTI REMOTE ENT

MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT) (With Super Lock)

INFOID:000000011008710

WORK SUPPORT

Test item	Description
AUTO LOCK SET	<p>Auto door lock time can be changed in this mode</p> <ul style="list-style-type: none"> MODE 1: Non-operation MODE 2: 30 sec. MODE 3: 1 minute MODE 4: 2 minute MODE 5: 3 minute MODE 6: 4 minute MODE 7: 5 minute
ANSWER BACK	<p>NOTE: This item is displayed, but cannot be used</p>
ANSWER BACK KEYLESS LOCK UNLOCK	<p>NOTE: This item is displayed, but cannot be used</p>
WELCOME LIGHT OP SET	<p>NOTE: This item is displayed, but cannot be used</p>

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
CONFIRM ID ALL	
CONFIRM ID4	
CONFIRM ID3	Indicates [Yet] at all time. Switches to [Done] when a registered key is inserted into ignition key cylinder.
CONFIRM ID2	
CONFIRM ID1	
NOT REGISTERED	Indicates [ID OK] when key ID that is registered is received or is not yet received. Indicates [ID NG] when key ID that is not registered is received.
TP 4	
TP 3	
TP 2	Indicates the number of IDs that are registered.
TP 1	
CLUTCH SW*1	Indicates [On/Off] condition of clutch interlock switch
BRAKE SW 1	Indicates [On/Off]*2 condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
START CLUTCH SW	Indicates [On/Off] condition of clutch pedal position switch

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
STOP/START SW	Indicates [On/Off] condition of stop/start off switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from keyfob
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from keyfob
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored
RKE-PANIC	NOTE: This item is displayed, but cannot be monitored
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from keyfob
KEY SW	Indicates [On/Off] condition of key switch
IGN SW	Indicates [On/Off] condition of ignition switch in ON position
START SW	Indicates [On/Off] condition of ignition switch in START position

*¹: It is displayed but does not operate on CVT models.

*²: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
FLASHER	This test is able to check flasher operation [LH/RH/Off]
HORN	NOTE: This item is displayed, but cannot be used
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
MIRROR+5	NOTE: This item is displayed, but cannot be used
TRUNK/BACK DOOR	NOTE: This item is displayed, but cannot be used
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used
AUTO ACC 2	This test is able to check BCM sends power supply to audio unit or NAVI control unit <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
AUTO ACC 1	This test is able to check BCM sends power supply to ignition relay <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk/luggage room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation

MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT) (Without Super Lock)

INFOID:000000011008713

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Description
AUTO LOCK SET	Auto door lock time can be changed in this mode <ul style="list-style-type: none"> • MODE 1: Non-operation • MODE 2: 30 sec. • MODE 3: 1 minute • MODE 4: 2 minute • MODE 5: 3 minute • MODE 6: 4 minute • MODE 7: 5 minute
ANSWER BACK	NOTE: This item is displayed, but cannot be used
ANSWER BACK KEYLESS LOCK UNLOCK	NOTE: This item is displayed, but cannot be used
WELCOME LIGHT OP SET	NOTE: This item is displayed, but cannot be used

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
CONFIRM ID ALL	
CONFIRM ID4	
CONFIRM ID3	Indicates [Yet] at all time. Switches to [Done] when a registered key is inserted into ignition key cylinder.
CONFIRM ID2	
CONFIRM ID1	
NOT REGISTERED	Indicates [ID OK] when key ID that is registered is received or is not yet received. Indicates [ID NG] when key ID that is not registered is received.
TP 4	
TP 3	
TP 2	Indicates the number of IDs that are registered.
TP 1	
CLUTCH SW ^{*1}	Indicates [On/Off] condition of clutch interlock switch
BRAKE SW 1	Indicates [On/Off] ^{*2} condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
START CLUTCH SW	Indicates [On/Off] condition of clutch pedal position switch
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
STOP/START SW	Indicates [On/Off] condition of stop/start off switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from keyfob
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from keyfob
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored
RKE-PANIC	NOTE: This item is displayed, but cannot be monitored
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from keyfob

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
KEY SW	Indicates [On/Off] condition of key switch
IGN SW	Indicates [On/Off] condition of ignition switch in ON position
START SW	Indicates [On/Off] condition of ignition switch in START position

*1: It is displayed but does not operate on CVT models.

*2: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
FLASHER	This test is able to check flasher operation [LH/RH/Off]
HORN	NOTE: This item is displayed, but cannot be used
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) <ul style="list-style-type: none"> On: Operates Off: Non-operation
MIRROR+5	NOTE: This item is displayed, but cannot be used
TRUNK/BACK DOOR	NOTE: This item is displayed, but cannot be used
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used
AUTO ACC 2	This test is able to check BCM sends power supply to audio unit or NAVI control unit <ul style="list-style-type: none"> On: Operate Off: Non-operation
AUTO ACC 1	This test is able to check BCM sends power supply to ignition relay <ul style="list-style-type: none"> On: Operate Off: Non-operation
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk/luggage room lamp operation <ul style="list-style-type: none"> On: Operates Off: Non-operation

REAR WINDOW DEFOGGER

REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:0000000011008741

WORK SUPPORT

Service item	Setting item	Description
SET R-DEF TIMER	MODE1*	NOTE: Do not use this function.
	MODE2	
	MODE3	

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Description
PUSH SW	Indicates [On/Off] condition of push switch
REAR DEF SW	Displays "Press (On)/other (Off)" status determined with the rear window defogger switch

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test Item	Description
REAR DEFOGGER	Rear window defogger operates when "On" on CONSULT screen is touched

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:0000000011008744

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Display item [Unit]	Description
PUSH SW [On/Off]	Status of push-button ignition switch judged by BCM.
VEH SPEED 1 [km/h]	Value of vehicle speed signal received from combination meter with CAN communication line.
TAIL LAMP SW [On/Off]	Status of lighting switch judged by BCM using the combination switch readout function.
FR FOG SW [On/Off]	Status of front fog lamp switch judged by BCM using the combination switch readout function.
DOOR SW-DR [On/Off]	Status of driver side door switch judged by BCM.
CDL LOCK SW [On/Off]	Status of door lock unlock switch judged by BCM.

ACTIVE TEST

Display item [Unit]	Description
IGN KEY WARN ALM	The key warning chime operation can be checked by operating the relevant function (On/Off).
SEAT BELT WARN TEST	This item is displayed, but cannot be monitored.
LIGHT WARN ALM	The light warning chime operation can be checked by operating the relevant function (On/Off).
REVERSE WARNING	This item is displayed, but cannot be monitored.

NOTE:

Some items are not available according to vehicle specification.

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:0000000011008729

WORK SUPPORT

Service item	Setting item	Setting
SET I/L D-UNLCK INTCON	On*	With interior room lamp timer function
	Off	Without interior room lamp timer function
FOG LAMP OVERRIDE	On*	With fog override function
	Off	Without fog override function

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW-AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	Indicated [On/Off] condition of back door switch
CDL LOCK SW [On/Off]	Indicated [On/Off] condition of lock signal from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Indicated [On/Off] condition of unlock signal from door lock and unlock switch
KEY CYL LK-SW [On/Off]	NOTE: This item is displayed, but cannot be monitored
KEY CYL UN-SW [On/Off]	NOTE: This item is displayed, but cannot be monitored
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key or keyfob
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key or keyfob
KEY SW [On/Off]	Indicates [On/Off] condition of key switch

ACTIVE TEST

Test item	Operation	Description
INT LAMP	On	Outputs interior room lamp control signal.
	Off	Stops interior room lamp control signal.

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP) (LED Headlamp) INFOID:0000000011010965

WORK SUPPORT

Service item	Setting item	Setting
CUSTOM A/LIGHT SETTING	MODE1*	Normal
	MODE2	More sensitive setting than normal setting (Turns ON earlier than normal operation)
	MODE3	More sensitive setting than MODE2 (Turns ON earlier than MODE2)
	MODE4	Less sensitive setting than normal setting (Turns ON later than normal operation)
TWILIGHT On	MODE1	NOTE:
	MODE2	This item is displayed, but cannot be used

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Service item	Setting item	Setting
WIPER LINK	MODE1	NOTE: This item is displayed, but cannot be used
	MODE2	
	MODE3	
	MODE4	

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates [STOP/STALL/CRANK/RUN] condition of engine states
VEH SPEED 1 [km/h]	Indicates [km/h] condition of vehicle speed signal from combination meter
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEADLAMP SW [On/Off]	
LIGHT OFF SW [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
RR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	Indicated [On/Off] condition of back door switch
OPTI SEN (DTCT) [V]	NOTE: This item is displayed, but cannot be monitored

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
OPTI SEN (FILT) [V]	NOTE: This item is displayed, but cannot be monitored
OPTICAL SENSOR [On/Off/NG]	The sensor condition received from light & rain sensor

ACTIVE TEST

Test item	Operation	Description
FR FOG LAMP	On	<ul style="list-style-type: none"> Transmits the front fog light request signal to IPDM E/R via CAN communication to turn the front fog lamp ON Transmits the front fog light request signal to combination meter via CAN communication to turn the front fog lamp indicator lamp ON
	Off	Stops the front fog light request signal transmission
RR FOG LAMP	On	<ul style="list-style-type: none"> Outputs voltage to turn the rear fog lamp ON Transmits the rear fog lamp status signal to combination meter via CAN communication to turn the rear fog lamp indicator lamp ON
	Off	<ul style="list-style-type: none"> Stops the voltage to turn the rear fog lamp OFF Stops the rear fog lamp status signal transmission
STOP LAMP 1	On	Outputs voltage to turn the stop lamp RH ON
	Off	Stops the voltage to turn the stop lamp RH OFF
STOP LAMP 2	On	Outputs voltage to turn the stop lamp LH ON
	Off	Stops the voltage to turn the stop lamp LH OFF
STOP LAMP 3	On	Outputs voltage to turn the high-mounted stop lamp ON
	Off	Stops the voltage to turn the high-mounted stop lamp OFF
DAYTIME RUNNING LIGHT	On	Transmits the daytime running light request signal to IPDM E/R using CAN communication to turn the daytime running light ON
	Off	Stops the daytime running light request signal transmission
ILL DIM SIGNAL*	On	Transmits the dimmer signal to NAVI control unit and dims display
	Off	Stops the dimmer signal transmission

*: For models without navigation, this item is displayed, but cannot be tested.

HEADLAMP : CONSULT Function (BCM - HEAD LAMP) (Halogen Headlamp)

INFOID:0000000011008727

WORK SUPPORT

Service item	Setting item	Setting
CUSTOM A/LIGHT SETTING	MODE1*	Normal
	MODE2	More sensitive setting than normal setting (Turns ON earlier than normal operation)
	MODE3	More sensitive setting than MODE2 (Turns ON earlier than MODE2)
	MODE4	Less sensitive setting than normal setting (Turns ON later than normal operation)
TWILIGHT On	MODE1	
	MODE2	NOTE: This item is displayed, but cannot be used
WIPER LINK	MODE1	
	MODE2	
	MODE3	NOTE: This item is displayed, but cannot be used
	MODE4	

*: Factory setting

DATA MONITOR

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates [STOP/STALL/CRANK/RUN] condition of engine states
VEH SPEED 1 [km/h]	Indicates [km/h] condition of vehicle speed signal from combination meter
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEADLAMP SW [On/Off]	
LIGHT OFF SW [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW ^{*1} [On/Off]	
FR FOG SW ^{*2} [On/Off]	
RR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	Indicated [On/Off] condition of back door switch
OPTI SEN (DTCT) [V]	NOTE: This item is displayed, but cannot be monitored
OPTI SEN (FILT) [V]	NOTE: This item is displayed, but cannot be monitored
OPTICAL SENSOR ^{*1} [On/Off/NG]	The sensor condition received from light & rain sensor

^{*1}: For models without auto light system, this item is displayed, but cannot be monitored.

^{*2}: For models without front fog lamp, this item is displayed, but cannot be monitored.

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Operation	Description
FR FOG LAMP* ¹	On	<ul style="list-style-type: none"> Transmits the front fog light request signal to IPDM E/R via CAN communication to turn the front fog lamp ON Transmits the front fog light request signal to combination meter via CAN communication to turn the front fog lamp indicator lamp ON
	Off	Stops the front fog light request signal transmission
RR FOG LAMP	On	<ul style="list-style-type: none"> Outputs voltage to turn the rear fog lamp ON Transmits the rear fog lamp status signal to combination meter via CAN communication to turn the rear fog lamp indicator lamp ON
	Off	<ul style="list-style-type: none"> Stops the voltage to turn the rear fog lamp OFF Stops the rear fog lamp status signal transmission
STOP LAMP 1	On	Outputs voltage to turn the stop lamp RH ON
	Off	Stops the voltage to turn the stop lamp RH OFF
STOP LAMP 2	On	Outputs voltage to turn the stop lamp LH ON
	Off	Stops the voltage to turn the stop lamp LH OFF
STOP LAMP 3	On	Outputs voltage to turn the high-mounted stop lamp ON
	Off	Stops the voltage to turn the high-mounted stop lamp OFF
DAYTIME RUNNING LIGHT	On	Transmits the daytime running light request signal to IPDM E/R using CAN communication to turn the daytime running light ON
	Off	Stops the daytime running light request signal transmission
ILL DIM SIGNAL* ²	On	Transmits the dimmer signal to NAVI control unit and dims display
	Off	Stops the dimmer signal transmission

*¹: For models without front fog lamp, this item is displayed, but cannot be tested.

*²: For models without navigation, this item is displayed, but cannot be tested.

WIPER

WIPER : CONSULT Function - WIPER

INFOID:000000011008738

WORK SUPPORT

Service item	Setting item	Description	
WIPER SPEED SETTING* ¹	On* ³	Linked with vehicle speed (Front wiper intermittent time linked with the vehicle speed and wiper volume dial position.)	The setting of front wiper INT operation can be changed.
	Off	Not linked with vehicle speed (Front wiper intermittent time linked with the wiper volume dial position.)	
RAIN SENSOR* ²	On* ³	Linked with light & rain sensor (Front wiper intermittent time linked with the light & rain sensor, vehicle speed, and wiper volume dial position)	The setting of front wiper AUTO operation can be changed
	Off	Not linked with light & rain sensor (Front wiper intermittent time linked with the vehicle speed and wiper volume dial position)	
FR RR DRIP	On* ³	Front wiper drop wipe and rear wiper drop wipe operation ON	The setting of drop wipe operation can be changed
	Off	Front wiper drop wipe and rear wiper drop wipe operation OFF	
REAR WIPER LINK WITH REVERSE SETTING	On	Rear wiper operation linked with reverse ON	The setting of rear wiper operation linked with reverse can be changed
	Off* ³	Rear wiper operation linked with reverse OFF	

*¹: For models without light & rain sensor

*²: For models with light & rain sensor

*³: Factory setting

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	Description
PUSH SW [Off/On]	The switch status input from push-button ignition switch.
VEH SPEED 1 [km/h]	Displays the value of the vehicle speed signal received from combination meter via CAN communication.
FR WIPER HI [Off/On]	Status of each switch judged by BCM using the combination switch reading function.
FR WIPER LOW [Off/On]	
FR WASHER SW [Off/On]	
FR WIPER INT [Off/On]	
FR WIPER STOP [Off/On]	Displays the status of the front wiper stop position signal received from IPDM E/R via CAN communication.
INT VOLUME [1 – 7]	Status of each switch judged by BCM using the combination switch reading function.
RR WIPER ON [Off/On]	Status of each switch judged by BCM using the combination switch reading function.
RR WIPER INT [Off/On]	
RR WASHER SW [Off/On]	
RR WIPER STOP [Off/On]	
H/L WSR SW* [Off/On]	Status of headlamp washer switch judged by BCM.
RAIN SENSOR [OFF/LOW/HIGH/SPLASH/NG]	Request signal from light & rain sensor detected by BCM is displayed.

*: For models without headlamp washer switch, this item is indicated but is not used.

ACTIVE TEST

Test item	Operation	Description
FR WIPER	Hi	Operates the front wiper HI operation.
	Lo	Operates the front wiper LO operation.
	INT	Operates the front wiper INT/AUTO operation.
	Off	Stops the front wiper operation.
RR WIPER	On	Operates the rear wiper operation.
	Off	Stops the rear wiper operation.
HEADLAMP WASHER*	On	Operates the headlamp washer operation.

*: For models without headlamp washer, this item is indicated but is not used.

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER) (LED Headlamp)

INFOID:0000000011010966

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Service item	Setting item	Setting
3-TIME FLASHER SETTING	On*	With 3-time flasher function
	Off	Without 3-time flasher function

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-PANIC [On/Off]	NOTE: This item is displayed, but cannot be monitored

FLASHER : CONSULT Function (BCM - FLASHER) (Halogen Headlamp)

INFOID:0000000011008728

WORK SUPPORT

Service item	Setting item	Setting
3-TIME FLASHER SETTING	On*	With 3-time flasher function
	Off	Without 3-time flasher function

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key or keyfob
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key or keyfob
RKE-PANIC [On/Off]	NOTE: This item is displayed, but cannot be monitored

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (With Super Lock)

INFOID:0000000011008715

WORK SUPPORT

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operation in this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
TRUNK/GLASS HATCH OPEN	NOTE: This item is displayed, but cannot be monitored
AUTO LOCK SET	Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"> MODE 1: OFF MODE 2: 30 sec MODE 3: 1 minute MODE 4: 2 minutes MODE 5: 3 minutes MODE 6: 4 minutes MODE 7: 5 minutes
SHORT CRANKING OUTPUT	NOTE: This item is displayed, but cannot be monitored
IGN/ACC BATTERY SAVER	Ignition battery saver system mode can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
ANSWER BACK	NOTE: This item is displayed, but cannot be used
ANSWER BACK I-KEY LOCK UN-LOCK	NOTE: This item is displayed, but cannot be monitored
ANSWER BACK KEYLESS LOCK UNLOCK	NOTE: This item is displayed, but cannot be monitored

SELF-DIAG RESULT

Refer to [BCS-78, "DTC Index"](#).

DATA MONITOR

NOTE:

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of back door request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
CLUTCH SW ^{*1}	Indicates [On/Off] condition of clutch interlock switch
BRAKE SW 1	Indicates [On/Off] ^{*2} condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
START CLUTCH SW	Indicates [On/Off] condition of clutch pedal position switch
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
NEUTRAL SW - IPDM	Indicates [On/Off] condition of reverse/neutral position switch
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
STARTER RELAY - IPDM	Indicates [On/Off] condition of starter relay
ENGINE STATE	Indicates [Stop/Stall/Crank/Run] condition of engine states
ST/INHIRELAY-IPDM	Display the starter relay/starter control relay status signal from IPDM E/R via CAN communication
REVERSE SIGNAL - IPDM	Indicates [On/Off] condition of R position
CRANKING PERMIT - ECM	Display the engine cranking permit signal from ECM via CAN communication
IS STATUS - ECM	Indicates [On/Off] condition of stop/start system
STARTER CUT RELAY - ECM	Indicates [On/Off] condition of starter control relay signal from ECM via CAN communication
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [Km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS actuator and electric unit (control unit) by numerical value [Km/h]
IGN REQ - IPDM	Display the ignition request signal from IPDM E/R via CAN communication
STARTER REQ - IPDM	Display the starter request signal from IPDM E/R via CAN communication
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
ID OK FLAG	Indicates [Set/Reset] condition of Intelligent Key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored
I-KEY OK FLAG	Indicates [KEY On/NOT On] condition of Intelligent Key ID and Intelligent Key is detected inside vehicle
PRBT ENG STRT	Indicates whether or not the engine is in start prohibited status
ID AUTHENT CANCEL TIMER	Indicates whether or not it is in engine start possible status when Intelligent Key verification is unnecessary
ACC BATTERY SAVER	Indicates [On/Off] whether or not ignition battery saver is in operation
CRNK PRBT TMR	Indicates [On/Off] whether or not in cranking prohibited status due to starter motor protection function operation

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
AUT CRANK TMR	Indicates [On/Off] whether or not in AUTO CRANKING MODE status
CRNK PRBT TME	Indicates the time for changing from cranking prohibited status to cranking possible status
AUT CRANK TMR	Indicates the time that AUTO CRANKING MODE operates
CRANKING TME	Indicates the cranking operation time
SHORT CRANK	NOTE: This item is displayed, but not used
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored
S/L IGN OFF POSITION	Indicates [On/Off] condition of Ignition OFF signal
S/L SENSOR CIRCUIT 1	Indicates [Gnd/On] condition of steering lock unit sensor circuit
S/L SENSOR CIRCUIT 2	Indicates [On/Off] condition of steering lock unit sensor circuit
S/L POWER OUTPUT	Indicates [On/Off] condition of steering lock unit power supply
S/L POWER CHECK	Indicates [On/Off] condition of steering lock unit power supply
ANTICIPATED POWER	Indicates [On/Off] condition of anticipated power supply
S/L LOCK REQ	Indicates [On/Off] condition of steering lock unit lock request signal
S/L - BCM (CAN)	Indicates [On/Off] condition of CAN communication
S/L POWER ERROR	Indicates [On/Off] condition of steering lock unit power supply error
VEH SPEED ERROR (S/L)	Indicates [On/Off] condition of vehicle speed signal
VEH SPEED NORMAL (S/L)	Indicates [On/Off] condition of vehicle speed signal
ENGINE RUNNING (S/L)	Indicates [On/Off] condition of engine running
S/L ID DISCORD	Indicates [Correct/Incorrect] condition of ID verification
S/L ANTI-SCAN MODE	Indicates [On/Off] condition of antiscan mode
S/L LOCK NOT PERMIT	Indicates [Inhibition/No inhibt] condition of inhibit steering lock
S/L UNLOCK (CAN)	Indicates [Finished/Unfinished] condition of steering lock unit unlock
S/L ID STATUS (CAN)	Indicates [Coded/Blank] condition of registration ID
S/L RESET STATUS (CAN)	Indicates [Exit/No exit] condition of steering lock unit reset signal
S/L LO-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of lo-level malfunction
S/L LOCK POSITION (CAN)	Indicates [Armed/Malf/Unlocked/Undefined] condition of lock/unlock position signal
S/L ACT MALFUNCTION (CAN)	Indicates [Malf/No malf] condition of steering lock unit malfunction
S/L HI-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of hi-level malfunction
S/L OPERATION PRHBT (SPD)	Indicates [On/Off] condition of vehicle speed signal
S/L OPERATION PRHBT (PWR)	Indicates [Allowed/Forbid] condition of safety line inhibition
S/L SENSOR POWER (CAN)	Indicates [On/Off] condition of sensor test power supply
S/L SEN TEST PERMIT (CAN)	Indicates [Forbid/Authorize] condition of sensor test
S/L STAT NOT DETECT (CAN)	Indicates [Ok/Undefind] condition of steering lock undefined position signal
S/L LOCKING FINISHED (CAN)	Indicates [Unfinshd/Finished] condition of steering lock unit lock status signal
STOP/START SW	Indicates [On/Off] condition of stop/start off switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored
RKE-PANIC	NOTE: This item is displayed, but cannot be monitored

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from Intelligent Key
RKE PBD	Indicates [On/Off] condition of back door open request signal from Intelligent Key
KEY SW	NOTE: This item is displayed, but cannot be monitored
IGN SW	NOTE: This item is displayed, but cannot be monitored
START SW	NOTE: This item is displayed, but cannot be monitored

*¹: It is displayed but does not operate on CVT models.

*²: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation • On: Operate • Off: Non-operation
INSIDE BUZZER	This test is able to check warning chime in combination meter operation • Buzzer 1: Combination meter buzzer sounds (pipipi...) when CONSULT screen is touched • Buzzer 2: Combination meter buzzer sounds (pipi-pipi...) when CONSULT screen is touched • Buzzer 3: Combination meter buzzer sounds (pipipipi-pipipipi...) when CONSULT screen is touched • Off: Non-operation
INDICATOR	This test is able to check warning lamp operation • KEY ON: [Intelligent Key system malfunction] displays when CONSULT screen is touched • KEY IND: "KEY" Warning lamp blinks when CONSULT screen is touched • Off: Non-operation
FLASHER	This test is able to check security hazard lamp operation The hazard lamps are activated after "LH/RH/Off" on CONSULT screen is touched
HORN	NOTE: This item is displayed, but cannot be used
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) • On: Operates • Off: Non-operation
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "ON" on CONSULT screen is touched
ENGINE START REQUEST	This test is able to check BCM sends starter request signal to IPDM E/R via CAN communication • MODE 1: IGN ON, START request OFF • MODE 2: IGN OFF, START request ON • MODE 3: IGN ON, START request ON • Off: Non-operation
IGNITION RELAY	NOTE: This item is displayed, but cannot be used
STARTER CUT RELAY	This test is able to operate the starter control relay • On: Operates • Off: Non-operation
ENGINE START	NOTE: This item is displayed, but cannot be used
TRUNK/BACK DOOR	NOTE: This item is displayed, but cannot be used
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Description
AUTO ACC 2	This test is able to check BCM sends power supply to audio unit or NAVI control unit <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
AUTOMATIC BACK DOOR	NOTE: This item is displayed, but cannot be used
AUTO ACC 1	This test is able to check BCM sends power supply to ignition relay <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk/luggage room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (Without Super Lock)

INFOID:000000011008716

WORK SUPPORT

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operation in this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
TRUNK/GLASS HATCH OPEN	NOTE: This item is displayed, but cannot be monitored
AUTO LOCK SET	Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"> • MODE 1: OFF • MODE 2: 30 sec • MODE 3: 1 minute • MODE 4: 2 minutes • MODE 5: 3 minutes • MODE 6: 4 minutes • MODE 7: 5 minutes
SHORT CRANKING OUTPUT	NOTE: This item is displayed, but cannot be monitored
IGN/ACC BATTERY SAVER	Ignition battery saver system mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
ANSWER BACK	NOTE: This item is displayed, but cannot be used
ANSWER BACK I-KEY LOCK UN-LOCK	NOTE: This item is displayed, but cannot be used
ANSWER BACK KEYLESS LOCK UNLOCK	NOTE: This item is displayed, but cannot be used

SELF-DIAG RESULT

Refer to [BCS-78, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of back door request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
CLUTCH SW*1	Indicates [On/Off] condition of clutch interlock switch
BRAKE SW 1	Indicates [On/Off]*2 condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
START CLUTCH SW	Indicates [On/Off] condition of clutch pedal position switch
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
NEUTRAL SW - IPDM	Indicates [On/Off] condition of reverse/neutral position switch
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
STARTER RELAY - IPDM	Indicates [On/Off] condition of starter relay
ENGINE STATE	Indicates [Stop/Stall/Crank/Run] condition of engine states
ST/INHIRELAY-IPDM	Display the starter relay/starter control relay status signal from IPDM E/R via CAN communication
REVERSE SIGNAL - IPDM	Indicates [On/Off] condition of R position
CRANKING PERMIT - ECM	Display the engine cranking permit signal from ECM via CAN communication
IS STATUS - ECM	Indicates [On/Off] condition of stop/start system
STARTER CUT RELAY - ECM	Indicates [On/Off] condition of starter control relay signal from ECM via CAN communication
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [Km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS actuator and electric unit (control unit) by numerical value [Km/h]
IGN REQ - IPDM	Display the ignition request signal from IPDM E/R via CAN communication
STARTER REQ - IPDM	Display the starter request signal from IPDM E/R via CAN communication
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
ID OK FLAG	Indicates [Set/Reset] condition of Intelligent Key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored
I-KEY OK FLAG	Indicates [KEY On/NOT On] condition of Intelligent Key ID and Intelligent Key is detected inside vehicle
PRBT ENG STRT	Indicates whether or not the engine is in start prohibited status
ID AUTHENT CANCEL TIMER	Indicates whether or not it is in engine start possible status when Intelligent Key verification is unnecessary
ACC BATTERY SAVER	Indicates [On/Off] whether or not ignition battery saver is in operation
CRNK PRBT TMR	Indicates [On/Off] whether or not in cranking prohibited status due to starter motor protection function operation
AUT CRANK TMR	Indicates [On/Off] whether or not in AUTO CRANKING MODE status
CRNK PRBT TME	Indicates the time for changing from cranking prohibited status to cranking possible status

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
AUT CRANK TMR	Indicates the time that AUTO CRANKING MODE operates
CRANKING TME	Indicates the cranking operation time
SHORT CRANK	NOTE: This item is displayed, but not used
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored
S/L IGN OFF POSITION	Indicates [On/Off] condition of Ignition OFF signal
S/L SENSOR CIRCUIT 1	Indicates [Gnd/On] condition of steering lock unit sensor circuit
S/L SENSOR CIRCUIT 2	Indicates [On/Off] condition of steering lock unit sensor circuit
S/L POWER OUTPUT	Indicates [On/Off] condition of steering lock unit power supply
S/L POWER CHECK	Indicates [On/Off] condition of steering lock unit power supply
ANTICIPATED POWER	Indicates [On/Off] condition of anticipated power supply
S/L LOCK REQ	Indicates [On/Off] condition of steering lock unit lock request signal
S/L - BCM (CAN)	Indicates [On/Off] condition of CAN communication
S/L POWER ERROR	Indicates [On/Off] condition of steering lock unit power supply error
VEH SPEED ERROR (S/L)	Indicates [On/Off] condition of vehicle speed signal
VEH SPEED NORMAL (S/L)	Indicates [On/Off] condition of vehicle speed signal
ENGINE RUNNING (S/L)	Indicates [On/Off] condition of engine running
S/L ID DISCORD	Indicates [Correct/Incorrect] condition of ID verification
S/L ANTI-SCAN MODE	Indicates [On/Off] condition of antiscan mode
S/L LOCK NOT PERMIT	Indicates [Inhibition/No inhibt] condition of inhibit steering lock
S/L UNLOCK (CAN)	Indicates [Finished/Unfinished] condition of steering lock unit unlock
S/L ID STATUS (CAN)	Indicates [Coded/Blank] condition of registration ID
S/L RESET STATUS (CAN)	Indicates [Exit/No exit] condition of steering lock unit reset signal
S/L LO-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of lo-level malfunction
S/L LOCK POSITION (CAN)	Indicates [Armed/Malf/Unlocked/Undefined] condition of lock/unlock position signal
S/L ACT MALFUNCTION (CAN)	Indicates [Malf/No malf] condition of steering lock unit malfunction
S/L HI-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of hi-level malfunction
S/L OPERATION PRHBT (SPD)	Indicates [On/Off] condition of vehicle speed signal
S/L OPERATION PRHBT (PWR)	Indicates [Allowed/Forbid] condition of safety line inhibition
S/L SENSOR POWER (CAN)	Indicates [On/Off] condition of sensor test power supply
S/L SEN TEST PERMIT (CAN)	Indicates [Forbid/Authorize] condition of sensor test
S/L STAT NOT DETECT (CAN)	Indicates [Ok/Undefind] condition of steering lock undefined position signal
S/L LOCKING FINISHED (CAN)	Indicates [Unfinshd/Finished] condition of steering lock unit lock status signal
STOP/START SW	Indicates [On/Off] condition of stop/start off switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored
RKE-PANIC	NOTE: This item is displayed, but cannot be monitored
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from Intelligent Key
RKE PBD	Indicates [On/Off] condition of back door open request signal from Intelligent Key

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
KEY SW	NOTE: This item is displayed, but cannot be monitored
IGN SW	NOTE: This item is displayed, but cannot be monitored
START SW	NOTE: This item is displayed, but cannot be monitored

*¹: It is displayed but does not operate on CVT models.

*²: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation • On: Operate • Off: Non-operation
INSIDE BUZZER	This test is able to check warning chime in combination meter operation • Buzzer 1: Combination meter buzzer sounds (pipipi...) when CONSULT screen is touched • Buzzer 2: Combination meter buzzer sounds (pipi-pipi-...) when CONSULT screen is touched • Buzzer 3: Combination meter buzzer sounds (pipipi-pipipi-...) when CONSULT screen is touched • Off: Non-operation
INDICATOR	This test is able to check warning lamp operation • KEY ON: [Intelligent Key system malfunction] displays when CONSULT screen is touched • KEY IND: "KEY" Warning lamp blinks when CONSULT screen is touched • Off: Non-operation
FLASHER	This test is able to check security hazard lamp operation The hazard lamps are activated after "LH/RH/Off" on CONSULT screen is touched
HORN	NOTE: This item is displayed, but cannot be used
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) • On: Operates • Off: Non-operation
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "ON" on CONSULT screen is touched
ENGINE START REQUEST	This test is able to check BCM sends starter request signal to IPDM E/R via CAN communication • MODE 1: IGN ON, START request OFF • MODE 2: IGN OFF, START request ON • MODE 3: IGN ON, START request ON • Off: Non-operation
IGNITION RELAY	NOTE: This item is displayed, but cannot be used
STARTER CUT RELAY	This test is able to operate the starter control relay • On: Operates • Off: Non-operation
ENGINE START	NOTE: This item is displayed, but cannot be used
TRUNK/BACK DOOR	NOTE: This item is displayed, but cannot be used
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used
AUTO ACC 2	This test is able to check BCM sends power supply to audio unit or NAVI control unit • On: Operate • Off: Non-operation

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Description
AUTOMATIC BACK DOOR	NOTE: This item is displayed, but cannot be used
AUTO ACC 1	This test is able to check BCM sends power supply to ignition relay <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk/luggage room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000010688597

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [UNIT]	Description
FR WIPER HI [Off/On]	Displays the status of the FR WIPER HI switch in combination switch judged by BCM with the combination switch reading function.
FR WIPER LOW [Off/On]	Displays the status of the FR WIPER LOW switch in combination switch judged by BCM with the combination switch reading function.
FR WASHER SW [Off/On]	Displays the status of the FR WASHER switch in combination switch judged by BCM with the combination switch reading function.
FR WIPER INT [Off/On]	Displays the status of the FR WIPER INT/AUTO switch in combination switch judged by BCM with the combination switch reading function.
INT VOLUME [1 - 7]	Displays the status of wiper volume dial position judged by BCM with the combination switch reading function.
RR WIPER ON [Off/On]	Displays the status of the RR WIPER ON switch in combination switch judged by BCM with the combination switch reading function.
RR WIPER INT [Off/On]	Displays the status of the RR WIPER INT switch in combination switch judged by BCM with the combination switch reading function.
RR WASHER SW [Off/On]	Displays the status of the RR WASHER switch in combination switch judged by BCM with the combination switch reading function.
TURN SIGNAL R [Off/On]	Displays the status of the TURN RH switch in combination switch judged by BCM with the combination switch reading function.
TURN SIGNAL L [Off/On]	Displays the status of the TURN LH switch in combination switch judged by BCM with the combination switch reading function.
TAIL LAMP SW [Off/On]	Displays the status of the TAIL LAMP switch in combination switch judged by BCM with the combination switch reading function.
HI BEAM SW [Off/On]	Displays the status of the HI BEAM switch in combination switch judged by BCM with the combination switch reading function.
HEAD LAMP SW [Off/On]	Displays the status of the HEADLAMP switch in combination switch judged by BCM with the combination switch reading function.
LIGHT OFF SW [Off/On]	Displays the status of the LIGHT OFF switch in combination switch judged by BCM with the combination switch reading function.
PASSING SW [Off/On]	Displays the status of the PASSING switch in combination switch judged by BCM with the combination switch reading function.
AUTO LIGHT SW [Off/On]	Displays the status of the AUTO LIGHT switch in combination switch judged by BCM with the combination switch reading function.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [UNIT]	Description
FR FOG SW [Off/On]	Displays the status of the FR FOG switch in combination switch judged by BCM with the combination switch reading function.
RR FOG SW [Off/On]	Displays the status of the RR FOG switch in combination switch judged by BCM with the combination switch reading function.

BCM

BCM : CONSULT Function (BCM - BCM)

INFOID:0000000010688598

WORK SUPPORT

Item	Description
RESET SETTING VALUE	Return a value set with Work Support of each system to a default value in factory shipment.
AUTO ACC FNCTN (AUDIO/NAVI SET AFTER IGN OFF)	Switches the operation of audio and navigation systems between continuous and not continuous after ignition is OFF.

IMMU

IMMU : CONSULT Function (BCM - IMMU) (With Intelligent Key System)

INFOID:0000000011008725

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Content
PUSH SW	Indicates [ON/OFF] condition of push-button ignition switch.

WORK SUPPORT

Service item	Description
CONFIRM DONGLE ID	It is possible to check that dongle unit is applied to the vehicle.

ACTIVE TEST

Test item	Description
THEFT IND	This test is able to check security indicator lamp operation. Security indicator lamp is turned on when "ON" on CONSULT screen touched.

IMMU : CONSULT Function (BCM - IMMU) (Without Intelligent Key System)

INFOID:0000000011008726

WORK SUPPORT

Service item	Description
CONFIRM DONGLE ID	It is possible to check that dongle unit is applied to the vehicle.

ACTIVE TEST

Test item	Description
THEFT IND	This test is able to check security indicator lamp operation. Security indicator lamp is turned on when "ON" on CONSULT screen touched.

BATTERY SAVER

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000011008732

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW-AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	Indicated [On/Off] condition of back door switch
CDL LOCK SW [On/Off]	Indicated [On/Off] condition of lock signal from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Indicated [On/Off] condition of unlock signal from door lock and unlock switch
KEY CYL LK-SW [On/Off]	NOTE: This item is displayed, but cannot be monitored
KEY CYL UN-SW [On/Off]	NOTE: This item is displayed, but cannot be monitored
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key or keyfob
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key or keyfob
KEY SW [On/Off]	Indicates [On/Off] condition of key switch

ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	ON	Turns interior room lamp relay ON.
	OFF	Turns interior room lamp relay OFF.

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK) (With Intelligent Key System and Super Lock)

INFOID:000000011008719

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Contents
PUSH SW	Indicates [On/Off] condition of push switch
STARTER CUT RELAY	Indicates [On/Off] condition of starter control relay
DETECTION SENSOR (BK)	NOTE: This item is displayed, but cannot be monitored
VEH SPEED 1	Indicates [Km/h] condition of vehicle speed signal from combination meter
KEY CYL SW-TR	NOTE: This item is displayed, but cannot be monitored
TR CANCEL SW	NOTE: This item is displayed, but cannot be monitored
TRUNK LID OPENER SW	NOTE: This item is displayed, but cannot be monitored
BACK DOOR OPENER SW	Indicates [On/Off] condition of back door opener switch
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored

TRUNK : CONSULT Function (BCM - TRUNK) (With Intelligent Key System, Without Super Lock)

INFOID:0000000011008720

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
PUSH SW	Indicates [On/Off] condition of push switch
STARTER CUT RELAY	Indicates [On/Off] condition of starter control relay
DETECTION SENSOR (BK)	Indicates [On/Off] condition of hands free sensor
VEH SPEED 1	Indicates [Km/h] condition of vehicle speed signal from combination meter
KEY CYL SW-TR	NOTE: This item is displayed, but cannot be monitored
TR CANCEL SW	NOTE: This item is displayed, but cannot be monitored
TRUNK LID OPENER SW	NOTE: This item is displayed, but cannot be monitored
BACK DOOR OPENER SW	Indicates [On/Off] condition of back door opener switch
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored

TRUNK : CONSULT Function (BCM - TRUNK) (Without Intelligent Key System, With Super Lock)

INFOID:0000000011008721

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
STARTER CUT RELAY	Indicates [On/Off] condition of starter control relay
KEY CYL SW-TR	NOTE: This item is displayed, but cannot be monitored

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Contents
TR CANCEL SW	NOTE: This item is displayed, but cannot be monitored
TRUNK LID OPENER SW	NOTE: This item is displayed, but cannot be monitored
BACK DOOR OPENER SW	Indicates [On/Off] condition of back door opener switch
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored

TRUNK : CONSULT Function (BCM - TRUNK) (Without Intelligent Key System and Super Lock)

INFOID:000000011008722

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
STARTER CUT RELAY	Indicates [On/Off] condition of starter control relay
KEY CYL SW-TR	NOTE: This item is displayed, but cannot be monitored
TR CANCEL SW	NOTE: This item is displayed, but cannot be monitored
TRUNK LID OPENER SW	NOTE: This item is displayed, but cannot be monitored
BACK DOOR OPENER SW	Indicates [On/Off] condition of back door opener switch
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored

THEFT ALM

THEFT ALM : CONSULT Function (BCM - THEFT) (With Intelligent Key System)

INFOID:000000011008723

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitored Item	Description
REQ SW -DR	Indicates [ON/OFF] condition of door request switch (driver side).
REQ SW -AS	Indicates [ON/OFF] condition of door request switch (passenger side).
REQ SW -BD/TR	Indicates [ON/OFF] condition of back door opener request switch.
PUSH SW	Indicates [ON/OFF] condition of push-button ignition switch
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch (passenger side).
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
DOOR SW-BK	Indicates [ON/OFF] condition of back door switch.
CDL LOCK SW	Indicates [ON/OFF] condition of lock signal from door lock/unlock switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of unlock signal from door lock/unlock switch.
KEY CYL LK-SW	NOTE: This item is indicated, but not monitored.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitored Item	Description
KEY CYL UN-SW	NOTE: This item is indicated, but not monitored.
KEY CYL SW-TR	NOTE: This item is indicated, but not monitored.
SEN CANCEL SW	Indicates [ON/OFF] condition of sensor cancel switch.
RKE-LOCK	Indicates [ON/OFF] condition of LOCK signal from Intelligent Key.
RKE-UNLOCK	Indicates [ON/OFF] condition of UNLOCK signal from Intelligent Key.
RKE-TR/BD	NOTE: This item is indicated, but not monitored.
KEY SW	NOTE: This item is indicated, but not monitored.

WORK SUPPORT

Service Item	Description
SECURITY ALARM SET	This mode is able to confirm and change vehicle security alarm ON-OFF setting.
SIREN SET	Select the siren function ON or OFF, and siren type. • MODE 1: Without siren • MODE 2: With siren • MODE 3: With external complete protection (with siren) • MODE 4: Without any external protection (with siren) • MODE 5: Without external tilt protection (with siren)

ACTIVE TEST

Test Item	Description
SIREN	Activates the self-diagnosis function for siren control unit.
VEHICLE SECURITY HORN	NOTE: This item is indicated, but not used
HEAD LAMP	NOTE: This item is indicated, but not used

THEFT ALM : CONSULT Function (BCM - THEFT) (Without Intelligent Key System)

INFOID:000000011008724

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

BCS

Monitored Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch (passenger side).
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
DOOR SW-BK	Indicates [ON/OFF] condition of back door switch.
CDL LOCK SW	Indicates [ON/OFF] condition of lock signal from door lock/unlock switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of unlock signal from door lock/unlock switch.
KEY CYL LK-SW	NOTE: This item is indicated, but not monitored.
KEY CYL UN-SW	NOTE: This item is indicated, but not monitored.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitored Item	Description
KEY CYL SW-TR	NOTE: This item is indicated, but not monitored.
SEN CANCEL SW	Indicates [ON/OFF] condition of sensor cancel switch.
RKE-LOCK	Indicates [ON/OFF] condition of LOCK signal from Keyfob.
RKE-UNLOCK	Indicates [ON/OFF] condition of UNLOCK signal from Keyfob.
RKE-TR/BD	NOTE: This item is indicated, but not monitored.
KEY SW	Indicates [ON/OFF] condition of Key switch.

WORK SUPPORT

Service Item	Description
SECURITY ALARM SET	This mode is able to confirm and change vehicle security alarm ON-OFF setting.
SIREN SET	Select the siren function ON or OFF, and siren type. <ul style="list-style-type: none"> • MODE 1: Without siren • MODE 2: With siren • MODE 3: With external complete protection (with siren) • MODE 4: Without any external protection (with siren) • MODE 5: Without external tilt protection (with siren)

ACTIVE TEST

Test Item	Description
SIREN	Activates the self-diagnosis function for siren control unit.
VEHICLE SECURITY HORN	NOTE: This item is indicated, but not used
HEAD LAMP	NOTE: This item is indicated, but not used

SIGNAL BUFFER

SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)

INFOID:000000010688605

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [UNIT]	Description
PUSH SW [Off/On]	Displays the status of the push-button ignition switch (push switch) judged by BCM.

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION**BCM****Reference Value**

INFOID:000000010688606

VALUES ON THE DIAGNOSIS TOOL**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
CONFIRM ID ALL	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by any Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by any Intelligent Key ID registered to BCM.	Done
CONFIRM ID4	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the fourth Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the fourth Intelligent Key ID registered to BCM.	Done
CONFIRM ID3	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the third Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the third Intelligent Key ID registered to BCM.	Done
CONFIRM ID2	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the second Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the second Intelligent Key ID registered to BCM.	Done
CONFIRM ID1	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the first Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the first Intelligent Key ID registered to BCM.	Done
NOT REGISTERED	BCM detects registered Intelligent Key ID, or BCM does not detect Intelligent Key ID.	ID OK
	BCM detects non-registration Intelligent Key ID.	ID NG
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -BD/TR	Trunk lid opener request switch is not pressed	Off
	Trunk lid opener request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
STARTER CUT RELAY	Other than engine cranking	Off
	At engine cranking	On
DETECTION SENSOR (BK)	Hands free sensor is not detected.	Off
	Hands free sensor is detected.	On
CLUCH SW	The clutch pedal is not depressed.	Off
	The clutch pedal is depressed	On
BRAKE SW 1	The brake pedal is not depressed and ignition switch ON	Off
	The brake pedal is depressed and ignition switch ON	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
START CLUTCH SW	The clutch pedal is depressed	Off
	The clutch pedal is not depressed	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Power position in OFF or ACC	Off
	Power position in ON	On
NEUTRAL SW - IPDM	<ul style="list-style-type: none"> • Selector lever in any position other than P or N (CVT models) • Control lever in any position other than neutral (M/T models) 	Off
	<ul style="list-style-type: none"> • Selector lever in P or N position (CVT models) • Control lever in neutral position (M/T models) 	On
SFT PN -IPDM	Selector lever in any position other than P or N	Off
	Selector lever in P or N position	On
STARTER RELAY - IPDM	Other than engine cranking	Off
	At engine cranking (short cranking)	Crank
	Operation prohibited status	Invalid
	At engine cranking	On
ENGINE STATE	Engine stopped	STOP
	While the engine stalls	STALL
	At engine cranking	CRANK
	Engine running	RUN
ST/INHI RELAY - IPDM	Power position in OFF	Off, Off
	Engine restart	Off, On
	At engine cranking	INVALID
	Engine running	On, On
REVERSE SIGNAL - IPDM	Selector lever in any position other than R position	Off
	Selector lever in R position	On
CRANKING PERMIT - ECM	The engine start is prohibited	PRHB
	The engine start is permitted	PERMIT
	When it is stopped requested during engine start	STOP
	When not communication with ECM	Off
IS STATUS - ECM	Stop/start system not operating	Off
	Stop/start system operating	On

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
STARTER CUT RELAY - ECM	Other than engine cranking	Off
	At engine cranking	On
VEH SPEED 1	While driving	Equivalent to speed-ometer reading
VEH SPEED 2	While driving	Equivalent to speed-ometer reading
IGN REQ - IPDM	Power position in OFF or ACC	Off
	Power position in ON	On
STARTER REQ - IPDM	Other than engine cranking	Off
	At engine cranking	On
DOOR STAT-DR	Driver door is locked	LOCK
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Passenger door is unlocked	UNLOCK
DOOR STAT-RR	Rear door RH is locked	LOCK
	Rear door RH is unlocked	UNLOCK
DOOR STAT-RL	Rear door LH is locked	LOCK
	Rear door LH is unlocked	UNLOCK
BK DOOR STATE	Back door is locked	LOCK
	Back door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	When the engine start is prohibited	Reset
	When the engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
I-KEY OK FLAG	Intelligent Key ID and Intelligent Key is detected outside vehicle	NOT On
	Intelligent Key ID and Intelligent Key is detected inside vehicle	KEY On
PRBT ENG STRT	Not activated fail safe function	Reset
	Engine start is prohibited by fail safe function	SET
ID AUTHENT CANCEL TIMER	Engine start is prohibited without Intelligent Key	STOP
	Engine start is permitted without Intelligent Key	OPRAT
ACC BATTERY SAVER	ACC battery saver timer is stop	STOP
	ACC battery saver timer is running	OPRAT
CRNK PRBT TMR	Cranking is permitted	Off
	Cranking is prohibited	On
AUT CRANK TMR	Not auto cranking	Off
	During auto cranking	On
CRNK PRBT TME	Cranking prohibit timer	sec
AUT CRANK TMR	Auto cranking timer	sec
CRANKING TME	Cranking timer	sec
SHORT CRANK	NOTE: The item is indicated, but not monitored.	—
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
S/L IGN OFF POSITION	Power position in ON	Off
	Power position in OFF or ACC	On
S/L SENSOR CIRCUIT 1	Steering lock unit is not operated	GND
	Steering is lock unit is operated	On
S/L SENSOR CIRCUIT 2	Steering lock unit is not operated	Off
	Steering is lock unit is operated	On
S/L POWER OUTPUT	Steering lock unit is operated	Off
	Steering is lock unit is not operated	On
S/L POWER CHECK	Steering lock unit is operated	Off
	Steering is lock unit is not operated	On
ANTICIPATED POWER	Not outputs the steering lock unit anticipated power supply	Off
	Outputs the steering lock unit anticipated power supply	On
S/L LOCK REQ	Steering lock unit is not operated	Off
	Steering is lock unit is operated	On
S/L - BCM (CAN)	When not communication between BCM and steering lock unit	Off
	When communication between BCM and steering lock unit	On
S/L POWER ERROR	Steering lock unit power supply is normal	Off
	Steering lock unit power supply is malfunction	On
VEH SPEED ERROR (S/L)	Power position ON and steering is unlocked	Off
	Power position ON and steering is locked	On
VEH SPEED NORMAL (S/L)	While the vehicle is stopped	Off
	While the vehicle is running	On
ENGINE RUNNING (S/L)	Engine stopped	Off
	Engine running	On
S/L ID DISCORD	When the BCM and steering lock unit ID becomes consistent	Correct
	When the BCM and steering lock unit ID becomes not consistent	Incorrect
S/L ANTI-SCAN MODE	Steering lock system is normal	Off
	Steering lock system is malfunction	On
S/L LOCK NOT PERMIT	Power position in OFF	No inhbt
	Power position in ACC or ON	Inhibition
S/L UNLOCK (CAN)	Steering is locked	Unfinshd
	Steering is unlocked	Finished
S/L ID STATUS (CAN)	The ID of steering lock unit is registered	Coded
	The ID of steering lock unit is not registered	Blank
S/L RESET STATUS (CAN)	Steering is unlocked	Exit
	Steering is lock unit is operated (look → unlock)	No exit
S/L LO-LEVEL MALFUNC (CAN)	Steering lock system is normal	No malf
	Steering lock system is malfunction	Malf
S/L LOCK POSITION (CAN)	Steering is locked	Armed
	Steering is unlocked	Malf
	Steering lock system is malfunction	Unlocked
	Steering is lock unit is operated	Undfined

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
S/L ACT MALFUNCTION (CAN)	Steering lock unit is normal	No malf
	Steering lock unit is malfunction	Malf
S/L HI-LEVEL MALFUNC (CAN)	Steering lock system is normal	No malf
	Steering lock system is malfunction	Malf
S/L OPERATION PRHBT (SPD)	When the steering lock unit receives the lock/unlock request signal to the vehicle stopped	0 km/h
	When the steering lock unit receives the lock/unlock request signal to the vehicle running	> 0 km/h
S/L OPERATION PRHBT (PWR)	Steering lock system is normal	Allowed
	Steering lock system is malfunction	Forbid
S/L SENSOR POWER (CAN)	Steering lock unit is not operated	On
	Steering is lock unit is operated	Off
S/L SEN TEST PERMIT (CAN)	Steering lock system is normal	Forbid
	Steering lock system is malfunction	Authorize
S/L STAT NOT DETECT (CAN)	Steering is locked	OK
	Steering is unlocked	Undfined
S/L LOCKING FINISHED (CAN)	Steering is unlocked	Unfinshd
	Steering is locked	Finished
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper volume dial is in a dial position	Wiper volume dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST	Off
	Lighting switch 1ST	On

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
LIGHT OFF SW	Other than lighting switch OFF	Off
	Lighting switch OFF	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	Rear fog lamp switch OFF	Off
	Rear fog lamp switch ON	On
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL UN-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
H/L WSR SW	Headlamp washer switch OFF	Off
	Headlamp washer switch ON	On
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TRUNK LID OPENER SW	NOTE: The item is indicated, but not monitored.	Off
BACK DOOR OPENER SW	Back door opener switch OFF	Off
	Back door opener switch ON	On

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
STOP/START SW	NOTE: The item is indicated, but not monitored.	Off
SEN CANCEL SW	Sensor cancel switch is not pressed	Off
	Sensor cancel switch is pressed	On
RKE-LOCK	<ul style="list-style-type: none"> LOCK button of the Intelligent Key is not pressed (with Intelligent Key system) LOCK button of the keyfob is not pressed (without Intelligent Key system) 	Off
	<ul style="list-style-type: none"> LOCK button of the Intelligent Key is pressed (with Intelligent Key system) LOCK button of the keyfob is pressed (without Intelligent Key system) 	On
	<ul style="list-style-type: none"> UNLOCK button of the Intelligent Key is not pressed (with Intelligent Key system) UNLOCK button of the keyfob is not pressed (without Intelligent Key system) 	Off
RKE-UNLOCK	<ul style="list-style-type: none"> UNLOCK button of the Intelligent Key is pressed (with Intelligent Key system) UNLOCK button of the keyfob is pressed (without Intelligent Key system) 	On
	<ul style="list-style-type: none"> UNLOCK button of the Intelligent Key is not pressed (with Intelligent Key system) UNLOCK button of the keyfob is not pressed (without Intelligent Key system) 	Off
RKE-TR/BD	NOTE: The item is indicated, but not monitored.	Off
RKE-PANIC	NOTE: The item is indicated, but not monitored.	Off
RKE-MODE CHG	NOTE: The item is indicated, but not monitored.	Off
RKE PBD	Power back door button OFF	Off
	Power back door button ON	On
SHOCK SENSOR	Car crash information signal (NORMAL) is detected.	NOMAL
	Car crash information signal (AIR BAG OPEN) is detected.	On
	Car crash information signal is not detected.	Off
OPTI SEN (DTCT)	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
OPTI SEN (FILT)	Bright outside of the vehicle (Lighting switch AUTO)	Close to 5 V
	Dark outside of the vehicle (Lighting switch AUTO)	Close to 1.50 V
OPTICAL SENSOR	NOTE: The item is indicated, but not monitored.	Off
RAIN SENSOR	No rain (or very light rain)	Off
	Light rain	LOW
	Heavy rain	HIGH
	When liquid is splashed on the front window	SPLSH
	Rain sensor internal error	NG
KEY SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
IGN SW	Other than power position in ON	Off
	Power position in ON	On
START SW	Other than power position in START	Off
	Power position in START	On

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N


O

P

BCM

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES




NOTE:

Waveform reference

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
6* ² (R)	Ground	Back door opener request switch	Input	Back door re- quest switch	ON (Pressed)	0 – 0.5 V
					OFF (Not pressed)	9 – 16 V
9* ¹ (G)	Ground	Hands free sensor	Input	Hands free sen- sor	Hold up hands to detec- tion area	0 – 0.5 V
					Other than above	9 – 16 V




BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
10 (W)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closed)	9 – 16 V
					ON (When rear RH door opened)	0 – 0.5 V
11 (LG)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed)	9 – 16 V
					ON (When back door opened)	0 – 0.5 V
12 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closed)	9 – 16 V
					ON (When rear LH door opened)	0 – 0.5 V
13 (SB)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)	9 – 16 V
					ON (When passenger door opened)	0 – 0.5 V
15 (LA/G)	Ground	Rear wiper auto stop	Input	Power position ON	Rear wiper stop position	0 – 0.5 V
					Any position other than rear wiper stop position	 JMMIA1654GB
16 (Y)	Ground	Back door opener switch	Input	Back door opener switch	OFF (Not pressed)	9 – 16 V
					ON (Pressed)	0 – 0.5 V
17 (SB)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)	9 – 16 V
					ON (When driver door opened)	0 – 0.5 V
20 (L)	Ground	CAN-H (CAN communication circuit 1)	Input/ Output	—		—
21*2 (BR)	Ground	Rear bumper antenna (-)	Input	Power position ON and any door is open	Intelligent Key is outside the vehicle	 JMMIA1652GB
					Intelligent Key is inside the vehicle	 JMMIA1653GB




BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
22* ² (Y)	Ground	Inside key antenna (Luggage room) (-)	Input	Power position ON and any door is open	Intelligent Key is outside the vehicle
					 JMMIA1652GB
23* ² (L)	Ground	Inside key antenna (Luggage room) (+)	Output	Power position ON and any door is open	Intelligent Key is outside the vehicle
					 JSMIA1507GB
24* ² (G)	Ground	Rear bumper anten- na (+)	Output	Power position ON and any door is open	Intelligent Key is outside the vehicle
					 JSMIA1506GB

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
38 (V)	Ground	Alarm link	Output	Disarmed phase	0 V
				Armed phase	 JSMIA1405GB
39 (LA/W)	Ground	High-mounted stop lamp output	Output	Brake pedal is not depressed	0 V
				Brake pedal is depressed	9 – 16 V
40 (P)	Ground	CAN-L (CAN communication circuit 1)	Input/ Output	—	
41*2 (V)	Ground	Steering lock unit power supply output	Output	Steering lock unit	Activated
					9 – 16 V
42 (LA/G)	Ground	Turn signal LH output (Side)	Output	Ignition switch ON	Turn signal switch OFF
					 PKID0926E 6.5 V (Turn signal lamp turn on: 9 - 16 V)
43 (LA/Y)	Ground	Turn signal RH output (Side)	Output	Ignition switch ON	Turn signal switch OFF
					 PKID0926E 6.5 V (Turn signal lamp turn on: 9 - 16 V)
44 (P)	Ground	Interior room lamp relay control	Output	Interior room lamp battery saver is activated	
				Interior room lamp battery saver is not activated	
45 (R)	Ground	CAN-L (CAN communication circuit 2)	Input/ Output	—	
46 (L)	Ground	CAN-H (CAN communication circuit 2)	Input/ Output	—	

A

B

C

D

E

F

G

H

I

J

K

L

BCS


N

O

P






BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
47 (G)	Ground	Rain sensor serial link	Input/ Output	Power position OFF	12 V
				Power position ON	 (V) 15 10 5 0 10ms
48 (L)	Ground	CAN-H (CAN com- munication circuit 2)	Input/ Output	—	—
49 (R)	Ground	CAN-L (CAN com- munication circuit 2)	Input/ Output	—	—
50 (BG)	Ground	Door lock and unlock switch LOCK	Input	Door lock and unlock switch NEUTRAL position	9 – 16 V
				LOCK position	0 V
51 (Y)	Ground	Hazard switch	Input	Hazard switch OFF	9 – 16 V
					0 V
57 (L)	Ground	Detention switch power supply	Output	Power position ACC or ON	9 – 16 V
					0 – 0.5 V
60 (R)	Ground	Headlamp washer switch	Input	Headlamp washer switch Pressed	0 V
					9 – 16 V
63 (G)	Ground	Power window relay control	Output	Power position OFF or ACC	9 – 16 V
					0 – 0.5 V
64 (LA/R)	Ground	Rear window defog- ger relay control	Output	Rear window defogger Not activated	9 – 16 V
					0 – 1.5 V
65 (BR)	Ground	ACC relay control	Output	Power position OFF	9 – 16 V
					0 – 0.5 V
67 (Y)	Ground	Ignition relay (J/B) control	Output	Power position OFF or ACC	9 – 16 V
					0 – 0.5 V
68 (LA/W)	Ground	Blower relay control	Output	Power position OFF or ACC	9 – 16 V
					0 – 0.5 V


BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	A B C D E F G H I J K L BCS N O P		
+	-	Signal name	Input/ Output					
73 (LG)	Ground	Combination switch INPUT 5	Input	Combination switch	All switches OFF (Wiper volume dial 3)	12 V		
					Rear wiper switch ON (Wiper volume dial 3)	 JMMIA1642GB		
					Wiper volume dial 1 (All switches OFF)			
					Rear wiper switch INT (Wiper volume dial 3)	 JMMIA1643GB		
					Wiper volume dial 4 (All switches OFF)			
					Wiper volume dial 5 (All switches OFF)	 JMMIA1644GB		
74 (Y)	Ground	Combination switch OUTPUT 5	Output	Combination switch	Lighting switch 2ND (Wiper volume dial 3)	0 V	K L BCS N	
					All switch OFF (Wiper volume dial 3)	 JMMIA1642GB		
					Lighting switch 1ST (Wiper volume dial 3)			
					Front fog lamp switch ON (Lighting switch 2ND)			
					Turn signal switch RH (Lighting switch 2ND)			
75 (BG)	Ground	Security indicator lamp control	Output	Security indica- tor lamp	ON	0 – 0.5 V	O P	
					Blinking	 JPMIA0590GB		
					OFF	12 V		
						9 – 16 V		









BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
76 (G)	Ground	Combination switch INPUT 3	Input	Combination switch (Wiper volume dial 3)	All switches OFF
					Front washer switch ON
					Rear washer switch ON
					Turn signal switch LH
					 JMMIA1643GB
					Turn signal switch RH
77 (GR)	Ground	Combination switch INPUT 4	Input	Combination switch	Lighting switch 2ND (Wiper volume dial 3)
					All switches OFF (Wiper volume dial 3)
					Front wiper switch INT/ AUTO (Lighting switch 2ND)
					Front wiper switch LO (Lighting switch 2ND)
					Front wiper switch MIST (Lighting switch 2ND)
					Front wiper switch HI (Lighting switch 2ND)






BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	A B C D E F G H I J K L BCS N O P
+	-	Signal name	Input/ Output			
78 (V)	Ground	Combination switch INPUT 1	Input	Combination switch	All switches OFF (Wiper volume dial 3)	12 V
					Front fog lamp switch ON (Wiper volume dial 3)	 JMMIA1642GB
					Lighting switch HI (Lighting switch 2ND)	 JMMIA1642GB
					Lighting switch PASS (Wiper volume dial 3)	 JMMIA1643GB
					Rear fog lamp switch ON (Wiper volume dial 3)	 JMMIA1643GB
79 (W)	Ground	Combination switch INPUT 2	Input	Combination switch	All switches OFF (Wiper volume dial 3)	12 V
					Wiper volume dial 1 (All switches OFF)	 JMMIA1642GB
					Lighting switch 1ST (Wiper volume dial 3)	 JMMIA1642GB
					Lighting switch 2ND (Wiper volume dial 3)	 JMMIA1643GB
					Lighting switch AUTO (Wiper volume dial 3)	 JMMIA1643GB
80 (SB)	Ground	Door lock and unlock switch UNLOCK	Input	Door lock and unlock switch	NEUTRAL position	9 – 16 V
					UNLOCK position	0 V
81* ³ (L)	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder		9 – 16 V
				Remove mechanical key from ignition key cylinder		0 V
82* ² (W)	Ground	Passenger door re- quest switch	Input	Passenger door request switch	ON (Pressed)	0 – 0.5 V
					OFF (Not pressed)	9 – 16 V
82* ³ (LA/R)	Ground	Key switch (START)	Input	Power position	START	9 – 16 V
					Other than START	0 – 0.5 V

BCM


< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
84 (BR)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper volume dial 3)	0 V
					Lighting switch HI (Lighting switch 2ND)	 JMMIA1643GB
					Front wiper switch HI (Lighting switch 2ND)	
					Rear washer switch ON (Wiper volume dial 3)	 JMMIA1642GB
					Wiper volume dial 4 (All switches OFF)	
					Wiper volume dial 5 (All switches OFF)	
85 (SB)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper volume dial 3)	0 V
					Front washer switch ON (Wiper volume dial 3)	 JMMIA1643GB
					Front wiper switch MIST (Wiper volume dial 3)	
					Front wiper switch LO (Wiper volume dial 3)	 JMMIA1642GB
					Wiper volume dial 2 (All switches OFF)	
					Wiper volume dial 5 (All switches OFF)	
					Wiper volume dial 1 (All switches OFF)	
86 (P)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper volume dial 3)	All switches OFF	0 V
					Lighting switch 2ND	 JMMIA1643GB
					Lighting switch PASS	
					Front wiper switch INT/ AUTO	 JMMIA1642GB
					Rear wiper switch INT	


BCM

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
87 (BG)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper volume dial 3)	All switches OFF
					Lighting switch AUTO
					Rear fog lamp switch ON
					Turn signal switch LH
					Rear wiper switch ON
88*2 (W)	Ground	Push-button ignition switch illumination power supply	Output	Push-button ig- nition switch illu- mination	0 V
					12 V
90*2 (Y)	Ground	Steering lock condi- tion	Input	Steering lock unit	9 – 16 V
					0 – 0.5 V
94 (G)	Ground	Detention switch	Input	Selector lever	0 – 0.5 V
					9 – 16 V
95 (V)	Ground	Extended storage fuse switch	Input	Extended stor- age fuse switch	0 – 0.5 V
					9 – 16 V
99 (R)	Ground	Stop/start OFF switch	Input	Stop/start OFF switch	0 – 0.5 V
					9 – 16 V
100*2 (V)	Ground	Driver door antenna (+)	Output	Power position ON and any door is open	Intelligent Key is outside the vehicle
					Intelligent Key is inside the vehicle
101*2 (Y)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ig- nition switch (push switch)	0 – 0.5 V
					9 – 16 V
104 (R)	Ground	Front door lock as- sembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sen- sor switch OFF)
					UNLOCK status (Unlock sensor switch ON)
105*2 (Y)	Ground	Driver door request switch	Input	Driver door re- quest switch	ON (Pressed)
					OFF (Not pressed)
105*3 (Y)	Ground	Key switch (IPDM E/ R)	Input	Power position	ON
					OFF



JMMIA1643GB



JSMIA1348GB



JSMIA1406GB

A

B

C

D

E

F

G

H

I

J

K

L

BCS



N

O

P






BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
106 (W)	Ground	ACC output	Output	Power position	ACC or ON	0 – 0.5 V
					OFF	3.15 V
107 (V)	Ground	Sensor cancel switch	Input	Sensor cancel switch	OFF (Not pressed)	 JPMIA0011GB
					ON (Pressed)	0 V
109*3 (P)	Ground	NATS antenna amp.	Input/ Output	Just after inserting ignition key in key cylinder		Pointer of tester should move
				Other than above		0 V
110 (BG)	Ground	Dimmer signal	Output	Power position ON	Either of the following conditions • Lighting switch OFF • Bright outside of the ve- hicle (Lighting switch AUTO)	0 V
					Either of the following conditions • Lighting switch 1ST or 2ND • Dark outside of the ve- hicle (Lighting switch AUTO)	12 V
111 (R)	Ground	Door lock status indi- cator lamp	Output	Door lock status indicator lamp	OFF	0 V
					ON	12 V
112 (SB)	Ground	Stop/start OFF switch indicator	Output	Stop/start OFF switch indicator	ON	0 – 0.5 V
					OFF	9 – 16 V
113*3 (LG)	Ground	NATS antenna amp.	Input/ Output	Just after inserting ignition key in key cylinder		Pointer of tester should move
				Other than above		0 V
114*2 (Y)	Ground	NATS antenna amp.	Input/ Output	Intelligent Key battery is re- moved and brake pedal is depressed	When a registered Intelli- gent Key backside is con- tacted to push-button ignition switch	0 V
					Other than above	 JMMIA1650GB







BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	A B C D E F G H I J K L BCS N O P
+	-	Signal name	Input/ Output			
115* ² (W)	Ground	NATS antenna amp.	Input/ Output	Intelligent Key battery is re- moved and brake pedal is depressed	When a registered Intelli- gent Key backside is con- tacted to push-button ignition switch	0 V
					Other than above	 JMMIA1651GB
116* ² (BG)	Ground	Inside key antenna (Console) (-)	Input	Power position ON and any door is open	Intelligent Key is outside the vehicle	 JMMIA1652GB
					Intelligent Key is inside the vehicle	 JMMIA1653GB
117* ² (GR)	Ground	Inside key antenna (Console) (+)	Output	Power position ON and any door is open	Intelligent Key is outside the vehicle	 JSMIA1348GB
					Intelligent Key is inside the vehicle	 JSMIA1406GB



BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
118* ² (SB)	Ground	Passenger door antenna (-)	Input	Power position ON and any door is open	Intelligent Key is outside the vehicle  JSMIA1507GB
					Intelligent Key is inside the vehicle  JSMIA1506GB
119* ² (P)	Ground	Passenger door antenna (+)	Output	Power position ON and any door is open	Intelligent Key is outside the vehicle  JSMIA1507GB
					Intelligent Key is inside the vehicle  JSMIA1506GB
120* ² (BR)	Ground	Driver door antenna (-)	Input	Power position ON and any door is open	Intelligent Key is outside the vehicle  JMMIA1652GB
					Intelligent Key is inside the vehicle  JMMIA1653GB

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	A
+	-	Signal name	Input/ Output				
121 (LA/V)	Ground	Back door open	Output	Back door opener actuator	Activated	9 – 16 V	B
					Not activated	0 V	
122 (Y)	Ground	Rear fog lamp	Output	Rear fog lamp	OFF	0 V	C
					ON	9 – 16 V	
123 (LA/R)	Ground	Rear wiper	Output	Power position ON	Rear wiper switch OFF	0 V	D
					Rear wiper switch ON	9 – 16 V	
124 (W)	Ground	Rear door UNLOCK	Output	Rear door	UNLOCK (Actuator is acti- vated)	9 – 16 V	E
					Other than UNLOCK (Ac- tuator is not activated)	0 V	
125 (L)	Ground	Rear door LOCK	Output	Rear door	LOCK (Actuator is activat- ed)	9 – 16 V	F
					Other than LOCK (Actua- tor is not activated)	0 V	
127 (R)	Ground	Luggage room lamp control	Output	Luggage room lamp	OFF	9 – 16 V	G
					ON	0 – 0.5 V	
129 (LA/W)	Ground	Stop lamp LH output	Output	Brake pedal	Not depressed	0 V	H
					Depressed	9 – 16 V	
131* ⁴ (R)	Ground	Super lock (Rear door)	Output	Super lock actua- tor (Rear door)	Activated	9 – 16 V	I
					Not activated	0 V	
133 (GR)	Ground	Turn signal LH out- put (Rear)	Output	Power position ON	Turn signal switch OFF	0 V	J
					Turn signal switch LH	 PKID0926E 6.5 V (Turn signal lamp turn on: 9 - 16 V)	
134 (LA/Y)	Ground	Stop lamp RH output	Output	Brake pedal	Not depressed	0 V	BCS
					Depressed	9 – 16 V	
136 (P)	Ground	Turn signal RH out- put (Rear)	Output	Power position ON	Turn signal switch OFF	0 V	N
					Turn signal switch RH	 PKID0926E 6.5 V (Turn signal lamp turn on: 9 - 16 V)	
137 (W)	Ground	Battery power sup- ply (BCM)	Input	Power position ON		9 – 16 V	O




BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
138 (SB)	Ground	Interior room lamp control	Output	Map lamp, room lamp and personal lamp (Door position)	When all doors are closed (Interior room lamp are turned OFF)	9 – 16 V
					Any doors opens (Interior room lamp are turned ON)	0 – 1 V
139 (L)	Ground	Passenger door UN-LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	9 – 16 V
					Other than UNLOCK (Actuator is not activated)	0 V
141 (V)	Ground	Front doors LOCK	Output	Front doors	LOCK (Actuator is activated)	9 – 16 V
					Other than LOCK (Actuator is not activated)	0 V
143 (LA/V)	Ground	Battery power supply (Front door lock actuator)	Input	Power position ON		9 – 16 V
144 (BG)	Ground	Battery power supply (Turn signal lamp)	Input	Power position ON		9 – 16 V
145 (GR)	Ground	Battery power supply (Stop lamp)	Input	Power position ON		9 – 16 V
146 (B)	Ground	Ground	—	Power position OFF		0 V
147 (B)	Ground	Ground	—	Power position OFF		0 V
148 (G)	Ground	Driver door UN-LOCK	Output	Driver door	UNLOCK (Actuator is activated)	9 – 16 V
					Other than UNLOCK (Actuator is not activated)	0 V
149*4 (W)	Ground	Super lock (Front door)	Output	Super lock actuator (Front door)	Activated	9 – 16 V
					Not activated	0 V
151 (R)	Ground	Battery power supply (Rear door lock actuator)	Input	Power position ON		9 – 16 V
152 (LG)	Ground	Battery power supply (Rear wiper)	Input	Power position ON		9 – 16 V
156 (V)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (Clutch pedal is depressed)	9 – 16 V
					ON (Clutch pedal is not depressed)	0 – 0.5 V
157 (LG)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is depressed)	9 – 16 V
158 (W)	Ground	Stop lamp switch 1	Input	Power position ON	Stop lamp switch OFF (Brake pedal is not depressed)	9 – 16 V
					Stop lamp switch ON (Brake pedal is depressed)	0 V

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
159 (R)	Ground	Clutch pedal position switch	Input	Clutch pedal position switch	OFF (Clutch pedal is depressed)	9 – 16 V
					ON (Clutch pedal is not depressed)	0 – 0.5 V
164*2 (Y)	Ground	Intelligent Key warning buzzer	Output	Intelligent Key warning buzzer	Sounding NOTE: The pulse cycle changes depending on buzzer sounds.	 JMMIA1702GB
					Not sounding	
166*2 (P)	Ground	Steering lock unit power supply	Input	Power position	OFF or ACC	9 – 16 V
					ON	0 – 0.5 V
167 (BR)	Ground	Turn signal LH output (Front)	Output	Power position ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V (Turn signal lamp turn on: 9 - 16 V)
168 (GR)	Ground	Turn signal RH output (Front)	Output	Power position ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V (Turn signal lamp turn on: 9 - 16 V)
170 (L)	Ground	PTC relay-3 control	Output	PTC heater	“HIGH” operation	9 – 16 V
					Other than above	0 – 0.1 V
171 (G)	Ground	Starter relay control	Output	Starter motor	At engine cranking	0 – 0.1 V
					Other than above	9 – 16 V
172 (V)	Ground	PTC relay-1 control signal	Output	PTC heater	OFF	9 – 16 V
					“LOW”, “MID” or “HIGH” operation	0 – 0.1 V
173 (BG)	Ground	PTC relay-2 control signal	Output	PTC heater	“MID” or “HIGH” operation	0 – 0.1 V
					Except above	9 – 16 V

*1: With automatic back door

*2: With Intelligent Key system

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

< ECU DIAGNOSIS INFORMATION >

*3: Without Intelligent Key system

*4: RHD models

Fail-safe

INFOID:0000000010688607

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

Display contents of CONSULT	Fail-safe
B2190-00: CHAIN OF BCM-IMM ANT	Inhibit engine cranking
B2191-00: ID DISCORD, BCM-IMMANT	Inhibit engine cranking
B2192-00: ID DISCORD BCM-ECM	Inhibit engine cranking
B2193-00: CHAIN OF BCM-ECM	Inhibit engine cranking
B2195-00: ANTI-SCANNING	Inhibit engine cranking
B2196-00: DONGLE NG	Inhibit engine cranking
B2198-00: NATS ANTENNA AMP	Inhibit engine cranking
B2557-00: VEHICLE SPEED	Inhibit steering lock
B2602-00: SHIFT POSITION	Inhibit steering lock
B2604-00: PNP/CLUTCH SW	Inhibit steering lock
B2608-00: STARTER RELAY	Inhibit engine cranking
B260F-00: ENG STATE SIG LOST	Inhibit engine cranking
B26F1-00: IGN RELAY OFF	Inhibit engine cranking
B26F2-00: IGN RELAY ON	Inhibit engine cranking
B27D4-00: BCM - S/L SENSOR CIRCUIT	Inhibit steering unlock
B27D5-00: S/L SENSOR TEST OUTPUT	Inhibit steering unlock
B27D6-00: S/L CAN COMM CIRCUIT	Inhibit steering lock
B27D7-00: S/L PWR RELAY	Inhibit steering lock
B27D8-00: S/L VEHICLE SPEED MALFUNCTION	Inhibit steering lock
B27D9-00: S/L IGN MALFUNCTION	Inhibit steering lock/unlock
B27DA-00: IPDM CAN COMM CIRCUIT	Inhibit steering lock
B27DC-00: S/L POWER SUPPLY	Inhibit steering lock
B27DD-00: BCM - S/L ID DISCORD	Inhibit steering lock
B27DE-00: S/L MECHANICAL MALFUNCTION	Inhibit steering lock
B27DF-00: S/L HIGH LEVEL MALFUNCTION	Inhibit steering lock/unlock
B27E0-00: S/L LOW LEVEL MALFUNCTION	Inhibit steering lock
B27E1-00: S/L SAFETY CIRCUIT	Inhibit steering lock
B27E5-00: S/L IGN OFF POSITION	Inhibit steering lock
B27E6-00: S/L ANTI-SCAN MODE	Inhibit steering lock
B27E8-00: S/L UNDETERMINED LOCK POS	Inhibit steering lock
U0415: VEHICLE SPEED	Inhibit steering lock

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

< ECU DIAGNOSIS INFORMATION >

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

BCM detects the rain sensor serial link error and the rain sensor malfunction. BCM controls the following fail-safe when rain sensor has a malfunction.

- Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
- Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

NOTE:

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

DTC Inspection Priority Chart

INFOID:000000010688608

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562-00: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000-00: CAN COMM • U1010-00: CONTROL UNIT (CAN)
3	<ul style="list-style-type: none"> • B2190-00: CHAIN OF BCM-IMM ANT • B2191-00: ID DISCORD, BCM-IMMANT • B2192-00: ID DISCORD BCM-ECM • B2193-00: CHAIN OF BCM-ECM • B2195-00: ANTI-SCANNING • B2196-00: DONGLE NG • B2198-00: NATS ANTENNA AMP

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

BCM

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
4	<ul style="list-style-type: none"> • B2556–00: PUSH-BTN IGN SW • B2557–00: VEHICLE SPEED • B2602–00: SHIFT POSITION • B2604–00: PNP/CLUTCH SW • B2608–00: STARTER RELAY • B260F–00: ENG STATE SIG LOST • B261A–00: PUSH-BTN IGN SW • B261F–00: ASCD CNCL/CLTCH SW • B2620–00: NEUTRAL SW • B26E8–00: CLUTCH SW • B26F1–00: IGN RELAY OFF • B26F2–00: IGN RELAY ON • B26FC–00: KEY REGISTRATION • B27D1–00: START CUT RELAY OFF • B27D2–00: START CUT RELAY ON • B27D3–00: S/L THERMAL PROTECTION • B27D4–00: BCM - S/L SENSOR CIRCUIT • B27D5–00: S/L SENSOR TEST OUTPUT • B27D6–00: S/L CAN COMM CIRCUIT • B27D7–00: S/L PWR RELAY • B27D8–00: S/L VEHICLE SPEED MALFUNCTION • B27D9–00: S/L IGN MALFUNCTION • B27DA–00: IPDM CAN COMM CIRCUIT • B27DB–00: S/L IGN OFF • B27DC–00: S/L POWER SUPPLY • B27DD–00: BCM - S/L ID DISCORD • B27DE–00: S/L MECHANICAL MALFUNCTION • B27DF–00: S/L HIGH LEVEL MALFUNCTION • B27E0–00: S/L LOW LEVEL MALFUNCTION • B27E1–00: S/L SAFETY CIRCUIT • B27E3–00: S/L KEY NOT REGISTRATION • B27E4–00: S/L REGISTRATION STATUS • B27E5–00: S/L IGN OFF POSITION • B27E6–00: S/L ANTI-SCAN MODE • B27E7–00: S/L UNDETERMINED UNLOCK POS • B27E8–00: S/L UNDETERMINED LOCK POS • U0415–00: VEHICLE SPEED
5	<ul style="list-style-type: none"> • B2621–00: INSIDE ANTENNA • B2622–00: INSIDE ANTENNA

DTC Index

INFO ID:0000000010688609

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

x:Applicable

CONSULT display	Fail-safe	Freeze Frame Data	Key system malfunction	Security indicator lamp ON	Reference
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000–00: CAN COMM	—	—	—	—	BCS-110
U1010–00: CONTROL UNIT (CAN)	—	—	—	—	BCS-111
U0415–00: VEHICLE SPEED	x	—	x	—	BCS-112
B2190–00: CHAIN OF BCM-IMM ANT	x	—	—	x	•SEC-110^{*1} •SEC-270^{*2}
B2191–00: ID DISCORD, BCM-IMM ANT	x	—	—	x	•SEC-113^{*1} •SEC-273^{*2}

BCM

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data	Key system malfunction	Security indicator lamp ON	Reference
B2192-00: ID DISCORD BCM-ECM	×	—	—	×	• SEC-114 * ¹ • SEC-274 * ²
B2193-00: CHAIN OF BCM-ECM	×	—	—	×	• SEC-116 * ¹ • SEC-275 * ²
B2195-00: ANTI-SCANNING	×	—	—	×	• SEC-118 * ¹ • SEC-277 * ²
B2196-00: DONGLE NG	×	—	—	×	• SEC-119 * ¹ • SEC-278 * ²
B2198-00: NATS ANTENNA AMP	×	—	—	×	• SEC-121 * ¹ • SEC-280 * ²
B2556-00: PUSH-BTN IGN SW	—	×	×	—	SEC-123
B2557-00: VEHICLE SPEED	×	×	×	—	SEC-125
B2562-00: LOW VOLTAGE	—	×	—	—	BCS-113
B2602-00: SHIFT POSITION	×	×	×	—	SEC-127
B2604-00: PNP/CLUTCH SW	×	×	×	—	SEC-130
B2608-00: STARTER RELAY	×	×	×	—	• SEC-133 * ¹ • SEC-283 * ²
B260F-00: ENG STATE SIG LOST	×	×	×	—	• SEC-134 * ¹ • SEC-284 * ²
B261A-00: PUSH-BTN IGN SW	—	×	×	—	PCS-101
B261F-00: ASCD CNCL/CLTCH SW	—	×	×	—	SEC-136
B2620-00: NEUTRAL SW	×	×	×	—	SEC-139
B2621-00: INSIDE ANTENNA	—	×	×	—	• DLK-149 * ³ • DLK-460 * ⁴
B2622-00: INSIDE ANTENNA	—	×	×	—	• DLK-152 * ³ • DLK-463 * ⁴
B26E8-00: CLUTCH SW	—	×	×	—	SEC-143
B26F1-00: IGN RELAY OFF	×	×	×	—	PCS-103
B26F2-00: IGN RELAY ON	×	×	×	—	PCS-105
B26FC-00: KEY REGISTRATION	—	×	×	—	SEC-142
B27D1-00: START CUT RELAY OFF	—	×	×	—	• SEC-146 * ¹ • SEC-286 * ²
B27D2-00: START CUT RELAY ON	—	×	×	—	• SEC-149 * ¹ • SEC-289 * ²
B27D3-00: S/L THERMAL PROTECTION	—	×	×	—	SEC-152
B27D4-00: BCM - S/L SENSOR CIRCUIT	×	×	×	—	SEC-153
B27D5-00: S/L SENSOR TEST OUTPUT	×	×	×	—	SEC-155
B27D6-00: S/L CAN COMM CIRCUIT	×	×	×	—	SEC-158
B27D7-00: S/L PWR RELAY	×	×	×	—	SEC-160
B27D8-00: S/L VEHICLE SPEED MALFUNCTION	×	×	×	—	SEC-162
B27D9-00: S/L IGN MALFUNCTION	×	×	×	—	SEC-164

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

BCM

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data	Key system malfunction	Security indicator lamp ON	Reference
B27DA-00: IPDM CAN COMM CIRCUIT	×	×	×	—	• SEC-165 *1 • SEC-292 *2
B27DB-00: S/L IGN OFF	—	×	×	—	SEC-167
B27DC-00: S/L POWER SUPPLY	×	×	×	—	SEC-169
B27DD-00: BCM - S/L ID DISCORD	×	×	×	—	SEC-171
B27DE-00: S/L MECHANICAL MALFUNCTION	×	×	×	—	SEC-173
B27DF-00: S/L HIGH LEVEL MALFUNCTION	×	×	×	—	SEC-174
B27E0-00: S/L LOW LEVEL MALFUNCTION	×	×	×	—	SEC-175
B27E1-00: S/L SAFETY CIRCUIT	×	×	×	—	SEC-176
B27E3-00: S/L KEY NOT REGISTRATION	—	×	×	—	SEC-178
B27E4-00: S/L REGISTRATION STATUS	—	×	×	—	SEC-179
B27E5-00: S/L IGN OFF POSITION	×	×	×	—	SEC-180
B27E6-00: S/L ANTI-SCAN MODE	×	×	×	—	SEC-182
B27E7-00: S/L UNDETERMINED UNLOCK POS	—	×	×	—	SEC-184
B27E8-00: S/L UNDETERMINED LOCK POS	×	×	×	—	SEC-186

*1: With Intelligent Key system

*2: Without Intelligent Key system

*3: With super lock

*4: Without super lock

< WIRING DIAGRAM >


WIRING DIAGRAM

BCM

Wiring Diagram

INFOID:0000000010688610

BCM (BODY CONTROL MODULE)




2014/03/17

JRMWF4030GB

BCM

< WIRING DIAGRAM >




JRMWF4031GB

BCM

< WIRING DIAGRAM >

(OS) : Without Stop / Start system
 (WS) : With personal lamp
 (FC) : R9M engine models With CVT
 (XR) : Except for R9M engine models with M / T
 (XS) : Without personal lamp




JRMWF4032GB

BCS

BCM

< WIRING DIAGRAM >




JRMWF4033GB

BCM

< WIRING DIAGRAM >

(CS) : With sonar system OFF switch
 (WC) : Without sonar system OFF switch
 (XR) : Except for RDM engine models
 (R9) : RDM engine models




JRMWF4034GB

BCS

BCM


< WIRING DIAGRAM >



JRMWF4035GB

BCM

< WIRING DIAGRAM >




JRMWF4036GB

BCS-87

BCM


< WIRING DIAGRAM >



JRMWF4037GB

BCM



< WIRING DIAGRAM >



JRMWF4038GB

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)		
Connector No. B71	Connector No. B72	Connector No. B127
Connector Name OPTION CONNECTOR (14)	Connector Name SIREN-CONTROL UNIT	Connector Name SIREN-CONTROL UNIT
Connector Type NS021B/BCS	Connector Type RH056B	Connector Type RH056B
		
		
Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]
1 Y -	1 Y -	1 BR -
2 SB -	2 V -	2 P -
		3 V -
		4 Y -
		5 B -
Connector No. B80	Connector No. B106	Connector No. B155
Connector Name REAR COMBINATION LAMP (L/BODY SIDE)	Connector Name FUSE BLOCK (J/B)	Connector Name REAR FOG LAMP
Connector Type NS04MW-CS	Connector Type NS06FW/CS	Connector Type RS021GY
		
		
Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]
1 LAIR -	1 LAIR -	1 LAIR -
2 LAY -	2 LAY -	2 P -
3 LAV -	3 GR -	3 G -
4 B -	4 B -	4 P -
		5 G -
		6 Y -

JRMWF4039GB

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)

Connector No.	B156	Connector No.	[D5	Connector No.	[D9	Connector No.	[D15
Connector Name	REAR FOG LAMP	Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	FRONT DOOR OUTSIDE HANDLE ASSEMBLY (DRIVER SIDE)	Connector Name	FRONT DOOR OUTSIDE HANDLE ASSEMBLY (PASSENGER SIDE)
Connector Type	RS02FGY	Connector Type	NST6FW-CS	Connector Type	E06FGY-RS	Connector Type	RH4FB
Connector No.	[D3	Connector No.	[D11	Connector No.	[D23	Connector No.	[D23
Connector Name	DOOR MIRROR (DRIVER SIDE)	Connector Name	FRONT DOOR OUTSIDE HANDLE ASSEMBLY (PASSENGER SIDE)	Connector Name	DOOR MIRROR (DRIVER SIDE)	Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH16NW-NH	Connector Type	TH16NW-NH	Connector Type	TH16NW-NH	Connector Type	TH16NW-NH
Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)
1 B	GROUND	1 B	LA/V	1 V	-	1 V	-
2 Y	-	2 LA/G	-	2 SB	-	2 SB	-
		3 L	-	3 W	-	3 W	-
		4 R	-	4 B	-	4 B	-
Connector No.	[D3	Connector Name	DOOR MIRROR (PASSENGER SIDE)	Connector No.	[D11	Connector No.	[D23
Connector Name	REAR POWER WINDOW MOTOR (R SIGNAL)	Connector Name	REAR POWER WINDOW MOTOR (R SIGNAL)	Connector Name	REAR POWER WINDOW MOTOR (L SIGNAL)	Connector Name	REAR POWER WINDOW MOTOR (L SIGNAL)
Connector Type	TH16NW-NH	Connector Type	TH16NW-NH	Connector Type	TH16NW-NH	Connector Type	TH16NW-NH
Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)
1 LG	REAR POWER WINDOW MOTOR (R SIGNAL)	2 LA/Y	REAR POWER WINDOW MOTOR (L SIGNAL)	3 LA/L	IGN ON POWER SUPPLY	4 LA/R	IGN ON POWER SUPPLY
3 LAPR	-	4 LA/W	IGN ON POWER SUPPLY	5 GR	ENCODER GROUND	6 GR	ENCODER GROUND
5 LA/W	-	7 GR	-	8 G	ENCODER POWER SUPPLY	9 G	ENCODER POWER SUPPLY
7 G	-	10 B	-	11 LA/SB	REAR POWER WINDOW MOTOR (PASSENGER SIDE) SIGNAL	12 LA/G	REAR POWER WINDOW MOTOR (PASSENGER SIDE) SIGNAL
10 B	-	11 LA/SB	-	12 LA/G	-	13 LA/V	-
12 LA/G	-	14 LA/B	-	14 LA/V	-	15 B	-
14 LA/B	-	15 B	-	15 B	-	16 Y	-
16 Y	-	16 Y	-	16 Y	-		
Connector No.	[D6	Connector Name	POWER WINDOW MAIN SWITCH	Connector No.	[D6	Connector No.	[D6
Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NST6FW-CS	Connector Type	NST6FW-CS	Connector Type	NST6FW-CS	Connector Type	NST6FW-CS
Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)
2 LG	-	1 R	-	2 GR	-	2 GR	-
3 LAPR	-	2 SB	-	3 LA/L	-	3 LA/L	-
5 LA/W	-	3 P	-	4 LA/R	-	4 LA/R	-
7 GR	-	4 B	-	5 LA/Y	-	5 LA/Y	-
8 G	-			6 L	-	6 L	-
10 B	-			7 L	-	7 L	-
11 LA/SB	-			8 G	-	8 G	-
12 LA/G	-			11 LA/G	-	11 LA/G	-
14 LA/B	-			12 LA/V	-	12 LA/V	-
15 B	-			14 LA/B	-	14 LA/B	-
16 Y	-			15 B	-	15 B	-
				16 Y	-	16 Y	-
Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)
17 LA/L	REAR POWER WINDOW MOTOR (PASSENGER SIDE) SIGNAL	17 LA/R	BATTERY POWER SUPPLY	17 LA/L	FRONT POWER WINDOW MOTOR (PASSENGER SIDE) SIGNAL	17 LA/R	FRONT POWER WINDOW MOTOR (PASSENGER SIDE) SIGNAL
18 LA/R	-	18 LA/R	-	18 LA/R	-	18 LA/R	-

JRMWF4040GB

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)


Connector No. D25	Connector No. D33	Connector No. D35	Connector No. D45
Connector Name POWER WINDOW MAIN SWITCH	Connector Name FRONT DOOR OUTSIDE HANDLE ASSEMBLY (DRIVERS SIDE)	Connector Name FRONT POWER WINDOW SWITCH (PASSENGER SIDE)	Connector Name FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type RH04FB	Connector Type FE04FB-FHA2-LC	Connector Type NS03FW-CS	Connector Type NS03FW-CS
 H.S.	 H.S.	 H.S.	 H.S.
7 6 5 4 8 9 10	1 2 3 4 5 6	2 3 4 5 6	4 3 1 5 2
7 6 5 4 8 9 10	1 2 3 4 5 6	2 3 4 5 6	4 3 1 5 2
Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]
1 B GROUND	1 V	2 B	1 LAGR
2 LAGR	2 SB	3 R	2 LAGR
3 L	3 W	4 V	3 UNLOCK
4 P	4 B	5 G	4 GND
5 W	-	6 LG	5 LAY
6 AIL	-	-	4 LAIL
7 LAG	-	-	5 LAIR
8 Y	-	-	-
9 G	-	-	-
10 SB	-	-	-
11 IGN/ON POWER SIGNAL	-	-	-
12 LG	-	-	-
13 GR	-	-	-
14 G	-	-	-
15 BG	-	-	-
16 LAV	-	-	-
REAR POWER WINDOW MOTOR/BLINDING SIGNAL	REAR POWER WINDOW MOTOR/LIFTUP SIGNAL	DOOR MIRROR (PASSENGER SIDE)	DOOR MIRROR (PASSENGER SIDE)
REAR POWER WINDOW MOTOR/LIFTUP SIGNAL	IGN/ON POWER SIGNAL	TH16MW/NH	TH16MW/NH
REAR POWER WINDOW MOTOR/BLINDING SIGNAL	ENCODER GROUND	 H.S.	 H.S.
1 2 3 4	5 6	8 7 16 [5] 4 [12] 11 [10]	5 6
1 2 3 4	5 6	8 7 16 [5] 4 [12] 11 [10]	5 6
Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]	Terminal Color Of No. Wire Signal Name [Specification]
1 R	2 SB	3 P	4 B
2 SB	-	-	-
3 P	-	-	-
4 B	-	-	-
5 V	-	-	-
6 V	-	-	-
7 L	-	-	-
8 V	-	-	-
10 B	-	-	-
11 LAGR	-	-	-
12 LAV	-	-	-
14 LAB	-	-	-
15 B	-	-	-
16 Y	-	-	-
FRONT POWER WINDOW MOTOR/BLINDING SIGNAL	FRONT POWER WINDOW MOTOR/LIFTUP SIGNAL	BATTERY POWER SUPPLY	BATTERY POWER SUPPLY
FRONT POWER WINDOW MOTOR/BLINDING SIGNAL	FRONT POWER WINDOW MOTOR/LIFTUP SIGNAL	BIG	BIG
FRONT POWER WINDOW MOTOR/BLINDING SIGNAL	FRONT POWER WINDOW MOTOR/LIFTUP SIGNAL	FRONT POWER CONDUCTOR (DRIVERS SIDE) DOWNSIGNAL	FRONT POWER CONDUCTOR (DRIVERS SIDE) DOWNSIGNAL
FRONT POWER CONDUCTOR (DRIVERS SIDE) DOWNSIGNAL	FRONT POWER CONDUCTOR (DRIVERS SIDE) DOWNSIGNAL	FRONT POWER CONDUCTOR (DRIVERS SIDE) DOWNSIGNAL	FRONT POWER CONDUCTOR (DRIVERS SIDE) DOWNSIGNAL

JRMWF4041GB

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)

Connector No. D67	Connector No. D83	Connector No. D93	Connector No. D98
Connector Name REAR POWER WINDOW SWITCH (PASSENGER SIDE)	Connector Name REAR POWER WINDOW SWITCH RH	Connector Name REAR DOOR LOCK ASSEMBLY RH	Connector Name REAR DOOR LOCK ASSEMBLY
Connector Type NS08FW-CS	Connector Type NS08FW-CS	Connector Type NS08FW-CS	Connector Type FEA4FB-FH42-LC
 HS.	 HS.	 HS.	 HS.
Terminal Color Of Wire No. Signal Name [Specification]	Terminal Color Of Wire No. Signal Name [Specification]	Terminal Color Of Wire No. Signal Name [Specification]	Terminal Color Of Wire No. Signal Name [Specification]
1 LG - LAGR	1 LAGR -	4 SB -	1 LAGR -
2 BR - LAGR	2 LAGR -	5 W -	2 LAGR -
3 B - LAY	3 LAY -	6 P -	3 LAY -
6 AY - G	4 G -	4 G -	4 G -
7 A/R - R	5 R -	5 R -	5 R -
8 A/L -	6 -	6 -	6 -
11 A/Y -	7 -	7 -	7 -
12 A/R -	8 -	8 -	8 -
Connector No. D85	Connector No. D98	Connector No. D103	Connector No. D103
Connector Name REAR DOOR LOCK ASSEMBLY LH	Connector Name DOOR MIRROR (PASSENGER SIDE)	Connector Name REAR POWER WINDOW SWITCH RH	Connector Name REAR POWER WINDOW SWITCH RH
Connector Type E06F0Y-RS	Connector Type TH16WW-NH	Connector Type NS08FW-CS	Connector Type NS08FW-CS
 HS.	 HS.	 HS.	 HS.
Terminal Color Of Wire No. Signal Name [Specification]	Terminal Color Of Wire No. Signal Name [Specification]	Terminal Color Of Wire No. Signal Name [Specification]	Terminal Color Of Wire No. Signal Name [Specification]
1 LAG - LAG	2 LAG -	1 LAGR -	1 LAGR -
2 LAV - LAV	3 LAV -	2 LAY -	2 LAY -
5 LAG -	4 LAG -	3 LAY -	3 LAY -
7 LAV -	8 V -	4 G -	4 G -
11 LAGB -	12 LAGR -	5 R -	5 R -
12 LAGR -	13 LAGB -		
14 LAB -	15 LAB -		
15 B -	16 Y -		

JRMWF4042GB

BCM

< WIRING DIAGRAM >


BCM (BODY CONTROL MODULE)

Connector No.	D105	Connector No.	D118	Connector No.	D168	Connector No.	D170
Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector Name	REAR DOOR LOCK ASSEMBLY LH	Connector Name	BACK DOOR LOCK ASSEMBLY	Connector Name	HANDS FREE SENSOR
Connector Type	FE040FB-FH421C	Connector Type	FE040FB-FH421C	Connector Type	NS04FW-CS	Connector Type	TH04FW-NH
							
Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]
1	W	1	W	1	W	1	W
2	V	2	GR	2	W	2	W
3	LG	3	W	3	W	3	W
4	GR	4	GR	4	W	4	W
5	-	5	-	5	-	5	-
6	-	6	-	6	-	6	-
Connector No.	D113	Connector No.	D154	Connector No.	D169	Connector No.	D172
Connector Name	REAR POWER WINDOW SWITCH LH	Connector Name	HIGH-MOUNTED STOP LAMP	Connector Name	BACK DOOR SWITCH ASSEMBLY	Connector Name	POWER MANAGEMENT PORT
Connector Type	NS04FW-CS	Connector Type	TK02hW	Connector Type	TH04MW-NH	Connector Type	Output Sensor GND
							
Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]
1	LA/GR	1	W	1	W	1	W
2	LA/Y	2	W	2	GR	2	W
3	G	3	-	3	GR	4	W
4	R	4	-	4	BR	5	W
5	-	5	-	5	- (Without PED)	6	W
				6	- (With PED)	7	W
				7	-	8	B

JRMWF4043GB

BCM

< WIRING DIAGRAM >



JRMWF4044GB

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)

Connector No.	E23	Connector No.	E27	Connector No.	E109	Connector No.	E112
Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	FRONT TURN SIGNAL LAMP LH	Connector Name	CLUTCH/INTERLOCK SWITCH	Connector Name	Brake Pedal Position Switch
Connector Type	TR24FB-NH	Connector Type	RS02FGY	Connector Type	MOZFER-LC	Connector Type	MOZFER-LC
							
Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]
164	164	1	164	1	P	1	P
165	165	2	165	2	V	2	GR
166	166					3	-
167	167					4	R
168	168						- [With MR20 or QR25 Engine]
169	169						- [With R30 Engine]
170	170						
171	171						
172	172						
173	173						
174	174						
175	175						
176	176						
177	177						
178	178						
179	179						
180	180						
181	181						
182	182						
183	183						
184	184						
185	185						
186	186						
187	187						
188	188						
189	189						
190	190						
191	191						
192	192						
193	193						
194	194						
195	195						
196	196						
197	197						
198	198						
199	199						
200	200						
201	201						
202	202						
203	203						
204	204						
205	205						
206	206						
207	207						
208	208						
209	209						
210	210						
211	211						
212	212						
213	213						
214	214						
215	215						
216	216						
217	217						
218	218						
219	219						
220	220						
221	221						
222	222						
223	223						
224	224						
225	225						
226	226						
227	227						
228	228						
229	229						
230	230						
231	231						
232	232						
233	233						
234	234						
235	235						
236	236						
237	237						
238	238						
239	239						
240	240						
241	241						
242	242						
243	243						
244	244						
245	245						
246	246						
247	247						
248	248						
249	249						
250	250						
251	251						
252	252						
253	253						
254	254						
255	255						
256	256						
257	257						
258	258						
259	259						
260	260						
261	261						
262	262						
263	263						
264	264						
265	265						
266	266						
267	267						
268	268						
269	269						
270	270						
271	271						
272	272						
273	273						
274	274						
275	275						
276	276						
277	277						
278	278						
279	279						
280	280						
281	281						
282	282						
283	283						
284	284						
285	285						
286	286						
287	287						
288	288						
289	289						
290	290						
291	291						
292	292						
293	293						
294	294						
295	295						
296	296						
297	297						
298	298						
299	299						
300	300						
301	301						
302	302						
303	303						
304	304						
305	305						
306	306						
307	307						
308	308						
309	309						
310	310						
311	311						
312	312						
313	313						
314	314						
315	315						
316	316						
317	317						
318	318						
319	319						
320	320						
321	321						
322	322						
323	323						
324	324						
325	325						
326	326						
327	327						
328	328						
329	329						
330	330						
331	331						
332	332						
333	333						
334	334						
335	335						
336	336						
337	337						
338	338						
339	339						
340	340						
341	341						
342	342						
343	343						
344	344						
345	345						
346	346						
347	347						
348	348						
349	349						
350	350						
351	351						
352	352						
353	353						
354	354						
355	355						
356	356						
357	357						
358	358						
359	359						
360	360						
361	361						
362	362						
363	363						
364	364						
365	365						
366	366						
367	367						
368	368						
369	369						
370	370						
371	371						
372	372						
373	373						
374	374						
375	375						
376	376						
377	377						
378	378						
379	379						
380	380						
381	381						
382	382						
383	383						
384	384						
385	385						
386	386						
387	387						
388	388						
389	389						
390	390						
391	391						
392	392						
393	393						
394	394						
395	395						
396	396						
397	397						
398	398						
399	399						

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)

Connector No.	E120	Connector No.	E138	Connector No.	E140	Connector No.	F22
Connector Name	STOP LAMP SWITCH	Connector Name	PTC HEATER	Connector Name	PTC RELAY-2	Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	M04FW-LC	Connector Type	AL405FB-R-RH	Connector Type	MS02FL-M2-LC	Connector Type	YDX06FB-HS4
							
Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)
1 V	-	1 BG	-	1 BG	-	1 SB	-
2 LG	-	2 GR	-	2 SB	-	2 GR	-
3 Y	-	3 G	-	3 P	-	3 W	-
4 W	-	4 GR	-	4 G	-	4 V	-
5	Y	5	-	5 G	-	5 G	-
						6 BR	-
						7 Y	-
						8 GR	-
Connector No.	E121	Connector No.	E139	Connector No.	E141	Connector No.	F69
Connector Name	STOP LAMP SWITCH	Connector Name	PTC RELAY-1	Connector Name	PTC RELAY-3	Connector Name	STARTER CONTROL RELAY
Connector Type	M04FW-LC	Connector Type	MS02FL-M2-LC	Connector Type	MS02FL-M2-LC	Connector Type	MS02FL-M2-LC
							
Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)	Terminal Color Of No.	Signal Name (Specification)
1 V	-	1 L	-	1 L	-	1 SB	-
2 LG	-	2 W	-	2 W	-	2 G	-
3 Y	-	3 GR	-	3 Y	-	3 L	-
4 W	-	5 L	-	5 L	-	5 GR	-

JRMWF4046GB

BCS

Z

O

P

A

B

C

D

E

G

I

K

L

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)

Connector No.	F72	86	LG	-
Connector Name	FROM ER (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)			
Connector Type	NS16FW-CS			
				
Terminal Color Of No.	Signal Name [Specification]			
65	P	-		
66	L	- (With R3M Engine)		
66	R	- (With MR20 or QR25 Engine)		
67	V	-		
70	BG	- (With CVT)		
70	GR	- (With MT)		
71	SB	-		
72	GR	-		
73	R	- (With R3M Engine)		
73	Y	- (With MR20 or QR25 Engine)		
75	BR	- (With R3M Engine)		
75	L	- (With R3M Engine)		
76	P	- (With R3M Engine)		
78	L	- (With QR25 Engine)		
78	R	- (With R3M Engine)		
79	G	-		
101	V	-		
102	Y	-		
105	W	-		
106	BR	-		
107	V	-		
110	S3	-		


Connector No.	M1	Connector No.	M3
Connector Name	FUSE BLOCK (JB)	Connector Name	FUSE BLOCK (JB)
Connector Type	NS16FW-M2	Connector Type	NS16FW-CS
			
Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]
1A	L	1C	LG
2A	LG	1C	LG
3A	Y	1C	R
4A	LG	1C	L
6A	BG	1C	LA/W
7A	BR	1C	R
8A	SB	2C	G
		3C	Y
		4C	LG
		5C	GR
		6C	LA/R
		7C	Y
		8C	BR
		9C	LA/R
		10C	- (With ISS)
		11C	- (Without ISS)

Connector No.	F74	Connector No.	M2
Connector Name	COM (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	FUSE BLOCK (JB)
Connector Type	TR24FB-NH	Connector Type	NS16FW-CS
			
Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]
87	L	1A	LG
88	P	2A	LG
89	W	3A	Y
90	R	4A	LG
92	GR	6A	BG
93	G	7A	BR
94	S3	8A	SB
95	LG		
96	W		
97	P		
98	Y		
99	BR		
100	LG		
101	V		
102	Y		
105	W		
106	BR		
107	V		
110	S3		

Connector No.	F73	Connector No.	M4
Connector Name	FROM ER (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	DATA LINK CONNECTOR
Connector Type	YLA08F6GY	Connector Type	BD16FW
			
Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]
81	G	108	GR
83	L	108	- (With MR20 engine or R3M engine)
84	GR	108	- (With QR25 engine)
85	P	108	-
128	BR	128	BR
129	W	129	W
130	GR	130	GR
131	W	131	W
132	GR	132	GR
133	W	133	W
134	GR	134	GR
135	W	135	W
136	GR	136	GR
137	W	137	W
138	GR	138	GR
139	W	139	W
140	GR	140	GR
141	W	141	W
142	GR	142	GR
143	W	143	W
144	GR	144	GR
145	W	145	W
146	GR	146	GR
147	W	147	W
148	GR	148	GR
149	W	149	W
150	GR	150	GR
151	W	151	W
152	GR	152	GR
153	W	153	W
154	GR	154	GR
155	W	155	W
156	GR	156	GR
157	W	157	W
158	GR	158	GR
159	W	159	W
160	GR	160	GR
161	W	161	W
162	GR	162	GR
163	W	163	W
164	GR	164	GR
165	W	165	W
166	GR	166	GR
167	W	167	W
168	GR	168	GR
169	W	169	W
170	GR	170	GR
171	W	171	W
172	GR	172	GR
173	W	173	W
174	GR	174	GR
175	W	175	W
176	GR	176	GR
177	W	177	W
178	GR	178	GR
179	W	179	W
180	GR	180	GR
181	W	181	W
182	GR	182	GR
183	W	183	W
184	GR	184	GR
185	W	185	W
186	GR	186	GR
187	W	187	W
188	GR	188	GR
189	W	189	W
190	GR	190	GR
191	W	191	W
192	GR	192	GR
193	W	193	W
194	GR	194	GR
195	W	195	W
196	GR	196	GR
197	W	197	W
198	GR	198	GR
199	W	199	W
200	GR	200	GR
201	W	201	W
202	GR	202	GR
203	W	203	W
204	GR	204	GR
205	W	205	W
206	GR	206	GR
207	W	207	W
208	GR	208	GR
209	W	209	W
210	GR	210	GR
211	W	211	W
212	GR	212	GR
213	W	213	W
214	GR	214	GR
215	W	215	W
216	GR	216	GR
217	W	217	W
218	GR	218	GR
219	W	219	W
220	GR	220	GR
221	W	221	W
222	GR	222	GR
223	W	223	W
224	GR	224	GR
225	W	225	W
226	GR	226	GR
227	W	227	W
228	GR	228	GR
229	W	229	W
230	GR	230	GR
231	W	231	W
232	GR	232	GR
233	W	233	W
234	GR	234	GR
235	W	235	W
236	GR	236	GR
237	W	237	W
238	GR	238	GR
239	W	239	W
240	GR	240	GR
241	W	241	W
242	GR	242	GR
243	W	243	W
244	GR	244	GR
245	W	245	W
246	GR	246	GR
247	W	247	W
248	GR	248	GR
249	W	249	W
250	GR	250	GR
251	W	251	W
252	GR	252	GR
253	W	253	W
254	GR	254	GR
255	W	255	W
256	GR	256	GR
257	W	257	W
258	GR	258	GR
259	W	259	W
260	GR	260	GR
261	W	261	W
262	GR	262	GR
263	W	263	W
264	GR	264	GR
265	W	265	W
266	GR	266	GR
267	W	267	W
268	GR	268	GR
269	W	269	W
270	GR	270	GR
271	W	271	W
272	GR	272	GR
273	W	273	W
274	GR	274	GR
275	W	275	W
276	GR	276	GR
277	W	277	W
278	GR	278	GR
279	W	279	W
280	GR	280	GR
281	W	281	W
282	GR	282	GR
283	W	283	W
284	GR	284	GR
285	W	285	W
286	GR	286	GR
287	W	287	W
288	GR	288	GR
289	W	289	W
290	GR	290	GR
291	W	291	W
292	GR	292	GR
293	W	293	W
294	GR	294	GR
295	W	295	W
296	GR	296	GR
297	W	297	W
298	GR	298	GR
299	W	299	W
300	GR	300	GR
301	W	301	W
302	GR	302	GR
303	W	303	W
304	GR	304	GR
305	W	305	W
306	GR	306	GR
307	W	307	W
308	GR	308	GR
309	W	309	W
310	GR	310	GR
311	W	311	W
312	GR	312	GR
313	W	313	W
314	GR	314	GR
315	W	315	W
316	GR	316	GR
317	W	317	W
318	GR	318	GR
319	W	319	W
320	GR	320	GR
321	W	321	W
322	GR	322	GR
323	W	323	W
324	GR	324	GR
325	W	325	W
326	GR	326	GR
327	W	327	W
328	GR	328	GR
329	W	329	W
330	GR	330	GR
331	W	331	W
332	GR	332	GR
333	W	333	W
334	GR	334	GR
335	W	335	W
336	GR	336	GR
337	W	337	W
338	GR	338	GR
339	W	339	W
340	GR	340	GR
341	W	341	W
342	GR	342	GR
343	W	343	W
344	GR	344	GR
345	W	345	W
346	GR	346	GR
347	W	347	W
348	GR	348	GR
349	W	349	W
350	GR	350	GR
351	W	351	W
352	GR	352	GR
353	W	353	W
354	GR	354	GR
355	W	355	W
356	GR	356	GR
357	W	357	W
358	GR	358	GR
359	W	359	W
360	GR	360	GR
361	W	361	W
362	GR	362	GR
363	W	363	

BCM

< WIRING DIAGRAM >



BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)

	HS.		HS.
Connector No. M44	Connector Name INTERIOR ROOM LAMP RELAY	Connector No. M44	Connector Name INTERIOR ROOM LAMP RELAY
Connector Type MS32FL-M2-LC	Connector Type MS32FL-M2-LC	Connector No. M44	Connector Name INTERIOR ROOM LAMP RELAY
Connector Type TH32FW-NH	Connector Type TH32FW-NH	Connector No. M44	Connector Name INTERIOR ROOM LAMP RELAY
Connector Type TH16FW-NH	Connector Type TH16FW-NH	Connector No. M44	Connector Name INTERIOR ROOM LAMP RELAY
Connector No. M31	Connector Name COMBINATION SWITCH	Connector No. M31	Connector Name COMBINATION SWITCH
Connector Type TH32FW-NH	Connector Type TH32FW-NH	Connector No. M31	Connector Name COMBINATION SWITCH
Connector No. M31	Connector Name COMBINATION SWITCH	Connector No. M31	Connector Name COMBINATION SWITCH


Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
37	V	ILLUMINATION CONTROL SWITCH SIGNAL (L)	21	B
38	G	VEHICLE SPEED SIGNAL (8-PULSE)	22	MICROPHONE (VCC)
39	W	VEHICLE SPEED SIGNAL (2-PULSE)	23	AUX SOUND SIGNAL (H)
			24	AUX SOUND SIGNAL (RH)
			25	Y
			26	SHIELD
			30	R
			37	W
			38	SHIELD
			43	B
			45	W
			46	SB
			47	LG
			48	SB
			49	LG

Connector No.	Connector Name	Terminal No.	Color Of Wire	Signal Name [Specification]
41	L	CANH	CANH	
42	P	CANL	CANL	
43	W			ILLUMINATION CONTROL SIGNAL
44	LAB			FUEL LEVEL SENSOR GROUND
45	LA/G			BATTERY POWER SUPPLY
46	LABR	1	GR	IGNITION SIGNAL [Without SS]
46	V	2	Y	IGNITION SIGNAL [With SS]
47	CO	3	R	ACCELERATOR POSITION SIGNAL
48	CO	4	CO	ACCELERATOR POSITION SIGNAL

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND	1	R	
7	BG	SECURITY SIGNAL	2	B	-
9	GR	ECO MODE SWITCH SIGNAL	3	LG	-
15	L	AMBIENT SENSOR SIGNAL	4	GR	-
17	BG	METER CONTROL SWITCH/GROUND	5	SB	-
18	SB	TRIP CONTROL SWITCH/SIGNAL	6	B	-
52	B	GROUND			

BCM (BODY CONTROL MODULE)

Connector No.	M52	Connector No.	M57
Connector Name	CVT SHIFT SELECTOR	Connector Name	STEERING LOCK UNIT
Connector Type	TH4F-FW-NH	Connector Type	TH3F-B-NH



Terminal Color Of

Signal Name (Specification)

3	R	1	GR
4	B	2	W
7	LG	3	L
8	-	4	-
9	BR	5	P
10	-	6	Y
11	BG	7	GR
12	-	8	P
13	BG	9	STEERING LOCK UNIT CAN L.
		10	STEERING LOCK UNIT CAN L.
		11	SB
		12	L
		13	G

Terminal Color Of

Signal Name (Specification)

1	WIRE	1	WIRE
2	-	2	-
3	WIRE	3	-
4	-	4	-

Signal Name (Specification)

Terminal Color Of

1	WIRE	1	WIRE
2	-	2	-
3	WIRE	3	-
4	-	4	-

Terminal Color Of

Signal Name (Specification)

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R	1	WIRE
2	B	2	-
3	LG	3	BR
4	-	4	LG

Signal Name (Specification)

Terminal Color Of

1	R</td

BCM

< WIRING DIAGRAM >


BCM (BODY CONTROL MODULE)

Terminal No.	Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	
88	W	PUSH-BTN IGN SW/LCNT	56	P	DONGLE		
90	Y	SL CONDITION	57	L	CVT SHIFT SELECT/DETENT SW/PWR		
94	G	DETENTION SW	60	R	HEADLAMP/WASHER SW		
95	V	EXTENDED STORAGE FUSE SW	63	G	POWER WINDOW RELAY/CON		
99	R	STOP/START OFF SW	64	LAIR	REAR WINDOW DEFROSTER RELAY/CON		
100	V	DRIVER DOOR ANT +	65	BR	ACC RELAY/CON		
101	Y	PUSH SW	67	Y	IGN RELAY (F/B) CON/OUTPUT		
104	R	DR DOOR UNLK SENS	68	LA/W	BLOWER RELAY/CON		
105	Y	DR DOOR REO SW	73	LG	COMBI SW INPUT 5		
106	W	ACC OUT/PUT	74	Y	COMBI SW INPUT 6		
107	V	SENSOR CANCEL SW	75	BG	SECURITY IND LAMP/CONT		
109	P	NATS ANTENNA AMP.	76	G	COMBI SW INPUT 3		
110	BG	DIMMER SIGNAL	77	GR	COMBI SW INPUT 4		
111	R	DOOR/LK STAT IND/OUTPUT	78	V	COMBI SW INPUT 1		
112	SB	STOP/START OFF SW/INDICATOR	79	W	COMBI SW INPUT 2		
113	LG	NATS ANTENNA AMP.	80	SB	DOOR UNLOCK SW		
114	Y	NATS ANTENNA AMP.					
115	W	NATS ANTENNA AMP.					
116	BG	ROOM ANT 1 +					
117	GR	PASSENGER DOOR ANT +					
118	SB	PASSENGER DOOR ANT +					
119	P	RIVER DOOR ANT +					
120	BR						
Connector No. M87		Connector Name BCM (BODY CONTROL MODULE)		Connector No. M144		Connector Name HEADLAMP/WASHER SWITCH	
Connector Type TH04F-G7-NH		Connector Type TH05F-NH		Connector Type TH05F-W		Connector Type TH05F-W	
							

BCM

< WIRING DIAGRAM >

BCM (BODY CONTROL MODULE)

Connector No.	R13	Connector No.	R23
Connector Name	SUNSHADE MOTOR ASSEMBLY	Connector Name	VANITY MIRROR LAMP LH
Connector Type	YEAT0FGY	Connector Type	MCAG0FW
			
Terminal No.	Signal Name (Specification)	Terminal No.	Signal Name (Specification)
1	GROUND	1	-
2	-	2	-
3	-	3	IGN ON POWER SUPPLY
4	-	6	BATTERY POWER SUPPLY
5	-	7	COMMUNICATION LINE
6	-		
7	-		
Connector No.	R12	Connector No.	R20
Connector Name	SUNROOF MOTOR ASSEMBLY	Connector Name	LIGHT & RAIN SENSOR
Connector Type	YEAT0FGY	Connector Type	AAE03FB
			
Terminal No.	Signal Name (Specification)	Terminal No.	Signal Name (Specification)
1	GROUND	1	-
2	-	2	-
3	-	3	IGN ON POWER SUPPLY
4	-		-
5	-		-
6	-		-
7	-		-
8	-		-
9	-		-
10	-		-
Terminal No.	Signal Name (Specification)	Terminal No.	Signal Name (Specification)
1	GROUND	1	-
2	OPEN CLOSE 2nd SIGNAL	2	-
3	-	3	-
4	-	4	PUSH SIGNAL
5	-	5	OPEN 1st SIGNAL
6	-	6	BATTERY POWER SUPPLY
7	-	7	COMMUNICATION LINE
8	-	8	VEHICLE SPEED SIGNAL
9	-	9	CLOSE 1st SIGNAL
10	-		

JRMWF4052GB

BCS

Z

O

P

A

B

C

D

M

G

I

K

L

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

BASIC INSPECTION

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

Description

INFOID:000000010688611

BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" of "Read / Write Configuration" cannot be used, use the "Manual Configuration" after replacing BCM.

AFTER REPLACEMENT

CAUTION:

When replacing BCM, always perform "Read / Write Configuration" or "Manual Configuration" with CONSULT. Or not doing so, BCM control function does not operate normally.

- Complete the procedure of "Read / Write Configuration" in order.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- If you set incorrect "Read / Write Configuration" or "Manual Configuration", incidents might occur.

NOTE:

- When replacing BCM, perform the system initialization (NATS) (if equipped).
- When replacing BCM, perform the system initialization (CAN gateway).

Work Procedure

INFOID:000000010688612

1. SAVING VEHICLE SPECIFICATION (BCM)

④ CONSULT Configuration

Perform "Before Replace ECU" of "Read/ Write Configuration" to save or print current vehicle specification. Refer to [BCS-106, "Description"](#).

NOTE:

If "Before Replace ECU" of "Read/Write Configuration" cannot be used, use the "Manual Configuration" after replacing BCM.

>> GO TO 2.

2. SAVING VEHICLE SPECIFICATION (CAN GATEWAY)

④ CONSULT Configuration

Perform "Before Replace ECU" of "Read / Write Configuration" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" of "Read / Write Configuration" cannot be used, use the "Manual Configuration" after replacing BCM.

>> GO TO 3.

3. REPLACE BCM

Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).

>> GO TO 4.

4. WRITING VEHICLE SPECIFICATION (BCM)

④ CONSULT Configuration

Perform "After Replace ECU" of "Read / Write Configuration" or "Manual Configuration" to write vehicle specification. Refer to [BCS-106, "Work Procedure"](#).

>> GO TO 5.

5. INITIALIZE BCM (NATS) (IF EQUIPPED)

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

Perform BCM initialization. (NATS)

>> GO TO 6.

6. INITIALIZE CAN GATEWAY

Perform CAN GATEWAY initialization. Refer to [LAN-113. "Work Procedure"](#).

>> WORK END

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

CONFIGURATION (BCM)

< BASIC INSPECTION >

CONFIGURATION (BCM)

Description

INFOID:0000000010688613

Vehicle specification needs to be written with CONSULT because it is not written after replacing BCM. Configuration has three functions as follows.

Function		Description
Read / Write Configuration	Before Replace ECU	<ul style="list-style-type: none">• Reads the vehicle configuration of current BCM.• Saves the read vehicle configuration.
	After Replace ECU	Writes the vehicle configuration with saved data.
Manual Configuration		Writes the vehicle configuration with manual selection.

NOTE:

Manual setting item: Items which need selection by vehicle specifications

Automatic setting item: Items which are written in automatically (Setting cannot be changed)

For some models and specifications, the automatic setting item may not be displayed.

CAUTION:

When replacing BCM, always perform “Re/programming, Configuration” with CONSULT. Or not doing so, BCM control function does not operate normally.

- Complete the procedure of “Read / Write Configuration” in order.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform “Read / Write Configuration” except for new BCM.
- If you set incorrect “Read / Write Configuration”, incidents might occur.

Work Procedure

INFOID:0000000010688614

1. WRITING MODE SELECTION

CONSULT Configuration

Select “Re/programming, Configuration” of BCM.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

2. PERFORM “AFTER REPLACE ECU” OF “READ / WRITE CONFIGURATION”

CONSULT Configuration

Perform “After Replace ECU” of “Read / Write Configuration”.

>> WORK END

3. PERFORM “MANUAL CONFIGURATION”

CONSULT Configuration

1. Select “Manual Configuration”.
2. Identify the correct model and configuration list. Refer to [BCS-107, “Configuration list”](#).
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

NOTE:

If items are not displayed, touch “Next”. Refer to [BCS-107, “Configuration list”](#) for written items and setting value.

4. Touch “Next”.
5. Touch “OK”.

CAUTION:

Make sure to select “OK” even if the indicated configuration of brand new BCM is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model cannot be memorized.

6. Check that the configuration has been successfully written and touch “End”.

CONFIGURATION (BCM)

< BASIC INSPECTION >

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by BCM operates normally.

>> WORK END

Configuration list

INFOID:0000000010688615

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

WITH INTELLIGENT KEY SYSTEM

SETTING ITEM		NOTE
Items	Setting value	
SUPER LOCK	WITH ⇄ WITHOUT	—
H/L WASHER	WITHOUT ⇄ MODE1	<ul style="list-style-type: none"> WITHOUT: Without headlamp washer MODE1: With headlamp washer
HLW CYL SW INP NMB OF TIM	MODE1 ⇄ MODE2	<ul style="list-style-type: none"> MODE1: Except for Europe (LHD) models with headlamp washer MODE2: For Europe (LHD) models with headlamp washer
THEFT ALM AREA	WITHOUT ⇄ MODE4	<ul style="list-style-type: none"> WITHOUT: Except for Europe (RHD) models MODE4: For Europe (RHD) models
HANDLE	LHD ⇄ RHD	—
ECM TYPE	MODE1 ⇄ MODE2	<ul style="list-style-type: none"> MODE1: For MR engine or QR engine models MODE2: Except for MR engine or QR engine models
DONGLE	WITH ⇄ WITHOUT	<ul style="list-style-type: none"> WITH: For Europe (RHD) models WITHOUT: Except for Europe (RHD) models
TPMS	WITH ⇄ WITHOUT	—
HBA SYSTEM	WITH ⇄ WITHOUT	<ul style="list-style-type: none"> WITH: With high beam assist system WITHOUT: Without high beam assist system
Key Fob Type	LCK/UNLCK/PBD	—
ALT TYPE	MODE1 ⇄ MODE4	<ul style="list-style-type: none"> MODE1: For MR engine or QR engine models MODE4: Except for MR engine or QR engine models
TRANSMISSION	MT with ABS ⇄ AT with ABS	<ul style="list-style-type: none"> MT with ABS: M/T models AT with ABS: Except M/T models

⇒: Items which confirm vehicle specifications

WITHOUT INTELLIGENT KEY SYSTEM

SETTING ITEM		NOTE
Items	Setting value	
AUTO LIGHT	WITHOUT ⇄ MODE5	<ul style="list-style-type: none"> WITHOUT: Without auto light MODE5: With auto light
SUPER LOCK	WITH ⇄ WITHOUT	—
H/L WASHER	WITHOUT ⇄ MODE1	<ul style="list-style-type: none"> WITHOUT: Without headlamp washer MODE1: With headlamp washer
HLW CYL SW INP NMB OF TIM	MODE1 ⇄ MODE2	<ul style="list-style-type: none"> MODE1: Except for Europe (LHD) models with headlamp washer MODE2: For Europe (LHD) models with headlamp washer

CONFIGURATION (BCM)

< BASIC INSPECTION >

SETTING ITEM		NOTE
Items	Setting value	
RAIN SENSOR CONFIG	WITH ⇄ WITHOUT	<ul style="list-style-type: none"> WITH: With light & rain sensor WITHOUT: Without light & rain sensor
THEFT ALM AREA	WITHOUT ⇄ MODE4	<ul style="list-style-type: none"> WITHOUT: Except for Europe (RHD) models MODE4: For Europe (RHD) models
HANDLE	LHD ⇄ RHD	—
ECM TYPE	MODE1 ⇄ MODE2	<ul style="list-style-type: none"> MODE1: For MR engine or QR engine models MODE2: Except for MR engine or QR engine models
DONGLE	WITH ⇄ WITHOUT	<ul style="list-style-type: none"> WITH: For Europe (RHD) models WITHOUT: Except for Europe (RHD) models
TPMS	WITH ⇄ WITHOUT	—
HBA SYSTEM	WITH ⇄ WITHOUT	<ul style="list-style-type: none"> WITH: With high beam assist system WITHOUT: Without high beam assist system
Key Fob Type	LCK/UNLCK	—
ALT TYPE	MODE1 ⇄ MODE4	<ul style="list-style-type: none"> MODE1: For MR engine or QR engine models MODE4: Except for MR engine or QR engine models
TRANSMISSION	MT with ABS ⇄ AT with ABS	<ul style="list-style-type: none"> MT with ABS: M/T models AT with ABS: Except M/T models

⇒: Items which confirm vehicle specifications

SHIPPING MODE CANCEL OPERATION

< BASIC INSPECTION >

SHIPPING MODE CANCEL OPERATION

Work Procedure

INFOID:0000000010688616

1. SHIPPING MODE CANCEL OPERATION

1. Turn ignition switch OFF.
2. Push in (switch on) the extended storage fuse switch. Refer to [PG-129, "How To Check"](#).
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 2 seconds.

>> GO TO 2.

2. SHIPPING MODE CANCEL CHECK

1. Turn ignition switch ON.
2. Check that extended storage fuse warning message is not displayed on information display.

>> WORK END

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM

DTC Description

INFOID:000000010688617

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. CAN Communication Signal Chart. Refer to [LAN-41, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
U1000-00	CAN COMM (CAN communication circuit)	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAG RESULT

With CONSULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Perform "Self Diagnostic Result" mode of "BCM" using CONSULT.

Is malfunctioning part detected?

YES >> Refer to [BCS-110, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010688618

1. CHECK CAN COMMUNICATION

Check CAN communication. Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

Is DTC "U1000-00" displayed?

YES >> Repair or replace the malfunctioning part.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Description

INFOID:0000000010688619

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
U1010-00	CONTROL UNIT (CAN) [Control unit (CAN)]	BCM detected internal CAN communication circuit malfunction.

POSSIBLE CAUSE

BCM

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAG RESULT

 With CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "BCM" using CONSULT.

Is malfunctioning part detected?

YES >> Refer to [BCS-111, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:0000000010688620

1. REPLACE BCM

When DTC "U1010-00" is detected, replace BCM.

>> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

U0415 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

U0415 VEHICLE SPEED

DTC Description

INFOID:0000000010688621

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
U0415-00	VEHICLE SPEED (Vehicle speed)	When the vehicle speed signal received from the ABS actuator and electric unit (control unit) remains abnormal for 2 seconds or more.

POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- BCM

FAIL-SAFE

Inhibit steering lock

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION

1. Erase the DTC.
2. Turn ignition switch OFF.
3. Perform the "Self Diagnostic Result" of BCM with CONSULT, when passed 2 seconds or more after the ignition switch is turned ON.

Is any DTC detected?

YES >> Refer to [BCS-112, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:0000000010688622

1.ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAG RESULTS

Perform "Self-Diagnostic Result" of ABS actuator and electric unit (control unit) with CONSULT. Refer to [BRC-84, "DTC Index"](#).

Is any DTC detected?

YES >> Repair or replace the malfunctioning part.

NO >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).

B2562 LOW VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

B2562 LOW VOLTAGE

DTC Description

INFOID:0000000010688623

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
B2562-00	LOW VOLTAGE (Low voltage)	When the power supply voltage to BCM remains less than 8.8 V for 120 seconds or more

POSSIBLE CAUSE

- Harness or connector (power supply circuit)
- BCM

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION

1. Erase DTC.
2. Turn ignition switch OFF.
3. Perform the "Self Diagnostic Result" of BCM with CONSULT, when passed 120 seconds or more after the ignition switch is turned ON.

Is any DTC detected?

YES >> Refer to [BCS-113, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:0000000010688624

1.CHECK POWER SUPPLY CIRCUIT

Check BCM power supply circuit. Refer to [BCS-114, "Diagnosis Procedure"](#).

Is the circuit normal?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).

NO >> Repair the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000010688625

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	14
	7

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

(+)	BCM	(-)	Voltage
Connector			
M86	95	Ground	9 – 16 V
M85	137		

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity		
Connector	Terminal		Existed		
M85					
146					
147					

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

COMBINATION SWITCH OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:0000000010688626

1. CHECK OUTPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.

NOTE:

BCM connector disconnects M86 and M87 only.

3. Check continuity between BCM harness connector and combination switch harness connector.

System	BCM		Combination switch		Continuity
	Connector	Terminal	Connector	Terminal	
OUTPUT 1	M86	85	M31	2	Existed
OUTPUT 2		84		10	
OUTPUT 3		86		15	
OUTPUT 4		87		4	
OUTPUT 5		74		7	

Does continuity exist?

YES >> GO TO 2.

NO >> Repair harnesses or connectors.

2. CHECK OUTPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM harness connector and ground.

System	BCM		Ground	Continuity
	Connector	Terminal		
OUTPUT 1	M86	85	Ground	Not existed
OUTPUT 2		84		
OUTPUT 3		86		
OUTPUT 4		87		
OUTPUT 5		74		

Does continuity exist?

YES >> Repair harnesses or connectors.

NO >> GO TO 3.

3. CHECK COMBINATION SWITCH INTERNAL CIRCUIT

1. Connect combination switch connector.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between BCM harness connector and ground.

NOTE:

Check that the combination switch outputs a signal from combination switch input system.

System	(+)		(-)	Voltage (Approx.)		
	Combination switch					
	Connector	Terminal				
OUTPUT 1	M31	2	Ground	Refer to BCS-53, "Reference Value" .		
OUTPUT 2		10				
OUTPUT 3		15				
OUTPUT 4		4				
OUTPUT 5		7				

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the measurement value normal?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).

NO >> Replace combination switch. Refer to [BCS-122, "Removal and Installation"](#).

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

COMBINATION SWITCH INPUT CIRCUIT

Diagnosis Procedure

INFOID:0000000010688627

1. CHECK INPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM harness connector and combination switch harness connector.

System	BCM		Combination switch		Continuity
	Connector	Terminal	Connector	Terminal	
INPUT 1	M87	78	M31	8	Existed
INPUT 2		79		6	
INPUT 3		76		5	
INPUT 4		77		3	
INPUT 5		73		1	

Does continuity exist?

YES >> GO TO 2.

NO >> Repair harnesses or connectors.

2. CHECK INPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM harness connector and ground.

System	BCM		Ground	Continuity
	Connector	Terminal		
INPUT 1	M87	78	Ground	Not existed
INPUT 2		79		
INPUT 3		76		
INPUT 4		77		
INPUT 5		73		

Does continuity exist?

YES >> Repair harnesses or connectors.

NO >> GO TO 3.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

BCS

System	(+)		(-)	Voltage (Approx.)		
	BCM					
	Connector	Terminal				
INPUT 1	M87	78	Ground	Refer to BCS-53, "Reference Value".		
INPUT 2		79				
INPUT 3		76				
INPUT 4		77				
INPUT 5		73				

Is the measurement value normal?

Yes >> GO TO 4.

No >> Replace BCM. Refer to [BCS-121, "Removal and Installation".](#)

4. CHECK BCM INPUT SIGNAL

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. Connect combination switch connector.
2. Turn ON any switch in the system that is malfunction.
3. Check voltage between BCM harness connector and ground.

System	(+)		(-)	Voltage (Approx.)		
	BCM					
	Connector	Terminal				
INPUT 1	M87	78	Ground	Refer to BCS-53, "Reference Value".		
INPUT 2		79				
INPUT 3		76				
INPUT 4		77				
INPUT 5		73				

Is the measurement value normal?

Yes >> Replace BCM. Refer to [BCS-121, "Removal and Installation".](#)

No >> Replace combination switch. Refer to [BCS-122, "Removal and Installation".](#)

COMBINATION SWITCH SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

COMBINATION SWITCH SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000010688628

1. Perform "Data Monitor" of CONSULT to check for any malfunctioning item.
2. Check the malfunction combinations.

Malfunction item: x

Data monitor item															Malfunction combination			
FR WIPER HI	FR WIPER LOW	FR WASHER SW	FR WIPER INT	WIP VOLUME	RR WIPER ON	RR WIPER INT	RR WASHER SW	TURN SIGNAL R	TURN SIGNAL L	TAIL LAMP SW	HI BEAM SW	HEAD LAMP SW	LIGHT OFF SW	PASSING SW	AUTO LIGHT SW	FR FOG SW	RR FOG SW	
x	x			x														A
x				x			x				x							B
		x			x						x		x					C
			x			x		x						x	x			D
				x					x				x		x	x		E
					x					x		x		x	x	x		F
			x							x		x		x				G
		x					x	x	x									H
x	x	x											x					I
			x	x	x													J
All Items															K			
If only one item is detected or the item is not applicable to the combinations A to K															L			
All Items are normal															M			

3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

Malfunction combination	Malfunctioning part	Repair or replace
A	Combination switch OUTPUT 1 circuit	Inspect the combination switch output circuit applicable to the malfunctioning part. Refer to BCS-117, "Diagnosis Procedure" .
B	Combination switch OUTPUT 2 circuit	
C	Combination switch OUTPUT 3 circuit	
D	Combination switch OUTPUT 4 circuit	
E	Combination switch OUTPUT 5 circuit	
F	Combination switch INPUT 1 circuit	Inspect the combination switch input circuit applicable to the malfunctioning part. Refer to BCS-115, "Diagnosis Procedure" .
G	Combination switch INPUT 2 circuit	
H	Combination switch INPUT 3 circuit	
I	Combination switch INPUT 4 circuit	
J	Combination switch INPUT 5 circuit	
K	BCM	Replace BCM. Refer to BCS-121, "Removal and Installation" .
L	Combination switch	Replace combination switch. Refer to BCS-122, "Removal and Installation" .
M	Connector and harness	Check intermittent incident. Refer to GI-44, "Intermittent Incident" .

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:0000000010688629

SHIPPING MODE

- Shipping mode inhibits battery power consumption during transportation or storage of the vehicle. Vehicle is set to shipping mode before being shipped from the factory.
- When ignition switch is OFF, BCM operates shipping mode.
- BCM control function is limited in shipping mode. Remote keyless entry function is not operated during the shipping mode.
- For shipping mode cancel operation, refer to [BCS-109. "Work Procedure"](#).

NOTE:

Do not cancel shipping mode during storage of the vehicle. Always cancel shipping mode before delivery of the vehicle to customer.

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

BCM

Removal and Installation


INFOID:000000010688630

NOTE:

Before replacing BCM, perform “Before Replace ECU” of “Read / Write Configuration” to save or print current vehicle specification. Refer to [BCS-106, “Description”](#).

REMOVAL (RHD MODELS)


1. Disconnect the battery cable from the negative terminal. Refer to [BCS-3, “Precautions for Removing Battery Terminal”](#).
2. Remove the glove box assembly and glove box housing, Refer to [IP-41, “Removal and Installation”](#).
3. Disconnect the harness connectors from the BCM ①.
4. Remove the BCM mounting nuts ②.



5. Remove the BCM.

REMOVAL (LHD MODELS)

1. Disconnect the battery cable from the negative terminal. Refer to [BCS-3, “Precautions for Removing Battery Terminal”](#).
2. Remove the instrument lower panel LH. Refer to [IP-14, “Removal and Installation”](#).
3. Remove the BCM mounting nut ②, then pull out the BCM ①.



4. Disconnect the harness connectors from the BCM and remove.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to perform “After Replace ECU” of “Read / Write Configuration” or “Manual Configuration” when replacing BCM. Refer to [BCS-104, “Work Procedure”](#).

NOTE:

- Be sure to perform the system initialization (NATS) when replacing BCM.
- Be sure to perform the system initialization (CAN gateway) when replacing BCM.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

COMBINATION SWITCH

< REMOVAL AND INSTALLATION >


COMBINATION SWITCH

Removal and Installation

INFOID:0000000010688631

REMOVAL

1. Remove steering column cover. Refer to [IP-41, "Removal and Installation"](#) (RHD models) or [IP-14, "Removal and Installation"](#) (LHD models).
2. Remove screws Ⓐ and disconnect connector ② then pull up combination switch ① to remove it.



INSTALLATION

Install in the reverse order of removal.