

SECTION **BR**

BRAKE SYSTEM

A
B
C
D
E

BR

CONTENTS

LHD

| | | | |
|--|----|--|----|
| PRECAUTION | 5 | Bleeding Brake System | 14 |
| PRECAUTIONS | 5 | BRAKE MASTER CYLINDER | 15 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 5 | Inspection | 15 |
| Precaution Necessary for Steering Wheel Rotation After Battery Disconnect | 5 | BRAKE BOOSTER | 16 |
| Precaution for Procedure without Cowl Top Cover | 6 | Inspection | 16 |
| Precautions for Removing Battery Terminal | 6 | FRONT DISC BRAKE | 17 |
| Precaution for Brake System | 7 | BRAKE PAD | 17 |
| PREPARATION | 8 | BRAKE PAD : Inspection and Adjustment | 17 |
| PREPARATION | 8 | DISC ROTOR | 17 |
| Commercial Service Tool | 8 | DISC ROTOR : Inspection and Adjustment | 17 |
| Lubricant or/and Sealant | 8 | REAR DISC BRAKE | 19 |
| SYSTEM DESCRIPTION | 9 | BRAKE PAD | 19 |
| SYSTEM | 9 | BRAKE PAD : Inspection and Adjustment | 19 |
| WARNING/INDICATOR/CHIME LIST | 9 | DISC ROTOR | 19 |
| WARNING/INDICATOR/CHIME LIST : Warning Lamp/Indicator Lamp | 9 | DISC ROTOR : Inspection and Adjustment | 19 |
| SYMPTOM DIAGNOSIS | 10 | REMOVAL AND INSTALLATION | 21 |
| NOISE, VIBRATION AND HARSHNESS | | BRAKE PEDAL | 21 |
| (NVH) TROUBLESHOOTING | 10 | Exploded View | 21 |
| NVH Troubleshooting Chart | 10 | Removal and Installation | 21 |
| PERIODIC MAINTENANCE | 11 | Inspection and Adjustment | 22 |
| BRAKE PEDAL | 11 | BRAKE PIPING | 24 |
| Inspection and Adjustment | 11 | FRONT | 24 |
| BRAKE FLUID | 13 | FRONT : Exploded View | 24 |
| Inspection | 13 | FRONT : Hydraulic Piping | 25 |
| Draining | 13 | FRONT : Removal and Installation | 25 |
| Refilling | 13 | FRONT : Inspection | 27 |
| | | REAR | 27 |
| | | REAR : Exploded View | 27 |
| | | REAR : Hydraulic Piping | 29 |
| | | REAR : Removal and Installation | 29 |
| | | REAR : Inspection | 31 |

| | | | |
|---|-----------|--|-----------|
| BRAKE MASTER CYLINDER | 32 | REAR DISC BRAKE | 60 |
| Exploded View | 32 | BRAKE PAD | 60 |
| Removal and Installation | 32 | BRAKE PAD : Exploded View | 60 |
| Disassembly and Assembly | 34 | BRAKE PAD : Removal and Installation | 60 |
| Inspection | 35 | BRAKE PAD : Inspection and Adjustment | 62 |
| BRAKE BOOSTER | 36 | BRAKE CALIPER ASSEMBLY | 62 |
| Exploded View | 36 | BRAKE CALIPER ASSEMBLY : Exploded View ... | 62 |
| Removal and installation | 36 | BRAKE CALIPER ASSEMBLY : Removal and In- | |
| Inspection and Adjustment | 38 | stallation | 63 |
| VACUUM LINES | 40 | BRAKE CALIPER ASSEMBLY : Disassembly and | |
| MR20DD | 40 | Assembly | 65 |
| MR20DD : Exploded View | 40 | BRAKE CALIPER ASSEMBLY : Inspection and | |
| MR20DD : Removal and Installation | 40 | Adjustment | 66 |
| MR20DD : Inspection | 40 | | |
| QR25DE | 40 | SERVICE DATA AND SPECIFICATIONS | |
| QR25DE : Exploded View | 41 | (SDS) | 67 |
| QR25DE : Removal and Installation | 41 | SERVICE DATA AND SPECIFICATIONS | |
| QR25DE : Inspection | 41 | (SDS) | 67 |
| R9M | 41 | General Specifications | 67 |
| R9M : Exploded View | 42 | Brake Pedal | 67 |
| R9M : Removal and Installation | 42 | Brake Booster | 67 |
| R9M : Inspection | 42 | Front Disc Brake | 67 |
| FRONT DISC BRAKE | 43 | Rear Disc Brake | 67 |
| BRAKE PAD (1 PISTON TYPE) | 43 | RHD | |
| BRAKE PAD (1 PISTON TYPE) : Exploded View... | 43 | PRECAUTION | 69 |
| BRAKE PAD (1 PISTON TYPE) : Removal and In- | | PRECAUTIONS | 69 |
| stallation | 43 | Precaution for Supplemental Restraint System | |
| BRAKE PAD (1 PISTON TYPE) : Inspection | 46 | (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- | |
| BRAKE PAD (2 PISTON TYPE) | 46 | SIONER" | 69 |
| BRAKE PAD (2 PISTON TYPE) : Exploded View... | 46 | Precaution Necessary for Steering Wheel Ro- | |
| BRAKE PAD (2 PISTON TYPE) : Removal and In- | | tion After Battery Disconnect | 69 |
| stallation | 47 | Precaution for Procedure without Cowl Top Cover... | 70 |
| BRAKE PAD (2 PISTON TYPE) : Inspection | 49 | Precautions for Removing Battery Terminal | 70 |
| BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) | 50 | Precaution for Brake System | 71 |
| BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | | PREPARATION | 72 |
| Exploded View | 50 | PREPARATION | 72 |
| BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | | Commercial Service Tool | 72 |
| Removal and Installation | 51 | Lubricant or/and Sealant | 72 |
| BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | | SYSTEM DESCRIPTION | 73 |
| Disassembly and Assembly | 52 | SYSTEM | 73 |
| BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | | WARNING/INDICATOR/CHIME LIST | 73 |
| Inspection | 54 | WARNING/INDICATOR/CHIME LIST : Warning | |
| BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) | 54 | Lamp/Indicator Lamp | 73 |
| BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | | SYMPTOM DIAGNOSIS | 74 |
| Exploded View | 55 | NOISE, VIBRATION AND HARSHNESS | |
| BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | | (NVH) TROUBLESHOOTING | 74 |
| Removal and Installation | 56 | NVH Troubleshooting Chart | 74 |
| BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | | PERIODIC MAINTENANCE | 75 |
| Disassembly and Assembly | 57 | | |
| BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | | | |
| Inspection | 59 | | |

| | | | |
|--|-----|---|-----|
| BRAKE PEDAL | 75 | VACUUM LINES | 102 |
| Inspection and Adjustment | 75 | Exploded View | 102 |
| BRAKE FLUID | 77 | Removal and Installation | 102 |
| Inspection | 77 | Inspection | 102 |
| Draining | 77 | | |
| Refilling | 77 | | |
| Bleeding Brake System | 78 | | |
| BRAKE MASTER CYLINDER | 79 | FRONT DISC BRAKE | 103 |
| Inspection | 79 | | |
| BRAKE BOOSTER | 80 | BRAKE PAD (1 PISTON TYPE) | 103 |
| Inspection | 80 | BRAKE PAD (1 PISTON TYPE) : Exploded View .. | 103 |
| FRONT DISC BRAKE | 81 | BRAKE PAD (1 PISTON TYPE) : Removal and In- | |
| BRAKE PAD | 81 | stallation | 103 |
| BRAKE PAD : Inspection and Adjustment | 81 | BRAKE PAD (1 PISTON TYPE) : Inspection | 106 |
| DISC ROTOR | 81 | | |
| DISC ROTOR : Inspection and Adjustment | 81 | BRAKE PAD (2 PISTON TYPE) | 106 |
| REAR DISC BRAKE | 83 | BRAKE PAD (2 PISTON TYPE) : Exploded View .. | 106 |
| BRAKE PAD | 83 | BRAKE PAD (2 PISTON TYPE) : Removal and In- | |
| BRAKE PAD : Inspection and Adjustment | 83 | stallation | 107 |
| DISC ROTOR | 83 | BRAKE PAD (2 PISTON TYPE) : Inspection | 109 |
| DISC ROTOR : Inspection and Adjustment | 83 | | |
| REMOVAL AND INSTALLATION | 85 | BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) | 110 |
| BRAKE PEDAL | 85 | BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | |
| Exploded View | 85 | Exploded View | 110 |
| Removal and Installation | 85 | BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | |
| Inspection and Adjustment | 86 | Removal and Installation | 111 |
| BRAKE PIPING | 88 | BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | |
| FRONT | 88 | Disassembly and Assembly | 112 |
| FRONT : Exploded View | 88 | BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : | |
| FRONT : Hydraulic Piping | 89 | Inspection | 114 |
| FRONT : Removal and Installation | 89 | | |
| FRONT : Inspection | 91 | BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) | 114 |
| REAR | 91 | BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | |
| REAR : Exploded View | 91 | Exploded View | 115 |
| REAR : Hydraulic Piping | 92 | BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | |
| REAR : Removal and Installation | 92 | Removal and Installation | 116 |
| REAR : Inspection | 94 | BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | |
| BRAKE MASTER CYLINDER | 95 | Disassembly and Assembly | 117 |
| Exploded View | 95 | BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : | |
| Removal and Installation | 95 | Inspection | 119 |
| Disassembly and Assembly | 97 | | |
| Inspection | 98 | REAR DISC BRAKE | 120 |
| BRAKE BOOSTER | 99 | | |
| Exploded View | 99 | BRAKE PAD | 120 |
| Removal and installation | 99 | BRAKE PAD : Exploded View | 120 |
| Inspection and Adjustment | 100 | BRAKE PAD : Removal and Installation | 120 |
| | | BRAKE PAD : Inspection and Adjustment | 122 |
| SERVICE DATA AND SPECIFICATIONS (SDS) | 127 | | |
| SERVICE DATA AND SPECIFICATIONS (SDS) | 127 | | |
| General Specifications | 127 | | |

| | | | |
|---------------------|-----|------------------------|-----|
| Brake Pedal | 127 | Front Disc Brake | 127 |
| Brake Booster | 127 | Rear Disc Brake | 128 |

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011022305

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000011022306

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition power source and accessory power source to the OFF, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Open driver door.
3. Turn the ignition switch to the ON position.
(At this time, the steering lock will be released.)
4. Turn the ignition switch to OFF position with driver door open.
5. Wait for 3 minutes or longer with driver door open.

NOTE:

- Do not close driver door because the steering wheel locks when driver door is closed.

PRECAUTIONS

[LHD]

< PRECAUTION >


- The auto acc function is adapted to this vehicle. For this reason, even when the ignition switch is turned to OFF position, the accessory power source does not turn OFF and continues to be supplied for a certain amount of time.

6. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
7. Perform the necessary repair operation.
8. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from OFF position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
9. Perform self-diagnosis check of all control units using CONSULT.

Precaution for Procedure without Cowl Top Cover

INFOID:0000000011022307

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precautions for Removing Battery Terminal

INFOID:0000000011062349

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.
2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine : 20 minutes
HRA2DDT : 12 minutes

< PRECAUTION >

- K9K engine : 4 minutes
- M9R engine : 4 minutes
- R9M engine : 4 minutes
- V9X engine : 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.


Precaution for Brake System

INFOID:0000000010838491

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

- Brake fluid use refer to [MA-6, "General Maintenance"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Always confirm the specified tightening torque when installing the brake pipes.
- After pressing the brake pedal more deeply or harder than normal driving, such as air bleeding, check each item of brake pedal.
- Always clean with new brake fluid when cleaning the master cylinder, brake caliper and other components.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a flare nut torque wrench (A).
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.
- Burnish the brake contact surfaces after refinishing or replacing rotors, after replacing pads, or if a soft pedal occurs at very low mileage.
- Front brake pad: Refer to [BR-17, "BRAKE PAD : Inspection and Adjustment"](#).
- Front disc rotor: Refer to [BR-17, "DISC ROTOR : Inspection and Adjustment"](#).
- Rear brake pad: Refer to [BR-19, "BRAKE PAD : Inspection and Adjustment"](#).
- Rear disc rotor: Refer to [BR-19, "DISC ROTOR : Inspection and Adjustment"](#).



JPFI0061ZZ

PREPARATION

[LHD]



<PREPARATION>

PREPARATION

PREPARATION

Commercial Service Tool

INFOID:0000000010838492

| Tool name | Description |
|----------------------|---|
| Handy vacuum pump |  ZZC1313D <ul style="list-style-type: none">• Air tight• Inspection of check valve |
| Brake caliper wrench |  NNFIA0040ZZ <ul style="list-style-type: none">Return the piston |
| Pick tool |  JMJIA0490ZZ <ul style="list-style-type: none">Removing piston seal and piston boot |

Lubricant or/and Sealant

INFOID:0000000010838493

| Name | Description | Note |
|---|-------------------------------|---|
| Multi-purpose grease | Clevis pin of brake pedal | — |
| Polyglycol ether based lubricant | • Master cylinder assembly | — |
| MOLYKOTE® AS880N or silicone-based grease | • Front brake | Molykote is a registered of Dow Corning Corporation |
| MOLYKOTE® 7439 or equivalent | • Front brake • Rear brake | Molykote is a registered of Dow Corning Corporation |
| Rubber grease | • Front brake • Rear brake | — |

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

SYSTEM

WARNING/INDICATOR/CHIME LIST

WARNING/INDICATOR/CHIME LIST : Warning Lamp/Indicator Lamp

INFOID:0000000010838494

| Name | Design | Layout/Function |
|--------------------|---|--|
| Brake warning lamp |  | <p>For layout: Refer to MWI-10, "METER SYSTEM : Design".</p> <p>For function: Refer to MWI-26, "WARNING LAMPS/INDICATOR LAMPS : Brake Warning Lamp (Red)".</p> |

A

B

C

D

E

BR

G

H

I

J

K

L

M

N

O

P

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000010838495

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

| Reference page | | | Pads damaged | BR-17, BR-19 | Pads uneven wear | BR-17, BR-19 | Shims damaged | BR-46, BR-49, BR-62 | Rotor imbalance | BR-17, BR-19 | Rotor damage | BR-17, BR-19 | Rotor runout | BR-17, BR-19 | Rotor deformation | BR-17, BR-19 | Rotor deflection | BR-17, BR-19 | Rotor rust | BR-17, BR-19 | Rotor thickness variation | BR-17, BR-19 | AXLE AND SUSPENSION | NVH in FAX, RAX and FSU, RSU section | TIRE | NVH in WT section | ROAD WHEEL | NVH in WT section | DRIVE SHAFT | NVH in FAX section | STEERING | NVH in ST section |
|------------------------------------|--|--|----------------|--------------|------------------|--------------|---------------|---------------------|-----------------|--------------|--------------|--------------|--------------|--------------|-------------------|--------------|------------------|--------------|------------|--------------|---------------------------|--------------|---------------------|--------------------------------------|------|-------------------|------------|-------------------|-------------|--------------------|----------|-------------------|
| Possible cause and SUSPECTED PARTS | | | × | | × | | × | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | Noise | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | Shake | | × | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | Shimmy, Judder | | | × | | × | | × | | × | | × | | × | | × | | × | | × | | | | | | | | | | |

x: Applicable

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

BRAKE PEDAL

Inspection and Adjustment

INFOID:0000000010838496

INSPECTION


Brake Pedal Height

Check the height (H_1) between the dash lower panel ① and the brake pedal upper surface.

H₁ : Refer to [BR-67, "Brake Pedal"](#).

CAUTION:

Remove the floor carpet.

A
B
C
D
E
BR

Stop Lamp Switch and Brake Pedal Position Switch (with ASCD).

Check the clearance (C) among the brake pedal bracket ① and the stop lamp switch and brake pedal position switch (with ASCD) ② threaded end.


C : Refer to [BR-67, "Brake Pedal"](#).

CAUTION:

The stop lamp must turn off when the brake pedal is released.

NOTE:


Pull the brake pedal pad to make the clearance between the stop lamp switch and brake pedal position switch (with ASCD) threaded end and the brake pedal lever.

G
H
I
J

Brake Pedal Play

Press the brake pedal. Check the brake pedal play (A) (stroke until fluid pressure occurs).

A : Refer to [BR-67, "Brake Pedal"](#).

K
L
M
N


Depressed Brake Pedal Height

Check the height between the dash lower panel ① and the brake pedal upper surface (H_2) when depressing the brake pedal at 490 N (50 kg, 110 lb) while turning engine ON.

H₂ : Refer to [BR-67, "Brake Pedal"](#).

CAUTION:

Remove the floor carpet.

O
P

ADJUSTMENT

BRAKE PEDAL

[LHD]

< PERIODIC MAINTENANCE >

Brake Pedal Height

Perform the following procedure when brake pedal height is not within the specified value because brake pedal height is not adjustable.

1. Check input rod length. Refer to [BR-38, "Inspection and Adjustment"](#).
2. Replace brake pedal assembly when input rod length is within specified value.

Stop Lamp Switch and Brake Pedal Position Switch (with ASCD).


1. Remove instrument lower panel. Refer to [IP-14, "Removal and Installation"](#).
2. Disconnect the harness connector from stop lamp switch and brake pedal position switch (with ASCD).
3. Loosen the stop lamp switch and brake pedal position switch (with ASCD) 45° counterclockwise.
4. Press-fit the stop lamp switch and brake position switch (with ASCD) ② until the stop lamp switch and brake pedal position switch (with ASCD) hits the brake pedal bracket ① 45° clockwise while pulling the brake pedal pad slightly.

CAUTION:

- The clearance (C) between the brake pedal bracket and stop lamp switch and brake pedal position switch (with ASCD) threaded end must be the specified value.

C : Refer to [BR-67, "Brake Pedal"](#).

- The stop lamp must be turned off when the brake pedal is released.




Depressed Brake Pedal Height

1. Perform the air bleeding. Refer to [BR-14, "Bleeding Brake System"](#).
2. Check the height between the dash lower panel ① and the brake pedal upper surface (H₂) when depressing the brake pedal at 490 N (50 kg, 110 lb) while turning engine ON.

H₂ : Refer to [BR-67, "Brake Pedal"](#).

CAUTION:

Remove the floor carpet.



< PERIODIC MAINTENANCE >


BRAKE FLUID

Inspection

INFOID:0000000010838497

BRAKE FLUID LEVEL

- Check that the brake fluid level in the reservoir tank is within the standard (between MAX – MIN lines).
- Visually check for any brake fluid leakage around the reservoir tank.
- Check the brake system for any leakage if the fluid level is extremely low (lower than MIN).
- Check the brake system for fluid leakage if the warning lamp remains illuminated even after the parking brake is released.
- Check the reservoir tank for the mixing of foreign matter (e.g. dust) and oils other than brake fluid.




BRAKE LINE

- Check brake line (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.
- Depress the brake pedal with a force of 785 N (80 kg, 176 lb) and hold down the pedal for approximately 5 seconds with the engine running. Check for any fluid leakage.

CAUTION:

Retighten the applicable connection to the specified torque and repair any abnormal (damaged, worn or deformed) part if any brake fluid leakage is present.




Draining

INFOID:0000000010838498

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing work.

- Connect a vinyl tube to the bleed valve.
- Depress the brake pedal and loosen the bleeder valve to gradually discharge brake fluid.



Refilling

INFOID:0000000010838499

CAUTION:

- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing work.

< PERIODIC MAINTENANCE >

- **Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.**


1. Check that there is no foreign material in the reservoir tank, and refill with new brake fluid.

CAUTION:

- **Never reuse drained brake fluid.**
- **Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.**

2. Loosen the bleeder valve, slowly depress the brake pedal to the full stroke, and then release the pedal. Repeat this operation at intervals of 2 or 3 seconds until new brake fluid is discharged. Then close the bleeder valve with the brake pedal depressed. Repeat the same work on each wheel.

3. Perform the air bleeding. Refer to [BR-14, "Bleeding Brake System".](#)



PFIA0403J

Bleeding Brake System

INFOID:000000010838500

CAUTION:

- **Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.**
- **Monitor the fluid level in the reservoir tank while performing the air bleeding**
- **Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.**
- **Never allow foreign matter (e.g. dust) and oil other than brake fluid to enter the reservoir tank.**

1. Connect a vinyl tube to the bleeder valve of the rear right brake.
2. Fully depress the brake pedal 4 to 5 times.
3. Loosen the bleeder valve and bleed air with the brake pedal depressed, and then quickly tighten the bleeder valve.
4. Repeat steps 3 and 4 until all of the air is out of the brake line.
5. Tighten the bleeder valve to the specified torque.
 - Front disc brake
 - 1 piston type: Refer to [BR-50, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Exploded View".](#)
 - 2 piston type: Refer to [BR-55, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Exploded View".](#)
 - Rear disc brake: Refer to [BR-62, "BRAKE CALIPER ASSEMBLY : Exploded View".](#)
6. Perform steps 2 to 6. Occasionally fill with the brake fluid in order to keep it in the reservoir tank at least half of MAX line. Bleed air in the following order: rear right brake → front left brake → rear left brake → and front right brake in order.
7. Check that the fluid level in the reservoir tank is within the specified range after air bleeding. Refer to [BR-13, "Inspection".](#)
8. Check each item of brake pedal. Adjust it if the measurement value is not the standard. Refer to [BR-11, "Inspection and Adjustment".](#)

< PERIODIC MAINTENANCE >

BRAKE MASTER CYLINDER

Inspection

INFOID:0000000010838501

FLUID LEAK

Check for brake fluid leakage from the master cylinder mounting face, reservoir tank mounting face and brake tube connections.

A

B

C

D

E

BR

G

H

I

J

K

L

M

N

O

P

< PERIODIC MAINTENANCE >

BRAKE BOOSTER**Inspection**

INFOID:0000000010838502

OPERATION

Depress the brake pedal several times at 5-second intervals with the engine stopped. Start the engine with the brake pedal fully depressed. Check that the clearance between brake pedal and dash lower panel decreases.

AIR TIGHT

1. Run the engine at idle for 1 minute to apply vacuum to the brake booster, and stop the engine.
2. Depress the brake pedal several times at 5-second intervals until the accumulated vacuum is released to atmospheric pressure. Check that the clearance between brake pedal and dash lower panel gradually increases each time the brake pedal is depressed when performing this operation.
3. Depress the brake pedal with the engine running. Then stop the engine while holding down the brake pedal. Check that the brake pedal stroke does not change after holding down the brake pedal for 30 seconds or more.

< PERIODIC MAINTENANCE >


FRONT DISC BRAKE**BRAKE PAD****BRAKE PAD : Inspection and Adjustment**

INFOID:0000000010838503

INSPECTION

Check brake pad wear thickness from an inspection hole on cylinder body. Check using a scale if necessary.

Wear thickness : Refer to [BR-67, "Front Disc Brake"](#).

**ADJUSTMENT**

Burnish contact surfaces between disc rotor and brake pads according to the following procedure after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pads and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.

DISC ROTOR**DISC ROTOR : Inspection and Adjustment**

INFOID:0000000010838504

INSPECTION**Appearance**

Check surface of disc rotor for uneven wear, cracks, and serious damage. Replace it if necessary.


- For 2WD, refer to [FAX-11, "Removal and Installation"](#).
- For 4WD, refer to [FAX-72, "Removal and Installation"](#).

Runout

1. Fix the disc rotor to the wheel hub and bearing assembly with wheel nuts (2 points at least).
2. Check the wheel bearing axial end play.
 - For 2WD, refer to [FAX-16, "Inspection"](#).
 - For 4WD, refer to [FAX-77, "Inspection"](#).
3. Inspect the runout with a dial indicator to measure at 10 mm (0.39 in) inside the disc edge.

Runout (with it attached to the vehicle) : Refer to [BR-67, "Front Disc Brake"](#).

4. Find the installation position that has a minimum runout by shifting the disc rotor-to-wheel hub and bearing assembly installation position by one hole at a time if the runout exceeds the limit value.
5. Refinish the disc rotor if the runout is outside the limit even after performing the above operation.

CAUTION:

FRONT DISC BRAKE

[LHD]

< PERIODIC MAINTENANCE >

- Check in advance that the thickness of the disc rotor is wear thickness + 0.3 mm (0.012 in) or more.
- If the thickness is less than wear thickness + 0.3 mm (0.012 in), replace the disc rotor.
- For 2WD, refer to [FAX-11, "Removal and Installation"](#).
- For 4WD, refer to [FAX-72, "Removal and Installation"](#).


Wear thickness : Refer to [BR-67, "Front Disc Brake"](#).

Thickness

Check the thickness of the disc rotor using a micrometer. Replace the disc rotor if the thickness is below the wear limit.

- For 2WD, refer to [FAX-11, "Removal and Installation"](#).
- For 4WD, refer to [FAX-72, "Removal and Installation"](#).

Wear thickness : Refer to [BR-67, "Front Disc Brake"](#).



ADJUSTMENT

Burnish contact surfaces between disc rotors and brake pads according to the following procedure after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pad and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.

< PERIODIC MAINTENANCE >


REAR DISC BRAKE**BRAKE PAD****BRAKE PAD : Inspection and Adjustment**

INFOID:0000000010838505

INSPECTION

Check brake pad wear thickness from an inspection hole on cylinder body. Check using a scale if necessary.

Wear thickness : Refer to [BR-67, "Rear Disc Brake"](#).

**ADJUSTMENT**

Burnish contact surfaces between disc rotor and brake pads according to the following procedure after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pads and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.

DISC ROTOR**DISC ROTOR : Inspection and Adjustment**

INFOID:0000000010838506

INSPECTION**Appearance**

Check surface of disc rotor for uneven wear, cracks, and serious damage. Replace it if necessary.


- For 2WD, refer to [RAX-7, "Removal and Installation"](#).
- For 4WD, refer to [RAX-18, "Removal and Installation"](#).

Runout

1. Fix the disc rotor to the wheel hub and bearing assembly with wheel nuts (2 points at least).
2. Check the wheel bearing axial end play.
 - For 2WD, refer to [RAX-9, "Inspection"](#).
 - For 4WD, refer to [RAX-21, "Inspection"](#).
3. Inspect the runout with a dial indicator to measure at 10 mm (0.39 in) inside the disc edge.

Runout (with it attached to the vehicle) : Refer to [BR-67, "Rear Disc Brake"](#).

4. Find the installation position that has a minimum runout by shifting the disc rotor-to-wheel hub and bearing assembly installation position by one hole at a time if the runout exceeds the limit value.
5. Refinish the disc rotor if the runout is outside the limit even after performing the above operation.

CAUTION:

REAR DISC BRAKE

[LHD]

< PERIODIC MAINTENANCE >

- Check in advance that the thickness of the disc rotor is wear thickness + 0.3 mm (0.012 in) or more.
- If the thickness is less than wear thickness + 0.3 mm (0.012 in), replace the disc rotor.
- For 2WD, refer to [RAX-7, "Removal and Installation"](#).
- For 4WD, refer to [RAX-18, "Removal and Installation"](#).


Wear thickness : Refer to [BR-67, "Rear Disc Brake"](#).

Thickness

Check the thickness of the disc rotor using a micrometer. Replace the disc rotor if the thickness is below the wear limit. .

- For 2WD, refer to [RAX-7, "Removal and Installation"](#).
- For 4WD, refer to [RAX-18, "Removal and Installation"](#).

Wear thickness : Refer to [BR-67, "Rear Disc Brake"](#).



ADJUSTMENT

Burnish contact surfaces between disc rotors and brake pads according to the following procedure after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pad and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

BRAKE PEDAL

Exploded View

INFOID:0000000010838507

SEC. 251-465



JSFIA2684GB

① Clevis pin

② Brake pedal assembly

③ Brake pedal pad

④ Snap pin

⑤ Clip

⑥ Stop lamp switch

⑦ Brake pedal position switch (with ASCD)

: Apply multi-purpose grease.

: N·m (kg·m, ft-lb)


: Always replace after every disassembly.

Removal and Installation

INFOID:0000000010838508

REMOVAL


1. Remove instrument lower panel. Refer to [IP-14, "Removal and Installation"](#).
2. Disconnect the stop lamp switch and the brake pedal position switch (with ASCD) harness connectors.
3. Rotate the stop lamp switch and the brake pedal switch (with ASCD) ① counterclockwise to remove.



JPFI0815ZZ

< REMOVAL AND INSTALLATION >

4. Disconnect the accelerator pedal harness connector.
5. Remove snap pin ① and clevis pin ② from clevis of brake booster ③.



6. Remove the brake pedal assembly.

CAUTION:

Hold the brake booster and master cylinder assembly so as not to drop out or contact them other parts.

7. Remove the accelerator pedal from the brake pedal assembly. Refer to [ACC-4, "Removal and Installation".](#)
8. Perform inspection after removal. Refer to [BR-22, "Inspection and Adjustment".](#)

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never reuse the clevis pin and snap pin.
- Apply the multi-purpose grease to the clevis pin and the mating faces. (Not necessary if grease has been already applied)

NOTE:

The clevis pin may be inserted in either direction.

- Never impact brake pedal such as drop and interference with tools and parts.
- Replace brake pedal when impacting brake pedal.
- Perform adjustment after installation. Refer to [BR-22, "Inspection and Adjustment".](#)

Inspection and Adjustment

INFOID:0000000010838509


INSPECTION AFTER REMOVAL

Check for the following items and replace the brake pedal assembly if necessary.

- Check rivet ① for deformation, crack, and damage.
- Check the brake pedal for bend, damage, and cracks on the welded parts.

CAUTION:

Never loose bolt ①.




BRAKE PEDAL

[LHD]

< REMOVAL AND INSTALLATION >

- Check clevis pin and plastic stopper **A** for damage and deformation. Replace clevis pin if necessary.



ADJUSTMENT AFTER INSTALLATION

- Adjust each item of brake pedal after installing the brake pedal assembly to the vehicle. Refer to [BR-11, "Inspection and Adjustment"](#).
- Perform the release position learning of the accelerator pedal.
- MR20DD: Refer to [EC-144, "Work Procedure"](#).
- QR25DE: Refer to [EC-553, "Work Procedure"](#).
- R9M: Refer to [EC-961, "Work Procedure"](#).

A
B
C
D

E
BR

G
H
I
J

K
L
M
N

O
P


< REMOVAL AND INSTALLATION >

BRAKE PIPING

FRONT

FRONT : Exploded View

INFOID:0000000010838510



① Brake tube

② ABS actuator and electric unit (control unit)

③ Connector bracket

④ Connector

⑤ Brake booster

⑥ Master cylinder assembly

⑦ Brake tube bracket

⑧ Lock plate

⑨ Brake hose

⑩ Union bolt

⑪ Copper washer

Ⓐ To rear brake tube

◆: Indicates that the part is connected at points with same symbol in actual vehicle.

Ⓐ: N·m (kg·m, ft·lb)


Ⓑ: N·m (kg·m, in·lb)

ⓧ: Always replace after every disassembly.

< REMOVAL AND INSTALLATION >

FRONT : Hydraulic Piping

INFOID:000000010838511



| | | |
|---|--------------------|----------------------------|
| ① ABS actuator and electric unit (control unit) | ② Front disc brake | ③ Master cylinder assembly |
| ④ Brake booster | ⑤ Connector | ⑥ Rear disc brake |
| Ⓐ Brake tube | Ⓑ Brake hose | |

○: Flare nut
■: Union bolt

FRONT : Removal and Installation

INFOID:000000010838512

REMOVAL

CAUTION:


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.

1. Remove tires. Refer to [WT-61, "Removal and Installation"](#).2. Drain brake fluid. Refer to [BR-13, "Draining"](#).

3. Loosen the flare nut ① with a flare nut wrench (A) and separate the brake tube ② from the brake hose ③.

CAUTION:

- Never scratch the flare nut and the brake tube.
- Never bend sharply, twist or strongly pull out the brake hoses and tubes.
- Cover open end of brake tubes and hoses when disconnecting to prevent entrance of dirt.




BRAKE PIPING

[LHD]

< REMOVAL AND INSTALLATION >

- Remove the union bolt ① and copper washers ②, and remove the brake hose ③ from the brake caliper assembly.
- Remove the lock plate ④ and remove the brake hose.



INSTALLATION

CAUTION:


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.
- Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.

- Assemble the union bolt ① and the copper washer ② to the brake hose.

CAUTION:

Never reuse the copper washer.


- Align the brake hose pin ④ with the brake caliper assembly projection ⑤, and tighten the union bolt to the specified torque.



- Install the brake tube ② to the brake hose ①, temporarily tighten the flare nut ③ by hand until it does not rotate further, and fix the brake hose to the bracket ⑤ with the lock plate ④.

CAUTION:

Check that all brake hoses and brake tubes are not twisted and bent.



- Tighten the flare nut to the specified torque with a flare nut torque wrench (A).

CAUTION:

Never scratch the flare nut and the brake tube.


- Refill with new brake fluid and perform the air bleeding. Refer to [BR-14, "Bleeding Brake System"](#).

CAUTION:

Never reuse drained brake fluid.

- Install tires. Refer to [WT-61, "Removal and Installation"](#).

- Perform inspection after installation. Refer to [BR-27, "FRONT : Inspection"](#).



< REMOVAL AND INSTALLATION >

FRONT : Inspection

INFOID:000000010838513

INSPECTION AFTER INSTALLATION

- Check the brake hoses and tubes for the following: no scratches; no twist and deformation; no interference with other components when steering the steering wheel; no looseness at connections.

CAUTION:

Clearance with brake hose and each parts being secured more than 10 mm (0.39 in) in unladen condition*.

*: Fuel, engine coolant and lubricant are quantity to specified. Spare tire, jack, hand tools and mats are brought out of vehicle.

- Depress the brake pedal with a force of 785 N (80 kg, 176 lb) and hold down the pedal for approximately 5 seconds with the engine running. Check for any fluid leakage.

CAUTION:


Retighten the applicable connection to the specified torque and repair any abnormal (damaged, worn or deformed) part if any brake fluid leakage is present.

REAR

REAR : Exploded View

INFOID:000000010838514

MR20DD



- ① Brake tube
- ④ Union bolt
- ⑦ Brake tube bracket
- Ⓐ To connector
- Ⓓ Caliper side

- ② Lock plate
- ⑤ Copper washer
- ⑧ Brake tube bracket
- Ⓑ To rear brake hose

- ③ Brake hose
- ⑥ Brake tube bracket
- ⑨ Floor side

Ⓐ: N·m (kg·m, ft·lb)

Ⓑ: N·m (kg·m, in·lb)


ⓧ: Always replace after every disassembly.


BRAKE PIPING

[LHD]

< REMOVAL AND INSTALLATION >

EXCEPT MR20DD





| | | |
|---|--------------------|----------------------------|
| ① ABS actuator and electric unit (control unit) | ② Front disc brake | ③ Master cylinder assembly |
| ④ Brake booster | ⑤ Connector | ⑥ Rear disc brake |
| Ⓐ Brake tube | Ⓑ Brake hose | |

○: Flare nut
■: Union bolt

REAR : Removal and Installation

REMOVAL

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.
- Wipe off immediately when attaching brake fluid with disc rotor and caliper assembly.


1. Remove tires. Refer to [WT-61, "Removal and Installation"](#).

2. Drain brake fluid. Refer to [BR-13, "Draining"](#).

3. Loosen the flare nut ① with a flare nut wrench (A) and separate the brake tube ② from the hose ③.

CAUTION:

- Never scratch the flare nut and the brake tube.
- Never bend sharply, twist or strongly pull out the brake hoses and tubes.
- Cover open end of brake tubes and hoses when disconnecting to prevent entrance of dirt.



4. Disconnect the lock plate ⑤, then remove the brake hose.

BRAKE PIPING

[LHD]


< REMOVAL AND INSTALLATION >

- Loosen the flare nut ① with a flare nut wrench (A) and separate the brake tube ② from the hose ③.


CAUTION:

- Never scratch the flare nut and the brake tube.
- Never bend sharply, twist or strongly pull out the brake hoses and tubes.
- Cover open end of brake tubes and hoses when disconnecting to prevent entrance of dirt.

- Disconnect the lock plate ④, then remove the brake hose from the brake hose bracket ⑤.



- Remove the union bolt ① and copper washers ②, and remove the brake hose ③ from the brake caliper assembly.



INSTALLATION

CAUTION:


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.
- Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.
- Wipe off immediately when attaching brake fluid with disc rotor and caliper assembly.

- Assemble the union bolt ① and copper washers ② to the brake hose.

CAUTION:

Never reuse the copper washer.


- Align the brake hose L-pin ④ with the brake caliper assembly hole ⑤, and tighten the union bolt to the specified torque.



- Install the brake hose ① to the brake tube ②, temporarily tighten the flare nut ③ by hand until it does not rotate further, and fix the brake hose to the brake hose bracket ⑤ with the lock plate ④.

CAUTION:

Check that all brake hoses and brake tubes are not twisted and bent.



BRAKE PIPING


[LHD]

< REMOVAL AND INSTALLATION >

4. Tighten the flare nut to the specified torque with a flare nut torque wrench (A).

CAUTION:


Never scratch the flare nut and the brake tube.



5. Install the brake hose ④ to the brake tube ② and the brake tube ③, temporarily tighten the flare nut ① by hand until it does not rotate further, and fix the brake hose to brake hose brackets with the lock plate ⑤.

CAUTION:

Check that all brake hoses and brake tubes are not twisted and bent.



6. Tighten the flare nut to the specified torque with a flare nut torque wrench (A).

CAUTION:

Never scratch the flare nut and the brake tube.


7. Refill with new brake fluid and perform the air bleeding. Refer to [BR-14, "Bleeding Brake System"](#).

CAUTION:

Never reuse drained brake fluid.

8. Install tires. Refer to [WT-61, "Removal and Installation"](#).

9. Perform inspection after installation. Refer to [BR-31, "REAR : Inspection"](#).



REAR : Inspection

INFOID:000000010838517

INSPECTION AFTER INSTALLATION

1. Check the brake hoses and tubes for the following: no scratches; no twist and deformation; no looseness at connections.

CAUTION:

Clearance with brake hose and each parts being secured more than 10 mm (0.39 in) in unladen condition*.

*: Fuel, engine coolant and lubricant are quantity to specified. Spare tire, jack, hand tools and mats are brought out of vehicle.

2. Depress the brake pedal with a force of 785 N (80 kg, 176 lb) and hold down the pedal for approximately 5 seconds with the engine running. Check for any fluid leakage.

CAUTION:


Retighten the applicable connection to the specified torque and repair any abnormal (damaged, worn or deformed) part if any brake fluid leakage is present.

< REMOVAL AND INSTALLATION >

BRAKE MASTER CYLINDER

Exploded View

INFOID:0000000010838518



JSFIA2562GB

| | | |
|-----------------|-----------------|------------------|
| ① Reservoir cap | ② Oil strainer | ③ Reservoir tank |
| ④ Grommet | ⑤ Cylinder body | ⑥ Screw |
| ⑦ O-ring | | |

: Apply polyglycol ether based lubricant.

: Apply brake fluid.

: N·m (kg·m, ft·lb)

: Always replace after every disassembly.

Removal and Installation

INFOID:0000000010838519

REMOVAL

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Depress the brake pedal several times to release the vacuum pressure from the brake booster. Then remove the master cylinder assembly.
- Never depress the brake pedal while removing the brake tube. If this is not complied with, brake fluid may splash.


1. Perform inspection before removal. Refer to [BR-35, "Inspection"](#).
2. Drain brake fluid. Refer to [BR-13, "Draining"](#).
3. Remove the battery. Refer to [PG-142, "EXCEPT FOR R9M : Removal and Installation"](#).
4. Remove the TCM (as a set with bracket). Refer to [TM-415, "Removal and Installation"](#).

BRAKE MASTER CYLINDER

[LHD]

< REMOVAL AND INSTALLATION >

5. Remove the air duct assembly, the air duct 1, the air duct 2, the air cleaner cover, the cleaner element, the air cleaner body, and the mass air flow sensor.
 - For MR20DD, refer to [EM-31, "Removal and Installation"](#).
 - For QR25DE, refer to [EM-175, "Removal and Installation"](#).
 - For R9M, refer to [EM-308, "Removal and Installation"](#).
6. Remove the engine cover.
 - For R9M, refer to [EM-306, "Removal and Installation"](#).
7. Disconnect the brake fluid level switch harness connector and the harness clip.
8. Separate the brake tube from the master cylinder assembly with a flare nut wrench (A).
CAUTION:
Never scratch the flare nut and the brake tube.




9. Remove the master cylinder assembly.

CAUTION:

- Never deform or bend the brake tubes.
- Never depress the brake pedal after the master cylinder assembly is removed.

- The piston (A) of the master cylinder assembly is exposed. Never damage it when removing the master cylinder.
- The piston may drop off when pulled out strongly. Never hold the piston. Hold the cylinder body when handling the master cylinder assembly.



10. Remove the O-ring.


INSTALLATION

CAUTION:

Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.


Note the following, and install in the reverse order of removal.

- Never reuse the O-ring.
- Never depress the brake pedal after the master cylinder assembly is removed.
- Apply polyglycol ether based lubricant to the brake booster [see (A) in the figure] when installing the master cylinder assembly to the brake booster.




< REMOVAL AND INSTALLATION >

- The piston (A) of the master cylinder assembly is exposed. Never damage it when handling the master cylinder.
- Check that no dirt and dust are present on the piston before installation. Clean it with new brake fluid if necessary.
- The piston may drop off when pulled strongly. Never hold the piston. Hold the cylinder body when handling the master cylinder assembly.
- Never deform or bend the brake tubes.



- Temporarily tighten the brake tube flare nut to the master cylinder assembly by hand. Then tighten it to the specified torque with a flare nut torque wrench (A). Refer to [BR-32, "Exploded View"](#).
- Perform the air bleeding. Refer to [BR-14, "Bleeding Brake System"](#).
- Perform inspection after installation. Refer to [BR-35, "Inspection"](#).



Disassembly and Assembly

INFOID:0000000010838520

DISASSEMBLY

CAUTION:

- Never disassemble the cylinder body.
- Remove the reservoir tank only when necessary.
- Never drop parts to remove. Replace new parts when dropping.

- Fix the master cylinder assembly to a vise.

CAUTION:

- Always set copper plates or cloth between vise grips when fixing the cylinder body to a vise.
- Never overtighten the vise.

- Remove the reservoir tank mounting screw.

- Remove the reservoir tank and grommet from the cylinder body.

ASSEMBLY

CAUTION:

- Never use mineral oils such as kerosene or gasoline and rubber grease during the cleaning and assembly process.
- Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.
- Never drop when installing. The parts must not be reused if they are dropped.

- Apply new brake fluid to the grommet and install it to the cylinder body.

CAUTION:

Never reuse grommets.

- Install the reservoir tank to the cylinder body.

- Fix the cylinder body to a vise.

CAUTION:


BRAKE MASTER CYLINDER

[LHD]

< REMOVAL AND INSTALLATION >

- Place the reservoir tank with the chamfered screw hole (➡ facing up).
- Always set copper plates or cloth between vise grips when fixing the cylinder body to a vise.
- Never overtighten the vise.

4. Tilt the reservoir tank so that a mounting screw can be fixed. Assemble with screw.



INFOID:000000010838521

Inspection

INSPECTION BEFORE REMOVAL

Check the brake fluid level switch. Refer to [BRC-159, "Component Inspection"](#).

INSPECTION AFTER INSTALLATION

Check the following items and replace if necessary.

- Check the master cylinder for deformation, twist, contact with other parts or looseness of connection.
- Check for fluid leakage from connection. Refer to [BR-27, "FRONT : Inspection"](#).

CAUTION:

If the fluid leakage is present, retighten to the specified torque. Replace parts if necessary.

A
B
C
D

BR

G

H

I

J

K

L

M

N


O

P

< REMOVAL AND INSTALLATION >

BRAKE BOOSTER**Exploded View**

INFOID:0000000010838522



① Brake booster

② Check valve

③ Master cylinder assembly

④ Vacuum sensor

⑤ Gasket

N·m (kg·m, ft·lb)

Removal and installation

INFOID:0000000010838523

REMOVAL**CAUTION:**

Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.


1. Perform inspection before removal. Refer to [BR-38, "Inspection and Adjustment"](#).
2. Drain brake fluid. Refer to [BR-13, "Draining"](#).
3. Remove brake master cylinder assembly. Refer to [BR-32, "Removal and Installation"](#).
4. Remove vacuum hose from check valve.
 - For MR20DD, refer to [BR-40, "MR20DD : Removal and Installation"](#).
 - For QR25DE, refer to [BR-41, "QR25DE : Removal and Installation"](#).
 - For R9M, refer to [BR-42, "R9M : Removal and Installation"](#).
5. Remove cowl top extension. Refer to [EXT-25, "Removal and Installation"](#).
6. Remove brake tube between master cylinder assembly and ABS actuator and electric unit (control unit). Refer to [BR-24, "FRONT : Exploded View"](#).

BRAKE BOOSTER

[LHD]

< REMOVAL AND INSTALLATION >

7. Remove snap pin ① and clevis pin ②.



8. Remove nuts on brake booster and brake pedal assembly.

CAUTION:

Hold the brake booster so as to avoid dropping out.

9. Remove brake booster.

CAUTION:

Never deform or bend the brake tubes.

10. Remove check valve from brake booster.

11. Perform inspection after removal. Refer to [BR-38, "Inspection and Adjustment"](#).

INSTALLATION


CAUTION:

Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.

Note the following, and install in the reverse order of removal.


- Install check valve ① and vacuum sensor ② as shown in figure.
- Except R9M

| | |
|---|--------------------------|
| A | : $98^\circ \pm 5^\circ$ |
| B | : $0^\circ \pm 5^\circ$ |
| ↖ | : Vehicle upper side |



- R9M

| | |
|---|--------------------------|
| A | : $70^\circ \pm 5^\circ$ |
| B | : $0^\circ \pm 5^\circ$ |
| ↖ | : Vehicle upper side |



- Be careful not to damage brake booster stud bolt threads. If brake booster is tilted during installation, the dash panel may damage threads.
- Never deform or bend the brake tubes when installing the brake booster.
- Always use new gasket between the brake booster and the dash panel.
- Replace clevis pin when found damage.
- Never allow foreign matter (e.g. dust) and oil other than brake fluid to enter reservoir tank.
- Perform the air bleeding. Refer to [BR-13, "Draining"](#).

< REMOVAL AND INSTALLATION >

CAUTION:

Never reuse brake fluid to drain.

- Check each item of brake pedal. Adjust it if the measurement value is not the standard. Refer to [BR-11, "Inspection and Adjustment".](#)

Inspection and Adjustment

INFOID:000000010838524

INSPECTION BEFORE REMOVAL

Air Tight

CAUTION:

Check the air tight condition when the master cylinder and the brake booster is installed.

- Check the air tight use a handy vacuum pump.

At vacuum of $-66.7 \text{ kPa} (-500 \text{ mmHg}, -19.69 \text{ inHg}, -0.067 \text{ bar})$: Vacuum should decrease within $3.3 \text{ kPa} (24.8 \text{ mmHg}, 0.98 \text{ inHg}, 0.033 \text{ bar})$ for 15 seconds.

- If the air tight condition cannot be maintained, perform the following operation.
 - Check the no dirt and dust are present on the brake booster and brake master cylinder mating faces. Clean it if necessary.
 - Check the O-ring on the master cylinder. If anything is found, replace the O-ring. Refer to [BR-32, "Removal and Installation".](#)
 - Check the air tight condition again. If the condition still cannot be maintained, replace the brake booster.

INSPECTION AFTER REMOVAL

Check Valve Inspection

- Check the check valve to use a handy vacuum pump.

In the case of connecting to brake booster : Vacuum should decrease within $3.3 \text{ kPa} (24.8 \text{ mmHg}, 0.98 \text{ inHg}, 0.033 \text{ bar})$ for 15 seconds at vacuum of $-66.7 \text{ kPa} (-500 \text{ mmHg}, -19.69 \text{ inHg}, -0.067 \text{ bar})$.

In the case of connecting to vacuum hose : Vacuum should not exist.


Input Rod Length rod Inspection

- Check the input length (A).

① : Input rod

A : Refer to [BR-67, "Brake Booster".](#)

- Replace the brake booster if the input rod length is not the standard.



INSPECTION AFTER INSTALLATION

Operation

Depress the brake pedal several times at 5-second intervals with the engine stopped. Start the engine with the brake pedal fully depressed. Check that the clearance between brake pedal and dash lower panel decreases.

NOTE:

A slight impact with a small click may be felt on the pedal when the brake pedal is fully depressed. this is normal phenomenon due to the brake system operation.

Air Tight

- Run the engine at idle for 1 minute to apply vacuum to the brake booster, and stop the engine.

< REMOVAL AND INSTALLATION >

2. Depress the brake pedal several times at 5-second intervals until the accumulated vacuum is released to atmospheric pressure. Check that the clearance between brake pedal and dash lower panel gradually increases each time.
3. Depress the brake pedal with the engine running. Then stop the engine while holding down the brake pedal. Check that the brake pedal stroke does not change after holding down the brake pedal for 30 seconds or more.

A

B

C

D

E

BR

G

H

I

J

K

L

M

N

O

P

< REMOVAL AND INSTALLATION >


VACUUM LINES

MR20DD

MR20DD : Exploded View

INFOID:0000000010838525

MR20DD



① Vacuum piping

② Vacuum hose

③ Clamp

Ⓐ To intake manifold

Ⓑ Paint mark

Ⓒ To brake booster

MR20DD : Removal and Installation

INFOID:0000000010838526

REMOVAL

1. Remove the vacuum hose and vacuum piping.
2. Perform inspection after removal. Refer to [BR-40, "MR20DD : Inspection"](#).


INSTALLATION

Note the following, install the vacuum hose.

- When installing vacuum hose, insert it until its tip reaches the back-end of length (A) or further as shown in the figure.

CAUTION:**Never use lubricating oil during assembly.****A : 24 mm (0.95 in) or more**

- Face the paint mark of vacuum hose (built-in check valve) to upward to assemble.
- Face the paint mark of vacuum piping (intake manifold side) to upward to assemble.
- Face the other paint marks to vehicle front side to assemble.
- For clamp mounting direction (the orientation of pawl), refer to [BR-40, "MR20DD : Exploded View"](#).



MR20DD : Inspection

INFOID:0000000010838527


INSPECTION AFTER REMOVAL

Appearance

Check for correct assembly, damage and deterioration.

QR25DE

QR25DE



① Vacuum piping

Ⓐ To intake manifold

② Vacuum hose

Ⓑ Paint mark

③ Clamp

Ⓒ To brake booster

QR25DE : Removal and Installation

INFOID:0000000010838529

REMOVAL

1. Remove the vacuum hose and vacuum piping.
2. Perform inspection after removal. Refer to [BR-41, "QR25DE : Inspection"](#).


INSTALLATION

Note the following, install the vacuum hose.

- When installing vacuum hose, insert it until its tip reaches the back-end of length (A) or further as shown in the figure.

CAUTION:**Never use lubricating oil during assembly.****A : 24 mm (0.95 in) or more**

- Face the paint mark of vacuum hose (built-in check valve) to upward to assemble.
- Face the paint mark of vacuum piping (intake manifold side) to upward to assemble.
- Face the other paint marks to vehicle front side to assemble.
- For clamp mounting direction (the orientation of pawl), refer to [BR-41, "QR25DE : Exploded View"](#).



QR25DE : Inspection

INFOID:0000000010838530


INSPECTION AFTER REMOVAL

Appearance

Check for correct assembly, damage and deterioration.

R9M

R9M



① Vacuum hose

② Clamp

③ Connector

④ Vacuum hose bracket

Ⓐ To vacuum pump

Ⓑ Paint mark

Ⓒ To brake booster

Nm: N·m (kg·m, in·lb)

R9M : Removal and Installation

INFOID:0000000010838984

REMOVAL

1. Remove engine cover. Refer to [EM-306, "Removal and Installation"](#).
2. Remove the vacuum hose and vacuum piping.
3. Perform inspection after removal. Refer to [BR-42, "R9M : Inspection"](#).

INSTALLATION

Note the following, install the vacuum hose.


- When installing vacuum hose, insert it until its tip reaches the back-end of length (A) or further as shown in the figure.

CAUTION:

Never use lubricating oil during assembly.

A : 24 mm (0.95 in) or more

- Face the paint mark of vacuum hose (built-in check valve) to upward to assemble.
- Face the paint mark of vacuum piping (intake manifold side) to upward to assemble.
- Face the other paint marks to vehicle front side to assemble.
- For clamp mounting direction (the orientation of pawl), refer to [BR-42, "R9M : Exploded View"](#).



JPFIA0023ZZ

R9M : Inspection

INFOID:0000000010838985

INSPECTION AFTER REMOVAL

Appearance

Check for correct assembly, damage and deterioration.

FRONT DISC BRAKE

[LHD]


< REMOVAL AND INSTALLATION >

FRONT DISC BRAKE

BRAKE PAD (1 PISTON TYPE)

BRAKE PAD (1 PISTON TYPE) : Exploded View

INFOID:0000000010838531



| | | |
|------------------------------------|--------------------|----------------|
| ① Cylinder body | ② Inner shim cover | ③ Inner shim |
| ④ Inner pad (with pad wear sensor) | ⑤ Return spring | ⑥ Pad retainer |
| ⑦ Torque member | ⑧ Outer pad | ⑨ Outer shim |
| ⑩ Outer shim cover | | |

1: Apply MOLYKOTE® AS 880N or silicone-based grease.

2: Apply MOLYKOTE® 7439 or equivalent.

Q: N·m (kg·m, ft·lb)

Molykote is a registered trademark of Dow Corning Corporation.

BRAKE PAD (1 PISTON TYPE) : Removal and Installation

INFOID:0000000010838532

REMOVAL


WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Remove tires with power tool.
2. Remove lower sliding pin bolt.




FRONT DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

- Suspend the cylinder body with suitable wire so that the brake hose will not stretch.




JPFIA0850ZZ

- Remove the brake pads, shims, shim covers and pad retainer (as a set with pad return spring) ② from the torque member ①.

CAUTION:

- Remove pad retainer together with pad return springs.
- Never deform the pad return springs and pad retainer when removing the pad retainer from the torque member.
- Never damage the piston boots.
- Never drop the brake pads, shims and shim covers.
- Remember each position of the removed brake pads.



JPFIA0118ZZ


- Remove the pad return springs ① from the pad retainer ②.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs when removing the pad return springs from the pad retainer.

- Perform inspection after removal. Refer to [BR-46, "BRAKE PAD \(1 PISTON TYPE\) : Inspection"](#).



JSFIA2329ZZ

INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

- Install the pad return springs ① to pad retainer ② if the pad return springs has been removed.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs.



JSFIA2329ZZ

FRONT DISC BRAKE


[LHD]

< REMOVAL AND INSTALLATION >

2. Apply MOLYKOTE® 7439 or equivalent to the match face Ⓐ between the pad retainers ① and torque member ② if the pad retainers has been removed.
Molykote is a registered trademark of Dow Corning Corporation.
3. Install the pad retainer (upper side with pad return spring) to torque member if the pad retainers has been removed.

CAUTION:

- Securely assemble the pad retainers so that it will not be lifted up from the torque member.
- Never deform the pad retainers and pad return springs.




4. Apply MOLYKOTE® AS880N or silicone-based grease to the matching faces Ⓐ between the shim ① and the shim cover ②, and install the shim and the shim covers to the brake pad ③.

CAUTION:


Always replace the shims and shim covers when replacing the brake pad.

Molykote is a registered trademark of Dow Corning Corporation.



5. Apply MOLYKOTE® 7439 or equivalent to the match face Ⓐ between the brake pad ① and torque member ②.


Molykote is a registered trademark of Dow Corning Corporation.



6. Install the brake pads to the torque member.

CAUTION:

Both inner and outer pads have a pad return system. Securely push the pad return spring ① into the disc rotor side of brake pad ②.



7. Install cylinder body to torque member.

CAUTION:

- Never damage the piston boot.
- When replacing brake pad with new one, check a brake fluid level in the reservoir tank because brake fluid returns to reservoir tank when pressing piston in.

NOTE:


Use a disc brake piston tool to easily press piston.

FRONT DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

8. Install the lower sliding pin bolt and tighten it to the specified torque.



9. Depress the brake pedal several times to check that no drag feel is present for the front disc brake. Refer to [BR-46, "BRAKE PAD \(1 PISTON TYPE\) : Inspection"](#).
10. Install tires. Refer to [WT-61, "Removal and Installation"](#).

BRAKE PAD (1 PISTON TYPE) : Inspection

INFOID:0000000010838533

INSPECTION AFTER REMOVAL

- Replace the shims and shim covers if rust is excessively attached.
- Eliminate rust on the pad return spring, pad retainers and the torque member. Replace them if rust is excessively attached.


INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.
 1. Remove brake pads. Refer to [BR-43, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
 2. Press the pistons. Refer to [BR-43, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
 3. Install brake pads. Refer to [BR-43, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
 4. Depress the brake pedal several times.
 5. Check a drag of front disc brake again. If any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-52, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage. Refer to [BR-17, "BRAKE PAD : Inspection and Adjustment"](#).

BRAKE PAD (2 PISTON TYPE)

BRAKE PAD (2 PISTON TYPE) : Exploded View

INFOID:0000000010838597



< REMOVAL AND INSTALLATION >

| | | |
|------------------------------------|--------------------|----------------|
| ① Cylinder body | ② Inner shim cover | ③ Inner shim |
| ④ Inner pad (with pad wear sensor) | ⑤ Return spring | ⑥ Pad retainer |
| ⑦ Torque member | ⑧ Outer pad | ⑨ Outer shim |
| ⑩ Outer shim cover | | |

 1: Apply MOLYKOTE® AS 880N or silicone-based grease.

 2: Apply MOLYKOTE® 7439 or equivalent.

 N·m (kg·m, ft·lb)

Molykote is a registered trademark of Dow Corning Corporation.

BRAKE PAD (2 PISTON TYPE) : Removal and Installation

INFOID:0000000010838598

REMOVAL


WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.


CAUTION:

- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Remove tires with power tool.
2. Remove lower sliding pin bolt.




3. Suspend the cylinder body with suitable wire so that the brake hose will not stretch.



4. Remove the brake pads, shims, shim covers and pad retainer (as a set with pad return spring) ② from the torque member ①.

CAUTION:

- Remove pad retainer together with pad return springs.
- Never deform the pad return springs and pad retainer when removing the pad retainer from the torque member.
- Never damage the piston boots.
- Never drop the brake pads, shims and shim covers.
- Remember each position of the removed brake pads.



FRONT DISC BRAKE

< REMOVAL AND INSTALLATION >

[LHD]


- Remove the pad return springs ① from the pad retainer ②.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs when removing the pad return springs from the pad retainer.

- Perform inspection after removal. Refer to [BR-49, "BRAKE PAD \(2 PISTON TYPE\) : Inspection"](#).



INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

- Install the pad return springs ① to pad retainer ② if the pad return springs has been removed.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs.




- Apply MOLYKOTE® 7439 or equivalent to the match face Ⓐ between the pad retainers ① and torque member ② if the pad retainers has been removed.

Molykote is a registered trademark of Dow Corning Corporation.

- Install the pad retainer (upper side with pad return spring) to torque member if the pad retainers has been removed.

CAUTION:

- Securely assemble the pad retainers so that it will not be lifted up from the torque member.
- Never deform the pad retainers and pad return springs.




- Apply MOLYKOTE® AS880N or silicone-based grease to the matching faces Ⓐ between the shim ① and the shim cover ②, and install the shim and the shim covers to the brake pad ③.

CAUTION:

Always replace the shims and shim covers when replacing the brake pad.

Molykote is a registered trademark of Dow Corning Corporation.




FRONT DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

5. Apply MOLYKOTE® 7439 or equivalent to the match face **A** between the brake pad **①** and torque member **②**.
Molykote is a registered trademark of Dow Corning Corporation.




JSFIA1337ZZ

6. Install the brake pads to the torque member.

CAUTION:

Both inner and outer pads have a pad return system. Securely push the pad return spring **①** into the disc rotor side of brake pad **②**.



JSFIA2330ZZ

7. Install cylinder body to torque member.


CAUTION:

- Never damage the piston boot.
- When replacing brake pad with new one, check a brake fluid level in the reservoir tank because brake fluid returns to reservoir tank when pressing piston in.

NOTE:

Use a disc brake piston tool to easily press piston.

8. Install the lower sliding pin bolt and tighten it to the specified torque.



JPFIA0832ZZ

9. Depress the brake pedal several times to check that no drag feel is present for the front disc brake. Refer to [BR-49, "BRAKE PAD \(2 PISTON TYPE\) : Inspection"](#).

10. Install tires. Refer to [WT-61, "Removal and Installation"](#).

BRAKE PAD (2 PISTON TYPE) : Inspection

INFOID:0000000010838599

INSPECTION AFTER REMOVAL

- Replace the shims and shim covers if rust is excessively attached.
- Eliminate rust on the pad return spring, pad retainers and the torque member. Replace them if rust is excessively attached.

INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.

FRONT DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >


1. Remove brake pads. Refer to [BR-47, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
2. Press the pistons. Refer to [BR-47, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
3. Install brake pads. Refer to [BR-47, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
4. Depress the brake pedal several times.
5. Check a drag of front disc brake again. If any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-57, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage. Refer to [BR-17, "BRAKE PAD : Inspection and Adjustment"](#).

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE)


BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Exploded View

INFOID:000000010838534

REMOVAL



DISASSEMBLY



< REMOVAL AND INSTALLATION >

| | | |
|-----------------|--------------------|-----------------|
| ① Cap | ② Bleeder valve | ③ Cylinder body |
| ④ Piston seal | ⑤ Piston | ⑥ Piston boot |
| ⑦ Sliding pin | ⑧ Sliding pin boot | ⑨ Bushing |
| ⑩ Torque member | | |

: Apply rubber grease.

: Apply brake fluid.

: N·m (kg·m, in-lb)

: Always replace after every disassembly.

A

B

C

D

E

INFOID:000000010838535

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Removal and Installation

BR

REMOVAL

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

G

H

1. Remove tires with power tool.

I

2. Fix the disc rotor using wheel nuts.

J

3. Drain brake fluid. Refer to [BR-13, "Draining"](#).

K

4. Remove union bolt and copper washer, and separate brake hose from brake caliper assembly. Refer to [BR-25, "FRONT : Removal and Installation"](#).

L

5. Remove torque member mounting bolts, and remove brake caliper assembly.

M

CAUTION:

Never drop brake pad and brake caliper assembly.

N


6. Remove disc rotor.

O

- 2WD: Refer to [FAX-11, "Removal and Installation"](#).

P

- 4WD: Refer to [FAX-72, "Removal and Installation"](#).



JPFIA0835ZZ

INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.
- Never allow foreign matter (e.g.dust) and oils other than brake fluid to enter the reservoir tank.

1. Install disc rotor.

- 2WD: Refer to [FAX-11, "Removal and Installation"](#).
- 4WD: Refer to [FAX-72, "Removal and Installation"](#).

FRONT DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

- Install the brake caliper assembly to the steering knuckle and tighten the torque member mounting bolts to the specified torque.

CAUTION:

Never spill or splash any grease and moisture on the brake caliper assembly mounting face, threads, mounting bolts and washers. Wipe out any grease and moisture.

- Install brake hose and copper washers to brake caliper assembly. Refer to [BR-25, "FRONT : Removal and Installation"](#).

CAUTION:

Never reuse copper washer.

- Refill with new brake fluid and perform the air bleeding. Refer to [BR-14, "Bleeding Brake System"](#).

CAUTION:

- Never reuse brake fluid.
- Never spill or splash brake fluid on the surface of disc rotor.

- Check a drag of front disc brake. If any drag is found, refer to [BR-54, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Inspection"](#).

- Install tires. Refer to [WT-61, "Removal and Installation"](#)

- Perform inspection after installation. Refer to [BR-54, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Inspection"](#).

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Disassembly and Assembly

INFOID:000000010838536

DISASSEMBLY

NOTE:

Never remove the torque member, brake pad and pad retainers when disassembling and assembling the cylinder body.



- Remove the sliding pin bolt, and remove the cylinder body from the torque member. Refer to [BR-43, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).

CAUTION:

Fix the brake pad at suitable tape so that the brake pad will not drop.

- Remove sliding pins and sliding pin boots from torque member.


- Remove bushing ① from sliding pin ②.



- Place a wooden block as shown in the figure, and blow air from union bolt mounting hole to remove pistons and piston boots.

CAUTION:

Never get fingers caught in the pistons.




FRONT DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

5. Remove piston seals from cylinder body using seal pick tool.
CAUTION:
Be careful not to damage a cylinder inner wall.
6. Remove bleeder valve and cap.
7. Perform inspection after disassembly. Refer to [BR-54, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Inspection".](#)



JPFI0038ZZ


A
B
C
D
E

BR

G
H

ASSEMBLY

1. Install bleeder valve and cap.
2. Apply new brake fluid to piston seals ①, and install them to cylinder body.
CAUTION:
Never reuse piston seals.




JPFI0039ZZ

I
J
K

3. Apply rubber grease to piston boots ①. Cover the piston ② end with piston boot, and then install cylinder side lip on piston boot securely into a groove on cylinder body.

CAUTION:

Never reuse piston boots.




JPFI0040ZZ

L
M
N

4. apply new brake fluid to pistons ①. Push piston into cylinder body by hand and push piston boot ② piston-side lip into the piston groove.

CAUTION:

Press the pistons evenly and vary the pressing point to prevent cylinder inner wall from being rubbed.



JPFI0034ZZ


O
P

FRONT DISC BRAKE

[LHD]


< REMOVAL AND INSTALLATION >

5. Apply rubber grease to mating faces Ⓐ between sliding pin ① and bushing ②, and install bushing to sliding pin.



JPFIA0836ZZ

6. Apply rubber grease to mating faces Ⓐ between sliding pins ① and sliding pin boots ②, and install sliding pins and sliding pin boots to torque member ③.
7. Install the cylinder body to tighten sliding pin bolts to the specified torque.



JPFIA0837ZZ

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Inspection

INFOID:0000000010838537

INSPECTION AFTER DISASSEMBLY

Check the following items and replace if necessary.

Cylinder Body

Check the cylinder inner wall for rust, wear, cracks or damage.

CAUTION:

Always clean with new brake fluid. Never clean with mineral oil such as gasoline and light oil.

Torque Member

Check the torque member for rust, wear, cracks or damage.

Pistons

Check the surface of the piston for rust, wear, cracks or damage.

CAUTION:

A piston sliding surface is plated. Never polish with sandpaper.

Sliding Pin, Sliding Pin Boot and Bushing

Check the sliding pins, sliding pin boots and bushing for rust, wear, cracks or damage.

INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.
- 1. Remove brake pads. Refer to [BR-43, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
- 2. Press the pistons. Refer to [BR-43, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
- 3. Install brake pads. Refer to [BR-43, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
- 4. Depress the brake pedal several times.
- 5. Check a drag of front disc brake again. When any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-52, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage. Refer to [BR-17, "BRAKE PAD : Inspection and Adjustment"](#).

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE)

FRONT DISC BRAKE


[LHD]

< REMOVAL AND INSTALLATION >

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Exploded View

INFOID:000000010838604


REMOVAL



① Brake caliper assembly

: N·m (kg-m, ft-lb)

DISASSEMBLY



① Cap

④ Sliding pin

⑦ Piston seal

⑩ Torque member

② Bleeder valve

⑤ Sliding pin boot

⑧ Piston

③ Cylinder body

⑥ Bushing

⑨ Piston boot

: Apply rubber grease.

: Apply brake fluid.

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

A

B

C

D

E

BR

G

H

I

J

K

L

M

N

O

P

< REMOVAL AND INSTALLATION >

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Removal and Installation

INFOID:000000010838605

REMOVAL

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.


CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Remove tires with power tool.
2. Fix the disc rotor using wheel nuts.
3. Drain brake fluid. Refer to [BR-13, "Draining"](#).
4. Remove union bolt and copper washer, and separate brake hose from brake caliper assembly. Refer to [BR-25, "FRONT : Removal and Installation"](#).
5. Remove torque member mounting bolts, and remove brake caliper assembly.

CAUTION:
Never drop brake pad and brake caliper assembly.

6. Remove disc rotor.
 - 2WD: Refer to [FAX-11, "Removal and Installation"](#).
 - 4WD: Refer to [FAX-72, "Removal and Installation"](#).



INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.
- Never allow foreign matter (e.g.dust) and oils other than brake fluid to enter the reservoir tank.

1. Install disc rotor.
 - 2WD: Refer to [FAX-11, "Removal and Installation"](#).
 - 4WD: Refer to [FAX-72, "Removal and Installation"](#).
2. Install the brake caliper assembly to the steering knuckle and tighten the torque member mounting bolts to the specified torque.


CAUTION:
Never spill or splash any grease and moisture on the brake caliper assembly mounting face, threads, mounting bolts and washers. Wipe out any grease and moisture.

3. Install brake hose and copper washers to brake caliper assembly. Refer to [BR-25, "FRONT : Removal and Installation"](#).

CAUTION:
Never reuse copper washer.

4. Refill with new brake fluid and perform the air bleeding. Refer to [BR-14, "Bleeding Brake System"](#).

CAUTION:



< REMOVAL AND INSTALLATION >

- Never reuse brake fluid.
- Never spill or splash brake fluid on the surface of disc rotor.

5. Check a drag of front disc brake. If any drag is found, refer to [BR-59, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection".](#)
6. Install tires. Refer to [WT-61, "Removal and Installation"](#)
7. Perform inspection after installation. Refer to [BR-59, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection".](#)

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Disassembly and Assembly

INFOID:0000000010838606

DISASSEMBLY

NOTE:


Never remove the torque member, brake pad and pad retainers when disassembling and assembling the cylinder body.

1. Remove the sliding pin bolt, and remove the cylinder body from the torque member. Refer to [BR-47, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation".](#)

CAUTION:

Fix the brake pad at suitable tape so that the brake pad will not drop.


2. Remove sliding pins and sliding pin boots from torque member.
3. Remove bushing ① from sliding pin ②.



4. Place a wooden block as shown in the figure, and blow air from union bolt mounting hole to remove pistons and piston boots.

CAUTION:

Never get fingers caught in the pistons.




5. Remove piston seals from cylinder body using seal pick tool.

CAUTION:

Be careful not to damage a cylinder inner wall.

6. Remove bleeder valve and cap.
7. Perform inspection after disassembly. Refer to [BR-59, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection".](#)



ASSEMBLY

1. Install bleeder valve and cap.

FRONT DISC BRAKE


[LHD]

< REMOVAL AND INSTALLATION >

2. Apply new brake fluid to piston seals ①, and install them to cylinder body.

CAUTION:


Never reuse piston seals.



3. Apply rubber grease to piston boots ①. Cover the piston ② end with piston boot, and then install cylinder side lip on piston boot securely into a groove on cylinder body.

CAUTION:


Never reuse piston boots.




4. apply new brake fluid to pistons ①. Push piston into cylinder body by hand and push piston boot ② piston-side lip into the piston groove.

CAUTION:

Press the pistons evenly and vary the pressing point to prevent cylinder inner wall from being rubbed.



5. Apply rubber grease to mating faces Ⓐ between sliding pin ① and bushing ②, and install bushing to sliding pin.




FRONT DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

6. Apply rubber grease to mating faces **A** between sliding pins **①** and sliding pin boots **②**, and install sliding pins and sliding pin boots to torque member **③**.
7. Install the cylinder body to tighten sliding pin bolts to the specified torque.



INFOID:000000010838607

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Inspection

A
B
C
D
E

BR

INSPECTION AFTER DISASSEMBLY

Check the following items and replace if necessary.

Cylinder Body

Check the cylinder inner wall for rust, wear, cracks or damage.

CAUTION:

Always clean with new brake fluid. Never clean with mineral oil such as gasoline and light oil.

Torque Member

Check the torque member for rust, wear, cracks or damage.

G

Pistons

Check the surface of the piston for rust, wear, cracks or damage.

H

CAUTION:

A piston sliding surface is plated. Never polish with sandpaper.

Sliding Pin, Sliding Pin Boot and Bushing

Check the sliding pins, sliding pin boots and bushing for rust, wear, cracks or damage.

I

INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.
 1. Remove brake pads. Refer to [BR-47, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
 2. Press the pistons. Refer to [BR-47, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
 3. Install brake pads. Refer to [BR-47, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
 4. Depress the brake pedal several times.
 5. Check a drag of front disc brake again. When any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-57, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage. Refer to [BR-17, "BRAKE PAD : Inspection and Adjustment"](#).

J

K

L

M

N

O

P


< REMOVAL AND INSTALLATION >

REAR DISC BRAKE

BRAKE PAD

BRAKE PAD : Exploded View

INFOID:0000000010838611



① Cylinder body ② Inner shim cover ③ Inner shim

④ Inner pad (with pad wear sensor) ⑤ Torque member ⑥ Outer pad

⑦ Outer shim ⑧ Outer shim cover

1: Apply rubber grease.

2 : Apply MOLYKOTE® AS 880N or silicone-based grease.

: N·m (kg·m, ft·lb)

Molykote is a registered trademark of Dow Corning Corporation.

BRAKE PAD : Removal and Installation

INFOID:0000000010838612

REMOVAL

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.


1. Release the parking brake.
2. Must be performed additional service when replacing brake pad. Refer to [PB-52, "Work Procedure"](#).
3. Remove tires.

REAR DISC BRAKE

[LHD]


< REMOVAL AND INSTALLATION >

4. Remove lower sliding pin bolt.



A
B
C
D
E

5. Suspend the cylinder body with suitable wire so that the brake hose and the electric parking brake harness will not stretch.



BR
G
H

6. Remove the brake pads, shims and shim covers.

CAUTION:

- Never damage the piston boots.
- Never drop the brake pads, shims and shim covers.
- Remember each position of the removed brake pads.
- Never damage the electric parking brake harness and bracket.

7. Perform inspection after removal. Refer to [BR-62, "BRAKE PAD : Inspection and Adjustment"](#).

INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Apply MOLYKOTE® AS880N or silicone-based grease to the mating faces Ⓐ between the shim ① and the pad ③, and the mating faces Ⓑ between the shim ① and the shim cover ②, and then install the shim and shim cover to the pad.

CAUTION:

Always replace the shims and shim covers when replacing the brake pad.

Molykote is a registered trademark of Dow Corning Corporation.



M
N
O
P

2. Install the brake pads to the torque member.
3. Apply rubber grease to the cylinder body mounting bolts, and then install the cylinder body to torque member.

CAUTION:


REAR DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

- Never damage the piston boot.
- When replacing brake pad with new one, check a brake fluid level in the reservoir tank because brake fluid returns to reservoir tank when pressing piston in.

4. Install the lower sliding pin bolt and tighten it to the specified torque.



5. Must be performed additional service when removing and installing/replacing brake pad.

When removing and installing brake pad

1. Perform "BRAKE OPERATION". Refer to [PB-61, "Work Procedure"](#).
2. Perform "BRAKE RELEASE". Refer to [PB-63, "Work Procedure"](#).

When replacing brake pad

- Refer to [PB-52, "Work Procedure"](#).

6. Depress the brake pedal several times to check that no drag feel is present for the front disc brake. Refer to [BR-62, "BRAKE PAD : Inspection and Adjustment"](#).

7. Install tires. Refer to [WT-61, "Removal and Installation"](#).

BRAKE PAD : Inspection and Adjustment

INFOID:000000010838613

INSPECTION AFTER REMOVAL

- Replace the shims and shim covers if rust is excessively attached.
- Eliminate rust on the pad and the torque member. Replace them if rust is excessively attached.

INSPECTION AFTER INSTALLATION

- Check a drag of rear disc brake. If any drag is found, follow the procedure described below.

1. Remove brake pads. Refer to [BR-60, "BRAKE PAD : Removal and Installation"](#).
2. Press the pistons. Refer to [BR-60, "BRAKE PAD : Removal and Installation"](#).
3. Install brake pads. Refer to [BR-60, "BRAKE PAD : Removal and Installation"](#).
4. Depress the brake pedal several times.
5. Check a drag of rear disc brake again. If any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-65, "BRAKE CALIPER ASSEMBLY : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage. Refer to [BR-19, "BRAKE PAD : Inspection and Adjustment"](#).


BRAKE CALIPER ASSEMBLY

BRAKE CALIPER ASSEMBLY : Exploded View

INFOID:000000010838618

REMOVAL


< REMOVAL AND INSTALLATION >



① Brake caliper assembly

: N·m (kg·m, ft·lb)

DISASSEMBLY



① Cap

② Bleeder valve

③ Cylinder body

④ Sliding pin

⑤ Bushing

⑥ Bushing

⑦ Torque member

: Apply rubber grease.

BRAKE CALIPER ASSEMBLY : Removal and Installation

INFOID:0000000010838619

REMOVAL

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

REAR DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Release the parking brake.
2. Must be performed additional service when replacing brake caliper. Refer to [PB-55, "Work Procedure"](#).
3. Remove tires.
4. Fix the disc rotor using wheel nuts.
5. Drain brake fluid. Refer to [BR-13, "Draining"](#).
6. Remove union bolt and copper washer, and separate brake hose from brake caliper assembly. Refer to [BR-29, "REAR : Removal and Installation"](#).
7. Remove torque member mounting bolts, and remove brake caliper assembly.

CAUTION:

- Never drop brake pad and brake caliper assembly.
- Never damage the electric parking brake harness and bracket.

8. Remove disc rotor.
 - 2WD: Refer to [RAX-7, "Removal and Installation"](#).
 - 4WD: Refer to [RAX-18, "Removal and Installation"](#).



INSTALLATION


WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.
- Never allow foreign matter (e.g.dust) and oils other than brake fluid to enter the reservoir tank.

1. Install disc rotor.
 - 2WD: Refer to [RAX-7, "Removal and Installation"](#).
 - 4WD: Refer to [RAX-18, "Removal and Installation"](#).
2. Install the brake caliper assembly to the steering knuckle and tighten the torque member mounting bolts to the specified torque.



CAUTION:

Never spill or splash any grease and moisture on the brake caliper assembly mounting face, threads, mounting bolts and washers. Wipe out any grease and moisture.

3. Install brake hose and copper washers to brake caliper assembly. Refer to [BR-29, "REAR : Removal and Installation"](#).

CAUTION:

Never reuse copper washer.

4. Must be performed additional service when removing and installing/replacing brake pad.

When removing and installing brake pad

1. Perform "BRAKE OPERATION". Refer to [PB-61, "Work Procedure"](#).
2. Perform "BRAKE RELEASE". Refer to [PB-63, "Work Procedure"](#).

When replacing brake pad

- Refer to [PB-52, "Work Procedure"](#).

5. Refill with new brake fluid and perform the air bleeding. Refer to [BR-14, "Bleeding Brake System"](#).

< REMOVAL AND INSTALLATION >

CAUTION:

- Never reuse brake fluid.
- Never spill or splash brake fluid on the surface of disc rotor.

6. Check a drag of rear disc brake. If any drag is found, refer to [BR-66, "BRAKE CALIPER ASSEMBLY : Inspection and Adjustment".](#)
7. Install tires. Refer to [WT-61, "Removal and Installation"](#)
8. Perform inspection after installation. Refer to [BR-66, "BRAKE CALIPER ASSEMBLY : Inspection and Adjustment".](#)

BRAKE CALIPER ASSEMBLY : Disassembly and Assembly

INFOID:0000000010838620

DISASSEMBLY

NOTE:


Never remove the torque member and brake pad when disassembling and assembling the cylinder body.

1. Remove the sliding pin bolt, and remove the cylinder body from the torque member. Refer to [BR-60, "BRAKE PAD : Removal and Installation".](#)

CAUTION:

Fix the brake pad at suitable tape so that the brake pad will not drop.


2. Remove sliding pins and sliding pin boots from torque member.
3. Remove bushing ① from sliding pin ②.



4. Remove bleeder valve and cap.
5. Perform inspection after disassembly. Refer to [BR-66, "BRAKE CALIPER ASSEMBLY : Inspection and Adjustment".](#)

ASSEMBLY

1. Install bleeder valve and cap.
2. Apply rubber grease to mating faces Ⓐ between sliding pin ① and bushing ②, and install bushing to sliding pin.




REAR DISC BRAKE

[LHD]

< REMOVAL AND INSTALLATION >

3. Apply rubber grease to mating faces ① between sliding pins ① and sliding pin boots ②, and install sliding pins and sliding pin boots to torque member ③.



4. Install the cylinder body to tighten cylinder body mounting bolts to the specified torque. Refer to [BR-60, "BRAKE PAD : Exploded View"](#).

BRAKE CALIPER ASSEMBLY : Inspection and Adjustment

INFOID:000000010838621

INSPECTION AFTER DISASSEMBLY

Check the following items and replace if necessary.

Cylinder Body

Check the cylinder inner wall for rust, wear, cracks or damage.

CAUTION:

Always clean with new brake fluid. Never clean with mineral oil such as gasoline and light oil.

Torque Member

Check the torque member for rust, wear, cracks or damage.

Sliding Pin, Sliding Pin Boot and Bushing

Check the sliding pins, sliding pin boots and bushing for rust, wear, cracks or damage.

INSPECTION AFTER INSTALLATION

- Check a drag of rear disc brake. If any drag is found, follow the procedure described below.
- 1. Remove brake pads. Refer to [BR-60, "BRAKE PAD : Removal and Installation"](#).
- 2. Press the pistons. Refer to [BR-60, "BRAKE PAD : Removal and Installation"](#).
- 3. Install brake pads. Refer to [BR-60, "BRAKE PAD : Removal and Installation"](#).
- 4. Depress the brake pedal several times.
- 5. Check a drag of rear disc brake again. When any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-65, "BRAKE CALIPER ASSEMBLY : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage. Refer to [BR-19, "BRAKE PAD : Inspection and Adjustment"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[LHD]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:0000000010838545

Unit: mm (in)

| | | | |
|-----------------|----------------------------------|---|---|
| | Caliper type | 1 piston type | 2 piston type |
| Front brake | Cylinder bore diameter | 60.33 (2.3752) | 44.45 × 2 (1.7500 × 2) |
| | Pad length × width × thickness | 123.6 × 47.5 × 10.5 (4.87 × 1.870 × 0.413) | 133.6 × 48.5 × 10.0 (5.26 × 1.909 × 0.39) |
| | Rotor outer diameter × thickness | 296 × 26.0 (11.65 × 1.024) | 320 × 28.0 (12.60 × 1.102) |
| Rear brake | Cylinder bore diameter | 38.2 (1.504) | |
| | Pad length × width × thickness | 82.9 × 39.8 × 9.0 (3.263 × 1.567 × 0.354) | |
| | Rotor outer diameter × thickness | 292 × 16.0 (11.50 × 0.630) | |
| Master cylinder | Cylinder bore diameter | 23.81 (0.9374) | |
| Control valve | Valve type | Electric brake force distribution | |
| Brake booster | Diaphragm diameter | 275 (10.83) | |
| | Recommended brake fluid | Refer to MA-23, "Fluids and Lubricants" . | |

Brake Pedal

INFOID:0000000010838546

Unit: mm (in)

| Item | Standard |
|---|-------------------------------|
| Brake pedal height | 175.9 – 185.9 (6.93 – 7.32) |
| Depressed brake pedal height [Depressing 490 N (50 kg, 110 lb) while turning the engine ON] | 75.0 (2.95) or more |
| Clearance between stop lamp switch and brake pedal position switch (with ASCD) threaded end and the brake pedal lever | 0.20 – 1.96 (0.0079 – 0.0772) |
| Brake pedal play | 3 – 11 (0.12 – 0.43) |

Brake Booster

INFOID:0000000010838547

Unit: mm (in)

| Item | Standard |
|------------------|-------------------------------|
| Input rod length | 158.95 – 160.45 (6.26 – 6.32) |

Front Disc Brake

INFOID:0000000010838548

Unit: mm (in)

| Item | | Limit | |
|--------------------|---|----------------|----------------|
| Brake caliper type | | 1 piston type | 2 piston type |
| Brake pad | Wear thickness | 2.0 (0.079) | 2.0 (0.079) |
| Disc rotor | Wear thickness | 24.0 (0.945) | 26.0 (1.0236) |
| | Thickness variation (measured at 8 positions) | 0.020 (0.0008) | 0.020 (0.0008) |
| | Runout (with it attached to the vehicle) | 0.035 (0.0014) | 0.035 (0.0014) |

Rear Disc Brake

INFOID:0000000010838549

Unit: mm (in)

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[LHD]

| Item | | Limit |
|------------|---|----------------|
| Brake pad | Wear thickness | 2.0 (0.079) |
| Disc rotor | Wear thickness | 14.0 (0.551) |
| | Thickness variation (measured at 8 positions) | 0.020 (0.0008) |
| | Runout (with it attached to the vehicle) | 0.070 (0.0028) |

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011022310

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000011022309

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition power source and accessory power source to the OFF, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Open driver door.
3. Turn the ignition switch to the ON position.
(At this time, the steering lock will be released.)
4. Turn the ignition switch to OFF position with driver door open.
5. Wait for 3 minutes or longer with driver door open.

NOTE:

- Do not close driver door because the steering wheel locks when driver door is closed.

PRECAUTIONS

[RHD]

< PRECAUTION >


- The auto acc function is adapted to this vehicle. For this reason, even when the ignition switch is turned to OFF position, the accessory power source does not turn OFF and continues to be supplied for a certain amount of time.

6. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
7. Perform the necessary repair operation.
8. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from OFF position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
9. Perform self-diagnosis check of all control units using CONSULT.

Precaution for Procedure without Cowl Top Cover

INFOID:0000000011022308

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precautions for Removing Battery Terminal

INFOID:0000000011062270

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.
2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine : 20 minutes
HRA2DDT : 12 minutes

< PRECAUTION >

- K9K engine : 4 minutes
- M9R engine : 4 minutes
- R9M engine : 4 minutes
- V9X engine : 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.


Precaution for Brake System

INFOID:0000000010838554

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

- Brake fluid use refer to [MA-6, "General Maintenance"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Always confirm the specified tightening torque when installing the brake pipes.
- After pressing the brake pedal more deeply or harder than normal driving, such as air bleeding, check each item of brake pedal.
- Always clean with new brake fluid when cleaning the master cylinder, brake caliper and other components.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a flare nut torque wrench (A).
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.
- Burnish the brake contact surfaces after refinishing or replacing rotors, after replacing pads, or if a soft pedal occurs at very low mileage.
- Front brake pad: Refer to [BR-81, "BRAKE PAD : Inspection and Adjustment"](#).
- Front disc rotor: Refer to [BR-81, "DISC ROTOR : Inspection and Adjustment"](#).
- Rear brake pad: Refer to [BR-83, "BRAKE PAD : Inspection and Adjustment"](#).
- Rear disc rotor: Refer to [BR-83, "DISC ROTOR : Inspection and Adjustment"](#).



JPFI0061ZZ

PREPARATION

[RHD]



<PREPARATION>

PREPARATION

PREPARATION

Commercial Service Tool

INFOID:0000000010838555

| Tool name | Description |
|----------------------|---|
| Handy vacuum pump |  ZZC1313D <ul style="list-style-type: none">• Air tight• Inspection of check valve |
| Brake caliper wrench |  NNFIA0040ZZ <ul style="list-style-type: none">Return the piston |
| Pick tool |  JMJIA0490ZZ <ul style="list-style-type: none">Removing piston seal and piston boot |

Lubricant or/and Sealant

INFOID:0000000010838556

| Name | Description | Note |
|---|-------------------------------|---|
| Multi-purpose grease | Clevis pin of brake pedal | — |
| Polyglycol ether based lubricant | • Master cylinder assembly | — |
| MOLYKOTE® AS880N or silicone-based grease | • Front brake | Molykote is a registered of Dow Corning Corporation |
| MOLYKOTE® 7439 or equivalent | • Front brake • Rear brake | Molykote is a registered of Dow Corning Corporation |
| Rubber grease | • Front brake • Rear brake | — |

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

SYSTEM

WARNING/INDICATOR/CHIME LIST

WARNING/INDICATOR/CHIME LIST : Warning Lamp/Indicator Lamp

INFOID:0000000010838557

| Name | Design | Layout/Function |
|--------------------|---|--|
| Brake warning lamp |  | <p>For layout: Refer to MWI-10, "METER SYSTEM : Design".</p> <p>For function: Refer to MWI-26, "WARNING LAMPS/INDICATOR LAMPS : Brake Warning Lamp (Red)".</p> |

A

B

C

D

E

BR

G

H

I

J

K

L

M

N

O

P

SYMPTOM DIAGNOSIS**NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING****NVH Troubleshooting Chart**

INFOID:0000000010838558

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

| Reference page | | | Pads damaged | Pads uneven wear | Shims damaged | Rotor imbalance | Rotor damage | Rotor runout | Rotor deformation | Rotor deflection | Rotor rust | Rotor thickness variation | AXLE AND SUSPENSION | NVH in FAX, RAX and FSU, RSU section | TIRE | NVH in WT section | ROAD WHEEL | NVH in WT section | DRIVE SHAFT | NVH in FAX section | STEERING | NVH in ST section | | |
|------------------------------------|-------|----------------|--------------|------------------|---------------|-----------------|--------------|--------------|-------------------|------------------|------------|---------------------------|---------------------|--------------------------------------|------|-------------------|------------|-------------------|-------------|--------------------|----------|-------------------|---|--|
| Possible cause and SUSPECTED PARTS | | | | | | | | | | | | | | | | | | | | | | | | |
| Symptom | BRAKE | Noise | × | × | × | × | × | × | × | × | × | × | × | × | × | × | × | × | × | × | × | × | × | |
| | | Shake | | | | × | | | | | | | | | | | | | | | | | | |
| | | Shimmy, Judder | | | | × | × | × | × | × | × | × | | | | | | | | | | | | |

x: Applicable

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

BRAKE PEDAL

Inspection and Adjustment

INFOID:0000000010838559

INSPECTION


Brake Pedal Height

Check the height (H_1) between the dash lower panel ① and the brake pedal upper surface.

H₁ : Refer to [BR-127, "Brake Pedal"](#).

CAUTION:

Remove the floor carpet.



Stop Lamp Switch and Brake Pedal Position Switch (with ASCD).

Check the clearance (C) among the brake pedal bracket ① and the stop lamp switch and brake pedal position switch (with ASCD) ② threaded end.


C : Refer to [BR-127, "Brake Pedal"](#).

CAUTION:

The stop lamp must turn off when the brake pedal is released.

NOTE:


Pull the brake pedal pad to make the clearance between the stop lamp switch and brake pedal position switch (with ASCD) threaded end and the brake pedal lever.



Brake Pedal Play

Press the brake pedal. Check the brake pedal play (A) (stroke until fluid pressure occurs).

A : Refer to [BR-127, "Brake Pedal"](#).




Depressed Brake Pedal Height

Check the height between the dash lower panel ① and the brake pedal upper surface (H_2) when depressing the brake pedal at 490 N (50 kg, 110 lb) while turning engine ON.

H₂ : Refer to [BR-127, "Brake Pedal"](#).

CAUTION:

Remove the floor carpet.



ADJUSTMENT

BRAKE PEDAL

[RHD]

< PERIODIC MAINTENANCE >

Brake Pedal Height

Perform the following procedure when brake pedal height is not within the specified value because brake pedal height is not adjustable.

1. Check input rod length. Refer to [BR-99, "Removal and installation"](#).
2. Replace brake pedal assembly when input rod length is within specified value.

Stop Lamp Switch and Brake Pedal Position Switch (with ASCD).


1. Remove instrument lower panel. Refer to [IP-41, "Removal and Installation"](#).
2. Disconnect the harness connector from stop lamp switch and brake pedal position switch (with ASCD).
3. Loosen the stop lamp switch and brake pedal position switch (with ASCD) 45° counterclockwise.
4. Press-fit the stop lamp switch and brake position switch (with ASCD) ② until the stop lamp switch and brake pedal position switch (with ASCD) hits the brake pedal bracket ① 45° clockwise while pulling the brake pedal pad slightly.

CAUTION:

- The clearance (C) between the brake pedal bracket and stop lamp switch and brake pedal position switch (with ASCD) threaded end must be the specified value.

C : Refer to [BR-127, "Brake Pedal"](#).

- The stop lamp must be turned off when the brake pedal is released.




Depressed Brake Pedal Height

1. Perform the air bleeding. Refer to [BR-78, "Bleeding Brake System"](#).
2. Check the height between the dash lower panel ① and the brake pedal upper surface (H₂) when depressing the brake pedal at 490 N (50 kg, 110 lb) while turning engine ON.

H₂ : Refer to [BR-127, "Brake Pedal"](#).

CAUTION:

Remove the floor carpet.




< PERIODIC MAINTENANCE >

BRAKE FLUID**Inspection**

INFOID:0000000010838560

BRAKE FLUID LEVEL

- Check that the brake fluid level in the reservoir tank is within the standard (between MAX – MIN lines).
- Visually check for any brake fluid leakage around the reservoir tank.
- Check the brake system for any leakage if the fluid level is extremely low (lower than MIN).
- Check the brake system for fluid leakage if the warning lamp remains illuminated even after the parking brake is released.
- Check the reservoir tank for the mixing of foreign matter (e.g. dust) and oils other than brake fluid.




JPFIA0007ZZ

BRAKE LINE

1. Check brake line (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.
2. Depress the brake pedal with a force of 785 N (80 kg, 176 lb) and hold down the pedal for approximately 5 seconds with the engine running. Check for any fluid leakage.

CAUTION:

Retighten the applicable connection to the specified torque and repair any abnormal (damaged, worn or deformed) part if any brake fluid leakage is present.



SBR389C


Draining

INFOID:0000000010838561

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing work.

1. Connect a vinyl tube to the bleed valve.
2. Depress the brake pedal and loosen the bleeder valve to gradually discharge brake fluid.



BRA0007D

Refilling

INFOID:0000000010838562

CAUTION:

- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing work.

< PERIODIC MAINTENANCE >

- **Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.**


1. Check that there is no foreign material in the reservoir tank, and refill with new brake fluid.

CAUTION:

- **Never reuse drained brake fluid.**
- **Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.**

2. Loosen the bleeder valve, slowly depress the brake pedal to the full stroke, and then release the pedal. Repeat this operation at intervals of 2 or 3 seconds until new brake fluid is discharged. Then close the bleeder valve with the brake pedal depressed. Repeat the same work on each wheel.

3. Perform the air bleeding. Refer to [BR-78, "Bleeding Brake System".](#)



PFIA0403J

Bleeding Brake System

INFOID:000000010838563

CAUTION:

- **Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.**
- **Monitor the fluid level in the reservoir tank while performing the air bleeding**
- **Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.**
- **Never allow foreign matter (e.g. dust) and oil other than brake fluid to enter the reservoir tank.**

1. Connect a vinyl tube to the bleeder valve of the rear left brake.
2. Fully depress the brake pedal 4 to 5 times.
3. Loosen the bleeder valve and bleed air with the brake pedal depressed, and then quickly tighten the bleeder valve.
4. Repeat steps 3 and 4 until all of the air is out of the brake line.
5. In case of rear brake caliper with electric parking brake system, operate parking brake 5 times to bleed the air.
6. Tighten the bleeder valve to the specified torque.
 - Front disc brake (1 piston type) : Refer to [BR-110, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Exploded View".](#)
 - Front disc brake (2 piston type) : Refer to [BR-115, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Exploded View".](#)
 - Rear disc brake: Refer to [BR-122, "BRAKE CALIPER ASSEMBLY : Exploded View".](#)
7. Perform steps 2 to 6. Occasionally fill with the brake fluid in order to keep it in the reservoir tank at least half of MAX line. Bleed air in the following order: rear right brake → front left brake → rear left brake → and front right brake in order.
8. Check that the fluid level in the reservoir tank is within the specified range after air bleeding. Refer to [BR-77, "Inspection".](#)
9. Check each item of brake pedal. Adjust it if the measurement value is not the standard. Refer to [BR-75, "Inspection and Adjustment".](#)

< PERIODIC MAINTENANCE >

BRAKE MASTER CYLINDER

Inspection

INFOID:0000000010838564

FLUID LEAK

Check for brake fluid leakage from the master cylinder mounting face, reservoir tank mounting face and brake tube connections.

A

B

C

D

E

BR

G

H

I

J

K

L

M

N

O

P

< PERIODIC MAINTENANCE >

BRAKE BOOSTER**Inspection**

INFOID:0000000010838565

OPERATION

Depress the brake pedal several times at 5-second intervals with the engine stopped. Start the engine with the brake pedal fully depressed. Check that the clearance between brake pedal and dash lower panel decreases.

AIR TIGHT

1. Run the engine at idle for 1 minute to apply vacuum to the brake booster, and stop the engine.
2. Depress the brake pedal several times at 5-second intervals until the accumulated vacuum is released to atmospheric pressure. Check that the clearance between brake pedal and dash lower panel gradually increases each time the brake pedal is depressed when performing this operation.
3. Depress the brake pedal with the engine running. Then stop the engine while holding down the brake pedal. Check that the brake pedal stroke does not change after holding down the brake pedal for 30 seconds or more.

< PERIODIC MAINTENANCE >


FRONT DISC BRAKE**BRAKE PAD****BRAKE PAD : Inspection and Adjustment**

INFOID:0000000010838566

INSPECTION

Check brake pad wear thickness from an inspection hole on cylinder body. Check using a scale if necessary.

Wear thickness : Refer to [BR-127, "Front Disc Brake"](#).

**ADJUSTMENT**

Burnish contact surfaces between disc rotor and brake pads according to the following procedure after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pads and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.

DISC ROTOR**DISC ROTOR : Inspection and Adjustment**

INFOID:0000000010838567

INSPECTION**Appearance**

Check surface of disc rotor for uneven wear, cracks, and serious damage. Replace it if necessary.


- For 2WD, refer to [FAX-11, "Removal and Installation"](#).
- For 4WD, refer to [FAX-72, "Removal and Installation"](#).

Runout

1. Fix the disc rotor to the wheel hub and bearing assembly with wheel nuts (2 points at least).
2. Check the wheel bearing axial end play.
 - For 2WD, refer to [FAX-16, "Inspection"](#).
 - For 4WD, refer to [FAX-77, "Inspection"](#).
3. Inspect the runout with a dial indicator to measure at 10 mm (0.39 in) inside the disc edge.

Runout (with it attached to the vehicle) : Refer to [BR-127, "Front Disc Brake"](#).

4. Find the installation position that has a minimum runout by shifting the disc rotor-to-wheel hub and bearing assembly installation position by one hole at a time if the runout exceeds the limit value.
5. Refinish the disc rotor if the runout is outside the limit even after performing the above operation.

CAUTION:

FRONT DISC BRAKE

[RHD]

< PERIODIC MAINTENANCE >

- Check in advance that the thickness of the disc rotor is wear thickness + 0.3 mm (0.012 in) or more.
- If the thickness is less than wear thickness + 0.3 mm (0.012 in), replace the disc rotor.
- For 2WD, refer to [FAX-11, "Removal and Installation"](#).
- For 4WD, refer to [FAX-72, "Removal and Installation"](#).


Wear thickness : Refer to [BR-127, "Front Disc Brake"](#).

Thickness

Check the thickness of the disc rotor using a micrometer. Replace the disc rotor if the thickness is below the wear limit.

- For 2WD, refer to [FAX-11, "Removal and Installation"](#).
- For 4WD, refer to [FAX-72, "Removal and Installation"](#).

Wear thickness : Refer to [BR-127, "Front Disc Brake"](#).



ADJUSTMENT

Burnish contact surfaces between disc rotors and brake pads according to the following procedure after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pad and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.

< PERIODIC MAINTENANCE >


REAR DISC BRAKE**BRAKE PAD****BRAKE PAD : Inspection and Adjustment**

INFOID:0000000010838568

INSPECTION

Check brake pad wear thickness from an inspection hole on cylinder body. Check using a scale if necessary.

Wear thickness : Refer to [BR-128, "Rear Disc Brake"](#).

**ADJUSTMENT**

Burnish contact surfaces between disc rotor and brake pads according to the following procedure after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pads and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.

DISC ROTOR**DISC ROTOR : Inspection and Adjustment**

INFOID:0000000010838569

INSPECTION**Appearance**

Check surface of disc rotor for uneven wear, cracks, and serious damage. Replace it if necessary.


- For 2WD, refer to [RAX-7, "Removal and Installation"](#).
- For 4WD, refer to [RAX-18, "Removal and Installation"](#).

Runout

1. Fix the disc rotor to the wheel hub and bearing assembly with wheel nuts (2 points at least).
2. Check the wheel bearing axial end play.
 - For 2WD, refer to [RAX-9, "Inspection"](#).
 - For 4WD, refer to [RAX-21, "Inspection"](#).
3. Inspect the runout with a dial indicator to measure at 10 mm (0.39 in) inside the disc edge.

Runout (with it attached to the vehicle) : Refer to [BR-128, "Rear Disc Brake"](#).

4. Find the installation position that has a minimum runout by shifting the disc rotor-to-wheel hub and bearing assembly installation position by one hole at a time if the runout exceeds the limit value.
5. Refinish the disc rotor if the runout is outside the limit even after performing the above operation.

CAUTION:

SBR019B

REAR DISC BRAKE

[RHD]

< PERIODIC MAINTENANCE >

- Check in advance that the thickness of the disc rotor is wear thickness + 0.3 mm (0.012 in) or more.
- If the thickness is less than wear thickness + 0.3 mm (0.012 in), replace the disc rotor.
- For 2WD, refer to [RAX-7, "Removal and Installation"](#).
- For 4WD, refer to [RAX-18, "Removal and Installation"](#).


Wear thickness : Refer to [BR-128, "Rear Disc Brake"](#).

Thickness

Check the thickness of the disc rotor using a micrometer. Replace the disc rotor if the thickness is below the wear limit. .

- For 2WD, refer to [RAX-7, "Removal and Installation"](#).
- For 4WD, refer to [RAX-18, "Removal and Installation"](#).

Wear thickness : Refer to [BR-128, "Rear Disc Brake"](#).



ADJUSTMENT

Burnish contact surfaces between disc rotors and brake pads according to the following procedure after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage.

CAUTION:

- Be careful of vehicle speed because the brake does not operate firmly/securely until pad and disc rotor are securely fitted.
- Only perform this procedure under safe road and traffic conditions. Use extreme caution.

1. Drive vehicle on straight, flat road.
2. Depress brake pedal with the power to stop vehicle within 3 to 5 seconds until the vehicle stops.
3. Drive without depressing brake for a few minutes to cool the brake.
4. Repeat steps 1 to 3 until pad and disc rotor are securely fitted.


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

BRAKE PEDAL

Exploded View

INFOID:0000000010838570



① Clevis pin

② Brake pedal assembly

③ Brake pedal pad

④ Snap pin

⑤ Clip

⑥ Stop lamp switch

⑦ Brake pedal position switch (with ASCD)

: Apply multi-purpose grease.

: N·m (kg·m, ft·lb)


: Always replace after every disassembly.

Removal and Installation

INFOID:0000000010838571

REMOVAL

1. Remove instrument lower panel. Refer to [IP-41, "Removal and Installation"](#).
2. Disconnect the stop lamp switch and the brake pedal position switch (with ASCD) harness connectors.
3. Rotate the stop lamp switch and the brake pedal switch (with ASCD) ① counterclockwise to remove.




BRAKE PEDAL

[RHD]

< REMOVAL AND INSTALLATION >

4. Disconnect the accelerator pedal harness connector.
5. Remove snap pin ① and clevis pin ② from clevis of brake booster ③.



JPFIA0816ZZ

6. Remove the brake pedal assembly.

CAUTION:

Hold the brake booster and master cylinder assembly so as not to drop out or contact them other parts.

7. Remove the accelerator pedal from the brake pedal assembly. Refer to [ACC-4, "Removal and Installation".](#)
8. Perform inspection after removal. Refer to [BR-86, "Inspection and Adjustment".](#)

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never reuse the clevis pin and snap pin.
- Apply the multi-purpose grease to the clevis pin and the mating faces. (Not necessary if grease has been already applied)

NOTE:

The clevis pin may be inserted in either direction.

- Never impact brake pedal such as drop and interference with tools and parts.
- Replace brake pedal when impacting brake pedal.
- Perform adjustment after installation. Refer to [BR-86, "Inspection and Adjustment".](#)

Inspection and Adjustment

INFOID:0000000010838572


INSPECTION AFTER REMOVAL

Check for the following items and replace the brake pedal assembly if necessary.

- Check rivet ① for deformation, crack, and damage.
- Check the brake pedal for bend, damage, and cracks on the welded parts.

CAUTION:

Never loose bolt ①.




JSFIA2250ZZ

BRAKE PEDAL

[RHD]

< REMOVAL AND INSTALLATION >

- Check clevis pin and plastic stopper **A** for damage and deformation. Replace clevis pin if necessary.



ADJUSTMENT AFTER INSTALLATION

- Adjust each item of brake pedal after installing the brake pedal assembly to the vehicle. Refer to [BR-75, "Inspection and Adjustment"](#).
- Perform the release position learning of the accelerator pedal. Refer to [EC-961, "Work Procedure"](#).

A
B
C
D

BR

G
H
I
J

K
L
M
N

O
P


< REMOVAL AND INSTALLATION >

BRAKE PIPING

FRONT

FRONT : Exploded View

INFOID:0000000010838573



| | | |
|---|----------------------------|--------------|
| ① Brake booster | ② Master cylinder assembly | ③ Brake tube |
| ④ ABS actuator and electric unit (control unit) | ⑤ Connector bracket | ⑥ Connector |
| ⑦ Brake tube bracket | ⑧ Lock plate | ⑨ Brake hose |
| ⑩ Union bolt | ⑪ Copper washer | |
| Ⓐ To rear brake tube | | |

◆, ●, ▲: Indicates that the part is connected at points with same symbol in actual vehicle.

Ⓐ: N·m (kg·m, ft·lb)

Ⓑ: N·m (kg·m, in·lb)

ⓧ: Always replace after every disassembly.

BRAKE PIPING

< REMOVAL AND INSTALLATION >


[RHD]

FRONT : Hydraulic Piping

INFOID:0000000010838574

A B C D E

SEC. 462



JSFIA2427ZZ

FRONT : Removal and Installation

INFOID:0000000010828575

REMOVAL

CAUTION:

Caution:


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.

1. Remove tires. Refer to [WT-61, "Removal and Installation"](#).
2. Drain brake fluid. Refer to [BR-77, "Draining"](#).

3. Loosen the flare nut ① with a flare nut wrench (A) and separate the brake tube ② from the brake hose ③.

CAUTION:

- Never scratch the flare nut and the brake tube.
- Never bend sharply, twist or strongly pull out the brake hoses and tubes.
- Cover open end of brake tubes and hoses when disconnecting to prevent entrance of dirt.




BRAKE PIPING

[RHD]

< REMOVAL AND INSTALLATION >

4. Remove the union bolt ① and copper washers ②, and remove the brake hose ③ from the brake caliper assembly.
5. Remove the lock plate ④ and remove the brake hose.



INSTALLATION

CAUTION:


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.
- Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.

1. Assemble the union bolt ① and the copper washer ② to the brake hose.

CAUTION:

Never reuse the copper washer.


2. Align the brake hose pin ④ with the brake caliper assembly projection ⑤, and tighten the union bolt to the specified torque.



3. Install the brake tube ② to the brake hose ①, temporarily tighten the flare nut ③ by hand until it does not rotate further, and fix the brake hose to the bracket ⑤ with the lock plate ④.

CAUTION:

Check that all brake hoses and brake tubes are not twisted and bent.



4. Tighten the flare nut to the specified torque with a flare nut torque wrench (A).

CAUTION:

Never scratch the flare nut and the brake tube.


5. Refill with new brake fluid and perform the air bleeding. Refer to [BR-77, "Refilling"](#).

CAUTION:

Never reuse drained brake fluid.

6. Install tires. Refer to [WT-61, "Removal and Installation"](#).

7. Perform inspection after installation. Refer to [BR-91, "FRONT : Inspection"](#).



BRAKE PIPING

< REMOVAL AND INSTALLATION >

[RHD]

FRONT : Inspection

INFOID:0000000010838576

INSPECTION AFTER INSTALLATION

1. Check the brake hoses and tubes for the following: no scratches; no twist and deformation; no interference with other components when steering the steering wheel; no looseness at connections.

CAUTION:

Clearance with brake hose and each parts being secured more than 10 mm (0.39 in) in unladen condition.*

***: Fuel, engine coolant and lubricant are quantity to specified. Spare tire, jack, hand tools and mats are brought out of vehicle.**

2. Depress the brake pedal with a force of 785 N (80 kg, 176 lb) and hold down the pedal for approximately 5 seconds with the engine running. Check for any fluid leakage.


CAUTION:

Retighten the applicable connection to the specified torque and repair any abnormal (damaged, worn or deformed) part if any brake fluid leakage is present.

REAR

REAR : Exploded View

INFOID:0000000010838577




| | | | | | |
|---|--------------------|---|--------------------|---|--------------------|
| ① | Brake tube | ② | Lock plate | ③ | Brake hose |
| ④ | Union bolt | ⑤ | Copper washer | ⑥ | Brake tube bracket |
| ⑦ | Brake tube bracket | | | | |
| Ⓐ | To connector | Ⓑ | To rear brake hose | Ⓒ | Floor side |
| Ⓓ | Caliper side | | | | |

 : N·m (kg·m, ft-lb)

 · N·m (kg·m, in·lb)

 Always replace after every disassembly.



| | | |
|---|----------------------------|--------------------|
| ① Brake booster | ② Master cylinder assembly | ③ Front disc brake |
| ④ ABS actuator and electric unit (control unit) | ⑤ Connector | ⑥ Rear disc brake |
| Ⓐ Brake tube | Ⓑ Brake hose | |
| ○: Flare nut | | |
| ■: Union bolt | | |

REAR : Removal and Installation

INFOID:0000000010838579

REMOVAL


CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.
- Wipe off immediately when attaching brake fluid with disc rotor and caliper assembly.

1. Remove tires. Refer to [WT-61, "Removal and Installation"](#).
2. Drain brake fluid. Refer to [BR-77, "Draining"](#).
3. Loosen the flare nut ① with a flare nut wrench (A) and separate the brake tube ② from the hose ③.

CAUTION:

- Never scratch the flare nut and the brake tube.
- Never bend sharply, twist or strongly pull out the brake hoses and tubes.
- Cover open end of brake tubes and hoses when disconnecting to prevent entrance of dirt.



4. Disconnect the lock plate ⑤, then remove the brake hose.

BRAKE PIPING

[RHD]


< REMOVAL AND INSTALLATION >

5. Loosen the flare nut ① with a flare nut wrench (A) and separate the brake tube ② from the hose ③.


CAUTION:

- Never scratch the flare nut and the brake tube.
- Never bend sharply, twist or strongly pull out the brake hoses and tubes.
- Cover open end of brake tubes and hoses when disconnecting to prevent entrance of dirt.

6. Disconnect the lock plate ④, then remove the brake hose from the brake hose bracket ⑤.



7. Remove the union bolt ① and copper washers ②, and remove the brake hose ③ from the brake caliper assembly.



INSTALLATION

CAUTION:


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Never depress the brake pedal while removing the brake hose or brake tube. If this is not complied with, brake fluid may splash.
- Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.
- Wipe off immediately when attaching brake fluid with disc rotor and caliper assembly.

1. Assemble the union bolt ① and copper washers ② to the brake hose.

CAUTION:

Never reuse the copper washer.


2. Align the brake hose L-pin ④ with the brake caliper assembly hole ⑤, and tighten the union bolt to the specified torque.



3. Install the brake hose ① to the brake tube ②, temporarily tighten the flare nut ③ by hand until it does not rotate further, and fix the brake hose to the brake hose bracket ⑤ with the lock plate ④.

CAUTION:

Check that all brake hoses and brake tubes are not twisted and bent.



BRAKE PIPING


[RHD]

< REMOVAL AND INSTALLATION >

4. Tighten the flare nut to the specified torque with a flare nut torque wrench (A).

CAUTION:


Never scratch the flare nut and the brake tube.



5. Install the brake hose ④ to the brake tube ② and the brake tube ③, temporarily tighten the flare nut ① by hand until it does not rotate further, and fix the brake hose to brake hose brackets with the lock plate ⑤.

CAUTION:

Check that all brake hoses and brake tubes are not twisted and bent.



6. Tighten the flare nut to the specified torque with a flare nut torque wrench (A).

CAUTION:

Never scratch the flare nut and the brake tube.


7. Refill with new brake fluid and perform the air bleeding. Refer to [BR-78, "Bleeding Brake System"](#).

CAUTION:

Never reuse drained brake fluid.

8. Install tires. Refer to [WT-61, "Removal and Installation"](#).

9. Perform inspection after installation. Refer to [BR-94, "REAR : Inspection"](#).



REAR : Inspection

INFOID:000000010838580

INSPECTION AFTER INSTALLATION

1. Check the brake hoses and tubes for the following: no scratches; no twist and deformation; no looseness at connections.

CAUTION:

Clearance with brake hose and each parts being secured more than 10 mm (0.39 in) in unladen condition*.

*: Fuel, engine coolant and lubricant are quantity to specified. Spare tire, jack, hand tools and mats are brought out of vehicle.

2. Depress the brake pedal with a force of 785 N (80 kg, 176 lb) and hold down the pedal for approximately 5 seconds with the engine running. Check for any fluid leakage.

CAUTION:

Retighten the applicable connection to the specified torque and repair any abnormal (damaged, worn or deformed) part if any brake fluid leakage is present.

BRAKE MASTER CYLINDER


[RHD]

< REMOVAL AND INSTALLATION >

BRAKE MASTER CYLINDER

Exploded View

INFOID:0000000010838581



① Reservoir cap

② Oil strainer

③ Reservoir tank

J

④ Grommet

⑤ Cylinder body

⑥ Screw

K

⑦ O-ring

: Apply polyglycol ether based lubricant.

: Apply brake fluid.

: N·m (kg·m, ft·lb)

: Always replace after every disassembly.

Removal and Installation

INFOID:0000000010838582

REMOVAL

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.
- Depress the brake pedal several times to release the vacuum pressure from the brake booster. Then remove the master cylinder assembly.
- Never depress the brake pedal while removing the brake tube. If this is not complied with, brake fluid may splash.

1. Perform inspection before removal. Refer to [BR-98, "Inspection"](#).
2. Drain brake fluid. Refer to [BR-77, "Draining"](#).
3. Disconnect the brake fluid level switch harness connector.

N

O

P

BRAKE MASTER CYLINDER


[RHD]

< REMOVAL AND INSTALLATION >

- Separate the brake tube from the master cylinder assembly with a flare nut wrench (A).

CAUTION:

Never scratch the flare nut and the brake tube.




JSFIA2238ZZ

- Remove the master cylinder assembly.

CAUTION:

- Never deform or bend the brake tubes.
- Never depress the brake pedal after the master cylinder assembly is removed.

- The piston (A) of the master cylinder assembly is exposed. Never damage it when removing the master cylinder.
- The piston may drop off when pulled out strongly. Never hold the piston. Hold the cylinder body when handling the master cylinder assembly.



JSFIA2239ZZ

- Remove the O-ring.


INSTALLATION

CAUTION:

Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.

Note the following, and install in the reverse order of removal.

- Never reuse the O-ring.
- Never depress the brake pedal after the master cylinder assembly is removed.
- Apply polyglycol ether based lubricant to the brake booster [see (A) in the figure] when installing the master cylinder assembly to the brake booster.




JPFIA0013ZZ

BRAKE MASTER CYLINDER


[RHD]

< REMOVAL AND INSTALLATION >

- The piston (A) of the master cylinder assembly is exposed. Never damage it when handling the master cylinder.
- Check that no dirt and dust are present on the piston before installation. Clean it with new brake fluid if necessary.
- The piston may drop off when pulled strongly. Never hold the piston. Hold the cylinder body when handling the master cylinder assembly.
- Never deform or bend the brake tubes.



- Temporarily tighten the brake tube flare nut to the master cylinder assembly by hand. Then tighten it to the specified torque with a flare nut torque wrench (A). Refer to [BR-95, "Exploded View"](#).
- Perform the air bleeding. Refer to [BR-78, "Bleeding Brake System"](#).
- Perform inspection after installation. Refer to [BR-98, "Inspection"](#).



Disassembly and Assembly

INFOID:0000000010838583

DISASSEMBLY

CAUTION:

- Never disassemble the cylinder body.
- Remove the reservoir tank only when necessary.
- Never drop parts to remove. Replace new parts when dropping.

1. Fix the master cylinder assembly to a vise.

CAUTION:

- Always set copper plates or cloth between vise grips when fixing the cylinder body to a vise.
- Never overtighten the vise.

2. Remove the reservoir tank mounting screw.

3. Remove the reservoir tank and grommet from the cylinder body.

ASSEMBLY

CAUTION:

- Never use mineral oils such as kerosene or gasoline and rubber grease during the cleaning and assembly process.
- Never allow foreign matter (e.g. dust) and oils other than brake fluid to enter the reservoir tank.
- Never drop when installing. The parts must not be reused if they are dropped.

1. Apply new brake fluid to the grommet and install it to the cylinder body.

CAUTION:

Never reuse grommets.

2. Install the reservoir tank to the cylinder body.

3. Fix the cylinder body to a vise.

CAUTION:


BRAKE MASTER CYLINDER

[RHD]

< REMOVAL AND INSTALLATION >

- Place the reservoir tank with the chamfered screw hole (➡ facing up).
- Always set copper plates or cloth between vise grips when fixing the cylinder body to a vise.
- Never overtighten the vise.

4. Tilt the reservoir tank so that a mounting screw can be fixed. Assemble with screw.



INFOID:000000010838584

Inspection

INSPECTION BEFORE REMOVAL

Check the brake fluid level switch. Refer to [BRC-159, "Component Inspection"](#).

INSPECTION AFTER INSTALLATION

Check the following items and replace if necessary.

- Check the master cylinder for deformation, twist, contact with other parts or looseness of connection.
- Check for fluid leakage from connection. Refer to [BR-91, "FRONT : Inspection"](#).

CAUTION:


If the fluid leakage is present, retighten to the specified torque. Replace parts if necessary.

< REMOVAL AND INSTALLATION >

BRAKE BOOSTER

Exploded View

INFOID:0000000010838585



① Master cylinder assembly

② Check valve

③ Vacuum sensor

④ Brake booster

⑤ Gasket

N·m (kg·m, ft·lb)

Removal and installation

INFOID:0000000010838586

REMOVAL

CAUTION:

Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.


1. Perform inspection before removal. Refer to [BR-100, "Inspection and Adjustment"](#).
2. Drain brake fluid. Refer to [BR-77, "Draining"](#).
3. Disconnect vacuum sensor harness connector.
4. Remove brake master cylinder assembly. Refer to [BR-95, "Removal and Installation"](#).
5. Remove vacuum hose from check valve. Refer to [BR-102, "Removal and Installation"](#).
6. Remove cowl top extension. Refer to [EXT-25, "Removal and Installation"](#).
7. Remove brake tube between master cylinder assembly and ABS actuator and electric unit (control unit). Refer to [BR-88, "FRONT : Exploded View"](#).

BRAKE BOOSTER

[RHD]

< REMOVAL AND INSTALLATION >

8. Remove snap pin ① and clevis pin ②.



9. Remove nuts on brake booster and brake pedal assembly.

CAUTION:

Hold the brake booster so as to avoid dropping out.

10. Remove brake booster.

CAUTION:

Never deform or bend the brake tubes.

11. Remove check valve from brake booster.

12. Remove vacuum sensor from brake booster.

13. Perform inspection after removal. Refer to [BR-100, "Inspection and Adjustment"](#).

INSTALLATION


CAUTION:

Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. For brake component parts, never wash them with water.

Note the following, and install in the reverse order of removal.

- Install check valve ① and vacuum sensor ② as shown in figure.

A : $\pm 15^\circ$
← :Vehicle upper side



- Be careful not to damage brake booster stud bolt threads. If brake booster is tilted during installation, the dash panel may damage threads.
- Never deform or bend the brake tubes when installing the brake booster.
- Always use new gasket between the brake booster and the dash panel.
- Replace clevis pin when found damage.
- Never allow foreign matter (e.g.dust) and oil other than brake fluid to enter reservoir tank.
- Perform the air bleeding. Refer to [BR-78, "Bleeding Brake System"](#).

CAUTION:

Never reuse brake fluid to drain.

- Check each item of brake pedal.

Inspection and Adjustment

INFOID:000000010838587

INSPECTION BEFORE REMOVAL

Air Tight

CAUTION:

Check the air tight condition when the master cylinder and the brake booster is installed.

1. Check the air tight use a handy vacuum pump.

< REMOVAL AND INSTALLATION >

At vacuum of -66.7 kPa (-500 mmHg , -19.69 inHg , -0.067 bar) : Vacuum should decrease within 3.3 kPa (24.8 mmHg , 0.98 inHg , 0.033 bar) for 15 seconds.

2. If the air tight condition cannot be maintained, perform the following operation.
 - a. Check the no dirt and dust are present on the brake booster and brake master cylinder mating faces. Clean it if necessary.
 - b. Check the O-ring on the master cylinder. If anything is found, replace the O-ring. Refer to [BR-95, "Removal and Installation"](#).
 - c. Check the air tight condition again. If the condition still cannot be maintained, replace the brake booster.

INSPECTION AFTER REMOVAL

Check Valve Inspection

1. Check the check valve to use a handy vacuum pump.

In the case of connecting to brake booster : Vacuum should decrease within 3.3 kPa (24.8 mmHg , 0.98 inHg , 0.033 bar) for 15 seconds at vacuum of -66.7 kPa (-500 mmHg , -19.69 inHg , -0.067 bar).

In the case of connecting to vacuum hose : Vacuum should not exist.


Input Rod Length rod Inspection

1. Check the input length (A).

① : Input rod

A : Refer to [BR-127, "Brake Booster"](#).

2. Replace the brake booster if the input rod length is not the standard.



INSPECTION AFTER INSTALLATION

Operation

Depress the brake pedal several times at 5-second intervals with the engine stopped. Start the engine with the brake pedal fully depressed. Check that the clearance between brake pedal and dash lower panel decreases.

NOTE:

A slight impact with a small click may be felt on the pedal when the brake pedal is fully depressed. this is normal phenomenon due to the brake system operation.

Air Tight

1. Run the engine at idle for 1 minute to apply vacuum to the brake booster, and stop the engine.
2. Depress the brake pedal several times at 5-second intervals until the accumulated vacuum is released to atmospheric pressure. Check that the clearance between brake pedal and dash lower panel gradually increases each time.
3. Depress the brake pedal with the engine running. Then stop the engine while holding down the brake pedal. Check that the brake pedal stroke does not change after holding down the brake pedal for 30 seconds or more.

ADJUSTMENT AFTER INSTALLATION


Perform the brake pedal adjustment after installing the brake assembly. Refer to [BR-75, "Inspection and Adjustment"](#).

< REMOVAL AND INSTALLATION >

VACUUM LINES

Exploded View

INFOID:0000000010838986



① Vacuum piping

② Clamp

③ Vacuum hose

④ Connector

⑤ Vacuum hose bracket

⑥ To vacuum pump

⑦ Paint mark

⑧ To brake booster

[Nm]: N·m (kg-m, in-lb)

Removal and Installation

INFOID:0000000010838987

REMOVAL

1. Remove engine cover. Refer to [EM-306, "Removal and Installation"](#).
2. Remove the vacuum hose and vacuum piping.
3. Perform inspection after removal. Refer to [BR-102, "Inspection"](#).

INSTALLATION

Note the following, install the vacuum hose.


- When installing vacuum hose, insert it until its tip reaches the back-end of length (A) or further as shown in the figure.

CAUTION:

Never use lubricating oil during assembly.

A : 24 mm (0.95 in) or more

- Face the paint mark of vacuum hose (built-in check valve) to upward to assemble.
- Face the paint mark of vacuum piping (intake manifold side) to upward to assemble.
- Face the other paint marks to vehicle front side to assemble.
- For clamp mounting direction (the orientation of pawl), refer to [BR-102, "Exploded View"](#).



Inspection

INFOID:0000000010838988

INSPECTION AFTER REMOVAL

Appearance

Check for correct assembly, damage and deterioration.


< REMOVAL AND INSTALLATION >

FRONT DISC BRAKE

BRAKE PAD (1 PISTON TYPE)

BRAKE PAD (1 PISTON TYPE) : Exploded View

INFOID:0000000010838594



| | | |
|------------------------------------|--------------------|----------------|
| ① Cylinder body | ② Inner shim cover | ③ Inner shim |
| ④ Inner pad (with pad wear sensor) | ⑤ Return spring | ⑥ Pad retainer |
| ⑦ Torque member | ⑧ Outer pad | ⑨ Outer shim |
| ⑩ Outer shim cover | | |

1: Apply MOLYKOTE® AS 880N or silicone-based grease.

2: Apply MOLYKOTE® 7439 or equivalent.

Q: N·m (kg·m, ft·lb)

Molykote is a registered trademark of Dow Corning Corporation.

BRAKE PAD (1 PISTON TYPE) : Removal and Installation

INFOID:0000000010838595

REMOVAL


WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Remove tires with power tool.
2. Remove lower sliding pin bolt.




FRONT DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >

- Suspend the cylinder body with suitable wire so that the brake hose will not stretch.




JPFIA0850ZZ

- Remove the brake pads, shims, shim covers and pad retainer (as a set with pad return spring) ② from the torque member ①.

CAUTION:

- Remove pad retainer together with pad return springs.
- Never deform the pad return springs and pad retainer when removing the pad retainer from the torque member.
- Never damage the piston boots.
- Never drop the brake pads, shims and shim covers.
- Remember each position of the removed brake pads.



JPFIA0118ZZ


- Remove the pad return springs ① from the pad retainer ②.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs when removing the pad return springs from the pad retainer.

- Perform inspection after removal. Refer to [BR-106, "BRAKE PAD \(1 PISTON TYPE\) : Inspection"](#).



JSFIA2329ZZ

INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

- Install the pad return springs ① to pad retainer ② if the pad return springs has been removed.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs.



JSFIA2329ZZ

FRONT DISC BRAKE


[RHD]

< REMOVAL AND INSTALLATION >

2. Apply MOLYKOTE® 7439 or equivalent to the match face Ⓐ between the pad retainers ① and torque member ② if the pad retainers has been removed.
Molykote is a registered trademark of Dow Corning Corporation.
3. Install the pad retainer (upper side with pad return spring) to torque member if the pad retainers has been removed.

CAUTION:

- Securely assemble the pad retainers so that it will not be lifted up from the torque member.
- Never deform the pad retainers and pad return springs.




4. Apply MOLYKOTE® AS880N or silicone-based grease to the matching faces Ⓐ between the shim ① and the shim cover ②, and install the shim and the shim covers to the brake pad ③.

CAUTION:


Always replace the shims and shim covers when replacing the brake pad.

Molykote is a registered trademark of Dow Corning Corporation.



5. Apply MOLYKOTE® 7439 or equivalent to the match face Ⓐ between the brake pad ① and torque member ②.


Molykote is a registered trademark of Dow Corning Corporation.



6. Install the brake pads to the torque member.

CAUTION:

Both inner and outer pads have a pad return system. Securely push the pad return spring ① into the disc rotor side of brake pad ②.



7. Install cylinder body to torque member.

CAUTION:

- Never damage the piston boot.
- When replacing brake pad with new one, check a brake fluid level in the reservoir tank because brake fluid returns to reservoir tank when pressing piston in.

NOTE:


Use a disc brake piston tool to easily press piston.

FRONT DISC BRAKE

< REMOVAL AND INSTALLATION >

[RHD]

8. Install the lower sliding pin bolt and tighten it to the specified torque.



9. Depress the brake pedal several times to check that no drag feel is present for the front disc brake. Refer to [BR-106, "BRAKE PAD \(1 PISTON TYPE\) : Inspection"](#).
10. Install tires. Refer to [WT-61, "Removal and Installation"](#).

BRAKE PAD (1 PISTON TYPE) : Inspection

INFOID:0000000010838596

INSPECTION AFTER REMOVAL

- Replace the shims and shim covers if rust is excessively attached.
- Eliminate rust on the pad return spring, pad retainers and the torque member. Replace them if rust is excessively attached.


INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.
- 1. Remove brake pads. Refer to [BR-103, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
- 2. Press the pistons. Refer to [BR-103, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
- 3. Install brake pads. Refer to [BR-103, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
- 4. Depress the brake pedal several times.
- 5. Check a drag of front disc brake again. If any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-112, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage. Refer to [BR-81, "BRAKE PAD : Inspection and Adjustment"](#).

BRAKE PAD (2 PISTON TYPE)

BRAKE PAD (2 PISTON TYPE) : Exploded View

INFOID:0000000010838969



< REMOVAL AND INSTALLATION >

| | | |
|------------------------------------|--------------------|----------------|
| ① Cylinder body | ② Inner shim cover | ③ Inner shim |
| ④ Inner pad (with pad wear sensor) | ⑤ Return spring | ⑥ Pad retainer |
| ⑦ Torque member | ⑧ Outer pad | ⑨ Outer shim |
| ⑩ Outer shim cover | | |

 1: Apply MOLYKOTE® AS 880N or silicone-based grease.

 2: Apply MOLYKOTE® 7439 or equivalent.

 N·m (kg·m, ft·lb)

Molykote is a registered trademark of Dow Corning Corporation.

BRAKE PAD (2 PISTON TYPE) : Removal and Installation

INFOID:0000000010838970

REMOVAL


WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.


CAUTION:

- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Remove tires with power tool.
2. Remove lower sliding pin bolt.




3. Suspend the cylinder body with suitable wire so that the brake hose will not stretch.



4. Remove the brake pads, shims, shim covers and pad retainer (as a set with pad return spring) ② from the torque member ①.

CAUTION:

- Remove pad retainer together with pad return springs.
- Never deform the pad return springs and pad retainer when removing the pad retainer from the torque member.
- Never damage the piston boots.
- Never drop the brake pads, shims and shim covers.
- Remember each position of the removed brake pads.



FRONT DISC BRAKE

< REMOVAL AND INSTALLATION >

[RHD]


- Remove the pad return springs ① from the pad retainer ②.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs when removing the pad return springs from the pad retainer.

- Perform inspection after removal. Refer to [BR-109, "BRAKE PAD \(2 PISTON TYPE\) : Inspection".](#)



INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

- Install the pad return springs ① to pad retainer ② if the pad return springs has been removed.

◀ : Disc rotor side

CAUTION:

Never deform the pad return springs.




- Apply MOLYKOTE® 7439 or equivalent to the match face Ⓐ between the pad retainers ① and torque member ② if the pad retainers has been removed.

Molykote is a registered trademark of Dow Corning Corporation.

- Install the pad retainer (upper side with pad return spring) to torque member if the pad retainers has been removed.

CAUTION:

- Securely assemble the pad retainers so that it will not be lifted up from the torque member.
- Never deform the pad retainers and pad return springs.




- Apply MOLYKOTE® AS880N or silicone-based grease to the matching faces Ⓐ between the shim ① and the shim cover ②, and install the shim and the shim covers to the brake pad ③.

CAUTION:

Always replace the shims and shim covers when replacing the brake pad.

Molykote is a registered trademark of Dow Corning Corporation.




FRONT DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >


5. Apply MOLYKOTE® 7439 or equivalent to the match face **A** between the brake pad **①** and torque member **②**.
Molykote is a registered trademark of Dow Corning Corporation.



6. Install the brake pads to the torque member.

CAUTION:

Both inner and outer pads have a pad return system. Securely push the pad return spring **①** into the disc rotor side of brake pad **②**.



7. Install cylinder body to torque member.


CAUTION:

- Never damage the piston boot.
- When replacing brake pad with new one, check a brake fluid level in the reservoir tank because brake fluid returns to reservoir tank when pressing piston in.

NOTE:

Use a disc brake piston tool to easily press piston.

8. Install the lower sliding pin bolt and tighten it to the specified torque.



9. Depress the brake pedal several times to check that no drag feel is present for the front disc brake. Refer to [BR-109, "BRAKE PAD \(2 PISTON TYPE\) : Inspection"](#).

10. Install tires. Refer to [WT-61, "Removal and Installation"](#).

BRAKE PAD (2 PISTON TYPE) : Inspection

INFOID:0000000010838971

INSPECTION AFTER REMOVAL

- Replace the shims and shim covers if rust is excessively attached.
- Eliminate rust on the pad return spring, pad retainers and the torque member. Replace them if rust is excessively attached.

INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.

FRONT DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >


1. Remove brake pads. Refer to [BR-107, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
2. Press the pistons. Refer to [BR-107, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
3. Install brake pads. Refer to [BR-107, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation"](#).
4. Depress the brake pedal several times.
5. Check a drag of front disc brake again. If any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-117, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage. Refer to [BR-81, "BRAKE PAD : Inspection and Adjustment"](#).

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE)

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Exploded View

INFOID:000000010838600


REMOVAL



① Brake caliper assembly

165 (17, 122) N·m (kg-m, ft-lb)

DISASSEMBLY



< REMOVAL AND INSTALLATION >

| | | |
|-----------------|--------------------|-----------------|
| ① Cap | ② Bleeder valve | ③ Cylinder body |
| ④ Piston seal | ⑤ Piston | ⑥ Piston boot |
| ⑦ Sliding pin | ⑧ Sliding pin boot | ⑨ Bushing |
| ⑩ Torque member | | |

: Apply rubber grease.

: Apply brake fluid.

: N·m (kg·m, in-lb)

: Always replace after every disassembly.

A

B

C

D

E

INFOID:000000010838601

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Removal and Installation

BR

REMOVAL

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

G

H

- Remove tires with power tool.

I

- Fix the disc rotor using wheel nuts.

J

- Drain brake fluid. Refer to [BR-77, "Draining"](#).

K

- Remove union bolt and copper washer, and separate brake hose from brake caliper assembly. Refer to [BR-89, "FRONT : Removal and Installation"](#).

L

- Remove torque member mounting bolts, and remove brake caliper assembly.

M

CAUTION:

Never drop brake pad and brake caliper assembly.

N


- Remove disc rotor.

O

- 2WD: Refer to [FAX-11, "Removal and Installation"](#).

P

- 4WD: Refer to [FAX-72, "Removal and Installation"](#).



JPFI0835ZZ

INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

Q

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.
- Never allow foreign matter (e.g.dust) and oils other than brake fluid to enter the reservoir tank.

R

- Install disc rotor.

S

- 2WD: Refer to [FAX-11, "Removal and Installation"](#).
- 4WD: Refer to [FAX-72, "Removal and Installation"](#).

T

FRONT DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >

2. Install the brake caliper assembly to the steering knuckle and tighten the torque member mounting bolts to the specified torque.

CAUTION:

Never spill or splash any grease and moisture on the brake caliper assembly mounting face, threads, mounting bolts and washers. Wipe out any grease and moisture.

3. Install brake hose and copper washers to brake caliper assembly. Refer to [BR-89, "FRONT : Removal and Installation"](#).

CAUTION:

Never reuse copper washer.

4. Refill with new brake fluid and perform the air bleeding. Refer to [BR-78, "Bleeding Brake System"](#).

CAUTION:

- Never reuse brake fluid.
- Never spill or splash brake fluid on the surface of disc rotor.

5. Check a drag of front disc brake. If any drag is found, refer to [BR-114, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Inspection"](#).

6. Install tires. Refer to [WT-61, "Removal and Installation"](#)

7. Perform inspection after installation. Refer to [BR-106, "BRAKE PAD \(1 PISTON TYPE\) : Inspection"](#).

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Disassembly and Assembly

INFOID:0000000010838602

DISASSEMBLY

NOTE:

Never remove the torque member, brake pad and pad retainers when disassembling and assembling the cylinder body.


1. Remove the sliding pin bolt, and remove the cylinder body from the torque member. Refer to [BR-103, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).

CAUTION:


Fix the brake pad at suitable tape so that the brake pad will not drop.

2. Remove sliding pins and sliding pin boots from torque member.

3. Remove bushing ① from sliding pin ②.



JPFIA0835ZZ




JPFIA0851ZZ

4. Place a wooden block as shown in the figure, and blow air from union bolt mounting hole to remove pistons and piston boots.

CAUTION:

Never get fingers caught in the pistons.




MAA0272D

FRONT DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >


5. Remove piston seals from cylinder body using seal pick tool.
CAUTION:
Be careful not to damage a cylinder inner wall.
6. Remove bleeder valve and cap.
7. Perform inspection after disassembly. Refer to [BR-114, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Inspection".](#)



JPFI0038ZZ

ASSEMBLY


1. Install bleeder valve and cap.
2. Apply new brake fluid to piston seals ①, and install them to cylinder body.
CAUTION:
Never reuse piston seals.



JPFI0039ZZ

3. Apply rubber grease to piston boots ①. Cover the piston ② end with piston boot, and then install cylinder side lip on piston boot securely into a groove on cylinder body.


CAUTION:
Never reuse piston boots.



JPFI0040ZZ

4. apply new brake fluid to pistons ①. Push piston into cylinder body by hand and push piston boot ② piston-side lip into the piston groove.

CAUTION:
Press the pistons evenly and vary the pressing point to prevent cylinder inner wall from being rubbed.




JPFI0034ZZ

FRONT DISC BRAKE

[RHD]


< REMOVAL AND INSTALLATION >

5. Apply rubber grease to mating faces Ⓐ between sliding pin ① and bushing ②, and install bushing to sliding pin.



JPFIA0836ZZ

6. Apply rubber grease to mating faces Ⓐ between sliding pins ① and sliding pin boots ②, and install sliding pins and sliding pin boots to torque member ③.
7. Install the cylinder body to tighten sliding pin bolts to the specified torque.



JPFIA0837ZZ

BRAKE CALIPER ASSEMBLY (1 PISTON TYPE) : Inspection

INFOID:0000000010838603

INSPECTION AFTER DISASSEMBLY

Check the following items and replace if necessary.

Cylinder Body

Check the cylinder inner wall for rust, wear, cracks or damage.

CAUTION:

Always clean with new brake fluid. Never clean with mineral oil such as gasoline and light oil.

Torque Member

Check the torque member for rust, wear, cracks or damage.

Pistons

Check the surface of the piston for rust, wear, cracks or damage.

CAUTION:

A piston sliding surface is plated. Never polish with sandpaper.

Sliding Pin, Sliding Pin Boot and Bushing

Check the sliding pins, sliding pin boots and bushing for rust, wear, cracks or damage.

INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.
 1. Remove brake pads. Refer to [BR-103, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
 2. Press the pistons. Refer to [BR-103, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
 3. Install brake pads. Refer to [BR-103, "BRAKE PAD \(1 PISTON TYPE\) : Removal and Installation"](#).
 4. Depress the brake pedal several times.
 5. Check a drag of front disc brake again. When any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-112, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage. Refer to [BR-81, "BRAKE PAD : Inspection and Adjustment"](#).

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE)

FRONT DISC BRAKE


[RHD]

< REMOVAL AND INSTALLATION >

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Exploded View

INFOID:000000010838972


REMOVAL



① Brake caliper assembly

: N·m (kg-m, ft-lb)

DISASSEMBLY



① Cap

② Bleeder valve

③ Cylinder body

④ Sliding pin

⑤ Sliding pin boot

⑥ Bushing

⑦ Piston seal

⑧ Piston

⑨ Piston boot

⑩ Torque member

: Apply rubber grease.

: Apply brake fluid.

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

< REMOVAL AND INSTALLATION >

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Removal and Installation

INFOID:000000010838973

REMOVAL

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.


CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Remove tires with power tool.
2. Fix the disc rotor using wheel nuts.
3. Drain brake fluid. Refer to [BR-77, "Draining"](#).
4. Remove union bolt and copper washer, and separate brake hose from brake caliper assembly. Refer to [BR-89, "FRONT : Removal and Installation"](#).
5. Remove torque member mounting bolts, and remove brake caliper assembly.

CAUTION:
Never drop brake pad and brake caliper assembly.

6. Remove disc rotor.
 - 2WD: Refer to [FAX-11, "Removal and Installation"](#).
 - 4WD: Refer to [FAX-72, "Removal and Installation"](#).



JPFIA0835ZZ

INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.
- Never allow foreign matter (e.g.dust) and oils other than brake fluid to enter the reservoir tank.

1. Install disc rotor.
 - 2WD: Refer to [FAX-11, "Removal and Installation"](#).
 - 4WD: Refer to [FAX-72, "Removal and Installation"](#).
2. Install the brake caliper assembly to the steering knuckle and tighten the torque member mounting bolts to the specified torque.


CAUTION:
Never spill or splash any grease and moisture on the brake caliper assembly mounting face, threads, mounting bolts and washers. Wipe out any grease and moisture.

3. Install brake hose and copper washers to brake caliper assembly. Refer to [BR-89, "FRONT : Removal and Installation"](#).

CAUTION:
Never reuse copper washer.

4. Refill with new brake fluid and perform the air bleeding. Refer to [BR-78, "Bleeding Brake System"](#).

CAUTION:



JPFIA0835ZZ

< REMOVAL AND INSTALLATION >

- Never reuse brake fluid.
- Never spill or splash brake fluid on the surface of disc rotor.

5. Check a drag of front disc brake. If any drag is found, refer to [BR-119, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection".](#)
6. Install tires. Refer to [WT-61, "Removal and Installation"](#)
7. Perform inspection after installation. Refer to [BR-119, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection".](#)

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Disassembly and Assembly

INFOID:0000000010838974

DISASSEMBLY

NOTE:


Never remove the torque member, brake pad and pad retainers when disassembling and assembling the cylinder body.

1. Remove the sliding pin bolt, and remove the cylinder body from the torque member. Refer to [BR-107, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation".](#)

CAUTION:

Fix the brake pad at suitable tape so that the brake pad will not drop.


2. Remove sliding pins and sliding pin boots from torque member.
3. Remove bushing ① from sliding pin ②.



4. Place a wooden block as shown in the figure, and blow air from union bolt mounting hole to remove pistons and piston boots.

CAUTION:

Never get fingers caught in the pistons.




5. Remove piston seals from cylinder body using seal pick tool.

CAUTION:

Be careful not to damage a cylinder inner wall.

6. Remove bleeder valve and cap.
7. Perform inspection after disassembly. Refer to [BR-119, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection".](#)



ASSEMBLY

1. Install bleeder valve and cap.

FRONT DISC BRAKE


[RHD]

< REMOVAL AND INSTALLATION >

2. Apply new brake fluid to piston seals ①, and install them to cylinder body.

CAUTION:

Never reuse piston seals.




JPFIA0032ZZ

3. Apply rubber grease to piston boots ①. Cover the piston ② end with piston boot, and then install cylinder side lip on piston boot securely into a groove on cylinder body.

CAUTION:

Never reuse piston boots.




JPFIA0033ZZ

4. apply new brake fluid to pistons ①. Push piston into cylinder body by hand and push piston boot ② piston-side lip into the piston groove.


CAUTION:

Press the pistons evenly and vary the pressing point to prevent cylinder inner wall from being rubbed.



JPFIA0034ZZ

5. Apply rubber grease to mating faces Ⓐ between sliding pin ① and bushing ②, and install bushing to sliding pin.




JSFIA0497ZZ

FRONT DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >

6. Apply rubber grease to mating faces **A** between sliding pins **①** and sliding pin boots **②**, and install sliding pins and sliding pin boots to torque member **③**.
7. Install the cylinder body to tighten sliding pin bolts to the specified torque.



INFOID:000000010838975

BRAKE CALIPER ASSEMBLY (2 PISTON TYPE) : Inspection

A
B
C
D
E

BR

INSPECTION AFTER DISASSEMBLY

Check the following items and replace if necessary.

Cylinder Body

Check the cylinder inner wall for rust, wear, cracks or damage.

CAUTION:

Always clean with new brake fluid. Never clean with mineral oil such as gasoline and light oil.

G

Torque Member

Check the torque member for rust, wear, cracks or damage.

H

Pistons

Check the surface of the piston for rust, wear, cracks or damage.

I

CAUTION:

A piston sliding surface is plated. Never polish with sandpaper.

J

Sliding Pin, Sliding Pin Boot and Bushing

Check the sliding pins, sliding pin boots and bushing for rust, wear, cracks or damage.

K

INSPECTION AFTER INSTALLATION

- Check a drag of front disc brake. If any drag is found, follow the procedure described below.
 1. Remove brake pads. Refer to [BR-107, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation".](#)
 2. Press the pistons. Refer to [BR-107, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation".](#)
 3. Install brake pads. Refer to [BR-107, "BRAKE PAD \(2 PISTON TYPE\) : Removal and Installation".](#)
 4. Depress the brake pedal several times.
 5. Check a drag of front disc brake again. When any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-117, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Disassembly and Assembly".](#)
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage. Refer to [BR-81, "BRAKE PAD : Inspection and Adjustment".](#)

L

M

N

O

P

REAR DISC BRAKE

< REMOVAL AND INSTALLATION >


[RHD]

REAR DISC BRAKE

BRAKE PAD

BRAKE PAD : Exploded View

INFOID:0000000010838976



| | | | | | |
|---|----------------------------------|---|------------------|---|------------|
| ① | Cylinder body | ② | Inner shim cover | ③ | Inner shim |
| ④ | Inner pad (with pad wear sensor) | ⑤ | Torque member | ⑥ | Outer pad |
| ⑦ | Outer shim | ⑧ | Outer shim cover | | |

 1: Apply rubber grease.

 2 : Apply MOLYKOTE® AS 880N or silicone-based grease.

• N·m (kg·m, ft-lb)

Molykote is a registered trademark of Dow Corning Corporation.

BRAKE PAD · Removal and Installation

ANSWER

REMOVAL

WARNING:

WARNING: Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.
 1. Release the parking brake.
 2. Must be performed additional service when replacing brake pad. Refer to [PB-52, "Work Procedure"](#).
 3. Remove tires.

REAR DISC BRAKE

[RHD]


< REMOVAL AND INSTALLATION >

4. Remove lower sliding pin bolt.



A
B
C
D
E

5. Suspend the cylinder body with suitable wire so that the brake hose and the electric parking brake harness will not stretch.



BR
G
H

6. Remove the brake pads, shims and shim covers.

CAUTION:

- Never damage the piston boots.
- Never drop the brake pads, shims and shim covers.
- Remember each position of the removed brake pads.
- Never damage the electric parking brake harness and bracket.

7. Perform inspection after removal. Refer to [BR-122, "BRAKE PAD : Inspection and Adjustment"](#).

INSTALLATION

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Apply MOLYKOTE® AS880N or silicone-based grease to the mating faces ④ between the shim ① and the pad ③, and the mating faces ⑤ between the shim ① and the shim cover ②, and then install the shim and shim cover to the pad.

CAUTION:

Always replace the shims and shim covers when replacing the brake pad.

Molykote is a registered trademark of Dow Corning Corporation.



M
N
O
P

2. Install the brake pads to the torque member.
3. Apply rubber grease to the cylinder body mounting bolts, and then install the cylinder body to torque member.

CAUTION:


REAR DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >

- Never damage the piston boot.
- When replacing brake pad with new one, check a brake fluid level in the reservoir tank because brake fluid returns to reservoir tank when pressing piston in.

4. Install the lower sliding pin bolt and tighten it to the specified torque.



5. Must be performed additional service when removing and installing/replacing brake pad.

When removing and installing brake pad

1. Perform "BRAKE OPERATION". Refer to [PB-61, "Work Procedure"](#).
2. Perform "BRAKE RELEASE". Refer to [PB-63, "Work Procedure"](#).

When replacing brake pad

- Refer to [PB-52, "Work Procedure"](#).

6. Depress the brake pedal several times to check that no drag feel is present for the front disc brake. Refer to [BR-122, "BRAKE PAD : Inspection and Adjustment"](#).

7. Install tires. Refer to [WT-61, "Removal and Installation"](#).

BRAKE PAD : Inspection and Adjustment

INFOID:000000010838978

INSPECTION AFTER REMOVAL

- Replace the shims and shim covers if rust is excessively attached.
- Eliminate rust on the pad and the torque member. Replace them if rust is excessively attached.

INSPECTION AFTER INSTALLATION

- Check a drag of rear disc brake. If any drag is found, follow the procedure described below.

1. Remove brake pads. Refer to [BR-120, "BRAKE PAD : Removal and Installation"](#).
2. Press the pistons. Refer to [BR-120, "BRAKE PAD : Removal and Installation"](#).
3. Install brake pads. Refer to [BR-120, "BRAKE PAD : Removal and Installation"](#).
4. Depress the brake pedal several times.
5. Check a drag of rear disc brake again. If any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-125, "BRAKE CALIPER ASSEMBLY : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing brake pads, or if a soft pedal occurs at very low mileage. Refer to [BR-83, "BRAKE PAD : Inspection and Adjustment"](#).

BRAKE CALIPER ASSEMBLY

BRAKE CALIPER ASSEMBLY : Exploded View


INFOID:000000010838979

REMOVAL

REAR DISC BRAKE

< REMOVAL AND INSTALLATION >


[RHD]



① Brake caliper assembly

N: N·m (kg·m, ft·lb)

DISASSEMBLY



① Cap

② Bleeder valve

③ Cylinder body

④ Sliding pin

⑤ Bushing

⑥ Bushing

⑦ Torque member

N: Apply rubber grease.

BRAKE CALIPER ASSEMBLY : Removal and Installation

INFOID:0000000010838980

REMOVAL

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

REAR DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >


- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.

1. Release the parking brake.
2. Must be performed additional service when replacing brake caliper. Refer to [PB-55, "Work Procedure"](#).
3. Remove tires.
4. Fix the disc rotor using wheel nuts.
5. Drain brake fluid. Refer to [BR-77, "Draining"](#).
6. Remove union bolt and copper washer, and separate brake hose from brake caliper assembly. Refer to [BR-92, "REAR : Removal and Installation"](#).
7. Remove torque member mounting bolts, and remove brake caliper assembly.

CAUTION:

- Never drop brake pad and brake caliper assembly.
- Never damage the electric parking brake harness and bracket.

8. Remove disc rotor.
 - 2WD: Refer to [RAX-7, "Removal and Installation"](#).
 - 4WD: Refer to [RAX-18, "Removal and Installation"](#).



INSTALLATION


WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface. However avoid washing brake components with water.
- Never depress the brake pedal while removing the brake pads because the piston may pop out.
- If the brake fluid or grease adheres to the brake caliper assembly and disc rotor, quickly wipe it off.
- Never allow foreign matter (e.g.dust) and oils other than brake fluid to enter the reservoir tank.

1. Install disc rotor.
 - 2WD: Refer to [RAX-7, "Removal and Installation"](#).
 - 4WD: Refer to [RAX-18, "Removal and Installation"](#).
2. Install the brake caliper assembly to the steering knuckle and tighten the torque member mounting bolts to the specified torque.



CAUTION:

Never spill or splash any grease and moisture on the brake caliper assembly mounting face, threads, mounting bolts and washers. Wipe out any grease and moisture.

3. Install brake hose and copper washers to brake caliper assembly. Refer to [BR-92, "REAR : Removal and Installation"](#).

CAUTION:

Never reuse copper washer.

4. Must be performed additional service when removing and installing/replacing brake pad.

When removing and installing brake pad

1. Perform "BRAKE OPERATION". Refer to [PB-61, "Work Procedure"](#).
2. Perform "BRAKE RELEASE". Refer to [PB-63, "Work Procedure"](#).

When replacing brake pad

- Refer to [PB-52, "Work Procedure"](#).

5. Refill with new brake fluid and perform the air bleeding. Refer to [BR-78, "Bleeding Brake System"](#).

< REMOVAL AND INSTALLATION >

CAUTION:

- Never reuse brake fluid.
- Never spill or splash brake fluid on the surface of disc rotor.

6. Check a drag of rear disc brake. If any drag is found, refer to [BR-126, "BRAKE CALIPER ASSEMBLY : Inspection and Adjustment".](#)
7. Install tires. Refer to [WT-61, "Removal and Installation"](#)
8. Perform inspection after installation. Refer to [BR-126, "BRAKE CALIPER ASSEMBLY : Inspection and Adjustment".](#)

BRAKE CALIPER ASSEMBLY : Disassembly and Assembly

INFOID:0000000010838981

DISASSEMBLY

NOTE:


Never remove the torque member and brake pad when disassembling and assembling the cylinder body.

1. Remove the sliding pin bolt, and remove the cylinder body from the torque member. Refer to [BR-120, "BRAKE PAD : Removal and Installation".](#)

CAUTION:

Fix the brake pad at suitable tape so that the brake pad will not drop.

2. Remove sliding pins and sliding pin boots from torque member.
3. Remove bushing ① from sliding pin ②.




4. Remove bleeder valve and cap.
5. Perform inspection after disassembly. Refer to [BR-126, "BRAKE CALIPER ASSEMBLY : Inspection and Adjustment".](#)

ASSEMBLY

1. Install bleeder valve and cap.

2. Apply rubber grease to mating faces Ⓐ between sliding pin ① and bushing ②, and install bushing to sliding pin.




REAR DISC BRAKE

[RHD]

< REMOVAL AND INSTALLATION >

3. Apply rubber grease to mating faces ① between sliding pins ① and sliding pin boots ②, and install sliding pins and sliding pin boots to torque member ③.



4. Install the cylinder body to tighten cylinder body mounting bolts to the specified torque. Refer to [BR-120, "BRAKE PAD : Exploded View"](#).

BRAKE CALIPER ASSEMBLY : Inspection and Adjustment

INFOID:000000010838982

INSPECTION AFTER DISASSEMBLY

Check the following items and replace if necessary.

Cylinder Body

Check the cylinder inner wall for rust, wear, cracks or damage.

CAUTION:

Always clean with new brake fluid. Never clean with mineral oil such as gasoline and light oil.

Torque Member

Check the torque member for rust, wear, cracks or damage.

Sliding Pin, Sliding Pin Boot and Bushing

Check the sliding pins, sliding pin boots and bushing for rust, wear, cracks or damage.

INSPECTION AFTER INSTALLATION

- Check a drag of rear disc brake. If any drag is found, follow the procedure described below.
- 1. Remove brake pads. Refer to [BR-120, "BRAKE PAD : Removal and Installation"](#).
- 2. Press the pistons. Refer to [BR-120, "BRAKE PAD : Removal and Installation"](#).
- 3. Install brake pads. Refer to [BR-120, "BRAKE PAD : Removal and Installation"](#).
- 4. Depress the brake pedal several times.
- 5. Check a drag of rear disc brake again. When any drag is found, disassemble the cylinder body and replace if necessary. Refer to [BR-125, "BRAKE CALIPER ASSEMBLY : Disassembly and Assembly"](#).
- Burnish contact surfaces brake pads and disc rotor after refinishing or replacing disc rotor, or if a soft pedal occurs at very low mileage. Refer to [BR-83, "BRAKE PAD : Inspection and Adjustment"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[RHD]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:0000000010930899

Unit: mm (in)

| | | | |
|-------------------------|----------------------------------|---|---|
| Front brake | Caliper type | 1 piston type | 2 piston type |
| | Cylinder bore diameter | 60.33 (2.3752) | 44.45 × 2 (1.7500 × 2) |
| | Pad length × width × thickness | 123.6 × 47.5 × 10.5 (4.87 × 1.870 × 0.413) | 133.6 × 48.5 × 10.0 (5.26 × 1.909 × 0.39) |
| | Rotor outer diameter × thickness | 296 × 26.0 (11.65 × 1.024) | 320 × 28.0 (12.60 × 1.102) |
| Rear brake | Cylinder bore diameter | 38.2 (1.504) | |
| | Pad length × width × thickness | 82.9 × 39.8 × 9.0 (3.263 × 1.567 × 0.354) | |
| | Rotor outer diameter × thickness | 292 × 16.0 (11.50 × 0.630) | |
| Master cylinder | Cylinder bore diameter | 23.81 (0.9374) | |
| Control valve | Valve type | Electric brake force distribution | |
| Brake booster | Diaphragm diameter | 250 (0.9374) | |
| Recommended brake fluid | | Refer to MA-23, "Fluids and Lubricants" . | |

Brake Pedal

INFOID:0000000010838623

Unit: mm (in)

| Item | Standard |
|---|-------------------------------|
| Brake pedal height | 175.0 – 185.0 (6.89 – 7.28) |
| Depressed brake pedal height [Depressing 490 N (50 kg, 110 lb) while turning the engine ON] | 85.0 (3.35) or more |
| Clearance between stop lamp switch and brake pedal position switch (with ASCD) threaded end and the brake pedal lever | 0.20 – 1.96 (0.0079 – 0.0772) |
| Brake pedal play | 3 – 11 (0.12 – 0.43) |

Brake Booster

INFOID:0000000010838624

Unit: mm (in)

| Item | Standard |
|------------------|-------------------------------|
| Input rod length | 124.25 – 125.75 (4.89 – 4.95) |

Front Disc Brake

INFOID:0000000010930900

Unit: mm (in)

| Item | | Limit | |
|--------------------|---|----------------|----------------|
| Brake caliper type | | 1 piston type | 2 piston type |
| Brake pad | Wear thickness | 2.0 (0.079) | 2.0 (0.079) |
| Disc rotor | Wear thickness | 24.0 (0.945) | 26.0 (1.0236) |
| | Thickness variation (measured at 8 positions) | 0.020 (0.0008) | 0.020 (0.0008) |
| | Runout (with it attached to the vehicle) | 0.035 (0.0014) | 0.035 (0.0014) |

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

[RHD]

Rear Disc Brake

INFOID:000000010930901

Unit: mm (in)

| Item | | Limit |
|------------|---|----------------|
| Brake pad | Wear thickness | 2.0 (0.079) |
| | Wear thickness | 14.0 (0.551) |
| Disc rotor | Thickness variation (measured at 8 positions) | 0.020 (0.0008) |
| | Runout (with it attached to the vehicle) | 0.070 (0.0028) |