

SECTION CHG

CHARGING SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

TYPE 1

HOW TO USE THIS MANUAL	3
APPLICATION NOTICE	3
Information	3
PRECAUTION	4
PRECAUTIONS	4
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4
Precautions for Removing Battery Terminal	4
Precaution for Stop/Start System Service	5
Precaution for Energy Management System	5
SYSTEM DESCRIPTION	6
COMPONENT PARTS	6
Component Parts Location	6
Alternator	6
Battery Current Sensor (With Battery Temperature Sensor)	6
SYSTEM	8
ENERGY MANAGEMENT SYSTEM	8
ENERGY MANAGEMENT SYSTEM : System Description	8
WARNING/INDICATOR/CHIME LIST	8
WARNING/INDICATOR/CHIME LIST : Warning Lamps/Indicator Lamps	8
ECU DIAGNOSIS INFORMATION	9
ECM, IPDM E/R	9
List of ECU Reference	9
WIRING DIAGRAM	10

CHARGING SYSTEM	10
Wiring Diagram	10
BASIC INSPECTION	14
DIAGNOSIS AND REPAIR WORK FLOW	14
Work Flow	14
CHARGING SYSTEM PRELIMINARY INSPECTION	15
Inspection Procedure	15
DTC/CIRCUIT DIAGNOSIS	16
B20BD BATTERY CURRENT SENSOR	16
DTC Description	16
Diagnosis Procedure	16
Component Inspection	19
B20BE BATTERY TEMPERATURE SENSOR	20
DTC Description	20
Diagnosis Procedure	20
Component Inspection	22
B TERMINAL CIRCUIT	24
Diagnosis Procedure	24
SYMPTOM DIAGNOSIS	25
CHARGING SYSTEM	25
Symptom Table	25
REMOVAL AND INSTALLATION	26
ALTERNATOR	26
R9M	26
R9M : Exploded View	26
R9M : Removal and Installation	26
SERVICE DATA AND SPECIFICATIONS (SDS)	29

CHG

SERVICE DATA AND SPECIFICATIONS (SDS)	29	CHARGING SYSTEM	36
Alternator	29	Wiring Diagram	36
TYPE 2			
HOW TO USE THIS MANUAL	30	BASIC INSPECTION	40
APPLICATION NOTICE	30	DIAGNOSIS AND REPAIR WORK FLOW	40
Information	30	Work Flow	40
PRECAUTION	31	CHARGING SYSTEM PRELIMINARY IN- SPECTION	41
PRECAUTIONS	31	Inspection Procedure	41
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	31	DTC/CIRCUIT DIAGNOSIS	42
Precautions for Removing Battery Terminal	31	B TERMINAL CIRCUIT	42
SYSTEM DESCRIPTION	33	Diagnosis Procedure	42
COMPONENT PARTS	33	SYMPTOM DIAGNOSIS	43
Component Parts Location	33	CHARGING SYSTEM	43
Alternator	33	Symptom Table	43
SYSTEM	34	REMOVAL AND INSTALLATION	44
CHARGING SYSTEM	34	ALTERNATOR	44
CHARGING SYSTEM : System Description	34	MR20DD	44
WARNING/INDICATOR/CHIME LIST	34	MR20DD : Exploded View	44
WARNING/INDICATOR/CHIME LIST : Warning Lamps/Indicator Lamps	34	MR20DD : Removal and Installation	44
ECU DIAGNOSIS INFORMATION	35	QR25DE	45
ECM, IPDM E/R	35	QR25DE : Exploded View	46
List of ECU Reference	35	QR25DE : Removal and Installation	46
WIRING DIAGRAM	36	SERVICE DATA AND SPECIFICATIONS (SDS)	48
		Alternator	48

< HOW TO USE THIS MANUAL >

HOW TO USE THIS MANUAL

APPLICATION NOTICE

Information

INFOID:000000010957593

A

B

Check the vehicle type to use the service information in this section.

Service information	System
TYPE 1	With stop/start system
TYPE 2	Without stop/start system

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010957594

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing Battery Terminal

INFOID:0000000010957595

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.

PRECAUTIONS

[TYPE 1]

< PRECAUTION >

2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

Precaution for Stop/Start System Service

INFOID:0000000010957630

CAUTION:

When performing an inspection and its related work with the engine at idle, always turn the stop/start OFF switch ON or open the hood to release the stop/start system.

Precaution for Energy Management System

INFOID:0000000010957597

CHG

CAUTION:

Never connect the electrical component or the ground wire directly to the battery terminal. The connection causes the malfunction of the energy management system, and then the battery discharge may occur.


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000010957631




No.	Component	Function
①	Battery current sensor (With battery temperature sensor)	Refer to CHG-6, "Battery Current Sensor (With Battery Temperature Sensor)".
②	Alternator	Refer to CHG-6, "Alternator".
③	ECM	ECM transmits the received alternator voltage request signal to alternator via LIN communication. Refer to EC-812, "Component Parts Location" for detailed installation location.
④	IPDM E/R	IPDM E/R sends the alternator voltage request signal to ECM via CAN communication. Refer to PCS-5, "Component Parts Location" for detailed installation location.

Alternator

INFOID:0000000010957599

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged.



Battery Current Sensor (With Battery Temperature Sensor)

INFOID:0000000010957600


BATTERY CURRENT SENSOR

COMPONENT PARTS

[TYPE 1]

< SYSTEM DESCRIPTION >

The battery current sensor is installed to the battery negative cable. The sensor measures the charging/discharging current of the battery.




A
B
C
D
E
F
G
H
I
J
K
L

BATTERY TEMPERATURE SENSOR

Battery temperature sensor is integrated in battery current sensor. The sensor measures temperature around the battery. The electrical resistance of the thermistor decreases as temperature increases.

Temperature [°C (°F)]	Resistance (kΩ)
25 (77)	1.9 - 2.1
90 (194)	0.222 - 0.258




M
N
O
P

CHG

< SYSTEM DESCRIPTION >

SYSTEM**ENERGY MANAGEMENT SYSTEM****ENERGY MANAGEMENT SYSTEM : System Description**

INFOID:0000000010957601

SYSTEM DIAGRAM**SYSTEM DESCRIPTION**

- Battery current sensor (With battery temperature sensor) measures the charging/discharging current of the battery and the temperature around the battery.
- IPDM E/R judges battery condition according to the charging/discharging current of the battery and the temperature around the battery.
- IPDM E/R calculates the target power generation voltage according to the battery condition and sends the calculated value as alternator voltage request signal to ECM via CAN communication.
- ECM transmits alternator voltage request signal to alternator via LIN communication.
- Control module inside alternator controls the power generation voltage based on the received alternator voltage request signal.
- Alternator includes a self-diagnosis function and transmits the diagnosis result to ECM via LIN communication when detecting any malfunction.

WARNING/INDICATOR/CHIME LIST**WARNING/INDICATOR/CHIME LIST : Warning Lamps/Indicator Lamps**

INFOID:0000000010957634

Item	Design	Reference
Charge warning lamp		For layout, refer to MWI-10, "METER SYSTEM : Design" . For function, refer to MWI-30, "WARNING LAMPS/INDICATOR LAMPS : Charge Warning Lamp" .

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

ECM, IPDM E/R

List of ECU Reference

INFOID:000000010957602

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

CHARGING SYSTEM

< WIRING DIAGRAM >


[TYPE 1]

WIRING DIAGRAM

CHARGING SYSTEM

Wiring Diagram

INFOID:000000010957603



CHARGING SYSTEM

[TYPE 1]

< WIRING DIAGRAM >

CHARGING SYSTEM

Connector No. E10

Connector Name FROM INTELLIGENT POWER DISTRIBUTION MODULE

Connector Type ENGINE ROOM

Connector Type NS16F6Y-CS



Terminal Color Of

Wire No. Signal Name [Specification]

3 P -

4 Y -

7 L -


8 BG -

9 L -

12 B -

16 G -

17 W -



Terminal Color Of

Wire No. Signal Name [Specification]

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

48 R -

36 Y -

37 B -

38 GR -

39 BR -

45 L -

46 P -

47 W -

CHARGING SYSTEM

< WIRING DIAGRAM >

[TYPE 1]

CHARGING SYSTEM

Connector No.	F7	Connector No.	F14	Terminal No.	Color Of Wire	Signal Name [Specification]
Connector Name	ECM	Connector Name	ALTERNATOR	1	P	OUTPUT
Connector Type	R144F-E22Z-R LH	Connector Type	24340_EM013	2	W	GND

卷之三

Terminal No.	Wire	Signal Name (Specification)	Terminal Color On Wire	Color Name (Specification)
1	W	FUEL INJECTOR NO.1(H)	1	BR
2	W	FUEL INJECTOR NO.2(H)	-	-
3	W	FUEL INJECTOR NO.3(H)	-	-
4	W	FUEL INJECTOR NO.4(H)	-	-
5	B	FUEL INJECTOR NO.1(L)	-	-

6	G	SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1)
8	B	ECM GROUND

Component	Part No.	Component Description	Pin No.	Pin Name (Specification)
FUEL INJECTOR NO.4(10)	8	B	2	WIRE
ECM GROUND	11	B	3	WIRE
SHIELD	12	BR	4	WIRE
PARK/NEUTRAL POSITION SIGNAL	14	W	5	WIRE
CRANKSHAFT POSITION SENSOR	15	R	6	WIRE
CRANKSHAFT POSITION SENSOR	19	W	7	WIRE

IGNITION SWITCH
ASCD STEERING SWITCH

Terminal No.	Color Of Wire	Signal Name [Specification]	70	BR	SENSOR GROUND
23	Y		71	GR	CRANKSHAFT POSITION SENSOR
24	Y	SENSOR POWER SUPPLY	72	L	SENSOR POWER SUPPLY
25	L	SENSOR GROUND	73	SHIELD	SHIELD
28	BR	MASS AIR FLOW SENSOR	77	W	THROTTLE POSITION SENSOR 2
29	GR	ENGINE OIL PRESSURE SENSOR	78	B	SENSOR GROUND
31	G	ENGINE COOLANT TEMPERATURE SENSOR			
		Connector No. F43			

30 BR 31 P ASCD MAIN SWITCH
CAN-L

Connector Type	Part No.	Component Name	Function
	RH04FB	REFRIGERANT PRESSURE SENSOR	
34	V	INTAKE AIR TEMPERATURE SENSOR	
35	V	SHIELD	
36	39	SENSOR GROUND	
39	R	SENSOR GROUND	
40	W	KNOCK SENSOR	
42	R	SENSOR GROUND	
42	C	SENSOR GROUND, DISPLAY	

JRMWF4094GB

CHARGING SYSTEM

< WIRING DIAGRAM >

[TYPE 1]

CHARGING SYSTEM

Connector No.	F74	Connector Name	INPUT INTELLIGENT POWER DISTRIBUTION MODULE (SINGLE CAN)	Connector Type	TH24FB-NH
Connector No.	F75	Connector Name	BATTERY TERMINAL WITH FUSIBLE LINK	Connector Type	2A348-51E05
Connector No.	F132	Connector Name	BATTERY TERMINAL WITH FUSIBLE LINK	Connector Type	2A340-1MG2A
Connector No.	F132	Connector Name	BATTERY TERMINAL WITH FUSIBLE LINK	Connector Type	2A340-1MG2A
Connector No.	F132	Connector Name	BATTERY TERMINAL WITH FUSIBLE LINK	Connector Type	2A340-1MG2A

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
6	B/R	-	6	B/R	-
87	L	-	85	G	TURBOCHARGER BOOST SENSOR
88	P	-	86	W	INTAKE AIR TEMPERATURE SENSOR 2
89	W	-	88	W	FUEL PRESSURE SENSOR
90	R	-	89	BR	A/F SENSOR HEATER
		Connector No. F117	91	G	SENSOR POWER SUPPLY & FUEL PRESSURE SENSOR
			93	B	FUEL HEATER RELAY CONTROL
					Connector No. M42

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
100	LG	-	41	L	CANH
101	V	-	42	P	CANL
102	Y	-	43	W	ILLUMINATION CONTROL SIGNAL
103	W	-	-	-	-
106	BR	-	-	-	-
107	V	-	-	-	-
108	SB	-	-	-	-
35	R	GLW PLUG CONTROL (COMMAND)	-	-	-
37	LG	VOLTAGE STABILIZER SIGNAL	-	-	-
38	GR	FUEL PUMP RELAY CONTROL	-	-	-

			No.	Wire	Signal Name [Specification]
41	G	ECM RELAY (SELF SHUT-OFF)	1	B/R	
42	Y	RESTART RELAY			-
43	R	FUEL FLOW ACTUATOR			
46	V	THERMOPLUNGER RELAY 2			
49	P	NAME: WARMFIELD RUNNER CONTROL VALVE 1			
50	B/G	THERMOPLUNGER RELAY 1			
53	Y	THERMAL MANAGEMENT CONTROL VALVE			
55	R	THERMOPLUNGER RELAY 3			
56	B	CRANKSHAFT POSITION SENSOR (POS)			
57	S/B	THERMOPLUNGER RELAY 3			

JRMWF4095GB

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000010957604

DETAILED FLOW

1. CHECK FOR DTC

Perform self diagnosis with CONSULT

Is any DTC detected?

YES >> Repair as needed.

NO >> GO TO 2.

2. PRELIMINARY INSPECTION

Perform the preliminary inspection. Refer to [CHG-15, "Inspection Procedure"](#).

>> GO TO 3.

3. STOP POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

Turn ignition switch OFF, and disconnect the battery current sensor connector to stop the operation of energy management system. [However, DTC (B20BD or B20BE) might remain. After finishing the inspection, connect the battery current sensor connector and erase the self-diagnostic results history using CONSULT.]

>> GO TO 4.

4. INSPECTION WITH CHARGE WARNING LAMP (IDLING)

Start the engine and run it at idle.

Does the charge warning lamp turn OFF?

YES >> GO TO 5.

NO >> GO TO 6.

5. INSPECTION WITH CHARGE WARNING LAMP (ENGINE AT 2,500 RPM)

Increase and maintain the engine speed at 2,500 rpm.

Does the charge warning lamp illuminate?

YES >> GO TO 6.

NO >> INSPECTION END

6. MEASURE "B" TERMINAL VOLTAGE

Start engine. With engine running at 2,500 rpm, measure "B" terminal voltage.

What voltage does the measurement result show?

Less than 13.0 V>>GO TO 7.

More than 16.0 V>>Replace alternator. Refer to [CHG-26, "R9M : Removal and Installation"](#).

7. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [CHG-24, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace alternator. Refer to [CHG-26, "R9M : Removal and Installation"](#).

NO >> Repair as needed.

CHARGING SYSTEM PRELIMINARY INSPECTION

[TYPE 1]

< BASIC INSPECTION >

A

CHARGING SYSTEM PRELIMINARY INSPECTION

Inspection Procedure

INFOID:0000000010957605

B

1. CHECK BATTERY TERMINALS CONNECTION

C

Check if battery terminals are clean and tight.

D

Is the inspection result normal?

E

YES >> GO TO 2.

F

NO >> Repair battery terminals connection.

2. CHECK "E" TERMINAL CONNECTION

G

Check if "E" terminal (alternator ground harness) is clean and tight.

H

Is the inspection result normal?

I

YES >> GO TO 3.

J

NO >> Repair "E" terminal connection.

K

3. CHECK BATTERY STATUS

L

Check battery status. Refer to [PG-120, "R9M : Work Flow"](#).

M

Is the inspection result normal?

N

YES >> INSPECTION END

O

NO >> Repair as needed.

P

CHG

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B20BD BATTERY CURRENT SENSOR

DTC Description

INFOID:0000000010957606

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detecting condition
B20BD	CURRENT SENSOR (Current sensor)	[CIRC SHORT TO GRND] An excessively low voltage from the sensor is sent to IPDM E/R.
		[CIRC SHORT TO BATTERY] An excessively high voltage from the sensor is sent to IPDM E/R.
		[CIRC OPEN] The output voltage of the battery current sensor is lower than the specified value while the battery voltage is high enough or the changing of voltage is lower than the specified value.
		[CMPNENT INTERNAL MLFNCTN]

POSSIBLE CAUSE

[CIRC SHORT TO GRND]

- Harness or connectors
- Battery current sensor input signal (Current) circuit is shorted (Ground)
- Battery current sensor power circuit is open
- Battery current sensor

[CIRC SHORT TO BATTERY]

- Harness or connectors
- Battery current sensor input signal (Current) circuit is shorted (Power)
- Battery current sensor

[CIRC OPEN] or [CMPNENT INTERNAL MLFNCTN]

- Battery terminal is not connected
- Harness or connectors
- Battery current sensor input circuit is open
- Battery current sensor

FAIL-SAFE

Stop/start system is inhibited when this DTC is detected.

DTC CONFIRMATION PROCEDURE

1. PERFORM COMPONENT FUNCTION CHECK

1. Start engine and wait for 10 seconds or more.
2. Perform "Self Diagnostic Result" mode of "IPDM E/R" using CONSULT.

Is the inspection result normal?

YES-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

YES-2 >> Confirmation after repair: INSPECTION END

NO >> Proceed to [CHG-16, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000010957607

1. CHECK DTC

Perform each inspection according to the displayed DTC.

Which DTC is displayed?

[CIRC SHORT TO GRND]>>GO TO 2.

[CIRC SHORT TO BATTERY]>>GO TO 7.

[CIRC OPEN] or [CMPNENT INTERNAL MLFNCTN]>>GO TO 8.

2. CHECK BATTERY CURRENT SENSOR POWER

B20BD BATTERY CURRENT SENSOR

[TYPE 1]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect battery current sensor connector.
3. Turn ignition switch ON.
4. Check the voltage between battery current sensor harness connector and ground.

(+) Battery current sensor		(-)	Voltage (V)
Connector	Terminal		
F43	4	Ground	Approx. 5

Is the inspection result normal?

YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK BATTERY CURRENT SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check the continuity between battery current sensor harness connector and IPDM E/R harness connector.

Battery current sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F43	4	F74	95	Existed

4. Check the continuity between battery current sensor harness connector and ground.

Battery current sensor		—	Continuity
Connector	Terminal		
F43	4	Ground	Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
NO >> Repair or replace harness.

4. CHECK BATTERY CURRENT SENSOR GROUND

1. Turn ignition switch OFF.
2. Check the continuity between battery current sensor harness connector and ground.

Battery current sensor		—	Continuity
Connector	Terminal		
F43	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 6.
NO >> GO TO 5.

5. CHECK BATTERY CURRENT SENSOR GROUND CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check the continuity between battery current sensor harness connector and IPDM E/R harness connector.

Battery current sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F43	2	F74	96	Existed

3. Check the continuity between battery current sensor harness connector and ground.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

B20BD BATTERY CURRENT SENSOR

[TYPE 1]

< DTC/CIRCUIT DIAGNOSIS >

Battery current sensor		—	Continuity
Connector	Terminal	—	
F43	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).

NO >> Repair or replace harness.

6. CHECK BATTERY CURRENT INPUT SIGNAL CIRCUIT 1

1. Disconnect IPDM E/R connector.
2. Check the continuity between battery current sensor harness connector and ground.

Battery current sensor		—	Continuity
Connector	Terminal	—	
F43	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace harness.

7. CHECK BATTERY CURRENT INPUT SIGNAL CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect battery current sensor connector.
3. Check the voltage between battery current sensor harness connector and ground.

(+)	(-)	Voltage (V)	
Battery current sensor			
Connector	Terminal	Ground	0

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace harness.

8. CHECK BATTERY NEGATIVE TERMINAL CONNECTION

Check if battery negative terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair battery negative terminal connection.

9. CHECK BATTERY CURRENT INPUT SIGNAL CIRCUIT 3

1. Turn ignition switch OFF.
2. Disconnect battery current sensor connector and IPDM E/R connector.
3. Check the continuity between battery current sensor harness connector and IPDM E/R harness connector.

Battery current sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F43	1	F74	97	Existed

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace harness.

10. CHECK BATTERY CURRENT SENSOR

Refer to [CHG-19, "Component Inspection"](#).

B20BD BATTERY CURRENT SENSOR

[TYPE 1]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Refer to [GI-44, "Intermittent Incident"](#). If the inspection result of the connector is normal then replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
NO >> Replace battery current sensor.


Component Inspection

INFOID:000000010957608

1. CHECK BATTERY CURRENT SENSOR

1. Turn ignition switch OFF.
2. Reconnect connector which is disconnected
3. Disconnect battery negative cable.
4. Install jumper cable between battery negative terminal and body ground.
5. Turn ignition switch ON.
6. Check the voltage between IPDM E/R harness connector terminals as per the following.

IPDM E/R		Voltage (V)	
Connector	+	-	
Terminal		Terminal	
F74	97 (Battery current sensor signal)	96	Approx. 2.5



Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to [PG-120, "R9M : Work Flow"](#).

Is the inspection result normal?

YES >> INSPECTION END
NO >> Replace battery current sensor.

A

B

C

D

E

F

G

H

J

K

L

CHG

N

O

P

B20BE BATTERY TEMPERATURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TYPE 1]

B20BE BATTERY TEMPERATURE SENSOR

DTC Description

INFOID:000000010957609

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)		DTC detecting condition
B20BE	TEMP SENSOR (Temperature sensor)	[CIRC SHORT TO GRND]	An excessively low voltage from the sensor is sent to IPDM E/R.
		[CIRC SHORT TO BATTERY OR OPEN]	An excessively high voltage from the sensor is sent to IPDM E/R.

POSSIBLE CAUSE

[CIRC SHORT TO GRND]

- Harness or connectors
- Battery current sensor input signal (Temperature) circuit is shorted (Ground)
- Battery current sensor power circuit is open
- Battery current sensor

[CIRC SHORT TO BATTERY]

- Harness or connectors
- Battery current sensor input signal (Temperature) circuit is shorted (Power)
- Battery current sensor input signal (Temperature) circuit is open
- Battery current sensor

FAIL-SAFE

DTC CONFIRMATION PROCEDURE

1. PERFORM COMPONENT FUNCTION CHECK

1. Turn ignition ON, and wait for 5 seconds or more.
2. Perform "Self Diagnostic Result" mode of "IPDM E/R" using CONSULT.

Is the inspection result normal?

YES-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

YES-2 >> Confirmation after repair: INSPECTION END

NO >> Proceed to [CHG-20, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:000000010957610

1. CHECK DTC

Perform each inspection according to the displayed DTC.

Which DTC is displayed?

[CIRC SHORT TO GRND]>>GO TO 2.

[CIRC SHORT TO BATTERY OR OPEN]>>GO TO 7.

2. CHECK BATTERY CURRENT SENSOR POWER

1. Turn ignition switch OFF.
2. Disconnect battery current sensor connector.
3. Turn ignition switch ON.
4. Check the voltage between battery current sensor harness connector and ground.

(+) (+)		(-)	Voltage (V)
Battery current sensor			
Connector	Terminal		
F43	4	Ground	Approx. 5

B20BE BATTERY TEMPERATURE SENSOR

[TYPE 1]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK BATTERY CURRENT SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check the continuity between battery current sensor harness connector and IPDM E/R harness connector.

Battery current sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F43	4	F74	95	Existed

4. Check the continuity between battery current sensor harness connector and ground.

Battery current sensor		—	Continuity
Connector	Terminal		
F43	4	Ground	Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
NO >> Repair or replace harness.

4. CHECK BATTERY CURRENT SENSOR GROUND

1. Turn ignition switch OFF.
2. Check the continuity between battery current sensor harness connector and ground.

Battery current sensor		—	Continuity
Connector	Terminal		
F43	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 6.
NO >> GO TO 5.

5. CHECK BATTERY CURRENT SENSOR GROUND CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check the continuity between battery current sensor harness connector and IPDM E/R harness connector.

Battery current sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F43	2	F74	96	Existed

3. Check the continuity between battery current sensor harness connector and ground.

Battery current sensor		—	Continuity
Connector	Terminal		
F43	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
NO >> Repair or replace harness.

6. CHECK BATTERY TEMPERATURE INPUT SIGNAL CIRCUIT 1

1. Disconnect IPDM E/R connector.

B20BE BATTERY TEMPERATURE SENSOR

[TYPE 1]

< DTC/CIRCUIT DIAGNOSIS >

- Check the continuity between battery current sensor harness connector and ground.

Battery current sensor		—	Continuity
Connector	Terminal		
F43	3	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

7. CHECK BATTERY TEMPERATURE INPUT SIGNAL CIRCUIT 2

- Turn ignition switch OFF.
- Disconnect battery current sensor connector and IPDM E/R connector.
- Check the continuity between battery current sensor connector and IPDM E/R harness connector.

Battery current sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F43	3	F74	110	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

8. CHECK BATTERY TEMPERATURE INPUT SIGNAL CIRCUIT 3

- Connect IPDM E/R connector.
- Check the voltage between battery current sensor harness connector and ground.

(+) Battery current sensor		(-)	Voltage (V)
Connector	Terminal	Connector	
F43	3	Ground	0

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

9. CHECK BATTERY CURRENT SENSOR

Refer to [CHG-22, "Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [GI-44, "Intermittent Incident"](#). If the inspection result of the connector is normal then replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).

NO >> Replace battery current sensor.

Component Inspection

INFOID:000000010957611

1. CHECK BATTERY TEMPERATURE SENSOR

- Turn ignition switch OFF.
- Disconnect battery current sensor connector.
- Check the resistance between battery current sensor terminals.

Battery current sensor		Resistance
Terminal		
2	3	Continuity existed and the resistance value is 100 Ω or more

Is the inspection result normal?

YES >> INSPECTION END

B20BE BATTERY TEMPERATURE SENSOR

[TYPE 1]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace battery current sensor.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

B TERMINAL CIRCUIT**Diagnosis Procedure**

INFOID:0000000010957612

1. CHECK "B" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "B" terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair "B" terminal connection.

2. CHECK "B" TERMINAL CIRCUIT

Check voltage between alternator "B" terminal and ground.

(+) Alternator		(-)	Voltage (Approx.)
Connector	Terminal	Ground	Battery voltage
F131	1		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness for open between alternator and fusible link.

3. CHECK "B" TERMINAL CONNECTION (VOLTAGE DROP TEST)

1. Start engine, then engine running at idle and warm.
2. Check voltage between battery positive terminal and alternator "B" terminal.

(+)	(-) Alternator		Voltage (Approx.)
	Connector	Terminal	
Battery positive terminal	F131	1	Less than 0.2 V

Is the inspection result normal?YES >> "B" terminal circuit is normal. Refer to [CHG-14, "Work Flow"](#).

NO >> Check harness between battery and alternator for poor continuity.

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

CHARGING SYSTEM

Symptom Table

INFOID:000000010957613

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION**ALTERNATOR**

R9M

R9M : Exploded View

INFOID:0000000010728733



① Alternator mounting bolt

② Alternator

③ "B" terminal harness

④ "B" terminal nut

⑤ Alternator bracket

⑥ Alternator connector

: N·m (kg·m, ft·lb)

R9M : Removal and Installation


INFOID:0000000010728734

REMOVAL

1. Disconnect battery cable from negative terminal. Refer to [PG-139, "R9M : Removal and Installation"](#).
2. Remove drive belt. Refer to [EM-300, "Removal and Installation"](#).
3. Remove air duct (inlet). Refer to [EM-308, "Removal and Installation"](#).
4. Remove electric throttle control actuator. Refer to [EM-314, "Removal and Installation"](#).

CAUTION:**Cover the openings to avoid entry of foreign materials.**

5. Remove electric throttle control actuator bracket mounting nut ① and bolt ②, and then remove electric throttle control actuator bracket ③.




6. Remove air inlet hose 2. Refer to [EM-310, "Removal and Installation"](#).

ALTERNATOR

[TYPE 1]


< REMOVAL AND INSTALLATION >

7. Remove air inlet tube 2 mounting bolt **A** and disconnect air inlet tube 2 **①** from charge air cooler, and then get air inlet tube 2 out of alternator removal area.




8. Remove solenoid valve and bracket assembly.
 - a. Remove water hose fixing clip **A** from solenoid valve bracket.

↖ : Vehicle front




- b. Disconnect vacuum hose **①** and **②** from solenoid valve.
- c. Disconnect solenoid valve connector **A**.
- d. Remove solenoid valve harness fixing clips **B** from solenoid valve bracket.

↖ : Vehicle front



- e. Remove mounting bolts **A** and **B**, and then remove solenoid valve **①** and bracket assembly **②** as a set.

↖ : Vehicle front



9. Remove oil level gauge and oil level gauge guide. Refer to [EM-330, "Exploded View"](#).

CAUTION:

Cover the openings to avoid entry of foreign materials.

10. Disconnect alternator connector.
11. Remove "B" terminal nut and disconnect "B" terminal harness.
12. Remove alternator mounting bolts.
13. Remove alternator upward from the vehicle.

CAUTION:

Never contact with and damage surrounding parts when removing alternator from the vehicle.

INSTALLATION

ALTERNATOR

[TYPE 1]


< REMOVAL AND INSTALLATION >

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Temporarily tighten the alternator bolts in order from the upper to the lower, and then tighten them in order from the upper to the lower.
For the alternator, the front side (pulley side) surface is the reference surface. Fit the reference surface to the alternator mounting part, and then tighten the bolts.
- Be careful to tighten "B" terminal nut to the specified torque.
- Install alternator, and check tension of belt. Refer to [EM-301, "Inspection"](#).
- For this model (with battery current sensor models), the energy management system that controls the power generation voltage of the alternator has been adopted. Therefore, the power generation voltage variable control system operation inspection should be performed after replacing the alternator, and then make sure that the system operates normally. Refer to [CHG-14, "Work Flow"](#).

The battery current sensor is installed to the battery cable at the negative terminal.



- When installing the tire assembly, tighten wheel nuts to the specified torque. Refer to [WT-61, "Exploded View"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

[TYPE 1]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Alternator

INFOID:0000000010957626

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

< HOW TO USE THIS MANUAL >

HOW TO USE THIS MANUAL

APPLICATION NOTICE

Information

INFOID:000000010957592

Check the vehicle type to use the service information in this section.

Service information	System
TYPE 1	With stop/start system
TYPE 2	Without stop/start system

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010957577

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing Battery Terminal

INFOID:0000000011009668

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.


HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.



SEF289H

PRECAUTIONS

[TYPE 2]

< PRECAUTION >

2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000010957581



JMMIA1712ZZ

A
B
C
D
E
F
G
H
I
J
K
L

CHG

N
O
P


No.	Component	Function
①	Battery current sensor*	—
②	Alternator	Refer to CHG-33, "Alternator" .
③	ECM	ECM transmits the received alternator voltage request signal to alternator via LIN communication. Refer to EC-28, "ENGINE CONTROL SYSTEM : Component Parts Location" (MR engine) or EC-440, "Component Parts Location" (QR engine) for detailed installation location.
④	IPDM E/R	IPDM E/R sends the alternator voltage request signal to ECM via CAN communication. Refer to PCS-5, "Component Parts Location" for detailed installation location.

*: Not applicable

Alternator

INFOID:0000000010957582

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged.



JMMIA1018ZZ

< SYSTEM DESCRIPTION >


SYSTEM

CHARGING SYSTEM

CHARGING SYSTEM : System Description

INFOID:0000000010957583

SYSTEM DIAGRAM



JMMIA1816GB

SYSTEM DESCRIPTION

- IPDM E/R sends alternator voltage request signal to ECM via CAN communication.
- ECM transmits alternator voltage request signal to alternator via LIN communication.
- Control module inside alternator controls the power generation voltage based on the received alternator voltage request signal.
- Alternator includes a self-diagnosis function and transmits the diagnosis result to ECM via LIN communication when detecting any malfunction.

WARNING/INDICATOR/CHIME LIST

WARNING/INDICATOR/CHIME LIST : Warning Lamps/Indicator Lamps

INFOID:0000000010957584

Item	Design	Reference
Charge warning lamp		For layout, refer to MWI-10, "METER SYSTEM : Design" . For function, refer to MWI-30, "WARNING LAMPS/INDICATOR LAMPS : Charge Warning Lamp" .

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

ECM, IPDM E/R

List of ECU Reference

INFOID:000000010957585

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

CHARGING SYSTEM

< WIRING DIAGRAM >


[TYPE 2]

WIRING DIAGRAM

CHARGING SYSTEM

Wiring Diagram

INFOID:000000010957586



CHARGING SYSTEM

[TYPE 2]

< WIRING DIAGRAM >

CHARGING SYSTEM

E10

Connector No. FROM INTELLIGENT POWER DISTRIBUTION MODULE
Connector Name ENGINE ROOM


Connector Type N16F6Y-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
97	W	BAROMETRIC PRESSURE SENSOR
99	P	CANL
100	L	CANH
101	Y	SENSOR POWER SUPPLY
108	R	CLUTCH PEDAL POSITION SWITCH
109	LG	IGNITION SWITCH
110	G	ASD STEERING SWITCH
111	BR	SENSOR GROUND
115	V	STOP LAMP SWITCH
116	GR	BRAKE PEDAL POSITION SWITCH
118	SB	SENSOR POWER SUPPLY
119	Y	ACCELERATOR PEDAL POSITION SENSOR 2
120	LG	SENSOR GROUND
121	BR	POWER SUPPLY FOR ECM
122	V	SENSOR POWER SUPPLY
123	B	ECM GROUND
124	R	SENSOR GROUND
125	B	ECM GROUND
126	GR	ACCELERATOR PEDAL POSITION SENSOR 1
127	R	SENSOR GROUND
128	B	ECM GROUND

Terminal No.	Color Of Wire	Signal Name [Specification]
25	LG	-
26	W	-
27	SB	-
28	P	-
30	L	-
31	G	-
32	B	-
33	BG	-
34	LG	-
36	V	-
37	B	-
38	GR	-
39	BR	-
45	L	-
46	P	-
47	W	-
48	R	-

Terminal Color Of Wire No.	Signal Name [Specification]
9	8
10	7
11	6
12	5
13	4
14	3
15	2
16	1
17	W



E11

Connector No. FROM INTELLIGENT POWER DISTRIBUTION MODULE
Connector Name ENGINE ROOM


Connector Type N16F6Y-RR




Terminal Color Of Wire No.	Signal Name [Specification]
19	V
20	R
21	LG
22	Y
23	B
24	W



Terminal No.	Color Of Wire	Signal Name [Specification]
97	W	BAROMETRIC PRESSURE SENSOR
99	P	CANL
100	L	CANH
101	Y	SENSOR POWER SUPPLY
108	R	CLUTCH PEDAL POSITION SWITCH
109	LG	IGNITION SWITCH
110	G	ASD STEERING SWITCH
111	BR	SENSOR GROUND
115	V	STOP LAMP SWITCH
116	GR	BRAKE PEDAL POSITION SWITCH
117	W	PNP SIGNAL




Terminal No.	Color Of Wire	Signal Name [Specification]
97	W	BAROMETRIC PRESSURE SENSOR
99	P	CANL
100	L	CANH
101	Y	SENSOR POWER SUPPLY
108	R	CLUTCH PEDAL POSITION SWITCH
109	LG	IGNITION SWITCH
110	G	ASD STEERING SWITCH
111	BR	SENSOR GROUND
115	V	STOP LAMP SWITCH
116	GR	BRAKE PEDAL POSITION SWITCH
117	W	PNP SIGNAL




Terminal No.	Color Of Wire	Signal Name [Specification]
97	W	BAROMETRIC PRESSURE SENSOR
99	P	CANL
100	L	CANH
101	Y	SENSOR POWER SUPPLY
108	R	CLUTCH PEDAL POSITION SWITCH
109	LG	IGNITION SWITCH
110	G	ASD STEERING SWITCH
111	BR	SENSOR GROUND
115	V	STOP LAMP SWITCH
116	GR	BRAKE PEDAL POSITION SWITCH
117	W	PNP SIGNAL


Terminal No.	Color Of Wire	Signal Name [Specification]
97	W	BAROMETRIC PRESSURE SENSOR
99	P	CANL
100	L	CANH
101	Y	SENSOR POWER SUPPLY
108	R	CLUTCH PEDAL POSITION SWITCH
109	LG	IGNITION SWITCH
110	G	ASD STEERING SWITCH
111	BR	SENSOR GROUND
115	V	STOP LAMP SWITCH
116	GR	BRAKE PEDAL POSITION SWITCH
117	W	PNP SIGNAL




Terminal No.	Color Of Wire	Signal Name [Specification]
97	W	BAROMETRIC PRESSURE SENSOR
99	P	CANL
100	L	CANH
101	Y	SENSOR POWER SUPPLY
108	R	CLUTCH PEDAL POSITION SWITCH
109	LG	IGNITION SWITCH
110	G	ASD STEERING SWITCH
111	BR	SENSOR GROUND
115	V	STOP LAMP SWITCH
116	GR	BRAKE PEDAL POSITION SWITCH
117	W	PNP SIGNAL



Terminal No.	Color Of Wire	Signal Name [Specification]
97	W	BAROMETRIC PRESSURE SENSOR
99	P	CANL
100	L	CANH
101	Y	SENSOR POWER SUPPLY
108	R	CLUTCH PEDAL POSITION SWITCH
109	LG	IGNITION SWITCH
110	G	ASD STEERING SWITCH
111	BR	SENSOR GROUND
115	V	STOP LAMP SWITCH
116	GR	BRAKE PEDAL POSITION SWITCH
117	W	PNP SIGNAL



Terminal Color Of Wire No.	Signal Name [Specification]
9	8
10	7
11	6
12	5
13	4
14	3
15	2
16	1
17	W



Terminal Color Of Wire No.	Signal Name [Specification]
19	V
20	R
21	LG
22	Y
23	B
24	W



JRMWF4093GB

CHARGING SYSTEM

< WIRING DIAGRAM >

[TYPE 2]

CHARGING SYSTEM

Connector No.	ER9	Connector No.	F7
Connector Name	ECM	Connector Name	ECM
Connector Type	RH24F-RZB-R-LH	Connector Type	RH40F-RZB-R-LH

Terminal No.	Color Of Wire	Signal Name (Specification)
1	B	ECM GROUND
2	W	ACCELERATOR POSITION SENSOR 1 SENSES POSITION OF THROTTLE POSITION SENSOR 1A
3	3	ECM GROUND
4	B	POWER SUPPLY FOR ECM
5	L	ACCELERATOR POSITION SENSOR 2 SENSES POSITION OF THROTTLE POSITION SENSOR 2A
6	6	ECM GROUND
8	B	FUEL HEATER AND WATER INLET FUEL SENSOR SENSES OWN SENSORS FOR FUEL POSITION SENSOR 2
9	10	ACCELERATOR POSITION SENSOR 2 SENSES POSITION OF THROTTLE POSITION SENSOR 2A
11	P	ACCELERATOR POSITION SENSOR 2 SENSES POSITION OF THROTTLE POSITION SENSOR 2A
12	16	STOP LAMP SWITCH (WITH MTC)
16	R	BREAK PEDAL POSITION SWITCH (WITH CVT)
17	LG	IGNITION SWITCH
18	G	ASCD STEERING SWITCH
19	BR	SENSOR FOR DASD STEERING SWITC
20	BR	FUEL LAMP CONTROL MODULE (COMMAND)
22	Z	FUEL LAMP CONTROL MODULE (DIAGNOSIS)
23	V	SPEED CONTROL MAIN SWITCH
24	R	CLUTCH PEDAL POSITION SWITCH
27	V	CLUTCH INTERLOCK SWITCH
30	BR	ASCD MAIN SWITCH
31	P	CAN-H
32	L	CAN-L

Terminal No.	Wire	Color Of	Signal Name (Specification)
1	W	FUEL INJECTOR NO.1(H)	
2	W	FUEL INJECTOR NO.2(H)	
3	W	FUEL INJECTOR NO.3(H)	
4	W	FUEL INJECTOR NO.4(H)	
5	B	FUEL INJECTOR NO.(CO)	
6	B	FUEL INJECTOR NO.2(L)	
7	B	FUEL INJECTOR NO.3(L)	
8	B	FUEL INJECTOR NO.4(L)	
11	EDM GROUND		
12	BR	SHIELD	
14	W	PARK/NEUTRAL POSITION SIGNAL	
15	R	CRANKSHAFT POSITION SENSOR	
19	W	CRANKSHAFT PHASE	
20	L	SENSOR GROUND	
21	L	SENSOR POWER SUPPLY	
23	Y	SENSOR POWER SUPPLY	
24	Y	SENSOR POWER SUPPLY	
25	L	SENSOR GROUND	
28	BR	MASS AIR FLOW SENSOR	
29	GR	ENGINE OIL PRESSURE SENSOR	
31	G	ENGINE COOLANT TEMPERATURE SENSOR	
32	P	ENGINE OIL TEMPERATURE SENSOR	
33	P	FUEL RAIL PRESSURE SENSOR	
34	P	REFRIGERANT PRESSURE SENSOR	
35	V	INTAKE AIR TEMPERATURE SENSOR	
36	SHIELD	SENSOR GROUND	
39	R	SENSOR GROUND	
40	W	KNOCK SENSOR	
42	B	SENSOR GROUND	
43	G	SENSOR POWER SUPPLY	
44	BR	SENSOR GROUND	
45	G	LIN COMMUNICATION LINE (Without ISS)	
45	L	LIN COMMUNICATION LINE (With ISS)	
46	GR	ENGINE OIL TEMPERATURE SENSOR (With ISS)	


Connector No.	F14	Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
Connector Name	ALTERNATOR	No.		
Connector Type	24340-EN013	1	P	OUTPUT
		2	W	GND
		3	SB	TEMP
		4	LG	PWR
				
Connector No.	F48	Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
Connector Name	ECM	No.		
Connector Type	RH40FBR-R23-LH	1	73	77
		70	78	88/89/93
		50	54	86/90/94
		51	71	82/85/91
		52	66	83/84/92
				
Connector No.	F15	Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
Connector Name	ALTERNATOR	No.		
Connector Type	FRH021B	1	B/R	-
Connector No.	F43	Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
Connector Name	BATTERY CURRENT SENSOR	No.		
Connector Type	RH04FB	2	G	-
				
Connector No.	F43	Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
Connector Name	BATTERY CURRENT SENSOR	No.		
Connector Type	RH04FB	2	G	-
				
Connector No.	F43	Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
Connector Name	BATTERY CURRENT SENSOR	No.		
Connector Type	RH04FB	2	G	-
				
Connector No.	F43	Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
Connector Name	BATTERY CURRENT SENSOR	No.		
Connector Type	RH04FB	2	G	-
				

CHARGING SYSTEM

[TYPE 2]

< WIRING DIAGRAM >

CHARGING SYSTEM



JRMWF4095GB

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000010957587

DETAILED FLOW

1. CHECK FOR DTC

Perform self diagnosis with CONSULT.

Is any DTC detected?

YES >> Repair as needed.

NO >> GO TO 2.

2. PRELIMINARY INSPECTION

Perform the preliminary inspection. Refer to [CHG-41, "Inspection Procedure"](#).

>> GO TO 3.

3. INSPECTION WITH CHARGE WARNING LAMP (IDLING)

Start the engine and run it at idle.

Does the charge warning lamp turn OFF?

YES >> GO TO 4.

NO >> GO TO 5.

4. INSPECTION WITH CHARGE WARNING LAMP (ENGINE AT 2,500 RPM)

Increase and maintain the engine speed at 2,500 rpm.

Does the charge warning lamp illuminate?

YES >> GO TO 5.

NO >> INSPECTION END

5. MEASURE "B" TERMINAL VOLTAGE

Start engine. With engine running at 2,500 rpm, measure "B" terminal voltage.

What voltage does the measurement result show?

Less than 13.0 V>>GO TO 6.

More than 16.0 V>>Replace alternator. Refer to [CHG-44, "MR20DD : Removal and Installation"](#) (MR engine) or [CHG-46, "QR25DE : Removal and Installation"](#) (QR engine).

6. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [CHG-42, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace alternator. Refer to [CHG-44, "MR20DD : Removal and Installation"](#) (MR engine) or [CHG-46, "QR25DE : Removal and Installation"](#) (QR engine).

NO >> Repair as needed.

CHARGING SYSTEM PRELIMINARY INSPECTION

[TYPE 2]

< BASIC INSPECTION >

CHARGING SYSTEM PRELIMINARY INSPECTION

Inspection Procedure

INFOID:0000000010957588

1. CHECK BATTERY TERMINALS CONNECTION

Check if battery terminals are clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair battery terminals connection.

2. CHECK "E" TERMINAL CONNECTION

Check if "E" terminal (alternator ground harness) is clean and tight.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair "E" terminal connection.

3. CHECK BATTERY STATUS

Check battery status. Refer to [PG-124, "EXCEPT FOR R9M : Work Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace battery. Refer to [PG-142, "EXCEPT FOR R9M : Removal and Installation"](#).

4. CHECK DRIVE BELT TENSION

Check drive belt tension. Refer to [EM-23, "Inspection"](#) (MR engine) or [EM-167, "Inspection"](#) (QR engine).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair as needed.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B TERMINAL CIRCUIT

Diagnosis Procedure

INFOID:0000000010957589

1. CHECK "B" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "B" terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair "B" terminal connection.

2. CHECK "B" TERMINAL CIRCUIT

Check voltage between alternator "B" terminal and ground.

MR engine

(+)		(-)	Voltage (Approx.)
Alternator			
Connector	Terminal		
E68	1	Ground	Battery voltage

QR engine

(+)		(-)	Voltage (Approx.)
Alternator			
Connector	Terminal		
F14	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness for open between alternator and fusible link.

3. CHECK "B" TERMINAL CONNECTION (VOLTAGE DROP TEST)

1. Start engine, then engine running at idle and warm.
2. Check voltage between battery positive terminal and alternator "B" terminal.

MR engine

(+)	(-)		Voltage (Approx.)	
	Alternator			
	Connector	Terminal		
Battery positive terminal	E68	1	Less than 0.2 V	

QR engine

(+)	(-)		Voltage (Approx.)	
	Alternator			
	Connector	Terminal		
Battery positive terminal	F14	1	Less than 0.2 V	

Is the inspection result normal?YES >> "B" terminal circuit is normal. Refer to [CHG-40, "Work Flow"](#).

NO >> Check harness between battery and alternator for poor continuity.

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

CHARGING SYSTEM

Symptom Table

INFOID:0000000010957590

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N


O

P

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION**ALTERNATOR****MR20DD****MR20DD : Exploded View**

INFOID:0000000010957571



① "B" terminal nut	② "B" terminal harness	③ Alternator
④ Alternator mounting bolt (upper)	⑤ Alternator mounting bolt (lower)	⑥ Alternator harness connector

Nm : N·m (kg·m, ft·lb)


MR20DD : Removal and Installation

INFOID:0000000010957572

REMOVAL

1. Disconnect battery cable from negative terminal. Refer to [PG-142, "EXCEPT FOR R9M : Removal and Installation"](#).
2. Remove drive belt. Refer to [EM-22, "Removal and Installation"](#).
3. Remove washer tank inlet. Refer to [WW-91, "Removal and Installation"](#).
4. Remove low pressure flexible hose bracket mounting bolt Ⓐ and nut Ⓑ.
5. Remove ground cable clip Ⓒ.

↖ : Vehicle front



JMMIA1601ZZ


ALTERNATOR

[TYPE 2]

< REMOVAL AND INSTALLATION >

6. Remove "B" terminal nut **(A)** and "B" terminal harness.
7. Disconnect alternator harness connector **(B)** and harness clips **(C)**.

◀ : Vehicle front



8. Remove alternator mounting bolt (upper).
9. Completely loosen alternator mounting bolt (lower), and pull it out until the bolt head is in contact with the side member. And then, remove the alternator by pulling it forward.


NOTE:
The alternator can be removed together with the bolts by pulling it forward and using the alternator bracket bolt hole cutout.

10. Remove alternator upward from the vehicle.

CAUTION:

- Never put excessive power on low pressure flexible hose and high pressure pipe.
- Never bend ground cable.

◀ : Vehicle front



INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Temporarily tighten the alternator bolts in order from the lower to the upper, and then tighten them in order from the upper to the lower.
- For the alternator, the front side (pulley side) surface is the reference surface. Fit the reference surface to the alternator mounting part, and then tighten the bolts.
- Be careful to tighten "B" terminal nut to the specified torque.
- Install alternator, and check tension of belt. Refer to [EM-23, "Inspection"](#).

QR25DE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CHG


ALTERNATOR

[TYPE 2]

< REMOVAL AND INSTALLATION >

QR25DE : Exploded View

INFOID:0000000010957573



① Alternator harness connector ② "B" terminal harness ③ "B" terminal nut
④ Alternator ⑤ Alternator mounting bracket
Nm : N·m (kg·m, ft·lb)

QR25DE : Removal and Installation

INFOID:0000000010957574


REMOVAL

1. Disconnect battery cable from negative terminal. Refer to [PG-142, "EXCEPT FOR R9M : Removal and Installation"](#).
2. Remove drive belt. Refer to [EM-166, "Removal and Installation"](#).
3. Remove washer tank inlet. Refer to [WW-91, "Removal and Installation"](#).
4. Remove ground cable bracket mounting bolt Ⓐ, and then move ground cable bracket ① to a location where it does not inhibit work.

CAUTION:


Never bend ground cable.

◀ : Vehicle front



5. Remove low pressure flexible hose bracket mounting bolts Ⓐ and nut Ⓑ.

◀ : Vehicle front



6. Remove "B" terminal nut and disconnect "B" terminal harness.

ALTERNATOR

[TYPE 2]

< REMOVAL AND INSTALLATION >

7. Disconnect alternator harness connector.
8. Remove alternator mounting bolts.
9. Remove alternator upward from the vehicle.

CAUTION:

Never strong force to low pressure flexible hose and high pressure pipe.

INSTALLATION


Note the following items, and then install in the reverse order of removal.

CAUTION:

- Temporarily tighten the alternator bolts in order from the lower side to the upper side, and then tighten them in order from the upper side to the lower side.
- For the alternator, the front side (pulley side) surface is the reference surface. Fit the reference surface to the alternator mounting part, and then tighten the bolts.
- Be careful to tighten "B" terminal nut to the specified torque.
- Install alternator and check tension of belt. Refer to [EM-167, "Inspection".](#)

NOTE:

Tighten mounting bolts according to the following procedure for installing alternator bracket.



SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

[TYPE 2]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Alternator

INFOID:000000010957591

Applied model		MR engine	QR engine
Type		2620093	2620168
		Valeo Make	Valeo Make
Nominal rating	[V - A]	12 - 120	12 - 120
Ground polarity		Negative	Negative
Minimum revolution under no-load (When 13.5 V is applied)	[rpm]	Less than 1,200	Less than 1,200
Hot output current (When 13.5 V is applied)	[A/rpm]	More than 46/1,500 More than 96/2,500 More than 117/5,000	More than 46/1,500 More than 96/2,500 More than 117/5,000
Regulated output voltage	[V]	14.0 – 14.6	14.0 – 14.6