

PCS

SECTION

POWER CONTROL SYSTEM

IPDM E/R	
PRECAUTION	3
PRECAUTIONS	3
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3
Precautions for Removing Battery Terminal	3
SYSTEM DESCRIPTION	5
COMPONENT PARTS	5
Component Parts Location	5
Smart FET	6
SYSTEM	7
RELAY CONTROL SYSTEM	7
RELAY CONTROL SYSTEM : System Description	7
RELAY CONTROL SYSTEM : Fail-safe	8
POWER CONTROL SYSTEM	11
POWER CONTROL SYSTEM : System Description	11
SIGNAL BUFFER SYSTEM	11
SIGNAL BUFFER SYSTEM : System Description	12
POWER CONSUMPTION CONTROL SYSTEM	12
POWER CONSUMPTION CONTROL SYSTEM : System Description	12
ENERGY MANAGEMENT SYSTEM	13
ENERGY MANAGEMENT SYSTEM : System Description	13
DIAGNOSIS SYSTEM (IPDM E/R)	14
CONSULT Function (IPDM E/R)	14
ECU DIAGNOSIS INFORMATION	22
IPDM E/R	22
Reference Value	22
Fail-safe	34
DTC Inspection Priority Chart	37
DTC Index	38
WIRING DIAGRAM	41
IPDM E/R	41
Wiring Diagram	41
BASIC INSPECTION	47
ADDITIONAL SERVICE WHEN REPLACING IPDM E/R	47
Description	47
Work Procedure	47
CONFIGURATION (IPDM E/R)	48
Description	48
Work Procedure	48
Configuration list	49
CUMULATIVE BATTERY DISCHARGE CURRENT CLEAR	51
Description	51
Work Procedure	51
DTC/CIRCUIT DIAGNOSIS	52
U1000 CAN COMM CIRCUIT	52
DTC Description	52
Diagnosis Procedure	53
B120E IPDM E/R	54
DTC Description	54
Diagnosis Procedure	54
B20DD IGNITION RELAY ON CIRCUIT	55
DTC Description	55
Diagnosis Procedure	55
B20DE IGNITION RELAY OFF CIRCUIT	58
DTC Description	58

Diagnosis Procedure	58	Work Flow	97
POWER SUPPLY AND GROUND CIRCUIT	59	PROCEDURE FOR TEMPORARILY DIS- ABLING THE IGNITION BATTERY SAVER SYSTEM	100
Diagnosis Procedure	59	Description	100
REMOVAL AND INSTALLATION	60	Work Procedure	100
IPDM E/R	60	DTC/CIRCUIT DIAGNOSIS	101
Exploded View	60	B261A PUSH-BUTTON IGNITION SWITCH ...	101
Removal and Installation	60	DTC Description	101
POWER DISTRIBUTION SYSTEM		Diagnosis Procedure	101
PRECAUTION	62	B26F1 IGNITION RELAY	103
PRECAUTIONS	62	DTC Description	103
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	62	Diagnosis Procedure	103
Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	62	Component Inspection	104
Precautions for Removing Battery Terminal	63	B26F2 IGNITION RELAY	105
SYSTEM DESCRIPTION	65	DTC Description	105
COMPONENT PARTS	65	Diagnosis Procedure	105
Component Parts Location	65	Component Inspection	106
Push-button Ignition Switch	66	ACCESSORY RELAY	107
SYSTEM	67	Diagnosis Procedure	107
POWER DISTRIBUTION SYSTEM	67	Component Inspection	108
POWER DISTRIBUTION SYSTEM : System De- scription	67	POWER SUPPLY AND GROUND CIRCUIT ...	109
AUTO ACC FUNCTION	68	Diagnosis Procedure	109
AUTO ACC FUNCTION : System Description	68	PUSH-BUTTON IGNITION SWITCH	110
Fail-safe	71	Component Function Check	110
DIAGNOSIS SYSTEM (BCM)	73	Diagnosis Procedure	110
COMMON ITEM	73	Component Inspection	111
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	73	SYMPTOM DIAGNOSIS	113
INTELLIGENT KEY	74	PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE	113
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (With Super Lock)	74	Diagnosis Procedure	113
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (Without Super Lock)	78	ACCESSORY POWER SUPPLY IS NOT SUP- PLIED EVEN IF DOOR IS UNLOCKED BY KEY	114
ECU DIAGNOSIS INFORMATION	83	ALL SWITCHES AND UNITS	114
BCM	83	ALL SWITCHES AND UNITS : Diagnosis Pro- cedure	114
List of ECU Reference	83	EXCEPT AUDIO/NAVIGATION	114
WIRING DIAGRAM	84	EXCEPT AUDIO/NAVIGATION : Diagnosis Pro- cedure	114
POWER DISTRIBUTION SYSTEM	84	AUDIO/NAVIGATION ONLY	114
Wiring Diagram	84	AUDIO/NAVIGATION ONLY : Diagnosis Pro- cedure	114
BASIC INSPECTION	97	REMOVAL AND INSTALLATION	116
DIAGNOSIS AND REPAIR WORK FLOW	97	PUSH-BUTTON IGNITION SWITCH	116
		Removal and Installation	116

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010741698

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing Battery Terminal

INFOID:0000000010869315

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.


HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.



SEF289H

PRECAUTIONS

[IPDM E/R]

< PRECAUTION >

2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000010741700



A Engine room (LH)

① IPDM E/R

A
B
C
D
E
F
G
H
I
J
K
L

PCS

N
O
P

COMPONENT PARTS

[IPDM E/R]

< SYSTEM DESCRIPTION >


Smart FET

INFOID:000000010741701

Smart FET, that uses MOS field effect transistor, is adopted for each lamps control.

NOTE:


A MOS field effect transistor is a transistor in which the gate is composed of a metal-oxide-semiconductor (MOS). Field effect transistor is controlled by voltage, while ordinary transistor is controlled by current. Electrode of field effect transistor is called source, drain, or gate, while electrode of ordinary transistor is called emitter, collector, or base.



< SYSTEM DESCRIPTION >

SYSTEM**RELAY CONTROL SYSTEM****RELAY CONTROL SYSTEM : System Description**

INFOID:0000000010741702

SYSTEM DIAGRAM

JMMIA1829GB

A
B
C
D
E
F
G
H
I
J
K
L
PCS
N
O
P

DESCRIPTION

IPDM E/R activates the internal control circuit to perform the relay ON-OFF control according to the input signals from various sensors and the request signals received from control units via CAN communication.

NOTE:

To prevent damage to the parts, IPDM E/R integrated relays cannot be removed.

Control relay	Input/output	Transmit unit	Control part	Reference page
• Front wiper relay • Front wiper HI/LO relay	Front wiper request signal	BCM (CAN)	Front wiper motor	WW-13
	Front wiper stop position signal	Front wiper motor		

SYSTEM

[IPDM E/R]

< SYSTEM DESCRIPTION >

Control relay	Input/output	Transmit unit	Control part	Reference page
Ignition relay	Ignition switch ON signal	BCM (CAN)	Each control unit, sensor, actuator and relay (Ignition power supply)	PCS-55
	Vehicle speed signal (Meter)	Combination meter (CAN)		
	Push-button ignition switch signal	Push-button ignition switch		
Cooling fan relay 1	Cooling fan speed request signal	ECM (CAN)	Cooling fan	EC-57
Headlamp washer relay	Headlamp washer relay	BCM (CAN)	Headlamp washer pump	WW-25

RELAY CONTROL SYSTEM : Fail-safe

INFOID:000000010741703

FAIL-SAFE CONTROL BY DTC

IPDM E/R performs fail-safe control when any DTC are detected.

DTC	CONSULT display description	Fail-safe	
B121D	S/L LOCK PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply until the vehicle switches to sleep status.
B121A	FR FOG LAMP LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the front fog lamp LH power supply circuit until the front fog lamp ON conditions are no longer satisfied.
B1231	DTRL RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the daytime running light RH power supply circuit until the daytime running light ON conditions are no longer satisfied.
B1256	FR FOG LAMP RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the front fog lamp RH power supply circuit until the front fog lamp ON conditions are no longer satisfied.
B1C00	HEIGHT SENSOR PWR SPLY CIRC	[CIRC SHORT TO GRND] [CIRC SHORT TO BATTERY]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C01	FR HEIGHT SENSOR SIGNAL	[CIRC SHORT TO BATTERY] [CIRC SHORT TO GROUND OR OPEN] [CIRC VOLTAGE OUT OF RANGE]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C02	RR HEIGHT SENSOR SIGNAL	[CIRC SHORT TO BATTERY] [CIRC SHORT TO GROUND OR OPEN] [CIRC VOLTAGE OUT OF RANGE]	Right and left headlamp aiming motors stop at the position when DTC is detected.

SYSTEM

[IPDM E/R]

< SYSTEM DESCRIPTION >

DTC	CONSULT display description		Fail-safe
B1C07	AIMING MOTOR DRIVE SIGNAL	[CIRC SHORT TO GRND]	Right and left headlamp aiming motors stop at the position when DTC is detected.
		[CIRC SHORT TO BATTERY]	
		[SIGNAL COMPARE FAILURE]	
B1C11	FR HEIGHT SENSOR SIGNAL	[SIG PRTCTN CLCLTN IN-CRCT]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C12	RR HEIGHT SENSOR SIGNAL	[SIG PRTCTN CLCLTN IN-CRCT]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B20CB	DTRL LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the daytime running light LH power supply circuit until the daytime running light ON conditions are no longer satisfied.
B20BD	BATTERY CURRENT SENSOR	[CIRC SHORT TO GRND]	Inhibit stop/start system operation
		[CIRC SHORT TO BATTERY]	
		[CIRC OPEN]	
		[CMPNENT INTERNAL MLFNCTN]	
B20CE	HL (HI) LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (HI) LH power supply circuit until the headlamp (HI) ON conditions are no longer satisfied.
B20CF	HL (HI) RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (HI) RH power supply circuit until the headlamp (HI) ON conditions are no longer satisfied.
B20D0	HL (LO) LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (LO) LH power supply circuit until the headlamp (LO) ON conditions are no longer satisfied.
B20D1	HL (LO) RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (LO) RH power supply circuit until the headlamp (LO) ON conditions are no longer satisfied.
B20D2	PARKING LAMP PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the parking lamp (LH/RH) power supply circuit until the parking lamp, license plate lamp, and tail lamp ON conditions are no longer satisfied.
B20D4	TAIL LAMP LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the following power supply circuits until the parking lamp, license plate lamp, and tail lamp ON conditions are no longer satisfied. <ul style="list-style-type: none"> • Tail lamp LH (body side) • Tail lamp LH (back door side) • License plate lamp LH • License plate lamp RH
B20D5	TAIL LAMP RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the following power supply circuits until the parking lamp, license plate lamp, and tail lamp ON conditions are no longer satisfied. <ul style="list-style-type: none"> • Tail lamp RH (body side) • Tail lamp RH (back door side)

SYSTEM

[IPDM E/R]

< SYSTEM DESCRIPTION >

DTC	CONSULT display description		Fail-safe
B20DB	HEIGHT SENS INITIALIZE NOT DONE	[MISSING CALIBRATION]	Right and left headlamp aiming motors fix at the initial aiming position.
		[NOT CONFIURED]	
B20E2	LED HEADLAMP RH	[COMPONENT INTERNAL MLFNCTN]	Transmits the headlamp warning signal (CAN communication) to the combination meter when the headlamp (LO) ON conditions are satisfied. (When the ignition switch turns ON, the headlamp warning is displayed on the information display of the combination meter.)
B20E3	LED HEADLAMP LH	[COMPONENT INTERNAL MLFNCTN]	Transmits the headlamp warning signal (CAN communication) to the combination meter when the headlamp (LO) ON conditions are satisfied. (When the ignition switch turns ON, the headlamp warning is displayed on the information display of the combination meter.)

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> The cooling fan is operated at HI operation when the ignition switch is turned ON. Turn OFF the cooling fan operation when the ignition switch is turned OFF.
A/C compressor	A/C relay OFF

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> Turns ON the headlamp (LO) when the ignition switch is turned ON. Turns OFF the headlamp (LO) when the ignition switch is turned OFF. Headlamp (HI): OFF
• Parking lamp • License plate lamp • Illumination • Tail lamp	<ul style="list-style-type: none"> Turns ON the tail lamp, parking lamp, license plate lamp and each illumination when the ignition switch is turned ON. Turns OFF the tail lamp, parking lamp, license plate lamp and each illumination when the ignition switch is turned OFF.
Front wiper	<ul style="list-style-type: none"> The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Daytime running light	Daytime running light: OFF
Front fog lamp	Front fog lamp: OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay: OFF
Headlamp washer	Headlamp washer relay: OFF

IGNITION RELAY CONTROL

- IPDM E/R monitors the voltage at the contact circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay control condition		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—

SYSTEM

[IPDM E/R]

< SYSTEM DESCRIPTION >

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay control condition		
ON	OFF	Ignition relay ON stuck	Detects DTC [B20DD: IGN RELAY ON CIRC]
OFF	ON	Ignition relay OFF stuck	Detects DTC [B20DE: IGN RELAY OFF CIRC]

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by front wiper stop position signal.

When front wiper stop position signal is in the condition listed below while the front wiper is operating, IPDM E/R activates the fail-safe.


Ignition switch	Front wiper switch	Front wiper stop position signal	Fail-safe
ON	OFF	The signal does not change from the battery voltage for 10 seconds.	Stops front wiper power supply for 20 seconds
	Except OFF	The signal does not change for 10 seconds.	

POWER CONTROL SYSTEM

POWER CONTROL SYSTEM : System Description

INFOID:0000000010741704

SYSTEM DIAGRAM



EACH LAMP CONTROL


IPDM E/R controls the smart FET to control each lamp according to the control signal status of each lamp received via CAN communication. Refer to [EXL-21, "HEADLAMP SYSTEM : System Description"](#) (LED headlamp) or [EXL-225, "HEADLAMP SYSTEM : System Description"](#) (halogen headlamp).

COOLING FAN CONTROL

IPDM E/R controls the cooling fan according to the cooling fan control signal received from ECM via CAN communication. Refer to [EC-57, "COOLING FAN CONTROL : System Description"](#).

SIGNAL BUFFER SYSTEM

SYSTEM DIAGRAM




DESCRIPTION

- IPDM E/R reads the status of the hood switch and transmits the hood switch signal to ECM and BCM via CAN communication.
- IPDM E/R receives the oil pressure switch signal from oil pressure switch and transmits the oil pressure signal to BCM via CAN communication.
- IPDM E/R receives the reverse position signal from transmission range switch and transmits the reverse position signal to BCM via CAN communication. (CVT models)
- IPDM E/R receives the reverse position signal and neutral position signal from reverse/neutral position switch. IPDM E/R transmits the reverse position signal and neutral position signal to BCM via CAN communication. (With MR20 engine with M/T models)
- IPDM E/R receives the reverse position signal from back-up lamp switch and transmits the reverse position signal to BCM via CAN communication. (With R9M engine and M/T models)

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Description

SYSTEM DIAGRAM



DESCRIPTION

Outline

< SYSTEM DESCRIPTION >

- IPDM E/R incorporates a power consumption control function that reduces the power consumption according to the vehicle status.
- IPDM E/R changes its status (control mode) with the sleep wake up signal received from BCM via CAN communication.

Normal mode (wake-up)

- CAN communication is normally performed with other control units.
- Individual unit control by IPDM E/R is normally performed.

Low power consumption mode (sleep)

- Low power consumption control is active.
- CAN transmission is stopped.

Sleep Mode Activation

- IPDM E/R judges that the sleep-ready conditions are fulfilled when the ignition switch is OFF and none of the conditions below are present. Then it transmits a sleep-ready signal (ready) to BCM via CAN communication.
 - Outputting signals to actuators
 - Output requests are being received from control units via CAN communication.
- IPDM E/R stops CAN communication and enters the low power consumption mode when it receives a sleep wake up signal (sleep) from BCM and the sleep-ready conditions are fulfilled.

Wake-Up Operation


- IPDM E/R changes from the low power consumption mode to the normal mode when it receives a sleep wake-up signal (wake up) from BCM or any of the following conditions is fulfilled. In addition, it transmits a sleep-ready signal (not-ready) to BCM via CAN communication to report the CAN communication start.
 - Ignition switch ON
 - Hood switch status changes.
 - An output request is received from a control unit via CAN communication.

ENERGY MANAGEMENT SYSTEM

ENERGY MANAGEMENT SYSTEM : System Description

INFOID:0000000010931269

SYSTEM DIAGRAM



IPDM E/R has an energy management system that recognizes the battery status from the battery current signal from the battery current sensor, the battery temperature sensor signal, and the battery voltage from the battery and maintains normal battery status. Refer to the following for details.

- Charging system control: [CHG-8, "ENERGY MANAGEMENT SYSTEM : System Description"](#)
- Stop/Start system control: [EC-856, "STOP/START SYSTEM : System Description \(CVT models\)"](#) or [EC-848, "STOP/START SYSTEM : System Description \(M/T models\)"](#).

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)

CONSULT Function (IPDM E/R)

INFOID:0000000010741707

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Work Support	Changes the setting for each system function.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
Ecu Identification	Allows confirmation of IPDM E/R part number.
Configuration	<ul style="list-style-type: none"> • Read and save the vehicle specification. • Write the vehicle specification when replacing IPDM E/R.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

SELF DIAGNOSTIC RESULT

Refer to [PCS-38, "DTC Index"](#).

Freeze Frame Data (FFD)

The IPDM E/R records the vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	Description
REVERSE SIGNAL [Open/Close]	Displays the status of reverse position signal judged by IPDM E/R.
IGN RELAY [Open/Close]	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Open/Close]	Displays the status of the push-button ignition switch judged by IPDM E/R.
NEUTRAL SW [Open/Close]	Displays the status of the neutral position signal (M/T) judged by IPDM E/R.
INTERLOCK/PNP SW [Open/Close]	Displays the status of the transmission range switch (CVT) judged by IPDM E/R.
OIL PRESSURE SW [Open/Close]	Displays the status of the oil pressure switch judged by IPDM E/R.
LED H/L RH STATUS [Open/Close]	<p>Displays the LED headlamp (right) ON/OFF status judged by IPDM E/R.</p> <p>NOTE: This item is monitored only on the vehicle with LED headlamp.</p>
LED H/L LH STATUS [Open/Close]	<p>Displays the LED headlamp (left) ON/OFF status judged by IPDM E/R.</p> <p>NOTE: This item is monitored only on the vehicle with LED headlamp.</p>
HOOD SW [Open/Close]	Displays the status of the hood switch judged by IPDM E/R.
COMPRESSOR [Off/On]	Displays the compressor drive status judged by IPDM E/R.
H/L WASHER PUMP [Off/On]	Displays the status of the headlamp washer relay judged by IPDM E/R.

DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
HORN RELAY [Off/On]	Displays the status of the horn relay judged by IPDM E/R.
COOLING FAN [Off/On]	Displays the cooling fan relay-4 drive status judged by IPDM E/R.
FRONT WIPER HI/LO RELAY [Off/On]	Displays the front wiper HI/LO relay drive status judged by IPDM E/R.
FRONT WIPER RELAY [Off/On]	Displays the front wiper relay drive status judged by IPDM E/R.
IGN RELAY OFF STATUS [Off/On]	Displays the status of the ignition relay OFF circuit judged by IPDM E/R.
IGN RELAY ON STATUS [Off/On]	Displays the status of the ignition relay ON circuit judged by IPDM E/R.
STEERING LOCK PWR SPLY [Off/On]	Displays the power supply status from IPDM E/R to the steering lock unit. NOTE: This item is monitored only on the vehicle with Intelligent Key system
HEIGHT SENSOR PWR SPLY [Off/On]	Displays the power supply status from IPDM E/R to the height sensor.
COOLING FAN RELAY 1 [Off/On]	Displays the status of the cooling fan relay-1 judged by IPDM E/R.
STARTER RELAY [Off/On]	Displays the status of the starter relay judged by IPDM E/R.
COMP ECV DUTY [%]	Displays the compressor control signal (PWM) status of IPDM E/R.
COOLING FAN RELAY 2 [%]	Displays the status of the cooling fan relay-5 judged by IPDM E/R.
FR FOG LAMP LH [%]	Displays the front fog lamp (left) output (PWM) status of IPDM E/R.
FR FOG LAMP RH [%]	Displays the front fog lamp (right) output (PWM) status of IPDM E/R.
LEVELIZER OUTPUT [%]	Displays the aiming motor drive signal (PWM) status of IPDM E/R.
PARKING LAMP [%]	Displays the parking lamp output (PWM) status of IPDM E/R.
TAIL LAMP LH [%]	Displays the tail lamp (left) output (PWM) status of IPDM E/R.
TAIL LAMP RH [%]	Displays the tail lamp (right) output (PWM) status of IPDM E/R.
DAYTIME RUNNING LIGHT LH [%]	Displays the daytime running light (left) output status of IPDM E/R.
DAYTIME RUNNING LIGHT RH [%]	Displays the daytime running light (right) output status of IPDM E/R.
HEADLAMP (HI) LH [%]	Displays the headlamp (HI) (left) output (PWM) status of IPDM E/R.
HEADLAMP (HI) RH [%]	Displays the headlamp (HI) (right) output (PWM) status of IPDM E/R.
HEADLAMP (LO) LH [%]	Displays the headlamp (LO) (left) output (PWM) status of IPDM E/R.
HEADLAMP (LO) RH [%]	Displays the headlamp (LO) (right) output (PWM) status of IPDM E/R.
A/C RELAY STUCK [OK/NG]	Displays the ON stuck status of the A/C relay judged by IPDM E/R.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Monitor Item [Unit]	Description
A/C RELAY [Off/On]	Displays the status of the A/C relay judged by IPDM E/R.
COMP ECV STATUS [OK/NG]	Displays the compressor malfunction diagnosis status judged by IPDM E/R.
VEHICLE SECURITY HORN [Off/On]	NOTE: The item is indicated, but not monitored.
BATTERY CURRENT SENSOR [OK/NG]	Displays the battery current sensor malfunction diagnosis status judged by IPDM E/R.
FRONT FOG LAMP [Off/On]	Displays the fog lamp illumination control status of IPDM E/R.
COMP ECV CURRENT [A]	Displays the electric current output to compressor judged by IPDM E/R.
BATTERY VOLTAGE [V]	Displays the status of the battery voltage judged by IPDM E/R.
COOLING FAN DUTY [%]	Displays the cooling fan output signal status of IPDM E/R.
HOOD SW (CAN) [Open/Close/NG]	Displays the status of the hood switch judged by IPDM E/R.
FRONT WIPER [STOP/HIGH/LOW/NG]	Displays the front wiper motor drive control status of IPDM E/R.
FR WIPER STOP POSITION [ACTIVE P/STOP P]	Displays the status of the front wiper position status judged by IPDM E/R.
HEADLAMP (HI) [Off/On]	Displays the headlamp (HI) illumination control status of IPDM E/R.
HEADLAMP (LO) [Off/On]	Displays the headlamp (LO) illumination control status of IPDM E/R.
IGNITION RELAY STATUS [Off/On]	Displays the ignition relay output status of IPDM E/R.
IGN RELAY MONITOR [Off/On]	Displays the status of the ignition relay judged by IPDM E/R.
IGNITION POWER SUPPLY [Off/On]	Displays the status of the ignition power supply judged by IPDM E/R.
INTERLOCK/PNP SW (CAN) [Off/On]	Displays the status of the transmission range switch signal that IPDM transmits via CAN communication.
NEUTRAL SWITCH (CAN) [Off/On/NG]	Displays the status of the neutral position switch (M/T) signal that IPDM transmits via CAN communication.
PUSH-BUTTON IGN SW (CAN) [Off/On]	Displays the status of the ignition switch signal that IPDM transmits via CAN communication.
TAIL LAMP [Off/On]	Displays the tail lamp illumination control status of IPDM E/R.
REVERSE SIGNAL (CAN) [Off/On/NG]	Displays the status of the reverse switch (M/T) signal that IPDM transmits via CAN communication.
ST&ST CONT RELAY STATUS [Off/Off, ON/ST R On]	Displays the status of the start control relay and start motor relay status judged by IPDM E/R.
STARTER MOTOR STATUS [Off/On/L-TIME]	Displays the status of the starter motor judged by IPDM E/R.
STARTER RELAY (CAN) [LOW/HIGH/NG]	Displays the status of the IPDM E/R transmits the starter control relay status signal via CAN communication.
IPDM NOT SLEEP [NO RDY/READY]	Displays the status of the IPDM E/R transmits the not sleep signal via CAN communication.

DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
AFTER COOLING TIME [No request/0.5min/1.0min/1.5min/ 2.0min/2.5min/3.0min/3.5min/4min/5min/ 6min/8min/10min/12min/14min/16min]	NOTE: The item is indicated, but not monitored.
AFTER COOLING SPEED [0%/25%/40%/55%/70%/78%/85%/ 100%]	NOTE: The item is indicated, but not monitored.
COOLING FAN TYPE [RENAULT/NISSAN]	NOTE: The item is indicated, but not monitored.
COMPRESSOR REQ 1 [Off/On]	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
VHCL SECURITY HORN REQ [Off/On]	NOTE: The item is indicated, but not monitored.
DTRL REQ [Off/On]	Displays the status of the daytime running light request signal received from BCM via CAN communication.
SLEEP/WAKE UP [SLEEP/WAKEUP]	NOTE: The item is indicated, but not monitored.
CLUTCH INTERLOCK SW [Off/On/NG]	NOTE: The item is indicated, but not monitored.
CRANKING ENABLE-TCM [OK/NG]	Displays the status of the cranking enable signal received from TCM via CAN communication.
CRANKING ENABLE-ECM [OK/NG/STOP/No request]	Displays the status of the cranking enable signal received from ECM via CAN communication.
CAN DIAGNOSIS [OK/NG]	Displays the status of the CAN diagnosis signal received from BCM via CAN communication.
FRONT FOG LAMP REQ [Off/On]	Displays the status of the front fog light request signal received from BCM via CAN communication.
H/L WASHER REQ [Off/On]	Displays the status of the headlamp washer request signal received from BCM via CAN communication.
PASSING REQ [Off/On]	NOTE: The item is indicated, but not monitored.
HIGH BEAM REQ [Off/On]	Displays the status of the high beam request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]	Displays the status of the horn reminder signal received from BCM via CAN communication.
COOLING FAN REQ [%]	Displays the status of the cooling fan speed request signal received from ECM via CAN communication.
ENGINE STATUS [STOP/IDLING/RUN]	Displays the status of the engine status signal received from ECM via CAN communication.
TURN SIGNAL REQ [Off/LH/RH]	Displays the status of the turn indicator signal received from BCM via CAN communication.
FR WIPER REQ [RETURN/STOP/NG/LOW/HIGH]	Displays the status of the front wiper request signal received from BCM via CAN communication.
SHIFT POSITION [OFF/P/R/N/D/S/L/B/1/2/3/4/5/6/7]	Displays the status of the shift position signal received from TCM via CAN communication.
LOW BEAM REQ [Off/On]	Displays the status of the low beam request signal received from BCM via CAN communication.
POSITION LIGHT REQ [Off/On]	Displays the status of the position light request signal received from BCM via CAN communication.
COMPRESSOR REQ 2 [Off/On]	Displays the status of the A/C ON signal received from A/C auto amp. via CAN communication.
IGNITION SW [Off/On/START/No request]	Displays the status of the ignition switch ON signal and starter control relay request signal received from BCM via CAN communication.

A
B
C
D
E
F
G
H
I
J
K
L
PCS
N
O
P

DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
VEHICLE SPEED (METER) [km/h]	Displays the status of the A/C ON signal received from A/C auto amp. via CAN communication.
BAT DISCHARGE COUNT [—]	Monitor the cumulative discharge value of the battery. NOTE: When 65,000 or more is counted, replace the battery.
P LAMP CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the parking lamp circuit. NOTE: When the number of parking lamp circuit retries count is 20, this item counts 1.
NMB P LAMP CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the parking lamp circuit. NOTE: When the number of short circuits in the parking lamp circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB P LAMP CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the parking lamp circuit.
DTRL LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the daytime running light (left) circuit. NOTE: When the number of daytime running light (left) circuit retries count is 20, this item counts 1.
NMB DTRL LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the daytime running light (left) circuit. NOTE: When the number of short circuits in the daytime running light (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB DTRL LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the daytime running light (left) circuit.
DTRL RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the daytime running light (right) circuit. NOTE: When the number of daytime running light (right) circuit retries count is 20, this item counts 1.
NMB DTRL RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the daytime running light (right) circuit. NOTE: When the number of short circuits in the daytime running light (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB DTRL RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the daytime running light (right) circuit.
F FOG LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the front fog lamp (left) circuit. NOTE: When the number of front fog lamp (left) circuit retries count is 20, this item counts 1.
NMB F FOG LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the front fog lamp (left) circuit. NOTE: When the number of short circuits in the front fog lamp (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB F FOG LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the front fog lamp (left) circuit.
F FOG RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the front fog lamp (right) circuit. NOTE: When the number of front fog lamp (right) circuit retries count is 20, this item counts 1.

DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
NMB F FOG RH CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the front fog lamp (right) circuit.</p> <p>NOTE: When the number of short circuits in the front fog lamp (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB F FOG RH CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the front fog lamp (right) circuit.</p>
HL (HI) LH CIRC MALFUNCTN [0 – 1]	<p>Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (HI) (left) circuit.</p> <p>NOTE: When the number of headlamp (HI) (left) circuit retries count is 20, this item counts 1.</p>
NMB HL (HI) LH CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (HI) (left) circuit.</p> <p>NOTE: When the number of short circuits in the headlamp (HI) (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB HL (HI) LH CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (HI) (left) circuit.</p>
HL (HI) RH CIRC MALFUNCTN [0 – 1]	<p>Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (HI) (right) circuit.</p> <p>NOTE: When the number of headlamp (HI) (right) circuit retries count is 20, this item counts 1.</p>
NMB HL (HI) RH CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (HI) (right) circuit.</p> <p>NOTE: When the number of short circuits in the headlamp (HI) (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB HL (HI) RH CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (HI) (right) circuit.</p>
S/L CIRC MALFUNCTN [0 – 1]	<p>Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the steering lock circuit.</p> <p>NOTE: When the number of steering lock circuit retries count is 20, this item counts 1.</p>
NMB S/L CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the steering lock circuit.</p> <p>NOTE: When the number of short circuits in the steering lock circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB S/L CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the steering lock circuit.</p>
HL (LO) LH CIRC MALFUNCTN [0 – 1]	<p>Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (LO) (left) circuit.</p> <p>NOTE: When the number of headlamp (LO) (left) circuit retries count is 20, this item counts 1.</p>
NMB HL (LO) LH CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (LO) (left) circuit.</p> <p>NOTE: When the number of short circuits in the headlamp (LO) (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB HL (LO) LH CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (LO) (left) circuit.</p>
HL (LO) RH CIRC MALFUNCTN [0 – 1]	<p>Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (LO) (right) circuit.</p> <p>NOTE: When the number of headlamp (LO) (right) circuit retries count is 20, this item counts 1.</p>

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Monitor Item [Unit]	Description
NMB HL (LO) RH CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (LO) (right) circuit.</p> <p>NOTE: When the number of short circuits in the headlamp (LO) (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB HL (LO) RH CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (LO) (right) circuit.</p>
T LAMP LH CIRC MALFUNCTN [0 – 1]	<p>Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the tail lamp (left) circuit.</p> <p>NOTE: When the number of tail lamp (left) circuit retries count is 20, this item counts 1.</p>
NMB T LAMP LH CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the tail lamp (left) circuit.</p> <p>NOTE: When the number of short circuits in the tail lamp (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB T LAMP LH CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the tail lamp (left) circuit.</p>
T LAMP RH CIRC MALFUNCTN [0 – 1]	<p>Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the tail lamp (right) circuit.</p> <p>NOTE: When the number of tail lamp (right) circuit retries count is 20, this item counts 1.</p>
NMB T LAMP RH CIRC RETRY [0 – 20]	<p>Monitor the number of times that the smart FET in IPDM E/R permits the retry of the tail lamp (right) circuit.</p> <p>NOTE: When the number of short circuits in the tail lamp (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.</p>
NMB T LAMP RH CIRC SHORT [0 – 5]	<p>Monitor the number of times that the smart FET in IPDM E/R detects the over current of the tail lamp (right) circuit.</p>
BATTERY STATUS [OK/NG]	Monitor the battery status from the battery output.

ACTIVE TEST

Test item	Operation	Description
HORN	Off	OFF
	On	Operates horn relay for 20 ms.
HEADLAMP WASHER	Off	OFF
	On	Operates headlamp washer relay for 10 ms.
FRONT WIPER	Off	OFF
	Low	Operates the front wiper relay.
	High	Operates the front wiper relay and front wiper HI/LO relay.
COMPRESSOR	Off	OFF
	On	Operates the A/C relay.
COOLING FAN (MONO)	Off	OFF
	Lo	Run the cooling fan at low speed.
	Hi	Run the cooling fan at high speed.
HEADLAMP (HI)	Off	OFF
	On	Operates the headlamp (HI)
HEADLAMP (LO)	Off	OFF
	On	Operates the headlamp (LO).

DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

Test item	Operation	Description
FRONT FOG LAMP	Off	OFF
	On	Operates the front fog lamp.
DAYTIME RUNNING LIGHT	Off	OFF
	On	Operates the parking lamp (daytime running light operation).
PARKING LAMP	Off	OFF
	On	Operates the parking lamp.
TAIL LAMP	Off	OFF
	On	Operates the tail lamp.
OPTIC AXIS ACTIVE TEST	Default	Return the optical axis to the default position. NOTE: While the headlamp is OFF, it does not return to the default position.
	Lower	Adjust the optical axis to the lowermost point.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION**IPDM E/R****Reference Value**

INFOID:0000000010741708

VALUES ON THE DIAGNOSIS TOOL**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor	Condition		Value/Status
REVERSE SIGNAL	Ignition switch ON	Selector lever in R position	CLOSE
		Selector lever in any position other than R	OPEN
IGN RELAY	Ignition switch OFF		OPEN
	Ignition switch ON		CLOSE
PUSH SW	Release the push-button ignition switch		OPEN
	Press the push-button ignition switch		CLOSE
NEUTRAL SW	Ignition switch ON	Selector lever in N position	CLOSE
		Selector lever in any position other than N	OPEN
INTERLOCK/PNP SW	Ignition switch ON	Selector lever in P or N position	CLOSE
		Selector lever in any position other than P or N	OPEN
OIL PRESSURE SW	Ignition switch OFF or engine running		OPEN
	Ignition switch ON		CLOSE
LED H/L RH STATUS	Lighting switch OFF		CLOSE
	Lighting switch 2ND or AUTO (light is illuminated)		OPEN
LED H/L LH STATUS	Lighting switch OFF		CLOSE
	Lighting switch 2ND or AUTO (light is illuminated)		OPEN
HOOD SW	Close the hood		OPEN
	Open the hood		CLOSE
COMPRESSOR	Engine running	A/C switch OFF	OFF
		A/C switch ON	ON
H/L WASHER PUMP	Not operating		OFF
	Headlamp washer operating		ON
HORN RELAY	Horn	Not operation	OFF
		Other than above	ON
COOLING FAN	Cooling fan	Stop or High speed operation	OFF
		Low speed operation	ON
FRONT WIPER HI/LO RELAY	Ignition switch ON	Front wiper HI operated	ON
		Other than above	OFF
FRONT WIPER RELAY	Ignition switch ON	Front wiper is operating	ON
		Other than above	OFF
IGN RELAY OFF STATUS	Ignition switch OFF		ON
	Ignition switch ON		OFF
IGN RELAY ON STATUS	Ignition switch ON		ON
	Ignition switch OFF		OFF

< ECU DIAGNOSIS INFORMATION >

Monitor	Condition		Value/Status
STEERING LOCK PWR SPLY NOTE: Only models with Intelligent Key	Ignition switch OFF		ON
	Ignition switch ON		OFF
HEIGHT SENSOR PWR SPLY	Ignition switch ON		ON
	Ignition switch OFF		OFF
COOLING FAN RELAY 1	Cooling fan	Low speed operation	ON
		Stop or high speed operation	OFF
STARTER RELAY	Engine	Cranking	ON
		Other than above	OFF
COMP ECV DUTY	Engine running	A/C switch OFF	0 %
		A/C switch ON	0 – 100 %
COOLING FAN RELAY 2	Cooling fan	Stop or low speed operation	0 %
		High speed operation	100 %
FR FOG LAMP LH	Lighting switch 1ST, 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	0 %
		Front fog lamp switch ON	80 – 100 %
FR FOG LAMP RH	Lighting switch 1ST, 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	0 %
		Front fog lamp switch ON	80 – 100 %
LEVELIZER OUTPUT	Lighting switch 2ND or AUTO (light is illuminated)	Headlamp aiming: Unloaded vehicle condition	70.0 %
		Headlamp aiming: Low	Value decreases from the unladen status.
PARKING LAMP	Lighting switch OFF		0 %
	Lighting switch 1ST, 2ND or AUTO (light is illuminated)		100 %
TAIL LAMP LH	Lighting switch OFF		0 %
	Lighting switch 1ST, 2ND or AUTO (light is illuminated)		100 %
TAIL LAMP RH	Lighting switch OFF		0 %
	Lighting switch 1ST, 2ND or AUTO (light is illuminated)		100 %
DAYTIME RUNNING LIGHT LH	Engine running	Lighting switch 1ST	0 %
		Lighting switch OFF	100 %
DAYTIME RUNNING LIGHT RH	Engine running	Lighting switch 1ST	0 %
		Lighting switch OFF	100 %
HEADLAMP (HI) LH	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch HI or PASS	80 – 100 %
		Lighting switch other than HI and PASS	0 %
HEADLAMP (HI) RH	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch HI or PASS	80 – 100 %
		Lighting switch other than HI and PASS	0 %
HEADLAMP (LO) LH	Lighting switch OFF		0 %
	Lighting switch 2ND or AUTO (light is illuminated)		80 – 100 %
HEADLAMP (LO) RH	Lighting switch OFF		0 %
	Lighting switch 2ND or AUTO (light is illuminated)		80 – 100 %
A/C RELAY STUCK	A/C relay	Normal	OK
		On stuck	NG

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< ECU DIAGNOSIS INFORMATION >

Monitor	Condition		Value/Status
A/C RELAY	Engine running	A/C switch OFF	OFF
		A/C switch ON (A/C compressor is operating)	ON
COMP ECV STATUS	Compressor	Normal	OK
		Malfunction	NG
VEHICLE SECURITY HORN	NOTE: This item is indicated, but not monitored.		OFF
BATTERY CURRENT SENSOR	Battery current sensor	Normal	OK
		Malfunction	NG
FRONT FOG LAMP	Lighting switch 1ST, 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	OFF
		Front fog lamp switch ON	ON
COMP ECV CURRENT	Compressor	Operating	0.00 A – 1.00 A
		Other than above	0.00 A
BATTERY VOLTAGE	Ignition switch ON		11 V – 14 V
COOLING FAN DUTY	Engine running		0 – 100%
HOOD SW (CAN)	Open the hood		OPEN
	Close the hood		CLOSE
	CAN communication system malfunction		NG
FRONT WIPER	Ignition switch ON	Front wiper stop	STOP
		Front wiper INT or LO operation	LOW
		Front wiper other than INT or LO operation	HIGH
		IPDM E/R cannot detect front wiper status	NG
FR WIPER STOP POSITION	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACTIVE P
HEADLAMP (HI)	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch HI or PASS	ON
		Other than above	OFF
HEADLAMP (LO)	Lighting switch OFF		OFF
	Lighting switch 2ND or AUTO (light is illuminated)		ON
IGNITION RELAY STATUS	Ignition switch ON		ON
	Ignition switch OFF		OFF
IGN RELAY MONITOR	Ignition switch ON		ON
	Ignition switch OFF		OFF
IGNITION POWER SUPPLY	Ignition switch ON		ON
	Ignition switch OFF		OFF
INTERLOCK/PNP SW (CAN)	Ignition switch ON	Selector lever in P or N position	ON
		Other than above	OFF
NEUTRAL SWITCH (CAN)	Ignition switch ON	Selector lever in N position	ON
		Other than above	OFF
	CAN communication system malfunction		NG
PUSH-BUTTON IGN SW (CAN) NOTE: Only models with Intelligent Key	Release the push-button ignition switch		OFF
	Press the push-button ignition switch		ON

< ECU DIAGNOSIS INFORMATION >

Monitor	Condition		Value/Status
TAIL LAMP	Lighting switch OFF		OFF
	Lighting switch 1ST, 2ND or AUTO (light is illuminated)		ON
REVERSE SIGNAL (CAN)	Ignition switch ON	Selector lever in R position	ON
		Other than above	OFF
	CAN communication system malfunction		NG
ST&ST CONT RELAY STATUS	Start control relay and start motor relay are OFF		OFF
	Start control relay is ON		OFF, ON
	Engine cranking		ST R ON
STARTER MOTOR STATUS	Engine	Cranking	ON
		Other than above	OFF
STARTER RELAY (CAN)	Engine	Cranking	HIGH
		Other than above	LOW
	CAN communication system malfunction		NG
IPDM NOT SLEEP	IPDM E/R	Operating	NO RDY
		Other than above	READY
AFTER COOLING TIME	NOTE: This item is indicated, but not monitored.		0min
AFTER COOLING SPEED	NOTE: This item is indicated, but not monitored.		0 %
COOLING FAN TYPE	NOTE: This item is indicated, but not monitored.		NISSAN
COMPRESSOR REQ1	Engine running	A/C switch OFF	OFF
		A/C switch ON	ON
VHCL SECURITY HORN REQ	NOTE: This item is indicated, but not monitored.		OFF
DTRL REQ	Engine running	Lighting switch 1ST	OFF
		Lighting switch OFF	ON
SLEEP/WAKE UP	NOTE: This item is indicated, but not monitored.		WAKEUP
CLUTCH INTERLOCK SW	NOTE: This item is indicated, but not monitored.		OFF
CRANKING ENABLE-TCM	Engine crank condition	Satisfied	OK
		Other than above	NG
CRANKING ENABLE-ECM	Engine crank condition	Satisfied	OK
		Other than above	NG
CAN DIAGNOSIS	Engine started		OK
	Other than above		NG
FRONT FOG LAMP REQ	Lighting switch 1ST, 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	OFF
		Front fog lamp switch ON	ON
H/L WASHER REQ	Not operating		OFF
	Headlamp washer operating		ON
PASSING REQ	NOTE: This item is indicated, but not monitored.		OFF
HIGH BEAM REQ	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch HI or PASS	ON
		Lighting switch other than HI and PASS	OFF

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< ECU DIAGNOSIS INFORMATION >

Monitor	Condition		Value/Status
HORN CHIRP	NOTE: This item is indicated, but not monitored.		OFF
COOLING FAN REQ	Engine running		0 – 100 %
ENGINE STATUS	Engine stopped		STOP
	Engine cranking		IDLING
	Engine running		RUN
TURN SIGNAL REQ	Turn signal switch	OFF	OFF
		Right	RH
		Left	LH
FR WIPER REQ	Ignition switch ON	Front wiper stopped	RETURN
		Front wiper INT or LO operation	LOW
		Front wiper HI operation	HIGH
		Front wiper forced termination	STOP
SHIFT POSITION	Ignition switch ON	Selector lever in P position	P
		Selector lever in R position	R
		Selector lever in N position	N
		Selector lever in D position	D
		Selector lever in L position	L
LOW BEAM REQ	Lighting switch OFF		OFF
	Lighting switch 2ND or AUTO (light is illuminated)		ON
POSITION LIGHT REQ	Lighting switch OFF		OFF
	Lighting switch 1ST, 2ND or AUTO (light is illuminated)		ON
COMPRESSOR REQ2	Engine running	A/C switch OFF	OFF
		A/C switch ON	ON
IGNITION SW	Ignition switch OFF		OFF
	Ignition switch ON		ON
	Ignition switch START		START
VEHICLE SPEED (METER)	While driving		Equivalent to speedometer reading
BAT DISCHARGE COUNT	Ignition switch ON		Discharge value of the battery
P LAMP CIRC MALFUNCTN	Parking lamp circuit reaches the retry upper limit.		0 – 1
NMB P LAMP CIRC RETRY	Retry of parking lamp circuit is permitted.		0 – 20
NMB P LAMP CIRC SHORT	Parking lamp circuit detects over current.		0 – 5
DTRL LH CIRC MAL-FUNCTN	Daytime running light LH circuit reaches the retry upper limit.		0 – 1
NMB DTRL LH CIRC RETRY	Retry of daytime running light LH circuit is permitted.		0 – 20
NMB DTRL LH CIRC SHORT	Daytime running light LH circuit detects over current.		0 – 5
DTRL RH CIRC MAL-FUNCTN	Daytime running light RH circuit reaches the retry upper limit.		0 – 1
NMB DTRL RH CIRC RETRY	Retry of daytime running light RH circuit is permitted.		0 – 20
NMB DTRL RH CIRC SHORT	Daytime running light RH circuit detects over current.		0 – 5
F FOG LH CIRC MAL-FUNCTN	Front fog lamp LH circuit reaches the retry upper limit.		0 – 1

< ECU DIAGNOSIS INFORMATION >

Monitor	Condition	Value/Status
NMB F FOG LH CIRC RETRY	Retry of front fog lamp LH circuit is permitted.	0 – 20
NMB F FOG LH CIRC SHORT	Front fog lamp LH circuit detects over current.	0 – 5
F FOG RH CIRC MAL-FUNCTN	Front fog lamp RH circuit reaches the retry upper limit.	0 – 1
NMB F FOG RH CIRC RETRY	Retry of front fog lamp RH circuit is permitted.	0 – 20
NMB F FOG RH CIRC SHORT	Front fog lamp RH circuit detects over current.	0 – 5
HL (HI) LH CIRC MAL-FUNCTN	Headlamp (HI) LH circuit reaches the retry upper limit.	0 – 1
NMB HL (HI) LH CIRC RETRY	Retry of headlamp (HI) LH circuit is permitted.	0 – 20
NMB HL (HI) LH CIRC SHORT	Headlamp (HI) LH circuit detects over current.	0 – 5
HL (HI) RH CIRC MAL-FUNCTN	Headlamp (HI) RH circuit reaches the retry upper limit.	0 – 1
NMB HL (HI) RH CIRC RETRY	Retry of headlamp (HI) RH circuit is permitted.	0 – 20
NMB HL (HI) RH CIRC SHORT	Headlamp (HI) RH circuit detects over current.	0 – 5
S/L CIRC MALFUNCTN NOTE: Only models with Intelligent Key	Steering lock circuit reaches the retry upper limit.	0 – 1
NMB S/L CIRC RETRY NOTE: Only models with Intelligent Key	Retry of steering lock circuit is permitted.	0 – 20
NMB S/L CIRC SHORT NOTE: Only models with Intelligent Key	Steering lock circuit detects over current.	0 – 5
HL (LO) LH CIRC MAL-FUNCTN	Headlamp (LO) LH circuit reaches the retry upper limit.	0 – 1
NMB HL (LO) LH CIRC RETRY	Retry of headlamp (LO) LH circuit is permitted.	0 – 5
NMB HL (LO) LH CIRC SHORT	Headlamp (LO) LH circuit detects over current.	0 – 20
HL (LO) RH CIRC MAL-FUNCTN	Headlamp (LO) RH circuit reaches the retry upper limit.	0 – 1
NMB HL (LO) RH CIRC RETRY	Retry of headlamp (LO) RH circuit is permitted.	0 – 20
NMB HL (LO) RH CIRC SHORT	Headlamp (LO) RH circuit detects over current.	0 – 5
T LAMP LH CIRC MAL-FUNCTN	Tail lamp LH circuit reaches the retry upper limit.	0 – 1
NMB T LAMP LH CIRC RETRY	Retry of tail lamp LH circuit is permitted.	0 – 20
NMB T LAMP LH CIRC SHORT	Tail lamp LH circuit detects over current.	0 – 5
T LAMP RH CIRC MAL-FUNCTN	Tail lamp RH circuit reaches the retry upper limit.	0 – 1

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N


O

P

< ECU DIAGNOSIS INFORMATION >

Monitor	Condition	Value/Status
NMB T LAMP RH CIRC RE-TRY	Retry of tail lamp RH circuit is permitted.	0 – 20
NMB T LAMP RH CIRC SHORT	Tail lamp RH circuit detects over current.	0 – 5
BATTERY STATUS	Engine: idling	Displays the battery status judgment results when starting with the ignition switch.

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value
		Signal name	Input/ Output		
+	-				
1 (R)	Ground	Battery power supply	Input	Ignition switch OFF	6 – 16 V
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF	6 – 16 V

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value
+	-	Signal name	Input/ Output			
3*2 (P)	Ground	Steering lock unit power supply	Output	Ignition switch OFF		6 – 16 V
				Ignition switch ON		0 – 1 V
4 (Y)	Ground	Tail lamp LH	Output	Lighting switch OFF		0 – 1 V
				Lighting switch 1ST, 2ND or AUTO (light is illuminated)		9 – 16 V
7 (L)	Ground	Headlamp washer re- lay control	Output	Ignition switch ON	Headlamp washer activat- ed	0 – 1 V
					Headlamp washer deacti- vated	9 – 16 V
8*8 (BG)	Ground	ECM relay	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 – 1 V
				<ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (For a few seconds after turning igni- tion switch OFF) 		6 – 16 V
9 (L)	Ground	Horn relay (control)	Output	Horn is deactivated		9 – 16 V
				Horn is activated		0 – 1 V
12 (B)	Ground	Ground	—	Ignition switch ON		0 – 1 V
16 (G)	Ground	Back up lamp	Output	Ignition switch ON	Selector lever in R	9 – 16 V
					Selector lever in any pos- ition other than R	0 – 1 V
17 (W)	Ground	Tail lamp RH	Output	Lighting switch OFF		0 – 1 V
				Lighting switch 1ST, 2ND or AUTO (light is illuminated)		9 – 16 V
19 (V)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 – 1 V
					Front wiper switch HI	9 – 16 V
20*13 (R)	Ground	Ignition power supply	Output	Ignition switch OFF		0 – 1 V
				Ignition switch ON		6 – 16 V
21*4 (LG)	Ground	Ignition power supply	Output	Ignition switch OFF		0 – 1 V
				Ignition switch ON		6 – 16 V
22 (Y)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch LO	
					Front wiper switch LO	
23 (B)	Ground	Ground	—	Ignition switch ON		0 – 1 V
24 (W)	Ground	Fuel pump relay	Output	<ul style="list-style-type: none"> Ignition switch OFF More than a few seconds after turning ignition switch ON 		0 – 1 V
				<ul style="list-style-type: none"> For a few seconds after turning igni- tion switch ON Engine running 		6 – 16 V
25 (LG)	Ground	Ignition power supply	Output	Ignition switch OFF		0 – 1 V
				Ignition switch ON		6 – 16 V
26*12 (W)	Ground	Front height sensor	Input	Ignition switch ON	Vehicle front height: Un- loaded vehicle condition	2.4 V
					Vehicle front height: Low	Voltage increases from the un- laden status.

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value
	Signal name	Input/ Output		
+	-			
27* ¹¹ (SB)	Ground	Rear height sensor	Input	Vehicle rear height: Unloaded vehicle condition
				Voltage increases from the unladen status.
28 (P)	Ground	CAN - L	Input/ Output	—
30 (L)	Ground	CAN - H	Input/ Output	—
31* ¹¹ (G)	Ground	Height sensor power supply	Output	Ignition switch ON
32* ¹¹ (B)	Ground	Height sensor ground	—	Ignition switch ON
33 (BG)	Ground	G sensor power supply	Input	Ignition switch ON
34 (LG)	Ground	G sensor ground	—	Ignition switch ON
35 (V)	Ground	G sensor	Input	Ignition switch ON Vehicle stopped: plain land
36* ¹ (Y)	Ground	Atmospheric pressure sensor power supply	Input	Ignition switch ON
37 (B)	Ground	Ground	—	Ignition switch ON
38* ¹⁰ (GR)	Ground	Ignition switch	Input	Ignition switch ON
				Ignition switch OFF
38* ² (GR)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch
				Release the push-button ignition switch
39 (BR)	Ground	Front wiper stop position	Input	Ignition switch ON Front wiper stop position
				Other than above
45* ⁵ (L)	—	CAN - H (TCM)	Input/ Output	—
46* ⁵ (P)	—	CAN - L (TCM)	Input/ Output	—
47* ¹ (W)	Ground	Atmospheric pressure sensor signal	Input	Ignition switch ON 0 – 5 V NOTE: Change depending to atmospheric pressure
48* ¹ (R)	Ground	Atmospheric pressure sensor ground	—	Ignition switch ON 0 – 1 V
49 (R)	Ground	Daytime running light LH	Output	Lighting switch 1ST 0 – 1 V
				Lighting switch OFF 9 – 16 V
50 (L)	Ground	Headlamp (LO) LH	Output	Lighting switch OFF 0 – 1 V
				Lighting switch 2ND 9 – 16 V
51 (V)	Ground	Front fog lamp LH	Output	Lighting switch 1ST, 2ND or AUTO Front fog lamp switch OFF 0 – 1 V
				Front fog lamp switch ON 9 – 16 V

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition		Value
+	-	Signal name	Input/ Output			
52 (W)	Ground	Hood switch	Input	Close the hood		9 – 16 V
				Open the hood		0 – 1 V
53 ^{*3} (GR)	Ground	LED headlamp warning LH	Output	Lighting switch OFF		9 – 16 V
				Lighting switch 2ND		0 – 1 V
54 (LG)	Ground	Headlamp (HI) RH	Output	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch OFF	0 – 1 V
				<ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS 		9 – 16 V
55 (SB)	Ground	Ignition power supply	Output	Ignition switch OFF		0 – 1 V
				Ignition switch ON		6 – 16 V
56 (BG)	Ground	Parking lamp LH	Output	Lighting switch OFF		0 – 1 V
				Lighting switch 1ST or 2ND		9 – 16 V
57 (W)	Ground	Front fog lamp RH	Output	Lighting switch 1ST, 2ND or AUTO	Front fog lamp switch OFF	0 – 1 V
				Front fog lamp switch ON		9 – 16 V
58 (R)	Ground	Daytime running light RH	Output	Engine running	Lighting switch 1ST	0 – 1 V
				Lighting switch OFF		9 – 16 V
59 (G)	Ground	Headlamp (HI) LH	Output	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch OFF	0 – 1 V
				<ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS 		9 – 16 V
60 ^{*3} (Y)	Ground	LED headlamp warning RH	Output	Lighting switch OFF		9 – 16 V
				Lighting switch 2ND		0 – 1 V
61 (GR)	Ground	Parking lamp RH	Output	Lighting switch OFF		0 – 1 V
				Lighting switch 1ST or 2ND		9 – 16 V
62 (SB)	Ground	Headlamp (LO) RH	Output	Lighting switch OFF		0 – 1 V
				Lighting switch 2ND		9 – 16 V
63 ^{*11} (B)	Ground	Headlamp aiming motors ground	—	Ignition switch ON		0 – 1 V
64 ^{*11} (V)	Ground	Aiming motor drive signal	Output	Lighting switch 2ND or AUTO (light is illuminated)	Headlamp aiming: Unloaded vehicle condition	8.75 V
				Headlamp aiming: Low		Voltage decreases from the unladen status.
65 (P)	Ground	A/C relay	Output	Engine running	A/C switch OFF	0 – 1 V
				A/C switch ON (A/C compressor is operating)		9 – 16 V

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value
	+	-		
66 (R) ^{*8} (L) ^{*7}	Ground	ECM relay	Output	Ignition switch OFF
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)
67 ^{*8} (V)	Ground	Throttle control motor relay control	Output	Ignition switch ON
				• When ignition switch is turned from OFF to ON • For a few seconds after turning ignition switch OFF
70 (BG) ^{*5} (GR) ^{*6}	Ground	Ignition power supply	Output	Ignition switch OFF
				Ignition switch ON
71 ^{*6} (SB)	Ground	Ignition power supply	Output	Ignition switch OFF
				Ignition switch ON
72 ^{*8} (GR)	Ground	Throttle control motor relay	Output	Ignition switch OFF
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)
73 (Y) ^{*8} (R) ^{*7}	Ground	ECM relay	Output	Ignition switch OFF
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)
75 (BR) ^{*8} (L) ^{*7}	Ground	ECM relay	Output	Ignition switch OFF
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)
76 (P)	Ground	Fuel pump relay control	Output	• Ignition switch OFF • Approximately 1 second after turning the ignition switch ON
				Approximately 1 second or more turning the ignition switch ON
78 ^{*9} (L) ^{*4} (R) ^{*7}	Ground	ECM relay	Output	Ignition switch OFF
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)
79 (G)	Ground	Reverse switch	Input	Ignition switch ON
				Select lever in R
81 (G)	Ground	Starter motor	Output	Select lever in any position other than R
				0 – 1 V
83 (L)	Ground	Battery power supply	Input	Other than at engine cranking
				At engine cranking
84 (GR)	Ground	Starter relay power supply	Input	Ignition switch OFF
				0 – 1 V
				6 – 16 V
				At engine cranking
				6 – 16 V

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value
	Signal name	Input/ Output		
+	-			
85 (P)	Ground	Cooling fan relay-1	Output	OFF
				LO operation
				MID or HI operation
86 (LG)	Ground	Battery power supply	Input	Ignition switch OFF
87 ^{*5} (L)	—	CAN - H (TCM)	Input/ Output	—
88 ^{*5} (P)	—	CAN - L (TCM)	Input/ Output	—
89 ^{*1} (W)	Ground	Atmospheric pres- sure sensor signal	Input	Ignition switch ON NOTE: Change depending to atmo- spheric pressure
90 ^{*1} (R)	Ground	Atmospheric pres- sure sensor ground	—	Ignition switch ON
92 ^{*5} (GR)	Ground	Transmission range switch	Input	Ignition switch in P or N
				Ignition switch in any pos- ition other than P or N
92 ^{*6} (GR)	Ground	Ignition power supply	Input	Ignition switch OFF
				Ignition switch ON
93 (P) ^{*8} (G) ^{*7}	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)
				0 – 1 V
94 ^{*6} (SB)	Ground	Neutral position switch	Output	Ignition switch ON
				Select lever in N
				Select lever in any position other than N
95 (LG)	Ground	Battery current sensor power supply	Input	Ignition switch ON
96 (W)	Ground	Battery current sensor ground	—	Ignition switch ON
97 (P)	Ground	Battery current sensor	Input	Engine running • Battery: full charge • Engine: idling
98 (Y)	Ground	ECV control	Output	Ignition switch ON
				Active test (ECV): 50 %
				Active test: 100 %
99 (BG)	Ground	G sensor power sup- ply	Output	Ignition switch ON
100 (LG)	Ground	G sensor ground	—	Ignition switch ON



JMMIA1600GB

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value
	Signal name	Input/ Output		
+	-			
101 (V)	Ground	G sensor	Output Ignition switch ON	Vehicle stopped: plain land 4 – 6 V
102 ^{*1} (Y)	Ground	Atmospheric pressure sensor power supply	Output	Ignition switch ON 4 – 6 V
105 ^{*7} (W)	Ground	Oil pressure switch	Input Ignition switch ON	Engine running 9 – 16 V Engine stopped 0 – 1 V
106 (BR)	Ground	Cooling fan relay-5	Output Cooling fan	• Stop • LO operation 9 – 16 V HI operation 0 – 1 V
107 ^{*8} (V)	Ground	Cooling fan relay-4	Output Cooling fan	• Stop • LO operation 9 – 16 V HI operation 0 – 1 V
110 (SB)	Ground	Battery current sensor	Input	Engine running • Battery temperature: 25°C • Idling 3.3 V

^{*1}: With MR20 engine models^{*2}: With Intelligent Key models^{*3}: With LED headlamp^{*4}: With QR25 engine models^{*5}: With CVT models^{*6}: With M/T models^{*7}: With R9M engine models^{*8}: Except for R9M engine models^{*9}: Except for MR20 engine models^{*10}: Without Intelligent Key system^{*11}: With headlamp aiming control system (AUTO)^{*12}: With 3-rows seat models^{*13}: With stop/start system

Fail-safe

INFOID:0000000010741709

FAIL-SAFE CONTROL BY DTC

IPDM E/R performs fail-safe control when any DTC are detected.

DTC	CONSULT display description		Fail-safe
B121D	S/L LOCK PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply until the vehicle switches to sleep status.
B121A	FR FOG LAMP LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the front fog lamp LH power supply circuit until the front fog lamp ON conditions are no longer satisfied.
B1231	DTRL RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the daytime running light RH power supply circuit until the daytime running light ON conditions are no longer satisfied.
B1256	FR FOG LAMP RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the front fog lamp RH power supply circuit until the front fog lamp ON conditions are no longer satisfied.

< ECU DIAGNOSIS INFORMATION >

DTC	CONSULT display description		Fail-safe
B1C00	HEIGHT SENSOR PWR SPLY CIRC	[CIRC SHORT TO GRND] [CIRC SHORT TO BATTERY]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C01	FR HEIGHT SENSOR SIGNAL	[CIRC SHORT TO BATTERY] [CIRC SHORT TO GROUND OR OPEN] [CIRC VOLTAGE OUT OF RANGE]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C02	RR HEIGHT SENSOR SIGNAL	[CIRC SHORT TO BATTERY] [CIRC SHORT TO GROUND OR OPEN] [CIRC VOLTAGE OUT OF RANGE]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C07	AIMING MOTOR DRIVE SIGNAL	[CIRC SHORT TO GRND] [CIRC SHORT TO BATTERY] [SIGNAL COMPARE FAILURE]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C11	FR HEIGHT SENSOR SIGNAL	[SIG PRTCTN CLCLTN IN-CRCT]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B1C12	RR HEIGHT SENSOR SIGNAL	[SIG PRTCTN CLCLTN IN-CRCT]	Right and left headlamp aiming motors stop at the position when DTC is detected.
B20CB	DTRL LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the daytime running light LH power supply circuit until the daytime running light ON conditions are no longer satisfied.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< ECU DIAGNOSIS INFORMATION >

DTC	CONSULT display description		Fail-safe
B20BD	BATTERY CURRENT SENSOR	[CIRC SHORT TO GRND]	Inhibit stop/start system operation
		[CIRC SHORT TO BATTERY]	
		[CIRC OPEN]	
		[CMPNENT INTERNAL MLFNCTN]	
B20CE	HL (HI) LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (HI) LH power supply circuit until the headlamp (HI) ON conditions are no longer satisfied.
B20CF	HL (HI) RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (HI) RH power supply circuit until the headlamp (HI) ON conditions are no longer satisfied.
B20D0	HL (LO) LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (LO) LH power supply circuit until the headlamp (LO) ON conditions are no longer satisfied.
B20D1	HL (LO) RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the headlamp (LO) RH power supply circuit until the headlamp (LO) ON conditions are no longer satisfied.
B20D2	PARKING LAMP PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the parking lamp (LH/RH) power supply circuit until the parking lamp, license plate lamp, and tail lamp ON conditions are no longer satisfied.
B20D4	TAIL LAMP LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the following power supply circuits until the parking lamp, license plate lamp, and tail lamp ON conditions are no longer satisfied. • Tail lamp LH (body side) • Tail lamp LH (back door side) • License plate lamp LH • License plate lamp RH
B20D5	TAIL LAMP RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	Shuts off the power supply to the following power supply circuits until the parking lamp, license plate lamp, and tail lamp ON conditions are no longer satisfied. • Tail lamp RH (body side) • Tail lamp RH (back door side)
B20DB	HEIGHT SENS INITIALIZE NOT DONE	[MISSING CALIBRATION]	Right and left headlamp aiming motors fix at the initial aiming position.
		[NOT CONFIGURED]	
B20E2	LED HEADLAMP RH	[CMPNENT INTERNAL MLFNCTN]	Transmits the headlamp warning signal (CAN communication) to the combination meter when the headlamp (LO) ON conditions are satisfied. (When the ignition switch turns ON, the headlamp warning is displayed on the information display of the combination meter.)
B20E3	LED HEADLAMP LH	[CMPNENT INTERNAL MLFNCTN]	Transmits the headlamp warning signal (CAN communication) to the combination meter when the headlamp (LO) ON conditions are satisfied. (When the ignition switch turns ON, the headlamp warning is displayed on the information display of the combination meter.)

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

< ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> The cooling fan is operated at HI operation when the ignition switch is turned ON. Turn OFF the cooling fan operation when the ignition switch is turned OFF.
A/C compressor	A/C relay OFF

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> Turns ON the headlamp (LO) when the ignition switch is turned ON. Turns OFF the headlamp (LO) when the ignition switch is turned OFF. Headlamp (HI): OFF
<ul style="list-style-type: none"> Parking lamp License plate lamp Illumination Tail lamp 	<ul style="list-style-type: none"> Turns ON the tail lamp, parking lamp, license plate lamp and each illumination when the ignition switch is turned ON. Turns OFF the tail lamp, parking lamp, license plate lamp and each illumination when the ignition switch is turned OFF.
Front wiper	<ul style="list-style-type: none"> The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Daytime running light	Daytime running light: OFF
Front fog lamp	Front fog lamp: OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay: OFF
Headlamp washer	Headlamp washer relay: OFF

IGNITION RELAY CONTROL

- IPDM E/R monitors the voltage at the contact circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay control condition		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	Detects DTC [B20DD: IGN RELAY ON CIRC]
OFF	ON	Ignition relay OFF stuck	Detects DTC [B20DE: IGN RELAY OFF CIRC]

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by front wiper stop position signal.

When front wiper stop position signal is in the condition listed below while the front wiper is operating, IPDM E/R activates the fail-safe.

Ignition switch	Front wiper switch	Front wiper stop position signal	Fail-safe
ON	OFF	The signal does not change from the battery voltage for 10 seconds.	Stops front wiper power supply for 20 seconds
	Except OFF	The signal does not change for 10 seconds.	

DTC Inspection Priority Chart

INFOID:000000010741710

Priority	DTC No.	CONSULT display
1	U1000	CAN COMM CIRCUIT

< ECU DIAGNOSIS INFORMATION >

Priority	DTC No.	CONSULT display
2	B120E	[SYSTEM INTERNAL FAILURES] [NOT CONFURED]
	B121D	[CIRC SHORT TO GRND]
3	B20BD	[CIRC SHORT TO GRND] [CIRC SHORT TO BATTERY] [CIRC OPEN] [CMPNENT INTERNAL MLFNCTN]
		[MISSING CALIBRATION] [NOT CONFURED]
	B20DB	[CIRC SHORT TO BATTERY]
	B20DD	[CIRC SHORT TO GROUND OR OPEN]
	B20DE	[CIRC SHORT TO GROUND OR OPEN]
	B20DF	[CIRC SHORT TO BATTERY]
	B121A	[CIRC SHORT TO GRND]
	B1231	[CIRC SHORT TO GRND]
4	B1256	[CIRC SHORT TO GRND]
	B1C00	[CIRC SHORT TO BATTERY] [CIRC SHORT TO GRND]
		[CIRC SHORT TO BATTERY] [CIRC SHORT TO GROUND OR OPEN] [CIRC VOLTAGE OUT OF RANGE]
	B1C01	[CIRC SHORT TO GROUND OR OPEN] [CIRC VOLTAGE OUT OF RANGE]
		[CIRC SHORT TO BATTERY] [CIRC SHORT TO GROUND OR OPEN] [CIRC VOLTAGE OUT OF RANGE]
		[CIRC SHORT TO BATTERY] [CIRC SHORT TO GRND] [SIGNAL COMPARE FAILURE]
	B1C11	[SIG PRTCTN CLCLTN INCRCT]
	B1C12	[SIG PRTCTN CLCLTN INCRCT]
	B20BE	[CIRC SHORT TO GRND] [CIRC SHORT TO BATTERY OR OPEN]
		[CIRC SHORT TO GRND]
	B20CB	[CIRC SHORT TO GRND]
	B20CE	[CIRC SHORT TO GRND]
	B20CF	[CIRC SHORT TO GRND]
	B20D0	[CIRC SHORT TO GRND]
	B20D1	[CIRC SHORT TO GRND]
	B20D2	[CIRC SHORT TO GRND]
	B20D4	[CIRC SHORT TO GRND]
	B20D5	[CIRC SHORT TO GRND]
5	B20E2	[CIRC SHORT TO GRND]
	B20E3	[CIRC SHORT TO GRND]

DTC Index

INFOID:000000010741711

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.

IPDM E/R

[IPDM E/R]

< ECU DIAGNOSIS INFORMATION >

- PASS: A malfunction was detected in the past.

x: Applicable

DTC No.	CONSULT display		Fail-safe	Reference
B120E	IPDM E/R	[SYSTEM INTERNAL FAILURES]	—	PCS-54
		[NOT CONFIURED]		
B121A	FR FOG LAMP LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-100 (LED headlamp) EXL-300 (halogen headlamp)
B121D	S/L LOCK PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	SEC-106
B1231	DTRL RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-102 (LED headlamp) EXL-302 (halogen headlamp)
B1256	FR FOG LAMP RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-104 (LED headlamp) EXL-304 (halogen headlamp)
B1C00	HEIGHT SENSOR PWR SPLY CIRC	[CIRC SHORT TO BATTERY]	×	EXL-106
		[CIRC SHORT TO GRND]		
B1C01	FR HEIGHT SENSOR SIGNAL	[CIRC SHORT TO BATTERY]	×	EXL-108
		[CIRC SHORT TO GROUND OR OPEN]		
		[CIRC VOLTAGE OUT OF RANGE]		
B1C02	RR HEIGHT SENSOR SIGNAL	[CIRC SHORT TO BATTERY]	×	EXL-111
		[CIRC SHORT TO GROUND OR OPEN]		
		[CIRC VOLTAGE OUT OF RANGE]		
B1C07	AIMING MOTOR DRIVE SIGNAL	[CIRC SHORT TO BATTERY]	×	EXL-114
		[CIRC SHORT TO GRND]		
		[SIGNAL COMPARE FAILURE]		
B1C11	FR HEIGHT SENSOR SIGNAL	[SIG PRTCTN CLCLTN INCRCT]	×	EXL-117
B1C12	RR HEIGHT SENSOR SIGNAL	[SIG PRTCTN CLCLTN INCRCT]	×	EXL-119
B20BD	BATTERY CURRENT SENSOR	[CIRC SHORT TO GRND]	×	CHG-16
		[CIRC SHORT TO BATTERY]		
		[CIRC OPEN]		
		[CMPNENT INTERNAL MLFNCTN]		
B20BE	BATTERY TEMPERATURE SENSOR	[CIRC SHORT TO GRND]	—	CHG-20
		[CIRC SHORT TO BATTERY OR OPEN]		
B20CB	DTRL LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-121 (LED headlamp) EXL-306 (halogen headlamp)
B20CE	HL (HI) LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-123 (LED headlamp) EXL-308 (halogen headlamp)

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< ECU DIAGNOSIS INFORMATION >

DTC No.	CONSULT display		Fail-safe	Reference
B20CF	HL (HI) RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-125 (LED headlamp) EXL-311 (halogen headlamp)
B20D0	HL (LO) LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-127 (LED headlamp) EXL-314 (halogen headlamp)
B20D1	HL (LO) RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-129 (LED headlamp) EXL-317 (halogen headlamp)
B20D2	PARKING LAMP PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-131 (LED headlamp) EXL-320 (halogen headlamp)
B20D4	TAIL LAMP LH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-134 (LED headlamp) EXL-323 (halogen headlamp)
B20D5	TAIL LAMP RH PWR SPLY CIRC	[CIRC SHORT TO GRND]	×	<ul style="list-style-type: none"> EXL-138 (LED headlamp) EXL-327 (halogen headlamp)
B20DB	HEIGHT SENS INITIALIZE NOT DONE	[MISSING CALIBRATION] [NOT CONFIURED]	×	EXL-141
B20DD	IGN RELAY ON CIRC	[CIRC SHORT TO BATTERY]	—	PCS-55
B20DE	IGN RELAY OFF CIRC	[CIRC SHORT TO GROUND OR OPEN]	—	PCS-58
B20DF	STARTER RELAY OFF CIRC	[CIRC SHORT TO GROUND OR OPEN]	—	SEC-108
B20E2	LED HEADLAMP RH	[CMPNENT INTERNAL MLFNCTN]	×	EXL-142
B20E3	LED HEADLAMP LH	[CMPNENT INTERNAL MLFNCTN]	×	EXL-144
U1000	CAN COMM CIRCUIT		×	PCS-52


< WIRING DIAGRAM >

WIRING DIAGRAM

IPDM E/R

Wiring Diagram


INFOID:0000000010741712




2014/03/17

JRMWF4073GB

< WIRING DIAGRAM >



JRMWF4074GB




JRMWF4075GB

PCS

N

O

P




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Connector No.	F73
Connector Name	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	YL08EFGY
102	Y
105	W
106	BR
107	V
110	SB



Terminal Color Of No.	Wire	Signal Name [Specification]
81	G	-
83	L	-
84	GR	-
85	P	-
86	LG	-

Connector No.	F74
Connector Name	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH24FB-NH



Terminal Color Of No.	Wire	Signal Name [Specification]
87	L	-
88	P	-
89	W	-
90	R	-
92	GR	-
93	G	- [With R9A Engine] - [With MR20 or QR25 Engine]
94	SB	-
95	IG	-
96	W	-
97	P	-
98	Y	-
99	BG	-
100	LG	-
101	V	-

BASIC INSPECTION

ADDITIONAL SERVICE WHEN REPLACING IPDM E/R

Description

INFOID:0000000010741713

After replaced IPDM E/R, it is necessary to perform control unit configuration and height sensor initialize (For LED headlamp models) with CONSULT.

BEFORE REPLACEMENT

When replacing IPDM E/R, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" of "Read/Write Configuration" cannot be used, use the "Manual Configuration" after replacing IPDM E/R.

AFTER REPLACEMENT

CAUTION:

- When replacing IPDM E/R, always perform "Read/Write Configuration" or "Manual Configuration" with CONSULT. Or not doing so, IPDM E/R control function does not operate normally.
- Never perform "Read / Write Configuration" or "Manual Configuration" except for new IPDM E/R or the control function may not operate normally.

Work Procedure

INFOID:0000000010741714

1. SAVING VEHICLE SPECIFICATION (IPDM E/R)

CONSULT Configuration

Perform "Before Replace ECU" of "Read / Write Configuration" to save or print current vehicle specification. Refer to [PCS-48, "Description"](#).

NOTE:

If "Before Replace ECU" of "Read/Write Configuration" cannot be used, use the "Manual Configuration" after replacing IPDM E/R.

>> GO TO 2.

2. REPLACE IPDM E/R

Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION (IPDM E/R)

CONSULT Configuration

Perform "After Replace ECU" of "Read/Write Configuration" or "Manual Configuration" to write vehicle specification. Refer to [PCS-48, "Work Procedure"](#).

>> GO TO 4.

4. CHECK HEADLAMP TYPE

Check headlamp type.

PCS

LED headlamp>>GO TO 5.
Halogen headlamp>>WORK END

5. HEIGHT SENSOR INITIALIZE

Perform height sensor initialize. Refer to [EXL-99, "Work Procedure"](#).

>> WORK END

< BASIC INSPECTION >

CONFIGURATION (IPDM E/R)

Description

INFOID:0000000010741715

There is no vehicle specification in new IPDM E/R, so the vehicle specification needs to be written in IPDM E/R with CONSULT.

Configuration has three functions as follows.

Function		Description
READ/WRITE CONFIGURATION	Before Replace ECU	<ul style="list-style-type: none"> Reads the vehicle configuration of current BCM. Saves the read vehicle configuration.
	After Replace ECU	Writes the vehicle configuration with saved data.
MANUAL CONFIGURATION		Writes the vehicle configuration with manual selection.

CAUTION:

- When replacing IPDM E/R, always perform “Read/Write Configuration” or “Manual Configuration” with CONSULT. Or not doing so, IPDM E/R control function does not operate normally.
- Never perform “Read / Write Configuration” or “Manual Configuration” except for new IPDM E/R or the control function may not operate normally.

Work Procedure

INFOID:0000000010741716

1. WRITING MODE SELECTION

④ CONSULT Configuration

Select “CONFIGURATION” of IPDM E/R.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

2. PERFORM “WRITE CONFIGURATION”

④ CONSULT Configuration

- Select “READ/WRITE CONFIGURATION”.
- Select “After Replace ECU”.

>> GO TO 4.

3. PERFORM “MANUAL CONFIGURATION”

④ CONSULT Configuration

- Select “MANUAL CONFIGURATION”.
- Identify the correct model and configuration list. Refer to [PCS-49, “Configuration list”](#).

CAUTION:

- Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.
- Make sure to select “SETTING” even if the indicated configuration of brand new IPDM E/R is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model cannot be memorized

- Sets the displayed item and then select “NEXT”.

NOTE:

If item is not displayed, select “NEXT”.

- Check that the configuration has been successfully written and touch “End”.

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by IPDM E/R operates normally.

>> WORK END

CONFIGURATION (IPDM E/R)

[IPDM E/R]

< BASIC INSPECTION >

Configuration list

INFOID:000000010741717

CAUTION:

Check vehicle specifications before servicing.

MANUAL SETTING ITEM			NOTE
System	Item	Setting value	
IPDM-E	Data part number	284B7-4CB1A	All of the following are satisfied • MR20 engine • M/T • Headlamp aiming control system (manual) • Halogen headlamp • Without Intelligent Key system • Without stop/start system
IPDM-E	Data part number	284B7-4CB1C	All of the following are satisfied • MR20 engine • CVT • Headlamp aiming control system (manual) • Halogen headlamp • With Intelligent Key system • Without stop/start system
IPDM-E	Data part number	284B7-4CB1E	All of the following are satisfied • MR20 engine • CVT • Headlamp aiming control system (manual) • Halogen headlamp • Without Intelligent Key system • Without stop/start system
IPDM-E	Data part number	284B7-4CB2B	All of the following are satisfied • MR20 engine • CVT • Headlamp aiming control system (auto) • LED headlamp • With Intelligent Key system • Without stop/start system
IPDM-E	Data part number	284B7-4CB2E	All of the following are satisfied • QR25 engine • CVT • Headlamp aiming control system (manual) • Halogen headlamp • With Intelligent Key system • Without stop/start system
IPDM-E	Data part number	284B7-4CB3B	All of the following are satisfied • QR25 engine • CVT • Headlamp aiming control system (auto) • LED headlamp • With Intelligent Key system • Without stop/start system
IPDM-E	Data part number	284B7-4CB3D	All of the following are satisfied • R9M engine • M/T • Headlamp aiming control system (manual) • Halogen headlamp • Without Intelligent Key system • With stop/start system

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

CONFIGURATION (IPDM E/R)

[IPDM E/R]

< BASIC INSPECTION >

MANUAL SETTING ITEM			NOTE
System	Item	Setting value	
IPDM-E	Data part number	284B7-4CB3E	All of the following are satisfied <ul style="list-style-type: none"> • R9M engine • M/T • Headlamp aiming control system (manual) • Halogen headlamp • With Intelligent Key system • With stop/start system
IPDM-E	Data part number	284B7-4CB4A	All of the following are satisfied <ul style="list-style-type: none"> • R9M engine • M/T • Headlamp aiming control system (auto) • LED headlamp • With Intelligent Key system • With stop/start system
IPDM-E	Data part number	284B7-4CB4C	All of the following are satisfied <ul style="list-style-type: none"> • R9M engine • CVT • Headlamp aiming control system (manual) • Halogen headlamp • Without Intelligent Key system • With stop/start system
IPDM-E	Data part number	284B7-4CB4D	All of the following are satisfied <ul style="list-style-type: none"> • R9M engine • CVT • Headlamp aiming control system (manual) • Halogen headlamp • With Intelligent Key system • With stop/start system
IPDM-E	Data part number	284B7-4CB4E	All of the following are satisfied <ul style="list-style-type: none"> • R9M engine • CVT • Headlamp aiming control system (auto) • LED headlamp • With Intelligent Key system • With stop/start system
HLL	Seat	2-ROM SEAT	Select the number of the seat
		3-ROM SEAT	

< BASIC INSPECTION >

CUMULATIVE BATTERY DISCHARGE CURRENT CLEAR

Description

INFOID:0000000011009276

CUMULATIVE BATTERY DISCHARGE CURRENT CLEAR is an operation to clear the cumulative value of battery discharge current which is memorized in IPDM E/R. This operation is necessary after replaced the battery.

Work Procedure

INFOID:0000000011009277

1. CLEAR CUMULATIVE BATTERY DISCHARGE CURRENT VALUE

1. Turn ignition switch ON.
2. Select “CML B/DCHRG CRNT CLEAR” in “Work Support” mode of “IPDM E/R” using CONSULT.
3. Touch “CLEAR” to clear the cumulative value of battery discharge current.

>> WORK END

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:0000000010741718

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC Detection Condition
U1000	CAN COMM CIRCUIT (CAN communication circuit)	When IPDM E/R cannot communicate CAN communication signal continuously for 2 seconds or more

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> • Cooling fan operates at high speed when the ignition switch is turned ON • Cooling fan stops when the ignition switch is turned OFF
A/C compressor	A/C relay OFF

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> • Turns ON the headlamp low when the ignition switch is turned ON • Turns OFF the headlamp low when the ignition switch is turned OFF • Turn OFF the headlamp high
<ul style="list-style-type: none"> • Parking lamp • License plate lamp • Illumination • Tail lamp 	<ul style="list-style-type: none"> • Turns ON the tail lamp, parking lamp, license plate lamp and illumination when the ignition switch is turned ON • Turns OFF the tail lamp, parking lamp, license plate lamp and illumination when the ignition switch is turned OFF
Front wiper motor	<ul style="list-style-type: none"> • The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. • The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Front fog lamp	Turns OFF the front fog lamp
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter relay OFF

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON and wait for 2 seconds or more.
3. Check "Self Diagnostic Result" of IPDM E/R.

s DTC "U1000" displayed?

< DTC/CIRCUIT DIAGNOSIS >

YES >> Refer to [PCS-53, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

A

INFOID:0000000010741719

B

Diagnosis Procedure

1 .PERFORM SELF DIAGNOSTIC

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON and wait for 2 seconds or more.
3. Check "Self Diagnostic Result" of IPDM E/R.

C

Is DTC "U1000" displayed?

YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

NO >> Refer to [GI-44, "Intermittent Incident"](#).

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

B120E IPDM E/R**DTC Description**

INFOID:000000010741720

DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)		DTC Detection Condition
B120E	IPDM E/R (Intelligent power distribution module engine room)	[SYSTEM INTERNAL FAILURES]	EEPROM in IPDM E/R is malfunctioning
		[NOT CONFIURED]	Control unit setting is not performed

POSSIBLE CAUSE

IPDM E/R

FAIL-SAFE**DTC CONFIRMATION PROCEDURE****1. PERFORM DTC CONFIRMATION PROCEDURE**

1. Turn ignition switch OFF.
2. Turn ignition switch ON.
3. Check DTC in "Self Diagnostic Result" mode of "IPDM E/R" using CONSULT.

Is DTC detected?YES >> Refer to [PCS-54, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010741721

1. CHECK DTC

Perform each inspection according to the displayed DTC.

Which DTC is detected?

[NOT CONFIURED]>>GO TO 2.

[SYSTEM INTERNAL FAILURES]>>GO TO 3.

2. PERFORM CONFIGURATION (IPDM E/R)

1. Perform Configuration (IPDM E/R). Refer to [PCS-48, "Description"](#).
2. Perform DTC confirmation procedure. Refer to [PCS-54, "DTC Description"](#)

Is DTC detected?

YES >> GO TO 3.

NO >> INSPECTION END

3. REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
2. Perform DTC confirmation procedure. Refer to [PCS-54, "DTC Description"](#)

Is DTC detected?YES >> Refer to [GI-44, "Intermittent Incident"](#).

NO >> INSPECTION END

< DTC/CIRCUIT DIAGNOSIS >

B20DD IGNITION RELAY ON CIRCUIT

DTC Description

INFOID:0000000010741722

- IPDM E/R operates the ignition relay when it receives an ignition switch ON signal from BCM via CAN communication.
- Turn the ignition relay OFF by pressing the push-button ignition switch once when the vehicle speed is 4 km/h (2.5 MPH) or less.
- Turn the ignition relay OFF with the following operation when the vehicle speed is more than 4 km/h (2.5 MPH) or when an abnormal condition occurs in CAN communication from the combination meter (Emergency OFF)
 - Press and hold the push-button ignition switch for 2 seconds or more.
 - Press the push-button ignition switch 3 times within 1.5 seconds.

NOTE:

The ignition relay does not turn ON for 3 seconds after emergency OFF even if the push-button ignition switch is pressed.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)		DTC Detection Condition
B20DD	IGN RELAY ON CIRC (Ignition relay on circuit)	[CIRC SHORT TO BATTERY]	The ignition relay OFF is detected for 1 second at ignition switch ON (CPU monitors the status at the contact circuits of the ignition relay inside it)

POSSIBLE CAUSE

IPDM E/R

FAIL-SAFE

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch OFF.
- Turn ignition switch ON.
- Check DTC in "Self Diagnostic Result" mode of "IPDM E/R" using CONSULT.

Is DTC detected?

PCS

YES >> Refer to [PCS-55, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:0000000010741723

1. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 1

- Turn ignition switch ON
- Display "Self-diagnosis Result" of IPDM E/R with CONSULT.
- Remove fuse [No. 91 (20 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

N

O

P

YES >> Perform an inspection of the downstream circuit of fuse [No. 91 (20 A)] at the downstream of ignition relay in IPDM E/R.

NO >> GO TO 2.

2. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 2

- Return fuse [No. 91 (20 A)] downstream of ignition relay in IPDM E/R back to the original position.
- Remove fuse [No. 95 (5 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

B20DD IGNITION RELAY ON CIRCUIT

[IPDM E/R]

< DTC/CIRCUIT DIAGNOSIS >

YES >> Perform an inspection of the downstream circuit of fuse [No. 95 (5 A)] at the downstream of ignition relay in IPDM E/R.

NO >> GO TO 3.

3. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 3

1. Return fuse [No. 95 (5 A)] downstream of ignition relay in IPDM E/R back to the original position
2. Remove fuse [No. 97 (10 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

YES >> Perform an inspection of the downstream circuit of fuse [No. 97 (10 A)] at the downstream of ignition relay in IPDM E/R.

NO >> GO TO 4.

4. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 4

1. Return fuse [No. 97 (10 A)] downstream of ignition relay in IPDM E/R back to the original position
2. Remove fuse [No. 93 (10 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

YES >> Perform an inspection of the downstream circuit of fuse [No. 93 (10 A)] at the downstream of ignition relay in IPDM E/R.

NO-1 >> With stop/start system models: GO TO 5.

NO-2 >> With QR engine models: GO TO 7.

NO-3 >> Except for QR engine and stop/start system models: GO TO 9.

5. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 5

1. Return fuse [No. 93 (10 A)] downstream of ignition relay in IPDM E/R back to the original position
2. Remove fuse [No. 96 (10 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

YES >> Perform an inspection of the downstream circuit of fuse [No. 96 (10 A)] at the downstream of ignition relay in IPDM E/R.

NO-1 >> With QR engine models: GO TO 6.

NO-2 >> Except for QR engine models: GO TO 9.

6. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 6

1. Return fuse [No. 96 (10 A)] downstream of ignition relay in IPDM E/R back to the original position
2. Remove fuse [No. 86 (15 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

YES >> Perform an inspection of the downstream circuit of fuse [No. 86 (15 A)] at the downstream of ignition relay in IPDM E/R.

NO >> GO TO 9.

7. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 7

1. Return fuse [No. 93 (10 A)] downstream of ignition relay in IPDM E/R back to the original position
2. Remove fuse [No. 86 (15 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

YES >> Perform an inspection of the downstream circuit of fuse [No. 86 (15 A)] at the downstream of ignition relay in IPDM E/R.

NO-1 >> With stop/start system models: GO TO 8.

NO-2 >> Except for stop/start system models: GO TO 9.

8. CHECK IGNITION RELAY POWER SUPPLY CIRCUIT 8

1. Return fuse [No. 86 (15 A)] downstream of ignition relay in IPDM E/R back to the original position
2. Remove fuse [No. 96 (10 A)] at the downstream of ignition relay in IPDM E/R, and check the change in "Self-diagnosis Result".

Is it now a past malfunction?

B20DD IGNITION RELAY ON CIRCUIT

[IPDM E/R]

< DTC/CIRCUIT DIAGNOSIS >

YES >> Perform an inspection of the downstream circuit of fuse [No. 96 (10 A)] at the downstream of ignition relay in IPDM E/R.

NO >> GO TO 9.

A

9.REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
2. Perform DTC confirmation procedure. Refer to [PCS-55, "DTC Description"](#).

B

Is DTC detected?

YES >> Refer to [GI-44, "Intermittent Incident"](#).
NO >> INSPECTION END

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

B20DE IGNITION RELAY OFF CIRCUIT

DTC Description

INFOID:0000000010741724

- IPDM E/R operates the ignition relay when it receives an ignition switch ON signal from BCM via CAN communication.
- Turn the ignition relay OFF by pressing the push-button ignition switch once when the vehicle speed is 4 km/h (2.5 MPH) or less.
- Turn the ignition relay OFF with the following operation when the vehicle speed is more than 4 km/h (2.5 MPH) or when an abnormal condition occurs in CAN communication from the combination meter (Emergency OFF)
 - Press and hold the push-button ignition switch for 2 seconds or more.
 - Press the push-button ignition switch 3 times within 1.5 seconds.

NOTE:

The ignition relay does not turn ON for 3 seconds after emergency OFF even if the push-button ignition switch is pressed.

DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)		DTC Detection Condition
B20DE	IGN RELAY OFF CIRC (Ignition relay OFF circuit)	[CIRC SHORT TO GROUND OR OPEN]	The ignition relay OFF is detected for 1 second at ignition switch ON (CPU monitors the status at the contact circuits of the ignition relay inside it)

POSSIBLE CAUSE

IPDM E/R

FAIL-SAFE

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch OFF.
- Turn ignition switch ON.
- Check DTC in "Self Diagnostic Result" mode of "IPDM E/R" using CONSULT.

Is DTC detected?

YES >> Refer to [PCS-58, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:0000000010741725

1. REPLACE IPDM E/R

- Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
- Perform DTC confirmation procedure. Refer to [PCS-58, "DTC Description"](#).

Is DTC detected?

YES >> Refer to [GI-44, "Intermittent Incident"](#).

NO >> INSPECTION END

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000010741726

1. CHECK FUSIBLE LINK

Check that the following IPDM E/R fusible links are not blown.

With QR engine models

Signal name	Fusible link No.
Battery power supply	D (80 A)
	Q (40 A)
	C (100 A)
	R (30 A)

Except for QR engine models

Signal name	Fusible link No.
Battery power supply	D (100 A)
	Q (40 A)
	U (100 A)
	R (30 A)

Is the fuse fusing?

YES >> Replace the blown fusible link after repairing the affected circuit if a fusible link is blown.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and the ground.

(+)		(-)	Voltage
IPDM E/R			
Connector	Terminal	Ground	6 – 16 V
	1		
E9	2		
	83		
F73	86		

Is the measurement value normal?

YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and the ground.

IPDM E/R		Continuity
Connector	Terminal	
E10	12	
E11	23	
E12	37	Existed

Does continuity exist?

YES >> INSPECTION END
NO >> Repair the harness or connector.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N


O

P

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION**IPDM E/R****Exploded View**

INFOID:0000000010741727



① IPDM E/R cover A

② IPDM E/R

③ IPDM E/R cover B

④ IPDM E/R cover C

⑤ IPDM E/R cover D

Removal and Installation

INFOID:0000000010741728

CAUTION:

When replacing IPDM E/R, save or print current vehicle specification with CONSULT configuration before replacement. Refer to [PCS-47, "Work Procedure"](#).


REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Remove air resonator and air duct. Refer to [EM-31, "Removal and Installation"](#) (for MR20DD engine), [EM-175, "Removal and Installation"](#) (for QR25DE engine) or [EM-308, "Removal and Installation"](#) (for R9M engine).

< REMOVAL AND INSTALLATION >


3. Pull up IPDM E/R cover A ① from IPDM E/R cover D ② with pressing the pawls of IPDM E/R cover A ①.

△ : Pawl



4. Pull up IPDM E/R ① with disengaging the pawls of IPDM E/R cover D ②

△ : Pawl



5. Disconnect the connector and remove IPDM E/R from the vehicle.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to perform “Read/Write Configuration” when replacing IPDM E/R. Or not doing so, IPDM E/R control function does not operate normally. Refer to [PCS-47, "Work Procedure"](#).

A
B
C
D
E
F
G
H
I
J
K
L

PCS

N
O
P

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010741729

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000010741730

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition power source and accessory power source to the OFF, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Open driver door.
3. Turn the ignition switch to the ON position.
(At this time, the steering lock will be released.)
4. Turn the ignition switch to OFF position with driver door open.
5. Wait for 3 minutes or longer with driver door open.

NOTE:

- Do not close driver door because the steering wheel locks when driver door is closed.

PRECAUTIONS

< PRECAUTION >

[POWER DISTRIBUTION SYSTEM]

- The auto acc function is adapted to this vehicle. For this reason, even when the ignition switch is turned to OFF position, the accessory power source does not turn OFF and continues to be supplied for a certain amount of time.
- 6. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
- 7. Perform the necessary repair operation.
- 8. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from OFF position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
- 9. Perform self-diagnosis check of all control units using CONSULT.

Precautions for Removing Battery Terminal

INFOID:0000000010869316

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.
2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.


5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.



PRECAUTIONS

< PRECAUTION >

[POWER DISTRIBUTION SYSTEM]

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:


After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000010741732



JMMIA1776ZZ

PCS

No.	Component	Description
①	CVT shift selector (detention switch) (CVT models)	CVT shift selector (detention switch) detects shift lever status, transmits detention switch signal to BCM. Refer to TM-235, "CVT CONTROL SYSTEM : Component Parts Location" for detailed installation location.
②	Push-button ignition switch (with Intelligent Key system)	Refer to PCS-66, "Push-button Ignition Switch" .
③	Stop lamp switch	Stop lamp switch detects that brake pedal is depressed, and transmits the signal to BCM. Refer to EC-812, "Component Parts Location" .
④	TCM	Transmits shift position signal to BCM via CAN communication line. Refer to TM-235, "CVT CONTROL SYSTEM : Component Parts Location" .

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[POWER DISTRIBUTION SYSTEM]

No.	Component	Description
⑤	IPDM E/R	IPDM E/R detects push-button ignition switch (push switch) status, and transmits push-button ignition switch status signal (CAN) to BCM. Refer to PCS-5, "Component Parts Location" for detailed installation location.
⑥	BCM	<ul style="list-style-type: none"> BCM controls power distribution system. BCM judges ignition switch position by push-button ignition switch (push switch) and vehicle condition BCM checks the ignition switch position internally. Refer to BCS-6, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
⑦	Key switch (without Intelligent Key system)	Key switch detects that ignition key is inserted into the ignition key cylinder, and then transmits the signal to BCM.
⑧	Door request switch (with Intelligent Key system)	Door request switch detects door lock/unlock operation and transmits door request switch signal to BCM
⑨	Door switch	Detects door open/close condition.

Push-button Ignition Switch

INFOID:0000000010741733


Push-button ignition switch is pressed, and transmits the status signal to BCM and IPDM E/R.



JMMIA1374ZZ

SYSTEM**POWER DISTRIBUTION SYSTEM****POWER DISTRIBUTION SYSTEM : System Description**

INFOID:000000010741734

SYSTEM DIADRAM**SYSTEM DESCRIPTION**

- POWER DISTRIBUTION SYSTEM is the system that BCM controls with the operation of push-button ignition switch and performs the power distribution to each power circuit. This system is used instead of the mechanical power supply changing mechanism with the operation of the conventional key cylinder.
- Push-button ignition switch can be operated when Intelligent Key is in the following condition.
 - Intelligent Key is in the detection area of the inside key antenna.
 - Intelligent Key backside is contacted to push-button ignition switch.
- Push-button ignition switch operation is input to BCM as a signal. BCM changes the ignition switch position according to the status and operates the following relays to supply power to each power circuit.
 - Ignition relay (IPDM E/R)
 - Ignition relay [fuse block (J/B)]
 - Accessory relay
 - Blower relay
- The ignition switch position can be confirmed with the lighting of the ON indicator lamp in push-button ignition switch.

IGNITION BATTERY SAVER SYSTEM

When all the following conditions are met for 10 minutes, the battery saver system will cut off the power supply (ignition switch position ON → OFF) to prevent battery discharge.

- Ignition switch is in the ON position
- Turn signal lamp is not in operation
- Selector lever is in the P position (CVT models)

NOTE:

For one minute after thirty minutes have passed or three minutes after twenty-seven minutes are passed, the following display is indicated on information display in combination meter and sounds buzzer in combination meter.

PCS

Combination meter		Time
Information display	Buzzer	
Power turned off to save the battery	Pipi-Pipi (two seconds)	For 1 minute after 10 minutes have passed
Power will turn off to save the battery		3 minutes after 7 minutes are passed

Reset Condition of Ignition Battery Saver System

If any of the following conditions are met the battery saver system is released.

- Ignition switch is not in the ON position.

N

O

P

< SYSTEM DESCRIPTION >

- Turn signal lamp is operation.
- Selector lever is not in the P position.

NOTE:

The ignition battery saver system can be temporarily disabled, without using CONSULT, to prevent it from functioning when performing trouble diagnosis. Refer to [PCS-100, "Work Procedure"](#).

IGNITION SWITCH POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

Refer to [PCS-68, "AUTO ACC FUNCTION : System Description"](#).


AUTO ACC FUNCTION

AUTO ACC FUNCTION : System Description


INFOID:0000000010741735

SYSTEM DIAGRAM

MODELS WITH INTELLIGENT KEY SYSTEM



MODELS WITHOUT INTELLIGENT KEY SYSTEM




DESCRIPTION

In conventional vehicles, power is supplied to the accessories of the vehicle after the ignition switch is turned to the ACC position.

The AUTO ACC function is a function that bypasses the ignition switch ACC position and automatically distributes the accessory power supply to each switch and unit by door unlock operation, etc. using the Intelligent Key (models with Intelligent Key) or the remote controller key (models without Intelligent Key).

OPERATION FLOW



Ignition Switch On Status

In this status the ignition switch is operated and turned ON.

Audio / Navigation Available Status

- In this status the audio, navigation, and each switch and unit that is activated by the accessory power source can be operated.
- When 10 minutes pass after conditions are satisfied while and audio and navigation are not operated, audio and navigation turn OFF.
- When audio or navigation is operated within 10 minutes after conditions are satisfied, operation time is extended for 10 minutes. Audio and navigation can be operated for a maximum of 30 minutes after the status is satisfied.

PCS

Audio / navigation use intention check status

This is a status for checking the intention of using audio and navigation again after audio and navigation are stopped.

N

Audio / navigation unavailable status

In this status audio and navigation become unavailable, but the switches and units other than those for audio or navigation that can operate by using the accessory power source are available until the accessory power source turns OFF.

O

OFF status

In this status the AUTO ACC function stops and power to the accessories is not supplied.

P

SYSTEM

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

No.	Function status	Shifting condition	Accessory power source
①	<ul style="list-style-type: none"> • Shifting from "OFF status" to "Ignition switch ON status" • Shifting from "Audio / navigation unavailable status" to "Ignition switch ON status" • Shifting from "Audio / navigation use intention confirmation status" to "Ignition switch ON status" 	Turn the ignition switch ON from OFF.	OFF → ON
②	<ul style="list-style-type: none"> • Shifting from "OFF status" to "Audio / navigation available status" • Shifting from "Audio / navigation unavailable status" to "Audio / navigation available status" 	<ul style="list-style-type: none"> • Models with Intelligent Key: Operate either the door request switch or the unlock button of the Intelligent Key to unlock the door. • Models without Intelligent Key: Operate the unlock button of remote controller button to unlock the door. 	OFF → ON
③	Shifting from "Ignition switch ON status" to "Audio / navigation available status"	Turn the ignition switch OFF from ON while driver door is closed.	ON
④	Shifting from "Audio / navigation available status" to "Ignition switch ON status"	Turn the ignition switch ON from OFF.	ON
⑤	"Audio / navigation available status" Time extension (10 minutes)	Operate audio or navigation.	ON
⑥	Shifting from "Ignition switch ON status" to "Audio / navigation use intention confirmation status"	Turn the ignition switch OFF from ON while driver door is open.	ON
⑦	Shifting from "Audio / navigation available status" to "Audio / navigation use intention confirmation status"	<ul style="list-style-type: none"> • For models with Intelligent Key, any of the following conditions is satisfied. <ul style="list-style-type: none"> - Close all doors, and lock all doors with the Intelligent Key or door request switch. - Ten minutes pass from "Audio / navigation available status." - Open driver door. • For models without Intelligent Key, any of the following conditions is satisfied. <ul style="list-style-type: none"> - Close all doors, and lock all doors with the remote controller button. - Remove the key from the ignition key cylinder. - Ten minutes pass from "Audio / navigation available status." - Driver door is opened. 	ON
⑧	Shifting from "Audio / navigation use intention confirmation status" to "Audio / navigation available status"	<ul style="list-style-type: none"> • Models with Intelligent Key: Operate either the door request switch or the unlock button of the Intelligent Key to unlock the door. • Models without Intelligent Key: Operate the unlock button of remote controller button to unlock the door. • Operate audio or navigation power switch 	ON
⑨	Shifting from "Audio / navigation available status" to "Audio / navigation unavailable status"	Thirty minutes pass from "Audio / navigation available status."	ON
⑩	Shifting from "Audio / navigation use intention confirmation status" to "Audio / navigation unavailable status"	<ul style="list-style-type: none"> • Two minutes pass from "Audio / navigation use intention confirmation status." • In "Audio / navigation use intention confirmation status," 30 minutes pass after "Audio / navigation available status" is satisfied. 	ON
⑪	Shifting from "Audio / navigation unavailable status" to "OFF status"	One minute passes from "Audio / navigation unavailable status."	ON → OFF

SYSTEM

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

No.	Function status	Shifting condition	Accessory power source
⑫	Shifting from "OFF status" to "Audio / navigation unavailable status"	Any of the following conditions is satisfied. • Driver door is opened or closed. • The steering lock operates.	OFF → ON
⑬	"Audio / navigation unavailable status" time extension (1 minute)	Any of the following conditions is satisfied. • Driver door is opened or closed. • The steering lock operates.	ON

Fail-safe

INFOID:000000010741736

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

Display contents of CONSULT	Fail-safe
B2190-00: CHAIN OF BCM-IMM ANT	Inhibit engine cranking
B2191-00: ID DISCORD, BCM-IMMANT	Inhibit engine cranking
B2192-00: ID DISCORD BCM-ECM	Inhibit engine cranking
B2193-00: CHAIN OF BCM-ECM	Inhibit engine cranking
B2195-00: ANTI-SCANNING	Inhibit engine cranking
B2198-00: NATS ANTENNA AMP	Inhibit engine cranking
B2557-00: VEHICLE SPEED	Inhibit steering lock
B2602-00: SHIFT POSITION	Inhibit steering lock
B2604-00: PNP/CLUTCH SW	Inhibit steering lock
B2608-00: STARTER RELAY	Inhibit engine cranking
B260F-00: ENG STATE SIG LOST	Inhibit engine cranking
B26F1-00: IGN RELAY OFF	Inhibit engine cranking
B26F2-00: IGN RELAY ON	Inhibit engine cranking
B27D4-00: BCM - S/L SENSOR CIRCUIT	Inhibit steering unlock
B27D5-00: S/L SENSOR TEST OUTPUT	Inhibit steering unlock
B27D6-00: S/L CAN COMM CIRCUIT	Inhibit steering lock
B27D7-00: S/L PWR RELAY	Inhibit steering lock
B27D8-00: S/L VEHICLE SPEED MALFUNCTION	Inhibit steering lock
B27D9-00: S/L IGN MALFUNCTION	Inhibit steering lock/unlock
B27DA-00: IPDM CAN COMM CIRCUIT	Inhibit steering lock
B27DC-00: S/L POWER SUPPLY	Inhibit steering lock
B27DD-00: BCM - S/L ID DISCORD	Inhibit steering lock
B27DE-00: S/L MECHANICAL MALFUNCTION	Inhibit steering lock
B27DF-00: S/L HIGH LEVEL MALFUNCTION	Inhibit steering lock/unlock
B27E0-00: S/L LOW LEVEL MALFUNCTION	Inhibit steering lock
B27E1-00: S/L SAFETY CIRCUIT	Inhibit steering lock
B27E5-00: S/L IGN OFF POSITION	Inhibit steering lock
B27E6-00: S/L ANTI-SCAN MODE	Inhibit steering lock
B27E8-00: S/L UNDETERMINED LOCK POS	Inhibit steering lock
U0415: VEHICLE SPEED	Inhibit steering lock

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

< SYSTEM DESCRIPTION >

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

BCM detects the rain sensor serial link error and the rain sensor malfunction.

BCM controls the following fail-safe when rain sensor has a malfunction.

- Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
- Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

NOTE:

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010869011

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> • Read and save the vehicle specification. • Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Exterior lamp	HEAD LAMP	x	x	x
Interior room lamp control	INT LAMP		x	
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	
—	AIR CONDITIONER*		x	x
Intelligent Key system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU		x	
Interior room lamp battery saver	BATTERY SAVER		x	
Back door open	TRUNK		x	
Vehicle security	THEFT ALM	x	x	
RAP	RETAINED PWR		x	
Remote keyless entry system	MULTI REMOTE ENT	x	x	
Signal buffer system	SIGNAL BUFFER		x	x

NOTE:

*: This item is displayed, but not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

CONSULT screen item	Indication/Unit	Description
BATTERY VOLTAGE	V	Battery voltage of the moment a particular DTC is detected.
VEHICLE SPEED	km/h	Vehicle speed of the moment a particular DTC is detected.
EXTERNAL TEMP	°C	External temperature of the moment a particular DTC is detected
VEHICLE COND	—	NOTE: This item is displayed, but cannot be used this item.
DOOR LOCK STATUS	—	NOTE: This item is displayed, but cannot be used this item.
POWER SUPPLY COUNTER	min	Displays the cumulative time from the time that the battery terminal is connected.

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (With Super Lock)

INFOID:0000000010869012

WORK SUPPORT

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operation in this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
TRUNK/GLASS HATCH OPEN	NOTE: This item is displayed, but cannot be monitored
AUTO LOCK SET	Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"> MODE 1: OFF MODE 2: 30 sec MODE 3: 1 minute MODE 4: 2 minutes MODE 5: 3 minutes MODE 6: 4 minutes MODE 7: 5 minutes
SHORT CRANKING OUTPUT	NOTE: This item is displayed, but cannot be monitored
IGN/ACC BATTERY SAVER	Ignition battery saver system mode can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
ANSWER BACK	NOTE: This item is displayed, but cannot be used
ANSWER BACK I-KEY LOCK UN-LOCK	NOTE: This item is displayed, but cannot be monitored
ANSWER BACK KEYLESS LOCK UNLOCK	NOTE: This item is displayed, but cannot be monitored

SELF-DIAG RESULT

Refer to [BCS-78, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of back door request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
CLUTCH SW*1	Indicates [On/Off] condition of clutch interlock switch
BRAKE SW 1	Indicates [On/Off]*2 condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
START CLUTCH SW	Indicates [On/Off] condition of clutch pedal position switch
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
NEUTRAL SW - IPDM	Indicates [On/Off] condition of reverse/neutral position switch
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
STARTER RELAY - IPDM	Indicates [On/Off] condition of starter relay
ENGINE STATE	Indicates [Stop/Stall/Crank/Run] condition of engine states
ST/INHIRELAY-IPDM	Display the starter relay/starter control relay status signal from IPDM E/R via CAN communication
REVERSE SIGNAL - IPDM	Indicates [On/Off] condition of R position
CRANKING PERMIT - ECM	Display the engine cranking permit signal from ECM via CAN communication
IS STATUS - ECM	Indicates [On/Off] condition of stop/start system
STARTER CUT RELAY - ECM	Indicates [On/Off] condition of starter control relay signal from ECM via CAN communication
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [Km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS actuator and electric unit (control unit) by numerical value [Km/h]
IGN REQ - IPDM	Display the ignition request signal from IPDM E/R via CAN communication
STARTER REQ - IPDM	Display the starter request signal from IPDM E/R via CAN communication
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
ID OK FLAG	Indicates [Set/Reset] condition of Intelligent Key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored
I-KEY OK FLAG	Indicates [KEY On/NOT On] condition of Intelligent Key ID and Intelligent Key is detected inside vehicle
PRBT ENG STRT	Indicates whether or not the engine is in start prohibited status
ID AUTHENT CANCEL TIMER	Indicates whether or not it is in engine start possible status when Intelligent Key verification is unnecessary
ACC BATTERY SAVER	Indicates [On/Off] whether or not ignition battery saver is in operation
CRNK PRBT TMR	Indicates [On/Off] whether or not in cranking prohibited status due to starter motor protection function operation
AUT CRANK TMR	Indicates [On/Off] whether or not in AUTO CRANKING MODE status
CRNK PRBT TME	Indicates the time for changing from cranking prohibited status to cranking possible status

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item	Condition
AUT CRANK TMR	Indicates the time that AUTO CRANKING MODE operates
CRANKING TME	Indicates the cranking operation time
SHORT CRANK	NOTE: This item is displayed, but not used
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored
S/L IGN OFF POSITION	Indicates [On/Off] condition of Ignition OFF signal
S/L SENSOR CIRCUIT 1	Indicates [Gnd/On] condition of steering lock unit sensor circuit
S/L SENSOR CIRCUIT 2	Indicates [On/Off] condition of steering lock unit sensor circuit
S/L POWER OUTPUT	Indicates [On/Off] condition of steering lock unit power supply
S/L POWER CHECK	Indicates [On/Off] condition of steering lock unit power supply
ANTICIPATED POWER	Indicates [On/Off] condition of anticipated power supply
S/L LOCK REQ	Indicates [On/Off] condition of steering lock unit lock request signal
S/L - BCM (CAN)	Indicates [On/Off] condition of CAN communication
S/L POWER ERROR	Indicates [On/Off] condition of steering lock unit power supply error
VEH SPEED ERROR (S/L)	Indicates [On/Off] condition of vehicle speed signal
VEH SPEED NORMAL (S/L)	Indicates [On/Off] condition of vehicle speed signal
ENGINE RUNNING (S/L)	Indicates [On/Off] condition of engine running
S/L ID DISCORD	Indicates [Correct/Incorrect] condition of ID verification
S/L ANTI-SCAN MODE	Indicates [On/Off] condition of antiscan mode
S/L LOCK NOT PERMIT	Indicates [Inhibition/No inhibt] condition of inhibit steering lock
S/L UNLOCK (CAN)	Indicates [Finished/Unfinished] condition of steering lock unit unlock
S/L ID STATUS (CAN)	Indicates [Coded/Blank] condition of registration ID
S/L RESET STATUS (CAN)	Indicates [Exit/No exit] condition of steering lock unit reset signal
S/L LO-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of lo-level malfunction
S/L LOCK POSITION (CAN)	Indicates [Armed/Malf/Unlocked/Undefined] condition of lock/unlock position signal
S/L ACT MALFUNCTION (CAN)	Indicates [Malf/No malf] condition of steering lock unit malfunction
S/L HI-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of hi-level malfunction
S/L OPERATION PRHBT (SPD)	Indicates [On/Off] condition of vehicle speed signal
S/L OPERATION PRHBT (PWR)	Indicates [Allowed/Forbid] condition of safety line inhibition
S/L SENSOR POWER (CAN)	Indicates [On/Off] condition of sensor test power supply
S/L SEN TEST PERMIT (CAN)	Indicates [Forbid/Authorize] condition of sensor test
S/L STAT NOT DETECT (CAN)	Indicates [Ok/Undefind] condition of steering lock undefined position signal
S/L LOCKING FINISHED (CAN)	Indicates [Unfinshd/Finished] condition of steering lock unit lock status signal
STOP/START SW	Indicates [On/Off] condition of stop/start off switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored
RKE-PANIC	NOTE: This item is displayed, but cannot be monitored
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from Intelligent Key
RKE PBD	Indicates [On/Off] condition of back door open request signal from Intelligent Key

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item	Condition
KEY SW	NOTE: This item is displayed, but cannot be monitored
IGN SW	NOTE: This item is displayed, but cannot be monitored
START SW	NOTE: This item is displayed, but cannot be monitored

*¹: It is displayed but does not operate on CVT models.

*²: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation • On: Operate • Off: Non-operation
INSIDE BUZZER	This test is able to check warning chime in combination meter operation • Buzzer 1: Combination meter buzzer sounds (pipipi...) when CONSULT screen is touched • Buzzer 2: Combination meter buzzer sounds (pipi-pipi-...) when CONSULT screen is touched • Buzzer 3: Combination meter buzzer sounds (pipipi-pipipi-...) when CONSULT screen is touched • Off: Non-operation
INDICATOR	This test is able to check warning lamp operation • KEY ON: [Intelligent Key system malfunction] displays when CONSULT screen is touched • KEY IND: "KEY" Warning lamp blinks when CONSULT screen is touched • Off: Non-operation
FLASHER	This test is able to check security hazard lamp operation The hazard lamps are activated after "LH/RH/Off" on CONSULT screen is touched
HORN	NOTE: This item is displayed, but cannot be used
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) • On: Operates • Off: Non-operation
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "ON" on CONSULT screen is touched
ENGINE START REQUEST	This test is able to check BCM sends starter request signal to IPDM E/R via CAN communication • MODE 1: IGN ON, START request OFF • MODE 2: IGN OFF, START request ON • MODE 3: IGN ON, START request ON • Off: Non-operation
IGNITION RELAY	NOTE: This item is displayed, but cannot be used
STARTER CUT RELAY	This test is able to operate the starter control relay • On: Operates • Off: Non-operation
ENGINE START	NOTE: This item is displayed, but cannot be used
TRUNK/BACK DOOR	NOTE: This item is displayed, but cannot be used
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used
AUTO ACC 2	This test is able to check BCM sends power supply to audio unit or NAVI control unit • On: Operate • Off: Non-operation

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Test item	Description
AUTOMATIC BACK DOOR	NOTE: This item is displayed, but cannot be used
AUTO ACC 1	This test is able to check BCM sends power supply to ignition relay <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk/luggage room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) (Without Super Lock)

INFOID:000000010869013

WORK SUPPORT

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operation in this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
TRUNK/GLASS HATCH OPEN	NOTE: This item is displayed, but cannot be monitored
AUTO LOCK SET	Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"> • MODE 1: OFF • MODE 2: 30 sec • MODE 3: 1 minute • MODE 4: 2 minutes • MODE 5: 3 minutes • MODE 6: 4 minutes • MODE 7: 5 minutes
SHORT CRANKING OUTPUT	NOTE: This item is displayed, but cannot be monitored
IGN/ACC BATTERY SAVER	Ignition battery saver system mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
ANSWER BACK	NOTE: This item is displayed, but cannot be used
ANSWER BACK I-KEY LOCK UN-LOCK	NOTE: This item is displayed, but cannot be used
ANSWER BACK KEYLESS LOCK UNLOCK	NOTE: This item is displayed, but cannot be used

SELF-DIAG RESULT

Refer to [BCS-78, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of door request switch (passenger side)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item	Condition
REQ SW -BD/TR	Indicates [On/Off] condition of back door request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
CLUTCH SW* ¹	Indicates [On/Off] condition of clutch interlock switch
BRAKE SW 1	Indicates [On/Off]* ² condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
START CLUTCH SW	Indicates [On/Off] condition of clutch pedal position switch
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
NEUTRAL SW - IPDM	Indicates [On/Off] condition of reverse/neutral position switch
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
STARTER RELAY - IPDM	Indicates [On/Off] condition of starter relay
ENGINE STATE	Indicates [Stop/Stall/Crank/Run] condition of engine states
ST/INHIRELAY-IPDM	Display the starter relay/starter control relay status signal from IPDM E/R via CAN communication
REVERSE SIGNAL - IPDM	Indicates [On/Off] condition of R position
CRANKING PERMIT - ECM	Display the engine cranking permit signal from ECM via CAN communication
IS STATUS - ECM	Indicates [On/Off] condition of stop/start system
STARTER CUT RELAY - ECM	Indicates [On/Off] condition of starter control relay signal from ECM via CAN communication
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [Km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS actuator and electric unit (control unit) by numerical value [Km/h]
IGN REQ - IPDM	Display the ignition request signal from IPDM E/R via CAN communication
STARTER REQ - IPDM	Display the starter request signal from IPDM E/R via CAN communication
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
ID OK FLAG	Indicates [Set/Reset] condition of Intelligent Key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored
I-KEY OK FLAG	Indicates [KEY On/NOT On] condition of Intelligent Key ID and Intelligent Key is detected inside vehicle
PRBT ENG STRT	Indicates whether or not the engine is in start prohibited status
ID AUTHENT CANCEL TIMER	Indicates whether or not it is in engine start possible status when Intelligent Key verification is unnecessary
ACC BATTERY SAVER	Indicates [On/Off] whether or not ignition battery saver is in operation
CRNK PRBT TMR	Indicates [On/Off] whether or not in cranking prohibited status due to starter motor protection function operation
AUT CRANK TMR	Indicates [On/Off] whether or not in AUTO CRANKING MODE status
CRNK PRBT TME	Indicates the time for changing from cranking prohibited status to cranking possible status
AUT CRANK TMR	Indicates the time that AUTO CRANKING MODE operates
CRANKING TME	Indicates the cranking operation time

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item	Condition
SHORT CRANK	NOTE: This item is displayed, but not used
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored
S/L IGN OFF POSITION	Indicates [On/Off] condition of Ignition OFF signal
S/L SENSOR CIRCUIT 1	Indicates [Gnd/On] condition of steering lock unit sensor circuit
S/L SENSOR CIRCUIT 2	Indicates [On/Off] condition of steering lock unit sensor circuit
S/L POWER OUTPUT	Indicates [On/Off] condition of steering lock unit power supply
S/L POWER CHECK	Indicates [On/Off] condition of steering lock unit power supply
ANTICIPATED POWER	Indicates [On/Off] condition of anticipated power supply
S/L LOCK REQ	Indicates [On/Off] condition of steering lock unit lock request signal
S/L - BCM (CAN)	Indicates [On/Off] condition of CAN communication
S/L POWER ERROR	Indicates [On/Off] condition of steering lock unit power supply error
VEH SPEED ERROR (S/L)	Indicates [On/Off] condition of vehicle speed signal
VEH SPEED NORMAL (S/L)	Indicates [On/Off] condition of vehicle speed signal
ENGINE RUNNING (S/L)	Indicates [On/Off] condition of engine running
S/L ID DISCORD	Indicates [Correct/Incorrect] condition of ID verification
S/L ANTI-SCAN MODE	Indicates [On/Off] condition of antiscan mode
S/L LOCK NOT PERMIT	Indicates [Inhibition/No inhibt] condition of inhibit steering lock
S/L UNLOCK (CAN)	Indicates [Finished/Unfinished] condition of steering lock unit unlock
S/L ID STATUS (CAN)	Indicates [Coded/Blank] condition of registration ID
S/L RESET STATUS (CAN)	Indicates [Exit/No exit] condition of steering lock unit reset signal
S/L LO-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of lo-level malfunction
S/L LOCK POSITION (CAN)	Indicates [Armed/Malf/Unlocked/Undefined] condition of lock/unlock position signal
S/L ACT MALFUNCTION (CAN)	Indicates [Malf/No malf] condition of steering lock unit malfunction
S/L HI-LEVEL MALFUNC (CAN)	Indicates [Malf/No malf] condition of hi-level malfunction
S/L OPERATION PRHBT (SPD)	Indicates [On/Off] condition of vehicle speed signal
S/L OPERATION PRHBT (PWR)	Indicates [Allowed/Forbid] condition of safety line inhibition
S/L SENSOR POWER (CAN)	Indicates [On/Off] condition of sensor test power supply
S/L SEN TEST PERMIT (CAN)	Indicates [Forbid/Authorize] condition of sensor test
S/L STAT NOT DETECT (CAN)	Indicates [Ok/Undefind] condition of steering lock undefined position signal
S/L LOCKING FINISHED (CAN)	Indicates [Unfinshd/Finished] condition of steering lock unit lock status signal
STOP/START SW	Indicates [On/Off] condition of stop/start off switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored
RKE-PANIC	NOTE: This item is displayed, but cannot be monitored
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from Intelligent Key
RKE PBD	Indicates [On/Off] condition of back door open request signal from Intelligent Key
KEY SW	NOTE: This item is displayed, but cannot be monitored

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item	Condition
IGN SW	NOTE: This item is displayed, but cannot be monitored
START SW	NOTE: This item is displayed, but cannot be monitored
* ¹ : It is displayed but does not operate on CVT models.	
* ² : OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.	
ACTIVE TEST	
Test item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation • On: Operate • Off: Non-operation
INSIDE BUZZER	This test is able to check warning chime in combination meter operation • Buzzer 1: Combination meter buzzer sounds (pipipi...) when CONSULT screen is touched • Buzzer 2: Combination meter buzzer sounds (pipi-pipi-...) when CONSULT screen is touched • Buzzer 3: Combination meter buzzer sounds (pipipi-pipipi-...) when CONSULT screen is touched • Off: Non-operation
INDICATOR	This test is able to check warning lamp operation • KEY ON: [Intelligent Key system malfunction] displays when CONSULT screen is touched • KEY IND: "KEY" Warning lamp blinks when CONSULT screen is touched • Off: Non-operation
FLASHER	This test is able to check security hazard lamp operation The hazard lamps are activated after "LH/RH/Off" on CONSULT screen is touched
HORN	NOTE: This item is displayed, but cannot be used
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) • On: Operates • Off: Non-operation
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "ON" on CONSULT screen is touched
ENGINE START REQUEST	This test is able to check BCM sends starter request signal to IPDM E/R via CAN communication • MODE 1: IGN ON, START request OFF • MODE 2: IGN OFF, START request ON • MODE 3: IGN ON, START request ON • Off: Non-operation
IGNITION RELAY	NOTE: This item is displayed, but cannot be used
STARTER CUT RELAY	This test is able to operate the starter control relay • On: Operates • Off: Non-operation
ENGINE START	NOTE: This item is displayed, but cannot be used
TRUNK/BACK DOOR	NOTE: This item is displayed, but cannot be used
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used
AUTO ACC 2	This test is able to check BCM sends power supply to audio unit or NAVI control unit • On: Operate • Off: Non-operation
AUTOMATIC BACK DOOR	NOTE: This item is displayed, but cannot be used

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Test item	Description
AUTO ACC 1	This test is able to check BCM sends power supply to ignition relay • On: Operate • Off: Non-operation
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk/luggage room lamp operation • On: Operates • Off: Non-operation

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:000000010741740

ECU	Reference
BCM	BCS-53, "Reference Value"
	BCS-76, "Fail-safe"
	BCS-77, "DTC Inspection Priority Chart"
	BCS-78, "DTC Index"

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >


[POWER DISTRIBUTION SYSTEM]

WIRING DIAGRAM

POWER DISTRIBUTION SYSTEM

Wiring Diagram

INFOID:0000000010741741



*: This connector is not shown in "Harness Layout".


2014/03/17

POWER DISTRIBUTION SYSTEM

[POWER DISTRIBUTION SYSTEM]

< WIRING DIAGRAM >

IS With stop/start system
OS Without stop/start system




JRMWF4080GB

PCS

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]



JRMWF4081GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

Connector No. B8	Wire To Wire	Signal Name [Specification]	Terminal Color Of No. 13	P	Signal Name [Specification]	Terminal Color Of No. 13	P
Connector Name NS16M/CS			14	S3		14	S3
Connector Type TH4FW-NH			15	V		15	V
			16	P		16	P
			17	P		17	P
			18	G		18	G
			19	P		19	P
			20	R		20	R
			21	BR		21	BR
			22	Y		22	Y
			23	BG		23	BG
			24	SB		24	SB
			25	G		25	G
			26	B		26	B
			27	P		27	P
			28	R		28	R
			29	LG		29	LG
			30	P		30	P
			92	BR		92	BR
			93	GR		93	GR
			94	Y		94	Y
			95	LG		95	LG
			97	LG		97	LG
Connector No. B27	Wire To Wire	Signal Name [Specification]	Terminal Color Of No. 6	R	Signal Name [Specification]	Terminal Color Of No. 6	R
Connector Name NS16M/CS			7	LA/G		7	LA/G
Connector Type TH4FW-NH			8	LA/R		8	LA/R
			9	LA/B		9	LA/B
			10	LA/W		10	LA/W
			11	LA/R		11	LA/R
			12	W		12	W
			13	LG		13	LG
			14	GR		14	GR
			15	Y		15	Y
			16	LG		16	LG
			17	SB		17	SB
			18	P		18	P
			19	LA/Y		19	LA/Y
			20	LA/R		20	LA/R
			21	BR		21	BR
			22	Y		22	Y
			23	LG		23	LG
			24	GR		24	GR
			25	LA/G		25	LA/G
			26	LA/R		26	LA/R
			27	LA/B		27	LA/B
			28	W		28	W
			29	LA/W		29	LA/W
			30	LA/N		30	LA/N
			31	LA/R		31	LA/R
			32	LA/B		32	LA/B
			33	W		33	W
			34	LG		34	LG
			35	GR		35	GR
			36	Y		36	Y
			37	LG		37	LG
			38	SB		38	SB
			39	P		39	P
			40	LA/W		40	LA/W
				CANL			CANL

JRMWF4082GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	B71	23 L	-		Connector No.	D21	23 L	-	
Connector Name	REAR DOOR SWITCH LH	24 BG	-		Connector Name	WIRE TO WIRE	-		
Connector Type	TH24FW-NH				Connector Type	TH24FW-NH			
Connector No.	D1	23 L	-		Connector No.	D11	23 L	-	
Connector Name	FRONT DOOR/OUTSIDE HANDLE ASSEMBLY/PASSENGER SIDE	24 BG	-		Connector Name	FRONT DOOR/OUTSIDE HANDLE ASSEMBLY/PASSENGER SIDE	23 L	-	
Connector Type	RH4FB				Connector Type	RH4FB			
Connector No.	D2	23 L	-		Connector No.	D15	23 L	-	
Connector Name	WIRE TO WIRE	24 BG	-		Connector Name	D15	23 L	-	
Connector Type	NS16FW-CS				Connector Name	FRONT DOOR/OUTSIDE HANDLE ASSEMBLY/DRIVER SIDE	23 L	-	
					Connector Type	RH4FB			
Terminal Color Of		7 6 5 4	3 2 1		Terminal Color Of		12 11 10 9 8 7 6 5 4 3 2 1		
No.		16 15 14 13 12 11 10 9 8			No.	24 23 22 21 20 19 18 17 16 15 14 13			
Wire					Wire				
Terminal Color Of		1 LAV	-		Terminal Color Of		1 R	-	
No.		2 R	-		No.	2 SB	-		
Wire					Wire				
Terminal Color Of		3 LAG	-		Terminal Color Of		3 P	-	
No.		4 B	-		No.	4 B	-		
Wire					Wire				
Connector No.	D1	23 L	-		Connector No.	D15	23 L	-	
Connector Name	WIRE TO WIRE	24 BG	-		Connector Name	D15	23 L	-	
Connector Type	TH24FW-NH				Connector Name	FRONT DOOR/OUTSIDE HANDLE ASSEMBLY/DRIVER SIDE	23 L	-	
					Connector Type	RH4FB			
Terminal Color Of		1 LAV	-		Terminal Color Of		1 LAV	-	
No.		2 SB	-		No.	2 SB	-		
Wire					Wire				
Terminal Color Of		3 LAG	-		Terminal Color Of		3 P	-	
No.		4 B	-		No.	4 B	-		
Wire					Wire				
Terminal Color Of		5 LAV	-		Terminal Color Of		5 V	-	
No.		6 SB	-		No.	6 SB	-		
Wire					Wire				
Terminal Color Of		7 LAV	-		Terminal Color Of		7 L	-	
No.		8 SB	-		No.	8 G	-		
Wire					Wire				
Terminal Color Of		9 LAV	-		Terminal Color Of		9 Y	-	
No.		10 SB	-		No.	10 B	-		
Wire					Wire				
Terminal Color Of		11 LAV	-		Terminal Color Of		11 G	-	
No.		12 SB	-		No.	11 G	-		
Wire					Wire				
Terminal Color Of		13 LAV	-		Terminal Color Of		13 LAV	-	
No.		14 LAV	-		No.	14 LAV	-		
Wire					Wire				
Terminal Color Of		15 LAV	-		Terminal Color Of		15 LAV	-	
No.		16 B	-		No.	16 B	-		
Wire					Wire				
Terminal Color Of		17 LAV	-		Terminal Color Of		17 LAV	-	
No.		18 SB	-		No.	18 SB	-		
Wire					Wire				
Terminal Color Of		19 LAV	-		Terminal Color Of		19 LAV	-	
No.		20 GR	-		No.	20 GR	-		
Wire					Wire				
Terminal Color Of		21 LAV	-		Terminal Color Of		21 LAV	-	
No.		22 BG	-		No.	22 BG	-		
Wire					Wire				
Terminal Color Of		23 L	-		Terminal Color Of		23 L	-	
No.		24 L	-		No.	24 L	-		
Wire					Wire				
Terminal Color Of		25 LAV	-		Terminal Color Of		25 LAV	-	
No.		26 SB	-		No.	26 SB	-		
Wire					Wire				
Terminal Color Of		27 LAV	-		Terminal Color Of		27 LAV	-	
No.		28 SB	-		No.	28 SB	-		
Wire					Wire				
Terminal Color Of		29 LAV	-		Terminal Color Of		29 LAV	-	
No.		30 GR	-		No.	30 GR	-		
Wire					Wire				
Terminal Color Of		31 LAV	-		Terminal Color Of		31 LAV	-	
No.		32 SB	-		No.	32 SB	-		
Wire					Wire				
Terminal Color Of		33 LAV	-		Terminal Color Of		33 LAV	-	
No.		34 SB	-		No.	34 SB	-		
Wire					Wire				
Terminal Color Of		35 LAV	-		Terminal Color Of		35 LAV	-	
No.		36 GR	-		No.	36 GR	-		
Wire					Wire				
Terminal Color Of		37 LAV	-		Terminal Color Of		37 LAV	-	
No.		38 SB	-		No.	38 SB	-		
Wire					Wire				
Terminal Color Of		39 LAV	-		Terminal Color Of		39 LAV	-	
No.		40 GR	-		No.	40 GR	-		
Wire					Wire				
Terminal Color Of		41 LAV	-		Terminal Color Of		41 LAV	-	
No.		42 SB	-		No.	42 SB	-		
Wire					Wire				
Terminal Color Of		43 LAV	-		Terminal Color Of		43 LAV	-	
No.		44 SB	-		No.	44 SB	-		
Wire					Wire				
Terminal Color Of		45 LAV	-		Terminal Color Of		45 LAV	-	
No.		46 SB	-		No.	46 SB	-		
Wire					Wire				
Terminal Color Of		47 LAV	-		Terminal Color Of		47 LAV	-	
No.		48 SB	-		No.	48 SB	-		
Wire					Wire				
Terminal Color Of		49 LAV	-		Terminal Color Of		49 LAV	-	
No.		50 GR	-		No.	50 GR	-		
Wire					Wire				
Terminal Color Of		51 LAV	-		Terminal Color Of		51 LAV	-	
No.		52 SB	-		No.	52 SB	-		
Wire					Wire				
Terminal Color Of		53 LAV	-		Terminal Color Of		53 LAV	-	
No.		54 GR	-		No.	54 GR	-		
Wire					Wire				
Terminal Color Of		55 LAV	-		Terminal Color Of		55 LAV	-	
No.		56 SB	-		No.	56 SB	-		
Wire					Wire				
Terminal Color Of		57 LAV	-		Terminal Color Of		57 LAV	-	
No.		58 GR	-		No.	58 GR	-		
Wire					Wire				
Terminal Color Of		59 LAV	-		Terminal Color Of		59 LAV	-	
No.		60 GR	-		No.	60 GR	-		
Wire					Wire				
Terminal Color Of		61 LAV	-		Terminal Color Of		61 LAV	-	
No.		62 SB	-		No.	62 SB	-		
Wire					Wire				
Terminal Color Of		63 LAV	-		Terminal Color Of		63 LAV	-	
No.		64 GR	-		No.	64 GR	-		
Wire					Wire				
Terminal Color Of		65 LAV	-		Terminal Color Of		65 LAV	-	
No.		66 SB	-		No.	66 SB	-		
Wire					Wire				
Terminal Color Of		67 LAV	-		Terminal Color Of		67 LAV	-	
No.		68 GR	-		No.	68 GR	-		
Wire					Wire				
Terminal Color Of		69 LAV	-		Terminal Color Of		69 LAV	-	
No.		70 SB	-		No.	70 SB	-		
Wire					Wire				
Terminal Color Of		71 LAV	-		Terminal Color Of		71 LAV	-	
No.		72 GR	-		No.	72 GR	-		
Wire					Wire				
Terminal Color Of		73 LAV	-		Terminal Color Of		73 LAV	-	
No.		74 SB	-		No.	74 SB	-		
Wire					Wire				
Terminal Color Of		75 LAV	-		Terminal Color Of		75 LAV	-	
No.		76 GR	-		No.	76 GR	-		
Wire					Wire				
Terminal Color Of		77 LAV	-		Terminal Color Of		77 LAV	-	
No.		78 SB	-		No.	78 SB	-		
Wire					Wire				
Terminal Color Of		79 LAV	-		Terminal Color Of		79 LAV	-	
No.		80 GR	-		No.	80 GR	-		
Wire					Wire				
Terminal Color Of		81 LAV	-		Terminal Color Of		81 LAV	-	
No.		82 SB	-		No.	82 SB	-		
Wire					Wire				
Terminal Color Of		83 LAV	-		Terminal Color Of		83 LAV	-	
No.		84 GR	-		No.	84 GR	-		
Wire					Wire				
Terminal Color Of		85 LAV	-		Terminal Color Of		85 LAV	-	
No.		86 SB	-		No.	86 SB	-		
Wire					Wire				
Terminal Color Of		87 LAV</td							

POWER DISTRIBUTION SYSTEM

[POWER DISTRIBUTION SYSTEM]

< WIRING DIAGRAM >

PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	D33	Connector Name	FRONT DOOR OUTSIDE HANDLE ASSEMBLY (DRIVERS SIDE)	Connector Type	RH4FB	Connector No.	D41	Connector Name	WIRE TO WIRE	Connector Type	TR24FW-NH	Connector No.	E7	Connector Name	WIRE TO WIRE	Connector Type	NST6FW-SC
Terminal Color Of No.		Signal Name (Specification)				Terminal Color Of No.		Signal Name (Specification)				Terminal Color Of No.		Signal Name (Specification)			
1	V	-	1	B	-	5	SB	-	6	LG	-	1	BR	-	1	BR	-
2	SB	-	3	B	-	7	L	-	8	V	-	2	SB	-	2	BR	-
3	W	-	4	P	-	9	Y	-	10	B	-	3	GR	-	3	GR	-
4	B	-	5	R	-	11	R	-	12	LA/W	-	4	R	-	4	R	-
			6	SB	-	13	B	-	14	LA/G	-	5	BR	-	5	LG	-
			7	L	-	15	LA/G	-	16	LA/R	-	6	BR	-	6	BR	-
			8	V	-	17	LA/P	-	18	LA/SB	-	7	BR	-	7	BR	-
			9	Y	-	19	B	-	20	LG	-	8	Y	-	8	Y	-
			10	B	-	21	BR	-	22	LA/G	-	9	BR	-	9	BR	-
			11	G	-							10	BR	-	10	BR	-
			13	LA/Y	-							11	Y	-	11	Y	-
			14	LA/R	-							12	L	-	12	L	-
			15	LA/V	-							13	BR	-	13	BR	-
			16	LA/L	-							14	R	-	14	R	-
			17	LA/G	-							15	L	-	15	L	-
			18	GR	-							16	SB	-	16	SB	-
			21	LA/G	-												

JRMWF4084GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
Connector No. E8	3	P	25	LG	1	G
Connector Name WIRE TO WIRE	4	Y	26	W	2	W
Connector Type M02MNL-C	7	L	27	SB	5	G
	8	BG	28	P	11	BR
	9	L	30	L	12	W
	12	B	31	G	13	P
	16	G	32	B	14	Sb
	17	W	33	BG	15	V
	35	V	36	Y	16	P
	37	B	38	GR	17	V
	39	BR	45	L	18	G
	46	P	47	W	19	P
	48	R			20	G
					21	BR
					22	LG
					23	Y
					24	Sb
					25	G
					26	B
					27	P
					28	R
					29	LG
					30	P
					32	BR
					33	GR
					34	R
					164	Y
					166	P
					167	BR
					168	W
					169	LG
					170	L
					171	G
					172	V
					173	BG

JRMWF4085GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	E105	Terminal Color Of Wire	Signal Name (Specification)	Terminal Color Of Wire	Signal Name (Specification)
Connector Name	WIRE TO WIRE	2	W	1	V
Connector Type	TH0FW-CS16-TMA	5	V	2	LG
		5	W	3	Y
		8	L	4	W
		9	LG		
		10	W		
		20	W		
		21	B		
		22	SHIELD		
		31	Y		
		32	W		
		33	SB		
		34	LG		
		35	BG		
		36	LG		
		37	V		
		38	G		
		39	BR		
		40	L		
		41	P		
		47	GR		
		48	SB		
		51	P		
		52	L		
		53	W		
		54	Y		
		55	BR		
		56	P		
		57	B		
		58	L		
		59	W		
		60	G		
		61	BR		
		62	V		
		63	BR		
		64	GR		


Connector No.	E121
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Connector No.	E120
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Connector No.	E169
Connector Name	WIRE TO WIRE
Connector Type	M06MMW-LC




Connector No.	E109
Connector Name	CLUTCH INTERLOCK SWITCH
Connector Type	M02FBR-LC




Connector No.	E120
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Connector No.	E169
Connector Name	WIRE TO WIRE
Connector Type	M06MMW-LC



Connector No.	E120
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



Connector No.	E169
Connector Name	WIRE TO WIRE
Connector Type	M06MMW-LC



POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)																																																																																																																																																																																						
Connector No. F22	Connector No. F48	Connector No. F72																																																																																																																																																																																				
Connector Name TRANSMISSION RANGE SWITCH	Connector Name NEUTRAL POSITION SWITCH	Connector Name POWER INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM																																																																																																																																																																																				
Connector Type YDK05FB-HSA	Connector Type RKC02FB	Connector Type NST6FW CS																																																																																																																																																																																				
																																																																																																																																																																																						
<table border="1"> <thead> <tr> <th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th><th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th><th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr> <td>1 BG</td><td>-</td><td>65 P</td><td>-</td><td>86 LG</td><td>-</td></tr> <tr> <td>2 GR</td><td>-</td><td>66 L</td><td>- [With R3M Engine]</td><td>87 L</td><td>-</td></tr> <tr> <td>3 W</td><td>-</td><td>67 R</td><td>- [With MR20 or QR25 Engine]</td><td>88 P</td><td>-</td></tr> <tr> <td>4 V</td><td>-</td><td>70 BG</td><td>- [With CVT]</td><td>89 W</td><td>-</td></tr> <tr> <td>5 G</td><td>-</td><td>70 GR</td><td>- [With MT]</td><td>90 R</td><td>-</td></tr> <tr> <td>6 BR</td><td>-</td><td>71 SB</td><td>-</td><td>92 GR</td><td>-</td></tr> <tr> <td>7 Y</td><td>-</td><td>72 R</td><td>-</td><td>93 G</td><td>- [With R3M Engine]</td></tr> <tr> <td>8 GR</td><td>-</td><td>73 Y</td><td>- [With R3M Engine]</td><td>94 SB</td><td>- [With MR20 or QR25 Engine]</td></tr> <tr> <td></td><td></td><td>75 BR</td><td>- [With MR20 or QR25 Engine]</td><td>95 LG</td><td>-</td></tr> <tr> <td></td><td></td><td>75 L</td><td>- [With R3M Engine]</td><td>96 W</td><td>-</td></tr> <tr> <td></td><td></td><td>76 P</td><td>-</td><td>97 P</td><td>-</td></tr> <tr> <td></td><td></td><td>78 L</td><td>- [With QR25 Engine]</td><td>98 Y</td><td>-</td></tr> <tr> <td></td><td></td><td>78 R</td><td>- [With R3M Engine]</td><td>99 BG</td><td>-</td></tr> <tr> <td></td><td></td><td>79 G</td><td>-</td><td>100 LG</td><td>-</td></tr> <tr> <td></td><td></td><td></td><td></td><td>101 V</td><td>-</td></tr> <tr> <td></td><td></td><td></td><td></td><td>102 Y</td><td>-</td></tr> <tr> <td></td><td></td><td></td><td></td><td>105 W</td><td>-</td></tr> <tr> <td></td><td></td><td></td><td></td><td>106 BR</td><td>-</td></tr> <tr> <td></td><td></td><td></td><td></td><td>107 V</td><td>-</td></tr> <tr> <td></td><td></td><td></td><td></td><td>110 SB</td><td>-</td></tr> </tbody> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	1 BG	-	65 P	-	86 LG	-	2 GR	-	66 L	- [With R3M Engine]	87 L	-	3 W	-	67 R	- [With MR20 or QR25 Engine]	88 P	-	4 V	-	70 BG	- [With CVT]	89 W	-	5 G	-	70 GR	- [With MT]	90 R	-	6 BR	-	71 SB	-	92 GR	-	7 Y	-	72 R	-	93 G	- [With R3M Engine]	8 GR	-	73 Y	- [With R3M Engine]	94 SB	- [With MR20 or QR25 Engine]			75 BR	- [With MR20 or QR25 Engine]	95 LG	-			75 L	- [With R3M Engine]	96 W	-			76 P	-	97 P	-			78 L	- [With QR25 Engine]	98 Y	-			78 R	- [With R3M Engine]	99 BG	-			79 G	-	100 LG	-					101 V	-					102 Y	-					105 W	-					106 BR	-					107 V	-					110 SB	-	<table border="1"> <thead> <tr> <th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th><th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th><th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr> <td>1 SB</td><td>-</td><td>81 G</td><td>-</td><td>83 L</td><td>-</td></tr> <tr> <td>2 G</td><td>-</td><td>84 GR</td><td>-</td><td>85 P</td><td>-</td></tr> <tr> <td>3 L</td><td>-</td><td></td><td></td><td></td><td></td></tr> <tr> <td>5 GR</td><td>-</td><td></td><td></td><td></td><td></td></tr> </tbody> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	1 SB	-	81 G	-	83 L	-	2 G	-	84 GR	-	85 P	-	3 L	-					5 GR	-					<table border="1"> <thead> <tr> <th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th><th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th><th>Terminal Color Of Wire No.</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr> <td>1</td><td>G</td><td>81</td><td>G</td><td>83</td><td>L</td></tr> <tr> <td>2</td><td>W</td><td>82</td><td>W</td><td>84</td><td>GR</td></tr> <tr> <td>3</td><td>SB</td><td>85</td><td>SB</td><td>86</td><td>P</td></tr> </tbody> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	1	G	81	G	83	L	2	W	82	W	84	GR	3	SB	85	SB	86	P
Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]																																																																																																																																																																																	
1 BG	-	65 P	-	86 LG	-																																																																																																																																																																																	
2 GR	-	66 L	- [With R3M Engine]	87 L	-																																																																																																																																																																																	
3 W	-	67 R	- [With MR20 or QR25 Engine]	88 P	-																																																																																																																																																																																	
4 V	-	70 BG	- [With CVT]	89 W	-																																																																																																																																																																																	
5 G	-	70 GR	- [With MT]	90 R	-																																																																																																																																																																																	
6 BR	-	71 SB	-	92 GR	-																																																																																																																																																																																	
7 Y	-	72 R	-	93 G	- [With R3M Engine]																																																																																																																																																																																	
8 GR	-	73 Y	- [With R3M Engine]	94 SB	- [With MR20 or QR25 Engine]																																																																																																																																																																																	
		75 BR	- [With MR20 or QR25 Engine]	95 LG	-																																																																																																																																																																																	
		75 L	- [With R3M Engine]	96 W	-																																																																																																																																																																																	
		76 P	-	97 P	-																																																																																																																																																																																	
		78 L	- [With QR25 Engine]	98 Y	-																																																																																																																																																																																	
		78 R	- [With R3M Engine]	99 BG	-																																																																																																																																																																																	
		79 G	-	100 LG	-																																																																																																																																																																																	
				101 V	-																																																																																																																																																																																	
				102 Y	-																																																																																																																																																																																	
				105 W	-																																																																																																																																																																																	
				106 BR	-																																																																																																																																																																																	
				107 V	-																																																																																																																																																																																	
				110 SB	-																																																																																																																																																																																	
Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]																																																																																																																																																																																	
1 SB	-	81 G	-	83 L	-																																																																																																																																																																																	
2 G	-	84 GR	-	85 P	-																																																																																																																																																																																	
3 L	-																																																																																																																																																																																					
5 GR	-																																																																																																																																																																																					
Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]																																																																																																																																																																																	
1	G	81	G	83	L																																																																																																																																																																																	
2	W	82	W	84	GR																																																																																																																																																																																	
3	SB	85	SB	86	P																																																																																																																																																																																	

JRMWTF4087GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

 
Connector No. F121
Connector Name WIRE TO WIRE
Connector Type NS16FRC-5
 
Connector No. F122
Connector Name WIRE TO WIRE
Connector Type NS16FRC-5
 
Connector No. E157
Connector Name BACK-UP LAMP SWITCH
Connector Type RK20FB
 
Connector No. M16
Connector Name PUSH-BUTTON IGNITION SWITCH
Connector Type T10DFV-NH

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	- (With MR20 or GR25 engine)	1	G	-
1	P	- (With RMR engine)	2	W	-
2	BR	- (With GR25 engine)			
2	GR	- (With MR20 engine)			
		Connect No. F136			

3	G	-	-	Connector No.	M18
4	BG	-	-	Connector Name	WIRE TO WIRE
5	B	- (With M12D0 engine)	- (With R3M engine)	Connector Type	TH24WW-NH
5	L	- (With R3M engine)	- (With QR225 engine)		
5	LG	-	-		
6	V	-	-		
7	C	-	-		
8	V	- (With M12D0 engine or R3M engine)	- (With QR225 engines)	Terminal Color Of	Signal Name (Specified)
8	W	- (With M12D0 engines)	- (With R3M engine)		
9	W	- (With R3M engine)	- (With QR225 engines)		

Signal Name [Specification]		Signal Name [Specification]	
No.	Wire	No.	Wire
10	BR	-	-
11	P	-	-
11	R	-	-
12	G	-	-
12	L	-	-
13	R	-	-
13	Y	-	-
15	L	-	-
16	LG	-	-
- (Without ISS)		- (With ISS)	
- (With SS)		- (With QR22 engine)	
- (With R30 engine)		- (With QR25 engine)	
- (With MR20 or QR25 engine)		- (With MR20 or QR25 engine)	
Terminal Color Of		Terminal Color Of	
No.		No.	
3		1	
3		B	
5		B	
6		B	
8		Y	
8		SB	
11		P	
15		BR	
1		B	
2		-	
4		-	
5		-	
6		-	
7		-	
9		-	
10		-	
12		-	
13		-	
14		-	
15		-	
16		-	

Terminal No.	Color Of Wire	Signal Name (Specification)
1	B	-
2	B	-
3	Y	-
4	V	-
5	BR	-
6	LG	-
7	L	-
8	Y	-
9	G	-
10	SHIELD	-
11	R	-
13	GR	-
14	LSAB	-
15	LAGR	-
16	LAV	-
17	LAL	-

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

20	B	GROUND
21	Y	
22	R	
23	G	
24	SB	
25	WIRE TO WIRE	
26	NS16MW/CS	
27	H.S.	
28	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
29	8 9 10 11 12 13 14 15 16	
30	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
31	8 9 10 11 12 13 14 15 16	
32	H.S.	
33	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
34	8 9 10 11 12 13 14 15 16	
35	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
36	8 9 10 11 12 13 14 15 16	
37	H.S.	
38	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
39	8 9 10 11 12 13 14 15 16	
40	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
41	8 9 10 11 12 13 14 15 16	
42	H.S.	
43	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
44	8 9 10 11 12 13 14 15 16	
45	H.S.	
46	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
47	8 9 10 11 12 13 14 15 16	
48	H.S.	
49	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
50	8 9 10 11 12 13 14 15 16	
51	H.S.	
52	1 2 3 4	
53	1 2 3 4	
54	H.S.	
55	1 2 3 4	
56	1 2 3 4	
57	H.S.	
58	1 2 3 4	
59	1 2 3 4	
60	H.S.	
61	1 2 3 4	
62	1 2 3 4	
63	H.S.	
64	1 2 3 4	
65	1 2 3 4	
66	H.S.	
67	1 2 3 4	
68	1 2 3 4	
69	H.S.	
70	1 2 3 4	
71	1 2 3 4	
72	H.S.	
73	1 2 3 4	
74	1 2 3 4	
75	H.S.	
76	1 2 3 4	
77	1 2 3 4	
78	H.S.	
79	1 2 3 4	
80	1 2 3 4	
81	H.S.	
82	1 2 3 4	
83	1 2 3 4	
84	H.S.	
85	1 2 3 4	
86	1 2 3 4	
87	H.S.	
88	1 2 3 4	
89	1 2 3 4	
90	H.S.	
91	1 2 3 4	
92	1 2 3 4	
93	H.S.	
94	1 2 3 4	
95	1 2 3 4	
96	H.S.	
97	1 2 3 4	
98	1 2 3 4	
99	H.S.	
100	1 2 3 4	
101	1 2 3 4	
102	H.S.	
103	1 2 3 4	
104	1 2 3 4	
105	H.S.	
106	1 2 3 4	
107	1 2 3 4	
108	H.S.	
109	1 2 3 4	
110	1 2 3 4	
111	H.S.	
112	1 2 3 4	
113	1 2 3 4	
114	H.S.	
115	1 2 3 4	
116	1 2 3 4	
117	H.S.	
118	1 2 3 4	
119	1 2 3 4	
120	H.S.	
121	1 2 3 4	
122	1 2 3 4	
123	H.S.	
124	1 2 3 4	
125	1 2 3 4	
126	H.S.	
127	1 2 3 4	
128	1 2 3 4	
129	H.S.	
130	1 2 3 4	
131	1 2 3 4	
132	H.S.	
133	1 2 3 4	
134	1 2 3 4	
135	H.S.	
136	1 2 3 4	
137	1 2 3 4	
138	H.S.	
139	1 2 3 4	
140	1 2 3 4	
141	H.S.	
142	1 2 3 4	
143	1 2 3 4	
144	H.S.	
145	1 2 3 4	
146	1 2 3 4	
147	H.S.	
148	1 2 3 4	
149	1 2 3 4	
150	H.S.	
151	1 2 3 4	
152	1 2 3 4	
153	H.S.	
154	1 2 3 4	
155	1 2 3 4	
156	H.S.	
157	1 2 3 4	
158	1 2 3 4	
159	H.S.	
160	1 2 3 4	
161	1 2 3 4	
162	H.S.	
163	1 2 3 4	
164	1 2 3 4	
165	H.S.	
166	1 2 3 4	
167	1 2 3 4	
168	H.S.	
169	1 2 3 4	
170	1 2 3 4	
171	H.S.	
172	1 2 3 4	
173	1 2 3 4	
174	H.S.	
175	1 2 3 4	
176	1 2 3 4	
177	H.S.	
178	1 2 3 4	
179	1 2 3 4	
180	H.S.	
181	1 2 3 4	
182	1 2 3 4	
183	H.S.	
184	1 2 3 4	
185	1 2 3 4	
186	H.S.	
187	1 2 3 4	
188	1 2 3 4	
189	H.S.	
190	1 2 3 4	
191	1 2 3 4	
192	H.S.	
193	1 2 3 4	
194	1 2 3 4	
195	H.S.	
196	1 2 3 4	
197	1 2 3 4	
198	H.S.	
199	1 2 3 4	
200	1 2 3 4	
201	H.S.	
202	1 2 3 4	
203	1 2 3 4	
204	H.S.	
205	1 2 3 4	
206	1 2 3 4	
207	H.S.	
208	1 2 3 4	
209	1 2 3 4	
210	H.S.	
211	1 2 3 4	
212	1 2 3 4	
213	H.S.	
214	1 2 3 4	
215	1 2 3 4	
216	H.S.	
217	1 2 3 4	
218	1 2 3 4	
219	H.S.	
220	1 2 3 4	
221	1 2 3 4	
222	H.S.	
223	1 2 3 4	
224	1 2 3 4	
225	H.S.	
226	1 2 3 4	
227	1 2 3 4	
228	H.S.	
229	1 2 3 4	
230	1 2 3 4	
231	H.S.	
232	1 2 3 4	
233	1 2 3 4	
234	H.S.	
235	1 2 3 4	
236	1 2 3 4	
237	H.S.	
238	1 2 3 4	
239	1 2 3 4	
240	H.S.	
241	1 2 3 4	
242	1 2 3 4	
243	H.S.	
244	1 2 3 4	
245	1 2 3 4	
246	H.S.	
247	1 2 3 4	
248	1 2 3 4	
249	H.S.	
250	1 2 3 4	
251	1 2 3 4	
252	H.S.	
253	1 2 3 4	
254	1 2 3 4	
255	H.S.	
256	1 2 3 4	
257	1 2 3 4	
258	H.S.	
259	1 2 3 4	
260	1 2 3 4	
261	H.S.	
262	1 2 3 4	
263	1 2 3 4	
264	H.S.	
265	1 2 3 4	
266	1 2 3 4	
267	H.S.	
268	1 2 3 4	
269	1 2 3 4	
270	H.S.	
271	1 2 3 4	
272	1 2 3 4	
273	H.S.	
274	1 2 3 4	
275	1 2 3 4	
276	H.S.	
277	1 2 3 4	
278	1 2 3 4	
279	H.S.	
280	1 2 3 4	
281	1 2 3 4	
282	H.S.	
283	1 2 3 4	
284	1 2 3 4	
285	H.S.	
286	1 2 3 4	
287	1 2 3 4	
288	H.S.	
289	1 2 3 4	
290	1 2 3 4	
291	H.S.	
292	1 2 3 4	
293	1 2 3 4	
294	H.S.	
295	1 2 3 4	
296	1 2 3 4	
297	H.S.	
298	1 2 3 4	
299	1 2 3 4	
300	H.S.	
301	1 2 3 4	
302	1 2 3 4	
303	H.S.	
304	1 2 3 4	
305	1 2 3 4	
306	H.S.	
307	1 2 3 4	
308	1 2 3 4	
309	H.S.	
310	1 2 3 4	
311	1 2 3 4	
312	H.S.	
313	1 2 3 4	
314	1 2 3 4	
315	H.S.	
316	1 2 3 4	
317	1 2 3 4	
318	H.S.	
319	1 2 3 4	
320	1 2 3 4	
321	H.S.	
322	1 2 3 4	
323	1 2 3 4	
324	H.S.	
325	1 2 3 4	
326	1 2 3 4	
327	H.S.	
328	1 2 3 4	
329	1 2 3 4	
330	H.S.	
331	1 2 3 4	
332	1 2 3 4	
333	H.S.	
334	1 2 3 4	
335	1 2 3 4	
336	H.S.	
337	1 2 3 4	
338	1 2 3 4	
339	H.S.	
340	1 2 3 4	
341	1 2 3 4	
342	H.S.	
343	1 2 3 4	
344	1 2 3 4	
345	H.S.	
346	1 2 3 4	
347	1 2 3 4	
348	H.S.	
349	1 2 3 4	
350	1 2 3 4	
351	H.S.	
352	1 2 3 4	
353	1 2 3 4	
354	H.S.	
355	1 2 3 4	
356	1 2 3 4	
357	H.S.	
358	1 2 3 4	
359	1 2 3 4	
360	H.S.	
361	1 2 3 4	
362	1 2 3 4	
363	H.S.	
364	1 2 3 4	
365	1 2 3 4	
366	H.S.	
367	1 2 3 4	
368	1 2 3 4	
369	H.S.	
370	1 2 3 4	
371	1 2 3 4	
372	H.S.	
373	1 2 3 4	
374	1 2 3 4	
375	H.S.	
376	1 2 3 4	
377	1 2 3 4	
378	H.S.	
379	1 2 3 4	
380	1 2 3 4	
381	H.S.	
382	1 2 3 4	
383	1 2 3 4	
384	H.S.	
385	1 2 3 4	
386	1 2 3 4	
387	H.S.	
388	1 2 3 4	
389	1 2 3 4	
390	H.S.	
391	1 2 3 4	
392	1 2 3 4	
393	H.S.	
394	1 2 3 4	
395	1 2 3 4	
396	H.S.	
397	1 2 3 4	
398	1 2 3 4	
399	H.S.	
400	1 2 3 4	
401	1 2 3 4	
402	H.S.	
403	1 2 3 4	
404	1 2 3 4	
405	H.S.	
406	1 2 3 4	
407	1 2 3 4	
408	H.S.	
409	1 2 3 4	
410	1 2 3 4	
411	H.S.	
412	1 2 3 4	
413	1 2 3 4	
414	H.S.	
415	1 2 3 4	
416	1 2 3 4	
417	H.S.	
418	1 2 3 4	
419	1 2 3 4	
420	H.S.	
421	1 2 3 4	
422	1 2 3 4	
423	H.S.	
424	1 2 3 4	
425	1 2 3 4	
426	H.S.	
427	1 2 3 4	
428	1 2 3 4	
429	H.S.	
430	1 2 3 4	
431	1 2 3 4	
432	H.S.	
433	1 2 3 4	
434	1 2 3 4	
435	H.S.	
436	1 2 3 4	
437	1 2 3 4	
438	H.S.	
439	1 2 3 4	
440	1 2 3 4	
441	H.S.	
442	1 2 3 4	
443	1 2 3 4	
444	H.S.	
445	1 2 3 4	
446	1 2 3 4	
447	H.S.	
448	1 2 3 4	
449	1 2 3 4	
450	H.S.	
451	1 2 3 4	
452	1 2 3 4	
453	H.S.	
454	1 2 3 4	
455	1 2 3 4	
456	H.S.	
457	1 2 3 4	
458	1 2 3 4	
459	H.S.	
460	1 2 3 4	
461	1 2 3 4	
462	H.S.	
463	1 2 3 4	
464	1 2 3 4	
465	H.S.	
466	1 2 3 4	
467	1 2 3 4	
468	H.S.	
469	1 2 3 4	
470	1 2 3 4	
471	H.S.	
472	1 2 3 4	
473	1 2 3 4	


POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	M47
Connector Name	AUDIO UNIT
Connector Type	TH22FW-NH



Terminal Color Of No.	Signal Name [Specification]
11	SB
12	L
13	G
60	LA/R
61	P
62	V
63	LA/R
64	Y
65	GR
66	BG
67	BR
68	R
71	V
72	L
73	Y
76	L
77	V
78	LG
79	SHIELD
80	L
82	LA/L
83	GR
84	SB
85	G
86	G
87	B
88	B
91	L
92	W
93	W
96	LG
97	BR
98	V
99	R



Terminal Color Of No.	Signal Name [Specification]
60	-
61	-
62	-
63	-
64	-
65	-
66	-
67	-
68	-
71	-
72	-
73	-
76	-
77	-
78	-
79	-
80	-
82	-
83	-
84	-
85	-
86	-
87	-
88	-
91	-
92	-
93	-
96	-
97	-
98	-
99	-

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Connector No.	M83
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH



Terminal Color Of No.	Signal Name [Specification]
1	3
2	4
3	5
4	6
5	7
6	8
7	9
8	10
9	11
10	12
11	13
12	14

Terminal Color Of No.	Signal Name [Specification]
1	3
2	4
3	5
4	6
5	7
6	8
7	9
8	10
9	11
10	12
11	13
12	14

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Connector No.	M81
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH




Terminal Color Of No.	Signal Name [Specification]
1	3
2	4
3	5
4	6
5	7
6	8
7	9
8	10
9	11
10	12
11	13
12	14

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Connector No.	M81
---------------	-----



Terminal Color Of No.	Signal Name [Specification]
1	3
2	4
3	5
4	6
5	7
6	8
7	9
8	10
9	11
10	12
11	13
12	14

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]
1	B
3	GR
4	Y
5	V
6	SB
7	B
8	L
9	Y
10	SHIELD

Terminal Color Of No.	Signal Name [Specification]

<tbl_r cells="2" ix="1" maxcspan="1" maxrspan="1" used

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

Terminal No.	Color Of Wire	Signal Name (Specification)	Terminal No.	Color Of Wire	Signal Name (Specification)
17 LAP	-		110	BG	DIMMER SIGNAL
18 L/A/SB	-		111	R	DOOR LK STAT IND OUTPUT
19 B	-		112	SB	STOP/START OFF SW INPUT
20 LG	-	BATT POWER SUPPLY (FUSE)	113	LG	COMBI SW INPUT 1
21 BR	-	INT ROOM LAMP CONTROL	114	Y	COMBI SW INPUT 2
22 L/AG	-	INT ROOM LAMP CONTROL	115	W	DOOR UNLOCK SW
					NATS ANTENNA AMP ¹
					NATS ANTENNA AMP ²
143 LAV	LG	FRONT DOOR UNLOCK OUTPUT	116	BG	ROOM ANT 1 -
144 BG	POWER SUPPLY (FR DOOR LK ACT)	117	GR	ROOM ANT 1 +	
145 GR	POWER SUPPLY (TURN SIGNAL)	118	SB	PASSENGER DOOR ANT -	
146 B	GROUND	119	P	PASSENGER DOOR ANT +	
147 B	GROUND	120	BR	RIVER DOOR ANT +	
148 G	DRIVER DOOR UNLOCK OUTPUT				
149 W	FRONT DOOR SUPERLOCK OUTPUT				
151 R	POWER SUPPLY (REAR DOOR LK ACT)				
152 LG	POWER SUPPLY (REAR WIPER)				
Connector No. M86			Connector No. M87		
Connector Name BCM (BODY CONTROL MODULE)			Connector Name BCM (BODY CONTROL MODULE)		
Connector Type 1H0f-B-NH			Connector Type 1H0f-G-NH		
Terminal No.	Color Of Wire	Signal Name (Specification)	Terminal No.	Color Of Wire	Signal Name (Specification)
1 L	-		3 W	-	
2 Y	-		4 BR	-	
3 W	-		7 G	-	
4 B	-		8 GR	-	- (RHD models)
5 B	-		9 G	-	- (RHD models)
6 Y	-		10 Y	-	- (RHD models)
7 R	-		11 UW	-	- (RHD models)
9 BR	-		12 O	-	
10 GR	-		13 LG	-	
11 SB	-				
Connector No. M85			Connector No. M86		
Connector Name BCM (BODY CONTROL MODULE)			Connector Name BCM (BODY CONTROL MODULE)		
Connector Type NS16fBPC-CS			Connector Type 1H0f-B-NH		
Terminal No.	Color Of Wire	Signal Name (Specification)	Terminal No.	Color Of Wire	Signal Name (Specification)
81 L	-	KEY SWITCH	41 V	-	STEERING LOCK INIT POWER SUPPLY
82 L/AR	KEY SW (ST) (Without intelligent key)	42 LA/G	43 LA/Y	-	TURN SIG LH (SIDE)
84 BR	COMBI SW OUTPUT 2	44 P	44 P	-	INTERIOR ROOM LAMP RELAY CONT
85 SB	COMBI SW OUTPUT 1	45 R	45 R	CANL	CANH
86 P	COMBI SW OUTPUT 3	46 L	46 L	CANL	CANH
87 BG	COMBI SW OUTPUT 4	47 G	47 G	LIGHT & RAIN SENSOR	CANH
88 W	PUSH/BINIGN SW/TLL CONT	48 L	49 R	POWER WINDOW RELAY CONT	CANL
90 Y	SIL CONDITION	50 BG	50 BG	DOOR LOCK SW	CANL
94 G	DETENTION SW	51 Y	51 Y	HAZARD SW	CANL
95 V	EXTENDED STORAGE FUSE SW	52 P	52 P	BLOWER RELAY CONT	CANL
99 R	STOP/START OFF SW	53 Y	53 Y	IGN RELAY (FB) CONT/OUTPUT	CANL
100 V	DRIVER DOOR ANT +	54 LA/W	54 LA/W	IGN RELAY (FB) CONT/OUTPUT	CANL
101 Y	PUSH SW	55 LG	55 LG	IGN RELAY (FB) CONT/OUTPUT	CANL
104 R	DR DOOR UNLK SENS	56 P	56 P	IGN RELAY (FB) CONT/OUTPUT	CANL
105 Y	DR DOOR REQ SW	57 L	57 L	IGN RELAY (FB) CONT/OUTPUT	CANL
106 W	ACC OUTPUT	58 R	58 R	IGN RELAY (FB) CONT/OUTPUT	CANL
107 V	SENSOR CANCEL SW	59 G	59 G	IGN RELAY (FB) CONT/OUTPUT	CANL
109 P	NATS ANTENNA AMP.	60 R	60 R	IGN RELAY (FB) CONT/OUTPUT	CANL
		61 G	61 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		62 G	62 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		63 G	63 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		64 LA/R	64 LA/R	IGN RELAY (FB) CONT/OUTPUT	CANL
		65 BR	65 BR	IGN RELAY (FB) CONT/OUTPUT	CANL
		66 Y	66 Y	IGN RELAY (FB) CONT/OUTPUT	CANL
		67 Y	67 Y	IGN RELAY (FB) CONT/OUTPUT	CANL
		68 LA/W	68 LA/W	IGN RELAY (FB) CONT/OUTPUT	CANL
		69 LG	69 LG	IGN RELAY (FB) CONT/OUTPUT	CANL
		70 Y	70 Y	IGN RELAY (FB) CONT/OUTPUT	CANL
		71 G	71 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		72 G	72 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		73 LG	73 LG	IGN RELAY (FB) CONT/OUTPUT	CANL
		74 Y	74 Y	IGN RELAY (FB) CONT/OUTPUT	CANL
		75 BG	75 BG	IGN RELAY (FB) CONT/OUTPUT	CANL
		76 G	76 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		77 G	77 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		78 V	78 V	IGN RELAY (FB) CONT/OUTPUT	CANL
		79 W	79 W	IGN RELAY (FB) CONT/OUTPUT	CANL
		80 SB	80 SB	IGN RELAY (FB) CONT/OUTPUT	CANL
		81 Y	81 Y	IGN RELAY (FB) CONT/OUTPUT	CANL
		82 G	82 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		83 G	83 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		84 G	84 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		85 G	85 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		86 G	86 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		87 G	87 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		88 G	88 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		89 G	89 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		90 G	90 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		91 G	91 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		92 G	92 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		93 G	93 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		94 G	94 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		95 G	95 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		96 G	96 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		97 G	97 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		98 G	98 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		99 G	99 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		100 G	100 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		101 G	101 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		102 G	102 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		103 G	103 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		104 G	104 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		105 G	105 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		106 G	106 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		107 G	107 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		108 G	108 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		109 G	109 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		110 G	110 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		111 G	111 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		112 G	112 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		113 G	113 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		114 G	114 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		115 G	115 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		116 G	116 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		117 G	117 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		118 G	118 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		119 G	119 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		120 G	120 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		121 G	121 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		122 G	122 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		123 G	123 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		124 G	124 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		125 G	125 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		126 G	126 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		127 G	127 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		128 G	128 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		129 G	129 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		130 G	130 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		131 G	131 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		132 G	132 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		133 G	133 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		134 G	134 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		135 G	135 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		136 G	136 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		137 G	137 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		138 G	138 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		139 G	139 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		140 G	140 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		141 G	141 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		142 G	142 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		143 G	143 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		144 G	144 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		145 G	145 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		146 G	146 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		147 G	147 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		148 G	148 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		149 G	149 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		150 G	150 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		151 G	151 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		152 G	152 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		153 G	153 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		154 G	154 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		155 G	155 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		156 G	156 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		157 G	157 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		158 G	158 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		159 G	159 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		160 G	160 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		161 G	161 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		162 G	162 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		163 G	163 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		164 G	164 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		165 G	165 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		166 G	166 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		167 G	167 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		168 G	168 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		169 G	169 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		170 G	170 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		171 G	171 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		172 G	172 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		173 G	173 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		174 G	174 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		175 G	175 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		176 G	176 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		177 G	177 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		178 G	178 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		179 G	179 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		180 G	180 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		181 G	181 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		182 G	182 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		183 G	183 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		184 G	184 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		185 G	185 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		186 G	186 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		187 G	187 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		188 G	188 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		189 G	189 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		190 G	190 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		191 G	191 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		192 G	192 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		193 G	193 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		194 G	194 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		195 G	195 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		196 G	196 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		197 G	197 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		198 G	198 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		199 G	199 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		200 G	200 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		201 G	201 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		202 G	202 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		203 G	203 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		204 G	204 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		205 G	205 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		206 G	206 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		207 G	207 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		208 G	208 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		209 G	209 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		210 G	210 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		211 G	211 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		212 G	212 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		213 G	213 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		214 G	214 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		215 G	215 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		216 G	216 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		217 G	217 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		218 G	218 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		219 G	219 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		220 G	220 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		221 G	221 G	IGN RELAY (FB) CONT/OUTPUT	CANL
		222 G	222 G	IGN RELAY (FB) CONT/OUTPUT</	


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000010741742

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

1. GET INFORMATION ABOUT SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).

>> GO TO 2.

2. CHECK DTC

1. Check DTC for BCM and IPDM E/R.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data (Print them out with CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3.

Symptom is described, DTC is not displayed>>GO TO 4.

Symptom is not described, DTC is displayed>>GO TO 5.

3. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT to the vehicle in the "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT to the vehicle in the "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

At this time, always connect CONSULT to the vehicle, and check diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-77, "DTC Inspection Priority Chart"](#), and determine trouble diagnosis order.

NOTE:

Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative, although DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

YES >> GO TO 7.

NO >> Refer to [GI-44, "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 7.

7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

NOTE:

The Diagnostic Procedure described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

DIAGNOSIS AND REPAIR WORK FLOW

[POWER DISTRIBUTION SYSTEM]

< BASIC INSPECTION >

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check voltage of related BCM terminals using CONSULT.

A

8.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

B

C

>> GO TO 9.

D

9.FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction is repaired securely.

E

When symptom was described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

F

Does the symptom reappear?

G

YES (DTC is detected)>>GO TO 7.

H

YES (Symptom remains)>>GO TO 6.

I

NO >> INSPECTION END

J

K

L

PCS

M

N

O

P

PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM

Description

INFOID:0000000010741743

The ignition battery saver system can be temporarily disabled, without using CONSULT, to prevent it from functioning when performing trouble diagnosis.

Work Procedure

INFOID:0000000010741744

1. Enter the vehicle carrying a registered Intelligent Key.
2. Place the ignition switch in the ACC position by operating the push-button ignition switch without depressing the brake pedal.
3. Press and hold the push button ignition switch continuously for ten seconds.
4. Check that the buzzer in the combination meter sounds for two seconds.
5. Operation is completed.

NOTE:

When the ignition switch is placed in any position other than ON, the ignition battery saver system is activated again.

DTC/CIRCUIT DIAGNOSIS

B261A PUSH-BUTTON IGNITION SWITCH

DTC Description

INFOID:000000010741745

DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B261A-00	PUSH-BTN IGN SW (Push-button ignition switch)	<p>The following signal status that BCM receives are compared, and it do not match for 1 second or more.</p> <ul style="list-style-type: none"> • Push-button Ignition switch (push switch) signal • Push-button Ignition switch (push switch) status signal (CAN)

POSSIBLE CAUSE

- Harness or connectors
[Push-button ignition switch (push switch) circuit is open or shorted.]
- BCM
- IPDM E/R

FAIL-SAFE

DTC CONFIRMATION PROCEDURE

1. CHECK DTC PRIORITY

If DTC B261A is displayed with DTC 1000 or 1010, first perform the trouble diagnosis for DTC U1000 or U1010.

Is DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-110, "DTC Description"](#). U1010: Refer to [BCS-111, "DTC Description"](#).

NO >> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch (push switch) under the following conditions, and wait for 1 second or more.
 - Shift position is in the P position
 - Do not depress brake pedal
2. Check "Self-diagnosis result" of BCM with CONSULT.

Is DTC detected?

YES >> Refer to [PCS-101, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010741746

1. CHECK PUSH-BUTTON IGNITION SWITCH (PUSH SWITCH) OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector and IPDM E/R connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+) Push-button Ignition switch		(-)	Voltage
Connector	Terminal		
M16	8	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 3.

B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

NO >> GO TO 2.

2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and push-button ignition switch harness connector.

BCM		Push-button Ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M86	101	M16	8	Existed

3. Check continuity between push-button ignition switch harness connector and ground.

Push-button Ignition switch		Ground	Continuity
Connector	Terminal		
M16	8		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK PUSH-BUTTON IGNITION SWITCH (PUSH SWITCH) OUTPUT SIGNAL (IPDM E/R)

1. Disconnect BCM connector.
2. Connect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and ground.

(+) IPDM E/R		(-)	Voltage
Connector	Terminal		
E12	38	Ground	6 – 16 V

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).

NO >> GO TO 4.

4. CHECK PUSH-BUTTON IGNITION SWITCH (PUSH SWITCH) CIRCUIT (IPDM E/R)

1. Check continuity between IPDM E/R harness connector and push-button ignition switch harness connector.

IPDM E/R		Push-button Ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E12	38	M16	8	Existed

2. Check continuity between push-button ignition switch harness connector and ground.

Push-button Ignition switch		Ground	Continuity
Connector	Terminal		
M16	8		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> INSPECTION END

< DTC/CIRCUIT DIAGNOSIS >

B26F1 IGNITION RELAY**DTC Description**

INFOID:0000000010741747

DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B26F1-00	IGN RELAY OFF (Ignition relay off)	BCM transmits the ignition relay control signal (ON) or ignition switch ON signal (ON) (CAN), but does not receives ignition switch ON signal (ON) (CAN) from IPDM E/R.

POSSIBLE CAUSE

- Harness or connectors
(Ignition relay circuit is open)
- BCM
- IPDM E/R

FAIL-SAFE

Inhibit engine cranking

DTC CONFIRMATION PROCEDURE**1. PERFORM DTC CONFIRMATION PROCEDURE**

1. Turn ignition switch ON, and wait for 2 seconds or more.
2. Check "Self-diagnosis result" with CONSULT.

Is DTC detected?YES >> Refer to [PCS-103, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:0000000010741748

1. CHECK IPDM E/R SELF-DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Erase the DTC of IPDM E/R.
3. Turn ignition switch OFF.
4. Turn ignition switch ON and check the DTC again.

Is DTC detected?YES >> Repair or replace the malfunctioning part. Refer to [PCS-38, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK IGNITION RELAY CONTROL SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition	Voltage
Connector	Terminal			
M87	67	Ground	Ignition switch ON	0 – 0.5 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK IGNITION RELAY CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check continuity between BCM harness connector and fuse block (J/B) harness connector.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

B26F1 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

BCM		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M87	67	M3	3C	Existed

4. Check continuity between BCM harness connector and ground.

BCM		—	Continuity
Connector	Terminal		
M87	67	Ground	Not existed

Is the inspection result normal?

YES >> Replace ignition relay.
NO >> Repair or replace harness.

4. CHECK IGNITION RELAY

Check ignition relay. Refer to [PCS-104, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.
NO >> Replace ignition relay.

5. REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
2. Turn ignition switch ON and check the DTC again.

Is DTC "B26F1-00" displayed?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).
NO >> INSPECTION END.

Component Inspection

INFOID:0000000010741749


1. CHECK IGNITION RELAY

1. Turn ignition switch OFF.
2. Remove ignition relay.
3. Check continuity between ignition relay terminals.

Terminal	Condition		Continuity
Ignition relay			
③	⑤	12 V direct current supply between terminals ① and ②.	Existed
		No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END.
NO >> Replace ignition relay.



SEF497Y

B26F2 IGNITION RELAY

DTC Description

INFOID:0000000010741750

DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B26F2-00	IGN RELAY ON (Ignition relay on)	BCM transmits the ignition relay control signal (OFF) or ignition switch ON signal (OFF) (CAN), but does not receives ignition switch ON signal (OFF) (CAN) from IPDM E/R.

POSSIBLE CAUSE

- Harness or connectors
(Ignition relay circuit is short)
- BCM
- IPDM E/R

FAIL-SAFE

Inhibit engine cranking

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON, and wait for 2 seconds or more.
2. Check "Self-diagnosis result" with CONSULT.

Is DTC detected?

YES >> Refer to [PCS-105, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:0000000010741751

1. CHECK IPDM E/R SELF-DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Erase the DTC of IPDM E/R.
3. Turn ignition switch OFF.
4. Turn ignition switch ON and check the DTC again.

Is DTC detected?

YES >> Repair or replace the malfunctioning part. Refer to [PCS-38, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK IGNITION RELAY CONTROL SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition		Voltage
Connector	Terminal				
M87	67	Ground	Ignition switch	ON	0 – 0.5 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK IGNITION RELAY CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and fuse block (J/B) connectors.
3. Check continuity between BCM harness connector and fuse block (J/B) harness connector.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

BCM		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M87	67	M3	3C	Existed

4. Check continuity between BCM harness connector and ground.

BCM		—	Continuity
Connector	Terminal		
M87	67	Ground	Not existed

Is the inspection result normal?

YES >> Replace ignition relay.
NO >> Repair or replace harness.

4. CHECK IGNITION RELAY

Check ignition relay. Refer to [PCS-104, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.
NO >> Replace ignition relay.

5. REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
2. Turn ignition switch ON and check the DTC again.

Is DTC "B26F2-00" displayed?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).
NO >> INSPECTION END.

Component Inspection

INFOID:0000000010741752


1. CHECK IGNITION RELAY

1. Turn ignition switch OFF.
2. Remove ignition relay.
3. Check continuity between ignition relay terminals.

Terminal	Condition		Continuity
Ignition relay			
③	⑤	12 V direct current supply between terminals ① and ②.	Existed
		No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END.
NO >> Replace ignition relay.



ACCESSORY RELAY

Diagnosis Procedure

INFOID:0000000010741753

1. CHECK ACCESSORY RELAY POWER SUPPLY

1. Turn ignition switch OFF.
2. Remove accessory relay.
3. Check voltage between accessory relay connector and ground.

(+)	(-)	Voltage
Fuse block (J/B)		
Accessory relay (Upstream side of relay excitation coil circuit)	Ground	Battery voltage

Is the inspection normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK ACCESSORY RELAY POWER SUPPLY CIRCUIT 1

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and accessory relay connector.

Fuse block (J/B)	BCM		Continuity
	Connector	Terminal	
Accessory relay (Downstream side of relay excitation coil circuit)	M87	65	Existed

3. Check continuity between accessory relay connector and ground.

Fuse block (J/B)	-	Continuity
Accessory relay (Downstream side of relay excitation coil circuit)	Ground	Not existed

Is the inspection normal?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK ACCESSORY RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between accessory relay connector and ground.

(+)	-	Continuity
Fuse block (J/B)		
Accessory relay (Downstream side of relay excitation coil circuit)	Ground	Existed

Is the inspection normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK ACCESSORY RELAY POWER SUPPLY CIRCUIT 2

Check voltage between accessory relay connector and ground.

PCS

(+)	-	Voltage
Fuse block (J/B)		
Accessory relay (Upstream side of relay contact circuit)	Ground	Battery voltage

Is the inspection normal?

YES >> GO TO 5.

ACCESSORY RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

NO >> Repair or replace harness.

5. CHECK ACCESSORY RELAY

Check accessory relay. Refer to [PCS-108, "Component Inspection"](#).

Is the inspection normal?

YES >> INSPECTION END.

NO >> Replace accessory relay.

Component Inspection

INFOID:0000000010741754

1. CHECK ACCESSORY RELAY


1. Turn ignition switch OFF.
2. Remove accessory relay.
3. Check continuity between accessory relay terminals.

Terminal		Condition	Continuity
Accessory relay			
(3)	(5)	12 V direct current supply between terminals (1) and (2).	Existed
		No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace accessory relay.



POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000010741755

1. CHECK FUNCTION

1. Turn ignition switch OFF.
2. Disconnect audio unit or NAVI control unit connector.
3. Turn ignition switch ON.
4. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
5. Select "AUTO ACC 2" in "ACTIVE TEST" mode.
6. Check continuity between audio unit or NAVI control unit harness connector and ground.

Without NAVI models

(+) Connector		(-)	Voltage (Approx.)
Audio unit	Terminal		
Connector	Terminal	Ground	3.15 V

With NAVI models

(+) Connector		(-)	Voltage (Approx.)
NAVI control unit	Terminal		
Connector	Terminal	Ground	3.15 V

Is the inspection normal?

YES >> Refer to [GI-44, "Intermittent Incident"](#).
NO >> GO TO 2.

2. CHECK BCM OUTPUT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and audio unit or NAVI control unit connector.

Without NAVI models

BCM		Audio unit		Continuity
Connector	Terminal	Connector	Terminal	
M86	106	M47	45	Existed

With NAVI models

BCM		NAVI control unit		Continuity
Connector	Terminal	Connector	Terminal	
M86	106	M27	7	Existed

4. Check continuity between BCM harness connector and ground.

BCM		—	Continuity
Connector	Terminal		
M86	106	Ground	Not existed

Is the inspection normal?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).
NO >> Repair or replace harness.

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

PUSH-BUTTON IGNITION SWITCH

Component Function Check

INFOID:0000000010741756

1. CHECK FUNCTION

1. Select "INTELLIGENT KEY" in "BCM" using CONSULT.
2. Select "PUSH SW" in "Data Monitor" mode with CONSULT.
3. Check that the function operates normally according to the following conditions.

Test item	Condition	Status
PUSH SW	Push-button ignition switch is pressed	ON
	Push-button ignition switch is not pressed	OFF

Is the indication normal?

YES >> INSPECTION END.
NO >> Refer to [PCS-110, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010741757

1. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector and IPDM E/R connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+) Push-button ignition switch		(-)	Voltage
Connector	Terminal		
M16	8	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT 1

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M86	101	M16	8	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M86	101		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-121, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL 2

1. Disconnect BCM connector.
2. Connect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and ground.

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

(+)	IPDM E/R	(-)	Voltage
IPDM E/R			
Connector	Terminal		
E12	38	Ground	6 – 16 V

Is the inspection result normal?

YES >> GO TO 5.
NO >> GO TO 4.

4. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT 2

1. Check continuity between IPDM E/R harness connector and push-button ignition switch harness connector.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E12	38	M16	8	Existed

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E12	38		Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-60, "Removal and Installation"](#).
NO >> Repair or replace harness.

5. CHECK PUSH-BUTTON IGNITION SWITCH GROUND CIRCUIT

Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M16	4		Existed

Is the inspection result normal?

YES >> GO TO 6.
NO >> Repair or replace harness.

6. CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [PCS-111, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.
NO >> Replace push-button ignition switch. Refer to [PCS-116, "Removal and Installation"](#).

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000010741758

1. CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Push-button ignition switch		Condition	Continuity
Terminal			
4	8	Pressed	Existed
		Not pressed	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace push-button ignition switch. Refer to [PCS-116, "Removal and Installation".](#)

SYMPTOM DIAGNOSIS

PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010741759

1. PERFORM WORK SUPPORT

Perform "INSIDE ANT DIAGNOSIS" on Work Support of "INTELLIGENT KEY".

Refer to [DLK-75, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\) \(With Super Lock\)".](#)

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS RESULT

Perform Self-Diagnosis Result of "BCM".

Is DTC detected?

YES >> Refer to [BCS-78, "DTC Index".](#)

NO >> GO TO 3.

3. CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [PCS-110, "Component Function Check".](#)

Is the operation normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

4. REPLACE BCM

Replace BCM. Refer to [BCS-121, "Removal and Installation"](#)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident".](#)

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

ACCESSORY POWER SUPPLY IS NOT SUPPLIED EVEN IF DOOR IS UN-LOCKED BY KEY

< SYMPTOM DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

ACCESSORY POWER SUPPLY IS NOT SUPPLIED EVEN IF DOOR IS UN-LOCKED BY KEY

ALL SWITCHES AND UNITS

ALL SWITCHES AND UNITS : Diagnosis Procedure

INFOID:0000000010741760

1. CHECK ACCESSORY RELAY

Check accessory relay

Refer to [PCS-107, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK AUTO ACC 2 POWER SUPPLY

Check auto ACC 2 power supply.

Refer to [PCS-109, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

Replace BCM. Refer to [BCS-121, "Removal and Installation"](#)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

EXCEPT AUDIO/NAVIGATION

EXCEPT AUDIO/NAVIGATION : Diagnosis Procedure

INFOID:0000000010741761

1. CHECK ACCESSORY RELAY

Check accessory relay

Refer to [PCS-107, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE BCM

Replace BCM. Refer to [BCS-121, "Removal and Installation"](#)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

AUDIO/NAVIGATION ONLY

AUDIO/NAVIGATION ONLY : Diagnosis Procedure

INFOID:0000000010741762

1. CHECK AUTO ACC 2 POWER SUPPLY

Check auto ACC 2 power supply.

Refer to [PCS-109, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE BCM

Replace BCM. Refer to [BCS-121, "Removal and Installation"](#)

ACCESSORY POWER SUPPLY IS NOT SUPPLIED EVEN IF DOOR IS UN-LOCKED BY KEY

< SYMPTOM DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

REMOVAL AND INSTALLATION

PUSH-BUTTON IGNITION SWITCH


Removal and Installation

INFOID:0000000010741763

REMOVAL

1. Remove instrument finisher E. Refer to [IP-41, "Removal and Installation"](#).
2. Disconnect push-button ignition switch connector and NATS antenna amp. connector.
3. Disengage NATS antenna amp. fixing pawls and then remove NATS antenna amp. and push-button ignition switch ① as a set from instrument finisher E.


△ : Pawl



JMMIA1607JP

4. Disengage push-button ignition switch fixing pawl and then remove push-button ignition switch ① from NATS antenna amp. ②.

△ : Pawl



JMMIA1435ZZ

INSTALLATION

Install in the reverse order of removal.