

# SECTION RAX

## REAR AXLE

A  
B  
C

RAX

E

F

G

H

I

J

K

L

M

N

O

P

## CONTENTS

## 2WD

<b>PRECAUTION</b> .....	2
<b>PRECAUTIONS</b> .....	2
Precautions for Removing Battery Terminal .....	2
<b>PREPARATION</b> .....	4
<b>PREPARATION</b> .....	4
Commercial Service Tools .....	4
<b>SYMPTOM DIAGNOSIS</b> .....	5
<b>NOISE, VIBRATION AND HARSHNESS</b>	
<b>(NVH) TROUBLESHOOTING</b> .....	5
NVH Troubleshooting Chart .....	5
<b>PERIODIC MAINTENANCE</b> .....	6
<b>REAR WHEEL HUB AND HOUSING</b> .....	6
Inspection .....	6
<b>REMOVAL AND INSTALLATION</b> .....	7
<b>REAR WHEEL HUB</b> .....	7
Exploded View .....	7
Removal and Installation .....	7
Inspection .....	9
<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>(SDS)</b> .....	10
<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>(SDS)</b> .....	10
Wheel Bearing .....	10

## 4WD

<b>PRECAUTION</b> .....	11
<b>PRECAUTIONS</b> .....	11
Precautions for Removing Battery Terminal .....	11
Precautions for Drive Shaft .....	12

<b>PREPARATION</b> .....	13
<b>PREPARATION</b> .....	13
Special Service Tool .....	13
Commercial Service Tool .....	14
Lubricant or/and Sealant .....	14
<b>SYMPTOM DIAGNOSIS</b> .....	15
<b>NOISE, VIBRATION AND HARSHNESS</b>	
<b>(NVH) TROUBLESHOOTING</b> .....	15
NVH Troubleshooting Chart .....	15
<b>PERIODIC MAINTENANCE</b> .....	16
<b>REAR WHEEL HUB AND HOUSING</b> .....	16
Inspection .....	16
<b>REAR DRIVE SHAFT</b> .....	17
Inspection .....	17
<b>REMOVAL AND INSTALLATION</b> .....	18
<b>REAR WHEEL HUB AND HOUSING</b> .....	18
Exploded View .....	18
Removal and Installation .....	18
Inspection .....	21
<b>REAR DRIVE SHAFT</b> .....	22
Exploded View .....	22
Removal and Installation .....	22
Disassembly and Assembly .....	24
Inspection .....	30
<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>(SDS)</b> .....	31
<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>(SDS)</b> .....	31
Wheel Bearing .....	31
Drive Shaft .....	31

&lt; PRECAUTION &gt;

## PRECAUTION

### PRECAUTIONS

#### Precautions for Removing Battery Terminal

INFOID:0000000010921176

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

**NOTE:**

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


**NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

**NOTE:**

The removal of 12V battery may cause a DTC detection error.



SEF289H

#### HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

#### INSTRUCTION 1

- Open the hood.
- Turn key switch to the OFF position with the driver side door opened.
- Get out of the vehicle and close the driver side door.
- Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

**CAUTION:**

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

- Remove 12V battery terminal.

**CAUTION:**

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

#### INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

- Unlock the door with intelligent key or remote keyless entry.

**NOTE:**

At this moment, ACC power is supplied.

- Open the driver side door.
- Open the hood.
- Close the driver side door.
- Wait at least 3 minutes.

## PRECAUTIONS

[2WD]

< PRECAUTION >

**CAUTION:**

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

**CAUTION:**

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

A

B

C

RAX

E

F

G

H

I

J

K

L

M

N


O

P

&lt;PREPARATION&gt;

**PREPARATION****PREPARATION****Commercial Service Tools**

INFOID:0000000010828152

Tool name	Description
Ball joint remover	 PAT.P NT146 A technical line drawing of a ball joint remover tool. It features a central threaded bolt with a lock washer. A U-shaped jaws are attached to the top and bottom of the bolt, designed to grip a ball joint. The tool is mounted on a base plate with a central slot for the bolt. The label 'PAT.P' is printed on the base plate, and the part number 'NT146' is printed below it.

## SYMPTOM DIAGNOSIS

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

## NVH Troubleshooting Chart

INFOID:0000000010828153

Use chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Reference									
Possible cause and SUSPECTED PARTS									
Symptom	REAR AXLE	Noise	×	×	×	×	×	×	×
		Shake	×	×	×	×	×	×	×
		Vibration	×	×	×	×	×		
		Shimmy	×	×		×	×	×	×
		Judder	×			×	×	×	×
		Poor quality ride or handling	×	×		×	×	×	

x: Applicable

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

&lt; PERIODIC MAINTENANCE &gt;

## PERIODIC MAINTENANCE

### REAR WHEEL HUB AND HOUSING

#### Inspection

INFOID:0000000010828154

##### COMPONENT PART

Make sure that the mounting conditions (looseness, backlash) of each component and component conditions (wear, damage) are normal.

##### WHEEL HUB ASSEMBLY (BEARING-INTEGRATED TYPE)

Check the following items, and replace the part if necessary.

- Move wheel hub and bearing assembly in the axial direction by hand. Check there is no looseness of wheel bearing.


**Axial end play** : Refer to [RAX-10, "Wheel Bearing"](#).

- Rotate wheel hub and make sure there is no unusual noise or other irregular conditions. If there is any of irregular conditions, replace wheel hub and bearing assembly.

&lt; REMOVAL AND INSTALLATION &gt;

**REMOVAL AND INSTALLATION****REAR WHEEL HUB****Exploded View**

INFOID:0000000010828155



① Suspension arm

② Back plate

③ Hub bolt

④ Wheel hub and bearing assembly

⑤ Disc rotor

⑥ Plug

N·m (kg-m, ft-lb)

X: Always replace after every disassembly.

**Removal and Installation**

INFOID:0000000010828156

**REMOVAL****Wheel Hub and Bearing Assembly**

1. Remove tires. Refer to [WT-61, "Removal and Installation"](#).
2. Remove wheel sensor from wheel hub and bearing assembly. Refer to [BR-213, "REAR WHEEL SENSOR : Exploded View"](#).
3. Remove caliper assembly. Hang caliper assembly in a place where it will not interfere with work.
  - LHD: Refer to [BR-63, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).
  - RHD: Refer to [BR-123, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).

**CAUTION:****Never depress brake pedal while brake caliper is removed.**

4. Remove disc rotor. If disc rotor cannot be removed, remove as follows.

**CAUTION:**

- **Parking brake completely in the released position.**


## REAR WHEEL HUB

[2WD]

### < REMOVAL AND INSTALLATION >


- Put matching marks Ⓐ on the wheel hub and bearing assembly and the disc rotor before removing the disc rotor.
- Never drop disc rotor.

a. Fix the disc rotor with wheel nuts and remove the adjusting hole plug.



b. Using suitable tool, rotate adjuster ① in the direction Ⓐ to retract and loosen brake shoe.

c. Remove disc rotor.



5. Remove wheel hub and bearing assembly.

**CAUTION:**


Remove parking brake assembly only when necessary.

6. Remove back plate.

7. Remove hub bolts ① from wheel hub and bearing assembly, using the ball joint remover (A) (commercial service tool).

**CAUTION:**

- Remove hub bolt only when necessary.
- Never hammer the hub bolt to avoid impact to the wheel hub and bearing assembly.
- Pull out the hub bolt in a direction perpendicular to the wheel hub and bearing assembly.



8. Perform inspection after removal. Refer to [RAX-9, "Inspection"](#).

### INSTALLATION


Note the following, and install in the reverse order of removal.

#### Hub Bolts

- Place a washer Ⓐ as shown in the figure to install the hub bolts ① by using the tightening force of the nut Ⓑ.

**CAUTION:**

- Check that there is no clearance between wheel hub and bearing assembly, and hub bolt.
- Never reuse hub bolt.




#### Disc rotor

## &lt; REMOVAL AND INSTALLATION &gt;

**CAUTION:**

- Align the matching marks **A** made during removal when reusing the disc rotor.
- Never drop disc rotor.

A  
B  
C  
RAX

- Perform inspection after installation. Refer to [RAX-9, "Inspection"](#).

### Inspection

INFOID:0000000010828157

E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

#### INSPECTION AFTER REMOVAL

Check wheel hub and bearing assembly for wear, cracks, and damage. Replace if there are.

#### INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-213, "REAR WHEEL SENSOR : Exploded View"](#).
2. Check wheel alignment. Refer to [RSU-7, "Inspection"](#).
3. Adjust neutral position of steering angle sensor. Refer to [BRC-99, "Work Procedure"](#).

## SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

[2WD]

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

Wheel Bearing

INFOID:000000010828158

Axial end play	0.05 mm (0.002 in) or less
----------------	----------------------------

&lt; PRECAUTION &gt;

# PRECAUTION

## PRECAUTIONS

### Precautions for Removing Battery Terminal

INFOID:0000000010921258

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

**NOTE:**

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

**NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

**NOTE:**

The removal of 12V battery may cause a DTC detection error.

#### HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

##### INSTRUCTION 1

- Open the hood.
- Turn key switch to the OFF position with the driver side door opened.
- Get out of the vehicle and close the driver side door.
- Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

**CAUTION:**

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

- Remove 12V battery terminal.

**CAUTION:**

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.


##### INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

- Unlock the door with intelligent key or remote keyless entry.

**NOTE:**

At this moment, ACC power is supplied.

- Open the driver side door.
- Open the hood.
- Close the driver side door.
- Wait at least 3 minutes.



SEF289H

## PRECAUTIONS

[4WD]

< PRECAUTION >

**CAUTION:**

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

**CAUTION:**

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

### Precautions for Drive Shaft

INFOID:000000010828160

**CAUTION:**

Note the following precautions when disassembling and assembling drive shaft.

- Joint sub-assembly does not disassemble because it is non-overhaul parts.
- Perform work in a dust-free location.
- Before disassembling and assembling, clean the parts.
- Prevent the entry of foreign objects during disassembly of the service location.
- Disassembled parts must be carefully reassembled in the correct order. If work is interrupted, a clean cover must be placed over parts.
- Paper shop cloths must be used. Fabric shop cloths must not be used because of the danger of lint adhering to parts.
- Disassembled parts (except for rubber parts) should be cleaned with kerosene which shall be removed by blowing with air or wiping with paper shop cloths.

# PREPARATION

[4WD]






< PREPARATION >

## PREPARATION

### PREPARATION

#### Special Service Tool

INFOID:000000010828161

Tool number Tool name	Description
KV40104000 Hub lock nut wrench a: 85 mm (3.35 in) b: 65 mm (2.56 in)	Removing and Installing wheel hub lock nut.   ZZA0802D
KV40107300 Boot band crimping tool	Installing boot band   ZZA1229D
KV40107500 Drive shaft attachment	Removing drive shaft   ZZA1230D
KV38107900 Protector a: 32 mm (1.26 in) dia.	Installing drive shaft   PDIA1183J
KV38100500 Drift a: 80 mm (3.15 in) dia. b: 60 mm (2.36 in) dia.	Installing sensor rotor   ZZA0701D
KV40101840 Collar a: 67 mm (2.64 in) dia. b: 85 mm (3.35 in) dia.	Installing sensor rotor   ZZA1113D





# PREPARATION

< PREPARATION >

[4WD]

Commercial Service Tool

INFOID:0000000010828162

Tool name	Description
Drive shaft puller	Removing drive shaft joint sub assembly
	 JPDIG0152ZZ
Sliding hammer	Removing drive shaft
	 ZZA0023D
Puller	Removing sensor rotor
	 ZZA0119D
Replacer	Removing sensor rotor
	 ZZA0700D
Ball joint remover	Removing hub bolt
	 NT146

## Lubricant or/and Sealant

INFOID:0000000010828163

Name	Description
Fill NISSAN Genuine grease or equivalent	<ul style="list-style-type: none"> <li>Joint sub-assembly inside</li> <li>Housing inside</li> </ul>

## SYMPTOM DIAGNOSIS

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

## NVH Troubleshooting Chart

INFOID:0000000010828164

Use chart below you find the cause of the symptom. If necessary, repair or replace these parts.

Reference														
-----------	--	--	--	--	--	--	--	--	--	--	--	--	--	--

## Possible cause and SUSPECTED PARTS

Symptom	DRIVE SHAFT	Noise	x	x	Excessive joint angle	—								
		Shake	x	x	Joint sliding resistance	<b>RAX-30</b>	—							
	REAR AXLE	Noise			Imbalance	—								
		Shake		x	Improper installation, looseness	<b>RAX-22</b>	—							
		Vibration			Parts interference			NVH in DLN section						
		Shimmy			PROPELLER SHAFT			NVH in DLN section						
		Judder		x	DIFFERENTIAL			NVH in RAX and RSU sections						
		Poor quality ride or handling	x	x	REAR AXLE AND REAR SUSPENSION									

x: Applicable

A  
B  
C  
RAX  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## PERIODIC MAINTENANCE

### REAR WHEEL HUB AND HOUSING

#### Inspection

INFOID:0000000010828165

##### COMPONENT PART

Make sure that the mounting conditions (looseness, backlash) of each component and component conditions (wear, damage) are normal.

##### WHEEL HUB ASSEMBLY (BEARING-INTEGRATED TYPE)

Check the following items, and replace the part if necessary.

- Move wheel hub and bearing assembly in the axial direction by hand. Check there is no looseness of wheel bearing.

**Axial end play** : Refer to [RAX-31, "Wheel Bearing"](#).

- Rotate wheel hub and make sure there is no unusual noise or other irregular conditions. If there is any of irregular conditions, replace wheel hub and bearing assembly.

&lt; PERIODIC MAINTENANCE &gt;

## REAR DRIVE SHAFT

### Inspection

INFOID:0000000010828166

#### REAR DRIVE SHAFT INSPECTION

Check the following items, and replace the part if necessary.

- Check drive shaft mounting point and joint for looseness and other damage.

**CAUTION:**

**Replace entire drive shaft assembly when noise or vibration occur from drive shaft.**

- Check boot for cracks and other damage.

A

B

C

RAX

E

F

G

H

I

J

K

L

M

N

O


P

## REMOVAL AND INSTALLATION

## REAR WHEEL HUB AND HOUSING

## Exploded View

INFOID:0000000010828167



- |                |                                  |              |
|----------------|----------------------------------|--------------|
| ① Axle housing | ② Suspension arm                 | ③ Back plate |
| ④ Hub bolt     | ⑤ Wheel hub and bearing assembly | ⑥ Disc rotor |
| ⑦ Plug         | ⑧ Wheel hub lock nut             | ⑨ Cotter pin |

N·m (kg·m, ft-lb)

Always replace after every disassembly.

## Removal and Installation

INFOID:0000000010828168

## REMOVAL

## Wheel Hub and Bearing Assembly

1. Remove tires. Refer to [WT-61, "Exploded View"](#).
2. Remove wheel sensor from axle housing. Refer to [BRC-213, "REAR WHEEL SENSOR : Exploded View"](#).
3. Remove caliper assembly. Hang caliper assembly in a place where it will not interfere with work.
  - LHD: Refer to [BR-63, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).
  - RHD: Refer to [BR-123, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).

**CAUTION:**

Never depress brake pedal while brake caliper is removed.

4. Remove disc rotor. If disc rotor cannot be removed, remove as follows.

**CAUTION:**

- Parking brake completely in the released position.


## REAR WHEEL HUB AND HOUSING

[4WD]


### < REMOVAL AND INSTALLATION >

- Put matching marks **A** on the wheel hub and bearing assembly and the disc rotor before removing the disc rotor.
- Never drop disc rotor.


- a. Fix the disc rotor with wheel nuts and remove the adjusting hole plug.



- b. Using suitable tool, rotate adjuster ① in the direction **A** to retract and loosen brake shoe.
- c. Remove disc rotor.




5. Remove cotter pin, and then loosen wheel hub lock nut, using a wheel hub lock nut wrench (A) (SST: KV40104000).



6. Patch wheel hub lock nut with a piece of wood. Hammer the wood to disengage wheel hub and bearing assembly from drive shaft.

**NOTE:**

Use suitable puller, if wheel hub and bearing assembly and drive shaft cannot be separated even after performing the above procedure.



7. Remove wheel hub and bearing assembly.

**CAUTION:**

Remove parking brake assembly only when necessary.

8. Remove back plate.

9. If axle housing need to be removed, remove drive shaft. Refer to [RAX-22, "Removal and Installation"](#).

# REAR WHEEL HUB AND HOUSING


[4WD]

## < REMOVAL AND INSTALLATION >

10. Remove hub bolts ① from wheel hub and bearing assembly, using the ball joint remover (A) (commercial service tool).

**CAUTION:**

- Remove hub bolt only when necessary.
- Never hammer the hub bolt to avoid impact to the wheel hub and bearing assembly.
- Pull out the hub bolt in a direction perpendicular to the wheel hub and bearing assembly.



11. Perform inspection after removal. Refer to [RAX-21, "Inspection"](#).

## INSTALLATION


Note the following, and install in the reverse order of removal.

### Hub Bolts

- Place a washer Ⓐ as shown in the figure to install the hub bolts ① by using the tightening force of the nut Ⓑ.

**CAUTION:**

- Check that there is no clearance between wheel hub and bearing assembly, and hub bolt.
- Never reuse hub bolt.



### Drive shaft

- Tighten the wheel hub lock nut to the specified torque. Refer to [RAX-18, "Exploded View"](#).

**CAUTION:**

- Since the drive shaft is assembled by press-fitting, use the tightening torque range for the wheel hub lock nut.
  - Be sure to use torque wrench to tighten the wheel hub lock nut. Never use a power tool.
  - Never reuse wheel hub lock nut.
- When installing a cotter pin, securely band the basal portion to prevent rattles.


**CAUTION:**

- Bend cotter pin at the root sufficiently to prevent any looseness.
- Never reuse cotter pin.

### Disc rotor

**CAUTION:**

- Align the matching marks Ⓐ made during removal when reusing the disc rotor.
- Never drop disc rotor.



- Perform inspection after installation. Refer to [RAX-21, "Inspection"](#).

### INSPECTION AFTER REMOVAL

Check wheel hub and bearing assembly for wear, cracks, and damage. Replace if there are.

### INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-213, "REAR WHEEL SENSOR : Exploded View"](#).
2. Check wheel alignment. Refer to [RSU-7, "Inspection"](#).
3. Adjust neutral position of steering angle sensor. Refer to [BRC-99, "Work Procedure"](#).

A

B

C

RAX

E

F

G

H

I

J

K

L

M

N

O

P

# REAR DRIVE SHAFT


< REMOVAL AND INSTALLATION >

[4WD]

## REAR DRIVE SHAFT

### Exploded View

INFOID:0000000010828170



- |                      |                   |                 |
|----------------------|-------------------|-----------------|
| ① Circular clip      | ② Dust shield     | ③ Housing       |
| ④ Snap ring          | ⑤ Spider assembly | ⑥ Boot band     |
| ⑦ Boot               | ⑧ Shaft           | ⑨ Circular clip |
| ⑩ Joint sub-assembly | ⑪ Sensor rotor    |                 |

⇨: Wheel side

■: Fill NISSAN genuine grease or an equivalent.


✗: Always replace after every disassembly.

### Removal and Installation

INFOID:0000000010828171

#### REMOVAL

1. Remove tires. Refer to [WT-61, "Removal and Installation"](#).
2. Remove wheel sensor from wheel hub and bearing assembly. Refer to [BRC-213, "REAR WHEEL SENSOR : Exploded View"](#).
3. Remove caliper assembly. Hang caliper assembly in a place where it will not interfere with work.
  - LHD: Refer to [BR-63, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).
  - RHD: Refer to [BR-123, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).
4. Remove disc rotor. Refer to [RAX-18, "Removal and Installation"](#).
5. Remove cotter pin, and then loosen wheel hub lock nut, using a wheel hub lock nut wrench (A) (SST: KV40104000).



# REAR DRIVE SHAFT


[4WD]

## < REMOVAL AND INSTALLATION >

6. Patch wheel hub lock nut with a piece of wood. Hammer the wood to disengage wheel hub and bearing assembly from drive shaft.

**NOTE:**

Use suitable puller, if wheel hub and bearing assembly and drive shaft cannot be separated even after performing the above procedure.



A  
B  
C  
RAX  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

7. Remove wheel hub and bearing assembly.

**CAUTION:**

Remove parking brake assembly only when necessary.

8. Remove back plate.

9. Remove stabilizer link. Refer to [RSU-19, "Removal and Installation"](#).

10. Remove shock absorber from suspension arm. Refer to [RSU-11, "Removal and Installation"](#).

11. Remove upper link from suspension arm. Refer to [RSU-17, "Removal and Installation"](#).

12. Remove lower link from suspension arm. Refer to [RSU-15, "Removal and Installation"](#).


13. Loosen the mounting bolt and nut of suspension arm and suspension arm braket. Refer to [RSU-13, "Removal and Installation"](#).

14. Remove drive shaft from final drive assembly.

- Use the drive shaft attachment (A) (SST: KV40107500) and a sliding hammer (B) (commercial service tool) while inserting tip of the drive shaft attachment between housing and final drive assembly.

**CAUTION:**

- Never place drive shaft joint at an extreme angle when removing drive shaft. Also be careful not to overextend slide joint.
- Confirm that the circular clip is attached to the drive shaft.



15. Perform inspection after removal. Refer to [RAX-30, "Inspection"](#).

## INSTALLATION

Note the following, and install in the reverse order of removal.


**CAUTION:**

Always replace side oil seal with new one when installing drive shaft. Refer to [DLN-229, "Removal and Installation"](#).

- Place the protector (A) (SST: KV38107900) onto final drive assembly to prevent damage to the side oil seal while inserting drive shaft. Slide drive shaft sliding joint and tap with a hammer to install securely.

**CAUTION:**

- Check that circular clip is completely engaged.
- Never reuse side oil seal.



- Tighten the wheel hub lock nut to the specified torque. Refer to [RAX-18, "Exploded View"](#).

**CAUTION:**

- Since the drive shaft is assembled by press-fitting, use the tightening torque range for the wheel hub lock nut.

## &lt; REMOVAL AND INSTALLATION &gt;

- Be sure to use torque wrench to tighten the wheel hub lock nut. Never use a power tool.
- Never reuse wheel hub lock nut.
- When installing a cotter pin, securely band the basal portion to prevent rattles.

**CAUTION:**

- Bend cotter pin at the root sufficiently to prevent any looseness.
- Never reuse cotter pin.
- Perform inspection after installation. Refer to [RAX-30, "Inspection"](#).

## Disassembly and Assembly

INFOID:000000010828172

## DISASSEMBLY

## Final Drive Side

1. Fix shaft with a vise.

**CAUTION:**

Protect shaft using aluminum or copper plates when fixing with a vise.

2. Remove boot bands, and then remove boot from housing.
3. Put matching marks on housing and shaft.


**CAUTION:**

Use paint or an equivalent for matching marks. Never scratch the surface.


4. Put matching marks **A** on the spider assembly and shaft.

**CAUTION:**

Use paint or an equivalent for matching marks. Never scratch the surface.



5. Remove snap ring ①, and then remove spider assembly from shaft.



6. Remove boot from shaft.
7. Remove circular clip housing.
8. Remove dust shield to housing.
9. Remove old grease on housing with paper towels.
10. Perform inspection after disassembly. Refer to [RAX-30, "Inspection"](#).


## Wheel Side

# REAR DRIVE SHAFT

[4WD]

## < REMOVAL AND INSTALLATION >

1. If sensor rotor needs to be removed, use a bearing replacer (A) and puller (B) (commercial service tool).



2. Fix shaft with a vise.

**CAUTION:**

**Protect shaft using aluminum or copper plates when fixing with a vise.**

3. Remove boot bands. Then remove boot from joint sub-assembly.
4. Screw drive shaft puller (A) (commercial service tool) into joint sub-assembly screw part to a length 30 mm (1.18 in) or more. Support drive shaft with one hand and pull out joint sub-assembly from shaft.

**CAUTION:**

- If joint sub-assembly cannot be removed after five or more unsuccessful attempts, replace shaft and joint sub assembly as a set.
- Align sliding hammer and drive shaft and remove them by pulling directory.

5. Remove circular clip from shaft.


**CAUTION:**

**Never reuse circular clip.**

6. Remove boot from shaft.

7. Remove old grease on joint sub-assembly with paper towels.

8. Perform inspection after disassembly. Refer to [RAX-30, "Inspection"](#).



JPDIG0151ZZ


## ASSEMBLY

### Final drive Side

1. Wrap serration on shaft with tape (A) to protect boot from damage. Install new boot and boot band to shaft.

**CAUTION:**

**Never reuse boot and boot band.**



JPDF0009ZZ


2. Remove the tape wrapped around the serrated on shaft.

## REAR DRIVE SHAFT

[4WD]

### < REMOVAL AND INSTALLATION >


- To install the spider assembly ①, align it with the matching marks Ⓐ on the shaft ② during the removal, and direct the serration mounting surface Ⓑ to the shaft.



- Secure spider assembly onto shaft with snap ring ①.

**CAUTION:**

Never reuse snap ring.



- Assemble the housing onto spider assembly, and apply the balance of the specified amount grease.


**Standard**

**Grease amount** : Refer to [RAX-31, "Drive Shaft"](#).

- Align matching marks painted when housing were removed.
- Install boot securely into grooves (indicated by "\*" marks) shown in the figure.

**CAUTION:**

If there is grease on boot mounting surfaces (indicated by "\*" marks) of shaft or housing, boot may be removed. Remove all grease from the surfaces.



- To prevent from deformation of the boot, adjust the boot installation length to the value shown below (L) by inserting the suitable tool into the inside of boot from the large diameter side of boot and discharging inside air.

**Standard**

**L** : Refer to [RAX-31, "Drive Shaft"](#).

**CAUTION:**

- If the boot installation length exceeds the standard, it may cause breakage in boot.
- Be careful not to touch the inside of the boot with the tip of tool.

- Install new boot bands securely.

**CAUTION:**

Never reuse boot band.


- For one-touch clamp band

# REAR DRIVE SHAFT

[4WD]

## < REMOVAL AND INSTALLATION >

- Secure the large and small ends of boot with new boot bands as shown in the figure.




A  
B  
C  
RAX  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


- For low profile type band
- Put boot band in the groove on drive shaft boot. Then fit pawls (➡) into holes to temporary installation.

**NOTE:**

For the large diameter side, fit projection (A) and guide slit (B) at first.



- Pinch projection on the band with suitable pliers to tighten band.
- Insert tip of band below end of the pawl.



10. Secure housing and shaft, and then make sure that they are in the correct position when rotating boot. Install them with new boot band when the mounting positions become incorrect.

11. Install dust shield to housing.

**CAUTION:**

Never reuse dust shield.

12. Install circular clip to housing.


**CAUTION:**

Never reuse circular clip.

13. Perform inspection after assembly. Refer to [RAX-30, "Inspection"](#).

### Wheel Side

- If sensor rotor (1) is removed, use a drift (A) (SST: KV38100500) and color (B) (SST: KV40101840) to press in a new one.



# REAR DRIVE SHAFT


## < REMOVAL AND INSTALLATION >

[4WD]

2. Fill serration slot joint sub-assembly ① with NISSAN genuine grease or equivalent until the serration slot and ball groove become full to the brim.

**CAUTION:**


After applying grease, use a shop cloth to wipe off old grease that has oozed out.



3. Wrap serrated part of shaft with tape A. Install boot band and boot to shaft. Be careful not to damage boot.

**CAUTION:**

Never reuse boot and boot band.



4. Remove the tape wrapped around the serrated on shaft.

5. Position circular clip on groove at the shaft edge.

**CAUTION:**

Never reuse circular clip.

**NOTE:**

Drive joint inserter is recommended when installing circular clip.

6. Align both center axles of the shaft edge and joint sub-assembly. Then assemble shaft with circular clip joint sub-assembly.

7. Install joint sub-assembly to shaft using plastic hammer.


**CAUTION:**

Confirm that joint sub-assembly is correctly engaged while rotating drive shaft.

8. Apply the balance of the specified amount of grease into the boot inside from large diameter side of boot.

**Standard**

**Grease amount** : Refer to [RAX-31, "Drive Shaft".](#)




9. Install the boot securely into grooves (indicated by "\*" marks) shown in the figure.

**CAUTION:**

If grease adheres to the boot mounting surface (with "\*" mark) on the shaft or joint sub-assembly, boot may be removed. Remove all grease from the surfaces.

10. To prevent from deformation of the boot, adjust the boot installation length to the specified value shown below (L) by inserting the suitable tool into inside of the boot from the large diameter side of boot and discharging the inside air.



**Standard**

**L** : Refer to [RAX-31, "Drive Shaft".](#)

## REAR DRIVE SHAFT

[4WD]

< REMOVAL AND INSTALLATION >

**CAUTION:**

- If the boot installation length exceeds the standard, it may cause breakage in boot.
- Be careful not to touch the inside of the boot with the tip of tool.


11. Secure large and small ends of boot with new boot bands as shown in the figure.

**CAUTION:**

Never reuse boot band.

a. For one-touch clamp band

- Secure the large and small ends of boot with new boot bands as shown in the figure.




b. For low profile type band

i. Put boot band in the groove on drive shaft boot. Then fit pawls (➡) into holes to temporary installation.


**NOTE:**

For the large diameter side, fit projection (A) and guide slit (B) at first.



ii. Pinch projection on the band with suitable pliers to tighten band.

iii. Insert tip of band below end of the pawl.




c. For omega type band

i. Secure the boot bands using the boot band crimping tool (A) (SST: KV40107300).

**CAUTION:**

Never reuse boot band.



**NOTE:**

# REAR DRIVE SHAFT


[4WD]

## < REMOVAL AND INSTALLATION >

Secure boot band so that dimension (M) meets the specification as shown in the figure.

**M**

: 1.0 – 4.0 mm (0.039 – 0.157 in)




12. Secure housing and shaft, and then make sure that they are in the correct position when rotating boot. Install them with new boot band when the mounting positions become incorrect.

## Inspection

INFOID:0000000010828173

### INSPECTION AFTER REMOVAL

- Move joint up/down, left/right, and in the axial direction. Check for motion that is not smooth and for significant looseness.
- Check boot for cracks or other damage, and also for grease leakage.
- If a malfunction is found, disassemble drive shaft, and then replace with new one.



### INSPECTION AFTER DISASSEMBLY

#### Shaft

Check shaft for runout, cracks, or other damage. Replace if there are any abnormal condition.

#### Joint Sub-Assembly (Wheel Side)

Check the following:

- Joint sub-assembly for rough rotation and excessive axial looseness.
- The inside of the joint sub-assembly for entry of foreign material.
- Joint sub-assembly for compression scars, cracks, and fractures inside of joint sub-assembly.

Replace joint sub-assembly if there are any non-standard conditions of components.

#### Housing and Spider assembly (Final Drive Side)

Replace housing and spider assembly if there is scratching or wear of housing roller contact surface or spider roller contact surface.

#### NOTE:

Housing and spider assembly are used in a set.

### INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-213, "REAR WHEEL SENSOR : Exploded View"](#).
2. Check wheel alignment. Refer to [RSU-7, "Inspection"](#).
3. Adjust neutral position of steering angle sensor. Refer to [BRC-99, "Work Procedure"](#).

## SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[4WD]

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### Wheel Bearing

INFOID:000000010828174

Axial end play	0.05 mm (0.002 in) or less
----------------	----------------------------

### Drive Shaft

INFOID:000000010828175

Item		Standard
Grease quantity	Wheel side	35 – 45 g (1.24 – 1.58 oz)
	Final drive side	40 – 50 g (1.42 – 1.76 oz)
Boots installed length*	Wheel side	90.2 – 92.2 mm (3.551 – 3.630 in)
	Final drive side	151.55 – 153.55 mm (5.97 – 6.05 in)

\*: For measuring position. Refer to [RAX-24, "Disassembly and Assembly"](#).

A

B

C

RAX

E

F

G

H

I

J

K

L

M

N

O

P