

RF

SECTION
ROOF

CONTENTS

PRECAUTION	3	BASIC INSPECTION	21
PRECAUTIONS	3	DIAGNOSIS AND REPAIR WORKFLOW	21
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	Work Flow	21
Precautions for Removing Battery Terminal	3		
PREPARATION	5	SYSTEM INITIALIZATION	24
PREPARATION	5	Description	24
Commercial Service Tool	5	Work Procedure	24
SYSTEM DESCRIPTION	6	ANTI-PINCH INSPECTION	25
COMPONENT PARTS	6	Description	25
SUNROOF SYSTEM	6	Work Procedure	25
SUNROOF SYSTEM : Component Description	6	DTC/CIRCUIT DIAGNOSIS	26
SUNROOF SYSTEM : Sunroof Switch	8	POWER SUPPLY AND GROUND CIRCUIT	26
SUNROOF SYSTEM : Sunroof Motor Assembly	8	SUNROOF MOTOR ASSEMBLY	26
SUNROOF SYSTEM : Sunshade Motor Assembly	8	SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure	26
SYSTEM	9	SUNSHADE MOTOR ASSEMBLY	28
System Description	9	SUNSHADE MOTOR ASSEMBLY : Diagnosis Procedure	28
Circuit Diagram	13	COMMUNICATION SIGNAL CIRCUIT	30
ECU DIAGNOSIS INFORMATION	14	Component Function Check	30
BCM (BODY CONTROL MODULE)	14	Diagnosis Procedure	30
List of ECU Reference	14	VEHICLE SPEED SIGNAL CIRCUIT	31
SUNROOF MOTOR ASSEMBLY	15	Component Function Check	31
Reference Value	15	Diagnosis Procedure	31
SUNSHADE MOTOR ASSEMBLY	17	SUNROOF SWITCH	32
Reference Value	17	Component Function Check	32
WIRING DIAGRAM	18	Diagnosis Procedure	32
SUNROOF SYSTEM	18	Component Inspection	33
Wiring Diagram	18	SYMPTOM DIAGNOSIS	34
		SUNROOF AND SUNSHADE DOES NOT OPERATE PROPERLY	34
		Description	34

Diagnosis Procedure	34	GLASS LID	46
SUNSHADE DOES NOT OPERATE PROPERLY	36	Exploded View	46
Description	36	Removal and Installation	47
Diagnosis Procedure	36	Adjustment	47
AUTO OPERATION DOES NOT OPERATE	37	REAR SUNROOF GLASS	49
SUNROOF	37	Exploded View	49
SUNROOF : Description	37	Removal and Installation	50
SUNROOF : Diagnosis Procedure	37	Adjustment	50
SUNSHADE	37	SUNROOF MOTOR ASSEMBLY	52
SUNSHADE : Description	37	Exploded View	52
SUNSHADE : Diagnosis Procedure	38	Removal and Installation	53
ANTI-PINCH FUNCTION DOES NOT OPERATE	39	SUNSHADE MOTOR ASSEMBLY	54
SUNROOF	39	Exploded View	54
SUNROOF : Diagnosis Procedure	39	Removal and Installation	55
SUNSHADE	39	SUNROOF UNIT ASSEMBLY	56
SUNSHADE : Diagnosis Procedure	39	Exploded View	56
SQUEAK AND RATTLE TROUBLE DIAGNOSES	40	Removal and Installation	57
Work Flow	40	Disassembly and Assembly	57
Inspection Procedure	42	SUNSHADE	59
Diagnostic Worksheet	44	Exploded View	59
REMOVAL AND INSTALLATION	46	Removal and Installation	60
		WIND DEFLECTOR	62
		Exploded View	62
		Removal and Installation	63
		SUNROOF SWITCH	64
		Removal and Installation	64

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010735386

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing Battery Terminal

INFOID:0000000010735480

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

RF


L

M

N

O

P



SEF289H

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.

PRECAUTIONS

< PRECAUTION >

2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

PREPARATION

< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tool

INFOID:0000000010735388

A

B

C

D

E

F

G

H

I

J

RF



L

M

N

O

P

Tool name	Description
Engine ear	 SIIA0995E
Remover tool	 JMKIA3050ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION


COMPONENT PARTS

SUNROOF SYSTEM

SUNROOF SYSTEM : Component Description

INFOID:0000000010735389

LHD MODELS



A View with headlining removed

B Behind A/C control


No.	Component	Function
①	Sunroof switch	Refer to RF-8, "SUNROOF SYSTEM : Sunroof Switch"
②	BCM	<ul style="list-style-type: none">Controls power window relayRefer to BCS-6, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location
③	Combination meter	Transmits vehicle speed signal to sunroof motor assembly
④	Sunshade motor assembly	Refer to RF-8, "SUNROOF SYSTEM : Sunshade Motor Assembly"

COMPONENT PARTS

< SYSTEM DESCRIPTION >

No.	Component	Function
⑤	Sunroof motor assembly	Refer to RF-8, "SUNROOF SYSTEM : Sunroof Motor Assembly"
⑥	Power window relay	Supplies power supply to sunroof motor assembly and sunshade motor assembly

RHD MODELS



[A] View with headlining removed

[B] Behind A/C control

JMKIB3960ZZ

No.	Component	Function
①	Sunroof switch	Refer to RF-8, "SUNROOF SYSTEM : Sunroof Switch"
②	Combination meter	Transmits vehicle speed signal to sunroof motor assembly
③	BCM	<ul style="list-style-type: none"> Controls power window relay Refer to BCS-6, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location
④	Sunshade motor assembly	Refer to RF-8, "SUNROOF SYSTEM : Sunshade Motor Assembly"
⑤	Sunroof motor assembly	Refer to RF-8, "SUNROOF SYSTEM : Sunroof Motor Assembly"
⑥	Power window relay	Supplies power supply to sunroof motor assembly and sunshade motor assembly


COMPONENT PARTS

< SYSTEM DESCRIPTION >

SUNROOF SYSTEM : Sunroof Switch

INFOID:0000000010735390

Transmits operation signal to sunroof motor assembly.




JMKIB2502ZZ

SUNROOF SYSTEM : Sunroof Motor Assembly

INFOID:0000000010735391

The sunroof motor and CPU integrated type enable tilt up/down and open/close sunroof operation by sunroof switch operation. And send sunroof switch signal to sunshade motor assembly via communication line.




JMKIA9876ZZ

SUNROOF SYSTEM : Sunshade Motor Assembly

INFOID:0000000010735392

The sunshade motor and CPU integrated type enable open/close sunshade operation by sunroof switch operation.



JMKIA9876ZZ

SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM

System Description

INFOID:0000000010735393

SYSTEM DIAGRAM




SUNROOF SYSTEM

- BCM controls the power window relay, and controls the ignition ON power source supplied to sunroof motor assembly and sunshade motor assembly.
- Sunroof motor assembly receive a vehicle speed signal from combination meter, and control the sunroof motor assembly.
- The sunroof motor assembly receives the signal from the sunroof switch to operate the sunroof, and transmits the signal from the sunroof switch to the sunshade motor assembly via communication line.
- The sunshade motor assembly operates the sunshade with the operation signal received from the sunroof motor assembly.

OPERATION DESCRIPTION

The sunroof switch can be operated in the directions of PUSH, OPEN (1st, 2nd) and CLOSE (1st, 2nd). It can operate the sunroof and sunshade by one switch.






Sunroof switch operation		Sunroof and sunshade action
(A)	PUSH	Tilt up/down
(B)	OPEN 1st	<ul style="list-style-type: none">• The sunshade opens during the 1st slide• The sunroof opens during the 2nd slide
(C)	OPEN 2nd	The sunshade opens, and then the sunroof opens
(D)	CLOSE 1st	<ul style="list-style-type: none">• The sunroof closes during the 1st slide• The sunshade closes during the 2nd slide
(E)	CLOSE 2nd	The sunroof closes, and then the sunshade closes



The sunroof and sunshade operate as per the following by operating the sunroof switch operation.




SYSTEM

< SYSTEM DESCRIPTION >

Before operation	Sunroof switch operation	Sunroof and sunshade action	After operation
Fully-closed  (A): Sunroof (B): Sunshade JMKB2714ZZ	PUSH	1. Sunshade: Open 2. Sunroof: Tilt up	 JMKB2703ZZ
	OPEN 1st	Sunshade: Open	 JMKB2704ZZ
	OPEN 2nd	1. Sunshade: Open 2. Sunroof: Open (Comfort position)	 JMKB2705ZZ
	• CLOSE 1st • CLOSE 2nd	Not action	—
	PUSH	Sunroof: Tilt down	 JMKB2709ZZ
Tilt up  (A): Sunroof (B): Sunshade JMKB2717ZZ	• OPEN 1st • OPEN 2nd	Not action	—
	CLOSE 1st	Sunroof: Tilt down	 JMKB2709ZZ
	CLOSE 2nd	1. Sunroof: Tilt down 2. Sunshade: Close	 JMKB2710ZZ

SYSTEM

< SYSTEM DESCRIPTION >




Before operation	Sunroof switch operation	Sunroof and sunshade action	After operation
 <p>Fully-open (sunshade only)</p> <p>(A): Sunroof (B): Sunshade</p>	PUSH	Sunroof: Tilt up	 <p>JMKIB2711ZZ</p>
	<ul style="list-style-type: none"> OPEN 1st OPEN 2nd 	Sunroof: Open (Comfort position)	 <p>JMKIB2712ZZ</p>
	<ul style="list-style-type: none"> CLOSE 1st CLOSE 2nd 	Sunshade: Close	 <p>JMKIB2713ZZ</p>
 <p>Comfort position</p> <p>(A): Sunroof (B): Sunshade</p>	PUSH	Not action	—
	<ul style="list-style-type: none"> OPEN 1st OPEN 2nd 	Sunroof: Open (Fully-open)	 <p>JMKIB2706ZZ</p>
	CLOSE 1st	Sunroof: Close	 <p>JMKIB2707ZZ</p>
	CLOSE 2nd	<ol style="list-style-type: none"> 1. Sunroof: Close 2. Sunshade: Close 	 <p>JMKIB2708ZZ</p>

A B C D E F G H I J

RF

SYSTEM

< SYSTEM DESCRIPTION >

Before operation	Sunroof switch operation	Sunroof and sunshade action	After operation
	<ul style="list-style-type: none"> • PUSH • OPEN 1st • OPEN 2nd 	Not action	—
Fully-open 	CLOSE 1st	Sunroof: Close	
	CLOSE 2nd	<ol style="list-style-type: none"> 1. Sunroof: Close 2. Sunshade: Close 	

AUTO OPERATION

The sunroof and sunshade operates automatically by operating the sunroof switch.

NOTE:

- If initialization setting is not performed, the automatic function does not operate.
- During automatic operation, when the sunroof switch is operated, automatic operation can be stopped.

ANTI-PINCH FUNCTION

- The CPU of sunroof motor assembly monitors the sunroof condition using the signals from sunroof motor. When sunroof motor assembly detects an interruption during auto operation (close or tilt down operation), sunroof motor will tilt up or open [150 mm (5.91 in) or more] sunroof.
- The CPU of sunshade motor assembly monitors the sunshade condition using the signals from sunshade motor. When sunshade motor assembly detects an interruption during auto close operation, sunshade motor will open [150 mm (5.91 in) or more] sunshade.

CAUTION:

There are some small distances immediately before the closed position which cannot be detected.

NOTE:


- If initialization setting is not performed, the anti-pinch function does not operate.
- When the distance between pinching position and fully-open position is less than 150 mm (5.91 in), sunroof or sunshade reverses to fully-open position.

SYSTEM

< SYSTEM DESCRIPTION >

Circuit Diagram

INFOID:000000010735394



JMKIB3745GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000010735395

ECU	Reference
BCM	BCS-53, "Reference Value"
	BCS-76, "Fail-safe"
	BCS-77, "DTC Inspection Priority Chart"
	BCS-78, "DTC Index"

SUNROOF MOTOR ASSEMBLY


< ECU DIAGNOSIS INFORMATION >

SUNROOF MOTOR ASSEMBLY

Reference Value

INFOID:0000000010735396

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No.		Description		Condition		Voltage
+	-	Signal name	Input/ Output			
1	Ground	Ground	—	—		0 – 1 V
2	Ground	OPEN/CLOSE 2nd signal	Input	Sunroof switch	• OPEN 2nd	0 – 1 V
					• CLOSE 2nd	
3	Ground	Ignition ON power supply	Input	Ignition switch ON		9 – 16 V
				Other than above		0 – 1 V
4	Ground	PUSH signal	Input	Sunroof switch	PUSH	0 – 1 V
					Other than above	9 – 16 V
5	Ground	OPEN 1st signal	Input	Sunroof switch	• OPEN 1st	0 – 1 V
					• OPEN 2nd	
6	Ground	Battery power supply	Input	—		9 – 16 V
				Ignition switch ON		<p>JMKIB2719GB</p>
7	Ground	Communication line	Input/ Output			
8	Ground	Vehicle speed signal	Input	Speed meter operated [When vehicle speed is approx. 40 km/h (25 MPH)]		<p>NOTE: The maximum voltage varies depending on the specification (destination unit).</p> <p>JSNIA0015GB</p>

SUNROOF MOTOR ASSEMBLY

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Description		Condition		Voltage
+	-	Signal name	Input/ Output			
10	Ground	CLOSE 1st signal	Input	Sunroof switch	• CLOSE 1st	0 – 1 V
					• CLOSE 2nd	
					Other than above	9 – 16 V

SUNSHADE MOTOR ASSEMBLY


< ECU DIAGNOSIS INFORMATION >

SUNSHADE MOTOR ASSEMBLY


Reference Value

INFOID:0000000010735397

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No.		Description		Condition	Voltage
+	-	Signal name	Input/ Output		
1	Ground	Ground	—	—	0 – 1 V
3	Ground	Ignition ON power supply	Input	Ignition switch ON	9 – 16 V
				Other than above	0 – 1 V
6	Ground	Battery power supply	Input	—	9 – 16 V
7	Ground	Communication line	Input/ Output	Ignition switch ON	 JMKIB2719GB

SUNROOF SYSTEM

< WIRING DIAGRAM >


WIRING DIAGRAM

SUNROOF SYSTEM

Wiring Diagram

INFOID:0000000010735398

- X9 : Except for R9M engine models
- R9 : R9M engine models




*: This connector is not shown in "Harness Layout".

2014/03/17

JRKWD4491GB

SUNROOF SYSTEM

< WIRING DIAGRAM >



JRKWD4492GB

SUNROOF SYSTEM

< WIRING DIAGRAM >

SUNROOF

Terminal No.	Signal Name (Specification)	Color Of Wire	Signal Name (Specification)	Terminal No.	Color Of Wire	Signal Name (Specification)
88	LAW	BLOWER CONTROL	COMBI SW INPUT 5	74	LG	COMBI SW INPUT 5
			COMBI SW OUTPUT 5	74	Y	COMBI SW OUTPUT 5
137	W	BATT POWER SUPPLY (FUSE)	SECURITY IND LAMP CONT	75	BG	SECURITY IND LAMP CONT
138	S	INSTRUMENT PANEL LAMP	COMBI SW INPUT 3	76	G	COMBI SW INPUT 3
139	L	PASSENGER DOOR UNLOCK OUTPUT	COMBI SW INPUT 4	77	GR	COMBI SW INPUT 4
141	V	FRONT DOOR LOCK OUTPUT	COMBI SW INPUT 1	78	Y	COMBI SW INPUT 1
143	W	POWER SUPPLY (TURN SIGNAL)	COMBI SW INPUT 2	79	W	COMBI SW INPUT 2
144	BG	POWER SUPPLY (TURN SIGNAL)	DOOR UNLOCK SW	80	SB	DOOR UNLOCK SW
					B	

145	GR	POWER SUPPLY (STOP LAMP) GROUND	9	W	-	Connector No. R16
146	B	GROUND	10	B	-	Connector Name SUNROOF SWITCH
147	B	DRIVEDOOR UNLOCK OUTPUT	11	LG	-	Connector Type TH12EW/NH
148	G	FRONT DOOR SUPERLOCK OUTPUT	12	L	-	
149	W	POWER SUPPLY REAR DOOR(L/ACT)				
151	R	POWER SUPPLY REAR DOOR(R/ACT)				
162	LG	POWER SUPPLY (REAR WIPER)				

Connector No.	BCM (BODY CONTROL MODULE)	Connector Name	TH40FCT-NH1	Connector Type	YEAR/FG/Y	Corrector Type	4 5
M87							

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
41	V	STEERING LOCK UNIT POWER SUPPLY	1	—	GROUND
42	LA	TURN SIG L/H (SIDE)	2	Y	OPEN/CLOSE 2nd SIGNAL
43	LAY	TURN SIG R/H (SIDE)	3	V	IGN ON POWER SUPPLY
44	LG	IGN	4	P	FLASH SIGNAL
45	—	—	5	GR	OPEN/FI
46	—	—	8	B	OPEN/POWER SIGNAL
47	—	—	9	W	OPEN/POWER SIGNAL
48	—	—	10	B	OPEN/POWER SIGNAL
49	—	—	11	LG	OPEN/POWER SIGNAL
50	—	—	12	L	OPEN/POWER SIGNAL
51	—	—	5	—	BATTERY POWER SUPPLY
52	—	—	6	—	—

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000010735399

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44, "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44, "Intermittent Incident"](#).

A

8.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

B

C

D

>> GO TO 9.

E

9.FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

F

Is DTC detected and does symptom remain?

G

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

H

NO >> Before returning the vehicle to the customer, always erase DTC.

I

J

RF

L

M

N

O

P

SYSTEM INITIALIZATION

< BASIC INSPECTION >

SYSTEM INITIALIZATION

Description

INFOID:000000010735400

Initialization of system should be conducted after the following conditions.

- When the sunroof motor assembly or sunshade motor assembly is changed.
- When the sunroof or sunshade does not operate normally. (Incomplete initialization conditions)

Work Procedure

INFOID:000000010735401

1. STEP 1

1. Close the sunroof and sunshade, then release the sunroof switch once.
2. Press and hold the sunroof switch CLOSE (1st or 2nd) again (for approx. 10 seconds), then sunroof tilt up, sunshade moves forward and stops mechanically.
3. Release the sunroof switch, and press and hold the sunroof switch CLOSE (1st or 2nd) again. Then sunroof and sunshade automatically move to the sunshade fully open → sunroof tilt down → sunroof fully open → sunroof fully closed → sunshade fully closed.
4. Release sunroof switch, after the sunshade is fully close position.

>> GO TO 2.

2. STEP 2

1. Operate sunroof switch and check that sunroof and sunshade automatically operated normally.
2. Perform anti-pinch function check. Refer to [RF-25, "Description"](#).

>> END

ANTI-PINCH INSPECTION

< BASIC INSPECTION >

ANTI-PINCH INSPECTION

Description

INFOID:0000000010735402

Check anti-pinching function when the initialization of sunroof and sunshade system is performed.

Work Procedure

INFOID:0000000010735403

1. CHECK ANTI-PINCH FUNCTION

1. Fully open the sunroof.
2. Place a piece of wood near the fully closed position.
3. Close the sunroof completely with auto-slide closed.
4. Check that sunroof lowers for approximately 150 mm (5.91 in) without pinching a piece of wood and stops.
5. Fully open the sunshade.
6. Place a piece of wood near fully closed position.
7. Close the sunshade completely with auto-slide closed.
8. Check that sunshade lowers for approximately 150 mm (5.91 in) without pinching a piece of wood and stops.

CAUTION:

- Never check with hands or another part of the body because they may be pinched. never get pinched.
- When the distance between pinching position and fully-open position is less than 150 mm (5.91 in), sunroof or sunshade reverses to fully-open position.

Is the inspection result normal?

YES >> END

NO >> Perform initialization procedure. Refer to [RF-24, "Description"](#).

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT SUNROOF MOTOR ASSEMBLY

SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure

INFOID:0000000010735404

1. CHECK FUSE AND FUSIBLE LINK

1. Turn ignition switch OFF.
2. Check that any of the following fuse and fusible link is not fusing.

R9M engine models

Signal name	Fuse and fusible link No.
Battery power supply	7 (10A)
	F (50A)

Except for R9M engine models

Signal name	Fuse and fusible link No.
Battery power supply	7 (10A)
	M (50A)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the applicable circuit. And then replace the fuse or fusible link.

2. CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY 1

1. Disconnect sunroof motor assembly connector.
2. Check voltage between sunroof motor assembly harness connector and ground.

(+)		(-)	Voltage
Sunroof motor assembly			
Connector	Terminal		
R12	6	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY 2

1. Turn ignition switch ON.
2. Check voltage between sunroof motor assembly harness connector and ground.

(+)		(-)	Voltage
Sunroof motor assembly			
Connector	Terminal		
R12	3	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 10.

NO >> GO TO 6.

4. CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY CIRCUIT 1

1. Disconnect circuit breaker connector.
2. Check voltage between circuit breaker harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

(+)	Circuit breaker	(-)	Voltage
Connector			
M63	1	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY CIRCUIT 2

Check continuity between circuit breaker harness connector and sunroof motor assembly harness connector.

Circuit breaker		Sunroof motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
M63	2	R12	6	Existed

Is the inspection result normal?

YES >> Replace circuit breaker.

NO >> Repair or replace harness.

6.CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY CIRCUIT 3

1. Turn ignition switch to OFF, and then wait for 3 minutes with driver door open.

NOTE:

- Even after ignition switch is OFF, power is supplied to accessories for a certain amount of time by the AUTO ACC function.
- When vehicle is operated while on standby, power may be supplied to accessories.

2. Disconnect power window relay connector.
3. Check voltage between power window relay harness connector and ground.

(+)	Power window relay	(-)	Voltage
Connector			
M64	2	Ground	9 – 16 V
	5		

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness.

7.CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY CIRCUIT 4

Check continuity between power window relay harness connector and sunroof motor assembly harness connector.

Power window relay		Sunroof motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
M64	3	R12	3	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

8.CHECK POWER WINDOW RELAY GROUND CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and power window relay harness connector.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Power window relay		Continuity
Connector	Terminal	Connector	Terminal	
M87	63	M64	1	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

9. CHECK POWER WINDOW RELAY

Check power window relay.

Refer to [PWC-62, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace power window relay.

10. CHECK SUNROOF MOTOR ASSEMBLY GROUND CIRCUIT

1. Turn ignition switch OFF.

2. Check continuity between sunroof motor assembly harness connector and ground.

Sunroof motor assembly		Ground	Continuity
Connector	Terminal		
R12	1		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

SUNSHADE MOTOR ASSEMBLY

SUNSHADE MOTOR ASSEMBLY : Diagnosis Procedure

INFOID:000000010735405

1. CHECK SUNSHADE MOTOR ASSEMBLY POWER SUPPLY 1

1. Turn ignition switch OFF.

2. Disconnect sunshade motor assembly connector.

3. Check voltage between sunshade motor assembly harness connector and ground.

(+) Sunshade motor assembly		(-)	Voltage
Connector	Terminal		
R13	6	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK SUNSHADE MOTOR ASSEMBLY POWER SUPPLY 2

1. Turn ignition switch ON.

2. Check voltage between sunshade motor assembly harness connector and ground.

(+) Sunshade motor assembly		(-)	Voltage
Connector	Terminal		
R13	3	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK SUNSHADE MOTOR ASSEMBLY POWER SUPPLY CIRCUIT 1

1. Disconnect circuit breaker connector.
2. Check continuity between circuit breaker harness connector and sunshade motor assembly harness connector.

Circuit breaker		Sunshade motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
M63	2	R13	6	Existed

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
NO >> Repair or replace harness.

4. CHECK SUNSHADE MOTOR ASSEMBLY POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect power window relay connector.
3. Check continuity between power window relay harness connector and sunshade motor assembly harness connector.

Power window relay		Sunshade motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
M64	3	R13	3	Existed

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
NO >> Repair or replace harness.

5. CHECK SUNSHADE MOTOR ASSEMBLY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sunshade motor assembly harness connector and ground.

Sunshade motor assembly		Ground	Continuity
Connector	Terminal		
R13	1		Existed

Is the inspection result normal?

YES >> INSPECTION END
NO >> Repair or replace harness.

COMMUNICATION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

COMMUNICATION SIGNAL CIRCUIT

Component Function Check

INFOID:0000000010735406

1. CHECK SUNSHADE FUNTION

Check sunshade open/close operations with sunroof switch.

Is the inspection result normal?

YES >> INSPECTION END.


NO >> Refer to [RF-30, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010735407

1. CHECK COMMUNICATION SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sunshade motor assembly connector.
3. Turn ignition switch ON.
4. Check signal between sunshade motor assembly harness connector and ground with oscilloscope.

		(+)	(-)	Signal (Reference value)
Connector	Terminal	Sunshade motor assembly		
R13	7		Ground	

Is the inspection result normal?

YES >> Replace sunshade motor assembly. Refer to [RF-55, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sunroof motor assembly connector.
3. Check continuity between sunroof motor assembly harness connector and sunshade motor assembly harness connector.

Sunroof motor assembly		Sunshade motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
R12	7	R13	7	Existed

4. Check continuity between sunshade motor assembly harness connector and ground.

Sunshade motor assembly		Ground	Continuity
Connector	Terminal		
R13	7		Not existed

Is the inspection result normal?

YES >> Replace sunroof motor assembly. Refer to [RF-53, "Removal and Installation"](#).

NO >> Repair or replace harness.

VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

VEHICLE SPEED SIGNAL CIRCUIT

Component Function Check

INFOID:0000000010735408

1. CHECK SUNROOF FUNCTION

1. Start engine.
2. Drive the vehicle at more than 40 km/h (25 MPH).

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

3. Check sunroof tilt up/down and open/close operations with sunroof switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [RF-31, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010735409

1. CHECK DTC WITH COMBINATION METER

Check that DTC is not detected with combination meter.

Refer to [MWI-105, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK VEHICLE SPEED SIGNAL CIRCUIT

1. Turn ignition switch to OFF, and then wait for 3 minutes with driver door open.

NOTE:

- Even after ignition switch is OFF, power is supplied to accessories for a certain amount of time by the AUTO ACC function.
- When vehicle is operated while on standby, power may be supplied to accessories.

2. Disconnect sunroof motor assembly connector and combination meter connector.

3. Check continuity between sunroof motor assembly harness connector and combination meter harness connector.

Sunroof motor assembly		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
R12	8	M34	39	Existed

4. Check continuity between sunroof motor assembly harness connector and ground.

Sunroof motor assembly		Ground	Continuity
Connector	Terminal		
R12	8		Not existed

Is the inspection result normal?

YES >> Replace sunroof motor assembly. [RF-53, "Removal and Installation"](#).

NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

SUNROOF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SUNROOF SWITCH

Component Function Check

INFOID:0000000010735410

1. CHECK SUNROOF AND SUNSHADE FUNTION

Check sunroof tilt up/down, open/close and sunshade open/close operations with sunroof switch.

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Refer to [RF-32, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010735411

1. CHECK SUNROOF SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sunroof switch connector.
3. Turn ignition switch ON.
4. Check voltage between sunroof switch harness connector and ground.

(+) Sunroof switch		(-)	Voltage
Connector	Terminal		
R16	2	Ground	9 – 16 V
	3		
	4		
	5		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK SUNROOF SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sunroof motor assembly connector.
3. Check continuity between sunroof motor assembly harness connector and sunroof switch harness connector.

Sunroof motor assembly		Sunroof switch		Continuity
Connector	Terminal	Connector	Terminal	
R12	2	R16	2	Existed
	5		3	
	10		4	
	4		5	

4. Check continuity between sunroof switch harness connector and ground.

Sunroof switch		Continuity
Connector	Terminal	
R16	2	Ground
	3	
	4	
	5	

Is the inspection result normal?

YES >> Replace sunroof motor assembly. Refer to [RF-53, "Removal and Installation"](#)

NO >> Repair or replace harness.

SUNROOF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK SUNROOF SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sunroof switch harness connector and ground.

Sunroof switch		Ground	Continuity
Connector	Terminal		Existed
R16	1		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the harness.

4.CHECK SUNROOF SWITCH

Check sunroof switch.

Refer to [RF-33, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace sunroof switch. Refer to [RF-64, "Removal and Installation"](#).

Component Inspection

INFOID:000000010735412

SUNROOF SWITCH

1.CHECK SUNROOF SWITCH

1. Turn ignition switch OFF.
2. Disconnect sunroof switch connector.
3. Check continuity sunroof switch terminals under the following conditions.

Terminals		Condition	Continuity
2	1	Sunroof switch is operated OPEN (2nd) or CLOSE (2nd)	Existed
		Other than above	Not existed
3	1	Sunroof switch is operated OPEN (1st) or OPEN (2nd)	Existed
		Other than above	Not existed
4	1	Sunroof switch is operated CLOSE (1st) or CLOSE (2nd)	Existed
		Other than above	Not existed
5	1	Sunroof switch is operated PUSH	Existed
		Other than above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sunroof switch. Refer to [RF-64, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

SUNROOF AND SUNSHADE DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SUNROOF AND SUNSHADE DOES NOT OPERATE PROPERLY

Description

INFOID:0000000010735413

Sunroof and sunshade does not operate normally.

- Sunroof tilt up/down, open/close or sunshade open/close does not operate.
- Sunroof tilt up/down, open/close or sunshade open/close operation is slow.
- Judder occurs during open/close operation of sunroof and sunshade.

Diagnosis Procedure

INFOID:0000000010735414

1. CHECK GLASS LID

Check the following items.

- Cracks, damage, or deformation of weather-strip.
- Sticking of weather-strip.
- Loose or missing glass lid mounting blot.
- Misalignment of glass lid.

Refer to [RF-47, "Adjustment"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK SUNROOF UNIT ASSEMBLY

Check the following items.

- Damage, deformation or trapped foreign material of slide rail.
- Insufficient application of grease to sliding section of slide rail.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK SUNSHADE

Check sunshade for damage, deformation, or interference with other parts.

Refer to [RF-60, "Removal and Installation"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-114, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY AND GROUND CIRCUIT

Check sunroof motor assembly power supply and ground circuit.

Refer to [RF-26, "SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. CHECK SUNROOF SWITCH

Check sunroof switch.

Refer to [RF-32, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

SUNROOF AND SUNSHADE DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

SUNSHADE DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

SUNSHADE DOES NOT OPERATE PROPERLY

Description

INFOID:0000000010735415

Sunshade does not operate normally.

- Sunshade open/close does not operate.
- Sunshade open/close operation is slow.
- Judder occurs during open/close operation of sunshade.

Diagnosis Procedure

INFOID:0000000010735416

1. CHECK SUNSHADE

Check sunshade for damage, deformation, or interference with other parts.

Refer to [RF-60, "Removal and Installation"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK SUNSHADE MOTOR ASSEMBLY POWER SUPPLY AND GROUND CIRCUIT

Check sunshade motor assembly power supply and ground circuit.

Refer to [RF-28, "SUNSHADE MOTOR ASSEMBLY : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK COMMUNICATION CIRCUIT

Check communication circuit.

Refer to [RF-30, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

AUTO OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE SUNROOF

SUNROOF : Description

INFOID:000000010735417

Auto operation does not operate

- Auto operation of sunroof does not operate.
- Sunroof stops halfway. (Without comfort position)
- Anti-pinch function operates.

SUNROOF : Diagnosis Procedure

INFOID:000000010735418

1. CHECK GLASS LID

Check the following items.

- Cracks, damage, or deformation of weather-strip.
- Sticking of weather-strip.
- Loose or missing glass lid mounting blot.
- Misalignment of glass lid.

Refer to [RF-47, "Adjustment"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK WIND DEFLECTOR

Check wind deflector for deformation and interference.

Refer to [RF-63, "Removal and Installation"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK SUNROOF UNIT ASSEMBLY

Check the following items.

- Damage, deformation or trapped foreign material of slide rail.
- Insufficient application of grease to sliding section of slide rail.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. PERFORM INITIALIZATION PROCEDURE

Initialization procedure is executed and operation is confirmed.

Refer to [RF-24, "Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK VEHICLE SPEED SIGNAL CIRCUIT

Check vehicle speed signal circuit.

Refer to [RF-31, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace sunroof motor assembly. Refer to [RF-53, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning parts.

SUNSHADE

SUNSHADE : Description

INFOID:000000010735419

Auto operation does not operate

- Auto operation of sunshade does not operate.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

AUTO OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- Sunshade stops halfway.
- Anti-pinching function operates.

SUNSHADE : Diagnosis Procedure

INFOID:0000000010735420

1. CHECK SUNSHADE

Check sunshade for damage, deformation, or interference with other parts.

Refer to [RF-60, "Removal and Installation"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. PERFORM INITIALIZATION PROCEDURE

Initialization procedure is executed and operation is confirmed.

Refer to [RF-24, "Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 3.

3. CHECK COMMUNICATION CIRCUIT

Check communication circuit.

Refer to [RF-30, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace sunshade motor assembly. Refer to [RF-55, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning parts.

ANTI-PINCH FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

ANTI-PINCH FUNCTION DOES NOT OPERATE SUNROOF

SUNROOF : Diagnosis Procedure

INFOID:000000010735421

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [RF-24, "Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sunroof motor assembly. Refer to [RF-53, "Removal and Installation"](#).

SUNSHADE

SUNSHADE : Diagnosis Procedure

INFOID:000000010735422

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [RF-24, "Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sunshade motor assembly. Refer to [RF-55, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P


SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000010735423



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of the customer's comments; refer to [RF-44, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by a test drive with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
- 2) Tap or push/pull around the area where the noise appears to be coming from.
- 3) Rev the engine.
- 4) Use a floor jack to recreate vehicle "twist".
- 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
- 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.

- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
- If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Engine ear or mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that is suspected to be the cause of the noise.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that is suspected to be the cause of the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration by hand by touching the component(s) that are suspected to be the cause of the noise.
 - Placing a piece of paper between components that are suspected to be the cause of the noise.
 - Looking for loose components and contact marks.
Refer to [RF-42, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. These insulators are available through the authorized Nissan Parts Department.

CAUTION:

Never use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

- URETHANE PADS
Insulates connectors, harness, etc.
- INSULATOR (Foam blocks)
Insulates components from contact. Can be used to fill space behind a panel.
- INSULATOR (Light foam block)
- FELT CLOTH TAPE
Used to insulate where movement does not occur. Ideal for instrument panel applications.
The following materials, not available through NISSAN Parts Department, can also be used to repair squeaks and rattles.
- UHMW(TEFLON) TAPE
Insulates where slight movement is present. Ideal for instrument panel applications.
- SILICONE GREASE
Used in place of UHMW tape that is be visible or does not fit.
Note: Will only last a few months.
- SILICONE SPRAY
Used when grease cannot be applied.
- DUCT TAPE
Used to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Inspection Procedure

INFOID:000000010735424

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for following:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. Trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SEATS

When isolating seat noise it is important to note the position the seat is in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. Rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:0000000010735425







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8740E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

<input type="checkbox"/> anytime	<input type="checkbox"/> after sitting out in the rain
<input type="checkbox"/> 1st time in the morning	<input type="checkbox"/> when it is raining or wet
<input type="checkbox"/> only when it is cold outside	<input type="checkbox"/> dry or dusty conditions
<input type="checkbox"/> only when it is hot outside	<input type="checkbox"/> other:

A

B

C

D

E

III. WHEN DRIVING:

<input type="checkbox"/> through driveways	<input type="checkbox"/> squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> over rough roads	<input type="checkbox"/> creak (like walking on an old wooden floor)
<input type="checkbox"/> over speed bumps	<input type="checkbox"/> rattle (like shaking a baby rattle)
<input type="checkbox"/> only about _____ mph	<input type="checkbox"/> knock (like a knock at the door)
<input type="checkbox"/> on acceleration	<input type="checkbox"/> tick (like a clock second hand)
<input type="checkbox"/> coming to a stop	<input type="checkbox"/> thump (heavy, muffled knock noise)
<input type="checkbox"/> on turns: left, right or either (circle)	<input type="checkbox"/> buzz (like a bumble bee)
<input type="checkbox"/> with passengers or cargo	
<input type="checkbox"/> other: _____	
<input type="checkbox"/> after driving _____ miles or _____ minutes	

IV. WHAT TYPE OF NOISE

<input type="checkbox"/> squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> creak (like walking on an old wooden floor)
<input type="checkbox"/> rattle (like shaking a baby rattle)
<input type="checkbox"/> knock (like a knock at the door)
<input type="checkbox"/> tick (like a clock second hand)
<input type="checkbox"/> thump (heavy, muffled knock noise)
<input type="checkbox"/> buzz (like a bumble bee)

F

G

H

I

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

YES	NO	Initials of person performing
-----	----	-------------------------------

L

Vehicle test driven with customer

<input type="checkbox"/>	<input type="checkbox"/>	_____
--------------------------	--------------------------	-------

M

- Noise verified on test drive

<input type="checkbox"/>	<input type="checkbox"/>	_____
--------------------------	--------------------------	-------

N

- Noise source located and repaired

<input type="checkbox"/>	<input type="checkbox"/>	_____
--------------------------	--------------------------	-------

- Follow up test drive performed to confirm repair

<input type="checkbox"/>	<input type="checkbox"/>	_____
--------------------------	--------------------------	-------

VIN: _____

Customer Name: _____

O

W.O.# _____

Date: _____

P

This form must be attached to Work Order

PIIB8742E

GLASS LID


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

GLASS LID

Exploded View

INFOID:000000010735426



- (1) Front sunroof bracket RH
- (4) Rear sunroof bracket RH
- (7) Front drain hose RH
- (10) Harness connector assembly

- (2) Glass lid
- (5) Side trim RH
- (8) Sunroof motor assembly
- (11) Front drain connector LH

- (3) Wind deflector
- (6) Sunroof unit assembly
- (9) Front drain connector RH
- (12) Sunshade motor assembly

GLASS LID

< REMOVAL AND INSTALLATION >

(13) Front drain hose LH	(14) Side trim LH	(15) Rear sunroof bracket LH
(16) Sunshade	(17) Rear drain connector LH	(18) Rear drain hose LH
(19) Rear drain hose RH	(20) Rear drain connector RH	(21) Front sunroof bracket LH
(22) Rear sunroof glass	(23) Drain assembly	

(○) : Clip

(扳手) : N·m (kg·m, in·lb)

●, ▲, ■, ▽, ♦, ○, △, □, ▽, ◇: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation


INFOID:0000000010735427

REMOVAL

CAUTION:

Always work with a helper.

1. Remove side trim (LH/RH).
2. Remove glass lid fixing screws Ⓐ, and then remove glass lid.



INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:


After installing the glass lid, perform the leak test and check that there is no malfunction.

NOTE:

After installation, carry out fitting adjustment. Refer to [RF-47, "Adjustment"](#).

Adjustment

INFOID:0000000010735428



① Roof panel

② Glass lid

③ Rear sunroof glass

If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

GLASS LID

< REMOVAL AND INSTALLATION >

NOTE:

Dimension (B) is given assuming that the glass upper side status is (+), and the glass lower side status is (−) relative to the roof panel.

Portion	A	B
Ⓐ – Ⓐ	6.5 – 8.1 mm (0.256 – 0.319 in)	(−2.2) – (+0.8) mm [(−0.087) – (+0.031) in]
Ⓑ – Ⓑ	6.5 – 8.1 mm (0.256 – 0.319 in)	(−2.2) – (+0.8) mm [(−0.087) – (+0.031) in]
Ⓒ – Ⓒ	6.5 – 8.1 mm (0.256 – 0.319 in)	(−1.5) – (+1.5) mm [(−0.059) – (+0.059) in]

1. Loosen glass lid mounting fixing screws.
2. Adjust the clearance of glass lid and roof panel according to the fitting standard dimension.
3. To prevent glass lid from moving after adjustment, first tighten the fixing screws of front left, and then tighten the screws of rear right.
4. Tilt glass lid up and down several times to check that it moves smoothly.

NOTE:

After adjustment the sunroof unit assembly, perform additional service. Refer to [RF-24, "Work Procedure"](#).


REAR SUNROOF GLASS

< REMOVAL AND INSTALLATION >

REAR SUNROOF GLASS

Exploded View


INFOID:0000000010735429



① Front sunroof bracket RH	② Glass lid	③ Wind deflector
④ Rear sunroof bracket RH	⑤ Side trim RH	⑥ Sunroof unit assembly
⑦ Front drain hose RH	⑧ Sunroof motor assembly	⑨ Front drain connector RH
⑩ Harness connector assembly	⑪ Front drain connector LH	⑫ Sunshade motor assembly
⑬ Front drain hose LH	⑭ Side trim LH	⑮ Rear sunroof bracket LH
⑯ Sunshade	⑯ Rear drain connector LH	⑯ Rear drain hose LH

REAR SUNROOF GLASS

< REMOVAL AND INSTALLATION >

(19) Rear drain hose RH	(20) Rear drain connector RH	(21) Front sunroof bracket LH
(22) Rear sunroof glass	(23) Drain assembly	
 : Clip		
 : N·m (kg·m, in·lb)		

●, ▲, ■, ▽, ◆, ○, △, □, ▽, ◇: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation

INFOID:0000000010735430


REMOVAL

CAUTION:

Always work with a helper.

1. Remove sunroof unit assembly. Refer to [RF-57, "Removal and Installation"](#).
2. Remove rear sunroof glass fixing screws Ⓐ, and then remove rear sunroof glass.

 : Vehicle front



INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:


After installing the rear sunroof glass, perform the leak test and check that there is no malfunction.

NOTE:

After installation, carry out fitting adjustment. Refer to [RF-50, "Adjustment"](#).

Adjustment

INFOID:0000000010735431



① Roof panel

② Glass lid

③ Rear sunroof glass

If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

NOTE:

Dimension (B) is given assuming that the glass upper side status is (+), and the glass lower side status is (-) relative to the roof panel.

REAR SUNROOF GLASS

< REMOVAL AND INSTALLATION >

Portion	A	B
Ⓐ – Ⓐ	6.5 – 8.1 mm (0.256 – 0.319 in)	(-2.2) – (+0.8) mm [(-0.087) – (+0.031) in]
Ⓑ – Ⓑ	6.5 – 8.1 mm (0.256 – 0.319 in)	(-2.2) – (+0.8) mm [(-0.087) – (+0.031) in]
Ⓒ – Ⓒ	6.5 – 8.1 mm (0.256 – 0.319 in)	(-1.5) – (+1.5) mm [(-0.059) – (+0.059) in]

1. Loosen rear sunroof glass fixing screws.
2. Adjust the clearance of rear sunroof glass and roof panel according to the fitting standard dimension.
3. To prevent rear sunroof glass from moving after adjustment, first tighten the fixing screws of front left, and then tighten the fixing screws of rear right.
4. Tighten remaining fixing screws, being careful to prevent rear sunroof glass from moving.

NOTE:

After adjustment the sunroof unit assembly, perform additional service. Refer to [RF-24, "Work Procedure".](#)

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P


SUNROOF MOTOR ASSEMBLY

< REMOVAL AND INSTALLATION >

SUNROOF MOTOR ASSEMBLY

Exploded View

INFOID:0000000010735432



(1) Front sunroof bracket RH	(2) Glass lid	(3) Wind deflector
(4) Rear sunroof bracket RH	(5) Side trim RH	(6) Sunroof unit assembly
(7) Front drain hose RH	(8) Sunroof motor assembly	(9) Front drain connector RH
(10) Harness connector assembly	(11) Front drain connector LH	(12) Sunshade motor assembly
(13) Front drain hose LH	(14) Side trim LH	(15) Rear sunroof bracket LH
(16) Sunshade	(17) Rear drain connector LH	(18) Rear drain hose LH

SUNROOF MOTOR ASSEMBLY

< REMOVAL AND INSTALLATION >

(19) Rear drain hose RH	(20) Rear drain connector RH	(21) Front sunroof bracket LH
(22) Rear sunroof glass	(23) Drain assembly	
○ : Clip		
扭 : N·m (kg·m, in·lb)		

●, ▲, ■, ▼, ♦, ○, △, □, ▽, ◇: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation


INFOID:0000000010735433

REMOVAL

CAUTION:

- Before removing sunroof motor, check that glass lid is fully closed.
- After removing sunroof motor, never attempt to rotate sunroof motor assembly as a single unit.

1. Disconnect battery cable from negative terminal.
2. Remove headlining to make work space. Refer to [INT-37, "Removal and Installation"](#).
3. Disconnect harness connector **(A)** from sunroof motor assembly.
4. Remove sunroof motor assembly fixing screws **(B)**, and then remove sunroof motor assembly.



INSTALLATION

CAUTION:

Before installing the sunroof motor assembly, always place the link and wire assembly in the symmetrical and fully closed position.

1. Move the sunroof motor assembly laterally a little so that the gear is completely engaged into the wire on the sunroof unit assembly and mounting surface becomes parallel. Then secure the sunroof motor assembly with screws.
2. Install headlining.

NOTE:

After installation sunroof motor assembly, perform additional service. Refer to [RF-24, "Description"](#)


SUNSHADE MOTOR ASSEMBLY

< REMOVAL AND INSTALLATION >

SUNSHADE MOTOR ASSEMBLY

Exploded View

INFOID:0000000010735434



(1) Front sunroof bracket RH	(2) Glass lid	(3) Wind deflector
(4) Rear sunroof bracket RH	(5) Side trim RH	(6) Sunroof unit assembly
(7) Front drain hose RH	(8) Sunroof motor assembly	(9) Front drain connector RH
(10) Harness connector assembly	(11) Front drain connector LH	(12) Sunshade motor assembly
(13) Front drain hose LH	(14) Side trim LH	(15) Rear sunroof bracket LH
(16) Sunshade	(17) Rear drain connector LH	(18) Rear drain hose LH

SUNSHADE MOTOR ASSEMBLY

< REMOVAL AND INSTALLATION >

(19) Rear drain hose RH	(20) Rear drain connector RH	(21) Front sunroof bracket LH
(22) Rear sunroof glass	(23) Drain assembly	
○ : Clip		
● : N·m (kg·m, in·lb)		

●, ▲, ■, ▼, ♦, ○, △, □, ▽, ◇: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation


INFOID:0000000010735435

REMOVAL

CAUTION:

- Before removing sunshade motor, check that sunshade is fully opened.
- After removing sunshade motor, never attempt to rotate sunshade motor assembly as a single unit.

1. Disconnect battery cable from negative terminal.
2. Remove headlining to make work space. Refer to [INT-37, "Removal and Installation"](#).
3. Disconnect harness connector **(A)** from sunshade motor assembly.
4. Remove sunshade motor assembly fixing screws **(B)**, and then remove sunshade motor assembly.



INSTALLATION

CAUTION:

Before installing the sunshade motor assembly, always place the link and wire assembly in the symmetrical and fully opened position.

1. Move the sunshade motor assembly laterally a little so that the gear is completely engaged into the wire on the sunroof unit assembly and mounting surface becomes parallel. Then secure the sunshade motor assembly with screws.
2. Install headlining.

NOTE:

After installation sunshade motor assembly, perform additional service. Refer to [RF-24, "Description"](#)


SUNROOF UNIT ASSEMBLY

< REMOVAL AND INSTALLATION >

SUNROOF UNIT ASSEMBLY

Exploded View


INFOID:0000000010735436



(1) Front sunroof bracket RH	(2) Glass lid	(3) Wind deflector
(4) Rear sunroof bracket RH	(5) Side trim RH	(6) Sunroof unit assembly
(7) Front drain hose RH	(8) Sunroof motor assembly	(9) Front drain connector RH
(10) Harness connector assembly	(11) Front drain connector LH	(12) Sunshade motor assembly
(13) Front drain hose LH	(14) Side trim LH	(15) Rear sunroof bracket LH
(16) Sunshade	(17) Rear drain connector LH	(18) Rear drain hose LH

SUNROOF UNIT ASSEMBLY

< REMOVAL AND INSTALLATION >

⑯ Rear drain hose RH	⑰ Rear drain connector RH	㉑ Front sunroof bracket LH
㉒ Rear sunroof glass	㉓ Drain assembly	
 : Clip		
 : N·m (kg·m, in·lb)		

●, ▲, ■, ▼, ♦, ○, △, □, ▽, ◇: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation


INFOID:0000000010735437

REMOVAL

CAUTION:

- Always work with a helper.
- When removing/installing sunroof unit, use cloths to protect the seats and trim from damage.

1. Remove glass lid. Refer to [RF-47, "Removal and Installation"](#).
2. Remove headlining. Refer to [INT-37, "Removal and Installation"](#).
3. Disconnect harness connector.
4. Disconnect front drain hoses ① and rear drain hoses ② from sunroof unit assembly ③.



 : Vehicle front

5. Remove front sunroof bracket mounting bolts, and then remove front sunroof brackets.
6. Remove rear sunroof bracket mounting bolts, and then remove rear sunroof brackets.
7. Remove sunroof unit assembly mounting nuts and bolts.
8. Remove sunroof unit assembly from back door opening.

INSTALLATION

1. Temporarily tighten the mounting nuts to the front end and side rail of sunroof unit assembly.
2. Temporarily tighten the mounting bolts to the front sunroof brackets and rear sunroof brackets.
3. Tighten the front end and side rail mounting nuts diagonally in order.

CAUTION:

Install sunroof unit assembly evenly without any distortion on sunroof unit assembly.

4. Tighten the mounting bolts to the rear sunroof brackets sunroof unit side, and then tighten the mounting bolts to the rear sunroof brackets vehicle side.
5. Tighten the mounting bolts to the front sunroof brackets.
6. Connect front drain hoses and rear drain hoses.
7. Connect harness connector.
8. Install headlining. Refer to [INT-37, "Removal and Installation"](#).
9. Install glass lid. Refer to [RF-47, "Removal and Installation"](#).

NOTE:

- After installation, perform fitting adjustment. Refer to [RF-47, "Adjustment"](#).
- After installation of sunroof unit assembly, perform additional service. Refer to [RF-24, "Description"](#)

Disassembly and Assembly

INFOID:0000000010735438


DISASSEMBLY

SUNROOF UNIT ASSEMBLY

< REMOVAL AND INSTALLATION >

1. Remove sunroof motor assembly. Refer to [RF-53, "Removal and Installation"](#).
2. Remove sunshade motor assembly. Refer to [RF-55, "Removal and Installation"](#).
3. Remove rear sunroof glass. Refer to [RF-50, "Removal and Installation"](#).
4. Remove sunshade. Refer to [RF-60, "Removal and Installation"](#).
5. Remove wind deflector. Refer to [RF-63, "Removal and Installation"](#).
6. Remove rear drain assembly ① fixing screws Ⓐ, and then remove rear drain assembly.

◀ : Vehicle front



JMKIB2809ZZ

ASSEMBLY

Assemble in the reverse order of disassembly.


SUNSHADE

< REMOVAL AND INSTALLATION >

SUNSHADE

Exploded View

INFOID:0000000010735439



(1) Front sunroof bracket RH	(2) Glass lid	(3) Wind deflector
(4) Rear sunroof bracket RH	(5) Side trim RH	(6) Sunroof unit assembly
(7) Front drain hose RH	(8) Sunroof motor assembly	(9) Front drain connector RH
(10) Harness connector assembly	(11) Front drain connector LH	(12) Sunshade motor assembly
(13) Front drain hose LH	(14) Side trim LH	(15) Rear sunroof bracket LH
(16) Sunshade	(17) Rear drain connector LH	(18) Rear drain hose LH

A
B
C
D
E
F
G
H
I
J
RF
L
M
N
O
P

SUNSHADE

< REMOVAL AND INSTALLATION >

⑯ Rear drain hose RH

⑰ Rear drain connector RH

⑲ Front sunroof bracket LH

⑳ Rear sunroof glass

㉑ Drain assembly

○ : Clip

● : N·m (kg·m, in·lb)

●, ▲, ■, ▽, ♦, ○, △, □, ▽, ♦: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation

INFOID:0000000010735440

REMOVAL

1. Remove sunroof unit assembly. Refer to [RF-57, "Removal and Installation"](#).


2. Remove rear sunroof glass. Refer to [RF-50, "Removal and Installation"](#).

3. Disengage sunshade stay ① using a remover tool (A) from sunroof unit assembly ②.

CAUTION:


Apply protective tape (B) on remover tool to protect from damage.

◀ : Vehicle front




4. Push sunshade stay ① as shown by the arrows in the figure, and then disengage sunshade stay from sunroof unit assembly ②.

◀ : Vehicle front



5. Rotate sunshade as shown by the arrows in the figure, and then remove sunshade stay from sunroof unit assembly.




SUNSHADE

< REMOVAL AND INSTALLATION >

6. Pull sunshade ① as shown by the arrows in the figure, and then remove sun shade from sunroof unit assembly ②.

◀ : Vehicle front



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J

RF

L
M
N
O
P


WIND DEFLECTOR

< REMOVAL AND INSTALLATION >

WIND DEFLECTOR

Exploded View

INFOID:0000000010735441



(1) Front sunroof bracket RH	(2) Glass lid	(3) Wind deflector
(4) Rear sunroof bracket RH	(5) Side trim RH	(6) Sunroof unit assembly
(7) Front drain hose RH	(8) Sunroof motor assembly	(9) Front drain connector RH
(10) Harness connector assembly	(11) Front drain connector LH	(12) Sunshade motor assembly
(13) Front drain hose LH	(14) Side trim LH	(15) Rear sunroof bracket LH
(16) Sunshade	(17) Rear drain connector LH	(18) Rear drain hose LH

WIND DEFLECTOR

< REMOVAL AND INSTALLATION >

(19) Rear drain hose RH	(20) Rear drain connector RH	(21) Front sunroof bracket LH
(22) Rear sunroof glass	(23) Drain assembly	
 : Clip		
 : N·m (kg·m, in·lb)		

●, ▲, ■, ▼, ♦, ○, △, □, ▽, ◇: Indicates that the part is connected at points with same symbol in actual vehicle.


Removal and Installation

INFOID:0000000010735442

REMOVAL


1. Fully open the glass lid.
2. Disengage wind deflector fixing pawl using a remover tool (A) according to the numerical order 1→2 as shown in the figure.

 : Pawl
 : Vehicle front



3. Remove wind deflector fixing screws Ⓐ, and then remove wind deflector from sunroof unit assembly.

 : Vehicle front



INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

G

H

I

J

RF

L

M

N

O

P

SUNROOF SWITCH

< REMOVAL AND INSTALLATION >


SUNROOF SWITCH

Removal and Installation

INFOID:0000000010735443


Removal

1. Remove map lamp assembly. Refer to [INL-76, "MAP LAMP : Removal and Installation"](#).
2. Remove the screws Ⓐ from map lamp assembly.




3. Disengage fixing pawls and remove map lamp finisher ① from map lamp assembly ②.

△ :Pawl



4. Disengage fixing pawls and remove sunroof switch ① from map lamp assembly ②.

△ :Pawl



Installation

Install in the reverse order of removal.