

# SECTION **SBC**

## SEAT BELT CONTROL SYSTEM

### CONTENTS

|  |    |   |    |
|--|----|---|----|
| <b>PRECAUTION</b>  | 2  | <b>SEAT BELT WARNING LAMP CONTROL SYSTEM</b>            | 11 |
| <b>PRECAUTIONS</b>   | 2  | Wiring Diagram  | 11 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... | 2  | <b>BASIC INSPECTION</b>                                 | 16 |
| Precaution Necessary for Steering Wheel Rotation After Battery Disconnect .....                  | 2  | <b>DIAGNOSIS AND REPAIR WORK FLOW</b>                   | 16 |
| Work Flow .....  | 16 | Diagnosis Procedure .....                               | 19 |
| Precautions for Removing Battery Terminal .....  | 3  | Component Inspection .....                              | 19 |
| <b>SYSTEM DESCRIPTION</b>  | 5  | <b>DTC/CIRCUIT DIAGNOSIS</b>                            | 19 |
| <b>COMPONENT PARTS</b>   | 5  | <b>SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)</b>         | 19 |
| Component Parts Location .....   | 5  | Diagnosis Procedure .....                               | 19 |
| Seat Belt Buckle Switch .....  | 6  | Component Inspection .....                              | 19 |
| <b>SYSTEM</b>  | 7  | <b>REAR SEAT BELT BUCKLE SWITCH</b>                     | 20 |
| <b>SEAT BELT WARNING LAMP CONTROL SYSTEM</b>   | 7  | Diagnosis Procedure .....                               | 20 |
| SEAT BELT WARNING LAMP CONTROL SYSTEM : System Description .....                                 | 7  | Component Inspection .....                              | 20 |
| SEAT BELT WARNING LAMP CONTROL SYSTEM : Circuit Diagram .....                                    | 8  | <b>SYMPTOM DIAGNOSIS</b>                                | 21 |
| <b>INFORMATION DISPLAY (COMBINATION METER)</b>   | 8  | <b>FRONT SEAT BELT WARNING LAMP DOES NOT ILLUMINATE</b> | 21 |
| INFORMATION DISPLAY (COMBINATION METER) : Rear Seat Belt Warning .....                           | 8  | Diagnosis Procedure .....                               | 21 |
| <b>WARNING/INDICATOR/CHIME LIST</b>  | 9  | <b>FRONT SEAT BELT WARNING LAMP DOES NOT TURN OFF</b>   | 23 |
| WARNING/INDICATOR/CHIME LIST : Warning Lamp/Indicator Lamp .....                                 | 9  | Diagnosis Procedure .....                               | 23 |
| WARNING/INDICATOR/CHIME LIST : Warning Chime .....   | 10 | <b>REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE</b>  | 25 |
| <b>WIRING DIAGRAM</b>  | 11 | Diagnosis Procedure .....                               | 25 |
|  |    | <b>REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF</b>    | 27 |
|  |    | Diagnosis Procedure .....                               | 27 |

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011006819

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000011006820

#### **CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition power source and accessory power source to the OFF, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Open driver door.
3. Turn the ignition switch to the ON position.  
(At this time, the steering lock will be released.)
4. Turn the ignition switch to OFF position with driver door open.
5. Wait for 3 minutes or longer with driver door open.

#### **NOTE:**

- Do not close driver door because the steering wheel locks when driver door is closed.

# PRECAUTIONS

## < PRECAUTION >

- The auto acc function is adapted to this vehicle. For this reason, even when the ignition switch is turned to OFF position, the accessory power source does not turn OFF and continues to be supplied for a certain amount of time.
- 6. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
- 7. Perform the necessary repair operation.
- 8. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from OFF position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
- 9. Perform self-diagnosis check of all control units using CONSULT.

## Precautions for Removing Battery Terminal

INFOID:0000000011006821

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.

### NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

### NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

### NOTE:

The removal of 12V battery may cause a DTC detection error.

## HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.

For vehicles parked by ignition switch OFF, refer to Instruction 2.

### INSTRUCTION 1

1. Open the hood.
2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

|            |              |
|------------|--------------|
| D4D engine | : 20 minutes |
| HRA2DDT    | : 12 minutes |
| K9K engine | : 4 minutes  |
| M9R engine | : 4 minutes  |
| R9M engine | : 4 minutes  |
| V9X engine | : 4 minutes  |

### CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.


5. Remove 12V battery terminal.

### CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

### INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.



## PRECAUTIONS

### < PRECAUTION >

---

**NOTE:**

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

**CAUTION:**

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

**CAUTION:**

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

## COMPONENT PARTS


< SYSTEM DESCRIPTION >

# SYSTEM DESCRIPTION

## COMPONENT PARTS

### Component Parts Location

INFOID:0000000010926545



A  
B  
C  
D  
E  
F  
G  
**SBC**  
I

| No. | Component                                      | Function  |
|-----|--|---|
| ①   | Rear seat belt buckle switch (Center and RH)   | Refer to <a href="#">SBC-6, "Seat Belt Buckle Switch"</a> .   |
| ②   | Combination meter                              | <ul style="list-style-type: none"><li>• Receives seat belt buckle switch signal from air bag diagnosis sensor unit.</li><li>• Turns the seat belt warning lamp ON when the seat belt is unfastened.</li><li>• Turns the rear seat belt warning (information display/buzzer) ON according to the request from air bag diagnosis sensor unit via CAN communication.</li></ul> |
| ③   | ABS actuator and electric unit (Control unit)  | Transmits vehicle speed signal to combination meter.<br>Refer to <a href="#">BRC-14, "Component Parts Location"</a> for detailed installation location.   |
| ④   | Air bag diagnosis sensor unit                  | Transmits seat belt buckle switch signal to combination meter.<br>Refer to <a href="#">SRC-6, "Component Parts Location"</a> for detailed installation location.  |
| ⑤   | Front seat belt buckle switch (Passenger side) | Refer to <a href="#">SBC-6, "Seat Belt Buckle Switch"</a> .   |
| ⑥   | Rear seat belt buckle switch (LH)              | Refer to <a href="#">SBC-6, "Seat Belt Buckle Switch"</a> .   |

J  
K  
L  
M  
N  
O  
P


## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### Seat Belt Buckle Switch

INFOID:0000000010926546

- Detects seat belt status and transmits seat belt buckle switch (passenger side and rear) signal to air bag diagnosis sensor unit.
- The seat belt buckle switch is installed in the seat belt buckle.



JMHIA2276ZZ

# SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM

### SEAT BELT WARNING LAMP CONTROL SYSTEM

#### SEAT BELT WARNING LAMP CONTROL SYSTEM : System Description

INFOID:0000000010926547

#### SYSTEM DIAGRAM



#### SEAT BELT WARNING LAMP OPERATION

Seat belt warning lamp on combination meter turns ON during a period when ignition switch is turned ON until front seat belts are fastened. Seat belt warning lamp turns OFF when front seat belt is fastened. Seat belt warning lamp turns ON again when front seat belt is unfastened. Refer to [MWI-54, "WARNING LAMPS/INDICATOR LAMPS : Seat Belt Warning Lamp"](#).

#### REAR SEAT BELT WARNING LAMP OPERATION

Seat belt warning is displayed on information display for approximately 35 seconds when the following conditions.

- Turn ignition switch is ON.
- Rear seat belt buckle switch is turned ON (rear seat belt is not fastened).

Seat belt warning is canceled when the following conditions.

- Ignition switch is turned OFF (rear seat belt is fastened).
- Approximately 35 seconds are passed since rear seat belt warning is displayed.

#### SEAT BELT WARNING CHIME OPERATION

Front


Front seat belt warning chime sounds for approximately 90 seconds when the vehicle speed is approximately 15 km/h (9.3 MPH) or more while front seat belts are not fastened. Front seat belt warning chime stops when front seat belt is fastened.

# SYSTEM

## < SYSTEM DESCRIPTION >

### SEAT BELT WARNING LAMP CONTROL SYSTEM : Circuit Diagram

INFOID:0000000010926548



JMHIA2948GB

### INFORMATION DISPLAY (COMBINATION METER)

### INFORMATION DISPLAY (COMBINATION METER) : Rear Seat Belt Warning

INFOID:0000000010926549

### DESIGN/PURPOSE

Rear seat belt warning warns the driver that rear seat belt is not fastened.

# SYSTEM


## < SYSTEM DESCRIPTION >

| Symbol   | Message |
|--|---------|
| <br>JMKIB3746ZZ | -       |

### SYNCHRONIZATION WITH MASTER WARNING LAMP

No applicable

### SYSTEM DIAGRAM



JMHIA2969GB

### SIGNAL PATH

- When combination meter detects ignition switch ON, rear seat belt warning displays.
- When combination meter judges according to received rear seat belt buckle switch signal that a rear seat belt is not fastened.

### WARNING OPERATION CONDITION

When all of the following conditions are satisfied.

- Ignition switch is ON
- Rear seat belt buckle switch: OFF → ON (rear seat belt fastened → not fastened)

### WARNING CANCEL CONDITION

When any of the following conditions are satisfied.

- Ignition switch: ON → OFF
- Approximately 35 seconds are passed since warning start.

### WARNING/INDICATOR/CHIME LIST

#### WARNING/INDICATOR/CHIME LIST : Warning Lamp/Indicator Lamp

INFOID:000000010926550

| Item                   | Reference   |
|------------------------|---|
| Seat belt warning lamp | For layout, refer to <a href="#">MWI-10, "METER SYSTEM : Design"</a> .<br>For function, refer to <a href="#">MWI-54, "WARNING LAMPS/INDICATOR LAMPS : Seat Belt Warning Lamp"</a> . |

# SYSTEM

## < SYSTEM DESCRIPTION >

| Item                   | Reference   |
|------------------------|---|
| Rear seat belt warning | For layout, refer to <a href="#">SBC-8, "INFORMATION DISPLAY (COMBINATION METER) : Rear Seat Belt Warning".</a> |
|                        | For function, refer to <a href="#">SBC-7, "SEAT BELT WARNING LAMP CONTROL SYSTEM : System Description".</a>     |

## WARNING/INDICATOR/CHIME LIST : Warning Chime

INFOID:000000010926551

| Item              | Reference   |
|-------------------|---|
| Seat belt warning | Refer to <a href="#">WCS-17, "WARNING CHIME : Seat Belt Warning".</a> |

## SEAT BELT WARNING LAMP CONTROL SYSTEM

## < WIRING DIAGRAM >


## WIRING DIAGRAM

## SEAT BELT WARNING LAMP CONTROL SYSTEM

## Wiring Diagram

INFOID:0000000010926552

## SEAT BELT WARNING SYSTEM



2014/03/17

JRHW2021GB

# SEAT BELT WARNING LAMP CONTROL SYSTEM

## < WIRING DIAGRAM >

### SEAT BELT WARNING SYSTEM

| Connector No.  | Connector No.    | Signal Name [Specification] | Terminal Color Of Wire  | Signal Name [Specification] | Terminal Color Of Wire | Signal Name [Specification]          |
|----------------|------------------|-----------------------------|-------------------------|-----------------------------|------------------------|--------------------------------------|
| B1             | B3               | 1 Y                         | 1 SB                    | 1 V                         | 6 W                    | CRH(+)                               |
| Connector Name | WIRE TO WIRE     | 2 LAY                       | 2 V                     | 2 G                         | 7 P                    | REAR SEAT BELT BUCKLE SWITCH(CENTER) |
| Connector Name | THEOMW-CSI-S-TM4 | 6 V                         | 3 LAR                   | 3 P                         | 10 GR                  | REAR SEAT BELT BUCKLE SWITCH(RH)     |
| Connector Type | THEOMW-CSI-S-TM4 | 7 LAV                       | 4 V                     | 6 L                         | 11 BR                  | C-SATELLITE RH(+)                    |
|                |                  | 20 L                        | -                       | 5 GR                        | 12 Y                   | C-SATELLITE RH(-)                    |
|                |                  | 20 LAL                      | -[With diesel engine]   | 7 L                         | 17 SHIELD              | GND                                  |
|                |                  | 21 LAB                      | -[With gasoline engine] | 8 Y                         | 18 R                   | B-SATELLITE RH(+)                    |
|                |                  | 24 G                        | -                       | 9 BG                        | 19 G                   | B-SATELLITE RH(-)                    |
|                |                  | 25 BR                       | -                       | 9 W                         | 20 SB                  | SEAT BELT BUCKLE SWITCH(FRONT, RH)   |
|                |                  | 73 LAY                      | -                       | 10 LAY                      | 21 V                   | PRH(+)                               |
|                |                  | 74 R                        | -                       | 11 BR                       | 22 LG                  | PRH(+)                               |
|                |                  | 75 R                        | -                       | 12 Y                        |                        |                                      |
|                |                  | 84 L                        | -                       | 13 W                        |                        |                                      |
|                |                  | 85 L                        | -                       | 14 V                        |                        |                                      |
|                |                  | 92 LAR                      | -                       | 15 L                        |                        |                                      |
|                |                  | 93 LAL                      | -                       | 16 BR                       |                        |                                      |
|                |                  | 95 LABR                     | -                       | 17 Y                        |                        |                                      |
|                |                  | 97 L                        | -                       | 18 LAL                      |                        |                                      |
|                |                  | 98 Y                        | -                       | 18 SB                       |                        |                                      |
|                |                  | 99 LAY                      | -                       | 20 LG                       |                        |                                      |
|                |                  | 100 GR                      | -[With diesel engine]   | 21 G                        |                        |                                      |
|                |                  | 100 LAGR                    | -[With gasoline engine] | 22 V                        |                        |                                      |
|                |                  | 100                         |                         | 23 BR                       |                        |                                      |
|                |                  |                             |                         | 24 P                        |                        |                                      |
|                |                  |                             |                         | 25 L                        |                        |                                      |
|                |                  |                             |                         | 26 G                        |                        |                                      |
|                |                  |                             |                         | 29 SHIELD                   |                        |                                      |
|                |                  |                             |                         | 30 W                        |                        |                                      |
|                |                  |                             |                         | 31 B                        |                        |                                      |
|                |                  |                             |                         | 32 R                        |                        |                                      |

| Connector No. | Connector No. | Signal Name [Specification] | Terminal Color Of Wire | Signal Name [Specification] | Terminal Color Of Wire        | Signal Name [Specification] |
|---------------|---------------|-----------------------------|------------------------|-----------------------------|-------------------------------|-----------------------------|
| B8            |               | WIRE TO WIRE                | 1 V                    | B14                         |                               |                             |
|               |               | NST6MW-LS                   | 2 G                    | Connector No.               | -                             |                             |
|               |               |                             | 3 P                    | Connector Name              | AIR BAG DIAGNOSIS SENSOR UNIT |                             |
|               |               |                             | 6 L                    | Connector Type              | NE2F-Y-IV-EX                  |                             |
|               |               |                             | 7 L                    |                             |                               |                             |
|               |               |                             | 8 Y                    |                             |                               |                             |
|               |               |                             | 9 BG                   |                             |                               |                             |
|               |               |                             | 10 GR                  |                             |                               |                             |
|               |               |                             | 11 BR                  |                             |                               |                             |
|               |               |                             | 12 Y                   |                             |                               |                             |
|               |               |                             | 13 W                   |                             |                               |                             |
|               |               |                             | 14 V                   |                             |                               |                             |
|               |               |                             | 15 P                   |                             |                               |                             |
|               |               |                             | 16 P                   |                             |                               |                             |
|               |               |                             | 17 SHIELD              |                             |                               |                             |
|               |               |                             | 18 R                   |                             |                               |                             |
|               |               |                             | 19 G                   |                             |                               |                             |
|               |               |                             | 20 SB                  |                             |                               |                             |
|               |               |                             | 21 V                   |                             |                               |                             |
|               |               |                             | 22 LG                  |                             |                               |                             |
|               |               |                             | 23 R                   |                             |                               |                             |
|               |               |                             | 24 P                   |                             |                               |                             |
|               |               |                             | 25 L                   |                             |                               |                             |
|               |               |                             | 26 G                   |                             |                               |                             |
|               |               |                             | 27 SHIELD              |                             |                               |                             |
|               |               |                             | 28 R                   |                             |                               |                             |
|               |               |                             | 29 V                   |                             |                               |                             |
|               |               |                             | 30 P                   |                             |                               |                             |
|               |               |                             | 31 G                   |                             |                               |                             |
|               |               |                             | 32 Y                   |                             |                               |                             |

JRHWC2022GB

## SEAT BELT WARNING LAMP CONTROL SYSTEM

## < WIRING DIAGRAM >

## SEAT BELT WARNING SYSTEM

|                |                                    |    |    |                               |
|----------------|------------------------------------|----|----|-------------------------------|
| Connector No.  | B65                                | 31 | BR | IR/LWHEEL SENSOR POWER SUPPLY |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH (L/H) | 38 | B  | GROUND (VALVE)                |
| Connector Type | TH04FW-NH                          |    |    |                               |
| Connector No.  | M3                                 |    |    |                               |
| Connector Name | FUSE BLOCK (J/B)                   |    |    |                               |
| Connector Type | NS16FW-CS                          |    |    |                               |

| Terminal No. | Color Of WIRE | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | GR            | -                           |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10C          | LG            | -                           |
| 13C          | LA/G          | -                           |
| 14C          | R             | -                           |
| 15C          | L             | -                           |
| 16C          | LA/W          | -                           |
| 1C           | R             | -                           |
| 2C           | G             | -                           |
| 3C           | Y             | -                           |
| 4C           | LG            | -                           |
| 5C           | GR            | -                           |
| 6C           | LA/R          | -                           |
| 7C           | Y             | -                           |
| 8C           | GR            | [With ISS]                  |
| 8C           | LA/R          | - [Without ISS]             |
| 9C           | L             | -                           |

|                |                     |
|----------------|---------------------|
| Connector No.  | M4                  |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BDI8FW              |

|  |  |    |    |    |
|--|--|----|----|----|
|  |  | 14 | 15 | 16 |
|  |  | 3  | 4  | 5  |
|  |  | 6  | 7  | 8  |
|  |  | 9  | 10 | 11 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | GR            | -                           |

| Connector No.  | E56   | Terminal No. | Color Of Wire | Signal Name [Specification] |
|----------------|---|--------------|---------------|-----------------------------|
| Connector Name | ASA-AQUARIUS (AND ELECTRIC UNIT) (CONTROL UNIT) | 10C          | LG            | -                           |
| Connector Type | BTZ34F-BH2-BU2Z-RRH                             | 13C          | LA/G          | -                           |
|                |   | 14C          | R             | -                           |
|                |   | 15C          | L             | -                           |
|                |   | 16C          | LA/W          | -                           |
|                |   | 1C           | R             | -                           |
|                |   | 2C           | G             | -                           |
|                |   | 3C           | Y             | -                           |
|                |   | 4C           | LG            | -                           |
|                |   | 5C           | GR            | -                           |
|                |   | 6C           | LA/R          | -                           |
|                |   | 7C           | Y             | -                           |
|                |   | 8C           | W             | -                           |
|                |   | 9C           | W             | -                           |
|                |   | 10C          | W             | -                           |
|                |   | 11C          | W             | -                           |
|                |   | 12C          | W             | -                           |
|                |   | 13C          | W             | -                           |
|                |   | 14C          | W             | -                           |
|                |   | 15C          | W             | -                           |
|                |   | 16C          | W             | -                           |
|                |   | 17C          | W             | -                           |
|                |   | 18C          | W             | -                           |
|                |   | 19C          | W             | -                           |
|                |   | 20C          | W             | -                           |
|                |   | 21C          | W             | -                           |
|                |   | 22C          | W             | -                           |
|                |   | 23C          | W             | -                           |
|                |   | 24C          | W             | -                           |
|                |   | 25C          | W             | -                           |
|                |   | 26C          | W             | -                           |
|                |   | 27C          | W             | -                           |
|                |   | 28C          | W             | -                           |
|                |   | 29C          | W             | -                           |
|                |   | 30C          | W             | -                           |
|                |   | 31C          | W             | -                           |
|                |   | 32C          | W             | -                           |
|                |   | 33C          | W             | -                           |
|                |   | 34C          | W             | -                           |
|                |   | 35C          | W             | -                           |
|                |   | 36C          | W             | -                           |
|                |   | 37C          | W             | -                           |
|                |   | 38C          | W             | -                           |

|    |        |                                  |                |                     |
|----|--------|----------------------------------|----------------|---------------------|
| 5  | P      | BRAKE VACUUM SENSOR/POWER SUPPLY | Connector No.  | M4                  |
| 8  | Y      | FR RL WHEEL SENSOR/POWER SUPPLY  | Connector Name | DATA LINK CONNECTOR |
| 9  | Y      | HL decent control SWITCH SIGNAL  | Connector Type | ED16FW              |
| 12 | LG     | BRAKE VACUUM SENSOR/SIGNAL       |                |                     |
| 13 | S      | GROUND (MOTOR)                   |                |                     |
| 14 | BR     | CAHL                             |                |                     |
| 15 | BR     | VDC OFF/ SWITCH SIGNAL           |                |                     |
| 16 | R      | FR RL WHEEL SENSOR/POWER SUPPLY  |                |                     |
| 17 | Y      | RR RL WHEEL SENSOR/POWER SUPPLY  |                |                     |
| 18 | G      | FR RL WHEEL SENSOR/SIGNAL        |                |                     |
| 19 | W      | FR RL WHEEL SENSOR/POWER SUPPLY  |                |                     |
| 24 | SHIELD | BRAKE VACUUM SENSOR/GROUND       |                |                     |
| 25 | BR     | VALVE POWER SUPPLY               |                |                     |
| 26 | L      | CAN-H                            |                |                     |
| 28 | GR     | IGNITION POWER SUPPLY            |                |                     |
| 29 | LG     | RR RL WHEEL SENSOR/POWER SUPPLY  |                |                     |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | P             | -                           |
| 2            | B             | -                           |
| 3            | LG            | -                           |
| 4            | BL            | -                           |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | LA/LG         | -                           |
| 2            | LA/GR         | -                           |
| 3            | P             | -                           |
| 6            | L             | -                           |
| 7            | L             | -                           |
| 8            | GR            | - [For RHD models]          |
| 8            | SB            | - [For RHD models]          |
| 9            | LA/R          | -                           |
| 10           | LA/Y          | -                           |
| 11           | LA/BR         | -                           |
| 12           | W             | -                           |
| 13           | LA/V          | -                           |
| 14           | R             | -                           |
| 15           | P             | -                           |
| 16           | P             | -                           |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | LA/Y          | -                           |
| 2            | B             | -                           |

|                |   |
|----------------|---|
| Connector No.  | B23   |
| Connector Name | FRONT SEA BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | THROFW-NH                                     |


JRHW2023GB

# SEAT BELT WARNING LAMP CONTROL SYSTEM

## < WIRING DIAGRAM >

| SEAT BELT WARNING SYSTEM |          | M13                         |  | M34               |          | TH32FW-NH                                  |  | TH40FW-NH         |          | TH32FW-NH                              |  | TH40FW-NH         |          | TH32FW-NH                              |  | TH40FW-NH         |          | TH32FW-NH                                  |  | TH40FW-NH         |          |  |
|--------------------------|----------|-----------------------------|--|-------------------|----------|--|--|-------------------|----------|--|--|-------------------|----------|--|--|-------------------|----------|--|--|-------------------|----------|--|
| Terminal Color Of        | Wire No. | Signal Name [Specification] |  | Terminal Color Of | Wire No. | Signal Name [Specification]                |  | Terminal Color Of | Wire No. | Signal Name [Specification]            |  | Terminal Color Of | Wire No. | Signal Name [Specification]            |  | Terminal Color Of | Wire No. | Signal Name [Specification]                |  | Terminal Color Of | Wire No. | Signal Name [Specification]                |
| 3                        | LG       | WIRE TO WIRE                |  | 1                 | B        | GROUND                                     |  | 41                | LG       | MANUAL MODE SIGNAL                     |  | 41                | L        | CANH                                   |  | 25                | LG       | INFLATOR AS-                               |  | 25                | LG       | INFLATOR AS-                               |
| 4                        | B        | -                           |  | 2                 | V        | MANUAL MODE SHIFT UP SIGNAL                |  | 42                | P        | MANUAL MODE SHIFT DOWN SIGNAL          |  | 42                | P        | CANL                                   |  | 26                | SB       | AS1(-)                                     |  | 26                | SB       | AS1(-)                                     |
| 5                        | B        | -                           |  | 3                 | SB       | MANUAL MODE CONTROL SIGNAL                 |  | 43                | W        | ILLUMINATION CONTROL SIGNAL            |  | 43                | B        | AS1(+)                                 |  | 27                | B        | AS1(+)                                     |  | 27                | B        | AS1(+)                                     |
| 6                        | L        | -                           |  | 4                 | BR       | AMBENT SENSOR SIGNAL                       |  | 44                | LA/B     | FUEL LEVEL SENSOR GROUND               |  | 44                | LA/B     | DR1(-)                                 |  | 28                | Y        | DR1(+)                                     |  | 28                | Y        | DR1(+)                                     |
| 8                        | Y        | -                           |  | 5                 | L        | METER CONTROL SWITCH GROUND                |  | 45                | LA/G     | BATTERY POWER SUPPLY                   |  | 45                | LA/G     | ECGS(+) (ECGS(-))                      |  | 29                | Y        | ECGS(+) (ECGS(-))                          |  | 29                | Y        | ECGS(+) (ECGS(-))                          |
| 11                       | SB       | -                           |  | 6                 | Y        | TRIP RESET SWITCH SIGNAL                   |  | 46                | LA/R     | IGNITION SIGNAL (WITHOUT ESSI)         |  | 46                | V        | IGNITION SIGNAL (WITH ESSI)            |  | 30                | Y        | IGNITION SIGNAL (WITH ESSI)                |  | 30                | Y        | IGNITION SIGNAL (WITH ESSI)                |
| 14                       | P        | -                           |  | 7                 | LG       | AMBIENT SENSOR GROUND                      |  | 47                | SB       | AV COMMUNICATION SIGNAL (H)            |  | 47                | SB       | AV COMMUNICATION SIGNAL (H)            |  | 31                | Y        | AV COMMUNICATION SIGNAL (L)                |  | 31                | Y        | AV COMMUNICATION SIGNAL (L)                |
| 15                       | BR       | -                           |  | 8                 | BG       | STEERING SWITCH SIGNAL A                   |  | 48                | LG       | AV COMMUNICATION SIGNAL (L)            |  | 48                | LG       | ECGS(+) (ECGS(-))                      |  | 32                | Y        | STEERING SWITCH SIGNAL A                   |  | 32                | Y        | STEERING SWITCH SIGNAL A                   |
| 16                       | W        | -                           |  | 9                 | W        | STEERING SWITCH SIGNAL B                   |  | 49                | Y        | STEERING SWITCH SIGNAL B               |  | 49                | Y        | STEERING SWITCH SIGNAL B               |  | 33                | Y        | STEERING SWITCH SIGNAL B                   |  | 33                | Y        | STEERING SWITCH SIGNAL B                   |
|                          |          |                             |  | 10                | Y        | BRAKE FLUID LEVEL SWITCH SIGNAL            |  | 50                | BG       | OIL LEVEL SENSOR GROUND                |  | 50                | BG       | OIL LEVEL SENSOR GROUND                |  | 34                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |  | 34                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |
|                          |          |                             |  | 11                | R        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |  | 51                | LA/L     | FUEL LEVEL SENSOR SIGNAL               |  | 51                | LA/L     | FUEL LEVEL SENSOR SIGNAL               |  | 35                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |  | 35                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |
|                          |          |                             |  | 12                | SB       | MANUAL MODE SIGNAL                         |  | 52                | B        | GROUND                                 |  | 52                | B        | GROUND                                 |  | 36                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |  | 36                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |
|                          |          |                             |  | 13                | LG       | MANUAL MODE SIGNAL                         |  | 31                | SB       | NONMANUAL MODE SIGNAL                  |  | 31                | SB       | NONMANUAL MODE SIGNAL                  |  | 37                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |  | 37                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |
|                          |          |                             |  | 14                | V        | MANUAL MODE SHIFT UP SIGNAL                |  | 32                | BG       | MANUAL MODE SHIFT UP SIGNAL            |  | 32                | BG       | MANUAL MODE SHIFT UP SIGNAL            |  | 38                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |  | 38                | Y        | SEATBELT BUCKLE SWITCH SIGNAL (NOISE SIDE) |
|                          |          |                             |  | 15                | SB       | MANUAL MODE SHIFT DOWN SIGNAL              |  | 33                | BR       | MANUAL MODE SHIFT DOWN SIGNAL          |  | 33                | BR       | MANUAL MODE SHIFT DOWN SIGNAL          |  | 39                | W        | VEHICLE SPEED SIGNAL (PULSE)               |  | 39                | W        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 16                | Y        | -  |  | 36                | GR       | ILLUMINATION CONTROL SWITCH SIGNAL (+) |  | 36                | GR       | ILLUMINATION CONTROL SWITCH SIGNAL (+) |  | 40                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 40                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 17                | LA/R     | -  |  | 37                | V        | ILLUMINATION CONTROL SWITCH SIGNAL (-) |  | 37                | V        | ILLUMINATION CONTROL SWITCH SIGNAL (-) |  | 41                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 41                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 18                | LA/L     | -  |  | 38                | G        | VEHICLE SPEED SIGNAL (PULSE)           |  | 38                | G        | VEHICLE SPEED SIGNAL (PULSE)           |  | 42                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 42                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 20                | BG       | -  |  | 39                | W        | VEHICLE SPEED SIGNAL (PULSE)           |  | 39                | W        | VEHICLE SPEED SIGNAL (PULSE)           |  | 43                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 43                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 21                | LA/B     | -  |  |                   |          |  |  |                   |          |  |  | 44                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 44                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 22                | GR       | -  |  |                   |          |  |  |                   |          |  |  | 45                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 45                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 23                | GR       | -  |  |                   |          |  |  |                   |          |  |  | 46                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 46                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 24                | P        | -  |  |                   |          |  |  |                   |          |  |  | 47                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 47                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 25                | BR       | -  |  |                   |          |  |  |                   |          |  |  | 48                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 48                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 73                | Y        | -  |  |                   |          |  |  |                   |          |  |  | 49                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 49                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 74                | R        | -  |  |                   |          |  |  |                   |          |  |  | 50                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 50                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 75                | R        | -  |  |                   |          |  |  |                   |          |  |  | 51                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 51                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 84                | L        | -  |  |                   |          |  |  |                   |          |  |  | 52                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 52                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 85                | L        | -  |  |                   |          |  |  |                   |          |  |  | 53                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 53                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 92                | LA/W     | -  |  |                   |          |  |  |                   |          |  |  | 54                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 54                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 93                | LA/Y     | -  |  |                   |          |  |  |                   |          |  |  | 55                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 55                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 95                | SB       | -  |  |                   |          |  |  |                   |          |  |  | 56                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 56                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 97                | BG       | -  |  |                   |          |  |  |                   |          |  |  | 57                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 57                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 98                | Y        | -  |  |                   |          |  |  |                   |          |  |  | 58                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 58                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 99                | W        | -  |  |                   |          |  |  |                   |          |  |  | 59                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 59                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 100               | LA/R     | -  |  |                   |          |  |  |                   |          |  |  | 60                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 60                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 31                | B        | -  |  |                   |          |  |  |                   |          |  |  | 61                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 61                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |
|                          |          |                             |  | 32                | R        | -  |  |                   |          |  |  |                   |          |  |  | 62                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |  | 62                | Y        | VEHICLE SPEED SIGNAL (PULSE)               |

# SEAT BELT WARNING LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

| SEAT BELT WARNING SYSTEM |             |
|--------------------------|-------------|
| 37                       | R           |
| 39                       | SHIELD      |
| 41                       | W           |
| 45                       | P           |
| 46                       | L           |
| 47                       | GR          |
| 48                       | W           |
| 49                       | BG          |
| 50                       | R           |
| ACTIVE                   |             |
|                          | GND         |
|                          | EC(S(+))    |
|                          | CANL        |
|                          | CANH        |
|                          | A/B ON IND  |
|                          | A/B OFF IND |
|                          | K-LINE      |
|                          | IGN         |

JRHWC2025GB

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

#### Work Flow

INFOID:0000000010926553

#### OVERALL SEQUENCE



#### DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

## 1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

## 2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

## 3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

## 4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

### NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44, "Intermittent Incident"](#).

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

## DIAGNOSIS AND REPAIR WORK FLOW

### < BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44, "Intermittent Incident"](#).

### 8.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9.FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

# SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

#### Diagnosis Procedure

INFOID:0000000010926554

##### 1. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

1. Disconnect seat belt buckle switch (passenger side) connector.
2. Check continuity between seat belt buckle switch (passenger side) and ground.

| Seat belt buckle switch (passenger side) |          | Ground | Continuity |
|--|----------|--------|------------|
| Connector                                | Terminal |        | Existed    |
| B23                                      | 2        |        |            |

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace harness.

##### 2. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check seat belt buckle switch (passenger side).

Refer to [SBC-19. "Component Inspection"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle (passenger side). Refer to [SB-14. "SEAT BELT BUCKLE : Removal and Installation"](#).

SBC

#### Component Inspection

INFOID:0000000010926555

##### 1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check continuity of seat belt buckle (passenger side).

| Seat belt buckle switch (passenger side) |   | Condition                                     | Continuity  |
|--|---|---|-------------|
| Terminal                                 |   |   | Existed     |
| 1  | 2 | When passenger side seat belt is not fastened | Existed     |
|  |   | When passenger side seat belt is fastened     | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle (passenger side). Refer to [SB-14. "SEAT BELT BUCKLE : Removal and Installation"](#).

# REAR SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## REAR SEAT BELT BUCKLE SWITCH

### Diagnosis Procedure

INFOID:0000000010926556

#### 1. CHECK REAR SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

1. Disconnect rear seat belt buckle switch connector.
2. Check the continuity between rear seat belt buckle switch harness connector and ground.

| Rear seat belt buckle switch |          |   | Ground | Continuity |
|------------------------------|----------|---|--------|------------|
| Connector                    | Terminal |   |        |            |
| LH                           | B65      | 2 | Ground | Existed    |
| Center                       | B64      | 4 |        |            |
| RH                           |          | 2 |        |            |

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace harness.

#### 2. CHECK REAR SEAT BELT BUCKLE SWITCH

Check rear seat belt buckle switch.

Refer to [SBC-20, "Component Inspection"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear seat belt buckle. Refer to [SB-19, "SEAT BELT BUCKLE : Removal and Installation"](#).

### Component Inspection

INFOID:0000000010926557

#### 1. CHECK REAR SEAT BELT BUCKLE SWITCH

Check continuity between rear seat belt buckle switch connector.

| Rear seat belt buckle switch |          |   |   | Condition                             | Continuity  |
|------------------------------|----------|---|---|---------------------------------------|-------------|
| Connector                    | Terminal |   |   |                                       |             |
| LH                           | B65      | 1 | 2 | Rear seat belt (LH) is unfastened     | Existed     |
|                              |          |   |   | Rear seat belt (LH) is fastened       | Not existed |
| Center                       | B64      | 3 | 4 | Rear seat belt (center) is unfastened | Existed     |
|                              |          |   |   | Rear seat belt (center) is fastened   | Not existed |
| RH                           |          | 1 | 2 | Rear seat belt (RH) is unfastened     | Existed     |
|                              |          |   |   | Rear seat belt (RH) is fastened       | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear seat belt buckle. Refer to [SB-19, "SEAT BELT BUCKLE : Removal and Installation"](#).

# FRONT SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### FRONT SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

#### Diagnosis Procedure

INFOID:0000000010926558

##### 1. CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" mode of "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-18, "DTC Index"](#).  
NO >> GO TO 2.

##### 2. CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" mode of "METER/M&A" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-105, "DTC Index"](#).  
NO >> GO TO 3.

##### 3. CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUIT

Check combination meter power supply and ground circuit. Refer to [MWI-129, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.  
NO >> Repair or replace the malfunctioning parts.

##### 4. CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 5.  
NO-1 >> Damage: Replace malfunctioning parts.  
NO-2 >> Disconnection or looseness: Securely lock the connector.

##### 5. CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

YES-1 >> GO TO 6. (driver side)  
YES-2 >> GO TO 7. (passenger side)  
NO >> Replace malfunctioning parts.

##### 6. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check the seat belt buckle switch. Refer to [WCS-55, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 9.  
NO >> Repair or replace the malfunctioning parts.

##### 7. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check the seat belt buckle switch. Refer to [SBC-19, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 8.  
NO >> Repair or replace the malfunctioning parts.

##### 8. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit.

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 9.

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

# FRONT SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

## 9. REPLACE COMBINATION METER

Replace combination meter. Refer to [MWI-151, "Removal and Installation".](#)

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 10.

## 10. CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident".](#)

>> INSPECTION END

# FRONT SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

## FRONT SEAT BELT WARNING LAMP DOES NOT TURN OFF

### Diagnosis Procedure

INFOID:0000000010926559

#### 1. CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" mode of "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-18, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" mode of "METER/M&A" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-105, "DTC Index"](#).  
NO >> GO TO 3.

#### 3. CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 4.  
NO-1 >> Damage: Replace malfunctioning parts.  
NO-2 >> Disconnection or looseness: Securely lock the connector.

#### 4. CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

YES-1 >> GO TO 5. (driver side)  
YES-2 >> GO TO 6. (passenger side)  
NO >> Replace malfunctioning parts.

#### 5. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check the seat belt buckle switch. Refer to [WCS-55, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 8.  
NO >> Repair or replace the malfunctioning parts.

#### 6. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check the seat belt buckle switch. Refer to [SBC-19, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 7.  
NO >> Repair or replace the malfunctioning parts.

#### 7. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit.

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 8.

#### 8. REPLACE COMBINATION METER

Replace combination meter. Refer to [MWI-151, "Removal and Installation"](#).

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 9.

#### 9. INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

## **FRONT SEAT BELT WARNING LAMP DOES NOT TURN OFF**

**< SYMPTOM DIAGNOSIS >**

---

**>> INSPECTION END**

# REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

## REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

### Diagnosis Procedure

INFOID:0000000010926560

#### 1. CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" mode of "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-18, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" mode of "METER/M&A" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-105, "DTC Index"](#).  
NO >> GO TO 3.

#### 3. CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUIT

Check combination meter power supply and ground circuit. Refer to [MWI-129, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.  
NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 5.  
NO-1 >> Damage: Replace malfunctioning parts.  
NO-2 >> Disconnection or looseness: Securely lock the connector.

#### 5. CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

YES >> GO TO 6.  
NO >> Replace malfunctioning parts.

#### 6. CHECK REAR SEAT BELT BUCKLE SWITCH

Check the applicable rear seat belt buckle switch. Refer to [SBC-20, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 7.  
NO >> Replace the applicable rear seat belt buckle switch.

#### 7. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit.

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 8.

#### 8. REPLACE COMBINATION METER

Replace combination meter. Refer to [MWI-151, "Removal and Installation"](#).

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 9.

#### 9. CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

## **REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE**

**< SYMPTOM DIAGNOSIS >**

---

**>> INSPECTION END**

# REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

## REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF

### Diagnosis Procedure

INFOID:0000000010926561

#### 1. CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" mode of "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-18, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" mode of "METER/M&A" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-105, "DTC Index"](#).  
NO >> GO TO 3.

#### 3. CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 4.  
NO-1 >> Damage: Replace malfunctioning parts.  
NO-2 >> Disconnection or looseness: Securely lock the connector.

#### 4. CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

YES >> GO TO 5.  
NO >> Replace malfunctioning parts.

#### 5. CHECK REAR SEAT BELT BUCKLE SWITCH

Check the applicable rear seat belt buckle switch. Refer to [SBC-20, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 6.  
NO >> Replace seat belt buckle switch.

#### 6. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit.

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 7.

#### 7. REPLACE COMBINATION METER

Replace combination meter. Refer to [MWI-151, "Removal and Installation"](#).

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 8.

#### 8. INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> INSPECTION END

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P