

STR

SECTION STR
STARTING SYSTEM

CONTENTS

PRECAUTION	2	B TERMINAL CIRCUIT	21
PRECAUTIONS	2	Diagnosis Procedure	21
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2		
Precaution for Stop/Start System Service	2	S TERMINAL CIRCUIT	23
Precautions for Removing Battery Terminal	2	Diagnosis Procedure	23
PREPARATION	4		
PREPARATION	4	SYMPTOM DIAGNOSIS	25
Commercial Service Tools	4		
SYSTEM DESCRIPTION	5	STARTING SYSTEM	25
COMPONENT PARTS	5	Symptom Table	25
Component Parts Location	5	REMOVAL AND INSTALLATION	26
Starter motor	8		
SYSTEM	9	STARTER MOTOR	26
STARTING SYSTEM	9		
STARTING SYSTEM : System Description	9	MR20DD	26
WIRING DIAGRAM	11	MR20DD : Exploded View	26
STARTING SYSTEM	11	MR20DD : Removal and Installation	27
Wiring Diagram	11	MR20DD : Inspection	28
BASIC INSPECTION	19	QR25DE	31
DIAGNOSIS AND REPAIR WORK FLOW	19	QR25DE : Exploded View	31
Work Flow	19	QR25DE : Removal and Installation	34
DTC/CIRCUIT DIAGNOSIS	21	QR25DE : Inspection	35
		R9M	39
		R9M : Exploded View	39
		R9M : Removal and Installation	39
		SERVICE DATA AND SPECIFICATIONS (SDS)	42
		SERVICE DATA AND SPECIFICATIONS (SDS)	42
		Starter Motor	42

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010957639

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Stop/Start System Service

INFOID:0000000010957657


CAUTION:

When performing an inspection and its related work with the engine at idle, always turn the stop/start OFF switch ON or open the hood to release the stop/start system.

Precautions for Removing Battery Terminal

INFOID:0000000010957641

- With the adoption of Auto ACC function, ACC power is automatically supplied by operating the intelligent key or remote keyless entry or by opening/closing the driver side door. In addition, ACC power is supplied even after the ignition switch is turned to the OFF position, i.e. ACC power is supplied for a certain fixed time.
- When disconnecting the 12V battery terminal, turn off the ACC power before disconnecting the 12V battery terminal, observing "How to disconnect 12V battery terminal" described below.



SEF289H

NOTE:

Some ECUs operate for a certain fixed time even after ignition switch is turned OFF and ignition power supply is stopped. If the battery terminal is disconnected before ECU stops, accidental DTC detection or ECU data damage may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

PRECAUTIONS

< PRECAUTION >

HOW TO DISCONNECT 12V BATTERY TERMINAL

Disconnect 12V battery terminal according to Instruction 1 or Instruction 2 described below.
For vehicles parked by ignition switch OFF, refer to Instruction 2.

INSTRUCTION 1

1. Open the hood.
2. Turn key switch to the OFF position with the driver side door opened.
3. Get out of the vehicle and close the driver side door.
4. Wait at least 3 minutes. For vehicle with the engine listed below, remove the battery terminal after a lapse of the specified time.

D4D engine	: 20 minutes
HRA2DDT	: 12 minutes
K9K engine	: 4 minutes
M9R engine	: 4 minutes
R9M engine	: 4 minutes
V9X engine	: 4 minutes

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

5. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

INSTRUCTION 2 (FOR VEHICLES PARKED BY IGNITION SWITCH OFF)

1. Unlock the door with intelligent key or remote keyless entry.

NOTE:

At this moment, ACC power is supplied.

2. Open the driver side door.
3. Open the hood.
4. Close the driver side door.
5. Wait at least 3 minutes.

CAUTION:

While waiting, never operate the vehicle such as locking, opening, and closing doors. Violation of this caution results in the activation of ACC power supply according to the Auto ACC function.

6. Remove 12V battery terminal.

CAUTION:

After installing 12V battery, always check self-diagnosis results of all ECUs and erase DTC.

PREPARATION

<PREPARATION>

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:0000000010957642

Tool name	Description
Power tool  PIIB1407E	Loosening bolts, nuts and screws

COMPONENT PARTS

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION


COMPONENT PARTS

Component Parts Location

INFOID:0000000010957652

STR

QR ENGINE



No.	Component	Function
①	Starter motor	Refer to STR-8, "Starter motor".
②	Transmission range switch	Transmission range switch supplies power to the starter relay inside IPDM E/R when the selector lever is shifted to the "P" or "N" position.


COMPONENT PARTS

< SYSTEM DESCRIPTION >

No.	Component	Function
③	IPDM E/R	CPU inside IPDM E/R controls starter relay. Refer to PCS-5, "Component Parts Location" for detailed installation location.
④	BCM	BCM controls starter control relay. Refer to BCS-6, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
⑤	Starter control relay	Power is supplied to the starter control relay with BCM control.

EXCEPT FOR QR ENGINE

For LHD models



Ⓐ Front side of IPDM E/R

⬅ : Vehicle front


JMBIA4649ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

No.	Component	Function
①	Starter motor	Refer to STR-8, "Starter motor".
②	Transmission range switch (For CVT models)	Transmission range switch supplies power to the starter relay inside IPDM E/R when the selector lever is shifted to the "P" or "N" position.
③	IPDM E/R	CPU inside IPDM E/R controls starter relay. Refer to PCS-5, "Component Parts Location" for detailed installation location.
④	BCM	BCM controls starter control relay. Refer to BCS-6, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
⑤	Starter control relay	Power is supplied to the starter control relay with BCM control.

For RHD models



A Front side of IPDM E/R

↖ : Vehicle front

COMPONENT PARTS


< SYSTEM DESCRIPTION >

No.	Component	Function
①	Starter motor	Refer to STR-8, "Starter motor".
②	Transmission range switch (For CVT models)	Transmission range switch supplies power to the starter relay inside IPDM E/R when the selector lever is shifted to the "P" or "N" position.
③	IPDM E/R	CPU inside IPDM E/R controls starter relay. Refer to PCS-5, "Component Parts Location" for detailed installation location.
④	BCM	BCM controls starter control relay. Refer to BCS-6, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
⑤	Starter control relay	Power is supplied to the starter control relay with BCM control.

Starter motor

INFOID:000000010957644

The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.



SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM

STARTING SYSTEM


STARTING SYSTEM : System Description

INFOID:000000010957645


STR

SYSTEM DIAGRAM

CVT Models



MT Models



NOTE:

For models without stop/start system, starter motor "B" terminal is connect to battery directly.

SYSTEM DESCRIPTION

CVT Models

- "B" terminal is constantly supplied with battery power*.
- When selector lever is P or N, power is supplied to starter control relay by transmission range switch.
- When starter operating condition is satisfied, IPDM E/R turns starter relay ON by starter relay control signal.
- When engine cranking condition is satisfied, BCM turns starter control relay ON by starter control relay control signal.
- Then battery power is supplied to starter motor ("S" terminal) through starter control relay and starter relay.

M/T Models

- "B" terminal is constantly supplied with battery power*.
- When starter operating condition is satisfied, IPDM E/R turns starter relay ON by starter relay control signal.

SYSTEM

< SYSTEM DESCRIPTION >


- When engine cranking condition is satisfied, BCM turns starter control relay ON by starter control relay control signal.
- Then battery power is supplied to starter motor (“S” terminal) through starter relay and starter control relay.
*: For models with stop/start system, starter motor “B” terminal receives the battery power via engine restart bypass relay.

STARTING SYSTEM

< WIRING DIAGRAM >


WIRING DIAGRAM STARTING SYSTEM

Wiring Diagram



STARTING SYSTEM

< WIRING DIAGRAM >



JRBWC7642GB

STARTING SYSTEM

< WIRING DIAGRAM >

STARTING SYSTEM

Connector No.	B11	Connector Name	WIRE TO WIRE	Terminal Color Of No.	9	BR	- (With MR20 engine)
Connector No.	B106	Connector Name	FUSE BLOCK (JB)	10	BR	-	
Connector Type	TH04MDGY-C516-TM4	Connector Type	NS06FW-CS	11	Y	- (With QR25 engine)	
				12	L	- (With QR25 engine)	
				13	BR	- (With MR20 or QR25 engine)	
				14	R	- (With R9M engine)	
				15	L	-	
				16	SB	-	
Connector No.	E11	Connector Name	FROM ER (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Terminal Color Of No.	19	V	Signal Name (Specification)
Connector Type	ER24050408R	Connector Type	ER24050408R	20	R	-	
				21	LG	-	
				22	Y	-	
				23	B	-	
				24	W	-	
Connector No.	E8	Connector Name	WIRE TO WIRE	Terminal Color Of No.	1	L	Signal Name (Specification)
Connector Type	NS06MW-C	Connector Type	NS06MW-C	2	P	-	
				3	Q	-	
				4	P	-	
				5	G	-	
Connector No.	E7	Connector Name	WIRE TO WIRE	Terminal Color Of No.	1	12	Signal Name (Specification)
Connector Type	NS16UBR-CS	Connector Type	NS16UBR-CS	2	3	4	
				3	5	6	
				4	7	8	
				5	11	12	
				6	13	14	
				7	15	16	
Connector No.	E10	Connector Name	FROM ER (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Terminal Color Of No.	9	8	Signal Name (Specification)
Connector Type	TR24FGY-NH	Connector Type	TR24FGY-NH	10	7	4	
				11	16	12	
				12	17	13	
				13	18	14	
				14	19	15	
				15	20	21	
				16	22	23	
				17	24	25	
Connector No.	E12	Connector Name	WIRE TO WIRE	Terminal Color Of No.	1	12	Signal Name (Specification)
Connector Type	NS16FGY-CS	Connector Type	NS16FGY-CS	2	3	4	
				3	5	6	
				4	7	8	
				5	11	12	
				6	13	14	
				7	15	16	
				8	17	18	
				9	19	20	
				10	21	22	
				11	23	24	
				12	25	26	
Connector No.		Connector Name	WIRE TO WIRE	Terminal Color Of No.	1	2	Signal Name (Specification)
Connector Type				2	3	4	
				3	5	6	
				4	7	8	
				5	11	12	
				6	13	14	
				7	15	16	
				8	17	18	
				9	19	20	
				10	21	22	
				11	23	24	
				12	25	26	
Connector No.		Connector Name	WIRE TO WIRE	Terminal Color Of No.	1	2	Signal Name (Specification)
Connector Type				2	3	4	
				3	5	6	
				4	7	8	
				5	11	12	
				6	13	14	
				7	15	16	
				8	17	18	
				9	19	20	
				10	21	22	
				11	23	24	
				12	25	26	

JRBWC7643GB

A

STR

C

D

T

G

W

—

—

X

—

Z

—

Z

O

P

STR-13

STARTING SYSTEM

< WIRING DIAGRAM >

STARTING SYSTEM

36	Y	-	116	GR	Brake Pedal Position Switch	6	G	Brake Pedal Position Switch (With CANH)
37	B	-	117	W	PIN SIGNAL	8	B	
38	GR	-	118	SB	SENSOR/POWER SUPPLY	9	L	FUEL/HEATER AND WATER/FUEL LEVEL SENSOR
39	BR	-	119	Y	ACCELERATOR PEDAL POSITION SENSOR 2	10	L	ACCELERATOR PEDAL POSITION SENSOR 2
45	L	-	120	LG	SENSOR GROUND	11	V	ACCELERATOR PEDAL POSITION SENSOR 2
46	P	-	121	BR	POWER SUPPLY FOR ECM	12	P	SENSE GROUND (CANH) (CANH)
47	W	-	122	V	SENSOR POWER SUPPLY	16	BG	STOP LAMP SWITCH (With CANH)
48	R	-	123	BR	ECM GROUND	16	R	BREAK POSITION SWITCH (With CANH)
49	W	-	124	W	ACCELERATOR PEDAL POSITION SENSOR 1	17	LG	ASCD STEERING SWITCH
50	R	-	125	LG	SENSOR GROUND	18	G	ASCD STEERING SWITCH
51	Y	-	126	GR	ACCELERATOR PEDAL POSITION SENSOR 1	19	BR	SENSOR GROUND (ASCD STEERING SWITCH)
52	W	-	127	R	SENSOR GROUND	20	BR	TRUE PUMP CONTROL MODULE (COMMAND)
53	LG	-	128	BR	ECM GROUND	22	G	TRUE PUMP CONTROL MODULE (DIAGNOSIS)
54	Y	-				23	V	SPEED LIMITER MAIN SWITCH
55	LG	-				24	R	CLUTCH POSITION SWITCH
56	W	-				27	V	CLUTCH INTERLOCK SWITCH
57	LG	-				30	BR	ASCD MAIN SWITCH
58	W	-				31	P	CANL
59	R	-				32	L	CANH
60	Y	-						
61	LG	-						
62	LG	-						
63	LG	-						
64	Y	-						
65	LG	-						
66	P	-						
67	LG	-						
68	BR	-						
69	LG	-						
70	LG	-						
71	G	-						
72	V	-						
73	BR	-						
74	LG	-						
75	LG	-						
76	LG	-						
77	LG	-						
78	LG	-						
79	LG	-						
80	LG	-						
81	LG	-						
82	LG	-						
83	LG	-						
84	LG	-						
85	LG	-						
86	LG	-						
87	LG	-						
88	LG	-						
89	LG	-						
90	LG	-						
91	LG	-						
92	LG	-						
93	LG	-						
94	LG	-						
95	LG	-						
96	LG	-						
97	LG	-						
98	LG	-						
99	LG	-						
100	LG	-						
101	LG	-						
102	LG	-						
103	LG	-						
104	LG	-						
105	LG	-						
106	LG	-						
107	LG	-						
108	LG	-						
109	LG	-						
110	LG	-						
111	LG	-						
112	LG	-						
113	LG	-						
114	LG	-						
115	LG	-						
116	LG	-						
117	LG	-						
118	LG	-						
119	LG	-						
120	LG	-						
121	LG	-						
122	LG	-						
123	LG	-						
124	LG	-						
125	LG	-						
126	LG	-						
127	LG	-						
128	LG	-						
129	LG	-						
130	LG	-						
131	LG	-						
132	LG	-						
133	LG	-						
134	LG	-						
135	LG	-						
136	LG	-						
137	LG	-						
138	LG	-						
139	LG	-						
140	LG	-						
141	LG	-						
142	LG	-						
143	LG	-						
144	LG	-						
145	LG	-						
146	LG	-						
147	LG	-						
148	LG	-						
149	LG	-						
150	LG	-						
151	LG	-						
152	LG	-						
153	LG	-						
154	LG	-						
155	LG	-						
156	LG	-						
157	LG	-						
158	LG	-						
159	LG	-						
160	LG	-						
161	LG	-						
162	LG	-						
163	LG	-						
164	LG	-						
165	LG	-						
166	LG	-						
167	LG	-						
168	LG	-						
169	LG	-						
170	LG	-						
171	LG	-						
172	LG	-						
173	LG	-						
174	LG	-						
175	LG	-						
176	LG	-						
177	LG	-						
178	LG	-						
179	LG	-						
180	LG	-						
181	LG	-						
182	LG	-						
183	LG	-						
184	LG	-						
185	LG	-						
186	LG	-						
187	LG	-						
188	LG	-						
189	LG	-						
190	LG	-						
191	LG	-						
192	LG	-						
193	LG	-						
194	LG	-						
195	LG	-						
196	LG	-						
197	LG	-						
198	LG	-						
199	LG	-						
200	LG	-						
201	LG	-						
202	LG	-						
203	LG	-						
204	LG	-						
205	LG	-						
206	LG	-						
207	LG	-						
208	LG	-						
209	LG	-						
210	LG	-						
211	LG	-						
212	LG	-						
213	LG	-						
214	LG	-						
215	LG	-						
216	LG	-						
217	LG	-						
218	LG	-						
219	LG	-						
220	LG	-						
221	LG	-						
222	LG	-						
223	LG	-						
224	LG	-						
225	LG	-						
226	LG	-						
227	LG	-						
228	LG	-						
229	LG	-						
230	LG	-						
231	LG	-						
232	LG	-						
233	LG	-						
234	LG	-						
235	LG	-						
236	LG	-						
237	LG	-						
238	LG	-						
239	LG	-						
240	LG	-						
241	LG	-						
242	LG	-						
243	LG	-						
244	LG	-						
245	LG	-						
246	LG	-						
247	LG	-						
248	LG	-						
249	LG	-						
250	LG	-						
251	LG	-						
252	LG	-						
253	LG	-						
254	LG	-						
255	LG	-						
256	LG	-						
257	LG	-						
258	LG	-						
259	LG	-						
260	LG	-						
261	LG	-						
262	LG	-						
263	LG	-						
264	LG	-						
265	LG	-						
266	LG	-						
267	LG	-						
268	LG	-						
269	LG	-						
270	LG	-						
271	LG	-						
272	LG	-						
273	LG	-						
274	LG	-						
275	LG	-						
276	LG	-						
277	LG	-						
278	LG	-						
279	LG	-						
280	LG	-						
281	LG	-						
282	LG	-						
283	LG	-						
284	LG	-						
285	LG	-						
286	LG	-						
287	LG	-						
288	LG	-						
289	LG	-						
290	LG	-						
291	LG	-						

STARTING SYSTEM

< WIRING DIAGRAM >

STARTING SYSTEM

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
23	Y	-	48	SB	-
24	SB	-	51	P	-
25	G	-	52	L	-
26	B	-	53	W	-
27	P	-	54	Y	-
28	R	-	55	BR	-
29	LG	-	56	P	-
30	P	-	57	B	-
92	BR	-	58	L	-
93	GR	-	59	W	-
94	R	-	60	G	-
95	L	-	61	BR	-
97	LG	-	62	V	-
			63	BR	-
			64	GR	-
			65	LG	-
			66	BG	-
			67	L	-
			68	R	-
			71	Y	-
			72	L	-
			73	R	-
			76	L	-
			77	V	-
			78	LG	-
			79	SHIELD	-
			80	GR	-
			82	Y	-
			83	SB	-
			84	L	-
		- (Without ISS)	85	G	-
		- (With ISS)	86	Y	-
			87	B	-
			88	B	-
			91	R	-
			10	W	-
			20	W	-
			21	B	-
			22	SHIELD	-
			31	Y	-
			32	W	-
			33	SB	-
			34	LG	-
			35	BG	-
			36	LG	-
			37	V	-
			38	G	-
			39	BR	-
			40	L	-
			41	P	-
			47	GR	-

STR-15

JRBWC7645GB

A

STR

C

D

E

G

H

I

K

M

Z

O

P

STARTING SYSTEM

< WIRING DIAGRAM >

STARTING SYSTEM

Connector No.	Color	Signal Name [Specification]	Connector No.	Color	Signal Name [Specification]
1	Black	-	1	Black	STARTER MOTOR
2	Grey	-	2	Grey	24340 ER024
3	White	-	3	White	-
4	Yellow	-	4	Yellow	-
5	Green	-	5	Green	-
6	Blue	-	6	Blue	-
7	Red	-	7	Red	-
8	Grey	-	8	Grey	-

Terminal No.		Signal Name [Specification]		Terminal No.		Signal Name [Specification]	
2	No.	Color Of Wire	G	1	No.	Color Of Wire	G
				2			

	CONNECTOR NAME STARTER MOTOR CONNECTOR TYPE 22340 JAV06A	CONNECTOR NAME STARTER CONTROL RELAY CONNECTOR TYPE INS20FL-M2-C	CONNECTOR NAME F69 CONNECTOR TYPE INS20FL-M2-C	CONNECTOR NAME F74 CONNECTOR TYPE INS20FL-M2-C
				

Terminal	Color Of	Signal Name [Specification]
1		
2		
3		
4		
5		

Terminal No.		Signal Name [Specification]	
1	SB		
2	G		
3	L		
5	GR		
		Terminal Color Of Wire	
		No.	

H.S.		Signal Name [Specification]				
Terminal No.	Color Of Wire	Signal Name [Specification]				
2	G	-	-	-	-	-
6	4	3	7	-	-	-
2	6	5	1	-	-	-

JRBWC7646GB

STARTING SYSTEM

< WIRING DIAGRAM >

A

STARTING SYSTEM

JRBWC7647GB


STR-17

STARTING SYSTEM


< WIRING DIAGRAM >

STARTING SYSTEM

CONNECTING CIRCUIT	CONNECTOR NO.	CONNECTOR NAME	CONNECTOR TYPE	CONNECTOR NO.	CONNECTOR NAME	CONNECTOR TYPE
1	F136	WIRE TO WIRE	M66FW-LC	F138	ENGINE RESTART BY PASS RELAY	E-BAB
2						
3						



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	BG	-
3	L	-
4	W	-
5	BG	-
6	W	-




Terminal No.	Color Of Wire	Signal Name [Specification]
2	B/R	-

Connector No.	F138
Connector Name	ENGINE RESTART BYPASS RELAY
Connector Type	E-Ba8

Connector No.	F138
Connector Name	ENGINE RESTART BYPASS RELAY
Connector Type	E-Ba8





Terminal No.	Color Of Wire	Signal Name [Specification]
3	B/R	-



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	=



Terminal No.	Color Of Wire	Signal Name [Specification]
1A	L	-
2A	LG	-
53	R	-
54	LAL	-
55	BR	-
56	P	-



< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000010957647

STR

A

C

D

E

F

G

H

I

J

K

L

M

N

O

P

DETAILED FLOW

NOTE:

If any malfunction is found, immediately disconnect the battery cable from the negative terminal.

CAUTION:

For models with stop/start system, erase the starter operation counter when the starter motor is replaced. Refer to [EC-960, "Work Procedure"](#).

1. CHECK ENGINE TYPE

Check the vehicle information.

Type	Engine
1	R9M engine
	QR engine
2	MR engine

>> GO TO 2.

2. CHECK ENGINE START

Crank the engine and check that the engine starts.

Does the engine start?

YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK THAT THE STARTER MOTOR STOPS

Check that the starter motor stops after starting the engine.

Does the starter motor stop?

YES >> INSPECTION END
NO-1 >> Type 1: Replace starter motor.
NO-2 >> Type 2: Replace magnetic switch.

4. CHECK THE ENGINE SPEED WITH CRANKING

Check that the engine runs at cranking.

Does engine turn by cranking?

YES >> GO TO 5.
NO >> GO TO 6.

5. CHECK THE ENGINE SPEED WITH CRANKING

Check that the engine speed is not low at cranking.

Does engine turn normally?

YES >> Check ignition/fuel system.
NO >> Check charge condition, corrosion and connection condition of the battery. Refer to [PG-120, "R9M : Work Flow"](#) (R9M engine) or [PG-124, "EXCEPT FOR R9M : Work Procedure"](#) (Except for R9M engine).

6. CHECK STARTER MOTOR ACTIVATION

Check that the starter motor runs at cranking.

Does starter motor turn?

YES-1 >> Type 1: Replace starter motor.
YES-2 >> Type 2: GO TO 7.
NO >> GO TO 8.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

7. CHECK STARTER MOTOR UNIT

1. Remove starter motor.
2. Check that the gear shaft of starter motor rotates.

Does gear shaft turn?

YES >> Check pinion clutch. Refer to [STR-28. "MR20DD : Inspection"](#) (MR engine) or [STR-35. "QR25DE : Inspection"](#) (QR engine)

NO >> Check reduction gear, armature and gear shaft.

8. CHECK POWER SUPPLY CIRCUIT

Check the following conditions.

- Fuse and fusible link
- Charge condition, corrosion and connection condition of the battery. Refer to [PG-120. "R9M : Work Flow"](#) (R9M engine) or [PG-124. "EXCEPT FOR R9M : Work Procedure"](#) (Except for R9M engine).

Are these inspection results normal?

YES >> GO TO 9.

NO >> Repair as needed.

9. CHECK STARTING SYSTEM WIRING

Check the following.

- "B" terminal circuit. Refer to [STR-21. "Diagnosis Procedure"](#).
- "S" terminal circuit. Refer to [STR-23. "Diagnosis Procedure"](#).

Are these inspection results normal?

YES-1 >> Type 1: Replace starter motor.

YES-2 >> Type 2: GO TO 10.

NO >> Repair as needed.

10. CHECK MAGNETIC SWITCH OPERATION SOUND

Check that a magnetic switch operation sound can be heard when the ignition switch is set at the starting position.

Does magnetic switch operation sound occur?

YES >> GO TO 11.

NO >> Replace magnetic switch.

11. PINION AND RING GEAR ENGAGEMENT CHECK

Check condition of pinion and ring gear mesh.

Is the inspection result normal?

YES >> GO TO 13.

NO >> GO TO 12.

12. CHECK STARTER MOTOR UNIT

Check the following.

- Adjust pinion movement. Refer to [STR-28. "MR20DD : Inspection"](#) (MR engine) or [STR-35. "QR25DE : Inspection"](#) (QR engine).
- Check pinion moving mechanism.
- Check ring gear.

Are these inspection results normal?

YES >> INSPECTION END

NO >> Repair or replace, if necessary.

13. CHECK STARTER MOTOR UNIT

Check that the starter motor runs when connecting the positive terminal (12 V) to starter motor terminal M and the negative terminal (ground) to starter motor body.

Does the starter motor run?

YES >> Replace magnetic switch.

NO >> Repair starter motor.

B TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B TERMINAL CIRCUIT

Diagnosis Procedure

INFOID:0000000010957648

STR

CAUTION:

- Perform diagnosis under the condition that engine cannot start by the following procedure.
- Remove fuel pump fuse.
- Crank or start the engine (where possible) until the fuel pressure is released.
- For models with stop/start system, erase the starter operation counter when the starter motor connector is disconnected. Refer to [EC-960, "Work Procedure"](#).

1. CHECK "B" TERMINAL CIRCUIT 1

1. Turn ignition switch OFF.
2. Check that starter motor "B" terminal connection is clean and tight.
3. Check voltage between starter motor "B" terminal and ground.

For QR engine

(+) Starter motor		(-)	Voltage (Approx.)
Connector	Terminal		
F11	1	Ground	Battery voltage

For MR engine

(+) Starter motor		(-)	Voltage (Approx.)
Connector	Terminal		
E64	1	Ground	Battery voltage

For R9M engine

(+) Starter motor		(-)	Voltage (Approx.)
Connector	Terminal		
F129	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> For models with stop/start system: GO TO 4.

NO-2 >> For models without stop/start system: Check harness between battery and starter motor for open circuit.

2. CHECK BATTERY CABLE CONNECTION STATUS (VOLTAGE DROP TEST)

1. Shift selector lever to "P" or "N" position. (CVT models)
Keep depressing clutch pedal fully. (M/T models)
2. Check voltage between battery positive terminal and starter motor "B" terminal.

For QR engine

(+)	(--) Starter motor		Condition	Voltage (Approx.)
	Connector	Terminal		
	Battery positive terminal	F11	1	When the ignition switch is in START position
				Less than 0.5 V

B TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

For MR engine

(+)	(-)		Condition	Voltage (Approx.)		
	Starter motor					
	Connector	Terminal				
Battery positive terminal	E64	1	When the ignition switch is in START position	Less than 0.5 V		

For R9M engine

(+)	(-)		Condition	Voltage (Approx.)		
	Starter motor					
	Connector	Terminal				
Battery positive terminal	F129	1	When the ignition switch is in START position	Less than 0.5 V		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between the battery and the starter motor for poor continuity.

3.CHECK GROUND CIRCUIT STATUS (VOLTAGE DROP TEST)

- Shift selector lever to "P" or "N" position. (CVT models)
Keep depressing clutch pedal fully. (M/T models)
- Check voltage between starter motor case and battery negative terminal.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Starter motor case	Battery negative terminal	When the ignition switch is in START position	Less than 0.2 V

Is the inspection result normal?

YES >> "B" terminal circuit is OK. Further inspection is necessary. Refer to [STR-19, "Work Flow"](#).

NO >> Check the starter motor case and ground for poor continuity.

4.CHECK "B" TERMINAL CIRCUIT 2

- Disconnect starter connector and engine restart bypass relay connector.
- Check continuity between starter motor harness connector and engine restart bypass relay harness connector.

Starter motor		Engine restart bypass relay		Continuity
Connector	Terminal	Connector	Terminal	
F129	1	F138	3	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK ENGINE RESTART BYPASS RELAY CIRCUIT

Check voltage between engine restart bypass relay harness connector and ground.

(+)		(-)	Voltage (Approx.)
Engine restart bypass relay			
Connector	Terminal	Ground	Battery voltage
F137	2		

Is the inspection result normal?

YES >> Replace engine restart bypass relay. Refer to [EC-1230, "Removal and Installation"](#).

NO >> Repair or replace harness.

S TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

S TERMINAL CIRCUIT

Diagnosis Procedure

INFOID:0000000010957649

A

STR

CAUTION:

- Perform diagnosis under the condition that engine cannot start by the following procedure.
- Remove fuel pump fuse.
- Crank or start the engine (where possible) until the fuel pressure is released.
- For models with stop/start system, erase the starter operation counter when the starter motor connector is disconnected. Refer to [EC-960, "Work Procedure"](#).

C

1. CHECK "S" TERMINAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect starter motor connector.
3. Shift selector lever to "P" or "N" position. (CVT models)
Keep depressing clutch pedal fully. (M/T models)
4. Check voltage between starter motor harness connector and ground.

For QR engine

(+)		(-)	Condition	Voltage (Approx.)
Starter motor	Connector			
F10	2	Ground	When the ignition switch is in START position	Battery voltage

For MR engine

(+)		(-)	Condition	Voltage (Approx.)
Starter motor	Connector			
F47	2	Ground	When the ignition switch is in START position	Battery voltage

For R9M engine

(+)		(-)	Condition	Voltage (Approx.)
Starter motor	Connector			
F130	2	Ground	When the ignition switch is in START position	Battery voltage

Is the inspection result normal?

A

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

YES >> "S" terminal circuit is OK. Further inspection is necessary. Refer to [STR-19, "Work Flow"](#).

A

STR

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect IPDM E/R connector.
2. Check continuity between starter motor harness connector and IPDM E/R harness connector.

For QR engine

Starter motor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F10	2	F73	81	Existed

For MR engine

Starter motor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F47	2	F73	81	Existed

S TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

For R9M engine

Starter motor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F130	2	F73	81	Existed

Is the inspection result normal?

YES >> Further inspection is necessary. Refer to [SEC-97, "Work Flow"](#) (With Intelligent Key System) or [SEC-259, "Work Flow"](#) (Without Intelligent Key System).

NO >> Repair or replace harness.

STARTING SYSTEM

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

STARTING SYSTEM

Symptom Table

INFOID:0000000010957650

STR

Symptom	Reference
No normal cranking	
Starter motor does not rotate	Refer to STR-19, "Work Flow" .

C

D

E

F

G

H

I

J

K

L

M

N

O

P

STARTER MOTOR

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION


STARTER MOTOR

MR20DD

MR20DD : Exploded View

INFOID:0000000010728720

REMOVAL



① "S" terminal connector

② Starter motor

③ Cylinder block

← : Vehicle front

Nm : N·m (kg·m, in-lb)


Nm : N·m (kg·m, ft-lb)

DISASSEMBLY

STARTER MOTOR

< REMOVAL AND INSTALLATION >

Type: S114-971



- ① Magnetic switch assembly
- ② Dust cover kit
- ③ Shift lever set
- ④ Center bracket (A)
- ⑤ Yoke assembly
- ⑥ Armature assembly
- ⑦ Brush holder assembly
- ⑧ Thrust washer
- ⑨ Rear cover assembly
- ⑩ Internal gear
- ⑪ Planetary gear
- ⑫ Pinion shaft
- ⑬ Packing
- ⑭ Thrust washer
- ⑮ Center bracket (P)
- ⑯ E-ring
- ⑰ Pinion assembly
- ⑱ Pinion stopper
- ⑲ Pinion stopper clip
- ⑳ Gear case assembly

: High-temperature grease point


MR20DD : Removal and Installation

INFOID:0000000010728721

REMOVAL

1. Disconnect battery cable from negative terminal. Refer to [PG-142, "EXCEPT FOR R9M : Removal and Installation"](#).
2. Remove "B" terminal nut Ⓐ and "B" terminal harness.
3. Disconnect "S" terminal connector Ⓑ.

: Vehicle front




4. Remove starter motor mounting bolts.

STARTER MOTOR

< REMOVAL AND INSTALLATION >

5. Remove starter motor upward from the vehicle.

↖ : Vehicle front



INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

Be careful to tighten "B" terminal nut to the specified torque.

MR20DD : Inspection

INFOID:000000010728722


MAGNETIC SWITCH

- Before starting to check, disconnect the battery cable from the negative terminal.
- Disconnect "M" terminal of starter motor.

1. Continuity test (between "S" terminal and switch body)

- Ⓐ : "S" terminal
- Ⓑ : "B" terminal
- Ⓒ : "M" terminal


- Replace magnetic switch if continuity does not exist.



2. Continuity test (between "S" terminal and "M" terminal)

- Ⓐ : "S" terminal
- Ⓑ : "B" terminal
- Ⓒ : "M" terminal

- Replace magnetic switch if continuity does not exist.




PINION PROTRUSION LENGTH

- With pinion driven out by magnetic switch, push pinion back to remove slack and measure the clearance "L" between the front edge of the pinion and the pinion stopper.

Clearance "L"


: Refer to SDS STR-42.
"Starter Motor".



STARTER MOTOR

< REMOVAL AND INSTALLATION >


- If the measurement value is not in the specified area, adjust with the adjusting plate.



A
STR

PINION ASSEMBLY

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth (If equipped).
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - Replace pinion assembly if it is locked or rotated in both directions or unusual resistance is evident.




C
D
E
F
G
H

BRUSH HOLDER ASSEMBLY

Brush

- Check wear of brush.

Minimum length of brush : Refer to SDS [STR-42, "Starter Motor"](#).




I
J
K
L

Brush Spring

- Check brush spring tension with brush spring detached from brush.

Spring tension (with new brush) : Refer to SDS [STR-42, "Starter Motor"](#).




M
N
O
P

Brush Holder

STARTER MOTOR

< REMOVAL AND INSTALLATION >

1. Perform insulation test between brush holder (positive side) and its base (negative side).
 - Replace brush holder assembly if continuity does not exist.
2. Check brush to see if it moves smoothly.
 - If brush holder is bent, replace it.
 - If sliding surface is dirty, clean it.




YODE CHECK

Magnet is secured to yoke by bonding agent. Check magnet to see that it is secured to yoke and for any cracks. Replace malfunctioning parts as an assembly.


CAUTION:

Never clamp yoke in a vise or strike it with a hammer.




ARMATURE CHECK

1. Continuity test (between two segments side by side)
 - Replace if continuity does not exist.
2. Insulation test (between each commutator bar and shaft)
 - Replace if continuity exists.



3. Check commutator surface.
 - Grind commutator with No. 500 – 600 emery paper if the surface is rough.




STARTER MOTOR

< REMOVAL AND INSTALLATION >

4. Check diameter of commutator.

Commutator minimum diameter : Refer to SDS [STR-42, "Starter Motor".](#)

- Replace armature assembly if the measurement value is less than the specified value.



A

STR

C

D

E

F

G

H

I

J

K

L

M


N

O

P

5. Check depth of insulating mold from commutator surface.

- Undercut to 0.5 – 0.8 mm (0.020 – 0.031 in) if the depth is 0.2 mm (0.008 in) or less.



QR25DE


QR25DE : Exploded View

INFOID:000000010728723

REMOVAL

STARTER MOTOR

< REMOVAL AND INSTALLATION >



① Converter housing

② "S" terminal harness

③ "B" terminal harness

④ Starter motor

① : N·m (kg·m, in·lb)


② : N·m (kg·m, ft·lb)

DISASSEMBLY

STARTER MOTOR

< REMOVAL AND INSTALLATION >

S114-961



① Magnetic switch assembly	② Adjusting plate	③ Dust cover
④ Shift lever set	⑤ Pinion stopper clip	⑥ Pinion stopper
⑦ Pinion	⑧ Pinion spring	⑨ Gear case assembly
⑩ Center bracket (A)	⑪ Yoke assembly	⑫ Armature assembly
⑬ Brush holder assembly	⑭ Thrust washer	⑮ Rear cover
⑯ Internal gear	⑰ Planetary gear	⑯ Pinion shaft
⑲ Packing	⑳ Thrust washer	㉑ Center gear assembly
㉒ Thrust washer	㉓ E-ring	㉔ Clutch gear assembly

: High-temperature grease point


A
STR
C
D
E
F
G
H
I
J
K
L
M
N
O
P

STARTER MOTOR

< REMOVAL AND INSTALLATION >

M000TB0071

SEC. 233



JSBIA4204GB

① Magnetic switch assembly	② Dust cover kit	③ Gear case assembly
④ Pinion assembly	⑤ Stopper	⑥ Ring
⑦ Ring	⑧ Stopper	⑨ Yoke assembly
⑩ Armature assembly	⑪ Brush holder assembly	⑫ Metal
⑬ Rear cover	⑭ Gear assembly	⑮ Shift lever set
⑯ Clutch gear assembly	⑰ Center bracket	⑱ Gear shaft

⑩ : N·m (kg·m, in-lb)


QR25DE : Removal and Installation

INFOID:0000000010728724

REMOVAL

1. Remove battery. Refer to [PG-142, "EXCEPT FOR R9M : Removal and Installation"](#).
2. Remove air duct. Refer to [EM-175, "Removal and Installation"](#).
3. Disconnect ECM harness connectors Ⓐ.

↖ : Vehicle front




JMBIA4626ZZ

STARTER MOTOR

< REMOVAL AND INSTALLATION >

4. Remove TCM bracket mounting bolts Ⓐ.
5. Remove harness fixing clip Ⓑ.
6. Remove battery tray mounting bolts Ⓒ, and then remove battery tray ①.


◀ : Vehicle front



JMBIA4627ZZ

7. Remove harness bracket mounting bolts Ⓐ and harness fixing clip Ⓑ.
8. Remove harness bracket ①.

◀ : Vehicle front



JMBIA4628ZZ

9. Remove "B" terminal nut and "B" terminal harness.
10. Remove "S" terminal nut and "S" terminal harness.
11. Remove starter motor mounting bolts.
12. Remove starter motor upward from the vehicle.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

Be careful to tighten "B" terminal nut to the specified torque.

QR25DE : Inspection

INFOID:0000000010728725

MAGNETIC SWITCH

- Before starting to check, disconnect the battery cable from the negative terminal.
- Disconnect "M" terminal of starter motor.


1. Continuity test (between "S" terminal and switch body)

Ⓐ : "S" terminal

Ⓑ : "B" terminal

Ⓒ : "M" terminal

- Replace magnetic switch if continuity does not exist.



SKIB9002E

STARTER MOTOR

< REMOVAL AND INSTALLATION >


2. Continuity test (between "S" terminal and "M" terminal)

(A) : "S" terminal

(B) : "B" terminal

(C) : "M" terminal

- Replace magnetic switch if continuity does not exist.




SKIB9003E

PINION PROTRUSION LENGTH

- Compare movement "L" in height of pinion when it is pushed out with magnetic switch energized and when it is pulled out by hand until it touches stopper.


Movement "L"

: Refer to SDS [STR-42..](#)
["Starter Motor".](#)



SKIB0230E


- If the measurement value is not in the specified area, adjust with the adjusting plate.



JPBIA1984ZZ

PINION ASSEMBLY

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - Replace pinion assembly if it is locked or rotated in both directions or unusual resistance is evident.



SEL630BA

BRUSH HOLDER ASSEMBLY

Brush


STARTER MOTOR

< REMOVAL AND INSTALLATION >

- Check wear of brush.

Minimum length of brush : Refer to SDS [STR-42, "Starter Motor".](#)

- Replace brush if the measurement value is less than the specified value.



A

STR

C

D

E

F

G

H

I

J

K

L

M

N

O


P

Brush Spring

- Check brush spring tension with brush spring detached from brush.

Spring tension (with new brush) : Refer to SDS [STR-42, "Starter Motor".](#)

- Replace brush spring if the measurement value is less than the specified value.



C

D

E

F

G

H

I

J

K

L


M

N

O

Brush Holder

1. Perform insulation test between brush holder (positive side) and its base (negative side).
 - Replace brush holder assembly if continuity does not exist.
2. Check brush to see if it moves smoothly.
 - If brush holder is bent, replace it if sliding surface is dirty, clean.



C

D

E

F

G

H

I

J

K

L

M

N


O

YODE CHECK

Magnet is secured to yoke by bonding agent. Check magnet to see that it is secured to yoke and for any cracks. Replace malfunctioning parts as an assembly.

CAUTION:

Never clamp yoke in a vise or strike it with a hammer.



C

D

E

F

G

H

I

J

K

L

M

N


O

ARMATURE CHECK

STARTER MOTOR

< REMOVAL AND INSTALLATION >


1. Continuity test (between two segments side by side)
 - Replace if continuity does not exist.
2. Insulation test (between each commutator bar and shaft)
 - Replace if continuity exists.



SKIB0461E

3. Check commutator surface.

- Grind commutator with No. 500 – 600 emery paper if the surface is rough.




SEL020Z

4. Check diameter of commutator.

Commutator minimum diameter : Refer to SDS [STR-42.](#)
["Starter Motor".](#)

- Replace armature assembly if the measurement value is less than the specified value.




SEL021Z

STARTER MOTOR

< REMOVAL AND INSTALLATION >

5. Check depth of insulating mold from commutator surface.
 - Undercut to 0.5 – 0.8 mm (0.020 – 0.031 in) if the depth is 0.2 mm (0.008 in) or less.




SEL022Z

R9M

R9M : Exploded View

INFOID:0000000010728730



JMBIA4638GB

① Starter motor
 ④ Transmission housing
 ← : Vehicle front
 ⚡ : N·m (kg·m, in-lb)
 ⚡ : N·m (kg·m, ft-lb)

② "B" terminal harness

③ "S" terminal harness

R9M : Removal and Installation

INFOID:0000000010728731

REMOVAL


1. Remove battery. Refer to [PG-139, "R9M : Removal and Installation".](#)

STARTER MOTOR

< REMOVAL AND INSTALLATION >


2. Remove air duct (inlet). Refer to [EM-308, "Removal and Installation"](#).
3. Disconnect ECM harness connectors Ⓐ.

◀ : Vehicle front



4. Remove harness bracket mounting bolts Ⓐ.
5. Remove harness fixing clip Ⓑ.
6. Remove battery tray mounting bolts Ⓒ, and then remove battery tray ①.

◀ : Vehicle front



7. Remove electric throttle control actuator. Refer to [EM-314, "Removal and Installation"](#).

CAUTION:

Cover the openings to avoid entry of foreign materials.

8. Remove air inlet hose 2. Refer to [EM-314, "Removal and Installation"](#).
9. Remove "B" terminal nut and "B" terminal harness.
10. Remove "S" terminal nut and "S" terminal harness.
11. Remove starter motor mounting bolts.
12. Remove starter motor upward from the vehicle.

CAUTION:


Never contact with and damage surrounding parts when removing starter motor from the vehicle.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:


- Be careful to insert pin Ⓐ of starter motor ① into hole Ⓑ of transmission housing ②. (CVT models)



STARTER MOTOR

< REMOVAL AND INSTALLATION >

- Be careful to insert pin Ⓐ of transmission housing ② into hole Ⓑ of starter motor ①. (MT models)



- Be careful to tighten "B" terminal nut to the specified torque.
- Erase the starter operation counter when the starter motor for models with STOP/START SYSTEM is replaced. Refer to [EC-960, "Work Procedure"](#).
- Replace the engine restart relay and the fuel pump relay when the starter motor for models with STOP/START SYSTEM is replaced.

A
STR
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Starter Motor

INFOID:0000000010957651

Engine		QR	MR	R9M	
Type			M000TB0071	S114-971	0 001 A01 527
	MITUBISHI make		HITACHI make	BOSCH make	
	Reduction gear type				
System voltage		[V]	12		
No-load	Terminal voltage	[V]	11	11	—
	Current	[A]	Less than 90	Less than 110	—
	Revolution	[rpm]	More than 2,370	More than 3,300	—
Minimum diameter of commutator		[mm (in)]	28.0 (1.102)	28.0 (1.102)	—
Minimum length of brush		[mm (in)]	5.5 (0.217)	10.5 (0.413)	—
Brush spring tension		[N (kg, lb)]	15.0 - 20.4 (1.53 - 2.08, 3.37 - 4.58)	16.2 (1.65, 3.6)	—
Clearance between bearing metal and armature shaft		[mm (in)]	Less than 0.2 (0.008)	Less than 0.2 (0.008)	—
Clearance "L" between pinion front edge and pinion stopper		[mm (in)]	—	0.3 - 2.5 (0.012 - 0.098)	—
Movement "L" in height of pinion assembly		[mm (in)]	0.5 - 2.0 (0.020 - 0.079)	—	—