

SECTION **AT****CONTENTS**

PREPARATION AND PRECAUTIONS	1003
Special Service Tools	1003
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ...	1004
Precautions	1004
Service Notice or Precautions	1006
OVERALL SYSTEM	1007
A/T Electrical Parts Location	1007
Circuit Diagram	1008
Wiring Diagram — A/T —	1009
Cross-sectional View	1022
Hydraulic Control Circuits	1023
Shift Mechanism	1024
Control System	1026
ON BOARD DIAGNOSTIC SYSTEM	
DESCRIPTION	1028
Self-diagnosis.....	1028
Diagnosis by CONSULT-II.....	1034
TROUBLE DIAGNOSIS — Introduction	1036
Introduction	1036
Diagnostic Worksheet.....	1037
Work Flow	1040
TROUBLE DIAGNOSIS — Basic Inspection	1041
A/T Fluid Check	1041
Stall Test	1041
Line Pressure Test.....	1044
Road Test	1046
TROUBLE DIAGNOSIS — General	
Description	1057
Symptom Chart.....	1057
TCM Terminals and Reference Value	1060
TROUBLE DIAGNOSIS FOR VHCL SPEED	
SEN-A/T	1064
Vehicle Speed Sensor-A/T (Revolution sensor)	1064
TROUBLE DIAGNOSIS FOR VHCL SPEED	
SEN-MTR	1066
Vehicle Speed Sensor-MTR.....	1066
TROUBLE DIAGNOSIS FOR THROTTLE POSI	
SEN	1068
Accelerator Position Sensor	1068
TROUBLE DIAGNOSIS FOR SHIFT	
SOLENOID/V A	1070
Shift Solenoid Valve A	1070
TROUBLE DIAGNOSIS FOR SHIFT	
SOLENOID/V B	1072
Shift Solenoid Valve B	1072
TROUBLE DIAGNOSIS FOR OVERRUN	
CLUTCH S/V	1074
Overrun Clutch Solenoid Valve	1074
TROUBLE DIAGNOSIS FOR T/C CLUTCH	
SOL/V	1076
Torque Converter Clutch Solenoid Valve	1076
TROUBLE DIAGNOSIS FOR BATT/FLUID	
TEMP SEN	1079
A/T Fluid Temperature Sensor and TCM Power Source	1079
TROUBLE DIAGNOSIS FOR ENGINE SPEED	
SIG	1082
Engine Speed Signal	1082
TROUBLE DIAGNOSIS FOR LINE PRESSURE	
S/V	1084
Line Pressure Solenoid Valve	1084
TROUBLE DIAGNOSIS FOR CONTROL UNIT (RAM), CONTROL UNIT (ROM)	1087
Description	1087

AT

Diagnostic Procedure.....	1088
TROUBLE DIAGNOSIS FOR CONTROL UNIT (EFP ROM).....	1089
Description	1089
Diagnostic Procedure.....	1090
TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS	1091
PNP, Overdrive Control, A/T Mode or Accelerator Position Switches	1091
DIAGNOSTIC PROCEDURES FOR SYMPTOMS	1097
1. SPORT Indicator Lamp Does Not Come On.....	1097
2. SPORT Indicator Lamp Does Not Come On.....	1098
3. O/D OFF Indicator Lamp Does Not Come On	1098
4. SPORT Indicator Lamp Does Not Come On.....	1099
5. Engine Cannot Be Started In "P" and "N" Position	1100
6. In "P" Position, Vehicle Moves Forward Or Backward When Pushed	1100
7. In "N" Position, Vehicle Moves	1101
8. Large Shock. "N" → "R" Position	1102
9. Vehicle Does Not Creep Backward In "R" Position	1103
10. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position	1104
11. Vehicle Cannot Be Started From D ₁	1105
12. A/T Does Not Shift: D ₁ → D ₂ Or Does Not Kickdown: D ₄ → D ₂	1106
13. A/T Does Not Shift: D ₂ → D ₃	1107
14. A/T Does Not Shift: D ₃ → D ₄	1108
15. A/T Does Not Perform Lock-up	1109
16. A/T Does Not Hold Lock-up Condition	1110
17. Lock-up Is Not Released	1110
18. Engine Speed Does Not Return To Idle (Light Braking D ₄ → D ₃)	1111
19. Vehicle Does Not Start From D ₁	1112
20. A/T Does Not Shift: D ₂ → D ₁ When Depressing Accelerator Pedal	1113
21. A/T Does Not Shift: D ₄ → D ₃ , When Overdrive Control Switch "ON" → "OFF"	1114
22. A/T Does Not Shift: D ₃ → 2 ₂ , When Selector Lever "D" → "2" Position	1114
23. A/T Does Not Shift: 2 ₂ → 1 ₁ , When	
Selector Lever "2" → "1" Position	1115
24. Vehicle Does Not Decelerate By Engine Brake.....	1115
TROUBLE DIAGNOSES — A/T Shift Lock System.....	1116
Description	1116
Wiring Diagram — SHIFT —	1117
Diagnostic Procedure.....	1118
Key Interlock Cable.....	1121
Component Check	1122
ON-VEHICLE SERVICE	1124
Control Valve Assembly and Accumulators	1124
Revolution Sensor Replacement	1125
Rear Oil Seal Replacement	1125
Parking Pawl Components Inspection.....	1125
PNP Switch Adjustment.....	1125
Manual Control Linkage Adjustment.....	1126
REMOVAL AND INSTALLATION	1127
Removal	1127
Installation	1128
MAJOR OVERHAUL	1129
Oil Channel	1131
Locations of Needle Bearings, Thrust Washers and Snap Rings	1132
DISASSEMBLY	1133
REPAIR FOR COMPONENT PARTS	1144
Oil Pump	1144
Control Valve Assembly.....	1148
Control Valve Upper Body	1154
Control Valve Lower Body	1159
Reverse Clutch	1161
High Clutch	1165
Forward and Overrun Clutches	1167
Low & Reverse Brake.....	1171
Forward Clutch Drum Assembly.....	1175
Rear Internal Gear and Forward Clutch Hub ..	1177
Band Servo Piston Assembly	1180
Parking Pawl Components	1184
ASSEMBLY	1186
Assembly (1)	1186
Adjustment	1190
Assembly (2)	1195
A/T FLUID COOLER SYSTEM	1205
A/T Fluid Cooler.....	1205
SERVICE DATA AND SPECIFICATIONS (SDS)	1206
General Specifications	1206
Specifications and Adjustment.....	1206








When you read wiring diagrams:

- **Read GI section, "HOW TO READ WIRING DIAGRAMS".**
- **See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.**

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".


PREPARATION AND PRECAUTIONS

Special Service Tools

Tool number Tool name	Description
ST2505S001 Oil pressure gauge set ① ST25051001 Oil pressure gauge ② ST25052000 Hose ③ ST25053000 Joint pipe ④ ST25054000 Adapter ⑤ ST25055000 Adapter	Measuring line pressure NT097 
KV31101201 Oil pressure gauge adapter	Measuring line pressure NT093 
ST07870000 Transmission case stand	Disassembling and assembling A/T NT421  a: 182 mm (7.17 in) b: 282 mm (11.10 in) c: 230 mm (9.06 in) d: 100 mm (3.94 in)
KV31102100 Torque converter one-way clutch check tool	Checking one-way clutch in torque converter NT098 
ST25850000 Sliding hammer	Removing oil pump assembly NT422  a: 179 mm (7.05 in) b: 70 mm (2.76 in) c: 40 mm (1.57 in) dia. d: M12 x 1.75P
ST33200000 Drift	Installing oil pump housing oil seal NT091  a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.
ST30720000 Drift	Installing rear oil seal NT115  a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.

PREPARATION AND PRECAUTIONS

Special Service Tools (Cont'd)

Tool number Tool name	Description
KV31102400 Clutch spring compressor	 <p>Removing and installing clutch return springs</p> <p>a: 320 mm (12.60 in) b: 174 mm (6.85 in)</p>

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL Y61 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.

Precautions

- Before proceeding with disassembly, thoroughly clean the outside of the transmission. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transmission.
- Place disassembled parts in order for easier and proper assembly.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the transmission is disassembled.
- It is very important to perform functional tests whenever they are indicated.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place removed parts in a parts rack in order to replace them in correct positions and sequences. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along bores in valve body under their own weight.
- Before assembly, apply a coat of recommended ATF to all parts. Apply petroleum jelly to protect O-rings and seals, and to hold bearings and washers in place during assembly. Do not use grease.

PREPARATION AND PRECAUTIONS

Precautions (Cont'd)

- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- After overhaul, refill the transmission with new ATF.
- When the A/T drain plug is removed, only some of the fluid is drained. Old A/T fluid will remain in torque converter and ATF cooling system.

Always follow the procedures under "Changing A/T Fluid" in the MA section when changing A/T fluid.

PREPARATION AND PRECAUTIONS

Service Notice or Precautions

FAIL-SAFE

The TCM has an electronic Fail-Safe (limp home mode). This allows the vehicle to be driven even if a major electrical input/output device circuit is damaged.

Under Fail-Safe, the vehicle always runs in third gear even with a shift lever position of "1", "2" or "D". Customer may complain of "sluggish or poor acceleration".

When the Fail-Safe operation occurs the next time the key is turned to the "ON" position, the SPORT indicator lamp will blink for about 8 seconds. (For diagnosis, refer to AT-1029.)

The blinking of the SPORT indicator lamp for about 8 seconds will appear only once and be cleared. The customer may resume normal driving conditions by chance.

Always follow the "WORK FLOW" (Refer to AT-1040).


The SELF-DIAGNOSIS results will be as follows:

The first SELF-DIAGNOSIS will indicate the damage of the vehicle speed sensor or the revolution sensor.

During the next SELF-DIAGNOSIS performed after checking the sensor, no damages will be indicated.


OVERALL SYSTEM

A/T Electrical Parts Location





OVERALL SYSTEM

Circuit Diagram



OVERALL SYSTEM





Wiring Diagram — A/T —



OVERALL SYSTEM





Wiring Diagram — A/T — (Cont'd)

AT-AT-02






OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)






Refer to last page (Foldout page).
(M21), (E127)





OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

AT-A/T-04



Refer to last page (Foldout page).
(M20, B19)



TAT026M

AT-1012

OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

- : Detectable line for DTC
- : Non-detectable line for DTC
- : LHD models
- : RHD models
- : With A/T mode switch
- : Without A/T mode switch
- : With overdrive control switch
- : Without overdrive control switch

*1 2 :


55K :

*2 3 :


67K :

*3 24 :



6K :



AT-A/T-05



Preceding page




TAT016M

AT-1013

OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

AT-A/T-06






TAT017M

AT-1014




OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

AT-A/T-07



Refer to last page (Foldout page).






OVERALL SYSTEM


Wiring Diagram — A/T — (Cont'd)

AT-A/T-08

- : Detectable line for DTC
- : Non-detectable line for DTC
- L : LHD models
- R : RHD models



Refer to last page (Foldout page).
F8









TAT019M

AT-1016

OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

AT-A/T-09






TAT020M

AT-1017

OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

AT-A/T-10





TAT021M

AT-1018

OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

AT-A/T-12






TAT023M

AT-1020

OVERALL SYSTEM

Wiring Diagram — A/T — (Cont'd)

AT-A/T-13




* : This connector is not shown in "HARNESS LAYOUT", EL section.

TAT024M

AT-1021

OVERALL SYSTEM

Cross-sectional View




SAT750HA

AT-1022

OVERALL SYSTEM

Hydraulic Control Circuits



OVERALL SYSTEM


Shift Mechanism

The automatic transmission uses compact, dual planetary gear systems to improve power-transmission efficiency, simplify construction and reduce weight.

It also employs an optimum shift control and superwide gear ratios. They improve starting performance and acceleration during medium and high-speed operation.

Two one-way clutches are also employed: one is used for the forward clutch and the other for the low clutch. These one-way clutches, combined with four accumulators, reduce shifting shock to a minimum.

CONSTRUCTION



SAT5091

① Torque converter clutch piston	⑨ Front sun gear	⑯ Forward one-way clutch
② Torque converter	⑩ Front internal gear	⑯ Overrun clutch
③ Oil pump	⑪ Front planetary carrier	⑯ Low one-way clutch
④ Input shaft	⑫ Rear sun gear	⑯ Low & reverse brake
⑤ Brake band	⑬ Rear pinion gear	⑯ Parking pawl
⑥ Reverse clutch	⑭ Rear internal gear	⑯ Parking gear
⑦ High clutch	⑮ Rear planetary carrier	⑯ Output shaft
⑧ Front pinion gear	⑯ Forward clutch	

FUNCTION OF CLUTCH AND BRAKE

Control members	Abbr.	Function
⑥ Reverse clutch	R/C	To transmit input power to front sun gear ⑨.
⑦ High clutch	H/C	To transmit input power to front planetary carrier ⑪.
⑯ Forward clutch	F/C	To connect front planetary carrier ⑪ with forward one-way clutch ⑯.
⑯ Overrun clutch	O/C	To connect front planetary carrier ⑪ with rear internal gear ⑭.
⑤ Brake band	B/B	To lock front sun gear ⑨.
⑯ Forward one-way clutch	F/O.C	When forward clutch is engaged, to stop rear internal gear ⑭ from rotating in opposite direction.
⑯ Low one-way clutch	L/O.C	At D ₁ position, to prevent rear internal gear ⑭ from rotating in opposite direction.
⑯ Low & reverse brake	L & R/B	To lock rear internal gear ⑭ (2, 1 ₂ and 1 ₁), to lock front planetary carrier ⑪ (R position).

OVERALL SYSTEM

Shift Mechanism (Cont'd)

CLUTCH AND BAND CHART

Shift position	⑥ Reverse clutch	⑦ High clutch	⑯ Forward clutch	⑯ Overrun clutch	Band servo			⑯ Forward one-way clutch	⑯ Low one-way clutch	⑯ Low & reverse brake	Lock-up	Remarks
					2nd apply	3rd release	4th apply					
P												PARK POSITION
R	○									○		REVERSE POSITION
N												NEUTRAL POSITION
D*4	1st			○	*1○			●	●			Automatic shift 1 ↔ 2 ↔ 3 ↔ 4
	2nd			○	*1○	○		●				
	3rd		○	○	*1○	*2○	○	●				
	4th		○	○	○	*3○	○				○	
2	1st			○	○			●	●			Automatic shift 1 ↔ 2
	2nd			○	*1○	○		●				
1	1st			○	○			●		○		Locks (held stationary) in 1st speed 1 ← 2
	2nd			○	○	○		●				

*1: Operates when overdrive control or A/T mode switch is being set in "OFF" or "SPORT" position.

*2: Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, brake band does not contract because oil pressure area on the "release" side is greater than that on the "apply" side.

*3: Oil pressure is applied to 4th "apply" side in condition *2 above, and brake band contracts.

*4: A/T will not shift to 4th when overdrive control or A/T mode switch is set in "OFF" or "SPORT" position.

○ : Operates

○ : Operates when throttle opening is less than 5.5/16, activating engine brake.

● : Operates during "progressive" acceleration.

○ : Operates but does not affect power transmission.


○ : Operates when throttle opening is less than 5.5/16, but does not affect engine brake.

OVERALL SYSTEM


Control System

OUTLINE

The automatic transmission senses vehicle operating conditions through various sensors. It always controls the optimum shaft position and reduces shifting and lock-up shocks.



CONTROL SYSTEM



OVERALL SYSTEM

Control System (Cont'd)

TCM FUNCTION



The function of the TCM is to:

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, and engine brake operation.
- Send required output signals to the respective solenoids.

INPUT/OUTPUT SIGNAL OF TCM

	Sensors and solenoid valves	Function
Input	PNP switch	Detects select lever position and sends a signal to TCM.
	Accelerator position sensor	Detects throttle valve position and sends a signal to TCM.
	Accelerator position switch (Off accel)	Detects throttle valve's fully-closed position and sends a signal to TCM.
	Accelerator position switch (Full accel)	Detects a throttle valve position of greater than 1/2 of full throttle and sends a signal to TCM.
	Engine speed signal	From ECM.
	A/T fluid temperature sensor	Detects transmission fluid temperature and sends a signal to TCM.
	Revolution sensor	Detects output shaft rpm and sends a signal to TCM.
	Vehicle speed sensor	Used as an auxiliary vehicle speed sensor. Sends a signal when revolution sensor (installed on transmission) malfunctions.
	Overdrive control switch A/T mode switch	Sends a signal, which prohibits a shift to "D ₄ " (overdrive) position, to the TCM.
Output	Shift solenoid valve A/B	Selects shifting point suited to driving conditions in relation to a signal sent from TCM.
	Line pressure solenoid valve	Regulates (or decreases) line pressure suited to driving conditions in relation to a signal sent from TCM.
	Torque converter clutch solenoid valve	Regulates (or decreases) lock-up pressure suited to driving conditions in relation to a signal sent from TCM.
	Overrun clutch solenoid valve	Controls an "engine brake" effect suited to driving conditions in relation to a signal sent from TCM.
	O/D OFF indicator lamp SPORT indicator lamp	Shows TCM faults, when A/T control components malfunction.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION



Self-diagnosis

After performing this procedure, place check marks for results on the "DIAGNOSTIC WORKSHEET", AT-1038. Reference pages are provided following the items.

SELF-DIAGNOSTIC PROCEDURE (With CONSULT-II)






1. Turn on CONSULT-II and touch "A/T".
If A/T is not displayed, check TCM power supply and ground circuit. Refer to AT-1060. If result is NG, refer to EL section ("POWER SUPPLY ROUTING").
2. Touch "SELF-DIAG RESULTS".
Display shows malfunction experienced since the last erasing operation.
CONSULT-II performs REAL-TIME SELF-DIAGNOSIS.
Also, any malfunction detected while in this mode will be displayed at real time.

Item	Display	Description	Remarks
No failure	****NO FAILURE****	<ul style="list-style-type: none"> • No failure has been detected. 	
Initial start	*INITIAL START*	<ul style="list-style-type: none"> • This is NOT a malfunction message. [Whenever shutting off a power supply to the TCM, this message appears on the screen.] 	
Vehicle speed sensor-A/T (Revolution sensor)	VHCL SPEED SEN-A/T	<ul style="list-style-type: none"> • No signal input from vehicle speed sensor-A/T (revolution sensor) during traveling due to disconnection, or input of abnormal signal. 	
Vehicle speed sensor-MTR (Meter)	VHCL SPEED SEN-MTR	<ul style="list-style-type: none"> • No signal input from vehicle speed sensor-MTR during traveling due to disconnection, or input of abnormal signal. 	
Accelerator position sensor	THROTTLE POSI SEN	<ul style="list-style-type: none"> • Accelerator position sensor signal voltage is abnormally high. • Throttle (accelerator) position sensor signal voltage is abnormally low with closed throttle position switch "OFF" or wide open throttle position switch "ON". 	
Shift solenoid valve A	SHIFT SOLENOID/V A	<ul style="list-style-type: none"> • Specified voltage is not applied to solenoid valve due to disconnection or shortcircuit. 	
Shift solenoid valve B	SHIFT SOLENOID/V B	<ul style="list-style-type: none"> • Specified voltage is not applied to solenoid valve due to disconnection or shortcircuit. 	
Overrun clutch solenoid valve	OVERRUN CLUTCH S/V	<ul style="list-style-type: none"> • Specified voltage is not applied to solenoid valve due to disconnection or shortcircuit. 	
T/C clutch solenoid valve	T/C CLUTCH SOL/V	<ul style="list-style-type: none"> • Specified voltage is not applied to solenoid valve due to disconnection or shortcircuit. 	
A/T fluid temperature sensor/TCM power source	BATT/FLUID TEMP SEN	<ul style="list-style-type: none"> • Supply voltage to TCM is abnormally low during traveling. • Fluid temperature signal voltage is abnormally high (fluid temperature is low) during traveling. 	To be displayed in case of abnormality and no recording is made
Engine speed signal	ENGINE SPEED SIG	<ul style="list-style-type: none"> • Engine RPM is abnormally low during traveling. 	
Line pressure solenoid valve	LINE PRESSURE S/V	<ul style="list-style-type: none"> • Specified voltage is not applied to solenoid valve due to disconnection or shortcircuit. 	
TCM (ROM)	CONTROL UNIT (ROM)	<ul style="list-style-type: none"> • TCM memory (ROM) is malfunctioning. 	
TCM (RAM)	CONTROL UNIT (RAM)	<ul style="list-style-type: none"> • TCM memory (RAM) is malfunctioning. 	
TCM (EEP ROM)	CONTROL UNIT (EEP ROM)	<ul style="list-style-type: none"> • TCM memory (EEP ROM) is malfunctioning. 	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Self-diagnosis (Cont'd)

SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)



DIAGNOSIS START

1. Start engine and warm it up to normal engine operating temperature.
2. Turn ignition switch to "OFF" position. Wait at least 5 seconds.

A

1. Set A/T mode switch to "AUTO" position.
2. Set overdrive control switch in "ON" position.
3. Move selector lever to "P" position.
4. Turn ignition switch to "ON" position. (Do not start engine.)
5. Does SPORT indicator lamp come on for about 2 seconds?

No → Go to 1. SPORT Indicator Lamp Does Not Come On, AT-1097.

Yes

B

1. Turn ignition switch to "ACC" position.
2. Move selector lever to "D" position.

C

1. Set overdrive control switch in "OFF" position.
2. Depress accelerator pedal fully and release it.
3. Turn ignition switch "ON". (Do not start engine.)





D

1. Move selector lever to "2" position.
2. Set overdrive control switch in "ON" position.

Ⓐ

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION
















Self-diagnosis (Cont'd)



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Self-diagnosis (Cont'd)

JUDGEMENT OF SELF-DIAGNOSIS CODE






SPORT indicator lamps: ^{*1}	
<p>All judgement flickers are same.</p>  <p>Self-diagnosis start</p>  <p>Start signal 10-judgement flickers</p> <p>t_1 t_2 SAT810H t_3</p> <p>All circuits that can be confirmed by self-diagnosis are OK.</p>	<p>4th judgement flicker is longer than others.</p>  <p>Self-diagnosis start</p>  <p>Light</p> <p>Shade</p> <p>SAT797H</p> <p>Shift solenoid valve A circuit is short-circuited or disconnected.</p> <p>Go to SHIFT SOLENOID VALVE A, AT-1070.</p>
<p>1st judgement flicker is longer than others.</p>   <p>Light</p> <p>Shade</p> <p>SAT794H</p> <p>Revolution sensor circuit is short-circuited or disconnected.</p> <p>Go to VEHICLE SPEED SENSOR·A/T (REVOLUTION SENSOR), AT-1064.</p>	<p>5th judgement flicker is longer than others.</p>   <p>Light</p> <p>Shade</p> <p>SAT798H</p> <p>Shift solenoid valve B circuit is short-circuited or disconnected.</p> <p>Go to SHIFT SOLENOID VALVE B, AT-1072.</p>
<p>2nd judgement flicker is longer than others.</p>   <p>Light</p> <p>Shade</p> <p>SAT795H</p> <p>Vehicle speed sensor circuit is short-circuited or disconnected.</p> <p>Go to VEHICLE SPEED SENSOR·MTR, AT-1066.</p>	<p>6th judgement flicker is longer than others.</p>   <p>Light</p> <p>Shade</p> <p>SAT799H</p> <p>Overrun clutch solenoid valve circuit is short-circuited or disconnected.</p> <p>Go to OVERRUN CLUTCH SOLENOID VALVE, AT-1074.</p>
<p>3rd judgement flicker is longer than others.</p>   <p>Light</p> <p>Shade</p> <p>SAT796H</p> <p>Throttle (accelerator) position sensor circuit is short-circuited or disconnected.</p> <p>Go to ACCELERATOR POSITION SENSOR, AT-1068.</p>	<p>7th judgement flicker is longer than others.</p>   <p>Light</p> <p>Shade</p> <p>SAT800H</p> <p>Torque converter clutch solenoid valve circuit is short-circuited or disconnected.</p> <p>Go to TORQUE CONVERTER CLUTCH SOLENOID VALVE, AT-1076.</p>

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second

^{*1}: Refer to applicable indicator lamps for specified areas on next page.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Self-diagnosis (Cont'd)

SPORT indicator lamps:	
8th judgement flicker is longer than others.  SAT801H	Flickers as shown below.  SAT804H
A/T fluid temperature sensor is disconnected or TCM power source circuit is damaged. Go to A/T FLUID TEMPERATURE SENSOR AND TCM POWER SOURCE, AT-1079.	Battery power is low. Battery has been disconnected for a long time. Battery is connected conversely. (When reconnecting TCM connectors. — This is not a problem.)
9th judgement flicker is longer than others.  SAT802H	Does not come on.  SAT805H
Engine speed signal circuit is short-circuited or disconnected. Go to ENGINE SPEED SIGNAL, AT-1082.	PNP, overdrive control, A/T mode or accelerator position switches circuit is disconnected or TCM is damaged. Go to PNP, OVERDRIVE CONTROL, A/T MODE AND ACCELERATOR POSITION SWITCHES, AT-1091.
10th judgement flicker is longer than others.  SAT803H	
Line pressure solenoid valve circuit is short-circuited or disconnected. Go to LINE PRESSURE SOLENOID VALVE, AT-1084.	

$t_4 = 1.0$ second

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Self-diagnosis (Cont'd)

HOW TO ERASE SELF-DIAGNOSTIC RESULTS (With CONSULT-II)


1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" again.
2. Turn CONSULT-II "ON", and touch "A/T".

SAT014K

SELECT SYSTEM

A/T

ENGINE



SAT014K


SELECT DIAG MODE

SELF-DIAG RESULTS

DATA MONITOR

DTC WORK SUPPORT

TCM PART NUMBER



SAT971J

3. Touch "SELF-DIAG RESULTS".


4. Touch "ERASE". (The self-diagnostic results will be erased.)

SAT970J

SELF-DIAG RESULTS

DTC RESULTS

T/C CLUTCH SOL/V



HOW TO ERASE SELF-DIAGNOSTIC RESULTS (Without CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)". Refer to AT-1029.
3. Turn ignition switch "OFF". (The self-diagnostic results will be erased.)

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Diagnosis by CONSULT-II

NOTICE

1. The CONSULT-II electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid).

Check for time difference between actual shift timing and the CONSULT-II display. If the difference is noticeable, mechanical parts (except solenoids, sensors, etc.) may be malfunctioning. Check mechanical parts using applicable diagnostic procedures.

2. Shift schedule (which implies gear position) displayed on CONSULT-II and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:

- Actual shift schedule has more or less tolerance or allowance,
- Shift schedule indicated in Service Manual refers to the point where shifts start. Gear position displayed on CONSULT-II indicates the point where shifts are completed.

3. Shift solenoid valve "A" or "B" is displayed on CONSULT-II at the start of shifting. Gear position is displayed upon completion of shifting (which is computed by TCM).

4. Additional CONSULT-II information can be found in the Operation Manual supplied with the CONSULT-II unit.

SELF-DIAGNOSTIC RESULT TEST MODE

Refer to AT-1028.

DATA MONITOR DIAGNOSTIC TEST MODE

Item	Display	Monitor item		Description	Remarks
		TCM input signals	Main signals		
Vehicle speed sensor 1 (A/T) (Revolution sensor)	VHCL/S SE-A/T [km/h] or [mph]	X	—	• Vehicle speed computed from signal of revolution sensor is displayed.	When racing engine in "N" or "P" position with vehicle stationary, CONSULT data may not indicate 0 km/h (0 MPH).
Vehicle speed sensor 2 (Meter)	VHCL/S SE-MTR [km/h] or [mph]	X	—	• Vehicle speed computed from signal of vehicle speed sensor is displayed.	Vehicle speed display may not be accurate under approx. 10 km/h (6 MPH). It may not indicate 0 km/h (0 MPH) when vehicle is stationary.
Accelerator position sensor	THRTL POS SEN [V]	X	—	• Accelerator position sensor signal voltage is displayed.	
A/T fluid temperature sensor	FLUID TEMP SE [V]	X	—	• A/T fluid temperature sensor signal voltage is displayed. • Signal voltage lowers as fluid temperature rises.	
Battery voltage	BATTERY VOLT [V]	X	—	• Source voltage of TCM is displayed.	
Engine speed	ENGINE SPEED [rpm]	X	X	• Engine speed, computed from engine speed signal, is displayed.	Engine speed display may not be accurate under approx. 800 rpm. It may not indicate 0 rpm even when engine is not running.
Overdrive control switch	OVERDRIVE SW [ON/OFF]	X	—	• ON/OFF state computed from signal of overdrive control SW is displayed.	
P/N position switch	PN POSI SW [ON/OFF]	X	—	• ON/OFF state computed from signal of PN position SW is displayed.	
R position switch	R POSITION SW [ON/OFF]	X	—	• ON/OFF state computed from signal of R position SW is displayed.	
D position switch	D POSITION SW [ON/OFF]	X	—	• ON/OFF state computed from signal of D position SW is displayed.	
2 position switch	2 POSITION SW [ON/OFF]	X	—	• ON/OFF status, computed from signal of 2 position SW, is displayed.	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


Diagnosis by CONSULT-II (Cont'd)

Item	Display	Monitor item		Description	Remarks
		TCM input signals	Main signals		
1 position switch	1 POSITION SW [ON/OFF]	X	—	● ON/OFF status, computed from signal of 1 position SW, is displayed.	
ASCD-cruise signal	ASCD-CRUISE [ON/OFF]	X	—	● Status of ASCD cruise signal is displayed. ON ... Cruising state OFF ... Normal running state	● This is displayed even when no ASCD is mounted.
ASCD-OD cut signal	ASCD-OD CUT [ON/OFF]	X	—	● Status of ASCD-OD release signal is displayed. ON ... OD released OFF ... OD not released	● This is displayed even when no ASCD is mounted.
Kickdown switch	KICKDOWN SW [ON/OFF]	X	—	● ON/OFF status, computed from signal of kickdown SW, is displayed.	● This is displayed even when no kickdown switch is equipped.
A/T mode switch	POWER SHIFT SW [ON/OFF]	X	—	● ON/OFF state computed from signal of POWER shift SW is displayed.	
Closed throttle position switch	CLOSED THL/SW [ON/OFF]	X	—	● ON/OFF status, computed from signal of closed throttle (accelerator) position SW, is displayed.	
Wide open throttle position switch	W/O THRL/P-SW [ON/OFF]	X	—	● ON/OFF status, computed from signal of wide open throttle (accelerator) position SW, is displayed.	
A/T mode switch	HOLD SW [ON/OFF]	X	—	● ON/OFF status, computed from signal of HOLD shift SW, is displayed.	
Gear position	GEAR	—	X	● Gear position data used for computation by TCM, is displayed.	
Selector lever position	SLCT LVR POSI	—	X	● Selector lever position data, used for computation by TCM, is displayed.	● A specific value used for control is displayed if fail-safe is activated due to error.
Vehicle speed	VEHICLE SPEED [km/h] or [mph]	—	X	● Vehicle speed data, used for computation by TCM, is displayed.	
Accelerator position	THROTTLE POSI [1/8]	—	X	● Throttle (accelerator) position data, used for computation by TCM, is displayed.	● A specific value used for control is displayed if fail-safe is activated due to error.
Line pressure duty	LINE PRES DTY [%]	—	X	● Control value of line pressure solenoid valve, computed by TCM from each input signal, is displayed.	
Torque converter clutch solenoid valve duty	TCC S/V DUTY [%]	—	X	● Control value of torque converter clutch solenoid valve, computed by TCM from each input signal, is displayed.	
Shift solenoid valve A	SHIFT S/V A [ON/OFF]	—	X	● Control value of shift solenoid valve A, computed by TCM from each input signal, is displayed.	Control value of solenoid is displayed even if solenoid circuit is disconnected. The "OFF" signal is displayed if solenoid circuit is shorted.
Shift solenoid valve B	SHIFT S/V B [ON/OFF]	—	X	● Control value of shift solenoid valve B, computed by TCM from each input signal, is displayed.	
Overrun clutch solenoid valve	OVERRUN/C S/V [ON/OFF]	—	X	● Control value of overrun clutch solenoid valve computed by TCM from each input signal is displayed.	
Self-diagnosis display lamp (SPORT indicator lamp)	SELF-D DP LMP [ON/OFF]	—	X	● Control status of SPORT indicator lamp is displayed.	

X: Applicable

—: Not applicable

TROUBLE DIAGNOSIS — Introduction



Introduction

The TCM receives a signal from the vehicle-speed sensor, accelerator position sensor or PNP switch and provides shift control or lock-up control via solenoid valves.



Input and output signals must always be correct and stable in the operation of the A/T system. The A/T system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the "Work Flow". Refer to AT-1040.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example (AT-1038) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.



TROUBLE DIAGNOSIS — Introduction

Diagnostic Worksheet

INFORMATION FROM CUSTOMER

KEY POINTS

WHAT Vehicle & A/T model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions, Symptoms

Customer name MR/MS	Model & Year	VIN
Trans. model	Engine	Mileage
Incident Date	Manuf. Date	In Service Date
Frequency	<input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day)	
Symptoms	<input type="checkbox"/> Vehicle does not move. (<input type="checkbox"/> Any position <input type="checkbox"/> Particular position)	
	<input type="checkbox"/> No up-shift (<input type="checkbox"/> 1st → 2nd <input type="checkbox"/> 2nd → 3rd <input type="checkbox"/> 3rd → O/D)	
	<input type="checkbox"/> No down-shift (<input type="checkbox"/> O/D → 3rd <input type="checkbox"/> 3rd → 2nd <input type="checkbox"/> 2nd → 1st)	
	<input type="checkbox"/> Lockup malfunction	
	<input type="checkbox"/> Shift point too high or too low.	
	<input type="checkbox"/> Shift shock or slip (<input type="checkbox"/> N → D <input type="checkbox"/> Lockup <input type="checkbox"/> Any drive position)	
	<input type="checkbox"/> Noise or vibration	
	<input type="checkbox"/> No kickdown	
	<input type="checkbox"/> No pattern select	
	<input type="checkbox"/> Others ()	
SPORT indicator lamp	Blinks for about 8 seconds.	
	<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit
Malfunction indicator (MI)	<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit

TROUBLE DIAGNOSIS — Introduction

Diagnostic Worksheet (Cont'd)

DIAGNOSTIC WORKSHEET

1.	<input type="checkbox"/> Read the Fail-safe and listen to customer complaints.	AT-1006
2.	<input type="checkbox"/> A/T FLUID CHECK <ul style="list-style-type: none"> <input type="checkbox"/> Leakage (Follow specified procedure) <input type="checkbox"/> Fluid condition <input type="checkbox"/> Fluid level 	AT-1041
3.	<input type="checkbox"/> Perform STALL TEST and LINE PRESSURE TEST. <ul style="list-style-type: none"> <input type="checkbox"/> Stall test — Mark possible damaged components/others. <ul style="list-style-type: none"> <input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Reverse clutch <input type="checkbox"/> Forward clutch <input type="checkbox"/> Overrun clutch <input type="checkbox"/> Forward one-way clutch <input type="checkbox"/> Low & reverse brake <input type="checkbox"/> Low one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure is low <input type="checkbox"/> Clutches and brakes except high clutch and brake band are OK <input type="checkbox"/> Line pressure test — Suspected parts: 	AT-1041, AT-1044
4.	<input type="checkbox"/> Perform all ROAD TEST and mark required procedures. <ul style="list-style-type: none"> 4-1. Check before engine is started. <ul style="list-style-type: none"> <input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items. <ul style="list-style-type: none"> <input type="checkbox"/> Vehicle speed sensor-A/T (Revolution sensor), AT-1064. <input type="checkbox"/> Vehicle speed sensor-MTR, AT-1066. <input type="checkbox"/> Accelerator position sensor, AT-1068. <input type="checkbox"/> Shift solenoid valve A, AT-1070. <input type="checkbox"/> Shift solenoid valve B, AT-1072. <input type="checkbox"/> Overrun clutch solenoid valve, AT-1074. <input type="checkbox"/> Torque converter clutch solenoid valve, AT-1076. <input type="checkbox"/> A/T fluid temperature sensor and TCM power source, AT-1079. <input type="checkbox"/> Engine speed signal, AT-1082. <input type="checkbox"/> Line pressure solenoid valve, AT-1084. <input type="checkbox"/> PNP, overdrive control, A/T mode and accelerator position switches, AT-1091. <input type="checkbox"/> Battery <input type="checkbox"/> Others 4-2. Check at idle <ul style="list-style-type: none"> <input type="checkbox"/> 1. SPORT Indicator Lamp Does Not Come On, AT-1097. <input type="checkbox"/> 2. SPORT Indicator Lamp Does Not Come On, AT-1098. <input type="checkbox"/> 3. O/D OFF Indicator Lamp Does Not Come On, AT-1098. <input type="checkbox"/> 4. SPORT Indicator Lamp Does Not Come On AT-1099. <input type="checkbox"/> 5. Engine Cannot Be Started In "P" And "N" Position, AT-1100. <input type="checkbox"/> 6. In "P" Position, Vehicle Moves Forward Or Backward When Pushed, AT-1100. <input type="checkbox"/> 7. In "N" Position, Vehicle Moves, AT-1101. <input type="checkbox"/> 8. Large Shock. "N" → "R" Position, AT-1102. <input type="checkbox"/> 9. Vehicle Does Not Creep Backward In "R" Position, AT-1103. <input type="checkbox"/> 10. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position, AT-1104. 4-3. Cruise test <ul style="list-style-type: none"> Part-1 <ul style="list-style-type: none"> <input type="checkbox"/> 11. Vehicle Cannot Be Started From D₁, AT-1105. <input type="checkbox"/> 12. A/T Does Not Shift: D₁ → D₂ Or Does Not Kickdown: D₄ → D₂, AT-1106. <input type="checkbox"/> 13. A/T Does Not Shift: D₂ → D₃, AT-1107. <input type="checkbox"/> 14. A/T Does Not Shift: D₃ → D₄, AT-1108. <input type="checkbox"/> 15. A/T Does Not Perform Lock-up, AT-1109. <input type="checkbox"/> 16. A/T Does Not Hold Lock-up Condition, AT-1110. <input type="checkbox"/> 17. Lock-up Is Not Released, AT-1110. <input type="checkbox"/> 18. Engine Speed Does Not Return To Idle (Light Braking D₄ → D₃), AT-1111. 	AT-1046 AT-1047 AT-1049 AT-1050, AT-1053

TROUBLE DIAGNOSIS — Introduction

Diagnostic Worksheet (Cont'd)

4.	<p>Part-2</p> <ul style="list-style-type: none"> <input type="checkbox"/> 19. Vehicle Does Not Start From D₁, AT-1112. <input type="checkbox"/> 12. A/T Does Not Shift: D₁ → D₂ Or Does Not Kickdown: D₄ → D₂, AT-1106. <input type="checkbox"/> 13. A/T Does Not Shift: D₂ → D₃, AT-1107. <input type="checkbox"/> 14. A/T Does Not Shift: D₃ → D₄, AT-1108. <p>Part-3</p> <ul style="list-style-type: none"> <input type="checkbox"/> 20. A/T Does Not Shift: D₂ → D₁ When Depressing Accelerator Pedal, AT-1113 <input type="checkbox"/> 21. A/T Does Not Shift: D₄ → D₃ When Overdrive Control Switch "ON" → "OFF", AT-1114 <input type="checkbox"/> 18. Engine Speed Does Not Return To Idle (Engine Brake In D₃), AT-1111. <input type="checkbox"/> 22. A/T Does Not Shift: D₃ → 2₂, When Selector Lever "D" → "2" Position, AT-1114. <input type="checkbox"/> 18. Engine Speed Does Not Return To Idle (Engine Brake In 2₂), AT-1111. <input type="checkbox"/> 23. A/T Does Not Shift: 2₂ → 1₁, When Selector Lever "2" → "1" Position, AT-1115. <input type="checkbox"/> 24. Vehicle Does Not Decelerate By Engine Brake, AT-1115. <input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items. <ul style="list-style-type: none"> <input type="checkbox"/> Vehicle speed sensor-A/T (Revolution sensor), AT-1064. <input type="checkbox"/> Vehicle speed sensor-MTR, AT-1066. <input type="checkbox"/> Accelerator position sensor, AT-1068. <input type="checkbox"/> Shift solenoid valve A, AT-1070. <input type="checkbox"/> Shift solenoid valve B, AT-1072. <input type="checkbox"/> Overrun clutch solenoid valve, AT-1074. <input type="checkbox"/> Torque converter clutch solenoid valve, AT-1076. <input type="checkbox"/> A/T fluid temperature sensor and TCM power source, AT-1079. <input type="checkbox"/> Engine speed signal, AT-1082. <input type="checkbox"/> Line pressure solenoid valve, AT-1084. <input type="checkbox"/> PNP, overdrive control, A/T mode and accelerator position switches, AT-1091. <input type="checkbox"/> Battery <input type="checkbox"/> Others 	AT-1055
5.	<input type="checkbox"/> For self-diagnosis NG items, inspect each component. Repair or replace the damaged parts.	AT-1028
6.	<input type="checkbox"/> Perform all ROAD TEST and re-mark required procedures.	AT-1046
7.	<input type="checkbox"/> Perform the Diagnostic Procedures for all remaining items marked NG. Repair or replace the damaged parts. Refer to the Symptom Chart when you perform the procedures. (The chart also shows some other possible symptoms and the component inspection orders.)	AT-1060 AT-1057
8.	<input type="checkbox"/> Erase self-diagnosis code from TCM memories.	AT-1033


TROUBLE DIAGNOSIS — Introduction

Work Flow





HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Make good use of the two sheets provided, "INFORMATION FROM CUSTOMER" and "DIAGNOSTIC WORKSHEET", to perform the best troubleshooting possible.



TROUBLE DIAGNOSIS — Basic Inspection



A/T Fluid Check

FLUID LEAKAGE CHECK

1. Clean area suspected of leaking. — for example, mating surface of converter housing and transmission case.
2. Start engine, apply foot brake, place selector lever in "D" position and wait a few minutes.
3. Stop engine.
4. Check for fresh leakage.

FLUID CONDITION CHECK

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling, — Overheating

FLUID LEVEL CHECK

Refer to MA section ("Checking A/T Fluid", "CHASSIS AND BODY MAINTENANCE").

Stall Test

STALL TEST PROCEDURE

1. Check A/T and engine fluid levels. If necessary, add.
2. Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.

ATF operating temperature:
50 - 80°C (122 - 176°F)

3. Set parking brake and block wheels.
4. Install a tachometer where it can be seen by driver during test.

• It is good practice to put a mark on point of specified engine rpm on indicator.


5. Start engine, apply foot brake, and place selector lever in "D" position.
6. Accelerate to wide open throttle gradually while applying foot brake.
7. Quickly note the engine stall revolution and immediately release throttle.

• During test, never hold throttle wide open for more than 5 seconds.

Stall revolution:
2,480 - 2,680 rpm

TROUBLE DIAGNOSIS — Basic Inspection

Stall Test (Cont'd)



SAT771B

8. Move selector lever to "N" position.
9. Cool off ATF.
- **Run engine at idle for at least one minute.**
10. Repeat steps 5 through 9 with selector lever in "2", "1" and "R" positions.

JUDGEMENT OF STALL TEST

The test result and possible damaged components relating to each result are shown in the illustration. In order to pinpoint the possible damaged components, follow the WORK FLOW shown in AT-1040.

Note

Stall revolution is too high in "D" or "2" position:

- Slippage occurs in 1st gear but not in 2nd and 3rd gears. Low one-way clutch slippage
- Slippage occurs at the following gears:
 - 1st through 3rd gears in "D" position and engine brake functions.
 - 1st and 2nd gears in "2" position and engine brake functions with accelerator pedal released (fully closed throttle). Forward clutch or forward one-way clutch slippage

Stall revolution is too high in "R" position:

- Engine brake does not function in "1" position. Low & reverse brake slippage
- Engine brake functions in "1" position. Reverse clutch slippage

Stall revolution within specifications:

- Vehicle does not achieve speed of more than 80 km/h (50 MPH). One-way clutch seizure in torque converter housing

CAUTION:

Be careful since automatic fluid temperature increases abnormally.

- Slippage occurs in 3rd and 4th gears in "D" position. High clutch slippage
- Slippage occurs in 2nd and 4th gear in "D" position. Brake band slippage

Stall revolution less than specifications:

- Poor acceleration during starts. One-way clutch seizure in torque converter

TROUBLE DIAGNOSIS — Basic Inspection


Stall Test (Cont'd)

JUDGEMENT OF STALL TEST

Selector lever position	Judgement		
	L	O	H
D	L	O	H
2	L	O	H
1	L	O	O
R	L	H	H

O : Stall revolution is normal.
 H : Stall revolution is higher than specified.
 L : Stall revolution is lower than specified.


Damaged components



Selector lever position	H	H	H	O
D	H	H	H	O
2	H	H	H	O
1	O	H	H	O
R	O	O	H	O

Clutches and brakes except high clutch and brake band are OK. (Condition of high clutch and brake band cannot be confirmed by stall test.)


TROUBLE DIAGNOSIS — Basic Inspection



Line Pressure Test

LINE PRESSURE TEST PORTS

- Location of line pressure test ports.
- **Always replace line pressure plugs as they are self-sealing bolts.**





LINE PRESSURE TEST PROCEDURE

1. Check A/T and engine fluid levels. If necessary, add fluid.
2. Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.


ATF operating temperature:
50 - 80°C (122 - 176°F)

3. Install pressure gauge to corresponding line pressure port.




TROUBLE DIAGNOSIS — Basic Inspection

Line Pressure Test (Cont'd)



- Set parking brake and block wheels.
- Continue to depress brake pedal fully while line pressure test is being performed at stall speed.



- Start engine and measure line pressure at idle and stall speed.

- When measuring line pressure at stall speed, follow the stall test procedure.

Line pressure:

Refer to SDS, AT-1207.

JUDGEMENT OF LINE PRESSURE TEST

Judgement		Suspected parts
At idle	Line pressure is low in all positions.	<ul style="list-style-type: none"> Oil pump wear Control piston damage Pressure regulator valve or plug sticking Spring for pressure regulator valve damaged A/T fluid pressure leakage between oil strainer and pressure regulator valve Clogged strainer
	Line pressure is low in particular position.	<ul style="list-style-type: none"> Fluid pressure leakage between manual valve and particular clutch For example, line pressure is: <ul style="list-style-type: none"> Low in "R" and "1" positions, but Normal in "D" and "2" positions. <p>Then, fluid leakage exists at or around low and reverse brake circuit. Refer to "CLUTCH AND BAND CHART", AT-1025.</p>
	Line pressure is high.	<ul style="list-style-type: none"> Mal-adjustment of throttle position sensor A/T fluid temperature sensor damaged Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure modifier valve sticking Pressure regulator valve or plug sticking Open in dropping resistor circuit
At stall speed	Line pressure is low.	<ul style="list-style-type: none"> Mal-adjustment of throttle position sensor Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure regulator valve or plug sticking Pressure modifier valve sticking Pilot valve sticking

TROUBLE DIAGNOSIS — Basic Inspection

ROAD TEST PROCEDURE

1. Check before engine is started.



2. Check at idle.



3. Cruise test.

SAT786A

Road Test

DESCRIPTION

- The purpose of the test is to determine overall performance of A/T and analyze causes of problems.
- The road test consists of the following three parts:
 1. Check before engine is started
 2. Check at idle
 3. Cruise test

- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items until specified symptom is found. Troubleshoot items which check out No Good after road test. Refer to "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION" and "DIAGNOSTIC PROCEDURES FOR SYMPTOMS", AT-1028 - AT-1034 and AT-1097 - AT-1115.








SAT496G

TROUBLE DIAGNOSIS — Basic Inspection

Road Test (Cont'd)

1. CHECK BEFORE ENGINE IS STARTED



1. Park vehicle on flat surface.
2. Turn ignition switch to "OFF" position.

1. Set A/T mode switch to "AUTO" position.
2. Move selector lever to "P" position.
3. Turn ignition switch to "ON" position.
(Do not start engine.)
4. Does SPORT indicator lamp come on for about 2 seconds?

No → Go to 1. SPORT Indicator Lamp Does Not Come On, AT-1097.

Yes

- Does SPORT indicator lamp flicker for about 8 seconds?

Yes → Perform self-diagnosis.
Refer to SELF-DIAGNOSIS PROCEDURE, AT-1028.

No

1. Set A/T mode switch to "SPORT" position.
2. Does SPORT indicator lamp come on?

No → Go to 2. SPORT Indicator Lamp Does Not Come On, AT-1098.

Yes

- Set overdrive control switch to "OFF" position.

- Does O/D OFF indicator lamp come on?





No → Go to 3. O/D OFF Indicator Lamp Does Not Come On, AT-1098.

Yes

(Go to next page)

TROUBLE DIAGNOSIS — Basic Inspection


Road Test (Cont'd)



TROUBLE DIAGNOSIS — Basic Inspection

Road Test (Cont'd)

2. CHECK AT IDLE



1. Park vehicle on flat surface.
2. Turn ignition switch to "OFF" position.
3. Move selector lever to "P" or "N" position.
4. Turn ignition switch to start position.
5. Is engine started?

Yes

1. Turn ignition switch to "OFF" position.
2. Move selector lever to "D", "1", "2" or "R" position.
3. Turn ignition switch to start position.
4. Is engine started?

No

No → Go to "5. Engine Cannot Be Started In "P" and "N" Position", AT-1100.

Yes → Go to "5. Engine Cannot Be Started In "P" and "N" Position", AT-1100.

1. Turn ignition switch to "OFF" position.
2. Move selector lever to "P" position.
3. Release parking brake.
4. Push vehicle forward or backward.
5. Does vehicle move when it is pushed forward or backward?

No

Yes → Go to "6. In "P" Position, Vehicle Moves Forward Or Backward When Pushed", AT-1100.

1. Apply parking brake.
2. Move selector lever to "N" position.
3. Turn ignition switch to "START" position and start engine.
4. Release parking brake.
5. Does vehicle move forward or backward?

Yes → Go to "7. In "N" Position, Vehicle Moves", AT-1101.

1. Apply foot brake.
2. Move selector lever to "R" position.
3. Is there large shock when changing from "N" to "R" position?

Yes → Go to "8. Large Shock. "N" → "R" Position", AT-1102.

1. Release foot brake for several seconds.
2. Does vehicle creep backward when foot brake is released?

No → Go to "9. Vehicle Does Not Creep Backward In "R" Position", AT-1103.

1. Move selector lever to "D", "1" and "2" position and check if vehicle creeps forward.
2. Does vehicle creep forward in all three positions?

No → Go to "10. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position", AT-1104.

Yes → Go to "3. Cruise test", AT-1050.

TROUBLE DIAGNOSIS — Basic Inspection






Road Test (Cont'd)

3. CRUISE TEST

- Check all items listed in Parts 1 through 3.

With CONSULT-II

- Using CONSULT-II, conduct a cruise test and record the result.
- Print the result and ensure that shifts and lock-ups take place as per Shift Schedule.



CONSULT-II Setting Procedure

- Turn ignition switch OFF.
- Connect CONSULT-II to data link connector, which is located in instrument lower panel on driver side.


- Turn ignition switch ON.
- Touch "START".

- Touch "A/T".


- Touch "DATA MONITOR".

TROUBLE DIAGNOSIS — Basic Inspection


Road Test (Cont'd)




SAT175K




SAT973J



SAT985J



SAT986J



SAT987J

7. Touch "MAIN SIGNALS" or "TCM INPUT SIGNALS".
8. See "Numerical Display", "Barchart Display" or "Line Graph Display".

9. Touch "SETTING" to set recording condition ("AUTO TRIG" or "MANU TRIG") and touch "BACK".

10. Touch "Start".


11. When performing cruise test, touch "Store Data".

12. After finishing cruise test part 1, touch "STOP".

13. Touch "STORE" and touch "BACK".


TROUBLE DIAGNOSIS — Basic Inspection

Road Test (Cont'd)



SAT974J

SAT975J



SAT215J





Without CONSULT-II

- Throttle position can be checked by voltage across terminals ④① and ④② of TCM.

TROUBLE DIAGNOSIS — Basic Inspection

Road Test (Cont'd)

CRUISE TEST — Part 1



Drive vehicle for approx. 10 minutes to warm engine oil and ATF up to operating temperature.

ATF operating temperature:
50 - 80°C (122 - 176°F)

A B

1. Park vehicle on flat surface.
2. Set overdrive control switch to "ON" position.
3. Move selector lever to "P" position.
4. Start engine.

C

Move selector lever to "D" position.

D

Accelerate vehicle by constantly depressing accelerator pedal halfway.

Does vehicle start from D₁?
Read gear position.

No

Go to "11. Vehicle Cannot Be Started From D₁", AT-1105.

Yes

E

Does A/T shift from D₁ to D₂ at the specified speed?

Read gear position, throttle opening and vehicle speed.

Specified speed when shifting from D₁ to D₂:
Refer to Shift schedule, AT-1206.

No

Go to "12. A/T Does Not Shift: D₁ → D₂ Or Does Not Kickdown: D₄ → D₂", AT-1106.

Yes

F

Does A/T shift from D₂ to D₃ at the specified speed?

Read gear position, throttle position and vehicle speed.

Specified speed when shifting from D₂ to D₃:
Refer to Shift schedule, AT-1206.

No

Go to "13. A/T Does Not Shift: D₂ → D₃", AT-1107.




Yes

(A)

(Go to next page.)

TROUBLE DIAGNOSIS — Basic Inspection





Road Test (Cont'd)



TROUBLE DIAGNOSIS — Basic Inspection

Road Test (Cont'd)

CRUISE TEST — Part 2



A

1. Confirm overdrive control switch is in "ON" position.
2. Confirm selector lever is in "D" position.
3. Accelerate vehicle by half throttle again.
4. Does vehicle start from D₁?

Read gear position.

No → Go to "19. Vehicle Does Not Start From D₁", AT-1112.

Yes

B

1. Accelerate vehicle to 80 km/h (50 MPH) as shown in illustration.
2. Release accelerator pedal and then quickly depress it fully.
3. Does A/T shift from D₄ to D₂ as soon as accelerator pedal is depressed fully?

Read gear position and throttle position.

No → Go to "12. A/T Does Not Shift: D₁ → D₂ Or Does Not Kickdown: D₄ → D₂", AT-1106.

Yes

C

Does A/T shift from D₂ to D₃ at the specified speed?

Read gear position, throttle position and vehicle speed.

Specified speed when shifting from D₂ to D₃:
Refer to Shift schedule, AT-1206.

No → Go to "13. A/T Does Not Shift: D₂ → D₃", AT-1107.

Yes

D

1. Release accelerator pedal after shifting from D₂ to D₃.
2. Does A/T shift from D₃ to D₄ and does vehicle decelerate by engine brake?

Read gear position, throttle position and vehicle speed.

No → Go to "14. A/T Does Not Shift: D₃ → D₄", AT-1108.

Yes

E

1. Decelerate to 10 km/h (6 MPH) with accelerator pedal released and then quickly depress it fully.
2. Does A/T shift from D₂ to D₁ as soon as accelerator pedal is depressed fully?

No → Go to "20. A/T Does Not Shift: D₂ → D₁ When Depressing Accelerator Pedal", AT-1113.






Yes

1. Stop vehicle.
2. Go to "Cruise test — Part 3", AT-1056.

TROUBLE DIAGNOSIS — Basic Inspection

Road Test (Cont'd)

CRUISE TEST — Part 3



1. Confirm overdrive control switch is in "ON" position.
2. Confirm selector lever is in "D" position.

A
Accelerate vehicle using half-throttle to D₄.

B
Release accelerator pedal.

C
Set overdrive control switch to "OFF" position while driving in D₄.

D
Does A/T shift from D₄ to D₃ (O/D OFF)?
Read gear position and vehicle speed.

No
Go to "21. A/T Does Not Shift: D₄ → D₃, When Overdrive Control Switch "ON" → "OFF", AT-1114."

E
Does vehicle decelerate by engine brake?
Yes
No
Go to "18. Engine Speed Does Not Return To Idle (Light Braking D₄ → D₃)", AT-1111.

F
Move selector lever from "D" to "2" position while driving in D₃ (O/D OFF).

G
Does A/T shift from D₃ (O/D OFF) to 2₂?
Read gear position.

No
Go to "22. A/T Does Not Shift: D₃ → 2₂, When Selector Lever "D" → "2" Position", AT-1114.

H
Does vehicle decelerate by engine brake?
Yes
No
Go to "18. Engine Speed Does Not Return To Idle (Light Braking D₄ → D₃)", AT-1111.

I, J
1. Move selector lever from "2" to "1" position while driving in 2₂.
2. Does A/T shift from 2₂ to 1₁ position?
Read gear position.

No
Go to "23. A/T Does Not Shift: 2₂ → 1₁, When Selector Lever "2" → "1" Position", AT-1115.

K
Does vehicle decelerate by engine brake?
Yes
No
Go to "24. Vehicle Does Not Decelerate By Engine Brake", AT-1115.

1. Stop vehicle.
2. Perform self-diagnosis. Refer to SELF-DIAGNOSTIC PROCEDURE, AT-1028.

TROUBLE DIAGNOSIS — General Description

Symptom Chart

Reference page (AT-)		ON vehicle										OFF vehicle										
		1041, 1126	1125	1064, 1066 1082	1044	1070, 1148	1072, 1084	1076, 1074	1079, 1124	1124	1124	1133, 1144	1161, 1165	1167, 1177	1167, 1175	1171, 1137	1184					
Reference page (AT-)	Numbers are arranged in order of probability. Perform inspections starting with number one and work up. Circled numbers indicate that the transmission must be removed from the vehicle.																					
1100	Engine does not start in "N", "P" positions.	.	2	3	
1100	Engine starts in position other than "N" and "P".	.	1	2	
—	Transmission noise in "P" and "N" positions.	1	.	3	4	5	2	⑦	⑥	.	.	.	
1100	Vehicle moves when changing into "P" position or parking gear does not disengage when shifted out of "P" position.	.	1	②	
1101	Vehicle runs in "N" position.	.	1	2	.	.	④	③	⑤	.	
1103	Vehicle will not run in "R" position (but runs in "D", "2" and "1" positions). Clutch slips. Very poor acceleration.	.	1	2	4	.	3	⑤	⑥	⑦	⑧	⑨	
—	Vehicle braked when shifting into "R" position.	1	2	3	5	.	4	⑥	⑧	⑨	⑦	.
—	Sharp shock in shifting from "N" to "D" position.	.	.	2	.	5	1	3	7	.	6	.	4	8	.	.	.	⑩
—	Vehicle will not run in "D" and "2" positions (but runs in "1" and "R" position).	.	1	②	.	.
1104	Vehicle will not run in "D", "1" and "2" positions (but runs in "R" position). Clutch slips. Very poor acceleration.	1	2	4	.	3	.	.	5	.	.	.	⑥	⑦	⑧	⑨	⑩	
—	Clutches or brakes slip somewhat in starting.	1	2	.	3	.	.	4	6	.	5	.	.	7	.	8	⑬	⑫	⑩	⑨	⑪	.
—	Excessive creep.	1
1103 - 1104	No creep at all.	1	2	3	⑥	⑤	.	④	.	.	.
—	Failure to change gear from "D ₁ " to "D ₂ ".	.	2	1	.	5	.	.	4	3	⑥	.
—	Failure to change gear from "D ₂ " to "D ₃ ".	.	2	1	.	5	.	.	4	.	3	⑥	.	.	.	⑦	.
—	Failure to change gear from "D ₃ " to "D ₄ ".	.	2	1	.	4	.	.	3	.	.	.	5	⑥	.
1106 - 1107, 1108	Too high a gear change point from "D ₁ " to "D ₂ ", from "D ₂ " to "D ₃ ", from "D ₃ " to "D ₄ ".	.	.	.	1	2	.	.	3	4
—	Gear change directly from "D ₁ " to "D ₃ " occurs.	1	2	③	.
—	Engine stops when shifting lever into "R", "D", "2" and "1".	1	.	3	.	.	2	.	.	.	④
—	Too sharp a shock in change from "D ₁ " to "D ₂ ".	.	.	.	1	.	.	2	4	.	.	.	5	.	3	⑥	.
—	Too sharp a shock in change from "D ₂ " to "D ₃ ".	.	.	.	1	.	.	2	4	3	.	.	⑤	.	.	.	⑥	.

TROUBLE DIAGNOSIS — General Description

Symptom Chart (Cont'd)


Reference page (AT-)		ON vehicle												OFF vehicle					
		1041, 1126	1125	1064, 1066 1082	1044	1070, 1148	1072, 1084	1076, 1074	1079, 1124	1124	1124	1133, 1144	1161, 1165	1167, 1177	1167, 1175	1171, 1137	1184		
Reference page (AT-)	Numbers are arranged in order of probability. Perform inspections starting with number one and work up. Circled numbers indicate that the transmission must be removed from the vehicle.	Fluid level Control linkage																	
—	Too sharp a shock in change from "D ₃ " to "D ₄ ".	.	.	1	.	.	2	4	3	
—	Almost no shock or clutches slipping in change from "D ₁ " to "D ₂ ".	1	.	2	.	.	3	5	4	
—	Almost no shock or slipping in change from "D ₂ " to "D ₃ ".	1	.	2	.	.	3	5	4	.	.	.	⑥	
—	Almost no shock or slipping in change from "D ₃ " to "D ₄ ".	1	.	2	.	.	3	5	4	.	.	.	⑦	
—	Vehicle braked by gear change from "D ₁ " to "D ₂ ".	1	②	④	.	⑤	
—	Vehicle braked by gear change from "D ₂ " to "D ₃ ".	1	②	
—	Vehicle braked by gear change from "D ₃ " to "D ₄ ".	1	④	.	③	②	.	
—	Maximum speed not attained. Acceleration poor.	1	.	2	.	.	5	3	4	⑪	⑩	⑥	⑦	⑨	⑧
—	Failure to change gear from "D ₄ " to "D ₃ ".	1	.	2	.	.	6	4	5	3	⑧	⑦	.
—	Failure to change gear from "D ₃ " to "D ₂ " or from "D ₄ " to "D ₂ ".	1	.	2	.	.	5	3	4	⑥	.	.	⑦	
—	Failure to change gear from "D ₂ " to "D ₁ " or from "D ₃ " to "D ₁ ".	1	.	2	.	.	5	3	4	⑦	.	⑥	⑧	
—	Gear change shock felt during deceleration by releasing accelerator pedal.	.	.	1	.	.	2	4	.	.	3	
—	Too high a change point from "D ₄ " to "D ₃ ", from "D ₃ " to "D ₂ ", from "D ₂ " to "D ₁ ".	.	.	1	2	
—	Kickdown does not operate when depressing pedal in "D ₄ " within kickdown vehicle speed.	.	.	1	2	.	.	3	4	
—	Kickdown operates or engine overruns when depressing pedal in "D ₄ " beyond kickdown vehicle speed limit.	.	.	2	1	.	.	3	4	
—	Races extremely fast or slips in changing from "D ₄ " to "D ₃ " when depressing pedal.	1	.	2	.	.	3	5	.	4	⑥	⑦	.	.	
—	Races extremely fast or slips in changing from "D ₄ " to "D ₂ " when depressing pedal.	1	.	2	.	.	3	6	5	.	4	.	.	.	⑧	.	.	⑦	
—	Races extremely fast or slips in changing from "D ₃ " to "D ₂ " when depressing pedal.	1	.	2	.	.	3	5	.	4	.	6	.	7	.	⑩	⑨	.	
—	Races extremely fast or slips in changing from "D ₄ " or "D ₃ " to "D ₁ " when depressing pedal.	1	.	2	.	.	3	5	.	4	⑥	⑦	⑧	.	
—	Vehicle will not run in any position.	1	2	.	.	.	3	.	4	⑨	⑤	⑥	.	⑧	
—	Transmission noise in "D", "2", "1" and "R" positions.	1	②	

TROUBLE DIAGNOSIS — General Description

Symptom Chart (Cont'd)

Reference page (AT-)		ON vehicle												OFF vehicle					
		1041, 1126	1125	1064, 1066 1082	1044	1070, 1148	1072, 1084	1076, 1074	1079, 1124	1124	1124	1133, 1144	1161, 1165	1167, 1177	1167, 1175	1171, 1137	1184		
	Numbers are arranged in order of probability. Perform inspections starting with number one and work up. Circled numbers indicate that the transmission must be removed from the vehicle.	Fluid level Control linkage PNP switch Throttle (accelerator) position sensor (Adjustment) Revolution sensor and vehicle speed sensor Engine speed signal Engine idling speed Line pressure Control valve assembly Shift solenoid valve A Shift solenoid valve B Line pressure solenoid valve Torque converter clutch solenoid valve Overrun clutch solenoid valve A/T fluid temperature sensor Accumulator N-D Accumulator 1-2 Accumulator 2-3 Accumulator 3-4 (N-R) Ignition switch and starter Torque converter Oil pump Reverse clutch High clutch Forward clutch Forward one-way clutch Overrun clutch Low one-way clutch Low & reverse brake Brake band Parking pawl components																	
1111	Failure to change from "D ₃ " to "2" when changing lever into "2" position.	. 7 1 2	6 5	4	. .	3	
—	Gear change from "2 ₁ " to "2 ₂ " in "2" position.	. . 1	
1112	Engine brake does not operate in "1" position.	. 2 1 3 4	. . .	6 5	. . .	7	
—	Gear change from "1 ₁ " to "1 ₂ " in "1" position.	. 2 1	
—	Does not change from "1 ₂ " to "1 ₁ " in "1" position.	. . 1 . 2	. . .	4 3	. . .	5	
—	Large shock changing from "1 ₂ " to "1 ₁ " in "1" position.	1	
—	Transmission overheats.	1 . . 3	. . .	2 4 6	. . 5	
	ATF shoots out during operation. White smoke emitted from exhaust pipe during operation.	1	
—	Offensive smell at fluid charging pipe.	1	
—	Torque converter is not locked up.	. . 3 1 2 4	. 6 8	. . .	7	5	
—	Torque converter clutch piston slip	1 . . 2	. . .	3 6	. . 5	4	. . .	3	
1109	Lock-up point is extremely high or low.	. . . 1 2	. . .	4	. . .	3	
—	A/T does not shift to "D ₄ " when driving with overdrive control switch "ON".	. . 2 1 3	. . .	8 6 4	. . .	5 7	
—	Engine is stopped at "R", "D", "2" and "1" positions.	1	5 4 3	. . 2	

TROUBLE DIAGNOSIS — General Description




TCM Terminals and Reference Value

PREPARATION

- Measure voltage between each terminal and terminal 25 or 48 by following "TCM INSPECTION TABLE".

TCM HARNESS CONNECTOR TERMINAL LAYOUT

TCM harness connector



SAT217J

TCM INSPECTION TABLE

(Data are reference values.)

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
1	G/Y	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine. 1.5 - 3.0V	
				When depressing accelerator pedal fully after warming up engine. 0V	
2	BR/Y	Line pressure solenoid valve (with dropping resistor)		When releasing accelerator pedal after warming up engine. 5 - 14V	
				When depressing accelerator pedal fully after warming up engine. 0V	
3	G/OR	Torque converter clutch solenoid valve		When A/T performs lock-up. 8 - 15V	
				When A/T does not perform lock-up. 0V	
4	—	—		—	
5*	PU/W	DT1		Refer to EC section.	
6*	P/B	DT2		—	
7*	P	DT3		Refer to EC section.	
8	—	—		—	
9*	L/OR	DT4		When turning ignition switch to "ON". Battery voltage	
10	G/OR	Power source		When turning ignition switch to "OFF". 0V	

*: These terminals are connected to the ECM.

TROUBLE DIAGNOSIS — General Description


TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
11	L/W	Shift solenoid valve A	 <p>When shift solenoid valve A operates. (When driving in "D₁" or "D₄".)</p> <p>When shift solenoid valve A does not operate. (When driving in "D₂" or "D₃".)</p>	Battery voltage
12	L/R	Shift solenoid valve B		0V
13	R/W	SPORT indicator lamp	 <p>When setting A/T mode switch in "SPORT" position.</p> <p>When setting A/T mode switch in other positions.</p>	Battery voltage
14*1	P/B	N position signal		Refer to EC section.
15	—	—	 <p>—</p>	—
16	R/L	Closed throttle position switch (in throttle (accelerator) position switch)	 <p>When releasing accelerator pedal after warming up engine.</p> <p>When depressing accelerator pedal after warming up engine.</p>	Battery voltage
17	W/G	Wide open throttle position switch (in throttle (accelerator) position switch)		0V
18	—	—	 <p>—</p>	—
19	G/OR	Power source	 <p>Same as No. 10</p>	

*1: These terminals are connected to the ECM.

TROUBLE DIAGNOSIS — General Description

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
20	L/B	Overrun clutch solenoid valve	 	When overrun clutch solenoid valve operates.	
				0V	
21	—	—	 	—	
22	GY	Overdrive control switch		When setting overdrive control switch in "ON" position	
				0V	
23	—	—		—	
24	—	—		—	
25	B	Ground	 	—	
26	G	PNP "1" position switch		When setting selector lever to "1" position.	
				0V	
27	G/W	PNP "2" position switch	 	When setting selector lever to "2" position.	
				0V	
28	R/Y	Power source (Back-up)	 	When turning ignition switch to "OFF".	
				Battery voltage	
29	W	Revolution sensor (Measure in AC range)		When vehicle cruises at 30 km/h (19 MPH).	
				0V	
30*1	Y/G	(RX)	 	—	
31*1	Y/R	(TX)		—	
32	G/R	Accelerator position sensor (Power source)	 	Turn ignition switch to "ON".	
				4.5 - 5.5V	
33	—	—		Turn ignition switch to "OFF".	
				0V	


*1: These terminals are connected to the data link connector.

TROUBLE DIAGNOSIS — General Description

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
34	P	PNP "D" position switch	 	When setting selector lever to "D" position. Battery voltage
				When setting selector lever to other positions. 0V
35	Y	PNP "R" position switch	 	When setting selector lever to "R" position. Battery voltage
				When setting selector lever to other positions. 0V
36	W	PNP "N" or "P" position switch	 	When setting selector lever to "N" or "P" position. Battery voltage
				When setting selector lever to other positions. 0V
37	—	—		—
38	—	—		—
39	Y/B	Engine speed signal	 	Refer to EC section.
40	L/OR	Vehicle speed sensor		When moving vehicle at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more. Voltage varies between less than 0V and more than 4.5V.
41	B/W	Accelerator position sensor		When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.) Fully-closed throttle: 0.5 - 0.7V Fully-open throttle: 4V
42	B	Accelerator position sensor (Ground)		— 0V
43	W/G	A/T mode switch ("SPORT")		When setting A/T mode switch in "SPORT" position. Battery voltage
				When setting A/T mode switch in other positions. 0V
44	Y/R	A/T mode switch ("*")		When setting A/T mode switch in "*" position. Battery voltage
				When setting A/T mode switch in other positions. 0V
45	—	—		—
46	—	—		—
47	R	A/T fluid temperature sensor		When ATF temperature is 20°C (68°F). 1.5V
				When ATF temperature is 80°C (176°F). 0.5V
48	B	Ground		— 0V

TROUBLE DIAGNOSIS FOR VHCL SPEED SEN-A/T




Vehicle Speed Sensor·A/T (Revolution sensor)

DESCRIPTION

The revolution sensor detects the revolution of the out put shaft parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed.

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: VHCL SPEED SEN-A/T	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Revolution sensor
1st judgement flicker		




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 30 km/h (19 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 5 seconds.

OR





- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 30 km/h (19 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 5 seconds.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.



TROUBLE DIAGNOSIS FOR VHCL SPEED SEN·A/T

Vehicle Speed Sensor·A/T (Revolution sensor) (Cont'd)

DIAGNOSTIC PROCEDURE




COMPONENT INSPECTION

Revolution sensor

- For removal, refer to AT-1124.
- Check resistance between terminals ①, ② and ③.

Terminal No.	Resistance
①	②
②	③
①	③

TROUBLE DIAGNOSIS FOR VHCL SPEED SEN·MTR



SAT237J


Vehicle Speed Sensor·MTR

DESCRIPTION

The vehicle speed sensor·MTR is built into the speedometer assembly. The sensor functions as an auxiliary device to the revolution sensor when it is malfunctioning. The TCM will then use a signal sent from the vehicle speed sensor·MTR.

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: VHCL SPEED SEN·MTR	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none">• Harness or connectors (The sensor circuit is open or shorted.)• Vehicle speed sensor
2nd judgement flicker		



SAT014K


SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position and vehicle speed higher than 20 km/h (12 MPH).

OR




- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position and vehicle speed higher than 20 km/h (12 MPH).
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.




SAT807H

TROUBLE DIAGNOSIS FOR VHCL SPEED SEN·MTR

Vehicle Speed Sensor·MTR (Cont'd) DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR THROTTLE POSI SEN



Accelerator Position Sensor

DESCRIPTION

The accelerator position sensor detects the throttle valve position and sends a signal to the TCM.


ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: THROTTLE POSI SEN	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Accelerator position sensor
: 3rd judgement flicker		

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Accelerator position sensor	Fully-closed throttle	Approximately 0.5V
	Fully-open throttle	Approximately 4V




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 3 seconds.




OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 3 seconds.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.




TROUBLE DIAGNOSIS FOR THROTTLE POSI SEN

Accelerator Position Sensor (Cont'd) DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR SHIFT SOLENOID/V A



Shift Solenoid Valve A


DESCRIPTION

Shift solenoid valves A and B are turned “ON” or “OFF” by the TCM in response to signals sent from the inhibitor switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.

Gear position	1	2	3	4
Shift solenoid valve A	ON	OFF	OFF	ON
Shift solenoid valve B	ON	ON	OFF	OFF

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: SHIFT SOLENOID/V A	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Shift solenoid valve A
: 4th judgement flicker		




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select “SELF-DIAG RESULTS” mode for A/T with CONSULT-II.
- 3) Drive vehicle in $D_1 \rightarrow D_2$ position.






OR

- 1) Start engine.
- 2) Drive vehicle in $D_1 \rightarrow D_2$ position.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.



TROUBLE DIAGNOSIS FOR SHIFT SOLENOID/V A

Shift Solenoid Valve A (Cont'd) DIAGNOSTIC PROCEDURE



COMPONENT INSPECTION


Shift solenoid valve A

- For removal, refer to AT-1124.

Resistance check

- Check resistance between terminal ③ and ground.


Solenoid valve	Terminal No.	Resistance (Approx.)
Shift solenoid valve A	③	Ground 20 - 40Ω



Operation check

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal ③ and ground.

TROUBLE DIAGNOSIS FOR SHIFT SOLENOID/V B



Shift Solenoid Valve B


DESCRIPTION

Shift solenoid valves A and B are turned “ON” or “OFF” by the TCM in response to signals sent from the inhibitor switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.

Gear position	1	2	3	4
Shift solenoid valve A	ON	OFF	OFF	ON
Shift solenoid valve B	ON	ON	OFF	OFF

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: SHIFT SOLENOID/V B	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Shift solenoid valve B
: 5th judgement flicker		




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.






- 1) Start engine.
- 2) Select “SELF-DIAG RESULTS” mode for A/T with CONSULT-II.
- 3) Drive vehicle in $D_1 \rightarrow D_2 \rightarrow D_3$ position.
OR

- 1) Start engine.
- 2) Drive vehicle in $D_1 \rightarrow D_2 \rightarrow D_3$ position.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.




TROUBLE DIAGNOSIS FOR SHIFT SOLENOID/V B

Shift Solenoid Valve B (Cont'd) DIAGNOSTIC PROCEDURE



NG


1. Remove control valve assembly. Refer to AT-1124.
2. Check the following items:
 - Shift solenoid valve B Refer to "COMPONENT INSPECTION" below.
 - Harness of terminal cord assembly for short or open



OK

NG

Repair open circuit or short to ground or short to power in harness or connector.



OK

NG

1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

COMPONENT INSPECTION

Shift solenoid valve B

- For removal, refer to AT-1124.

Resistance check


- Check resistance between terminal ② and ground.

Solenoid valve	Terminal No.	Resistance (Approx.)	
Shift solenoid valve B	②	Ground	20 - 40Ω

Operation check

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal ② and ground.

TROUBLE DIAGNOSIS FOR OVERRUN CLUTCH S/V




Overrun Clutch Solenoid Valve

DESCRIPTION

The overrun clutch solenoid valve is activated by the TCM in response to signals sent from the inhibitor switch, overdrive control switch, vehicle speed and throttle position sensors. The overrun clutch operation will then be controlled.

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: OVERRUN CLUTCH S/V	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Overrun clutch solenoid valve
: 6th judgement flicker		




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, overdrive control switch in "OFF" position and vehicle speed higher than 10 km/h (6 MPH).





OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, overdrive control switch in "OFF" position and vehicle speed higher than 10 km/h (6 MPH).
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.



TROUBLE DIAGNOSIS FOR OVERRUN CLUTCH S/V

Overrun Clutch Solenoid Valve (Cont'd) DIAGNOSTIC PROCEDURE



A

CHECK GROUND CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ④ and ground.

Resistance: 20 - 40Ω

OK

NG

1. Remove control valve assembly. Refer to AT-1124.
2. Check the following items:
 - Overrun clutch solenoid valve
Refer to "COMPONENT INSPECTION" below.
 - Harness of terminal cord assembly for short or open

B

CHECK POWER SOURCE CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect TCM harness connector.
3. Check resistance between terminal ④ and TCM harness connector terminal ⑩.

Resistance:

Approximately 0Ω

If OK, check harness for short to ground and short to power.

4. Reinstall any part removed.

OK

NG

Repair open circuit or short to ground or short to power in harness or connector.

OK

NG

1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

COMPONENT INSPECTION

Overrun clutch solenoid valve

- For removal, refer to AT-1124.

Resistance check


- Check resistance between terminal ④ and ground.

Solenoid valve	Terminal No.	Resistance (Approx.)	
Overrun clutch solenoid valve	④	Ground	20 - 40Ω

Operation check

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal ④ and ground.

TROUBLE DIAGNOSIS FOR T/C CLUTCH SOL/V



Torque Converter Clutch Solenoid Valve

DESCRIPTION

The torque converter clutch solenoid valve is activated, with the gear in D₄, by the TCM in response to signals sent from the vehicle speed and throttle (accelerator) position sensors. Torque converter clutch piston operation will then be controlled. Lock-up operation, however, is prohibited when A/T fluid temperature is too low.


ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: T/C CLUTCH SOL/V	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • T/C clutch solenoid valve
: 7th judgement flicker		

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF" ↓ Lock-up "ON"	Approximately 4% ↓ Approximately 94%




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) Drive vehicle in D₁ → D₂ → D₃ → D₄ → D₄ lock-up position.

OR



- 1) Start engine.
- 2) Drive vehicle in D₁ → D₂ → D₃ → D₄ → D₄ lock-up position.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.



TROUBLE DIAGNOSIS FOR T/C CLUTCH SOL/V

Torque Converter Clutch Solenoid Valve (Cont'd)

DIAGNOSTIC PROCEDURE



A

CHECK GROUND CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal 7 and ground.

Resistance: 10 - 20Ω

NG

1. Remove oil pan. Refer to AT-1124.
2. Check the following items:
 - Torque converter clutch solenoid valve Refer to "COMPONENT INSPECTION" on next page.
 - Harness of terminal cord assembly for short or open

OK

B

CHECK POWER SOURCE CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect TCM harness connector.
3. Check resistance between terminal 7 and TCM harness connector terminal 3.

Resistance:

Approximately 0Ω

If OK, check harness for short to ground and short to power.

4. Reinstall any part removed.

NG

Repair open circuit or short to ground or short to power in harness or connector.

OK

Perform "SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE", AT-1076.

NG

1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

INSPECTION END

TROUBLE DIAGNOSIS FOR T/C CLUTCH SOL/V

Torque Converter Clutch Solenoid Valve (Cont'd)

COMPONENT INSPECTION



Torque converter clutch solenoid valve

- For removal, refer to AT-1124.

Resistance check

- Check resistance between terminal ⑦ and ground.


Solenoid valve	Terminal No.		Resistance (Approx.)
Torque converter clutch solenoid valve	⑦	Ground	10 - 20Ω



Operation check

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal ⑦ and ground.

TROUBLE DIAGNOSIS FOR BATT/FLUID TEMP SEN



A/T Fluid Temperature Sensor and TCM Power Source

DESCRIPTION

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM.


ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: BATT/FLUID TEMP SEN	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • A/T fluid temperature sensor
: 8th judgement flicker		

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)] ↓ Hot [80°C (176°F)]	Approximately 1.5V ↓ Approximately 0.5V




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full open position, engine speed higher than 450 rpm and driving for more than 10 minutes.



OR



- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full open position, engine speed higher than 450 rpm and driving for more than 10 minutes.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.

TROUBLE DIAGNOSIS FOR BATT/FLUID TEMP SEN

A/T Fluid Temperature Sensor and TCM Power Source (Cont'd) DIAGNOSTIC PROCEDURE



A

CHECK TCM POWER SOURCE.

1. Turn ignition switch to "ON" position.
(Do not start engine.)
2. Check voltage between TCM terminals ⑩, ⑯ and ground.

Battery voltage should exist.

NG

Check the following items:

- Harness for short or open between ignition switch and TCM (Main harness)
- Ignition switch and fuse
Refer to EL section ("POWER SUPPLY ROUTING").

OK

B

CHECK A/T FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY.

1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminals ⑧ and ⑨ when A/T is cold.
Resistance:
Cold [20°C (68°F)]
Approximately 2.5 kΩ
4. Reinstall any part removed.

NG

1. Remove oil pan.
2. Check the following items:
 - A/T fluid temperature sensor
Refer to "COMPONENT INSPECTION" on next page.
 - Harness of terminal cord assembly for short or open





OK

Ⓐ

(Go to next page.)

TROUBLE DIAGNOSIS FOR BATT/FLUID TEMP SEN

A/T Fluid Temperature Sensor and TCM Power Source (Cont'd)



COMPONENT INSPECTION

A/T fluid temperature sensor

- For removal, refer to AT-1124.
- Check resistance between terminals 8 and 9 while changing temperature as shown at left.

Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ

TROUBLE DIAGNOSIS FOR ENGINE SPEED SIG


Engine Speed Signal

DESCRIPTION

The engine speed signal is sent from the ECM to the TCM.

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : ENGINE SPEED SIG	TCM does not receive the proper voltage signal from ECM.	<ul style="list-style-type: none">• Harness or connectors (The sensor circuit is open or shorted.)
 : 9th judgement flicker		




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 10 seconds.




OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 10 seconds.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.




TROUBLE DIAGNOSIS FOR ENGINE SPEED SIG

Engine Speed Signal (Cont'd) DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR LINE PRESSURE S/V



Line Pressure Solenoid Valve

DESCRIPTION

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.


ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: LINE PRESSURE S/V	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Line pressure solenoid valve
: 10th judgement flicker		

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Line pressure solenoid valve duty	Low line-pressure (Small throttle opening) ↓ High line-pressure (Large throttle opening)	Approximately 0% ↓ Approximately 95%




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for A/T with CONSULT-II.
- 3) With brake pedal depressed, shift the lever from "P" → "N" → "D" → "N" → "P" positions.



OR

- 1) Start engine.
- 2) With brake pedal depressed, shift the lever from "P" → "N" → "D" → "N" → "P" positions.
- 3) Perform self-diagnosis.
Refer to SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II), AT-1029.



TROUBLE DIAGNOSIS FOR LINE PRESSURE S/V

Line Pressure Solenoid Valve (Cont'd) DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR LINE PRESSURE S/V

Line Pressure Solenoid Valve (Cont'd) COMPONENT INSPECTION


Line pressure solenoid valve

- For removal, refer to AT-1124.

Resistance check


- Check resistance between terminal ⑥ and ground.

Solenoid valve	Terminal No.	Resistance (Approx.)
Line pressure solenoid valve	⑥	Ground 2.5 - 5Ω



Operation check


- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal ⑥ and ground.




Dropping resistor

- Check resistance between terminals ① and ②.

Resistance: 11.2 - 12.8Ω



TROUBLE DIAGNOSIS FOR CONTROL UNIT (RAM), CONTROL UNIT (ROM)




Description

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the A/T.

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
 : CONTROL UNIT (RAM)	TCM memory (RAM) or (ROM) is malfunctioning.	TCM
 : CONTROL UNIT (ROM)		




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NOTE:

If "SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.




TROUBLE DIAGNOSIS FOR CONTROL UNIT (RAM), CONTROL UNIT (ROM)

Diagnostic Procedure

1	CHECK DTC
 WITH CONSULT-II	
1. Turn ignition switch "ON" and select "SELF DIAG RESULTS" mode for A/T with CONSULT-II. 2. Touch "ERASE". Perform Self-diagnosis Code confirmation procedure. See previous page.	
Is the "CONTROL UNIT (RAM) or CONTROL UNIT (ROM)" displayed again?	
Yes	► Replace TCM.
No	► INSPECTION END

TROUBLE DIAGNOSIS FOR CONTROL UNIT (EEP ROM)




Description

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the A/T.

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
 : CONT UNIT (EEP ROM)	TCM memory (EEP ROM) is malfunctioning.	TCM




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NOTE:

If "SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.




TROUBLE DIAGNOSIS FOR CONTROL UNIT (EEP ROM)

Diagnostic Procedure

1	CHECK DTC
 WITH CONSULT-II	
1. Turn ignition switch "ON" and select "SELF DIAG RESULTS" mode for A/T with CONSULT-II. 2. Move selector lever to "R" position. 3. Depress accelerator pedal (Full throttle position). 4. Touch "ERASE". 5. Turn ignition switch "OFF" position for 10 seconds. Perform Self-diagnosis Code confirmation procedure. See previous page.	
Is the "CONT UNIT (EEP ROM)" displayed again?	
Yes	► Replace TCM.
No	► INSPECTION END



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS



PNP, Overdrive Control, A/T Mode or Accelerator Position Switches

DESCRIPTION

- PNP switch
Detects the selector lever position and sends a signal to the TCM.
- Overdrive control switch, A/T mode switch
Detects the overdrive control switch position (ON or OFF) and sends a signal to the TCM.
- Accelerator position switch
Consists of a wide open throttle position switch and a closed Accelerator position switch.
The wide open throttle position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS


PNP, Overdrive Control, A/T Mode or Accelerator Position Switches (Cont'd)

DIAGNOSTIC PROCEDURE

A

DATA MONITOR	
MONITORING	
VHCL/S SE-A/T	XXX km/h
VHCL/S SE-MTR	XXX km/h
THRTL POS SEN	XXX V
FLUID TEMP SE	XXX V
BATTERY VOLT	XXX V

SAT738J



A

CHECK PNP SWITCH CIRCUIT.



1. Turn ignition switch to "ON" position.
(Do not start engine.)
2. Select "TCM INPUT SIGNALS" in Data Monitor.
3. Read out "R, N, D, 2 and 1 position switches" moving selector lever to each position. Check the signal of the selector lever position is indicated properly.



1. Turn ignition switch to "ON" position. (Do not start engine.)
2. Check voltage between TCM terminals 26, 27, 34, 35, 36 and ground while moving selector lever through each position.

Voltage:

B: Battery voltage

0: 0V

NG

Check the following items:

- PNP switch
Refer to "COMPONENT INSPECTION", AT-1095.
- Harness for short or open between ignition switch and PNP switch (Main harness)
- Harness for short or open between PNP switch and TCM (Main harness)
- Diode

Lever position	Terminal No.				
	(36)	(35)	(34)	(27)	(26)
P, N	B	0	0	0	0
R	0	B	0	0	0
D	0	0	B	0	0
2	0	0	0	B	0
1	0	0	0	0	B

OK

Ⓐ

(Go to next page.)


TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

PNP, Overdrive Control, A/T Mode or Accelerator Position Switches (Cont'd)

B

DATA MONITOR	
MONITORING	
ENGINE SPEED	XXX rpm
TURBINE REV	XXX rpm
OVERDRIVE SW	ON
PN POSI SW	OFF
R POSITION SW	OFF

SAT740J



B

CHECK OVERDRIVE CONTROL SWITCH CIRCUIT.

— Except for the Middle East —

1. Turn ignition switch to "ON" position.
(Do not start engine.)
2. Select "TCM INPUT SIGNALS" in Data Monitor.
3. Read out "OVERDRIVE SWITCH".
Check the signal of the overdrive control switch is indicated properly.
(Overdrive control switch "ON" displayed on CONSULT-II means overdrive "OFF".)

OR

1. Turn ignition switch to "ON" position.
(Do not start engine.)
2. Check voltage between TCM terminal 22 and ground when overdrive control switch is "ON" and "OFF".

Switch position	Voltage
ON	Battery voltage
OFF	1V or less

NG

Check the following items.

- Overdrive control switch
Refer to "COMPONENT INSPECTION", AT-1095.
- Harness for short or open between TCM and overdrive control switch (Main harness)
- Harness for short or open of ground circuit for overdrive control switch (Main harness)




OK

B

(Go to next page.)

TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

PNP, Overdrive Control, A/T Mode or Accelerator Position Switches (Cont'd)



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS






PNP, Overdrive Control, A/T Mode or Accelerator Position Switches (Cont'd)

COMPONENT INSPECTION

Overdrive control switch

- Check continuity between terminals ① and ②.

Switch position	Continuity
ON	No
OFF	Yes



A/T mode switch

- Check continuity between terminals ①, (③) and ②.

Switch position	Terminal No.	Continuity
SPORT	ON ② — ③	Yes
	OFF	No
*	ON ① — ②	Yes
	OFF	No


PNP switch

- Check continuity between terminals ① and ② and between terminals ③ and ④, ⑤, ⑥, ⑦, ⑧, ⑨ while moving manual shaft through each position.

Lever position	Terminal No.	
P	① — ②	③ — ⑦
R	③ — ⑧	
N	① — ②	③ — ⑨
D	③ — ⑥	
2	③ — ⑤	
1	③ — ④	

- If NG, check again with manual control linkage disconnected from manual shaft of A/T assembly. Refer to step 1.
- If OK on step 2, adjust manual control linkage. Refer to AT-1126.
- If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
- If OK on step 4, adjust PNP switch. Refer to AT-1125.
- If NG on step 4, replace PNP switch.

TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS



PNP, Overdrive Control, A/T Mode or Accelerator Position Switches (Cont'd)


Accelerator position switch

Accelerator position switch (Off accel)

- Check continuity between terminals ⑤ and ⑥.

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No


- To adjust closed throttle (accelerator) position switch, refer to EC section ("Basic Inspection", "TROUBLE DIAGNOSIS — Basic Inspection").



Accelerator position switch (Full accel)

- Check continuity between terminals ④ and ⑤.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes







A/T fluid temperature switch

- Make sure the A/T fluid warning lamp lights when the key is inserted and turned to "ON".
- Make sure the A/T fluid warning lamp goes off when turning the ignition switch to "ON".
- For removal, refer to AT-1124.
- Check resistance between terminal ⑩ and ground while changing temperature as shown at left.

Temperature °C (°F)	Resistance
140 (284) or more	Yes
140 (284) or less	No

DIAGNOSTIC PROCEDURES FOR SYMPTOMS



1. SPORT Indicator Lamp Does Not Come On

SYMPTOM:

SPORT indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".

A

CHECK TCM POWER SOURCE.

1. Turn ignition switch to "ON" position.
(Do not start engine.)
2. Check voltage between TCM terminals ⑩, ⑯ and ground.

Battery voltage should exist.

NG

Check the following items:

- Harness for short or open between ignition switch and TCM (Main harness)
- Ignition switch and fuse
Refer to EL section ("POWER SUPPLY ROUTING").

OK

B

CHECK TCM GROUND CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect TCM harness connector.
3. Check resistance between TCM terminals ⑩, ⑯ and ground.

Resistance:

Approximately 0Ω

If OK, check harness for short to ground and short to power.

NG

Repair open circuit or short to ground or short to power in harness or connector.

OK

C

CHECK LAMP CIRCUIT.

1. Turn ignition switch to "ON" position.
2. Set A/T mode switch to "SPORT" position.
3. Check voltage between TCM terminal ⑩ and ground.

Voltage: Battery voltage

4. Reinstall any part removed.

NG

Check the following items:

- Fuse (7.5A)
- SPORT indicator lamp
Refer to EL section ("WARNING LAMPS").
- Harness for short or open between ignition switch and SPORT indicator lamp (Main harness)
Refer to EL section ("POWER SUPPLY ROUTING").
- Harness for short or open between SPORT indicator lamp and TCM

OK


Check again.

NG

INSPECTION END



1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

DIAGNOSTIC PROCEDURES FOR SYMPTOMS




2. SPORT Indicator Lamp Does Not Come On

SYMPTOM:
SPORT indicator lamp does not come on when turning A/T mode switch to the appropriate position.






3. O/D OFF Indicator Lamp Does Not Come On

SYMPTOM:
O/D OFF indicator lamp does not come on when setting overdrive control switch to "OFF" position.



DIAGNOSTIC PROCEDURES FOR SYMPTOMS



4. SPORT Indicator Lamp Does Not Come On

SYMPTOM:

SPORT indicator lamp does not come on for about 3 seconds when depressing and releasing accelerator pedal fully.

A

Does self-diagnosis show damage to accelerator position sensor circuit?

Yes

No

Check accelerator position sensor. Refer to AT-1068.

B

Check accelerator position sensor. — Refer to EC section [TROUBLE DIAGNOSIS FOR "THROTTLE (ACCEL) POSI SEN" (DTC 43)].



OK

NG

Repair or replace accelerator position sensor.

1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.



DIAGNOSTIC PROCEDURES FOR SYMPTOMS



5. Engine Cannot Be Started In “P” and “N” Position

SYMPTOM:


- Engine cannot be started with selector lever in “P” or “N” position.
- Engine can be started with selector lever in “D”, “2”, “1” or “R” position.






6. In “P” Position, Vehicle Moves Forward Or Backward When Pushed

SYMPTOM:

Vehicle moves when it is pushed forward or backward with selector lever in “P” position.




DIAGNOSTIC PROCEDURES FOR SYMPTOMS





7. In "N" Position, Vehicle Moves

SYMPTOM:

Vehicle moves forward or backward when selecting "N" position.



DIAGNOSTIC PROCEDURES FOR SYMPTOMS



8. Large Shock. “N” → “R” Position

SYMPTOM:

There is large shock when changing from “N” to “R” position.

A

Does self-diagnosis show damage to line pressure solenoid valve or accelerator position sensor, A/T fluid temperature sensor circuit?

Yes

Check damaged circuit.
Refer to AT-1068, 1079 or 1084.

No

B

Check accelerator position sensor. Refer to EC section [TROUBLE DIAGNOSIS FOR “THROTTLE (ACCEL) POSI SEN” (DTC 43)].

NG

Repair or replace throttle position sensor.

OK

C

Check line pressure at idle with selector lever in “D” position. Refer to “Line Pressure Test”, AT-1044.

NG

1. Remove control valve assembly. Refer to AT-1124.
2. Check the following items:
 - Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter)
 - Line pressure solenoid valve

OK

Check again.




NG

1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

OK

INSPECTION END

DIAGNOSTIC PROCEDURES FOR SYMPTOMS



9. Vehicle Does Not Creep Backward In "R" Position

SYMPTOM:

Vehicle does not creep backward when selecting "R" position.

A

Check A/T fluid level again.

OK

NG → Refill ATF.

NG in both "1" and "R" positions

B

Check stall revolution with selector lever in "1" and "R" positions.

OK

OK in "1" position
NG in "R" position

1. Remove control valve assembly. Refer to AT-1124.
2. Check the following items:
 - Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter)
 - Line pressure solenoid valve
3. Disassemble A/T.
4. Check the following items:
 - Oil pump assembly
 - Torque converter
 - Reverse clutch assembly
 - High clutch assembly
 - Low & reverse brake assembly
 - Low one-way clutch

C

Check line pressure at idle with selector lever in "R" position. Refer to "Line Pressure Test", AT-1044.

OK

NG →

1. Remove control valve assembly. Refer to AT-1124.
2. Check the following items:
 - Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter)
 - Line pressure solenoid valve

3. Disassemble A/T.
4. Check the following item:
 - Oil pump assembly

D

1. Remove oil pan.
2. Check A/T fluid condition.

NG

OK

NG →



Check again.

OK

INSPECTION END

1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.


DIAGNOSTIC PROCEDURES FOR SYMPTOMS






10. Vehicle Does Not Creep Forward In “D”, “2” Or “1” Position

SYMPTOM:

Vehicle does not creep forward when selecting “D”, “2” or “1” position.




DIAGNOSTIC PROCEDURES FOR SYMPTOMS






11. Vehicle Cannot Be Started From D₁

SYMPTOM:

Vehicle cannot be started from D, on Cruise test — Part 1.



DIAGNOSTIC PROCEDURES FOR SYMPTOMS



12. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$

SYMPTOM:

A/T does not shift from D_1 to D_2 at the specified speed.
A/T does not shift from D_4 to D_2 when depressing accelerator pedal fully at the specified speed.

Are 10. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position and 11. Vehicle Cannot Be Started From D₁ OK?

No → Go to 10. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position and 11. Vehicle Cannot Be Started From D₁, AT-1104, 1105.

Yes → Check PNP switch. Refer to AT-1091.

Does “TCM INPUT SIGNALS” in Data Monitor show damage to PNP switch circuit?

A Does self-diagnosis show damage to PNP switch circuit?

NG → Repair or replace vehicle speed sensor-A/T (revolution sensor) and vehicle speed sensor-MTR. Refer to AT-1064, 1066.

Check vehicle speed sensor-A/T (revolution sensor) and vehicle speed sensor-MTR. Refer to AT-1064, 1066.

Check accelerator position sensor. Refer to EC section [TROUBLE DIAGNOSIS FOR "THROTTLE (ACCEL) POSI SEN" (DTC 43)].

NG → Repair or replace throttle position sensor.

C

NG →

1. Remove control valve.
Refer to AT-1124.
2. Check the following items:
 - Shift valve A
 - Shift solenoid valve A
 - Pilot valve
 - Pilot filter
3. Disassemble A/T.
4. Check the following items:
 - Servo piston assembly
 - Brake band
 - Oil pump assembly

OK

1. Remove control valve. Refer to AT-1124.

- Shift valve A
- Shift solenoid valve A
- Pilot valve
- Pilot filter

3. Disassemble A/T.

4. Check the following items:

- Servo piston assembly
- Brake band
- Oil pump assembly

Oh

NG →




1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

Check again.

2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

INSPECTION END


DIAGNOSTIC PROCEDURES FOR SYMPTOMS






13. A/T Does Not Shift: D₂ → D₃

SYMPTOM:

A/T does not shift from D₂ to D₃ at the specified speed.




DIAGNOSTIC PROCEDURES FOR SYMPTOMS





14. A/T Does Not Shift: D₃ → D₄

SYMPTOM:

- A/T does not shift from D₃ to D₄ at the specified speed.
- A/T must be warm before D₃ to D₄ shift will occur.



DIAGNOSTIC PROCEDURES FOR SYMPTOMS



15. A/T Does Not Perform Lock-up

SYMPTOM:

A/T does not perform lock-up at the specified speed.

A

Does self-diagnosis show damage to torque converter clutch solenoid valve after cruise test?

No

Yes

Check torque converter clutch solenoid valve. Refer to AT-1076.

B

Check accelerator position sensor. Refer to EC section [TROUBLE DIAGNOSIS FOR "THROTTLE (ACCEL) POSI SEN" (DTC 43)].

OK

NG

Repair or replace throttle position sensor.

1. Remove control valve. Refer to AT-1124.

2. Check following items:

- Torque converter clutch control valve
- Torque converter relief valve
- Torque converter clutch solenoid valve
- Pilot valve
- Pilot filter

NG

Repair or replace damaged parts.

OK

Check again.

OK



NG

INSPECTION END

1. Perform TCM input/output signal inspection.

2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.



DIAGNOSTIC PROCEDURES FOR SYMPTOMS



16. A/T Does Not Hold Lock-up Condition

SYMPTOM:


A/T does not hold lock-up condition for more than 30 seconds.






17. Lock-up Is Not Released

SYMPTOM:

Lock-up is not released when accelerator pedal is released.




DIAGNOSTIC PROCEDURES FOR SYMPTOMS




18. Engine Speed Does Not Return To Idle (Light Braking D₄ → D₃)

SYMPTOM:

- Engine speed does not smoothly return to idle when A/T shifts from D₄ to D₃.
- Vehicle does not decelerate by engine brake when turning overdrive control switch OFF.
- Vehicle does not decelerate by engine brake when shifting A/T from "D" to "2" position.



DIAGNOSTIC PROCEDURES FOR SYMPTOMS



19. Vehicle Does Not Start From D₁

SYMPTOM:

Vehicle does not start from D₁ on Cruise test — Part 2.

A

Does self-diagnosis show damage to vehicle speed sensor-A/T (revolution sensor), shift solenoid valve A, B or vehicle speed sensor-MTR after cruise test?

No

Check again.

OK




Go to 8. Vehicle Cannot Be Started From D₁, AT-1102.

Yes

Check damaged circuit. Refer to AT-1064, 1066, 1070 or 1072.

1. Perform TCM input/output signal inspection.
2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.


DIAGNOSTIC PROCEDURES FOR SYMPTOMS




20. A/T Does Not Shift: D₂ → D₁ When Depressing Accelerator Pedal

SYMPTOM:

A/T does not shift from D₂ to D₁ when depressing accelerator pedal fully at the specified speed.





DIAGNOSTIC PROCEDURES FOR SYMPTOMS



21. A/T Does Not Shift: $D_4 \rightarrow D_3$, When Overdrive Control Switch “ON” → “OFF”

SYMPTOM:


A/T does not shift from D_4 to D_3 when changing overdrive control switch to “OFF” position.





22. A/T Does Not Shift: $D_3 \rightarrow 2_2$, When Selector Lever “D” → “2” Position

SYMPTOM:

A/T does not shift from D_3 to 2_2 when changing selector lever from “D” to “2” position.




DIAGNOSTIC PROCEDURES FOR SYMPTOMS



23. A/T Does Not Shift: $2_2 \rightarrow 1_1$, When Selector Lever “2” → “1” Position

SYMPTOM:


A/T does not shift from 2_2 to 1_1 when changing selector lever from “2” to “1” position.



24. Vehicle Does Not Decelerate By Engine Brake

SYMPTOM:


Vehicle does not decelerate by engine brake when shifting from 2_2 (1_2) to 1_1 .



TROUBLE DIAGNOSES — A/T Shift Lock System


Description

- The mechanical key interlock mechanism also operates as a shift lock:
With the key switch turned to "ON", the selector lever cannot be shifted from "P" (parking) to any other position unless the brake pedal is depressed.
With the key removed, the selector lever cannot be shifted from "P" to any other position.
The key cannot be removed unless the selector lever is placed in "P".
- The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder, respectively.





TROUBLE DIAGNOSES — A/T Shift Lock System

Wiring Diagram — SHIFT —



Refer to EL-POWER.



AT-SHIFT-01

LHD models

RHD models

*1 9K :

18K :

*2 69K :





4K :

*3 42K :

1K :

*4 47M :

46M :



Refer to last page (Foldout page).

(M20, B19)

(M21, E127)

(M1)

(M3)


Diagnostic Procedure

SYMPTOM 1:

- Selector lever cannot be moved from “P” position with key in “ON” position and brake pedal applied.
- Selector lever can be moved from “P” position with key in “ON” position and brake pedal released.
- Selector lever can be moved from “P” position when key is removed from key cylinder.









SYMPTOM 2:

Ignition key cannot be removed when selector lever is set to “P” position. It can be removed when selector lever is set to any position except “P”.





TROUBLE DIAGNOSES — A/T Shift Lock System

Diagnostic Procedure (Cont'd)



TROUBLE DIAGNOSES — A/T Shift Lock System


Diagnostic Procedure (Cont'd)



TROUBLE DIAGNOSES — A/T Shift Lock System

Key Interlock Cable

SEC. 349




CAUTION:

- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions. If casing cap can be removed with an external load of less than 39.2 N (4.0 kg, 8.8 lb), replace key interlock cable with new one.

REMOVAL

Unlock slider from adjuster holder and remove rod from cable.



SAT919J




AT-1121

TROUBLE DIAGNOSES — A/T Shift Lock System

Key Interlock Cable (Cont'd)


INSTALLATION

1. Set key interlock cable to steering lock assembly and install lock plate.
2. Clamp cable to steering column and fix to control cable with band.
3. Set selector lever to P position.



4. Insert interlock rod into adjuster holder.


5. Install casing cap to bracket.
6. Move slider in order to fix adjuster holder to interlock rod.



Component Check

SHIFT LOCK SOLENOID

- Check operation by applying battery voltage between A/T device harness connector terminals ⑤ and ⑥.



PARK POSITION SWITCH

- Check continuity between A/T device harness connector terminals ⑦ and ⑧.


Condition	Continuity
When selector lever is set in "P" position and selector lever button is released	Yes
Except above	No

TROUBLE DIAGNOSES — A/T Shift Lock System





Component Check (Cont'd)

STOP LAMP SWITCH

- Check continuity between stop lamp switch harness connector terminals ① and ②.



Check stop lamp switch after adjusting brake pedal — refer to BR section.



Control Valve Assembly and Accumulators REMOVAL

1. Drain ATF.
2. Remove oil pan and gasket.

3. Remove A/T fluid temperature sensor if necessary.
4. Remove oil strainer.

5. Remove control valve assembly by removing fixing bolts and disconnecting harness connector.

Bolt length and location

Bolt symbol	ℓ mm (in)
Ⓐ	33 (1.30)
Ⓑ	45 (1.77)


6. Remove solenoids and valves from valve body if necessary.
7. Remove terminal cord assembly if necessary.

8. Remove accumulator Ⓐ, Ⓑ, Ⓒ and Ⓓ by applying compressed air if necessary.

● Hold each piston with rag.


9. Reinstall any part removed.

● Always use new sealing parts.




Revolution Sensor Replacement

1. Remove revolution sensor from A/T.
2. Reinstall any part removed.
- **Always use new sealing parts.**





Rear Oil Seal Replacement

1. Remove transfer case from vehicle. Refer to TF section ("Removal", "REMOVAL AND INSTALLATION").
2. Remove rear oil seal.
3. Install rear oil seal.
- **Apply ATF before installing.**
4. Reinstall any part removed.




Parking Pawl Components Inspection

1. Remove front and rear propeller shafts. Refer to PD section ("Removal", "PROPELLER SHAFT").
2. Remove transfer case from vehicle. Refer to TF section ("Removal", "REMOVAL AND INSTALLATION").
3. Remove select rod.
4. Support A/T assembly with a jack.
5. Remove rear engine mounting member from body. Refer to EM section ("ENGINE REMOVAL").
6. Remove adapter case from transmission case.
7. Replace parking pawl components if necessary.
8. Reinstall any part removed.
- **Always use new sealing parts.**



PNP Switch Adjustment

1. Remove manual control linkage from manual shaft of A/T assembly.
2. Set manual shaft of A/T assembly in "N" position.
3. Loosen PNP switch fixing bolts.
4. Insert pin into adjustment holes in both PNP switch and manual shaft of A/T assembly as near vertical as possible.
5. Reinstall any part removed.
6. Check continuity of PNP switch. Refer to AT-1095.




Manual Control Linkage Adjustment

Move selector lever from "P" position to "1" position. You should be able to feel the detents in each position.


If the detents cannot be felt or the pointer indicating the position is improperly aligned, the linkage needs adjustment.

1. Place selector lever in "P" position.




2. Loosen lock nuts.
3. Place manual shaft in "P" position.
4. Tighten lock nuts to the specified torque.
5. Move selector lever from "P" position to "1" position. Make sure that selector lever can move smoothly.

REMOVAL AND INSTALLATION




Removal



1. Remove battery negative terminal.
2. Remove air breather hose.
3. Remove heat insulator and exhaust front tube.
4. Remove fluid charging pipe from A/T assembly.
5. Remove oil cooler pipe from A/T assembly.
6. Plug up openings such as the fluid charging pipe hole, etc.
7. Remove front and rear propeller shafts. Refer to PD section ("Removal", "PROPELLER SHAFT").
8. Remove center brake control cable from center brake. Refer to BR section ("PARKING BRAKE CONTROL").
9. Remove transfer control linkage and transfer harness connectors from transfer. Refer to TF section ("Removal", "REMOVAL AND INSTALLATION").
10. Remove A/T control linkage from A/T assembly.
11. Disconnect A/T solenoid, PNP switch and revolution sensor harness connectors.
12. Remove starter motor. Refer to EL section ("STARTING SYSTEM").


13. Remove bolts securing torque converter to drive plate.

- **Remove the bolts by turning crankshaft.**




REMOVAL AND INSTALLATION

Removal (Cont'd)



14. Support A/T and transfer assembly with a jack.
15. Remove engine rear mounting member from body and A/T assembly. Refer to EM section ("ENGINE REMOVAL").
16. Remove bolts securing A/T assembly to engine.
- **Secure torque converter to prevent it from dropping.**
- **Secure A/T assembly with transfer to a jack.**
17. Lower A/T assembly with transfer.



Installation

- Drive plate runout


CAUTION:

Do not allow any magnetic materials to contact the ring gear teeth.

Maximum allowable runout:

Refer to EM section ("Inspection", CYLINDER BLOCK").

If this runout is out of specification, replace drive plate with ring gear.




- When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled.

Distance "A":

Refer to SDS, AT-1210.

- Install converter to drive plate.
- **After converter is installed to drive plate, rotate crank-shaft several turns and check to be sure that transmission rotates freely without binding.**
- Tighten bolts securing transmission.



Bolt No.	Tightening torque N·m (kg·m, ft·lb)	Bolt length "ℓ" mm (in)
①	83 - 113 (8.4 - 11.6, 61 - 83)	65 (2.56)
②	29 - 39 (2.9 - 4.0, 21 - 28)	63 (2.48)
③	29 - 39 (3.0 - 4.0, 22 - 29)	43 (1.69)

- Reinstall any part removed.



- Check fluid level in transmission.
- Move selector lever through all positions to be sure that transmission operates correctly.

With parking brake applied, rotate engine at idling. Move selector lever through "N" to "D", to "2", to "1" and to "R" positions. A slight shock should be felt by hand gripping selector each time transmission is shifted.

- Perform road test. Refer to "ROAD TEST", AT-1046.

MAJOR OVERHAUL

SEC. 311•313•315

 : N·m (kg·m, ft-lb)

 : Apply recommended sealant (Nissan genuine part: KP610-00250) or equivalent.


ATF : Apply ATF.

 **P** : Apply petroleum jelly.

★ : Select with proper thickness.

© 74 - 77

(7.5 - 7.9, 54 - 57)




MAJOR OVERHAUL

SEC. 311•315•317

MAJOR OVERHAUL

Oil Channel



MAJOR OVERHAUL

Locations of Needle Bearings, Thrust Washers and Snap Rings


Outer diameter of snap rings	
Item number	Outer diameter mm (in)
②, ⑤	164.0 (6.46)
③	176.0 (6.93)
⑥	172.0 (6.77)

Thrust washers	
Item number	Color
①	Black
④	White


Outer diameter of bearing races	
Item number	Outer diameter mm (in)
⑦	43.5 (1.713)
⑬	62.5 (2.461)

Installation of one-piece bearings	
Item number	Bearing face (Black) location
⑪	Rear side
⑮	Rear side
⑯	Rear side


Inner and outer diameter of needle bearings		
Item number	Outer diameter mm (in)	Inner diameter mm (in)
⑦	47.0 (1.850)	30.0 (1.181)
⑧	53.0 (2.087)	35.1 (1.382)
⑨	85.0 (3.346)	62.7 (2.468)
⑩	85.0 (3.346)	60.0 (2.362)
⑪, ⑫, ⑬	64.0 (2.520)	45.0 (1.772)
⑭	59.5 (2.343)	38.0 (1.496)
⑮	78.0 (3.071)	64.4 (2.535)
⑯	64.0 (2.520)	45.0 (1.772)




DISASSEMBLY




1. Drain ATF through drain plug.
2. Remove torque converter by holding it firmly and turning while pulling straight out.



3. Check torque converter one-way clutch.
 - a. Insert Tool into spline of one-way clutch inner race.
 - b. Hook bearing support unitized with one-way clutch outer race with suitable wire.
 - c. Check that one-way clutch inner race rotates only clockwise with Tool while holding bearing support with wire.








4. Remove PNP switch from transmission case.



5. Remove oil pan.
 - **Always place oil pan straight down so that foreign particles inside will not move.**

DISASSEMBLY



6. Place transmission into Tool with the control valve facing up.

7. Check foreign materials in oil pan to help determine cause of malfunction. If the fluid is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and may inhibit pump pressure.

- If frictional material is detected, replace radiator after repair of A/T. Refer to LC section ("Radiator", "ENGINE COOLING SYSTEM").

8. Remove torque converter clutch solenoid valve and A/T fluid temperature sensor connectors.


- Be careful not to damage connector.

9. Remove oil strainer.

- a. Remove oil strainer from control valve assembly. Then remove O-ring from oil strainer.


- b. Check oil strainer screen for damage.

DISASSEMBLY




10. Remove control valve assembly.

- Straighten terminal clips to free terminal cords then remove terminal clips.




- Remove bolts **A** and **B**, and remove control valve assembly from transmission.

Bolt symbol	Length mm (in)
A	33 (1.30)
B	45 (1.77)




- Remove solenoid connector.

● **Be careful not to damage connector.**




- Remove manual valve from control valve assembly.


DISASSEMBLY




11. Remove terminal cord assembly from transmission case while pushing on stopper.
 - **Be careful not to damage cord.**
 - **Do not remove terminal cord assembly unless it is damaged.**




12. Remove converter housing from transmission case.
 - **Be careful not to scratch converter housing.**



13. Remove O-ring from input shaft.




14. Remove oil pump assembly.
 - a. Attach Tool to oil pump assembly and extract it evenly from transmission case.




- b. Remove O-ring from oil pump assembly.
 - c. Remove traces of sealant from oil pump housing.

- **Be careful not to scratch pump housing.**


DISASSEMBLY



d. Remove needle bearing and thrust washer from oil pump assembly.




15. Remove input shaft and oil pump gasket.




16. Remove brake band and band strut.

a. Loosen lock nut and remove band servo anchor end pin from transmission case.




b. Remove brake band and band strut from transmission case.




c. Hold brake band in a circular shape with clip.

DISASSEMBLY




17. Remove front side clutch and gear components.


- Remove clutch pack (reverse clutch, high clutch and front sun gear) from transmission case.




- Remove front bearing race from clutch pack.
- Remove rear bearing race from clutch pack.



- Remove front planetary carrier from transmission case.




- Remove front needle bearing from front planetary carrier.
- Remove rear bearing from front planetary carrier.




- Remove rear sun gear from transmission case.


DISASSEMBLY




18. Remove adapter case.
 - a. Remove adapter case from transmission case.
 - b. Remove adapter case gasket from transmission case.




- c. Remove oil seal from adapter case.
 - **Do not remove oil seal unless it is to be replaced.**



- d. Remove revolution sensor from adapter case.
- e. Remove O-ring from revolution sensor.




19. Remove output shaft and parking gear.
 - a. Remove rear snap ring from output shaft.




- b. Slowly push output shaft all the way forward.
 - **Do not use excessive force.**
- c. Remove snap ring from output shaft.


DISASSEMBLY



- d. Remove output shaft and parking gear as a unit from transmission case.
- e. Remove parking gear from output shaft.




- f. Remove needle bearing from transmission case.




- 20. Remove rear side clutch and gear components.

- a. Remove front internal gear.




- b. Remove bearing race from front internal gear.




- c. Remove needle bearing from rear internal gear.


DISASSEMBLY




- d. Remove rear internal gear, forward clutch hub and overrun clutch hub as a set from transmission case.




- e. Remove needle bearing from overrun clutch hub.
- f. Remove overrun clutch hub from rear internal gear and forward clutch hub.



- g. Remove thrust washer from overrun clutch hub.




- h. Remove forward clutch assembly from transmission case.




- 21. Remove band servo and accumulator components.
- a. Remove band servo retainer from transmission case.

DISASSEMBLY




- b. Apply compressed air to oil hole until band servo piston comes out of transmission case.
- **Hold piston with a rag and gradually direct air to oil hole.**
- c. Remove return springs.




- d. Remove springs from accumulator pistons **B**, **C** and **D**.
- **Hold piston with a rag and gradually direct air to oil hole.**


Identification of accumulator pistons	(A)	(B)	(C)	(D)
Identification of oil holes	(a)	(b)	(c)	(d)



- f. Remove O-ring from each piston.




- 22. Remove manual shaft components, if necessary.
- a. Hold width across flats of manual shaft (outside the transmission case) and remove lock nut from shaft.




- b. Remove retaining pin from transmission case.


DISASSEMBLY




c. While pushing detent spring down, remove manual plate and parking rod from transmission case.



d. Remove manual shaft from transmission case.



e. Remove spacer and detent spring from transmission case.




f. Remove oil seal from transmission case.

REPAIR FOR COMPONENT PARTS

Oil Pump


SEC. 313



SAT648AB

DISASSEMBLY

1. Loosen bolts in numerical order and remove oil pump cover.




SAT649A

2. Remove rotor, vane rings and vanes.

- **Inscribe a mark on back of rotor for identification of fore-aft direction when reassembling rotor. Then remove rotor.**


Inscribe identification mark.



SAT650A

3. While pushing on cam ring remove pivot pin.


- **Be careful not to scratch oil pump housing.**



SAT651A


REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)




SAT652A

4. While holding cam ring and spring lift out cam ring spring.
 - Be careful not to damage oil pump housing.
 - Hold cam ring spring to prevent it from jumping.




SAT653A

5. Remove cam ring and cam ring spring from oil pump housing.




SAT654A

6. Remove pivot pin from control piston and remove control piston assembly.



SAT655A

7. Remove oil seal from oil pump housing.
 - Be careful not to scratch oil pump housing.



SAT656A

INSPECTION

Oil pump cover, rotor, vanes, control piston, side seals, cam ring and friction ring

- Check for wear or damage.

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)

Side clearances

- Measure side clearances between end of oil pump housing and cam ring, rotor, vanes and control piston. Measure in at least four places along their circumferences. Maximum measured values should be within specified positions.
- Before measurement, check that friction rings, O-ring, control piston side seals and cam ring spring are removed.**

Standard clearance (Cam ring, rotor, vanes and control piston):

Refer to SDS, AT-1210.

- If not within standard clearance, replace oil pump assembly except oil pump cover assembly.

Seal ring clearance

- Measure clearance between seal ring and ring groove.

Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Wear limit:






0.25 mm (0.0098 in)

- If not within wear limit, replace oil pump cover assembly.

ASSEMBLY

- Drive oil seal into oil pump housing.

- Apply ATF to outer periphery and lip surface.**



- Install cam ring in oil pump housing by the following steps.

- Install side seal on control piston.

- Pay attention to its direction — Black surface goes toward control piston.**

- Apply petroleum jelly to side seal.**


- Install control piston on oil pump.

- Install O-ring and friction ring on cam ring.


- Apply petroleum jelly to O-ring.**

REPAIR FOR COMPONENT PARTS


Oil Pump (Cont'd)




- d. Assemble cam ring, cam ring spring and spring seat. Install spring by pushing it against pump housing.




- e. While pushing on cam ring install pivot pin.



3. Install rotor, vanes and vane rings.
● Pay attention to direction of rotor.



4. Install oil pump housing and oil pump cover.
 - a. Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly in oil pump housing assembly, then remove masking tape.
 - b. Tighten bolts in a criss-cross pattern.




5. Install new seal rings carefully after packing ring grooves with petroleum jelly. Press rings down into jelly to a close fit.
● Seal rings come in two different diameters. Check fit carefully in each groove.
 Small dia. seal ring:
 No mark
 Large dia. seal ring:
 Yellow mark in area shown by arrow
● Do not spread gap of seal ring excessively while installing. It may deform ring.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly

SEC. 317




REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd) DISASSEMBLY




SAT194B




SAT667A



SAT043G



SAT195B



SAT670A

1. Remove solenoids.
 - a. Remove torque converter clutch solenoid valve and side plate from lower body.
 - b. Remove O-ring from solenoid.

- c. Remove line pressure solenoid valve from upper body.
- d. Remove O-ring from solenoid.

- e. Remove 3-unit solenoid assembly from upper body.
- f. Remove O-rings from solenoids.






2. Disassemble upper and lower bodies.
 - a. Place upper body facedown, and remove bolts, reamer bolts and support plates.
 - b. Remove lower body, separator plate and separate gasket as a unit from upper body.
 - **Be careful not to drop pilot filter, orifice check valve, spring and steel balls.**

- c. Place lower body facedown, and remove separate gasket and separator plate.
- d. Remove pilot filter, orifice check valve and orifice check spring.

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)

- e. Check to see that steel balls are properly positioned in upper body. Then remove them from upper body.



INSPECTION

Lower and upper bodies

- Check to see that there are pins and retainer plates in lower body.

- Check to see that there are pins and retainer plates in upper body.
- **Be careful not to lose these parts.**

- Check to make sure that oil circuits are clean and free from damage.
- Check tube brackets and tube connectors for damage.

Separator plates


- Make sure that separator plate is free of damage and not deformed and oil holes are clean.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)

Pilot filter


- Check to make sure that filter is not clogged or damaged.




SAT676A




SAT149G



SAT095B



SAT096BA



SAT671A

Torque converter clutch solenoid valve

- Check that filter is not clogged or damaged.
- Measure resistance. Refer to "COMPONENT INSPECTION", AT-1078.

Line pressure solenoid valve

- Check that filter is not clogged or damaged.
- Measure resistance. Refer to "COMPONENT INSPECTION", AT-1086.

3-unit solenoid assembly (Shift solenoid valves A and B and overrun clutch solenoid valve)

- Measure resistance of each solenoid. Refer to "COMPONENT INSPECTION", AT-1071, 1073, 1075.

A/T fluid temperature sensor and A/T fluid temperature switch


- Measure resistance. Refer to "COMPONENT INSPECTION", AT-1081.

ASSEMBLY


- Install upper and lower bodies.
 - Place oil circuit of upper body face up. Install steel balls in their proper positions.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)



b. Install reamer bolts from bottom of upper body and install separate gaskets.




c. Place oil circuit of lower body face up. Install orifice check spring, orifice check valve and pilot filter.



d. Install lower separate gaskets and separator plates on lower body.

e. Install and temporarily tighten support plates, fluid temperature sensor and tube brackets.



f. Temporarily assemble lower and upper bodies, using reamer bolt as a guide.

- **Be careful not to dislocate or drop steel balls, orifice check spring, orifice check valve and pilot filter.**




REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)

g. Install and temporarily tighten bolts and tube brackets in their proper locations.

Bolt length and location:

Bolt symbol	(a)	(b)	(c)	(d)
Bolt length mm (in)	70 (2.76)	50 (1.97)	33 (1.30)	27 (1.06)



2. Install solenoids.

a. Attach O-ring and install torque converter clutch solenoid valve and side plates onto lower body.


b. Attach O-rings and install 3-unit solenoids assembly onto upper body.

c. Attach O-ring and install line pressure solenoid valve onto upper body.

3. Tighten all bolts.

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body




Apply ATF to all components before their installation.

SAT270J


Numbers preceding valve springs correspond with those shown in SDS on page AT-1208.

REPAIR FOR COMPONENT PARTS


Control Valve Upper Body (Cont'd) DISASSEMBLY




1. Remove valves at parallel pins.
 - **Do not use a magnetic hand.**




- a. Use a wire paper clip to push out parallel pins.



- b. Remove parallel pins while pressing their corresponding plugs and sleeves.
 - **Remove plug slowly to prevent internal parts from jumping out.**



- c. Place mating surface of valve facedown, and remove internal parts.
 - **If a valve is hard to remove, place valve body facedown and lightly tap it with a soft hammer.**
 - **Be careful not to drop or damage valves and sleeves.**








2. Remove valves at retainer plates.
 - a. Pry out retainer plate with wire paper clip.

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)

- b. Remove retainer plates while holding spring.



- c. Place mating surface of valve facedown, and remove internal parts.

- If a valve is hard to remove, lightly tap valve body with a soft hammer.
- Be careful not to drop or damage valves, sleeves, etc.

- 4-2 sequence valve and relay valve are located far back in upper body. If they are hard to remove, carefully push them out using stiff wire.

- Be careful not to scratch sliding surface of valve with wire.

INSPECTION

Valve springs

- Measure free length and outer diameter of each valve spring. Also check for damage or deformation.

Inspection standard:

Refer to SDS, AT-1208.

- Replace valve springs if deformed or fatigued.

Control valves

- Check sliding surfaces of valves, sleeves and plugs.

ASSEMBLY




1. Lubricate the control valve body and all valves with ATF. Install control valves by sliding them carefully into their bores.

- Be careful not to scratch or damage valve body.

REPAIR FOR COMPONENT PARTS


Control Valve Upper Body (Cont'd)

- Wrap a small screwdriver with vinyl tape and use it to insert the valves into proper position.




Pressure regulator valve

- If pressure regulator plug is not centered properly, sleeve cannot be inserted into bore in upper body. If this happens, use vinyl tape wrapped screwdriver to center sleeve until it can be inserted.
- Turn sleeve slightly while installing.



- Install parallel pins and retainer plates.





- While pushing plug, install parallel pin.

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)

4-2 sequence valve and relay valve

- Push 4-2 sequence valve and relay valve with wire wrapped in vinyl tape to prevent scratching valve body. Install parallel pins.




- Insert retainer plate while pushing spring.

REPAIR FOR COMPONENT PARTS

Control Valve Lower Body

SEC. 317



Apply ATF to all components before their installation.

Numbers preceding valve springs correspond with those shown in SDS on page AT-1208.


SAT271J

REPAIR FOR COMPONENT PARTS


Control Valve Lower Body (Cont'd) DISASSEMBLY

1. Remove valves at parallel pins.
2. Remove valves at retainer plates.

For removal procedures, refer to "DISASSEMBLY" of Control Valve Upper Body, AT-1155.



SAT838A



SAT829A

INSPECTION

Valve springs

- Check each valve spring for damage or deformation. Also measure free length and outer diameter.

Inspection standard:

Refer to SDS, AT-1208.

- Replace valve springs if deformed or fatigued.


Control valves

- Check sliding surfaces of control valves, sleeves and plugs for damage.

ASSEMBLY

- Install control valves.

For installation procedures, refer to "ASSEMBLY" of Control Valve Upper Body, AT-1156.




SAT838A

REPAIR FOR COMPONENT PARTS

Reverse Clutch


SEC. 315

For the number of clutch plates (drive and driven plates), refer to the below cross-section.



(ATF) : Apply ATF.


★ : Select with proper thickness.




SAT211K

DISASSEMBLY

1. Check operation of reverse clutch.
 - a. Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.
 - b. Check to see that retaining plate moves to snap ring.
 - c. If retaining plate does not contact snap ring,
 - D-ring might be damaged.
 - Oil seal might be damaged.
 - Fluid might be leaking past piston check ball.
2. Remove drive plates, driven plates, retaining plate, dish plate and snap ring.




SAT841A




SAT842A

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)



3. Remove snap ring from clutch drum while compressing clutch springs.
- **Do not expand snap ring excessively.**
4. Remove spring retainer and return spring.




5. Install seal ring onto oil pump cover and install reverse clutch drum. While holding piston, gradually apply compressed air to oil hole until piston is removed.
- **Do not apply compressed air abruptly.**
6. Remove D-ring and oil seal from piston.

INSPECTION

Reverse clutch snap ring and spring retainer

- Check for deformation, fatigue or damage.




Reverse clutch return springs

- Check for deformation or damage. Also measure free length and outside diameter.

Inspection standard:

Refer to SDS, AT-1208.



Reverse clutch drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:

Standard value 1.90 - 2.05 mm (0.0748 - 0.0807 in)

Wear limit 1.8 mm (0.071 in)

- If not within wear limit, replace.

Reverse clutch dish plate






- Check for deformation or damage.

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)

Reverse clutch piston

- Shake piston to assure that balls are not seized.
- Apply compressed air to check ball oil hole opposite the return spring. Make sure there is no air leakage.
- Also apply compressed air to oil hole on return spring side to assure that air leaks past ball.







ASSEMBLY

1. Install D-ring and oil seal on piston.
 - **Apply ATF to both parts.**
2. Install piston assembly by turning it slowly and evenly.
 - **Apply ATF to inner surface of drum.**
3. Install return springs and spring retainer.
4. Install snap ring while compressing clutch springs.

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)

- Do not align snap ring gap with spring retainer stopper.



5. Install drive plates, driven plates, retaining plate and dish plate.
6. Install snap ring.

7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard

0.5 - 0.8 mm (0.020 - 0.031 in)

Allowable limit

1.4 mm (0.055 in)

Retaining plate:

Refer to SDS, AT-1209.


8. Check operation of reverse clutch.
Refer to "DISASSEMBLY" AT-1161.

REPAIR FOR COMPONENT PARTS

High Clutch


SEC. 315

For the number of clutch plates (drive and driven plates), refer to the below cross-section.




(ATF) : Apply ATF.

★ : Select with proper thickness.




SAT212K



SAT853A

DISASSEMBLY AND ASSEMBLY

Service procedures for high clutch are essentially the same as those for reverse clutch, with the following exception:




SAT854A

- Check of high clutch operation


REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)


- Removal and installation of return spring



SAT488GA



SAT829A



SAT845A

- Inspection of high clutch return springs

Inspection standard:

Refer to SDS, AT-1208.

- Inspection of high clutch drive plate

Thickness of drive plate:

Standard

1.52 - 1.67 mm (0.0598 - 0.0657 in)

Wear limit

1.4 mm (0.055 in)

- Measurement of clearance between retaining plate and snap ring

Specified clearance:

Standard


1.8 - 2.2 mm (0.071 - 0.087 in)

Allowable limit

3.6 mm (0.142 in)

Retaining plate:

Refer to SDS, AT-1209.




SAT858A

REPAIR FOR COMPONENT PARTS

Forward and Overrun Clutches

SEC. 315

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.





REPAIR FOR COMPONENT PARTS


Forward and Overrun Clutches (Cont'd) DISASSEMBLY AND ASSEMBLY

Forward and overrun clutches are serviced essentially the same way as reverse clutch is serviced. However, note the following exceptions.


- Check of forward clutch operation



- Check of overrun clutch operation




- Removal of forward clutch drum
Remove forward clutch drum from transmission case by holding snap ring.



- Removal of forward clutch and overrun clutch pistons

1. While holding overrun clutch piston, gradually apply compressed air to oil hole.





2. Remove overrun clutch from forward clutch.


REPAIR FOR COMPONENT PARTS

Forward and Overrun Clutches (Cont'd)

- Removal and installation of return springs



- Inspection of forward clutch and overrun clutch return springs
Inspection standard:
 Refer to SDS, AT-1208.




- Inspection of forward clutch drive plates

Thickness of drive plate:
Standard

1.90 - 2.05 mm (0.0748 - 0.0807 in)

Wear limit

1.8 mm (0.071 in)




- Inspection of overrun clutch drive plates

Thickness of drive plate:
Standard

1.52 - 1.67 mm (0.0598 - 0.0657 in)

Wear limit

1.4 mm (0.055 in)




- Installation of forward clutch piston and overrun clutch piston

1. Install forward clutch piston by turning it slowly and evenly.

- **Apply ATF to inner surface of clutch drum.**


REPAIR FOR COMPONENT PARTS

Forward and Overrun Clutches (Cont'd)




SAT867A

- Align notch in forward clutch piston with groove in forward clutch drum.



SAT868A

2. Install overrun clutch by turning it slowly and evenly.
- Apply ATF to inner surface of forward clutch piston.



Feeler gauge

SAT869A

- Measurement of clearance between retaining plate and snap ring of overrun clutch

Specified clearance:

Standard


1.0 - 1.4 mm (0.039 - 0.055 in)

Allowable limit

2.4 mm (0.094 in)

Retaining plate:

Refer to SDS, AT-1209.



Feeler gauge

SAT870A

- Measurement of clearance between retaining plate and snap ring of forward clutch

Specified clearance:

Standard

0.35 - 0.75 mm (0.0138 - 0.0295 in)

Allowable limit

2.55 mm (0.1004 in)

Retaining plate:


Refer to SDS, AT-1209.

REPAIR FOR COMPONENT PARTS

Low & Reverse Brake

SEC. 315

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.




(ATF) : Apply ATF.

■ P : Apply petroleum jelly.

★ : Select with proper thickness.


Model 52X24 Retaining plate ★




SAT214K

DISASSEMBLY

1. Check operation of low and reverse brake.
- a. Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.
- b. Check to see that retaining plate moves to snap ring.
- c. If retaining plate does not contact snap ring,
 - D-ring might be damaged.
 - Oil seal might be damaged.
 - Fluid might be leaking past piston check ball.
2. Remove snap ring, low and reverse brake drive plates, driven plates and dish plate.




SAT872A



SAT873A


REPAIR FOR COMPONENT PARTS

Low & Reverse Brake (Cont'd)



SAT382I

3. Remove low one-way clutch inner race, spring retainer and return spring from transmission case.
4. Remove seal rings from low one-way clutch inner race.
5. Remove needle bearing from low one-way clutch inner race.




SAT876A

6. Remove low and reverse brake piston using compressed air.
7. Remove oil seal and D-ring from piston.

INSPECTION

Low and reverse brake snap ring and spring retainer

- Check for deformation, or damage.




SAT829A

Low and reverse brake return springs

- Check for deformation or damage. Also measure free length and outside diameter.

Inspection standard:

Refer to SDS, AT-1208.



SAT845A

Low and reverse brake drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:

Standard value

1.52 - 1.67 mm (0.0598 - 0.0657 in)

Wear limit

1.4 mm (0.055 in)






- If not within wear limit, replace.

REPAIR FOR COMPONENT PARTS

Low & Reverse Brake (Cont'd)

Low one-way clutch inner race

- Check frictional surface of inner race for wear or damage.




ASSEMBLY


- Install needle bearing onto one-way clutch inner race.
 - Pay attention to its direction — Black surface goes to rear side.**
 - Apply petroleum jelly to needle bearing.**
- Install oil seal and D-ring onto piston.
 - Apply ATF to oil seal and D-ring.**
- Install piston by rotating it slowly and evenly.
 - Apply ATF to inner surface of transmission case.**

REPAIR FOR COMPONENT PARTS


Low & Reverse Brake (Cont'd)



4. Install return springs, spring retainer and low one-way clutch inner race onto transmission case.
5. Install dish plate, low and reverse brake drive plates, driven plates and retaining plate.
6. Install snap ring on transmission case.



7. Check operation of low and reverse brake clutch piston. Refer to "DISASSEMBLY", AT-1171.



8. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard


0.5 - 0.8 mm (0.020 - 0.031 in)

Allowable limit

2.4 mm (0.094 in)

Retaining plate:

Refer to SDS, AT-1210.




9. Install low one-way clutch inner race seal ring.

- **Apply petroleum jelly to seal ring.**
- **Make sure seal rings are pressed firmly into place and held by petroleum jelly.**

REPAIR FOR COMPONENT PARTS

Forward Clutch Drum Assembly


SEC. 315



SAT211GA


DISASSEMBLY

1. Remove snap ring from forward clutch drum.
2. Remove side plate from forward clutch drum.




SAT212G

3. Remove low one-way clutch from forward clutch drum.
4. Remove snap ring from forward clutch drum.



SAT213G

5. Remove needle bearing from forward clutch drum.




SAT891A

REPAIR FOR COMPONENT PARTS


Forward Clutch Drum Assembly (Cont'd) INSPECTION

Forward clutch drum


- Check spline portion for wear or damage.
- Check frictional surfaces of low one-way clutch and needle bearing for wear or damage.



SAT892A




SAT893A



SAT214G


ASSEMBLY

1. Install needle bearing in forward clutch drum.
2. Install snap ring onto forward clutch drum.
3. Install low one-way clutch onto forward clutch drum by pushing the roller in evenly.



SAT894A


- Install low one-way clutch with flange facing rearward.



SAT895A

REPAIR FOR COMPONENT PARTS


Forward Clutch Drum Assembly (Cont'd)




4. Install side plate onto forward clutch drum.
5. Install snap ring onto forward clutch drum.

Rear Internal Gear and Forward Clutch Hub

SEC. 315




SAT896AA



DISASSEMBLY

1. Remove rear internal gear by pushing forward clutch hub forward.
2. Remove thrust washer from rear internal gear.




SAT898A


REPAIR FOR COMPONENT PARTS

Rear Internal Gear and Forward Clutch Hub (Cont'd)

3. Remove snap ring from forward clutch hub.




SAT899A




SAT900A

4. Remove end bearing.




SAT955A

5. Remove forward one-way clutch and end bearing as a unit from forward clutch hub.



SAT901A

6. Remove snap ring from forward clutch hub.



SAT902A

INSPECTION

Rear internal gear and forward clutch hub






- Check gear for excessive wear, chips or cracks.
- Check frictional surfaces of forward one-way clutch and thrust washer for wear or damage.
- Check spline for wear or damage.

REPAIR FOR COMPONENT PARTS

Rear Internal Gear and Forward Clutch Hub (Cont'd)

Snap ring and end bearing

- Check for deformation or damage.



ASSEMBLY

- Install snap ring onto forward clutch hub.
- Install end bearing.

- Install forward one-way clutch onto clutch hub.
 - Install forward one-way clutch with flange facing rearward.
- Install end bearing.
- Install snap ring onto forward clutch hub.


- Install thrust washer onto rear internal gear.
 - Apply petroleum jelly to thrust washer.
 - Securely insert pawls of thrust washer into holes in rear internal gear.

- Position forward clutch hub in rear internal gear.



REPAIR FOR COMPONENT PARTS

Rear Internal Gear and Forward Clutch Hub (Cont'd)

8. After installing, check to assure that forward clutch hub rotates clockwise.




Band Servo Piston Assembly




DISASSEMBLY

1. Block one oil hole in OD servo piston retainer and the center hole in OD band servo piston.
2. Apply compressed air to the other oil hole in piston retainer to remove OD band servo piston from retainer.
3. Remove D-ring from OD band servo piston.
4. Remove band servo piston assembly from servo piston retainer by pushing it forward.




REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)




5. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, remove E-ring.




6. Remove servo piston spring retainer, return spring C and piston stem from band servo piston.



7. Remove E-ring from band servo piston.



8. Remove servo cushion spring retainer from band servo piston.
9. Remove D-rings from band servo piston.
10. Remove O-rings from servo piston retainer.



INSPECTION

Pistons, retainers and piston stem

- Check frictional surfaces for abnormal wear or damage.

REPAIR FOR COMPONENT PARTS






Band Servo Piston Assembly (Cont'd)

Return springs

- Check for deformation or damage. Measure free length and outer diameter.

Inspection standard:

Refer to SDS, AT-1208.



ASSEMBLY

1. Install O-rings onto servo piston retainer.
 - Apply ATF to O-rings.
 - Pay attention to position of each O-ring.


2. Install servo cushion spring retainer onto band servo piston.

3. Install E-ring onto servo cushion spring retainer.


4. Install D-rings onto band servo piston.
 - Apply ATF to D-rings.

REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)




5. Install servo piston spring retainer, return spring C and piston stem onto band servo piston.




6. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, install E-ring.



7. Install band servo piston assembly onto servo piston retainer by pushing it inward.




8. Install D-ring on OD band servo piston.
 - **Apply ATF to D-ring.**



9. Install OD band servo piston onto servo piston retainer by pushing it inward.




REPAIR FOR COMPONENT PARTS

Parking Pawl Components



DISASSEMBLY

1. Slide return spring to the front of adapter case flange.
2. Remove return spring, pawl spacer and parking pawl from adapter case.
3. Remove parking pawl shaft from adapter case.
4. Remove parking actuator support from adapter case.
5. Remove rear oil seal.








REPAIR FOR COMPONENT PARTS

Parking Pawl Components (Cont'd) INSPECTION

Parking pawl and parking actuator support


- Check contact surface of parking rod for wear.



ASSEMBLY





1. Install rear oil seal.
2. Install parking actuator support onto adapter case.
3. Install parking pawl shaft into adapter case.
4. Install return spring, pawl spacer and parking pawl onto parking pawl shaft.
5. Bend return spring upward and install it onto adapter case.

ASSEMBLY








Assembly (1)

1. Install manual shaft components.
 - a. Install oil seal onto manual shaft.
 - **Apply ATF to oil seal.**
 - **Wrap threads of manual shaft with masking tape.**
 - b. Insert manual shaft and oil seal as a unit into transmission case.
 - c. Remove masking tape.
- d. Push oil seal evenly and install it onto transmission case.
- e. Align groove in shaft with drive pin hole, then drive pin into position as shown in figure at left.
- f. Install detent spring and spacer.
- g. While pushing detent spring down, install manual plate onto manual shaft.
- h. Install lock nuts onto manual shaft.



ASSEMBLY

Assembly (1) (Cont'd)



2. Install accumulator piston.

- a. Install O-rings onto accumulator piston.

● **Apply ATF to O-rings.**

Accumulator piston O-rings

Unit: mm (in)

Accumulator	Ⓐ	Ⓑ	Ⓒ	Ⓓ
Small diameter end	29 (1.14)	32 (1.26)	45 (1.77)	29 (1.14)
Large diameter end	45 (1.77)	50 (1.97)	50 (1.97)	45 (1.77)

- b. Install return spring for accumulator A onto transmission case.

Free length of return spring:

Refer to SDS, AT-1208.

- c. Install accumulator pistons Ⓐ, Ⓑ, Ⓒ and Ⓓ.

● **Apply ATF to transmission case.**

- 3. Install band servo piston.

- a. Install return springs onto servo piston.

- b. Install band servo piston onto transmission case.






● **Apply ATF to O-ring of band servo piston and transmission case.**

- c. Install gasket for band servo onto transmission case.

ASSEMBLY

Assembly (1) (Cont'd)

- d. Install band servo retainer onto transmission case.



4. Install rear side clutch and gear components.

- a. Place transmission case in vertical position.

- b. Slightly lift forward clutch drum assembly. Then slowly rotate it clockwise until its hub passes fully over clutch inner race inside transmission case.

- c. Check to be sure that rotation direction of forward clutch assembly is correct.


- d. Install thrust washer onto front of overrun clutch hub.

- **Apply petroleum jelly to the thrust washer.**
- **Insert pawls of thrust washer securely into holes in overrun clutch hub.**


ASSEMBLY

Assembly (1) (Cont'd)


- e. Install overrun clutch hub onto rear internal gear assembly.




- f. Install needle bearing onto rear of overrun clutch hub.
● **Apply petroleum jelly to needle bearing.**




- g. Check that overrun clutch hub rotates as shown while holding forward clutch hub.
- h. Place transmission case into horizontal position.



- i. Install rear internal gear, forward clutch hub and overrun clutch hub as a unit onto transmission case.




- j. Install needle bearing onto rear internal gear.
● **Apply petroleum jelly to needle bearing.**




ASSEMBLY

Assembly (1) (Cont'd)



k. Install bearing race onto rear of front internal gear.
 • **Apply petroleum jelly to bearing race.**
 • **Securely engage pawls of bearing race with holes in front internal gear.**




I. Install front internal gear on transmission case.

Adjustment

When any parts listed in the following table are replaced, total end play or reverse clutch end play must be adjusted.


Part name	Total end play	Reverse clutch end play
Transmission case	•	•
Low one-way clutch inner race	•	•
Overrun clutch hub	•	•
Rear internal gear	•	•
Rear planetary carrier	•	•
Rear sun gear	•	•
Front planetary carrier	•	•
Front sun gear	•	•
High clutch hub	•	•
High clutch drum	•	•
Oil pump cover	•	•
Reverse clutch drum	—	•




1. Install front side clutch and gear components.
 a. Install rear sun gear on transmission case.
 • **Pay attention to its direction.**

ASSEMBLY


Adjustment (Cont'd)




- b. Install needle bearing on front of front planetary carrier.
- **Apply petroleum jelly to needle bearing.**
- c. Install needle bearing on rear of front planetary carrier.
- **Apply petroleum jelly to bearing.**
- **Pay attention to its direction — Black side goes to front.**




- d. While rotating forward clutch drum clockwise, install front planetary carrier on forward clutch drum.



- **Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.**



- e. Install bearing races on rear of clutch pack.
- **Apply petroleum jelly to bearing races.**
- **Securely engage pawls of bearing race with hole in clutch pack.**








- f. Place transmission case in vertical position.

ASSEMBLY

Adjustment (Cont'd)

- g. Install clutch pack into transmission case.



2. Adjust total end play.

- a. Install new oil pump gasket on transmission case.

- b. Install pump cover bearing race on clutch pack.

- c. Measure distance "B" between front end of transmission case and oil pump cover bearing race.





- d. Measure distance "C" between front end of transmission case and oil pump gasket.

ASSEMBLY

Adjustment (Cont'd)

e. Determine dimension "A" by using the following equation.

$$A = B - C$$



h. Determine total end play "T₁" by using the following equation.

$$T_1 = A - D - 0.1$$

Total end play "T₁:

$$0.25 - 0.55 \text{ mm (0.0098 - 0.0217 in)}$$

- If end play is out of specification, decrease or increase thickness of oil pump cover bearing race as necessary.

Available oil pump cover bearing race:





Refer to SDS, AT-1210.

3. Adjust reverse clutch drum end play.

a. Install oil pump thrust washer on clutch pack.

ASSEMBLY

Adjustment (Cont'd)



d. Determine dimension "E" by using the following equation.

$$E = F - G$$

e. Measure distance "H".

f. Determine reverse clutch drum end play " T_2 " by using the following equation.

$$T_2 = E - H - 0.1$$

Reverse clutch drum end play " T_2 :

0.55 - 0.90 mm (0.0217 - 0.0354 in)

- If end play is out of specification, decrease or increase thickness of oil pump thrust washer as necessary.

Available oil pump thrust washer:


Refer to SDS, AT-1210.

4. Remove any part installed to adjust end plays.


ASSEMBLY

Assembly (2)

1. Install output shaft and parking gear.
 - a. Insert output shaft from rear of transmission case while slightly lifting front internal gear.
 - **Do not force output shaft against front of transmission case.**




SAT216B




SAT957A

- b. Carefully push output shaft against front of transmission case. Install snap ring on front of output shaft.
- **Check to be sure output shaft cannot be removed in rear direction.**




SAT217B

- c. Install needle bearing on transmission case.
- **Pay attention to its direction — Black side goes to rear.**
- **Apply petroleum jelly to needle bearing.**



SAT218B

- d. Install parking gear on transmission case.








SAT960A

- e. Install snap ring on rear of output shaft.
- **Check to be sure output shaft cannot be removed in forward direction.**

ASSEMBLY

Assembly (2) (Cont'd)

2. Install adapter case.
 - a. Install oil seal on adapter case.
 - **Apply ATF to oil seal.**



- b. Install O-ring on revolution sensor.
 - **Apply ATF to O-ring.**
- c. Install revolution sensor on adapter case.
- d. Install adapter case gasket on transmission case.






- e. Install parking rod on transmission case.

- f. Install adapter case on transmission case.

ASSEMBLY

Assembly (2) (Cont'd)

3. Install front side clutch and gear components.
 - a. Install rear sun gear on transmission case.
 - **Pay attention to its direction.**



- b. Make sure needle bearing is on front of front planetary carrier.
 - **Apply petroleum jelly to needle bearing.**
 - c. Make sure needle bearing is on rear of front planetary carrier.
 - **Apply petroleum jelly to bearing.**
 - **Pay attention to its direction — Black side goes to front.**
- d. While rotating forward clutch drum clockwise, install front planetary carrier on forward clutch drum.






- **Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.**

- e. Make sure bearing races are on front and rear of clutch pack.
 - **Apply petroleum jelly to bearing races.**
 - **Securely engage pawls of bearing races with holes in clutch pack.**

ASSEMBLY

Assembly (2) (Cont'd)

- f. Install clutch pack into transmission case.



4. Install brake band and band strut.
 - a. Install band strut on brake band.
 - **Apply petroleum jelly to band strut.**

- b. Place brake band on periphery of reverse clutch drum, and insert band strut into end of band servo piston stem.






- c. Install anchor end pin on transmission case. Then, tighten anchor end pin just enough so that reverse clutch drum (clutch pack) will not tilt forward.

5. Install input shaft on transmission case.
 - **Pay attention to its direction — O-ring groove side is front.**
6. Install gasket on transmission case.

ASSEMBLY

Assembly (2) (Cont'd)






7. Install oil pump assembly.
 - a. Install needle bearing on oil pump assembly.
 - **Apply petroleum jelly to the needle bearing.**
 - b. Install selected thrust washer on oil pump assembly.
 - **Apply petroleum jelly to thrust washer.**
- c. Carefully install seal rings into grooves and press them into the petroleum jelly so that they are a tight fit.
- d. Install O-ring on oil pump assembly.
 - **Apply petroleum jelly to O-ring.**
- e. Apply petroleum jelly to mating surface of transmission case and oil pump assembly.
- f. Install oil pump assembly.
 - **Install two converter housing securing bolts in bolt holes in oil pump assembly as guides.**



ASSEMBLY

Assembly (2) (Cont'd)

- Insert oil pump assembly to the specified position in transmission, as shown at left.



8. Install O-ring on input shaft.

- **Apply ATF to O-rings.**

9. Install converter housing.

- Apply recommended sealant (Nissan genuine part: KP610-00250 or equivalent) to outer periphery of bolt holes in converter housing.

- **Do not apply too much sealant.**

- Apply recommended sealant (Nissan genuine part: KP610-00250 or equivalent) to seating surfaces of bolts that secure front of converter housing.

- c. Install converter housing on transmission case.

10. Adjust brake band.

- a. Tighten anchor end pin to specified torque.

Anchor end pin:

3.9 - 5.9 N·m






(0.4 - 0.6 kg·m, 35 - 52 in-lb)

- b. Back off anchor end pin two and a half turns.

ASSEMBLY

Assembly (2) (Cont'd)

- c. While holding anchor end pin, tighten lock nut.



11. Install terminal cord assembly.

- a. Install O-ring on terminal cord assembly.

● **Apply petroleum jelly to O-ring.**

- b. Compress terminal cord assembly stopper and install terminal cord assembly on transmission case.

12. Install control valve assembly.

- a. Install accumulator piston return springs **B**, **C** and **D**.

Free length of return springs:

Refer to SDS, AT-1208.

- b. Install manual valve on control valve.

● **Apply ATF to manual valve.**

- c. Place control valve assembly on transmission case. Connect solenoid connector for upper body.


- d. Install connector clip.

ASSEMBLY


Assembly (2) (Cont'd)

- e. Install control valve assembly on transmission case.
- f. Install connector tube brackets and tighten bolts **(A)** and **(B)**.
- **Check that terminal assembly does not catch.**


Bolt symbol	ℓ mm (in)
(A)	33 (1.30)
(B)	45 (1.77)




SAT353B



SAT221B



SAT009B



SAT010B






- g. Install O-ring on oil strainer.
- **Apply petroleum jelly to O-ring.**
- h. Install oil strainer on control valve.

- i. Securely fasten terminal harness with clips.

- j. Install torque converter clutch solenoid valve and A/T fluid temperature sensor connectors.

ASSEMBLY

Assembly (2) (Cont'd)



13. Install oil pan.

- Attach a magnet to oil pan.

- Install new oil pan gasket on transmission case.

- Install oil pan and bracket on transmission case.

- Always replace oil pan bolts as they are self-sealing bolts.
- Before installing bolts, remove traces of sealant and oil from mating surface and thread holes.
- Tighten four bolts in a criss-cross pattern to prevent dislocation of gasket.

- Tighten drain plug.

14. Install PNP switch.

- Check that manual shaft is in "1" position.

- Temporarily install PNP switch on manual shaft.

- Move manual shaft to "N".

- Tighten bolts while inserting 4.0 mm (0.157 in) dia. pin vertically into locating holes in PNP switch and manual shaft.

15. Install torque converter.

- Pour ATF into torque converter.


- Approximately 2 liters (1-3/4 Imp qt) of fluid are required for a new torque converter.

- When reusing old torque converter, add the same amount of fluid as was drained.


ASSEMBLY

Assembly (2) (Cont'd)

b. Install torque converter while aligning notches and oil pump.



SAT016B



SAT017B


c. Measure distance A to check that torque converter is in proper position.

Distance "A":

Refer to SDS, AT-1210.

A/T FLUID COOLER SYSTEM

A/T Fluid Cooler



REMOVAL AND INSTALLATION

1. Remove front radiator grill. Refer to BT section ("BODY END").
2. Disconnect fluid hoses from A/T fluid cooler unit.
3. Remove A/T fluid cooler unit.
4. Remove A/T fluid cooler upper and lower brackets.
5. Remove clips securing fluid hose (A/T fluid cooler unit to radiator) and loosen hose clamps, then remove the fluid hose.
6. Loosen clamps securing fluid hose (A/T assembly to A/T fluid cooler unit), then remove the fluid hose.
7. Remove bolts securing A/T fluid cooler tube bracket.
8. Remove fluid hose with bracket.

- Reverse the removal procedure to install the A/T fluid cooler unit. Refer to the component drawing and specified tightening torque.
- Check A/T fluid level and refill if necessary. Refer to MA section ("CHASSIS AND BODY MAINTENANCE").

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Engine	ZD30DDTi
Automatic transmission model	RE4R03A
Transmission model code number	57X17
Stall torque ratio	2.0 : 1
Transmission gear ratio	
1st	2.784
2nd	1.544
Top	1.000
OD	0.694
Reverse	2.275
Recommended fluid	Genuine Nissan ATF or equivalent*
Fluid capacity ℓ (Imp qt)	11.8 (10-3/8)

*: Refer to MA section ("Fluids and Lubricants", "RECOMMENDED FLUIDS AND LUBRICANTS").

Specifications and Adjustment

SHIFT SCHEDULE

Vehicle speed when shifting gears

Throttle position	Shift pattern	Vehicle speed km/h (MPH)						
		D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	Standard	36 - 46 (22 - 29)	72 - 80 (45 - 50)	117 - 127 (73 - 79)	113 - 123 (70 - 76)	65 - 73 (40 - 45)	33 - 37 (21 - 23)	36 - 46 (22 - 29)
	Power	36 - 46 (22 - 29)	72 - 80 (45 - 50)	117 - 127 (73 - 79)	113 - 123 (70 - 76)	65 - 73 (40 - 45)	33 - 37 (21 - 23)	36 - 46 (22 - 29)
Half throttle	Standard	36 - 46 (22 - 29)	72 - 80 (45 - 50)	117 - 127 (73 - 79)	113 - 123 (70 - 76)	65 - 73 (40 - 45)	33 - 37 (21 - 23)	36 - 46 (22 - 29)
	Power	36 - 46 (22 - 29)	72 - 80 (45 - 50)	117 - 127 (73 - 79)	113 - 123 (70 - 76)	65 - 73 (40 - 45)	33 - 37 (21 - 23)	36 - 46 (22 - 29)

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustment (Cont'd)

Vehicle speed when performing and releasing lock-up

Throttle position	Shift pattern	D ₄	
		Vehicle speed km/h (MPH)	
		Lock-up "ON"	Lock-up "OFF"
Full throttle	Standard	118 - 126 (73 - 78)	114 - 122 (71 - 76)
	Power	118 - 126 (73 - 78)	114 - 122 (71 - 76)
Half throttle	Standard	118 - 126 (73 - 78)	114 - 122 (71 - 76)
	Power	118 - 126 (73 - 78)	114 - 122 (71 - 76)

STALL REVOLUTION

Stall revolution rpm	2,480 - 2,680
----------------------	---------------

LINE PRESSURE

Engine speed rpm	Line pressure kPa (bar, kg/cm ² , psi)	
	D, 2 and 1 positions	R position
Idle	450 - 490 (4.50 - 4.90, 4.59 - 5.00, 65.3 - 71.1)	670 - 700 (6.70 - 7.00, 6.83 - 7.14, 97.1 - 101.5)
Stall	1,020 - 1,098 (10.20 - 10.98, 10.4 - 11.2, 148 - 159)	1,422 - 1,500 (14.22 - 15.00, 14.5 - 15.3, 206 - 218)

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustment (Cont'd)

RETURN SPRINGS

Unit: mm (in)

Parts		Item				
		Part No.*	Free length	Outer diameter		
Control valve	Upper body	① Torque converter relief valve spring	31742-41X23	38.0 (1.496)	9.0 (0.354)	
		② Pressure regulator valve spring	31742-41X24	44.02 (1.7331)	14.0 (0.551)	
		③ Pressure modifier valve spring	31742-41X19	31.95 (1.2579)	6.8 (0.268)	
		④ Shuttle shift valve D spring	31762-41X01	25.0 (0.984)	7.0 (0.276)	
		⑤ 4-2 sequence valve sprig	31756-41X00	29.1 (1.146)	6.95 (0.2736)	
		⑥ Shift valve B spring	31762-41X01	25.0 (0.984)	7.0 (0.276)	
		⑦ 4-2 relay valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)	
		⑧ Shift valve A spring	31762-41X01	25.0 (0.984)	7.0 (0.276)	
		⑨ Overrun clutch control valve spring	31762-41X03	23.6 (0.929)	7.0 (0.276)	
		⑩ Overrun clutch reducing valve spring	31742-41X20	32.5 (1.280)	7.0 (0.276)	
		⑪ Shuttle shift valve S spring	31762-41X01	25.0 (0.984)	7.0 (0.276)	
		⑫ Pilot valve spring	31742-41X13	25.7 (1.012)	9.0 (0.354)	
		⑬ Torque converter clutch control valve spring	31742-41X22	18.5 (0.728)	13.0 (0.512)	
Lower body	Lower body	① Modifier accumulator piston spring	31742-27X70	31.4 (1.236)	9.8 (0.386)	
		② 1st reducing valve spring	31756-41X05	25.4 (1.000)	6.75 (0.266)	
		③ 3-2 timing valve spring	31742-41X06	23.0 (0.906)	6.7 (0.264)	
		④ Servo charger valve spring	31742-41X06	23.0 (0.906)	6.7 (0.264)	
Reverse clutch		12 pcs	31521-51X02 (Assembly)	40.0 (1.575)	14.8 (0.583)	
High clutch		10 pcs	31521-51X03 (Assembly)	24.2 (0.953)	11.6 (0.457)	
Forward clutch (Overrun clutch)		20 pcs	32521-51X01 (Assembly)	36.8 (1.449)	10.7 (0.421)	
Low & reverse brake	Inner spring	16 pcs	31505-51X06	20.43 (0.8043)	10.3 (0.406)	
	Outer spring	16 pcs	31505-51X05	20.35 (0.8012)	13.0 (0.512)	
Band servo	Spring ⑧		31605-41X18	47.6 (1.874)	26.3 (1.035)	
	Spring ⑨		31605-41X01	29.7 (1.169)	27.6 (1.087)	
Accumulator	Accumulator ④		31605-41X02	43.0 (1.693)	20.0 (0.787)	
	Accumulator ⑤		31605-41X10	66.0 (2.598)	20.0 (0.787)	
	Accumulator ⑥		31605-41X09	45.0 (1.772)	29.3 (1.154)	
	Accumulator ⑦		31605-41X06	58.4 (2.299)	17.3 (0.681)	

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustment (Cont'd)

ACCUMULATOR O-RING

Accumulator	Diameter mm (in)			
	(A)	(B)	(C)	(D)
Small diameter end	29 (1.14)	32 (1.26)	45 (1.77)	29 (1.14)
Large diameter end	45 (1.77)	50 (1.97)	50 (1.97)	45 (1.77)

CLUTCHES AND BRAKES

Reverse clutch		57X17	
Number of drive plates		3	
Number of driven plates		3	
Thickness of drive plate mm (in)			
Standard		1.90 - 2.05 (0.0748 - 0.0807)	
Wear limit		1.8 (0.071)	
Clearance mm (in)			
Standard		0.5 - 0.8 (0.020 - 0.031)	
Allowable limit		1.4 (0.055)	
Thickness of retaining plate		Thickness mm (in)	Part number*
		4.4 (0.173)	31537-51X61
		4.6 (0.181)	31537-51X00
		4.8 (0.189)	31537-51X01
		5.0 (0.197)	31537-51X02
		5.2 (0.205)	31537-51X03
High clutch		57X17	
Number of drive plates		6	
Number of driven plates		6	
Thickness of drive plate mm (in)			
Standard		1.52 - 1.67 (0.0598 - 0.0657)	
Wear limit		1.4 (0.055)	
Clearance mm (in)			
Standard		1.8 - 2.2 (0.071 - 0.087)	
Allowable limit		3.6 (0.142)	
Thickness of retaining plate		Thickness mm (in)	Part number*
		4.4 (0.173)	31537-51X61
		4.6 (0.181)	31537-51X00
		4.8 (0.189)	31537-51X01
		5.0 (0.197)	31537-51X02
		5.2 (0.205)	31537-51X03
		5.4 (0.213)	31537-51X04

*: Always check with the Parts Department for the latest parts information.

Forward clutch		57X17	
Number of drive plates	8	Number of driven plates	8
Thickness of drive plate mm (in)		Standard	1.90 - 2.05 (0.0748 - 0.0807)
		Wear limit	1.8 (0.071)
Clearance mm (in)		Standard	0.35 - 0.75 (0.0138 - 0.0295)
		Allowable limit	2.55 (0.1004)
		Thickness mm (in)	Part number*
		4.6 (0.181)	31537-51X06
		4.8 (0.189)	31537-51X07
		5.0 (0.197)	31537-51X08
		5.2 (0.205)	31537-51X09
		5.4 (0.213)	31537-51X10
		5.6 (0.220)	31537-51X69
Overrun clutch		57X17	
Number of drive plates	4	Number of driven plates	7
Thickness of drive plate mm (in)		Standard	1.52 - 1.67 (0.0598 - 0.0657)
		Wear limit	1.4 (0.055)
Clearance mm (in)		Standard	1.0 - 1.4 (0.039 - 0.055)
		Allowable limit	2.4 (0.094)
		Thickness mm (in)	Part number*
		3.8 (0.150)	31537-51X11
		4.0 (0.157)	31537-51X12
		4.2 (0.165)	31537-51X13
		4.4 (0.173)	31537-51X14
		4.6 (0.181)	31537-51X15
		4.8 (0.189)	31537-51X64

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustment (Cont'd)

TOTAL END PLAY

Low & reverse brake	57X17	
Number of drive plates	7	
Number of driven plates	7	
Thickness of drive plate mm (in)		
Standard	1.52 - 1.67 (0.0598 - 0.0657)	
Wear limit	1.4 (0.055)	
Clearance mm (in)		
Standard	0.5 - 0.8 (0.020 - 0.031)	
Allowable limit	2.4 (0.094)	
	Thickness mm (in)	Part number*
Thickness of retaining plate	3.6 (0.142) 4.0 (0.157) 4.2 (0.165) 4.4 (0.173) 4.6 (0.181) 4.8 (0.189) 5.0 (0.197) 5.2 (0.205) 5.4 (0.213) 5.6 (0.220) 5.8 (0.228) 6.0 (0.236)* 6.2 (0.244)*	31667-51X12 31667-51X11 31667-51X10 31667-51X00 31667-51X01 31667-51X02 31667-51X03 31667-51X04 31667-51X05 31667-51X06 31667-51X07 31667-51X08 31667-51X09
Brake band		
Anchor end pin tightening torque N·m (kg·m, in·lb)	3.9 - 5.9 (0.4 - 0.6, 35 - 52)	
Number of returning revolutions for anchor end pin	2.5	

*: Always check with the Parts Department for the latest parts information.

OIL PUMP AND LOW ONE-WAY CLUTCH

Oil pump clearance mm (in)	
Cam ring — oil pump housing	
Standard	0.01 - 0.024 (0.0004 - 0.0009)
Rotor, vanes and control piston — oil pump housing	
Standard	0.03 - 0.044 (0.0012 - 0.0017)
Seal ring clearance mm (in)	
Standard	0.10 - 0.25 (0.0039 - 0.0098)
Allowable limit	0.25 (0.0098)

Total end play "T₁"

Total end play "T ₁ "	Thickness mm (in)	Part number*
0.25 - 0.55 mm (0.0098 - 0.0217 in)		
Thickness of oil pump cover bearing race	0.8 (0.031) 1.0 (0.039) 1.2 (0.047) 1.4 (0.055) 1.6 (0.063) 1.8 (0.071) 2.0 (0.079)	31435-41X01 31435-41X02 31435-41X03 31435-41X04 31435-41X05 31435-41X06 31435-41X07

*: Always check with the Parts Department for the latest parts information.

REVERSE CLUTCH DRUM END PLAY

Reverse clutch drum end play "T ₂ "	Thickness mm (in)	Part number*
0.55 - 0.90 mm (0.0217 - 0.0354 in)		
Thickness of oil pump thrust washer	0.9 (0.035) 1.1 (0.043) 1.3 (0.051) 1.5 (0.059) 1.7 (0.067) 1.9 (0.075)	31528-21X01 31528-21X02 31528-21X03 31528-21X04 31528-21X05 31528-21X06

*: Always check with the Parts Department for the latest parts information.

REMOVAL AND INSTALLATION MODEL

Manual control linkage		
Number of returning revolutions for lock nut	1	
Lock nut tightening torque	25.5 - 32.4 N·m (2.6 - 3.3 kg·m, 19 - 24 ft-lb)	
Distance between end of converter housing and torque converter	57X17	18.1 mm (0.713 in) or more