

# SECTION EL

**When you read wiring diagrams:**

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

**When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".**

- Check for any service bulletins before servicing the vehicle.

### MODIFICATION NOTICE:

- Power window (driver's side only) with an interruption detection function has been adopted.
- ID code entry procedure of multi-remote control system has been changed.
- NATS (Nissan Anti-Theft System) has been adopted on ZD engine model.

## CONTENTS

<b>PRECAUTIONS AND PREPARATION</b> .....	1003	Service Data and Specifications (SDS).....	1039
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ...	1003	<b>CHARGING SYSTEM</b> .....	1040
<b>POWER SUPPLY ROUTING</b> .....	1004	Wiring Diagram — CHARGE.....	1040
Schematic .....	1004	Construction .....	1041
Wiring Diagram — POWER —.....	1005	Service Data and Specifications (SDS).....	1041
<b>GROUND DISTRIBUTION/LHD MODELS</b> .....	1013	<b>COMBINATION SWITCH</b> .....	1042
Engine Room Harness.....	1013	Check .....	1042
Engine Control Harness.....	1016	<b>STEERING SWITCH</b> .....	1043
Main Harness.....	1017	Check .....	1043
Body Harness .....	1020	<b>HEADLAMP — Daytime Light System —</b> .....	1044
Body No. 2 Harness .....	1022	Wiring Diagram — DTRL — .....	1044
Back Door and Rear Window Defogger Harness.....	1023	<b>PARKING, LICENSE AND TAIL LAMPS</b> .....	1046
<b>GROUND DISTRIBUTION/RHD MODELS</b> .....	1024	Wiring Diagram — TAIL/L —/LHD Models.....	1046
Engine Room Harness.....	1024	Wiring Diagram — TAIL/L —/RHD Models .....	1048
Engine Control Harness.....	1027	<b>STOP LAMP</b> .....	1050
Main Harness.....	1028	Wiring Diagram — STOP/L —.....	1050
Body Harness .....	1031	<b>BACK-UP LAMP</b> .....	1051
Body No. 2 Harness .....	1033	Wiring Diagram — BACK/L —/RHD Models ...	1051
Back Door and Rear Window Defogger Harness.....	1034	<b>FRONT FOG LAMP</b> .....	1052
<b>BATTERY</b> .....	1035	Wiring Diagram — F/FOG — .....	1052
Service Data and Specifications (SDS).....	1035	<b>REAR FOG LAMP</b> .....	1053
<b>STARTING SYSTEM</b> .....	1036	Wiring Diagram — R/FOG — .....	1053
Wiring Diagram — START —/M/T Models.....	1036	<b>CORNERING LAMP</b> .....	1054
Wiring Diagram — START —/A/T Models .....	1037	Wiring Diagram — CORNER —/LHD Models.	1054
Construction .....	1038	System Description/RHD Models .....	1055
		Wiring Diagram — CORNER —/RHD Models	1056
		Trouble Diagnoses/RHD Models .....	1057

# ELECTRICAL SYSTEM

<b>TURN SIGNAL AND HAZARD WARNING LAMPS</b> .....	1058
Wiring Diagram — TURN — .....	1058
<b>ILLUMINATION</b> .....	1060
Schematic .....	1060
Wiring Diagram — ILL — .....	1061
<b>INTERIOR ROOM LAMP</b> .....	1067
System Description .....	1067
Wiring Diagram — ROOM/L —/LHD Models ..	1068
Wiring Diagram — ROOM/L —/RHD Models..	1070
Trouble Diagnoses.....	1072
<b>METER AND GAUGES</b> .....	1073
Wiring Diagram — METER —/LHD Models....	1073
Wiring Diagram — METER —/RHD Models ...	1075
<b>WARNING LAMPS</b> .....	1078
Schematic .....	1078
Wiring Diagram — WARN — .....	1080
<b>WARNING CHIME</b> .....	1091
System Description .....	1091
Wiring Diagram — CHIME —/LHD Models....	1092
Wiring Diagram — CHIME —/RHD Models ...	1093
Trouble Diagnoses.....	1094
Electrical Components Inspection .....	1097
<b>FRONT WIPER AND WASHER</b> .....	1098
Wiring Diagram — WIPER —.....	1098
<b>HEADLAMP WIPER AND WASHER</b> .....	1099
Wiring Diagram — HLC — .....	1099
<b>HORN</b> .....	1100
Wiring Diagram — HORN —.....	1100
<b>REAR WINDOW DEFOGGER</b> .....	1101
System Description .....	1101
Wiring Diagram — DEF —/LHD Models .....	1102
Wiring Diagram — DEF —/RHD Models.....	1104
Trouble Diagnoses.....	1106
Electrical Components Inspection .....	1107
<b>AUDIO</b> .....	1108
Wiring Diagram — REMOTE — .....	1108
<b>AUDIO ANTENNA</b> .....	1109
Wiring Diagram — P/ANT —/RHD Models ....	1109
<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b> .....	1110
Schematic .....	1110
Wiring Diagram — ASCD — .....	1111
<b>POWER WINDOW</b> .....	1115
System Description .....	1115
Schematic .....	1116
Wiring Diagram — WINDOW —.....	1117
Trouble Diagnoses.....	1122
<b>POWER DOOR LOCK — Super Lock —</b> .....	1124
Component Parts and Harness Connector Location.....	1124
System Description .....	1125
Schematic .....	1127
Wiring Diagram — S/LOCK —/LHD Models ...	1128
Wiring Diagram — S/LOCK —/RHD Models...	1133
Trouble Diagnoses.....	1138
<b>MULTI-REMOTE CONTROL SYSTEM</b> .....	1149
System Description .....	1149
Wiring Diagram — MULTI —/LHD Models.....	1150
Wiring Diagram — MULTI —/RHD Models ....	1152
Trouble Diagnoses.....	1154
ID Code Entry Procedure .....	1156
Remote Controller Battery Replacement.....	1157
<b>SUPER LOCK CONTROL UNIT</b> .....	1159
Description .....	1159
Schematic .....	1160
Input/Output Operation Signal .....	1162
<b>NATS (Nissan Anti-Theft System)</b> .....	1163
Component Parts and Harness Connector Location.....	1163
System Description .....	1164
System Composition .....	1165
Wiring Diagram — NATS —.....	1166
Wiring Diagram — NATS —/LHD Models.....	1167
Wiring Diagram — NATS —/RHD Models .....	1168
CONSULT-II.....	1169
Trouble Diagnoses.....	1172
How to Replace NATS IMMU.....	1183
<b>LOCATION OF ELECTRICAL UNITS</b> .....	1185
Engine Compartment .....	1185
Passenger Compartment — LHD Models.....	1186
Passenger Compartment — RHD Models .....	1188
<b>HARNES LAYOUT</b> .....	1191
How to Read Harness Layout .....	1191
Main Harness/LHD Models.....	1192
Main Harness/RHD Models .....	1196
Engine Room Harness/LHD Models.....	1200
Engine Room Harness/RHD Models.....	1204
Engine Harness .....	1208
Engine Control Harness.....	1209
Body Harness/LHD Models .....	1210
Body Harness/RHD Models.....	1214
Body No. 2 Harness/LHD Models .....	1218
Body No. 2 Harness/RHD Models.....	1220
Chassis Harness.....	1222
Room Lamp Harness.....	1223
Front Door Harness (Driver side) .....	1224
Front Door Harness (Passenger side).....	1225
Back Door Harness and Rear Window Defogger Harness.....	1226
<b>WIRING DIAGRAM CODES (CELL CODES)</b> .....	1227
Wiring Diagram Codes (Cell Codes) .....	1227

## PRECAUTIONS AND PREPARATION

---

### Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL Y61 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision  
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision  
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.**




# POWER SUPPLY ROUTING


## Wiring Diagram — POWER —

### BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION

EL-POWER-01



- : TD and ZD engine models for cold areas
- : Diesel engine models
- : With electrical winch



Refer to last page (Foldout page).



(M21), (E127)



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)



EL-POWER-02




# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-03




Refer to last page (Foldout page).



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-04





# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

### ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

EL-POWER-05



Refer to last page (Foldout page).

M2, M3, M4, M6, E110, E111


1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

### IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

EL-POWER-06



⬅ L : LHD models

⬅ R : RHD models

⬅ AU : For Australia

FUSE BLOCK (J/B)  
 (M2),  
 (M3),  
 (M4),  
 (M6),  
 (E110),  
 (E111),  
 (E112)

3	5	1
4	2	6

(E114)  
W

Refer to last page (Foldout page).


(M2), (M3), (M4), (M6),  
 (E110), (E111), (E112)

1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-07



Refer to last page (Foldout page).


(M1)	(M2)	(M3)	(M6)	
(E112)				
1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-08

- L : LHD models
- R : RHD models
- LR : LHD models except for France
- RR : RHD models and for France
- TE : TB45E engine models
- TC : LHD TB45E engine A/T models and for China
- XT : Except for TC
- ZD : ZD engine models
- TD : TD engine models
- TL : TD engine models for cold areas and Australia
- XL : Except for TD engine models for cold areas and Australia



3	5	1
4	2	6

E114  
W



Refer to last page (Foldout page).

M1, M2, M3, E111				
E112				
1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

TEL207M


# GROUND DISTRIBUTION/LHD MODELS

## Engine Room Harness




# GROUND DISTRIBUTION/LHD MODELS

## Engine Room Harness (Cont'd)





# GROUND DISTRIBUTION/LHD MODELS

## Engine Room Harness (Cont'd)






Fuse and fusible link box





# GROUND DISTRIBUTION/LHD MODELS

## Engine Control Harness





# GROUND DISTRIBUTION/LHD MODELS

## Main Harness





# GROUND DISTRIBUTION/LHD MODELS

## Main Harness (Cont'd)



# GROUND DISTRIBUTION/LHD MODELS


## Main Harness (Cont'd)





# GROUND DISTRIBUTION/LHD MODELS

## Body Harness

### Wagon models




### Hardtop models



# GROUND DISTRIBUTION/LHD MODELS

## Body Harness (Cont'd)




CEL247A



# GROUND DISTRIBUTION/LHD MODELS

## Body No. 2 Harness




### Wagon models



### Hardtop models





CON-NECTOR NUMBER	CONNECT TO
(B107)	Rear heater unit
(B114)	Rear wiper amp.
(B117)	Rear combination lamp RH
(D66)	Rear door lock actuator RH



# GROUND DISTRIBUTION/LHD MODELS

## Back Door and Rear Window Defogger Harness

### BACK DOOR HARNESS LH





CON-NECTOR NUMBER	CONNECT TO
D82	License plate lamp
D86	Back door lock actuator
D88	Back door key cylinder switch (For China)

### REAR WINDOW DEFOGGER HARNESS LH



### BACK DOOR HARNESS RH



D104	High-mounted stop lamp
D105	Rear wiper motor
D107	Back door switch RH


### REAR WINDOW DEFOGGER HARNESS RH



CEL249A

# GROUND DISTRIBUTION/RHD MODELS



## Engine Room Harness



CEL089M

# GROUND DISTRIBUTION/RHD MODELS






## Engine Room Harness (Cont'd)



CON-NECTOR NUMBER	CONNECT TO
(M33)	Combination meter (Terminal No. 19) (Without ABS)
(E10)	Diff lock solenoid (Terminal No. 3)
(E10)	Diff lock solenoid (Terminal No. 4)
(E19)	Power antenna
(E20)	Side turn signal lamp LH
(E24)	Front combination lamp LH
(E26)	Headlamp aiming motor LH
(E30)	Headlamp LH
(E31)	Distributor (TB45S engine models)
(E33)	Headlamp wiper motor LH
(E36)	Cooling fan motor-1 (Terminal No. 2)
(E36)	Cooling fan motor-1 (Terminal No. 4)
(E80)	Front fog lamp LH
(E94)	Engine coolant temperature switch-1 (Except for ECM control engine models)
(E121)	Condenser (TB45S engine models)
(E160)	Hood switch (OPT) (For Europe)
(E183)	Winch relay




# GROUND DISTRIBUTION/RHD MODELS

## Engine Room Harness (Cont'd)



# GROUND DISTRIBUTION/RHD MODELS



## Engine Control Harness







# GROUND DISTRIBUTION/RHD MODELS

## Main Harness (Cont'd)



# GROUND DISTRIBUTION/RHD MODELS


## Main Harness (Cont'd)





# GROUND DISTRIBUTION/RHD MODELS

## Body Harness

Wagon models






Hardtop models



CON-NECTOR NUMBER	CONNECT TO
B4	Power seat (Passenger side)
B5	Heated seat LH
B6	Wiper deicer switch (Terminal No. 4)
B6	Wiper deicer switch (Terminal No. 6)
B7	Heated seat switch LH
B8	Heated seat switch RH
B9	Ashtray illumination
B11	A/T device (Overdrive control switch) (Terminal No. 2)
B11	A/T device (Overdrive control switch) (Terminal No. 4)
B11	A/T device (Terminal No. 8)
B12	A/T mode switch
B13	Rear cooler switch (Terminal No. 3)
B13	Rear cooler switch (Terminal No. 6)
B14	Rear fan switch
B15	Heated seat RH
B16	Seat belt buckle switch (Driver side)
B17	Power seat (Driver side)
B18	Rear heater unit
B20	Front door switch (Driver side)
B26	CD auto changer (Wagon models)
B27	Rear wiper amp.
B30	Rear combination lamp RH

# GROUND DISTRIBUTION/RHD MODELS


## Body Harness (Cont'd)





# GROUND DISTRIBUTION/RHD MODELS

## Body No. 2 Harness

### Wagon models





### Hardtop models



# GROUND DISTRIBUTION/RHD MODELS


## Back Door and Rear Window Defogger Harness

### BACK DOOR HARNESS LH





CON-NECTOR NUMBER	CONNECT TO
D82	License plate lamp

### REAR WINDOW DEFOGGER HARNESS LH




D131	Rear window defogger LH
------	-------------------------

### BACK DOOR HARNESS RH



D104	High-mounted stop lamp
D105	Rear wiper motor
D107	Back door switch RH

### REAR WINDOW DEFOGGER HARNESS RH



D123	Rear window defogger RH
------	-------------------------

# BATTERY

---




## Service Data and Specifications (SDS)

Applied model	ZD30	
	Standard	Option
Type	115D31L	110D26L × 2
Capacity V-AH	12-80	12-75

# STARTING SYSTEM

## Wiring Diagram — START —/M/T Models




EL-START-01





# STARTING SYSTEM

## Wiring Diagram — START —/A/T Models

EL-START-02



E106  
W




Refer to last page (Foldout page).

M1

# STARTING SYSTEM

## Construction



# STARTING SYSTEM

## Service Data and Specifications (SDS)


### STARTER

		S13-551A	S14-407A
Type		HITACHI	
		Reduction	
	Applied model	ZD30	
		Standard	Option
System voltage	V	12	
No-load			
Terminal voltage	V	11.0	
Current	A	Less than 160	
Revolution	rpm	More than 3,300	More than 3,400
Minimum diameter of commutator	mm (in)	35.5 (1.398)	
Minimum length of brush	mm (in)	11.0 (0.433)	
Brush spring tension	N (kg, lb)	28.4 - 34.3 (2.9 - 3.5, 6.4 - 7.7)	
Clearance between bearing metal and armature shaft	mm (in)	—	
Clearance "ℓ" between pinion front edge and pinion stopper	mm (in)	—	
Movement "ℓ" in height of pinion assembly	mm (in)	0.3 - 2.0 (0.012 - 0.079)	


# CHARGING SYSTEM

## Wiring Diagram — CHARGE —

EL-CHARGE-01



Refer to EL-POWER.




Refer to last page (Foldout page).

M21, E127  
M3

# CHARGING SYSTEM

## Construction





## Service Data and Specifications (SDS)

### ALTERNATOR

Type		LR190-752
		HITACHI
Applied model		ZD30
Nominal rating	V-A	12-90
Ground polarity		Negative
Minimum revolution under no-load (When 13.5V is applied)	rpm	Less than 1,000
Hot output current (When 13.5V is applied)	A/rpm	More than 23/1,300 More than 65/2,500 More than 87/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	6.0 (0.236)
Brush spring pressure	N (g, oz)	1.0 - 3.43 (102 - 350, 3.60 - 12.34)
Slip ring minimum outer diameter	mm (in)	26.0 (1.024)
Rotor (Field coil) resistance	$\Omega$	2.67


# COMBINATION SWITCH

## Check



FRONT WIPER AND WASHER SWITCH

	LO	AUTO STOP	AMP	WASH	HI	EARTH
OFF	<input type="checkbox"/>	<input type="checkbox"/>				<input type="checkbox"/>
INT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			<input type="checkbox"/>
LO	<input type="checkbox"/>					<input type="checkbox"/>
HI					<input type="checkbox"/>	<input type="checkbox"/>
WASH				<input type="checkbox"/>		<input type="checkbox"/>



VARIABLE INTERMITTENT WIPER VOLUME

CORNERING LAMP SWITCH

	L	N	R
61	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
62	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
63	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

FRONT AND REAR FOG LAMP SWITCH

	OFF	FRONT	FRONT REAR
28	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
29	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
27	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

REAR WIPER AND WASHER SWITCH

	WASH	OFF	INT	ON	WASH
21			<input type="checkbox"/>		
22			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
23	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
24	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

TURN SIGNAL SWITCH

	L	N	R
1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>


LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
6		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
7		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
25		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
8		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
9		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
10		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
11		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
12		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	

REAR FOG LAMP SWITCH

	OFF	ON
26	<input type="checkbox"/>	<input type="checkbox"/>
27	<input type="checkbox"/>	<input type="checkbox"/>



HORN SWITCH



# STEERING SWITCH

## Check


### WITH ASCD AND AUDIO SWITCH



# HEADLAMP — Daytime Light System —

## Wiring Diagram — DTRL —

EL-DTRL-01







Refer to last page (Foldout page).  
M21, E127

# HEADLAMP — Daytime Light System —

## Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



Refer to last page (Foldout page).

M21, E127



M3

M4

# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/LHD Models

EL-TAIL/L-03





Refer to last page (Foldout page).  
 M21, E127

# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/LHD Models (Cont'd)

EL-TAIL/L-04






Refer to last page (Foldout page).  
M20, B19


# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/RHD Models

EL-TAIL/L-05



Refer to last page (Foldout page).







# STOP LAMP

## Wiring Diagram — STOP/L —

EL-STOP/L-02



- : LHD models
- : RHD models
- : With high-mounted stop lamp





Refer to last page (Foldout page).

- M20, B19
- M3

# BACK-UP LAMP

## Wiring Diagram — BACK/L —/RHD Models


EL-BACK/L-01



# FRONT FOG LAMP

## Wiring Diagram — F/FOG —

EL-F/FOG-01



2	1	4
6	5	3

M108  
B

1	2
---	---

E79, E80  
BR, BR

3	1
2	5

E152  
L

Refer to last page (Foldout page).




M21, E127

M3

# REAR FOG LAMP

## Wiring Diagram — R/FOG —

EL-R/FOG-03







Refer to last page (Foldout page).

M20 , B19  
M21 , E127  
M4

# CORNERING LAMP

## Wiring Diagram — CORNER —/LHD Models

EL-CORNER-01



Refer to last page (Foldout page).

(M21), (E127)

(M3)

(E112)

# CORNERING LAMP

---

## System Description/RHD Models

The cornering lamp operation is controlled by the lighting switch which is built into the combination switch and cornering lamp relay unit.

Power is supplied at all times

- to lighting switch terminal ①
- through 10A fuse [No. 15], located in the fuse block (J/B)].

### Lighting operation by lighting switch

When lighting switch is in 1ST (or 2ND) position, power is supplied

- to cornering lamp relay unit terminal ③
- through lighting switch terminal ⑫.

With the ignition switch in the ON or START position, power is supplied to cornering lamp relay unit terminal ②

- through 7.5A fuse [No. 11], located in the fuse block (J/B)].

### RH turn

When the turn signal lever is moved to the RH position, ground is supplied

- to cornering lamp relay unit terminal ⑥
- through turn signal lamp switch terminals ② and ①
- through body grounds (E25) and (E40).

Power is supplied

- from terminal ⑤ of the cornering lamp relay unit
- to front combination lamp RH terminal ③.

Ground is supplied to terminal ④ of front combination lamp RH through body grounds (E25) and (E40).

The RH cornering lamp illuminates until the turn signal lever returns to NEUTRAL position.

### LH turn

When the turn signal lever is moved to the LH position, ground is supplied

- to cornering lamp relay unit terminal ⑧
- through turn signal lamp switch terminals ③ and ①
- through body grounds (E25) and (E40).

Power is supplied

- from terminal ⑩ of the cornering lamp relay unit
- to front combination lamp LH terminal ③.





Ground is supplied to terminal ④ of front combination lamp LH through body grounds (E25) and (E40).

The LH cornering lamp illuminates until the turn signal lever returns to NEUTRAL position.

# CORNERING LAMP

## Wiring Diagram — CORNER —/RHD Models

EL-CORNER-02



Refer to last page (Foldout page).

M21, E127

M2

M3

# CORNERING LAMP






## Trouble Diagnoses/RHD Models

Symptom	Possible cause	Repair order
Cornering lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"><li>1. 10A fuse</li><li>2. Lighting switch circuit</li><li>3. Lighting switch</li><li>4. Cornering lamp relay unit</li></ol>	<ol style="list-style-type: none"><li>1. Check 10A fuse [No. 15], located in fuse block (J/B). Verify battery voltage is present at terminal ① of lighting switch.</li><li>2. Check harness for open or short between lighting switch and cornering lamp relay unit.</li><li>3. Check lighting switch.</li><li>4. Replace the cornering lamp relay unit.</li></ol>
LH cornering lamp does not operate but RH cornering operates.	<ol style="list-style-type: none"><li>1. Bulb</li><li>2. Cornering lamp LH circuit</li><li>3. Cornering lamp ground LH circuit</li></ol>	<ol style="list-style-type: none"><li>1. Check bulb</li><li>2. Check harness for open or short between cornering lamp LH and cornering lamp relay unit.</li><li>3. Check harness for open or short between cornering lamp LH and ground.</li></ol>
RH cornering lamp does not operate but LH cornering operates.	<ol style="list-style-type: none"><li>1. Bulb</li><li>2. Cornering lamp RH circuit</li><li>3. Cornering lamp ground RH circuit</li></ol>	<ol style="list-style-type: none"><li>1. Check bulb</li><li>2. Check harness for open or short between cornering lamp RH and cornering lamp relay unit.</li><li>3. Check harness for open or short between cornering lamp RH and ground.</li></ol>

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —

EL-TURN-05



Refer to last page (Foldout page).


M21, E127

M2

# TURN SIGNAL AND HAZARD WARNING LAMPS



## Wiring Diagram — TURN — (Cont'd)

EL-TURN-06



L : LHD models  
R : RHD models

\*1 GY : L  
SB : R




Refer to last page (Foldout page).

M20 : B19  
M21 : E127

# ILLUMINATION



## Schematic



# ILLUMINATION

## Wiring Diagram — ILL —

EL-ILL-01





Refer to last page (Foldout page).

M21, E127  
M3

# ILLUMINATION

## Wiring Diagram — ILL — (Cont'd)

EL-ILL-02










Refer to last page (Foldout page).  
M3

# ILLUMINATION

## Wiring Diagram — ILL — (Cont'd)

EL-ILL-03





\* : This connector is not shown in "HARNES LAYOUT", EL section.

# ILLUMINATION

## Wiring Diagram — ILL — (Cont'd)








EL-ILL-04



# ILLUMINATION

## Wiring Diagram — ILL — (Cont'd)

EL-ILL-05





# INTERIOR ROOM LAMP

---

## System Description

### POWER SUPPLY AND GROUND

Power is supplied at all times:

- through 10A fuse [No. 20], located in the fuse block (J/B)]
- to front and rear interior room lamp terminal ①
- through 7.5A fuse [No. 24], located in the fuse block (J/B)]
- to key switch terminal ② and
- to super lock control unit terminal ①.

When the key is removed from ignition key cylinder, power is interrupted:

- through key switch terminal ①
- to super lock control unit terminal 18.

With the ignition key switch in the ON or START position, power is supplied:

- through 10A fuse [No. 25], located in the fuse block (J/B)]
- to super lock control unit terminal 17.

Ground is supplied:

- to super lock control unit terminal 16
- through body grounds terminals (M30) and (M19) (LHD models) or (M98) (RHD models).

When the front driver side door is opened, ground is supplied:

- through body grounds (B23) and (M19) (LHD models) or (M98) (RHD models).
- to front door switch (driver side) terminal ③
- from front door switch (driver side) terminal ①
- to super lock control unit terminal 30.

When any other door is opened, ground is supplied to super lock control unit terminal 31 in the same manner as the driver door switch.

When the front driver side door is unlocked, the super lock control unit receives a ground signal:

- through body grounds terminals (M30) and (M19) (LHD models) or (M98) (RHD models).
- to front door lock actuator (driver side) (door unlock sensor) terminal ⑤
- from front door lock actuator (driver side) (door unlock sensor) terminal ②
- to super lock control unit terminal 28.

When a signal, or combination of signals is received by the super lock control unit, ground is supplied:

- through super lock control unit terminal 26
- to front interior room lamp terminal ②.

With power and ground supplied, the front interior room lamp illuminates.

### INTERIOR ROOM LAMP TIMER OPERATION

When front interior room lamp switch is in the "DOOR" position, the super lock control unit keeps the front interior room lamp illuminated for about 30 seconds when:

- unlock signal is supplied from driver's door unlock sensor while all doors are closed and key is out of ignition key cylinder
- key is removed from ignition key cylinder while all doors are closed
- driver's door is opened and then closed while key is out of the ignition key cylinder. (However, if the driver's door is closed with the key inserted in the ignition key cylinder after the driver's door is opened with the key removed, the timer is operated.)

The timer is canceled when:

- driver's door is locked or
- ignition switch is turned ON.



### ON-OFF CONTROL

When the driver side door, front passenger door, rear LH or RH door, back door LH or RH is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position.

# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —/LHD Models

EL-ROOM/L-06



Refer to last page (Foldout page).



- (M21), (E127)
- (M22), (D1)
- (M2)
- (M4)

# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —/LHD Models (Cont'd)

EL-ROOM/L-07

WG : Wagon models





Refer to last page (Foldout page).

M20, B19

# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —/RHD Models

EL-ROOM/L-08








Refer to last page (Foldout page).

- (M21), (E127)
- (M22), (D1)
- (M2)
- (M4)

# INTERIOR ROOM LAMP



## Wiring Diagram — ROOM/L —/RHD Models (Cont'd)

EL-ROOM/L-09





Refer to last page (Foldout page).

M20, B19




# INTERIOR ROOM LAMP



## Trouble Diagnoses

### DIAGNOSTIC PROCEDURE


**SYMPTOM: Front interior room lamp does not turn on when any door is opened, or timer does not operate properly.**



# METER AND GAUGES


## Wiring Diagram — METER —/LHD Models

### EL-METER-01



- ME : For the Middle East
  - TE : TB45E engine models
  - TS : TB45S engine models
  - TD : TD engine models
  - ZD : ZD engine models
  - EG : ECM control engine models
  - XG : Except for ECM control engine models
  - SF : With sub fuel tank
- \*1 7 : TE  
5 : ZD



- COMBINATION METER
- M32, M33, M34, M35



# METER AND GAUGES



## Wiring Diagram — METER —/LHD Models (Cont'd)

EL-METER-02



Refer to last page (Foldout page).


M20, B19  
M21, E127



# METER AND GAUGES

## Wiring Diagram — METER —/RHD Models

### EL-METER-03




- TE : TB45E engine models
- TS : TB45S engine models
- TD : TD engine models
- ZD : ZD engine models
- EG : ECM control engine models
- XG : Except for ECM control engine models
- SF : With sub fuel tank
- \*1 7 : TE
- 5 : ZD



To EC-VSS, GLOW, AT-A/T, PD-DIFF/L, EL-COMPAS, ASCD

To EC-IGN

COMBINATION METER  
M32, M33, M34, M35





Refer to last page (Foldout page).  
M2, M3  
M21, E127  
F8




# METER AND GAUGES

## Wiring Diagram — METER —/RHD Models (Cont'd)

EL-METER-04



Refer to last page (Foldout page).  
(M21, E127)




# METER AND GAUGES

---

NOTE

# WARNING LAMPS

## Schematic



(AU) :For Australia

(ES) :For Europe and South Africa

(ME) :For the Middle East

(A) :A/T models

(TE) :TB45E engine models

(TS) :TB45S engine models

(XS) :Except for TB45S engine models

(TD) :TD engine models

(TL) :TD engine models for cold areas and Australia

(XL) :TD engine models except for cold areas and Australia

(ZD) :ZD engine models

(EG) :ECM control engine models

(D) :Diesel engine models

(DX) :Diesel engine models except for Australia

(WG) :Wagon models

(AB) :With air bag

(AS) :With ABS

(OA) :Without ABS

(AM) :With A/T mode switch

(OM) :Without A/T mode switch

(DL) :With diff lock

(SB) :With seat belt warning lamp

(SF) :With sub fuel tank

(OF) :Without sub fuel tank

(ST) :With rear stabilizer release device

(VD) :With overdrive control switch

(OD) :Without overdrive control switch

(SP) :With seat belt pre-tensioner

(OP) :Without seat belt pre-tensioner

\*1 18:(ZD)


32:(TE)

\*2 3:(XL)

14:(TL)

# WARNING LAMPS


## Schematic (Cont'd)



# WARNING LAMPS


## Wiring Diagram — WARN —

EL-WARN-01



- ⬡ AU : For Australia
- ⬡ A : A/T models
- ⬡ TS : TB45S engine models
- ⬡ XS : Except for TB45S engine models

Refer to EL-POWER.




Refer to last page (Foldout page).

- ⬡ M21, E127
- ⬡ M3
- ⬡ M4
- ⬡ E112

# WARNING LAMPS

## Wiring Diagram — WARN — (Cont'd)


EL-WARN-02



Refer to EL-POWER.

- ⬡ L : LHD models
- ⬡ R : RHD models
- ⬡ A : A/T models
- \*1 19: ⬡ L
- 2K: ⬡ R

COMBINATION METER  
M32, M34





Refer to last page (Foldout page).

- M21, E127
- M3
- M4
- E112

# WARNING LAMPS

## Wiring Diagram — WARN — (Cont'd)

EL-WARN-03




Refer to last page (Foldout page).  
M21, E127

# WARNING LAMPS

## Wiring Diagram — WARN — (Cont'd)

EL-WARN-04



27	28	29	30	31	32	33		
34	35	36	37	38	39	40	41	42

(M34)  
W

1 (E64), (B10)  
W B

1  
2 (E76)  
GY

Refer to last page (Foldout page).






(M20), (B19)

(M21), (E127)

# WARNING LAMPS

## Wiring Diagram — WARN — (Cont'd)

EL-WARN-05



Refer to last page (Foldout page).





M21, E127

F8

# WARNING LAMPS

## Wiring Diagram — WARN — (Cont'd)

EL-WARN-06



Refer to last page (Foldout page).

M21, E127, E18








# WARNING LAMPS

## Wiring Diagram — WARN — (Cont'd)

EL-WARN-08

- ◁ L ▷ : LHD models
- ◁ R ▷ : RHD models
- ◁ DL ▷ : With diff lock
- ◁ SF ▷ : With sub fuel tank
- ◁ ST ▷ : With rear stabilizer release device
- \*1 4 : ◁ L ▷
- 80K : ◁ R ▷



Refer to last page (Foldout page).  
M21, E127




# WARNING LAMPS


## Wiring Diagram — WARN — (Cont'd)

LHD MODELS


EL-WARN-10



WG : Wagon models



Refer to last page (Foldout page).  
M20, B19




# WARNING LAMPS


## Wiring Diagram — WARN — (Cont'd)

RHD MODELS

EL-WARN-11



WG : Wagon models



Refer to last page (Foldout page).  
M20, B19

# WARNING CHIME

---

## System Description

The warning chime is combined with the super lock control unit.

Both the ignition key and light warning chime will not sound, when ignition switch in the ON or START position (when power supply exists at super lock control unit terminal ⑰).

### IGNITION KEY WARNING CHIME

With the key in the ignition key cylinder, the ignition switch in the OFF or ACC position, and the driver's door open and locked, the warning chime will sound. Power is supplied

- from key switch terminal ①
- to super lock control unit terminal ⑱.

Ground is supplied

- through driver front door switch terminal ①
- to super lock control unit terminal ⑳, and
- through front door lock actuator assembly (driver side) (unlock sensor) terminal ②
- to super lock control unit terminal ㉘.

### LIGHT WARNING CHIME

With ignition switch in the OFF or ACC position, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. Power is supplied

- from combination switch terminal ⑫
- to super lock control unit terminal ⑲.

Ground is supplied




- through driver front door switch terminal ①
- to super lock control unit terminal ㉙.

# WARNING CHIME

## Wiring Diagram — CHIME —/LHD Models

EL-CHIME-03

Refer to EL-POWER.



Refer to last page (Foldout page).




- M20, B19
- M21, E127
- M22, D1
- M2
- M4

# WARNING CHIME

## Wiring Diagram — CHIME —/RHD Models

EL-CHIME-04

Refer to EL-POWER.



Refer to last page (Foldout page).


- M20, B19
- M21, E127
- M22, D1
- M2
- M3
- M4

# WARNING CHIME


## Trouble Diagnoses

### SYMPTOM CHART

REFERENCE PAGE	EL-1094	EL-1095	EL-1095	EL-1096
SYMPTOM	DIAGNOSTIC PROCEDURE 1 (Lighting switch input signal check)	DIAGNOSTIC PROCEDURE 2 (Key switch input signal check)	DIAGNOSTIC PROCEDURE 3 (Door unlock sensor check)	DIAGNOSTIC PROCEDURE 4
Light warning chime does not activate.	X			X
Ignition key warning chime does not activate.		X	X	X
All warning chimes do not activate.				X



### DIAGNOSTIC PROCEDURE 1 (Lighting switch input signal check)




# WARNING CHIME

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

#### (Key switch input signal check)



**A**

**CHECK KEY SWITCH INPUT SIGNAL.**  
Check voltage between super lock control unit terminal ⑱ and ground.

Condition of key switch	Voltage [V]
Key is inserted.	Approx. 12
Key is withdrawn.	0


NG

Check the following.

- Key switch  
Refer to "Electrical Components Inspection" (EL-1097).
- 7.5A fuse [No. 24], located in fuse block (J/B)
- Harness for open or short between key switch and fuse
- Harness for open or short between super lock control unit and key switch

OK

Go to DIAGNOSTIC PROCEDURE 4.



### DIAGNOSTIC PROCEDURE 3

#### (Door unlock sensor check)

**A**

**CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.**  
Check voltage between super lock control unit terminal ⑳ and ground.

Terminals		Condition	Voltage [V]
⊕	⊖		
⑳	Ground	Locked	Approx. 5
		Unlocked	0

NG

Check the following.

- Door unlock sensor  
Refer to "Electrical Components Inspection" (EL-1097).
- Harness for open or short between super lock control unit and door unlock sensor


OK

Go to DIAGNOSTIC PROCEDURE 4.

# WARNING CHIME

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4



**A**

CHECK POWER SUPPLY CIRCUIT FOR SUPER LOCK CONTROL UNIT.  
Check voltage between super lock control unit terminals ①, ⑰ and ground.

Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	Approx. 12V		
⑰	Ground	0V	0V	Approx. 12V

NG

Check the following.

- 10A fuse [No. 25], located in the fuse block (J/B)
- 7.5A fuse [No. 24], located in the fuse block (J/B)
- Harness for open or short between super lock control unit and fuse

OK

**B**

CHECK GROUND CIRCUIT FOR SUPER LOCK CONTROL UNIT.  
Check continuity between super lock control unit terminal ⑯ and ground.  
**Continuity should exist.**

NG

Repair harness or connectors.

OK

**C**

CHECK DOOR SWITCH INPUT SIGNAL.  
Check voltage between super lock control unit terminal ⑳ and ground.

Condition of driver's door	Voltage [V]
Driver side door is closed.	Approx. 12
Driver side door is open.	0



NG

Check the following.


- Driver side door switch  
Refer to "Electrical Components Inspection" (EL-1097).
- Door switch ground circuit
- Harness for open or short between super lock control unit and door switch

OK

Replace super lock control unit.



# WARNING CHIME




## Electrical Components Inspection

### KEY SWITCH (insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.


Terminal No.	Condition	Continuity
① - ②	Key is inserted.	Yes
	Key is removed.	No



### DRIVER SIDE DOOR SWITCH

Check continuity between terminals when door switch is pushed and released.

Terminal No.	Condition	Continuity
① - ③	Door switch is pushed.	No
	Door switch is released.	Yes



### DRIVER SIDE DOOR UNLOCK SENSOR


Check continuity between door unlock sensor terminals with the door locked and unlocked.

Terminal No.	Condition	Continuity
② - ⑤	Locked	No
	Unlocked	Yes


# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —

EL-WIPER-01



- (L) : LHD models
- (R) : RHD models
- (EL) : RHD models for Europe and LHD models
- (RX) : RHD models except for Europe



Refer to last page (Foldout page).

(M21), (E127)


(M4)

# HEADLAMP WIPER AND WASHER

## Wiring Diagram — HLC —

EL-HLC-01

L : LHD models  
R : RHD models





Refer to last page (Foldout page).

M21, E127  
E111

# HORN

## Wiring Diagram — HORN —

EL-HORN-01



Refer to last page (Foldout page).

(M21), (E127)

\*: This connector is not shown in "HARNESS LAYOUT", EL section.

TEL577B

# REAR WINDOW DEFOGGER

---

## System Description

The rear window defogger system is controlled by the super lock control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal ③
- through 15A fuse (No. 43, located in the fuse and fusible link box),
- to rear window defogger relay terminal ⑥
- through 20A fuse (No. 44, located in the fuse and fusible link box) and
- to super lock control unit terminal ①
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ①
- through 7.5A fuse [No. 8, located in the fuse block (J/B)] and
- to super lock control unit terminal ⑱
- through 10A fuse [No. 25, located in the fuse block (J/B)].

Ground is supplied to terminal ② of the rear window defogger switch through body grounds.

When the rear window defogger switch is turned ON, ground is supplied

- through terminal ① of the rear window defogger switch
- to super lock control unit terminal ⑳.

Terminal ⑲ of the super lock control unit then supplies ground to the rear window defogger relay terminal ②.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to the rear window defogger and door mirror defogger (with door mirror defogger).

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied




- to terminal ③ of the rear window defogger switch
- from terminal ⑤ of the rear window defogger relay.

Terminal ④ of the rear window defogger switch is grounded through body grounds.

# REAR WINDOW DEFOGGER

## Wiring Diagram — DEF —/LHD Models

EL-DEF-04



Refer to last page (Foldout page).

(M21), (E127)

(M2)




(M3)



# REAR WINDOW DEFOGGER

## Wiring Diagram — DEF —/RHD Models

EL-DEF-06



Refer to last page (Foldout page).

(M21), (E127)



(M2)

(M3)

# REAR WINDOW DEFOGGER

## Wiring Diagram — DEF —/RHD Models (Cont'd)


EL-DEF-07




(M84)  
W



(B104)  
W




(D3), (D23)  
W W



(D81)  
W



(D102), (D121), (D133)  
BR BR BR



(D122), (D134), (D123), (D131)  
B B B B






Refer to last page (Foldout page).

(M20), (B19)  
(M22), (D1)

# REAR WINDOW DEFOGGER

## Trouble Diagnoses

**SYMPTOM:** Rear window defogger does not activate, or does not go off after activating.



**A**

**CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL.**

1. Turn ignition switch to ON position.
2. Check voltage between super lock control unit harness terminal 27 and ground.

Condition	Voltage [V]
Rear window defogger switch is released.	Approx. 12
Rear window defogger switch is pushed.	0

OK → Check the following.

- Rear window defogger relay (Refer to EL-1107.)
- Rear window defogger circuit
- Rear window defogger filament [Refer to "Filament Check" in Service Manual (SM7E-2Y61G1).]

NG

**B**

1. Disconnect super lock control unit connector.
2. Turn ignition switch to ON position.
3. Check voltage between super lock control unit terminal 27 and ground. **Battery voltage should exist.**

NG → Check the following.

- 7.5A fuse [No. 8], located in the fuse block (J/B)]
- Rear window defogger relay
- Harness for open or short between super lock control unit and rear window defogger relay
- Harness for open or short between rear window defogger relay and fuse

OK

**C**

**CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL.**

Check continuity between super lock control unit terminal 35 and ground.

Condition of defogger switch	Continuity
Rear window defogger switch is pushed.	Yes
Rear window defogger switch is released.	No

NG → Check the following.

- Rear window defogger switch (Refer to EL-1107.)
- Harness for open or short between super lock control unit and rear window defogger switch
- Rear window defogger switch ground circuit

OK

**D**

**CHECK IGNITION INPUT SIGNAL.**

Check voltage between super lock control unit terminal 17 and ground.

Condition	Voltage [V]
Ignition switch is "ON".	Approx. 12
Ignition switch is "OFF".	0

NG → Check the following.

- 10A fuse [No. 25] located in the fuse block (J/B)]
- Harness for open or short between super lock control unit and fuse

OK

**E**


**CHECK SUPER LOCK CONTROL UNIT GROUND CIRCUIT.**

Check continuity between super lock control unit terminal 16 and ground. **Continuity should exist.**

NG → Repair harness or connectors.

OK → Replace super lock control unit.

# REAR WINDOW DEFOGGER




## Electrical Components Inspection

### REAR WINDOW DEFOGGER RELAY

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.

Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No



### REAR WINDOW DEFOGGER SWITCH




Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
① - ②	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No

# AUDIO

## Wiring Diagram — REMOTE —

EL-REMOTE-01



\* : This connector is not shown in "HARNESS LAYOUT", EL section.





Refer to last page (Foldout page).

M21, E127

# AUDIO ANTENNA

## Wiring Diagram — P/ANT —/RHD Models

EL-P/ANT-01




Refer to last page (Foldout page).

M3

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Schematic







# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-02





Refer to last page (Foldout page).  
M21, E127  
M3  
E112





# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-03



Refer to last page (Foldout page).  
M21, E127





\* : This connector is not shown in "HARNESS LAYOUT", EL section.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)






## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-04



Refer to last page (Foldout page).

- M21, E127
- M3
- E101



# POWER WINDOW

---

## System Description

### OUTLINE

Power window system consists of

- CPU (combined with power window main switch)
- four power window regulators

When ignition switch is in the "ON" position, power window can be operated depending on power window sub/main switch condition.

### OPERATIVE CONDITION

- Power windows can be raised or lowered with each sub-switch or the power window main switch located on the driver's door trim when ignition switch is in the "ON" position and power window lock switch on the driver's door trim is unlocked.
- When power window lock switch is locked, no windows can be raised or lowered except for driver's side window.
- When ignition switch is in the "ON" position, to fully open/close the driver's side window, press down/pull up completely on the automatic switch (main switch) and release it; it needs not be held. The window will automatically open/close all the way. To stop the window, pull up/press down then release the switch.
- After turning ignition switch to OFF, the driver's side window can be raised or lowered for 15 minutes. The timer control for supplying power after turning ignition switch to OFF will be canceled when the driver's side door is open and then closed.

### INTERRUPTION DETECTION FUNCTION

CPU (combined with power window main switch) monitors the power window regulator motor operation and the power window position (full closed or other) for driver's power window by the signals from encoder and limit switch in front power window regulator (driver's side).


When CPU (combined with power window main switch) detects interruption during the following close operation in the driver's side door,

- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during power window timer operation
- manual close operation during power window timer operation

CPU (combined with power window main switch) controls driver's power window regulator motor for open and the power window will be lowered about 150 mm (5.91 in).

# POWER WINDOW



## Schematic



# POWER WINDOW

## Wiring Diagram — WINDOW —

EL-WINDOW-01



Refer to last page (Foldout page).



M21, E127

M3



# POWER WINDOW

## Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02





Refer to last page (Foldout page).





# POWER WINDOW

## Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03



Refer to last page (Foldout page).  
(M22) (D1)




# POWER WINDOW

## Wiring Diagram — WINDOW — (Cont'd)

LHD WAGON MODELS

EL-WINDOW-04



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(B21), (B110)  
W W

1	2	3	4
5	6	7	8

(B104)  
W

7	6	5	4	3	2	1
16	15	14	13	12	11	10

(D5)  
W

Refer to last page (Foldout page).

(M20), (B19)  
(M22), (D1)

1	2
---	---

(D43), (D63)  
B B

4	1	3	2	5
---	---	---	---	---


(D44), (D64)  
W W

# POWER WINDOW

## Wiring Diagram — WINDOW — (Cont'd)

RHD WAGON MODELS

EL-WINDOW-05



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(B21), (B110)  
W W

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(B103)  
W

1	2	3	4	5	6	7		
8	9	15	14	12	13	11	10	16

(D5)  
W

(1 2) (D43), (D63)  
B B

(4 1 3 2 5) (D44), (D64)  
W W

Refer to last page (Foldout page).

(M20), (B19)  
(M22), (D1)

# POWER WINDOW


## Trouble Diagnoses

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>7.5A fuse, 40A fusible link and (M123) circuit breaker</li> <li>Power window main switch ground circuit</li> <li>Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>Check 7.5A fuse [No. 8], located in fuse block (J/B)], 40A fusible link (letter e), located in fuse and fusible link box) and (M123) circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminals 5 and 13 of power window main switch.</li> <li>Check ground circuit of power window main switch.</li> <li>Check power window main switch.</li> </ol>
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>Driver side power window regulator circuit</li> <li>Driver side power window regulator</li> <li>Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>Check harness between power window main switch and power window regulator for open or short circuit.</li> <li>Check driver side power window regulator.</li> <li>Check power window main switch.</li> </ol>
Passenger power window cannot be operated.	<ol style="list-style-type: none"> <li>(M92) circuit breaker</li> <li>Power supply of power window relay</li> <li>Power window relay ground circuit</li> <li>Power window relay</li> <li>Power window sub-switches</li> <li>Passenger side power window regulators</li> <li>Power window main switch</li> <li>Power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>Check (M92) circuit breaker. Verify battery positive voltage is present at terminal 3 of power window relay.</li> <li>Check harness between 7.5A fuse and power window relay.</li> <li>Check power window ground circuit.</li> <li>Check power window relay.</li> <li>Check power window sub-switch.</li> <li>Check passenger side power window regulator.</li> <li>Check power window main switch.</li> <li>8-1. Check harness between power window relay and power window sub-switch.</li> <li>8-2. Check harnesses between power window main switch and power window sub-switch for open/short circuit.</li> <li>8-3. Check harnesses between power window sub-switch and power window regulator for open/short circuit.</li> </ol>
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> <li>Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>Check power window main switch.</li> </ol>
Driver side power window auto function cannot be operated properly.	<ol style="list-style-type: none"> <li>Power window main switch</li> <li>Encoder and limit switch</li> </ol>	<ol style="list-style-type: none"> <li>Check power window main switch.</li> <li>Check encoder and limit switch. (EL-1123)</li> </ol>
Timer control for supplying power after turning ignition switch to OFF does not operate properly.	<ol style="list-style-type: none"> <li>Driver side door switch circuit.</li> <li>Driver side door switch</li> <li>Ignition switch ON signal circuit</li> <li>Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1-1. Check harness between driver side door switch and power window main switch.</li> <li>1-2. Check ground circuit of driver side door switch.</li> <li>2. Check driver side door switch.</li> <li>3. Check ignition switch ON signal circuit to power window main switch.</li> <li>4. Check power window main switch.</li> </ol>

# POWER WINDOW

## Trouble Diagnoses (Cont'd)

### ENCODER AND LIMIT SWITCH CHECK



**CHECK DRIVER SIDE DOOR WINDOW SLIDE MECHANISM**


Check the following.

- Obstacles in window, glass molding, etc.
- Worn or deformed glass molding
- Door sash tilted too far inward or outward
- Door window regulator

NG

Remove obstacles or repair door window slide mechanism.

OK




**CHECK POWER SUPPLY TO LIMIT SWITCH**

1. Disconnect driver side power window regulator connector.
2. Turn ignition switch ON.
3. Check voltage between power window main switch terminal (9) and ground. **Approx. 5V should exist.**

NG

Replace power window main switch.


OK



OK

**CHECK ENCODER**  
Measure voltage between power window main switch terminal (16) and ground with oscilloscope when power window is in automatic closing operation. If result is NG, replace power window regulator motor (front driver side). If result is OK, replace power window main switch.


NG



NG

Replace power window regulator (front driver side).

OK



NG


Replace power window regulator (front driver side).

OK

Replace power window main switch.

# POWER DOOR LOCK — Super Lock —

## Component Parts and Harness Connector Location



<p>Fuse block (J/B)</p> <table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr> <tr><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td></tr> <tr><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td></tr> <tr><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td></tr> <tr><td>21</td><td>22</td><td>23</td><td></td><td></td></tr> <tr><td>24</td><td>25</td><td>26</td><td></td><td></td></tr> <tr><td>27</td><td>28</td><td>29</td><td></td><td></td></tr> </table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23			24	25	26			27	28	29			<p><b>A</b> LHD models Driver side view with dash side lower finisher removed</p> <p>Super lock control unit <b>M117</b> , <b>M118</b></p>	<p><b>B</b> RHD models Driver side view with dash side lower finisher removed</p> <p>Super lock control unit <b>M117</b> , <b>M118</b></p>
1	2	3	4	5																																	
6	7	8	9	10																																	
11	12	13	14	15																																	
16	17	18	19	20																																	
21	22	23																																			
24	25	26																																			
27	28	29																																			
<p><b>C</b></p> <p>Front door lock actuator</p>	<p><b>D</b></p> <p>Rear door lock actuator</p>	<p><b>E</b> Front door key cylinder switch is combined with the key cylinder</p> <p>Lock    Unlock</p> <p>Front</p>																																			
<p><b>F</b></p> <p>Key switch connector <b>E113</b></p>	<p><b>G</b> Power window main switch (Door lock and unlock switch)</p>	<p><b>H</b></p> <p>Door lock and unlock switch</p>																																			



## POWER DOOR LOCK — Super Lock —

---

### System Description (Cont'd)

#### Key reminder system

● If the ignition key is in the ignition key cylinder and the driver door is open, setting lock knob on driver door, key or multi-remote controller to "LOCK" locks the door once but then immediately unlocks all doors. (Signal from unlock sensor driver side)

#### System initialization

● System initialization is required when battery cables are reconnected. Conduct one of the followings to release super lock once;



- insert the key into ignition key cylinder and turn it to ON.
- LOCK/UNLOCK operation using door key cylinder or multi-remote controller.



# POWER DOOR LOCK — Super Lock —

## Wiring Diagram — S/LOCK —/LHD Models

EL-S/LOCK-01



Refer to last page (Foldout page).


(M21), (E127)  
(M2)

# POWER DOOR LOCK — Super Lock —

## Wiring Diagram — S/LOCK —/LHD Models (Cont'd)

### EL-S/LOCK-02


SUPER LOCK  
CONTROL UNIT  
(M118)



- HT : Hardtop models
- WG : Wagon models
- WP : With power window
- OP : Without power window

- D5 : HT
- D10 : WG

- EL22 : OP



Refer to last page (Foldout page).


- M20 : B19
- M22 : D1

\* : This connector is not shown in "HARNESS LAYOUT", EL section.

# POWER DOOR LOCK — Super Lock —

## Wiring Diagram — S/LOCK —/LHD Models (Cont'd)

EL-S/LOCK-03



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

M84  
W



D6, D26  
BR BR



D7  
B



D28  
B

Refer to last page (Foldout page).  
M22, D1

17	18	19	20	21	22	23	24	25	26
27	28	29	30	31	32	33	34	35	36

M118  
GY







# POWER DOOR LOCK — Super Lock —



## Wiring Diagram — S/LOCK —/LHD Models (Cont'd)

EL-S/LOCK-04

: Wagon models



Refer to last page (Foldout page).





# POWER DOOR LOCK — Super Lock —


## Wiring Diagram — S/LOCK —/LHD Models (Cont'd)

EL-S/LOCK-05


: Wagon models




(M84), (B21), (B110)  
W W W




(B104)  
W




(D7), (D45)  
B B




(D28), (D65)  
B B



(D81)  
W



(D86)  
GY



(M117)  
GY





Refer to last page (Foldout page).

(M20), (B19)  
(M22), (D1)

# POWER DOOR LOCK — Super Lock —

## Wiring Diagram — S/LOCK —/RHD Models

EL-S/LOCK-06



Refer to last page (Foldout page).

(M21), (E127)



(M2)

# POWER DOOR LOCK — Super Lock —

## Wiring Diagram — S/LOCK —/RHD Models (Cont'd)

EL-S/LOCK-07

SUPER LOCK CONTROL UNIT (M118)



Refer to last page (Foldout page).

(M20), (B19)  
(M22), (D1)

\* : This connector is not shown in "HARNESS LAYOUT", EL section.





# POWER DOOR LOCK — Super Lock —


## Wiring Diagram — S/LOCK —/RHD Models (Cont'd)

EL-S/LOCK-09


WG : Wagon models




M84, B21, B110  
W W W




B103  
W



D7, D65  
B B



D28, D45  
B B



M117  
GY



Refer to last page (Foldout page).



M20, B19  
M22, D1

# POWER DOOR LOCK — Super Lock —


## Wiring Diagram — S/LOCK —/RHD Models (Cont'd)

EL-S/LOCK-10


: Wagon models




(M84), (B21), (B110)  
W W W




(B103)  
W




(D7), (D65)  
B B




(D28), (D45)  
B B



(D81)  
W



(D86)  
GY



(M117)  
GY



Refer to last page (Foldout page).


(M20), (B19)

(M22), (D1)

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses

### PRELIMINARY CHECK



After performing preliminary check, go to symptom chart on the next page.

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd)

**Before starting trouble diagnoses below, perform preliminary check, EL-1138.**

Symptom numbers in the symptom chart correspond with those of Preliminary check.

### SYMPTOM CHART

REFERENCE PAGE	EL-1140	EL-1141	EL-1142	EL-1143	EL-1144	EL-1145	EL-1146	EL-1147	EL-1148	EL-1148
SYMPTOM	Power supply and ground circuit check	Procedure 1 (Door unlock sensor check)	Procedure 2 (Door key cylinder switch check)	Procedure 3 (Door lock and unlock switch check)	Procedure 4 (Door lock actuator check)	Procedure 5 (Super lock actuator check)	Procedure 6 (Driver's door switch check)	Procedure 7 (NATS release signal check)	Procedure 8 (Key switch check)	Procedure 9 (Ignition switch "ON" circuit check)
1	Power door lock does not operate using any switch.	X			X					
2	Power door lock does not operate with both door key cylinders.		X							
3	Power door lock does not operate with door lock and unlock switch.			X						
4	Specific door lock actuator does not operate.				X					
5	Super lock cannot be set by both door key cylinders.	X	X			X			X	X
6	Super lock cannot be set by one of door key cylinders.		X							
7	*Super lock cannot be released by one or both door key cylinders.		X							
8	*Super lock cannot be released by ignition key switch. (Signal from NATS IMMU and ignition switch)	X						X		X
9	Specific super lock actuator does not operate.					X				
10	*Key reminder system does not operate.	X					X		X	

X: Applicable

\*: Make sure the power door lock system operates properly.



# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd)

### POWER SUPPLY AND GROUND CIRCUIT CHECK

#### Main power supply circuit check

Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage
⑩	Ground	Battery voltage	Battery voltage	Battery voltage





#### Ground circuit check

Terminals	Continuity
⑩ - Ground	Yes

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1 (Door unlock sensor check)



**A**

#### CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.

Check voltage between super lock control unit terminals ⑳ or ㉑ and ground.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
Driver side	⑳	Ground	Locked	Approx. 5
			Unlocked	0
Passenger side	㉑	Ground	Locked	Approx. 5
			Unlocked	0

Refer to wiring diagram in EL-1130 (LHD), EL-1135 (RHD).

OK → Door unlock sensor is OK.

NG

**B**

#### CHECK DOOR UNLOCK SENSOR.

1. Disconnect door unlock sensor connector.
2. Check continuity between door unlock sensor terminals.

Terminals	Condition	Continuity
② - ⑤	Locked	No
	Unlocked	Yes

NG → Replace door lock actuator assembly.

OK

Check the following.


- Door unlock sensor ground circuit
- Harness for open or short between control unit and door unlock sensor

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

#### (Door key cylinder switch check)



**A**

CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL).


Check voltage between super lock control unit terminal ②④ or ②⑤ and ground.

Terminals		Key position	Voltage [V]
⊕	⊖		
②④	Ground	Between neutral and lock	0
		Other positions	Approx. 5
②⑤	Ground	Between neutral and unlock	0
		Other positions	Approx. 5

OK

Door key cylinder switch is OK.

NG



**B**

CHECK DOOR KEY CYLINDER SWITCH.

1. Disconnect door key cylinder switch connector.
2. Check continuity between door key cylinder switch terminals.

Terminals	Key position	Continuity
Front LH: ① - ②	Neutral	No
	Between neutral and lock	Yes
Front RH: ③ - ②	Neutral	No
	Between neutral and unlock	Yes

NG

Replace door key cylinder switch.

OK

Check the following.




- Door key cylinder switch ground circuit
- Harness for open or short between super lock control unit and door key cylinder switch

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3

#### (Door lock and unlock switch check)



**A**

**CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL.**  
Check voltage between control unit terminal ⑳ or ㉓ and ground.

Terminals	Door lock and unlock switch condition	Voltage (V)
⑳ - Ground	Lock	0
	N and Unlock	Battery voltage
㉓ - Ground	Unlock	0
	N and Lock	Battery voltage

OK

Door lock and unlock switch is OK.

NG

**B C**

**CHECK DOOR LOCK AND UNLOCK SWITCH.**  
1. Disconnect door lock and unlock switch connector.  
2. Check continuity between each door lock and unlock switch terminals.

**B** Power window main switch [Door lock and unlock switch (with power window)]

Condition	Terminals		
	17	18	19
Unlock	○	○	○
N	No continuity		
Lock		○	○

**C** Door lock and unlock switch (without power window)

Condition	Terminals		
	1	2	3
Lock		○	○
N	No continuity		
Unlock	○		○

NG

Replace power window main switch (with power window) or door lock and unlock switch (without power window).






OK

Check the following.

- Ground circuit for power window main switch [Door lock and unlock switch (with power window)] or door lock and unlock switch (without power window)
- Harness for open or short between power window main switch [Door lock and unlock switch (with power window)] or door lock and unlock switch (without power window) and control unit connector

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 4 (Door lock actuator check)



CHECK OUTPUT SIGNAL FOR DOOR LOCK ACTUATOR.

Check voltage for door lock actuator.

**A** Door lock actuator driver

Door lock/unlock switch condition	Terminals		Voltage (V)
	⊕	⊖	
Unlock → Lock	(14)	Ground	Battery voltage
Lock → Unlock	(11)	Ground	

**B** Door lock actuator passenger, rear and back

Door lock/unlock switch condition	Terminals		Voltage (V)
	⊕	⊖	
Unlock → Lock	(14)	Ground	Battery voltage
Lock → Unlock	(4)	Ground	

Refer to wiring diagram in EL-1132 (LHD), EL-1137 (RHD).

NG → Door lock actuator is OK.

OK

CHECK DOOR LOCK ACTUATOR.

1. Disconnect door lock actuator connector.
2. Apply 12V direct current to door lock actuator and check operation.

**C D** Door lock actuator operation

Door lock actuator operation	Terminals	
	⊕	⊖
Unlocked → Locked	(6)	(3)
Locked → Unlocked	(3)	(6)

**E** Back door lock actuator operation

Back door lock actuator operation	Terminals	
	⊕	⊖
Unlocked → Locked	(3)	(1)
Locked → Unlocked	(1)	(3)

OK → Check harness between control unit and door lock actuator.

NG



Replace door lock actuator assembly.

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

#### [Super lock actuator (in door lock actuator assembly) check]



**A**

CHECK OUTPUT SIGNAL FOR SUPER LOCK ACTUATOR.

Check voltage for super lock actuator.

NG → Super lock actuator is OK.

Door key cylinder switch condition	Terminals		Voltage (V)
	⊕	⊖	
Lock (Set)	⑥	Ground	Approx. 12
Unlock (Released)	③	Ground	

**Put the system in set condition before checking release signal.**

Refer to wiring diagram in EL-1131 (LHD), EL-1136 (RHD).

OK

**B**

CHECK SUPER LOCK ACTUATOR.

1. Disconnect door lock actuator assembly connector.
2. Set lever A in Lock position.
3. Apply 12V direct current to door lock actuator assembly and check operation.

OK → Check harness between control unit and door lock actuator assembly.



Super lock actuator operation	Terminals		Connection from lever B to lever A
	⊕	⊖	
Released → Set	①	④	Disconnect
Set → Released	④	①	Connect

NG

Replace door lock actuator assembly.

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 6 (Driver's door switch check)



**A**

**CHECK DOOR SWITCH INPUT SIGNAL.**  
Check voltage between super lock control unit terminal ③⑩ and ground.

Condition	Voltage [V]
Any door is opened.	0
Driver's door is closed.	Approx. 12

OK

Door switch is OK.

Refer to wiring diagram in EL-1129 (LHD), EL-1134 (RHD).

NG

**B**

**CHECK DOOR SWITCH.**  
1. Disconnect door switch connector.  
2. Check continuity between door switch terminals.

	Terminals	Condition	Continuity
Driver side door switch	① - ground	Closed	No
		Open	Yes

NG

Replace door switch.



OK

Check the following.

- Driver side door switch ground condition
- Harness for open or short between control unit and door switch

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 7 (NATS release signal check)



Does engine start properly? No → Check NATS system.

Yes

**A**

NG → Repair harness.

**CHECK NATS SIGNAL CIRCUIT.**

1. Disconnect super lock control unit connector and NATS IMMU connector.
2. Check continuity between super lock control unit terminal ③④ and NATS IMMU terminal ③.

**Continuity should exist.**

3. Check continuity between super lock control unit terminal ③④ and ground.

**Continuity should not exist.**

Refer to wiring diagram in EL-1128 (LHD), EL-1133 (RHD).

OK

**B**

NG → Check NATS system.

**CHECK NATS RELEASE SIGNAL.**

1. Connect super lock control unit connector and NATS IMMU connector.
2. Check voltage between super lock control unit terminal ③④ and ground.




Ignition switch condition	Voltage [V]
OFF	5
More than 20 seconds after ignition switch turned ON	
For 20 seconds after ignition switch turned ON	Pulse

OK

Replace super lock control unit.

# POWER DOOR LOCK — Super Lock —

## Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 8 (Key switch check)



**A** CHECK KEY SWITCH INPUT SIGNAL.  
Check voltage between super lock control unit terminal ⑱ and ground.

OK → Key switch is OK.

Condition of key switch	Voltage [V]
Key is inserted.	Approx. 12
Key is withdrawn.	0

Refer to wiring diagram in EL-1128 (LHD), EL-1133 (RHD).

NG

**B** CHECK KEY SWITCH POWER SUPPLY.  
1. Disconnect key switch connector.  
2. Check voltage between key switch harness terminal ② and ground.  
**Battery voltage should exist.**

NG → Check the following.

- 7.5A fuse [No. 24], located in fuse block (J/B)]
- Harness for open or short between key switch and fuse

OK


**C** CHECK KEY SWITCH.  
Check continuity between key switch terminals.

NG → Replace key switch.

Terminals	Condition	Continuity
① - ②	Key is inserted.	Yes
	Key is withdrawn.	No

OK

Check harness for open or short between control unit and key switch.



## DIAGNOSTIC PROCEDURE 9 (Ignition switch "ON" circuit check)

Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
⑰	Ground	0V	0V	Battery voltage

If NG, check the following.

- 10A fuse [No. 25], located in the fuse block (J/B)]
- Harness for open or short

# MULTI-REMOTE CONTROL SYSTEM

---

## System Description

### FUNCTION

Multi-remote control system has the following function.

- Door lock
- Door unlock
- Hazard reminder

### LOCK OPERATION

When the LOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi-remote control unit), ground is supplied

- through multi-remote control unit terminal ⑤
- to super lock control unit terminal ⑫.

Then super lock control unit locks all doors and set super lock. (Super lock will not be set while key is inserted in the ignition key cylinder.)

### UNLOCK OPERATION

When the UNLOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi-remote control unit) once, ground is supplied

- through multi-remote control unit terminal ⑥
- to super lock control unit terminal ⑬.

Then super lock control unit unlocks driver's door and release super lock on all doors.

If the UNLOCK signal is sent to the multi-remote control unit again within 5 seconds, all other doors will be unlocked.

### HAZARD REMINDER

When the doors are locked or unlocked (signal from front door unlock sensor LH) by multi-remote controller, power is supplied

- through multi-remote control unit terminals ③ and ⑧
- to the hazard warning lamps

Then hazard warning lamp flashes as follows.

- Lock operation: Flash once
- Unlock operation: Flash twice

### MULTI-REMOTE CONTROLLER ID CODE ENTRY

A maximum of four remote controllers can be entered. Any attempt to enter a remote controller will erase all ID codes previously entered. Therefore, be sure to receive all remote controllers from the vehicle owner when any ID code entry is performed.

To enter ID code entry, the following signals must be input to the multi-remote control unit.



- Ignition switch ON signal
- Battery power supply
- Signal from remote controller

For detailed procedure, refer to "ID Code Entry Procedure" in EL-1156.

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI —/LHD Models

EL-MULTI-09



Refer to last page (Foldout page).



- M21, E127
- M22, D1
- M3

TEL274M

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI —/LHD Models (Cont'd)

EL-MULTI-10





Refer to last page (Foldout page).  
M21, E127  
M2

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI —/RHD Models

EL-MULTI-11





Refer to last page (Foldout page).

- (M21), (E127)
- (M22), (D1)
- (M3)

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI —/RHD Models (Cont'd)

EL-MULTI-12



Refer to last page (Foldout page).

- (M21), (E127)
- (M2)

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses

### SYMPTOM CHART

Symptom	Possible cause	Diagnoses/service order
No doors can be locked or unlocked by remote control operation. (See NOTE.)	<ol style="list-style-type: none"> <li>1. Power door lock system</li> <li>2. Remote controller battery</li> <li>3. Door lock/unlock circuit</li> <li>4. Ignition power supply circuit for multi-remote control unit</li> <li>5. Power supply circuit for multi-remote control unit</li> <li>6. Ground circuit for multi-remote control unit</li> <li>7. Remote controller</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power door lock operation.</li> <li>2. Check remote controller battery. Refer to "Remote controller battery check" in EL section of Service Manual (SM7E-2Y61G1).</li> <li>3. Check harness for open or short between multi-remote control unit and super lock control unit.</li> <li>4. Make sure battery voltage is present at terminal ④ of multi-remote control unit while ignition switch is in IGN position.</li> <li>5. Make sure battery voltage is present at terminal ② of multi-remote control unit.</li> <li>6. Check continuity between terminal ① of multi-remote control unit and ground.</li> <li>7. Replace remote controller. Refer to EL-1156.</li> </ol>
Hazard reminder does not operate properly.	<ol style="list-style-type: none"> <li>1. Hazard reminder output to hazard warning lamps</li> <li>2. Hazard reminder circuit</li> <li>3. Driver's door unlock sensor</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard reminder output to hazard warning lamps at terminals ③ and ⑧ of multi-remote control unit.</li> <li>2. Check the harness for open or short between hazard warning lamps and multi-remote control unit.</li> <li>3. Check driver's door unlock sensor signal at terminal ⑦ of multi-remote control unit.</li> </ol>
The new ID of remote controller cannot be entered.	<ol style="list-style-type: none"> <li>1. Remote controller battery</li> <li>2. Ignition power supply circuit for multi-remote control unit</li> <li>3. Driver's door unlock sensor</li> <li>4. Remote controller</li> </ol>	<ol style="list-style-type: none"> <li>1. Check remote controller battery. Refer to "Remote controller battery check" in EL section of Service Manual (SM7E-2Y61G1).</li> <li>2. Make sure battery voltage is present at terminal ④ of multi-remote control unit while ignition switch is in IGN position.</li> <li>3. Check driver's door unlock sensor signal at terminal ⑦ of multi-remote control unit.</li> <li>4. Replace remote controller. Refer to EL-1156.</li> </ol>

Refer to "MULTI-REMOTE CONTROL UNIT INSPECTION TABLE" on next page to check the control unit signals.

**NOTE:**


- The lock operation of multi-remote control system does not activate with the ignition key ON position.

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### MULTI-REMOTE CONTROL UNIT INSPECTION TABLE

Terminal No.	Connections	Condition	Voltage (V) (approximate values)
1	Ground	—	—
2	Power source (BAT)	—	12
3	Hazard warning lamp RH	Remote controller LOCK/UNLOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)	12
		Other than above condition	0
4	Ignition power supply	Ignition switch	OFF 0
			ON or START 12
5	Lock signal (to super lock control unit)	Remote controller LOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)	0
		Other than above condition	5
6	Unlock signal (to super lock control unit)	Remote controller UNLOCK button is pushed (Key is not in ignition key cylinder.)	0
		Other than above condition	5
7	Driver side door unlock sensor	Driver side door	Locked 5
			Unlocked 0
8	Hazard warning lamp LH	Remote controller LOCK/UNLOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)	12
		Other than above condition	0



# MULTI-REMOTE CONTROL SYSTEM

## ID Code Entry Procedure

### Activation of the registration mode:

The vehicle must have been unlocked by either the multi-remote controller or a transponder OK signal (TPOK) from the vehicle's immobilizer.

Preparation: - Make sure all doors unlock.

- Make sure all multi-remote controllers to be registered are available.
- Make sure the batteries of all multi-remote controllers are in a good condition.
- Make sure all transmitting sources are out of the neighbourhood of the vehicle.
- Make sure the battery of the vehicle is in a good condition.

Switch ignition-switch exactly six times from the "LOCK" to the "ON" position within 10 seconds and return the ignition switch to the "LOCK" position (leaving the key in the ignition switch).

After 2 seconds the registration mode is activated. The turn signal lamps will flash twice.

NG

OK

Proceed with the registration mode.

#### NOTE

The registration mode is operated when:

- The ignition-switch is turned to the "ON" position.
- 4 multi remote controllers have been learned.
- No multi-remote controller or ignition switch input is received within 120 seconds.

### Registration mode

Press and hold the "UNLOCK" button of the multi-remote controller.

Press the "LOCK" button 3 times.

Release the "UNLOCK" button.

Do you want to register another multi-remote controller? (max. 4)

No

Yes

After registration of the requested No. of multi-remote controller(s), confirm the ID-code(s) by switching the ignition switch to the "ON" position.

If the multi-remote controller registration is performed correctly, the turn signal lamp will flash twice.

Take the ignition key out of the ignition switch and confirm the functioning of all multi-remote controllers by locking and unlocking the vehicle with each of the multi-remote controllers.

OK

NG

End

# MULTI-REMOTE CONTROL SYSTEM

## Remote Controller Battery Replacement


**NOTE:**

- Be careful not to touch the circuit board or battery terminal.
- The remote controller is water-resistant. However, if it does get wet, immediately wipe it dry.
- Push the remote controller button two or three times to check its operation after replacing battery.

STEP 1

STEP 2

STEP 3



SEL241X

# MULTI-REMOTE CONTROL SYSTEM

---

NOTE

# SUPER LOCK CONTROL UNIT

## Description

The following systems are controlled by the super lock control unit.


- Warning chime
- Rear window defogger timer
- Power door lock (super lock)
- Interior room lamp timer

For detailed description and wiring diagrams, refer to the relevant pages for the each system. The control unit receives data from the switches, control units and sensors to control their corresponding system relays and actuators.

System	Input	Output
Power door lock (super lock)	Door switches Key switch (Insert) Door key cylinder switch (lock/unlock) Ignition switch (ON) Door unlock sensors Multi-remote control signals (lock/unlock) NATS IMMU signal (Anti-theft cancel)	Door lock actuator Super lock actuator
Warning chime	Key switch (Insert) Ignition switch (ON) Lighting switch (1st and 2nd) Front door switch (Driver side) Door unlock sensor (Driver side)	Warning chime
Rear window defogger timer	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Interior room lamp timer	Door switches Door unlock sensor (Driver side) Ignition switch (ON) Key switch (Insert)	Interior lamp


# SUPER LOCK CONTROL UNIT

## Schematic



# SUPER LOCK CONTROL UNIT

## Schematic (Cont'd)



TEL286M

# SUPER LOCK CONTROL UNIT


## Input/Output Operation Signal

### SUPER LOCK CONTROL UNIT INSPECTION TABLE

Terminal No.	Wire color	Connections	Operated condition	Voltage (Approximate values)
1	R	Power source (Fuse)	—	12V
3	L/Y	Super lock actuators	Key inserted into front door key cylinder, turning it to UNLOCK (Key is not in ignition key cylinder.)	5V
4	L/R	Passenger door lock actuator	Door lock & unlock switch      Unlocked	12V
6	L/W	Super lock actuators	Key inserted into front door key cylinder, turning it to LOCK (When super lock is in release condition)	12V
10	W/R	Power source (C/B)	—	12V
11	L/R	Driver door lock actuator	Door lock & unlock switch      Free	0V
14	L	Door lock actuators	Door lock & unlock switch      Free	0V
			Door lock & unlock switch      Locked	12V
16	B	Ground	—	—
17	B/W	Ignition switch (ON)	Ignition key is in "ON" position	12V
18	BR	Ignition key switch (Insert)	key inserted → key removed from IGN key cylinder	12V → 0V
19	L/B	Lighting switch (1ST)	1ST, 2ND positions: ON → OFF	12V → 0V
20	P	Door lock/unlock switches	Neutral → Locked	5V → 0V
23	LG	Door lock/unlock switches	Neutral → Unlocked	5V → 0V
24	R/Y	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	5V → 0V
25	Y/G	Door key cylinder unlock switch	OFF (Neutral) → ON (Unlocked)	5V → 0V
26	R/W	Interior room lamp	When interior lamp is operated with driver's door is unlocked. (Lamp switch in "DOOR" position)      Locked	12V
			When interior lamp is operated with driver's door is unlocked. (Lamp switch in "DOOR" position)      Unlocked	0V
27	B/W	Rear window defogger relay	OFF → ON (Ignition key is in "ON" position)	12V → 0V
28	L/W	Driver door unlock sensor	Driver door: Locked → Unlocked	12V → 0V
29	PU	Passenger door unlock sensor	Passenger and back door: Locked → Unlocked	5V → 0V
30	R/Y	Driver door switch	OFF (Closed) → ON (Open)	12V → 0V
31	R/B	All door switches	OFF (Closed) → ON (Open)	12V → 0V
32	B/R	Lock signal (from multi-remote control unit)	Remove controller LOCK button is pushed (Key is not in ignition key cylinder.)	0V
			Other than above condition	5V
33	B/Y	Unlock signal (from multi-remote control unit)	Remove controller UNLOCK button is pushed (When super lock is in release condition)	0V
			Other than above condition	12V
34	R	Anti-theft cancel signal	When super lock is in set condition with driver and passenger door is locked, insert the key into ignition key cylinder and turn it to ON.	5V
35	SB	Rear window defogger switch	OFF → ON	5V → 0V

# NATS (Nissan Anti-Theft System)

## Component Parts and Harness Connector Location



**NOTE:**

If customer reports a "No Start" condition, request ALL KEYS to be brought to the Dealer in case of a NATS malfunction.

# NATS (Nissan Anti-Theft System)

## System Description

NATS has the following immobilizer functions:

- Since only NATS ignition keys, whose ID nos. have been registered into the ECM and IMMU of NATS, allow the engine to run, operation of a stolen vehicle without a NATS registered key is prevented by NATS.  
That is to say, NATS will immobilize the engine if someone tries to start it without the registered key of NATS.
- This version of NATS has dongle unit to improve its anti-theft performance (RHD models). Dongle unit has its own ID which is registered into NATS IMMU. So it dongle unit is replaced, initialization must be carried out.
- When malfunction of dongle unit is detected:
  - The security indicator lamp illuminates for about 15 minutes after ignition switch is turned to ON.
  - When dongle unit has a malfunction and the indicator lamp is illuminated, engine can not be started. However, engine can be started only one time when security indicator turns off in about 15 minutes after ignition switch is turned to ON.
- Both of the originally supplied ignition key IDs have been NATS registered.  
If requested by the vehicle owner, a maximum of five key IDs can be registered into the NATS components.
- The NATS security indicator (NATS security ind.) blinks when the ignition switch is in “OFF” or “ACC” position. Therefore, NATS warns outsiders that the vehicle is equipped with the anti-theft system.
- When NATS detects trouble, the security indicator lamp lights up as follows.

Condition IGN ON and	With Dongle		Without Dongle	
	MIL	Security Indicator	MIL	Security Indicator
NATS malfunction (except dongle unit) is detected	—	1. 6 times blinking 2. Staying ON after ignition switch is turned ON	—	Staying ON
Only malfunction of dongle unit is detected.	—	Staying ON <b>for about 15 minutes</b> after ignition switch is turned ON.	—	—
Malfunction of NATS and engine related parts are detected	Staying ON	1. 6 times blinking 2. Staying ON after ignition switch is turned ON	Staying ON	Staying ON
Only engine related part malfunction is detected	Staying ON	—	Staying ON	—
Just after initialization of NATS	—	6 times blinking	—	—


- NATS trouble diagnoses, system initialization and additional registration of other NATS ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NATS software.  
Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.
- **When servicing a malfunction of the NATS (indicated by lighting up of security Indicator Lamp) or registering another NATS ignition key ID no., it is necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

# NATS (Nissan Anti-Theft System)

## System Composition

The immobilizer function of the NATS consists of the following:


- NATS ignition key
- NATS immobilizer control unit (NATS IMMU), located in the ignition key cylinder
- Engine control module (ECM)
- Dongle unit (RHD models)
- NATS security indicator



# NATS (Nissan Anti-Theft System)


## Wiring Diagram — NATS —

EL-NATS-01



Refer to EL-POWER.

L : LHD models  
R : RHD models  
 \*1 1 : L  
 23K : R



Refer to last page (Foldout page).


M21, E127  
M2  
M3  
F8




# NATS (Nissan Anti-Theft System)

## Wiring Diagram — NATS —/LHD Models

EL-NATS-02



WG : Wagon models



Refer to last page (Foldout page).

(M20, B19)  
(M21, E127)



# NATS (Nissan Anti-Theft System)

---

## CONSULT-II


### CONSULT-II INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Insert NATS program card into CONSULT-II.


#### Program card

#### EEN99A

3. Connect CONSULT-II to Data link connector which is located behind the fuse box cover.



4. Turn ignition switch ON.
5. Touch "START".



6. Perform each diagnostic test mode according to each service procedure.

**For further information, see the CONSULT-II Operation Manual, NATS.**

# NATS (Nissan Anti-Theft System)

## CONSULT-II (Cont'd)

### CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

CONSULT-II DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following components, C/U initialization is necessary. [NATS ignition key/IMMU/ECM/Dongle unit]
SELF-DIAG RESULTS	Detected items (screen terms) are as shown in the chart below.


**NOTE:**

When any initialization is performed, all ID previously registered will be erased. So all NATS ignition keys must be registered again.

The engine cannot be started with an unregistered key. In this case, the system may show “DIFFERENCE OF KEY” or “LOCK MODE” as a self-diagnostic result on the CONSULT-II screen.

When initialization is performed (for RHD models), security indicator will flash six times to demonstrate recognition of dongle unit ID.

### HOW TO READ SELF-DIAGNOSTIC RESULTS



# NATS (Nissan Anti-Theft System)

## CONSULT-II (Cont'd)

### SELF-DIAGNOSTIC RESULTS ITEM CHART

Detected items (Screen terms)	Description	Reference page
ECM INT CIRC-IMMU	The malfunction of ECM internal circuit of IMMU communication line is detected.	EL-1175
CHAIN OF ECM-IMMU	Communication impossible between ECM and IMMU. (In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.)	EL-1176
DIFFERENCE OF KEY	IMMU can receive the key ID signal but the result of ID verification between key ID and IMMU is NG.	EL-1178
CHAIN OF IMMU-KEY	IMMU cannot receive the key ID signal. Otherwise, the registered ID signal from dongle unit cannot be received when the IMMU requests the ID.	EL-1179
ID DISCORD, IMM-ECM	The result of ID verification between IMMU and ECM is NG. System initialization is required.	EL-1180
DON'T ERASE BEFORE CHECKING ENG DIAG	Engine trouble data and NATS trouble data have been detected in ECM.	EL-1172
LOCK MODE	When the starting operation is carried out 5 or more times consecutively under the following conditions, NATS will shift the mode to one which prevents the engine from being started. <ul style="list-style-type: none"><li>● unregistered ignition key is used</li><li>● IMMU or ECM malfunctioning</li></ul>	EL-1181



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### SYMPTOM MATRIX CHART 1 (Self-diagnosis related item)

SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON DIAGNOSTIC SYSTEM DIAGRAM
<ul style="list-style-type: none"> <li>● Security indicator lighting up*</li> <li>● Engine does not start</li> </ul>	ECM INT CIRC-IMMU	PROCEDURE 1 (EL-1175)	ECM	B
	CHAIN OF ECM-IMMU	PROCEDURE 2 (EL-1176)	In rare case, "CHAIN OF ECM-IMMU might be stored during key registration procedure, even if the system is not malfunctioning.	—
			Open circuit in battery voltage line of IMMU circuit	C1
			Open circuit in ignition line of IMMU circuit	C2
			Open circuit in ground line of IMMU circuit	C3
			Open circuit in communication line between IMMU and ECM	C4
			Short circuit between IMMU and ECM communication line and battery voltage line	C4
			Short circuit between IMMU and ECM communication line and ground line	C4
			ECM	B
	IMMU	A		
	DIFFERENCE OF KEY	PROCEDURE 3 (EL-1178)	Unregistered key	D
			IMMU	A
	CHAIN OF IMMU-KEY	PROCEDURE 4 (EL-1179)	Malfunction of key ID chip	E
			IMMU	A
			Open circuit in ground line of dongle unit circuit	C6
Open or short circuit in communication line between IMMU and dongle unit			C5	
Dongle unit			G	
<ul style="list-style-type: none"> <li>● Security indicator lighting up*</li> <li>● Engine hard to start</li> </ul>	ID DISCORD, IMM-ECM	PROCEDURE 5 (EL-1180)	System initialization has not yet been completed.	F
	ECM			B
	LOCK MODE	PROCEDURE 6 (EL-1181)	LOCK MODE	D
<ul style="list-style-type: none"> <li>● MIL staying ON</li> <li>● Security indicator lighting up*</li> </ul>	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (EL-1172)	Engine trouble data and NATS trouble data have been detected in ECM	—

\*: When NATS detects trouble, the security indicator lights up while ignition key is in the "ON" position.

\*: When the vehicle is equipped with dongle unit, the security indicator blinks 6 times just after ignition switch is turned to ON. Then the security indicator will light up while ignition key is in the ON position.


# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON DIAG- NOSTIC SYSTEM DIAGRAM
Security ind. does not light up.	PROCEDURE 7 (EL-1182)	Security ind.	—
		Open circuit between Fuse and NATS IMMU	—
		Continuation of initialization mode	—
		NATS IMMU	A
Security ind. does not blink just after initialization even if the vehicle is equipped with dongle unit.	PROCEDURE 8 (EL-1183)	NATS might be initialized without connecting dongle unit properly.	—
		Open circuit in ground line of dongle unit circuit	C6
Security ind. does not blink just after ignition switch is turned to ON when some mal- function related to NATS is detected even if the vehicle is equipped with dongle unit.	PROCEDURE 8 (EL-1183)	Open or short circuit in communication line between IMMU and dongle unit	C5
		Dongle unit	G

### DIAGNOSTIC SYSTEM DIAGRAM



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

Self-diagnostic results:

“ECM INT CIRC-IMMU” displayed on CONSULT-II screen

**A**

SELF-DIAG RESULTS	
DTC RESULTS	TIME
ECM INT CIRC-IMMU	0

SEL152X

**A**



Confirm SELF-DIAGNOSTIC RESULTS “ECM INT CIRC-IMMU” displayed on CONSULT-II screen.  
Ref. part No. B.



Replace ECM.



Perform initialization with CONSULT-II.  
For the operation of initialization, refer to “CONSULT-II operation manual NATS”.

# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

Self-diagnostic results:

“CHAIN OF ECM-IMMU” displayed on CONSULT-II screen

\*: In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.

**A**


SELF-DIAG RESULTS	
DTC RESULTS	TIME
ECM INT CIRC-IMMU	0

SEL153X

**A**

Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF ECM-IMMU”\* displayed on CONSULT-II screen.

OK



**B**

**CHECK POWER SUPPLY CIRCUIT FOR IMMU.**

Check voltage between terminal ⑧ of IMMU and ground.

**Voltage: Battery voltage**


NG

Check the following:

- 20A fuse (No. 50), located in the fuse and fusible link box
- Harness for open or short between fuse and IMMU connector

**Ref. part No. C1**

OK



**C**

**CHECK IGN SW. ON SIGNAL.**

Check voltage between terminal ⑦ of IMMU and ground while ignition switch is in the “ON” position.

**Voltage: Battery voltage**


NG

Check the following:

- 10A fuse [No. 25], located in the fuse block (J/B)
- Harness for open or short between fuse and IMMU connector

**Ref. part No. C2**

OK



**D**

**CHECK GROUND CIRCUIT FOR IMMU.**

Check harness continuity between IMMU terminal ④ and ground.


**Continuity should exist.**

NG

Repair harness.

**Ref. part No. C3**

OK



**E**

**CHECK COMMUNICATION ON OPEN CIRCUIT.**

Check harness continuity between the following ECM terminal and IMMU terminal.

ECM terminal ⑤⑤ or IMMU terminal ①

**Continuity should exist.**

NG

Repair harness.

**Ref. part No. C4**

OK

Ⓐ



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3

Self-diagnostic results:

“DIFFERENCE OF KEY” displayed on CONSULT-II screen

**A**


SELF DIAG RESULTS	
DTC RESULTS	TIME
DIFFERENCE OF KEY	0

SEL163X

**B**

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4





Self-diagnostic results:

“CHAIN OF IMMU-KEY” displayed on CONSULT-II screen

**A**

SELF DIAG RESULTS	
DTC RESULTS	TIME
CHAIN OF IMMU-KEY	0

SEL165X



OK

**CHECK NATS IGNITION KEY ID CHIP.**  
Start engine with another registered NATS ignition key.  
**Does the engine start?**

Yes

- Ignition key ID chip is malfunctioning.
1. Replace the ignition key.
- Ref. part No. E**
  2. Perform initialization with CONSULT-II. For the initialization procedure, refer to “CONSULT-II operation manual NATS”.

No

**Is this vehicle equipped with dongle unit (RHD models)?**

No

- IMMU is malfunctioning.
1. Replace IMMU.
- Ref. part No. A**
  2. Perform initialization with CONSULT-II. For the initialization procedure, refer to “CONSULT-II operation manual NATS”.

yes

**CHECK HARNESS CONNECTOR CONNECTION.**  
Check the following harness connector connection: (M29), (M121)  
**Does the engine start?**

Yes

System is OK.  
(The malfunction is caused by improper connector connection.)

No

**CHECK GROUND CIRCUIT FOR DONGLE UNIT.**  
Check continuity between dongle unit terminal ① and ground.  
**Continuity should exist.**

No

Repair harness.  
**Ref. part No. C6**

Yes

**C D**

**CHECK INTERFACE CIRCUIT.**

1. Check continuity between IMMU terminal ② and dongle unit terminal ① (Open circuit check)  
**Continuity should exist.**
2. Check continuity between IMMU terminal ② and ground. (Short circuit check)  
**Continuity should not exist.**

No

Repair harness.  
**Ref. part No. C5**

Yes

Dongle unit is malfunctioning.

1. Replace dongle unit. **Ref. part No. G**
2. Perform initialization with CONSULT-II. For the initialization procedure, refer to “CONSULT-II operation manual NATS”.

# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

Self-diagnostic results:

"ID DISCORD, IMM-ECM" displayed on CONSULT-II screen

**A**


SELF-DIAG RESULTS	
DTC RESULTS	TIME
ID DISCORD, IMM-ECM	0

SEL166X

**B**

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 6

#### Self-diagnostic results:

“LOCK MODE” displayed on CONSULT-II screen

**A**


SELF DIAG RESULTS	
DTC RESULTS	TIME
LOCK MODE	0

SEL167X

**B**

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W






# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 7


#### “SECURITY IND. DOES NOT LIGHT UP”



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 8




**A**

**CHECK GROUND CIRCUIT FOR DONGLE UNIT.**  
Check continuity between dongle unit terminal ① and ground.  
**Continuity should exist.**

No → Repair harness.  
Ref. part No. C6

Yes





**B**

**CHECK INTERFACE CIRCUIT.**  
1. Check continuity between IMMU terminal ② and dongle unit terminal ⑦.  
(Open circuit check)  
**Continuity should exist.**  
2. Check continuity between IMMU terminal ② and ground.  
(Short circuit check)  
**Continuity should exist.**

No → Repair harness.  
Ref. part No. C5

Yes

Dongle unit is malfunctioning.  
1. Replace dongle unit.  
**Ref. part No. G**  
2. Perform initialization with CONSULT-II.  
For the initialization procedure, refer to "CONSULT-II operation manual NATS".



## How to Replace NATS IMMU

### NOTE:

- If NATS IMMU is not installed correctly, NATS system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE".



## NATS (Nissan Anti-Theft System)

---

NOTE



# LOCATION OF ELECTRICAL UNITS

## Engine Compartment














# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment — LHD Models




# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment — LHD Models (Cont'd)

<p><b>B</b> Driver side view with dash side lower finisher removed</p>  <p>ASCD control unit (M17) ASCD hold relay (M15)</p>	<p><b>C</b> Driver side view with dash side lower finisher removed</p>  <p>Super lock control unit (M117, M118)</p>	<p><b>D</b></p>  <p>NATS IMMU (M29) Ignition key cylinder</p>
<p><b>E</b> Driver side view with lower instrument panel removed</p>  <p>ECM (F8)</p>	<p><b>F</b> Driver side view lower instrument panel removed</p>  <p>Combination flasher unit (M37)</p>	<p><b>G</b></p>  <p>Sub fuel tank control unit (M69) Stabilizer control unit (M44) Air bag diagnosis sensor unit (M54, B131, B132)</p>
<p><b>H</b></p>  <p>Smart entrance control unit (M41) Diff lock control unit (M68)</p>	<p><b>J</b> View with glove box assembly removed</p>  <p>Multi-remote control unit (M129, M133)</p>	<p><b>K</b> View with glove box assembly removed</p>  <p>Heated seat relay (M111) Theft warning horn relay (M125) Blower motor Circuit breaker-2 (M123) Power window relay (M91) Circuit breaker-1 (M92)</p>
<p><b>L</b> Passenger side view with dash side lower finisher removed</p>  <p>TCM (Transmission control module) (E101, E102)</p>	<p><b>M</b> Passenger side view with dash side lower finisher removed</p>  <p>Glow control unit (M16, M106)</p>	













# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment — RHD Models



# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment — RHD Models (Cont'd)

<p><b>B</b> Driver side view with dash side lower finisher removed</p>  <p>ASCD control unit (M17)</p> <p>ASCD hold relay (M15)</p>	<p><b>C</b> Driver side view with dash side lower finisher removed</p>  <p>Super lock control unit (M117, M118)</p>	<p><b>D</b> Driver side view with dash side lower finisher removed</p>  <p>Glow control unit (M16, M106)</p>
<p><b>E</b> Models except TD engine for Australia</p>  <p>NATS IMMU (M29)</p> <p>Ignition key cylinder</p>	<p><b>F</b> Driver side view with lower instrument panel removed</p>  <p>ECM (F8)</p>	<p><b>G</b> Driver side view with lower instrument panel removed</p>  <p>Combination flasher unit (M37)</p>
<p><b>H</b></p> <p>Seat belt timer (M43)</p> <p>Sub fuel tank control unit (M69)</p> <p>Stabilizer control unit (M44)</p> <p>Cornering lamp relay unit (M110)</p>  <p>Air bag diagnosis sensor unit (M54, B44, B45)</p>	<p><b>J</b></p> <p>Diff lock control unit (M68)</p>  <p>Smart entrance control unit (M41)</p>	<p><b>K</b> View with glove box assembly removed</p>  <p>Multi-remote control unit (M129, M133)</p>
<p><b>L</b> View with glove box assembly removed</p> <p>Heated seat relay (M111)</p> <p>Circuit breaker-2 (M123)</p> <p>Power window relay (M91)</p> <p>Circuit breaker-1 (M92)</p> <p>Blower motor</p> 	<p><b>M</b> Passenger side view with dash side lower finisher removed</p>  <p>TCM (Transmission control module) (E101, E102)</p>	<p><b>N</b> NATS IMMU locates behind cooling unit</p>  <p>Cooling unit</p>

## LOCATION OF ELECTRICAL UNITS


---

NOTE

# HARNESS LAYOUT

## How to Read Harness Layout

Example:



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)

### To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.


### CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> <li>● Cavity: Less than 4</li> <li>● Relay connector</li> </ul>				
<ul style="list-style-type: none"> <li>● Cavity: From 5 to 8</li> </ul>				
<ul style="list-style-type: none"> <li>● Cavity: More than 9</li> </ul>	—	—		
<ul style="list-style-type: none"> <li>● Ground terminal etc.</li> </ul>	—			

# HARNESS LAYOUT

## Main Harness/LHD Models



# HARNESS LAYOUT

## Main Harness/LHD Models (Cont'd)


B3	M1	W/8	: Fuse block (J/B)	D2	M46	W/6	: Rear window defogger switch
A3	M2	BR/16	: Fuse block (J/B)	D1	M47	BR/8	: Headlamp wiper switch
B4	M3	GY/16	: Fuse block (J/B)	D1	M48	BR/8	: Sub fuel tank switch
B4	M4	GY/8	: Fuse block (J/B)	D1	M49	W/8	: Hazard switch
B4	M5	B/2	: Fuse block (J/B)	D1	M50	W/6	: To F5
B3	M6	W/12	: Fuse block (J/B)	C1	M51	W/16	: To F6
C4	M7	GY/14	: Data link connector (TB, TD engine models for the Middle East and for China)	C3	M52	W/24	: To F7
C3	M8	L/4	: ECM relay (TB45E engine models)	E2	M53	W/8	: Rear heater front switch
C3	M9	BR/6	: ECM relay (ZD engine models)	E3	M54	Y/20	: Air bag diagnosis sensor unit
C4	M10	W/16	: Data link connector (TB, TD engine models except for the Middle East and except for China)	F1	M56	B/2	: Sunload sensor (With front auto A/C)
B3	M11	W/8	: Headlamp aiming switch	F2	M57	Y/2	: Air bag module (Passenger side) (With dual air bag system)
B2	M12	W/6	: ASCD main switch	F2	M58	W/2	: Intake sensor (With front auto A/C)
B2	M13	W/6	: Heat up switch (ZD engine models)	G3	M59	W/3	: Thermo control amp.
B2	M14	GY/12	: Door mirror remote control switch	E1	M61	W/8	: Rear cooler front switch
A5	M15	L/4	: ASCD hold relay	E2	M62	W/6	: Radio and cassette player
F4	M16	W/12	: Glow control unit (TD engine models except for cold areas)	E1	M63	W/10	: Radio or radio and cassette player
A4	M17	B/20	: ASCD control unit	D1	M64	W/12	: Radio and cassette player (With CD auto changer)
A5	M19	—	: Body ground	E1	M65	W/4	: CD player
A3	M20	SMJ	: To B19	D4	M67	BR/8	: Diff lock switch
A3	M21	SMJ	: To E127	F3	M68	B/12	: Diff lock control unit
A2	M22	SMJ	: To D1	E4	M69	BR/16	: Sub fuel tank control unit
G1	M23	W/3	: Tweeter RH	F4	M70	B/16	: A/C auto amp. (With front auto A/C)
G1	M24	W/10	: To R1	D1	M71	W/6	: Fan switch
C3	M28	Y/7	: Spiral cable (With air bag)	F4	M73	W/3	: Fan switch illumination } (With front manual A/C)
C3	M29	W/8	: NATS IMM (With NATS)	F3	M74	W/8	: Recirculation switch
C1	M30	—	: Body ground	D4	M75	B/20	: A/C auto amp. } (With front auto A/C)
C1	M31	W/2	: Security indicator lamp (With NATS)	F1	M76	W/4	: Intake door motor
B2	M32	W/10	: Combination meter	F1	M77	W/4	: Intake door motor (With front manual A/C)
C1	M33	BR/16	: Combination meter	F1	M78	W/4	: Fan control amp. (With front auto A/C)
C1	M34	W/16	: Combination meter	B1	M79	W/20	: Joint connector-1
C1	M35	W/10	: Combination meter	B1	M80	B/12	: Joint connector-2
B2	M36	L/2	: ASCD clutch switch (M/T models with ASCD)	G1	M84	W/18	: To D21
D3	M37	B/3	: Combination flasher unit	F2	M85	W/2	: Diode (With front manual A/C)
D3	M38	W/3	: Mode door motor (With front auto A/C)	G3	M86	W/12	: To E104
C2	M39	W/3	: Illumination control switch	G2	M87	W/16	: To E105
D4	M40	W/3	: Air mix door motor (With front auto A/C)	G3	M88	W/24	: To E106
D3	M41	W/18	: Smart entrance control unit (Except for China)				
E4	M42	B/2	: Cigarette lighter				
E4	M44	W/12	: Stabilizer control unit				
D3	M45	W/2	: In-vehicle sensor (With front auto A/C)				

# HARNESS LAYOUT


## Main Harness/LHD Models (Cont'd)

A3	(M90)	L/4	: Fuel pump relay (TB45E engine models)
G2	(M91)	L/4	: Power window relay
G2	(M92)	W/2	: Circuit breaker-1
G2	(M93)	BR/4	: Blower resistor (With front manual A/C)
G2	(M94)	W/2	: Blower motor
G3	(M95)	W/10	: To (B104)
G3	(M96)	W/16	: To (B103)
G3	(M97)	W/12	: To (B102)
G2	(M98)	—	: Body ground
B2	(M100)	L/6	: Stabilizer switch
C2	(M101)	B/2	: Stop lamp switch
C3	(M102)	L/2	: ASCD brake switch
F3	(M106)	W/16	: Glow control unit (TD engine models for cold areas)
C3	(M107)	L/2	: A/T check switch (A/T models for the Middle East)
C3	(M108)	B/6	: Front fog lamp switch
G1	(M111)	L/4	: Heated seat relay
E4	(M112)	B/1	: Cigarette lighter illumination
F2	(M113)	W/2	: Resistor (With diff lock)
C3	(M115)	W/8	: Check connector (TB45S engine models)
A4	(M116)	W/6	: Fuel pump control module (FPCM) (TB45S engine models)
A4	(M117)	GY/16	: Super lock control unit
A4	(M118)	GY/20	: Super lock control unit
D4	(M119)	W/3	: Jumping connector
E4	(M120)	GY/20	: Steering wheel receiver control switch
E1	(M121)	BR/8	: Not used
D1	(M122)	W/16	: Radio
G2	(M123)	W/2	: Circuit breaker-2
G1	(M125)	BR/6	: Theft warning horn relay
E1	(M126)	W/18	: Smart entrance control unit
F1	(M127)	B/24	: Smart entrance control unit
B1	(M128)	BR/2	: Security indicator lamp
F1	(M129)	W/16	: Multi-remote control unit (Except for Europe)
C3	(M130)	L/4	: Fuel pump relay (TB45S engine models)
E1	(M133)	BR/8	: Multi-remote control unit
E1	(M134)	W/6	: Anti-theft unit (Opt)

Diode (M85)



Resistor (M113)




# HARNESS LAYOUT

---

NOTE

# HARNESS LAYOUT

## Main Harness/RHD Models




# HARNESS LAYOUT

## Main Harness/RHD Models (Cont'd)

F4	(M1)	W/8	: Fuse block (J/B)	C4	(M43)	W/8	: Seat belt timer (Without sub fuel tank for Australia)
E4	(M2)	BR/16	: Fuse block (J/B)	C4	(M44)	W/12	: Stabilizer control unit
F4	(M3)	GY/16	: Fuse block (J/B)	D4	(M45)	W/2	: In-vehicle sensor (With front auto A/C)
F4	(M4)	GY/8	: Fuse block (J/B)	D1	(M46)	W/6	: Rear window defogger switch
F4	(M5)	B/2	: Fuse block (J/B)	E1	(M47)	BR/8	: Headlamp wiper switch
E4	(M6)	W/12	: Fuse block (J/B)	D1	(M48)	BR/6	: Sub fuel tank switch
E3	(M7)	GY/14	: Data link connector (TD engine models for Australia)	D1	(M49)	W/8	: Hazard switch
F1	(M8)	L/4	: ECM relay (TB45E engine models)	E4	(M50)	W/6	: To (F5)
G2	(M9)	BR/6	: ECM relay (ZD engine models)	D2	(M51)	W/16	: To (F6)
E4	(M10)	W/16	: Data link connector (Except for TD engine models for Australia)	E4	(M52)	W/24	: To (F7)
D4	(M11)	W/8	: Headlamp aiming switch	C1	(M53)	W/8	: Rear heater front switch
G2	(M12)	W/6	: ASCD main switch	C3	(M54)	Y/20	: Air bag diagnosis sensor unit
G2	(M13)	W/6	: Heat up switch (ZD engine models)	B1	(M56)	B/2	: Sunload sensor (With front auto A/C)
F1	(M14)	GY/12	: Door mirror remote control switch	A1	(M57)	Y/2	: Air bag module (Passenger side) (With dual air bag system)
G4	(M15)	L/4	: ASCD hold relay	B2	(M58)	W/2	: Intake sensor (With front auto A/C)
G4	(M16)	W/12	: Glow control unit (TD engine models except for Australia)	B2	(M59)	W/3	: Thermo control amp.
G4	(M17)	B/20	: ASCD control unit	C2	(M60)	L/6	: Power antenna switch
A2	(M19)	—	: Body ground	C1	(M61)	W/8	: Rear cooler front switch
G3	(M20)	SMJ	: To (B19)	D1	(M62)	W/6	: Radio and cassette player
G3	(M21)	SMJ	: To (E127)	C1	(M63)	W/10	: Radio or radio and cassette player
G2	(M22)	SMJ	: To (D1)	C2	(M64)	W/12	: Radio and cassette player (With CD auto changer)
G1	(M23)	W/3	: Tweeter RH	D1	(M65)	W/4	: CD player
G2	(M24)	W/10	: To (R1)	C4	(M67)	BR/8	: Diff lock switch
G3	(M25)	BR/3	: Accelerator position sensor	B3	(M68)	B/12	: Diff lock control unit
F5	(M26)	GY/3	: Accelerator position switch	C4	(M69)	BR/16	: Sub fuel tank control unit
G3	(M27)	W/3	: Accelerator switch (F/C)	C3	(M70)	B/16	: A/C auto amp. (With front auto A/C)
E3	(M28)	Y/7	: Spiral cable (With air bag)	D1	(M71)	W/6	: Fan switch
E2	(M29)	W/8	: NATS IMM (With NATS)	C3	(M73)	W/3	: Fan switch illumination } (With front manual A/C)
E2	(M30)	—	: Body ground	B3	(M74)	W/8	: Recirculation switch
E1	(M31)	W/2	: Security indicator lamp (With NATS)	D1	(M75)	B/20	: A/C auto amp. } (With front auto A/C)
E1	(M32)	W/10	: Combination meter	B1	(M76)	W/4	: Intake door motor
E1	(M33)	BR/16	: Combination meter	B1	(M77)	W/4	: Intake door motor (With front manual A/C)
E2	(M34)	W/16	: Combination meter	A1	(M78)	W/4	: Fan control amp. (With front auto A/C)
E1	(M35)	W/10	: Combination meter	B1	(M79)	W/20	: Joint connector-1
D3	(M36)	L/2	: ASCD clutch switch (M/T models with ASCD)	B1	(M80)	B/12	: Joint connector-2
E3	(M37)	B/3	: Combination flasher unit	A1	(M83)	W/3	: Tweeter LH
D3	(M38)	W/3	: Mode door motor (With front auto A/C)	A2	(M84)	W/18	: To (D21)
F2	(M39)	W/3	: Illumination control switch	A1	(M85)	W/2	: Diode (With front manual A/C)
D4	(M40)	W/3	: Air mix door motor (With front auto A/C)	A3	(M86)	BR/16	: To (E1D4)
C4	(M41)	W/18	: Smart entrance control unit	A2	(M87)	W/16	: To (E1D5)
C4	(M42)	B/2	: Cigarette lighter	B3	(M88)	W/24	: To (E1D6)

# HARNESS LAYOUT

## Main Harness/RHD Models (Cont'd)



F3	(M90)	L/4	: Fuel pump relay (TB45E engine models)
A2	(M91)	L/4	: Power window relay
A2	(M92)	W/2	: Circuit breaker-1
B3	(M93)	BR/4	: Blower resistor (With front manual A/C)
B3	(M94)	W/2	: Blower motor
A3	(M95)	W/16	: To (B101)
A3	(M96)	W/20	: To (B102)
A3	(M97)	W/16	: To (B103)
G5	(M98)	—	: Body ground
B3	(M99)	W/6	: To (B104)
E1	(M100)	L/6	: Stabilizer switch
E3	(M101)	B/2	: Stop lamp switch
E3	(M102)	L/2	: ASCD brake switch
C1	(M103)	W/12	: NATS IMMU
E2	(M104)	W/4	: NATS antenna amp. } (TD engine models for Australia)
G4	(M106)	W/16	: Grow control unit
F2	(M108)	B/6	: Front fog lamp switch
C3	(M110)	W/10	: Cornering lamp relay unit
A1	(M111)	L/4	: Heated seat relay
D4	(M112)	B/1	: Cigarette lighter illumination
B2	(M113)	W/2	: Resistor (With diff lock)
E3	(M115)	W/8	: Check connector (TB45S engine models)
G4	(M116)	W/6	: Fuel pump control module (FPCM) (TB45S engine models)
G4	(M117)	GY/16	: Super lock control unit
G4	(M118)	GY/20	: Super lock control unit
C2	(M121)	BR/8	: Dongle unit
A2	(M123)	W/2	: Circuit breaker-2
B2	(M129)	W/16	: Multi-remote control unit (Except for Europe and South Africa)
F2	(M130)	L/4	: Fuel pump relay (TB45S engine models)
B1	(M133)	BR/8	: Multi-remote control unit (For Europe and South Africa)
C1	(M133)	W/6	: Anti-theft unit (Opt)


# HARNESS LAYOUT

---

NOTE

# HARNESS LAYOUT

## Engine Room Harness/LHD Models



# HARNESS LAYOUT


## Engine Room Harness/LHD Models (Cont'd)

C1	(E1)	—	: Fuse and fusible link box	C1	(E54)	—	: Body ground
A1	(E3)	B/5	: Transfer neutral relay	D2	(E55)	B/2	: Side turn signal lamp RH
A1	(E4)	L/4	: Cornering lamp relay	G2	(E57)	B/2	: Wiper deicer
B1	(E5)	BR/6	: Air conditioner relay	F2	(E58)	W/6	: Front wiper motor
B1	(E7)	L/4	: Bulb check relay	E1	(E59)	G/2	: Grow relay-1
A1	(E8)	L/4	: Cooling fan relay-1	E1	(E60)	W/1	: Grow relay-1
A1	(E9)	W/3	: Horn relay	E1	(E61)	W/1	: Grow relay-1
G2	(E10)	GY/4	: Diff lock solenoid	F3	(E62)	BR/2	: Front wheel sensor LH (With ABS)
B1	(E12)	L/4	: Wiper deicer relay	E2	(E64)	W/1	: Vacuum warning switch
C2	(E13)	—	: Battery (+)	C1	(E65)	B/2	: To (E204)
D2	(E18)	SMJ	: ABS actuator and electric unit	C3	(E66)	L/2	: To (E205)
D3	(E19)	GY/3	: Power antenna	C3	(E67)	R/2	: To (E223)
G3	(E20)	B/2	: Side turn signal lamp LH	C2	(E68)	GY/8	: To (E222) (TD engine models)
C1	(E22)	—	: Body ground (With ABS)	C2	(E69)	B/8	: To (E202)
E4	(E24)	GY/4	: Front combination lamp LH	C2	(E70)	GY/10	: To (E201)
F3	(E25)	—	: Body ground	D3	(E71)	GY/3	: Revolution sensor
D4	(E26)	GY/6	: Headlamp aiming motor LH	D3	(E72)	BR/8	: A/T solenoid valve
E4	(E30)	B/3	: Headlamp LH	D3	(E73)	GY/8	: Park/Neutral position switch
D4	(E33)	GY/4	: Headlamp wiper motor LH	D3	(E74)	GY/2	: Park/Neutral position switch
C3	(E34)	B/2	: Ambient air temperature sensor (With compass and thermometer)	D3	(E75)	BR/2	: Fuel filter switch
D3	(E35)	B/2	: Ambient sensor (With front auto A/C)	F2	(E76)	GY/2	: Brake fluid level switch
D3	(E36)	GY/4	: Cooling fan motor-1	D2	(E77)	GY/2	: Front wheel sensor RH (With ABS)
B4	(E38)	GY/6	: Headlamp wiper motor RH	F2	(E78)	GY/2	: Dropping resistor (A/T models)
A2	(E39)	B/2	: Dual-pressure switch	C4	(E79)	BR/2	: Front fog lamp RH
A2	(E40)	—	: Body ground	D4	(E80)	BR/2	: Front fog lamp LH
A4	(E41)	GY/6	: Headlamp aiming motor RH	A3	(E82)	GY/8	: Daytime light control unit
D4	(E42)	GY/2	: Engine coolant temperature switch-2 (TD engine models with A/C)	C4	(E83)	GY/6	: Daytime light control unit
B4	(E43)	GY/2	: To (E181) (With electrical winch)	D1	(E87)	G/2	: Grow relay-2
B4	(E44)	B/1	: Horn low	D1	(E88)	W/1	: Grow relay-2
A3	(E45)	B/3	: Headlamp RH	D1	(E89)	W/1	: Grow relay-2
B2	(E46)	GY/2	: Front washer motor	B1	(E91)	BR/6	: Rear window defogger relay
A2	(E47)	BR/2	: Rear washer motor	A1	(E92)	B/5	: A/C cut relay
A2	(E48)	GY/2	: Headlamp washer motor	C4	(E94)	GY/2	: Engine coolant temperature switch-1
A3	(E49)	GY/4	: Front combination lamp RH	D2	(E95)	B/1	: IACV-FICD solenoid valve
D4	(E50)	B/1	: Horn high	D2	(E96)	B/1	: IACV-FICD solenoid valve
B2	(E51)	BR/2	: Park/Neutral position relay-1	B1	(E152)	L/4	: Front fog lamp relay
C3	(E52)	BR/2	: Park/Neutral position relay-1	A1	(E153)	L/4	: Rear fog lamp relay
				E3	(E155)	B/2	: Exhaust gas control valve control solenoid valve
				B1	(E157)	B/5	: Shift lock relay (A/T models)
				C3	(E160)	GY/2	: Hood switch (Opt) (For Europe)

# HARNESS LAYOUT


## Engine Room Harness/LHD Models (Cont'd)

### PASSENGER COMPARTMENT



# HARNESS LAYOUT

## Engine Room Harness/LHD Models (Cont'd)



- (E101) W/24 : TCM (Transmission control module)
- (E102) GY/24 : TCM (Transmission control module)
- (E103) L/4 : Diode (A/T models)
- (E104) W/12 : To (M86)
- (E105) W/16 : To (M87)
- (E106) W/24 : To (M88)
- (E107) W/2 : To (B101)
- (E108) L/10 : Diode
- (E109) B/1 : Horn switch (Without air bag)
- (E110) B/2 : Fuse block (J/B)
- (E111) W/4 : Fuse block (J/B)
- (E112) W/16 : Fuse block (J/B)
- (E113) BR/2 : Key switch
- (E114) W/6 : Ignition switch
- (E115) BR/8 : Combination switch } (Lighting switch)
- (E116) BR/4 : Combination switch }
- (E117) BR/3 : Combination switch (Cornering lamp switch)
- (E118) W/4 : Combination switch (Rear wiper switch)
- (E119) GY/8 : Combination switch (Front wiper switch) (Without intermittent wiper)
- (E120) GY/8 : Combination switch (Front wiper switch) (With intermittent wiper)
- (E121) W/2 : Condenser (TB45S engine models)
- (E122) W/2 : Diode (Except for TB45S engine models)
- (E127) SMJ : To (M21)
- (E128) W/6 : Combination switch (Rear fog lamp switch)
- (E129) W/6 : Combination switch (Front and rear fog lamp switch)
- (E131) W/3 : Tweeter LH



# HARNESS LAYOUT


## Engine Room Harness/RHD Models (Cont'd)

C1	(E1)	—	: Fuse and fusible link box	B3	(E54)	—	: Body ground
A1	(E3)	B/5	: Transfer neutral relay	B3	(E55)	B/2	: Side turn signal lamp RH
B1	(E5)	BR/6	: Air conditioner relay	B2	(E57)	B/2	: Wiper deicer
B1	(E7)	L/4	: Bulb check relay	C2	(E58)	W/6	: Front wiper motor
A1	(E8)	L/4	: Cooling fan relay-1	B2	(E59)	G/2	: Grow relay-1
A1	(E9)	W/3	: Horn relay	B2	(E60)	W/1	: Grow relay-1
E2	(E10)	SB/4	: Diff lock solenoid	B2	(E61)	W/1	: Grow relay-1
B1	(E12)	L/4	: Wiper deicer relay	E2	(E62)	BR/2	: Front wheel sensor LH (With ABS)
C3	(E13)	—	: Battery (+)	D2	(E64)	W/1	: Vacuum warning switch (Except for Australia)
E2	(E18)	SMJ	: ABS actuator and electric unit	D2	(E65)	B/2	: To (E204)
E3	(E19)	SB/4	: Power antenna	D3	(E66)	L/2	: To (E203)
E3	(E20)	B/2	: Side turn signal lamp LH	D3	(E67)	R/2	: To (E223)
F2	(E22)	—	: Body ground (With ABS)	C3	(E68)	SB/8	: To (E222) (TD engine models)
G3	(E24)	SB/4	: Front combination lamp LH	B3	(E69)	GY/8	: To (E202)
G2	(E25)	—	: Body ground	C3	(E70)	GY/10	: To (E201)
G4	(E26)	GY/6	: Headlamp aiming motor LH	D2	(E71)	GY/3	: Revolution sensor
G3	(E30)	B/3	: Headlamp LH	D2	(E72)	BR/8	: A/T solenoid valve
G3	(E33)	GY/4	: Headlamp wiper motor LH	D3	(E73)	GY/8	: Park/Neutral position switch
F3	(E34)	B/2	: Ambient air temperature sensor (With compass and thermometer)	D3	(E74)	GY/2	: Park/Neutral position switch
F4	(E35)	B/2	: Ambient sensor (With auto A/C)	D3	(E75)	BR/2	: Fuel filter switch
F4	(E36)	GY/4	: Cooling fan motor-1	C2	(E76)	GY/2	: Brake fluid level switch
F4	(E38)	GY/6	: Headlamp wiper motor RH	C2	(E77)	GY/2	: Front wheel sensor RH (With ABS)
E3	(E39)	B/2	: Dual-pressure switch	C2	(E78)	GY/2	: Dropping resistor (A/T models)
C4	(E40)	—	: Body ground	E4	(E79)	BR/2	: Front fog lamp RH
D4	(E41)	GY/6	: Headlamp aiming motor RH	F3	(E80)	BR/2	: Front fog lamp LH
F3	(E42)	GY/2	: Engine coolant temperature switch-2 (TD engine models with A/C)	B2	(E87)	G/2	: Glow relay-2
E4	(E43)	GY/2	: To (E181) (With electrical winch)	B3	(E88)	W/1	: Glow relay-2
D5	(E44)	B/1	: Horn low	B3	(E89)	W/1	: Glow relay-2
D4	(E45)	B/3	: Headlamp RH	B1	(E91)	BR/6	: Rear window defogger relay
E4	(E46)	GY/2	: Front washer motor	A1	(E92)	B/5	: A/C cut relay
D5	(E47)	BR/2	: Rear washer motor	E4	(E94)	GY/2	: Engine coolant temperature switch-1
C4	(E48)	GY/2	: Headlamp washer motor	C1	(E95)	B/1	: IACV-FICD solenoid valve
C4	(E49)	SB/4	: Front combination lamp RH	C2	(E96)	B/1	: IACV-FICD solenoid valve
F4, G4	(E50)	B/1	: Horn high	B1	(E152)	L/4	: Front fog lamp relay
C4	(E51)	GY/2	: Park/Neutral position relay-1	A1	(E153)	L/4	: Rear fog lamp relay
C4	(E52)	GY/2	: Park/Neutral position relay-1	E2	(E155)	B/2	: Exhaust gas control valve control solenoid valve
			(A/T models)	B1	(E157)	B/5	: Shift lock relay (A/T models)
				E3	(E160)	GY/2	: Hood switch (Opt) (For Europe)
							(ZD engine models)
							(TD engine models with A/C)

# HARNESS LAYOUT

## Engine Room Harness/RHD Models (Cont'd)




### PASSENGER COMPARTMENT



# HARNESS LAYOUT


## Engine Room Harness/RHD Models (Cont'd)

- (E101) W/24 : TCM (Transmission control module)
- (E102) GY/24 : TCM (Transmission control module)
- (E103) L/4 : Diode (A/T models)
- (E104) BR/16 : To (M86)
- (E105) W/16 : To (M87)
- (E106) W/24 : To (M88)
- (E108) L/10 : Diode
- (E109) B/1 : Horn switch (Without air bag)
- (E110) B/2 : Fuse block (J/B)
- (E111) W/4 : Fuse block (J/B)
- (E112) W/16 : Fuse block (J/B)
- (E113) BR/2 : Key switch (Except for TD engine models for Australia)
- (E114) W/6 : Ignition switch
- (E115) BR/8 : Combination switch } (Lighting switch)
- (E116) BR/4 : Combination switch }
- (E118) W/4 : Combination switch (Rear wiper switch)
- (E119) GY/8 : Combination switch (Front wiper switch)  
(Without intermittent wiper)
- (E120) GY/8 : Combination switch (Front wiper switch)  
(With intermittent wiper)
- (E121) W/2 : Condenser (TB45S engine models)
- (E122) W/2 : Diode (Except for TB45S engine models)
- (E127) SMJ : To (M21)
- (E128) W/6 : Combination switch (Rear fog lamp switch)
- (E165) W/2 : Key switch (TD engine models for Australia)



# HARNESS LAYOUT

## Engine Harness



### Engine harness

(E201)	GY/10	:	To (E70)
(E202)	B/8	:	To (E69)
(E203)	L/2	:	To (E66)
(E204)	B/2	:	To (E65)
(E205)	-	:	Fuse and fusible link box
(E206)	-	:	Battery (+)
(E207)	GY/1	:	Starter motor
(E208)	-	:	Starter motor
(E209)	GY/2	:	Vehicle speed sensor
(E210)	GY/2	:	Back-up lamp switch
(E211)	B/2	:	Park/Neutral position switch } (M/T models)
(E212)	GY/2	:	4WD switch
(E213)	BR/2	:	Transfer neutral switch
(E214)	-	:	Alternator
(E215)	-	:	Alternator
(E216)	GY/2	:	Alternator
(E217)	B/1	:	Oil pressure switch
(E219)	GY/2	:	Engine coolant temperature sensor
(E223)	R/2	:	To (E67)
(E225)	B/1	:	To (E241)


(E226)	B/1	:	Compressor
(E229)	-	:	Battery (+) (For cold areas)
(E230)	B/8	:	To (F12)
(E231)	GY/5	:	Mass air flow sensor
(E232)	BR/2	:	Variable nozzle turbocharger control solenoid valve
(E235)	B/1	:	Thermal transmitter

### Glow sub-harness

(E241)	B/1	:	To (E225)
(E242)	-	:	Glow plug

# HARNESS LAYOUT


## Engine Control Harness



# HARNESS LAYOUT


## Body Harness/LHD Models

WAGON



# HARNESS LAYOUT


## Body Harness/LHD Models (Cont'd)




# HARNESS LAYOUT

## Body Harness/LHD Models (Cont'd)

HARDTOP




Body ground



# HARNES LAYOUT

## Body Harness/LHD Models (Cont'd)




(B1)	W/12	:	To (B105)
(B2)	W/8	:	To (B106)
(B5)	W/3	:	Heated seat LH
(B6)	W/6	:	Wiper deicer switch
(B7)	W/4	:	Heated seat switch LH
(B8)	L/4	:	Heated seat switch RH
(B9)	W/3	:	Heated seat switch RH
(B10)	B/1	:	Ashtray illumination
(B11)	W/8	:	Parking brake switch
(B12)	W/8	:	A/T device
(B15)	W/3	:	A/T mode switch
(B16)	W/3	:	Heated seat RH
(B19)	SMJ	:	Seat belt buckle switch
(B20)	B/3	:	To (M20)
(B22)	B/3	:	Front door switch (Driver side)
(B23)	W/4	:	Seat belt pre-tensioner (Driver side)
(B26)	-	:	Body ground
(B29)	W/16	:	CD auto changer
(B29)	W/6	:	To (D81)
(B30)	BR/6	:	Rear combination lamp LH
(B31)	BR/2	:	Rear speaker LH
(B33)	BR/2	:	G sensor } (With ABS)
(B34)	GY/2	:	G sensor }
(B35)	GY/8	:	To (C1)
(B36)	SB/6	:	To (C3)
(B37)	SB/8	:	To (C2)
(B40)	W/6	:	Cool box
(B41)	B/2	:	Power socket
(B42)	L/4	:	Power socket relay
(B52)	W/2	:	Diode-1 } (A/T models)
(B53)	W/2	:	Diode-2 }


# HARNESS LAYOUT

## Body Harness/RHD Models


WAGON




Body ground



Body ground




Body ground



# HARNESS LAYOUT

## Body Harness/RHD Models (Cont'd)




(B1)	W/12	:	To (B105)
(B2)	W/10	:	To (B106)
(B3)	W/4	:	To (B130)
(B4)	W/2	:	Power seat (Passenger side)
(B5)	W/3	:	Heated seat LH
(B6)	W/6	:	Wiper deicer switch
(B7)	W/4	:	Heated seat switch LH
(B8)	L/4	:	Heated seat switch RH
(B9)	W/3	:	Ashtray illumination
(B10)	B/1	:	Parking brake switch
(B11)	W/8	:	A/T device
(B12)	W/8	:	A/T mode switch
(B13)	W/6	:	Rear cooler switch
(B14)	W/6	:	Rear fan switch
(B15)	W/3	:	Heated seat RH
(B16)	W/3	:	Seat belt buckle switch
(B17)	W/2	:	Power seat (Driver side)
(B18)	W/6	:	Rear heater unit
(B19)	SMJ	:	To (M20)
(B20)	B/3	:	Front door switch (Driver side)
(B21)	W/18	:	To (D61)
(B22)	W/4	:	Seat belt pre-tensioner (Driver side)
(B23)	-	:	Body ground
(B24)	BR/1	:	Rear door switch RH
(B26)	W/16	:	CD auto changer
(B27)	B/8	:	Rear wiper amp.
(B28)	BR/1	:	To (D102)
(B29)	W/6	:	To (D101)
(B30)	BR/6	:	Rear combination lamp RH
(B44)	Y/12	:	Air bag diagnosis sensor unit
(B45)	Y/12	:	Air bag diagnosis sensor unit
(B46)	Y/2	:	Side air bag module RH
(B47)	Y/2	:	Side air bag module LH
(B48)	Y/2	:	Satellite sensor RH
(B49)	-	:	Body ground
(B50)	Y/2	:	Satellite sensor LH
(B51)	-	:	Body ground
(B52)	W/2	:	Diode-1 } (A/T models)
(B53)	W/2	:	Diode-2 }

# HARNESS LAYOUT


## Body Harness/RHD Models (Cont'd)

HARDTOP



# HARNES LAYOUT

## Body Harness/RHD Models (Cont'd)




(B1)	W/12	:	To (B105)
(B2)	W/10	:	To (B106)
(B5)	W/3	:	Heated seat LH
(B6)	W/6	:	Wiper deicer switch
(B7)	W/4	:	Heated seat switch LH
(B8)	L/4	:	Heated seat switch RH
(B9)	W/3	:	Ashtray illumination
(B10)	B/1	:	Parking brake switch
(B11)	W/8	:	A/T device
(B12)	W/8	:	A/T mode switch
(B15)	W/3	:	Heated seat RH
(B16)	W/3	:	Seat belt buckle switch
(B19)	SMJ	:	To (M20)
(B20)	B/3	:	Front door switch (Driver side)
(B22)	W/4	:	Seat belt pre-tensioner (Driver side)
(B23)	—	:	Body ground
(B27)	B/8	:	Rear wiper amp.
(B28)	BR/1	:	To (D102)
(B29)	W/6	:	To (D101)
(B30)	BR/6	:	Rear combination lamp RH
(B31)	BR/2	:	Rear speaker RH
(B44)	Y/12	:	Air bag diagnosis sensor unit
(B45)	Y/12	:	Air bag diagnosis sensor unit
(B46)	Y/2	:	Side air bag module RH
(B47)	Y/2	:	Side air bag module LH
(B48)	Y/2	:	Satellite sensor RH
(B49)	—	:	Body ground
(B50)	Y/2	:	Satellite sensor LH
(B51)	—	:	Body ground
(B52)	W/2	:	Diode-1 } (A/T models)
(B53)	W/2	:	Diode-2 }


# HARNESS LAYOUT

## Body No. 2 Harness/LHD Models

WAGON




Body ground




View with center pillar lower garnish RH removed

Body ground



View with center pillar lower garnish LH removed

Body ground



View with luggage room side finisher RH removed


- (B101) W/2 : To (E107)
- (B102) W/12 : To (M97)
- (B103) W/16 : To (M96)
- (B104) W/10 : To (M95)
- (B105) W/12 : To (B1)
- (B106) W/8 : To (B2)
- (B107) W/6 : Rear heater unit
- (B108) BR/1 : Front door switch (Passenger side)
- (B109) W/4 : Seat belt pre-tensioner (Passenger side)
- (B110) W/18 : To (D61)
- (B111) BR/1 : Rear door switch RH
- (B112) - : Body ground
- (B113) W/16 : CD auto changer
- (B114) B/8 : Rear wiper amp.
- (B115) BR/1 : To (D102)

- (E116) W/6 : To (D101)
- (B117) BR/6 : Rear combination lamp RH
- (B131) Y/12 : Air bag diagnosis sensor unit
- (B132) Y/12 : Air bag diagnosis sensor unit
- (B133) Y/2 : Side air bag module RH
- (B134) Y/2 : Side air bag module LH
- (B135) Y/2 : Satellite sensor LH
- (B136) - : Body ground
- (B137) Y/2 : Satellite sensor RH
- (B138) - : Body ground

# HARNESS LAYOUT

## Body No. 2 Harness/LHD Models (Cont'd)



### HARDTOP



# HARNESS LAYOUT

## Body No. 2 Harness/RHD Models

WAGON




- |             |      |   |  |              |
|-------------|------|---|--|--------------|
| <b>B101</b> | W/16 | : | To                                       | <b>M95</b>   |
| <b>B102</b> | W/20 | : | To                                       | <b>M96</b>   |
| <b>B103</b> | W/16 | : | To                                       | <b>M97</b>   |
| <b>B104</b> | W/6  | : | To                                       | <b>M99</b>   |
| <b>B105</b> | W/12 | : | To                                       | <b>B1</b>    |
| <b>B106</b> | W/10 | : | To                                       | <b>B2</b>    |
| <b>B108</b> | BR/1 | : | Front door switch (Passenger side)       |              |
| <b>B109</b> | W/4  | : | Seat belt pre-tensioner (Passenger side) |              |
| <b>B110</b> | W/18 | : | To                                       | <b>D41</b>   |
| <b>B111</b> | BR/1 | : | Rear door switch LH                      |              |
| <b>B112</b> | -    | : | Body ground                              |              |
| <b>B116</b> | W/6  | : | To                                       | <b>D81</b>   |
| <b>B117</b> | BR/6 | : | Rear combination lamp LH                 |              |
| <b>B120</b> | BR/2 | : | G sensor                                 | } (With ABS) |
| <b>B121</b> | GY/2 | : | G sensor                                 |              |
| <b>B122</b> | GY/2 | : | Rear cooler solenoid valve               |              |
| <b>B123</b> | GY/8 | : | To                                       | <b>C1</b>    |
| <b>B124</b> | SB/6 | : | To                                       | <b>C3</b>    |
| <b>B125</b> | SB/8 | : | To                                       | <b>C2</b>    |
| <b>B126</b> | L/4  | : | Power socket relay                       |              |
| <b>B127</b> | W/8  | : | Rear cooler unit                         |              |
| <b>B128</b> | B/6  | : | Rear cooler unit                         |              |
| <b>B129</b> | B/2  | : | Power socket                             |              |
| <b>B130</b> | W/4  | : | To                                       | <b>B3</b>    |

# HARNES LAYOUT


## Body No. 2 Harness/RHD Models (Cont'd)

### HARDTOP



# HARNES LAYOUT

## Chassis Harness





- C1** GY/8 : To **(B35)** (LHD models)  
To **(B123)** (RHD models)
- C2** SB/8 : To **(B37)** (LHD models)  
To **(B125)** (RHD models)
- C3** GY/6 : To **(B36)** (LHD models)  
To **(B124)** (RHD models)
- C4** B/3 : Stabilizer actuator
- C5** BR/2 : Rear wheel sensor LH

- C6** GY/2 : Rear wheel sensor RH
- C7** BR/2 : Diff lock indicator switch
- C8** GY/3 : Sub fuel tank gauge unit
- C9** GY/2 : Sub fuel tank gauge unit
- C10** SB/4 : Rear bumper combination lamp LH
- C11** GY/6 : Fuel tank gauge unit
- C12** SB/4 : Rear bumper combination lamp RH

# HARNESS LAYOUT

## Room Lamp Harness

R1	R2	R3	R4	R5	R6	R7	R8	R9	W/10	W/2	W/1	W/2	W/8	W/2	-	W/2	W/2	To (M24)	
																			Vanity mirror lamp RH
																			Vanity mirror lamp LH
																			To sunroof harness
																			Map lamp
																			Compass and thermo meter
																			Vanity mirror lamp LH
																			Body ground
																			Front interior room lamp
																			Rear interior room lamp (Wagon models)




# HARNESS LAYOUT

## Front Door Harness (Driver side)

### LHD MODELS


- D1** SMJ : To **M22**
- D2** BR/2 : Front door speaker LH
- D3** W/8 : Door mirror (Driver side)
- D4** GY/6 : Front power window regulator (Driver side)
- D5** W/16 : Power window main switch
- D6** BR/3 : Front door key cylinder switch (Driver side)  
(For China and with super lock)
- D7** B/6 : Front door lock actuator assembly LH (With super lock)
- D8** GY/2 : Front door lock switch (Driver side) (Without multi-remote control system)
- D9** GY/4 : Front door lock actuator (Driver side) (With multi-remote control system)
- D10** W/3 : Power window main switch (Wagon models)



CEL245A

### RHD MODELS

- D1** SMJ : To **M22**
- D2** BR/2 : Front door speaker RH
- D3** W/8 : Door mirror (Driver side)
- D4** GY/6 : Front power window regulator (Driver side)
- D5** W/16 : Power window main switch
- D6** BR/3 : Front door key cylinder switch (Driver side) (With super lock)
- D7** B/6 : Front door lock actuator assembly RI (With super lock)
- D8** GY/2 : Front door lock switch (Driver side) (Without multi-remote control system)
- D9** GY/4 : Front door lock actuator (Driver side) (With multi-remote control system)
- D10** W/3 : Power window main switch (Wagon models)




CEL138M


# HARNESS LAYOUT

## Front Door Harness (Passenger side)

### LHD MODELS




### RHD MODELS



# HARNES LAYOUT

## Back Door Harness and Rear Window Defogger Harness

- BACK DOOR HARNESS LH**
- D81 : To B29 (LHD models)
  - W/6 : To B116 (RHD models)
  - D82 : License plate lamp
  - D83 : Body ground
  - D84 : To D133
  - BR/1 : Back door switch LH
  - D85 : Back door lock actuator
  - D86 : GY/4
  - D87 : W/4 : To B55
  - D88 : BR/3 : Back door key cylinder switch (For China)
- BACK DOOR HARNESS RH**
- D101 : To B116 (LHD models)
  - W/6 : To B29 (RHD models)
  - D102 : BR/1 : To B115 (LHD models)
  - D103 : To B28 (RHD models)
  - BR/1 : To D121
  - W/2 : High-mounted stop lamp
  - D104 : W/4 : Rear wiper motor
  - D105 : - : Body ground
  - D106 : W/3 : Back door switch RH
- REAR DEFOGGER HARNESS RH**
- D121 : BR/1 : To D103
  - D122 : B/1 : Rear window defogger RH (+)
  - D123 : B/1 : Rear window defogger RH (-)
  - D124 : - : Body ground
- REAR DEFOGGER HARNESS LH**
- D131 : B/1 : Rear window defogger LH (-)
  - D132 : - : Body ground
  - D133 : BR/1 : To D84
  - D134 : B/1 : Rear window defogger LH (+)



## WIRING DIAGRAM CODES (CELL CODES)

### Wiring Diagram Codes (Cell Codes)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (Page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C,A	HA	Auto Air Conditioner
A/C,M	HA	Manual Air Conditioner
A/CCUT	EC	Air Conditioner Control
A/T	AT	A/T
ABS	BR	Anti-lock Brake System
ACC/SW	EC	Accelerator Switch (FC)
ACL/SW	EC	Accelerator Position Switch
APS	EC	Accelerator Position Sensor
ASCD	EL	Automatic Speed Control Device
AT/C	EC	A/T Control
BACK/L	EL	Back-up Lamp
BCDD	EC	BCDD System
BOOST	EC	Turbo Charger Boost Sensor
BRK/SW	EC	Brake Switch Signal
CHARGE	EL	Charging System
CHIME	EL	Warning Chime
CHOKE	EC	Automatic Choke
CKPS	EC	Crankshaft Position Sensor (OBD)
COOL/B	HA	Cool Box
COOL/F	EC	Cooling Fan Control
CORNER	EL	Cornering Lamp
DEF	EL	Rear Window Defogger
DIFF/L	PD	Differential Lock Control System
DTRL	EL	Headlamp — With Daytime Light System
ECMRLY	EC	ECM Relay
ECTS	EC	Engine Coolant Temperature Sensor
EGVC/V	EC	EGR Volume Control Valve
EXH	EC	Exhaust Gas Control Valve Control Solenoid Valve
F/FOG	EL	Front Fog Lamp
F/PUMP	EC	Fuel Pump
FCUT	EC	Fuel Cut System
FICD	EC	IACV-FICD Solenoid Valve
FIPO	EC	ISC-FI POT
FPCM	EC	Fuel Pump Control Module
GLOW	EC	Quick Glow System
HEATER	HA	Heater System
HEATUP	EC	Heat up Switch

Code	Section	Wiring Diagram Name
HLC	EL	Headlamp Wiper and Washer
HORN	EL	Horn
IGN	EC	Ignition Control System
ILL	EL	Illumination
INJPMP	EC	Electronic Control Fuel Injection Pump
INT/V	EC	Intake Air Control Valve Control Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	EC	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp., Oil and Fuel Gauges
MIL/DL	EC	Mil and Data Link Connectors
MULTI	EL	Multi-remote Control System
NATS	EL	Nissan Anti-Theft System
P/ANT	EL	Power Antenna
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
R/COOL	HA	Rear Cooler System
R/FOG	EL	Rear Fog Lamp
R/HEAT	HA	Rear Heater System
REMOTE	EL	Audio (Remote Control Switch)
ROOM/L	EL	Interior Room Lamp
S/LOCK	EL	Power Door Lock — Super Lock
S/SIG	EC	Start Signal
S/TANK	FE	Sub Fuel Tank Control System
SHIFT	AT	A/T Shift Lock System
SRS	RS	Supplemental Restraint System
STAB	RA	Stabilizer Release Device
START	EL	Starting System
STOP/L	EL	Stop Lamp
SWL/V	EC	Swirl Control Valve Control Solenoid Valve
TAIL/L	EL	Parking, License and Tail Lamps
TURN	EL	Turn Signal and Hazard Warning Lamps
VSS	EC	Vehicle Speed Sensor
WARN	EL	Warning Lamps

## WIRING DIAGRAM CODES (CELL CODES)

### Wiring Diagram Codes (Cell Codes) (Cont'd)

Code	Section	Wiring Diagram Name
VNT	EC	Variable Nozzle Turbocharger Control Solenoid Valve
WINCH	SE	Electrical Winch
WINDOW	EL	Power Window
WIPER	EL	Front Wiper and Washer