

SECTION **EC**

MODIFICATION NOTICE:

- TB48DE engine models have been applied to Europe.

CONTENTS

<input type="checkbox"/>	TB48DE A/T	<input type="checkbox"/>
ENGINE AND EMISSION CONTROL OVERALL	7	
Circuit Diagram.....	7	

<input type="checkbox"/>	TB48DE A/T (WITH EURO-OBD)	<input type="checkbox"/>
--------------------------	-----------------------------------	--------------------------

INDEX FOR DTC	9
Alphabetical Index.....	9
DTC No. Index.....	12
PRECAUTIONS	15
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER".....	15
On Board Diagnostic (OBD) System of Engine and A/T.....	15
Precaution.....	16
Wiring Diagrams and Trouble Diagnosis.....	19
PREPARATION	20
Special Service Tools.....	20
Commercial Service Tools.....	20
ENGINE CONTROL	22
System Diagram.....	22
Vacuum Hose Drawing.....	23
System Chart.....	24
Multiport Fuel Injection (MFI) System.....	24
Electronic Ignition (EI) System.....	27
Air Conditioning Cut Control.....	28
Fuel Cut Control (at No Load and High Engine Speed).....	28
CAN Communication.....	29
BASIC SERVICE	30
Idle Speed and Ignition Timing Check.....	30
Accelerator Pedal Released Position Learning.....	31
Throttle Valve Closed Position Learning.....	31

Idle Air Volume Learning.....	31
Fuel Pressure Check.....	34
Injector Removal and Installation.....	35
ON BOARD DIAGNOSTIC (OBD)	37
Introduction.....	37
Two Trip Detection Logic.....	37
Emission-related Diagnostic Information.....	38
NATS (Nissan Anti-theft System).....	50
Malfunction Indicator (MI).....	51
OBD System Operation Chart.....	54
TROUBLE DIAGNOSIS	59
Trouble Diagnosis Introduction.....	59
DTC Inspection Priority Chart.....	64
Fail-safe Chart.....	65
Basic Inspection.....	66
Symptom Matrix Chart.....	71
Engine Control Component Parts Location.....	74
Circuit Diagram.....	78
ECM Harness Connector Terminal Layout.....	80
ECM Terminals and Reference Value.....	80
CONSULT-II Function.....	89
Generic Scan Tool (GST) Function.....	101
CONSULT-II Reference Value in Data Monitor Mode.....	103
Major Sensor Reference Graph in Data Monitor Mode.....	106
TROUBLE DIAGNOSIS - SPECIFICATION VALUE	108
Description.....	108
Testing condition.....	108
Inspection Procedure.....	108
Diagnostic Procedure.....	109
TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT	112

ENGINE CONTROL SYSTEM

Description	112	Component Description	157
Diagnostic Procedure	112	CONSULT-II Reference Value in Data Monitor	
POWER SUPPLY CIRCUIT FOR ECM	113	Mode	157
Wiring Diagram	113	On Board Diagnosis Logic.....	157
Diagnostic Procedure	116	DTC Confirmation Procedure	158
Component Inspection.....	120	Wiring Diagram	159
DTC U1000 CAN COMMUNICATION LINE	121	Diagnostic Procedure	160
Description	121	Component Inspection.....	162
On Board Diagnosis Logic.....	121	DTC P0132, P0152 HO2S1	163
DTC Confirmation Procedure	121	Component Description	163
Wiring Diagram	122	CONSULT-II Reference Value in Data Monitor	
Diagnostic Procedure	123	Mode.....	163
DTC P0031, P0032, P0051, P0052 HO2S1		On Board Diagnosis Logic.....	163
HEATER	124	DTC Confirmation Procedure	164
Description	124	Wiring Diagram	165
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure	168
Mode	124	Component Inspection.....	170
On Board Diagnosis Logic.....	124	DTC P0133, P0153 HO2S1	172
DTC Confirmation Procedure	124	Component Description	172
Wiring Diagram	126	CONSULT-II Reference Value in Data Monitor	
Diagnostic Procedure	129	Mode.....	172
Component Inspection.....	131	On Board Diagnosis Logic.....	172
DTC P0037, P0038, P0057, P0058 HO2S2		DTC Confirmation Procedure	173
HEATER	132	Overall Function Check	174
Description	132	Wiring Diagram	175
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure	178
Mode	132	Component Inspection.....	183
On Board Diagnosis Logic.....	132	DTC P0134, P0154 HO2S1	185
DTC Confirmation Procedure	132	Component Description	185
Wiring Diagram	134	CONSULT-II Reference Value in Data Monitor	
Diagnostic Procedure	137	Mode.....	185
Component Inspection.....	139	On Board Diagnosis Logic.....	185
DTC P0102, P0103 MAF SENSOR	140	DTC Confirmation Procedure	186
Component Description	140	Overall Function Check	187
CONSULT-II Reference Value in Data Monitor		Wiring Diagram	188
Mode	140	Diagnostic Procedure	191
On Board Diagnosis Logic.....	140	Component Inspection.....	193
DTC Confirmation Procedure	140	DTC P0138, P0158 HO2S2	195
Wiring Diagram	142	Component Description	195
Diagnostic Procedure	143	CONSULT-II Reference Value in Data Monitor	
Component Inspection.....	146	Mode.....	195
DTC P0112, P0113 IAT SENSOR	147	On Board Diagnosis Logic.....	195
Component Description	147	DTC Confirmation Procedure	196
On Board Diagnosis Logic.....	147	Wiring Diagram	197
DTC Confirmation Procedure	147	Diagnostic Procedure	200
Wiring Diagram	149	Component Inspection.....	203
Diagnostic Procedure	150	DTC P0139, P0159 HO2S2	205
Component Inspection.....	151	Component Description	205
DTC P0117, P0118 ECT SENSOR	152	CONSULT-II Reference Value in Data Monitor	
Component Description	152	Mode.....	205
On Board Diagnosis Logic.....	152	On Board Diagnosis Logic.....	205
DTC Confirmation Procedure	153	DTC Confirmation Procedure	206
Wiring Diagram	154	Overall Function Check	207
Diagnostic Procedure	155	Wiring Diagram	209
Component Inspection.....	156	Diagnostic Procedure	212
DTC P0122, P0123 TP SENSOR	157	Component Inspection.....	215

ENGINE CONTROL SYSTEM

DTC P0171, P0174 FUEL INJECTION SYSTEM

FUNCTION	218
On Board Diagnosis Logic.....	218
DTC Confirmation Procedure	218
Wiring Diagram.....	220
Diagnostic Procedure	222

DTC P0172, P0175 FUEL INJECTION SYSTEM

FUNCTION	227
On Board Diagnosis Logic.....	227
DTC Confirmation Procedure	227
Wiring Diagram.....	229
Diagnostic Procedure	231

DTC P0222, P0223 TP SENSOR

Component Description	235
CONSULT-II Reference Value in Data Monitor Mode.....	235
On Board Diagnosis Logic.....	235
DTC Confirmation Procedure	235
Wiring Diagram.....	237
Diagnostic Procedure	238
Component Inspection.....	240

DTC P0300 - P0306 MULTIPLE CYLINDER

MISFIRE, NO. 1 - 6 CYLINDER MISFIRE	241
On Board Diagnosis Logic.....	241
DTC Confirmation Procedure	241
Diagnostic Procedure	242

DTC P0327, P0328, P0332, P0333 KS

Component Description	247
On Board Diagnosis Logic.....	247
DTC Confirmation Procedure	247
Wiring Diagram.....	248
Diagnostic Procedure	249
Component Inspection.....	250

DTC P0335 CKP SENSOR (OBD)

Component Description	251
CONSULT-II Reference Value in Data Monitor Mode.....	251
On Board Diagnosis Logic.....	251
DTC Confirmation Procedure	251
Wiring Diagram.....	253
Diagnostic Procedure	254
Component Inspection.....	256

DTC P0340 CAMSHAFT POSITION

Component Description	257
ECM Terminals and Reference Value.....	257
On Board Diagnosis Logic.....	258
DTC Confirmation Procedure	258
Wiring Diagram.....	260
Diagnostic Procedure	261
Component Inspection.....	262

DTC P0420, P0430 THREE WAY CATALYST

FUNCTION	264
On Board Diagnosis Logic.....	264
DTC Confirmation Procedure	264
Overall Function Check	265
Diagnostic Procedure	266

DTC P0444, P0445 EVAP CANISTER PURGE

VOLUME CONTROL SOLENOID VALVE

Description	269
CONSULT-II Reference Value in Data Monitor Mode.....	269
On Board Diagnosis Logic.....	269
DTC Confirmation Procedure	270
Wiring Diagram.....	271
Diagnostic Procedure	273
Component Inspection.....	275

DTC P0500 VSS

Description	276
On Board Diagnosis Logic.....	276
DTC Confirmation Procedure	276
Overall Function Check	277
Diagnostic Procedure	277

DTC P0550 PSP SENSOR

Component Description	278
CONSULT-II Reference Value in Data Monitor Mode.....	278
On Board Diagnosis Logic.....	278
DTC Confirmation Procedure	278
Wiring Diagram.....	279
Diagnostic Procedure	280
Component Inspection.....	282

DTC P0605 ECM

Component Description	283
On Board Diagnosis Logic.....	283
DTC Confirmation Procedure	283
Diagnostic Procedure	285

DTC P0650 MI

Component Description	286
On Board Diagnosis Logic.....	286
DTC Confirmation Procedure	286
Wiring Diagram.....	287
Diagnostic Procedure	288

DTC P1065 ECM POWER SUPPLY

Component Description	290
On Board Diagnosis Logic.....	290
DTC Confirmation Procedure	290
Wiring Diagram.....	291
Diagnostic Procedure	292

DTC P1111 IVT CONTROL SOLENOID VALVE

Description	294
Operation	294
CONSULT-II Reference Value in Data Monitor Mode.....	295
On Board Diagnosis Logic.....	295
DTC Confirmation Procedure	295
Wiring Diagram.....	296
Diagnostic Procedure	297
Component Inspection.....	298

DTC P1121 ELECTRIC THROTTLE CONTROL

ACTUATOR	299
Component Description	299
On Board Diagnosis Logic.....	299


ENGINE CONTROL SYSTEM

DTC Confirmation Procedure	299	Component Description	348
Diagnostic Procedure	300	CONSULT-II Reference Value in Data Monitor Mode	348
DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION	301	On Board Diagnosis Logic.....	348
Description	301	DTC Confirmation Procedure	349
On Board Diagnosis Logic.....	301	Overall Function Check	350
DTC Confirmation Procedure	301	Wiring Diagram	352
Wiring Diagram	302	Diagnostic Procedure	355
Diagnostic Procedure	303	Component Inspection.....	358
Component Inspection.....	308	DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)	361
DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY	309	System Description.....	361
Component Description	309	Operation	361
CONSULT-II Reference Value in Data Monitor Mode	309	CONSULT-II Reference Value In Data Monitor Mode	361
On Board Diagnosis Logic.....	309	ECM Terminals and Reference Value.....	362
DTC Confirmation Procedure	309	On Board Diagnosis Logic.....	362
Wiring Diagram	311	Overall Function Check	363
Diagnostic Procedure	312	Wiring Diagram	364
Component Inspection.....	314	Diagnostic Procedure	365
DTC P1128 THROTTLE CONTROL MOTOR	315	Main 12 Causes of Overheating.....	370
Component Description	315	Component Inspection.....	371
On Board Diagnosis Logic.....	315	DTC P1225 TP SENSOR	372
DTC Confirmation Procedure	315	Component Description	372
Wiring Diagram	316	On Board Diagnosis Logic.....	372
Diagnostic Procedure	317	DTC Confirmation Procedure	372
Component Inspection.....	319	Diagnostic Procedure	373
DTC P1143, P1163 HO2S1	320	DTC P1226 TP SENSOR	374
Component Description	320	Component Description	374
CONSULT-II Reference Value in Data Monitor Mode	320	On Board Diagnosis Logic.....	374
On Board Diagnosis Logic.....	320	DTC Confirmation Procedure	374
DTC Confirmation Procedure	321	Diagnostic Procedure	375
Overall Function Check	322	DTC P1229 SENSOR POWER	376
Diagnostic Procedure	322	On Board Diagnosis Logic.....	376
Component Inspection.....	325	DTC Confirmation Procedure	376
DTC P1144, P1164 HO2S1	327	Wiring Diagram	377
Component Description	327	Diagnostic Procedure	378
CONSULT-II Reference Value in Data Monitor Mode	327	DTC P1336 CKP SENSOR (OBD)	381
On Board Diagnosis Logic.....	327	Component Description	381
DTC Confirmation Procedure	328	ECM Terminals and Reference Value.....	381
Overall Function Check	329	On Board Diagnosis Logic.....	382
Diagnostic Procedure	329	DTC Confirmation Procedure	382
Component Inspection.....	332	Wiring Diagram	383
DTC P1146, P1166 HO2S2	335	Diagnostic Procedure	384
Component Description	335	DTC P1706 PNP SWITCH	388
CONSULT-II Reference Value in Data Monitor Mode	335	Component Description	388
On Board Diagnosis Logic.....	335	CONSULT-II Reference Value in Data Monitor Mode	388
DTC Confirmation Procedure	336	On Board Diagnosis Logic.....	388
Overall Function Check	337	DTC Confirmation Procedure	388
Wiring Diagram	339	Overall Function Check	389
Diagnostic Procedure	342	Wiring Diagram	390
Component Inspection.....	345	Diagnostic Procedure	392
DTC P1147, P1167 HO2S2	348	DTC P1805 BRAKE SWITCH	395
		Description	395

ENGINE CONTROL SYSTEM

CONSULT-II Reference Value in Data Monitor	447
Mode	448
On Board Diagnosis Logic.....	449
DTC Confirmation Procedure	450
Wiring Diagram.....	451
Diagnostic Procedure	452
Component Inspection.....	453
DTC P2122, P2123 APP SENSOR	454
Component Description	455
CONSULT-II Reference Value in Data Monitor	456
Mode.....	457
On Board Diagnosis Logic.....	458
DTC Confirmation Procedure	459
Wiring Diagram.....	460
Diagnostic Procedure	461
Component Inspection.....	462
DTC P2127, P2128 APP SENSOR	463
Component Description	464
CONSULT-II Reference Value in Data Monitor	465
Mode.....	466
On Board Diagnosis Logic.....	467
DTC Confirmation Procedure	468
Wiring Diagram.....	469
Diagnostic Procedure	470
Component Inspection.....	471
DTC P2135 TP SENSOR	472
Component Description	473
CONSULT-II Reference Value in Data Monitor	474
Mode.....	475
On Board Diagnosis Logic.....	476
DTC Confirmation Procedure	477
Wiring Diagram.....	478
Diagnostic Procedure	479
Component Inspection.....	480
DTC P2138 APP SENSOR	481
Component Description	482
CONSULT-II Reference Value in Data Monitor	483
Mode.....	484
On Board Diagnosis Logic.....	485
DTC Confirmation Procedure	486
Wiring Diagram.....	487
Diagnostic Procedure	488
Component Inspection.....	489
IGNITION SIGNAL	490
Component Description	491
Wiring Diagram.....	492
Diagnostic Procedure	493
Component Inspection.....	494
SNOW MODE SWITCH	495
Component Description	496
ECM Terminals and Reference Value.....	497
Wiring Diagram.....	498
Diagnostic Procedure	499
VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)	500
Description	501
ECM Terminals and Reference Value.....	502
Wiring Diagram.....	503
Diagnostic Procedure	504
START SIGNAL	505
CONSULT-II Reference Value in Data Monitor	506
Mode.....	507
ECM Terminals and Reference Value.....	508
Wiring Diagram.....	509
Diagnostic Procedure	510
INJECTOR CIRCUIT	511
Component Description	512
CONSULT-II Reference Value in Data Monitor	513
Mode.....	514
Wiring Diagram.....	515
Diagnostic Procedure	516
Component Inspection.....	517
FUEL PUMP	518
System Description.....	519
Component Description	520
CONSULT-II Reference Value in Data Monitor	521
Mode.....	522
ECM Terminals and Reference Value.....	523
Wiring Diagram.....	524
Diagnostic Procedure	525
Component Inspection.....	526
REFRIGERANT PRESSURE SENSOR	527
Component Description	528
Wiring Diagram.....	529
Diagnostic Procedure	530
ELECTRICAL LOAD SIGNAL	531
Description.....	532
CONSULT-II Reference Value in Data Monitor	533
Mode.....	534
Wiring Diagram.....	535
Diagnostic Procedure	536
DATA LINK CONNECTORS	537
Wiring Diagram.....	538
EVAPORATIVE EMISSION	539
Description	540
Component Inspection.....	541
POSITIVE CRANKCASE VENTILATION	542
Description.....	543
Component Inspection.....	544
SERVICE DATA AND SPECIFICATIONS	545
Fuel Pressure Regulator.....	546
Idle Speed and Ignition Timing.....	547
Mass Air Flow Sensor	548
Engine Coolant Temperature Sensor.....	549
Heated Oxygen Sensor 1	550
Heated Oxygen Sensor 2	551
Fuel Pump	552
EVAP Canister Purge Volume Control Solenoid Valve.....	553
Injector	554
Ignition Coil with Power Transistor.....	555
Condenser	556

Circuit Diagram




Next page

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

TB48DE A/T

Circuit Diagram (Cont'd)



Alphabetical Index

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to GI section.

NOTE:

If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to EC-121, "DTC U1000 CAN COMMUNICATION LINE".

x: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC*1		Trip	MI lighting up	Reference page
	CONSULT-II GST*2	ECM*3			
APP SEN 1/CIRC	P2122	2122	1	x	EC-401
APP SEN 1/CIRC	P2123	2123	1	x	EC-401
APP SEN 2/CIRC	P2127	2127	1	x	EC-408
APP SEN 2/CIRC	P2128	2128	1	x	EC-408
APP SENSOR	P2138	2138	1	x	EC-421
BRAKE SW/CIRCUIT	P1805	1805	2	—	EC-395
CAN COMM CIRCUIT	U1000	1000*5	1	x	EC-121
CKP SEN/CIRCUIT	P0335	0335	2	x	EC-251
CKP SENSOR (COG)	P1336	1336	2	x	EC-381
CMP SEN/CIRC-B1	P0340	0340	2	x	EC-257
CTP LEARNING	P1225	1225	2	—	EC-372
CTP LEARNING	P1226	1226	2	—	EC-374
CYL 1 MISFIRE	P0301	0301	2	x	EC-241
CYL 2 MISFIRE	P0302	0302	2	x	EC-241
CYL 3 MISFIRE	P0303	0303	2	x	EC-241
CYL 4 MISFIRE	P0304	0304	2	x	EC-241
CYL 5 MISFIRE	P0305	0305	2	x	EC-241
CYL 6 MISFIRE	P0306	0306	2	x	EC-241
ECM	P0605	0605	1 or 2	x or —	EC-283
ECM BACK UP/CIRC	P1065	1065	2	x	EC-290
ECT SEN/CIRCUIT	P0117	0117	1	x	EC-152
ECT SEN/CIRCUIT	P0118	0118	1	x	EC-152
ENG OVER TEMP	P1217	1217	1	x	EC-361
ETC ACTR	P1121	1121	1 or 2	x	EC-299
ETC FUNCTION/CIRC	P1122	1122	1	x	EC-301
ETC MOT	P1128	1128	1	x	EC-315
ETC MOT PWR	P1124	1124	1	x	EC-309
ETC MOT PWR	P1126	1126	1	x	EC-309
FUEL SYS-LEAN-B1	P0171	0171	2	x	EC-218
FUEL SYS-LEAN-B2	P0174	0174	2	x	EC-218
FUEL SYS-RICH-B1	P0172	0172	2	x	EC-227
FUEL SYS-RICH-B2	P0175	0175	2	x	EC-227
HO2S1 (B1)	P0132	0132	2	x	EC-163
HO2S1 (B1)	P0133	0133	2	x	EC-172
HO2S1 (B1)	P0134	0134	2	x	EC-172

Alphabetical Index (Cont'd)

Items (CONSULT-II screen terms)	DTC*1		Trip	MI lighting up	Reference page
	CONSULT-II GST*2	ECM*3			
HO2S1 (B1)	P1143	1143	2	x	EC-320
HO2S1 (B1)	P1144	1144	2	x	EC-327
HO2S1 (B2)	P0152	0152	2	x	EC-163
HO2S1 (B2)	P0153	0153	2	x	EC-172
HO2S1 (B2)	P0154	0154	2	x	EC-172
HO2S1 (B2)	P1163	1163	2	x	EC-320
HO2S1 (B2)	P1164	1164	2	x	EC-327
HO2S1 HTR (B1)	P0031	0031	2	x	EC-124
HO2S1 HTR (B1)	P0032	0032	2	x	EC-124
HO2S1 HTR (B2)	P0051	0051	2	x	EC-124
HO2S1 HTR (B2)	P0052	0052	2	x	EC-124
HO2S2 (B1)	P0138	0138	2	x	EC-195
HO2S2 (B1)	P0139	0139	2	x	EC-205
HO2S2 (B1)	P1146	1146	2	x	EC-335
HO2S2 (B1)	P1147	1147	2	x	EC-348
HO2S2 (B2)	P0158	0158	2	x	EC-195
HO2S2 (B2)	P0159	0159	2	x	EC-205
HO2S2 (B2)	P1166	1166	2	x	EC-335
HO2S2 (B2)	P1167	1167	2	x	EC-348
HO2S2 HTR (B1)	P0037	0037	2	x	EC-132
HO2S2 HTR (B1)	P0038	0038	2	x	EC-132
HO2S2 HTR (B2)	P0057	0057	2	x	EC-132
HO2S2 HTR (B2)	P0058	0058	2	x	EC-132
IAT SEN/CIRCUIT	P0112	0112	2	x	EC-147
IAT SEN/CIRCUIT	P0113	0113	2	x	EC-147
INT/V TIM V/CIR-B1	P1111	1111	2	x	EC-294
KNOCK SEN/CIRC-B1	P0327	0327	2	—	EC-247
KNOCK SEN/CIRC-B1	P0328	0328	2	—	EC-247
KNOCK SEN/CIRC-B2	P0332	0332	2	—	EC-247
KNOCK SEN/CIRC-B2	P0333	0333	2	—	EC-247
L/PRESS SOL/CIRC	P0745	0745	2	x	AT section
MAF SEN/CIRCUIT	P0102	0102	1	x	EC-140
MAF SEN/CIRCUIT	P0103	0103	1	x	EC-140
MIL/CIRC	P0650	0650	2	—	EC-286
MULTI CYL MISFIRE	P0300	0300	2	x	EC-241
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	2	—	EC-50
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing*4	—	Flashing*4	EC-51
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—	—	—

Alphabetical Index (Cont'd)

Items (CONSULT-II screen terms)	DTC*1		Trip	MI lighting up	Reference page
	CONSULT-II GST*2	ECM*3			
P-N POS SW/CIRCUIT	P1706	1706	2	x	EC-388
PURG VOLUME CONT/V	P0444	0444	2	x	EC-269
PURG VOLUME CONT/V	P0445	0445	2	x	EC-269
PW ST P SEN/CIRC	P0550	0550	2	—	EC-401
SENSOR POWER/CIRC	P1229	1229	1	x	EC-376
TCC SOLENOID/CIRC	P0740	0740	2	x	AT section
TP SEN 1/CIRC	P0222	0222	1	x	EC-235
TP SEN 1/CIRC	P0223	0223	1	x	EC-235
TP SEN 2/CIRC	P0122	0122	1	x	EC-157
TP SEN 2/CIRC	P0123	0123	1	x	EC-157
TP SENSOR	P2135	2135	1	x	EC-415
TW CATALYST SYS-B1	P0420	0420	2	x	EC-264
TW CATALYST SYS-B2	P0430	0430	2	x	EC-264
VEH SPEED SEN/CIRC	P0500	0500	2	x	EC-276

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: The trouble shooting for these DTCs needs CONSULT-II.

NOTE:

Regarding Y61 models with TB48DE engine, "B1" indicates bank 1 (cylinders number 1, 2 and 3), "B2" indicates bank 2 (cylinders number 4, 5 and 6).

DTC No. Index

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the “Type approval number” on the identification plate. Refer to GI section.

NOTE:

If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to EC-121, “DTC U1000 CAN COMMUNICATION LINE”.

x: Applicable —: Not applicable

DTC*1		Items (CONSULT-II screen terms)	Trip	MI lighting up	Reference page
CONSULT-II GST*2	ECM*3				
No DTC	Flashing*4	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	Flashing*4	EC-51
U1000	1000*5	CAN COMM CIRCUIT	1	x	EC-121
P0000	0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—
P0031	0031	HO2S1 HTR (B1)	2	x	EC-124
P0032	0032	HO2S1 HTR (B1)	2	x	EC-124
P0037	0037	HO2S2 HTR (B1)	2	x	EC-132
P0038	0038	HO2S2 HTR (B1)	2	x	EC-132
P0051	0051	HO2S1 HTR (B2)	2	x	EC-124
P0052	0052	HO2S1 HTR (B2)	2	x	EC-124
P0057	0057	HO2S2 HTR (B2)	2	x	EC-132
P0058	0058	HO2S2 HTR (B2)	2	x	EC-132
P0102	0102	MAF SEN/CIRCUIT	1	x	EC-140
P0103	0103	MAF SEN/CIRCUIT	1	x	EC-140
P0112	0112	IAT SEN/CIRCUIT	2	x	EC-147
P0113	0113	IAT SEN/CIRCUIT	2	x	EC-147
P0117	0117	ECT SEN/CIRCUIT	1	x	EC-152
P0118	0118	ECT SEN/CIRCUIT	1	x	EC-152
P0122	0122	TP SEN 2/CIRC	1	x	EC-157
P0123	0123	TP SEN 2/CIRC	1	x	EC-157
P0132	0132	HO2S1 (B1)	2	x	EC-163
P0133	0133	HO2S1 (B1)	2	x	EC-172
P0134	0134	HO2S1 (B1)	2	x	EC-172
P0138	0138	HO2S2 (B1)	2	x	EC-195
P0139	0139	HO2S2 (B1)	2	x	EC-205
P0152	0152	HO2S1 (B2)	2	x	EC-163
P0153	0153	HO2S1 (B2)	2	x	EC-172
P0154	0154	HO2S1 (B2)	2	x	EC-172
P0158	0158	HO2S2 (B2)	2	x	EC-195
P0159	0159	HO2S2 (B2)	2	x	EC-205
P0171	0171	FUEL SYS-LEAN-B1	2	x	EC-218
P0172	0172	FUEL SYS-RICH-B1	2	x	EC-227
P0174	0174	FUEL SYS-LEAN-B2	2	x	EC-218

DTC No. Index (Cont'd)

DTC*1		Items (CONSULT-II screen terms)	Trip	MI lighting up	Reference page
CONSULT-II GST*2	ECM*3				
P0175	0175	FUEL SYS-RICH-B2	2	x	EC-227
P0222	0222	TP SEN 1/CIRC	1	x	EC-235
P0223	0223	TP SEN 1/CIRC	1	x	EC-235
P0300	0300	MULTI CYL MISFIRE	2	x	EC-241
P0301	0301	CYL 1 MISFIRE	2	x	EC-241
P0302	0302	CYL 2 MISFIRE	2	x	EC-241
P0303	0303	CYL 3 MISFIRE	2	x	EC-241
P0304	0304	CYL 4 MISFIRE	2	x	EC-241
P0305	0305	CYL 5 MISFIRE	2	x	EC-241
P0306	0306	CYL 6 MISFIRE	2	x	EC-241
P0327	0327	KNOCK SEN/CIRC-B1	2	—	EC-247
P0328	0328	KNOCK SEN/CIRC-B1	2	—	EC-247
P0332	0332	KNOCK SEN/CIRC-B2	2	—	EC-247
P0333	0333	KNOCK SEN/CIRC-B2	2	—	EC-247
P0335	0335	CKP SEN/CIRCUIT	2	x	EC-251
P0340	0340	CMP SEN/CIRC-B1	2	x	EC-257
P0420	0420	TW CATALYST SYS-B1	2	x	EC-264
P0430	0430	TW CATALYST SYS-B2	2	x	EC-264
P0444	0444	PURG VOLUME CONT/V	2	x	EC-269
P0445	0445	PURG VOLUME CONT/V	2	x	EC-269
P0500	0500	VEH SPEED SEN/CIRC	2	x	EC-276
P0550	0550	PW ST P SEN/CIRC	2	—	EC-278
P0605	0605	ECM	1 or 2	x or —	EC-283
P0650	0650	MIL/CIRC	2	—	EC-286
P0740	0740	TCC SOLENOID/CIRC	2	x	AT section
P0745	0745	L/PRESS SOL/CIRC	2	x	AT section
P1065	1065	ECM BACK UP/CIRC	2	x	EC-290
P1111	1111	INT/V TIM V/CIR-B1	2	x	EC-294
P1121	1121	ETC ACTR	1 or 2	x	EC-299
P1122	1122	ETC FUNCTION/CIRC	1	x	EC-301
P1124	1124	ETC MOT PWR	1	x	EC-309
P1126	1126	ETC MOT PWR	1	x	EC-309
P1128	1128	ETC MOT	1	x	EC-315
P1143	1143	HO2S1 (B1)	2	x	EC-320
P1144	1144	HO2S1 (B1)	2	x	EC-327
P1146	1146	HO2S2 (B1)	2	x	EC-335
P1147	1147	HO2S2 (B1)	2	x	EC-348
P1163	1163	HO2S1 (B2)	2	x	EC-320
P1164	1164	HO2S1 (B2)	2	x	EC-327
P1166	1166	HO2S2 (B2)	2	x	EC-335
P1167	1167	HO2S2 (B2)	2	x	EC-348

DTC No. Index (Cont'd)

DTC*1		Items (CONSULT-II screen terms)	Trip	MI lighting up	Reference page
CONSULT-II GST*2	ECM*3				
P1217	1217	ENG OVER TEMP	1	x	EC-361
P1225	1225	CTP LEARNING	2	—	EC-372
P1226	1226	CTP LEARNING	2	—	EC-374
P1229	1229	SENSOR POWER/CIRC	1	x	EC-376
P1336	1336	CKP SENSOR (COG)	2	x	EC-381
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	2	—	EC-50
P1706	1706	P-N POS SW/CIRCUIT	2	x	EC-388
P1805	1805	BRAKE SW/CIRCUIT	2	—	EC-395
P2122	2122	APP SEN 1/CIRC	1	x	EC-401
P2123	2123	APP SEN 1/CIRC	1	x	EC-401
P2127	2127	APP SEN 2/CIRC	1	x	EC-408
P2128	2128	APP SEN 2/CIRC	1	x	EC-408
P2135	2135	TP SENSOR	1	x	EC-415
P2138	2138	APP SENSOR	1	x	EC-421

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: The trouble shooting for these DTCs need CONSULT-II.

NOTE:

Regarding Y61 models with TB48DE engine, "B1" indicates bank 1 (cylinders number 1, 2 and 3), "B2" indicates bank 2 (cylinders number 4, 5 and 6).

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL Y61 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:





- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow harness connector.

On Board Diagnostic (OBD) System of Engine and A/T

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery ground cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to EL section.
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to the malfunction of the fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.




Precaution

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect battery ground cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.
- Do not disassemble ECM.
- If battery cable is disconnected, the memory will return to the initial ECM values.


The ECM will now start to self-control at its initial values. Engine operation can vary slightly when the cable is disconnected. However, this is not an indication of a malfunction. Do not replace parts because of a slight variation.

- When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown at right.


Precaution (Cont'd)



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.




- Before replacing ECM, perform "ECM Terminals and Reference Value" inspection and make sure ECM functions properly. Refer to EC-80, "ECM Terminals and Reference Value".
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor, crankshaft position sensor (OBD).




- After performing each TROUBLE DIAGNOSIS, perform "DTC Confirmation Procedure" or "Overall Function Check".
The DTC should not be displayed in the "DTC Confirmation Procedure" if the repair is completed. The "Overall Function Check" should be a good result if the repair is completed.


Precaution (Cont'd)




- When measuring ECM signals with a circuit tester, connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.





- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - Keep the antenna as far as possible from the electronic control units.
 - Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - Be sure to ground the radio to vehicle body.

Precaution (Cont'd)

- Regarding Y61 models with TB48DE engine, “B1” indicates bank 1 (cylinders number 1, 2, 3), “B2” indicates bank 2 (cylinders number 4, 5, 6).



Wiring Diagrams and Trouble Diagnosis



When you read wiring diagrams, refer to the following:

- “How to Read Wiring Diagrams” in GI section
- “POWER SUPPLY ROUTING” for power distribution circuit in EL section




When you perform trouble diagnosis, refer to the following:

- “HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES” in GI section
- “How to Perform Efficient Diagnosis for an Electrical Incident” in GI section


Special Service Tools

Tool number Tool name	Description
KV10117100 Heated oxygen sensor wrench	 <p>Loosening or tightening heated oxygen sensors with 22 mm (0.87 in) hexagon nut</p> <p>NT379</p>
KV10114400 Heated oxygen sensor wrench	 <p>Loosening or tightening heated oxygen sensors a: 22 mm (0.87 in)</p> <p>NT636</p>


Commercial Service Tools

Tool name	Description
Fuel filler cap adapter	 <p>Checking fuel tank vacuum relief valve opening pressure</p> <p>NT653</p>
Socket wrench	 <p>Removing and installing engine coolant temperature sensor</p> <p>NT705</p>
Oxygen sensor thread cleaner ie: (J-43897-18) (J-43897-12)	 <p>Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below. a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor</p> <p>AEM488</p>


Commercial Service Tools (Cont'd)

Tool name	Description
Anti-seize lubricant ie: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A- 907)	 <p data-bbox="973 246 1460 313">Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p> <p data-bbox="391 492 454 526">NT779</p>

System Diagram



Vacuum Hose Drawing



NOTE:
Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

Refer to EC-22, "System Diagram" for Vacuum Control System

System Chart

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> ● Camshaft position sensor ● Crankshaft position sensor (OBD) ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Throttle position sensor ● Accelerator pedal position sensor ● Park/neutral position (PNP) switch ● Intake air temperature sensor ● Power steering pressure sensor ● Ignition switch ● Stop lamp switch ● Battery voltage ● Knock sensor ● Refrigerant pressure sensor ● Heated oxygen sensor 2*1 ● TCM (Transmission control module)*2 ● Air conditioner switch*2 ● Vehicle speed sensor*2 ● Electrical load signal*2 	Fuel injection & mixture ratio control	Fuel injectors
	Electronic ignition system	Power transistor
	Fuel pump control	Fuel pump relay
	On board diagnostic system	MI (On the instrument panel)
	Intake valve timing control	Intake valve timing control solenoid valve
	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
	Air conditioning cut control	Air conditioner relay
	Power valve control	VIAS control solenoid valve
	Cooling fan control	Cooling fan relay

*1: This sensor is not used to control the engine system under normal conditions.

*2: The signals are sent to the ECM through CAN communication line.

Multiport Fuel Injection (MFI) System

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor	Engine speed and piston position	Fuel injection & mixture ratio control	Fuel injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Park/neutral position (PNP) switch	Gear position		
Knock sensor	Engine knocking condition		
Battery	Battery voltage		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2*1	Density of oxygen in exhaust gas		
Vehicle speed sensor*2	Vehicle speed		
Air conditioner switch*2	Air conditioner operation		
Ignition switch	Start signal		

*1: Under normal conditions, this sensor is not for engine control operation.

*2: This signal is sent to the ECM through CAN communication line.

Multipoint Fuel Injection (MFI) System (Cont'd)

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from "N" to "D"
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about heated oxygen sensor 1, refer to EC-163. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

Open loop control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from "N" to "D"
- When starting the engine

Multiport Fuel Injection (MFI) System (Cont'd)

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential multiport fuel injection system

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous multiport fuel injection system

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF


Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Electronic Ignition (EI) System

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor	Engine speed and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage		
Vehicle speed sensor*1	Vehicle speed		
Ignition switch	Start signal		

*1: This signal is sent to the ECM through CAN communication line.



SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec

A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioning Cut Control

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Air conditioner switch*1	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Camshaft position sensor	Engine speed		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
Vehicle speed sensor*1	Vehicle speed		
Ignition switch	Start signal		

*1: These signals are sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

Fuel Cut Control (at No Load and High Engine Speed)

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Park/neutral position (PNP) switch	Neutral position	Fuel cut control	Fuel injectors
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Engine coolant temperature sensor	Engine coolant temperature		
Camshaft position sensor	Engine speed		
Vehicle speed sensor*1	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

If the engine speed is above 3,950 rpm with no load (for example, in neutral and engine speed over 3,950 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:


This function is different from deceleration control listed under "Multiport Fuel Injection (MFI) System", EC-24.

CAN Communication

SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


SYSTEM DIAGRAM



Input/output signal chart

T: Transmit R: Receive

Signals	Combination meter	TCM	ECM
Engine speed signal	R	R	T
Engine coolant temperature signal	R	R	T
Accelerator pedal position signal		R	T
Closed throttle position signal		R	T
Wide open throttle position signal		R	T
A/T fluid temperature warning lamp signal	R	T	R
Current gear position signal	R	T	R
Shift change signal		T	R
Air conditioner switch signal	T		R
Headlamp switch signal	T		R
Rear window defogger switch signal	T		R
Brake switch signal	T	R	
Vehicle speed signal	T	R	R
A/T self diagnosis signal		T	R
Manual mode signal	T	R	



Idle Speed and Ignition Timing Check


IDLE SPEED

With CONSULT-II

Check idle speed in "DATA MONITOR" mode with CONSULT-II.

With GST

Check idle speed with GST.




IGNITION TIMING

Any of following two methods may be used.



Method A

1. Slide the harness protector of ignition coil No. 1 to clear the wires.
2. Attach timing light to the wires as shown.
3. Check ignition timing.



Method B

1. Remove No. 1 ignition coil.
2. Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.



3. Check ignition timing.

Accelerator Pedal Released Position Learning

DESCRIPTION

“Accelerator Pedal Released Position Learning” is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON” and wait at least 2 seconds.
3. Turn ignition switch “OFF” wait at least 10 seconds.
4. Turn ignition switch “ON” and wait at least 2 seconds.
5. Turn ignition switch “OFF” wait at least 10 seconds.

Throttle Valve Closed Position Learning

DESCRIPTION

“Throttle Valve Closed Position Learning” is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON”.
3. Turn ignition switch “OFF” wait at least 10 seconds.
Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

Idle Air Volume Learning

DESCRIPTION

“Idle Air Volume Learning” is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

PREPARATION

Before performing “Idle Air Volume Learning”, make sure that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.




- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 - 95°C (158 - 203°F)
- PNP switch: ON
- Electric load switch: OFF
(Air conditioner, headlamp, rear window defogger)
On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.
- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up
For models with CONSULT-II, drive vehicle until “FLUID TEMP SE” in “DATA MONITOR” mode of “A/T” system indicates less than 0.9V.
For A/T models without CONSULT-II, drive vehicle for 10 minutes.

Idle Air Volume Learning (Cont'd)

OPERATION PROCEDURE

④ With CONSULT-II

1. Perform EC-31, "Accelerator Pedal Released Position Learning".
2. Perform EC-31, "Throttle Valve Closed Position Learning".
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PREPARATION" (previously mentioned) are in good order.
5. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.



6. Touch "START" and wait 20 seconds.

7. Make sure that "CMPLT" is displayed on CONSULT-II screen. If "CMPLT" is not displayed, "Idle Air Volume Learning" will not be carried out successfully. In this case, find the cause of the incident by referring to the "Diagnostic Procedure" below.
8. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.


ITEM	SPECIFICATION
Idle speed	675±50 rpm (in "P" or "N" position)
Ignition timing	10±5° BTDC (in "P" or "N" position)

Idle Air Volume Learning (Cont'd)

⊗ Without CONSULT-II

NOTE:

- It is better to count the time accurately with a clock.
 - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
1. Perform EC-31, "Accelerator Pedal Released Position Learning".
 2. Perform EC-31, "Throttle Valve Closed Position Learning".
 3. Start engine and warm it up to normal operating temperature.
 4. Check that all items listed under the topic "PREPARATION" (previously mentioned) are in good order.
 5. Turn ignition switch "OFF" and wait at least 10 seconds.
 6. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
 7. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
 8. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MI stops blinking and turned ON.
 9. Fully release the accelerator pedal within 3 seconds after the MI turned ON.
 10. Start engine and let it idle.
 11. Wait 20 seconds.



12. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.


ITEM	SPECIFICATION
Idle speed	675±50 rpm (in "P" or "N" position)
Ignition timing	10±5° BTDC (in "P" or "N" position)

13. If idle speed and ignition timing are not within the specification, "Idle Air Volume Learning" will not be carried out successfully. In this case, find the cause of the incident by referring to the "Diagnostic Procedure" below.

DIAGNOSTIC PROCEDURE

If idle air volume learning cannot be performed successfully, proceed as follows:

1. Check that throttle valve is fully closed.
2. Check PCV valve operation.
3. Check that downstream of throttle valve is free from air leakage.
4. When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the incident.
It is useful to perform EC-108, "TROUBLE DIAGNOSIS — SPECIFICATION VALUE".
5. If any of the following conditions occur after the engine has started, eliminate the cause of the incident and perform "Idle air volume learning" all over again:
 - Engine stalls.
 - Erroneous idle.



Fuel Pressure Check

FUEL PRESSURE RELEASE



Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

☑ With CONSULT-II

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".

⊗ Without CONSULT-II

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.



FUEL PRESSURE CHECK

- When reconnecting fuel line, always use new clamps.
- Make sure that clamp screw does not contact adjacent parts.


- Use a torque driver to tighten clamps.
 - Use Pressure Gauge to check fuel pressure.
1. Release fuel pressure to zero, refer to above.
 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
 3. Install pressure gauge between fuel filter and fuel tube.
 4. Start engine and check for fuel leakage.
 5. Read the indication of fuel pressure gauge.

At idling:

Approximately 245 kPa (2.45 bar, 2.5 kg/cm², 36 psi)

A few seconds after ignition switch is turned OFF to ON:

Approximately 294 kPa (2.94 bar, 3.0 kg/cm², 43 psi)







6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
7. Plug intake manifold with a rubber cap.
8. Connect variable vacuum source to fuel pressure regulator.

- Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.


Injector Removal and Installation

- Release fuel pressure to zero.
- Disconnect harness connector clip.
- Disconnect injector harness connectors.
- Disconnect fuel hoses from fuel tube assembly.
- Remove fuel tube assemblies in reverse numerical sequence of that shown in the figure at left.



- Expand and remove clips securing fuel injectors.
- Extract fuel injectors straight from fuel tubes.
 - Do not extract injector by pinching connector.
 - Be careful not to damage injector nozzles during removal.
 - Do not bump or drop fuel injectors.
- Install injector to fuel tube assembly.
 - Lubricate O-rings with a smear of silicone oil.
 - Be careful not to damage O-rings with service tools, finger nails or clips. Do not expand or twist O-rings.
 - Discard old clips, replace with new ones.
- Position clips in grooves on fuel injectors.
 - Make sure that protrusions of fuel injectors are aligned with cutouts of clips after installation.
- Align protrusions of fuel tubes with those of fuel injectors. Insert fuel injectors straight into fuel tubes.
- After properly inserting fuel injectors, check to make sure that fuel tube protrusions are engaged with those of fuel injectors, and that flanges of fuel tube are engaged with clips.

Injector Removal and Installation (Cont'd)



12. Tighten fuel tube assembly mounting nuts in numerical sequence (indicated in the figure at left) and in two stages.

: Tightening torque N·m (kg·m, ft·lb)

1st stage:

9 - 20 (0.9 - 2.1, 7 - 15)

2nd stage:

21 - 26 (2.1 - 2.7, 16 - 19)

13. Insert fuel hoses into fuel tubes so that ends of fuel hoses butt up against fuel tubes; fasten with clamps, avoiding bulges.

CAUTION:

After properly connecting fuel tube assembly to injector and fuel hose, check connection for fuel leakage.

Introduction

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	ISO Standard
Diagnostic Trouble Code (DTC)	Mode 3 of ISO 15031-5
Freeze Frame data	Mode 2 of ISO 15031-5
System Readiness Test (SRT) code	Mode 1 of ISO 15031-5
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of ISO 15031-5
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of ISO 15031-5
Calibration ID	Mode 9 of ISO 15031-5

The above information can be checked using procedures listed in the table below.

x: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	x	x	x	x	x	—
GST	x	x*1	x	—	x	x
ECM	x	x*2	—	—	—	—

*1: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

*2: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator (MI) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to EC-65.)

Two Trip Detection Logic

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MI will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MI lights up. The MI lights up at the same time when the DTC is stored. <2nd trip> The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MI, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

x: Applicable —: Not applicable

Items	MI				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	x	—	—	—	—	—	x	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	—	—	x	—	—	x	—	—
One trip detection diagnoses (Refer to EC-9.)	—	x	—	—	x	—	x	—
Except above	—	—	—	x	—	x	x	—

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information

EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Value/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
CAN COMM CIRCUIT	U1000	1000*3	—	—	—	EC-121
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—	—	—	—
HO2S1 HTR (B1)	P0031	0031	x	x	x*4	EC-124
HO2S1 HTR (B1)	P0032	0032	x	x	x*4	EC-124
HO2S2 HTR (B1)	P0037	0037	x	x	x*4	EC-132
HO2S2 HTR (B1)	P0038	0038	x	x	x*4	EC-132
HO2S1 HTR (B2)	P0051	0051	x	x	x*4	EC-124
HO2S1 HTR (B2)	P0052	0052	x	x	x*4	EC-124
HO2S2 HTR (B2)	P0057	0057	x	x	x*4	EC-132
HO2S2 HTR (B2)	P0058	0058	x	x	x*4	EC-132
MAF SEN/CIRCUIT	P0102	0102	—	—	—	EC-140
MAF SEN/CIRCUIT	P0103	0103	—	—	—	EC-140
IAT SEN/CIRCUIT	P0112	0112	—	—	x	EC-147
IAT SEN/CIRCUIT	P0113	0113	—	—	x	EC-147
ECT SEN/CIRCUIT	P0117	0117	—	—	—	EC-152
ECT SEN/CIRCUIT	P0118	0118	—	—	—	EC-152
TP SEN 2/CIRC	P0122	0122	—	—	—	EC-157
TP SEN 2/CIRC	P0123	0123	—	—	—	EC-157
HO2S1 (B1)	P0132	0132	x	x	x*4	EC-163
HO2S1 (B1)	P0133	0133	x	x	x*4	EC-172
HO2S1 (B1)	P0134	0134	x	x	x*4	EC-172
HO2S2 (B1)	P0138	0138	x	x	x*4	EC-195
HO2S2 (B1)	P0139	0139	x	x	x*4	EC-205
HO2S1 (B2)	P0152	0152	x	x	x*4	EC-163
HO2S1 (B2)	P0153	0153	x	x	x*4	EC-172
HO2S1 (B2)	P0154	0154	x	x	x*4	EC-172
HO2S2 (B2)	P0158	0158	x	x	x*4	EC-195
HO2S2 (B2)	P0159	0159	x	x	x*4	EC-205
FUEL SYS-LEAN-B1	P0171	0171	—	—	x	EC-218
FUEL SYS-RICH-B1	P0172	0172	—	—	x	EC-227
FUEL SYS-LEAN-B2	P0174	0174	—	—	x	EC-218
FUEL SYS-RICH-B2	P0175	0175	—	—	x	EC-227
TP SEN 1/CIRC	P0222	0222	—	—	—	EC-235
TP SEN 1/CIRC	P0223	0223	—	—	—	EC-235
MULTI CYL MISFIRE	P0300	0300	—	—	x	EC-241
CYL 1 MISFIRE	P0301	0301	—	—	x	EC-241
CYL 2 MISFIRE	P0302	0302	—	—	x	EC-241

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information (Cont'd)

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Value/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
CYL 3 MISFIRE	P0303	0303	—	—	x	EC-241
CYL 4 MISFIRE	P0304	0304	—	—	x	EC-241
CYL 5 MISFIRE	P0305	0305	—	—	x	EC-241
CYL 6 MISFIRE	P0306	0306	—	—	x	EC-241
KNOCK SEN/CIRC-B1	P0327	0327	—	—	x	EC-247
KNOCK SEN/CIRC-B1	P0328	0328	—	—	x	EC-247
KNOCK SEN/CIRC-B2	P0332	0332	—	—	x	EC-247
KNOCK SEN/CIRC-B2	P0333	0333	—	—	x	EC-247
CKP SEN/CIRCUIT	P0335	0335	—	—	x	EC-251
CMP SEN/CIRC-B1	P0340	0340	—	—	x	EC-257
TW CATALYST SYS-B1	P0420	0420	x	x	x*4	EC-264
TW CATALYST SYS-B2	P0430	0430	x	x	x*4	EC-264
PURG VOLUME CONT/V	P0444	0444	—	—	x	EC-269
PURG VOLUME CONT/V	P0445	0445	—	—	x	EC-269
VEH SPEED SEN/CIRC	P0500	0500	—	—	x	EC-276
PW ST P SEN/CIRC	P0550	0550	—	—	x	EC-278
ECM	P0605	0605	—	—	x	EC-283
MIL/CIRC	P0650	0650	—	—	x	EC-286
TCC SOLENOID/CIRC	P0740	0740	—	—	x	AT section
L/PRESS SOL/CIRC	P0745	0745	—	—	x	AT section
ECM BACK UP/CIRC	P1065	1065	—	—	x	EC-290
INT/V TIM V/CIR-B1	P1111	1111	—	—	x	EC-294
ETC ACTR	P1121	1121	—	—	x	EC-299
ETC FUNCTION/CIRC	P1122	1122	—	—	—	EC-301
ETC MOT PWR	P1124	1124	—	—	—	EC-309
ETC MOT PWR	P1126	1126	—	—	—	EC-309
ETC MOT	P1128	1128	—	—	—	EC-315
HO2S1 (B1)	P1143	1143	x	x	x*4	EC-320
HO2S1 (B1)	P1144	1144	x	x	x*4	EC-327
HO2S2 (B1)	P1146	1146	x	x	x*4	EC-335
HO2S2 (B1)	P1147	1147	x	x	x*4	EC-348
HO2S1 (B2)	P1163	1163	x	x	x*4	EC-320
HO2S1 (B2)	P1164	1164	x	x	x*4	EC-327
HO2S2 (B2)	P1166	1166	x	x	x*4	EC-335
HO2S2 (B2)	P1167	1167	x	x	x*4	EC-348
ENG OVER TEMP	P1217	1217	—	—	—	EC-361
CTP LEARNING	P1225	1225	—	—	x	EC-372
CTP LEARNING	P1226	1226	—	—	x	EC-374
SENSOR POWER/CIRC	P1229	1229	—	—	—	EC-376
CKP SENSOR (COG)	P1336	1336	—	—	x	EC-381

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information (Cont'd)

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Value/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	—	—	x	EC-50
P-N POS SW/CIRCUIT	P1706	1706	—	—	x	EC-388
BRAKE SW/CIRCUIT	P1805	1805	—	—	x	EC-395
APP SEN 1/CIRC	P2122	2122	—	—	—	EC-401
APP SEN 1/CIRC	P2123	2123	—	—	—	EC-401
APP SEN 2/CIRC	P2127	2127	—	—	—	EC-408
APP SEN 2/CIRC	P2128	2128	—	—	—	EC-408
TP SENSOR	P2135	2135	—	—	—	EC-415
APP SENSOR	P2138	2138	—	—	—	EC-421

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: The trouble shooting for these DTCs need CONSULT-II.

*4: These are not displayed with GST.

NOTE:

Regarding Y61 models with TB48DE engine, “B1” indicates bank 1 (cylinders number 1, 2 and 3), “B2” indicates bank 2 (cylinders number 4, 5 and 6).

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MI will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MI lights up. In other words, the DTC is stored in the ECM memory and the MI lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MI during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in EC-49, “HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION”.

For malfunctions in which 1st trip DTCs are displayed, refer to EC-38, “EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS. These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II. 1st trip DTC is specified in Mode 7 of ISO 15031-5. 1st trip DTC detection occurs without lighting up the MI and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in “Work Flow” procedure Step II, refer to EC-60, “WORK FLOW”. Then perform “DTC Confirmation Procedure” or “Overall Function Check” to try to duplicate the malfunction. If the malfunction is duplicated, the item requires repair.

How to read DTC and 1st trip DTC

DTC and 1st trip DTC can be read by the following methods.

 **With CONSULT-II**

 **With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P0705, P0750, etc.

These DTCs are prescribed by ISO 15031-5.

(CONSULT-II also displays the malfunctioning component or system.)

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information (Cont'd)



No Tools

The number of blinks of the MI in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0102, 0340 etc.

These DTCs are controlled by NISSAN.

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, GST or the Diagnostic Test Mode II do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	SELF DIAG RESULTS		1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS			DTC RESULTS	
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see EC-92, "Freeze Frame Data and 1st Trip Freeze Frame Data".

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information (Cont'd)

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in EC-52, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Mode 1 of ISO 15031-5.

As part of an enhanced emissions test for Inspection & Maintenance (I/M), certain states require the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this Service Manual to set the SRT to "CMPLT".

In most cases the ECM will automatically complete its self-diagnosis cycle during normal usage, and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern; the SRT will indicate "INCMP" for these items.

NOTE:

- **The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.**
If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items the vehicle is returned to the customer untested.
- **If MI is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.**

SRT item

The table below shows required self-diagnostic items to set the SRT to "CMPLT".

SRT item (CONSULT-II indication)	Performance Priority*1	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.
CATALYST	2	Three way catalyst function	P0420, P0430
HO2S	1	Heated oxygen sensor 1	P0132, P0152
		Heated oxygen sensor 1	P0133, P0153
		Heated oxygen sensor 1	P0134, P0154
		Heated oxygen sensor 1	P1143, P1163
		Heated oxygen sensor 1	P1144, P1164
		Heated oxygen sensor 2	P0138, P0158
		Heated oxygen sensor 2	P0139, P0159
		Heated oxygen sensor 2	P1146, P1166
HO2S HTR	1	Heated oxygen sensor 1 heater	P0031, P0032, P0051, P0052
		Heated oxygen sensor 2 heater	P0037, P0038, P0057, P0058

*1: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure), one by one based on the priority for models with CONSULT-II.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information (Cont'd)

SRT set timing

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

Self-diagnosis result		Example					
		Diagnosis	Ignition cycle				
			← ON →	OFF	← ON →	OFF	← ON →
All OK	Case 1	P0400	OK (1)	— (1)	OK (2)	— (2)	
		P0402	OK (1)	— (1)	— (1)	OK (2)	
		P1402	OK (1)	OK (2)	— (2)	— (2)	
		SRT of EGR	"CMPLT"	"CMPLT"	"CMPLT"	"CMPLT"	
	Case 2	P0400	OK (1)	— (1)	— (1)	— (1)	
		P0402	— (0)	— (0)	OK (1)	— (1)	
		P1402	OK (1)	OK (2)	— (2)	— (2)	
		SRT of EGR	"INCMP"	"INCMP"	"CMPLT"	"CMPLT"	
NG exists	Case 3	P0400	OK	OK	—	—	
		P0402	—	—	—	—	
		P1402	NG	—	NG	NG (Consecutive NG)	
		(1st trip) DTC	1st trip DTC	—	1st trip DTC	DTC (= MI "ON")	
		SRT of EGR	"INCMP"	"INCMP"	"INCMP"	"CMPLT"	

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is NG.

—: Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a single cycle (Ignition OFF-ON-OFF), the SRT will indicate "CMPLT". → Case 1 above

When all SRT related self-diagnoses showed OK results through several different cycles, the SRT will indicate "CMPLT" at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate "CMPLT". → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as "INCMP" is one (1) for each self-diagnosis (Case 1 & 2) or two (2) for one of self-diagnoses (Case 3). However, in preparation for the state emissions inspection, it is unnecessary for each self-diagnosis to be executed twice (Case 3) for the following reasons:

- The SRT will indicate "CMPLT" at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires "CMPLT" of the SRT only with OK self-diagnosis results.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to "CMPLT" of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate "INCMP".

NOTE:

SRT can be set as "CMPLT" together with the DTC(s). Therefore, DTC check must always be carried out prior to the state emission inspection even though the SRT indicates "CMPLT".


SRT service procedure

If a vehicle has failed the state emissions inspection due to one or more SRT items indicating "INCMP", review the flowchart diagnostic sequence on the next page.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information (Cont'd)



SEF573XB

*1EC-40

*2EC-45

*3EC-45

Emission-related Diagnostic Information (Cont'd)

How to display SRT code

④ WITH CONSULT-II

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

A sample of CONSULT-II display for SRT code is shown at right. "INCMP" means the self-diagnosis is incomplete and SRT is not set. "CMPLT" means the self-diagnosis is complete and SRT is set.

④ WITH GST

Selecting Mode 1 with GST (Generic Scan Tool)

SRT STATUS	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	CMPLT

PBIB0666E

How to set SRT code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

④ WITH CONSULT-II

Perform corresponding DTC Confirmation Procedure one by one based on "Performance Priority" in the table on EC-42, "SRT Item".


⊗ WITHOUT CONSULT-II

The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.

Emission-related Diagnostic Information
(Cont'd)

Driving pattern

**Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws.
Refer to next page for more information and explanation of chart.**



**Emission-related Diagnostic Information
(Cont'd)**

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time, required for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 121 and ground is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 121 and ground is lower than 1.4V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Checking the vehicle speed with GST is advised.

Suggested Transmission Gear Position

Set the selector lever in the "D" position with the overdrive switch turned ON.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Emission-related Diagnostic Information (Cont'd)

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of ISO 15031-5.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

x: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function (Bank1)	01H	01H	Max.	x
		02H	81H	Min.	x
	Three way catalyst function (Bank2)	03H	02H	Max.	x
		04H	82H	Min.	x
HO2S	Heated oxygen sensor 1 (Bank 1)	09H	04H	Max.	x
		0AH	84H	Min.	x
		0BH	04H	Max.	x
		0CH	04H	Max.	x
		0DH	04H	Max.	x
	Heated oxygen sensor 1 (Bank 2)	11H	05H	Max.	x
		12H	85H	Min.	x
		13H	05H	Max.	x
		14H	05H	Max.	x
		15H	05H	Max.	x
	Heated oxygen sensor 2 (Bank 1)	19H	86H	Min.	x
		1AH	86H	Min.	x
		1BH	06H	Max.	x
		1CH	06H	Max.	x
	Heated oxygen sensor 2 (Bank 2)	21H	87H	Min.	x
		22H	87H	Min.	x
23H		07H	Max.	x	
24H		07H	Max.	x	
HO2S HTR	Heated oxygen sensor 1 heater (Bank 1)	29H	08H	Max.	x
		2AH	88H	Min.	x
	Heated oxygen sensor 1 heater (Bank 2)	2BH	09H	Max.	x
		2CH	89H	Min.	x
	Heated oxygen sensor 2 heater (Bank 1)	2DH	0AH	Max.	x
		2EH	8AH	Min.	x
	Heated oxygen sensor 2 heater (Bank 2)	2FH	0BH	Max.	x
		30H	8BH	Min.	x

Emission-related Diagnostic Information (Cont'd)

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

Ⓟ How to Erase DTC (With CONSULT-II)


The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).

NOTE:

If the DTC is not for A/T related items (see EC-9, "INDEX FOR DTC"), skip steps 2 through 4.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Turn CONSULT-II "ON" and touch "A/T".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". [The DTC in the TCM (Transmission control module) will be erased.] Then touch "BACK" twice.
5. Touch "ENGINE".
6. Touch "SELF-DIAG RESULTS".
7. Touch "ERASE". (The DTC in the ECM will be erased.)



**Emission-related Diagnostic Information
(Cont'd)**

Ⓢ How to erase DTC (With GST)

The emission related diagnostic information in the ECM can be erased by selecting Mode 4 with GST.

NOTE:

If the DTC is not for A/T related items (see EC-9, "INDEX FOR DTC"), skip step 2.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with GST (Generic Scan Tool).

Ⓝ How to erase DTC (No Tools)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch OFF" once.
2. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
3. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal. Refer to EC-52, "HOW TO SWITCH DIAGNOSTIC TEST MODE".

● **If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.**

● **The following data are cleared when the ECM memory is erased.**

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data
4. 1st trip freeze frame data
5. System readiness test (SRT) codes
6. Test values
7. Others


Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF515Y

NATS (Nissan Anti-theft System)

- **If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to EL section, "NATS (NISSAN ANTI-THEFT SYSTEM)".**
- **Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DIAG RESULTS" mode with CONSULT-II.**
- **When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card. Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.**



Malfunction Indicator (MI)

DESCRIPTION

The MI is located on the instrument panel.

1. The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MI does not light up, refer to EL section "WARNING LAMPS", or see EC-286.
2. When the engine is started, the MI should go off. If the MI remains on, the on board diagnostic system has detected an engine system malfunction.

ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following four functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in "ON" position  Engine stopped 	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.). If the MI does not come on, check MI circuit.
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MI will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MI in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (Possible three way catalyst damage)" ● "One trip detection diagnoses"
Mode II	Ignition switch in "ON" position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.
	Engine running 	HEATED OXYGEN SENSOR 1 MONITOR	This function allows the fuel mixture condition (lean or rich), monitored by heated oxygen sensor 1, to be read.

MI flashing without DTC

If the ECM is in Diagnostic Test Mode II, MI may flash when engine is running. In this case, check ECM diagnostic test mode, EC-52 "HOW TO SWITCH DIAGNOSTIC TEST MODE".

How to switch the diagnostic test (function) modes, and details of the above functions are described later, EC-52 "HOW TO SWITCH DIAGNOSTIC TEST MODE".

The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values
- Others

Malfunction Indicator (MI) (Cont'd)


HOW TO SWITCH DIAGNOSTIC TEST MODE

NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned "OFF".

How to set diagnostic test mode II (Self-diagnostic results)

1. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
2. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MI starts blinking.
4. Fully release the accelerator pedal.
ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).




How to set diagnostic test mode II (Heated oxygen sensor 1 monitor)

1. Set the ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to EC-52, "How to set diagnostic test mode II (Self-diagnostic results)".
2. Start Engine.
ECM has entered to Diagnostic Test Mode II (Heated oxygen sensor 1 monitor).
ECM will start heated oxygen sensor 1 monitoring from the bank 1 sensor.

How to switch monitored sensor from bank 1 to bank 2 or vice versa

1. Fully depress the accelerator pedal quickly and then release it immediately.
2. Make sure that monitoring sensor has changed by MI blinking as follows.



How to erase diagnostic test mode II (Self-diagnostic results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to EC-52, "How to set diagnostic test mode II (Self-diagnostic results)".
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.
The emission-related diagnostic information has been erased from the backup memory in the ECM.
3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

Malfunction Indicator (MI) (Cont'd)

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to EL section or see EC-286.


DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MI	Condition
ON	When the malfunction is detected.
OFF	No malfunction.

• These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MI as shown below. The DTC and 1st trip DTC are displayed at the same time. If the MI does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MI illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-II or GST. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The “zero” is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC “0000” refers to no malfunction. (See EC-9.)

How to erase diagnostic test mode II (Self-diagnostic results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to EC-52, “HOW TO SWITCH DIAGNOSTIC TEST MODE”.

- If the battery is disconnected, the DTC will be lost from the backup memory after approx 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

Malfunction Indicator (MI) (Cont'd)

DIAGNOSTIC TEST MODE II — HEATED OXYGEN SENSOR 1 MONITOR

In this mode, the MI displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor 1.

MI	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the heated oxygen sensor 1 function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MI comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

OBD System Operation Chart

RELATIONSHIP BETWEEN MI, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MI will come on. For details, refer to EC-37, "Two Trip Detection Logic".
- The MI will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

SUMMARY CHART

Items	Fuel Injection System	Misfire	Other
MI (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)

For details about patterns "B" and "C" under "Fuel Injection System" and "Misfire", see EC-56.


For details about patterns "A" and "B" under "Other", see EC-58.

*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MI, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MISFIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"



*1:When the same malfunction is detected in two consecutive trips, MI will light up.

*2:MI will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3:When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4:The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

*5:When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6:The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.

*7:When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

*8:1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MI will go off when the B counter reaches 3. (*2 in "OBD SYSTEM OPERATION CHART")

<Driving pattern C>

Driving pattern C means the vehicle operation as follows:

1. The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), "T" should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), "T" should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)


- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

TB48DE A/T (WITH EURO-OBD)

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MI, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MI will light up.

*2: MI will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.


*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving pattern A>





- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

<Driving pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MI will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").



Trouble Diagnosis Introduction

INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, fouled spark plugs, or other malfunctions with the engine.

It is much more difficult to diagnose an incident that occurs intermittently rather than continuously. Most intermittent incidents are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the incidents. A roadtest with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on EC-60.


Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on EC-63 should be used.

Start your diagnosis by looking for "conventional" malfunctions first. This will help troubleshoot driveability malfunctions on an electronically controlled engine vehicle.

Trouble Diagnosis Introduction (Cont'd)

WORK FLOW

Flow chart



MBIB0159E

*1:If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".
*2:If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform EC-112, "TROUBLE DIAGNO-

SIS FOR INTERMITTENT INCIDENT".
*3:If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to EC-113, "POWER SUPPLY CIRCUIT FOR ECM".
*4:If malfunctioning part cannot be

detected, perform EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".
*5:EC-46, "Driving Pattern"
*6:EC-108, "TROUBLE DIAGNOSIS — SPECIFICATION VALUE"

Trouble Diagnosis Introduction (Cont'd)

Description for work flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-62.
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT". Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-71.) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT". If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT". In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-66.) If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the "TROUBLE DIAGNOSIS — SPECIFICATION VALUE". (Refer to EC-108) (If malfunction is detected, proceed to "PERAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-71.)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-80, 103. The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "Circuit Inspection" in GI section. Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a method different from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" and AT section.)

Trouble Diagnosis Introduction (Cont'd)
DIAGNOSTIC WORKSHEET**KEY POINTS**

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

Description

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MI to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

NOTE:

If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to EC-121, "DTC U1000 CAN COMMUNICATION LINE".

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> ● U1000 CAN communication line ● P0102 P0103 Mass air flow sensor ● P0112 P0113 Intake air temperature sensor ● P0117 P0118 Engine coolant temperature sensor ● P0122 P0123 P0222 P0223 P1225 P1226 P1229 P2135 Throttle position sensor ● P0327 P0328 P0332 P0333 Knock sensor ● P0335 P1336 Crankshaft position sensor (OBD) ● P0340 Camshaft position sensor ● P0500 Vehicle speed sensor ● P0605 ECM ● P0705 Park/Neutral position (PNP) switch ● P1610-P1615 NATS ● P1706 Park/Neutral position (PNP) switch ● P2122 P2123 P2127 P2128 P2138 Accelerator pedal position sensor
2	<ul style="list-style-type: none"> ● P0031 P0032 P0051 P0052 Heated oxygen sensor 1 heater ● P0037 P0038 P0057 P0058 Heated oxygen sensor 2 heater ● P0132 P0133 P0134 P0152 P0153 P0154 P1143 P1144 P1163 P1164 Heated oxygen sensor 1 ● P0138 P0139 P0158 P0159 P1146 P1147 P1166 P1167 Heated oxygen sensor 2 ● P0550 Power steering pressure sensor ● P0740 P0745 A/T solenoid valves ● P1065 ECM power supply ● P1111 Intake valve timing control solenoid valve ● P1122 Electric throttle control function ● P1124 P1126 P1128 Electric throttle control actuator ● P1805 Brake switch
3	<ul style="list-style-type: none"> ● P0171 P0172 P0174 P0175 Fuel injection system function ● P0300 - P0306 Misfire ● P0420 P0430 Three way catalyst function ● P0444 P0445 EVAP canister purge volume control solenoid valve ● P1121 Electric throttle control actuator ● P1217 Engine over temperature (OVERHEAT)

Fail-safe Chart




●When the DTC listed below is detected, the ECM enters fail-safe mode and the MI lights up.

DTC No.	Detected items	Engine operating condition in fail-safe mode								
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.								
P0117 P0118	Engine coolant temperature sensor circuit	<p>Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Engine coolant temperature decided (CONSULT-II display)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Just as ignition switch is turned ON or Start</td> <td style="text-align: center;">40°C (104°F)</td> </tr> <tr> <td style="text-align: center;">More than approx. 4 minutes after ignition ON or Start</td> <td style="text-align: center;">80°C (176°F)</td> </tr> <tr> <td style="text-align: center;">Except as shown above</td> <td style="text-align: center;">40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table> <p>When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.</p>	Condition	Engine coolant temperature decided (CONSULT-II display)	Just as ignition switch is turned ON or Start	40°C (104°F)	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
Condition	Engine coolant temperature decided (CONSULT-II display)									
Just as ignition switch is turned ON or Start	40°C (104°F)									
More than approx. 4 minutes after ignition ON or Start	80°C (176°F)									
Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)									
P0122 P0123 P0222 P0223 P2135	Throttle position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								
P1121	Electric throttle control actuator (ECM detect the throttle valve is stuck open.)	<p>While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.</p>								
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring								
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P2122 P2123 P2127 P2128 P2138	Accelerator pedal position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								

Basic Inspection

Preparation

- Make sure that the following parts are in good order.
- (1) Battery
- (2) Ignition system
- (3) Engine oil and coolant levels
- (4) Fuses
- (5) ECM harness connector
- (6) Vacuum hoses
- (7) Air intake system
(Oil filler cap, oil level gauge, etc.)
- (8) Fuel pressure
- (9) Engine compression
- (10) Throttle valve
- On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
- When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- Turn off headlamps, heater blower, rear window defogger.
- Keep front wheels pointed straight ahead.



Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

A

BEFORE STARTING

1. Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches, and cuts
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket

B

1. Start engine and warm it up until engine coolant temperature indicator points the middle of gauge.
2. Run engine at about 2,000 rpm for about 2 minutes under no-load.
3. Make sure that no DTC is displayed with CONSULT-II.

NG


Repair or replace components as necessary according to corresponding "Diagnostic Procedure".

OK

A




A

Basic Inspection (Cont'd)





DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm




Reference code: SEF058Y





Basic Inspection (Cont'd)



Basic Inspection (Cont'd)



Basic Inspection (Cont'd)



Symptom Matrix Chart

SYSTEM — BASIC ENGINE CONTROL SYSTEM

SYSTEM — Basic engine control system		SYMPTOM														Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERCOOLS	OVERCHARGING		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	1P	1X	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		3	3			3				2	EC-459
	Fuel pressure regulator system	2	3	4	4	4	4	4	4	4		4					EC-34
	Injector circuit	1	1	2	3	2	2	2	2			2					EC-453
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4					EC-269
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1				EC-481
	Incorrect idle speed adjustment	3	3				1	1	1	1		1					EC-30
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2				2	EC-299 EC-301 EC-309 EC-315
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1					EC-30
	Ignition circuit	1	1	2	2	2		2	2			2					EC-428
Main power supply and ground circuit		2	2	3	3	3		3	3		3	3				2	EC-113
Cooling	Cooling fan circuit	3	3	3	2	3	3	3	3	3	1	2		1		3	EC-361
Air conditioner circuit		3	2	3	3	3	3	3	3	3		3				2	HA section

1 - 6: The numbers refer to the order of inspection.

Symptom Matrix Chart (Cont'd)

		SYMPTOM													Reference page			
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERCOOLS		OVERCHARGING	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	1P	1X	HA		
SYSTEM — Engine control system	Camshaft position sensor circuit	2	2	2	2	2	3	3	3			3					EC-257	
	Mass air flow sensor circuit	1	1	2	2	2	2	2	2	2		2					EC-140	
	Engine coolant temperature sensor circuit	1	1	2	3	2	3	2	2	3	2	2						EC-152
	Throttle position sensor circuit		1	2		2	2	2	2	2		2						EC-235 EC-372 EC-374 EC-415
	Accelerator pedal position sensor circuit			3	2	1	2			2								EC-401 EC-408 EC-421
	Heated oxygen sensor 1 circuit		1	2	3	2		2	2				2					EC-172 EC-372 EC-320 EC-327
	Intake valve timing control system		3	3		2		3	3				3					EC-294
	Vehicle speed sensor circuit		2	3		3							3					EC-276
	Knock sensor circuit			2	2	2							3					EC-247
	ECM	2	2	3	3	3	3	3	3	3	3	3						EC-283
	Start signal circuit	2																EC-450
	Park/Neutral position switch circuit			3		3		3	3				3					EC-388
	Variable Induction Air Control (VIAS) system					2												EC-446
	Electrical load signal circuit		2					3	3									EC-470
	Power steering pressure sensor circuit		2					3	3									EC-278

1 - 6: The numbers refer to the order of inspection.


Symptom Matrix Chart (Cont'd)

SYSTEM — ENGINE MECHANICAL & OTHER








SYSTEM — Engine mechanical & other		SYMPTOM													Reference page			
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERCOOLS		OVERCHARGING	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	1P	1X	HA		
Fuel	Fuel tank	5															FE section	
	Fuel piping	5		5	5	5		5	5			5						
	Vapor lock		5															
	Valve deposit																	
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5			5	5			5					
Air	Air duct	5															—	
	Air cleaner																	
	Air leakage from air duct (Mass air flow sensor — Electric throttle control actuator)		5	5		5		5	5			5						
	Electric throttle control actuator, Throttle wire	5			5		5				5	5						FE section
	Air leakage from intake manifold/ Collector/Gasket																—	
Cranking	Battery																EL section	
	Alternator circuit	1	1	1		1		1	1			1			1	1		
	Starter circuit	3																
	PNP switch	4																AT section
	Drive plate	6																EM section
Engine	Cylinder head																EM section	
	Cylinder head gasket										4							
	Cylinder block												6					
	Piston	6	6	6	6	6		6	6			6						
	Piston ring																	
	Connecting rod																	
	Bearing																	
	Crankshaft													6				
Valve mechanism	Timing chain	6	6	6	6	6		6	6			6	6					
	Camshaft	5	5	5	5	5		5	5			5						
	Intake valve																	
	Exhaust valve	6	6	6	6	6		6	6			6	6					
Exhaust	Exhaust manifold/Tube/Muffler/Gasket			5		5		5	5			5					EM section & FE section	
	Three way catalyst*	5	5	5	5	5		5	5			5					FE section	
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5		5		5	5		5	5	5				—	
	Oil level (Low)/Filthy oil																	
Cooling	Radiator/Hose/Radiator filler cap																LC section	
	Thermostat													2				
	Water pump																	
	Water gallery		5	5	5	5					4	5						
	Cooling fan														2			EC section
	Coolant level (low)/Contaminated coolant																	MA section
NATS (Nissan Anti-Theft System)		1	1														EC-50 or EL section	

1 - 6: The numbers refer to the order of inspection.









Engine Control Component Parts Location







**Engine Control Component Parts Location
(Cont'd)**




Engine Control Component Parts Location (Cont'd)




**Engine Control Component Parts Location
(Cont'd)**



Circuit Diagram






Circuit Diagram (Cont'd)



Pre-
ceding
page

ECM Harness Connector Terminal Layout



ECM Terminals and Reference Value

PREPARATION

1. ECM is located behind the center console. For this inspection, remove instrument lower driver panel.
2. Remove ECM harness protector.

3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.

- Open harness securing clip to make testing easily.
- Use extreme care not to touch 2 pins at one time.
- Data is for comparison and may not be exact.

ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground.





Pulse signal is measured by CONSULT-II.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

**ECM Terminals and Reference Value
(Cont'd)**

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
5 6 7 13 14 15	BR/W GY/L BR/Y GY/R BR GY	Injector No. 1 Injector No. 2 Injector No. 3 Injector No. 4 Injector No. 5 Injector No. 6	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Warm-up condition <input type="checkbox"/> Idle speed 	BATTERY VOLTAGE (11 - 14V)*1  SEC984C
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Warm-up condition <input type="checkbox"/> Engine speed is 2,000 rpm. 	BATTERY VOLTAGE (11 - 14V)*1  SEC985C
8	G/Y	Heated oxygen sensor 1 heater (bank 2)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Warm-up condition <input type="checkbox"/> Engine speed is below 2,800 rpm. 	Approximately 7.0V*1  PBIB0519E
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Engine speed is above 2,800 rpm. 	BATTERY VOLTAGE (11 - 14V)
9	Y/B	Heated oxygen sensor 1 heater (bank 1)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Warm-up condition <input type="checkbox"/> Engine speed is below 2,800 rpm. 	Approximately 7.0V*1  PBIB0519E
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Engine speed is above 2,800 rpm. 	BATTERY VOLTAGE (11 - 14V)
10	Y/R	Heated oxygen sensor 2 heater (bank 2)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Warm-up condition <input type="checkbox"/> After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load <input type="checkbox"/> Engine speed is below 3,200 rpm 	0 - 1.0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> <input type="checkbox"/> Engine stopped <div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> <input type="checkbox"/> Engine speed is above 3,200 rpm 	BATTERY VOLTAGE (11 - 14V)



TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

**ECM Terminals and Reference Value
(Cont'd)**

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
11	R/G	Heated oxygen sensor 2 heater (bank 1)	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition — After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load — Engine speed is below 3,200 rpm 	0 - 1.0V
			<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> — Engine stopped <div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> — Engine speed is above 3,200 rpm 	BATTERY VOLTAGE (11 - 14V)
18 19 20 21 29 30	Y/R G Y R/B R/G R	Ignition signal No. 1 Ignition signal No. 2 Ignition signal No. 3 Ignition signal No. 4 Ignition signal No. 5 Ignition signal No. 6	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition — Idle speed 	0 - 0.1V*1  SEC986C
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition — Engine speed is 2,000 rpm. 	0 - 0.2V*1  SEC987C
26	P/L	Throttle control motor relay	<div style="border: 1px solid black; padding: 2px;">Ignition switch "OFF"</div>	BATTERY VOLTAGE (11 - 14V)
			<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div>	0 - 1.0V
27	LG/R	VIAS control solenoid valve	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> — Idle speed 	BATTERY VOLTAGE (11 - 14V)
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> — Engine speed is above 5,000 rpm. 	0 - 1.0V
35	Y/G	MI	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div>	0 - 1.0V
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> — Idle speed 	BATTERY VOLTAGE (11 - 14V)
41	R/Y	Fuel pump relay	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> — For 5 seconds after turning ignition switch "ON" 	0 - 1.0V
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div>	BATTERY VOLTAGE (11 - 14V)
			<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> — More than 5 seconds after turning ignition switch "ON" 	BATTERY VOLTAGE (11 - 14V)





TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

**ECM Terminals and Reference Value
(Cont'd)**

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
42	B/Y	ECM relay (Self shut-off)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "OFF"</div> └ For 5 seconds after turning ignition switch "OFF"	0 - 1.0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "OFF"</div> └ 5 seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
53	W/G	Ignition switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "OFF"</div>	0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	BATTERY VOLTAGE (11 - 14V)
54	W/B	EVAP canister purge volume control solenoid valve	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Idle speed	BATTERY VOLTAGE (11 - 14V)*1  SEC990C
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Engine speed is about 2,000 rpm (More than 100 seconds after starting engine).	BATTERY VOLTAGE (11 - 14V)*1  SEC991C
55	L/B	Cooling fan relay (High)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Cooling fan is operating at high speed.	0 - 1.0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
56	L	Cooling fan relay (Low)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Cooling fan is operating.	0 - 1.0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
59	R/W	Start signal	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "START"</div>	9 - 14V
60	Y/G	Snow mode switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Snow mode switch is "OFF"	Approx. 0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Snow mode switch is "ON"	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

**ECM Terminals and Reference Value
(Cont'd)**



TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
63	B/W	Camshaft position sensor (POS signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Idle speed 	Approx. 2.6 - 2.7V*1  SEC750D
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Engine speed is 2,000 rpm 	Approx. 2.5 - 2.6V*1  SEC751D
80	R/PU	PNP switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Gear position is Neutral. 	Approximately 0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Except the above gear position 	Approximately 5V
83 84	L L	Camshaft position sensor (REF signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running. (Warm-up condition)</div> <ul style="list-style-type: none"> └ Idle speed 	Approx. 0.3 - 0.6V*1  SEC746D
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Engine speed is 2,000 rpm 	Approx. 0.3 - 0.6V*1  SEC747D
87	W	Accelerator pedal position sensor 1	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully released 	More than 0.36V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully depressed 	Less than 4.75V

TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

**ECM Terminals and Reference Value
(Cont'd)**


TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
88	R/G	Refrigerant pressure sensor	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Both A/C switch and blower switch are "ON" (Compressor operates) 	1.0 - 4.0V
89	B	Sensors' ground	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Idle speed 	Approximately 0V
91	W/G	Mass air flow sensor	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Idle speed 	0.75 - 1.2V
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Engine speed is 2,500 rpm. 	1.7 - 2.4V
94	LG	Accelerator pedal position sensor 2 power supply	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div>	Approximately 2.5V
95	W	Power supply for ECM (Buck-up)	<div style="border: 1px solid black; padding: 2px;">Ignition switch "OFF"</div>	BATTERY VOLTAGE (11 - 14V)
98	R/L	Throttle position sensor 2	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully released 	Less than 4.75V
			<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully depressed 	More than 0.36V
99	L/W	Intake air temperature sensor	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div>	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
100	R	Accelerator pedal position sensor 2 ground	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div>	Approximately 0V
103	Y	Sensors' power supply	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div>	Approximately 5V
106	G/Y	Stop lamp switch	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Brake pedal fully released 	Approximately 0V
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Brake pedal fully depressed 	BATTERY VOLTAGE (11 - 14V)

ECM Terminals and Reference Value (Cont'd)

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
108	L	Throttle position sensor 1	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully released 	More than 0.36V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully depressed 	Less than 4.75V
109	B/W	Mass air flow sensor ground	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Idle speed 	Approximately 0V
111	W	Crankshaft position sensor (OBD)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Idle speed 	1 - 2V (AC range)  SEC748D
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Engine speed is 2,000 rpm. 	3 - 4V (AC range)  SEC749D
114	W	Heated oxygen sensor 1 (bank 1)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
115	W	Heated oxygen sensor 1 (bank 2)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
117	G	Accelerator pedal position sensor 2	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully released 	More than 0.18V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Gear position is "D" └ Accelerator pedal fully depressed 	Less than 2.37V
118	BR/W	Power steering pressure sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Steering wheel is being turned 	0.5 - 4.5V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> └ Steering wheel is not being turned 	0.4 - 0.8V


TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

**ECM Terminals and Reference Value
(Cont'd)**

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
121	LG/B	Engine coolant temperature sensor	Engine is running.	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.
123	W	Heated oxygen sensor 2 (bank 2)	Engine is running. — Warm-up condition — Revving engine from idle to 3,000 rpm quickly after the following conditions are met — After keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load	0 - Approximately 1.0V
124	W	Heated oxygen sensor 2 (bank 1)	Engine is running. — Warm-up condition — Revving engine from idle to 3,000 rpm quickly after the following conditions are met — After keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load	0 - Approximately 1.0V
125 126	W W	Knock sensor (Bank 1) Knock sensor (Bank 2)	Engine is running. — Idle speed	Approximately 2.5V
151	L/W	Throttle control motor (Open)	Ignition switch "ON" — Engine stopped — Gear position is "D" — Accelerator pedal is depressing	0 - 14V*1  PBIB1105E
152	R	Intake valve timing control solenoid valve	Engine is running. — Warm-up condition — Engine speed is between 1,000 rpm and 4,200 rpm — During high load condition — Vehicle speed is more than 8 km/h (5 MPH)	Approximately 0V
			Engine is running. — Those other than above	BATTERY VOLTAGE (11 - 14V)
153 156 159 165 168	B B B B B	ECM ground	Engine is running. — Idle speed	Engine ground

TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

**ECM Terminals and Reference Value
(Cont'd)**

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
154	L/B	Throttle control motor (Close)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> — Engine stopped — Gear position is "D" — Accelerator pedal is releasing 	0 - 14V*1  PBIB1105E
157	G	Throttle control motor relay power supply	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	BATTERY VOLTAGE (11 - 14V)
163 166	B/R	Power supply for ECM	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	BATTERY VOLTAGE (11 - 14V)
164	PU	Data link connector	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> <ul style="list-style-type: none"> — CONSULT-II or GST is disconnected. 	BATTERY VOLTAGE (11 - 14V)
171	W/R	CAN communication line	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 1.7 - 2.3V Output voltage varies with the communication status.
174	G/B	CAN communication line	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 2.6 - 3.2V Output voltage varies with the communication status.

*1: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

CONSULT-II Function

FUNCTION

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for Basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
DTC & SRT confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.
ECM part number	ECM part number can be read.

*1: The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values
- Others

CONSULT-II Function (Cont'd)

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOS-TIC RESULTS		DATA MONI-TOR	DATA MONI-TOR (SPEC)	ACTIVE TEST	DTC & SRT CON-FIRMATION	
			DTC*1	FREEZE FRAME DATA				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (OBD)		x	x	x	x		
	Camshaft position sensor		x	x	x	x			
	Mass air flow sensor		x		x	x			
	Engine coolant temperature sensor		x	x	x	x	x		
	Heated oxygen sensor 1		x		x	x		x	
	Heated oxygen sensor 2		x		x	x		x	
	Vehicle speed signal		x	x	x	x			
	Accelerator pedal position sensor		x		x	x			
	Throttle position sensor		x		x	x			
	Intake air temperature sensor		x	x	x	x			
	Knock sensor		x						
	Refrigerant pressure sensor				x	x			
	Closed throttle position switch (accelerator pedal position sensor signal)				x	x			
	Air conditioner switch				x	x			
	Park/neutral position (PNP) switch		x		x	x			
	Stop lamp switch		x		x	x			
	Power steering pressure sensor		x		x	x			
	Battery voltage				x	x			
	Electrical load signal				x	x			
	OUTPUT	Injectors			x	x	x		
	Power transistor (Ignition timing)				x	x	x		
	Throttle control motor relay		x		x	x			
	Throttle control motor		x						
	EVAP canister purge volume control solenoid valve		x		x	x	x		
	Air conditioner relay				x	x			
	Fuel pump relay	x			x	x	x		
	Cooling fan relay		x		x	x	x		
	Heated oxygen sensor 1 heater		x		x	x		x	
Heated oxygen sensor 2 heater		x		x	x		x		
Intake valve timing control solenoid valve		x		x	x	x			
Calculated load value			x	x	x				
VIAS control solenoid valve				x	x	x			


x: Applicable

*1: This item includes 1st trip DTCs.


*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-41, "FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA".

CONSULT-II Function (Cont'd)


CONSULT-II INSPECTION PROCEDURE




1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector, which is located under the drivers side dash panel.
3. Turn ignition switch ON.



4. Touch "START (NISSAN BASED VHCL)".



5. Touch "ENGINE".
If "ENGINE" is not indicated, go to GI section, "CONSULT-II Data Link Connector (DLC) Circuit".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.

CONSULT-II Function (Cont'd)

WORK SUPPORT MODE

Work item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> ● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> ● THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM. 	When learning the idle air volume
SELF-LEARNING CONT	<ul style="list-style-type: none"> ● THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clearing the coefficient of self-learning control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> ● IDLE CONDITION 	When setting target idle speed
TARGET IGN TIM ADJ*	<ul style="list-style-type: none"> ● IDLE CONDITION 	When adjusting target ignition timing

*: This function is not necessary in the usual service procedure.

SELF-DIAG RESULTS MODE

Self diagnostic item

Regarding items of "DTC and 1st trip DTC", refer to EC-9, "INDEX FOR DTC".

Freeze frame data and 1st trip freeze frame data

Freeze frame data item*1	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> ● The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-9, "INDEX FOR DTC".)
FUEL SYS-B1	<ul style="list-style-type: none"> ● "Fuel injection system status" at the moment a malfunction is detected is displayed. ● One mode in the following is displayed.
FUEL SYS-B2	<ul style="list-style-type: none"> "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> ● The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> ● The engine coolant temperature at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Long-term fuel trim" at the moment a malfunction is detected is displayed. ● The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Short-term fuel trim" at the moment a malfunction is detected is displayed. ● The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> ● The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> ● The vehicle speed at the moment a malfunction is detected is displayed.
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> ● The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> ● The intake air temperature at the moment a malfunction is detected is displayed.

*1: The items are the same as those of 1st trip freeze frame data.

CONSULT-II Function (Cont'd)

DATA MONITOR MODE

Monitored item

x: Applicable

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
ENG SPEED [rpm]	x	x		<ul style="list-style-type: none"> Indicates the engine speed computed from the POS signal (1° signal) of the camshaft position sensor. 	<ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS A/F SE-B1 [V]	x	x		<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		x		<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		x		<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%]		x			
COOLAN TEMP/S [°C] or [°F]	x	x		<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
HO2S1 (B1) [V]	x	x		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 is displayed. 	
HO2S1 (B2) [V]	x				
HO2S2 (B1) [V]	x	x		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 2 is displayed. 	
HO2S2 (B2) [V]	x				
HO2S1 MNTR (B1) [RICH/LEAN]	x	x		<ul style="list-style-type: none"> Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
HO2S1 MNTR (B2) [RICH/LEAN]	x				
HO2S2 MNTR (B1) [RICH/LEAN]	x			<ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
HO2S2 MNTR (B2) [RICH/LEAN]	x				
VHCL SPEED SE [km/h] or [mph]	x	x		<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal is displayed. 	

TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

CONSULT-II Function (Cont'd)

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
BATTERY VOLT [V]	x	x		<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
ACCEL SEN 1 [V]	x	x		<ul style="list-style-type: none"> The accelerator pedal position sensor signal voltage is displayed. 	
ACCEL SEN 2 [V]	x				
THRTL SEN 1 [V]	x	x		<ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. 	
THRTL SEN 2 [V]	x				
INT/A TEMP SE [°C] or [°F]	x	x		<ul style="list-style-type: none"> The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated. 	
START SIGNAL [ON/OFF]	x	x		<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the starter signal computed from the signals of the crankshaft position sensor (POS), camshaft position sensor (PHASE) and battery voltage. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL POS [ON/OFF]	x	x		<ul style="list-style-type: none"> Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal. 	
AIR COND SIG [ON/OFF]	x	x		<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. 	
P/N POSI SW [ON/OFF]	x	x		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal. 	
PW/ST SIGNAL [ON/OFF]	x	x		<ul style="list-style-type: none"> [ON/OFF] condition of the power steering oil pressure switch as determined by the power steering oil pressure signal is indicated. 	
LOAD SIGNAL [ON/OFF]	x	x		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the electrical load signal. ON ... Rear window defogger switch is ON and/or lighting switch is in 2nd position. OFF ... Both rear window defogger switch and lighting switch are OFF. 	
IGNITION SW [ON/OFF]	x			<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. 	
BRAKE SW [ON/OFF]	x			<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the stop lamp switch signal. 	
INJ PULSE-B1 [msec]		x		<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated.
INJ PULSE-B2 [msec]					
IGN TIMING [BTDC]		x		<ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.

CONSULT-II Function (Cont'd)

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	CAN DIAG SUPPORT MNTR	Description	Remarks
CAL/LD VALUE [%]				<ul style="list-style-type: none"> ● "Calculated load value" indicates the value of the current airflow divided by peak airflow. 	
MASS AIRFLOW [g·m/s]				<ul style="list-style-type: none"> ● Indicates the mass airflow computed by ECM according to the signal voltage of the mass air flow sensor. 	
PURG VOL C/V [%]				<ul style="list-style-type: none"> ● Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. ● The opening becomes larger as the value increases. 	
VIAS S/V [ON/OFF]				<ul style="list-style-type: none"> ● The control condition of the VIAS control solenoid valve (determined by ECM according to the input signal) is indicated. ● OFF ... VIAS control solenoid valve is not operating. ● ON ... VIAS control solenoid valve is operating. 	
INT/V SOL (B1) [%]				<ul style="list-style-type: none"> ● The control condition of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated. ON ... intake valve timing control is operating. OFF ... Intake valve timing control is not operating. 	
AIR COND RLY [ON/OFF]		x		<ul style="list-style-type: none"> ● The air conditioner relay control condition (determined by ECM according to the input signals) is indicated. 	
FUEL PUMP RLY [ON/OFF]		x		<ul style="list-style-type: none"> ● Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
THRTL RELAY [ON/OFF]		x*2		<ul style="list-style-type: none"> ● Indicates the throttle control motor relay control condition determined by the ECM according to the input signals. 	
COOLING FAN [HI/LOW/OFF]				<ul style="list-style-type: none"> ● Indicates the condition of the cooling fan (determined by ECM according to the input signals). HI ... High speed operation LOW ... Low speed operation OFF ... Stop 	
HO2S1 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> ● Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 	
HO2S1 HTR (B2) [ON/OFF]					

TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

CONSULT-II Function (Cont'd)

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	CAN DIAG SUPPORT MNTR	Description	Remarks
HO2S2 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 	
HO2S2 HTR (B2) [ON/OFF]					
IDL A/V LEARN [YET/CMPLT]				<ul style="list-style-type: none"> Display the condition of idle air volume learning YET ... Idle air volume learning has not been performed yet. CMPLT ... Idle air volume learning has already been performed successfully. 	
TRVL AFTER MIL [km] or [mile]				<ul style="list-style-type: none"> Distance traveled while MI is activated. 	
O2SEN HTR DTY [%]				<ul style="list-style-type: none"> Indicates the heated oxygen sensor 1 heater control value computed by the ECM according to the input signals. 	
AC PRESS SEN [V]	x			<ul style="list-style-type: none"> The signal voltage from the refrigerant pressure sensor is displayed. 	
Voltage [V]				<ul style="list-style-type: none"> Voltage, frequency, duty cycle or pulse width measured by the probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.
Frequency [msec], [Hz] or [%]					
DUTY-HI					
DUTY-LOW					
PLS WIDTH-HI					
PLS WIDTH-LOW					
CAN COMM [OK/NG]			x	<ul style="list-style-type: none"> Indicates the communication condition of CAN communication line. 	<ul style="list-style-type: none"> These items are not displayed in “SELECTION FROM MENU” mode.
CAN CIRC 1 [OK/UNKWN]			x		
CAN CIRC 2 [OK/UNKWN]			x		
CAN CIRC 3 [OK/UNKWN]			x		
CAN CIRC 4 [OK/UNKWN]			x		
CAN CIRC 5 [OK/UNKWN]			x		
CAN CIRC 6 [OK/UNKWN]			x		
CAN CIRC 7 [OK/UNKWN]			x		

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

CONSULT-II Function (Cont'd)

DATA MONITOR (SPEC) MODE

Monitored item

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
ENG SPEED [rpm]	x	x	<ul style="list-style-type: none"> Indicates the engine speed computed from the POS signal (1° signal) of the camshaft position sensor. 	
MAS A/F SE-B1 [V]	x	x	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
B/FUEL SCHDL [msec]		x	<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
A/F ALPHA-B1 [%]		x	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When engine is running specification range is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%]		x		

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

Test item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Fuel injectors Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Perform "Idle Air Volume Learning".
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connectors Compression Fuel injectors Power transistor Spark plugs Ignition coils
COOLING FAN*	<ul style="list-style-type: none"> Ignition switch: ON Turn the cooling fan "ON" and "OFF" with CONSULT-II. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> Harness and connectors Cooling fan relay Cooling fan motor
ENG COOLANT TEMP	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Engine coolant temperature sensor Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connectors Fuel pump relay
VIAS SOL VALVE	<ul style="list-style-type: none"> Ignition switch: ON Turn solenoid valve "ON" and "OFF" with CONSULT-II and listen for operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connectors Solenoid valve

CONSULT-II Function (Cont'd)

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
PURG VOL CONT/V	<ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connectors ● Solenoid valve
V/T ASSIGN ANGLE	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change intake valve timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connectors ● Intake valve timing control solenoid valve

*: Leaving cooling fan "OFF" with CONSULT-II while engine is running may cause the engine to overheat.

DTC & SRT CONFIRMATION MODE

SRT STATUS mode

For details, refer to EC-42, "SYSTEM READINESS TEST (SRT) CODE".

SRT work support mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

DTC work support mode

Test mode	Test item	Condition	Reference page
HO2S1	HO2S1 (B1) P0133, P0153	Refer to corresponding trouble diagnosis for DTC.	EC-172
	HO2S1 (B1) P0134, P0154		EC-185
	HO2S1 (B1) P1143, P1163		EC-320
	HO2S1 (B1) P1144, P1164		EC-327
HO2S2	HO2S2 (B1) P0139, P0159		EC-205
	HO2S2 (B1) P1146, P1166		EC-335
	HO2S2 (B1) P1147, P1167		EC-348

CONSULT-II Function (Cont'd)

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at right, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.

2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.

Operation



1. "AUTO TRIG"

- While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.

When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "Incident Simulation Tests" in GI section.)



2. "MANU TRIG"



- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.





CONSULT-II Function (Cont'd)

DATA MONITOR
SELECTION FROM MENU
ECM INPUT SIGNALS
MAIN SIGNALS
CAN COMM SIGNALS
SELECTION FROM MENU

SET RECORDING CONDITION			
AUTO TRIG			
MANUTRIG			
TRIGGER POINT			
			
Recording speed			
			
MODE	BACK	LIGHT	COPY

SET RECORDING CONDITION			
AUTO TRIG			
MANUTRIG			
TRIGGER POINT			
			
Recording speed			
			
MODE	BACK	LIGHT	COPY






Generic Scan Tool (GST) Function

DESCRIPTION

Generic Scan Tool (OBDII scan tool) complying with ISO 15031-4 has 8 different functions explained below. ISO9141 is used as the protocol. The name “GST” or “Generic Scan Tool” is used in this service manual.

FUNCTION

Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. For details, refer to EC-41, “FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA”.
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.
MODE 4	CLEAR DIAG INFO	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7)
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	This mode is not applicable on this vehicle.
MODE 9	(CALIBRATION ID)	This mode enables the off-board test device to request specific vehicle information such as Vehicle Identification Number (VIN) and Calibration IDs.





GST INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect “GST” to data link connector, which is located under the driver side dash panel near the fuse box cover.
3. Turn ignition switch ON.

Generic Scan Tool (GST) Function (Cont'd)

4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.

CONSULT-II Reference Value in Data Monitor Mode

Remarks:

- Specification data are reference values.
 - Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.
 i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare CONSULT-II value with the tachometer indication. 		Almost the same speed as the tachometer indication.
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load 	Idle	Approx. 1.3 - 1.7V
		2,500 rpm	Approx. 1.7 - 2.4V
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	5.0 - 5.5 msec
		2,000 rpm	5.0 - 5.5 msec
A/F ALPHA-B1 A/F ALPHA-B2	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	75% - 125%
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
HO2S1 (B1) HO2S1 (B2)	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	LEAN ↔ RICH
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare CONSULT-II value with the speedometer indication. 		Almost the same speed as the speedometer indication
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		11 - 14V
ACCEL SEN1 ACCEL SEN2*	<ul style="list-style-type: none"> ● Ignition switch: ON (engine stopped) ● Shift lever: D 	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V
THRTL SEN1 THRTL SEN2*	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Shift lever: D 	Accelerator pedal: Fully released	More than 0.5V
		Accelerator pedal: Fully depressed	Less than 1.5V
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 		OFF → ON → OFF
CLSD THL POS	<ul style="list-style-type: none"> ● Ignition switch: ON 	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF OFF
		Air conditioner switch: ON (Compressor operates.) ON
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N ON
		Shift lever: Except above OFF
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel is in neutral position. (Forward direction) OFF
		Steering wheel is turned. ON
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is in 2nd. ON
		Rear window defogger switch is OFF and lighting switch is OFF. OFF
IGNITION SW	● Ignition switch: ON → OFF → ON	ON → OFF → ON
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released OFF
		Brake pedal: Slightly depressed ON
INJ PULSE-B1 INJ PULSE-B2	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle 3.0 - 4.0 msec
		2,000 rpm 3.0 - 4.0 msec
IGN TIMING	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle 10°±5° BTDC
		2,000 rpm 25° - 45° BTDC
CAL/LD VALUE	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle 10% - 35%
		2,500 rpm 10% - 35%
MASS AIRFLOW	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle 3.0 - 9.0 g·m/s
		2,500 rpm 10.0 - 25.0 g·m/s
PURG VOL C/V	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle 0%
		2,000 rpm 65 - 85%
VIAS S/V	● Engine: After warming up	Idle OFF
		More than 5,000 rpm ON
INT/V SOL-B1	● Engine: Idle OFF	
	● Engine: After warming up ● Engine speed is between 1,000 rpm and 4,200 rpm ● Vehicle speed is more than 8 km/h (5 MPH). ● During high load condition ON	
AIR COND RLY	● Engine: After warming up, idle the engine	Air conditioner switch: OFF OFF
		Air conditioner switch: ON (Compressor operates) ON
FUEL PUMP RLY	● For 1 seconds after turning ignition switch ON ● Engine running or cranking ON	
	● Except above conditions OFF	
THRTL RELAY	● Ignition switch: ON ON	

TROUBLE DIAGNOSIS TB48DE A/T (WITH EURO-OBD)

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION
COOLING FAN	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine ● Air conditioner switch: OFF ● Vehicle stopped 	Engine coolant temperature is 94°C (201°F) or less
		Engine coolant temperature is between 95°C (203°F) and 99°C (210°F)
		Engine coolant temperature is 100°C (212°F) or more
HO2S1 HTR (B1) HO2S1 HTR (B2)	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed: Below 2,800 rpm 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 2,800 rpm 	OFF
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> ● Engine speed: Below 3,200 rpm after the following conditions are met. ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,200 rpm 	OFF
TRVL AFTER MIL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Vehicle has traveled after MI has turned ON.
O2SEN HTR DTY	<ul style="list-style-type: none"> ● Engine coolant temperature when engine started: More than 80° (176°F) ● Engine speed: Below 2,800 rpm 	Approx. 50%
AC PRESS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Approx. 1.6V
	<ul style="list-style-type: none"> ● Engine: Idle ● Air conditioner switch: OFF 	1.0 - 2.0V
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value
CAN COMM	<ul style="list-style-type: none"> ● Ignition switch: ON 	OK
CAN CIRC 1		OK
CAN CIRC 2		OK
CAN CIRC 3		UNKWN
CAN CIRC 4		OK
CAN CIRC 5		UNKWN
CAN CIRC 6		UNKWN
CAN CIRC 7		UNKWN

*: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.


Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.

CLSD THL POS, ACCEL SEN 1, THRTL SEN 1

Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch "ON" and with selector lever in "D" position.


The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.


Each value is for reference, the exact value may vary.




Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




- "THRTL SEN 1" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

Description

The specification (SP) value indicates the tolerance of the value that is displayed in “DATA MONITOR (SPEC)” mode of CONSULT-II during normal operation of the Engine Control System. When the value in “DATA MONITOR (SPEC)” mode is within the SP value, the Engine Control System is confirmed OK. When the value in “DATA MONITOR (SPEC)” mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:


- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing condition

- Vehicle driven distance: More than 5,000 km (3,017 miles)
- Barometric pressure: 98.3 - 104.3 kPa (0.98 - 1.04 bar, 1.003 - 1.064 kg/cm², 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*1
- Electrical load: Not applied*2
- Engine speed: Idle

*1: After the engine is warmed up to normal operating temperature, drive vehicle until “FLUID TEMP SE” (A/T fluid temperature sensor signal) indicates more than 60°C (140°F).

*2: Rear window defogger switch, air conditioner switch, lighting switch are “OFF”. Steering wheel is straight ahead.



Inspection Procedure

NOTE:


Perform “DATA MONITOR (SPEC)” mode in maximum scale display.

1. Perform EC-66, “Basic Inspection”.
2. Confirm that the testing conditions indicated above are met.
3. Select “B/FUEL SCHDL”, “A/F ALPHA-B1/B2” and “MAS A/F SE-B1” in “DATA MONITOR (SPEC)” mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to EC-109, “Diagnostic Procedure”.

TROUBLE DIAGNOSIS — SPECIFICATION VALUE

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)



SEF615ZA

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

TB48DE A/T (WITH EURO-OBD)

Description

Intermittent incidents (I/I) may occur. In many cases, the malfunction resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunctioning area.

Common I/I Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the malfunctioning area.

Diagnostic Procedure

1	INSPECTION START		
Erase (1st trip) DTCs. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".			
		▶	GO TO 2.
2	CHECK GROUND TERMINALS		
Check ground terminals for corroding or loose connection. Refer to GI section, "Incident Simulation Tests".			
OK or NG			
OK		▶	GO TO 3.
NG		▶	Repair or replace.
3	SEARCH FOR ELECTRICAL INCIDENT		
Perform GI section, "Incident Simulation Tests".			
OK or NG			
OK		▶	INSPECTION END
NG		▶	Repair or replace.



POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram


EC-MAIN-01

— : Detectable line for DTC
 — : Non-detectable line for DTC



Refer to last page (Foldout page).

M21, E127
 M2



POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
42	B/Y	ECM relay (Self-shutoff)	Engine is running.	0 - 1.0V
			Ignition switch "OFF" └ For 5 seconds after turning ignition switch "OFF"	
53	W/G	Ignition switch	Ignition switch "OFF"	0V
			Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
163 166	B/R	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

EC-MAIN-02



POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
156	B	ECM ground	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> Idle speed	Engine ground
159	B			
165	B			
168	B			

Diagnostic Procedure

1	INSPECTION START
Start engine.	
Is engine running?	
Yes or No	
Yes	▶ GO TO 11.
No	▶ GO TO 2.

2	CHECK ECM POWER SUPPLY CIRCUIT-I
1. Turn ignition switch "OFF" and then "ON". 2. Check voltage between ECM terminal 53 and ground with CONSULT-II or tester.	
	
Voltage: Battery voltage OK or NG	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

SEC817C

3	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> ● Harness connectors M52, F7 ● Fuse block (J/B) connector M2 ● 10A fuse ● Harness for open or short between ECM and fuse 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	



POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4	CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminals 156, 159, 165, 168 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

5	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between ECM and ground 		
		▶ Repair open circuit or short to power in harness or connectors.

6	CHECK ECM POWER SUPPLY CIRCUIT-II	
<p>1. Disconnect ECM relay.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEC668D</p> <p>2. Check voltage between ECM relay terminals 2 and 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">PBIB0071E</p>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)



Diagnostic Procedure (Cont'd)

7	DETECT MALFUNCTIONING PART	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● 10A fuse ● 15A fuse ● Harness for open or short between ECM relay and battery 	
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	<p>1. Check harness continuity between ECM terminal 42 and ECM relay terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power. OK or NG</p>	
OK		▶	GO TO 10.
NG		▶	GO TO 9.
9	DETECT MALFUNCTIONING PART	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M52, F7 ● Harness for open or short between ECM and ECM relay 	
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
10	CHECK ECM RELAY	<p>Refer to EC-120.</p> <p style="text-align: center;">OK or NG</p>	
OK		▶	GO TO EC-428.
NG		▶	Replace ECM relay.
11	CHECK ECM POWER SUPPLY CIRCUIT-III	<p>1. Stop engine and wait at least 10 seconds.</p> <p>2. Turn ignition switch "ON" and then "OFF".</p> <p>3. Check voltage between ECM terminals 163, 166 and ground with CONSULT-II or tester.</p> <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; font-size: small;">SEC819C</p> <p>Voltage: After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop approximately 0V.</p> <p style="text-align: center;">OK or NG</p>	
OK		▶	GO TO 15.
NG (Battery voltage does not exist.)		▶	GO TO 12.
NG (Battery voltage exists for more than a few seconds.)		▶	GO TO 14.

POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

12	CHECK ECM POWER SUPPLY CIRCUIT-IV							
<p>1. Disconnect ECM relay.</p> <div style="text-align: center;">  <p>View with instrument driver lower panel removed</p> <p>ECM relay Fuel pump relay</p> </div> <p>2. Check voltage between ECM relay terminal 7 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>								
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 14.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 13.</td> </tr> </table>			OK	▶	GO TO 14.	NG	▶	GO TO 13.
OK	▶	GO TO 14.						
NG	▶	GO TO 13.						

SEC668D

PBIB0074E

13	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness for open or short between ECM relay and 10A fuse 		
▶ Repair open circuit or short to ground or short to power in harness or connectors.		

14	CHECK ECM POWER SUPPLY CIRCUIT-V							
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminals 163, 166 and ECM relay terminal 6. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>								
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 16.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 15.</td> </tr> </table>			OK	▶	GO TO 16.	NG	▶	GO TO 15.
OK	▶	GO TO 16.						
NG	▶	GO TO 15.						

15	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M52, F7 ● Harness for open or short between ECM and ECM relay 		
▶ Repair open circuit or short to ground or short to power in harness or connectors.		

POWER SUPPLY CIRCUIT FOR ECM

TB48DE A/T (WITH EURO-OBD)


Diagnostic Procedure (Cont'd)

16	CHECK ECM RELAY	
Refer to EC-120, "Component Inspection".		
OK or NG		
OK	▶	GO TO 17.
NG	▶	Replace ECM relay.

17	CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II	
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 156, 159, 165, 168 and engine ground. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to power.		
OK or NG		
OK	▶	GO TO 19.
NG	▶	GO TO 18.

18	DETECT MALFUNCTIONING PART	
Check the following.		
<ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between ECM and ground 		
		▶ Repair open circuit or short to power in harness or connectors.

19	CHECK INTERMITTENT INCIDENT	
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".		
OK or NG		
OK	▶	INSPECTION END



Component Inspection

ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.

DTC U1000 CAN COMMUNICATION LINE

TB48DE A/T (WITH EURO-OBD)

Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	<ul style="list-style-type: none">• ECM can not communicate to other control units.• ECM can not communicate for more than the specified time.	<ul style="list-style-type: none">• Harness or connectors (CAN communication line is open or shorted).

DTC Confirmation Procedure

1. Turn ignition switch "ON" and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to EC-123, "Diagnostic Procedure".



DTC U1000 CAN COMMUNICATION LINE

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-CAN-01

- : Detectable line for DTC
- : Non-detectable line for DTC
- : DATA LINE



DTC U1000 CAN COMMUNICATION LINE

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure

1 INSPECTION START

1. Turn ignition switch "ON".
2. Select "CAN DIAG SUPPORT MNTR" in "DATA MONITOR" mode with CONSULT-II.
3. Print out the CONSULT-II screen.

OK data

DATA MONITOR	
MONITOR	
CAN COMM	OK
CAN CIRC 1	OK
CAN CIRC 2	OK
CAN CIRC 3	UNKWN
CAN CIRC 4	OK
CAN CIRC 5	UNKWN
CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN

NG data

DATA MONITOR	
MONITOR	
CAN COMM	OK
CAN CIRC 1	UNKWN
CAN CIRC 2	UNKWN
CAN CIRC 3	UNKWN
CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN
CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN

SEC575D

▶ Go to EL section.

DTC P0031, P0032, P0051, P0052 HO2S1

HEATER

TB48DE A/T (WITH EURO-OBD)

Description

SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heater
Above 2,800	OFF
Below 2,800	ON

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1) HO2S1 HTR (B2)	<ul style="list-style-type: none">● Engine: After warming up● Engine speed: Below 2,800 rpm	ON
	<ul style="list-style-type: none">● Engine speed: Above 2,800 rpm	OFF

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031 0031 (Bank 1)	Heated oxygen sensor 1 heater control circuit low	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none">● Harness or connectors (The heated oxygen sensor 1 heater circuit is open or shorted.)● Heater oxygen sensor 1 heater
P0051 0051 (Bank 2)			
P0032 0032 (Bank 1)	Heated oxygen sensor 1 heater control circuit high	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none">● Harness or connectors (The heated oxygen sensor 1 heater circuit is shorted.)● Heater oxygen sensor 1 heater
P0052 0052 (Bank 2)			

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

DTC Confirmation Procedure (Cont'd)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and run it for at least 6 seconds at idle speed.
5. If 1st trip DTC is detected, go to EC-129, "Diagnostic Procedure".



 **WITH GST**

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Start engine and run it for at least 6 seconds at idle speed.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine and run it for at least 6 seconds at idle speed.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to EC-129, "Diagnostic Procedure".
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

Wiring Diagram


BANK 1

EC-O2H1B1-01



Refer to last page (Foldout page).

(M21, E127)
(E112)



DTC P0031, P0032, P0051, P0052 HO2S1 HEATER


TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
9	Y/B	Heated oxygen sensor 1 heater (bank 1)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Engine is running.</div> <div style="margin-left: 20px;"> └─ Warm-up condition. └─ Engine speed is below 2,800 rpm. </div>	Approximately 7.0V★ 
			<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Ignition switch "ON"</div> <div style="margin-left: 20px;"> └─ Engine stopped. </div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Engine is running.</div> <div style="margin-left: 20px;"> └─ Engine speed is above 2,800 rpm. </div>	BATTERY VOLTAGE (11 - 14V)


PBIB0519E

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)



Wiring Diagram (Cont'd)

BANK 2

EC-O2H1B2-01



Refer to last page (Foldout page).



DTC P0031, P0032, P0051, P0052 HO2S1

HEATER

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
8	G/Y	Heated oxygen sensor 1 heater (bank 2)	<p>Engine is running.</p> <ul style="list-style-type: none"> Warm-up condition. Engine speed is below 2,800 rpm. 	<p>Approximately 7.0V★</p> <p>PBIB0519E</p>
			<p>Ignition switch "ON"</p> <ul style="list-style-type: none"> Engine stopped. <p>Engine is running.</p> <ul style="list-style-type: none"> Engine speed is above 2,800 rpm. 	<p>BATTERY VOLTAGE (11 - 14V)</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

1	CHECK HO2S1 POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect heated oxygen sensor 1 harness connector.</p>	
SEC671D	
<p>3. Turn ignition switch "ON".</p> <p>4. Check voltage between HO2S1 terminal 3 and ground with CONSULT-II or tester.</p>	
PBIB0112E	
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

DTC P0031, P0032, P0051, P0052 HO2S1

HEATER

TB48DE A/T (WITH EURO-OBID)

Diagnostic Procedure (Cont'd)


2	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Harness connectors E127, M21● Harness connectors M55, F35● Fuse block (J/B) connector E112● 15A fuse● Harness for open or short between heated oxygen sensor 1 and fuse	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK HO2S1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT														
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal and HO2S1 terminal as follows. Refer to Wiring Diagram.															
<table border="1"><thead><tr><th rowspan="2">DTC</th><th colspan="2">Terminals</th><th rowspan="2">Bank</th></tr><tr><th>ECM</th><th>Sensor</th></tr></thead><tbody><tr><td>P0031, P0032</td><td>9</td><td>2</td><td>1</td></tr><tr><td>P0051, P0052</td><td>8</td><td>2</td><td>2</td></tr></tbody></table>		DTC	Terminals		Bank	ECM	Sensor	P0031, P0032	9	2	1	P0051, P0052	8	2	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0031, P0032	9	2	1												
P0051, P0052	8	2	2												
Continuity should exist.															
4. Also check harness for short to ground and short to power. OK or NG															
OK	▶ GO TO 4.														
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.														

MTBL1566

4	CHECK HEATED OXYGEN SENSOR 1 HEATER
Refer to EC-131, "Component Inspection". OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace malfunctioning heated oxygen sensor 1.

5	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
	▶ INSPECTION END



Component Inspection

HEATED OXYGEN SENSOR 1 HEATER

1. Check resistance between HO2S1 terminals as follows.

Terminal No.	Resistance
2 and 3	3.3 - 4.0Ω at 20°C (68°F)
1 and 2, 3, 4	∞Ω
4 and 1, 2, 3	(Continuity should not exist.)

2. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Description

SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Engine coolant temperature sensor	Engine coolant temperature		
Mass air flow sensor	Amount of intake air		

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed, amount of intake air and engine coolant temperature.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,200	OFF
<ul style="list-style-type: none"> Below 3,200 rpm after the following conditions are met. Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	ON

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> Engine speed: Below 3,200 rpm after the following conditions are met. Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	ON
	<ul style="list-style-type: none"> Engine speed: Above 3,200 rpm 	OFF

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037 0037 (Bank 1)	Heated oxygen sensor 2 heater control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) Heater oxygen sensor 2 heater
P0057 0057 (Bank 2)			
P0038 0038 (Bank 1)	Heated oxygen sensor 2 heater control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) Heater oxygen sensor 2 heater
P0058 0058 (Bank 2)			

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

DTC Confirmation Procedure (Cont'd)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

 **WITH CONSULT-II**

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minute.
6. If 1st trip DTC is detected, go to EC-137, "Diagnostic Procedure".



 **WITH GST**

1. Start engine and warm it up to the normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 4. Let engine idle for one minute.
 5. Turn ignition switch "OFF" and wait at least 10 seconds.
 6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 7. Let engine idle for one minute.
 8. Select "MODE 3" with GST.
 9. If DTC is detected, go to EC-137, "Diagnostic Procedure".
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

Wiring Diagram


BANK 1

EC-O2H2B1-01



Refer to last page (Foldout page).

(M21, E127)
(E112)



DTC P0037, P0038, P0057, P0058 HO2S2

HEATER

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:



Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	R/G	Heated oxygen sensor 2 heater (bank 1)	<p>Engine is running.</p> <ul style="list-style-type: none"> └ Warm-up condition └ Engine speed: Below 3,200 rpm after the following conditions are met. └ Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - 1.0V
			<p>Ignition switch "ON"</p> <ul style="list-style-type: none"> └ Engine stopped. <p>Engine is running.</p> <ul style="list-style-type: none"> └ Engine speed is above 3,200 rpm. 	BATTERY VOLTAGE (11 - 14V)

Wiring Diagram (Cont'd)


BANK 2

EC-O2H2B2-01



Refer to last page (Foldout page).

M21, E127
E112



Wiring Diagram (Cont'd)



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
10	Y/R	Heated oxygen sensor 2 heater (bank 2)	Engine is running. — Warm-up condition — Engine speed: Below 3,200 rpm after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load	0 - 1.0V
			Ignition switch "ON" — Engine stopped. Engine is running. — Engine speed is above 3,200 rpm.	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

1	CHECK HO2S2 POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect heated oxygen sensor 2 harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEC669D</p> <p>3. Turn ignition switch "ON". 4. Check voltage between HO2S2 terminal 3 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">PBIB0112E</p> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.


DTC P0037, P0038, P0057, P0058 HO2S2**HEATER****TB48DE A/T (WITH EURO-OBD)****Diagnostic Procedure (Cont'd)**

2	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness connectors M55, F35 ● Fuse block (J/B) connector E112 ● 15A fuse ● Harness for open or short between heated oxygen sensor 2 and fuse 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT														
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.															
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0037, P0038</td> <td style="text-align: center;">11</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0057, P0058</td> <td style="text-align: center;">10</td> <td style="text-align: center;">2</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>		DTC	Terminals		Bank	ECM	Sensor	P0037, P0038	11	2	1	P0057, P0058	10	2	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0037, P0038	11	2	1												
P0057, P0058	10	2	2												
Continuity should exist. MTBL1567															
4. Also check harness for short to ground and short to power. <div style="text-align: center;">OK or NG</div>															
OK	▶ GO TO 4.														
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.														

4	CHECK HEATED OXYGEN SENSOR 2 HEATER
Refer to EC-139, "Component Inspection". <div style="text-align: center;">OK or NG</div>	
OK	▶ GO TO 5.
NG	▶ Replace malfunctioning heated oxygen sensor 2.

5	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	



Component Inspection

HEATED OXYGEN SENSOR 2 HEATER

1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
2 and 3	5.0 - 7.0Ω at 25°C (77°F)
1 and 2, 3, 4	∞Ω
4 and 1, 2, 3	(Continuity should not exist)


2. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

DTC P0102, P0103 MAF SENSOR

TB48DE A/T (WITH EURO-OBD)



Component Description

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS A/F SE-B1	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load Idle	Approx. 1.3 - 1.7V
	2,500 rpm	Approx. 1.7 - 2.4V
CAL/LD VALUE	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	10% - 35%
	2,500 rpm	10% - 35%
MASS AIRFLOW	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	3.0 - 9.0 g/m/s
	2,500 rpm	10.0 - 25.0 g/m/s

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

DTC P0102, P0103 MAF SENSOR

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd) PROCEDURE FOR DTC P0102

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds.
4. If DTC is detected, go to EC-143, "Diagnostic Procedure".

With GST

Follow the procedure "With CONSULT-II" above.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

PROCEDURE FOR DTC P0103

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to EC-143, "Diagnostic Procedure".
If DTC is not detected, go to next step.
5. Start engine and wait at least 5 seconds.
6. If DTC is detected, go to EC-143, "Diagnostic Procedure".

With GST

Follow the procedure "With CONSULT-II" above.

DTC P0102, P0103 MAF SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
91	W/G	Mass air flow sensor	Engine is running. └ Warm-up condition └ Idle speed	1.3 - 1.7V
			Engine is running. └ Warm-up condition └ Engine speed is 2,500 rpm.	1.7 - 2.4V
103	Y	Sensor power supply (Mass air flow sensor)	Ignition switch "ON"	Approximately 5V
109	B/W	Sensor ground (Mass air flow sensor)	Engine is running. └ Warm-up condition └ Idle speed	Approximately 0V

Diagnostic Procedure

1	INSPECTION START	
Which malfunction (P0102 or P0103) is duplicated?		
P0102 or P0103		
P0102	▶	GO TO 2.
P0103	▶	GO TO 3.

2	CHECK INTAKE SYSTEM	
Check the following for connection.		
<ul style="list-style-type: none"> ● Air duct ● Vacuum hoses ● Intake air passage between air duct to intake manifold 		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Reconnect the parts.


DTC P0102, P0103 MAF SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3 RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.




SEC690C

▶ GO TO 4.


4 CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.



SEC688C

2. Turn ignition switch "ON".
3. Check voltage between MAF sensor terminals 2, 4 and ground with CONSULT-II or tester.



PBIB0076E

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

MTBL1568

OK or NG


- | | |
|----|------------|
| OK | ▶ GO TO 6. |
| NG | ▶ GO TO 5. |

DTC P0102, P0103 MAF SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	DETECT MALFUNCTIONING PART	
Check the following. <ul style="list-style-type: none"> ● Harness connectors M52, F7 ● Harness for open or short between mass air flow sensor and ECM ● Harness for open or short between mass air flow sensor and ECM relay 		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.
6	CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT	
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 109. Refer to Wiring Diagram. Continuity should exist.		
4. Also check harness for short to ground and short to power. OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
7	CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	
1. Check harness continuity between MAF sensor terminal 1 and ECM terminal 91. Refer to Wiring Diagram. Continuity should exist.		
2. Also check harness for short to ground and short to power. OK or NG		
OK	▶	GO TO 8.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK MASS AIR FLOW SENSOR	
Refer to EC-146, "Component Inspection".		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Replace mass air flow sensor.
9	CHECK INTERMITTENT INCIDENT	
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".		
		▶ INSPECTION END



Component Inspection

MASS AIR FLOW SENSOR

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 91 (Mass air flow sensor signal) and ground.



Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.3 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.7 - 2.4
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 4.0

*: Check for liner voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
 - a. Turn ignition switch "OFF".
 - b. Disconnect mass air flow sensor harness connector and reconnect it again.
 - c. Perform steps 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.
6. If NG, clean or replace mass air flow sensor.

DTC P0112, P0113 IAT SENSOR

TB48DE A/T (WITH EURO-OBD)



Component Description

The intake air temperature sensor is built into mass air flow sensor. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.43	7.9 - 9.3
25 (77)	3.32	1.9 - 2.1
80 (176)	1.23	0.31 - 0.37

*: These data are reference values and are measured between ECM terminal 99 (Intake air temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112 0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Intake air temperature sensor
P0113 0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.



WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to EC-150, "Diagnostic Procedure".

**DTC P0112, P0113 IAT
SENSOR**

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.



DTC P0112, P0113 IAT SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-IATS-01



 : Detectable line for DTC
 : Non-detectable line for DTC



DTC P0112, P0113 IAT SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure

1	CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect mass air flow sensor (intake air temperature sensor is built-into) harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">MAF sensor</p> <p style="margin-left: 50px;">Mass air flow sensor harness connector</p> </div> <p>3. Turn ignition switch "ON". 4. Check voltage between MAF sensor terminal 5 and ground.</p> <div style="text-align: center;">  </div> <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

SEC688C

PBIB0066E

2	CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 109. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK INTAKE AIR TEMPERATURE SENSOR
<p>Refer to EC-151, "Component Inspection".</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Replace mass air flow sensor (with intake air temperature sensor).

DTC P0112, P0113 IAT SENSOR



TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4 CHECK INTERMITTENT INCIDENT

Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".

► INSPECTION END



Component Inspection

INTAKE AIR TEMPERATURE SENSOR



1. Check resistance between mass air flow sensor terminals 3 and 5 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1

2. If NG, replace mass air flow sensor (with intake air temperature sensor).

DTC P0117, P0118 ECT SENSOR

TB48DE A/T (WITH EURO-OBD)



Component Description

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 121 (Engine coolant temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Engine coolant temperature sensor
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC P0117, P0118 ECT SENSOR

TB48DE A/T (WITH EURO-OBD)

On Board Diagnosis Logic (Cont'd)

FAIL-SAFE MODE


When this malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
	When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.	

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.



WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to EC-155, "Diagnostic Procedure".

WITH GST



Follow the procedure "WITH CONSULT-II" above.

DTC P0117, P0118 ECT SENSOR



TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-ECTS-01



Diagnostic Procedure

1	CHECK ECT SENSOR POWER SUPPLY CIRCUIT	
<p>1. Turn ignition switch "OFF". 2. Disconnect engine coolant temperature (ECT) sensor harness connector.</p> <div style="text-align: center;">  </div> <p>3. Turn ignition switch "ON". 4. Check voltage between ECT sensor terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p>Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

SEC689C

SEF645R

2	CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT	
<p>1. Turn ignition switch "OFF". 2. Check harness continuity between ECT sensor terminal 1 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

3	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between engine coolant temperature sensor and ECM 		
	▶	Repair open circuit or short to ground or short to power in harness or connectors.


DTC P0117, P0118 ECT SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4	CHECK ENGINE COOLANT TEMPERATURE SENSOR	
Refer to EC-156, "Component Inspection".		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Replace engine coolant temperature sensor.


5	CHECK INTERMITTENT INCIDENT	
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".		
▶ INSPECTION END		



Component Inspection

ENGINE COOLANT TEMPERATURE SENSOR

1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.




<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 121 (Engine coolant temperature sensor) and ground.

2. If NG, replace engine coolant temperature sensor.



Component Description

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN1 THRTL SEN2*	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Shift lever: D 	Accelerator pedal: Fully released	More than 0.5V
		Accelerator pedal: Fully depressed	Less than 1.5V

*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs for ECM terminal voltage signal.

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122 0122	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor 2 circuit is open or shorted.) ● Electric throttle control actuator (TP sensor 2)
P0123 0123	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH CONSULT-II**

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to EC-160, “Diagnostic Procedure”.

 **WITH GST**

Follow the procedure “WITH CONSULT-II” above.



DTC P0122, P0123 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-TPS2-01

: Detectable line for DTC
 : Non-detectable line for DTC



DTC P0122, P0123 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
89	B	Sensor ground	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └─ Warm-up condition └─ Idle speed	Approximately 0V
98	R/L	Throttle position sensor 2	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully released	Less than 4.75V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully depressed	More than 0.36V
103	Y	Sensor power supply	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 5V
108	L	Throttle position sensor 1	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully released	More than 0.36V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully depressed	Less than 4.75V



Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.	
	
SEC690C	
▶ GO TO 2.	

DTC P0122, P0123 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2	CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT
<p>1. Disconnect electric throttle control actuator harness connector.</p> <div style="text-align: center;"> <p>View with intake air duct removed</p>  <p>Electric throttle control actuator Accelerator pedal position sensor harness connector Throttle position sensor and throttle control motor harness connector</p> </div> <p style="text-align: right;">SEC182D</p> <p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="text-align: right;">PBIB0082E</p> </div> <p>Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between electric throttle control actuator terminal 5 and ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Check harness continuity between ECM terminal 98 and electric throttle control actuator terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0122, P0123 TP SENSOR


TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK THROTTLE POSITION SENSOR
Refer to EC-162, "Component Inspection".	
OK or NG	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

6	REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR
1. Replace the electric throttle control actuator. 2. Perform EC-31, "Accelerator Pedal Released Position Learning". 3. Perform EC-31, "Throttle Valve Closed Position Learning". 4. Perform EC-31, "Idle Air Volume Learning".	
▶ INSPECTION END	

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	




Component Inspection

THROTTLE POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Perform EC-31, "Throttle Valve Closed Position Learning".
3. Turn ignition switch "ON".
4. Set selector lever to "D" position.
5. Check voltage between ECM terminals 108 (TP sensor 1 signal), 98 (TP sensor 2 signal) and engine ground under the following conditions.


Terminal	Accelerator pedal	Voltage
108 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
98 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform EC-31, "Accelerator Pedal Released Position Learning".
8. Perform EC-31, "Throttle Valve Closed Position Learning".
9. Perform EC-31, "Idle Air Volume Learning".



Component Description


The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



On Board Diagnosis Logic

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 0132 (Bank 1)	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted). ● Heated oxygen sensor 1
P0152 0152 (Bank 2)			

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Turn ignition switch “ON”.
4. Select “DATA MONITOR” mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to EC-168, “Diagnostic Procedure”.



⑤ WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch “OFF” and wait at least 10 seconds.
 3. Restart engine and let it idle for 2 minutes.
 4. Turn ignition switch “OFF” and wait at least 10 seconds.
 5. Restart engine and let it idle for 2 minutes.
 6. Select “MODE 3” with GST.
 7. If DTC is detected, go to EC-168, “Diagnostic Procedure”.
- **When using GST, “DTC Confirmation Procedure” should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

Wiring Diagram


BANK 1

EC-O2S1B1-01



Refer to last page (Foldout page).

(M21, E127)
(E112)



**DTC P0132, P0152
HO2S1**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
115	W	Heated oxygen sensor 1 (bank 1)	Engine is running. — Warm-up condition — Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)



Wiring Diagram (Cont'd)

BANK 2

EC-O2S1B2-01



Refer to last page (Foldout page).



DTC P0132, P0152 HO2S1

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
114	W	Heated oxygen sensor 1 (bank 2)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> — Warm-up condition — Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)

Diagnostic Procedure

1	RETIGHTEN HEATED OXYGEN SENSOR 1
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten corresponding heated oxygen sensor 1. 	
	
<p style="text-align: center;">Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg-m, 30 - 44 ft-lb)</p>	
<p>▶ GO TO 2.</p>	

SEC888C

2	CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT
<ol style="list-style-type: none"> 1. Disconnect heated oxygen sensor 1 harness connector. 	
	
<ol style="list-style-type: none"> 2. Disconnect ECM harness connector. 3. Check harness continuity between HO2S1 terminal 4 and ground. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. 	
OK or NG	
<p>OK ▶ GO TO 4.</p>	
<p>NG ▶ GO TO 3.</p>	

SEC671D

DTC P0132, P0152 HO2S1

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between HO2S1 and ground 	
▶ Repair open circuit or short to power in harness or connectors.	

4	CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT														
1. Check harness continuity between ECM terminal and HO2S1 terminal as follows. Refer to Wiring Diagram.															
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0132</td> <td style="text-align: center;">115</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0152</td> <td style="text-align: center;">114</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>		DTC	Terminals		Bank	ECM	Sensor	P0132	115	1	1	P0152	114	1	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0132	115	1	1												
P0152	114	1	2												
MTBL1569															
Continuity should exist.															
2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.															
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0132</td> <td style="text-align: center;">115</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0152</td> <td style="text-align: center;">114</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>		DTC	Terminals		Bank	ECM	Sensor	P0132	115	1	1	P0152	114	1	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0132	115	1	1												
P0152	114	1	2												
MTBL1570															
Continuity should not exist.															
3. Also check harness for short to power.															
OK or NG															
OK	▶ GO TO 5.														
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.														

5	CHECK HO2S1 CONNECTOR FOR WATER
Check heated oxygen sensor 1 connectors for water. Water should not exist.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair or replace harness or connectors.

6	CHECK HEATED OXYGEN SENSOR 1
Refer to EC-170, "Component Inspection".	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace malfunctioning heated oxygen sensor 1.

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	

Component Inspection

HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLANTEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

Bank 1	cycle	1 2 3 4 5
HO2S1 MNTR (B1)		R-L-R-L-R-L-R-L-R-L-R
Bank 2	cycle	1 2 3 4 5
HO2S1 MNTR (B2)		R-L-R-L-R-L-R-L-R-L-R
R means HO2S1		
MNTR (B1)/(B2) indicates RICH		
L means HO2S1		
MNTR (B1)/(B2) indicates LEAN		

SEF647Y


6. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
 - 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Component Inspection (Cont'd)




⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Component Description


The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



On Board Diagnosis Logic

To judge the malfunction of heated oxygen sensor 1, this diagnosis measures response time of heated oxygen sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 temperature index. Judgment is based on whether the compensated time (heated oxygen sensor 1 cycling time index) is inordinately long or not.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0133 0133 (Bank 1)	Heated oxygen sensor 1 circuit slow response	The response of the voltage signal from the sensor takes more than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks ● Exhaust gas leaks ● PCV valve ● Mass air flow sensor
P0153 0153 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓜ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S1 (B1) P0133" or "HO2S1 (B2) P0153" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.

4. Touch "START".
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P0133	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF338Z


HO2S1 (B1) P0133	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF339Z

6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 20 to 50 seconds.)

ENG SPEED	1,550 - 2,500 rpm
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	5 - 16.7 msec
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.




7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to EC-178, "Diagnostic Procedure".

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

WITH GST



1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1(B1) signal] or 114 [HO2S1(B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V**
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V**
4. If NG, go to EC-178, "Diagnostic Procedure".



Wiring Diagram


BANK 1

EC-O2S1B1-01



Refer to last page (Foldout page).

M21, E127
E112



**DTC P0133, P0153
HO2S1**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
115	W	Heated oxygen sensor 1 (bank 1)	Engine is running. └ Warm-up condition └ Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)


DTC P0133, P0153 HO2S1

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


BANK 2

EC-O2S1B2-01



Refer to last page (Foldout page).

M21, E127
E112



TEC412M

DTC P0133, P0153 HO2S1

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
114	W	Heated oxygen sensor 1 (bank 2)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Engine is running.</div> <ul style="list-style-type: none"> └ Warm-up condition └ Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)

Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p>	
	
SEC690C	
▶ GO TO 2.	

2	RETIGHTEN HEATED OXYGEN SENSOR 1
<p>Loosen and retighten heated oxygen sensor 1. Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)</p>	
	
SEC888C	
▶ GO TO 3.	

Diagnostic Procedure (Cont'd)

3	CHECK FOR EXHAUST GAS LEAK
<p>1. Start engine and run it at idle. 2. Listen for an exhaust gas leak before three way catalyst (Manifold).</p>	
SEC502D	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Repair or replace.


4	CHECK FOR INTAKE AIR LEAK
<p>Listen for an intake air leak after the mass air flow sensor.</p>	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair or replace.

Diagnostic Procedure (Cont'd)

5 CLEAR THE SELF-LEARNING DATA

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".




SEF215Z

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?

 Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.



SEC688C

4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?


Yes or No

Yes	▶	Perform trouble diagnosis for DTC P0171, P0174 or DTC P0172, P0175 (Refer to EC-218 or EC-227).
No	▶	GO TO 6.

**DTC P0133, P0153
HO2S1**

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

6	CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF". 2. Disconnect heated oxygen sensor 1 harness connector.</p> <div style="text-align: center;">  <p>Heated oxygen sensor 1 (bank 2) harness connector</p> <p>Heated oxygen sensor 1 (bank 1) harness connector</p> </div> <p style="text-align: right;">SEC671D</p> <p>3. Disconnect ECM harness connector. 4. Check harness continuity between HO2S1 terminal 4 and ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

7	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between HO2S1 and ground 	
	▶ Repair open circuit or short to power in harness or connectors.

Diagnostic Procedure (Cont'd)

8 CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0133	115	1	1
P0153	114	1	2

MTBL1571

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0133	115	1	1
P0153	114	1	2

MTBL1572

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK	▶	GO TO 9.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

9 CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to EC-131, "Component Inspection".

OK or NG

OK	▶	GO TO 9.
NG	▶	Replace malfunctioning heated oxygen sensor 1.

10 CHECK MASS AIR FLOW SENSOR

Refer to EC-146, "Component Inspection".

OK or NG

OK	▶	GO TO 11.
NG	▶	Replace mass air flow sensor.

11 CHECK PCV VALVE

Refer to EC-482, "Component Inspection".

OK or NG

OK	▶	GO TO 12.
NG	▶	Replace PCV valve.

12 CHECK HEATED OXYGEN SENSOR 1

Refer to EC-183, "Component Inspection".


OK or NG

OK	▶	GO TO 13.
NG	▶	Replace malfunctioning heated oxygen sensor 1.

Component Inspection (Cont'd)

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.




⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Component Description


The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



On Board Diagnosis Logic

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134 (Bank 1)	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1
P0154 0154 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select “HO2S1 (B1) P0134” or “HO2S1 (B2) P0154” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
3. Touch “START”.
4. Let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 4.

5. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,550 - 2,500 rpm
Vehicle speed	More than 64 km/h (40 MPH)
B/FUEL SCHDL	5 - 16.7 msec
Selector lever	Suitable position

If “TESTING” is not displayed after 5 minutes, retry from step 2.

HO2S1 (B1) P0134	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0544E

HO2S1 (B1) P0134	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0545E

HO2S1 (B1) P0134	
COMPLETED	

SEC750C


6. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to EC-191, “Diagnostic Procedure”.

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

WITH GST



1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 to 0.4V.
4. If NG, go to EC-191, "Diagnostic Procedure".



Wiring Diagram


BANK 1

EC-O2S1B1-01



Refer to last page (Foldout page).

M21, E127
E112



**DTC P0134, P0154
HO2S1**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
115	W	Heated oxygen sensor 1 (bank 1)	Engine is running. — Warm-up condition — Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)



Wiring Diagram (Cont'd)

BANK 2

EC-O2S1B2-01



Refer to last page (Foldout page).



Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
114	W	Heated oxygen sensor 1 (bank 2)	<p>Engine is running.</p> <ul style="list-style-type: none"> └ Warm-up condition └ Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)

Diagnostic Procedure

1	INSPECTION START
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p>	
	
SEC690C	
▶ GO TO 2.	

2	CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Disconnect heated oxygen sensor 1 harness connector.</p>	
	
SEC888C	
<p>2. Disconnect ECM harness connector. 3. Check harness continuity between HO2S1 terminal 4 and ground. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

DTC P0134, P0154 HO2S1

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)


3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between HO2S1 and ground 	
▶ Repair open circuit or short to power in harness or connectors.	

4	CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT																																
<p>1. Check harness continuity between ECM terminal and HO2S1 terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0134</td> <td style="text-align: center;">115</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0154</td> <td style="text-align: center;">114</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL1573</p> <p>Continuity should exist.</p> <p>2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0134</td> <td style="text-align: center;">115</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0154</td> <td style="text-align: center;">114</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL1574</p> <p>Continuity should not exist.</p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border-bottom: 1px solid black;">OK</td> <td style="border-bottom: 1px solid black;">▶ GO TO 5.</td> </tr> <tr> <td style="border-bottom: 1px solid black;">NG</td> <td style="border-bottom: 1px solid black;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>		DTC	Terminals		Bank	ECM	Sensor	P0134	115	1	1	P0154	114	1	2	DTC	Terminals		Bank	ECM	Sensor	P0134	115	1	1	P0154	114	1	2	OK	▶ GO TO 5.	NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.
DTC	Terminals		Bank																														
	ECM	Sensor																															
P0134	115	1	1																														
P0154	114	1	2																														
DTC	Terminals		Bank																														
	ECM	Sensor																															
P0134	115	1	1																														
P0154	114	1	2																														
OK	▶ GO TO 5.																																
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.																																

5	CHECK HEATED OXYGEN SENSOR 1
Refer to EC-193, "Component Inspection".	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace malfunctioning heated oxygen sensor 1.

6	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	

Component Inspection (Cont'd)




⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Component Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.


This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH



On Board Diagnosis Logic

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138 (Bank 1)	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Heated oxygen sensor 2
P0158 0158 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

Ⓜ WITH CONSULT-II

1. Turn ignition switch “ON” and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch “OFF” and wait at least 10 seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for two minutes.
6. If 1st trip DTC is detected, go to EC-200, “Diagnostic Procedure”.



Ⓜ WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for two minutes.
5. Turn ignition switch “OFF” and wait at least 10 seconds.
6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
7. Let engine idle for two minutes.
8. Select “Mode 3” with GST.
9. If NG, go to EC-200, “Diagnostic Procedure”.
 - **When using GST, “DTC Confirmation Procedure” should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

Wiring Diagram


BANK 1

EC-O2S2B1-01



Refer to last page (Foldout page).

(M21, E127)
(E112)



**DTC P0138, P0158
HO2S2**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:



Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
124	W	Heated oxygen sensor 2 (bank 1)	<p>Engine is running.</p> <ul style="list-style-type: none">— Warm-up condition— Revving engine from idle to 3,000 rpm quickly after the following conditions are met.— Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load	0 - Approximately 1.0V

Wiring Diagram (Cont'd)


BANK 2

EC-O2S2B2-01



Refer to last page (Foldout page).

M21, E127
E112



DTC P0138, P0158 HO2S2

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
123	W	Heated oxygen sensor 2 (bank 2)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition — Revving engine from idle to 3,000 rpm quickly after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V

Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
SEC690C	
▶ GO TO 2.	

Diagnostic Procedure (Cont'd)

2	CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF". 2. Disconnect heated oxygen sensor 2 harness connector.</p> <div style="text-align: center;">  <p>Heated oxygen sensor 2 (bank 2) harness connector</p> <p>Heated oxygen sensor 2 (bank 1) harness connector</p> </div> <p style="text-align: right;">SEC669D</p> <p>3. Disconnect ECM harness connector. 4. Check harness continuity between HO2S2 terminal 4 and ground. Refer to Wiring Diagram. Continuity should exist. 5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between HO2S2 and ground 	
	▶ Repair open circuit or short to power in harness or connectors.

DTC P0138, P0158 HO2S2

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4	CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT																																			
<p>1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 20%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 20%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM</th> <th style="width: 20%;">Sensor</th> </tr> </thead> <tbody> <tr> <td>P0138</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0158</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL1575</p> <p>Continuity should exist.</p> <p>2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 20%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 20%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM</th> <th style="width: 20%;">Sensor</th> </tr> </thead> <tbody> <tr> <td>P0138</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0158</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL1576</p> <p>Continuity should not exist.</p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border: none;">OK</td> <td style="width: 5%; border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 5.</td> </tr> <tr> <td style="border: none;">NG</td> <td style="border: none; text-align: center;">▶</td> <td style="border: none;">Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>			DTC	Terminals		Bank	ECM	Sensor	P0138	124	1	1	P0158	123	1	2	DTC	Terminals		Bank	ECM	Sensor	P0138	124	1	1	P0158	123	1	2	OK	▶	GO TO 5.	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
DTC	Terminals			Bank																																
	ECM	Sensor																																		
P0138	124	1	1																																	
P0158	123	1	2																																	
DTC	Terminals		Bank																																	
	ECM	Sensor																																		
P0138	124	1	1																																	
P0158	123	1	2																																	
OK	▶	GO TO 5.																																		
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.																																		

5	CHECK HEATED OXYGEN SENSOR 2							
<p>Refer to EC-203, "Component Inspection".</p> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border: none;">OK</td> <td style="width: 5%; border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 6.</td> </tr> <tr> <td style="border: none;">NG</td> <td style="border: none; text-align: center;">▶</td> <td style="border: none;">Replace heated oxygen sensor 2.</td> </tr> </table>			OK	▶	GO TO 6.	NG	▶	Replace heated oxygen sensor 2.
OK	▶	GO TO 6.						
NG	▶	Replace heated oxygen sensor 2.						

6	CHECK INTERMITTENT INCIDENT				
<p>Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border: none;"></td> <td style="width: 5%; border: none; text-align: center;">▶</td> <td style="border: none;">INSPECTION END</td> </tr> </table>				▶	INSPECTION END
	▶	INSPECTION END			

Component Inspection

HEATED OXYGEN SENSOR 2


☎ With CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

6. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.

"HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:


- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

☒ Without CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.

Component Inspection (Cont'd)


- Set voltmeter probes between ECM terminal 124 [HO2S2 (B1) signal] or 123 [HO2S2 (B2) signal] and engine ground.



- Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage is above 0.68V at step 6, step 7 is not necessary.
- Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF.
The voltage should be below 0.48V at least once during this procedure.
- If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Component Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.


This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revvng engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revvng engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH



On Board Diagnosis Logic

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139 0139 (Bank 1)	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Heated oxygen sensor 2 Fuel pressure Injectors Intake air leaks
P0159 0159 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in “Procedure for COND1”.

WITH CONSULT-II

Procedure for COND1

For the best results, perform “DTC WORK SUPPORT” at a temperature of 0 to 30°C (32 to 86°F)

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle one minute.
5. Select “HO2S2 (B1) P0139” or “HO2S2 (B2) P0159” of “HO2S2” in “DTC WORK SUPPORT” mode with CONSULT-II.
6. Touch “START”.
7. Let engine idle for at least 30 seconds.
8. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If “COMPLETED” appears on CONSULT-II screen, go to step 2 in “Procedure for COND3”.
If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
9. When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 100°C
Selector level	Suitable position

<table border="1"> <tr><td align="center" colspan="2">HO2S2 (B1) P0139</td></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><td align="center" colspan="2">MONITOR</td></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><td align="center" colspan="2">HO2S2 (B1) P0139</td></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><td align="center" colspan="2">MONITOR</td></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><td align="center" colspan="2">HO2S2 (B1) P0139</td></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><td align="center" colspan="2">MONITOR</td></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P0139																																												
COND1:	OUT OF CONDITION																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P0139																																												
COND1:	TESTING																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P0139																																												
COND1:	COMPLETED																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											

PBIB0552E

NOTE:

- If “TESTING” is not displayed after 5 minutes, retry from step 2 in “Procedure for COND1”.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before “Procedure for COND2” is conducted, it is unnecessary to conduct step 1 in “Procedure for COND2”.

DTC Confirmation Procedure (Cont'd)

Procedure for COND2

1. While driving, release accelerator pedal completely with "OD" OFF from the above condition [step 9] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED". (It will take approximately 4 seconds.)

NOTE:

If "COMPLETED" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

Procedure for COND3




1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to EC-212, "Diagnostic Procedure".
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II.
 - c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
 - d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to "Procedure for COND 1" step 3.

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 124 [HO2S2 (B1) signal] or 123 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
A change of voltage should be more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage.
Or check the voltage when coasting from 80 km/h (50 MPH)



Overall Function Check (Cont'd)

in "D" position with "OD" OFF.



A change of voltage should be more than 0.06V for 1 second during this procedure.

8. If NG, go to EC-212, "Diagnostic Procedure".

Wiring Diagram


BANK 1

EC-O2S2B1-01



Refer to last page (Foldout page).

(M21), (E127)
(E112)



**DTC P0139, P0159
HO2S2**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:



Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
124	W	Heated oxygen sensor 2 (bank 1)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition — Revving engine from idle to 3,000 rpm quickly after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V

Wiring Diagram (Cont'd)


BANK 2

EC-O2S2B2-01



Refer to last page (Foldout page).

M21, E127
E112



**DTC P0139, P0159
HO2S2**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
123	W	Heated oxygen sensor 2 (bank 2)	<p>Engine is running.</p> <ul style="list-style-type: none"> — Warm-up condition — Revving engine from idle to 3,000 rpm quickly after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V

Diagnostic Procedure


1	RETIGHTEN GROUND SCREWS
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p>	
	
SEC690C	
▶ GO TO 2.	

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".




SEF215Z

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.



SEC688C

5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?


Yes or No

Yes	▶	Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-218 or EC-227.
No	▶	GO TO 3.

DTC P0139, P0159 HO2S2

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT							
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect heated oxygen sensor 2 harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Heated oxygen sensor 2 (bank 2) harness connector</p> <p style="margin-left: 100px;">Heated oxygen sensor 2 (bank 1) harness connector</p> </div> <p style="text-align: right;">SEC669D</p> <p>3. Disconnect ECM harness connector.</p> <p>4. Check harness continuity between HO2S2 terminal 4 and ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>								
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border-right: 1px solid black; padding: 2px;">OK</td> <td style="width: 5%; text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">GO TO 5.</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">NG</td> <td style="text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">GO TO 4.</td> </tr> </table>			OK	▶	GO TO 5.	NG	▶	GO TO 4.
OK	▶	GO TO 5.						
NG	▶	GO TO 4.						

4	DETECT MALFUNCTIONING PART				
<p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between HO2S2 and ground 					
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border-right: 1px solid black;"></td> <td style="width: 5%; text-align: center;">▶</td> <td>Repair open circuit or short to power in harness or connectors.</td> </tr> </table>				▶	Repair open circuit or short to power in harness or connectors.
	▶	Repair open circuit or short to power in harness or connectors.			

DTC P0139, P0159 HO2S2

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT																																		
<p>1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 20%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 20%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM</th> <th style="width: 20%;">Sensor</th> </tr> </thead> <tbody> <tr> <td>P0139</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0159</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL1577</p> <p>Continuity should exist.</p> <p>2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 20%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 20%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM</th> <th style="width: 20%;">Sensor</th> </tr> </thead> <tbody> <tr> <td>P0139</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0159</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL1578</p> <p>Continuity should not exist.</p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 6.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>		DTC	Terminals		Bank	ECM	Sensor	P0139	124	1	1	P0159	123	1	2	DTC	Terminals		Bank	ECM	Sensor	P0139	124	1	1	P0159	123	1	2	OK	▶	GO TO 6.	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
DTC	Terminals		Bank																																
	ECM	Sensor																																	
P0139	124	1	1																																
P0159	123	1	2																																
DTC	Terminals		Bank																																
	ECM	Sensor																																	
P0139	124	1	1																																
P0159	123	1	2																																
OK	▶	GO TO 6.																																	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.																																	

6	CHECK HEATED OXYGEN SENSOR 2	
Refer to EC-215, "Component Inspection".		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Replace heated oxygen sensor 2.

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	

Component Inspection

HEATED OXYGEN SENSOR 2

④ With CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.


Component Inspection (Cont'd)

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

5. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

6. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
"HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 124 [HO2S2 (B1) signal] or 123 [HO2S2 (B2) signal] and engine ground.

Component Inspection (Cont'd)



6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 6, step 7 is not necessary.

7. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF.

The voltage should be below 0.48V at least once during this procedure.

8. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

DTC P0171, P0174 FUEL INJECTION

SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

On Board Diagnosis Logic

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171 0171 (Bank 1)	Fuel injection system too lean	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> Intake air leaks Heated oxygen sensor 1 Injectors Exhaust gas leaks Incorrect fuel pressure Lack of fuel Mass air flow sensor Incorrect PCV hose connection
P0174 0174 (Bank 2)			


DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch “OFF” and wait at least 10 seconds.
- Turn ignition switch “ON” and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.



- Clear the self-learning control coefficient by touching “CLEAR”.
- Select “DATA MONITOR” mode with CONSULT-II.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to EC-222, “Diagnostic Procedure”.
- If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
- Crank engine while depressing accelerator pedal. If engine starts, go to EC-222, “Diagnostic Procedure”. If engine does not start, check exhaust and intake air leak visually.

EC-218

DTC P0171, P0174 FUEL INJECTION


SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.



3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to EC-222, "Diagnostic Procedure".
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to EC-222, "Diagnostic Procedure". If engine does not start, check exhaust and intake air leak visually.




DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

BANK 1

EC-FUELB1-01










DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

BANK 2

EC-FUELB2-01





Refer to last page (Foldout page).

M21, E127

M2

E112



DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure

1	CHECK EXHAUST GAS LEAK	
<p>1. Start engine and run it at idle. 2. Listen for an exhaust gas leak before three way catalyst (manifold).</p>		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair or replace.


2	CHECK FOR INTAKE AIR LEAK	
<p>1. Listen for an intake air leak after the mass air flow sensor. 2. Check PCV hose connection.</p>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace.

**DTC P0171, P0174 FUEL INJECTION
SYSTEM FUNCTION** TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3 CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect corresponding heated oxygen sensor 1 (HO2S1) harness connector.



SEC671D

3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0171	115	1	1
P0174	114	1	2

MTBL1579

Continuity should exist.

5. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0171	115	1	1
P0174	114	1	2

MTBL1580

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

4 CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to EC-34, "FUEL PRESSURE RELEASE".
2. Install fuel pressure gauge and check fuel pressure. Refer to EC-34, "FUEL PRESSURE CHECK".
At idling: 245 kPa (2.45 bar, 2.5 kg/cm², 36 psi)

OK or NG

OK	▶	GO TO 6.
NG	▶	GO TO 5.

DTC P0171, P0174 FUEL INJECTION

SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Fuel pump and circuit (Refer to EC-459, "FUEL PUMP CIRCUIT".)● Fuel pressure regulator (Refer to EC-34, "FUEL PRESSURE CHECK".)● Fuel lines (Refer to MA section.)● Fuel filter for clogging	
	▶ Repair or replace.
6	CHECK MASS AIR FLOW SENSOR
Ⓜ With CONSULT-II <ol style="list-style-type: none">1. Install all removed parts.2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II. 3.0 - 9.0 g-m/sec: at idling 10.0 - 25.0 g-m/sec: at 2,500 rpm	
Ⓜ With GST <ol style="list-style-type: none">1. Install all removed parts.2. Check mass air flow sensor signal in MODE 1 with GST. 3.0 - 9.0 g-m/sec: at idling 10.0 - 25.0 g-m/sec: at 2,500 rpm	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-140, "DTC P0102, P0103 MAF SENSOR".

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

7 CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

3. Make sure that each circuit produces a momentary engine speed drop.

Without CONSULT-II

1. Start engine.



MEC703B

2. Listen to each injector operating sound.
Clicking noise should be heard.

OK or NG


OK	▶	GO TO 8.
NG	▶	Perform trouble diagnosis for EC-453, "INJECTOR CIRCUIT".

DTC P0171, P0174 FUEL INJECTION

SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

8	CHECK INJECTOR
<p>1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.</p> <p>2. Turn ignition switch "OFF".</p> <p>3. Disconnect injector harness connectors on bank 2 (for DTC P0171), bank 1 (for DTC P0174).</p> <p>4. Remove injector gallery assembly. Refer to EM section. Keep fuel hose and all injectors connected to injector gallery. The injector harness connectors on bank 1 (for DTC P0171), bank 2 (for DTC P0174) should remain connected.</p> <p>5. Disconnect all ignition coil harness connectors.</p> <p>6. Prepare pans or saucers under each injector.</p> <p>7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.</p>	
	
<p>Fuel should be sprayed evenly for each injector.</p> <p style="text-align: right;">SEF595Q</p>	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace injectors from which fuel does not spray out. Always replace O-ring with new ones.

9	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
	▶ INSPECTION END

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

On Board Diagnosis Logic

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172 0172 (Bank 1)	Fuel injection system too rich	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor
P0175 0175 (Bank 2)			


DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.




4. Clear the self-learning control coefficient by touching “CLEAR”.
5. Select “DATA MONITOR” mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172, P0175 should be detected at this stage, if a malfunction exists. If so, go to EC-231, “Diagnostic Procedure”.
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal. If engine starts, go to EC-231, “Diagnostic Procedure”. If engine does not start, remove ignition plugs and check for fouling, etc.

DTC P0172, P0175 FUEL INJECTION SYSTEM

FUNCTION

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)



WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0172 or P0175 should be detected at this stage, if a malfunction exists. If so, go to EC-231, "Diagnostic Procedure".
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to EC-231, "Diagnostic Procedure". If engine does not start, check exhaust and intake air leak visually.




DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)


Wiring Diagram

BANK 1

EC-FUELB1-01



Refer to last page (Foldout page).
M21, E127
M2
E112



DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure

1	CHECK EXHAUST GAS LEAK	
<p>1. Start engine and run it at idle. 2. Listen for an exhaust gas leak before three way catalyst (manifold).</p>		
SEC502D		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair or replace.

2	CHECK FOR INTAKE AIR LEAK	
Listen for an intake air leak after the mass air flow sensor.		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace.

DTC P0172, P0175 FUEL INJECTION SYSTEM


FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3 CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect corresponding heated oxygen sensor 1 (HO2S1) harness connector.



SEC671D

3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0172	115	1	1
P0175	114	1	2

MTBL1581

Continuity should exist.

5. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0172	115	1	1
P0175	114	1	2

MTBL1582

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

4 CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to EC-34, "FUEL PRESSURE RELEASE".
2. Install fuel pressure gauge and check fuel pressure. Refer to EC-34, "FUEL PRESSURE CHECK".
At idling: 245 kPa (2.45 bar, 2.5 kg/cm², 36 psi)

OK or NG

OK	▶	GO TO 6.
NG	▶	GO TO 5.

5 DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to EC-459, "FUEL PUMP CIRCUIT".)
- Fuel pressure regulator (Refer to EC-34, "FUEL PRESSURE CHECK".)

▶ Repair or replace.


DTC P0172, P0175 FUEL INJECTION SYSTEM

FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

6	CHECK MASS AIR FLOW SENSOR	
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Install all removed parts. 2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II. 3.0 - 9.0 g-m/sec: at idling 10.0 - 25.0 g-m/sec: at 2,500 rpm <p> With GST</p> <ol style="list-style-type: none"> 1. Install all removed parts. 2. Check mass air flow sensor signal in MODE 1 with GST. 3.0 - 9.0 g-m/sec: at idling 10.0 - 25.0 g-m/sec: at 2,500 rpm <p style="text-align: center;">OK or NG</p>		
OK		▶ GO TO 7.
NG		▶ Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-140, "DTC P0102, P0103 MAF SENSOR".

7	CHECK FUNCTION OF INJECTORS																					
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II. <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse; width: 150px; margin: auto;"> <thead> <tr> <th colspan="2" style="text-align: center;">ACTIVE TEST</th> </tr> <tr> <th style="text-align: center;">POWER BALANCE</th> <th style="text-align: center;">MONITOR</th> </tr> <tr> <th style="text-align: center;">ENG SPEED</th> <th style="text-align: center;">XXX rpm</th> </tr> <tr> <th style="text-align: center;">MAS A/F SE-B1</th> <th style="text-align: center;">XXX V</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table> </div> <p style="text-align: right; margin-right: 20px;">PBIB0133E</p> <ol style="list-style-type: none"> 3. Make sure that each circuit produces a momentary engine speed drop. <p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Listen to each injector operating sound. <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: center;">Clicking noise should be heard.</p> <p style="text-align: center;">OK or NG</p> <p style="text-align: right; margin-right: 20px;">MEC703B</p>			ACTIVE TEST		POWER BALANCE	MONITOR	ENG SPEED	XXX rpm	MAS A/F SE-B1	XXX V												
ACTIVE TEST																						
POWER BALANCE	MONITOR																					
ENG SPEED	XXX rpm																					
MAS A/F SE-B1	XXX V																					
OK		▶ GO TO 8.																				
NG		▶ Perform trouble diagnosis for EC-453, "INJECTOR CIRCUIT".																				

DTC P0172, P0175 FUEL INJECTION SYSTEM

FUNCTION


TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

8	CHECK INJECTOR
<p>1. Remove injector assembly. Refer to EM section. Keep fuel hose and all injectors connected to injector gallery.</p> <p>2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.</p> <p>3. Disconnect injector harness connectors bank 2 (for DTC P0172), bank 1 (for P0175). The injector harness connectors on bank 1 (for P0172), bank 2 (for P0175) should remain connected.</p> <p>4. Disconnect all ignition coil harness connectors.</p> <p>5. Prepare pans or saucers under each injectors.</p> <p>6. Crank engine for about 3 seconds. Make sure fuel does not drip from injector.</p> <p style="text-align: center;">OK or NG</p>	
OK (Does not drip.)	▶ GO TO 9.
NG (Drips.)	▶ Replace the injectors from which fuel is dripping. Always replace O-ring with new one.
9	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
	▶ INSPECTION END

DTC P0222, P0223 TP SENSOR

TB48DE A/T (WITH EURO-OBD)



Component Description

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1 THRTL SEN2*	● Ignition switch: ON (Engine stopped) ● Shift lever: D Accelerator pedal: Fully released	More than 0.5V
	Accelerator pedal: Fully depressed	Less than 1.5V

*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor 1 circuit is open or shorted.) ● Electric throttle control actuator (TP sensor 1)
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

DTC P0222, P0223 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to EC-238, "Diagnostic Procedure".

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0222, P0223 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-TPS1-01

: Detectable line for DTC
 : Non-detectable line for DTC



DTC P0222, P0223 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
89	B	Sensor ground (Throttle position sensor)	Engine is running. └ Warm-up condition └ Idle speed	Approximately 0V
98	R/L	Throttle position sensor 2	Ignition switch "ON" └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released	Less than 4.75V
			Ignition switch "ON" └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed	More than 0.36V
103	Y	Sensor power supply (Throttle position sensor)	Ignition switch "ON"	Approximately 5V
108	L	Throttle position sensor 1	Ignition switch "ON" └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released	More than 0.36V
			Ignition switch "ON" └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed	Less than 4.75V



Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
SEC690C	
▶ GO TO 2.	

DTC P0222, P0223 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2	CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT
<p>1. Disconnect electric throttle control actuator harness connector.</p> <div style="text-align: center;"> <p>View with intake air duct removed</p>  <p>Electric throttle control actuator</p> <p>Accelerator pedal position sensor harness connector</p> <p>Throttle position sensor and throttle control motor harness connector</p> </div> <p style="text-align: right;">SEC182D</p> <p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> </div> <p style="text-align: right;">PBIB0082E</p>	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between electric throttle control actuator terminal 5 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Check harness continuity between ECM terminal 108 and electric throttle control actuator terminal 4. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0222, P0223 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK THROTTLE POSITION SENSOR
Refer to EC-240, "Component Inspection".	
OK or NG	
OK	▶ GO TO 7.
NG	▶ GO TO 6.


6	REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR
1. Replace the electric throttle control actuator. 2. Perform EC-31, "Accelerator Pedal Released Position Learning". 3. Perform EC-31, "Throttle Valve Closed Position Learning". 4. Perform EC-31, "Idle Air Volume Learning".	
▶ INSPECTION END	

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	

Component Inspection

THROTTLE POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Perform EC-31, "Throttle Valve Closed Position Learning".
3. Turn ignition switch "ON".
4. Set selector lever to "D" position.



5. Check voltage between ECM terminals 108 (TP sensor 1 signal), 98 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
108 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
98 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform EC-31, "Accelerator Pedal Released Position Learning".
8. Perform EC-31, "Throttle Valve Closed Position Learning".
9. Perform EC-31, "Idle Air Volume Learning".

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE TB48DE A/T (WITH EURO-OBD)

On Board Diagnosis Logic

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the crankshaft position (CKP) sensor (OBD) signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (OBD)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

1. One Trip Detection Logic (Three Way Catalyst Damage)

On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MI will blink.

When a misfire condition occurs, the ECM monitors the CKP sensor (OBD) signal every 200 engine revolutions for a change.

When the misfire condition decreases to a level that will not damage the TWC, the MI will turn off.

If another misfire condition occurs that can damage the TWC on a second trip, the MI will blink.

When the misfire condition decreases to a level that will not damage the TWC, the MI will remain on.

If another misfire condition occurs that can damage the TWC, the MI will begin to blink again.

2. Two Trip Detection Logic (Exhaust quality deterioration)

For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MI will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.

A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300 0300	Multiple cylinder misfire detected	Multiple cylinder misfire.	<ul style="list-style-type: none"> ● Improper spark plug ● Insufficient compression ● Incorrect fuel pressure ● The injector circuit is open or shorted ● Fuel injectors ● Intake air leak ● The ignition signal circuit is open or shorted ● Lack of fuel ● Drive plate or flywheel ● Heated oxygen sensor 1 ● Incorrect PCV hose connection
P0301 0301	No.1 cylinder misfire detected	No. 1 cylinder misfires.	
P0302 0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	
P0303 0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	
P0304 0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	
P0305 0305	No. 5 cylinder misfire detected	No. 5 cylinder misfires.	
P0306 0306	No. 6 cylinder misfire detected	No. 6 cylinder misfires.	

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6

CYLINDER MISFIRE TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

WITH CONSULT-II

1. Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.

Hold the accelerator pedal as steady as possible.

NOTE:

Refer to the freeze frame data for the test driving conditions.

5. If 1st trip DTC is detected, go to EC-242, "Diagnostic Procedure".

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec


PBIB0164E


Diagnostic Procedure

1	CHECK FOR INTAKE AIR LEAK AND PCV HOSE
1. Start engine and run it at idle speed. 2. Listen for the sound of the intake air leak. 3. Check PCV hose connection.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace.
2	CHECK FOR EXHAUST SYSTEM CLOGGING
Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace.

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE TB48DE A/T (WITH EURO-OBD)


Diagnostic Procedure (Cont'd)

3	PERFORM POWER BALANCE TEST																										
<p><input checked="" type="checkbox"/> With CONSULT-II</p> <p>1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.</p> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse; width: 150px; margin: auto;"> <tr><th colspan="2" style="text-align: center;">ACTIVE TEST</th></tr> <tr><td style="text-align: center;">POWER BALANCE</td><td style="width: 50px;"></td></tr> <tr><th colspan="2" style="text-align: center;">MONITOR</th></tr> <tr><td style="text-align: center;">ENG SPEED</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">MAS A/F SE-B1</td><td style="text-align: center;">XXX V</td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;"> </td></tr> </table> </div> <p style="text-align: right; margin-right: 20px;">PBIB0133E</p> <p>2. Is there any cylinder which does not produce a momentary engine speed drop?</p> <p><input checked="" type="checkbox"/> Without CONSULT-II</p> <p>When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">SEC793C</p> <p style="text-align: center;">Yes or No</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border: none;">Yes</td> <td style="width: 5%; border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 4.</td> </tr> <tr> <td style="border: none;">No</td> <td style="border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 7.</td> </tr> </table>		ACTIVE TEST		POWER BALANCE		MONITOR		ENG SPEED	XXX rpm	MAS A/F SE-B1	XXX V											Yes	▶	GO TO 4.	No	▶	GO TO 7.
ACTIVE TEST																											
POWER BALANCE																											
MONITOR																											
ENG SPEED	XXX rpm																										
MAS A/F SE-B1	XXX V																										
Yes	▶	GO TO 4.																									
No	▶	GO TO 7.																									


4	CHECK INJECTOR						
<p>Does each injector make an operating sound at idle?</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">MEC703B</p> <p style="text-align: center;">Yes or No</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; border: none;">Yes</td> <td style="width: 5%; border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 5.</td> </tr> <tr> <td style="border: none;">No</td> <td style="border: none; text-align: center;">▶</td> <td style="border: none;">Check injector(s) and circuit(s). Refer to EC-453, "INJECTOR CIRCUIT".</td> </tr> </table>		Yes	▶	GO TO 5.	No	▶	Check injector(s) and circuit(s). Refer to EC-453, "INJECTOR CIRCUIT".
Yes	▶	GO TO 5.					
No	▶	Check injector(s) and circuit(s). Refer to EC-453, "INJECTOR CIRCUIT".					

**DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6
CYLINDER MISFIRE** TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK IGNITION SPARK	
<p>1. Disconnect ignition coil assembly from rocker cover. 2. Connect a known good spark plug to the ignition coil assembly. 3. Place end of spark plug against a suitable ground and crank engine. 4. Check for spark.</p>		
		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Check ignition coil, power transistor and their circuits. Refer to EC-428, "IGNITION SIGNAL".

SEF575Q

6	CHECK SPARK PLUGS	
Remove the spark plugs and check for fouling, etc.		
		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to MA section.

SEF156I

7	CHECK COMPRESSION PRESSURE	
<p>Check compression pressure. Refer to EM section. Standard: 1,226 kPa (12.26 bar, 12.5 kg/cm², 178 psi)/200 rpm Minimum: 1,030 kPa (10.30 bar, 10.5 kg/cm², 149 psi)/200 rpm Difference between each cylinder: 98 kPa (0.98 bar, 1.0 kg/cm², 14 psi)/200 rpm OK or NG</p>		
OK	▶	GO TO 8.
NG	▶	Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6

CYLINDER MISFIRE TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

8	CHECK FUEL PRESSURE
1. Install all removed parts. 2. Release fuel pressure to zero. Refer to EC-34, "FUEL PRESSURE RELEASE". 3. Install fuel pressure gauge and check fuel pressure. Refer to EC-34, "FUEL PRESSURE CHECK". At idle: Approx. 245 kPa (2.45 bar, 2.5 kg/cm², 36 psi) OK or NG	
OK	▶ GO TO 9.
NG	▶ Follow the construction of "FUEL PRESSURE CHECK".

9	CHECK IGNITION TIMING						
Check the following items. Refer to EC-66, "Basic Inspection".							
<table border="1"><thead><tr><th>Items</th><th>Specifications</th></tr></thead><tbody><tr><td>Target idle speed</td><td>675 ± 50 rpm (in "P" or "N" position)</td></tr><tr><td>Ignition timing</td><td>10° ± 5° BTDC (in "P" or "N" position)</td></tr></tbody></table>		Items	Specifications	Target idle speed	675 ± 50 rpm (in "P" or "N" position)	Ignition timing	10° ± 5° BTDC (in "P" or "N" position)
Items	Specifications						
Target idle speed	675 ± 50 rpm (in "P" or "N" position)						
Ignition timing	10° ± 5° BTDC (in "P" or "N" position)						
OK or NG MTBL1583							
OK	▶ GO TO 10.						
NG	▶ Follow the "Basic Inspection".						

10	CHECK HEATED OXYGEN SENSOR 1
Refer to EC-170, "Component Inspection". OK or NG	
OK	▶ GO TO 12.
NG	▶ GO TO 11.

11	CHECK MASS AIR FLOW SENSOR
 With CONSULT-II Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II. 3.0 - 9.0 g-m/sec: at idling 10.0 - 25.0 g-m/sec: at 2,500 rpm	
 With GST Check mass air flow sensor signal in MODE 1 with GST. 3.0 - 9.0 g-m/sec: at idling 10.0 - 25.0 g-m/sec: at 2,500 rpm OK or NG	
OK	▶ GO TO 12.
NG	▶ Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-140, "DTC P0102, P0103 MAF SENSOR".


12	CHECK SYMPTOM MATRIX CHART
Check items on the rough idle symptom in EC-71, "Symptom Matrix Chart". OK or NG	
OK	▶ GO TO 13.
NG	▶ Repair or replace.

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6
CYLINDER MISFIRE **TB48DE A/T (WITH EURO-OBD)**

Diagnostic Procedure (Cont'd)

13	ERASE THE 1ST TRIP DTC
Some tests may cause a 1st trip DTC to be set. Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".	
	▶ GO TO 14.

14	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
	▶ INSPECTION END



Component Description

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

On Board Diagnosis Logic

The MI will not light up for these self-diagnoses.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0327 0327 (bank 1) P0332 0332 (bank 2)	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328 0328 (bank 1) P0333 0333 (bank 2)	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	


DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.



WITH CONSULT-II



1. Turn ignition switch “ON” and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to EC-249, “Diagnostic Procedure”.

WITH GST

Follow the procedure “WITH CONSULT-II” above.

Wiring Diagram

EC-KS-01



**DTC P0327, P0328, P0332,
P0333 KS**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
125	W	Knock sensor (bank 1)	Engine is running. └ Idle speed	Approximately 2.5V
126	W	Knock sensor (bank 2)	Engine is running. └ Idle speed	Approximately 2.5V

Diagnostic Procedure

1	CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-I
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check resistance between ECM terminal 125 (bank 1) or 126 (bank 2) and engine ground. Refer to Wiring Diagram. NOTE: It is necessary to use an ohmmeter which can measure more than 10 MΩ. Resistance: Approximately 530 - 590 kΩ [at 20°C (68°F)] 4. Also check harness for short to ground and short to power.</p> <p align="center">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 2.


2	CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-II
<p>1. Disconnect knock sensor harness connector.</p> <div style="text-align: center;">  <p>Knock sensor (B2) Knock sensor (B1)</p> </div> <p align="right">SEC889C</p> <p>2. Check harness continuity between ECM terminal 125 (bank 1) or 126 (bank 2) and knock sensor terminal 1. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power.</p> <p align="center">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

**DTC P0327, P0328, P0332,
P0333 KS**


TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	CHECK KNOCK SENSOR
Refer to EC-250, "Component Inspection".	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace knock sensor.

4	RETIGHTEN GROUND SCREWS
Loosen and retighten engine ground screws.	
	
▶ GO TO 5.	

5	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	



Component Inspection

KNOCK SENSOR

Check resistance between knock sensor terminal 1 and ground.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.


Resistance: Approximately 530 - 590 kΩ [at 20°C (68°F)]

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.

DTC P0335 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)



Component Description

The crankshaft position sensor (OBD) is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil. When the engine is running, the high and low parts of the teeth cause the gap with the sensor change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> • Tachometer: Connect • Run engine and compare CONSULT-II value with the tachometer indication. 	Almost the same speed as the tachometer indication.

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor (OBD) circuit	<ul style="list-style-type: none"> • The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. 	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Crankshaft position sensor (OBD)

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON".

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 15 seconds at idle speed.
3. If 1st trip DTC is detected, go to EC-254, "Diagnostic Procedure".

**DTC P0335 CKP SENSOR
(OBD)**

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

 **WITH GST**



Follow the procedure "WITH CONSULT-II" above.

DTC P0335 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-CKPS-01



Refer to last page (Foldout page).

(M21), (E127)

TEC344M

DTC P0335 CKP SENSOR (OBD)



TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
89	B	Crankshaft position sensor (OBD) ground	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Idle speed	Approximately 0V
111	W	Crankshaft position sensor (OBD)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Warm-up condition. └ Idle speed	Approximately 1 - 2V★ <div style="text-align: center;">  <small>10.0 V/Div 1 ms/Div</small> </div> <p style="text-align: right; margin-top: 5px;">SEC748D</p>
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Engine speed is 2,000 rpm	Approximately 3 - 4V★ <div style="text-align: center;">  <small>10.0 V/Div 1 ms/Div</small> </div> <p style="text-align: right; margin-top: 5px;">SEC749D</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure


1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
▶ GO TO 2.	

SEC690C

DTC P0335 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2	CHECK CKP SENSOR (OBD) POWER SUPPLY CIRCUIT
<p>1. Disconnect crankshaft position (CKP) sensor (OBD) harness connector and ECM harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEC732D</p> <p>2. Check harness continuity between CKP sensor (OBD) terminal 1 and ECM terminal 111. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power. OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E201, E70 ● Harness connectors E127, M21 ● Harness connectors M51, F6 ● Harness for open or short between crankshaft position sensor (OBD) and ECM 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK CKP SENSOR (OBD) GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Reconnect ECM harness connector.</p> <p>2. Check harness continuity between CKP sensor (OBD) terminal 2 and ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for and short to ground and short to power. OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E202, E69 ● Harness connectors E127, M21 ● Harness connectors M51, F6 ● Harness for open or short between crankshaft position sensor (OBD) and ECM 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0335 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)



Diagnostic Procedure (Cont'd)

6	CHECK SHIELD CIRCUIT
1. Disconnect harness connectors E201, E70. 2. Check harness continuity between harness connector E70 terminal 10 and ground. Continuity should exist. 3. Also check harness for short to power. 4. Then reconnect harness connectors.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

7	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Harness connectors E127, M21● Harness connectors M51, F6● Joint connector-7● Harness for open or short between harness connector E70 and ground	
	▶ Repair open circuit or short to power in harness or connectors.

8	CHECK CRANKSHAFT POSITION SENSOR (OBD)
Refer to EC-256, "Component Inspection".	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace crankshaft position sensor (OBD).

9	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
	▶ INSPECTION END





Component Inspection

CRANKSHAFT POSITION SENSOR (OBD)

1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor (OBD) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.
5. Check resistance as shown in the figure.
Resistance: Approximately 512 - 632Ω [at 20°C (68°F)]
6. If NG, replace crankshaft position sensor (OBD).

DTC P0340 CAMSHAFT POSITION (CMP) SENSOR

TB48DE A/T (WITH EURO-OBD)



Component Description

The camshaft position sensor (CMPS) is a basic component of the ECM. It monitors engine speed and piston position. It sends signals to the ECM to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 6 slits for 120° signal. Light Emitting Diodes (LED) and photo diodes are built into the wave-forming circuit.

When the rotor plate passes between the LED and the photo diode, the following happens:



Slits in the rotor plate continually cut the transmitted light to the photo diode from the LED. This generates rough-shaped pulses converted into on-off pulses by the wave forming circuit sent to the ECM.

ECM Terminals and Reference Value

Specification data are reference values, and are measured between each terminal and ground.

CAUTION:



Do not use ECM ground terminals when measuring voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals such as the body ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
63	B/W	Camshaft position sensor (POS signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> (Warmed-up condition) └ Idle speed	1.0 - 4.0V*1  SEC750D
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> (Warmed-up condition) └ Engine speed is 2,000 rpm.	1.0 - 4.0V*1  SEC751D

DTC P0340 CAMSHAFT POSITION (CMP) SENSOR

TB48DE A/T (WITH EURO-OBD)

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
83 84	L	Camshaft position sensor (REF signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> (Warmed-up condition) └ Idle speed	Approximately 0.3 - 0.6V*1  SEC746D
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> (Warmed-up condition) └ Engine speed is 2,000 rpm.	Approximately 0.3 - 0.6V*1  SEC747D

*1: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

On Board Diagnosis Logic

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0340 0340	A) Either 1° or 120° signal is not sent to ECM for the first few seconds during engine cranking. B) Either 1° or 120° signal is not sent to ECM during engine running. C) Either 1° or 120° signal is not in the normal pattern during engine running.	<ul style="list-style-type: none"> ● Harness or connectors (The camshaft position sensor circuit is open or shorted.) ● Camshaft position sensor ● Starter motor (Refer to EL section.) ● Starting system circuit (Refer to EL section.) ● Dead (Weak) battery

DTC Confirmation Procedure

Perform "Procedure for malfunction A" first. If DTC cannot be confirmed, perform "Procedure for malfunction B and C".

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

DTC P0340 CAMSHAFT POSITION

(CMP) SENSOR

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

PROCEDURE FOR MALFUNCTION A

DATA MONITOR	
MONITOR	NO DTC
COOLAN TEMP/S	XXX °C

SEF013Y

☑ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Crank engine at least 2 seconds.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) If DTC is detected, go to "Diagnostic Procedure", EC-261.

☒ Without CONSULT-II

- 1) Crank engine for at least 2 seconds.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-261.

PROCEDURE FOR MALFUNCTION B AND C

☑ With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If DTC is detected, go to "DIAGNOSTIC PROCEDURE", EC-261.

☒ Without CONSULT-II




- 1) Start engine and run it for at least 2 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-261.

DTC P0340 CAMSHAFT POSITION (CMP) SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram





EC-CMPS-01



DTC P0340 CAMSHAFT POSITION (CMP) SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure





	CMPS terminal	ECM terminal	Continuity
120° signal (REF signal)	①	⑧3, ⑧4	Yes
1° signal (POS signal)	②	⑧3	Yes

Refer to Wiring Diagram.
If OK, check harness for short to ground and short to power.

DTC P0340 CAMSHAFT POSITION (CMP) SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)



Component Inspection

CAMSHAFT POSITION SENSOR

1. Start engine and warm it up to the normal operating temperature.
2. Check voltage between the following ECM terminals and ground with DC range.

	ECM terminal	Reference illustration
1° signal (POS signal)	63	A
120° signal (REF signal)	83 , 84	B





CAUTION:

Do not use ECM ground terminals when measuring voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals such as the body ground.

DTC P0340 CAMSHAFT POSITION (CMP) SENSOR

TB48DE A/T (WITH EURO-OBD)

Component Inspection (Cont'd)


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
63	B/W	Camshaft position sensor (POS signal)	<p>Engine is running. (Warmed-up condition)</p> <p>└ Idle speed</p>	<p>1.0 - 4.0V*1</p>  <p style="text-align: right;">SEC750D</p>
			<p>Engine is running. (Warmed-up condition)</p> <p>└ Engine speed is 2,000 rpm.</p>	<p>1.0 - 4.0V*1</p>  <p style="text-align: right;">SEC751D</p>
83 84	L	Camshaft position sensor (REF signal)	<p>Engine is running. (Warmed-up condition)</p> <p>└ Idle speed</p>	<p>Approximately 0.3 - 0.6V*1</p>  <p style="text-align: right;">SEC746D</p>
			<p>Engine is running. (Warmed-up condition)</p> <p>└ Engine speed is 2,000 rpm.</p>	<p>Approximately 0.3 - 0.6V*1</p>  <p style="text-align: right;">SEC747D</p>

*1: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

If NG, replace camshaft position sensor.

DTC P0420, P0430 THREE WAY CATALYST FUNCTION

TB48DE A/T (WITH EURO-OBD)



On Board Diagnosis Logic

The ECM monitors the switching frequency ratio of heated oxygen sensors 1 and 2.

A three way catalyst (manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst (manifold) malfunction is diagnosed.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 0420 (Bank 1)	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> • Three way catalyst (manifold) does not operate properly. • Three way catalyst (manifold) does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> • Three way catalyst (manifold) • Exhaust tube • Intake air leaks • Fuel injectors • Fuel injector leaks • Spark plug • Improper ignition timing
P0430 0430 (Bank 2)			

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION:

- Open engine hood before conducting the following procedure.
 - Do not hold engine speed for more than the specified minutes below.
1. Start engine and warm it up to the normal operating temperature.
 2. Turn ignition switch “OFF” and wait at least 10 seconds.
 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 4. Let engine idle for one minute.
 5. Select “DTC & SRT CONFIRMATION” then “SRT WORK SUPPORT” mode with CONSULT-II.
 6. Rev engine up to 2,500 to 3,500 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely.
If “INCMP” of “CATALYST” changed to “COMPLT”, go to step 9
 7. Wait 5 seconds at idle.

SRT WORK SUPPORT	
CATALYST	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0566E

DTC P0420, P0430 THREE WAY CATALYST

FUNCTION

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

SRT WORK SUPPORT	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	INCMP

MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0567E

DATA MONITOR	
MONITOR	NO DTC
COOLANTEMP/S	XXX °C

SEF013Y

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF535Z

8. Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).
If not "CMPLT", stop engine and cool it down to less than 70°C (158°F) and then retest from step 1.
 - a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II.
 - c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
 - d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to step 3.
9. Select "SELF-DIAG RESULTS" mode with CONSULT-II.
10. Confirm that the 1st trip DTC is not detected.
If the 1st trip DTC is detected, go to EC-266, "Diagnostic Procedure".

Overall Function Check

Use this procedure to check the overall function of the three way catalyst (Manifold). During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST



1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.

DTC P0420, P0430 THREE WAY CATALYST

FUNCTION

TB48DE A/T (WITH EURO-OBD)

Overall Function Check (Cont'd)



- Set voltmeters probes between ECM terminals 115 [HO2S1 (B 1) signal], 114 [HO2S1 (B 2) signal] and engine ground, and ECM terminals 124 [HO2S2 (B 1) signal], 123 [HO2S2 (B 2) signal] and engine ground.
- Keep engine speed at 2,000 rpm constant under no load.

- Make sure that the voltage switching frequency (high & low) between ECM terminals 124 and engine ground, or 123 and engine ground, is very less than that of ECM terminals 115 and engine ground, or 114 and engine ground.

Switching frequency ratio = A/B

A: Heated oxygen sensor 2 voltage switching frequency

B: Heated oxygen sensor 1 voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst does not operate properly. Go to EC-266, "Diagnostic Procedure".

NOTE:

If the voltage at terminal 35 or 36 does not switch periodically more than 5 times within 10 seconds at step 7, perform trouble diagnosis for "DTC P0133, P0153" first. (See EC-172.)

Diagnostic Procedure

1	CHECK EXHAUST SYSTEM
Visually check exhaust tubes and muffler for dent.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace.

2	CHECK EXHAUST GAS LEAK
1. Start engine and run it at idle.	
2. Listen for an exhaust gas leak before the three way catalyst (manifold).	
<p>Diagram showing the exhaust system components: HO2S1, Three way catalyst (Manifold), HO2S2, Three way catalyst (Under floor), and Muffler. Exhaust gas flow is indicated by arrows.</p>	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace.

DTC P0420, P0430 THREE WAY CATALYST


FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	CHECK INTAKE AIR LEAK	
Listen for an intake air leak after the mass air flow sensor.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace.

4	CHECK IGNITION TIMING							
Check the following items. Refer to EC-66, "Basic Inspection".								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Items</th> <th>Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>10° ± 5° BTDC (in "P" or "N" position)</td> </tr> <tr> <td>Target idle speed</td> <td>675 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table>			Items	Specifications	Ignition timing	10° ± 5° BTDC (in "P" or "N" position)	Target idle speed	675 ± 50 rpm (in "P" or "N" position)
Items	Specifications							
Ignition timing	10° ± 5° BTDC (in "P" or "N" position)							
Target idle speed	675 ± 50 rpm (in "P" or "N" position)							
MTBL1584								
OK or NG								
OK	▶	GO TO 5.						
NG	▶	Follow the EC-66, "Basic Inspection".						

5	CHECK INJECTORS	
<ol style="list-style-type: none"> 1. Stop engine and then turn ignition switch "ON". 2. Check voltage between ECM terminals 5, 6, 7, 13, 14, 15 and ground with CONSULT-II or tester. 		
		
<p>Battery voltage should exist.</p>		
3. Refer to Wiring Diagram for Injectors, EC-454.		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Perform EC-455, "Diagnostic Procedure".


SEC743D

DTC P0420, P0430 THREE WAY CATALYST

FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

6 CHECK IGNITION SPARK	
<p>1. Turn ignition switch "OFF". 2. Disconnect ignition coil assembly from rocker cover. 3. Connect a known good spark plug to the ignition coil assembly. 4. Place end of spark plug against a suitable ground and crank engine. 5. Check for spark.</p> <div style="text-align: center;"><p>SEF575Q</p></div> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Check ignition coil with power transistor and their circuit. Refer to EC-428, "IGNITION SIGNAL".

7 CHECK INJECTOR	
<p>1. Turn ignition switch "OFF". 2. Remove injector assembly. Refer to EM section. Keep fuel hose and all injectors connected to injector gallery. 3. Disconnect all ignition coil harness connectors. 4. Turn ignition switch "ON". Make sure fuel does not drip from injector.</p> <p style="text-align: center;">OK or NG</p>	
OK (Does not drip.)	▶ GO TO 8.
NG (Drips.)	▶ Replace the injector(s) from which fuel is dripping.

8 CHECK INTERMITTENT INCIDENT	
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
Trouble is fixed.	▶ INSPECTION END
Trouble is not fixed.	▶ Replace three way catalyst (Manifold).

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBDD)


Description

SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Vehicle speed sensor	Vehicle speed		

*: This signal is sent to the ECM through CAN communication line.

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0%
		2,000 rpm	65 - 85%

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444 0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is open or shorted.) ● EVAP canister purge volume control solenoid valve
P0445 0445	EVAP canister purge volume control solenoid valve circuit shorted	An excessively high voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is shorted.) ● EVAP canister purge volume control solenoid valve

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH CONSULT-II**

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for at least 30 seconds.
4. If 1st trip DTC is detected, go to EC-273, “Diagnostic Procedure”.

 **WITH GST**


Follow the procedure “WITH CONSULT-II” above.

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBD)


Wiring Diagram

EC-PGC/V-01




: Detectable line for DTC
 : Non-detectable line for DTC

Refer to EL-POWER.



Refer to last page (Foldout page).

M2



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE



TB48DE A/T (WITH EURO-OBd)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	W/B	EVAP canister purge volume control solenoid valve	<p>Engine is running.</p> <p>└ Idle speed</p>	<p>BATTERY VOLTAGE (11 - 14V)</p>  <p>PBIB0050E</p>
			<p>Engine is running.</p> <p>└ Engine speed is about 2,000 rpm (More than 100 seconds after starting engine)</p>	<p>Approximately 10V★</p>  <p>PBIB0520E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBID)

Diagnostic Procedure

1	CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect EVAP canister purge volume control solenoid valve harness connector.</p>		
 <p>Oil filler cap</p> <p>EVAP canister purge volume control solenoid valve</p>		
SEC785C		
<p>3. Turn ignition switch "ON".</p> <p>4. Check voltage between EVAP canister purge volume control solenoid valve terminal 1 and ground with CONSULT-II or tester.</p>		
		
SEC815C		
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

2	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse ● Fuse block (J/B) connector M2 ● Harness connectors M52, F7 ● Harness for open or short between EVAP canister purge volume control solenoid valve and fuse 		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)


3	CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 54 and EVAP canister purge volume control solenoid valve terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK (With CONSULT-II) ▶		GO TO 4.
OK (Without CONSULT-II) ▶		GO TO 5.
NG ▶		Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION																					
<p>Ⓜ With CONSULT-II</p> <p>1. Reconnect all harness connectors disconnected.</p> <p>2. Start engine.</p> <p>3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.</p>																						
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>PURG VOL CONT/V</td><td style="text-align: center;">0 %</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td>HO2S1 MNTR (B1)</td><td style="text-align: center;">LEAN</td></tr> <tr><td>HO2S1 MNTR (B2)</td><td style="text-align: center;">LEAN</td></tr> <tr><td>A/F ALPHA-B1</td><td style="text-align: center;">XXX %</td></tr> <tr><td>A/F ALPHA-B2</td><td style="text-align: center;">XXX %</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table>			ACTIVE TEST		PURG VOL CONT/V	0 %	MONITOR		ENG SPEED	XXX rpm	HO2S1 MNTR (B1)	LEAN	HO2S1 MNTR (B2)	LEAN	A/F ALPHA-B1	XXX %	A/F ALPHA-B2	XXX %				
ACTIVE TEST																						
PURG VOL CONT/V	0 %																					
MONITOR																						
ENG SPEED	XXX rpm																					
HO2S1 MNTR (B1)	LEAN																					
HO2S1 MNTR (B2)	LEAN																					
A/F ALPHA-B1	XXX %																					
A/F ALPHA-B2	XXX %																					
OK or NG																						
OK ▶		GO TO 6.																				
NG ▶		GO TO 5.																				

PBIB0147E

5	CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	
Refer to EC-275, "Component Inspection".		
OK or NG		
OK ▶		GO TO 6.
NG ▶		Replace EVAP canister purge volume control solenoid valve.

6	CHECK INTERMITTENT INCIDENT	
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".		
▶		INSPECTION END




Component Inspection

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

④ With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition (PURG VOL CONT/V value)	Air passage continuity between A and B
100.0%	Yes
0.0%	No



⊗ Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

Description

NOTE:

If DTC P0500 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to EC-121, “DTC U1000 CAN COMMUNICATION LINE”.

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the combination meter. The combination meter then sends a signal to the ECM through CAN communication line.

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500 0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> ● Harness or connectors (The CAN communication line is open or shorted.) ● Harness or connectors (The vehicle speed signal circuit is open or shorted.) ● Combination meter ● Vehicle speed signal

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

 **WITH CONSULT-II**

1. Start engine.
2. Read “VHCL SPEED SE” in “DATA MONITOR” mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
If NG, go to EC-277, “Diagnostic Procedure”.
If OK, go to following step.
3. Select “DATA MONITOR” mode with CONSULT-II.
4. Warm engine up to normal operating temperature.

5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	More than 1,350 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	More than 6.5 msec
Selector lever	Suitable position
PW/ST SIGNAL	OFF

6. If 1st trip DTC is detected, go to EC-277, “Diagnostic Procedure”.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

Overall Function Check


Use this procedure to check the overall function of the vehicle speed signal circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Lift up drive wheels.
2. Start engine.
3. Read vehicle speed signal in "MODE 1" with GST.
The vehicle speed signal on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to EC-277, "Diagnostic Procedure".

Diagnostic Procedure

1	CHECK VEHICLE SPEED SENSOR CIRCUIT	
Refer to EL section.		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair or replace.
2	CHECK COMBINATION METER	
Check combination meter function. Refer to EL section.		
		▶ INSPECTION END



Component Description

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON

On Board Diagnosis Logic

The MI will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0550 0550	Power steering pressure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Power steering pressure sensor

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If 1st trip DTC is detected, go to EC-280, "Diagnostic Procedure".

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0550 PSP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-PS/SEN-01

 : Detectable line for DTC
 : Non-detectable line for DTC



DTC P0550 PSP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
89	B	Sensor ground (Power steering pressure sensor)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Idle speed	Approximately 0V
103	Y	Sensor power supply (Power steering pressure sensor)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 5V
118	BR/W	Power steering pressure sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Steering wheel is being turned.	0.5 - 4.0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Steering wheel is not being turned.	0.4 - 0.8V

Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
SEC690C	
▶ GO TO 2.	


DTC P0550 PSP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)


2 CHECK PSP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect PSP sensor harness connector.



SEC735D

2. Turn ignition switch "ON".
3. Check voltage between PSP sensor terminal 1 and ground with CONSULT-II or tester.



PBIB0085E

Voltage: Approximately 5V

OK or NG

OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

3 CHECK PSP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between PSP sensor terminal 3 and ground.
Refer to Wiring Diagram.
Continuity should exist.
4. Also check harness for short to ground and short to power.

OK or NG

OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

4 CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 118 and PSP sensor terminal 2.
Continuity should exist.
2. Also check harness for short to ground and short to power.

OK or NG

OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.


DTC P0550 PSP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK PSP SENSOR
Refer to EC-282, "Component Inspection".	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace PSP sensor.

6	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	




Component Inspection

POWER STEERING PRESSURE SENSOR

1. Reconnect all harness connectors disconnected.
2. Start engine and let it idle.
3. Check voltage between ECM terminal 118 and ground under the following conditions.

Condition	Voltage
Steering wheel is being turned fully.	0.5 - 4.0V
Steering wheel is not being turned.	0.4 - 0.8V



Component Description

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.

On Board Diagnosis Logic

This self-diagnosis has one or two trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0605 0605	Engine control module	A)	ECM calculation function is malfunctioning.	● ECM
		B)	ECM EEPROM system is malfunctioning.	
		C)	ECM self shut-off function is malfunctioning.	

FAIL-SAFE MODE

ECM enters fail-safe mode when malfunction A is detected.


Detected items	Engine operation condition in fail-safe mode
Malfunction A	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If the DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no malfunction on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.



PROCEDURE FOR MALFUNCTION A

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st DTC is detected, go to EC-285, "Diagnostic Procedure".

With GST

Follow the procedure "With CONSULT-II" above.

DTC Confirmation Procedure (Cont'd) PROCEDURE FOR MALFUNCTION B

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. If 1st trip DTC is detected, go to EC-285, "Diagnostic Procedure".

With GST

Follow the procedure "With CONSULT-II" above.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

PROCEDURE FOR MALFUNCTION C

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. Repeat step 3 for 32 times.
5. If 1st trip DTC is detected, go to EC-285, "Diagnostic Procedure".

With GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure

1	INSPECTION START	
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Select "SELF DIAG RESULTS" mode with CONSULT-II. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See EC-283. 5. Is the 1st trip DTC P0605 displayed again? <p> With GST</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Select MODE 4 with GST. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See EC-283. 5. Is the 1st trip DTC P0605 displayed again? 		
Yes or No		
Yes	▶	GO TO 2.
No	▶	INSPECTION END

2	REPLACE ECM	
<ol style="list-style-type: none"> 1. Replace ECM. 2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to EC-50, "NATS (Nissan Anti-theft System)". 3. Perform EC-31, "Accelerator Pedal Released Position Learning". 4. Perform EC-31, "Throttle Valve Closed Position Learning". 5. Perform EC-31, "Idle Air Volume Learning". 		
		▶ INSPECTION END

Component Description

Malfunction Indicator (MI) is located on the instrument panel. When the ignition switch is turned ON without engine running, MI will light up. This is a bulb check. When the engine is started, MI should go off. If MI remains on, the on board diagnostic system has detected an engine system malfunction.

On Board Diagnosis Logic

The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0650 0650	Malfunction indicator (MI) control circuit	<ul style="list-style-type: none"> An excessively high voltage is sent to ECM through the MI circuit under the condition that calls for MI light up. An excessively low voltage is sent to ECM through the MI circuit under the condition that calls for MI not to light up. 	<ul style="list-style-type: none"> Harness or connectors (MI circuit is open or shorted.) MI

FAIL-SAFE MODE


ECM enters fail-safe mode when both DTC P0650 and another DTC, which calls for MI to light up, are detected at the same time.

Detected items	Engine operating condition in fail-safe mode
MI circuit	Engine speed will not rise more than 2,500 rpm due to the fuel cut.

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.



Ⓜ WITH CONSULT-II


1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-288.

Ⓜ WITH GST




Follow the procedure "WITH CONSULT-II" above.

Wiring Diagram

EC-MIL-01



— : Detectable line for DTC
 — : Non-detectable line for DTC



Refer to last page (Foldout page).
 M3

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and body ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	Y/G	MI	Ignition switch "ON"	0 - 1.0V
			Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

1	CHECK MIL POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect combination meter harness connector. 3. Turn ignition switch "ON". 4. Check voltage between combination meter terminal 46 and ground with CONSULT-II or tester.</p>	
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

SEC737D

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Fuse block (J/B) connector M3 ● 10A fuse ● Harness for open or short between fuse block (J/B) and combination meter 	
	▶ Repair harness or connectors.

3	CHECK MIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 35 and combination meter terminal 3. Refer to Wiring Diagram. Continuity should exist.</p>	
<p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

Diagnostic Procedure (Cont'd)


4	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> • Harness connectors M52, F7 • Harness for open or short between ECM and combination meter 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

5	CHECK COMBINATION METER						
Check continuity between combination meter terminals 46 and 3 under the following conditions.							
SEC777D							
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Should exit.</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Should not exit.</td> </tr> </tbody> </table>		Condition	Continuity	1	Should exit.	2	Should not exit.
Condition	Continuity						
1	Should exit.						
2	Should not exit.						
MTBL1599							
OK or NG							
OK	▶ GO TO 6.						
NG	▶ Replace combination meter.						

6	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-112. OK or NG	
OK	▶ Replace combination meter. Refer to EL section.
NG	▶ Repair or replace.

DTC P1065 ECM POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)



Component Description

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.


On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply circuit	ECM back up RAM system does not function properly.	<ul style="list-style-type: none"> • Harness or connectors [ECM power supply (back-up) circuit is open or shorted.] • ECM

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.



WITH CONSULT-II

1. Turn ignition switch “ON” and wait at least 1 second.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. Turn ignition switch “OFF”, wait at least 10 seconds, and then turn “ON”.
5. Repeat steps 3 and 4 four times.
6. If 1st trip DTC is detected, go to EC-292, “Diagnostic Procedure”.

WITH GST

Follow the procedure “WITH CONSULT-II” above.




DTC P1065 ECM POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-POWER-01

 : Detectable line for DTC
 : Non-detectable line for DTC



Refer to last page (Foldout page).

(M21), (E127)

DTC P1065 ECM POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
95	W	Power supply for ECM (Buck-up)	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

1	CHECK ECM POWER SUPPLY
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check voltage between ECM terminal 95 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">PBIB0087E</p> <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness connectors M52, F7 ● 10A fuse ● Harness for open or short between ECM and battery 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK INTERMITTENT INCIDENT
<p>Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".</p> <p>OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1065 ECM POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4	PERFORM DTC CONFIRMATION PROCEDURE
<p> With CONSULT-II</p> <ol style="list-style-type: none">1. Turn ignition switch "ON".2. Select "SELF DIAG RESULTS" mode with CONSULT-II.3. Touch "ERASE".4. Perform "DTC Confirmation Procedure". See EC-290.5. Is the 1st trip DTC P1065 displayed again? <p> With GST</p> <ol style="list-style-type: none">1. Turn ignition switch "ON".2. Select MODE 4 with GST.3. Touch "ERASE".4. Perform "DTC Confirmation Procedure". See EC-290.5. Is the 1st trip DTC P1065 displayed again? <p style="text-align: right;">Yes or No</p>	
Yes	▶ GO TO 5.
No	▶ INSPECTION END

5	REPLACE ECM
<ol style="list-style-type: none">1. Replace ECM.2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to EC-50, "NATS (Nissan Anti-theft System)".3. Perform EC-31, "Accelerator Pedal Released Position Learning".4. Perform EC-31, "Throttle Valve Closed Position Learning".5. Perform EC-31, "Idle Air Volume Learning".	
	▶ INSPECTION END

DTC P1111 IVT CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBD)


Description

SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor	Engine speed	Intake valve timing control	Intake valve timing control solenoid valve
Engine coolant temperature sensor	Engine coolant temperature		
Vehicle speed sensor	Vehicle speed		

The intake valve timing control system is utilized to control intake valve opening and closing timing. Engine coolant temperature signals, engine speed, amount of intake air, vehicle speed and throttle position are used to determine intake valve timing. The intake camshaft sprocket position is regulated by oil pressure controlled by the intake valve timing control.

When ECM sends ON signal to intake valve timing control solenoid valve, oil pressure is transmitted to camshaft sprocket. Then, intake side camshaft is advanced.



Operation

Engine operating condition	Intake valve timing control solenoid valve	Intake valve opening and closing time	Valve overlap	Engine valve timing
<ul style="list-style-type: none"> Engine coolant temperature is between 70°C (158°F) to 119°C (246°F) and engine speed is between 1,000 rpm and 4,200 rpm. During high load condition Vehicle speed is more than 8 km/h (5 MPH). 	ON	Advance	Increased	II
Those other than above	OFF	Normal	Normal	I

DTC P1111 IVT CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBD)

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
INT/V SOL-B1	<ul style="list-style-type: none"> ● Engine: Idle 	OFF
	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed is between 1,000 rpm and 4,200 rpm ● Vehicle speed is more than 8 km/h (5 MPH). ● During high load condition 	ON


On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1111 1111	Intake valve timing control solenoid valve circuit	An improper voltage is sent to the ECM through intake valve timing control solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (Solenoid valve circuit is open or shorted.) ● Intake valve timing control solenoid valve

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.



WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If 1st trip DTC is detected, go to EC-297, "Diagnostic Procedure".

WITH GST



Following the procedure "WITH CONSULT-II" above.

DTC P1111 IVT CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBD)


Wiring Diagram

EC-IVC-01



Refer to last page (Foldout page).

M2



DTC P1111 IVT CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
152	R	Intake valve timing control solenoid valve	Engine is running. └ Intake valve timing control solenoid is operating.	Approximately 0V
			Engine is running. └ Intake valve timing control solenoid is not operating.	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure


1	CHECK IVT CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect intake valve timing control solenoid valve harness connector.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">SEC793C</p> <p>3. Turn ignition switch "ON". 4. Check voltage between intake valve timing control solenoid valve terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">SEC794C</p> <p>Voltage: Battery voltage</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

DTC P1111 IVT CONTROL SOLENOID VALVE

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2	DETECT MALFUNCTION PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M52, F7 ● 10A fuse ● Fuse block (J/B) connector M2 ● Harness for open or short between intake valve timing control solenoid valve and fuse 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	
3	CHECK IVT CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 152 and intake valve timing control solenoid valve terminal 1. Refer to Wiring Diagram.</p> <p style="padding-left: 20px;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.
4	CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE
<p>Refer to EC-298, "Component Inspection".</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Replace intake valve timing control solenoid valve.
5	CHECK INTERMITTENT INCIDENT
<p>Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT."</p>	
▶ INSPECTION END	



Component Inspection

INTAKE VALVE TIMING CONTROL SOLENOID VALVE

1. Check oil passage visually for any metal debris.
2. Supply intake valve timing control solenoid valve terminals with battery voltage.
3. Make sure that inside plunger protrudes.
If NG, replace intake valve timing control solenoid valve.

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

TB48DE A/T (WITH EURO-OBD)

Component Description

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121 1121	Electric throttle control actuator	A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	● Electric throttle control actuator
		B)	Throttle valve opening angle in fail-safe mode is not in specified range.	
		C)	ECM detect the throttle valve is stuck open. This self-diagnosis has the one trip detection logic.	

FAIL-SAFE MODE

When the malfunction A or B is detected in the two consecutive trips, the ECM enters fail-safe mode and the MI lights up.

When the malfunction C is detected even in the 1st trip, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Malfunction A	The ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.

DTC Confirmation Procedure


NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A AND B" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION C".
If there is no malfunction on "PROCEDURE FOR MALFUNCTION A AND B", perform "PROCEDURE FOR MALFUNCTION C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A AND B

① With CONSULT-II

1. Turn ignition witch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position and wait at least 2 seconds.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. If 1st trip DTC is detected, go to EC-300, "Diagnostic Procedure".



DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

 With GST

Follow the procedure "With CONSULT-II" above.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

PROCEDURE FOR MALFUNCTION C


 With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position and wait at least 2 seconds.
4. Shift selector lever to "N" or "P" position.
5. Start engine and let it idle for 3 seconds.
6. If DTC is detected, go to EC-300, "Diagnostic Procedure".

 With GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure

1	CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY
<ol style="list-style-type: none"> 1. Remove the intake air duct. 2. Perform 31, "Accelerator Pedal Released Position Learning". 3. Check if a foreign matter is caught between the throttle valve and the housing. 	
	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Remove the foreign matter and clean the electric throttle control actuator inside.
2	REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR
<ol style="list-style-type: none"> 1. Replace the electric throttle control actuator. 2. Perform EC-31, "Accelerator Pedal Released Position Learning". 3. Perform EC-31, "Throttle Valve Closed Position Learning". 4. Perform EC-31, "Idle Air Volume Learning". 	
▶ INSPECTION END	

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

TB48DE A/T (WITH EURO-OBD)

Description

NOTE:

If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or P1126. Refer to EC-299 or EC-309.

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.


DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1122 1122	Electric throttle control performance problem	Electric throttle control function does not operate properly.	<ul style="list-style-type: none">● Harness or connectors (Throttle control motor circuit is open or shorted.)● Harness or connectors (Throttle control motor relay circuit is open or shorted.)● Electric throttle control actuator● Throttle control motor relay

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.



DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to EC-303, "Diagnostic Procedure".

④ WITH GST



Follow the procedure "WITH CONSULT-II" above.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-ETC1-01



DTC P1122 ELECTRIC THROTTLE CONTROL

FUNCTION



TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
26	P/L	Throttle control motor relay	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
			Ignition switch "ON"	0 - 1.0V
151	L/W	Throttle control motor (Open)	Ignition switch "ON" — Engine stopped — Shift lever position is "D" — Accelerator pedal is depressed	0 - 14V★  PBIB0534E
153	B	Throttle control motor ground	Engine is running.	Approximately 0V
154	L/B	Throttle control motor (Close)	Ignition switch "ON" — Engine stopped — Shift lever position is "D" — Accelerator pedal is released	0 - 14V★  PBIB0533E
157	G	Throttle control motor power supply	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure


1	RETIGHTEN GROUND SCREWS
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.	
	
SEC690C	
▶ GO TO 2.	

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)



2	CHECK THROTTLE CONTROL MOTOR GROUND CIRCUIT FOR OPEN AND SHORT	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 153 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to power in harness or connectors.

3	CHECK THROTTLE CONTROL MOTOR RELAY SIGNAL CIRCUIT							
<p>1. Reconnect harness connectors disconnected.</p> <p>2. Check voltage between ECM terminal 157 and ground under the following conditions with CONSULT-II or tester.</p>								
								
SEC740D								
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="width: 50%;">Ignition switch</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">OFF</td> <td style="text-align: center;">Approximately 0V</td> </tr> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">Battery voltage (11 - 14V)</td> </tr> </tbody> </table>			Ignition switch	Voltage	OFF	Approximately 0V	ON	Battery voltage (11 - 14V)
Ignition switch	Voltage							
OFF	Approximately 0V							
ON	Battery voltage (11 - 14V)							
MTBL1585								
OK or NG								
OK	▶	GO TO 11.						
NG	▶	GO TO 4.						

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4	CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect throttle control motor relay.</p>	
	
SEC185D	
<p>3. Check voltage between throttle control motor relay terminals 2, 3 and ground.</p>	
	
PBIB0097E	
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● 15A fuse ● Harness for open or short between throttle control motor relay and fuse 	
<p>▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	

6	CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 157 and throttle control motor relay terminal 5. Refer to Wiring Diagram. Continuity should exist.</p>	
<p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

7	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Harness connectors E127, M21● Harness connectors M55, F35● Harness for open or short between ECM and throttle control motor relay	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT
1. Check continuity between ECM terminal 26 and throttle control motor relay terminal 1. Refer to Wiring Diagram. Continuity should exist.	
2. Also check harness for short to ground and short to power. OK or NG	
OK	▶ GO TO 10.
NG	▶ GO TO 9.
9	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Harness connectors E127, M21● Harness connectors M55, F35● Harness for open or short between ECM and throttle control motor relay	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.
10	CHECK THROTTLE CONTROL MOTOR RELAY
Refer to EC-308, "Component Inspection". OK or NG	
OK	▶ GO TO 14.
NG	▶ Replace throttle control motor relay.


DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

TB48DE A/T (WITH EURO-OBID)

Diagnostic Procedure (Cont'd)

11 CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.



SEC182D

3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals.
Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	154	Should exist
	151	Should not exist
6	154	Should not exist
	151	Should exist

MTBL1586


5. Also check harness for short to ground and short to power.

OK or NG

OK	▶	GO TO 12.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

12 CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if foreign matter is caught between the throttle valve and the housing.



SEC183D

OK or NG

OK	▶	GO TO 13.
NG	▶	Remove the foreign matter and clean the electric throttle control actuator inside.

DTC P1122 ELECTRIC THROTTLE CONTROL

FUNCTION


TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

13	CHECK THROTTLE CONTROL MOTOR
Refer to EC-308, "Component Inspection".	
OK or NG	
OK	▶ GO TO 14.
NG	▶ GO TO 15.

14	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT."	
OK or NG	
OK	▶ GO TO 15.
NG	▶ Repair or replace harness or connectors.

15	REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR
<ol style="list-style-type: none"> 1. Replace the electric throttle control actuator. 2. Perform EC-31, "Accelerator Pedal Released Position Learning". 3. Perform EC-31, "Throttle Valve Closed Position Learning". 4. Perform EC-31, "Idle Air Volume Learning". 	
▶ INSPECTION END	




Component Inspection

THROTTLE CONTROL MOTOR RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.



THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.
Resistance: Approximately 1 - 15 Ω [at 25°C (77°F)]
3. If NG, replace electric throttle control actuator and go to next step.
4. Perform EC-31, "Accelerator Pedal Released Position Learning".
5. Perform EC-31, "Throttle Valve Closed Position Learning".
6. Perform EC-31, "Idle Air Volume Learning".

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

TB48DE A/T (WITH EURO-OBD)

Component Description

Power supply for the Throttle Control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	● Ignition switch: ON	ON

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detect the throttle control motor relay is stuck ON.	● Harness or connectors (Throttle control motor relay circuit is shorted.) ● Throttle control motor relay
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low.	● Harness or connectors (Throttle control motor relay circuit is open.) ● Throttle control motor relay

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR DTC P1124

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

TB48DE A/T (WITH EURO-OBD)

DTC Confirmation Procedure (Cont'd)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to EC-312, "Diagnostic Procedure".

With GST

Follow the procedure "With CONSULT-II" above.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

PROCEDURE FOR DTC P1126

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to EC-312, "Diagnostic Procedure".

With GST



Follow the procedure "With CONSULT-II" above.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-ETC2-01



DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
26	P/L	Throttle control motor relay	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
			Ignition switch "ON"	0 - 1.0V
157	G	Throttle control motor power supply	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

1	CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect throttle control motor relay.</p>	
	
<p>3. Check voltage between throttle control motor relay terminals 2, 3 and ground.</p>	
	
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

SEC185D

PBIB0097E

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● 15A fuse ● Harness for open or short between throttle control motor relay and fuse 	
<p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY


TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 157 and throttle control motor relay terminal 5. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK		▶ GO TO 5.
NG		▶ GO TO 4.
4	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness connectors M51, F35 ● Harness for open or short between ECM and throttle control motor relay 		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.
5	CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT	
<p>1. Check continuity between ECM terminal 26 and throttle control motor relay terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK		▶ GO TO 7.
NG		▶ GO TO 6.
6	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness connectors M55, F35 ● Harness for open or short between ECM and throttle control motor relay 		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.
7	CHECK THROTTLE CONTROL MOTOR RELAY	
<p>Refer to EC-314, "Component Inspection".</p> <p style="text-align: center;">OK or NG</p>		
OK		▶ GO TO 8.
NG		▶ Replace throttle control motor relay.
8	CHECK INTERMITTENT INCIDENT	
<p>Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".</p>		
		▶ INSPECTION END

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

TB48DE A/T (WITH EURO-OBD)



Component Inspection

THROTTLE CONTROL MOTOR RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.

DTC P1128 THROTTLE CONTROL MOTOR

TB48DE A/T (WITH EURO-OBD)

Component Description

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short both circuits between ECM and throttle control motor.	<ul style="list-style-type: none">• Harness or connectors (Throttle control motor circuit is shorted.)• Electric throttle control actuator (Throttle control motor)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.


Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.



WITH CONSULT-II

1. Turn ignition switch “ON” and wait at least 2 seconds.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to EC-317, “Diagnostic Procedure”.

WITH GST



Follow the procedure “WITH CONSULT-II” above.

DTC P1128 THROTTLE CONTROL MOTOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-ETC3-01



DTC P1128 THROTTLE CONTROL MOTOR



TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
151	L/W	Throttle control motor (Open)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal is depressed 	<p>0 - 14V★</p>  <p style="text-align: right; font-size: small;">PBIB0534E</p>
154	L/B	Throttle control motor (Close)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal is released 	<p>0 - 14V★</p>  <p style="text-align: right; font-size: small;">PBIB0533E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

1	<p>RETIGHTEN GROUND SCREWS</p> <p>1. Turn ignition switch "OFF".</p> <p>2. Loosen and retighten engine ground screws.</p>
	
<p>▶ GO TO 2.</p> <p style="text-align: right; font-size: small;">SEC690C</p>	


DTC P1128 THROTTLE CONTROL MOTOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2 CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.



SEC182D

3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals.
Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	154	Should exist
	151	Should not exist
6	154	Should not exist
	151	Should exist

MTBL1587

5. Also check harness for short to ground and short to power.
OK or NG

OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

3 CHECK THROTTLE CONTROL MOTOR

- Refer to EC-319, "Component Inspection".
- OK or NG**

OK	▶	GO TO 4.
NG	▶	GO TO 5.

4 CHECK INTERMITTENT INCIDENT


- Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".
- OK or NG**

OK	▶	GO TO 5.
NG	▶	Repair or replace harness or connectors.

5 REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform EC-31, "Accelerator Pedal Released Position Learning".
3. Perform EC-31, "Throttle Valve Closed Position Learning".
4. Perform EC-31, "Idle Air Volume Learning".


	▶	INSPECTION END
--	---	-----------------------



Component Inspection


THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.
Resistance: Approximately 1 - 15Ω [at 25°C (77°F)]
3. If NG, replace electric throttle control actuator and go to next step.
4. Perform EC-31, "Accelerator Pedal Released Position Learning".
5. Perform EC-31, "Throttle Valve Closed Position Learning".
6. Perform EC-31, "Idle Air Volume Learning".



Component Description


The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



On Board Diagnosis Logic

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the "rich" output is sufficiently high and whether the "lean" output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1143 1143 (Bank 1)	Heated oxygen sensor 1 lean shift monitoring	The maximum and minimum voltage from the sensor are not reached to the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks
P1163 1163 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1) P1143” of “HO2S1” or “HO2S1 (B2) P1163” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

ENG SPEED	1,050 - 2,500 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	5 - 16.7 msec
Selector lever	Suitable position

If “TESTING” is not displayed after 5 minutes, retry from step 2.

HO2S1 (B1) P1143	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0546E

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0547E


HO2S1 (B1) P1143	
COMPLETED	

SEC769C

7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to EC-322, “Diagnostic Procedure”.

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.




WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
4. If NG, go to EC-322, "Diagnostic Procedure".

Diagnostic Procedure

1 RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.




SEC690C

▶ GO TO 2.

Diagnostic Procedure (Cont'd)

2 RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten corresponding heated oxygen sensor 1.



Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)


SEC888C

▶ GO TO 3.

Diagnostic Procedure (Cont'd)

3 CLEAR THE SELF-LEARNING DATA


- With CONSULT-II**
1. Start engine and warm it up to normal operating temperature.
 2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
 3. Clear the self-learning control coefficient by touching "CLEAR".



SEF215Z

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?

- Without CONSULT-II**
1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF".
 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
 4. Stop engine and reconnect mass air flow sensor harness connector.



SEC688C

5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?

Yes or No

Yes	▶	Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-218.
No	▶	GO TO 4.

4 CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to EC-131, "Component Inspection".

OK or NG

OK	▶	GO TO 5.
NG	▶	Replace malfunctioning heated oxygen sensor 1.

Diagnostic Procedure (Cont'd)

5	CHECK HEATED OXYGEN SENSOR 1
Refer to EC-325, "Component Inspection".	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace malfunctioning heated oxygen sensor 1.

6	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT. For circuit, refer to EC-165, "Wiring Diagram".	
	▶ INSPECTION END

Component Inspection

HEATED OXYGEN SENSOR 1

Ⓜ **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN


SEF646Y

Bank 1	cycle	1 2 3 4 5
	HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R-L-R
Bank 2	cycle	1 2 3 4 5
	HO2S1 MNTR (B2)	R-L-R-L-R-L-R-L-R-L-R
R means HO2S1 MNTR (B1)/(B2) indicates RICH L means HO2S1 MNTR (B1)/(B2) indicates LEAN		

SEF647Y


6. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Component Inspection (Cont'd)



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.




⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Component Description


The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



On Board Diagnosis Logic

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the "rich" output is sufficiently high. The "lean" output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1144 1144 (Bank 1)	Heated oxygen sensor 1 rich shift monitoring	The maximum and minimum voltages from the sensor are beyond the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors
P1164 1164 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓜ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch "ON" and select "HO2S1 (B1) P1144" or "HO2S1 (B2) P1164" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.

HO2S1 (B1) P1144	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0548E

4. Touch "START".

5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.


HO2S1 (B1) P1144	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0549E

6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

ENG SPEED	1,500 - 2,500 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	5 - 16.7 msec
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.




7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to EC-329, "Diagnostic Procedure".

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.32V at least one time.
4. If NG, go to EC-329, "Diagnostic Procedure".



Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
SEC690C	
▶ GO TO 2.	


DTC P1144, P1164 HO2S1

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2 RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.



Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)

SEC888C


▶ GO TO 3.

Diagnostic Procedure (Cont'd)

3 CLEAR THE SELF-LEARNING DATA

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".




SEF215Z

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?

 Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.



SEC688C

5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?


Yes or No

Yes	▶	Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-227.
No	▶	GO TO 4.

DTC P1144, P1164 HO2S1

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4	CHECK HO2S1 CONNECTOR FOR WATER
<p>1. Turn ignition switch "OFF". 2. Disconnect heated oxygen sensor 1 harness connector. 3. Check connectors for water.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEC671D</p>	
Water should not exist.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair or replace harness or connectors.

5	CHECK HEATED OXYGEN SENSOR 1 HEATER
Refer to EC-131, "Component Inspection".	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace malfunctioning heated oxygen sensor 1.

6	CHECK HEATED OXYGEN SENSOR 1
Refer to EC-332, "Component Inspection".	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace malfunctioning heated oxygen sensor 1.

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT". For circuit, refer to EC-165, "Wiring Diagram".	
▶	INSPECTION END

Component Inspection

HEATED OXYGEN SENSOR 1

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.

Component Inspection (Cont'd)

5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLANT TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

Bank 1
cycle | 1 | 2 | 3 | 4 | 5 |
HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R

Bank 2
cycle | 1 | 2 | 3 | 4 | 5 |
HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R


R means HO2S1
MNTR (B1)/(B2) indicates RICH

L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y


6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



⊗ Without CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 115 [HO2S1 (B1) signal] or 114 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.

Component Inspection (Cont'd)

- The voltage never exceeds 1.0V.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Component Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.


This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revvng engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revvng engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH



On Board Diagnosis Logic

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1146 1146 (Bank 1)	Heated oxygen sensor 2 minimum voltage monitoring	The minimum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors
P1166 1166 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in “Procedure for COND1”

WITH CONSULT-II

Procedure for COND1

For the best results, perform “DTC WORK SUPPORT” at a temperature of 0 to 30°C (32 to 86°F).

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select “HO2S2 (B1) P1146” of “HO2S2” in “DTC WORK SUPPORT” mode with CONSULT-II.
6. Touch START”.
7. Let engine idle for at least 30 seconds.
8. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If “COMPLETED” appears on CONSULT-II screen, go to step 2 in Procedure for COND3”.
If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
9. When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 100°C
Selector lever	Suitable position

<table border="1"> <tr><th align="center">HO2S2 (B1) P1146</th></tr> <tr><td>COND1: OUT OF CONDITION</td></tr> <tr><td>COND2: INCOMPLETE</td></tr> <tr><td>COND3: INCOMPLETE</td></tr> <tr><th align="center">MONITOR</th></tr> <tr><td>ENG SPEED XXX rpm</td></tr> <tr><td>B/FUEL SCHDL XXX msec</td></tr> </table>	HO2S2 (B1) P1146	COND1: OUT OF CONDITION	COND2: INCOMPLETE	COND3: INCOMPLETE	MONITOR	ENG SPEED XXX rpm	B/FUEL SCHDL XXX msec	<table border="1"> <tr><th align="center">HO2S2 (B1) P1146</th></tr> <tr><td>COND1: TESTING</td></tr> <tr><td>COND2: INCOMPLETE</td></tr> <tr><td>COND3: INCOMPLETE</td></tr> <tr><th align="center">MONITOR</th></tr> <tr><td>ENG SPEED XXX rpm</td></tr> <tr><td>B/FUEL SCHDL XXX msec</td></tr> </table>	HO2S2 (B1) P1146	COND1: TESTING	COND2: INCOMPLETE	COND3: INCOMPLETE	MONITOR	ENG SPEED XXX rpm	B/FUEL SCHDL XXX msec	<table border="1"> <tr><th align="center">HO2S2 (B1) P1146</th></tr> <tr><td>COND1: COMPLETED</td></tr> <tr><td>COND2: INCOMPLETE</td></tr> <tr><td>COND3: INCOMPLETE</td></tr> <tr><th align="center">MONITOR</th></tr> <tr><td>ENG SPEED XXX rpm</td></tr> <tr><td>B/FUEL SCHDL XXX msec</td></tr> </table>	HO2S2 (B1) P1146	COND1: COMPLETED	COND2: INCOMPLETE	COND3: INCOMPLETE	MONITOR	ENG SPEED XXX rpm	B/FUEL SCHDL XXX msec
HO2S2 (B1) P1146																							
COND1: OUT OF CONDITION																							
COND2: INCOMPLETE																							
COND3: INCOMPLETE																							
MONITOR																							
ENG SPEED XXX rpm																							
B/FUEL SCHDL XXX msec																							
HO2S2 (B1) P1146																							
COND1: TESTING																							
COND2: INCOMPLETE																							
COND3: INCOMPLETE																							
MONITOR																							
ENG SPEED XXX rpm																							
B/FUEL SCHDL XXX msec																							
HO2S2 (B1) P1146																							
COND1: COMPLETED																							
COND2: INCOMPLETE																							
COND3: INCOMPLETE																							
MONITOR																							
ENG SPEED XXX rpm																							
B/FUEL SCHDL XXX msec																							

PBIB0555E

NOTE:

- If “TESTING” is not displayed after 5 minutes, retry from step 2 in “Procedure for COND1”.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before “Procedure for COND2” is conducted, it is unnecessary to conduct step 1 in “Procedure for COND2”.

DTC Confirmation Procedure (Cont'd)

Procedure for COND2

1. While driving, release accelerator pedal completed with "OD" OFF from the above condition [step 9] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)

NOTE:

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

HO2S2 (B1) P1146	
COND1:	COMPLETED
COND2:	COMPLETED
COND3:	INCOMPLETE
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0556E

HO2S2 (B1) P1146	
COMPLETED	
SELF-DIAG RESULTS	

SEC775C

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to EC-342, "Diagnostic Procedure".
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II
 - c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
 - d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to "Procedure for COND 1" step 3.

Overall Function Check


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 124 [HO2S2 (B1) signal] or 123 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)

The voltage should be below 0.48V at least once during this procedure.

If the voltage can be confirmed in step 6, step 7 is not necessary.





Overall Function Check (Cont'd)

7. Keep vehicle at idling for 10 minutes, then check the voltage.
Or check the voltage when coasting from 80 km/h (50 MPH)
in "D" position with "OD" OFF.
**The voltage should be below 0.48V at least once during
this procedure.**
8. If NG, go to EC-342, "Diagnostic Procedure".

Wiring Diagram


BANK 1

EC-O2S2B1-01



Refer to last page (Foldout page).

(M21, E127)
(E112)



**DTC P1146, P1166
HO2S2**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:



Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
124	W	Heated oxygen sensor 2 (bank 1)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition. — Revving engine from idle to 3,000 rpm quickly after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V

Wiring Diagram (Cont'd)


BANK 2

EC-O2S2B2-01



Refer to last page (Foldout page).

M21, E127
E112



DTC P1146, P1166 HO2S2

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
123	W	Heated oxygen sensor 2 (bank 2)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition. — Revving engine from idle to 3,000 rpm quickly after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V

Diagnostic Procedure


1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
SEC690C	
▶ GO TO 2.	

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".




SEF215Z

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?

 Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.



SEC688C

5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?

Yes or No

Yes	▶	Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-227.
No	▶	GO TO 3.


DTC P1146, P1166 HO2S2

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3 CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.



SEC669D

3. Disconnect ECM harness connector.
4. Check harness continuity between HO2S2 terminal 4 and ground.
Refer to Wiring Diagram.
Continuity should exist.
5. Also check harness for short to ground and short to power.

OK or NG

OK ► GO TO 5.

NG ► GO TO 4.

4 DETECT MALFUNCTIONING PART

Check the following.

- Joint connector-7
- Harness for open or short between heated oxygen sensor 2 and ground

► Repair open circuit or short to power in harness or connectors.

DTC P1146, P1166 HO2S2

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT																
1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P1146</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P1166</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM	Sensor	P1146	124	1	1	P1166	123	1	2
DTC	Terminals		Bank														
	ECM	Sensor															
P1146	124	1	1														
P1166	123	1	2														
MTBL1588																	
Continuity should exist.																	
2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P1146</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P1166</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM	Sensor	P1146	124	1	1	P1166	123	1	2
DTC	Terminals		Bank														
	ECM	Sensor															
P1146	124	1	1														
P1166	123	1	2														
MTBL1589																	
Continuity should not exist.																	
3. Also check harness for short to power.																	
OK or NG																	
OK	▶	GO TO 6.															
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.															

6	CHECK HEATED OXYGEN SENSOR 2		
Refer to EC-345, "Component Inspection".			
OK or NG			
OK	▶	GO TO 7.	
NG	▶	Replace heated oxygen sensor 2.	

7	CHECK INTERMITTENT INCIDENT		
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".			
▶ INSPECTION END			

Component Inspection

HEATED OXYGEN SENSOR 2

🔧 With CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle one minute.


Component Inspection (Cont'd)

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

5. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

6. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.

"HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 124 [HO2S2 (B1) signal] or 123 [HO2S2 (B2) signal] and engine ground.

Component Inspection (Cont'd)



6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 6, step 7 is not necessary.


7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF.

The voltage should be below 0.48V at least once during this procedure.

8. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Component Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.


This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH



On Board Diagnosis Logic

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1147 1147 (Bank 1)	Heated oxygen sensor 2 maximum voltage monitoring	The maximum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks
P1167 1167 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in “Procedure for COND1”

 **WITH CONSULT-II**

Procedure for COND1

For the best results, perform “DTC WORK SUPPORT” at a temperature of 0 to 30°C (32 to 86°F).

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select “HO2S2 (B1) P1147” or “HO2S2 (B2) P1167” of “HO2S2” in “DTC WORK SUPPORT” mode with CONSULT-II.
6. Touch “START”.
7. Let engine idle for at least 30 seconds.
8. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If “COMPLETED” appears on CONSULT-II screen, go to step 2 in “Procedure for COND3”.
If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
9. When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 100°C
Selector lever	Suitable position

<table border="1"> <tr><th align="center">HO2S2 (B1) P1147</th></tr> <tr><td>COND1: OUT OF CONDITION</td></tr> <tr><td>COND2: INCOMPLETE</td></tr> <tr><td>COND3: INCOMPLETE</td></tr> <tr><th align="center">MONITOR</th></tr> <tr><td>ENG SPEED XXX rpm</td></tr> <tr><td>B/FUEL SCHDL XXX msec</td></tr> </table>	HO2S2 (B1) P1147	COND1: OUT OF CONDITION	COND2: INCOMPLETE	COND3: INCOMPLETE	MONITOR	ENG SPEED XXX rpm	B/FUEL SCHDL XXX msec	<table border="1"> <tr><th align="center">HO2S2 (B1) P1147</th></tr> <tr><td>COND1: TESTING</td></tr> <tr><td>COND2: INCOMPLETE</td></tr> <tr><td>COND3: INCOMPLETE</td></tr> <tr><th align="center">MONITOR</th></tr> <tr><td>ENG SPEED XXX rpm</td></tr> <tr><td>B/FUEL SCHDL XXX msec</td></tr> </table>	HO2S2 (B1) P1147	COND1: TESTING	COND2: INCOMPLETE	COND3: INCOMPLETE	MONITOR	ENG SPEED XXX rpm	B/FUEL SCHDL XXX msec	<table border="1"> <tr><th align="center">HO2S2 (B1) P1147</th></tr> <tr><td>COND1: COMPLETED</td></tr> <tr><td>COND2: INCOMPLETE</td></tr> <tr><td>COND3: INCOMPLETE</td></tr> <tr><th align="center">MONITOR</th></tr> <tr><td>ENG SPEED XXX rpm</td></tr> <tr><td>B/FUEL SCHDL XXX msec</td></tr> </table>	HO2S2 (B1) P1147	COND1: COMPLETED	COND2: INCOMPLETE	COND3: INCOMPLETE	MONITOR	ENG SPEED XXX rpm	B/FUEL SCHDL XXX msec
HO2S2 (B1) P1147																							
COND1: OUT OF CONDITION																							
COND2: INCOMPLETE																							
COND3: INCOMPLETE																							
MONITOR																							
ENG SPEED XXX rpm																							
B/FUEL SCHDL XXX msec																							
HO2S2 (B1) P1147																							
COND1: TESTING																							
COND2: INCOMPLETE																							
COND3: INCOMPLETE																							
MONITOR																							
ENG SPEED XXX rpm																							
B/FUEL SCHDL XXX msec																							
HO2S2 (B1) P1147																							
COND1: COMPLETED																							
COND2: INCOMPLETE																							
COND3: INCOMPLETE																							
MONITOR																							
ENG SPEED XXX rpm																							
B/FUEL SCHDL XXX msec																							

PBIB0557E

NOTE:

- If “TESTING” is not displayed after 5 minutes, retry from step 2 in Procedure for COND1”.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before “Procedure for COND2” is conducted, it is unnecessary to conduct step 1 in “Procedure for COND2”.

DTC Confirmation Procedure (Cont'd)

Procedure for COND2

1. While driving, release accelerator pedal completed with "OD" OFF from the above condition [step 9] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)

NOTE:

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

HO2S2 (B1) P1147	
COND1:	COMPLETED
COND2:	COMPLETED
COND3:	INCOMPLETE
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0558E

HO2S2 (B1) P1147	
COMPLETED	
SELF-DIAG RESULTS	

SEC778C

Procedure for COND3


1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to EC-355, "Diagnostic Procedure".
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II
 - c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
 - d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to "Procedure for COND 1" step 3.

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 124 [HO2S2 (B1) signal] or 123 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.





Overall Function Check (Cont'd)

7. Keep vehicle idling for 10 minutes, then check the voltage.
Or check the voltage when coasting from 80 km/h (50 MPH)
in "D" position with "OD" OFF.
**The voltage should be above 0.68V at least once during
this procedure.**
8. If NG, go to EC-355, "Diagnostic Procedure".

Wiring Diagram


BANK 1

EC-O2S2B1-01



Refer to last page (Foldout page).

(M21, E127)
(E112)



**DTC P1147, P1167
HO2S2**

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
124	W	Heated oxygen sensor 2 (bank 1)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition. — Revving engine from idle to 3,000 rpm quickly after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V



DTC P1147, P1167 HO2S2

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


BANK 2

EC-O2S2B2-01



Refer to last page (Foldout page).

M21, E127
E112



TEC336M

DTC P1147, P1167 HO2S2

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
123	W	Heated oxygen sensor 2 (bank 2)	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Engine is running.</div> <ul style="list-style-type: none"> — Warm-up condition. — Revving engine from idle to 3,000 rpm quickly after the following conditions are met. — Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V

Diagnostic Procedure


1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
SEC690C	
▶ GO TO 2.	

Diagnostic Procedure (Cont'd)

2 CLEAR THE SELF-LEARNING DATA

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".




SEF215Z

4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?

 Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.



SEC688C

5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to EC-49, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?


Yes or No

Yes	▶	Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-218.
No	▶	GO TO 3.

DTC P1147, P1167 HO2S2

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect heated oxygen sensor 2 harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Heated oxygen sensor 2 (bank 2) harness connector</p> <p style="margin-left: 100px;">Heated oxygen sensor 2 (bank 1) harness connector</p> </div> <p style="text-align: right;">SEC669D</p> <p>3. Disconnect ECM harness connector.</p> <p>4. Check harness continuity between HO2S2 terminal 4 and ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>5. Also check harness for short to ground and short to power. OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

4	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Joint connector-7 ● Harness for open or short between heated oxygen sensor 2 and ground 		
		▶ Repair open circuit or short to power in harness or connectors.

DTC P1147, P1167 HO2S2

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT																
1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P1147</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P1167</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM	Sensor	P1147	124	1	1	P1167	123	1	2
DTC	Terminals		Bank														
	ECM	Sensor															
P1147	124	1	1														
P1167	123	1	2														
MTBL1590																	
Continuity should exist.																	
2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P1147</td> <td style="text-align: center;">124</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P1167</td> <td style="text-align: center;">123</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM	Sensor	P1147	124	1	1	P1167	123	1	2
DTC	Terminals		Bank														
	ECM	Sensor															
P1147	124	1	1														
P1167	123	1	2														
MTBL1591																	
Continuity should not exist.																	
3. Also check harness for short to power.																	
OK or NG																	
OK		▶	GO TO 6.														
NG		▶	Repair open circuit or short to ground or short to power in harness or connectors.														

6	CHECK HEATED OXYGEN SENSOR 2		
Refer to EC-358, "Component Inspection".			
OK or NG			
OK		▶	GO TO 7.
NG		▶	Replace heated oxygen sensor 2.

7	CHECK INTERMITTENT INCIDENT		
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".			
		▶	INSPECTION END

Component Inspection

HEATED OXYGEN SENSOR 2

🔧 **With CONSULT-II**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.


Component Inspection (Cont'd)

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

5. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

6. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.

"HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 124 [HO2S2 (B1) signal] or 123 [HO2S2 (B2) signal] and engine ground.

Component Inspection (Cont'd)



6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 6, step 7 is not necessary.

7. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF.

The voltage should be below 0.56V at least once during this procedure.

8. If NG, replace heated oxygen sensor 2.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)


TB48DE A/T (WITH EURO-OBD)

System Description



The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

Operation



CONSULT-II Reference Value In Data Monitor Mode

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
COOLING FAN	<ul style="list-style-type: none"> ● After warming up engine, idle the engine. ● Air conditioner switch "OFF" ● Vehicle stopped 	Engine coolant temperature is 94°C (201°F) or less. OFF
		Engine coolant temperature is between 95°C (203°F) and 99°C (210°F) LOW
		Engine coolant temperature is 100°C (212°F) or more. HIGH
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: "OFF" OFF
		Air conditioner switch: "ON" (Compressor operates.) ON

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
56	L	Cooling fan relay (Low speed)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
			Engine is running. └ Cooling fan is operating.	Approximately 0V
55	L/B	Cooling fan relay (High speed)	Engine is running. └ Cooling fan is not operating. └ Cooling fan is operating at low speed.	BATTERY VOLTAGE (11 - 14V)
			Engine is running. └ Cooling fan is operating at high speed.	Approximately 0V

On Board Diagnosis Logic

This diagnosis continuously monitors the engine coolant temperature.

If the cooling fan or another component in the cooling system malfunctions, the engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is detected by the ECM and the MIL lights on.

Diagnostic trouble code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1217 1217	<ul style="list-style-type: none"> ● Cooling fan does not operate properly (Overheat). ● Cooling fan system does not operate properly (Overheat). ● Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted) ● Cooling fan ● Thermostat ● Improper ignition timing ● Engine coolant temperature sensor ● Blocked radiator ● Blocked front end (Improper fitting of nose mask) ● Crushed vehicle frontal area (Vehicle frontal is collided but not repaired) ● Blocked air passage by improper installation of front fog lamp or fog lamps. ● Improper mixture ratio of coolant ● Damaged bumper <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", EC-370.</p>


CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- a. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED LUBRICANTS AND FLUIDS").
- b. After refilling coolant, run engine to ensure that no water-flow noise is emitted.


DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)



ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLANT TEMP/S	XXX °C

SEF646X



Overall Function Check

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

With CONSULT-II

- 1) Check the coolant level and mixture ratio (using coolant tester) in the reservoir tank and radiator.
Allow engine to cool before checking coolant level and mixture ratio.
 - If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-365.
 - If the coolant mixture ratio is out of the range of 45 to 55% (varies depending on destinations), replace the coolant in the following procedure LC section, "Changing Engine Coolant".
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-365.
- 3) Turn ignition switch "ON".
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
- 5) If the results are NG, go to "Diagnostic Procedure", EC-365.

Without CONSULT-II



- 1) Check the coolant level and mixture ratio (using coolant tester) in the reservoir tank and radiator.
Allow engine to cool before checking coolant level and mixture ratio.
 - If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-365.
 - If the coolant mixture ratio is out of the range of 45 to 55% (varies depending on destinations), replace the coolant in the following procedure LC section, "Changing Engine Coolant".
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-365.
- 3) Start engine.
Be careful not to overheat engine.
- 4) Set temperature control lever to full cold position.
- 5) Turn air conditioner switch "ON".
- 6) Turn blower fan switch "ON".
- 7) Run engine at idle for a few minutes with air conditioner operating.
Be careful not to overheat engine.
- 8) Make sure that cooling fan operates. Refer to "OPERATION" table of Cooling fan, EC-361.
If NG, go to "Diagnostic Procedure", EC-365.

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)


Wiring Diagram

EC-COOL/F-01



DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)



A

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	XXX °C


SEF646X

B

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	XXX °C

SEF111X





Diagnostic Procedure



DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)


Diagnostic Procedure (Cont'd)



DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)




E

CHECK COOLING SYSTEM FOR LEAK.
Apply pressure to the cooling system with a tester, and check if the pressure drops.
Testing pressure:
157 kPa (1.6 kg/cm², 23 psi)
CAUTION:
Higher than the specified pressure may cause radiator damage.
Pressure should not drop.

NG → Check the following for leak.

- Hose
- Radiator
- Water pump (Refer to LC section, "Water Pump".)


If NG, repair or replace.



F

CHECK RADIATOR CAP.
Apply pressure to cap with a tester and check radiator cap relief pressure.
Radiator cap relief pressure:
For the Middle East:
78 - 98 kPa (0.78 - 0.98 bar, 0.8 - 1.0 kg/cm², 11 - 14 psi)
Except above:
108 - 127 kPa (1.08 - 1.27 bar, 1.1 - 1.3 kg/cm², 16 - 18 psi)

NG → Replace radiator cap.



G

CHECK THERMOSTAT.

1. Remove thermostat.
2. Check valve seating condition at normal room temperatures.
It should seat tightly.
3. Check valve opening temperature and valve lift.
Valve opening temperature:
76.5°C (170°F) [standard]
Valve lift:
More than 10 mm/90°C (0.39 in/194°F)
4. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC section, "Thermostat".

NG → Replace thermostat.

CHECK ENGINE COOLANT TEMPERATURE SENSOR.
Refer to "COMPONENT INSPECTION", EC-156.

NG → Replace engine coolant temperature sensor.




CHECK MAIN 12 CAUSES.
If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-370.

CHECK INSPECTION END

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)


Diagnostic Procedure (Cont'd)



DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)



J

①

CHECK COOLING FAN POWER SUPPLY CIRCUIT.


1. Turn ignition switch "OFF".
2. Disconnect cooling fan relays-2 and -3.
3. Turn ignition switch "ON".
4. Check voltage between cooling fan relays-2 and -3 terminals ①, ⑥ and ground with CONSULT-II or tester.

Battery voltage

NG → Check the following.

- Harness for open or short between cooling fan relays-2 and -3 and 10A fuse
- Harness for open or short between cooling fan relays-2 and fusible link

If NG, repair harness or connectors.




K

CHECK COOLING FAN GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.
3. Check harness continuity between cooling fan relay-2 terminal ⑦ and cooling fan motor-1 terminal ②, cooling fan relay-2 terminal ③ and cooling fan motor-1 terminal ③, cooling fan relay-2 terminal ⑤ and body ground. Refer to Wiring Diagram.
Continuity should exist.
4. Also check harness for short to ground and short to power.
5. Check harness continuity between cooling fan relay-3 terminal ⑦ and cooling fan motor-2 terminal ②, cooling fan relay-3 terminal ③, cooling fan relay-2 terminal ⑤. Refer to Wiring Diagram.
Continuity should exist.
6. Also check harness for short to ground and short to power.

NG → Repair open circuit or short to ground or short to power in harness or connectors.



K

CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT.

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal ⑥ and cooling fan relay-2 terminal ②, cooling fan relay-3 terminal ②. Refer to Wiring Diagram.
Continuity should exist.
3. Also check harness for short to ground and short to power.

NG → Check the following.

- Harness connectors (E127), (M21)
- Harness connectors (M52), (F7)
- Harness for open or short between cooling fan relay-2 and -3 and ECM

If NG, repair open circuit or short to ground or short to power in harness or connectors.

CHECK COOLING FAN RELAYS-2 AND -3.
Refer to "Component Inspection", EC-371.

NG → Replace cooling fan relays.

CHECK COOLING FAN MOTORS.
Refer to "Component Inspection", EC-371.

NG → Replace cooling fan motors.

CHECK INTERMITTENT INCIDENT.
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-112.

INSPECTION END

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)

Main 12 Causes of Overheating

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	30 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section.
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
	4	● Radiator cap	● Pressure tester	108 - 127 kPa (1.08 - 1.27 bar, 1.1 - 1.3 kg/cm ² , 16 - 18 psi) 59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See "System Check", "ENGINE COOLING SYSTEM" in LC section.
ON*2	5	● Coolant leaks	● Visual	No leaks	See "System Check", "ENGINE COOLING SYSTEM" in LC section.
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot.	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section.
ON*1	7	● Cooling fan	● Visual (Coupling) ● CONSULT-II	Operating	See "TROUBLE DIAGNOSIS FOR DTC P1217", EC-361.
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 gas analyzer	Negative	—
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See "ENGINE MAINTENANCE" in MA section.
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYLINDER HEAD" in EM section.
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See "Inspection", "CYLINDER BLOCK" in EM section.

*1: Engine running at idle for coupling type. Turn ignition switch ON for electrical cooling fan.

*2: Engine running at 3,000 rpm for 10 minutes.


*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

TB48DE A/T (WITH EURO-OBD)



Component Inspection

COOLING FAN RELAYS-1, -2 AND -3


Check continuity between terminals ③ and ⑤, ⑥ and ⑦.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

If NG, replace relay.

COOLING FAN MOTORS-1 AND -2


1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.



	Speed	Terminals	
		(+)	(-)
Cooling fan motor	Low	1	4
	High	1, 2	3, 4

Cooling fan motor should operate.

If NG, replace cooling fan motor.



Component Description

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance problem	Closed throttle position learning value is excessively low.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

The screenshot shows the CONSULT-II interface. At the top, it says 'DATA MONITOR'. Below that, there are two columns: 'MONITOR' and 'NO DTC'. Under 'MONITOR', it displays 'ENG SPEED' and 'XXX rpm'. The rest of the screen is blank. The identifier 'SEF058Y' is located at the bottom right of the screenshot.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds.
4. Turn ignition switch "ON".
5. If 1st trip DTC is detected, go to EC-373, "Diagnostic Procedure".


WITH GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure

1 CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.



SEC183D


OK or NG

OK	▶	GO TO 2.
NG	▶	Remove the foreign matter and clean the electric throttle control actuator inside.

2 REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform EC-31, "Accelerator Pedal Released Position Learning".
3. Perform EC-31, "Throttle Valve Closed Position Learning".
4. Perform EC-31, "Idle Air Volume Learning".

▶ **INSPECTION END**



Component Description

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226 1226	Closed throttle position learning performance problem	Closed throttle position learning is not performed successfully, repeatedly.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)


DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.



WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds.
4. Turn ignition switch "ON".
5. Repeat steps 3 and 4, 32 times.
6. If 1st trip DTC is detected, go to EC-375, "Diagnostic Procedure".


WITH GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure

1 CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.



SEC183D

OK or NG

OK	▶	GO TO 2.
NG	▶	Remove the foreign matter and clean the electric throttle control actuator inside.

2 REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform EC-31, "Accelerator Pedal Released Position Learning".
3. Perform EC-31, "Throttle Valve Closed Position Learning".
4. Perform EC-31, "Idle Air Volume Learning".

▶ **INSPECTION END**

DTC P1229 SENSOR POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor 1 and 2 circuit is shorted.) (APP sensor circuit is shorted.) (MAF sensor circuit is shorted.) (Power steering pressure sensor circuit is shorted.) (Refrigerant pressure sensor circuit is shorted.) ● Electric throttle control actuator (TP sensor 1 and 2) ● Accelerator pedal position sensor (APP sensor 1) ● MAF sensor ● Power steering pressure sensor ● Refrigerant pressure sensor ● ECM pin terminal

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.


DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.



WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to EC-378, “Diagnostic Procedure”.

WITH GST

Follow the procedure “WITH CONSULT-II” above.



DTC P1229 SENSOR POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-SEN/PW-01

: Detectable line for DTC
 : Non-detectable line for DTC



DTC P1229 SENSOR POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
103	Y	Sensors' power supply	Ignition switch "ON"	Approximately 5V

Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
SEC690C	
▶ GO TO 2.	


DTC P1229 SENSOR POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2 CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT


1. Disconnect electric throttle control actuator harness connector.



SEC182D

2. Turn ignition switch "ON".

3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.



PBIB0082E

Voltage: Approximately 5V

OK or NG

OK	▶	GO TO 4.
NG	▶	GO TO 3.

3 CHECK SENSOR POWER SUPPLY CIRCUITS FOR SHORT

Check the following.

- Harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminals	Reference Wiring Diagram
103	Electric throttle actuator terminal 1	EC-449
	APP sensor terminal 7	EC-455
	MAF sensor terminal 2	EC-174
	Power steering pressure sensor terminal 1	EC-311
	Refrigerant pressure sensor terminal 1	EC-498

MTBL1592

- ECM pin terminal.

OK or NG

OK	▶	GO TO 4.
NG	▶	Repair short to ground or short to power in harness or connectors.

DTC P1229 SENSOR POWER SUPPLY

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4	CHECK COMPONENTS
Check the following. <ul style="list-style-type: none">● Accelerator pedal position sensor (Refer to EC-427, "Component Inspection".)● Mass air flow sensor (Refer to EC-146, "Component Inspection".)● Power steering pressure sensor (Refer to EC-282, "Component Inspection".) <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Replace malfunctioning component.



5	CHECK THROTTLE POSITION SENSOR
Refer to EC-420, "Component Inspection". <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

6	REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR
1. Replace electric throttle control actuator. 2. Perform EC-31, "Accelerator Pedal Released Position Learning". 3. Perform EC-31, "Throttle Valve Closed Position Learning". 4. Perform EC-31, "Idle Air Volume Learning".	
	▶ INSPECTION END

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
	▶ INSPECTION END

DTC P1336 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)



Component Description

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil. When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
111	W	Crankshaft position sensor (OBD)	Engine is running. └ Warm-up condition. └ Idle speed	Approximately 1 - 2V★ SEC748D
			Engine is running. └ Engine speed is 2,000 rpm	3 - 4V★ (AC range) SEC749D

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

DTC P1336 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)

On Board Diagnosis Logic

Malfunction is detected when a chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM.

POSSIBLE CAUSE

- Harness or connectors
- Crankshaft position sensor (OBD)
- Drive plate/Flywheel

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With CONSULT-II

1. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine and run it for at least 2 minutes at idle speed.
3. If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-384.

With GST



Follow the procedure “With CONSULT-II”.

DTC P1336 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-CKPS-01



Refer to last page (Foldout page).


(M21), (E127)


TEC344M

DTC P1336 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<p>1. Turn ignition switch OFF. 2. Loosen and retighten engine ground screws.</p>	
	
SEC690C	
▶ GO TO 2.	

2	CHECK CKPS (OBD) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.</p>	
	
SEC732D	
<p>2. Check continuity between ECM terminal 111 and sensor terminal 1. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E201, E70 ● Harness connectors E127, M21 ● Harness connectors M51, F6 ● Harness for open or short between ECM and crankshaft position sensor (OBD) 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

DTC P1336 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

4 CHECK CKPS (OBD) GROUND CIRCUIT FOR OPEN AND SHORT	
1. Reconnect ECM harness connectors. 2. Check harness continuity between CKPS (OBD) terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.



5 DETECT MALFUNCTIONING PART	
Check the following. <ul style="list-style-type: none">● Harness connectors E202, E69● Harness connectors E127, M21● Harness connectors M51, F6● Harness for open between crankshaft position sensor (OBD) and ECM	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.

6 CHECK IMPROPER INSTALLATION	
1. Loosen and retighten the fixing bolt of the crankshaft position sensor (OBD). 2. Perform "DTC Confirmation Procedure", again. Is a 1st trip DTC P1336 detected? <p style="text-align: center;">Yes or No</p>	
Yes	▶ GO TO 7.
No	▶ INSPECTION END

DTC P1336 CKP SENSOR (OBD)

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

7	CHECK CRANKSHAFT POSITION SENSOR (OBD)
<p>1. Disconnect crankshaft position sensor (OBD) harness connector. 2. Loosen the fixing bolt of the sensor. 3. Remove the sensor. 4. Visually check the sensor for chipping.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF960N</p> <p>5. Check resistance as shown in the figure.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF504V</p> <p>Resistance: Approximately 512 - 632Ω [at 20°C (68°F)] OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ Replace crankshaft position sensor (OBD).

8	CHECK CKPS (OBD) SHIELD CIRCUIT FOR OPEN AND SHORT
<p>1. Disconnect harness connectors E201, E70. 2. Check harness continuity between harness connector E70 terminal 10 and engine ground. Continuity should exist. 3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 10.
NG	▶ GO TO 9.

9	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E201, E70 ● Harness connectors E127, M21 ● Harness connectors M51, F6 ● Joint connector-7 ● Harness for open between harness connector F38 and engine ground 	
▶	Repair open circuit or short to power in harness or connectors.

**DTC P1336 CKP SENSOR
(OBD)**

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

10	CHECK GEAR TOOTH
Visually check for chipping flywheel or drive plate gear tooth (cog). OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace the flywheel or drive plate.

11	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-112.	
	▶ INSPECTION END

DTC P1706 PNP SWITCH

TB48DE A/T (WITH EURO-OBD)

Component Description

When the shift lever position is “P” or “N”, park/neutral position (PNP) switch is “ON”. ECM detects the position because the continuity of the line (the “ON” signal) exists.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N ON
		Shift lever: Except above OFF

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706 1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none"> ● Harness or connectors (PNP switch circuit is open or shorted.) ● Park/neutral position (PNP) switch

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

SEF212Y

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “P/N POSI SW” in “DATA MONITOR” mode with CONSULT-II. Then check the “P/N POSI SW” signal under the following conditions.

Position (Selector lever)	Known-good signal
“N” and “P” position	ON
Except the above position	OFF

If NG, go to EC-392, “Diagnostic Procedure”.

If OK, go to following step.

3. Select “DATA MONITOR” mode with CONSULT-II.
4. Start engine and warm it up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.


ENG SPEED	1,250 - 6,375 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	More than 5 msec
VHCL SPEED SE	More than 64 km/h (40 MPH)
Selector lever	Suitable position

DTC Confirmation Procedure (Cont'd)

- If 1st trip DTC is detected, go to EC-392, "Diagnostic Procedure".

Overall Function Check

Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.



WITH GST

- Turn ignition switch "ON".
- Check voltage between ECM terminal 80 (PNP switch signal) and body ground under the following conditions.

Condition (Gear position)	Voltage V (Known-good data)
"P" and "N" position	Approximately 0
Except the above position	Battery voltage



- If NG, go to EC-392, "Diagnostic Procedure".

DTC P1706 PNP SWITCH

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-PNP/SW-01









Refer to last page (Foldout page).
 (M21), (E127)

DTC P1706 PNP SWITCH

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

EC-PNP/SW-02



*: This connector is not shown in "HARNESS LAYOUT", EL section.

DTC P1706 PNP SWITCH

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
80	R/PU	PNP switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ Shift lever position is "P" or "N".	Approximately 0V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> ↳ Except the above gear position	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

1	INSPECTION START
Do you have CONSULT-II?	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

2	CHECK PNP SWITCH SIGNAL						
1. Turn ignition switch "ON". 2. Select "A/T", then "DATA MONITOR" mode while CONSULT-II. 3. Select "P/N POSI SW" signal and check its indication under the following conditions.							
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITORING</th> <th style="width: 50%;">NO DTC</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">P/N POSI SW</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>		DATA MONITOR		MONITORING	NO DTC	P/N POSI SW	ON
DATA MONITOR							
MONITORING	NO DTC						
P/N POSI SW	ON						
PBIB0102E							
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition (Gear position)</th> <th style="width: 50%;">P/N POSI SW</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">"P" or "N" position</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">Other positions</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table>		Condition (Gear position)	P/N POSI SW	"P" or "N" position	ON	Other positions	OFF
Condition (Gear position)	P/N POSI SW						
"P" or "N" position	ON						
Other positions	OFF						
MTBL1597							
OK or NG							
OK	▶ GO TO 5.						
NG	▶ GO TO 4.						



DTC P1706 PNP SWITCH

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	CHECK PNP SWITCH SIGNAL
Confirm that the PNP switch signal is sent to TCM correctly. Refer to AT section.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	CHECK PNP SWITCH CIRCUIT
Check the PNP switch circuit. Refer to AT section.	
▶ INSPECTION END	

5	CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I
<p>1. Turn ignition switch "OFF". 2. Disconnect TCM harness connector.</p> <div style="text-align: center;">  <p>TCM</p> </div> <p style="text-align: right;">SEC298D</p> <p>3. Disconnect park/neutral position relay-3 harness connector.</p> <div style="text-align: center;">  <p>Air cleaner Throttle control motor relay Vehicle front Park/Neutral position relay-3</p> </div> <p style="text-align: right;">SEC185D</p> <p>4. Check harness continuity between TCM terminal 48 and park/neutral position relay-3 terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1706 PNP SWITCH

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

6	CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II	
<p>1. Check harness continuity between park/neutral position relay-3 terminal 1, 6 and ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 7.
NG	▶	Repair open circuit or short to power in harness or connectors.

7	CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-III	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 80 and park/neutral position relay-3 terminal 7. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

8	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F7, M52 ● Harness connectors M21, E127 ● Harness for open between ECM and park/neutral position relay-3 		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.

9	CHECK PARK/NEUTRAL POSITION RELAY-3	
<p>Refer to AT section.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	
NG	▶	

10	CHECK INTERMITTENT INCIDENT	
<p>Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".</p>		
		▶ INSPECTION END

DTC P1805 BRAKE SWITCH

TB48DE A/T (WITH EURO-OBD)

Description

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON

On Board Diagnosis Logic

The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805 1805	Brake switch	A brake switch signal is not sent to ECM for an extremely long time while the vehicle is driving.	● Harness or connectors (Stop lamp switch circuit is open or shorted.) ● Stop lamp switch

FALI-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM controls the electric throttle control actuator by regulating the throttle opening to a small range. Therefore, acceleration will be poor.

Vehicle condition	Driving condition
When engine is idling	Normal
When accelerating	Poor acceleration

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC Confirmation Procedure

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the DTC with CONSULT-II.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If 1st trip DTC is detected, go to EC-397, "Diagnostic Procedure".

WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P1805 BRAKE SWITCH

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-BRK/SW-01

: Detectable line for DTC
 : Non-detectable line for DTC



Refer to last page (Foldout page).

(M3)

DTC P1805 BRAKE SWITCH

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
106	G/Y	Stop lamp switch	Engine is running. └ Brake pedal fully released	Approximately 0V
			Engine is running. └ Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

1	CHECK STOP LAMP SWITCH CIRCUIT							
<p>1. Turn ignition switch "OFF". 2. Check the stop lamp when depressing and releasing the brake pedal.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <tr> <td style="padding: 5px;">Brake pedal</td> <td style="padding: 5px;">Stop lamp</td> </tr> <tr> <td style="padding: 5px;">Fully released</td> <td style="padding: 5px;">Not illuminated</td> </tr> <tr> <td style="padding: 5px;">Depressed</td> <td style="padding: 5px;">Illuminated</td> </tr> </table>			Brake pedal	Stop lamp	Fully released	Not illuminated	Depressed	Illuminated
Brake pedal	Stop lamp							
Fully released	Not illuminated							
Depressed	Illuminated							
MTBL1593								
OK or NG								
OK	▶	GO TO 4.						
NG	▶	GO TO 2.						


DTC P1805 BRAKE SWITCH

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)


2 CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch harness connector.



SEC194D

2. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.



PBIB0117E

Voltage: Battery voltage

OK or NG

OK	▶	GO TO 4.
NG	▶	GO TO 3.

3 DETECT MALFUNCTIONING PART

Check the following.


- 10A fuse
- Fuse block (J/B) connector M3
- Harness for open and short between stop lamp switch and battery

▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1805 BRAKE SWITCH

TB48DE A/T (WITH EURO-OBD)


Diagnostic Procedure (Cont'd)

4	CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Disconnect stop lamp switch harness connector.</p>	
	
SEC194D	
<p>4. Check harness continuity between ECM terminal 106 and stop lamp switch terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M52, F7 ● Harness for open or short between ECM and stop lamp switch 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

6	CHECK STOP LAMP SWITCH
Refer to EC-399, "Component Inspection".	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace stop lamp switch.

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	



Component Inspection

STOP LAMP SWITCH

1. Disconnect stop lamp switch harness connector.

DTC P1805 BRAKE SWITCH


TB48DE A/T (WITH EURO-OBD)


Component Inspection (Cont'd)

2. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Conditions	Continuity
Brake pedal fully released	Should not exist.
Brake pedal depressed	Should exist.

If NG, adjust brake pedal installation, refer to BR section, and perform step 2 again.





Component Description

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ACCEL SEN1 ACCEL SEN2*	● Ignition switch: ON (engine stopped) ● Shift lever position is "D" Accelerator pedal: Fully released	More than 0.36V
	Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (engine stopped) ● Shift lever position is "D" Accelerator pedal: Fully released	ON
	Accelerator pedal: Slightly depressed	OFF

*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2122 2122	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 1 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 1)
P2123 2123	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH CONSULT-II



1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to EC-405, “Diagnostic Procedure”.

WITH GST

Follow the procedure “WITH CONSULT-II” above.

Wiring Diagram

EC-APPS1-01



DTC P2122, P2123 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
87	W	Accelerator pedal position sensor 1	Ignition switch "ON"	More than 0.36V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released 	
89	B	Sensor ground (Accelerator pedal position sensor 1)	Ignition switch "ON"	Less than 4.75V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed 	
89	B	Sensor ground (Accelerator pedal position sensor 1)	Engine is running. <ul style="list-style-type: none"> └ Warm-up condition. └ Idle speed 	Approximately 0V
94	LG	Sensor power supply (Accelerator pedal position sensor 2)	Ignition switch "ON"	Approximately 2.5V
100	R	Sensor ground (Accelerator pedal position sensor 2)	Ignition switch "ON"	Approximately 0V
103	Y	Sensor power supply (Accelerator pedal position sensor 1)	Ignition switch "ON"	Approximately 5V
117	G	Accelerator pedal position sensor 2	Ignition switch "ON"	More than 0.18V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released 	
117	G	Accelerator pedal position sensor 2	Ignition switch "ON"	Less than 2.37V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed 	

Diagnostic Procedure

1 RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.




SEC690C

▶ GO TO 2.


2 CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.



SEC182D

2. Turn ignition switch "ON".
3. Check voltage between APP sensor terminal 7 and ground with CONSULT-II or tester.



SEC673D

Voltage: Approximately 5V

OK or NG

OK	▶	GO TO 4.
NG	▶	GO TO 3.

DTC P2122, P2123 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)


3	DETECT MALFUNCTIONING PART		
Check the following.			
<ul style="list-style-type: none"> ● Harness for open or short between ECM and accelerator pedal position sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
4	CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT		
1. Turn ignition switch "OFF".			
2. Disconnect ECM harness connector.			
3. Check harness continuity between APP sensor terminal 9 and ground. Refer to Wiring Diagram.			
Continuity should exist.			
4. Also check harness for short to ground and short to power.			
OK or NG			
OK		▶	GO TO 6.
NG		▶	GO TO 5.
5	DETECT MALFUNCTIONING PART		
Check the following.			
<ul style="list-style-type: none"> ● Harness for open or short between ECM and accelerator pedal position sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
6	CHECK APP SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT		
1. Check harness continuity between ECM terminal 87 and APP sensor terminal 8. Refer to Wiring Diagram.			
Continuity should exist.			
2. Also check harness for short to ground and short to power.			
OK or NG			
OK		▶	GO TO 8.
NG		▶	GO TO 7.
7	DETECT MALFUNCTIONING PART		
Check the following.			
<ul style="list-style-type: none"> ● Harness for open or short between ECM and accelerator pedal position sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK APP SENSOR		
Refer to EC-407, "Component Inspection".			
OK or NG			
OK		▶	GO TO 10.
NG		▶	GO TO 9.
9	REPLACE APP SENSOR		
1. Replace the accelerator pedal position sensor.			
2. Perform EC-31, "Accelerator Pedal Released Position Learning".			
3. Perform EC-31, "Throttle Valve Closed Position Learning".			
4. Perform EC-31, "Idle Air Volume Learning".			
		▶	INSPECTION END

DTC P2122, P2123 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

10	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	




Component Inspection

ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 87 (APP sensor 1 signal), 117 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
87 (Accelerator pedal position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
117 (Accelerator pedal position sensor 2)	Fully released	More than 0.18V
	Fully depressed	Less than 2.37V

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform EC-31, "Accelerator Pedal Released Position Learning".
6. Perform EC-31, "Throttle Valve Closed Position Learning".
7. Perform EC-31, "Idle Air Volume Learning".



Component Description

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ACCEL SEN1 ACCEL SEN2*	● Ignition switch: ON (engine stopped) ● Shift lever position is "D" Accelerator pedal: Fully released	More than 0.36
	Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (engine stopped) ● Shift lever position is "D" Accelerator pedal: Fully released	ON
	Accelerator pedal: Slightly depressed	OFF

*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2127 2127	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 2 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 2)
P2128 2128	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH CONSULT-II



1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to EC-411, “Diagnostic Procedure”.

WITH GST

Follow the procedure “WITH CONSULT-II” above.

Wiring Diagram

EC-APPS2-01



DTC P2127, P2128 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
87	W	Accelerator pedal position sensor 1	Ignition switch "ON"	More than 0.36V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released 	
89	B	Sensors' ground	Ignition switch "ON"	Less than 4.75V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed 	
94	LG	Sensor power supply (Accelerator pedal position sensor 2)	Ignition switch "ON"	Approximately 2.5V
100	R	Sensor ground (Accelerator pedal position sensor 2)	Ignition switch "ON"	Approximately 0V
103	Y	Sensors' power supply	Ignition switch "ON"	Approximately 5V
117	G	Accelerator pedal position sensor 2	Ignition switch "ON"	More than 0.18V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released 	
117	G	Accelerator pedal position sensor 2	Ignition switch "ON"	Less than 2.37V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed 	




Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p>	
	
SEC690C	
▶ GO TO 2.	

DTC P2127, P2128 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2	CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT	<p>1. Disconnect accelerator pedal position (APP) sensor harness connector.</p> <div style="text-align: center;"> <p>View with intake air duct removed</p>  <p>Electric throttle control actuator Accelerator pedal position sensor harness connector Throttle position sensor and throttle control motor harness connector</p> </div> <p style="text-align: right;">SEC182D</p> <p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between APP sensor terminal 10 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">   </div> <p style="text-align: right;">SEC674D</p> <p>Voltage: Approximately 2.5V</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 4.
NG	▶	GO TO 3.

3	DETECT MALFUNCTIONING PART	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ECM and accelerator pedal position sensor <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>
----------	-----------------------------------	--


4	CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT	<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between APP sensor terminal 12 and ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 6.
NG	▶	GO TO 5.

DTC P2127, P2128 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	DETECT MALFUNCTIONING PART	
Check the following. ● Harness for open or short between ECM and accelerator pedal position sensor		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.
6	CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	
1. Check harness continuity between ECM terminal 117 and APP sensor terminal 11. Refer to Wiring Diagram. Continuity should exist.		
2. Also check harness for short to ground and short to power. <div style="text-align: right;">OK or NG</div>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.
7	DETECT MALFUNCTIONING PART	
Check the following. ● Harness for open or short between ECM and accelerator pedal position sensor		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK APP SENSOR	
Refer to EC-414, "Component Inspection". <div style="text-align: right;">OK or NG</div>		
OK	▶	GO TO 10.
NG	▶	GO TO 9.
9	REPLACE APP SENSOR	
1. Replace the accelerator pedal position sensor. 2. Perform EC-31, "Accelerator Pedal Released Position Learning". 3. Perform EC-31, "Throttle Valve Closed Position Learning". 4. Perform EC-31, "Idle Air Volume Learning".		
		▶ INSPECTION END
10	CHECK INTERMITTENT INCIDENT	
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".		
		▶ INSPECTION END




Component Inspection

ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 87 (APP sensor 1 signal), 117 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
87 (Accelerator pedal position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
117 (Accelerator pedal position sensor 2)	Fully released	More than 0.18V
	Fully depressed	Less than 2.37V

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform EC-31, "Accelerator Pedal Released Position Learning".
6. Perform EC-31, "Throttle Valve Closed Position Learning".
7. Perform EC-31, "Idle Air Volume Learning".



Component Description

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement. The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN1 THRTL SEN2*	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Shift lever: D 	Accelerator pedal: Fully released	More than 0.5V
		Accelerator pedal: Fully depressed	Less than 1.5V

*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2135 2135	Throttle position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul style="list-style-type: none"> Harness or connector (The TP sensor 1 and 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1 and 2)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH CONSULT-II**

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to EC-418, “Diagnostic Procedure”.



 **WITH GST**

Follow the procedure “WITH CONSULT-II” above.

Wiring Diagram

EC-TPS3-01

: Detectable line for DTC
 : Non-detectable line for DTC



DTC P2135 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
89	B	Sensor ground (Throttle position sensor)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └─ Warm-up condition. └─ Idle speed	Approximately 0V
98	R/L	Throttle position sensor 2	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully released	Less than 4.75V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully depressed	More than 0.36V
103	Y	Sensor power supply (Throttle position sensor)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 5V
108	L	Throttle position sensor 1	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully released	More than 0.36V
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └─ Engine stopped └─ Shift lever position is "D" └─ Accelerator pedal fully depressed	Less than 4.75V



Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.	
	
SEC690C	
▶ GO TO 2.	

DTC P2135 TP SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2	CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT
<p>1. Disconnect electric throttle control actuator harness connector.</p> <div style="text-align: center;"> <p>View with intake air duct removed</p>  </div>	
SEC182D	
<p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.</p>	
	
<p>Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between electric throttle control actuator terminal 5 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Check harness continuity between ECM terminal 108 and electric throttle control actuator terminal 4, ECM terminal 98 and electric throttle control actuator terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC P2135 TP SENSOR


TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	CHECK THROTTLE POSITION SENSOR
Refer to EC-420, "Component Inspection".	
OK or NG	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

6	REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR
<ol style="list-style-type: none"> 1. Replace the electric throttle control actuator. 2. Perform EC-31, "Accelerator Pedal Released Position Learning". 3. Perform EC-31, "Throttle Valve Closed Position Learning". 4. Perform EC-31, "Idle Air Volume Learning". 	
▶ INSPECTION END	

7	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	




Component Inspection

THROTTLE POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Perform EC-31, "Throttle Valve Closed Position Learning".
3. Turn ignition switch "ON".
4. Set selector lever to "D" position.
5. Check voltage between ECM terminals 108 (TP sensor 1 signal), 98 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
108 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
98 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform EC-31, "Accelerator Pedal Released Position Learning".
8. Perform EC-31, "Throttle Valve Closed Position Learning".
9. Perform EC-31, "Idle Air Volume Learning".



Component Description

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ACCEL SEN1 ACCEL SEN2*	● Ignition switch: ON (engine stopped) ● Shift lever position is "D" Accelerator pedal: Fully released	More than 0.36V
	Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (engine stopped) ● Shift lever position is "D" Accelerator pedal: Fully released	ON
	Accelerator pedal: Slightly depressed	OFF

*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2138 2138	Accelerator pedal position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul style="list-style-type: none"> ● Harness or connector (The APP sensor 1 and 2 circuit is open or shorted.) ● Accelerator pedal position sensor 1 and 2

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH CONSULT-II**

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to EC-425, “Diagnostic Procedure”.

 **WITH GST**



Follow the procedure “WITH CONSULT-II” above.

DTC P2138 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-APPS3-01



TEC403M

DTC P2138 APP SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)


Specification data are reference values and are measured between each terminal and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
87	W	Accelerator pedal position sensor 1	Ignition switch "ON"	More than 0.36V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released 	
87	W	Accelerator pedal position sensor 1	Ignition switch "ON"	Less than 4.75V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed 	
89	B	Sensor ground (Accelerator pedal position sensor 1)	Engine is running. <ul style="list-style-type: none"> └ Warm-up condition. └ Idle speed 	Approximately 0V
94	LG	Sensor power supply (Accelerator pedal position sensor 2)	Ignition switch "ON"	Approximately 2.5V
100	R	Sensor ground (Accelerator pedal position sensor 2)	Ignition switch "ON"	Approximately 0V
103	Y	Sensor power supply (Accelerator pedal position sensor 1)	Ignition switch "ON"	Approximately 5V
117	G	Accelerator pedal position sensor 2	Ignition switch "ON"	More than 0.18V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully released 	
117	G	Accelerator pedal position sensor 2	Ignition switch "ON"	Less than 2.37V
			<ul style="list-style-type: none"> └ Engine stopped └ Shift lever position is "D" └ Accelerator pedal fully depressed 	

Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
SEC690C	
▶ GO TO 2.	

2	CHECK APP SENSOR POWER SUPPLY CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect accelerator pedal position (APP) sensor harness connector. 	
	
SEC182D	
<ol style="list-style-type: none"> 2. Turn ignition switch "ON". 3. Check voltage between APP sensor terminals 7, 10 and ground with CONSULT-II or tester. 	
	
<p>Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

PBIB0084E

DTC P2138 APP SENSOR


TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

3	DETECT MALFUNCTIONING PART		
Check the following.			
<ul style="list-style-type: none"> ● Harness for open or short between ECM and accelerator pedal position sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
4	CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT		
1. Turn ignition switch "OFF".			
2. Disconnect ECM harness connector.			
3. Check harness continuity between APP sensor terminals 9, 12 and ground. Refer to Wiring Diagram.			
Continuity should exist.			
4. Also check harness for short to ground and short to power.			
OK or NG			
OK		▶	GO TO 6.
NG		▶	GO TO 5.
5	DETECT MALFUNCTIONING PART		
Check the following.			
<ul style="list-style-type: none"> ● Harness for open or short between ECM and accelerator pedal position sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
6	CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT		
1. Check harness continuity between ECM terminal 87 and APP sensor terminal 8, ECM terminal 117 and APP sensor terminal 11. Refer to Wiring Diagram.			
Continuity should exist.			
2. Also check harness for short to ground and short to power.			
OK or NG			
OK		▶	GO TO 8.
NG		▶	GO TO 7.
7	DETECT MALFUNCTIONING PART		
Check the following.			
<ul style="list-style-type: none"> ● Harness for open or short between ECM and accelerator pedal position sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK APP SENSOR		
Refer to EC-427, "Component Inspection".			
OK or NG			
OK		▶	GO TO 10.
NG		▶	GO TO 9.
9	REPLACE APP SENSOR		
1. Replace the accelerator pedal position sensor.			
2. Perform EC-31, "Accelerator Pedal Released Position Learning".			
3. Perform EC-31, "Throttle Valve Closed Position Learning".			
4. Perform EC-31, "Idle Air Volume Learning".			
		▶	INSPECTION END

10 CHECK INTERMITTENT INCIDENT

Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".




Component Inspection

ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 87 (APP sensor 1 signal), 117 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
87 (Accelerator pedal position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
117 (Accelerator pedal position sensor 2)	Fully released	More than 0.18V
	Fully depressed	Less than 2.37V

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform EC-31, "Accelerator Pedal Released Position Learning".
6. Perform EC-31, "Throttle Valve Closed Position Learning".
7. Perform EC-31, "Idle Air Volume Learning".



Component Description

IGNITION COIL & POWER TRANSISTOR

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
42	B/Y	ECM relay (Self shut-off)	Engine is running.	0 - 1.0V
			Ignition switch "OFF" └ For a few seconds after turning ignition switch "OFF"	
			Ignition switch "OFF" └ More than a few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
163 166	B/R B/R	Power supply for ECM	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)

Wiring Diagram (Cont'd)

EC-IGNSYS-02





Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:




Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
18 19 20	Y/R G Y	Ignition signal No. 1 Ignition signal No. 2 Ignition signal No. 3	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <div style="margin-left: 20px;">└─ Warm-up condition. └─ Idle speed</div>	<p>0 - 0.1V★</p>  <p style="text-align: right;">PBIB0521E</p>
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <div style="margin-left: 20px;">└─ Warm-up condition. └─ Engine speed is 2,000 rpm</div>	<p>0 - 0.2V★</p>  <p style="text-align: right;">PBIB0522E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Wiring Diagram (Cont'd)

EC-IGNSYS-03





Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
21 29 30	R/B R/G R	Ignition signal No. 4 Ignition signal No. 5 Ignition signal No. 6	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <div style="margin-left: 20px;">└─ Warm-up condition. └─ Idle speed</div>	<p>0 - 0.1V★</p>  <p style="text-align: right;">PBIB0521E</p>
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> <div style="margin-left: 20px;">└─ Warm-up condition. └─ Engine speed is 2,000 rpm</div>	<p>0 - 0.2V★</p>  <p style="text-align: right;">PBIB0522E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

1	CHECK ENGINE START	
Turn ignition switch "OFF", and restart engine. Is engine running?		
Yes or No		
Yes (With CONSULT-II)	▶	GO TO 2.
Yes (Without CONSULT-II)	▶	GO TO 3.
No	▶	GO TO 4.

2	CHECK OVERALL FUNCTION																							
<p> With CONSULT-II</p> <p>1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II. 2. Make sure that each circuit produces a momentary engine speed drop.</p>																								
<table border="1"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>POWER BALANCE</th> <th></th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>ENG SPEED</th> <th>XXX rpm</th> </tr> <tr> <th>MAS A/F SE-B1</th> <th>XXX V</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table>			ACTIVE TEST		POWER BALANCE		MONITOR		ENG SPEED	XXX rpm	MAS A/F SE-B1	XXX V												
ACTIVE TEST																								
POWER BALANCE																								
MONITOR																								
ENG SPEED	XXX rpm																							
MAS A/F SE-B1	XXX V																							
OK or NG																								
OK	▶	INSPECTION END																						
NG	▶	GO TO 13.																						


PBIB0133E

Diagnostic Procedure (Cont'd)

3 CHECK OVERALL FUNCTION


⊗ Without CONSULT-II

1. Let engine idle.
2. Read the voltage signal between ECM terminals 18, 19, 20, 21, 29, 30 and ground with an oscilloscope.



SEC828C

3. Verify that the oscilloscope screen shows the signal wave as shown below.




PBIB0521E

OK or NG

OK	▶	INSPECTION END
NG	▶	GO TO 13.

4 CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "ON".
2. Check voltage between ECM terminals 163, 166 and ground with CONSULT-II or tester.



PBIB0135E

Voltage: Battery voltage


OK or NG

OK	▶	GO TO 5.
NG	▶	Go to EC-113, "POWER SUPPLY CIRCUIT FOR ECM".

Diagnostic Procedure (Cont'd)

5 CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Turn ignition switch "ON".
4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester.



Voltage: Battery voltage


OK or NG

PBIB0624E

OK	▶	GO TO 11.
NG	▶	GO TO 6.

6 CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch "OFF".
2. Disconnect ECM relay.



SEC668D

3. Check harness continuity between ECM relay terminal 3 and condenser terminal 1.
Refer to Wiring Diagram.
Continuity should exist.
4. Also check harness for short to ground and short to power.

OK or NG

OK	▶	GO TO 8.
NG	▶	GO TO 7.

7 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M55, F35
- Harness for open or short between ECM relay and condenser

▶ Repair open circuit or short to ground or short to power in harness or connectors.

Diagnostic Procedure (Cont'd)

8	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV
<p>Check voltage between ECM relay terminal 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;"> </div> <p>Voltage: Battery voltage</p> <p style="text-align: right;">SEC741D</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 10.
NG	▶ GO TO 9.

9	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● 15A fuse ● Harness for open or short between ECM relay and battery 	
	▶ Repair or replace harness or connectors.

10	CHECK ECM RELAY
<p>Refer to EC-112, "Component Inspection".</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 20.
NG	▶ Replace ECM relay.


11	CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect condenser harness connector. 3. Check harness continuity between condenser terminal 2 and ground. Refer to Wiring diagram. Continuity should exist. 4. Also check harness for short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 12.
NG	▶ Repair open circuit or short to power in harness or connector.

12	CHECK CONDENSER
<p>Refer to EC-441, "Component Inspection".</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 13.
NG	▶ Replace condenser.


Diagnostic Procedure (Cont'd)

13 CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V

1. Turn ignition switch "OFF".
2. Reconnect all harness connectors disconnected.
3. Disconnect ignition coil harness connector.




SEC783C



SEC784C

4. Turn ignition switch "ON".
5. Check voltage between ignition coil terminal 1 and ground with CONSULT-II or tester.



SEF107S

Voltage: Battery voltage

OK or NG

OK	▶	GO TO 15.
NG	▶	GO TO 14.

14 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F25, F121
- Harness for open or short between ignition coil and ECM relay

▶ Repair open circuit or short to ground or short to power in harness or connectors.

Diagnostic Procedure (Cont'd)

15	CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT	
<p>1. Turn ignition switch "OFF".</p> <p>2. Check harness continuity between ignition coil terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 17.
NG	▶	GO TO 16.


16	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F25, F121 ● Harness for open or short between ignition coil and ground 		
	▶	Repair open circuit or short to power in harness or connectors.

17	CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminals 18, 19, 20, 21, 29, 30 and ignition coil terminal 3. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 19.
NG	▶	GO TO 18.

18	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F25, F121 ● Harness for open or short between ECM and ignition coil 		
	▶	Repair open circuit or short to ground or short to power in harness or connectors.

19	CHECK IGNITION COIL WITH POWER TRANSISTOR	
<p>Refer to EC-441, "Component Inspection".</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 20.
NG	▶	Replace ignition coil with power transistor.

20	CHECK INTERMITTENT INCIDENT	
<p>Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".</p>		
	▶	INSPECTION END




Component Inspection

ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.


Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



CONDENSER


1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Check resistance between condenser terminals 1 and 2.
Resistance: Above 1 MΩ at 25°C (77°F)



IGNITION COIL WITH POWER TRANSISTOR

1. Turn ignition switch "OFF".
2. Disconnect ignition coil harness connector.
3. Check resistance between ignition coil terminals as follows.

Terminal No.	Resistance Ω [at 25°C (77°F)]
3 and 1	Except 0 or ∞
3 and 2	Except 0
1 and 2	



Component Description

To turn on the switch, push the lower side of it. The indicator light of the switch will illuminate and the transmission shifts into the snow driving mode.

- This mode is used for standing starts on slippery (snowy, sandy) roads.
- When the selector lever is in the D position, the transmission shifts from 1st to 5th gear automatically from standing starts or when accelerating from low speed.

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
60	Y/G	Snow mode switch	Ignition switch "ON" └ Snow mode switch is snow position. └ Snow switch is "ON".	Battery voltage (11 - 14V)
			Ignition switch "ON" └ Except above switch position	Approximately 0V

Wiring Diagram

EC-TRQ/SG-01



: Detectable line for DTC
 : Non-detectable line for DTC

L : LHD models
R : RHD models

- *1 66M : L
- 19M : R
- *2 65M : L
- 20M : R
- *3 23 : L
- 3 : R
- *4 47M : L
- 46M : R

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M51)
W

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M52)
W

151	152	153	1	2	3	4	5	6	7	8	9	10	11	43	44	45	46	47	48	49	50	51	52	53
154	155	156	12	13	14	15	16	17	18	19	20	21		54	55	56	57	58	59	60	61	62	63	
157	158	159	22	23	24	25	26	27	28	29	30	31	32	64	65	66	67	68	69	70	71	72	73	74
160	161	162	33	34	35	36	37	38	39	40	41	42		75	76	77	78	79	80	81	82	83	84	

(F38)
W




6		0	
7	2	1	


(B57)
W

Refer to last page (Foldout page).


(M20), (B19)
(M1)



Diagnostic Procedure



Diagnostic Procedure (Cont'd)




VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)

TB48DE A/T (WITH EURO-OBD)

Description

SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator
Mass air flow sensor	Amount of intake air	VIAS control	VIAS control solenoid valve
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Ignition switch	Start signal		
Camshaft position sensor	Engine speed		
Engine coolant temperature sensor	Engine coolant temperature		



When the engine is running at low or medium speed, the ECM sends the signal to the VIAS control solenoid valve then power valve is fully closed. Under this condition, the effective suction port length is equivalent to the total length of the intake manifold collector's suction port including the intake valve. This long suction port provides increased air intake which results in improved suction efficiency and higher torque generation.

The surge tank and one-way valve are provided. When engine is running at high speed, the ECM does not send the signal to the VIAS control solenoid valve, thus enabling power valve to be fully opened. This signal introduces the intake manifold vacuum into the power valve actuator and therefore opens the power valve to two suction passages together in the collector.



Under this condition, the effective port length is equivalent to the

VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)

TB48DE A/T (WITH EURO-OBD)

Description (Cont'd)

length of the suction port provided independently for each cylinder. This shortened port length results in enhanced engine output with reduced suction resistance under high speeds.



COMPONENT DESCRIPTION

Power valve

The power valve is installed in intake manifold collector and used to control the suction passage of the variable induction air control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the surge tank. The vacuum in the surge tank is controlled by the VIAS control solenoid valve.

VIAS control solenoid valve

The VIAS control solenoid valve cuts the intake manifold vacuum signal for power valve control. It responds to ON/OFF signals from the ECM. When the solenoid is off, the vacuum signal from the intake manifold is for high speed. When the ECM sends an ON signal the coil pulls the plunger downward and feeds the vacuum signal to the power valve actuator.

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
27	LG/R	VIAS control solenoid valve	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)
			Engine is running. └ Engine speed is above 5,000 rpm.	0 - 1.0V

VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)

TB48DE A/T (WITH EURO-OBD)


Wiring Diagram

EC-VIAS/V-01



Refer to last page (Foldout page).

M2






VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)

TB48DE A/T (WITH EURO-OBD)


A

ACTIVE TEST	
VIAS SOL VALVE	OFF
MONITOR	
ENG SPEED	XXX rpm
IACV-AAC/V	XXX step

SEC805C



Diagnostic Procedure



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	• Ignition switch: ON → START → ON	OFF → ON → OFF

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
59	R/W	Start signal	Ignition switch "ON"	Approximately 0V
			Ignition switch "START"	9 - 12V

Wiring Diagram

EC-S/SIG-01




1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M52)
W

3	5	1
4	2	6

(E114)
W



(F38)
W




Refer to last page (Foldout page).

(M3)
(E112)


A


DATA MONITOR	
MONITOR	NO DTC
START SIGNAL	OFF
CLSD THL POS	ON
AIR COND SIG	OFF
P/N POSI SW	ON

PBIB0182E



Diagnostic Procedure





Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	5.0 - 5.5 msec
		2,000 rpm	5.0 - 5.5 msec
INJ PULSE-B1 INJ PULSE-B2	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	3.0 - 4.0 msec
		2,000 rpm	3.0 - 4.0 msec



INJECTOR CIRCUIT TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
5	BR/W	Injector No. 1	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Engine is running.</div> <div style="margin-left: 20px;"> Warm-up condition. Idle speed </div>	BATTERY VOLTAGE (11 - 14V)★  PBIB0529E
6	GY/L	Injector No. 2		
7	BR/Y	Injector No. 3		
13	GY/R	Injector No. 4		
14	BR	Injector No. 5		
15	GY	Injector No. 6		
			<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Engine is running.</div> <div style="margin-left: 20px;"> Warm-up condition. Engine speed is 2,000 rpm </div>	BATTERY VOLTAGE (11 - 14V)★  PBIB0530E

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

1	INSPECTION START	
Turn ignition switch to "START".		
Is any cylinder ignited?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

Diagnostic Procedure (Cont'd)

2 CHECK OVERALL FUNCTION

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

3. Make sure that each circuit produces a momentary engine speed drop.

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.





MEC703B

Clicking noise should be heard.

OK or NG

OK	▶	INSPECTION END
NG	▶	GO TO 3.

Diagnostic Procedure (Cont'd)


3	CHECK INJECTOR POWER SUPPLY CIRCUIT	<p>1. Turn ignition switch "OFF". 2. Disconnect injector harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEC793C</p> <p>3. Turn ignition switch "ON". 4. Check voltage between injector terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">PBIB0289E</p> <p>Voltage: Battery voltage</p> <p align="center">OK or NG</p>
OK	▶	GO TO 5.
NG	▶	GO TO 4.

4	DETECT MALFUNCTIONING PART	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F12, F101 ● Harness connectors M52, F7 ● Fuse block (J/B) connector M2 ● 10A fuse ● Harness for open or short between injector and fuse <p align="right">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>
----------	-----------------------------------	--

5	CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between injector terminal 1 and ECM terminals 5, 6, 7, 13, 14, 15. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power.</p> <p align="center">OK or NG</p>
OK	▶	GO TO 7.
NG	▶	GO TO 6.

Diagnostic Procedure (Cont'd)

6	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors F101, F12 ● Harness for open or short between ECM and injector 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	
7	CHECK INJECTOR
Refer to EC-458, "Component Inspection". <p align="center">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ Replace injector.
8	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
▶ INSPECTION END	




Component Inspection

INJECTOR


1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.
Resistance: 13.5 - 17.5Ω [at 20°C (68°F)]

System Description



The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine storability. If the ECM receives a 120° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to operate. If the 120° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1 second.
Except as shown above	Stops.



Component Description

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).

CONSULT-II Reference Value in Data Monitor Mode

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> ● Ignition switch is turned to ON (Operates for 5 seconds). ● Engine running and cranking ● When engine is stopped (Stops in 1 second) 	ON
	Except as shown above	OFF

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
41	R/Y	Fuel pump relay	Ignition switch "ON" └ For 5 seconds after turning ignition switch "ON" Engine is running.	0 - 1.0V
			Ignition switch "ON" └ 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)






Wiring Diagram

EC-F/PUMP-01



Refer to last page (Foldout page).
 (M20), (B19)
 (M3)

Diagnostic Procedure





(Go to next page.)

Diagnostic Procedure (Cont'd)

D	ACTIVE TEST	
	FUEL PUMP RELAY	ON
	MONITOR	
	ENG SPEED	XXX rpm

SEF073Y






Component Inspection

FUEL PUMP RELAY

Check continuity between terminals ③ and ⑤.

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.




FUEL PUMP

1. Disconnect fuel pump harness connector.
2. Check resistance between terminals ④ and ⑥.
Resistance: 0.2 - 5.0Ω at 25°C (77°F)
 If NG, replace fuel pump.



REFRIGERANT PRESSURE SENSOR

TB48DE A/T (WITH EURO-OBD)



Component Description

The refrigerant pressure sensor is installed at the liquid tank of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.




REFRIGERANT PRESSURE SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram



EC-RP/SEN-01

 : Detectable line for DTC
 : Non-detectable line for DTC



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M51)
W



(F39)
W



Refer to last page (Foldout page).

(M21), (E127)

REFRIGERANT PRESSURE SENSOR

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
88	R/G	Refrigerant pressure sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └─ Warm-up condition. Both A/C switch and blower switch are "ON". (Compressor operates.)	1.0 - 4.0V
89	B	Sensor ground (Refrigerant pressure sensor)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └─ Warm-up condition. Idle speed	Approximately 0V
103	Y	Sensors' power supply	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 5V

Diagnostic Procedure

1	CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION
1. Start engine and warm it up to normal operating temperature. 2. Turn A/C switch and blower switch "ON". 3. Check voltage between ECM terminal 88 and ground with CONSULT-II or tester.	
<p>Voltage: 1.0 - 4.0V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ GO TO 2.

PBIB0187E


REFRIGERANT PRESSURE SENSOR

TB48DE A/T (WITH EURO-OBID)

Diagnostic Procedure (Cont'd)


2 CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn A/C switch and blower switch "OFF".
2. Stop engine.
3. Disconnect refrigerant pressure sensor harness connector.



SEC742D

4. Turn ignition switch "ON".
5. Check voltage between refrigerant pressure sensor terminal 1 and ground with CONSULT-II or tester.



PBIB0085E

Voltage: Approximately 5V

OK or NG

OK	▶	GO TO 4.
NG	▶	GO TO 3.

3 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E127, M21
- Harness connectors M51, F6
- Harness for open or short between ECM and refrigerant pressure sensor

▶ Repair open circuit or short to ground or short to power in harness or connectors.

4 CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between refrigerant pressure sensor terminal 3 and ground.
Refer to Wiring Diagram.
Continuity should exist.
4. Also check harness for short to ground and short to power.

OK or NG

OK	▶	GO TO 6.
NG	▶	GO TO 5.

REFRIGERANT PRESSURE SENSOR

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

5	DETECT MALFUNCTIONING PART		
Check the following. <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness connectors M51, F6 ● Harness for open or short between ECM and refrigerant pressure sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
6	CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT		
1. Check harness continuity between ECM terminal 88 and refrigerant pressure sensor terminal 2. Refer to Wiring Diagram. Continuity should exist.			
2. Also check harness for short to ground and short to power. <div style="text-align: center;">OK or NG</div>			
OK		▶	GO TO 8.
NG		▶	GO TO 7.
7	DETECT MALFUNCTIONING PART		
Check the following. <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness connectors M51, F6 ● Harness for open or short between ECM and refrigerant pressure sensor 			
		▶	Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK INTERMITTENT INCIDENT		
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT". <div style="text-align: center;">OK or NG</div>			
OK		▶	Replace refrigerant pressure sensor.
NG		▶	Repair or replace.

ELECTRICAL LOAD SIGNAL

TB48DE A/T (WITH EURO-OBD)

Description

The electrical load signal (Headlamp switch signal, rear window defogger switch signal, etc.) is transferred through the CAN communication line from combination meter to ECM.

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.





MONITOR ITEM	CONDITION		SPECIFICATION
LOAD SIGNAL	• Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is 2nd.	ON
		Rear window defogger switch is OFF and lighting switch is OFF.	OFF

ELECTRICAL LOAD SIGNAL

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram

EC-LOAD-01



Refer to last page (Foldout page).

M2

M3

M4







F39

ELECTRICAL LOAD SIGNAL

TB48DE A/T (WITH EURO-OBD)

Wiring Diagram (Cont'd)

EC-LOAD-02



Refer to last page (Foldout page).

M21, E127

M3

Diagnostic Procedure

1	CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I							
<p> With CONSULT-II</p> <p> With GST</p> <p>1. Turn ignition switch "ON".</p> <p>2. Connect CONSULT-II or GST and select "DATA MONITOR" mode.</p> <p>3. Select "LOAD SIGNAL" and check indication under the following conditions.</p>								
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>LOAD SIGNAL</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING	NO DTC	LOAD SIGNAL	ON
DATA MONITOR								
MONITORING	NO DTC							
LOAD SIGNAL	ON							
PBIB0103E								
<table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>Indication</th> </tr> </thead> <tbody> <tr> <td>Rear window defogger switch "ON"</td> <td>ON</td> </tr> <tr> <td>Rear window defogger switch "OFF"</td> <td>OFF</td> </tr> </tbody> </table>			Condition	Indication	Rear window defogger switch "ON"	ON	Rear window defogger switch "OFF"	OFF
Condition	Indication							
Rear window defogger switch "ON"	ON							
Rear window defogger switch "OFF"	OFF							
MTBL1594								
OK or NG								
OK (With CONSULT-II)	▶	GO TO 2.						
OK (Without CONSULT-II)	▶	GO TO 3.						
NG	▶	GO TO 4.						

ELECTRICAL LOAD SIGNAL

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

2	CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II						
<p> With CONSULT-II Check "LOAD SIGNAL" indication under the following conditions.</p>							
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITORING</th><th>NO DTC</th></tr> <tr><td>LOAD SIGNAL</td><td>ON</td></tr> </table>		DATA MONITOR		MONITORING	NO DTC	LOAD SIGNAL	ON
DATA MONITOR							
MONITORING	NO DTC						
LOAD SIGNAL	ON						
PBIB0103E							
<table border="1" style="margin: auto;"> <tr><th>Condition</th><th>Indication</th></tr> <tr><td>Lighting switch "ON" at 2nd position</td><td>ON</td></tr> <tr><td>Lighting switch "OFF"</td><td>OFF</td></tr> </table>		Condition	Indication	Lighting switch "ON" at 2nd position	ON	Lighting switch "OFF"	OFF
Condition	Indication						
Lighting switch "ON" at 2nd position	ON						
Lighting switch "OFF"	OFF						
MTBL1595							
OK or NG							
OK	▶ INSPECTION END						
NG	▶ GO TO 5.						

3	CHECK REAR WINDOW DEFOGGER FUNCTION
<p>1. Start engine. 2. Turn "ON" the rear window defogger switch. 3. Check the rear windshield. Is the rear windshield heated up? Yes or No</p>	
Yes	▶ GO TO 4.
No	▶ Check rear window defogger circuit. Refer to xx.

4	CHECK REAR WINDOW DEFOGGER INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT
<p>1. Stop engine. 2. Disconnect rear window defogger relay. 3. Disconnect combination meter harness connector. 4. Check harness continuity between rear window defogger relay terminal 5 and combination meter terminal 27. Refer to Wiring Diagram. Continuity should exist. 5. Also check harness for short to ground and short to power. OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness for open or short between rear window defogger relay and combination meter 	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.



ELECTRICAL LOAD SIGNAL

TB48DE A/T (WITH EURO-OBD)

Diagnostic Procedure (Cont'd)

6	CHECK COMBINATION METER	
Refer to EL section.		
OK or NG		
OK	▶	GO TO 10.
NG	▶	Replace combination meter.

7	CHECK HEADLAMP FUNCTION	
1. Start engine. 2. Lighting switch "ON" at 2nd position. 3. Check that headlamp high beams are illuminated.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Check headlamp circuit. Refer to EL section.

8	CHECK HEADLAMP INPUT SIGNAL CIRCUIT							
1. Stop engine. 2. Disconnect combination meter harness connector. 3. Disconnect combination switch harness connector. 4. Check harness continuity between combination switch terminals 6, 7 and combination meter terminal 26.								
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>CONDITION 1</p>  </div> <div style="text-align: center;"> <p>CONDITION 2</p>  </div> </div>								
SEC761D								
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Should exist.</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Should not exist.</td> </tr> </tbody> </table>			Condition	Continuity	1	Should exist.	2	Should not exist.
Condition	Continuity							
1	Should exist.							
2	Should not exist.							
MTBL1596								
5. Also check harness for short to ground and short to power.								
OK or NG								
OK	▶	GO TO 10.						
NG	▶	GO TO 9.						

9	DETECT MALFUNCTIONING PART	
Check the following.		
<ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Diode E108 ● Harness for open or short between combination switch and combination meter 		
▶ Repair open circuit or short to ground or short to power.		

ELECTRICAL LOAD SIGNAL

TB48DE A/T (WITH EURO-OBD)





Diagnostic Procedure (Cont'd)

10	CHECK COMBINATION METER
Refer to EL section.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace combination meter.

11	CHECK INTERMITTENT INCIDENT
Refer to EC-112, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".	
	▶ INSPECTION END

Wiring Diagram

EC-DLC-01




Refer to last page (Foldout page).

(M3), (M6)

Description

SYSTEM DESCRIPTION




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases. EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

EVAPORATIVE EMISSION SYSTEM

TB48DE A/T (WITH EURO-OBD)


Description (Cont'd)

EVAPORATIVE EMISSION LINE DRAWING



NOTE:

Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.




Component Inspection

EVAP CANISTER


Check EVAP canister as follows:

1. Block port C. Orally blow air through port A. Check that air flows freely through port B.
2. Block port A. Orally blow air through port C. Check that air flows freely through port B.




FUEL CHECK VALVE

1. Blow air through connector on fuel tank side. A considerable resistance should be felt and a portion of air flow should be directed toward the EVAP canister side.
2. Blow air through connector on EVAP canister side. Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.



2. Check valve opening pressure and vacuum.

Pressure:

16.0 - 20.0 kPa (0.16 - 0.200 bar, 0.163 - 0.204 kg/cm², 2.32 - 2.90 psi)

Vacuum:

-6.0 to -3.5 kPa (-0.060 to -0.035 bar, -0.061 to -0.036 kg/cm², -0.87 to -0.51 psi)


3. If out of specification, replace fuel filler cap as an assembly.

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


Refer to EC-275, "Component Inspection".

Description


SYSTEM DESCRIPTION



This system returns blow-by gas to the intake manifold. The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.




On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.



Component Inspection

PCV (POSITIVE CRANKCASE VENTILATION) VALVE

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.



PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

SERVICE DATA AND SPECIFICATIONS (SDS)

TB48DE A/T (WITH EURO-OBD)

Fuel Pressure Regulator

Fuel pressure kPa (bar, kg/cm ² , psi)	
At idle	Approximately 245 (2.45, 2.5, 36)
A few seconds after ignition switch is turned OFF to ON	Approximately 294 (2.94, 3.0, 43)

Idle Speed and Ignition Timing

Idle speed rpm		
No-load*1 (in "N" position)	Target idle speed	675±50
Air conditioner: ON (in "N" position)	750 rpm or more	
Ignition timing	10°±5° BTDC	

*1: Under the following conditions:

- Air conditioner switch: OFF
- Steering wheel: Kept in straight-ahead position
- Electrical load: OFF (Lights, heater fan & rear window defogger)

Mass Air Flow Sensor

Supply voltage	V	Battery voltage (11 - 14)
Output voltage at idle	V	0.75 - 1.5 at idle* 1.7 - 2.4 at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and running under no-load.

Engine Coolant Temperature Sensor

Temperature °C (°F)	Resistance
20 (68)	2.1 - 2.9 kΩ
50 (122)	0.68 - 1.00 kΩ
90 (194)	0.236 - 0.260 kΩ

Heated Oxygen Sensor 1

Resistance [at 25°C (77°F)]	3.3 - 4.0Ω
-----------------------------	------------

Heated Oxygen Sensor 2

Resistance [at 25°C (77°F)]	5.0 - 7.0Ω
-----------------------------	------------

Fuel Pump

Resistance [at 25°C (77°F)]	Ω	0.2 - 5.0
-----------------------------	---	-----------

SERVICE DATA AND SPECIFICATIONS (SDS)

TB48DE A/T (WITH EURO-OBD)

EVAP Canister Purge Volume Control Solenoid Valve

Resistance [at 20°C (68°F)]	Ω	31 - 35
-----------------------------	---	---------

Injector

Resistance [at 20°C (77°F)]	Ω	14.0 - 15.0
-----------------------------	---	-------------

Ignition Coil with Power Transistor

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 2 (-)	Except 0 or ∞
1 (+) - 3 (-)	Except 0
1 (+) - 2 (-)	


Condenser

Resistance [at 25°C (77°F)]	MΩ	Above 1
-----------------------------	----	---------

Throttle Control Motor



Resistance [at 25°C (77°F)]	Ω	Approximately 1 - 15
-----------------------------	---	----------------------

Circuit Diagram




Main Power Supply and Ground Circuit

EC-MAIN-01





Refer to last page (Foldout page).

M21, E127
M2




Wiring Diagram

EC-MAFS-01




Wiring Diagram

EC-VSS-01





- : Detectable line for DTC
- : Non-detectable line for DTC
- ◁ : LHD models
- ▷ : RHD models
- *1 2: ▷
- 55K: ▷
- *2 3: ▷
- 67K: ▷





Wiring Diagram

EC-COOL/F-01




Refer to last page (Foldout page).



Diagnostic Procedure

1	INSPECTION START		
Do you have CONSULT-II?			
Yes or No			
Yes	▶	GO TO 2.	
No	▶	GO TO 3.	


2	CHECK COOLING FAN OPERATION																								
<p> With CONSULT-II</p> <p>1. Turn ignition switch "ON". 2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.</p>																									
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>COOLING FAN</th> <th>OFF</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>COOLAN TEMP/S</th> <th>XXX °C</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table>				ACTIVE TEST		COOLING FAN	OFF	MONITOR		COOLAN TEMP/S	XXX °C														
ACTIVE TEST																									
COOLING FAN	OFF																								
MONITOR																									
COOLAN TEMP/S	XXX °C																								
SEF646X																									
3. Make sure that cooling fan-1 operates.																									
OK or NG																									
OK	▶	GO TO 12.																							
NG	▶	GO TO 4.																							

3	CHECK COOLING FAN OPERATION		
<p> Without CONSULT-II</p> <p>1. Turn ignition switch "OFF". 2. Disconnect engine coolant temperature sensor harness connector. 3. Connect 150Ω resistor to engine coolant temperature sensor harness connector. 4. Restart engine and make sure that cooling fan operates.</p>			
			
MEC475B			
OK or NG			
OK	▶	GO TO 12.	
NG	▶	GO TO 4.	

Diagnostic Procedure (Cont'd)


4 CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.



SEF690V

3. Turn ignition switch "ON".
4. Check voltage between cooling fan relay-1 terminals 1, 3, 6 and ground with CONSULT-II or tester.



OK or NG

SEC533D

OK	▶	GO TO 6.
NG	▶	GO TO 5.


5 DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E112
- 10A fuse or 20A fuse
- 40A fusible links
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

	▶	Repair open circuit or short to ground or short to power in harness or connectors.
--	---	--

Diagnostic Procedure (Cont'd)

6	CHECK COOLING FAN GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF". 2. Disconnect cooling fan motor-1 harness connector.</p> <div style="text-align: center;">  <p>Labels in diagram: Cooling fan motor harness connector, Hood lock release lever</p> </div> <p style="text-align: right;">SEF691V</p>	
<p>3. Check harness continuity between cooling fan relay-1 terminal 5 and cooling fan motor-1 terminal 1, cooling fan relay-1 terminal 7 and cooling fan motor-1 terminal 3, cooling fan motor-1 terminals 2, 4 and body ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 14 and cooling fan relay-1 terminal 2. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 9.
NG	▶ GO TO 8.


8	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E127, M21 ● Harness connectors M52, F7 ● Harness for open or short between cooling fan relay-1 and ECM 	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.

9	CHECK COOLING FAN RELAY-1
<p>Refer to "Component Inspection", EC-495.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 10.
NG	▶ Replace cooling fan relay.

Diagnostic Procedure (Cont'd)

10 CHECK COOLING FAN MOTOR-1

Supply battery voltage between the following terminals and check operation.



SEF645V

	Terminals	
	(+)	(-)
Cooling fan motor-1	1, 3	2, 4

MTBL1304

OK or NG

OK	▶	GO TO 11.
NG	▶	Replace cooling fan motor.

11 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".

	▶	INSPECTION END
--	---	-----------------------


12 CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

Testing pressure: 98 kPa (0.98 bar, 1.0 kg/cm², 14 psi)

CAUTION:

Higher than the specified pressure may cause radiator damage.



SLC754A


Pressure should not drop.


OK or NG

OK	▶	GO TO 14.
NG	▶	GO TO 13.

Diagnostic Procedure (Cont'd)

13	DETECT MALFUNCTIONING PART
Check the following for leak. <ul style="list-style-type: none"> ● Hose ● Radiator ● Water pump (Refer to LC section, "Water Pump".) 	
▶ Repair or replace.	


14	CHECK RADIATOR CAP
Apply pressure to cap with a tester and check radiator cap relief pressure.	
 <p>EG17650301 (J33984-A)</p>	
SLC755A	
Radiator cap relief pressure: 59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm ² , 9 - 14 psi)	
OK or NG	
OK	▶ GO TO 15.
NG	▶ Replace radiator cap.

15	CHECK THERMOSTAT
1. Remove thermostat. 2. Check valve seating condition at normal room temperatures. It should seat tightly. 3. Check valve opening temperature and valve lift.	
	
SLC343	
Valve opening temperature: 82°C (180°F) [standard] (Models for cold areas) 76.5°C (170°F) [standard] (Models for except cold areas)	
Valve lift: More than 10 mm/95°C (0.394 in/203°F)	
4. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC section, "Thermostat".	
OK or NG	
OK	▶ GO TO 16.
NG	▶ Replace thermostat.

Diagnostic Procedure (Cont'd)


16 CHECK ENGINE COOLANT TEMPERATURE SENSOR

1. Remove engine coolant temperature sensor.
2. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260



OK or NG


SEF304X

OK	▶ GO TO 17.
NG	▶ Replace engine coolant temperature sensor.

17 CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-496.

▶ INSPECTION END



SEC202B

Component Inspection

COOLING FAN RELAY-1

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

If NG, replace relay.

Main 12 Causes of Overheating

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper 	<ul style="list-style-type: none"> Visual 	No blocking	—
	2	<ul style="list-style-type: none"> Coolant mixture 	<ul style="list-style-type: none"> Coolant tester 	30 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section.
	3	<ul style="list-style-type: none"> Coolant level 	<ul style="list-style-type: none"> Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
	4	<ul style="list-style-type: none"> Radiator cap 	<ul style="list-style-type: none"> Pressure tester 	59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See "System Check", "ENGINE COOLING SYSTEM" in LC section.
ON*2	5	<ul style="list-style-type: none"> Coolant leaks 	<ul style="list-style-type: none"> Visual 	No leaks	See "System Check", "ENGINE COOLING SYSTEM" in LC section.
ON*2	6	<ul style="list-style-type: none"> Thermostat 	<ul style="list-style-type: none"> Touch the upper and lower radiator hoses 	Both hoses should be hot.	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section.
ON*1	7	<ul style="list-style-type: none"> Cooling fan 	<ul style="list-style-type: none"> Visual 	Operating	See "DTC 0208 OVER HEAT".
OFF	8	<ul style="list-style-type: none"> Combustion gas leak 	<ul style="list-style-type: none"> Color checker chemical tester 4 gas analyzer 	Negative	—
ON*3	9	<ul style="list-style-type: none"> Coolant temperature gauge 	<ul style="list-style-type: none"> Visual 	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> Coolant overflow to reservoir tank 	<ul style="list-style-type: none"> Visual 	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
OFF*4	10	<ul style="list-style-type: none"> Coolant return from reservoir tank to radiator 	<ul style="list-style-type: none"> Visual 	Should be initial level in reservoir tank	See "ENGINE MAINTENANCE" in MA section.
OFF	11	<ul style="list-style-type: none"> Cylinder head 	<ul style="list-style-type: none"> Straight gauge feeler gauge 	0.1 mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYLINDER HEAD" in EM section.
	12	<ul style="list-style-type: none"> Cylinder block and pistons 	<ul style="list-style-type: none"> Visual 	No scuffing on cylinder walls or piston	See "Inspection", "CYLINDER BLOCK" in EM section.

*1: Engine running at idle.

*2: Engine running at 3,000 rpm for 10 minutes.



*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.


Wiring Diagram

EC-INJPMP-01





Refer to last page (Foldout page).
 (M21), (E127)

*: This connector is not shown in "HARNESS LAYOUT", EL section.






Wiring Diagram

EC-APS-02





Wiring Diagram

EC-ECMRLY-01




Wiring Diagram

EC-EGVC/V-01



Refer to last page (Foldout page).


(M21), (E127)



(F8) W

Wiring Diagram

EC-MIL/DL-01



- : Detectable line for DTC
- - - : Non-detectable line for DTC
- L : LHD models
- R : RHD models
- XE : Except for Europe

