

SECTION **HA****MODIFICATION NOTICE:**

- Wiring diagram has been changed.
- Automatic A/C controller has been changed.
- Front thermo amp. for auto A/C has been eliminated.

**CONTENTS****AUTO**

<b>DESCRIPTION</b> .....	4002
Features (TB48 Engine Models) .....	4002

**REAR HEATER**

<b>TROUBLE DIAGNOSES</b> .....	4003
Wiring Diagram — R/HEAT —/LHD Models .....	4003
Wiring Diagram — R/HEAT —/RHD Models.....	4004

**MANUAL**

<b>TROUBLE DIAGNOSES</b> .....	4005
Wiring Diagram — A/C, M —/Wagon and Hardtop Models with ZD Engine .....	4005

**AUTO**

<b>DESCRIPTION</b> .....	4007
Control Operation .....	4007
<b>TROUBLE DIAGNOSES</b> .....	4008
Circuit Diagram — A/C, A —/TB48 Engine .....	4008
Wiring Diagram — A/C, A —/TB48 Engine .....	4009
Circuit Diagram — A/C, A —/TB45 Engine .....	4013
Wiring Diagram — A/C, A —/TB45 Engine .....	4014
Circuit Diagram — A/C, A —/TD Engine .....	4017
Wiring Diagram — A/C, A —/TD Engine .....	4018
Circuit Diagram — A/C, A —/ZD Engine .....	4021
Wiring Diagram — A/C, A —/ZD Engine .....	4022
Self-diagnosis .....	4025
Operational Check .....	4032
A/C System.....	4034

Mode Door Motor.....	4035
Air Mix Door Motor .....	4036
Intake Door Motor.....	4037
Blower Motor.....	4038
Magnet Clutch.....	4039
Insufficient Cooling .....	4052
Insufficient Heating .....	4053
Self-diagnosis .....	4054

**REAR COOLER**

<b>TROUBLE DIAGNOSES</b> .....	4055
Wiring Diagram — R/COOL —/LHD Models with Front Auto A/C .....	4055
Wiring Diagram — R/COOL —/LHD Models with Front Manual A/C Except for TB45E Engine .....	4057
Wiring Diagram — R/COOL —/LHD Models with Front Manual A/C for TB45E Engine.....	4059
Wiring Diagram — R/COOL —/RHD Models with Front Auto A/C .....	4061
Wiring Diagram — R/COOL —/RHD Models with Front Manual A/C.....	4063

**COOL BOX**

<b>TROUBLE DIAGNOSES</b> .....	4065
Wiring Diagram — COOL/B —/All Engines Except TB48 and TB45E Wagon Models for the Middle East .....	4065
Wiring Diagram — COOL/B —/TB48 and TB45E Engine Wagon Models for the Middle East.....	4066


## Features (TB48 Engine Models)

### CAN COMMUNICATION SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### SYSTEM CONSTRUCTION

#### Magnet clutch control








When A/C switch is pressed, turn fan control dial to ON or set mode control dial to DEF position, A/C auto amp. inputs compressor ON signal to ECM.

ECM judges whether compressor can be turned ON, based on each sensor status (refrigerant pressure sensor signal, throttle angle, etc.).

When sending compressor ON signal to ECM from A/C auto amp., ECM simultaneously sends compressor feedback signal to unified meter C/U via CAN communication line.

Unified meter control unit sends compressor feedback signal to A/C auto amp. Then, A/C auto amp. uses input compressor feedback signal to control air inlet.

## Wiring Diagram — R/HEAT —/LHD Models




Refer to last page (Foldout page).

M2  
M6

## Wiring Diagram — R/HEAT —/RHD Models

HA-R/HEAT-02





Refer to last page (Foldout page).

(M20, B19)

(M2)

(M6)

## **Wiring Diagram — A/C, M —/Wagon and Hardtop Models with ZD Engine**









\*: This connector is not shown in "HARNESS LAYOUT", EL section.

| Refer to last page (Foldout page).

M1  
M2  
E112

## Wiring Diagram — A/C, M —/Wagon and Hardtop Models with ZD Engine (Cont'd)




Refer to last page (Foldout page).

(M21, E127)

(F8)

\*: This connector is not shown in "HARNESS LAYOUT", EL section.

## Control Operation



### MODE CONTROL DIAL

Controls the air discharge outlets.

Positions the air outlet doors to the defrost position. Also positions the intake doors to the outside air position. When shifting mode control dial to DEF under the following conditions compressor is turned ON. (A/C LED ON)

- FAN: ON
- A/C: OFF

### TEMPERATURE CONTROL DIAL (POTENTIO TEMPERATURE CONTROL)

Increase or decrease the set temperature.

### FAN CONTROL DIAL

Automatically or Manually control the blower speed. Twenty-five speeds are available for manual control. Shifting fan control dial to AUTO, compressor is turned ON automatically.

### INTAKE SWITCH


- When intake switch is ON, REC LED turns ON, and air inlet is fixed to REC.
- When press intake switch again, FRE LED turns ON, and air inlet is fixed to FRE.
- When intake switch is pressed for approximately 1.5 seconds or longer, REC and FRE LEDs blink twice. Then, automatic control mode is entered. Inlet status is displayed even during automatic control.
- Automatic control mode is entered when REC and FRE LEDs are turned OFF.
- When shifting mode control dial to DEF position, FRE LED is turned ON, or when compressor is turned from ON to OFF, FRE indicator is automatically turned OFF (fixed to FRE mode). REC mode can be re-entered by pressing intake switch again. (Except DEF position)

### A/C SWITCH


The compressor is ON or OFF.

(Pressing the A/C switch when the fan control dial is ON will turn off the A/C switch and compressor.)

## Circuit Diagram — A/C, A —/TB48 Engine



## Wiring Diagram — A/C, A —/TB48 Engine



Refer to last page (Foldout page).


- M1
- M2
- M3
- E112

## TROUBLE DIAGNOSES

**AUTO**




## Wiring Diagram — A/C, A —/TB48 Engine (Cont'd)

HA-A/C,A-02



Refer to last page (Foldout page).




M21, E127



## TROUBLE DIAGNOSES

**AUTO**

## **Wiring Diagram — A/C, A —/TB48 Engine (Cont'd)**



| Refer to last page (Foldout page).

M21 E127

M2

10


F38

# TROUBLE DIAGNOSES

AUTO

## Wiring Diagram — A/C, A —/TB48 Engine (Cont'd)

HA-A/C,A-04



1	2	3	4	5	6	—	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22	24


W M52

25	26	27	28	29	—	30	31	32	33
34	35	36	37	38	39	40	41	42	44

M142 BR

45	46	47	48	49	50	—	51	52	53	54	55
56	57	58	59	60	61	62	63	64	65	66	68

M143 BR




Refer to last page (Foldout page).

M21, E127

F38


F39

## Circuit Diagram — A/C, A —/TB45 Engine



THA194M

## Wiring Diagram — A/C, A —/TB45 Engine





## TROUBLE DIAGNOSES

**AUTO**



## **Wiring Diagram — A/C, A —/TB45 Engine (Cont'd)**

HA-A/C,A-06



Refer to last page (Foldout page).









M21, E127



# TROUBLE DIAGNOSES

AUTO


## Wiring Diagram — A/C, A —/TB45 Engine (Cont'd)



Refer to last page (Foldout page).



(M21), (E127)  
(M1)  
(F8)

## Circuit Diagram — A/C, A —/TD Engine



THA198M

## Wiring Diagram — A/C, A —/TD Engine



Refer to last page (Foldout page).


M3  
E112

# TROUBLE DIAGNOSES

AUTO



## Wiring Diagram — A/C, A —/TD Engine (Cont'd)

HA-A/C,A-09



Refer to last page (Foldout page).

(M21, E127)





THA200M

HA-4019

# TROUBLE DIAGNOSES

AUTO

## Wiring Diagram — A/C, A —/TD Engine (Cont'd)




Refer to last page (Foldout page).

M1


THA201M

HA-4020

## Circuit Diagram — A/C, A —/ZD Engine



## Wiring Diagram — A/C, A —/ZD Engine




# TROUBLE DIAGNOSES

AUTO


## Wiring Diagram — A/C, A —/ZD Engine (Cont'd)

HA-A/C,A-12



Refer to last page (Foldout page).

(M21), (E127)




THA204M

HA-4023

## TROUBLE DIAGNOSES

**AUTO**

## Wiring Diagram — A/C, A —/ZD Engine (Cont'd)








Refer to last page (Foldout page).

M21 F127

M1

10



## **Self-diagnosis**

### **INTRODUCTION AND GENERAL DESCRIPTION**

The self-diagnostic system diagnoses sensors, door motors, blower motor, etc. by system line. Self-diagnosis is step-1 to 7. There are two ways of changing method during self-diagnosis.

- Switching to self-diagnosis step-1 to 4.


Shifting from usual control to the self-diagnostic system is accomplished by starting the engine (turning the ignition switch from OFF to ON) and pressing A/C switch for at least 5 seconds. The A/C switch must be pressed within 10 seconds after starting the engine (ignition switch is turned ON). This system will be canceled by either pressing intake switch or turning the ignition switch OFF. Shifting from one step to another is accomplished by means of turning fan control dial, as required.

- Switching to self-diagnosis step-5 to 7 (Auxiliary mechanism).


Shifting from usual control to the self-diagnostic system is accomplished by starting the engine (turning the ignition switch from OFF to ON) and pressing intake switch for at least 5 seconds. The intake switch must be pressed within 10 seconds after starting the engine (ignition switch is turned ON). This system will be canceled by either pressing A/C switch or turning the ignition switch OFF. Shifting from one step to another is accomplished by means of turning fan control dial, as required.

## Self-diagnosis (Cont'd)

STEP - 1 to 4



STEP - 5 to 7 (Auxiliary mechanism)





## CAUTION:



This A/C system cannot perform the setup of the FOOT position (Self-diagnosis: STEP-6). LED of A/C switch illuminates. It means that it is fixed to the initial setting.

## Self-diagnosis (Cont'd)

### STEP-BY-STEP PROCEDURE




## Self-diagnosis (Cont'd)



**\*1: Conduct self-diagnosis STEP 2 under sunshine.**  
When conducting indoors, aim a light (more than 60W) at sunload sensor, otherwise LED of A/C switch will indicate despite that sunload sensor is functioning properly.


## Self-diagnosis (Cont'd)



# TROUBLE DIAGNOSES

AUTO

## Self-diagnosis (Cont'd)



## Self-diagnosis (Cont'd)

**AUXILIARY MECHANISM: TEMPERATURE SETTING TRIMMER**

The trimmer compensates for differences in range of  $\pm 3^{\circ}\text{C}$  between temperature setting (Temperature control dial position) and temperature felt by driver.

Operating procedures for this trimmer are as follows:

1. Set temperature at  $25^{\circ}\text{C}$ .
2. Set fan control dial to OFF.
3. Turn ignition switch ON.
4. Set in self-diagnostic mode as follows. Within 10 seconds after starting engine (ignition switch is turned ON.), press intake switch for at least 5 seconds.
5. Turn temperature control dial as desired. Temperature will change at a rate of  $1^{\circ}\text{C}$  each time a dial is turned.

Setting temperature	LED status of each switch		
	FRE	REC	A/C
$-3^{\circ}\text{C}$	ON	ON	ON
$-2^{\circ}\text{C}$	ON	ON	OFF
$-1^{\circ}\text{C}$	ON	OFF	ON
$0^{\circ}\text{C}$ (Initial setting)	OFF	OFF	OFF
$1^{\circ}\text{C}$	OFF	OFF	ON
$2^{\circ}\text{C}$	OFF	ON	OFF
$3^{\circ}\text{C}$	OFF	ON	ON

When battery cable is disconnected, trimmer operation is canceled. Temperature set becomes that of initial condition, i.e.  $0^{\circ}\text{C}$ .

**AUXILIARY MECHANISM: FOOT POSITION SETTING TRIMMER****CAUTION:**

This A/C system cannot perform the setup of the FOOT position.

LED of A/C switch illuminates. It means that it is fixed to the initial setting.

**AUXILIARY MECHANISM: INLET PORT MEMORY FUNCTION**

When ignition switch is turned from OFF to ON, inlet port can be set to AUTO or manual.

Operating procedures for this trimmer are as follows:

1. Set fan control dial to 1st - 25th step.
2. Turn ignition switch ON.
3. Set in self-diagnostic mode as follows. Within 10 seconds after starting engine (ignition switch is turned ON.), press intake switch for at least 5 seconds.
4. Press intake switch as desired.



LED status of intake switch		Setting status		Setting changeover method
FRE	REC	FRE	REC	
OFF	ON	AUTO control (Initial setting)	Manual REC status is memorized. (Initial setting)	Intake switch: ON
ON	OFF	Manual FRE status is memorized.	AUTO control	
ON	ON	Manual FRE status is memorized.	Manual REC status is memorized.	
OFF	OFF	AUTO control	AUTO control	

## Operational Check

The purpose of the operational check is to confirm that the system is as it should be. The systems which will be checked are the blower, mode (discharge air), intake air, temperature decrease, temperature increase and A/C switch.

### CONDITIONS:

- Engine running and at normal operating temperature.




Discharge air flow				
Mode door position	Air outlet/distribution			
	Face	Foot	Defroster	
	100%	–	–	
	60%	40%	–	
	–	80%	20%	
	–	60%	40%	
	–	–	100%	

RHA654FF

**Operational Check (Cont'd)****3. Check intake door**


- 1) Press intake switch. Recirculation indicator should illuminate.
- 2) Press intake switch again. Fresh indicator should illuminate.
- 3) Listen for intake door position change (you should hear blower sound change slightly).



RHA375I

**4. Check temperature decrease**


- 1) Turn temperature control dial until 18°C.
- 2) Check for cold air at discharge air outlets.



RHA376I

**5. Check temperature increase**


- 1) Turn temperature control dial until 32°C.
- 2) Check for hot air at discharge air outlets.



RHA377I

**6. Check A/C switch**

- 1) Turn fan control dial to AUTO position.
- 2) Press A/C switch. (LED will turn ON.)  
Confirm that the compressor clutch engages (sound or visual inspection).  
(Discharge air and suction air will depend on ambient, in-vehicle and set temperatures.)



RHA378I


## A/C System

### TROUBLE DIAGNOSIS PROCEDURE FOR A/C SYSTEM

#### SYMPTOM:

- A/C system does not come on.

#### Inspection flow



RHA379I

\*1: HA-96 in Y61 SERVICE MANUAL,  
Publication No. SM7E-2Y61G1

\*2: HA-4032

## Mode Door Motor


## TROUBLE DIAGNOSIS PROCEDURE FOR MODE DOOR MOTOR (LAN)

## SYMPTOM:

- Air outlet does not change.
- Mode door motor does not operate normally.

## Inspection flow

1. Confirm symptom by performing the following operational check.



## OPERATIONAL CHECK – Discharge air

a. Turn mode control dial to each position.


### Discharge air flow

Mode door position	Air outlet/distribution		
	Vent	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	80%	20%
	—	60%	40%
	—	—	100%

b. Confirm that discharge air comes out according to the air distribution table at left.  
Refer to "Discharge Air Flow" (\*1).

**NOTE:**

- If OK (symptom cannot be duplicated), perform complete operational check (\*2).  
If NG (symptom is confirmed), continue with STEP-2 following.
- Confirm that the compressor clutch is engaged (sound or visual inspection) and intake door position is at FRESH when DEF  is selected.  
Intake door position is checked in the next step.



RHA380I

\*1: HA-14\* \*6: HA-4030  
\*2: HA-4032 \*7: HA-125\*  
\*3: HA-4027 \*8: HA-127\*  
\*4: HA-4028 \*9: HA-129\*  
\*5: HA-4029 \*10: HA-132\*

- \*6: HA-4030
- \*7: HA-125\*
- \*8: HA-127\*
- \*9: HA-129\*
- \*10: HA-132\*

- \*11: HA-101\*
- \*12: HA-87\*
- \*13: HA-99\*
- \*14: HA-91\*

\*: Refer to Y61 SERVICE MANUAL, Publication No. SM7E-2Y61G1.


## Air Mix Door Motor

## TROUBLE DIAGNOSIS PROCEDURE FOR AIR MIX DOOR (LAN)

## SYMPTOM:

- Discharge air temperature does not change.
- Air mix door motor does not operate.

## Inspection flow



RHA381I

\*1: HA-4027

\*2: HA-4028

\*3: HA-4027 see STEP 4

\*4: HA-125\*

\*5: HA-127\*

\*6: HA-129\*

\*7: HA-132\*

\*8: HA-101\*

\*9: HA-91\*

\*10: HA-100\*

\*11: HA-103\*

\*12: HA-4032

\*: Refer to Y61 SERVICE MANUAL, Publication No. SM7E-2Y61G1.


## Intake Door Motor

## TROUBLE DIAGNOSIS PROCEDURE FOR INTAKE DOOR

## SYMPTOM:

- Intake door does not change.
- Intake door motor does not operate normally.

## Inspection flow



RHA382I

\*1: HA-4027

\*2: HA-4028

\*3: HA-4027 see STEP 4

\*4: HA-125\*

\*5: HA-127\*

\*6: HA-129\*

\*7: HA-132\*

\*8: HA-101\*

\*9: HA-107\*

\*10: HA-106\*

\*11: HA-4032

\*12: HA-91\*

\*: Refer to Y61 SERVICE MANUAL, Publication No. SM7E-2Y61G1.


## Blower Motor

## TROUBLE DIAGNOSIS PROCEDURE FOR BLOWER MOTOR

## SYMPTOM:

- Blower motor operation is malfunctioning.
- Blower motor operation is malfunctioning under out of starting fan speed control.

## Inspection flow



RHA3831

\*1: HA-4027

\*2: HA-4028

\*3: HA-4030

\*4: HA-111\*

\*5: HA-125\*

\*6: HA-127\*

\*7: HA-129\*

\*8; HA-132\*

\*9: HA-91\*

\*10: HA-4032

\*: Refer to Y61 SERVICE MANUAL, Publication No. SM7E-2Y61G1.


## Magnet Clutch

### TROUBLE DIAGNOSIS PROCEDURE FOR MAGNET CLUTCH

#### SYMPTOM:

- Magnet clutch does not engage.

#### Inspection flow



\*1: HA-4027

\*2: HA-4027 see STEP 2

\*3: HA-4027 see STEP 4

\*4: HA-4040: TB48 engine  
HA-4043: TB45 engine

HA-4046: TD engine

HA-4049: ZD engine





\*5: HA-125 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1

\*6: HA-132 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1

\*7: HA-4032

\*8: HA-91 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1

\*9: HA-43 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1



## Magnet Clutch (Cont'd)

## DIAGNOSTIC PROCEDURE (TB48 ENGINE EXCEPT FOR THE MIDDLE EAST)

**SYMPTOM:** Magnet clutch does not engage when A/C switch and fan control dial are ON.

CHECK INTAKE SENSOR CIRCUIT.  
Refer to self-diagnosis (HA-4027) and  
intake sensor circuit (HA-132 in Y61 SER-  
VICE MANUAL, publication No. SM7E-  
2Y61G1.).

**A**   
CHECK POWER SUPPLY FOR COMPRESSOR.  
Disconnect compressor harness connector.  
Do approx. 12 volts exist between compressor harness connector terminal No. ① and ground?

```

graph LR
    A[Yes] --> B[Check magnet clutch coil]
    B --> C[NG]
    C --> D[Replace magnet clutch.  
Refer to HA-178 in Y61  
SERVICE MANUAL (publica-  
tion No. SM7E-2Y61G1).]
  
```

Disconnect A/C relay.

**B** Note  
CHECK CIRCUIT CONTINUITY  
BETWEEN A/C RELAY HARNESS CON-  
NECTOR TERMINAL NO. ③ AND COM-  
PRESSOR HARNESS CONNECTOR TER-  
MINAL NO. ① .

**Continuity should exist.**  
If OK, check harness for short.

C  
CHECK POWER SUPPLY FOR A/C RELAY.  
Disconnect A/C relay.  
Do approx. 12 volts exist between A/C relay harness connector terminal Nos. ① ⑤ and ground?

→ Check power supply circuit and 10A or 20A (No. **6**) located in the fuse block (J/B). Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

CHECK A/C RELAY AFTER DISCONNECTING IT.  
Refer to HA-41 in Y61 SERVICE MANUAL, publication No. SM1E-Y61EG1.

NG → Replace A/C relay.

(A)  
(Go to next page.)




### Note:

If the result is NG or No after checking circuit continuity, repair harness or connector.

# TROUBLE DIAGNOSES


AUTO

## Magnet Clutch (Cont'd)



No

Disconnect A/C relay.  
Disconnect ECM harness connector.



Yes



M/T models

Yes

A/T models

(B)

(Go to next page.)





No


CHECK ECM. Refer to EC section.

Yes

Disconnect ECM harness connector.  
Disconnect auto amp. harness connector.



Note



NG

Replace refrigerant pressure sensor.

OK

Replace auto amp.


**Note:**

If the result is NG or No after checking circuit continuity, repair harness or connector.

# TROUBLE DIAGNOSES

AUTO

## Magnet Clutch (Cont'd)



**H**

⑧

**CHECK VOLTAGE FOR COMBINATION METER. (COMPRESSOR ON SIGNAL)**  
Do approx. 12V exist between combination meter harness connector terminal No. ⑧ and ground?

**J**


**Note**

CHECK CIRCUIT CONTINUITY BETWEEN COMBINATION METER HARNESS CONNECTOR TERMINAL NO. ⑧ AND ECM HARNESS CONNECTOR TERMINAL NO. ⑯.  
**Continuity should exist.**  
If OK, check harness for short.

OK

Replace ECM.


Replace combination meter.



**I**

**CHECK VOLTAGE FOR COMBINATION METER. (FAN ON SIGNAL)**  
Do approx. 12V exist between combination meter harness connector terminal No. ⑨ and ground?

No




Disconnect combination meter and auto amp. harness connector.

Yes

OK

NG



**K**

**Note**

CHECK CIRCUIT CONTINUITY BETWEEN COMBINATION METER HARNESS CONNECTOR TERMINAL NO. ⑨ AND AUTO AMP. HARNESS CONNECTOR TERMINAL NO. ⑯.  
**Continuity should exist.**  
If OK, check harness for short.

**CHECK REFRIGERANT PRESSURE SENSOR.**  
Refer to EC-498 (publication No. SM2E-Y61FG1).

OK

NG

Replace refrigerant pressure sensor.

**Replace auto amp.**

**Note:**  
If the result is NG or No after checking circuit continuity, repair harness or connector.


# TROUBLE DIAGNOSES

AUTO

## Magnet Clutch (Cont'd)

### DIAGNOSTIC PROCEDURE (MODELS WITH TB45 ENGINE)

**SYMPTOM:** Magnet clutch does not engage when A/C switch and fan control dial are ON.



**A**

CHECK POWER SUPPLY FOR COMPRESSOR.  
Disconnect compressor harness connector.  
Do approx. 12 volts exist between compressor harness connector terminal No. ① and ground?

Yes

Check magnet clutch coil.

↓ NG

Replace magnet clutch.  
Refer to HA-178 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1.

No

Disconnect A/C relay.

**B**

**Note**  
CHECK CIRCUIT CONTINUITY  
BETWEEN A/C RELAY HARNESS CON-  
NECTOR TERMINAL NO. ③ AND COM-  
PRESSOR HARNESS CONNECTOR TER-  
MINAL NO. ①.

**Continuity should exist.**

If OK, check harness for short.

OK

**C**

CHECK POWER SUPPLY FOR A/C  
RELAY.  
Disconnect A/C relay.  
Do approx. 12 volts exist between A/C  
relay harness connector terminal Nos. ① ,  
⑤ and ground?

No

Check power supply circuit  
and 10A or 20A (No. ⑥) located in the fuse block  
(J/B).  
Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

Yes

NG




Replace A/C relay.

OK

Ⓐ  
(Go to next page.)

**Note:**






If the result is NG or No after checking circuit continuity, repair harness or connector.



# TROUBLE DIAGNOSES

AUTO

## Magnet Clutch (Cont'd)




(B)  
(Go to next page.)

**Note:**

If the result is NG or No after checking circuit continuity, repair harness or connector.

## Magnet Clutch (Cont'd)

**H**

Note

Check circuit continuity between dual-pressure switch harness connector terminal No. ① and auto amp. harness connector terminal No. ④.

**Continuity should exist.**  
If OK, check harness for short.



OK

Replace auto amp.


**Note:**

If the result is NG or No after checking circuit continuity, repair harness or connector.

## Magnet Clutch (Cont'd)

## DIAGNOSTIC PROCEDURE (MODELS WITH TD ENGINE)

**SYMPTOM:** Magnet clutch does not engage when A/C switch and fan control dial are ON.



A

CHECK POWER SUPPLY FOR COMPRESSOR.  
Disconnect compressor harness connector.  
Do approx. 12 volts exist between compressor harness terminal No. ① and ground?

Yes → Check magnet clutch coil.  
NG → Replace magnet clutch.  
Refer to HA-178 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1.

Disconnect A/C cut relay.

B

CHECK CIRCUIT CONTINUITY BETWEEN A/C CUT RELAY HARNESS CONNECTOR TERMINAL NO. ③ AND COMPRESSOR HARNESS CONNECTOR TERMINAL NO. ①.

**Continuity should exist.**  
If OK, check harness for short.

OK

CHECK A/C CUT RELAY.  
Refer to HA-4051.

NG → Replace A/C cut relay.

OK

CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY HARNESS CONNECTOR TERMINAL NO. ⑦ AND A/C CUT RELAY HARNESS CONNECTOR TERMINAL NO. ④.

**Continuity should exist.**  
If OK, check harness for short.




OK

Ⓐ


(Go to next page.)

## Note:

If the result is NG or No after checking circuit continuity, repair harness or connector.



## Magnet Clutch (Cont'd)



**D**


Note

CHECK CIRCUIT CONTINUITY BETWEEN A/C CUT RELAY HARNESS CONNECTOR TERMINAL NO. ① AND GROUND.

**E**

Note

CHECK CIRCUIT CONTINUITY BETWEEN A/C CUT RELAY HARNESS CONNECTOR TERMINAL NO. ② AND ENGINE COOLANT TEMPERATURE SWITCH-2 HARNESS CONNECTOR TERMINAL NO. ②.



**E**

Note

CHECK CIRCUIT CONTINUITY BETWEEN A/C CUT RELAY HARNESS CONNECTOR TERMINAL NO. ② AND ENGINE COOLANT TEMPERATURE SWITCH-2 HARNESS CONNECTOR TERMINAL NO. ②.


**F**

OK

CHECK ENGINE COOLANT TEMPERATURE SWITCH-2. Refer to HA-4051.

NG

Replace engine coolant temperature switch-2.



**F**


OK

CHECK POWER SUPPLY FOR ENGINE COOLANT TEMPERATURE SWITCH-2. Do approx. 12 volts exist between engine coolant temperature switch-2 harness connector terminal No. ① and ground?

No

Check power supply circuit and 10A or 20A (No. 6) located in the fuse block (J/B). Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

Yes




**G**

OK

CHECK POWER SUPPLY FOR A/C RELAY. Do approx. 12 volts exist between A/C relay harness connector terminal Nos. ①, ⑥ and ground?

No



**H**

Note



CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY HARNESS CONNECTOR TERMINAL NO. ② AND DUAL-PRESSURE SWITCH HARNESS CONNECTOR TERMINAL NO. ②. Continuity should exist.

If OK, check harness for short.

OK

If OK, check harness for short

## Magnet Clutch (Cont'd)

**Note:**

If the result is NG or No after checking circuit continuity, repair harness or connector.


# TROUBLE DIAGNOSES

AUTO

## Magnet Clutch (Cont'd)

### DIAGNOSTIC PROCEDURE (MODELS WITH ZD ENGINE)

**SYMPTOM:** Magnet clutch does not engage when A/C switch and fan control dial are ON.



**A**

CHECK POWER SUPPLY FOR COMPRESSOR.  
Disconnect compressor harness connector.  
Do approx. 12 volts exist between compressor harness connector terminal No. ① and ground?

Yes

Check magnet clutch coil.

↓ NG

Replace magnet clutch.  
Refer to HA-178 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1.

No

Disconnect A/C relay.

**B**

CHECK CIRCUIT CONTINUITY  
BETWEEN A/C RELAY HARNESS CONNECTOR TERMINAL NO. ⑦ AND COMPRESSOR HARNESS CONNECTOR TERMINAL NO. ①.  
Continuity should exist.  
If OK, check harness for short.

Note

OK

**C**

CHECK POWER SUPPLY FOR A/C RELAY.  
Disconnect A/C relay.  
Do approx. 12 volts exist between A/C relay harness connector terminal Nos. ①, ⑥ and ground?

No

Check power supply circuit and 10A or 20A (No. ⑥) located in the fuse block (J/B).  
Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

Yes

CHECK A/C RELAY AFTER DISCONNECTING IT.  
Refer to HA-119 in Y61 SERVICE MANUAL, publication No. SM7E-2Y61G1.

NG




Replace A/C relay.

OK

Ⓐ  
(Go to next page.)

**Note:**






If the result is NG or No after checking circuit continuity, repair harness or connector.



# TROUBLE DIAGNOSES

AUTO


## Magnet Clutch (Cont'd)



OK  
Ⓑ

**Note:**  
If the result is NG or No after checking circuit continuity, repair harness or connector.

## Magnet Clutch (Cont'd)

**H**

Check circuit continuity between dual-pressure switch harness connector terminal No. ① and auto amp. harness connector terminal No. ④ .  
**Continuity should exist.**  
 If OK, check harness for short.


Yes

Replace auto amp.

Note

**Note:**

If the result is NG or No after checking circuit continuity, repair harness or connector.



## COMPONENT INSPECTION

**A/C cut relay (TD engine models)**

Check continuity between terminal Nos. ④ and ③ .

Conditions	Continuity
12V direct current supply between terminal Nos. ② and ①	No
No current supply	Yes

If NG, replace relay.

**Engine coolant temperature switch-2 (TD engine models)**

Check engine coolant temperature switch-2 for proper operation.

Operating temperature °C (°F)	Operation
Increasing to 87 - 93 (189 - 199)	OFF → ON
Decreasing to 82 - 84 (180 - 183)	ON → OFF

OFF: Continuity does not exist.

ON: Continuity exists.


## Insufficient Cooling

## TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT COOLING

## SYMPTOM:

- Insufficient cooling.

## Inspection flow



RHA405I

\*1: HA-4032

\*2: HA-4027

\*3: HA-4028

\*4: HA-4030

\*5: HA-101\*

\*6: HA-41\*

\*7: HA-4031

\*8: HA-100\*

\*9: HA-111\*

\*10: HA-4039

\*11: HA-41\*

\*: Refer to Y61 SERVICE MANUAL, Publication No. SM7E-2Y61G1.


## Insufficient Heating

## TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT HEATING

## **SYMPTOM:**

- Insufficient heating.

## Inspection flow



RHA406I

\*1: HA-4032

\*2: HA-4027

\*3: HA-4028

\*4: HA-4030

\*5: HA-100\*

\*6: HA-111\*

\*7: HA-4036

\*: Refer to Y61 SERVICE MANUAL, Publication No. SM7E-2Y61G1.


## Self-diagnosis

## TROUBLE DIAGNOSIS PROCEDURE FOR SELF-DIAGNOSIS

## SYMPTOM:

- Self-diagnosis cannot be performed.

## Inspection flow





RHA407I

\*1: HA-4032

\*2: HA-96 in Y61 SERVICE MANUAL,  
Publication No. SM7E-2Y61G1\*3: HA-91 in Y61 SERVICE MANUAL,  
Publication No. SM7E-2Y61G1

## Wiring Diagram — R/COOL —/LHD Models with Front Auto A/C



Refer to last page (Foldout page).


M20, B19  
 M2  
 M5  
 F38

## TROUBLE DIAGNOSES


## REAR COOLER

## **Wiring Diagram — R/COOL —/LHD Models with Front Auto A/C (Cont'd)**



HA-R/COOL-02



Refer to last page (Foldout page).  
**M20** , **B19**



## **Wiring Diagram — R/COOL —/LHD Models with Front Manual A/C Except for TB45E Engine**






| Refer to last page (Foldout page).

M20, B19  
M2  
M5  
E38

**Wiring Diagram — R/COOL —/LHD Models with  
Front Manual A/C Except for TB45E Engine  
(Cont'd)**




HA-R/COOL-04

\* FRONT : ON REAR : OFF  
FRONT : OFF REAR : ON



Refer to last page (Foldout page).  
(M20), (B19)

## Wiring Diagram — R/COOL —/LHD Models with Front Manual A/C for TB45E Engine



Refer to last page (Foldout page).


(M20, B19)

(M21, E127)

(M2)

(M5)

(E112)




## TROUBLE DIAGNOSES

## REAR COOLER

## **Wiring Diagram — R/COOL —/LHD Models with Front Manual A/C for TB45E Engine (Cont'd)**





HA-R/COOL-06

\* FRONT : ON REAR : OFF  
FRONT : OFF REAR : ON



Refer to last page (Foldout page).  
**M20** , **B19**

## **Wiring Diagram — R/COOL —/RHD Models with Front Auto A/C**



| Refer to last page (Foldout page).

Refer to last p

M20 ,

ME







# TROUBLE DIAGNOSES

REAR COOLER

## Wiring Diagram — R/COOL —/RHD Models with Front Auto A/C (Cont'd)

HA-R/COOL-08





\* FRONT : ON REAR : OFF  
FRONT : OFF REAR : ON



HA-4062

THA213M

## **Wiring Diagram — R/COOL —/RHD Models with Front Manual A/C**



| Refer to last page (Foldout page).

M20 B19

M20

M2

## TROUBLE DIAGNOSES

## **REAR COOLER**



---

## **Wiring Diagram — R/COOL —/RHD Models with Front Manual A/C (Cont'd)**

---





HA-R/COOL-10

\* FRONT : ON REAR : OFF  
FRONT : OFF REAR : ON






Refer to last page (Foldout page).  
**M20** , **B19**

## **Wiring Diagram — COOL/B —/All Engines Except TB48 and TB45E Wagon Models for the Middle East**





| Refer to last page (Foldout page)



\*: This connector is not shown in "HARNESS LAYOUT", EL section.

## **Wiring Diagram — COOL/B —/TB48 and TB45E Engine Wagon Models for the Middle East**



Refer to last page (Foldout page).

M30 B10

M20