



3. Ignition Coil and Ignitor Assembly

A: REMOVAL

- 1) Disconnect the ground cable from the battery.




- 2) Disconnect the spark plug cords from ignition coil and ignitor assembly.



- 3) Disconnect the connector (A) from ignition coil and ignitor assembly.

- 4) Remove the bolt (B) which secures the ignition coil and ignitor assembly to intake manifold.



B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

$6.4 \text{ N}\cdot\text{m} (0.65 \text{ kgf}\cdot\text{m}, 4.7 \text{ ft}\cdot\text{lb})$

CAUTION:

Connect the spark plug cords to correct positions. Failure to do so will damage the unit.

C: INSPECTION

Check the following items using a tester. Replace if defective.

- Secondary coil resistance

CAUTION:

- If the resistance is extremely low, it indicates the presence of a short-circuit.
- Ignitor is integrated with the coil. Therefore the resistance of primary side coil cannot be measured.

Specified resistance:

[Secondary side]

Between (A) and (B)

$11.2 \text{ k}\Omega \pm 15\%$

Between (C) and (D)

$11.2 \text{ k}\Omega \pm 15\%$

