


9. Engine Assembly


A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Open the front hood fully and support with the front hood stay.
- 3) Collect the refrigerant from the A/C system.
<Ref. to AC-21, PROCEDURE, Refrigerant Recovery Procedure.>
- 4) Release the fuel pressure.
<Ref. to FU(H4SO)-45, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 5) Disconnect the battery cable, and then remove the battery from the vehicle body.
- 6) Remove the air intake duct, air cleaner case and air intake chamber.
<Ref. to IN(H4SO)-7, REMOVAL, Air Intake Duct.>
<Ref. to IN(H4SO)-5, REMOVAL, Air Cleaner Case.>
<Ref. to IN(H4SO)-6, REMOVAL, Air Intake Chamber.>
- 7) Remove the under cover.
- 8) Remove the radiator from the vehicle. <Ref. to CO(H4SO)-25, REMOVAL, Radiator.>
- 9) Disconnect the A/C pressure hoses from A/C compressor.
- 10) Remove the air intake chamber stay.




- 11) Disconnect the following connectors and cables.

- (1) Front oxygen (A/F) sensor connector
- (2) Rear oxygen sensor connector




(A) Front oxygen (A/F) sensor connector
(B) Rear oxygen sensor connector


(3) Engine ground terminal



(4) Engine harness connectors




(5) Generator connector and terminal




(A) Terminals

(B) Generator connector


(6) A/C compressor connector



(7) Power steering switch connector




(4) Remove the power steering reservoir tank from the bracket by pulling it upwards.



12) Disconnect the following hoses.

(1) Brake booster vacuum hose




(2) Heater inlet and outlet hoses


13) Remove the power steering pump.

(1) Remove the front side belts. <Ref. to ME(H4SO)-41, FRONT SIDE BELT, REMOVAL, V-belt.>


(2) Remove the bolts which hold the power steering pipes onto the fuel pipe protector RH.



(3) Remove the power steering pump from the engine.



(5) Place the power steering pump on the right side wheel apron.




14) Remove the front and center exhaust pipes.


<Ref. to EX(H4SO)-4, REMOVAL, Front Exhaust Pipe.>

15) Remove the bolts and nuts which hold lower side of transmission to engine.

- AT model




- MT model



Engine Assembly


MECHANICAL

16) Remove the nuts which install front cushion rubber onto front crossmember.




17) Separate the torque converter clutch from drive plate. (AT model)

- (1) Lower the vehicle.
- (2) Remove the service hole plug.
- (3) Remove the bolts which hold torque converter clutch to drive plate.
- (4) Remove other bolts while rotating the crank-shaft using socket wrench.



18) Remove the pitching stopper.



19) Disconnect the fuel hoses from fuel pipe.


(1) Disconnect the quick connector on the fuel delivery line by pushing the ST in the direction of the arrow.

ST 42099AE000 CONNECTOR REMOVER

(2) Remove the clip and disconnect the evaporation hose from the pipe.

CAUTION:


- Be careful not to spill fuel.
- Catch the fuel from hoses using a container or cloth.



(A) Fuel delivery hose

(B) Evaporation hose


20) Support the engine with a lifting device and wire ropes.



21) Support the transmission with a garage jack.

CAUTION:

Be sure to always perform this work, in order to prevent the transmission from lowering for its own weight.



ME-00215

(A) Transmission

(B) Garage jack

22) Separation of engine and transmission


CAUTION:

Before removing the engine away from transmission, check to be sure no work has been overlooked.

(1) Remove the starter. <Ref. to SC(H4SO)-6, REMOVAL, Starter.>

(2) Attach the ST to converter case. (AT model)


ST 498277200 STOPPER SET



ME-00217


(3) Remove the bolts which hold upper side of transmission to engine.

- AT model



AT-00106

- MT model



MT-01524

23) Remove the engine from vehicle.

(1) Slightly raise the engine.

(2) Raise the transmission with garage jack.

(3) Move the engine horizontally until main shaft is withdrawn from clutch cover.

(4) Slowly move the engine away from engine compartment.

NOTE:

Be careful not to damage adjacent parts or body panels with crank pulley, oil level gauge, etc.

24) Remove the front cushion rubbers.

B: INSTALLATION

1) Install the front cushion rubbers to engine.

Tightening torque:

35 N·m (3.6 kgf-m, 25.8 ft-lb)

2) Apply a small amount of grease to splines of mainshaft. (MT model)

3) Position the engine in engine compartment and connect the engine to the transmission.

NOTE:


Be careful not to damage adjacent parts or body panels with crank pulley, oil level gauge, etc.

4) Tighten the bolts which hold upper side of transmission to engine.


Tightening torque:

50 N·m (5.1 kgf-m, 36.9 ft-lb)


- AT model



- MT model



5) Remove the lifting device and wire ropes.




6) Remove the garage jack.

7) Install the pitching stopper.

Tightening torque:

T1: 50 N·m (5.1 kgf-m, 36.9 ft-lb)

T2: 58 N·m (5.9 kgf-m, 42.8 ft-lb)



8) Remove the ST from the torque converter clutch case. (AT model)

NOTE:

Be careful not to drop the ST into the torque converter clutch case when removing the ST.

ST 498277200 STOPPER SET

9) Install the starter. <Ref. to SC(H4SO)-6, INSTALLATION, Starter.>

10) Install the torque converter clutch to drive plate. (AT model)

(1) Tighten the bolts which hold torque converter clutch to drive plate.


(2) Tighten other bolts while rotating the crankshaft using socket wrench.

NOTE:

Be careful not to drop bolts into the torque converter clutch housing.

Tightening torque:


25 N·m (2.5 kgf-m, 18.4 ft-lb)



(3) Install the service hole plug to prevent getting foreign matter inside.

11) Install the power steering pump.


(1) Install the power steering reservoir tank to the bracket.




(2) Install the power steering pump to the bracket, and tighten the bolts.

Tightening torque:


Refer to "COMPONENT" of "Power Steering" for the tightening torque. <Ref. to PS-4, COMPONENT, General Description.>



(3) Install the power steering pipe along with the bracket.



(4) Connect the power steering switch connector.



(5) Install and adjust the front side belt. <Ref. to ME(H4SO)-41, FRONT SIDE BELT, INSTALLATION, V-belt.>


12) Lift up the vehicle.

13) Tighten the bolts and nuts which hold lower side of the transmission to engine.


Tightening torque:

50 N·m (5.1 kgf·m, 36.9 ft-lb)

- AT model



- MT model




14) Tighten the nuts which install the front cushion rubber onto crossmember.

NOTE:

Make sure the front cushion rubber mounting bolts (A) and locator (B) are securely installed.

Tightening torque:

85 N·m (8.7 kgf·m, 62.7 ft-lb)



15) Install the front and center exhaust pipe.

<Ref. to EX(H4SO)-5, INSTALLATION, Front Exhaust Pipe.>

16) Lower the vehicle.

Engine Assembly

MECHANICAL

- 17) Connect the following hoses.
 - (1) Fuel delivery hose, and evaporation hose
 - (2) Heater inlet and outlet hoses
 - (3) Brake booster vacuum hose
- 18) Connect the following connectors and terminals.
 - (1) Front oxygen (A/F) sensor connector
 - (2) Rear oxygen sensor connector
 - (3) Engine harness connectors
 - (4) Generator connector and terminal
 - (5) A/C compressor connector
- 19) Install the air intake chamber stay.

Tightening torque:

16 N·m (1.6 kgf·m, 11.8 ft-lb)

- 20) Tighten the engine ground cable.

Tightening torque:

14 N·m (1.4 kgf·m, 10.1 ft-lb)

- 21) Install the A/C pressure hoses. <Ref. to AC-36, INSTALLATION, Hose and Tube.>
- 22) Install the radiator to vehicle. <Ref. to CO(H4SO)-27, INSTALLATION, Radiator.>
- 23) Install the air intake duct, air cleaner case and air intake chamber. <Ref. to IN(H4SO)-7, INSTALLATION, Air Intake Duct.> <Ref. to IN(H4SO)-5, INSTALLATION, Air Cleaner Case.> <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Chamber.>
- 24) Install the under cover.
- 25) Install the battery in the vehicle, and connect cables.
- 26) Fill engine coolant.
<Ref. to CO(H4SO)-17, FILLING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>
- 27) Check the ATF level and replenish it if necessary.
<Ref. to 4AT-28, INSPECTION, Automatic Transmission Fluid.>
- 28) Charge the A/C system with refrigerant. <Ref. to AC-22, PROCEDURE, Refrigerant Charging Procedure.>
- 29) Remove the front hood stay, and close the front hood.
- 30) Lower the vehicle from lift.

C: INSPECTION

- 1) Check that pipes, hoses, connectors and clamps are installed firmly.
- 2) Check the engine coolant and ATF are at specified levels.
- 3) Start the engine and check for exhaust gas, engine coolant, leaks of fuel, etc. Also check for noise and vibrations.