


11. Fuel Injector

A: REMOVAL

1. RH SIDE

1) Release the fuel pressure. <Ref. to FU(H4DOTC)-51, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>

2) Disconnect the ground cable from the battery.



3) Open the fuel filler flap lid, and remove the fuel filler cap.

4) Remove the collector cover.

5) Remove the air cleaner upper cover and air intake boot. <Ref. to IN(H4DOTC)-8, REMOVAL, Air Cleaner Case.>

6) Remove the air cleaner element.


7) Remove the coolant filler tank.

<Ref. to CO(H4SO)-40, REMOVAL, Coolant Filler Tank.>

8) Remove the power steering pump.

(1) Remove the front side belts. <Ref. to ME(H4DOTC)-39, FRONT SIDE BELT, REMOVAL, V-belt.>


(2) Disconnect the power steering switch connector.




(3) Remove the bolts which install the power steering pipe bracket to the intake manifold.

NOTE:


Do not disconnect the power steering hose.




(4) Remove the bolts which install power steering pump bracket.



(5) Remove the reservoir tank from the bracket by pulling it upward.




(6) Place the power steering pump on the right side wheel apron.




Fuel Injector

FUEL INJECTION (FUEL SYSTEMS)



9) Remove the fuel pipe protector RH.




10) Disconnect the connector from fuel injector.



11) Remove the bolt which holds fuel injector pipe onto intake manifold.




12) Remove the fuel injector while lifting up the fuel injector pipe.



2. LH SIDE

1) Release the fuel pressure. <Ref. to FU(H4DOTC)-51, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>

2) Disconnect the ground cable from the battery.




3) Open the fuel filler flap lid, and remove the fuel filler cap.

4) Remove the collector cover.

5) Remove the intake manifold.


<Ref. to FU(H4DOTC)-14, REMOVAL, Intake Manifold.>

6) Remove the fuel pipe protector LH.





7) Disconnect the connector from fuel injector.

8) Remove the bolts which hold fuel injector pipes on the left side of intake manifold.



9) Remove the bolt which holds fuel injector pipe onto intake manifold.



10) Remove the fuel injector while lifting up the fuel injector pipe.


B: INSTALLATION

1. RH SIDE

Install in the reverse order of removal.

NOTE:

Use new O-rings.




(A) O-ring

(B) Fuel injector


Tightening torque:

19 N·m (1.9 kgf-m, 14.0 ft-lb)



Tightening torque:


19 N·m (1.9 kgf-m, 14.0 ft-lb)




Fuel Injector

FUEL INJECTION (FUEL SYSTEMS)

Tightening torque:
19 N·m (1.9 kgf-m, 14.0 ft-lb)



Tightening torque:
19 N·m (1.9 kgf-m, 14.0 ft-lb)




2. LH SIDE

Install in the reverse order of removal.


NOTE:

Use new O-rings.




- (A) O-ring
- (B) Fuel injector

Tightening torque:
6.4 N·m (0.65 kgf-m, 4.7 ft-lb)



Tightening torque:
19 N·m (1.9 kgf-m, 14.0 ft-lb)



Tightening torque:
19 N·m (1.9 kgf-m, 14.0 ft-lb)

