


7. Timing Belt

A: REPLACEMENT

1. NON-TURBO MODEL


- 1) Remove the radiator fan and air conditioner fan. <Ref. to CO(H4SO)-32, Radiator Main Fan and Fan Motor. > <Ref. to CO(H4SO)-38, Radiator Sub Fan and Fan Motor. >
- 2) Protect the radiator with cardboard and blanket.
- 3) Remove the V-belt covers.



PM-00348


- 4) Remove the V-belts. <Ref. to ME(H4SO)-41, V-belt. >
- 5) Remove the A/C compressor V-belt tensioner.
- 6) Using the ST, lock the crankshaft and remove pulley bolt.

ST 499977100 CRANK PULLEY WRENCH



PM-00007


- 7) Remove the crank pulley.
- 8) Remove the belt cover LH.
- 9) Remove the front timing belt cover.
- 10) Remove the timing belt guide. (MT model)



PM-00008

- 11) Turn the crankshaft and align the alignment marks on crankshaft, and left and right cam sprockets with notches of belt cover and cylinder block.

ST 499987500 CRANKSHAFT SOCKET




PM-00009

(A) Notch


(B) Alignment mark

- 12) Remove the belt idler.
- 13) Remove the belt idler (No. 2).



PM-00010

- 14) Remove the timing belt.
- 15) Remove the automatic belt tension adjuster assembly.




PM-00011

16) Install in the reverse order of removal. <Ref. to ME(H4SO)-46, INSTALLATION, Timing Belt.>





2. TURBO MODEL

- 1) Remove the radiator fan and air conditioner fan. <Ref. to CO(H4SO)-33, TURBO MODEL, REMOVAL, Radiator Main Fan and Fan Motor.> <Ref. to CO(H4SO)-38, Radiator Sub Fan and Fan Motor.>
- 2) Protect the radiator with cardboard and blanket.
- 3) Remove the V-belts. <Ref. to ME(H4SO)-41, V-belt.>
- 4) Remove the A/C compressor V-belt tensioner.
- 5) Using the ST, lock the crankshaft and remove pulley bolt.

ST 499977100 CRANK PULLEY WRENCH





- 6) Remove the crank pulley.
- 7) Remove the belt cover (LH).
- 8) Remove the belt cover (RH).
- 9) Remove the front belt cover.
- 10) Remove the timing belt guide. (MT model)



- 11) Turn the crankshaft and align the alignment marks on crankshaft, and left and right cam sprockets with notches of belt cover and cylinder block. Use the ST to turn crankshaft.


ST 499987500 CRANKSHAFT SOCKET



Timing Belt


PERIODIC MAINTENANCE SERVICES

12) Remove the belt idler.



13) Remove the timing belt.

14) Remove the automatic belt tension adjuster assembly.



15) Install in the reverse order of removal. <Ref. to ME(H4DOTC)-45, INSTALLATION, Timing Belt.>


CAUTION:

When installing the timing belt, be sure to align all alignment marks on the belt with corresponding marks on the sprockets. If incorrectly installed, interference between pistons and valves may occur.

B: INSPECTION

1. SOHC MODEL


- 1) Remove the timing belt cover (LH).
- 2) While cranking engine at least four rotations, check the timing belt back surface for cracks or damage. Replace the faulty timing belt as needed.
- 3) If the surface of timing belt (surface indicated by the arrow in the figure) is worn abnormally (scuffing and coming out of core) or damaged, inspect the idlers, tensioner, water pump pulley and cam sprocket and check the idler alignment for squareness. Replace the worn or damaged timing belt.



4) Install the timing belt cover (LH).

2. DOHC MODEL

- 1) Remove the timing belt cover (LH).
- 2) While cranking engine at least four rotations, check the timing belt back surface for cracks or damage. Replace the faulty timing belt as needed.
- 3) If the surface of timing belt (surface indicated by the arrow in the figure) is worn abnormally (scuffing and coming out of core) or damaged, inspect the idlers, tensioner, water pump pulley and cam sprocket and check the idler alignment for squareness. Replace the worn or damaged timing belt.



4) Install the timing belt cover (LH).