

25. Tail/Stop Light Bulb


A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the light assembly - rear combination.


CAUTION:

Be careful not to damage the clips.

- (1) Release the bolts and clips, then pull out the light assembly - rear combination to the vehicle rear.
- (2) Disconnect the connector and remove the light assembly - rear combination.



- 3) Remove the bulb sockets and bulbs.



(a) Tail light/stop light

(b) Tail light

B: INSTALLATION

Install each part in the reverse order of removal.

Tightening torque:

Light assembly - rear combination: 7.5 N·m (0.76 kgf·m, 5.5 ft-lb)

C: INSPECTION

- 1) Visually check the bulb for blow out.
- 2) Check the bulb specification. <Ref. to LI-2, SPECIFICATION, General Description.>
- 3) Replace the bulb if it is found defective.