


9. Camshaft Position Sensor


A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the air intake duct (rear). (RH side only) <Ref. to IN(H4DO)-12, REMOVAL, Air Intake Duct.>
- 3) Disconnect the connector (A) from the camshaft position sensor, and remove the camshaft position sensor from the chain cover.

- RH side



- LH side



B: INSTALLATION

Install in the reverse order of removal.

NOTE:

- Use new O-rings.
- Apply engine oil to O-ring.

Tightening torque:

6.4 N·m (0.7 kgf-m, 4.7 ft-lb)


Camshaft Position Sensor

FUEL INJECTION (FUEL SYSTEMS)

C: INSPECTION

1. CAMSHAFT POSITION SENSOR (METHOD WITH OSCILLOSCOPE)

- 1) Prepare an oscilloscope.
- 2) Remove the glove box. <Ref. to EI-61, REMOVAL, Glove Box.>
- 3) Connect the probe to ECM connector.




(A) To ECM connector

Camshaft position sensor	Terminal No.	Probe
RH	26	+
LH	15	+
RH and LH	34	-

- 4) Start the engine and let it idle.

5) Check the pattern is the same as the waveform and voltage shown below.



(A) One camshaft rotation

(B) Camshaft position sensor RH

(C) Camshaft position sensor LH

6) After inspection, install the related parts in the reverse order of removal.

2. OTHER INSPECTIONS

Check that the camshaft position sensor has no deformation, cracks or other damages.