

3. Ignition Coil

A: REMOVAL

Direct ignition type is adopted. Refer to "Spark Plug" for removal procedure. <Ref. to IG(H4DOTC)-4, REMOVAL, Spark Plug.>

B: INSTALLATION

Direct ignition type is adopted. Refer to "Spark Plug" for the installation procedure. <Ref. to IG(H4DOTC)-5, INSTALLATION, Spark Plug.>

C: INSPECTION

For inspection procedure, refer to "Diagnostics for Engine Starting Failure". <Ref. to EN(H4DOTC)(diag)-76, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>

Ignition Coil

IGNITION

STARTING/CHARGING SYSTEMS

SC(H4DOTC)

	Page
1. General Description	2