


## 11. Air By-pass Valve

### A: REMOVAL

- 1) Remove the intake duct No. 1. <Ref. to IN(H4DOTC)-20, INTAKE DUCT NO. 1, REMOVAL, Intake Duct.>
- 2) Disconnect the vacuum hose from the air by-pass valve, and remove the air by-pass valve from the intake duct No. 2.



### B: INSTALLATION

Install in the reverse order of removal.


#### ***Tightening torque:***

***3 N·m (0.3 kgf·m, 2.2 ft-lb)***

### C: INSPECTION

#### 1. AIR BY-PASS VALVE


- 1) Check that the air by-pass valve has no deformation, cracks or other damages.
- 2) Connect the Mighty Vac to the nipple (A) of the air by-pass valve.



# Air By-pass Valve

## INTAKE (INDUCTION)

- 3) Using the Mighty Vac, generate the vacuum pressure to  $-93.3 \text{ kPa}$  ( $-0.95 \text{ kgf/cm}^2$ ,  $-13.5 \text{ psi}$ ). Check that the Mighty Vac gauge needle holds 10 seconds without falling by  $-92.6 \text{ kPa}$  ( $-0.94 \text{ kgf/cm}^2$ ,  $-13.4 \text{ psi}$ ).
- 4) Set a dial gauge to the end of valve rod of the air by-pass valve.



- 5) Using the Mighty Vac, generate the negative pressure, and check the pressure when dial gauge needle (valve stroke) shows  $0.5 \text{ mm}$  ( $0.02 \text{ in}$ ). If it is not within the standard, replace the air by-pass valve.

***Opening pressure (valve stroke  $0.5 \text{ mm}$  ( $0.02 \text{ in}$ )):***

***Standard***

***$-13.3 \text{ --- } -21.3 \text{ kPa}$  ( $-0.14 \text{ --- } -0.22 \text{ kgf/cm}^2$ ,  $-1.93 \text{ --- } -3.09 \text{ psi}$ )***

## 2. OTHER INSPECTIONS

Check that the vacuum hose and air by-pass pipe have no cracks, damage or loose part.