


### 40. Transmission Case

#### A: REMOVAL

- 1) Remove the transmission assembly from the vehicle. <Ref. to CVT(TR690)-55, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the air breather hose. <Ref. to CVT(TR690)-132, REMOVAL, Air Breather Hose.>
- 3) Remove the transmission harness. <Ref. to CVT(TR690)-118, REMOVAL, Transmission Harness.>
- 4) Remove the secondary speed sensor. <Ref. to CVT(TR690)-98, REMOVAL, Secondary Speed Sensor.>
- 5) Remove the inhibitor switch. <Ref. to CVT(TR690)-94, REMOVAL, Inhibitor Switch.>
- 6) Remove the extension case. <Ref. to CVT(TR690)-138, REMOVAL, Extension Case.>
- 7) Remove the rear drive shaft. <Ref. to CVT(TR690)-141, REMOVAL, Rear Drive Shaft.>
- 8) Remove the transfer clutch assembly. <Ref. to CVT(TR690)-146, REMOVAL, Transfer Clutch.>
- 9) Remove the transfer reduction driven gear assembly. <Ref. to CVT(TR690)-158, REMOVAL, Transfer Reduction Driven Gear.>
- 10) Remove the intermediate case. <Ref. to CVT(TR690)-165, REMOVAL, Intermediate Case.>
- 11) Remove the forward clutch assembly. <Ref. to CVT(TR690)-180, REMOVAL, Forward Clutch Assembly.>
- 12) Remove the reduction driven gear. <Ref. to CVT(TR690)-200, REMOVAL, Reduction Driven Gear.>
- 13) Remove the oil pan and control valve body. <Ref. to CVT(TR690)-108, REMOVAL, Control Valve Body.>

NOTE:

When removing the control valve body, also remove the pressure pipe if it is attached on the case.




## Transmission Case

### CONTINUOUSLY VARIABLE TRANSMISSION

14) Remove the CVTF pipe using a tire lever etc.

NOTE:


Remove by hooking the stepped portion of CVTF pipe with a tire lever etc.



(A) CVTF pipe

(B) Tire lever

15) Remove the CVTF cooler hose.




16) Remove the transmission case.

NOTE:

The total number of transmission case mounting bolts is 15.

17) Remove the O-ring of lubrication pipe.



AT-05279


18) Remove the control device system. <Ref. to CVT(TR690)-207, REMOVAL, Transmission Control Device.>

## B: INSTALLATION

- 1) Clean the mating surface of transmission case and converter case.
- 2) Install the control device system. <Ref. to CVT(TR690)-209, INSTALLATION, Transmission Control Device.>
- 3) Install the O-ring to the lubrication pipe.

NOTE:

- Use new O-rings.
- Apply CVTF to the O-ring.




AT-05279

## Transmission Case


### CONTINUOUSLY VARIABLE TRANSMISSION

- 4) Make sure the lubrication pipe and support rod are in vertical position.



- 5) Apply liquid gasket seamlessly to the mating surface of transmission case.

**Liquid gasket:**  
**THREE BOND 1215 (Part No. 004403007) or equivalent**



- 6) Install the transmission case.

**CAUTION:**

**If the transmission case gets in contact with the lubrication pipe and support rod, do not install the transmission case forcibly.**

**NOTE:**

- Install while checking the lubrication pipe and support rod is being inserted properly into transmission case.
- If installing the transmission is difficult, check if the lubrication pipe and support rod are bent.
- The total number of transmission case mounting bolts is 15.

**Tightening torque:**

**41 N·m (4.2 kgf·m, 30.2 ft-lb)**

# Transmission Case

## CONTINUOUSLY VARIABLE TRANSMISSION

7) Install the O-ring to CVTF pipe.



NOTE:

Use new O-rings.

8) The smaller opening of CVTF pipe should be inserted to transmission.

NOTE:

After installing, make sure the CVTF pipe does not stick out of transmission case.




## Transmission Case

### CONTINUOUSLY VARIABLE TRANSMISSION

9) Install the CVTF hose.

NOTE:

- Use new CVTF hoses.
- Install the CVTF hose with the painted position facing the rear side of transmission.



10) Install the reduction driven gear. <Ref. to CVT(TR690)-201, INSTALLATION, Reduction Driven Gear.>

11) Install the forward clutch assembly. <Ref. to CVT(TR690)-181, INSTALLATION, Forward Clutch Assembly.>

12) Install the intermediate case. <Ref. to CVT(TR690)-166, INSTALLATION, Intermediate Case.>

13) Install the transfer reduction driven gear assembly. <Ref. to CVT(TR690)-158, INSTALLATION, Transfer Reduction Driven Gear.>

14) Install the transfer clutch assembly. <Ref. to CVT(TR690)-147, INSTALLATION, Transfer Clutch.>

15) Install the rear drive shaft. <Ref. to CVT(TR690)-141, INSTALLATION, Rear Drive Shaft.>

16) Install the extension case. <Ref. to CVT(TR690)-139, INSTALLATION, Extension Case.>

17) Install the inhibitor switch. <Ref. to CVT(TR690)-96, INSTALLATION, Inhibitor Switch.>

18) Install the secondary speed sensor. <Ref. to CVT(TR690)-99, INSTALLATION, Secondary Speed Sensor.>

19) Install the transmission harness. <Ref. to CVT(TR690)-120, INSTALLATION, Transmission Harness.>


20) Install the control valve body and oil pan. <Ref. to CVT(TR690)-112, INSTALLATION, Control Valve Body.>

21) Install the air breather hose. <Ref. to CVT(TR690)-132, INSTALLATION, Air Breather Hose.>

22) Install the transmission assembly to the vehicle. <Ref. to CVT(TR690)-68, INSTALLATION, Automatic Transmission Assembly.>

### C: DISASSEMBLY


- 1) Remove the CVTF inlet pipe and CVTF outlet pipe.



(A) CVTF outlet pipe

(B) CVTF inlet pipe


- 2) Remove all plugs from the transmission case.




## Transmission Case

### CONTINUOUSLY VARIABLE TRANSMISSION

- 3) Remove the lubrication pipe.




- 4) Remove the oil seal using a screwdriver wrapped with cloth etc.



# Transmission Case


CONTINUOUSLY VARIABLE TRANSMISSION

5) Remove the ball bearing from reduction driven gear using ST.  
ST 398527700 PULLER ASSY



AT-05286

6) Remove the snap ring on primary pulley side.



AT-05287

# Transmission Case


## CONTINUOUSLY VARIABLE TRANSMISSION

7) Using the ST, remove the roller bearing on primary pulley side.


NOTE:

Warm up the bearing area of transmission case using a drier or heat gun.

ST 398527700 PULLER ASSY



8) Remove the snap ring on secondary pulley side.



# Transmission Case


CONTINUOUSLY VARIABLE TRANSMISSION

9) Using the ST, remove the roller bearing on secondary pulley side.

NOTE:

Warm up the bearing area of transmission case using a drier or heat gun.


ST 398527700 PULLER ASSY



## D: ASSEMBLY

1) Using the ST, install the oil seal.

ST 18657AA000 INSTALLER



# Transmission Case

## CONTINUOUSLY VARIABLE TRANSMISSION


2) Using ST1 and ST2, install the ball bearing on the reduction gear side.

NOTE:

Use a new ball bearing.

ST1 398177700 INSTALLER

ST2 499755602 PRESS SNAP RING



3) Using ST1 and ST2, install the roller bearing on primary pulley side.


NOTE:

- Use a new roller bearing.

- Make adjustment so that the press gets in contact with the center of ST2.

ST1 398177700 INSTALLER

ST2 20299AG010 PRESS SNAP RING




# Transmission Case

CONTINUOUSLY VARIABLE TRANSMISSION

4) Install the snap ring on primary pulley side.

NOTE:

Use new snap rings.



AT-05287


5) Using ST1 and ST2, install the roller bearing on secondary pulley side.

NOTE:

- Use a new roller bearing.
- Make adjustment so that the press gets in contact with the center of ST2.

ST1 398177700 INSTALLER

ST2 499755602 PRESS SNAP RING



AT-05293


# Transmission Case

## CONTINUOUSLY VARIABLE TRANSMISSION

6) Install the snap ring on secondary pulley side.

NOTE:

Use new snap rings.



AT-05289

7) Install all plugs.

NOTE:


Use new gaskets and O-rings.

**Tightening torque:**

**T1: 13 N·m (1.3 kgf-m, 9.6 ft-lb)**

**T2: 25 N·m (2.5 kgf-m, 18.4 ft-lb)**

**T3: 35 N·m (3.5 kgf-m, 25.8 ft-lb)**



AT-05294

# Transmission Case

## CONTINUOUSLY VARIABLE TRANSMISSION


8) Install the lubrication pipe and O-ring.

NOTE:

- Use new O-rings.
- Apply CVTF to the O-ring.

**Tightening torque:**

**16 N·m (1.6 kgf-m, 11.8 ft-lb)**



9) Install the CVTF inlet pipe and CVTF outlet pipe.


NOTE:

Use a new gasket.

**Tightening torque:**

**T1: 16 N·m (1.6 kgf-m, 11.8 ft-lb)**

**T2: 40 N·m (4.1 kgf-m, 29.5 ft-lb)**



## E: INSPECTION

- Check the transmission case for damage.
- Check for leakage of CVTF from the connection between converter case and transmission case.
- Check for leakage of CVTF from the connection between intermediate case and transmission case.
- Check the lubrication pipe for bend or damage.
- Check the bearing for smooth operation.
- Check the bearing for seizure or wear.

## F: ADJUSTMENT

### NOTE:

When replacing the transmission case with a new part, perform the following check and adjustment for the selection.

- Select the thrust bearing for the forward clutch assembly. <Ref. to CVT(TR690)-198, ADJUSTMENT, Forward Clutch Assembly.>
- Select the snap ring for the reduction gear. <Ref. to CVT(TR690)-206, ADJUSTMENT, Reduction Driven Gear.>