

50. Converter Case

A: REMOVAL

- 1) Remove the transmission assembly from the vehicle. <Ref. to CVT(TR690)-55, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the air breather hose. <Ref. to CVT(TR690)-132, REMOVAL, Air Breather Hose.>
- 3) Remove the oil pan and control valve body. <Ref. to CVT(TR690)-108, REMOVAL, Control Valve Body.>
- 4) Remove the transmission harness. <Ref. to CVT(TR690)-118, REMOVAL, Transmission Harness.>
- 5) Remove the secondary pressure sensor. <Ref. to CVT(TR690)-106, REMOVAL, Secondary Pressure Sensor.>
- 6) Remove the primary speed sensor. <Ref. to CVT(TR690)-101, REMOVAL, Primary Speed Sensor.>
- 7) Remove the extension case. <Ref. to CVT(TR690)-138, REMOVAL, Extension Case.>
- 8) Remove the rear drive shaft. <Ref. to CVT(TR690)-141, REMOVAL, Rear Drive Shaft.>
- 9) Remove the transfer clutch assembly. <Ref. to CVT(TR690)-146, REMOVAL, Transfer Clutch.>
- 10) Remove the transfer reduction driven gear assembly. <Ref. to CVT(TR690)-158, REMOVAL, Transfer Reduction Driven Gear.>
- 11) Remove the intermediate case. <Ref. to CVT(TR690)-165, REMOVAL, Intermediate Case.>
- 12) Remove the forward clutch assembly. <Ref. to CVT(TR690)-180, REMOVAL, Forward Clutch Assembly.>
- 13) Remove the transmission case. <Ref. to CVT(TR690)-211, REMOVAL, Transmission Case.>
- 14) Remove the primary pulley, secondary pulley and variator chain. <Ref. to CVT(TR690)-227, REMOVAL, Primary Pulley and Secondary Pulley.>
- 15) Remove the drive pinion shaft assembly. <Ref. to CVT(TR690)-243, REMOVAL, Drive Pinion Shaft Assembly.>
- 16) Remove the front differential assembly. <Ref. to CVT(TR690)-265, REMOVAL, Front Differential Assembly.>
- 17) Remove the converter case cover. <Ref. to CVT(TR690)-291, REMOVAL, Converter Case Cover.>
- 18) Remove the front reduction drive gear and front reduction driven gear. <Ref. to CVT(TR690)-301, REMOVAL, Front Reduction Drive Gear.>

B: INSTALLATION


- 1) Install the front reduction drive gear and front reduction driven gear. <Ref. to CVT(TR690)-302, INSTALLATION, Front Reduction Drive Gear.>
- 2) Install the converter case cover. <Ref. to CVT(TR690)-294, INSTALLATION, Converter Case Cover.>
- 3) Install the front differential assembly. <Ref. to CVT(TR690)-266, INSTALLATION, Front Differential Assembly.>
- 4) Install the drive pinion shaft assembly. <Ref. to CVT(TR690)-245, INSTALLATION, Drive Pinion Shaft Assembly.>
- 5) Install the primary pulley, secondary pulley and steel chain. <Ref. to CVT(TR690)-231, INSTALLATION, Primary Pulley and Secondary Pulley.>
- 6) Install the transmission case. <Ref. to CVT(TR690)-211, REMOVAL, Transmission Case.>
- 7) Install the forward clutch assembly. <Ref. to CVT(TR690)-181, INSTALLATION, Forward Clutch Assembly.>
- 8) Install the intermediate case. <Ref. to CVT(TR690)-166, INSTALLATION, Intermediate Case.>
- 9) Install the transfer reduction driven gear. <Ref. to CVT(TR690)-158, INSTALLATION, Transfer Reduction Driven Gear.>
- 10) Install the transfer clutch assembly. <Ref. to CVT(TR690)-147, INSTALLATION, Transfer Clutch.>
- 11) Install the rear drive shaft. <Ref. to CVT(TR690)-141, INSTALLATION, Rear Drive Shaft.>
- 12) Install the extension case. <Ref. to CVT(TR690)-139, INSTALLATION, Extension Case.>
- 13) Install the primary speed sensor. <Ref. to CVT(TR690)-102, INSTALLATION, Primary Speed Sensor.>
- 14) Install the secondary pressure sensor. <Ref. to CVT(TR690)-106, INSTALLATION, Secondary Pressure Sensor.>
- 15) Install the transmission harness. <Ref. to CVT(TR690)-120, INSTALLATION, Transmission Harness.>
- 16) Install the control valve body and oil pan. <Ref. to CVT(TR690)-112, INSTALLATION, Control Valve Body.>
- 17) Install the air breather hose. <Ref. to CVT(TR690)-132, INSTALLATION, Air Breather Hose.>
- 18) Install the transmission assembly to the vehicle. <Ref. to CVT(TR690)-68, INSTALLATION, Automatic Transmission Assembly.>

Converter Case


CONTINUOUSLY VARIABLE TRANSMISSION

C: DISASSEMBLY

- 1) Remove the CVTF cooler pipe COMPL.



- 2) Remove the pitching stopper bracket and transmission radio ground cord, if mounted.
- 3) Remove the oil drain plug and overflow drain plug. <Ref. to CVT(TR690)-42, REPLACEMENT, Differential Gear Oil.>
- 4) Remove all plugs.



D: ASSEMBLY

- 1) Install the oil drain plug and overflow drain plug.

NOTE:

Overflow plug of differential gear oil is temporarily attached.


- 2) Install all plugs.

NOTE:

Use new O-rings.

Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft-lb)



AT-07554

- 3) Install the pitching stopper bracket and transmission radio ground cord.


Tightening torque:

41 N·m (4.2 kgf·m, 30.2 ft-lb)

- 4) Install the CVTF cooler pipe COMPL.

Tightening torque:

16 N·m (1.6 kgf·m, 11.8 ft-lb)



AT-07841

Converter Case

CONTINUOUSLY VARIABLE TRANSMISSION

E: INSPECTION

- Check for leakage of CVTF from the connection between converter case and transmission case.
- Check there is no damage or cracks on the converter case.

F: ADJUSTMENT

When replacing the converter case cover, select the following shims.

- Select the shim for front reduction drive gear. <Ref. to CVT(TR690)-307, ADJUSTMENT, Front Reduction Drive Gear.>
- Select the shim for front reduction driven gear. <Ref. to CVT(TR690)-315, ADJUSTMENT, Front Reduction Driven Gear.>
- Select shims for primary pulley. <Ref. to CVT(TR690)-237, ADJUSTMENT, Primary Pulley and Secondary Pulley.>