



19.Reverse Idler Gear

A: REMOVAL

- 1) Remove the manual transmission assembly from the vehicle. <Ref. to 6MT-26, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the back-up light switch and the neutral position switch. <Ref. to 6MT-40, REMOVAL, Switches and Harness.>
- 3) Remove the transfer case together with the extension case assembly. <Ref. to 6MT-44, REMOVAL, Transfer Case and Extension Case Assembly.>
- 4) Remove the transmission case. <Ref. to 6MT-63, REMOVAL, Transmission Case.>
- 5) Remove the drive pinion shaft assembly. <Ref. to 6MT-76, REMOVAL, Drive Pinion Shaft Assembly.>
- 6) Remove the main shaft assembly. <Ref. to 6MT-67, REMOVAL, Main Shaft Assembly for Single-Range.>
- 7) Remove the front differential assembly. <Ref. to 6MT-87, REMOVAL, Front Differential Assembly.>
- 8) Shift into 4th.
- 9) Remove the snap ring.




- 10) Remove the reverse idler gear shaft securing bolt.




- 11) Press out the reverse idler gear shaft from the backside of the transmission to remove.

NOTE:

Support the reverse idler gear assembly with hands to avoid collapsing.



- 12) Remove the reverse idler gear.
- 13) Remove the reverse idler gear bushing.




Reverse Idler Gear

MANUAL TRANSMISSION AND DIFFERENTIAL

B: INSTALLATION


NOTE:

Rotate the reverse idler sub gear by two teeth from free status in the direction of the arrow to make it engage with the reverse gear of the main shaft and install the main shaft assembly.



- (A) Free status
- (B) Set status
- (C) Reverse idler sub gear
- (D) Reverse idler gear

1) Install the reverse idler gear bushing with the cutout portion of the reverse idler gear bushing facing the front of the transmission.




2) Assembling reverse idler gear assembly

(1) Install the reverse coupling sleeve to the reverse idler gear No. 2.

NOTE:


- Install the reverse coupling sleeve in the correct direction.
- Make sure that the oval-shaped cutout portion inside the reverse coupling sleeve matches the center of the reverse idler gear No. 2 groove.



(2) Install the shifting insert.

NOTE:


Press in the ball part to install.



Reverse Idler Gear


MANUAL TRANSMISSION AND DIFFERENTIAL

(3) Install the baulk ring and reverse idler gear.



- (A) Reverse idler gear
- (B) Baulk ring

(4) Install the needle bearing and reverse idler gear collar.




- (A) Needle bearing
- (B) Reverse idler gear collar

(5) Install the thrust bearing and washer.

NOTE:

Install the thrust bearing in the correct direction.



3) Install the assembled reverse idler gear assembly to the transmission case and hold it with hands.


Reverse Idler Gear

MANUAL TRANSMISSION AND DIFFERENTIAL

4) Install the reverse idler gear shaft.

NOTE:

- Install with the cutout portion of the reverse idler gear shaft facing the RH side of the transmission case.
- Make sure that the groove of the reverse idler gear shaft comes out of the reverse idler gear bushing.




- (A) Cutout portion of the reverse idler gear shaft
(B) Snap ring installation groove


5) Install the reverse idler gear shaft securing bolt.

Tightening torque:

25 N·m (2.5 kgf-m, 18.4 ft-lb)



6) Install the snap ring.



7) Select the reverse idler gear bushing. <Ref. to 6MT-101, ADJUSTMENT, Reverse Idler Gear.>

8) Remove the reverse idler gear assembly and replace with the selected bushing. <Ref. to 6MT-95, REMOVAL, Reverse Idler Gear.>


Reverse Idler Gear

MANUAL TRANSMISSION AND DIFFERENTIAL

9) Install the reverse idler gear assembly, oil case guide and reverse idler gear shaft.

NOTE:

- Install with the cutout portion of the reverse idler gear shaft facing the RH side of the transmission case.
- Make sure that the groove of the reverse idler gear shaft comes out of the reverse idler gear bushing.
- Insert the cutout portion of the reverse idler gear bushing into the oil case guide.



(A) Oil case guide


10) Install the reverse idler gear shaft securing bolt.

NOTE:

Use a new gasket.


Tightening torque:

25 N·m (2.5 kgf-m, 18.4 ft-lb)



MT-02517

11) Install the snap ring.



MT-02516

12) Check the reverse shifter fork. <Ref. to 6MT-104, INSPECTION, Shifter Fork and Rod.>

13) Install the front differential assembly. <Ref. to 6MT-87, INSTALLATION, Front Differential Assembly.>

Reverse Idler Gear

MANUAL TRANSMISSION AND DIFFERENTIAL

14) Install the main shaft assembly. <Ref. to 6MT-67, INSTALLATION, Main Shaft Assembly for Single-Range.>

15) Install the drive pinion shaft assembly. <Ref. to 6MT-76, INSTALLATION, Drive Pinion Shaft Assembly.>

16) Install the transmission case. <Ref. to 6MT-64, INSTALLATION, Transmission Case.>

17) Install the transfer case together with the extension case assembly. <Ref. to 6MT-45, INSTALLATION, Transfer Case and Extension Case Assembly.>


18) Install the back-up light switch and the neutral position switch. <Ref. to 6MT-40, INSTALLATION, Switches and Harness.>

19) Install the manual transmission assembly to the vehicle. <Ref. to 6MT-29, INSTALLATION, Manual Transmission Assembly.>

C: DISASSEMBLY


1. REVERSE IDLER GEAR ASSY

1) Remove the snap ring and friction plate from reverse gear.



- (A) Friction plate
- (B) Snap ring

2) Remove the sub gear and spring.



- (A) Reverse idler sub gear
- (B) Reverse idler spring
- (C) Reverse idler gear


D: ASSEMBLY

1. REVERSE IDLER GEAR ASSY

1) Attach the sub gear and spring.

NOTE:

Point the stamp (marking A) towards the outside, and install the sub gear.




- (A) Reverse idler sub gear
- (B) Reverse idler spring
- (C) Reverse idler gear
- (D) Stamp (marking A)

2) Install the friction plate and snap ring.

NOTE:

Make sure the friction plate is installed in the proper direction.



- (A) Friction plate
- (B) Snap ring

Reverse Idler Gear


MANUAL TRANSMISSION AND DIFFERENTIAL

E: INSPECTION

1) Check the clearance between the reverse idler gear bushing and reverse idler gear washer. If out of specification, select the appropriate reverse idler gear bushing and adjust.

Clearance (a):


0.1 — 0.3 mm (0.004 — 0.012 in)



MT-02527

2) Check the reverse idler gear and shaft for damage. Replace if it is damaged.

3) Apply gear oil to the cone of the gear and while press-fitting the baulk ring, check there is no rotation in the circumferential direction.




MT-02530

4) Coupling sleeve and synchronizer hub

- Check the slipping condition of the coupling sleeve.
- Check the splines on the coupling sleeve and reverse idler gear for wear.

5) Shifting insert

Replace the shifting insert if there is deformation, excessive wear on the ball section or any defectiveness.




MT-02493

F: ADJUSTMENT

1) Select the appropriate reverse idler gear bushing from the table below, and adjust until the clearance between the reverse idler gear and reverse idler gear washer is within specification.

Clearance (a):

0.1 — 0.3 mm (0.004 — 0.012 in)



MT-02527

Reverse idler gear bushing		
Part No.	Length mm (in)	Groove for identification
32289AA080	27.75 (1.093)	None
32289AA090	27.90 (1.098)	1
32289AA100	28.05 (1.104)	2
32289AA110	28.20 (1.110)	3
32289AA120	28.35 (1.116)	4