

Read Diagnostic Trouble Code (DTC)

AUTO HEADLIGHT BEAM LEVELER SYSTEM (DIAGNOSTICS)

7. Read Diagnostic Trouble Code (DTC)

A: OPERATION

- For operation procedures, refer to the “PC application help for Subaru Select Monitor”.
- For details concerning DTC, refer to the List of Diagnostic Trouble Codes (DTC). <Ref. to AL(diag)-12, LIST, List of Diagnostic Trouble Code (DTC).>