

## 7. Tachometer

### A: SPECIFICATION

Since the meter - main assembly cannot be disassembled, do not remove or inspect the tachometer alone.  
(Do not remove the cover on the back surface.)