


# General Description

## LIGHTING SYSTEM

### 1. General Description

#### A: SPECIFICATION



LI-01495

No.	Description	Capacity and wattage	Type
(1)	Headlight	Low beam (halogen type)	12 V — 55 W
		Low beam (HID type)	12 V — 35 W
		High beam	12 V — 60 W
		Front turn signal light	12 V — 21 W
		Parking light (halogen type)	12 V — 5 W
		Parking light (HID type)	12 V — 1.8 W (LED)
		Side marker light	12 V — 5 W
(2)	Front fog light	12 V — 19 W	H16
(3)	Side turn signal light	12 V — 1.1 W (LED)	*1
(4)	Rear combination light	Tail & side marker/stop light	12 V — 5 / 21 W
		Back-up light	12 V — 16 W
		Turn signal light	12 V — 21 W
		Tail light	12 V — 5 / 21 W
(5)	High-mounted stop light (rear gate type)	12 V — 1.2 W (LED)	*1
(6)	High-mounted stop light (rear spoiler type)	12 V — 1.2 W (LED)	*1
(7)	License plate light	12 V — 5 W	W5W
(8)	Room light	12 V — 8 W	—
(9)	Spot map light	12 V — 8 W	—
(10)	Luggage room light	12 V — 5 W	W5W
(11)	Door step light	12 V — 5 W	W5W

\*1: Non-disassembly type


\*2: Only 5W illuminates.

## B: CAUTION

- Before disassembling or reassembling parts, always disconnect the battery ground cable from battery. When replacing the audio, control module and other parts provided with memory functions, record the memory contents before disconnecting the battery ground cable. Otherwise, the memory is cleared.
- Reassemble the parts in the reverse order of disassembly procedure unless otherwise indicated.
- Connect the connectors securely during reassembly.
- After reassembly, make sure that the each component operates normally.
- Yellow connectors and harnesses with yellow tapes around them are the connectors and harnesses for the airbag system. Using a tester above such circuits may cause malfunction of airbag system. Follow the cautions of "AIRBAG SYSTEM" in this case.<Ref. to AB-9, CAUTION, General Description.>
- Be careful not to damage the airbag system wiring harness when servicing electrical parts and switches.
- If the steering wheel and steering angle sensor (steering roll connector) are removed, adjust the steering angle sensor.<Ref. to VDC-23, ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDC-CM&H/U).>
- When removing and installing the valve, use a dry and clean cloth so that no grease or water adheres to the glass portion.

## C: PREPARATION TOOL

### 1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST1B022XU0	1B022XU0	SUBARU SELECT MONITOR III KIT	Used for setting of each function and troubleshooting for electrical system.  NOTE: For detailed operation procedures of SUBARU SELECT MONITOR III KIT, refer to "PC application help for Subaru Select Monitor".

### 2. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
Steering wheel puller	Used for removing the steering wheel.