

17. Brake Vacuum Sensor

A: NOTE

CAUTION:

- Do not remove the vacuum sensor (a). If removed, replace the vacuum booster assembly (b) with a new part.
- Do not rotate the vacuum sensor (a) when disconnecting the connector of vacuum sensor (a). Otherwise the grommet on the mounting location of the vacuum sensor (a) may be damaged.

