

Steering Column

POWER ASSISTED SYSTEM (POWER STEERING)

5. Steering Column


A: REMOVAL

- 1) Disconnect the ground cable from battery and wait for at least 60 seconds before starting work.
- 2) Remove the driver's airbag module.


CAUTION:

Before performing service on the airbag module, always refer to "CAUTION" of "General Description" in "AIRBAG SYSTEM" section.<Ref. to AB-9, CAUTION, General Description.>

- (1) Using a hexagon wrench etc. wrapped by protective tape, insert the snap pins and release the locks (3 locations).



- (2) Disconnect the horn harness and airbag connector and remove the airbag module assembly.<Ref. to AB-22, DRIVER'S AIRBAG MODULE, KNEE AIRBAG MODULE, CURTAIN AIRBAG MODULE AND PRETENSIONER, PROCEDURE, Airbag Connector.>



3) Remove the steering wheel.


CAUTION:

- Always use the steering wheel puller for removal to avoid deforming the steering wheel.
- If the steering wheel has been removed, make sure that the steering roll connector is not turned from the original position.

Preparation tool:


Steering wheel puller

- (1) Disconnect the connector and remove the nut.
- (2) Put alignment marks and remove the steering wheel.



4) Remove the cover assembly - instrument panel LWR driver.<Ref. to EI-59, REMOVAL, Instrument Panel Lower Cover.>

5) Remove the nuts to remove the knee airbag module and disconnect the harness connector.<Ref. to AB-22, DRIVER'S AIRBAG MODULE, KNEE AIRBAG MODULE, CURTAIN AIRBAG MODULE AND PRETENSIONER, PROCEDURE, Airbag Connector.>




Steering Column

POWER ASSISTED SYSTEM (POWER STEERING)

6) Remove the cover assembly - column.

- (1) Release the screws and claws.
- (2) Remove the cap - key cylinder (a). (Model with keyless access)
- (3) Remove the cover assembly - column UPR and the cover assembly - column LWR.




A Model without keyless access

B Model with keyless access

7) Remove the switch assembly - combination.

- (1) Disconnect the connector, and loosen the clamp to release the claws.
- (2) Pull out the switch assembly - combination from the column assembly - steering.



Steering Column

POWER ASSISTED SYSTEM (POWER STEERING)

8) Remove all connectors from the column assembly - steering.

9) Remove the universal joint assembly - steering.

CAUTION:

To prevent damage to the universal joint assembly - steering and improper steering effort, make sure to remove the universal joint assembly - steering.


(1) Place alignment marks on the universal joint assembly - steering.

NOTE:


Place alignment marks on the following positions.

- Between the column assembly - steering and the universal joint assembly - steering
- Between the steering gearbox assembly and the universal joint assembly - steering

(2) Remove the bolt, and remove the universal joint assembly - steering.



10) Remove the two nuts under the beam COMPL - steering securing the column assembly - steering.



11) Pull out the column assembly - steering from the hole on toe board.

CAUTION:

Do not loosen the tilt lever when the column assembly - steering is not secured to the vehicle.

12) Remove the ignition key lock from the column assembly - steering. <Ref. to SL-59, REPLACEMENT, Ignition Key Lock.>

Steering Column


POWER ASSISTED SYSTEM (POWER STEERING)

B: INSTALLATION

CAUTION:

If the steering wheel and steering angle sensor are removed, perform "VDC sensor midpoint setting mode" of the VDC. <Ref. to VDC-23, ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>

- 1) Install the grommet to the toe board.



- 2) Insert the end of the column assembly - steering into the toe board grommet.
- 3) Tighten the column assembly - steering installation nut located under the beam COMPL - steering with the tilt lever fixed.

Tightening torque:

20 N·m (2.04 kgf·m, 14.8 ft-lb)

- 4) Connect all connectors located under the beam COMPL - steering.
- 5) Connect the horn harness and airbag connector, and install the airbag module.
- 6) Install the knee airbag module.
- 7) Install the cover assembly - instrument panel LWR driver INN and OUT.
- 8) Install the universal joint assembly - steering. <Ref. to PS-14, INSTALLATION, Universal Joint.>

CAUTION:

- Always install the universal joint assembly - steering after installing the steering column to avoid damage to the universal joint assembly - steering.
- Be sure to follow the tightening order and tightening torque of the universal joint assembly - steering to avoid the steering effort from becoming heavy.

- 9) Align the center position of the steering roll connector. <Ref. to AB-107, ADJUSTMENT, Roll Connector.>
- 10) Install the steering wheel. <Ref. to PS-10, INSTALLATION, Steering Wheel.>


C: DISASSEMBLY

1) Remove the cover assembly - column.

(1) Release the screws and claws.

(2) Remove the cap - key cylinder (a). (Model with keyless access)

(3) Remove the cover assembly - column UPR and the cover assembly - column LWR.




A Models without keyless access

B Models with keyless access

2) Remove the switch assembly - combination.

(1) Disconnect the connector, and loosen the clamp to release the claws.

(2) Pull out the switch assembly - combination from the column assembly - steering.



Steering Column

POWER ASSISTED SYSTEM (POWER STEERING)

D: ASSEMBLY

Assemble each part in the reverse order of disassembly.

E: INSPECTION


1. UNIT INSPECTION

Measure the overall length of the column assembly - steering. If not within specification, replace it.

Standard: Overall length L

Tilt and telescopic column (measure while minimized):

$819.7^{+1.5}_{-1.5}$ mm (32.3 $^{+0.059}_{-0.059}$ in)



2. INSPECTION OF AIRBAG SYSTEM

Refer to "Airbag System" for airbag inspection procedure. <Ref. to AB-40, INSTALLATION, Driver's Airbag Module.>