

General Description

VEHICLE DYNAMICS CONTROL (VDC)


1. General Description

A: SPECIFICATION

Item				Specification or identification
ABS wheel speed sensor	ABS wheel speed sensor gap (for reference)	Front		0.77 — 1.43 mm (0.030 — 0.056 in)
		Rear		0.44 — 1.76 mm (0.017 — 0.069 in)
	Identifications of harness (symbol)	Front	RH	Z1
			LH	Z2
		Rear	RH	Z5
			LH	Z6
VDCCM&H/U identification	Models without EyeSight	MT model		B2
		CVT model	Model without X MODE	B1
			Model with X MODE	B3 or B9
	Models with EyeSight			B7

B: COMPONENT

1. ABS WHEEL SPEED SENSOR



VDC01144

- | | |
|----------------------------------|------------------------------|
| (1) Front ABS wheel speed sensor | (4) Housing ASSY - rear axle |
| (2) Housing ASSY - front axle | (5) Hub unit COMPL |
| (3) Rear ABS wheel speed sensor | (6) Magnetic encoder |


Tightening torque: N-m (kgf-m, ft-lb)

T1: 7.5 (0.76, 5.5)

T2: 33 (3.36, 24.3)

2. YAW RATE & G SENSOR

Models with EyeSight only



VDC01192

(1) Yaw rate & G sensor


(2) Bracket

Tightening torque: N·m (kgf-m, ft-lb)
T: 7.5 (0.76, 5.5)

General Description

VEHICLE DYNAMICS CONTROL (VDC)

3. STEERING ANGLE SENSOR




(1) Steering roll connector

(2) Steering angle sensor

4. VDC CONTROL MODULE & HYDRAULIC CONTROL UNIT (VDCCM&H/U)

- Models without EyeSight



VDC01037

- | | |
|---|-------------------------------|
| (1) Primary inlet | (7) Rear LH outlet |
| (2) Secondary inlet | (8) Damper - hydraulic unit |
| (3) VDC control module and hydraulic control unit (VDCCM&H/U) | (9) Spacer |
| (4) Rear RH outlet | (10) Nut |
| (5) Front LH outlet | (11) Bracket - hydraulic unit |
| (6) Front RH outlet | |

Tightening torque: N·m (kgf-m, ft-lb)

T1: 7.5 (0.76, 5.5)

T2: 15 (1.53, 11.1)

T3: 19 (1.94, 14.0)


T4: 33 (3.36, 24.3)

T5: <Ref. to VDC-20, REPLACEMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>

General Description

VEHICLE DYNAMICS CONTROL (VDC)

• Models with EyeSight



- | | |
|------------------------------|--|
| (1) Hose ASSY | (8) Front LH outlet |
| (2) Bracket - hydraulic unit | (9) Rear RH outlet |
| (3) Damper - hydraulic unit | (10) VDC control module and hydraulic control unit (VDCCM&H/U) |
| (4) Primary inlet | |
| (5) Secondary inlet | |
| (6) Rear LH outlet | |
| (7) Front RH outlet | |

Tightening torque: N·m (kgf-m, ft-lb)

T1: 7.5 (0.76, 5.5)

T2: 15 (1.53, 11.1)

T3: 18 (1.84, 13.3)

T4: 19 (1.94, 14.0)

T5: 27 (2.75, 19.9)

T6: 33 (3.36, 24.3)

C: CAUTION


- Wear appropriate work clothing, including a helmet, protective goggles and protective shoes when performing any work.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Before disconnecting connectors of sensors or units, be sure to disconnect the ground cable from battery.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- When removing, installing or replacing the VDCCM&H/U, VDCCM&H/U bracket, steering wheel or steering angle sensor, perform "VDC sensor midpoint setting mode" of the VDC. <Ref. to VDC-23, ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>

General Description

VEHICLE DYNAMICS CONTROL (VDC)

D: PREPARATION TOOL

1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST1B022XU0	1B022XU0	SUBARU SELECT MONITOR III KIT	Used for setting of each function and trouble-shooting for electrical system.

2. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
Pressure gauge	Used for measuring oil pressure.
Oscilloscope	Used for measuring the sensor.
Steering wheel puller	Used for removing the steering wheel.