

## General Description

### FUEL INJECTION (FUEL SYSTEMS)

---


## 1. General Description

### A: SPECIFICATION

Fuel tank	Capacity	60 L (15.9 US gal, 13.2 Imp gal)
	Location	Under rear seat
Fuel pump	Type	Impeller
	Shutoff discharge pressure	840 kPa (8.6 kg/cm <sup>2</sup> , 121.8 psi), or less
	Discharge rate	114 L (30.1 US gal, 25.1 Imp gal)/h or more [12 V at 343 kPa (3.5 kg/cm <sup>2</sup> , 49.7 psi)]
Fuel filter		In-tank type

### B: COMPONENT

#### 1. INTAKE MANIFOLD 1



FU-08171

(1) Intake manifold protector	(7) Gasket
(2) Cap	(8) Tumble generator valve actuator
(3) Manifold absolute pressure sensor	(9) Tumble generator valve RH
(4) O-ring	(10) Gasket
(5) Intake manifold	(11) Purge control solenoid valve
(6) Tumble generator valve LH	(12) Cushion

#### Tightening torque: N·m (kgf·m, ft-lb)

T1: 3.4 (0.3, 2.5)

T2: 6 (0.6, 4.4)

T3: 6.4 (0.7, 4.7)


T4: 8.3 (0.8, 6.1)

T5: 25 (2.5, 18.4)

# General Description

## FUEL INJECTION (FUEL SYSTEMS)

### 2. INTAKE MANIFOLD 2



FU-08524

(1) Fuel delivery pipe	(6) Seal ring
(2) Vacuum hose	(7) Rubber
(3) Fuel pipe A	(8) O-ring
(4) Fuel pipe B	(9) Cylinder head plate
(5) Fuel injector	(10) Fuel injector holder


**Tightening torque: N·m (kgf·m, ft·lb)**

**T: 6.4 (0.7, 4.7)**

# General Description

## FUEL INJECTION (FUEL SYSTEMS)

### 3. THROTTLE BODY



FU-06448

(1) Gasket

(2) Throttle body


**Tightening torque: N·m (kgf·m, ft·lb)**

**T: 8 (0.8, 5.9)**

# General Description

## FUEL INJECTION (FUEL SYSTEMS)

### 4. CRANKSHAFT POSITION, CAMSHAFT POSITION AND KNOCK SENSORS



- (1) Oil control solenoid
- (2) Camshaft position sensor
- (3) Crankshaft position sensor
- (4) Knock sensor


- (5) O-ring
- (6) Back-up ring
- (7) O-ring

**Tightening torque:N·m (kgf·m, ft·lb)**  
**T1: 6.4 (0.7, 4.7)**  
**T2: 24 (2.4, 17.7)**

# General Description

## FUEL INJECTION (FUEL SYSTEMS)

### 5. FUEL TANK



FU-07738

## General Description

### FUEL INJECTION (FUEL SYSTEMS)

---


(1) Fuel tank	(15) Stopper LH	(29) Cushion
(2) Fuel tank band	(16) Heat shield cover	(30) Cushion
(3) Delivery tube	(17) Fuel tank protector RH	(31) Cushion
(4) Jet pump tube	(18) Fuel tank protector LH	
(5) Fuel pump ASSY	(19) Self-locking nut	<b>Tightening torque: N·m (kgf·m, ft·lb)</b>
(6) Fuel pump upper plate	(20) Rubber cap	<b>T1: 2 (0.2, 1.5)</b>
(7) Fuel pump gasket	(21) Fuel filler hose	<b>T2: 2.5 (0.3, 1.8)</b>
(8) Fuel level sensor	(22) Clamp	<b>T3: 9 (0.9, 6.6)</b>
(9) Fuel sub level sensor	(23) Clamp	<b>T4: 18 (1.8, 13.3)</b>
(10) Fuel sub level sensor upper plate	(24) Air vent hose	<b>T5: &lt;Ref. to FU(H4DO)-115, INSTALLATION, Fuel Tank.&gt;</b>
(11) Fuel sub level sensor gasket	(25) Clip	<b>T6: &lt;Ref. to FU(H4DO)-134, INSTALLATION, Fuel Pump.&gt;</b>
(12) Fuel sub level sensor filter	(26) Tube clamp	<b>T7: &lt;Ref. to FU(H4DO)-142, INSTALLATION, Fuel Sub Level Sensor.&gt;</b>
(13) Fuel sub level sensor protector	(27) Fuel pump upper plate cushion	
(14) Stopper RH	(28) Fuel sub level sensor upper plate cushion	

---

# General Description

## FUEL INJECTION (FUEL SYSTEMS)

### 6. FUEL LINE



FU-07857

## General Description

### FUEL INJECTION (FUEL SYSTEMS)

---

(1) Fuel delivery tube	(12) Pipe clamp	(23) Leak check valve bracket A
(2) Evaporation hose	(13) Fuel pipe rear grommet	(24) Leak check valve ASSY
(3) Tube clamp	(14) Canister	(25) Drain tube B
(4) Clip	(15) Drain tube A	(26) Drain tube C
(5) Hose clamp	(16) Clip	(27) Leak check valve bracket B
(6) Hose clamp bracket	(17) Vent tube	(28) Tube clamp
(7) Fuel pipe ASSY	(18) Vent hose	
(8) Fuel pipe front grommet	(19) Purge pipe	
(9) Pipe clamp	(20) Pipe clamp	
(10) Pipe clamp	(21) Canister bracket	
(11) Pipe clamp	(22) Clip	

---

***Tightening torque: N·m (kgf·m, ft-lb)***

***T1: 7.5 (0.8, 5.5)***


***T2: 18 (1.8, 13.3)***

---

# General Description

## FUEL INJECTION (FUEL SYSTEMS)

### 7. FUEL FILLER PIPE



- (1) Fuel filler pipe ASSY
- (2) Neck holder A
- (3) Neck holder B
- (4) Fuel filler pipe protector
- (5) Fuel filler cap

- (6) Clip
- (7) Drain hose
- (8) Drain pipe
- (9) Upper bracket
- (10) Lower bracket


- (11) Drain lower bracket
- (12) Drain hose clamp

**Tightening torque: N·m (kgf·m, ft·lb)**  
**T: 7.5 (0.8, 5.5)**

# General Description

## FUEL INJECTION (FUEL SYSTEMS)

### 8. FUEL PUMP



FU-08466

(1) Fuel filter ASSY	(6) Connector cable	(11) Spring
(2) O-ring	(7) Fuel pump holder	(12) Fuel chamber ASSY
(3) O-ring	(8) O-ring	(13) Clip
(4) Back-up ring	(9) Spacer	(14) Fuel level sensor
(5) Pressure regulator	(10) Fuel pump	(15) Cushion

\* When removing the cushion from the fuel chamber assembly, replace it with a new part.

# General Description



## FUEL INJECTION (FUEL SYSTEMS)

### C: CAUTION

- Prior to starting work, pay special attention to the following:
  1. Always wear work clothes, a work cap, and protective shoes. Additionally, wear a helmet, protective goggles, etc. if necessary.
  2. Protect the vehicle using a seat cover, fender cover, etc.
  3. Prepare the service tools, clean cloth, containers to catch grease and oil, etc.
- Place "NO OPEN FLAMES" signs near the working area.
- Prepare a container and cloth to prevent scattering of fuels when performing work where fuels can be spilled. If the oil spills, wipe it off immediately to prevent from penetrating into floor or flowing out for environmental protection.
- Vehicle components are extremely hot immediately after driving. Be wary of receiving burns from heated parts.
- When performing a repair, identify the cause of trouble and avoid unnecessary removal, disassembly and replacement.
- Before disconnecting connectors of sensors or units, be sure to disconnect the ground cable from battery.
- Always use the jack-up point when the shop jacks or rigid racks are used to support the vehicle.
- Remove contamination including dirt and corrosion before removal, installation, disassembly or assembly.
- Keep the removed parts in order and protect them from dust and dirt.
- All removed parts, if to be reused, should be reinstalled in the original positions with attention to the correct directions, etc.
- Bolts, nuts and washers should be replaced with new parts as required.
- Follow all government and local regulations concerning disposal of refuse when disposing fuel.

### D: PREPARATION TOOL

#### 1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST18471AA000	18471AA000	FUEL PIPE ADAPTER	Used for draining fuel.
 ST1B022XU0	1B022XU0	SUBARU SELECT MONITOR III KIT	Used for draining fuel and each inspection.

#### 2. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
Oscilloscope	Used for inspecting the waveform of each sensor.
Mighty Vac	Used for inspecting the manifold absolute pressure sensor.