

42. Variator Chain

A: REMOVAL

For removal of variator chain, refer to "Primary Pulley and Secondary Pulley". <Ref. to CVT(TR690)-231, REMOVAL, Primary Pulley and Secondary Pulley.>

B: INSTALLATION

For installation of variator chain, refer to "Primary Pulley and Secondary Pulley". <Ref. to CVT(TR690)-235, INSTALLATION, Primary Pulley and Secondary Pulley.>

C: INSPECTION

Check the variator chain for damage and wear.