
	Page
T DIAGNOSTICS <small>AIRBAG</small>	2
1. Supplemental Restraint System "Airbag"	2
2. Pre-inspection	2
3. Electrical Components Location	4
4. Schematic	6
5. Control Module I/O Signal	7
6. Diagnostics Chart for On-board Diagnosis System.....	10
7. Diagnostics Chart for ABS Warning Light Circuit and Diagnosis Circuit Failure.....	16
8. Diagnostics Chart with Trouble Code by ABS Warning Light	26
9. Select Monitor Function Mode.....	108
10. Diagnostics Chart with Select Monitor.....	120
11. General Diagnostics Table	263

1. Supplemental Restraint System "Airbag"

Airbag system wiring harness is routed near the ABS control module, ABS sensor and hydraulic control unit.

CAUTION:

- All Airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.
- Be careful not to damage Airbag system wiring harness when servicing the ABS control module, ABS sensor and hydraulic control unit.

2. Pre-inspection

Before performing diagnostics, check the following items which might affect ABS problems:

A: MECHANICAL INSPECTION

1. POWER SUPPLY

- 1) Measure battery voltage and specific gravity of electrolyte.

Standard voltage: 12 V, or more

Specific gravity: Above 1.260

- 2) Check the condition of the main and other fuses, and harnesses and connectors. Also check for proper grounding.

2. BRAKE FLUID

- 1) Check brake fluid level.
- 2) Check brake fluid leakage.

3. BRAKE DRAG

Check brake drag. <Ref. to 4-4 [K100].>

4. BRAKE PAD AND ROTOR


Check brake pad and rotor. <Ref. to 4-4 [K100].>

5. TIRE SPECIFICATIONS, TIRE WEAR AND AIR PRESSURE

Check tire specifications, tire wear and air pressure. <Ref. to 4-2 [S1A0], [S1B0].>

B: ELECTRICAL INSPECTION

1. WARNING LIGHT ILLUMINATION PATTERN




B4M0781A

- 1) When the ABS warning light does not illuminate in accordance with this illumination pattern, there must be an electrical malfunction.
- 2) When the ABS warning light remains constantly OFF, repair the ABS warning light circuit or diagnosis circuit. <Ref. to 4-4 [T7A0].>

NOTE:


Even though the ABS warning light does not go out 1.5 seconds after it illuminates, the ABS system operates normally when the warning light goes out while driving at approximately 12 km/h (7 MPH). However, the Anti-lock brakes do not work while the ABS warning light is illuminated.

3. Electrical Components Location




H4M1098A


① Hydraulic control unit (H/U)	⑧ Tone wheel
② Proportioning valve	⑨ ABS sensor
③ ABS control module (ABSCM)	⑩ Wheel cylinder
④ ABS diagnosis connector	⑪ G sensor (only AWD vehicle)
⑤ ABS warning light	⑫ Brake switch
⑥ Data link connector (for Subaru select monitor)	⑬ Master cylinder
⑦ Transmission control module (only AT vehicle)	⑭ Relay box




B4M0783A




H4M1099A




H4M1100A



H4M1152A




B4M0646B



B4M0645B

4. Schematic




B4M0787A


① Hydraulic control unit (H/U)	⑯ Valve relay
② Front left inlet solenoid valve	⑯ Relay box
③ Front left outlet solenoid valve	⑯ Data link connector
④ Front right inlet solenoid valve	⑯ ABS diagnosis connector
⑤ Front right outlet solenoid valve	⑯ Stop light switch
⑥ Rear left inlet solenoid valve	⑯ Stop light
⑦ Rear left outlet solenoid valve	⑯ G sensor (only AWD model)
⑧ Rear right inlet solenoid valve	⑯ Front left ABS sensor
⑨ Rear right outlet solenoid valve	⑯ Front right ABS sensor
⑩ Motor	⑯ Rear left ABS sensor
⑪ Transmission control module (only AT model)	⑯ Rear right ABS sensor
⑫ ABS warning light	⑯ ABS control module (ABSCM)
⑬ Motor relay	

5. Control Module I/O Signal


1. I/O SIGNAL VOLTAGE




1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
✗ 29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	✗



1	2	3	4	5	6	7	8	9	10
✗ 29	30	31	32	33	34	35	36	37	38



10	11	12	13	14	15	16	17	18	19
38	39	40	41	42	43	44	45	46	47



19	20	21	22	23	24	25	26	27	28
46	47	48	49	50	51	52	53	54	55


B4M1024A

NOTE:

The terminal numbers in the ABS control module connector are as shown in the figure.


Contents		Terminal No.	Input/Output signal			
			Measured value and measuring conditions			
ABS sensor (Wheel speed sensor)	Front left wheel	49—19	0.12 — 1 V (When it is 20 Hz.)			
	Front right wheel	14—15				
	Rear left wheel	16—17				
	Rear right wheel	18—46				
Hydraulic control unit	Solenoid valve	Front left outlet	51—1	10 — 13 V when the valve is OFF and less than 1.5 V when the valve is ON.		
		Front right outlet	3—1			
		Rear left outlet	4—1			
		Rear right outlet	50—1			
		Front left inlet	24—1			
		Front right inlet	30—1			
		Rear left inlet	31—1			
		Rear right inlet	23—1			
Relay box	Valve relay power supply		27—1	10 — 13 V when ignition switch is ON.		
	Valve relay coil		47—1	Less than 1.5 V when ignition switch is ON.		
	Motor relay coil		22—1	More than 10 V when the ABS control does not operate still and less than 1.5 V when ABS operates.		
	Motor monitoring		10—1	Less than 1.5 V when the ABS control does not operate still and more than 10 V when ABS operates.		
G sensor (AWD model only)	power supply		8—45	4.75 — 5.25 V		
	ground		45	—		
	output		7—45	2.3±0.2 V when vehicle is in horizontal position.		
Stop light switch			36—1	Less than 1.5 V when the stop light is OFF and more than 4.5 V when the stop light is ON.		
ABS warning light			54—1	Less than 1.5 V during 1.5 seconds when ignition switch is ON, and 10 — 14 V after 1.5 seconds.		
AT ABS signal (AT model only)			12—1	Less than 1.5 V when the ABS control does not operate still and more than 5.5 V when ABS operates.		
ABS operation signal monitor			39—1	Less than 1.5 V when the ABS control does not operate still and more than 5.5 V when ABS operates.		
Select monitor	Data is received.		11—1	Less than 1.5 V when no data is received.		
	Data is sent.		38—1	4.75 — 5.25 V when no data is sent.		
ABS diagnosis connector	Terminal No. 1		5—1	10 — 14 V when ignition switch is ON.		
	Terminal No. 2		13—1	10 — 14 V when ignition switch is ON.		
Power supply			28—1	10 — 14 V when ignition switch is ON.		
Grounding line			1	—		
Grounding line			55	—		

2. I/O SIGNAL DIAGRAM



6. Diagnostics Chart for On-board Diagnosis System

A: BASIC DIAGNOSTICS PROCEDURE



B4M1051A

NOTE:

- To check harness for broken wires or short circuits, shake it while holding it or the connector.
- When ABS warning light illuminates, read and record trouble code indicated by ABS warning light.

B: CHECK LIST FOR INTERVIEW

Check the following items about the vehicle's state.

1. THE STATE OF THE ABS WARNING LIGHT			
ABS warning light comes on.	<input type="checkbox"/> Always <input type="checkbox"/> Sometimes <input type="checkbox"/> Only once <input type="checkbox"/> Does not come on <ul style="list-style-type: none"> ● When /how long does it come on?: 		
Ignition key position	<input type="checkbox"/> LOCK <input type="checkbox"/> ACC <input type="checkbox"/> ON (before starting engine) <input type="checkbox"/> START <input type="checkbox"/> On after starting (Engine is running) <input type="checkbox"/> On after starting (Engine is stop)		
Timing	<input type="checkbox"/> Immediately after ignition is ON. <input type="checkbox"/> Immediately after ignition starts.		
	<input type="checkbox"/> When advancing	km/h to	km/h
		MPH to	MPH
	<input type="checkbox"/> While traveling at a constant speed	km/h	MPH
		km/h to	km/h
	<input type="checkbox"/> When decelerating	MPH to	MPH
		Steering angle :	deg
	<input type="checkbox"/> When turning to right	Steering time :	sec
		Steering angle :	deg
	<input type="checkbox"/> When turning to left	Steering time :	sec
<input type="checkbox"/> When moving other electrical parts			
<ul style="list-style-type: none"> ● Parts name : ● Operating condition : 			
2. SYMPTOMS			
ABS operating condition	<input type="checkbox"/> Performs no work. <input type="checkbox"/> Operates only when abruptly applying brakes.		
	<input type="checkbox"/> Operates only when abruptly applying brakes.	Vehicle speed :	km/h
			MPH
	<ul style="list-style-type: none"> ● How to step on brake pedal : 		
	a) Operating time :	sec	
	b) Operating noise : <input type="checkbox"/> Produce / <input type="checkbox"/> Does not produce		
	<ul style="list-style-type: none"> ● What kind of noise? 		<input type="checkbox"/> Knock <input type="checkbox"/> Gong gong <input type="checkbox"/> Bong <input type="checkbox"/> Buzz <input type="checkbox"/> Gong gong buzz <input type="checkbox"/> Others :
	c) Reaction force of brake pedal		
			<input type="checkbox"/> Stick <input type="checkbox"/> Press down once with a clunk <input type="checkbox"/> Press and released <input type="checkbox"/> Others :

Behavior of vehicle	a) Directional stability cannot be obtained or steering arm refuses to work when applying brakes : <input type="checkbox"/> Yes / <input type="checkbox"/> No	
	● When :	<input type="checkbox"/> Vehicle turns to right <input type="checkbox"/> Vehicle turns to left <input type="checkbox"/> Spins <input type="checkbox"/> Others :
	b) Directional stability cannot be obtained or steering arm refuses to work when accelerating : <input type="checkbox"/> Yes / <input type="checkbox"/> No	
	● When :	<input type="checkbox"/> Vehicle turns to right <input type="checkbox"/> Vehicle turns to left <input type="checkbox"/> Spins <input type="checkbox"/> Others :
	c) Brakes are out of order : <input type="checkbox"/> Yes / <input type="checkbox"/> No	
	● What :	<input type="checkbox"/> Braking distance is long <input type="checkbox"/> Brakes lock or drag <input type="checkbox"/> Pedal stroke is long <input type="checkbox"/> Pedal sticks <input type="checkbox"/> Others :
	d) Poor acceleration : <input type="checkbox"/> Yes / <input type="checkbox"/> No	
	● What :	<input type="checkbox"/> Fails to accelerate <input type="checkbox"/> Engine stalls <input type="checkbox"/> Others :
	e) Occurrence of vibration : <input type="checkbox"/> Yes / <input type="checkbox"/> No	
● Where		
● What kind :		
f) Occurrence of abnormal noise : <input type="checkbox"/> Yes / <input type="checkbox"/> No		
● Where		
● What kind :		
g) Occurrence of other phenomena : <input type="checkbox"/> Yes / <input type="checkbox"/> No		
● What kind :		

3. CONDITIONS UNDER WHICH TROUBLE OCCURS


Environment	a) Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Various/Others :
	b) Ambient temperature	F(°C)
	c) Road	<input type="checkbox"/> Urban area <input type="checkbox"/> Suburbs <input type="checkbox"/> Highway <input type="checkbox"/> General road <input type="checkbox"/> Ascending slope <input type="checkbox"/> Descending slope <input type="checkbox"/> Paved road <input type="checkbox"/> Gravel road <input type="checkbox"/> Muddy road <input type="checkbox"/> Sandy place <input type="checkbox"/> Others :
	d) Road surface	<input type="checkbox"/> Dry <input type="checkbox"/> Wet <input type="checkbox"/> New-fallen snow <input type="checkbox"/> Compressed snow <input type="checkbox"/> Frozen slope <input type="checkbox"/> Others :

Condition	a) Brakes	Deceleration :	g
		<input type="checkbox"/> Continuous / <input type="checkbox"/> Intermittent	
	b) Accelerator	Acceleration :	g
		<input type="checkbox"/> Continuous / <input type="checkbox"/> Intermittent	
	c) Vehicle speed	km/h	MPH
		<input type="checkbox"/> Advancing <input type="checkbox"/> Accelerating <input type="checkbox"/> Reducing speed <input type="checkbox"/> Low speed <input type="checkbox"/> Turning <input type="checkbox"/> Others :	
	d) Tire inflation pressure	Front RH tire :	kPa
		Front LH tire :	kPa
		Rear RH tire :	kPa
		Rear LH tire :	kPa
	e) Degree of wear	Front RH tire :	
		Front LH tire :	
		Rear RH tire :	
		Rear LH tire :	
	f) Genuine parts are used. : <input type="checkbox"/> Yes / <input type="checkbox"/> No		
	g) Chain is passed around tires. : <input type="checkbox"/> Yes / <input type="checkbox"/> No		
	h) T tire is used. : <input type="checkbox"/> Yes / <input type="checkbox"/> No		
	i) Condition of suspension alignment :		
	j) Loading state :		
	k) Repair parts are used. : <input type="checkbox"/> Yes / <input type="checkbox"/> No		
	● What :		
	l) Others :		

C: INSPECTION MODE

Reproduce the condition under which the problem has occurred as much as possible.

Drive the vehicle at a speed more than 40 km/h (25 MPH) for at least one minute.



D: TROUBLE CODES

When on-board diagnosis of the ABS control module detects a problem, the information (up to a maximum of three) will be stored in the EEPROM as a trouble code. When there are more than three, the most recent three will be stored. (Stored codes will stay in memory until they are cleared.)

1. CALLING UP A TROUBLE CODE


- 1) Take out ABS diagnosis connector from side of driver's seat heater unit.
- 2) Turn ignition switch OFF.
- 3) Connect ABS diagnosis connector terminal 2 to diagnosis terminal.
- 4) Turn ignition switch ON.
- 5) ABS warning light is set in the diagnostic mode and blinks to identify trouble code.
- 6) After the start code (11) is shown, the trouble codes will be shown in order of the last information first.

These NOTE


NOTE: When there are no trouble codes in memory, only the start code (11) is shown.

Example of code indication


Trouble code: 21



Trouble code: 22, 31




B4M0232A



2. CLEARING MEMORY

- 1) After calling up a trouble code, disconnect ABS diagnosis connector terminal 2 from diagnosis terminal.
- 2) Repeat 3 times within approx. 12 seconds; connecting and disconnecting terminal 2 and diagnosis terminal for at least 0.05 seconds each time.



B4M0233C

NOTE:

After diagnostics is completed, make sure to clear memory. Make sure only start code (11) is shown after memory is cleared.

7. Diagnostics Chart for ABS Warning Light Circuit and Diagnosis Circuit Failure

A: ABS WARNING LIGHT DOES NOT COME ON.


DIAGNOSIS:

- ABS warning light circuit is open or shorted.

TROUBLE SYMPTOM:

- When ignition switch is turned ON (engine OFF), ABS warning light does not come on.

WIRING DIAGRAM:



7A1	CHECK IF OTHER WARNING LIGHTS TURN ON.
------------	---

Turn ignition switch to ON (engine OFF).

CHECK : *Do other warning lights turn on?*

YES : Go to step **7A2**.

NO : Repair combination meter.


7A2	CHECK ABS WARNING LIGHT BULB.
------------	--------------------------------------

- 1) Turn ignition switch to OFF.
- 2) Remove combination meter.
- 3) Remove ABS warning light bulb from combination meter.

CHECK : *Is ABS warning light bulb OK?*

YES : Go to step **7A3**.

NO : Replace ABS warning light bulb.



7A3	CHECK WIRING HARNESS.
------------	------------------------------

- 1) Disconnect connector from ABSCM.
- 2) Disconnect connector (F50) from relay box.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between connector (F49) and chassis ground.


Connector & terminal

(F49) No. 54 (+) — Chassis ground (-):

CHECK : *Is the voltage more than 10 V?*

YES : Go to step **7A4**.

NO : Repair broken wire in harness or connector.



7A4	CHECK WIRING HARNESS.
------------	------------------------------

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector (F49) and chassis ground.


Connector & terminal

(F49) No. 54 (+) — Chassis ground (-):

CHECK : *Is voltage less than 3 V?*

YES : Go to step **7A5**.


NO : Repair battery short of harness.



7A5

CHECK BATTERY SHORT OF RELAY BOX.

- 1) Disconnect connector from relay box.
- 2) Measure voltage between relay box and chassis ground.

Connector & terminal**(ABS4) No. 2 (+) — Chassis ground (-):****CHECK** : *Is the voltage less than 1 V?***YES** : Go to step **7A6**.**NO** : Replace relay box.

7A6

CHECK BATTERY SHORT OF RELAY BOX.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between relay box and chassis ground.

Connector & terminal**(ABS4) No. 2 (+) — Chassis ground (-):****CHECK** : *Is the voltage less than 1 V?***YES** : Go to step **7A7**.**NO** : Replace relay box.

7A7

CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connectors between combination meter and ABSCM? <Ref. to FOREWORD [T3C1].>***YES** : Repair connector.**NO** : Replace ABSCM.

B: ABS WARNING LIGHT DOES NOT GO OFF.


DIAGNOSIS:

- ABS warning light circuit is open or shorted.

TROUBLE SYMPTOM:

- When starting the engine and while ABS warning light is kept ON.

WIRING DIAGRAM:



7B1


CHECK INSTALLATION OF ABSCM CONNECTOR.

Turn ignition switch to OFF.

CHECK : *Is ABSCM connector inserted into ABSCM until the clamp locks onto it?*

YES : Go to step 7B2.

NO : Insert ABSCM connector into ABSCM until the clamp locks onto it.



7B2

CHECK GENERATOR.

1) Start the engine.

2) Idle the engine.

3) Measure voltage between generator and chassis ground.

Terminal**Generator B terminal (+) — Chassis ground (-):**

CHECK : *Is the voltage between 10 and 15 V?*

YES : Go to step 7B3.

NO : Repair generator.

7B3


CHECK BATTERY TERMINAL.

Turn ignition switch to OFF.

CHECK : *Is there poor contact at battery terminal?*

YES : Repair battery terminal.

NO : Go to step 7B4.



7B4

CHECK POWER SUPPLY OF ABSCM.

1) Disconnect connector from ABSCM.

2) Start engine.

3) Idle the engine.


4) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 28 (+) — Chassis ground (-):**

CHECK : *Is the voltage between 10 and 15 V?*

YES : Go to step 7B5.

NO : Repair ABSCM power supply circuit.



7B5 CHECK GROUND CIRCUIT OF ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 1 — Chassis ground:

(F49) No. 55 — Chassis ground:

CHECK : Is the resistance less than 0.5Ω ?

YES : Go to step 7B6.

NO : Repair ABSCM ground harness.

7B6 CHECK WIRING HARNESS.

- 1) Disconnect connector (F50) from relay box.
- 2) Turn ignition switch to ON.

CHECK : Does the ABS warning light remain off?

YES : Go to step 7B7.

NO : Repair front wiring harness.


7B7 CHECK RELAY BOX.

- 1) Turn ignition switch to OFF.
- 2) Connect connector (F50) to relay box.
- 3) Remove valve relay from relay box.
- 4) Disconnect connector (ABS1) from hydraulic control unit.
- 5) Turn ignition switch to ON.

CHECK : Does the ABS warning light remain off?

YES : Go to step 7B8.

NO : Repair relay box and check fuse.


7B8 **CHECK CONTACT POINT OF VALVE RELAY.**


- 1) Connect battery to valve relay terminals No. 85 and No. 86.
- 2) Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **7B9**.

NO : Replace valve relay.


7B9 **CHECK CONTACT POINT OF VALVE RELAY.**


Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87a:

Is the resistance more than 1 MΩ?

YES : Go to step **7B10**.

NO : Replace valve relay.


7B10 **CHECK CONTACT POINT OF VALVE RELAY.**


- 1) Disconnect battery from valve relay terminals.
- 2) Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **7B11**.

NO : Replace valve relay.


7B11 **CHECK CONTACT POINT OF VALVE RELAY.**

Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87a:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **7B12**.

NO : Replace valve relay.


7B12 CHECK HYDRAULIC CONTROL UNIT.

- 1) Turn ignition switch to OFF.
- 2) Connect connector (ABS1) to hydraulic control unit.
- 3) Turn ignition switch to ON.

CHECK : *Is the ABS warning light off?*

YES : Go to step **7B13**.

NO : Replace hydraulic control unit and check fuse No. 19.

**7B13 CHECK DIAGNOSIS TERMINAL.**

Measure resistance between diagnosis terminals (B81) and chassis ground.

Terminals


Diagnosis terminal (A) — Chassis ground:

Diagnosis terminal (B) — Chassis ground:

CHECK : *Is the resistance less than 1 Ω?*

YES : Go to step **7B14**.

NO : Repair diagnosis terminal harness.

**7B14 CHECK DIAGNOSIS LINE.**

- 1) Turn ignition switch to OFF.
- 2) Connect diagnosis terminal to ABS diagnosis connector (B115) No. 2.
- 3) Disconnect connector from ABSCM.
- 4) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 13 — Chassis ground:

CHECK : *Is the resistance less than 1 Ω?*

YES : Go to step **7B15**.

NO : Repair harness connector between ABSCM and ABS diagnosis connector.

7B15 CHECK POOR CONTACT IN ABSCM CONNECTOR.

CHECK : *Is there poor contact in ABSCM connector?
<Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Replace ABSCM.

C: TROUBLE CODE DOES NOT APPEAR.


DIAGNOSIS:


- Diagnosis circuit is open

TROUBLE SYMPTOM

- The ABS warning light turns on or off normally but the start code cannot be read out in the diagnostic mode.

WIRING DIAGRAM:





7C1 CHECK DIAGNOSIS TERMINAL.

Measure resistance between diagnosis terminals (B81) and chassis ground.

Terminals


Diagnosis terminal (A) — Chassis ground:

Diagnosis terminal (B) — Chassis ground:

CHECK : Is the resistance less than $0.5\ \Omega$?

YES : Go to step 7C2.

NO : Repair diagnosis terminal harness.



7C2 CHECK DIAGNOSIS LINE.

- 1) Turn ignition switch to OFF.
- 2) Connect diagnosis terminal to ABS diagnosis connector (B115) No. 2.
- 3) Disconnect connector from ABSCM.
- 4) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 13 — Chassis ground:

CHECK : Is the resistance less than $0.5\ \Omega$?

YES : Go to step 7C3.

NO : Repair harness connector between ABSCM and ABS diagnosis connector.

7C3 CHECK POOR CONTACT IN ABSCM CONNECTOR.

CHECK : Is there poor contact in ABSCM connector?
<Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Replace ABSCM.

8. Diagnostics Chart with Trouble Code by ABS Warning Light

A: LIST OF TROUBLE CODE

Trouble code	Contents of diagnosis	Ref. to 4-4
11	Start code ● Trouble code is shown after start code. ● Only start code is shown in normal condition.	—
21	Abnormal ABS sensor (Open circuit or input voltage too high)	Front right ABS sensor
23		Front left ABS sensor
25		Rear right ABS sensor
27		Rear left ABS sensor
22	Abnormal ABS sensor (Abnormal ABS sensor signal)	Front right ABS sensor
24		Front left ABS sensor
26		Rear right ABS sensor
28		Rear left ABS sensor
29		Any one of four
31	Abnormal solenoid valve circuit(s) in hydraulic unit	Front right inlet valve
32		Front right outlet valve
33		Front left inlet valve
34		Front left outlet valve
35		Rear right inlet valve
36		Rear right outlet valve
37		Rear left inlet valve
38		Rear left outlet valve
41	Abnormal ABS control module	[T8S0]
42	Source voltage is low.	[T8T0]
44	A combination of AT control abnormal	[T8U0]
46	Abnormal G sensor power supply voltage	[T8V0]
51	Abnormal valve relay	[T8W0]
52	Abnormal motor and/or motor relay	[T8X0]
54	Abnormal stop light switch	[T8Y0]
56	Abnormal G sensor output voltage	[T8Z0]

B: TROUBLE CODE 21 (FRONT RH)

C: TROUBLE CODE 23 (FRONT LH)

D: TROUBLE CODE 25 (REAR RH)

E: TROUBLE CODE 27 (REAR LH)

— ABNORMAL ABS SENSOR (OPEN CIRCUIT OR INPUT VOLTAGE TOO HIGH) —


DIAGNOSIS:


- Faulty ABS sensor (Broken wire, input voltage too high)
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:





B4M0806

8E1

CHECK ABS SENSOR.


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABS sensor.
- 3) Measure resistance of ABS sensor connector terminals.

Terminal**Front RH No. 1 — No. 2:****Front LH No. 1 — No. 2:****Rear RH No. 1 — No. 2:****Rear LH No. 1 — No. 2:**

CHECK : *Is the resistance between 0.8 and 1.2 kΩ?*

YES : Go to step 8E2.

NO : Replace ABS sensor.



B4M0807

8E2

**CHECK BATTERY SHORT OF ABS SEN-
SOR.**


- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between ABS sensor and chassis ground.

Terminal**Front RH No. 1 (+) — Chassis ground (-):****Front LH No. 1 (+) — Chassis ground (-):****Rear RH No. 1 (+) — Chassis ground (-):****Rear LH No. 1 (+) — Chassis ground (-):**

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 8E3.


NO : Replace ABS sensor.



8E3

CHECK BATTERY SHORT OF ABS SENSOR.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABS sensor and chassis ground.


Terminal**Front RH No. 1 (+) — Chassis ground (-):****Front LH No. 1 (+) — Chassis ground (-):****Rear RH No. 1 (+) — Chassis ground (-):****Rear LH No. 1 (+) — Chassis ground (-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 8E4.****NO : Replace ABS sensor.**

8E4

CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND ABS SENSOR.

- 1) Turn ignition switch to OFF.
- 2) Connect connector to ABS sensor.
- 3) Measure resistance between ABSCM connector terminals.

Connector & terminal**Trouble code 21 / (F49) No. 14 — No. 15:****Trouble code 23 / (F49) No. 49 — No. 19:****Trouble code 25 / (F49) No. 18 — No. 46:****Trouble code 27 / (F49) No. 16 — No. 17:****CHECK : Is the resistance between 0.8 and 1.2 kΩ?****YES : Go to step 8E5.****NO : Repair harness/connector between ABSCM and ABS sensor.**



8E5 CHECK BATTERY SHORT OF HARNESS.

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 21 / (F49) No. 14 (+) — Chassis ground (-):

Trouble code 23 / (F49) No. 49 (+) — Chassis ground (-):


Trouble code 25 / (F49) No. 18 (+) — Chassis ground (-):

Trouble code 27 / (F49) No. 16 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8E6.

NO : Repair harness between ABSCM and ABS sensor.



8E6 CHECK BATTERY SHORT OF HARNESS.

1) Turn ignition switch to ON.

2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 21 / (F49) No. 14 (+) — Chassis ground (-):

Trouble code 23 / (F49) No. 49 (+) — Chassis ground (-):

Trouble code 25 / (F49) No. 18 (+) — Chassis ground (-):

Trouble code 27 / (F49) No. 16 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8E7.

NO : Repair harness between ABSCM and ABS sensor.

8E7 CHECK INSTALLATION OF ABS SEN- SOR.

Tightening torque:

$32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft-lb}$)

CHECK : Are the ABS sensor installation bolts tightened securely?

YES : Go to step 8E8.

NO : Tighten ABS sensor installation bolts securely.


8E8

CHECK INSTALLATION OF TONE WHEEL.**Tightening torque:** **$13\pm3\text{ N}\cdot\text{m}$ ($1.3\pm0.3\text{ kg}\cdot\text{m}$, $9\pm2.2\text{ ft}\cdot\text{lb}$)**


CHECK : Are the tone wheel installation bolts tightened securely?

YES : Go to step 8E9.

NO : Tighten tone wheel installation bolts securely.



G4M0700



G4M0701

8E9

CHECK ABS SENSOR GAP.

Measure tone wheel-to-pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)

YES : Go to step 8E10.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

8E10

CHECK HUB RUNOUT.

Measure hub runout.

CHECK : Is the runout less than 0.05 mm (0.0020 in)?

YES : Go to step 8E11.

NO : Repair hub.

8E11

CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between ABS/CM and ABS sensor? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8E12.

8E12	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

 : *Is the same trouble code as in the current diagnosis still being output?*

 : Replace ABSCM.

 : Go to step **8E13**.

8E13	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

 : *Are other trouble codes being output?*

 : Proceed with the diagnosis corresponding to the trouble code.

 : A temporary poor contact.

NOTE:

Check harness and connectors between ABSCM and ABS sensor.

**F: TROUBLE CODE 22 (FRONT RH)
G: TROUBLE CODE 24 (FRONT LH)
H: TROUBLE CODE 26 (REAR RH)
I: TROUBLE CODE 28 (REAR LH)
— ABNORMAL ABS SENSOR (ABNORMAL
ABS SENSOR SIGNAL) —**


DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty harness/connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



8I1	CHECK INSTALLATION OF ABS SENSOR.
------------	--

Tightening torque: $32 \pm 10 \text{ N}\cdot\text{m} (3.3 \pm 1.0 \text{ kg}\cdot\text{m}, 24 \pm 7 \text{ ft-lb})$

CHECK : Are the ABS sensor installation bolts tightened securely?

YES : Go to step **8I2**.

NO : Tighten ABS sensor installation bolts securely.


8I2	CHECK INSTALLATION OF TONE WHEEL.
------------	--

Tightening torque: $13 \pm 3 \text{ N}\cdot\text{m} (1.3 \pm 0.3 \text{ kg}\cdot\text{m}, 9 \pm 2.2 \text{ ft-lb})$

CHECK : Are the tone wheel installation bolts tightened securely?

YES : Go to step **8I3**.

NO : Tighten tone wheel installation bolts securely.




8I3	CHECK ABS SENSOR GAP.
------------	------------------------------

Measure tone wheel to pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)



YES : Go to step **8I4**.

NO : Adjust the gap.

NOTE:


Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

8I4	CHECK OSCILLOSCOPE.
------------	----------------------------

CHECK : Is an oscilloscope available?

YES : Go to step **8I5**.

NO : Go to step **8I6**.




8I5

CHECK ABS SENSOR SIGNAL.


- 1) Raise all four wheels of ground.
- 2) Turn ignition switch OFF.
- 3) Disconnect connector from ABS control module.
- 4) Remove band.
- 5) Remove cable clamp cover.
- 6) Remove screws securing connector cover.

CAUTION:

Do not allow harness to catch on adjacent parts during installation.




- 7) Remove connector cover.

**NOTE:**

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

- 8) Connect connector to ABS control module.
- 9) Connect the oscilloscope to the ABS control module connector in accordance with trouble code.
- 10) Turn ignition switch ON.



11) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

Connector & terminal

Trouble code 22 / (F49) No. 14 (+) — No. 15 (-):

Trouble code 24 / (F49) No. 49 (+) — No. 19 (-):

Trouble code 26 / (F49) No. 18 (+) — No. 46 (-):

Trouble code 28 / (F49) No. 16 (+) — No. 17 (-):

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : Is oscilloscope pattern smooth, as shown in figure?

YES : Go to step 8I9.

NO : Go to step 8I6.

8I6

CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL.

Remove disc rotor or drum from hub in accordance with trouble code.

CHECK : Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to step 8I7.

8I7

CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL.

CHECK : Are there broken or damaged in the ABS sensor pole piece or the tone wheel?

YES : Replace ABS sensor or tone wheel.

NO : Go to step 8I8.

8I8


CHECK HUB RUNOUT.

Measure hub runout.

CHECK : Is the runout less than 0.05 mm (0.0020 in)?

YES : Go to step 8I9.

NO : Repair hub.



B4M0806

8I9

CHECK RESISTANCE OF ABS SENSOR.


- 1) Turn ignition switch OFF.
- 2) Disconnect connector from ABS sensor.
- 3) Measure resistance between ABS sensor connector terminals.

Terminal**Front RH No. 1 — No. 2:****Front LH No. 1 — No. 2:****Rear RH No. 1 — No. 2:****Rear LH No. 1 — No. 2:**

CHECK : Is the resistance between 0.8 and 1.2 kΩ?

YES : Go to step 8I10.

NO : Replace ABS sensor.



B4M0818D

8I10

CHECK GROUND SHORT OF ABS SENSOR.


Measure resistance between ABS sensor and chassis ground.

Terminal**Front RH No. 1 — Chassis ground:****Front LH No. 1 — Chassis ground:****Rear RH No. 1 — Chassis ground:****Rear LH No. 1 — Chassis ground:**

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step 8I11.

NO : Replace ABS sensor.


8I11 CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND ABS SENSOR.

- 1) Connect connector to ABS sensor.
- 2) Disconnect connector from ABS control module.
- 3) Measure resistance at ABSCM connector terminals.

Connector & terminal

Trouble code 22 / (F49) No. 14 — No. 15:

Trouble code 24 / (F49) No. 49 — No. 19:


Trouble code 26 / (F49) No. 18 — No. 46:

Trouble code 28 / (F49) No. 16 — No. 17:

CHECK : Is the resistance between 0.8 and 1.2 k Ω ?

YES : Go to step 8I12.

NO : Repair harness/connector between ABSCM and ABS sensor.


8I12 CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 22 / (F49) No. 14 — Chassis ground:

Trouble code 24 / (F49) No. 49 — Chassis ground:


Trouble code 26 / (F49) No. 18 — Chassis ground:

Trouble code 28 / (F49) No. 16 — Chassis ground:

CHECK : Is the resistance more than 1 M Ω ?

YES : Go to step 8I13.

NO : Repair harness/connector between ABSCM and ABS sensor.


8I13 CHECK GROUND CIRCUIT OF ABSCM.

Measure resistance between ABSCM and chassis ground.

Connector & terminal

(F49) No. 1 — GND:

(F49) No. 55 — GND:

CHECK : Is the resistance less than 0.5 Ω ?

YES : Go to step 8I14.

NO : Repair ABSCM ground harness.

8I14	CHECK POOR CONTACT IN CONNECTORS.
-------------	--

CHECK : *Is there poor contact in connectors between ABSCM and ABS sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **8I15**.

8I15	CHECK SOURCES OF SIGNAL NOISE.
-------------	---------------------------------------

CHECK : *Is the car telephone or the wireless transmitter properly installed?*

YES : Go to step **8I16**.


NO : Properly install the car telephone or the wireless transmitter.

8I16	CHECK SOURCES OF SIGNAL NOISE.
-------------	---------------------------------------

CHECK : *Are noise sources (such as an antenna) installed near the sensor harness?*

YES : Install the noise sources apart from the sensor harness.

NO : Go to step **8I17**.



8I17	CHECK SHIELD CIRCUIT.
-------------	------------------------------

1) Connect all connectors.

2) Measure resistance between shield connector and chassis ground.

Connector & terminal

Trouble code 22 / (B100) No. 6 — Chassis ground:

Trouble code 24 / (B100) No. 2 — Chassis ground:

Trouble code 26 / (F55) No. 6 — Chassis ground:

Trouble code 28 / (F55) No. 1 — Chassis ground:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **8I18**.

NO : Repair shield harness.

8I18	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **8I19**.

8I19	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary noise interference.

J: TROUBLE CODE 29
— ABNORMAL ABS SENSOR SIGNAL (ANY ONE OF FOUR) —


DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty tone wheel
- Wheels turning freely for a long time

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



8J1	CHECK IF THE WHEELS HAVE TURNED FREELY FOR A LONG TIME.
------------	--

 : *Check if the wheels have been turned freely for more than one minute, such as when the vehicle is jacked-up, under full-lock cornering or when tire is not in contact with road surface.*

 : The ABS is normal. Erase the trouble code.

NOTE:

When the wheels turn freely for a long time, such as when the vehicle is towed or jacked-up, or when steering wheel is continuously turned all the way, this trouble code may sometimes occur.

 : Go to step **8J2**.

8J2	CHECK TIRE SPECIFICATIONS.
------------	-----------------------------------

 : *Are the tire specifications correct?*

 : Go to step **8J3**.

 : Replace tire.

8J3	CHECK WEAR OF TIRE.
------------	----------------------------

 : *Is the tire worn excessively?*

 : Replace tire.

 : Go to step **8J4**.

8J4	CHECK TIRE PRESSURE.
------------	-----------------------------

 : *Is the tire pressure correct?*

 : Go to step **8J5**.

 : Adjust tire pressure.

8J5	CHECK INSTALLATION OF ABS SENSOR.
------------	--

Tightening torque:

32±10 N·m (3.3±1.0 kg-m, 24±7 ft-lb)

 : *Are the ABS sensor installation bolts tightened securely?*

 : Go to step **8J6**.

 : Tighten ABS sensor installation bolts securely.


8J6

CHECK INSTALLATION OF TONE WHEEL.**Tightening torque:** $13\pm3\text{ N}\cdot\text{m}$ ($1.3\pm0.3\text{ kg}\cdot\text{m}$, $9\pm2.2\text{ ft}\cdot\text{lb}$)


CHECK : Are the tone wheel installation bolts tightened securely?

YES : Go to step 8J7.

NO : Tighten tone wheel installation bolts securely.



G4M0700



G4M0701

8J7

CHECK ABS SENSOR GAP.

Measure tone wheel to pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)

YES : Go to step 8J8.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.


8J8

CHECK OSCILLOSCOPE.

CHECK : Is an oscilloscope available?

YES : Go to step 8J9.

NO : Go to step 8J10.




8J9

CHECK ABS SENSOR SIGNAL.


- 1) Raise all four wheels of ground.
- 2) Turn ignition switch OFF.
- 3) Disconnect connector from ABS control module.
- 4) Remove band.
- 5) Remove cable clamp cover.
- 6) Remove screws securing connector cover.

CAUTION:

Do not allow harness to catch on adjacent parts during installation.




- 7) Remove connector cover.

**NOTE:**

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

- 8) Connect connector to ABS control module.
- 9) Connect the oscilloscope to the ABS control module connector in accordance with trouble code.
- 10) Turn ignition switch ON.



1) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

Connector & terminal

(F49) No. 14 (+) — No. 15 (-) (Front RH):

(F49) No. 49 (+) — No. 19 (-) (Front LH):

(F49) No. 18 (+) — No. 46 (-) (Rear RH):

(F49) No. 16 (+) — No. 17 (-) (Rear LH):

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : Is oscilloscope pattern smooth, as shown in figure?

YES : Go to step 8J13.

NO : Go to step 8J10.

8J10 CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL.

Remove disc rotor from hub.

CHECK : Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to step 8J11.

8J11 CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL.

CHECK : Are there broken or damaged teeth in the ABS sensor pole piece or the tone wheel?

YES : Replace ABS sensor or tone wheel.

NO : Go to step 8J12.

8J12 CHECK HUB RUNOUT.

Measure hub runout.

CHECK : Is the runout less than 0.05 mm (0.0020 in)?

YES : Go to step 8J13.

NO : Repair hub.

8J13 CHECK ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.

5) Read out the trouble code.

 : *Is the same trouble code as in the current diagnosis still being output?*

 : Replace ABSCM.

 : Go to step **8J14**.

8J14	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

 : *Are other trouble codes being output?*

 : Proceed with the diagnosis corresponding to the trouble code.

 : A temporary poor contact.

K: TROUBLE CODE 31 (FRONT RH)
L: TROUBLE CODE 33 (FRONT LH)
M: TROUBLE CODE 35 (REAR RH)
N: TROUBLE CODE 37 (REAR LH)
— ABNORMAL INLET SOLENOID VALVE CIRCUIT(S) IN HYDRAULIC UNIT —


DIAGNOSIS:


- Faulty harness/connector
- Faulty inlet solenoid valve in hydraulic unit

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




8N1 **CHECK RESISTANCE OF SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 — (ABS2) No. 2:

Trouble code 33 / (ABS5) No. 1 — (ABS2) No. 2:


Trouble code 35 / (ABS5) No. 2 — (ABS2) No. 2:

Trouble code 37 / (ABS5) No. 3 — (ABS2) No. 2:

CHECK : *Is the resistance between 7.8 and 9.2 Ω?*

YES : Go to step 8N2.

NO : Replace hydraulic unit.


8N2 **CHECK GROUND SHORT OF SOLENOID VALVE.**

Measure resistance between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 — Chassis ground:

Trouble code 33 / (ABS5) No. 1 — Chassis ground:


Trouble code 35 / (ABS5) No. 2 — Chassis ground:

Trouble code 37 / (ABS5) No. 3 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 8N3.

NO : Replace hydraulic unit.



8N3

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 (+) — Chassis ground (-):

Trouble code 33 / (ABS5) No. 1 (+) — Chassis ground (-):


Trouble code 35 / (ABS5) No. 2 (+) — Chassis ground (-):

Trouble code 37 / (ABS5) No. 3 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8N4.

NO : Replace hydraulic unit.



8N4

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 (+) — Chassis ground (-):

Trouble code 33 / (ABS5) No. 1 (+) — Chassis ground (-):


Trouble code 35 / (ABS5) No. 2 (+) — Chassis ground (-):

Trouble code 37 / (ABS5) No. 3 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8N5.

NO : Replace hydraulic unit.



8N5

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 (+) — Chassis ground (-):

Trouble code 33 / (F49) No. 24 (+) — Chassis ground (-):


Trouble code 35 / (F49) No. 23 (+) — Chassis ground (-):

Trouble code 37 / (F49) No. 31 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8N6.

NO : Repair harness between ABSCM and hydraulic unit.



8N6

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 (+) — Chassis ground (-):

Trouble code 33 / (F49) No. 24 (+) — Chassis ground (-):


Trouble code 35 / (F49) No. 23 (+) — Chassis ground (-):

Trouble code 37 / (F49) No. 31 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8N7.

NO : Repair harness between ABSCM and hydraulic unit.



8N7

CHECK GROUND SHORT OF HARNESS.


- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal**Trouble code 31 / (F49) No. 30 — Chassis ground:****Trouble code 33 / (F49) No. 24 — Chassis ground:****Trouble code 35 / (F49) No. 23 — Chassis ground:****Trouble code 37 / (F49) No. 31 — Chassis ground:**

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 8N8.

NO : Repair harness between ABSCM and hydraulic unit.



8N8

CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal**Trouble code 31 / (F49) No. 30 — No. 1:****Trouble code 33 / (F49) No. 24 — No. 1:****Trouble code 35 / (F49) No. 23 — No. 1:****Trouble code 37 / (F49) No. 31 — No. 1:**

CHECK : *Is the resistance between 8.3 and 9.7 Ω?*

YES : Go to step 8N9.

NO : Repair harness/connector between ABSCM and hydraulic unit.

8N9

CHECK POOR CONTACT IN CONNECTORS.

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 8N10.

8N10	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **8N11**.

8N11	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

O: TROUBLE CODE 32 (FRONT RH)
P: TROUBLE CODE 34 (FRONT LH)
Q: TROUBLE CODE 36 (REAR RH)
R: TROUBLE CODE 38 (REAR LH)
— ABNORMAL OUTLET SOLENOID VALVE CIRCUIT(S) IN HYDRAULIC UNIT —


DIAGNOSIS:


- Faulty harness/connector
- Faulty outlet solenoid valve in hydraulic unit

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




8R1 **CHECK RESISTANCE OF SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 — (ABS2) No. 2:

Trouble code 34 / (ABS5) No. 5 — (ABS2) No. 2:


Trouble code 36 / (ABS5) No. 6 — (ABS2) No. 2:

Trouble code 38 / (ABS5) No. 7 — (ABS2) No. 2:

CHECK : *Is the resistance between 3.8 and 4.8 Ω?*

YES : Go to step 8R2.

NO : Replace hydraulic unit.


8R2 **CHECK GROUND SHORT OF SOLENOID VALVE.**

Measure resistance between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 — Chassis ground:

Trouble code 34 / (ABS5) No. 5 — Chassis ground:


Trouble code 36 / (ABS5) No. 6 — Chassis ground:

Trouble code 38 / (ABS5) No. 7 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 8R3.

NO : Replace hydraulic unit.



8R3

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 (+) — Chassis ground (-):

Trouble code 34 / (ABS5) No. 5 (+) — Chassis ground (-):


Trouble code 36 / (ABS5) No. 6 (+) — Chassis ground (-):

Trouble code 38 / (ABS5) No. 7 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8R4.

NO : Replace hydraulic unit.



8R4

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 (+) — Chassis ground (-):

Trouble code 34 / (ABS5) No. 5 (+) — Chassis ground (-):


Trouble code 36 / (ABS5) No. 6 (+) — Chassis ground (-):

Trouble code 38 / (ABS5) No. 7 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8R5.


NO : Replace hydraulic unit.



8R5

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector and chassis ground.


Connector & terminal**Trouble code 32 / (F49) No. 3 (+) — Chassis ground****(-):****Trouble code 34 / (F49) No. 51 (+) — Chassis ground****(-):****Trouble code 36 / (F49) No. 50 (+) — Chassis ground****(-):****Trouble code 38 / (F49) No. 4 (+) — Chassis ground****(-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 8R6.****NO : Repair harness between ABSCM and hydraulic unit.**

8R6

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**Trouble code 32 / (F49) No. 3 (+) — Chassis ground****(-):****Trouble code 34 / (F49) No. 51 (+) — Chassis ground****(-):****Trouble code 36 / (F49) No. 50 (+) — Chassis ground****(-):****Trouble code 38 / (F49) No. 4 (+) — Chassis ground****(-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 8R7.****NO : Repair harness between ABSCM and hydraulic unit.**



8R7

CHECK GROUND SHORT OF HARNESS.


- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal**Trouble code 32 / (F49) No. 3 — Chassis ground:****Trouble code 34 / (F49) No. 51 — Chassis ground:****Trouble code 36 / (F49) No. 50 — Chassis ground:****Trouble code 38 / (F49) No. 4 — Chassis ground:**

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 8R8.

NO : Repair harness between ABSCM and hydraulic unit.



8R8

CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal**Trouble code 32 / (F49) No. 3 — No. 1:****Trouble code 34 / (F49) No. 51 — No. 1:****Trouble code 36 / (F49) No. 50 — No. 1:****Trouble code 38 / (F49) No. 4 — No. 1:**

CHECK : Is the resistance between 4.3 and 5.3Ω ?

YES : Go to step 8R9.

NO : Repair harness/connector between ABSCM and hydraulic unit.

8R9

CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8R10.

8R10	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **8R11**.

8R11	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.


NO : A temporary poor contact.

**S: TROUBLE CODE 41
— ABNORMAL ABS CONTROL MODULE —****DIAGNOSIS:**

- Faulty ABSCM


TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X	
X	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

B4M0837



8S1 CHECK GROUND CIRCUIT OF ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM and chassis ground.

Connector & terminal

(F49) No. 1 — Chassis ground:

(F49) No. 55 — Chassis ground:

CHECK : Is the resistance less than 0.5 Ω?

YES : Go to step 8S2.

NO : Repair ABSCM ground harness.

8S2 CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between battery, ignition switch and ABSCM? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8S3.

8S3 CHECK SOURCES OF SIGNAL NOISE.

CHECK : Is the car telephone or the wireless transmitter properly installed?

YES : Go to step 8S4.

NO : Properly install the car telephone or the wireless transmitter.

8S4 CHECK SOURCES OF SIGNAL NOISE.

CHECK : Are noise sources (such as an antenna) installed near the sensor harness?

YES : Install the noise sources apart from the sensor harness.

NO : Go to step 8S5.

8S5 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 8S6.

8S6	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
------------	--

CHECK***Are other trouble codes being output?*****YES**

: Proceed with the diagnosis corresponding to the trouble code.

NO

: A temporary poor contact.

T: TROUBLE CODE 42
— SOURCE VOLTAGE IS LOW. —


DIAGNOSIS:

- Power source voltage of the ABSCM is low.


TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



H4M1108



8T1 CHECK GENERATOR.

- 1) Start engine.
- 2) Idling after warm-up.
- 3) Measure voltage between generator B terminal and chassis ground.

Terminal


Generator B terminal — Chassis ground:

CHECK : Is the voltage between 10 V and 15 V?
YES : Go to step 8T2.
NO : Repair generator.

8T2 CHECK BATTERY TERMINAL.

Turn ignition switch to OFF.

CHECK : Are the positive and negative battery terminals tightly clamped?
YES : Go to step 8T3.
NO : Tighten the clamp of terminal.




8T3 CHECK INPUT VOLTAGE OF ABSCM.

- 1) Disconnect connector from ABSCM.
- 2) Run the engine at idle.
- 3) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 28 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 15 V?
YES : Go to step 8T4.
NO : Repair harness connector between battery, ignition switch and ABSCM.



8T4 CHECK GROUND CIRCUIT OF ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 1 — Chassis ground:

CHECK : Is the resistance less than 0.5 Ω?
YES : Go to step 8T5.
NO : Repair ABSCM ground harness.

8T5	CHECK POOR CONTACT IN CONNECTORS.
------------	--

CHECK : *Is there poor contact in connectors between generator, battery and ABSCM? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **8T6**.

8T6	CHECK ABSCM.
------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **8T7**.

8T7	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

U: TROUBLE CODE 44
— A COMBINATION OF AT CONTROL
ABNORMAL —


DIAGNOSIS:


- Combination of AT control faults

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:






8U1 CHECK SPECIFICATIONS OF THE ABSCM.

Check specifications of the plate attached to the ABSCM.

CHECK : *Is an ABSCM for AT model installed on a MT model?*

YES : Replace ABSCM.

NO : Go to step **8U2**.



8U2 CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors from TCM.
- 3) Disconnect connector from ABSCM.
- 4) Measure resistance between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 12 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **8U3**.

NO : Repair harness between TCM and ABSCM.



8U3 CHECK BATTERY SHORT OF HARNESS.

Measure voltage between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 12 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **8U4**.

NO : Repair harness between TCM and ABSCM.



8U4 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 12 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **8U5**.

NO : Repair harness between TCM and ABSCM.



8U5 CHECK TCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors to TCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between TCM connector terminals.


Connector & terminal

(B55) No. 1 (+) — (B56) No. 5 (-):

CHECK : Is the voltage between 10 V and 13 V?

YES : Go to step 8U7.

NO : Go to step 8U6.



8U6 CHECK TCM.

Measure voltage between TCM connector and chassis ground.

Connector & terminal


(B54) No. 6 (+) — Chassis ground (-):

(B55) No. 1 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 13 V?

YES : Replace TCM.

NO : Repair harness/connector between battery, ignition switch and TCM.



8U7 CHECK OPEN CIRCUIT OF HARNESS.

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 12 (+) — Chassis ground (-):

(F49) No. 39 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 13 V?

YES : Go to step 8U8.

NO : Repair harness/connector between TCM and ABSCM.

8U8 CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between TCM and ABSCM? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8U9.

8U9 CHECK ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 8U10.

8U10 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

V: TROUBLE CODE 46
— ABNORMAL G SENSOR POWER SUPPLY VOLTAGE —


DIAGNOSIS:


- Faulty G sensor power supply voltage

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




**8V1 CHECK G SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Disconnect connector from G sensor.
- 4) Measure resistance of G sensor.

Terminal**No. 1 — No. 3:**


CHECK : *Is the resistance between 42 and 58 kΩ?*
YES : Go to step **8V2**.
NO : Replace G sensor.

**8V2 CHECK GROUND SHORT OF G SENSOR.**

Measure resistance between G sensor and bracket.

Terminal**No. 3 — Bracket:**


CHECK : *Is the resistance more than 1 MΩ?*
YES : Go to step **8V3**.
NO : Replace G sensor.

**8V3 CHECK SHORT CIRCUIT IN HARNESS BETWEEN ABSCM AND G SENSOR.**

- 1) Disconnect connector from ABSCM.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal**(F49) No. 45 — No. 8:**

CHECK : *Is the resistance more than 1 MΩ?*
YES : Go to step **8V4**.
NO : Repair harness between ABSCM and G sensor.



8V4 CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM connector and chassis ground.

Connector & terminal


(F49) No. 8 — Chassis ground:

(F49) No. 45 — Chassis ground:

CHECK : Is the resistance more than $1\text{ M}\Omega$?

YES : Go to step 8V5.

NO : Repair harness between ABSCM and G sensor.



8V5 CHECK BATTERY SHORT OF HARNESS.

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal


(F49) No. 8 (+) — Chassis ground (-):

(F49) No. 45 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8V6.

NO : Repair harness between ABSCM and G sensor.



8V6 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM and chassis ground.

Connector & terminal

(F49) No. 8 (+) — Chassis ground (-):

(F49) No. 45 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8V7.

NO : Repair harness between ABSCM and chassis ground.

8V7 CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8V8.

8V8 CHECK ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 8V9.

8V9 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

W: TROUBLE CODE 51

— ABNORMAL VALVE RELAY —


DIAGNOSIS:


- Faulty valve relay

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:






B4M0858A

8W1 CHECK RESISTANCE OF VALVE RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove valve relay from relay box.
- 3) Measure resistance between valve relay terminals.

Terminals**No. 85 — No. 86:**

CHECK : *Is the resistance between 93 and 113 Ω?*
YES : Go to step **8W2**.
NO : Replace valve relay.




B4M1052A

8W2 CHECK CONTACT POINT OF VALVE RELAY.

- 1) Connect battery to valve relay terminals No. 85 and No. 86.
- 2) Measure resistance between valve relay terminals.

Terminals**No. 30 — No. 87:**

CHECK : *Is the resistance less than 0.5 Ω?*
YES : Go to step **8W3**.
NO : Replace valve relay.




B4M1111A

8W3 CHECK CONTACT POINT OF VALVE RELAY.

Measure resistance between valve relay terminals.

Terminals**No. 30 — No. 87a:**

Is the resistance more than 1 MΩ?
YES : Go to step **8W4**.
NO : Replace valve relay.



B4M1054A

8W4

CHECK CONTACT POINT OF VALVE RELAY.


- 1) Disconnect battery from valve relay terminals.
- 2) Measure resistance between valve relay terminals.

Terminals**No. 30 — No. 87:**

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **8W5**.

NO : Replace valve relay.



B4M1113A

8W5

CHECK CONTACT POINT OF VALVE RELAY.


Measure resistance between valve relay terminals.

Terminals**No. 30 — No. 87a:**

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **8W6**.

NO : Replace valve relay.



B4M0861A

8W6

CHECK SHORT OF VALVE RELAY.


Measure resistance between valve relay terminals.

Terminals**No. 86 — No. 87:****No. 86 — No. 87a:**

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **8W7**.

NO : Replace valve relay.



B4M0862B

8W7

CHECK POWER SUPPLY FOR VALVE RELAY.


- 1) Disconnect connector (F8) from relay box.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between relay box connector and chassis ground.

Connector & terminal**(F8) No. 1 (+) — Chassis ground (-):**

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step **8W8**.

NO : Repair harness between battery and relay box connector. Check fuse No. 19.


8W8 **CHECK GROUND CIRCUIT OF RELAY BOX.**


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector (F50) from relay box.
- 3) Measure resistance between relay box connector and chassis ground.

Connector & terminal
(F50) No. 3 — Chassis ground:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **8W9**.

NO : Repair relay box ground harness.


8W9 **CHECK OPEN CIRCUIT AND GROUND SHORT IN POWER SUPPLY CIRCUIT OF RELAY BOX.**


- 1) Disconnect connector (ABS1) from hydraulic unit.
- 2) Connect connector (F8) to relay box.
- 3) Turn ignition switch to ON.
- 4) Measure voltage of relay box.

Connector & terminal
Valve relay installing point No. 87 — Chassis ground:

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step **8W10**.


NO : Replace relay box and check fuse No. 19.



8W10

CHECK OPEN CIRCUIT IN CONTACT POINT CIRCUIT OF RELAY BOX.


- 1) Turn ignition switch to OFF.
- 2) Measure resistance between hydraulic unit connector and valve relay installing point.

Connector & terminal**(ABS1) No. 2 — Valve relay installing point No. 30:****CHECK** : Is the resistance less than $0.5\ \Omega$?**YES** : Go to step **8W11**.**NO** : Replace relay box.

8W11

CHECK GROUND SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

Measure resistance between hydraulic unit connector and chassis ground.


Connector & terminal**(ABS1) No. 2 — Chassis ground:****CHECK** : Is the resistance more than $1\ M\Omega$?**YES** : Go to step **8W12**.**NO** : Replace relay box and check fuse SBF6.

8W12

CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal**(ABS1) No. 2 (+) — Chassis ground (-):****CHECK** : Is the voltage less than 1 V?**YES** : Go to step **8W13**.**NO** : Replace relay box. Check fuse No. 19 and SBF6.



B4M0867A

8W13 **CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.


Connector & terminal

(ABS1) No. 2 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **8W14**.

NO : Replace relay box. Check fuse No. 19 and SBF6.



B4M0868C

8W14 **CHECK DIODE OF RELAY BOX.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between relay box connector and valve relay installing point.


Connector & terminal

Valve relay installing point No. 30 (+) — (ABS4) No. 2 (-):

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step **8W15**.

NO : Replace relay box.



B4M0869C

8W15 **CHECK OPEN CIRCUIT IN GROUND CIRCUIT OF RELAY BOX.**

Measure resistance between relay box connector and valve relay installing point.


Connector & terminal

(ABS4) No. 3 — Valve relay installing point No. 87a:

CHECK : Is the resistance less than 0.5Ω ?

YES : Go to step **8W16**.

NO : Replace relay box.



B4M0870C

8W16

CHECK BATTERY SHORT IN GROUND CIRCUIT OF RELAY BOX.

Measure voltage between relay box connector and chassis ground.


Connector & terminal

(ABS4) No. 3 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 8W17.

NO : Replace relay box and check all fuses.



B4M0870C

8W17

CHECK BATTERY SHORT IN GROUND CIRCUIT OF RELAY BOX.

1) Turn ignition switch to ON.

2) Measure voltage between relay box connector and chassis ground.


Connector & terminal

(ABS4) No. 3 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 8W18.

NO : Replace relay box and check all fuses.



B4M0871C

8W18

CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX.

1) Turn ignition switch to OFF.

2) Install valve relay to relay box.

3) Measure resistance between relay box connector terminals.


Connector & terminal

(ABS4) No. 1 — No. 5:

CHECK : *Is the resistance between 93 and 113 Ω?*

YES : Go to step 8W19.

NO : Replace relay box.



B4M0872C

8W19

CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.


Measure resistance between relay box connector and chassis ground.

Connector & terminal**(ABS4) No. 1 — Chassis ground:**

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step **8W20**.

NO : Replace relay box and check all fuses.



B4M0873C

8W20

CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.


Measure voltage between relay box connector and chassis ground.

Connector & terminal**(ABS4) No. 1 (+) — Chassis ground (-):**

CHECK : Is the voltage less than 1 V?

YES : Go to step **8W21**.

NO : Replace relay box. Check fuse No. 19 and SBF45A.



B4M0873C

8W21

CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.

1) Turn ignition switch to ON.


2) Measure voltage between relay box connector and chassis ground.

Connector & terminal**(ABS4) No. 1 (+) — Chassis ground (-):**

CHECK : Is the voltage less than 1 V?

YES : Go to step **8W22**.

NO : Replace relay box. Check fuse No. 19 and SBF45A.



8W22

CHECK OPEN CIRCUIT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.


- 1) Turn ignition switch to OFF.
- 2) Connect connector (F50) to relay box.
- 3) Measure resistance between ABSCM connector terminals.

Connector & terminal**(F49) No. 27 — No. 47:**

CHECK : *Is the resistance between 93 and 113 Ω?*

YES : Go to step 8W23.

NO : Repair harness between ABSCM and relay box.
Check fuse No. 18.



8W23

CHECK GROUND SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.


Measure resistance between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 27 — Chassis ground:**

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 8W24.

NO : Repair harness between ABSCM and relay box.
Check fuse No. 18.



8W24

CHECK BATTERY SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 27 (+) — Chassis ground (-):

CHECK


: Is the voltage less than 1 V?

YES

: Go to step 8W25.

NO

: Repair harness between ABSCM and relay box and check all fuses.



8W25

CHECK BATTERY SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.

1) Turn ignition switch to ON.

2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 27 (+) — Chassis ground (-):

CHECK


: Is the voltage less than 1 V?

YES

: Go to step 8W26.

NO

: Repair harness between ABSCM and relay box and check all fuses.



8W26

CHECK RESISTANCE OF INLET SOLENOID VALVE.


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal**(ABS5) No. 4 — (ABS2) No. 2:****(ABS5) No. 1 — (ABS2) No. 2:****(ABS5) No. 2 — (ABS2) No. 2:****(ABS5) No. 3 — (ABS2) No. 2:**

CHECK : Is the resistance between 7.8 and 9.2 Ω ?

YES : Go to step 8W27.

NO : Replace hydraulic unit.



8W27

CHECK RESISTANCE OF OUTLET SOLENOID VALVE.


Measure resistance between hydraulic unit connector terminals.

Connector & terminal**(ABS5) No. 8 — (ABS2) No. 2:****(ABS5) No. 5 — (ABS2) No. 2:****(ABS5) No. 6 — (ABS2) No. 2:****(ABS5) No. 7 — (ABS2) No. 2:**

CHECK : Is the resistance between 3.8 and 4.8 Ω ?

YES : Go to step 8W28.

NO : Replace hydraulic unit.



8W28

CHECK GROUND SHORT OF SOLENOID VALVE.


Measure resistance between hydraulic unit connector and chassis ground.

Connector & terminal**(ABS5) No. 4 — Chassis ground:**

CHECK : Is the resistance more than 1 $M\Omega$?

YES : Go to step 8W29.

NO : Replace hydraulic unit and check all fuses.



8W29

CHECK BATTERY SHORT OF SOLENOID VALVE.


Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal**(ABS5) No. 4 (+) — Chassis ground (-):**

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 8W30.

NO : Replace hydraulic unit and check all fuses.



8W30

CHECK BATTERY SHORT OF SOLENOID VALVE.

1) Turn ignition switch to ON.


2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal**(ABS5) No. 4 (+) — Chassis ground (-):**

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 8W31.

NO : Replace hydraulic unit and check all fuses.



8W31

CHECK BATTERY SHORT OF HARNESS.

1) Turn ignition switch to OFF.

2) Disconnect connector from hydraulic unit.


3) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 30 (+) — Chassis ground (-):****(F49) No. 24 (+) — Chassis ground (-):****(F49) No. 23 (+) — Chassis ground (-):****(F49) No. 31 (+) — Chassis ground (-):****(F49) No. 3 (+) — Chassis ground (-):****(F49) No. 51 (+) — Chassis ground (-):****(F49) No. 50 (+) — Chassis ground (-):****(F49) No. 4 (+) — Chassis ground (-):**

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 8W32.

NO : Repair harness between hydraulic unit and ABSCM and check all fuses.



8W32

CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 30 (+) — Chassis ground (-):
 (F49) No. 24 (+) — Chassis ground (-):
 (F49) No. 23 (+) — Chassis ground (-):
 (F49) No. 31 (+) — Chassis ground (-):
 (F49) No. 3 (+) — Chassis ground (-):
 (F49) No. 51 (+) — Chassis ground (-):
 (F49) No. 50 (+) — Chassis ground (-):
 (F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8W33.

NO : Repair harness between hydraulic unit and ABSCM and check all fuses.



8W33

CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 30 — Chassis ground:
 (F49) No. 24 — Chassis ground:
 (F49) No. 23 — Chassis ground:
 (F49) No. 31 — Chassis ground:
 (F49) No. 3 — Chassis ground:
 (F49) No. 51 — Chassis ground:
 (F49) No. 50 — Chassis ground:
 (F49) No. 4 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 8W34.

NO : Repair harness between hydraulic unit and ABSCM.

8W37	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

 : *Is the same trouble code as in the current diagnosis still being output?*

 : Replace ABSCM.

 : Go to step **8W38**.

8W38	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

 : *Are other trouble codes being output?*

 : Proceed with the diagnosis corresponding to the trouble code.

 : A temporary poor contact.

X: TROUBLE CODE 52
— ABNORMAL MOTOR AND/OR MOTOR RELAY —


DIAGNOSIS:


- Faulty motor
- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:





B4M0886A


8X1

CHECK RESISTANCE OF MOTOR RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove motor relay from relay box.
- 3) Measure resistance between motor relay terminals.

Terminals**No. 85 — No. 86:**

CHECK : *Is the resistance between 70 and 90 Ω ?*
YES : Go to step 8X2.
NO : Replace motor relay.



B4M0887A


8X2

CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Connect battery to motor relay terminals No. 85 and No. 86.
- 2) Measure resistance between motor relay terminals.

Terminals**No. 30 — No. 87:**

CHECK : *Is the resistance less than 0.5 Ω ?*
YES : Go to step 8X3.
NO : Replace motor relay.



B4M0888A


8X3

CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Disconnect battery from motor relay terminals.
- 2) Measure resistance between motor relay terminals.

Terminals**No. 30 — No. 87:**

CHECK : *Is the resistance more than 1 $M\Omega$?*
YES : Go to step 8X4.
NO : Replace motor relay.



B4M0889A


8X4 CHECK SHORT OF MOTOR RELAY.

Measure resistance between motor relay terminals.

Terminals**No. 85 — No. 30:****No. 85 — No. 87:**CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 8X5.

NO : Replace motor relay.



B4M0890B

8X5 CHECK INPUT VOLTAGE OF RELAY BOX.

1) Disconnect connector (F8) from relay box.


2) Turn ignition switch to ON.

3) Measure voltage between relay box connector and chassis ground.

Connector & terminal**(F8) No. 2 (+) — Chassis ground (-):**CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step 8X6.

NO : Repair harness/connector between battery and relay box, and check fuse SBF6.



B4M0891

8X6 CHECK INPUT VOLTAGE OF MOTOR RELAY.

1) Turn ignition switch to OFF.

2) Connect connector (F8) to relay box.


3) Turn ignition switch to ON.

4) Measure voltage between relay box and chassis ground.

Connector & terminal**Relay installing point No. 87 (+) — Chassis ground (-):**CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step 8X7.

NO : Replace relay box, and check fuse SBF6.



8X7

CHECK OPEN CIRCUIT IN CONTACT POINT CIRCUIT OF RELAY BOX.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector (ABS1) from hydraulic unit.
- 3) Measure resistance between hydraulic unit and motor relay installing portion.


Connector & terminal

(ABS1) No. 1 — Motor relay installing portion No. 30:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 8X8.

NO : Replace relay box.



8X8

CHECK GROUND SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

Measure resistance between hydraulic unit and chassis ground.


Connector & terminal

(ABS1) No. 1 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 8X9.

NO : Replace relay box. Check fuse No. 19.



8X9

CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between ABSCM connector and chassis ground.


Connector & terminal

(ABS1) No. 1 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 8X10.


NO : Replace relay box.



8X10

CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.


Connector & terminal**(ABS1) No. 1 (+) — Chassis ground (-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 8X11.****NO : Replace relay box.**

8X11

CHECK OPEN CIRCUIT IN MONITOR SYSTEM CIRCUIT OF RELAY BOX.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector (F50) from relay box.
- 3) Measure resistance between relay box connector and motor relay installing point.

Connector & terminal**(ABS4) No. 6 — Motor relay installing point No. 30:****CHECK : Is the resistance less than 0.5 Ω?****YES : Go to step 8X12.****NO : Replace relay box.**



8X12

CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Remove valve relay from relay box.
- 2) Measure resistance between motor relay installing point and valve relay installing point.


Connector & terminal

Motor relay installing point No. 86 — Valve relay installing point No. 30:

CHECK : Is the resistance less than $0.5\ \Omega$?

YES : Go to step 8X13.

NO : Replace relay box.



8X13

CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX.

Measure resistance between motor relay installing point and relay box connector.


Connector & terminal

Motor relay installing point No. 86 — (ABS4) No. 4:

CHECK : Is the resistance less than $0.5\ \Omega$?

YES : Go to step 8X14.

NO : Replace relay box.



8X14

CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.

Measure resistance between relay box and chassis ground.

Connector & terminal


Motor relay installing point No. 86 — Chassis ground:

Motor relay installing point No. 85 — Chassis ground:

CHECK : Is the resistance more than $1\ M\Omega$?

YES : Go to step 8X15.

NO : Replace relay box. Check fuse No. 19.



8X15

CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.

Measure voltage between motor relay installing point and chassis ground.

Connector & terminal


Motor relay installing point (+) No. 86 — Chassis ground (-):

Motor relay installing point (+) No. 85 — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 8X16.

NO : Replace relay box and check all fuses.



8X16

CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.

1) Turn ignition switch to ON.

2) Measure voltage between motor relay installing point and chassis ground.

Connector & terminal


Motor relay installing point (+) No. 86 — Chassis ground:

Motor relay installing point (+) No. 85 — Chassis ground:

CHECK : Is the voltage less than 1 V?

YES : Go to step 8X17.

NO : Replace relay box and check all fuses.

**8X17****CHECK OPEN CIRCUIT IN MONITOR SYSTEM HARNESS.**


- 1) Turn ignition switch to OFF.
- 2) Connect between terminals No. 10 and No. 1 of ABSCM connector (F49) with a lead wire.
- 3) Measure resistance between relay box connector and chassis ground.

Connector & terminal**(F50) No. 6 — Chassis ground:**

CHECK : Is the resistance less than 0.5Ω ?

YES : Go to step **8X18**.

NO : Repair harness/connector between ABSCM and relay box.

**8X18****CHECK OPEN CIRCUIT IN RELAY CONTROL SYSTEM HARNESS.**


- 1) Connect valve relay and motor relay to relay box.
- 2) Connect connector (F50) to relay box.
- 3) Connect connector to hydraulic unit.
- 4) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 22 — Chassis ground:**

CHECK : Is the resistance between 70 and 90Ω ?

YES : Go to step **8X19**.

NO : Repair harness/connector between ABSCM and relay box.



8X19

**CHECK GROUND SHORT IN HARNESS
BETWEEN RELAY BOX AND ABSCM.**

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 22 — Chassis ground:

(F49) No. 10 — Chassis ground:

CHECK


YES

NO

Is the resistance more than $1 M\Omega$?

Go to step 8X20.

Repair harness between ABSCM and relay box.
Check fuse No. 19 and SBF6.



8X20

**CHECK BATTERY SHORT IN HARNESS
BETWEEN RELAY BOX AND ABSCM.**

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 22 (+) — Chassis ground (-):

(F49) No. 10 (+) — Chassis ground (-):

CHECK


YES

NO

Is the voltage less than 1 V?

Go to step 8X21.


Repair harness between relay box and ABSCM.
Check fuse SBF6.



NOTE:

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

5) Connect all connectors.



6) Measure voltage between ABSCM connector terminals.


Connector & terminal

(F49) No. 10 (+) — No. 1 (-):

CHECK : *Is the voltage less than 2 V?*

YES : Go to step 8X24.

NO : Replace ABSCM.



8X24

CHECK BATTERY SHORT IN ABSCM CONNECTOR TERMINAL.

1) Turn ignition switch to ON.

2) Measure voltage between ABSCM connector terminals.


Connector & terminal

(F49) No. 10 (+) — No. 1 (-):

CHECK : *Is the voltage less than 2 V?*

YES : Go to step 8X25.

NO : Replace ABSCM.



8X25

CHECK CONDITION OF MOTOR GROUND.


Tightening torque:

$32 \pm 10 \text{ N}\cdot\text{m} (3.3 \pm 1.0 \text{ kg}\cdot\text{m}, 24 \pm 7 \text{ ft-lb})$:

CHECK : *Is the motor ground terminal tightly clamped?*

YES : Go to step 8X26.

NO : Tighten the clamp of motor ground terminal.



8X26

CHECK ABSCM MOTOR DRIVE TERMINAL.


- 1) Operate the check sequence. <Ref. to 4-4 [W12D0].>
- 2) Measure voltage between ABSCM connector terminals.

Connector & terminal**(F49) No. 22 (+) — No. 1 (-):**

CHECK : Does the voltage drop from between 10 V and 13 V to less than 1.5 V, and rise to between 10 V and 13 V again when carrying out the check sequence?

YES : Go to step 8X27.

NO : Replace ABSCM.



8X27

CHECK MOTOR OPERATION.

- 1) Operate the check sequence. <Ref. to 4-4 [W12D0].>
- 2) Measure voltage between ABSCM connector terminals.

Connector & terminal**(F49) No. 10 (+) — No. 1 (-):**

CHECK : Does the voltage raise from less than 1.5 V to between 10 V and 13 V, and return to less than 1.5 V again when carrying out the check sequence?

YES : Go to step 8X28.

NO : Replace hydraulic unit.

8X28

CHECK MOTOR OPERATION.

Operate the check sequence. <Ref. to 4-4 [W12D0].>

CHECK : Can motor revolution noise (buzz) be heard when carrying out the check sequence?

YES : Go to step 8X29.

NO : Replace hydraulic unit.

8X29

CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : Is there poor contact in connector between hydraulic unit, relay box and ABSMC? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 8X30.

8X30	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **8X31**.

8X31	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

Y: TROUBLE CODE 54 — ABNORMAL STOP LIGHT SWITCH —


DIAGNOSIS:

- Faulty stop light switch

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




8Y1	CHECK STOP LIGHTS COME ON.
-----	----------------------------

Depress the brake pedal.

CHECK : *Do stop lights come on?*

YES : Go to step 8Y2.

NO : Repair stop lights circuit.



8Y2	CHECK OPEN CIRCUIT IN HARNESS.
-----	--------------------------------

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Depress brake pedal.
- 4) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 36 — Chassis ground:

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step 8Y3.

NO : Repair harness between stop light switch and ABSCM.

8Y3	CHECK POOR CONTACT IN CONNECTORS.
-----	-----------------------------------

CHECK : *Is there poor contact in connector between stop light switch and ABSCM? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 8Y4.

8Y4	CHECK ABSCM.
-----	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 8Y5.

8Y5	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-----	---

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

Z: TROUBLE CODE 56
— ABNORMAL G SENSOR OUTPUT VOLTAGE —


DIAGNOSIS:

- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




8Z1	CHECK ALL FOUR WHEELS FOR FREE TURNING.
------------	--

CHECK : *Have the wheels been turned freely such as when the vehicle is lifted up, or operated on a rolling road?*

YES : The ABS is normal. Erase the trouble code.

NO : Go to step **8Z2**.



8Z2	CHECK SPECIFICATIONS OF ABSCM.
------------	---------------------------------------

Check specifications of the plate attached to the ABSCM.

CHECK : *Is an ABSCM for 4WD model installed on a FWD model?*

CAUTION:

Be sure to turn ignition switch to OFF when removing ABSCM.

YES : Replace ABSCM.

NO : Go to step **8Z3**.

8Z3	CHECK INPUT VOLTAGE OF G SENSOR.
------------	---

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Disconnect G sensor from body. (Do not disconnect connector.)
- 4) Turn ignition switch to ON.
- 5) Measure voltage between G sensor connector terminals.


Connector & terminal


(R70) No. 1 (+) — No. 3 (-):

CHECK : *Is the voltage between 4.75 and 5.25 V?*

YES : Go to step **8Z4**.

NO : Repair harness/connector between G sensor and ABSCM.





8Z4 **CHECK OPEN CIRCUIT IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.


Connector & terminal

(F49) No. 7 — No. 45:

CHECK : Is the resistance between 4.3 and 4.9 k Ω ?

YES : Go to step **8Z5**.

NO : Repair harness/connector between G sensor and ABSCM.



8Z5 **CHECK GROUND SHORT IN G SENSOR OUTPUT HARNESS.**

- 1) Disconnect connector from G sensor.
- 2) Measure resistance between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 7 — Chassis ground:

CHECK : Is the resistance more than 1 M Ω ?

YES : Go to step **8Z6**.

NO : Repair harness between G sensor and ABSCM.



8Z6 **CHECK BATTERY SHORT OF HARNESS.**

Measure voltage between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 7 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **8Z7**.

NO : Repair harness between G sensor and ABSCM.



B4M0914A

8Z7

CHECK BATTERY SHORT OF HARNESS.


- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 7 (+) — Chassis ground (-):****CHECK** : *Is the voltage less than 1 V?***YES** : Go to step 8Z8.**NO** : Repair harness between G sensor and ABSCM.

8Z8

CHECK G SENSOR.

- 1) Turn ignition switch to OFF.
- 2) Remove G sensor from vehicle.
- 3) Connect connector to G sensor.
- 4) Connect connector to ABSCM.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between G sensor connector terminals.

Connector & terminal**(R70) No. 2 (+) — No. 1 (-):****CHECK** : *Is the voltage between 2.1 and 2.4 V when G sensor is horizontal?***YES** : Go to step 8Z9.**NO** : Replace G sensor.


H4M1147A

8Z9

CHECK G SENSOR.

Measure voltage between G sensor connector terminals.

Connector & terminal**(R70) No. 2 (+) — No. 1 (-):****CHECK** : *Is the voltage between 3.7 and 4.1 V when G sensor is inclined forwards to 90°?***YES** : Go to step 8Z10.**NO** : Replace G sensor.



Front
H4M1148A

8Z10 CHECK G SENSOR.

Measure voltage between G sensor connector terminals.

Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 0.5 and 0.9 V when G sensor is inclined backwards to 90°?*

YES : Go to step 8Z11.

NO : Replace G sensor.

8Z11 CHECK POOR CONTACT IN CONNECTORS.

CHECK : *Is there poor contact in connector between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 8Z12.

8Z12 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.


NO : Go to step 8Z13.

8Z13 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.



9. Select Monitor Function Mode

Applicable cartridge of select monitor: No. 498346200

A: LIST OF FUNCTION MODE

1. F MODE (ROM ID, ANALOG DATA ARE DISPLAYED.)

Function code		Measuring items	Contents to be monitored	Scroll	Ref. to 4-4
Code	Abbreviation				
F00	ROM ID	ECM identification	ROM ID number of ECM is read and enabled communication state is displayed.	Possible	[T9B0]
F01	FR	FR wheel speed (mile/h)	Wheel speed detected by the FR ABS sensor is displayed in mile/h.	Possible	[T9C0]
F02	FL	FL wheel speed (mile/h)	Wheel speed detected by the FL ABS sensor is displayed in mile/h.	Possible	[T9D0]
F03	RR	RR wheel speed (mile/h)	Wheel speed detected by the RR ABS sensor is displayed in mile/h.	Possible	[T9E0]
F04	RL	RL wheel speed (mile/h)	Wheel speed detected by the RL ABS sensor is displayed in mile/h.	Possible	[T9F0]
F05	FR	FR wheel speed (km/h)	Wheel speed detected by the FR ABS sensor is displayed in km/h.	Possible	[T9C0]
F06	FL	FL wheel speed (km/h)	Wheel speed detected by the FL ABS sensor is displayed in km/h.	Possible	[T9D0]
F07	RR	RR wheel speed (km/h)	Wheel speed detected by the RR ABS sensor is displayed in km/h.	Possible	[T9E0]
F08	RL	RL wheel speed (km/h)	Wheel speed detected by the RL ABS sensor is displayed in km/h.	Possible	[T9F0]
F09	BLS	Stop light switch monitor	Stop light switch monitor voltage is displayed.	Possible	[T9G0]
F10	G-SENS	G sensor output voltage (V)	Refers to vehicle acceleration detecting by the analog G sensor. It appears on the select monitor display in volts.	Possible	[T9H0]

2. FA MODE (ON/OFF DATA ARE DISPLAYED.)


Function code		Measuring items	Contents to be monitored	Scroll	Ref. to 4-4
Code	Abbreviation				
FA0	B1	Stop light switch	LED 1 comes on with the switch on (with the brake pedal down).	Possible	[T9I0]
	VR	Valve relay signal	LED 2 comes on with the valve relay off.		
	MR	Motor relay signal	LED 3 comes on with the motor on.		
	AT	AT ABS signal	LED 4 comes on when ABS control is on.		
	AW	ABS warning light	LED 6 comes on when the warning light is on.		
	VM	Valve relay monitor	LED 1 comes on with the valve relay off.		
	MM	Motor relay monitor	LED 8 comes on when the motor relay is on.		
	CM	CCM signal	LED 9 comes on when ABS control is on.		

3. FB MODE (TROUBLE CODES ARE DISPLAYED.)

Function code		Measuring items	Contents to be monitored	Scroll	Ref. to 4-4
Code	Abbreviation				
FB1	D-ALL	History of trouble codes is displayed.	A maximum of 3 trouble codes are displayed in order of occurrence.	Possible	[T10B0]
	D-NEW		The most recent trouble code appears on the select monitor display.		
	D-MID		The second most recent trouble code appears on the select monitor display.		
	D-OLD		The third most recent trouble code appears on the select monitor display.		

NOTE:

- If a particular trouble code is not properly stored in memory (due to a drop in ABS/CM power supply, etc.) when a problem occurs, the trouble code, followed by a question mark "?", appears on the select monitor display. This shows it may be an unreliable reading.
- * a * refers to the troubles in order of occurrence (NEW, MID and OLD).



4. FC MODE (TROUBLE CODES ARE ERASED.)

Function code		Measuring items	Contents to be monitored	Scroll	Ref. to 4-4
Code	Abbreviation				
FC0	D-CLR	History of trouble codes is erased.	Function of clearing trouble code.	Possible	[T9J0]

5. FD MODE (ABS SEQUENCE CHECK MODE)

Function code		Measuring items	Contents to be monitored	Scroll	Ref. to 4-4
Code	Abbreviation				
FD1	A-CHK	ABS sequence control	Perform ABS sequence control by operating valve and pump motor sequentially.	Impossible	[W12D0]


6. FE MODE (FREEZE FRAME DATA)**NOTE:**

- Data stored at the time of trouble occurrence is shown on display.
- Each time trouble occurs, the latest information is stored in the freeze frame data in memory.


Function code		Measuring items	Contents to be monitored	Scroll	Ref. to 4-4
Code	Abbreviation				
FE1	FR	FR wheel speed (mile/h)	Wheel speed detected by the FR ABS sensor is displayed in mile/h.	Possible	[T9K0]
FE2	FL	FL wheel speed (mile/h)	Wheel speed detected by the FL ABS sensor is displayed in mile/h.	Possible	[T9L0]
FE3	RR	RR wheel speed (mile/h)	Wheel speed detected by the RR ABS sensor is displayed in mile/h.	Possible	[T9M0]
FE4	RL	RL wheel speed (mile/h)	Wheel speed detected by the RL ABS sensor is displayed in mile/h.	Possible	[T9N0]
FE5	FR	FR wheel speed (km/h)	Wheel speed detected by the FR ABS sensor is displayed in km/h.	Possible	[T9K0]
FE6	FL	FL wheel speed (km/h)	Wheel speed detected by the FL ABS sensor is displayed in km/h.	Possible	[T9L0]
FE7	RR	RR wheel speed (km/h)	Wheel speed detected by the RR ABS sensor is displayed in km/h.	Possible	[T9M0]
FE8	RL	RL wheel speed (km/h)	Wheel speed detected by the RL ABS sensor is displayed in km/h.	Possible	[T9N0]
FE13	POWER	ABSCM power supply voltage (V)	Power (in volts) supplied to ABSCM appears on the select monitor display.	Possible	[T9O0]
FE14	G-SENS	G sensor output voltage (V)	Refers to vehicle acceleration detected by the analog G sensor. It appears on the select monitor display in volts.	Possible	[T9P0]
FE15	MM	Motor relay monitor	LED 1 comes on when motor relay is on.	Possible	[T9Q0]
	B1	Stop light switch	LED 2 comes on with the stop light switch on (with the brake pedal depressed).		
	AT	AT ABS signal	LED 3 comes on when ABS control is on.		
	CM	CCM signal	LED 4 comes on when ABS control is on.		
	A0	ABS control	LED 5 comes on when ABS control is on.		
FE16	CODE	Trouble code	The most recent trouble code appears on select monitor display.	Possible	[T9R0]

1) When a trouble code is not stored in memory, activating the FE mode causes the initial value to appear on the select monitor display.

- FE1 — 4: 159 mile/h
- FE5 — 8: 255 km/h
- FE13: 16.84 V
- FE14: 5.00 V
- FE15: The MM, B1 and A0 LEDs are on.
The AT and CM LEDs are out.
- FE16: NO HISTORY OF OCCURED



2) If freeze frame data is not properly stored in memory (due to a drop in ABS/CM power supply, etc.), a trouble code, preceded by a question mark "?", appears on the select monitor display. This shows it may be an unreliable reading.



3) When a trouble code is detected in the FE mode, a question mark "?" appears continuously on the select monitor display until the freeze frame data is stored in memory.

1997 (F00)
ABS 4WD•AT

H4M1117

B: MODE F00
— ROM ID NUMBER (ROM) —

CONDITION:

Ignition switch ON

SPECIFIED DATA:

Presentation display

9B1 CHECK MESSAGE OF DISPLAY.

CHECK : Does display indicate message “Error 1”?

YES : Repair loose or disconnect connector, or discontinued circuit in data link circuit.

NO : Go to step **9B2**.

9B2 CHECK MESSAGE OF DISPLAY.

CHECK : Does display indicate message “Error 2”?

YES : Repair poor contact of select monitor cartridge, or installation of different type select monitor cartridge.

NO : Data link system is normal.

FR (F05)
30 km/h


B4M0922

C: MODE F01 AND F05
— FRONT RIGHT WHEEL SPEED SIGNAL (FR) —

- Compare speedometer with monitor indications.
- F01: FR wheel speed is indicated in mile per hour (mile/h).
- F05: FR wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that FR wheel speed is 30 km/h.




D: MODE F02 AND F06
— FRONT LEFT WHEEL SPEED SIGNAL (FL) —

- Compare speedometer with monitor indications.
- F02: FL wheel speed is indicated in mile per hour (mile/h).
- F06: FL wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that FL wheel speed is 29 km/h.



E: MODE F03 AND F07
— REAR RIGHT WHEEL SPEED SIGNAL (RR) —

- Compare speedometer with monitor indications.
- F03: RR wheel speed is indicated in mile per hour (mile/h).
- F07: RR wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that RR wheel speed is 10 km/h.

RL (F08)
50 km/h

B4M0925

BLS (F09)
5.00 V

B4M0926

G-SENS (F10)
2.30 V

B4M0927

F: MODE F04 AND F08

— REAR LEFT WHEEL SPEED SIGNAL (RL)

- Compare speedometer with monitor indications.
- F04: RL wheel speed is indicated in mile per hour (mile/h).
- F08: RL wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that RL wheel speed is 50 km/h.

G: MODE F09

— STOP LIGHT SWITCH MONITOR (BLS) —

- Stop light switch monitor voltage is displayed.

H: MODE F10

— G SENSOR OUTPUT VOLTAGE (G-SENS)

- Refers to vehicle acceleration detecting by the analog G sensor. It appears on the select monitor display in volts.

NOTE:

Only AWD model

LED No.	Signal name	Display
1	Stop light switch	B1
2	Valve relay signal	VR
3	Motor relay signal	MR
4	AT ABS signal	AT
5	—	—
6	ABS warning light	AW
7	Valve relay monitor	VM
8	Motor relay monitor	MM
9	CCM signal	CM
10	—	—

B1	VR	MR	AT	—
AW	VM	MM	CM	—
1	2	3	4	5
6	7	8	9	10

I: MODE FA0

— ON ↔ OFF SIGNAL —

Requirement for LED “ON”

- LED No. 1 Stop light switch is turned ON. (With brake pedal depressed.)
- LED No. 2 Valve relay is turned OFF.
- LED No. 3 Motor relay is turned ON.
- LED No. 4 ABS control operates.
- LED No. 6 ABS warning light is ON.
- LED No. 7 Valve relay is turned OFF.
- LED No. 8 Motor relay is turned ON.
- LED No. 9 ABS control operates.

MEMORY CLR ?
0 : YES 1 : NO

B4M0930

J: MODE FC0
— HISTORY OF TROUBLE CODES IS
ERASED (D-CLR) —

- Deletes the recorded trouble codes in ABS control module.

1) Press the function key [F] [C] [O] [ENT] in that order.

[F] [C] [O] [ENT]

B4M0931

2) System indicates as shown.

MEMORY CLR ?
0 : YES 1 : NO

B4M0930

3) Press the function key [0], to clear memories. The indication of * is added to screen.


MEMORY CLR ?
* 0 : YES 1 : NO

B4M0933

4) Press the function key [ENT]. System indicates as shown.
5) Turn ignition switch to OFF.

PLEASE
KEY OFF

B4M0934




K: MODE FE1 AND FE5 — FRONT RIGHT WHEEL SPEED SIGNAL (FR) —

- The wheel speed is indicated at the time of malfunction.
- FE1: FR wheel speed is indicated in mile per hour (mile/h).
- FE5: FR wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that FR wheel speed is 30 km/h.



L: MODE FE2 AND FE6 — FRONT LEFT WHEEL SPEED SIGNAL (FL) —

- The wheel speed is indicated at the time of malfunction.
- FE2: FL wheel speed is indicated in mile per hour (mile/h).
- FE6: FL wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that FL wheel speed is 29 km/h.

RR (FE7)
10 km/h

B4M0937

M: MODE FE3 AND FE7
— REAR RIGHT WHEEL SPEED SIGNAL (RR) —

- The wheel speed is indicated at the time of malfunction.
- FE3: RR wheel speed is indicated in mile per hour (mile/h).
- FE7: RR wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that RR wheel speed is 10 km/h.

RL (FE8)
50 km/h

B4M0938

N: MODE FE4 AND FE8
— REAR LEFT WHEEL SPEED SIGNAL (RL) —

- The wheel speed is indicated at the time of malfunction.
- FE4: RL wheel speed is indicated in mile per hour (mile/h).
- FE8: RL wheel speed is indicated in kilometer per hour (km/h).

NOTE:

The monitor as shown, indicates that RL wheel speed is 50 km/h.

POWER (FE13)
12.34 V

B4M0942

O: MODE FE13
— ABSCM POWER SUPPLY VOLTAGE (POWER) —

- ABSCM power supply voltage is indicated at the time of malfunction.

G-SENS (FE14)
2.27 V

B4M0939

LED No.	Signal name	Display
1	Motor relay monitor	MM
2	Stop light switch	B1
3	AT ABS signal	AT
4	CCM signal	CM
5	ABS signal	AO
6	—	—
7	—	—
8	—	—
9	—	—
10	—	—

MM	B1	AT	CM	AO
—	—	—	—	—
1	2	3	4	5
6	7	8	9	10

CODE 21 (FE16)
FR. SS HARD

H4M1151

P: MODE FE14
— G SENSOR OUTPUT VOLTAGE (G-SENS) —

- Refers to vehicle acceleration detected by the analog G sensor at the time of malfunction. It appears on the select monitor display in volts.

NOTE:

Only AWD model

Q: MODE FE15
— ON ↔ OFF SIGNAL —

- ON or OFF is indicated at the time of malfunction.
- Requirement for LED “ON”

LED No. 1 Motor relay is turned ON.

LED No. 2 Stop light switch is turned ON. (With brake pedal depressed.)

LED No. 3 ABS control operates.

LED No. 4 ABS control operates.

LED No. 5 ABS control operates.

R: MODE FE16
— TROUBLE CODE (CODE) —


- When freeze frame data is stored in memory, trouble code appears on monitor.

NOTE:

The monitor as shown, indicates trouble code 21.

10. Diagnostics Chart with Select Monitor

A: BASIC DIAGNOSTIC CHART



B4M1076A

NOTE:

To check harness for broken wires or short circuits, shake it while holding it or the connector.

B: LIST OF TROUBLE CODE

Code	Display screen (FB1)	Contents of diagnosis	Ref. to 4-4
—	ERROR 3 (1)	Select monitor communication failure	[T10C0]
11	NO TROUBLE	Although no trouble appears on the select monitor display, the ABS warning light remains on	[T10D0]
21	FR. SS HARD	Open circuit or input voltage too high of FR sensor	[T10E0]
22	FR. SS SOFT	Abnormal ABS sensor signal of FR sensor	[T10I0]
23	FL. SS HARD	Open circuit or input voltage too high of FL sensor	[T10F0]
24	FL. SS SOFT	Abnormal ABS sensor signal of FL sensor	[T10J0]
25	RR. SS HARD	Open circuit or input voltage too high of RR sensor	[T10G0]
26	RR. SS SOFT	Abnormal ABS sensor signal of RR sensor	[T10K0]
27	RL. SS HARD	Open circuit or input voltage too high of RL sensor	[T10H0]
28	RL. SS SOFT	Abnormal ABS sensor signal of RL sensor	[T10L0]
29	EITHER. SS SOFT	Abnormal ABS sensor signal (any one of four)	[T10M0]
31	FR. EV VALVE	Abnormal FR inlet valve	[T10N0]
32	FR. AV VALVE	Abnormal FR outlet valve	[T10R0]
33	FL. EV VALVE	Abnormal FL inlet valve	[T10O0]
34	FL. AV VALVE	Abnormal FL outlet valve	[T10S0]
35	RR. EV VALVE	Abnormal RR inlet valve	[T10P0]
36	RR. AV VALVE	Abnormal RR outlet valve	[T10T0]
37	RL. EV VALVE	Abnormal RL inlet valve	[T10Q0]
38	RL. AV VALVE	Abnormal RL outlet valve	[T10U0]
41	ECU	Abnormal ABSCM	[T10V0]
42	LOW VOLTAGE	Source voltage is low	[T10W0]
44	CCM LINE	A combination of AT control abnormals (ABS not in control)	[T10X0]
	CCM OPEN	A combination of AT control abnormals (ABS in control)	[T10Y0]
46	GS POWER OVER	G sensor line voltage too high	[T10Z0]
	GS POWER LOW	G sensor line voltage too low	[T10AA0]
51	V. RELAY	Abnormal valve relay	[T10AB0]
	V. RELAY ON	Valve relay ON failure	[T10AC0]
52	M. RELAY OPEN	Open circuit of motor relay	[T10AD0]
	M. RELAY ON	Motor relay ON failure	[T10AE0]
	MOTOR	Abnormal motor	[T10AF0]
54	BLS	Abnormal stop light switch	[T10AG0]
56	G SENSOR LINE	Open or short circuit of G sensor	[T10AH0]
	G SENSOR +B	Battery short of G sensor	[T10AI0]
	G SENSOR H μ	Abnormal G sensor high μ output	[T10AJ0]
	G SENSOR STICK	G sensor output is stuck	[T10AK0]

NOTE:

High μ means high friction coefficient against road surface.

* * * * * * * * * * * * * * * *

ERROR 3

B4M0943

C: ERROR 3 (1) — SELECT MONITOR COMMUNICATION FAILURE —





DIAGNOSIS:

- Faulty harness connector


TROUBLE SYMPTOM

- ABS warning light remains on.
- ERROR 3 or 1 appears on the select monitor display.

WIRING DIAGRAM:



H4M1116



10C1 CHECK GENERATOR.

- 1) Start the engine.
- 2) Idle the engine.
- 3) Measure voltage between generator and chassis ground.

Terminal

Generator B terminal (+) — Chassis ground (-):

CHECK	: <i>Is the voltage between 10 and 15 V?</i>
YES	: Go to step 10C2.
NO	: Repair generator.

10C2 CHECK BATTERY TERMINAL.

Turn ignition switch to OFF.

CHECK	: <i>Is there poor contact at battery terminal?</i>
YES	: Repair battery terminal.
NO	: Go to step 10C3.

10C3 CHECK COMMUNICATION OF SELECT MONITOR.


Using the select monitor, check whether communication to other system (such as engine, AT, etc.) can be executed normally.

CHECK	: <i>Are the name and year of the system displayed on the select monitor?</i>
YES	: Go to step 10C4.
NO	: Repair select monitor communication cable and connector.


10C4 CHECK INSTALLATION OF ABSCM CONNECTOR.

Turn ignition switch to OFF.

CHECK	: <i>Is ABSCM connector inserted into ABSCM until the clamp locks onto it?</i>
YES	: Go to step 10C5.
NO	: Insert ABSCM connector into ABSCM until the clamp locks onto it.


**10C5 CHECK POWER SUPPLY OF ABSCM.**

- 1) Disconnect connector from ABSCM.
- 2) Start engine.
- 3) Idle the engine.
- 4) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 28 (+) — Chassis ground (-):****CHECK : Is the voltage between 10 and 15 V?****YES : Go to step 10C6.****NO : Repair ABSCM power supply circuit.****10C6 CHECK GROUND CIRCUIT OF ABSCM.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 1 — Chassis ground:****(F49) No. 55 — Chassis ground:****CHECK : Is the resistance less than 0.5 Ω?****YES : Repair harness/connector between ABSCM and select monitor.****NO : Go to step 10C7.**



10C7

**CHECK HARNESS/CONNECTOR
BETWEEN ABSCM AND DATA LINK.**

- 1) Turn ignition switch OFF.
- 2) Measure resistance between ABSCM connector and data link connector.

Connector & terminal

(F49) No. 11 — (B78) No. 3:

(F49) No. 38 — (B78) No. 2:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Repair harness and connector between ABSCM and data link connector.

NO : Go to step 10C8.

10C8

**CHECK POOR CONTACT IN CONNEC-
TORS.**

CHECK : *Is there poor contact in connectors between ABSCM and data link? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Replace ABSCM.

D•ALL 11 (FB1)
NO TROUBLE

B4M0944

D: NO TROUBLE

— ALTHOUGH NO TROUBLE APPEARS ON THE SELECT MONITOR DISPLAY, THE ABS WARNING LIGHT REMAINS ON —

DIAGNOSIS:


- ABS warning light circuit is shorted.

TRouble SYMPTOM:

- ABS warning light remains on.
- NO TROUBLE displayed on the select monitor.

NOTE:

When the ABS warning light is OFF and "NO TROUBLE" is displayed on the select monitor, the system is in normal condition.

WIRING DIAGRAM:

H4M1104

10D1	CHECK GROUND SHORT OF HARNESS.
-------------	---------------------------------------

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Disconnect connector (F50) from relay box.
- 4) Turn ignition switch to ON.

 : **Does the ABS warning light remain OFF?**

 : Go to step **10D2**.

 : Repair harness between ABSCM, relay box ABS warning light.

10D2	CHECK GROUND SHORT OF RELAY BOX.
-------------	---

- 1) Turn ignition switch to OFF.
- 2) Connect connector (F50) to relay box.
- 3) Disconnect connector (ABS1) from hydraulic unit.
- 4) Remove valve relay from relay box.
- 5) Turn ignition switch to ON.

 : **Does the ABS warning light remain OFF?**

 : Replace ABSCM.

 : Replace relay box.

D•NEW 21 (FB1)
FR. SS HARD

B4M0945

E: TROUBLE CODE 21 FR. SS HARD
— ABNORMAL FRONT RH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

D•NEW 23 (FB1)
FL. SS HARD

B4M0946

F: TROUBLE CODE 23 FL. SS HARD
— ABNORMAL FRONT LH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

D•NEW 25 (FB1)
RR. SS HARD

B4M0947

G: TROUBLE CODE 25 RR. SS HARD
— ABNORMAL REAR RH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

D•NEW 27 (FB1)
RL. SS HARD

B4M0948


H: TROUBLE CODE 27 RL. SS HARD
— ABNORMAL REAR LH ABS SENSOR
(OPEN CIRCUIT OR INPUT VOLTAGE TOO
HIGH) —

DIAGNOSIS:

- Faulty ABS sensor (Broken wire, input voltage too high)
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:

H4M1106

BRAKES

FR (F05)
30 km/h

B4M0922

10H1	CHECK OUTPUT OF ABS SENSOR USING SELECT MONITOR.
------	---

Read the ABS sensor output corresponding to the faulty system in the select monitor function mode.

NOTE:

The select monitor display shows that the front right wheel is rotating at 30 km/h.

CHECK : *Does the speed indicated on the display change in response to the speedometer reading during acceleration/deceleration when the steering wheel is in the straight-ahead position?*

YES : Go to step 10H2.

NO : Go to step 10H9.

10H2	CHECK INSTALLATION OF ABS SENSOR.
------	--

Tightening torque:

$32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft-lb}$)

CHECK : *Are the ABS sensor installation bolts tightened securely?*

YES : Go to step 10H3.

NO : Tighten ABS sensor installation bolts securely.

10H3	CHECK INSTALLATION OF TONE WHEEL.
------	--


Tightening torque:

$13 \pm 3 \text{ N}\cdot\text{m}$ ($1.3 \pm 0.3 \text{ kg}\cdot\text{m}$, $9 \pm 2.2 \text{ ft-lb}$)


CHECK : *Are the tone wheel installation bolts tightened securely?*

YES : Go to step 10H4.

NO : Tighten tone wheel installation bolts securely.



G4M0700



G4M0701

10H4 CHECK ABS SENSOR GAP.

Measure tone wheel-to-pole piece gap over entire perimeter of the wheel.

CHECK : *Is the gap within the specifications shown in the following table?*

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)

YES : Go to step 10H5.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

10H5 CHECK HUB RUNOUT.

Measure hub runout.

CHECK : *Is the runout less than 0.05 mm (0.0020 in)?*

YES : Go to step 10H6.

NO : Repair hub.

10H6 CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connectors between ABSCM and ABS sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10H7.

10H7 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10H8.

10H8	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--


CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

NOTE:

Check harness and connectors between ABSCM and ABS sensor.



B4M0806

10H9	CHECK RESISTANCE OF ABS SENSOR.
-------------	--

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABS sensor.
- 3) Measure resistance of ABS sensor connector terminals.

Terminal

Front RH No. 1 — No. 2:

Front LH No. 1 — No. 2:


Rear RH No. 1 — No. 2:

Rear LH No. 1 — No. 2:

CHECK : Is the resistance between 0.8 and 1.2 kΩ?

YES : Go to step 10H10.

NO : Replace ABS sensor.



B4M0807

10H10	CHECK BATTERY SHORT OF ABS SEN- SOR.
--------------	---

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between ABS sensor and chassis ground.

Terminal

Front RH No. 1 (+) — Chassis ground (-):

Front LH No. 1 (+) — Chassis ground (-):


Rear RH No. 1 (+) — Chassis ground (-):

Rear LH No. 1 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10H11.


NO : Replace ABS sensor.



10H11

CHECK BATTERY SHORT OF ABS SENSOR.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABS sensor and chassis ground.


Terminal**Front RH No. 1 (+) — Chassis ground (-):****Front LH No. 1 (+) — Chassis ground (-):****Rear RH No. 1 (+) — Chassis ground (-):****Rear LH No. 1 (+) — Chassis ground (-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 10H12.****NO : Replace ABS sensor.**

10H12

CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND ABS SENSOR.

- 1) Connect connector to ABS sensor.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal**Trouble code 21 / (F49) No. 14 — No. 15:****Trouble code 23 / (F49) No. 49 — No. 19:****Trouble code 25 / (F49) No. 18 — No. 46:****Trouble code 27 / (F49) No. 16 — No. 17:****CHECK : Is the resistance between 0.8 and 1.2 kΩ?****YES : Go to step 10H13.****NO : Repair harness/connector between ABSCM and ABS sensor.**



10H13 CHECK BATTERY SHORT OF HARNESS.

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 21 / (F49) No. 14 — Chassis ground:

Trouble code 23 / (F49) No. 49 — Chassis ground:


Trouble code 25 / (F49) No. 18 — Chassis ground:

Trouble code 27 / (F49) No. 16 — Chassis ground:

CHECK : Is the voltage less than 1 V?

YES : Go to step 10H14.

NO : Repair harness between ABSCM and ABS sensor.



10H14 CHECK BATTERY SHORT OF HARNESS.

1) Turn ignition switch to ON.

2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 21 / (F49) No. 14 — Chassis ground:

Trouble code 23 / (F49) No. 49 — Chassis ground:

Trouble code 25 / (F49) No. 18 — Chassis ground:

Trouble code 27 / (F49) No. 16 — Chassis ground:

CHECK : Is the voltage less than 1 V?

YES : Go to step 10H15.

NO : Repair harness between ABSCM and ABS sensor.

10H15 CHECK INSTALLATION OF ABS SEN- SOR.

CHECK : Tightening torque:

$32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft-lb}$)

Are the ABS sensor installation bolts tightened securely?

YES : Go to step 10H16.

NO : Tighten ABS sensor installation bolts securely.

10H16	CHECK INSTALLATION OF TONE WHEEL.
--------------	--

CHECK

: *Tightening torque:*

$13\pm3\text{ N}\cdot\text{m}$ ($1.3\pm0.3\text{ kg}\cdot\text{m}$, $9\pm2.2\text{ ft-lb}$)


Are the tone wheel installation bolts tightened securely?

YES

: Go to step **10H17**.

NO

: Tighten tone wheel installation bolts securely.




10H17	CHECK ABS SENSOR GAP.
--------------	------------------------------

Measure tone wheel-to-pole piece gap over entire perimeter of the wheel.

CHECK

Is the gap within the specifications shown in the following table?

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)



YES : Go to step **10H18**.

NO : Adjust the gap.

NOTE:

Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.

10H18	CHECK HUB RUNOUT.
--------------	--------------------------

Measure hub runout.

CHECK

Is the runout less than 0.05 mm (0.0020 in)?

YES

: Go to step **10H19**.

NO

: Repair hub.

10H19	CHECK POOR CONTACT IN CONNECTORS.
--------------	--

Turn ignition switch to OFF.

CHECK

Is there poor contact in connectors between ABS CM and ABS sensor? <Ref. to FOREWORD [T3C1].>

YES

: Repair connector.

NO

: Go to step **10H20**.

10H20	CHECK ABSCM.
--------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10H21**.

10H21	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
--------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

NOTE:

Check harness and connectors between ABSCM and ABS sensor.

D•NEW 22 (FB1)
FR. SS SOFT

B4M0812

I: TROUBLE CODE 22 FR. SS SOFT
— ABNORMAL FRONT RH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

D•NEW 24 (FB1)
FL. SS SOFT

B4M0949

J: TROUBLE CODE 24 FL. SS SOFT
— ABNORMAL FRONT LH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

D•NEW 26 (FB1)
RR. SS SOFT

B4M0950

K: TROUBLE CODE 26 RR. SS SOFT
— ABNORMAL REAR RH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

D•NEW 28 (FB1)
RL. SS SOFT

B4M0951


L: TROUBLE CODE 28 RL. SS SOFT
— ABNORMAL REAR LH ABS SENSOR
(ABNORMAL ABS SENSOR SIGNAL) —

DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty harness/connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:

FR (F05)
30 km/h

B4M0922

10L1

CHECK OUTPUT OF ABS SENSOR USING SELECT MONITOR.

Read the ABS sensor output corresponding to the faulty system in the select monitor function mode.

NOTE:

The select monitor display shows that the front right wheel is rotating at 30 km/h.

 CHECK

Does the speed indicated on the display change in response to the speedometer reading during acceleration/deceleration when the steering wheel is in the straight-ahead position?

 YES

: Go to step **10L2**.

 NO

: Go to step **10L8**.

10L2

CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

 CHECK

Is there poor contact in connectors between ABSCM and ABS sensor?

 YES

: Repair connector.

 NO

: Go to step **10L3**.

10L3

CHECK SOURCES OF SIGNAL NOISE.

 CHECK

Is the car telephone or the wireless transmitter properly installed?

 YES

: Go to step **10L4**.

 NO

: Properly install the car telephone or the wireless transmitter.

10L4

CHECK SOURCES OF SIGNAL NOISE.

 CHECK


Are noise sources (such as an antenna) installed near the sensor harness?

 YES

: Install the noise sources apart from the sensor harness.

 NO

: Go to step **10L5**.



10L5

CHECK SHIELD CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Measure resistance between shield connector and chassis ground.

Connector & terminal

Trouble code 22 / (B100) No. 6 — Chassis ground:

Trouble code 24 / (B100) No. 2 — Chassis ground:

Trouble code 26 / (F55) No. 6 — Chassis ground:

Trouble code 28 / (F55) No. 1 — Chassis ground:

CHECK : Is the resistance less than 0.5Ω ?

YES : Go to step 10L6.

NO : Repair shield harness.

10L6

CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 10L7.

10L7

CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary noise interference.

10L8

CHECK INSTALLATION OF ABS SENSOR.

Tightening torque:

$32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft}\cdot\text{lb}$)

CHECK : Are the ABS sensor installation bolts tightened securely?

YES : Go to step 10L9.

NO : Tighten ABS sensor installation bolts securely.


10L9

CHECK INSTALLATION OF TONE WHEEL.**Tightening torque:** **$13\pm3\text{ N}\cdot\text{m}$ ($1.3\pm0.3\text{ kg}\cdot\text{m}$, $9\pm2.2\text{ ft}\cdot\text{lb}$)**

CHECK : Are the tone wheel installation bolts tightened securely?

YES : Go to step **10L10**.

NO : Tighten tone wheel installation bolts securely.



G4M0700


10L10

CHECK ABS SENSOR GAP.

Measure tone wheel to pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)



G4M0701


10L11

CHECK OSCILLOSCOPE.

CHECK : Is an oscilloscope available?

YES : Go to step **10L12**.


NO : Go to step **10L13**.


10L12 CHECK ABS SENSOR SIGNAL.


- 1) Turn ignition switch OFF.
- 2) Raise all four wheels of ground.
- 3) Disconnect connector from ABS control module.
- 4) Remove band.
- 5) Remove cable clamp cover.
- 6) Remove screws securing connector cover.

CAUTION:

Do not allow harness to catch on adjacent parts during installation.




- 7) Remove connector cover.


NOTE:

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

- 8) Connect connector to ABS control module.
- 9) Connect the oscilloscope to the ABS control module connector in accordance with trouble code.
- 10) Turn ignition switch ON.



11) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

Connector & terminal

Trouble code 22 / (F49) No. 14 (+) — No. 15 (-):

Trouble code 24 / (F49) No. 49 (+) — No. 19 (-):

Trouble code 26 / (F49) No. 18 (+) — No. 46 (-):

Trouble code 28 / (F49) No. 16 (+) — No. 17 (-):

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : Is oscilloscope pattern smooth, as shown in figure?

YES : Go to step 10L16.

NO : Go to step 10L13.

10L13 CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL.

Remove disc rotor or drum from hub in accordance with trouble code.

CHECK : Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to step 10L14.

10L14 CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL.

CHECK : Are there broken or damaged teeth in the ABS sensor pole piece or the tone wheel?

YES : Replace ABS sensor or tone wheel.

NO : Go to step 10L15.


10L15 CHECK HUB RUNOUT.

Measure hub runout.

CHECK : Is the runout less than 0.05 mm (0.0020 in)?

YES : Go to step 10L16.

NO : Repair hub.



B4M0806

10L16 CHECK RESISTANCE OF ABS SENSOR.


- 1) Turn ignition switch OFF.
- 2) Disconnect connector from ABS sensor.
- 3) Measure resistance between ABS sensor connector terminals.

Terminal**Front RH No. 1 — No. 2:****Front LH No. 1 — No. 2:****Rear RH No. 1 — No. 2:****Rear LH No. 1 — No. 2:**

CHECK : Is the resistance between 0.8 and 1.2 kΩ?

YES : Go to step **10L17**.

NO : Replace ABS sensor.



B4M0818D

10L17 CHECK GROUND SHORT OF ABS SENSOR.


Measure resistance between ABS sensor and chassis ground.

Terminal**Front RH No. 1 — Chassis ground:****Front LH No. 1 — Chassis ground:****Rear RH No. 1 — Chassis ground:****Rear LH No. 1 — Chassis ground:**

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step **10L18**.

NO : Replace ABS sensor.



10L18

**CHECK HARNESS/CONNECTOR
BETWEEN ABSCM AND ABS SENSOR.**

- 1) Connect connector to ABS sensor.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance at ABSCM connector terminals.

Connector & terminal

Trouble code 22 / (F49) No. 14 — No. 15:

Trouble code 24 / (F49) No. 49 — No. 69:


Trouble code 26 / (F49) No. 18 — No. 46:

Trouble code 28 / (F49) No. 16 — No. 17:

(CHECK) : Is the resistance between 0.8 and 1.2 kΩ?

(YES) : Go to step 10L19.

(NO) : Repair harness/connector between ABSCM and ABS sensor.



10L19

CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 22 / (F49) No. 14 — Chassis ground:

Trouble code 24 / (F49) No. 49 — Chassis ground:


Trouble code 26 / (F49) No. 18 — Chassis ground:

Trouble code 28 / (F49) No. 16 — Chassis ground:

(CHECK) : Is the resistance more than 1 MΩ?

(YES) : Go to step 10L20.

(NO) : Repair harness between ABSCM and ABS sensor.



10L20

CHECK GROUND CIRCUIT OF ABSCM.

Measure resistance between ABSCM and chassis ground.

Connector & terminal

(F49) No. 1 — Chassis ground:

(F49) No. 55 — Chassis ground:

(CHECK) : Is the resistance less than 0.5 Ω?

(YES) : Go to step 10L21.

(NO) : Repair ABSCM ground harness.

BRAKES

10L21 CHECK POOR CONTACT IN CONNECTORS.

CHECK : *Is there poor contact in connectors between ABS CM and ABS sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10L22.

10L22 CHECK SOURCES OF SIGNAL NOISE.

CHECK : *Is the car telephone or the wireless transmitter properly installed?*

YES : Go to step 10L23.


NO : Properly install the car telephone or the wireless transmitter.

10L23 CHECK SOURCES OF SIGNAL NOISE.

CHECK : *Are noise sources (such as an antenna) installed near the sensor harness?*

YES : Install the noise sources apart from the sensor harness.

NO : Go to step 10L24.



10L24 CHECK SHIELD CIRCUIT.

- 1) Connect all connectors.
- 2) Measure resistance between shield connector and chassis ground.

Connector & terminal

Trouble code 22 / (B100) No. 6 — Chassis ground:

Trouble code 24 / (B100) No. 2 — Chassis ground:

Trouble code 26 / (F55) No. 6 — Chassis ground:

Trouble code 28 / (F55) No. 1 — Chassis ground:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 10L25.

NO : Repair shield harness.

10L25	CHECK ABSCM.
--------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10L26**.

10L26	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
--------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary noise interference.

D•NEW 29 (FB1)
EITHER. SS SOFT

B4M0952

**M: TROUBLE CODE 29 EITHER. SS SOFT
— ABNORMAL ABS SENSOR SIGNAL (ANY
ONE OF FOUR) —**


DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty tone wheel
- Wheels turning freely for a long time

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



10M1	CHECK IF THE WHEELS HAVE TURNED FREELY FOR A LONG TIME.
-------------	--

CHECK : *Check if the wheels have been turned freely for more than one minute, such as when the vehicle is jacked-up, under full-lock cornering or when tire is not in contact with road surface.*

YES : The ABS is normal. Erase the trouble code.

NOTE:

When the wheels turn freely for a long time, such as when the vehicle is towed or jacked-up, or when steering wheel is continuously turned all the way, this trouble code may sometimes occur.

NO : Go to step **10M2**.

10M2	CHECK TIRE SPECIFICATIONS.
-------------	-----------------------------------

Turn ignition switch to OFF.

CHECK : *Are the tire specifications correct?*

YES : Go to step **10M3**.

NO : Replace tire.

10M3	CHECK WEAR OF TIRE.
-------------	----------------------------

CHECK : *Is the tire worn excessively?*

YES : Replace tire.

NO : Go to step **10M4**.

10M4	CHECK TIRE PRESSURE.
-------------	-----------------------------

CHECK : *Is the tire pressure correct?*

YES : Go to step **10M5**.

NO : Adjust tire pressure.

10M5	CHECK INSTALLATION OF ABS SENSOR.
-------------	--

Tightening torque:


$32\pm10 \text{ N}\cdot\text{m}$ ($3.3\pm1.0 \text{ kg}\cdot\text{m}$, $24\pm7 \text{ ft-lb}$)

CHECK : *Are the ABS sensor installation bolts tightened securely?*

YES : Go to step **10M6**.

NO : Tighten ABS sensor installation bolts securely.

BRAKES

10M6 **CHECK INSTALLATION OF TONE WHEEL.****Tightening torque:** **13 ± 3 N·m (1.3±0.3 kg·m, 9±2.2 ft·lb)****CHECK** : Are the tone wheel installation bolts tightened securely?**YES** : Go to step **10M7**.**NO** : Tighten tone wheel installation bolts securely.


G4M0700

10M7 **CHECK ABS SENSOR GAP.**

Measure tone wheel to pole piece gap over entire perimeter of the wheel.

CHECK : Is the gap within the specifications shown in the following table?

Specifications	Front wheel	Rear wheel
	0.9 — 1.4 mm (0.035 — 0.055 in)	0.7 — 1.2 mm (0.028 — 0.047 in)




G4M0701

YES : Go to step **10M8**.**NO** : Adjust the gap.**NOTE:**

Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.


10M8 **CHECK OSCILLOSCOPE.****CHECK** : Is an oscilloscope available?**YES** : Go to step **10M9**.**NO** : Go to step **10M10**.

**10M9 CHECK ABS SENSOR SIGNAL.**


- 1) Turn ignition switch OFF.
- 2) Raise all four wheels of ground.
- 3) Disconnect connector from ABS control module.
- 4) Remove band.
- 5) Remove cable clamp cover.
- 6) Remove screws securing connector cover.

CAUTION:

Do not allow harness to catch on adjacent parts during installation.




- 7) Remove connector cover.

**NOTE:**

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

- 8) Connect connector to ABS control module.
- 9) Connect the oscilloscope to the ABS control module connector.
- 10) Turn ignition switch ON.



11) Rotate wheels and measure voltage at specified frequency.

NOTE:

When this inspection is completed, the ABS control module sometimes stores the trouble code 29.

Connector & terminal

(F49) No. 14 (+) — No. 15 (-) (Front RH):

(F49) No. 49 (+) — No. 19 (-) (Front LH):

(F49) No. 18 (+) — No. 46 (-) (Rear RH):

(F49) No. 16 (+) — No. 17 (-) (Rear LH):

Specified voltage: 0.12 — 1 V (When it is 20 Hz.)

CHECK : Is oscilloscope pattern smooth, as shown in figure?

YES : Go to step 10M13.

NO : Go to step 10M10.

10M10 CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL.

Remove disc rotor from hub.

CHECK : Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?

YES : Thoroughly remove dirt or other foreign matter.

NO : Go to step 10M11.

10M11 CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL.

CHECK : Are there broken or damaged teeth in the ABS sensor pole piece or the tone wheel?

YES : Replace ABS sensor or tone wheel.

NO : Go to step 10M12.

10M12 CHECK HUB RUNOUT.

Measure hub runout.

CHECK : Is the runout less than 0.05 mm (0.0020 in)?

YES : Go to step 10M13.

NO : Repair hub.

10M13	CHECK ABSCM.
--------------	---------------------

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10M14**.

10M14	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
--------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 31 (FB1)
FR. EV VALVE

B4M0953

D•NEW 33 (FB1)
FL. EV VALVE

B4M0954

D•NEW 35 (FB1)
RR. EV VALVE

B4M0955

D•NEW 37 (FB1)
RL. EV VALVE

B4M0956

N: TROUBLE CODE 31 FR. EV VALVE
— ABNORMAL FRONT RH INLET SOLENOID
VALVE —

O: TROUBLE CODE 33 FL. EV VALVE
— ABNORMAL FRONT LH INLET SOLENOID
VALVE —

P: TROUBLE CODE 35 RR. EV VALVE
— ABNORMAL REAR RH INLET SOLENOID
VALVE —


Q: TROUBLE CODE 37 RL. EV VALVE
— ABNORMAL REAR LH INLET SOLENOID
VALVE —

DIAGNOSIS:


- Faulty harness/connector
- Faulty inlet solenoid valve in hydraulic unit

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:

H4M1115

**10Q1 CHECK FREEZE FRAME DATA.**

Press [F], [E], [1] and [5] on the select monitor.

CHECK : *Is the select monitor LED 5 off? Was the ABS inactive when the problem occurred?*

YES : Go to step 10Q2.

NO : Go to step 10Q15.

10Q2 CHECK THE CONDITION WHEN THE TROUBLE OCCURRED.

Ask the vehicle owner about driving conditions when the trouble occurred. Attempt to duplicate the conditions.

CHECK : *Is the trouble immediately apparent?*

YES : Go to step 10Q3.


NO : Go to step 10Q15.

10Q3 CHECK THE CONDITION WHEN THE TROUBLE OCCURRED.

CHECK : *Did the trouble occur immediately after engine starting or during standing starts?*

YES : Go to step 10Q11.

NO : Go to step 10Q4.

**10Q4 CHECK RESISTANCE OF SOLENOID VALVE.**

1) Turn ignition switch to OFF.

2) Disconnect two connectors (ABS1, F9) from hydraulic unit.

3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 — (ABS2) No. 2:

Trouble code 33 / (ABS5) No. 1 — (ABS2) No. 2:


Trouble code 35 / (ABS5) No. 2 — (ABS2) No. 2:

Trouble code 37 / (ABS5) No. 3 — (ABS2) No. 2:

CHECK : *Is the resistance between 7.8 and 9.2 Ω?*

YES : Go to step 10Q5.

NO : Replace hydraulic unit.



10Q5

CHECK GROUND SHORT OF SOLENOID VALVE.

Measure resistance between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 — Chassis ground:

Trouble code 33 / (ABS5) No. 1 — Chassis ground:


Trouble code 35 / (ABS5) No. 2 — Chassis ground:

Trouble code 37 / (ABS5) No. 3 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 10Q6.

NO : Replace hydraulic unit.



10Q6

CHECK GROUND SHORT OF HARNESS.

1) Disconnect connector from ABSCM.

2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 — Chassis ground:

Trouble code 33 / (F49) No. 24 — Chassis ground:


Trouble code 35 / (F49) No. 23 — Chassis ground:

Trouble code 37 / (F49) No. 31 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 10Q7.

NO : Repair harness between ABSCM and hydraulic unit.



10Q7

**CHECK HARNESS/CONNECTOR
BETWEEN ABSCM AND HYDRAULIC
UNIT.**

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal

Trouble code 31 / (F49) No. 30 — No. 1:

Trouble code 33 / (F49) No. 24 — No. 1:

Trouble code 35 / (F49) No. 23 — No. 1:

Trouble code 37 / (F49) No. 31 — No. 1:

CHECK : *Is the resistance between 8.3 and 9.7 Ω?*

YES : Go to step 10Q8.

NO : Repair harness/connector between ABSCM and hydraulic unit.

10Q8

**CHECK POOR CONTACT IN CONNEC-
TORS.**

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10Q9.

10Q9

CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10Q10.


10Q10

**CHECK ANY OTHER TROUBLE CODES
APPEARANCE.**

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.



10Q11

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Disconnect connector from ABSCM.
- 4) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 (+) — Chassis ground (-):

Trouble code 33 / (ABS5) No. 1 (+) — Chassis ground (-):


Trouble code 35 / (ABS5) No. 2 (+) — Chassis ground (-):

Trouble code 37 / (ABS5) No. 3 (+) — Chassis ground (-):

: Is the voltage less than 1 V?

: Go to step 10Q12.

: Replace hydraulic unit.



10Q12

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 (+) — Chassis ground (-):

Trouble code 33 / (ABS5) No. 1 (+) — Chassis ground (-):


Trouble code 35 / (ABS5) No. 2 (+) — Chassis ground (-):

Trouble code 37 / (ABS5) No. 3 (+) — Chassis ground (-):

: Is the voltage less than 1 V?

: Go to step 10Q13.

: Replace hydraulic unit.



10Q13 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 (+) — Chassis ground (-):

Trouble code 33 / (F49) No. 24 (+) — Chassis ground (-):


Trouble code 35 / (F49) No. 23 (+) — Chassis ground (-):

Trouble code 37 / (F49) No. 31 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10Q14.

NO : Repair harness between ABSCM and hydraulic unit.



10Q14 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 (+) — Chassis ground (-):

Trouble code 33 / (F49) No. 24 (+) — Chassis ground (-):


Trouble code 35 / (F49) No. 23 (+) — Chassis ground (-):

Trouble code 37 / (F49) No. 31 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Replace ABSCM.

NO : Repair harness between ABSCM and hydraulic unit.


10Q15 **CHECK RESISTANCE OF SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 — (ABS2) No. 2:

Trouble code 33 / (ABS5) No. 1 — (ABS2) No. 2:


Trouble code 35 / (ABS5) No. 2 — (ABS2) No. 2:

Trouble code 37 / (ABS5) No. 3 — (ABS2) No. 2:

CHECK : *Is the resistance between 7.8 and 9.2 Ω ?*

YES : Go to step **10Q16**.

NO : Replace hydraulic unit.


10Q16 **CHECK GROUND SHORT OF SOLENOID VALVE.**

Measure resistance between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 — Chassis ground:

Trouble code 33 / (ABS5) No. 1 — Chassis ground:


Trouble code 35 / (ABS5) No. 2 — Chassis ground:

Trouble code 37 / (ABS5) No. 3 — Chassis ground:

CHECK : *Is the resistance more than 1 $M\Omega$?*

YES : Go to step **10Q17**.

NO : Replace hydraulic unit.



10Q17

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 (+) — Chassis ground (-):

Trouble code 33 / (ABS5) No. 1 (+) — Chassis ground (-):


Trouble code 35 / (ABS5) No. 2 (+) — Chassis ground (-):

Trouble code 37 / (ABS5) No. 3 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10Q18.

NO : Replace hydraulic unit.



10Q18

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 31 / (ABS5) No. 4 (+) — Chassis ground (-):

Trouble code 33 / (ABS5) No. 1 (+) — Chassis ground (-):


Trouble code 35 / (ABS5) No. 2 (+) — Chassis ground (-):

Trouble code 37 / (ABS5) No. 3 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10Q19.

NO : Replace hydraulic unit.



10Q19 | CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 (+) — Chassis ground (-):

Trouble code 33 / (F49) No. 24 (+) — Chassis ground (-):

Trouble code 35 / (F49) No. 23 (+) — Chassis ground (-):

Trouble code 37 / (F49) No. 31 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **10Q20**.

NO : Repair harness between ABSCM and hydraulic unit.

10Q20 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 (+) — Chassis ground (-):

Trouble code 33 / (F49) No. 24 (+) — Chassis ground (−):


Trouble code 35 / (F49) No. 23 (+) — Chassis ground (-):

Trouble code 37 / (F49) No. 31 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10Q21.

NO : Repair harness between ABS/CM and hydraulic unit.



10Q21 CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 31 / (F49) No. 30 — Chassis ground:

Trouble code 33 / (F49) No. 24 — Chassis ground:


Trouble code 35 / (F49) No. 23 — Chassis ground:

Trouble code 37 / (F49) No. 31 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 10Q22.

NO : Repair harness between ABSCM and hydraulic unit.



10Q22 CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal

Trouble code 31 / (F49) No. 30 — No. 1:

Trouble code 33 / (F49) No. 24 — No. 1:

Trouble code 35 / (F49) No. 23 — No. 1:

Trouble code 37 / (F49) No. 31 — No. 1:

CHECK : Is the resistance between 8.3 and 9.7Ω ?

YES : Go to step 10Q23.

NO : Repair harness/connector between ABSCM and hydraulic unit.

10Q23	CHECK POOR CONTACT IN CONNECTORS.
-------	-----------------------------------

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10Q24.

10Q24	CHECK ABSCM.
-------	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10Q25.

10Q25	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------	---

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 32 (FB1)
FR. AV VALVE

B4M0958

R: TROUBLE CODE 32 FR. AV VALVE
— ABNORMAL FRONT RH OUTLET
SOLENOID VALVE —

D•NEW 34 (FB1)
FL. AV VALVE

B4M0959

S: TROUBLE CODE 34 FL. AV VALVE
— ABNORMAL FRONT LH OUTLET
SOLENOID VALVE —

D•NEW 36 (FB1)
RR. AV VALVE

B4M0960

T: TROUBLE CODE 36 RR. AV VALVE
— ABNORMAL REAR RH OUTLET SOLENOID
VALVE —

D•NEW 38 (FB1)
RL. AV VALVE

B4M0961


U: TROUBLE CODE 38 RL. AV VALVE
— ABNORMAL REAR LH OUTLET SOLENOID
VALVE —

DIAGNOSIS:


- Faulty harness/connector
- Faulty outlet solenoid valve in hydraulic unit

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:

H4M1115

**10U1 CHECK FREEZE FRAME DATA.**

Press [F], [E], [1] and [5] on the select monitor.

CHECK : *Is the select monitor LED 5 off? Was the ABS inactive when the problem occurred?*

YES : Go to step **10U2**.

NO : Go to step **10U15**.

10U2 CHECK THE CONDITION WHEN THE TROUBLE OCCURRED.

Ask the vehicle owner about driving conditions when the trouble occurred. Attempt to duplicate the conditions.

CHECK : *Is the trouble immediately apparent?*

YES : Go to step **10U3**.


NO : Go to step **10U15**.

10U3 CHECK THE CONDITION WHEN THE TROUBLE OCCURRED.

CHECK : *Did the trouble occur immediately after engine starting or during standing starts?*

YES : Go to step **10U11**.

NO : Go to step **10U4**.

**10U4 CHECK RESISTANCE OF SOLENOID VALVE.**

1) Turn ignition switch to OFF.

2) Disconnect two connectors (ABS1, F9) from hydraulic unit.

3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 — (ABS2) No. 2:

Trouble code 34 / (ABS5) No. 5 — (ABS2) No. 2:


Trouble code 36 / (ABS5) No. 6 — (ABS2) No. 2:

Trouble code 38 / (ABS5) No. 7 — (ABS2) No. 2:

CHECK : *Is the resistance between 3.8 and 4.8 Ω?*

YES : Go to step **10U5**.

NO : Replace hydraulic unit.

**10U5****CHECK GROUND SHORT OF SOLENOID VALVE.**

Measure resistance between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 — Chassis ground:

Trouble code 34 / (ABS5) No. 5 — Chassis ground:


Trouble code 36 / (ABS5) No. 6 — Chassis ground:

Trouble code 38 / (ABS5) No. 7 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step **10U6**.

NO : Replace hydraulic unit.

**10U6****CHECK GROUND SHORT OF HARNESS.**

1) Disconnect connector from ABSCM.

2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 32 / (F49) No. 3 — Chassis ground:

Trouble code 34 / (F49) No. 51 — Chassis ground:


Trouble code 36 / (F49) No. 50 — Chassis ground:

Trouble code 38 / (F49) No. 4 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step **10U7**.

NO : Repair harness between ABSCM and hydraulic unit.



10U7 **CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.**

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal

Trouble code 32 / (F49) No. 3 — No. 1:

Trouble code 34 / (F49) No. 51 — No. 1:

Trouble code 36 / (F49) No. 50 — No. 1:

Trouble code 38 / (F49) No. 4 — No. 1:

CHECK : *Is the resistance between 4.3 and 5.3 Ω?*

YES : Go to step **10U8**.

NO : Repair harness/connector between ABSCM and hydraulic unit.

10U8 **CHECK POOR CONTACT IN CONNECTORS.**

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **10U9**.

10U9 **CHECK ABSCM.**

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.


NO : Go to step **10U10**.

10U10 **CHECK ANY OTHER TROUBLE CODES APPEARANCE.**

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

**10U11****CHECK BATTERY SHORT OF SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Disconnect connector from ABSCM.
- 4) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 (+) — Chassis ground (-):

Trouble code 34 / (ABS5) No. 5 (+) — Chassis ground (-):


Trouble code 36 / (ABS5) No. 6 (+) — Chassis ground (-):

Trouble code 38 / (ABS5) No. 7 (+) — Chassis ground (-):

: Is the voltage less than 1 V?

: Go to step 10U12.

: Replace hydraulic unit.

**10U12****CHECK BATTERY SHORT OF SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 (+) — Chassis ground (-):

Trouble code 34 / (ABS5) No. 5 (+) — Chassis ground (-):


Trouble code 36 / (ABS5) No. 6 (+) — Chassis ground (-):

Trouble code 38 / (ABS5) No. 7 (+) — Chassis ground (-):

: Is the voltage less than 1 V?

: Go to step 10U13.

: Replace hydraulic unit.



10U13 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 32 / (F49) No. 3 (+) — Chassis ground (-):

Trouble code 34 / (F49) No. 51 (+) — Chassis ground (-):


Trouble code 36 / (F49) No. 50 (+) — Chassis ground (-):

Trouble code 38 / (F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10U14.

NO : Repair harness between ABSCM and hydraulic unit.



10U14 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 32 / (F49) No. 3 (+) — Chassis ground (-):

Trouble code 34 / (F49) No. 51 (+) — Chassis ground (-):


Trouble code 36 / (F49) No. 50 (+) — Chassis ground (-):

Trouble code 38 / (F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Replace ABSCM.

NO : Repair harness between ABSCM and hydraulic unit.


10U15 **CHECK RESISTANCE OF SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors (ABS1, F9) from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 — (ABS2) No. 2:

Trouble code 34 / (ABS5) No. 5 — (ABS2) No. 2:


Trouble code 36 / (ABS5) No. 6 — (ABS2) No. 2:

Trouble code 38 / (ABS5) No. 7 — (ABS2) No. 2:

CHECK : *Is the resistance between 3.8 and 4.8 Ω?*

YES : Go to step **10U16**.

NO : Replace hydraulic unit.


10U16 **CHECK GROUND SHORT OF SOLENOID VALVE.**

Measure resistance between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 — Chassis ground:

Trouble code 34 / (ABS5) No. 5 — Chassis ground:


Trouble code 36 / (ABS5) No. 6 — Chassis ground:

Trouble code 38 / (ABS5) No. 7 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **10U17**.

NO : Replace hydraulic unit.



10U17

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 (+) — Chassis ground (-):

Trouble code 34 / (ABS5) No. 5 (+) — Chassis ground (-):


Trouble code 36 / (ABS5) No. 6 (+) — Chassis ground (-):

Trouble code 38 / (ABS5) No. 7 (+) — Chassis ground (-):

: Is the voltage less than 1 V?

: Go to step 10U18.

: Replace hydraulic unit.



10U18

CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal

Trouble code 32 / (ABS5) No. 8 (+) — Chassis ground (-):

Trouble code 34 / (ABS5) No. 5 (+) — Chassis ground (-):


Trouble code 36 / (ABS5) No. 6 (+) — Chassis ground (-):

Trouble code 38 / (ABS5) No. 7 (+) — Chassis ground (-):

: Is the voltage less than 1 V?

: Go to step 10U19.

: Replace hydraulic unit.



10U19 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 32 / (F49) No. 3 (+) — Chassis ground (−):

Trouble code 34 / (F49) No. 51 (+) — Chassis ground (-):


Trouble code 36 / (F49) No. 50 (+) — Chassis ground (-):

Trouble code 38 / (F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10U20.

NO : Repair harness between ABS/CM and hydraulic unit.



10U20 CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABS CM connector and chassis ground.

Connector & terminal

Trouble code 32 / (F49) No. 3 (+) — Chassis ground (-):

Trouble code 34 / (F49) No. 51 (+) — Chassis ground (-):


Trouble code 36 / (F49) No. 50 (+) — Chassis ground (-):

Trouble code 38 / (F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10U21.

NO : Repair harness between ABS/CM and hydraulic unit.



10U21 CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

Trouble code 32 / (F49) No. 3 — Chassis ground:

Trouble code 34 / (F49) No. 51 — Chassis ground:


Trouble code 36 / (F49) No. 50 — Chassis ground:

Trouble code 38 / (F49) No. 4 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 10U22.

NO : Repair harness between ABSCM and hydraulic unit.



10U22 CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal

Trouble code 32 / (F49) No. 3 — No. 1:

Trouble code 34 / (F49) No. 51 — No. 1:

Trouble code 36 / (F49) No. 50 — No. 1:

Trouble code 38 / (F49) No. 4 — No. 1:

CHECK : Is the resistance between 4.3 and 5.3 Ω ?

YES : Go to step 10U23.

NO : Repair harness/connector between ABSCM and hydraulic unit.

10U23	CHECK POOR CONTACT IN CONNECTORS.
-------	-----------------------------------

CHECK : *Is there poor contact in connectors between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **10U24**.

10U24	CHECK ABSCM.
-------	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10U25**.

10U25	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------	---

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 41 (FB1)
ECU

B4M0962

**V: TROUBLE CODE 41 ECU
— ABNORMAL ABS CONTROL MODULE —**


DIAGNOSIS:

- Faulty ABSCM

TROUBLE SYMPTOM:


- ABS does not operate.

WIRING DIAGRAM:



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X	
X	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

B4M0837



10V1 CHECK GROUND CIRCUIT OF ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM and chassis ground.

Connector & terminal

(F49) No. 1 — Chassis ground:

(F49) No. 55 — Chassis ground:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 10V2.

NO : Repair ABSCM ground harness.

10V2 CHECK POOR CONTACT IN CONNECTORS.

CHECK : *Is there poor contact in connectors between battery, ignition switch and ABSCM? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10V3.

10V3 CHECK SOURCES OF SIGNAL NOISE.

CHECK : *Is the car telephone or the wireless transmitter properly installed?*

YES : Go to step 10V4.

NO : Properly install the car telephone or the wireless transmitter.

10V4 CHECK SOURCES OF SIGNAL NOISE.

CHECK : *Are noise sources (such as an antenna) installed near the sensor harness?*

YES : Install the noise sources apart from the sensor harness.

NO : Go to step 10V5.

10V5 CHECK ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10V6.

10V6	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
CHECK	: <i>Are other trouble codes being output?</i>
YES	: Proceed with the diagnosis corresponding to the trouble code.
NO	: A temporary poor contact.

D•NEW 42 (F B1)
LOW VOLTAGE

B4M0963

**W: TROUBLE CODE 42 LOW VOLTAGE
— SOURCE VOLTAGE IS LOW —**


DIAGNOSIS:

- Power source voltage of the ABSCM is low.

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




F2
1 2 3 4 □ 5 6 7
8 9 10 11 12 13 14 15 16

F49

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	

H4M1108



10W1 CHECK GENERATOR.

- 1) Start engine.
- 2) Idling after warm-up.
- 3) Measure voltage between generator B terminal and chassis ground.

Terminal


Generator B terminal — Chassis ground:

CHECK : Is the voltage between 10 V and 15 V?
YES : Go to step 10W2.
NO : Repair generator.

10W2 CHECK BATTERY TERMINAL.

Turn ignition switch to OFF.

CHECK : Are the positive and negative battery terminals tightly clamped?
YES : Go to step 10W3.
NO : Tighten the clamp of terminal.




10W3 CHECK INPUT VOLTAGE OF ABSCM.

- 1) Disconnect connector from ABSCM.
- 2) Run the engine at idle.
- 3) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 28 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 15 V?
YES : Go to step 10W4.
NO : Repair harness connector between battery, ignition switch and ABSCM.



10W4 CHECK GROUND CIRCUIT OF ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 1 — Chassis ground:

CHECK : Is the resistance less than 0.5 Ω?
YES : Go to step 10W5.
NO : Repair ABSCM ground harness.

10W5	CHECK POOR CONTACT IN CONNECTORS.
------	-----------------------------------

CHECK : *Is there poor contact in connectors between generator, battery and ABSCM? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10W6.

10W6	CHECK ABSCM.
------	--------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10W7.

10W7	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
------	---

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 44 (F B1)
CCM LINE

B4M0964

X: TROUBLE CODE 44 CCM LINE — A COMBINATION OF AT CONTROL ABNORMALS —


DIAGNOSIS:

- Combination of AT control faults

TROUBLE SYMPTOM:


- ABS does not operate

WIRING DIAGRAM:



1997 (F00)
ABS 4WD•AT

H4M1117



10X1 CHECK SPECIFICATIONS OF ABSCM USING SELECT MONITOR.

- 1) Press [F], [0] and [0] on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is an ABSCM for AT model installed on a MT model?*

YES : Replace ABSCM.

NO : Go to step 10X2.

10X2 CHECK GROUND SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors from TCM.
- 3) Disconnect connector from ABSCM.
- 4) Measure resistance between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 12 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 10X3.

NO : Repair harness between TCM and ABSCM.



10X3 CHECK TCM.

- 1) Connect all connectors to TCM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between TCM connector terminals.


Connector & terminal

(B55) No. 1 (+) — (B56) No. 5 (-):

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step 10X5.

NO : Go to step 10X4.



10X4 CHECK POWER SUPPLY FOR TCM.

Measure voltage between TCM connector and chassis ground.

Connector & terminal


(B54) No. 6 (+) — Chassis ground (-):

(B55) No. 1 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 13 V?

YES : Replace TCM.

NO : Repair harness/connector between battery, ignition switch and TCM.



10X5 CHECK OPEN CIRCUIT OF HARNESS.

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 12 (+) — Chassis ground (-):

(F49) No. 39 (+) — Chassis ground (-):

CHECK : Is the voltage more than 10 V?

YES : Go to step 10X6.

NO : Repair harness/connector between AT control module and ABSCM.

10X6 CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between AT control module and ABSCM? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 10X7.

10X7	CHECK ABSCM.
-------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10X8**.

10X8	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
-------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 44 (FB1)
CCM OPEN

B4M0965

**Y: TROUBLE CODE 44 CCM OPEN
— A COMBINATION OF AT CONTROL
ABNORMALS —**


DIAGNOSIS:


- Combination of AT control faults

TROUBLE SYMPTOM:


- ABS does not operate.

WIRING DIAGRAM:




**10Y1****CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect two connectors from AT control module.
- 3) Disconnect connector from ABSCM.
- 4) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 12 (+) — Chassis ground (-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 10Y2.****NO : Repair harness between AT control module and ABSCM.****10Y2****CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 12 (+) — Chassis ground (-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 10Y3.****NO : Repair harness between AT control module and ABSCM.**



10Y3 CHECK OPEN CIRCUIT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors to TCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 12 (+) — Chassis ground (-):

(F49) No. 39 (+) — Chassis ground (-):

CHECK : Is the voltage between 10 V and 13 V?

YES : Go to step 10Y4.

NO : Repair harness/connector between TCM and ABSCM.

10Y4 CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : Is there poor contact in connectors between AT control module and ABSCM? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 10Y5.

10Y5 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 10Y6.

10Y6 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 46 (FB1)
GS POWER OVER

B4M0966

**Z: TROUBLE CODE 46 GS POWER OVER
— G SENSOR LINE VOLTAGE TOO HIGH —**



DIAGNOSIS:

- Faulty G sensor power supply voltage

TROUBLE SYMPTOM:

- ABS does not operate.


WIRING DIAGRAM:




F49

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
X	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X
X	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

H4M1111

**10Z1****CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Remove console cover from console box.
- 3) Disconnect connector from G sensor.
- 4) Disconnect connector from ABSCM.
- 5) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 8 (+) — Chassis ground (-):****(F49) No. 45 (+) — Chassis ground (-):****CHECK : Is the voltage less than 1 V?****YES : Go to step 10Z2.****NO : Repair harness between ABSCM and G sensor.****10Z2****CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM and chassis ground.

Connector & terminal**(F49) No. 8 (+) — Chassis ground (-):****(F49) No. 45 (+) — Chassis ground (-):****CHECK : Is the voltage less than 1 V?****YES : Replace ABSCM.****NO : Repair harness between ABSCM and chassis ground.**

D•NEW 46 (FB1)
GS POWER LOW

B4M0967

**AA: TROUBLE CODE 46 GS POWER LOW
— G SENSOR LINE VOLTAGE TOO LOW —**



DIAGNOSIS:

- Faulty G sensor power supply voltage

TROUBLE SYMPTOM:

- ABS does not operate.


WIRING DIAGRAM:



F49

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
X	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X
X	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83


H4M1111

**10AA1 CHECK G SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove console cover from console box.
- 3) Disconnect connector from G sensor.
- 4) Measure resistance of G sensor.

Terminal**No. 1 — No. 3:**


CHECK : *Is the resistance between 42 and 58 kΩ?*
YES : Go to step 10AA2.
NO : Replace G sensor.

**10AA2 CHECK GROUND SHORT OF G SENSOR.**

Measure resistance between G sensor and bracket.

Terminal**No. 3 — Bracket:**


CHECK : *Is the resistance more than 1 MΩ?*
YES : Go to step 10AA3.
NO : Replace G sensor.

**10AA3 CHECK SHORT OF HARNESS BETWEEN ABSCM AND G SENSOR.**

- 1) Disconnect connector from ABSCM.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal**(F49) No. 45 — No. 8**

CHECK : *Is the resistance more than 1 MΩ?*
YES : Go to step 10AA4.
NO : Repair harness between ABSCM and G sensor.



10AA4

CHECK GROUND SHORT OF HARNESS.

Measure resistance between ABSCM connector and chassis ground.

Connector & terminal**(F49) No. 8 — Chassis ground:****(F49) No. 45 — Chassis ground:**

CHECK : Is the resistance more than $1\text{ M}\Omega$?

YES : Go to step 10AA5.

NO : Repair harness between ABSCM and G sensor.

10AA5

CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 10AA6.

10AA6

CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 10AA7.

10AA7

CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 51 (FB1)
V. RELAY

B4M0968

AB: TROUBLE CODE 51 V. RELAY — ABNORMAL VALVE RELAY —


DIAGNOSIS:

- Faulty valve relay

TROUBLE SYMPTOM:


- ABS does not operate.

WIRING DIAGRAM:



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X	
X	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

H4M1112




10AB1 CHECK FREEZE FRAME DATA.

Press [F], [E], [1] and [5] on the select monitor.

CHECK : *Is the select monitor LED 5 off? Was the ABS inactive when the problem occurred?*

YES : Go to step 10AB2.

NO : Go to step 10AB32.



10AB2 CHECK RESISTANCE OF VALVE RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove valve relay from relay box.
- 3) Measure resistance between valve relay terminals.


Terminals

No. 85 — No. 86:

CHECK : *Is the resistance between 93 and 113 Ω?*

YES : Go to step 10AB3.

NO : Replace valve relay.



10AB3 CHECK CONTACT POINT OF VALVE RELAY.

- 1) Connect battery to valve relay terminals No. 85 and No. 86.
- 2) Measure resistance between valve relay terminals.


Terminals

No. 30 — No. 87:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 10AB4.

NO : Replace valve relay.



10AB4 CHECK CONTACT POINT OF VALVE RELAY.

Measure resistance between valve relay terminals.


Terminals

No. 30 — No. 87a:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 10AB5.

NO : Replace valve relay.


10AB5 **CHECK CONTACT POINT OF VALVE RELAY.**


- 1) Disconnect battery from valve relay terminals.
- 2) Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **10AB6**.

NO : Replace valve relay.


10AB6 **CHECK CONTACT POINT OF VALVE RELAY.**


Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87a:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **10AB7**.

NO : Replace valve relay.


10AB7 **CHECK SHORT OF VALVE RELAY.**


Measure resistance between valve relay terminals.

Terminals
No. 86 — No. 87:
No. 86 — No. 87a:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **10AB8**.

NO : Replace valve relay.


10AB8 **CHECK POWER SUPPLY VOLTAGE AT VALVE RELAY CONTACT POINT.**

- 1) Disconnect connector (F8) from relay box.


- 2) Measure voltage between relay box connector and chassis ground.

Connector & terminal
(F8) No. 1 (+) — Chassis ground (-):

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step **10AB9**.

NO : Repair harness connector between battery and relay box, and check fuse No. 19.



10AB9

CHECK OPEN AND GROUND SHORT CIRCUIT IN POWER SUPPLY CIRCUIT OF RELAY BOX.


- 1) Disconnect connector (ABS1) from hydraulic unit.
- 2) Connect connector (F8) to relay box.
- 3) Disconnect connector (F50) from relay box.
- 4) Measure voltage of relay box.

Connector & terminal
Valve relay installing point No. 87 — Chassis ground:

CHECK : Is the voltage between 10 V and 13 V?

YES : Go to step 10AB10.

NO : Replace relay box, and check fuse No. 19.



10AB10

CHECK OPEN CIRCUIT IN CONTACT POINT CIRCUIT OF RELAY BOX.


Measure resistance between hydraulic unit connector and valve relay installing point.

Connector & terminal
(ABS1) No. 2 — Valve relay installing point No. 30:

CHECK : Is the resistance less than 0.5 Ω?

YES : Go to step 10AB11.

NO : Replace relay box.



10AB11

CHECK GROUND SHORT CIRCUIT IN CONTACT POINT CIRCUIT OF RELAY BOX.


Measure resistance between relay box connector and chassis ground.

Connector & terminal
(ABS1) No. 2 — Chassis ground:

CHECK : Is the resistance more than 1 MΩ?

YES : Go to step 10AB12.

NO : Replace relay box, and check fuse SBF6.


10AB12 CHECK DIODE OF RELAY BOX.

Measure resistance between relay box connector and valve relay installing point.


Connector & terminal

Valve relay installing point No. 30 (+) — (ABS4) No. 2 (-):

CHECK : Is the resistance more than $1\text{ M}\Omega$?

YES : Go to step 10AB13.

NO : Replace relay box.


10AB13 CHECK BATTERY SHORT IN GROUND CIRCUIT OF RELAY BOX.

1) Disconnect connector from ABSCM.

2) Measure voltage between relay box connector and chassis ground.


Connector & terminal

(ABS4) No. 3 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10AB14.

NO : Replace relay box, and check all fuses.


10AB14 CHECK BATTERY SHORT IN GROUND CIRCUIT OF RELAY BOX.

1) Turn ignition switch to ON.

2) Measure voltage between relay box connector and chassis ground.


Connector & terminal

(ABS4) No. 3 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10AB15.

NO : Replace relay box, and check all fuses.



B4M0871C

10AB15 **CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX.**


- 1) Turn ignition switch to OFF.
- 2) Install valve relay to relay box.
- 3) Measure resistance between relay box connector terminals.

Connector & terminal**(ABS4) No. 1 — No. 5:**

CHECK : *Is the resistance between 93 and 113 Ω?*

YES : Go to step **10AB16**.

NO : Replace relay box.



B4M0872C

10AB16 **CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.**


Measure resistance between relay box connector and chassis ground.

Connector & terminal**(ABS4) No. 1 — Chassis ground:**

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **10AB17**.

NO : Replace relay box, and check all fuses.



B4M0873C

10AB17 **CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.**


Measure voltage between relay box connector and chassis ground.

Connector & terminal**(ABS4) No. 1 (+) — Chassis ground (-):**

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AB18**.

NO : Replace relay box, and check fuse No. 19 and SBF6.


10AB18 **CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between relay box connector and chassis ground.


Connector & terminal

(ABS4) No. 1 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AB19**.

NO : Replace relay box, and check fuse No. 19 and SBF6.


10AB19 **CHECK OPEN CIRCUIT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.**

- 1) Turn ignition switch to OFF.
- 2) Connect connector (F50) to relay box.
- 3) Measure resistance between ABSCM connector terminals.


Connector & terminal

(F49) No. 27 — No. 47:

CHECK : *Is the resistance between 93 and 113 Ω?*

YES : Go to step **10AB20**.

NO : Repair harness between ABSCM and relay box, and check fuse No. 18.


10AB20 **CHECK GROUND SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.**

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 27 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **10AB21**.

NO : Repair harness between ABSCM and relay box, and check fuse No. 18.


10AB21 **CHECK BATTERY SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.**

- 1) Connect connector (F50) to relay box.
- 2) Measure voltage between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 27 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AB22**.

NO : Repair harness between ABSCM and relay box, and check all fuses.


10AB22 **CHECK BATTERY SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 27 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AB23**.

NO : Repair harness between ABSCM and relay box, and check all fuses.


10AB23 **CHECK RESISTANCE OF INLET SOLE-NOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from hydraulic unit.
- 3) Measure resistance between hydraulic unit connector terminals.

Connector & terminal

(ABS5) No. 4 — (ABS2) No. 2:

(ABS5) No. 1 — (ABS2) No. 2:


(ABS5) No. 2 — (ABS2) No. 2:

(ABS5) No. 3 — (ABS2) No. 2:

CHECK : *Is the resistance between 7.8 and 9.2 Ω?*

YES : Go to step **10AB24**.

NO : Replace hydraulic unit.


10AB24 CHECK RESISTANCE OF OUTLET SOLENOID VALVE.

Measure resistance between hydraulic unit connector terminals.

Connector & terminal

(ABS5) No. 8 — (ABS2) No. 2:

(ABS5) No. 5 — (ABS2) No. 2:


(ABS5) No. 6 — (ABS2) No. 2:

(ABS5) No. 7 — (ABS2) No. 2:

CHECK : Is the resistance between 3.8 and 4.8 Ω ?

YES : Go to step 10AB25.

NO : Replace hydraulic unit.


10AB25 CHECK GROUND SHORT OF SOLENOID VALVE.

Measure resistance between hydraulic unit connector and chassis ground.


Connector & terminal

(ABS5) No. 4 — Chassis ground:

CHECK : Is the resistance more than 1 $M\Omega$?

YES : Go to step 10AB26.

NO : Replace hydraulic unit, and check all fuses.


10AB26 CHECK GROUND SHORT OF HARNESS.

1) Disconnect connector from hydraulic unit.

2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 30 — Chassis ground:

(F49) No. 24 — Chassis ground:

(F49) No. 23 — Chassis ground:

(F49) No. 31 — Chassis ground:

(F49) No. 3 — Chassis ground:

(F49) No. 51 — Chassis ground:


(F49) No. 50 — Chassis ground:

(F49) No. 4 — Chassis ground:

CHECK : Is the resistance more than 1 $M\Omega$?

YES : Go to step 10AB27.

NO : Repair harness between hydraulic unit and ABSCM.



10AB27 **CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.**

- 1) Connect connector to hydraulic unit.
- 2) Measure resistance between ABSCM connector terminals.

Connector & terminal

(F49) No. 30 — No. 1:

(F49) No. 24 — No. 1:


(F49) No. 23 — No. 1:

(F49) No. 31 — No. 1:

CHECK : Is the resistance between 8.3 and 9.7 Ω ?

YES : Go to step **10AB28**.

NO : Repair harness/connector between hydraulic unit and ABSCM.



10AB28 **CHECK HARNESS/CONNECTOR BETWEEN ABSCM AND HYDRAULIC UNIT.**

Measure resistance between ABSCM connector terminals.

Connector & terminal

(F49) No. 3 — No. 1:

(F49) No. 51 — No. 1:

(F49) No. 50 — No. 1:

(F49) No. 4 — No. 1:

CHECK : Is the resistance between 4.3 and 5.3 Ω ?

YES : Go to step **10AB29**.

NO : Repair harness/connector between hydraulic unit and ABSCM.

10AB29 **CHECK POOR CONTACT IN CONNECTORS.**

CHECK : Is there poor contact in connector between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step **10AB30**.

10AB30 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.


NO : Go to step **10AB31**.

10AB31 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

**10AB32 CHECK BATTERY SHORT OF SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors (ABS1, F9) from hydraulic unit.
- 3) Disconnect connector from ABSCM.
- 4) Measure voltage between hydraulic unit connector and chassis ground.


Connector & terminal

(ABS5) No. 4 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AB33**.

NO : Replace hydraulic unit, and check all fuses.


10AB33 **CHECK BATTERY SHORT OF SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.


Connector & terminal

(ABS5) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **10AB34**.

NO : Replace hydraulic unit, and check all fuses.


10AB34 **CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 30 (+) — Chassis ground (-):

(F49) No. 24 (+) — Chassis ground (-):

(F49) No. 23 (+) — Chassis ground (-):

(F49) No. 31 (+) — Chassis ground (-):

(F49) No. 3 (+) — Chassis ground (-):

(F49) No. 51 (+) — Chassis ground (-):


(F49) No. 50 (+) — Chassis ground (-):

(F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **10AB35**.

NO : Repair harness between hydraulic unit and ABSCM, and check all fuses.



10AB35 | CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 30 (+) — Chassis ground (-):

(F49) No. 24 (+) — Chassis ground (-):

(F49) No. 23 (+) — Chassis ground (-):

(F49) No. 31 (+) — Chassis ground (-):

(F49) No. 3 (+) — Chassis ground (-):

(F49) No. 51 (+) — Chassis ground (-):

(F49) No. 50 (+) — Chassis ground (-):

(F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10AB36.

NO : Repair harness between hydraulic unit and ABSCM, and check all fuses.

10AB36 | CHECK ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 10AB37.

10AB37 | CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 51 (FB1)
V. RELAY ON

B4M0802

AC: TROUBLE CODE 51 V. RELAY ON — VALVE RELAY ON FAILURE —


DIAGNOSIS:

- Faulty valve relay

TROUBLE SYMPTOM:


- ABS does not operate

WIRING DIAGRAM:



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28		
☒	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	☒	
☒	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	☒


H4M1112


10AC1 CHECK RESISTANCE OF VALVE RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove valve relay from relay box.
- 3) Measure resistance between valve relay terminals.

Terminals
No. 85 — No. 86:


CHECK : *Is the resistance between 93 and 113 Ω?*
YES : Go to step 10AC2.
NO : Replace valve relay.


10AC2 CHECK CONTACT POINT OF VALVE RELAY.

- 1) Connect battery to valve relay terminals No. 85 and No. 86.
- 2) Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87:


CHECK : *Is the resistance less than 0.5 Ω?*
YES : Go to step 10AC3.
NO : Replace valve relay.


10AC3 CHECK CONTACT POINT OF VALVE RELAY.

Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87a:

CHECK : *Is the resistance more than 1 MΩ?*
YES : Go to step 10AC4.
NO : Replace valve relay.


10AC4 **CHECK CONTACT POINT OF VALVE RELAY.**


- 1) Disconnect battery from valve relay terminals.
- 2) Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 10AC5.

NO : Replace valve relay.


10AC5 **CHECK CONTACT POINT OF VALVE RELAY.**


Measure resistance between valve relay terminals.

Terminals
No. 30 — No. 87a:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 10AC6.

NO : Replace valve relay.


10AC6 **CHECK GROUND CIRCUIT OF RELAY BOX.**


- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between relay box connector and chassis ground.

Connector & terminal
(F50) No. 3 — Chassis ground:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 10AC7.


NO : Repair relay box ground harness.



B4M0867A

10AC7 **CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.**

- 1) Disconnect connector from ABSCM.
- 2) Disconnect connector (ABS1) from hydraulic unit.
- 3) Measure voltage between hydraulic unit connector and chassis ground.


Connector & terminal
(ABS1) No. 2 (+) — Chassis ground (-):
 CHECK
: Is the voltage less than 1 V?
 YES
: Go to step 10AC8.
 NO
: Replace relay box, and check fuse No. 19 and SBF6.


B4M0867A

10AC8 **CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.

Connector & terminal
(ABS1) No. 2 (+) — Chassis ground (-):
 CHECK
: Is the voltage less than 1 V?
 YES
: Go to step 10AC9.
 NO
: Replace relay box, and check fuse No. 9 and SBF6.


10AC9 **CHECK OPEN CIRCUIT IN GROUND CIRCUIT OF RELAY BOX.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between relay box connector and valve relay installing point.


Connector & terminal

(ABS4) No. 3 — Valve relay installing point No. 87a:

CHECK : Is the resistance less than $0.5\ \Omega$?

YES : Go to step **10AC10**.

NO : Replace relay box.


10AC10 **CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.**

- 1) Install valve relay to relay box.
- 2) Measure resistance between relay box connector and chassis ground.


Connector & terminal

(ABS4) No. 1 — Chassis ground:

CHECK : Is the resistance more than $1\ M\Omega$?

YES : Go to step **10AC11**.

NO : Replace relay box, and check all fuses.



10AC11 **CHECK GROUND SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY.**

Measure resistance between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 27 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 10AC12.

NO : Repair harness between ABSCM and relay box, and check fuse No. 18.



10AC12 **CHECK BATTERY SHORT OF SOLENOID VALVE.**

- 1) Disconnect connector (ABS1, F9) from hydraulic unit.
- 2) Measure voltage between hydraulic unit connector and chassis ground.


Connector & terminal

(ABS5) No. 4 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step 10AC13.

NO : Replace hydraulic unit, and check all fuses.


10AC13 | CHECK BATTERY SHORT OF SOLENOID VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between hydraulic unit connector and chassis ground.


Connector & terminal

(ABS5) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **10AC14**.

NO : Replace hydraulic unit, and check all fuses.


10AC14 | CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from hydraulic unit.
- 3) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 30 (+) — Chassis ground (-):

(F49) No. 24 (+) — Chassis ground (-):

(F49) No. 23 (+) — Chassis ground (-):

(F49) No. 31 (+) — Chassis ground (-):

(F49) No. 3 (+) — Chassis ground (-):

(F49) No. 51 (+) — Chassis ground (-):


(F49) No. 50 (+) — Chassis ground (-):

(F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step **10AC15**.

NO : Repair harness between hydraulic unit and ABSCM, and check all fuses.



10AC15 | CHECK BATTERY SHORT OF HARNESS.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 30 (+) — Chassis ground (-):

(F49) No. 24 (+) — Chassis ground (-):

(F49) No. 23 (+) — Chassis ground (-):

(F49) No. 31 (+) — Chassis ground (-):

(F49) No. 3 (+) — Chassis ground (-):

(F49) No. 51 (+) — Chassis ground (-):

(F49) No. 50 (+) — Chassis ground (-):

(F49) No. 4 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10AC16.

NO : Repair harness between hydraulic unit and ABSCM, and check all fuses.

10AC16 | CHECK POOR CONTACT IN CONNECTORS.

CHECK : Is there poor contact in connectors between ABSCM and hydraulic unit? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 10AC17.

10AC17 | CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 10AC18.

10AC18 | CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 52 (FB1)
M. RELAY OPEN

B4M0969

**AD: TROUBLE CODE 52 M. RELAY OPEN
— OPEN CIRCUIT OF MOTOR RELAY —**


DIAGNOSIS:

- Faulty motor
- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:


- ABS does not operate.

WIRING DIAGRAM:



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	


H4M1113


10AD1 CHECK RESISTANCE OF MOTOR RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove motor relay from relay box.
- 3) Measure resistance between motor relay terminals.

Terminals
No. 85 — No. 86:


CHECK : *Is the resistance between 70 and 90 Ω ?*
YES : Go to step 10AD2.
NO : Replace motor relay.


10AD2 CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Connect battery to motor relay terminals No. 85 and No. 86.
- 2) Measure resistance between motor relay terminals.

Terminals
No. 30 — No. 87:


CHECK : *Is the resistance less than 0.5 Ω ?*
YES : Go to step 10AD3.
NO : Replace motor relay.


10AD3 CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Disconnect battery from motor relay terminals.
- 2) Measure resistance between motor relay terminals.

Terminals
No. 30 — No. 87:

CHECK : *Is the resistance more than 1 $M\Omega$?*
YES : Go to step 10AD4.
NO : Replace motor relay.



B4M0889A

10AD4 CHECK SHORT OF MOTOR RELAY.


Measure resistance between motor relay terminals.

Terminals**No. 85 — No. 30:****No. 85 — No. 87:**

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **10AD5**.

NO : Replace motor relay.



B4M0890B

10AD5 CHECK INPUT VOLTAGE OF RELAY BOX.

1) Disconnect connector (F8) from relay box.


2) Measure voltage between relay box connector and chassis ground.

Connector & terminal**(F8) No. 2 (+) — Chassis ground (-):**

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step **10AD6**.

NO : Repair harness/connector between battery and relay box, and check fuse SBF6.



B4M0891

10AD6 CHECK INPUT VOLTAGE OF MOTOR RELAY.

1) Connect connector (F8) to relay box.

2) Measure voltage between relay box and chassis ground.


Connector & terminal**Relay installing point No. 87 (+) — Chassis ground (-):**

CHECK

Is the voltage between 10 V and 13 V?

YES : Go to step **10AD7**.

NO : Replace relay box, and fuse SBF6.


10AD7 **CHECK OPEN CIRCUIT IN CONTACT POINT CIRCUIT OF RELAY BOX.**

- 1) Disconnect connector (ABS1) from hydraulic unit.
- 2) Measure resistance between hydraulic unit and motor relay installing portion.


Connector & terminal

(ABS1) No. 1 — Motor relay installing portion No. 30:

CHECK : Is the resistance less than $0.5\ \Omega$?

YES : Go to step **10AD8**.

NO : Replace relay box.


10AD8 **CHECK GROUND SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.**

Measure resistance between hydraulic unit and chassis ground.


Connector & terminal

(ABS1) No. 1 — Chassis ground:

CHECK : Is the resistance more than $1\ M\Omega$?

YES : Go to step **10AD9**.

NO : Replace relay box, and check fuse No. 19.


10AD9 **CHECK OPEN CIRCUIT IN MONITOR SYSTEM CIRCUIT OF RELAY BOX.**

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between relay box connector and motor relay installing point.


Connector & terminal

(ABS4) No. 6 — Motor relay installing point No. 30:

CHECK : Is the resistance less than $0.5\ \Omega$?

YES : Go to step **10AD10**.

NO : Replace relay box.


10AD10 **CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX.**

- 1) Remove valve relay from relay box.
- 2) Measure resistance between motor relay installing point and valve relay installing point.


Connector & terminal

Motor relay installing point No. 86 — Valve relay installing point No. 30:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 10AD11.

NO : Replace relay box.


10AD11 **CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX.**

Measure resistance between motor relay installing point and relay box connector.


Connector & terminal

Motor relay installing point No. 86 — (ABS4) No. 4:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step 10AD12.

NO : Replace relay box.


10AD12 **CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.**

Measure resistance between relay box and chassis ground.

Connector & terminal


Motor relay installing point No. 86 — Chassis ground:

Motor relay installing point No. 85 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 10AD13.

NO : Replace relay box, and check fuse No. 19.


10AD13 CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Disconnect connector from ABSCM.
- 2) Measure voltage between motor relay installing point and chassis ground.

Connector & terminal


Motor relay installing point No. 85 (+) — Chassis ground (-):

Motor relay installing point No. 86 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10AD14.

NO : Replace relay box, and check all fuses.


10AD14 CHECK BATTERY SHORT IN CONTROL CIRCUIT OF RELAY BOX.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between motor relay installing point and chassis ground.

Connector & terminal


Motor relay installing point No. 85 (+) — Chassis ground (-):

Motor relay installing point No. 86 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10AD15.

NO : Replace relay box, and check all fuses.


10AD15 **CHECK OPEN CIRCUIT IN MONITOR SYSTEM HARNESS.**


- 1) Turn ignition switch to OFF.
- 2) Connect between terminals No. 10 and No. 1 of ABSCM connector (F49) with a lead wire.
- 3) Measure resistance between relay box connector and chassis ground.

Connector & terminal
(F50) No. 6 — Chassis ground:

CHECK : Is the resistance less than 0.5Ω ?

YES : Go to step 10AD16.

NO : Repair harness/connector between ABSCM and relay box.


10AD16 **CHECK OPEN CIRCUIT IN RELAY CONTROL SYSTEM HARNESS.**


- 1) Connect valve relay and motor relay to relay box.
- 2) Connect connector (F50) to relay box.
- 3) Connect connector to hydraulic unit.
- 4) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal
(F49) No. 22 — Chassis ground:

CHECK : Is the resistance between 70 and 90Ω ?

YES : Go to step 10AD17.

NO : Repair harness/connector between ABSCM and relay box.




10AD17

**CHECK GROUND SHORT IN HARNESS
BETWEEN RELAY BOX AND ABSCM.**

- 1) Disconnect connector (F50) from relay box.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal
(F49) No. 22 — Chassis ground:
(F49) No. 10 — Chassis ground:
CHECK : *Is the resistance more than 1 MΩ?*
YES : Go to step 10AD18.

NO : Repair harness between ABSCM and relay box, and check fuse No. 19 and SBF6.



10AD18

**CHECK BATTERY SHORT IN HARNESS
BETWEEN RELAY BOX AND ABSCM.**

Measure voltage between ABSCM and chassis ground.

Connector & terminal
(F49) No. 22 (+) — Chassis ground (-):
(F49) No. 10 (+) — Chassis ground (-):
CHECK : *Is the voltage less than 1 V?*
YES : Go to step 10AD19.

NO : Repair harness between relay box and ABSCM, and check fuse SBF6.


10AD19 **CHECK BATTERY SHORT IN HARNESS BETWEEN RELAY BOX AND ABSCM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM and chassis ground.

Connector & terminal


(F49) No. 22 (+) — Chassis ground (-):

(F49) No. 10 (+) — Chassis ground (-):

CHECK : Is the voltage less than 1 V?

YES : Go to step 10AD20.

NO : Repair harness between relay box and ABSCM, and check fuse SBF6.


10AD20 **CHECK GROUND SHORT AT ABSCM MONITOR TERMINAL.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ABSCM terminals.


Terminal

No. 10 — No. 1:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 10AD21.


NO : Replace ABSCM.


10AD21 **CHECK ABSCM MOTOR DRIVE TERMINAL.**


- 1) Disconnect connector cover from ABSCM connector.
- 2) Remove band.
- 3) Remove cable clamp cover.
- 4) Remove screws securing connector cover.

CAUTION:

Do not allow harness to catch on adjacent parts during installation.




- 5) Remove connector cover.



NOTE:

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

6) Connect all connectors.




7) Measure voltage between ABSCM connector terminals.
 8) Operate the check sequence. <Ref. to 4-4 [W12D0].>

Connector & terminals**(F49) No. 22 (+) — No. 1 (-):**

CHECK : Does the voltage drop from between 10 V and 13 V to less than 1.5 V, and rise to between 10 V and 13 V again when carrying out the check sequence?

YES : Go to step 10AD22.

NO : Replace ABSCM.



10AD22 CHECK MOTOR OPERATION.

- 1) Measure voltage between ABSCM connector terminal.
- 2) Operate the check sequence. <Ref. to 4-4 [W12D0].>

Connector & terminals

(F49) No. 10 (+) — No. 1 (-):

CHECK : *Does the voltage raise from less than 1.5 V to between 10 V and 13 V and return to less than 1.5 V again when carrying out the check sequence?*

YES : Go to step 10AD23.

NO : Replace hydraulic unit.

10AD23 CHECK MOTOR OPERATION.

Operate the check sequence. <Ref. to 4-4 [W12D0].>

CHECK : *Can motor revolution noise (buzz) be heard when carrying out the check sequence?*

YES : Go to step 10AD24.

NO : Replace hydraulic unit.

10AD24 CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connectors between hydraulic unit, relay box and ABSCM? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10AD25.

10AD25 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10AD26.

10AD26 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 52 (FB1)
M. RELAY ON

B4M0970

**AE: TROUBLE CODE 52 M. RELAY ON
— MOTOR RELAY ON FAILURE —**


DIAGNOSIS:

- Faulty motor
- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:


- ABS does not operate.

WIRING DIAGRAM:



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

H4M1113




B4M0886A

10AE1 CHECK RESISTANCE OF MOTOR RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove motor relay from relay box.
- 3) Measure resistance between motor relay terminals.

Terminals**No. 85 — No. 86:**

CHECK : *Is the resistance between 70 and 90 Ω ?*
YES : Go to step 10AE2.
NO : Replace motor relay.




B4M0887A

10AE2 CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Connect battery to motor relay terminals No. 85 and No. 86.
- 2) Measure resistance between motor relay terminals.

Terminals**No. 30 — No. 87:**

CHECK : *Is the resistance less than 0.5 Ω ?*
YES : Go to step 10AE3.
NO : Replace motor relay.




B4M0888A

10AE3 CHECK CONTACT POINT OF MOTOR RELAY.

- 1) Disconnect battery from motor relay terminals.
- 2) Measure resistance between motor relay terminals.

Terminals**No. 30 — No. 87:**

CHECK : *Is the resistance more than 1 $M\Omega$?*
YES : Go to step 10AE4.
NO : Replace motor relay.




B4M0889A

10AE4 CHECK SHORT OF MOTOR RELAY.

Measure resistance between motor relay terminals.

Terminals**No. 85 — No. 30:****No. 85 — No. 87:**

CHECK : *Is the resistance more than 1 $M\Omega$?*
YES : Go to step 10AE5.
NO : Replace motor relay.




B4M0793A

10AE5 | **CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.**

- 1) Disconnect connector from ABSCM.
- 2) Disconnect connector (ABS1) from hydraulic unit.
- 3) Measure voltage between relay box connector and chassis ground.

Connector & terminal
(ABS1) No. 1 (+) — Chassis ground (-):
CHECK : *Is the voltage less than 1 V?*
YES : Go to step **10AE6**.

NO : Replace relay box.



B4M0793A

10AE6 | **CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between relay box connector and chassis ground.

Connector & terminal
(ABS1) No. 1 (+) — Chassis ground (-):
CHECK : *Is the voltage less than 1 V?*
YES : Go to step **10AE7**.

NO : Replace relay box.


10AE7 **CHECK GROUND SHORT IN CONTROL CIRCUIT OF RELAY BOX.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector (F50) from relay box.
- 3) Measure resistance between relay box and chassis ground.

Connector & terminal


Motor relay installing point No. 85 — Chassis ground:

Motor relay installing point No. 86 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 10AE8.

NO : Replace relay box, and check fuse No. 19.


10AE8 **CHECK GROUND SHORT IN HARNESS BETWEEN RELAY BOX AND ABSCM.**

- 1) Disconnect connector (F49) from ABSCM.
- 2) Measure resistance between ABSCM connector and chassis ground.

Connector & terminal


(F49) No. 22 — Chassis ground:

(F49) No. 10 — Chassis ground:

CHECK : Is the resistance more than $1 M\Omega$?

YES : Go to step 10AE9.

NO : Repair harness between ABSCM and relay box, and check fuse No. 19 and SBF6.



10AE9 **CHECK BATTERY SHORT IN HARNESS
BETWEEN RELAY BOX AND ABSCM.**

Measure voltage between ABSCM connector and chassis ground.

Connector & terminal


(F49) No. 22 (+) — Chassis ground (-):

(F49) No. 10 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AE10**.

NO : Repair harness between relay box and ABSCM connector, and check fuse SBF6.



10AE10 **CHECK BATTERY SHORT IN HARNESS
BETWEEN RELAY BOX AND ABSCM.**

1) Turn ignition switch to ON.

2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal


(F49) No. 22 (+) — Chassis ground (-):

(F49) No. 10 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AE11**.

NO : Repair harness between relay box and ABSCM, and check fuse SBF6.



10AE11



CHECK BATTERY SHORT AT ABS/SCM MONITOR TERMINAL.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABS control module.
- 3) Remove band.
- 4) Remove cable clamp cover.
- 5) Remove screws securing connector cover.

CAUTION:


Do not allow harness to catch on adjacent parts during installation.

- 6) Remove connector cover.

**NOTE:**

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

- 7) Connect all connectors.



8) Measure voltage between ABSCM connector terminals.

Connector & terminal

(F49) No. 10 (+) — No. 1 (-):

CHECK


: *Is the voltage less than 2 V?*

YES

: Go to step 10AE12.

NO

: Replace ABSCM.



10AE12 CHECK BATTERY SHORT AT ABSCM MONITOR TERMINAL.

1) Turn ignition switch to ON.

2) Measure voltage between ABSCM connector terminals.

Connector & terminal

(F49) No. 10 (+) — No. 1 (-):

CHECK


: *Is the voltage less than 2 V?*

YES

: Go to step 10AE13.

NO

: Replace ABSCM.



10AE13 CHECK MOTOR GROUND.

Turn ignition switch to OFF.

CHECK

: *Tightening torque:*

$32 \pm 10 \text{ N}\cdot\text{m}$ ($3.3 \pm 1.0 \text{ kg}\cdot\text{m}$, $24 \pm 7 \text{ ft-lb}$)


Is the motor ground terminal tightly clamped?

YES

: Go to step 10AE14.

NO

: Tighten the clamp of motor ground terminal.



10AE14 CHECK ABSCM MOTOR DRIVE TERMINAL.

1) Measure voltage between ABSCM connector terminals.
2) Operate the check sequence. <Ref. to 4-4 [W12D0].>

Connector & terminals

(F49) No. 22 (+) — No. 1 (-):

CHECK


: *Does the voltage drop from between 10 V and 13 V to less than 1.5 V, and rise to between 10 V and 13 V again when carrying out the check sequence?*

YES

: Go to step 10AE15.

NO

: Replace ABSCM.



10AE15 CHECK MOTOR OPERATION.

- 1) Measure voltage between ABSCM connector terminal.
- 2) Operate the check sequence. <Ref. to 4-4 [W12D0].>

Connector & terminals

(F49) No. 10 (+) — No. 1 (-):

CHECK : *Does the voltage raise from less than 1.5 V to between 10 V and 13 V, and return to less than 1.5 V again when carrying out the check sequence?*

YES : Go to step 10AE16.

NO : Replace hydraulic unit.

10AE16 CHECK MOTOR OPERATION.

Operate the check sequence. <Ref. to 4-4 [W12D0].>

CHECK : *Can motor revolution noise (buzz) be heard when carrying out the check sequence?*

YES : Go to step 10AE17.

NO : Replace hydraulic unit.

10AE17 CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connector between hydraulic unit, relay box and ABSCM? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10AE18.

10AE18 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10AE19.

10AE19 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 52 (FB1)
MOTOR

B4M0971

**AF: TROUBLE CODE 52 MOTOR
— ABNORMAL MOTOR —**


DIAGNOSIS:


- Faulty motor
- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:




10AF1 **CHECK CONTACT POINT OF MOTOR RELAY.**


- 1) Turn ignition switch to OFF.
- 2) Remove motor relay from relay box.
- 3) Connect battery to motor relay terminals No. 85 and No. 86.
- 4) Measure resistance between motor relay terminals.

Terminals
No. 30 — No. 87:

CHECK : *Is the resistance less than 0.5 Ω?*

YES : Go to step **10AF2**.

NO : Replace motor relay.


10AF2 **CHECK CONTACT POINT OF MOTOR RELAY.**


- 1) Disconnect battery from motor relay terminals.
- 2) Measure resistance between motor relay terminals.

Terminals
No. 30 — No. 87:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step **10AF3**.

NO : Replace motor relay.


10AF3 **CHECK INPUT VOLTAGE OF RELAY BOX.**


- 1) Disconnect connector (F8) from relay box.
- 2) Measure voltage between relay box connector and chassis ground.

Connector & terminal
(F8) No. 2 (+) — Chassis ground (-):

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step **10AF4**.

NO : Repair harness/connector between battery and relay box, and check fuse SBF6.



10AF4 CHECK MOTOR GROUND.


Tightening torque:

$32\pm10 \text{ N}\cdot\text{m}$ ($3.3\pm1.0 \text{ kg}\cdot\text{m}$, $24\pm7 \text{ ft-lb}$)

CHECK : Is the motor ground terminal tightly clamped?

YES : Go to step 10AF5.

NO : Tighten the clamp of motor ground terminal.





10AF5 CHECK MOTOR OPERATION.

- 1) Disconnect connector from ABS control module.
- 2) Remove band.
- 3) Remove cable clamp cover.
- 4) Remove screws securing connector cover.

CAUTION:

Do not allow harness to catch on adjacent parts during installation.


- 5) Remove connector cover.



NOTE:

- To install, reverse above removal procedures.
- Align connector cover rib with connector hole before installation.

- 6) Connect connector to ABSCM.
- 7) Connect motor relay to relay box.
- 8) Connect all connectors.



- 9) Measure voltage between ABSCM connector terminal.
- 10) Operate the check sequence. <Ref. to 4-4 [W12D0].>

Connector & terminals

(F49) No. 10 (+) — No. 1 (-):

CHECK : Does the voltage raise from less than 1.5 V to between 10 V and 13 V, and return to less than 1.5 V again when carrying out the check sequence?

YES : Go to step 10AF6.

NO : Replace hydraulic unit.

10AF6 CHECK MOTOR OPERATION.

Operate the check sequence. <Ref. to 4-4 [W12D0].>

CHECK : Can motor revolution noise (buzz) be heard when carrying out the check sequence?

YES : Go to step 10AF7.

NO : Replace hydraulic unit.

10AF7 CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : Is there poor contact in connector between hydraulic unit, relay box and ABSCM? <Ref. to FOREWORD [T3C1].>

YES : Repair connector.

NO : Go to step 10AF8.

10AF8 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : Is the same trouble code as in the current diagnosis still being output?

YES : Replace ABSCM.

NO : Go to step 10AF9.

10AF9 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : Are other trouble codes being output?

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 54 (FB1)
BLS

B4M0972

AG: TROUBLE CODE 54 BLS — ABNORMAL STOP LIGHT SWITCH —



DIAGNOSIS:

- Faulty stop light switch

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



H4M1114

BRAKES

BLS (F09)
0.00 V

B4M0973

10AG1 **CHECK OUTPUT OF STOP LIGHT SWITCH USING SELECT MONITOR.**

- 1) Press [F], [0] and [9] on the select monitor.
- 2) Depress the brake pedal.
- 3) Read the stop light switch output on the select monitor display.

CHECK : *Is the reading indicated on monitor display less than 1.5 V?*

YES : Go to step **10AG2**.

NO : Go to step **10AG3**.

BLS (F09)
5.00 V

H4M1118

10AG2 **CHECK OUTPUT OF STOP LIGHT SWITCH USING SELECT MONITOR.**

- 1) Release the brake pedal.
- 2) Read the stop light switch output on the select monitor display.

CHECK : *Is the reading indicated on monitor display greater than 4.5 V?*

YES : Go to step **10AG5**.

NO : Go to step **10AG3**.


10AG3 **CHECK IF STOP LIGHTS COME ON.**

Depress the brake pedal.

CHECK : *Do stop lights turn on?*

YES : Go to step **10AG4**.

NO : Repair stop lights circuit.



10AG4 CHECK OPEN CIRCUIT IN HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Depress brake pedal.
- 4) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 36 — Chassis ground:

CHECK : *Is the voltage between 10 V and 13 V?*

YES : Go to step 10AG5.

NO : Repair harness between stop light switch and ABSCM connector.

10AG5 CHECK POOR CONTACT IN CONNECTORS.

CHECK : *Is there poor contact in connector between stop light switch and ABSCM? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10AG6.

10AG6 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10AG7.

10AG7 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (FB1)
G SENSOR LINE

B4M0974

AH: TROUBLE CODE 56 G SENSOR LINE — OPEN OR SHORT CIRCUIT OF G SENSOR



DIAGNOSIS:

- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

H4M1111

1997 (F00)
ABS 4WD•AT

H4M1117

G-SENS (F10)
2.30 V

B4M0927

10AH1 **CHECK SPECIFICATIONS OF ABSCM USING SELECT MONITOR.**

- 1) Press [F], [0] and [0] on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is an ABSCM for 4WD model installed on a FWD model?*

YES : Replace ABSCM.

NO : Go to step **10AH2**.

10AH2 **CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.**

- 1) Press [F], [1] and [0] on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is the indicated reading between 2.1 and 2.5 V when the G sensor is in horizontal position?*

YES : Go to step **10AH3**.

NO : Go to step **10AH6**.

10AH3 **CHECK POOR CONTACT IN CONNECTORS.**

CHECK : *Is there poor contact in connector between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **10AH4**.

10AH4 **CHECK ABSCM.**

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10AH5**.

10AH5 **CHECK ANY OTHER TROUBLE CODES APPEARANCE.**

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

BRAKES

FR (FE5)
0 km/h

B4M0977

FL (FE6)
0 km/h

B4M0978

RR (FE7)
0 km/h

B4M0979

RL (FE8)
0 km/h

B4M0980

G-SENS (FE14)
3.70 V

B4M0981

10AH6 CHECK FREEZE FRAME DATA.

- 1) Press [F], [E] and [5] on the select monitor.
- 2) Read the select monitor display.



: Is the reading indicated on monitor display 0 km?



: Go to step 10AH7.



: Go to step 10AH15.

10AH7 CHECK FREEZE FRAME DATA.

- 1) Press the scroll key so that FE6 appears on the monitor display.
- 2) Read the select monitor display.



: Is the reading indicated on monitor display 0 km?



: Go to step 10AH8.



: Go to step 10AH15.

10AH8 CHECK FREEZE FRAME DATA.

- 1) Press the scroll key so that FE7 appears on the monitor display.
- 2) Read the select monitor display.



: Is the reading indicated on monitor display 0 km?



: Go to step 10AH9.



: Go to step 10AH15.

10AH9 CHECK FREEZE FRAME DATA.

- 1) Press the scroll key so that FE8 appears on the monitor display.
- 2) Read the select monitor display.



: Is the reading indicated on monitor display 0 km?



: Go to step 10AH10.



: Go to step 10AH15.

10AH10 CHECK FREEZE FRAME DATA.

- 1) Press the scroll key so that FE14 appears on the monitor display.
- 2) Read the select monitor display.




: Is the reading indicated on monitor display more than 3.65 V?



: Go to step 10AH11.



: Go to step 10AH15.



10AH11 **CHECK OPEN CIRCUIT IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.

Connector & terminal

(F49) No. 7 — No. 45:

CHECK : *Is the resistance between 4.3 and 4.9 kΩ?*

YES : Go to step **10AH12**.

NO : Repair harness/connector between G sensor and ABSCM.

10AH12 **CHECK POOR CONTACT IN CONNECTORS.**

CHECK : *Is there poor contact in connector between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **10AH13**.

10AH13 **CHECK ABSCM.**

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.


NO : Go to step **10AH14**.

10AH14 **CHECK ANY OTHER TROUBLE CODES APPEARANCE.**

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.


10AH15 | CHECK INPUT VOLTAGE OF G SENSOR.

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Disconnect G sensor from body. (Do not disconnect connector.)
- 4) Turn ignition switch to ON.
- 5) Measure voltage between G sensor connector terminals.


Connector & terminal

(R70) No. 1 (+) — No. 3 (-):

CHECK : Is the voltage between 4.75 and 5.25 V?

YES : Go to step 10AH16.

NO : Repair harness/connector between G sensor and ABSCM.


10AH16 | CHECK OPEN CIRCUIT IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.


Connector & terminal

(F49) No. 7 — No. 45:

CHECK : Is the resistance between 4.3 and 4.9 kΩ?

YES : Go to step 10AH17.

NO : Repair harness/connector between G sensor and ABSCM.


10AH17 | CHECK G SENSOR OUTPUT HARNESS.

- 1) Disconnect connector from G sensor.
- 2) Measure resistance between ABSCM connector and chassis ground.


Connector & terminal

(F49) No. 7 — Chassis ground:

CHECK : *Is the resistance more than 1 MΩ?*

YES : Go to step 10AH18.

NO : Repair harness between G sensor and ABSCM.


10AH18 | CHECK G SENSOR.

- 1) Connect connector to G sensor.
- 2) Connect connector to ABSCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between G sensor connector terminals.


Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 2.1 and 2.5 V when G sensor is horizontal?*

YES : Go to step 10AH19.

NO : Replace G sensor.


10AH19 | CHECK G SENSOR.

Measure voltage between G sensor connector terminals.


Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 3.7 and 4.1 V when G sensor is inclined forwards to 90°?*

YES : Go to step 10AH20.

NO : Replace G sensor.



Front
H4M1148A

10AH20 CHECK G SENSOR.

Measure voltage between G sensor connector terminals.

Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 0.5 and 0.9 V when G sensor is inclined backwards to 90°?*

YES : Go to step 10AH21.

NO : Replace G sensor.

10AH21 CHECK POOR CONTACT IN CONNECTORS.

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connector between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step 10AH22.

10AH22 CHECK ABSCM.

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step 10AH23.

10AH23 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (FB1)
G SENSOR +B

B4M0982

**AI: TROUBLE CODE 56 G SENSOR +B
— BATTERY SHORT OF G SENSOR —**



DIAGNOSIS:

- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



F49

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
X	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X
X	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

H4M1111

G-SENS (F10)
2.30 V

B4M0927

10AI1 **CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.**

- 1) Press [F], [1] and [0] on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is the indicated reading between 2.1 and 2.5 V when the G sensor is in horizontal position?*

YES : Replace ABSCM.

NO : Go to step **10AI2**.

10AI2 **CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Disconnect connector from G sensor.
- 4) Disconnect connector from ABSCM.
- 5) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal


(F49) No. 7 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AI3**.


NO : Repair harness between G sensor and ABSCM.

F49



B4M0914A

F49



B4M0914A

10AI3 **CHECK BATTERY SHORT OF HARNESS.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ABSCM connector and chassis ground.

Connector & terminal

(F49) No. 7 (+) — Chassis ground (-):

CHECK : *Is the voltage less than 1 V?*

YES : Go to step **10AI4**.

NO : Repair harness between G sensor and ABSCM.

10AI4	CHECK ABSCM.
--------------	---------------------

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10AI5**.

10AI5	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
--------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (FB1)
G SENSOR H μ

B4M0984

**AJ: TROUBLE CODE 56 G SENSOR H μ
— ABNORMAL G SENSOR HIGH H μ OUTPUT**


DIAGNOSIS:

- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



G-SENS (F10)
2.30 V

B4M0927

10AJ1 **CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.**

- 1) Press [F], [1] and [0] on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is the indicated reading 2.3±0.2 V when the G sensor is in horizontal position?*

YES : Go to step 10AJ2.
NO : Go to step 10AJ6.

10AJ2 **CHECK POOR CONTACT IN CONNECTORS.**

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connector between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.
NO : Go to step 10AJ3.

10AJ3 **CHECK ABSCM.**

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.


CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.
NO : Go to step 10AJ4.

10AJ4 **CHECK ANY OTHER TROUBLE CODES APPEARANCE.**

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.
NO : A temporary poor contact.



10AJ5 **CHECK OPEN CIRCUIT IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.


Connector & terminal

(F49) No. 7 — No. 45:

CHECK : *Is the resistance between 4.3 and 4.9 kΩ?*

YES : Go to step **10AJ6**.

NO : Repair harness/connector between G sensor and ABSCM.



10AJ6 **CHECK G SENSOR.**

- 1) Remove console box.
- 2) Remove G sensor from vehicle.
- 3) Connect connector to G sensor.
- 4) Connect connector to ABSCM.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between G sensor connector terminals.


Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 2.1 and 2.5 V when G sensor is horizontal?*

YES : Go to step **10AJ7**.

NO : Replace G sensor.

Front
◀

H4M1147A

10AJ7 CHECK G SENSOR.


Measure voltage between G sensor connector terminals.

Connector & terminal**(R70) No. 2 (+) — No. 1 (-):**

CHECK : *Is the voltage between 3.7 and 4.1 V when G sensor is inclined forwards to 90°?*

YES : Go to step **10AJ8**.

NO : Replace G sensor.

Front
◀

H4M1148A

10AJ8 CHECK G SENSOR.

Measure voltage between G sensor connector terminals.

Connector & terminal**(R70) No. 2 (+) — No. 1 (-):**

CHECK : *Is the voltage between 0.5 and 0.9 V when G sensor is inclined backwards to 90°?*

YES : Go to step **10AJ9**.

NO : Replace G sensor.

10AJ9 CHECK ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10AJ10**.

10AJ10 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

D•NEW 56 (F B1)
G SENSOR STICK

B4M0813

**AK: TROUBLE CODE 56 G SENSOR STICK
— G SENSOR OUTPUT IS STUCK —**



DIAGNOSIS:

- Faulty G sensor output voltage

TROUBLE SYMPTOM:

- ABS does not operate.

WIRING DIAGRAM:



F49

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
X	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	X
X	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

H4M1111

10AK1	CHECK ALL FOUR WHEELS FOR FREE TURNING.
--------------	--


CHECK : *Have the wheels been turned freely such as when the vehicle is lifted up, or operated on a rolling road?*

YES : The ABS is normal. Erase the trouble code.

NO : Go to step **10AK2**.

G-SENS (F10)
2.30 V

B4M0927



H4M1147A

10AK2	CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.
--------------	---

- 1) Press [F], [1] and [0] on the select monitor.
- 2) Read the select monitor display.

CHECK : *Is the indicated reading between 2.1 and 2.5 V when the vehicle is in horizontal position?*

YES : Go to step **10AK3**.

NO : Go to step **10AK8**.


10AK3	CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.
--------------	---

- 1) Turn ignition switch to OFF.
- 2) Remove console box.
- 3) Remove G sensor from vehicle. (Do not disconnect connector.)
- 4) Turn ignition switch to ON.
- 5) Press [F], [1] and [0] on the select monitor.
- 6) Read the select monitor display.

CHECK : *Is the indicated reading between 3.7 and 4.1 V when G sensor is inclined forwards to 90°?*

YES : Go to step **10AK4**.

NO : Replace G sensor.



H4M1148A

10AK4	CHECK OUTPUT OF G SENSOR USING SELECT MONITOR.
--------------	---

Read the select monitor display.

CHECK : *Is the indicated reading between 0.5 and 0.9 V when G sensor is inclined backwards to 90°?*

YES : Go to step **10AK5**.

NO : Replace G sensor.

BRAKES

10AK5	CHECK POOR CONTACT IN CONNECTORS.
--------------	--

Turn ignition switch to OFF.

CHECK : *Is there poor contact in connector between ABSCM and G sensor? <Ref. to FOREWORD [T3C1].>*

YES : Repair connector.

NO : Go to step **10AK6**.

10AK6	CHECK ABSCM.
--------------	---------------------

- 1) Connect all connectors.
- 2) Erase the memory.
- 3) Perform inspection mode.
- 4) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.


NO : Go to step **10AK7**.

10AK7	CHECK ANY OTHER TROUBLE CODES APPEARANCE.
--------------	--

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.



10AK8	CHECK OPEN CIRCUIT IN G SENSOR OUTPUT HARNESS AND GROUND HARNESS.
--------------	--


- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ABSCM.
- 3) Measure resistance between ABSCM connector terminals.

**Connector & terminal
(F49) No. 7 — No. 45:**

CHECK : *Is the resistance between 4.3 and 4.9 kΩ?*

YES : Go to step **10AK9**.

NO : Repair harness/connector between G sensor and ABSCM.



H4M1146

10AK9 CHECK G SENSOR.

- 1) Remove console box.
- 2) Remove G sensor from vehicle.
- 3) Connect connector to G sensor.
- 4) Connect connector to ABSCM.
- 5) Turn ignition switch to ON.
- 6) Measure voltage between G sensor connector terminals.


Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 2.1 and 2.5 V when G sensor is horizontal?*

YES : Go to step 10AK10.

NO : Replace G sensor.



H4M1147A

10AK10 CHECK G SENSOR.

Measure voltage between G sensor connector terminals.


Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 3.7 and 4.1 V when G sensor is inclined forwards to 90°?*

YES : Go to step 10AK11.

NO : Replace G sensor.



H4M1148A

10AK11 CHECK G SENSOR.

Measure voltage between G sensor connector terminals.

Connector & terminal

(R70) No. 2 (+) — No. 1 (-):

CHECK : *Is the voltage between 0.5 and 0.9 V when G sensor is inclined backwards to 90°?*

YES : Go to step 10AK12.

NO : Replace G sensor.

10AK12 CHECK ABSCM.

- 1) Turn ignition switch to OFF.
- 2) Connect all connectors.
- 3) Erase the memory.
- 4) Perform inspection mode.
- 5) Read out the trouble code.

CHECK : *Is the same trouble code as in the current diagnosis still being output?*

YES : Replace ABSCM.

NO : Go to step **10AK13**.

10AK13 CHECK ANY OTHER TROUBLE CODES APPEARANCE.

CHECK : *Are other trouble codes being output?*

YES : Proceed with the diagnosis corresponding to the trouble code.

NO : A temporary poor contact.

11. General Diagnostics Table

A: SYMPTOMS AND PROBABLE CAUSES

Symptom		Probable faulty units/parts
Vehicle instability during braking	Vehicle pulls to either side.	<ul style="list-style-type: none"> • Hydraulic unit (solenoid valve) • ABS sensor • Brake (caliper & piston, pads) • Wheel alignment • Tire specifications, tire wear and air pressures • Incorrect wiring or piping connections • Road surface (uneven, camber)
	Vehicle spins.	<ul style="list-style-type: none"> • Hydraulic unit (solenoid valve) • ABS sensor • Brake (pads) • Tire specifications, tire wear and air pressures • Incorrect wiring or piping connections
Poor braking	Long braking/stopping distance	<ul style="list-style-type: none"> • Hydraulic unit (solenoid valve) • Brake (pads) • Air in brake line • Tire specifications, tire wear and air pressures • Incorrect wiring or piping connections
	Wheel locks.	<ul style="list-style-type: none"> • Hydraulic unit (solenoid valve, motor) • ABS sensor • Incorrect wiring or piping connections
	Brake dragging	<ul style="list-style-type: none"> • Hydraulic unit (solenoid valve) • ABS sensor • Master cylinder • Brake (caliper & piston) • Parking brake • Axle & wheels • Brake pedal play
	Long brake pedal stroke	<ul style="list-style-type: none"> • Air in brake line • Brake pedal play
	Vehicle pitching	<ul style="list-style-type: none"> • Suspension play or fatigue (reduced damping) • Incorrect wiring or piping connections • Road surface (uneven)
	Unstable or uneven braking	<ul style="list-style-type: none"> • Hydraulic unit (solenoid valve) • ABS sensor • Brake (caliper & piston, pads) • Tire specifications, tire wear and air pressures • Incorrect wiring or piping connections • Road surface (uneven)
Vibration and/or noise (while driving on slippery roads)	Excessive pedal vibration	<ul style="list-style-type: none"> • Incorrect wiring or piping connections • Road surface (uneven)
	Noise from hydraulic unit	<ul style="list-style-type: none"> • Hydraulic unit (mount bushing) • ABS sensor • Brake piping
	Noise from front of vehicle	<ul style="list-style-type: none"> • Hydraulic unit (mount bushing) • ABS sensor • Master cylinder • Brake (caliper & piston, pads, rotor) • Brake piping • Brake booster & check valve • Suspension play or fatigue
	Noise from rear of vehicle	<ul style="list-style-type: none"> • ABS sensor • Brake (caliper & piston, pads, rotor) • Parking brake • Brake piping • Suspension play or fatigue

B: CHECKING THE HYDRAULIC UNIT OPERATION**11B1 PREPARING THE BRAKE TESTER.**

 : *Is the brake tester available?*

 : CHECKING THE HYDRAULIC UNIT ABS OPERATION WITH BRAKE TESTER <Ref. to 4-4 [W12C2].>

 : CHECKING THE HYDRAULIC UNIT ABS OPERATION BY PRESSURE GAUGE <Ref. to 4-4 [W12C1].>