

CLUTCH 2-10


	Page
S SPECIFICATIONS AND SERVICE DATA	2
1. Specifications	2
C COMPONENT PARTS	3
1. Clutch System.....	3
W SERVICE PROCEDURE	4
1. General	4
2. On-Car Service	4
3. Release Bearing and Lever	5
4. Clutch Disc and Cover	7
K DIAGNOSTICS	11
1. Clutch Trouble in General	11

1. Specifications

			1800 cc	2200 cc
Clutch cover	Diaphragm set load	kg (lb)	450 (992)	
Clutch disc	Facing material		Woven	
	O.D. x I.D. x thickness	mm (in)	225 x 150 x 3.5 (8.86 x 5.91 x 0.138)	
	Spline O.D. (No. of teeth)	mm (in)	25.2 (0.992) (24)	
	Depth of rivet head	mm (in)	Standard	1.3 — 1.9 (0.051 — 0.075)
			Limit of sinking	0.3 (0.012)
	Limit for runout	mm (in)	1.0 (0.039) at R = 107 (4.21)	
Clutch release lever ratio			3.0	
Release lever	Stroke	mm (in)	24 — 26 (0.94 — 1.02)	
	Play at release lever center	mm (in)	3 — 4 (0.12 — 0.16)	
Release bearing			Grease-packed self-aligning	
Clutch pedal	Full stroke	mm (in)	140 — 145 (5.51 — 5.71)	

O.D.; Outer Diameter I.D.; Inner Diameter

1. Clutch System



H2M1562A

- ① Clutch cable bracket
- ② Clutch release lever sealing
- ③ Pivot
- ④ Retainer spring
- ⑤ Clutch release lever
- ⑥ Clip
- ⑦ Clutch release bearing
- ⑧ Clutch cover
- ⑨ Clutch disc

- ⑩ Flywheel
- ⑪ Return spring
- ⑫ Clutch return spring bracket

Tightening torque: N·m (kg·m, ft·lb)
T: 15.7±1.5 (1.6±0.15, 11.6±1.1)


1. General

A: PRECAUTION

1. MECHANICAL APPLICATION TYPE

When servicing clutch system, pay attention to the following items.

- 1) Check the routing of clutch cable for smoothness.
- 2) Excessive tightness or looseness of clutch cable have a bad influence upon the cable durability.
- 3) Apply grease sufficiently to the connecting portion of clutch pedal.
- 4) Apply grease sufficiently to the release lever portion.
- 5) Position clutch cable through the center of toe board hole and route it smoothly. Adjustment is done by moving the outer cable.
- 6) Make sure not to let the clutch chatter when starting forward or rearward. If clutch chattering occurs, readjust so that the bend of clutch outer cable becomes flatter.



2. On-Car Service

A: ADJUSTMENT

1. MECHANICAL APPLICATION TYPE


- 1) Remove release lever return spring from lever.
- 2) Adjust spherical nut so that the play is within the specified value at the lever end (center of spherical nut).

CAUTION:

Take care not to twist the cable during adjustment

Play: 3 — 4 mm (0.12 — 0.16 in)

Full stroke: 24 — 26 mm (0.94 — 1.02 in)




- 3) Upon completion of adjustment, securely lock spherical nut with lock nut.


Install return spring on lever.

NOTE:

Hook the long hook side of the return spring with the lever.



- 4) Depress clutch pedal to assure there is no abnormality in the clutch system.



3. Release Bearing and Lever

A: REMOVAL


1. MECHANICAL APPLICATION TYPE

- 1) Remove release lever return spring ①.
- 2) Remove the two clips ② from clutch release lever ③ and remove release bearing ⑥.


CAUTION:

Be careful not to deform clips.

- 3) Remove release lever seal ④.



- 4) Remove release lever retainer spring from release lever pivot with a screwdriver by accessing it through clutch housing release lever hole. Then remove release lever.



B: INSPECTION

1. RELEASE BEARING

CAUTION:


Since this bearing is grease sealed and is of a nonlubrication type, do not wash with gasoline or any solvent when servicing the clutch.

- 1) Check the bearing for smooth movement by applying force in the radial direction.


Radial direction stroke:

Approx.

1.4 mm (0.055 in)



- 2) Check the bearing for smooth rotation by applying pressure in the thrust direction.
- 3) Check wear and damage of bearing case surface contacting with lever.



2. RELEASE LEVER

Check lever pivot portion and the point of contact with release bearing case for wear.


C: INSTALLATION

1. MECHANICAL APPLICATION TYPE

CAUTION:

Before or during assembling, lubricate the following points with a light coat of grease.

- Inner groove of release bearing
- Contact surface of lever and pivot
- Contact surface of lever and bearing
- Transmission main shaft spline (Use grease containing molybdenum disulphide.)




- 1) While pushing release lever (3) to pivot and twisting it to both sides, fit retainer spring (5) onto the constricted portion of pivot.

NOTE:

Confirm that retainer spring is securely fitted by observing it through the main case hole.

- 2) Install release bearing (6) and fasten it with two clips (2).
- 3) Install release lever seal (4).



- 4) After remounting engine and transmission on body, make adjustment of the clutch release lever end play.


CAUTION:

Take care not to twist the cable during adjustment.

- 5) Install release lever return spring.

NOTE:

Hook up the return spring to right side hole of the release lever.



4. Clutch Disc and Cover

A: REMOVAL

- 1) Install ST on flywheel.


ST 498497100 CRANKSHAFT STOPPER


- 2) Remove clutch cover and clutch disc.

CAUTION:

- Take care not to allow oil on the clutch disc facing.
- Do not disassemble either clutch cover or clutch disc.

- 3) Remove flywheel.





B: INSPECTION

1. CLUTCH DISC

1) Facing wear

Measure the depth of rivet head from the surface of facing. Replace if facings are worn locally or worn down to less than the specified value.

Depth of rivet head:

Standard value


1.3 — 1.9 mm (0.051 — 0.075 in)

Limit of sinking

0.3 mm (0.012 in)

CAUTION:

Do not wash clutch disc with any cleaning fluid.




2) Hardened facing

Correct by using emery paper or replace.

3) Oil soakage on facing

Replace clutch disc and inspect transmission front oil seal, transmission case mating surface, engine rear oil seal and other points for oil leakage.




4) Deflection on facing

If deflection exceeds the specified value at the outer circumference of facing, repair or replace.


Limit for deflection:

1.0 mm (0.039 in) at R = 107 mm (4.21 in)



5) Worn spline, loose rivets and torsion spring failure


Replace defective parts.



2. CLUTCH COVER


Visually check for the following items without disassembling, and replace or repair if defective.

- 1) Loose thrust rivet.
- 2) Damaged or worn bearing contact area at center of diaphragm spring.



- 3) Damaged or worn disc contact surface of pressure plate.

- 4) Loose strap plate setting bolt.
- 5) Worn diaphragm sliding surface.



3. FLYWHEEL

CAUTION:

Since this bearing is grease sealed and is of a nonlubrication type, do not wash with gasoline or any solvent.

- 1) Damage of facing and ring gear
If defective, replace flywheel.


- 2) Smoothness of rotation


Rotate ball bearing applying pressure in thrust direction.

If noise or excessive play is noted, replace ball bearing as follows:

- (1) Drive out ball bearing from flywheel.
- (2) Press bearing into flywheel until bearing end surface is flush with clutch disc contact surface of flywheel.
Do not press inner race.

ST 899754112 SNAP RING PRESS





C: INSTALLATION

- 1) Install flywheel.
- 2) Install ST, and tighten the flywheel attaching bolts to the specified torque.



ST 498497100 CRANKSHAFT STOPPER

Tightening torque:

$72 \pm 3 \text{ N}\cdot\text{m} (7.3 \pm 0.3 \text{ kg}\cdot\text{m}, 52.8 \pm 2.2 \text{ ft-lb})$


NOTE:

Tighten flywheel installing bolts gradually. Each bolt should be tightened to the specified torque in a crisscross fashion.



- 3) Insert ST into the clutch disc and install them on the flywheel by inserting the ST end into the pilot bearing.

ST 499747100 CLUTCH DISC GUIDE



- 4) Install clutch cover on flywheel and tighten bolts to the specified torque.

NOTE:

- When installing the clutch cover on the flywheel, position the clutch cover so that there is a gap of 120° or more between "0" marks on the flywheel and clutch cover. ("0" marks indicate the directions of residual unbalance.)
- Note the front and rear of the clutch disc when installing.
- Tighten clutch cover installing bolts gradually. Each bolt should be tightened to the specified torque in a crisscross fashion.

Tightening torque:

$15.7 \pm 1.5 \text{ N}\cdot\text{m} (1.6 \pm 0.15 \text{ kg}\cdot\text{m}, 11.6 \pm 1.1 \text{ ft-lb})$

- 5) Remove ST.

ST 499747100 CLUTCH DISC GUIDE

1. Clutch Trouble in General

Condition	Possible cause and testing	Corrective action
1. Clutch slip-page	<p>It is hard to perceive clutch slippage in the early stage, but pay attention to the following symptoms.</p> <p>(a) Engine revs up when shifting. (b) High speed driving is impossible; especially rapid acceleration impossible and vehicle speed does not increase in proportion to an increase in engine speed. (c) Power falls, particularly when ascending a slope, and there is a smell of burning of the clutch facing.</p> <p>● Method of testing: Put the vehicle in stationary condition with parking brake fully applied. Disengage the clutch and shift the transmission gear into the first. Gradually allow the clutch to engage while gradually increasing the engine speed. The clutch function is satisfactory if the engine stalls. However, the clutch is slipping if the vehicle does not start off and the engine does not stall.</p>	
	<p>(a) No clutch pedal play (b) No release lever end play (c) Clutch facing smeared by oil (d) Worn clutch facing (e) Deteriorated diaphragm spring (f) Distorted pressure plate or flywheel (g) Defective release bearing holder (h) Defective pedal and cable system</p>	<p>Readjust. Readjust. Replace. Replace. Replace. Correct or replace. Correct or replace. Correct or replace.</p>
2. Clutch drags.	<p>As a symptom of this trouble, a harsh scratching noise develops and control becomes quite difficult when shifting gears. The symptom becomes more apparent when shifting into the first gear. However, because much trouble of this sort is due to defective synchronization mechanism, carry out the test as described after.</p> <p>● Method of testing: Refer to DIAGNOSTIC DIAGRAM on page after.</p> <p>It may be judged as insufficient disengagement of clutch if any noise occurs during this test.</p>	
	<p>(a) Excessive clutch pedal play (b) Excessive clutch release lever play (c) Worn or rusty clutch disc hub spline (d) Excessive deflection of clutch disc facing (e) Seized crankshaft pilot needle bearing (f) Malfunction of pedal and cable system (g) Cracked clutch disc facing (h) Sticked clutch disc (smeared by oil or water)</p>	<p>Readjust. Readjust. Replace clutch disc. Correct or replace. Replace. Correct or replace. Replace. Replace.</p>
3. Clutch chatters.	<p>Clutch chattering is an unpleasant vibration to the whole body when the vehicle is just started with clutch partially engaged.</p>	
	<p>(a) Improper clutch cable routing (b) Adhesion of oil on the facing (c) Weak or broken torsion spring (d) Defective facing contact or excessive disc (e) Warped pressure plate or flywheel (f) Loose disc rivets (g) Loose engine mounting (h) Improper adjustment of pitching stopper</p>	<p>Correct. Replace clutch disc. Replace clutch disc. Replace clutch disc deflection. Correct or replace. Replace clutch disc. Retighten or replace mounting. Adjustment.</p>

Condition	Possible cause and testing	Corrective action
4. Noisy clutch	<p>Examine whether the noise is generated when the clutch is disengaged, engaged, or partially engaged.</p> <p>(a) Broken, worn or unlubricated release bearing (b) Insufficient lubrication of pilot bearing (c) Loose clutch disc hub (d) Loose torsion spring retainer (e) Deteriorated or broken torsion spring</p>	<p>Replace release bearing. Apply grease. Replace clutch disc. Replace clutch disc. Replace clutch disc.</p>
5. Clutch grabs.	<p>When starting the vehicle with the clutch partially engaged, the clutch engages suddenly and the vehicle jumps instead of making a smooth start.</p> <p>(a) Grease or oil on facing (b) Deteriorated cushioning spring (c) Worn or rusted spline of clutch disc or main (d) Deteriorated or broken torsion spring (e) Loose engine mounting (f) Deteriorated diaphragm spring</p>	<p>Replace clutch disc. Replace clutch disc. Take off rust, apply grease or replace clutch shaft disc or mainshaft. Replace clutch disc. Retighten or replace mounting. Replace.</p>

A: DIAGNOSTIC DIAGRAM OF CLUTCH DRAG

Test (1)

Disengage the clutch and shift quickly from neutral to reverse in idling condition.

Gear noise

Yes

Sufficient disengagement of clutch

Test (2)

Shift to reverse after 0.5 to 1.0 sec of clutch disengagement.

Gear noise

Yes

Defective transmission or excessive clutch drag torque

[Cause]

1. Defective pilot bearing
2. Excessive disc deflection
3. Defective transmission
4. Defective clutch disc hub spline

Test (3)

Shift the gear N → R several times during disengaging clutch as test (2).

Gear noise

Yes

Sticked clutch disc

[Cause]

1. Clutch disc smeared by oil
2. Clutch disc smeared by rust
3. Defective clutch disc hub spline

Clutch drags.

[Cause]

1. Cracked clutch disc facing
2. Damaged or worn clutch cover
3. Malfunction of clutch release system
4. Insufficient clutch release amount
5. Excessive clutch pedal play