


5. Front Strut S202115

A: REMOVAL S202115A18


- 1) Remove wheel.
- 2) Depress brake pedal and hold it down using a wooden block etc.
- 3) Remove union bolts from caliper.

CAUTION:

Use brake hose cap to prevent brake fluid from escaping.



- 4) Remove brake hose clamp and disconnect brake hose from strut. Attach brake hose to body using gum tape.




- 5) Scribe an alignment mark on the camber adjusting bolt which secures strut to housing.
- 6) Remove bolt securing the ABS sensor harness on models equipped with ABS.

- 7) Remove two bolts securing housing to strut.

CAUTION:

While holding head of adjusting bolt, loosen self-locking nut.

- 8) Remove the three nuts securing strut mount to body.



FRONT STRUT

Front Suspension

B: INSTALLATION

S202115A11

- 1) Install upper strut mount at upper side of strut to body and tighten with nuts.

Tightening torque:

20 N·m (2.0 kgf-m, 14.5 ft-lb)

- 2) Install ABS sensor harness to strut. (ABS equipped models)

Tightening torque:

32 N·m (3.3 kgf-m, 24 ft-lb)

- 3) Position aligning mark on camber adjustment bolt with aligning mark on lower side of strut.

CAUTION:

- While holding head of adjusting bolt, tighten self-locking nut.
- Be sure to use new self-locking nut.

Tightening torque:

152 N·m (15.5 kgf-m, 112 ft-lb)

- 4) Install brake hose at lower side of strut with clamp.
- 5) Install brake hose to brake caliper.

Tightening torque:

18 N·m (1.8 kgf-m, 13.0 ft-lb)

CAUTION:

Be sure to bleed air from brake system.

- 6) Install wheels.


NOTE:

Check wheel alignment and adjust if necessary.


C: DISASSEMBLY

S202115A06

- 1) Using a coil spring compressor, compress coil spring.



- 2) Using ST, remove self-locking nut.
ST 927760000 STRUT MOUNT SOCKET



- 3) Remove strut mount, upper spring seat and rubber seat from strut.
- 4) Gradually decreasing compression force, and remove coil spring.
- 5) Remove dust cover and helper spring.

D: ASSEMBLY S202115A02

1) Before installing coil spring, strut mount, etc., on the strut, check for the presence of air in the dampening force generating mechanism of the strut since air prevents proper dampening force from being produced.

2) Checking for the presence of air

(1) Place the strut vertically with the piston rod facing up.

(2) Move the piston rod to the center of its entire stroke.

(3) While holding the piston rod end with fingertips, move the rod up and down.

(4) If the piston rod moves at least 10 mm (0.39 in) in step (3), purge air from the strut.

3) Air purging procedure

(1) Place the strut vertically with the piston rod facing up.

(2) Fully extend the piston rod.

(3) With the piston rod fully extended, place the piston rod side down. The strut must stand vertically.

(4) Fully contract the piston rod.

(5) Repeat the former four steps, 3 or 4 times.


NOTE:

After completely purging air from the strut, be sure to place the strut with the piston rod facing up. If it is laid down, check for entry of air in the strut as outlined under "Cheking for the presence of air".

4) Using a coil spring compressor, compress the coil spring.

NOTE:


Make sure that the vertical installing direction of coil spring is as shown in figure.



G4M0509

5) Set the coil spring correctly so that its end face fits well into the spring seat as shown.

6) Install helper and dust cover to the piston rod.




G4M0510

7) Pull the piston rod fully upward, and install rubber seat and spring seat.

NOTE:

Ensure that upper spring seat is positioned with "OUT" mark facing outward.



G4M0511

8) Install strut mount to the piston rod, and tighten the self-locking nut temporarily.

CAUTION:


Be sure to use a new self-locking nut.

9) Using hexagon wrench to prevent strut rod from turning, tighten self-locking nut with ST.

Tightening torque:

54 N·m (5.5 kgf·m, 39.8 ft-lb)

ST 927760000 STRUT MOUNT SOCKET



G4M0507

10) Loosen the coil spring carefully.

E: INSPECTION

S202115A10

Check the disassembled parts for cracks, damage and wear, and replace with new parts if defective.


1. DAMPER STRUT

S202115A1001

- 1) Check for oil leakage.
- 2) Move the piston rod up and down to check its operates smoothly without any binding.
- 3) Play of piston rod

● Measure the play as follows:

Fix outer shell and fully extend the rod. Set a dial gauge at the end of the rod: L [10 mm (0.39 in)], then apply a force of: W [± 20 N (± 2 kgf, ± 4 lb)] to threaded portion. With the force of ± 20 N (± 2 kgf, ± 4 lb) applied, read both dial gauge readings, P_1 and P_2 .



The free play is determined by the following equation:

Limit of play:

Less than 0.8 mm (0.031 in)

If the play is greater, replace the strut.

2. STRUT MOUNT

S202115A1002

Check rubber part for creep, cracks and deterioration, and replace it with new one if defective.

3. DUST COVER

S202115A1003

If any cracks or damage are found, replace it with a new one.

4. COIL SPRING

S202115A1004

One having permanent strain should be replaced with a new one. When vehicle posture is uneven, although there are no considerable reasons like tire puncture, uneven loading, etc., check coil spring for its free length, cracks, etc., referring to specifications, and replace it with a new one if defective.

5. HELPER

S202115A1005

Replace it with new one if cracked or damaged.

F: DISPOSAL

S202115A07

CAUTION:

- On struts which have “GAS FILLED” marked on outer housing under spring seat, completely discharge gas before disposing, following the methods below.
- Do not disassemble strut damper or place into a fire.
- Drill holes before disposing of gas filled struts.
- Before handling gas filled struts, be sure to wear goggles to protect eyes from gas, oil and/or filings.

**GAS FILLED
DO NOT OPEN
DO NOT HEAT**

B4M1201

- 1) Place gas filled strut on a flat and level surface with piston rod fully extended.
- 2) Using a 2 to 3 mm (0.08 to 0.12 in) dia. drill, make holes in areas shown in the figure.

