


7. Subaru Select Monitor S004503

A: OPERATION S004503A16

1. READ DIAGNOSTIC TROUBLE CODE


S004503A1601

- 1) Prepare Subaru Select Monitor kit.




- 2) Connect diagnosis cable to Subaru Select Monitor.

- 3) Insert cartridge into Subaru Select Monitor.



- 4) Connect Subaru Select Monitor to data link connector.

- (1) Data link connector located in the lower portion of the instrument panel (on the driver's side).




- (2) Connect diagnosis cable to data link connector.

CAUTION:

Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.

- 5) Turn ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

- 6) On the 'Main Menu' display screen, select the {Each System Check} and press the [YES] key.

- 7) On the 'System Selection Menu' display screen, select the {Engine Control System} and press the [YES] key.

- 8) Press the [YES] key after displayed the information of engine type.

- 9) On the 'Transmission Diagnosis' display screen, select the {Diagnostic Code(s) Display} and press the [YES] key.

- 10) On the 'Diagnostic Code(s) Display' display screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)} and press the [YES] key.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

- For detailed concerning diagnostic trouble codes, refer to the "List of Diagnostic Trouble Code". <Ref. to AT-23 LIST, List of Diagnostic Trouble Code.>

2. READ CURRENT DATA S004503A1602

- 1) On the 'Main Menu' display screen, select the {Each System Check} and press the [YES] key.

- 2) On the 'System Selection Menu' display screen, select the {Transmission Control System} and press the [YES] key.

- 3) Press the [YES] key after displayed the information of transmission type.

- 4) On the 'Transmission Diagnosis' display screen, select the {Current Data Display & Save} and press the [YES] key.

- 5) On the 'Data Display Menu' display screen, select the {Data Display} and press the [YES] key.

- 6) Using the scroll key, move the display screen up or down until the desired data is shown.

- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Vehicle speed sensor 1 signal	Vehicle Speed #1	km/h or MPH
Vehicle speed sensor 2 signal	Vehicle Speed #2	km/h or MPH
Engine speed signal	Engine Speed	rpm
Automatic transmission fluid temperature signal	ATF Temp.	°C or °F
Throttle position signal	Throttle Sensor Voltage	V
Gear position	Gear Position	—
Line pressure control duty ratio	Line Pressure Duty Ratio	%
Lock up clutch control duty ratio	Lock Up Duty Ratio	%
Transfer clutch control duty ratio	Transfer Duty Ratio	%
Power supply for throttle position sensor	Throttle Sensor Power	V
Torque converter turbine speed signal	AT Turbine Speed	rpm
2-4 brake timing pressure control duty ratio	2-4B Duty Ratio	%
Intake manifold pressure sensor voltage	Mani. Pressure Voltage	V
2 wheel drive switch signal	2WD Switch	ON or OFF
Kick down switch signal	Kick Down Switch	ON or OFF
Stop lamp switch signal	Stop Lamp Switch	ON or OFF
Anti lock brake system signal	ABS Signal	ON or OFF
Cruise control system signal	Cruise Control Signal	ON or OFF
Neutral/Parking range signal	N/P Range Signal	ON or OFF
Reverse range signal	R Range Signal	ON or OFF
Drive range signal	D Range Signal	ON or OFF
3rd range signal	3rd Range Signal	ON or OFF
2nd range signal	2nd Range Signal	ON or OFF
1st range signal	1st Range Signal	ON or OFF
Shift control solenoid A	Shift Solenoid #1	ON or OFF
Shift control solenoid B	Shift Solenoid #2	ON or OFF
Torque control output signal #1	Torque Control Signal #1	ON or OFF
Torque control output signal #2	Torque Control Signal #2	ON or OFF
Torque control cut signal	Torque Control Cut Sig.	ON or OFF
2-4 brake timing control solenoid valve	2-4 Brake Timing Sol.	ON or OFF
Low clutch timing control solenoid valve	Low Clutch Timing Sol.	ON or OFF
Automatic transmission diagnosis indicator lamp	AT Diagnosis Lamp	ON or OFF

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

3. CLEAR MEMORY MODE S004503A1603

- 1) On the 「Main Menu」 display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the 「System Selection Menu」 display screen, select the {Transmission Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the 「Transmission Diagnosis」 display screen, select the {Clear Memory} and press the [YES] key.
- 5) When the 'Done' and 'Turn Ignition Switch OFF' are shown on the display screen, turn the Subaru Select Monitor and ignition switch to OFF.

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.