


3. Front Disc Rotor

A: REMOVAL

- 1) Set the vehicle on the lift.
- 2) Loosen the wheel nuts.
- 3) Jack-up the vehicle, and remove the front wheel.
- 4) Remove the caliper body from housing, and suspend it from strut using a wire.




BR-00017

- 5) Remove the disc rotor.

NOTE:

If the disc rotor seizes up within the hub, drive the disc rotor out by installing an 8-mm bolt in holes B on the rotor.



BR-00018

- 6) Clean mud and foreign particles from the caliper body assembly and support.

B: INSTALLATION

- 1) Install the disc rotor.
- 2) Install the caliper body on housing.

Tightening torque:

80 N·m (8.2 kgf·m, 59 ft-lb)


- 3) Install the wheel.

C: INSPECTION

- 1) Secure the disc rotor by tightening the five wheel nuts.
- 2) Set a dial gauge on the disc rotor. Turn the disc rotor to check runout.

CAUTION:

Securely fix the disc rotor to hub.



BR-00019

NOTE:

- Make sure the dial gauge is set 10 mm (0.39 in) inward of rotor outer perimeter.
- If the runout of disc rotor exceeds the limit, check for abnormal free play at hub bearing and runout in the thrust direction. <Ref. to DS-22, INSPECTION, Front Axle.>


If the hub bearing is okay, resurface the disc rotor. After resurfacing, check disc rotor thickness as in step 3.

Disc rotor runout limit:

0.075 mm (0.0030 in)

- 3) Measure the disc rotor thickness.

If the thickness of disc rotor is below service limit, replace the disc rotor.



BR-00018

NOTE:

Make sure the micrometer is set 10 mm (0.39 in) inward of rotor outer perimeter.

		Standard value	Service limit	Disc outer diameter
Disc rotor thickness A	15"	24.0 mm (0.945 in)	22.0 mm (0.866 in)	277 mm (10.91 in)
	16"	24.0 mm (0.945 in)	22.0 mm (0.866 in)	294 mm (11.57 in)